

ROW CROP PLANTERS

PST2 - 08/09/10/12 LINES

Code: 0501090580
Series: S-0195
Revision: 00
Date Revision: FEVEREIRO/2022

PARTS CATALOGUE



MARCHESAN



PRODUCTS

Code	Description	
0111021661	PST2 8/4 D44	S-0195
0111021662	PST2 8/5 D44	S-0195
0111021663	PST2 8/6 D44	S-0195
0111021948	PST2 8/6 D54	S-0195
0111021664	PST2 8/7 D44	S-0195
0111021718	PST2 8/7 D54	S-0195
0111021665	PST2 8/8 D44	S-0195
0111021719	PST2 8/8 D54	S-0195
0111021666	PST2 9/4 D44	S-0195
0111021667	PST2 9/5 D44	S-0195
0111021668	PST2 9/6 D44	S-0195
0111021669	PST2 9/7 D44	S-0195
0111021945	PST2 9/7 D54	S-0195
0111021670	PST2 9/8 D44	S-0195
0111021720	PST2 9/8 D54	S-0195
0111021671	PST2 9/9 D44	S-0195
0111021721	PST2 9/9 D54	S-0195
0111022146	PST2 10/ 5 D54 S/LINHAS	S-0195
0111021677	PST2 10/10 D44	S-0195
0111021723	PST2 10/10 D54	S-0195
0111021928	PST2 10/4 D44	S-0195
0111021672	PST2 10/5 D44	S-0195
0111021673	PST2 10/6 D44	S-0195
0111021674	PST2 10/7 D44	S-0195
0111021949	PST2 10/7 D54	S-0195
0111021675	PST2 10/8 D44	S-0195
0111021917	PST2 10/8 D54	S-0195
0111021676	PST2 10/9 D44	S-0195
0111021722	PST2 10/9 D54	S-0195
0111021682	PST2 12/10 D44	S-0195

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



PRODUCTS

0111021724	PST2 12/10 D54	S-0195
0111021683	PST2 12/11 D44	S-0195
0111021725	PST2 12/11 D54	S-0195
0111021708	PST2 12/12 D44	S-0195
0111021726	PST2 12/12 D54	S-0195
0111021678	PST2 12/6 D44	S-0195
0111021679	PST2 12/7 D44	S-0195
0111021680	PST2 12/8 D44	S-0195
0111021681	PST2 12/9 D44	S-0195

ATTENTION: IMPORTANT


Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909091098	ASSY FRAME	1
0501044358	50,8 X 101,6 X 617 X 180 HYDRAULIC CYLINDER	2
0501047376	50,8 X 114,3 X 637 X 160 HYDRAULIC CYLINDER	3
0501042497	OPEN U ESTABILIZER	4
0501050647	ROW MARKER DISC ASSY	5
0909091099	TRANSMISSION SISTEM	6
0501051577	STUB SHAFT HUB ASSEMBLY	7
0501051596	TRANSMISSION RIGHT DRIVING	8
0909091100	FERTILIZER BOX	9
0909091101	D 44/54 SEED/FERTILIZER ROW ASSEMBLY	10
0909091102	D 44/54 FERTILIZER ROW	11
0909091103	16/18 SHORT BLADE DISC D 44/54	12
0909091105	15 X15 FERTILIZER UNAL DOUB-DISC	13
0909090102	FERTILIZER UNAL DOUB-DISC ASSEMBLY	14
0909091110	SCARIFIER SPINDLE	15
0909091030	ROD SCARIFIER SPINDLE	16
0909091113	D 56/56A SEED/FERTILIZER ROW ASSEMBLY	17
0909091104	D 46/56 FERTILIZER ROW ASSEMBLY	18
0909091106	D 46A/56A FERTILIZER ROW ASSEMBLY	19
0909091112	16 SHORT BLADE DISC ASSEMBLY	20
0501051172	16 SHOT BLADE DISC	21
0909091107	SEED ROW	22
0501050076	SEED SISTEM	23
0909091108	SEED UNAL DOUBLE-DISC	24
0909090004	15 X 15 SEED UNAL DOUB-DISC ASSEMBLY	25
0909090134	SEED DISTRIBUTOR ASSEMBLY	26
0501043613	DEPTH WHEEL	27
0501050927	PRESS WHEELS ASSEMBLY	28
0501050464	CONCAVE PRESS WHELL ASSEMBLY	29
0909091011	DEPTH CONTROL WHEEL ASSEMBLY	30
0909091109	SEPARATE PARTS	31
0909091111	FRONT PLATFORM ASSEMBLY	32
0501043422	SEED COTTON SYSTEM ASSEMBLY	33
0501041659	SEED PEANUT SYSTEM ASSY	34
0501044301	8 SUBSOILER ASSEMBLY	35
0909094459	HEX AXLE ASSEMBLY	36



Item	Code	Description	See page	08	09	10	12
01	0501065680	FRAME		01	00	00	00
02	0501065681	FRAME		00	01	00	00
03	0501065682	FRAME		00	00	01	00
04	0501065683	FRAME		00	00	01	00
05	0501047376	50,8 X 114,3 X 637 X 160 HYDRAULIC CYLINDER	3	00	00	01	00
06	0501044358	50,8 X 101,6 X 617 X 180 HYDRAULIC CYLINDER	2	01	01	01	00
07	0521010579	COUPLING SHAFT		01	01	01	01
08	0521010574	C0.9" X 3.3" COUPLING SHAFT		01	01	01	01
09	0503010571	1/4" X 1.1/2 COTTERPIN		02	02	02	02
10	0502010890	SPRING ROD SUPPORT		01	01	01	01
11	0502010891	SPRING CHOCK SUPPORT VARON		01	01	01	01
12	0503010920	1/2" X 1.1/2" BOLT		03	03	03	03
13	0503010395	1/2" X 1-1/4" BOLT		10	10	10	10
14	0501065678	SEAT		01	01	01	01
15	0503010019	1/2" SPRING WASHER		21	21	21	21
16	0503010060	1/2" NUT		19	19	19	19
17	0501065653	RIGHT REAR HANDRAIL		01	00	00	00
18	0501065654	RIGHT REAR HANDRAIL		00	01	00	00
19	0501065655	RIGHT REAR HANDRAIL		00	00	00	01
20	0501065656	RIGHT REAR HANDRAIL		00	00	00	01
21	0501065688	LEFT REAR HANDRAIL		01	00	00	00
22	0501065689	LEFT REAR HANDRAIL		00	01	00	00
23	0501065690	LEFT REAR HANDRAIL		00	00	01	00
24	0501065691	LEFT REAR HANDRAIL		00	00	01	00
25	0511011233	REAR PLATFORM		02	00	00	00
26	0511011234	REAR PLATFORM		00	02	00	00
27	0511011235	REAR PLATFORM		00	00	02	00
28	0511011236	REAR PLATFORM		00	00	02	00
29	0511011222	REAR PLATFORM FIXER		04	04	04	04
30	0501068062	REAR PLATLFORM FIXER		00	00	04	00
31	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04	04	04	04



ASSY FRAME

0909091098


Item	Code	Description	See page	08	09	10	12
32	0503010025	3/8" SPRING WASHER		10	10	10	10
33	0503010026	3/8" NUT		10	10	10	10
34	0501043882	PULLEY SUPPORT		01	01	01	01
34A	0501065642	ROW MARKER SUPPORT		01	01	01	01
34B	0502011231	CENTRAL PULLEY		02	02	02	02
34C	0502010693	ROW SUPPORT ARTICULACION		01	01	01	01
34D	0511011308	BOLT		02	02	02	02
35	0503010232	5/8" X 1.3/4" BOLT		02	02	02	02
36	0503010027	5/8" SPRING WASHER		26	26	26	26
37	0503010013	5/8" NUT		26	26	26	26
38	0521010641	COUPLING SHAFT		02	02	02	02
39	0503010257	1/8" X 1" COTTERPIN		02	02	02	02
40	0502010421	SIDE PULLEY		02	02	02	02
41	0501013783	HOOK WITH CHAIN		02	02	02	02
42	0501043881	ROW MARKER PIVOT		01	01	01	01
42A	0501065640	ROW MARKER ROD GUIDE		02	02	02	02
42B	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		04	04	04	04
42C	0501065644	ROW MARKER ARM/DISARMENT ROD		01	01	01	01
42D	0501064229	REGULATOR ARM/DISARMENT ROD		01	01	01	01
42E	0521010454	0.83" X 1.25" X 0.79" SLEEVE		02	02	02	02
42F	0501062547	ROW MARKER BAR REGULATOR		01	01	01	01
42G	0521010446	0.4" X 0.8" X 0.2" SLEEVE		02	02	02	02
42H	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02	02	02	02
42I	0521010539	0.3" X 1.2" COUPLING SHAFT		02	02	02	02
42J	0503010140	1/8" X 3/4" COTTERPIN		02	02	02	02
42K	0511011413	ROW MARK ARM LOCK		02	02	02	02
42L	0503030755	STEEL CABLE		01	01	01	01
42M	0503011404	BOLT		02	02	02	02
42N	0501010984	FLAT WASHER		06	04	04	04
43	0503011126	6,4 X 1000 CHAIN		02	00	00	00
44	0503011127	6,4 X 1260 CHAIN		00	02	00	00
45	0503011128	6,4 X 1400 CHAIN		00	00	02	00
46	0503011129	6,4 X 1900 CHAIN		00	00	00	02
47	0502011291	CHAIN SLEEVE		02	02	02	02
48	0503010683	0,2" X 1,2" SPRING PIN		02	02	02	02
49	0511011243	PROTECTION COVER ARM/DISARMENT		01	00	00	00
50	0511011270	PROTECTION COVER ARM/DISARMENT		00	01	00	00
51	0511011272	PROTECTION COVER ARM/DISARMENT		00	00	01	00
52	0511011274	PROTECTION COVER ARM/DISARMENT		00	00	00	01
53	0511011269	PROTECTION COVER ARM/DISARMENT		01	00	00	00
54	0511011271	PROTECTION COVER ARM/DISARMENT		00	01	00	00
55	0511011273	PROTECTION COVER ARM/DISARMENT		00	00	01	00
56	0511011275	PROTECTION COVER ARM/DISARMENT		00	00	00	01
57	0511017961	1/2" X 1-1/4" REB BOLT		02	02	02	02
58	0501067038	RIGHT ROW MARK		01	00	00	00
59	0501065684	RIGHT ROW MARK		00	01	01	00
60	0501065686	RIGHT ROW MARK		00	00	01	00
61	0501067039	LEFT ROW MARK		01	00	00	00
62	0501065685	LEFT ROW MARK		01	01	01	00
63	0501065687	LEFT ROW MARK		00	00	00	01
64	0503010769	5/8" X 2-1/4" BOLT		04	04	04	04
65	0521010479	SLEEVE ARTICULATION		04	04	04	04
66	0503030403	1.85" X 2.87" BEATER		02	02	02	02
67	0503011114	QUICK COUPLING PUMP		02	02	02	02
68	0511011417	HEX STUD 3/8" X 3/8" X 5.79"		04	04	04	04
69	0511011426	RH CHAIN PROTECTION CAP		01	01	01	01
70	0511011427	LEFT CHAIN PROTECTION CAP		01	01	01	01
71	0503010209	3/8" UNC BUTTERFLY NUT		04	04	04	04
72	0502010889	PARKING SUPPORT		02	02	02	02




ASSY FRAME

0909091098


Item	Code	Description	See page	08	09	10	12
73	0503010480	5/8" X 4.3/4" BOLT		20	20	20	20
74	0501067817	PLOUGH SUPPORT		02	02	02	02
75	0501011075	PIN		02	02	02	02
76	0503030012	HAIR PIN		02	02	02	02
77	0501068332	ARTICULATER AXLE		01	01	01	01
78	0501012916	FLAT WASHER 38,50 X 66 X 4,75 ZN		01	01	01	01
79	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01	01	01	01
80	0501042547	DRAWBAR ASSY		01	01	01	01
80A	0501063935	DRAWBAR		01	01	01	01
80B	0501066277	TRACTOR HITCH		01	01	01	01
80C	0501010098	3/4" UNC BOLT		04	04	04	04
80D	0503010023	3/4" SPRING WASHER		04	04	04	04
80E	0503010014	3/4" NUT		04	04	04	04
80F	0503010002	1800 GREASE FITTING		01	01	01	01
81	0503010003	1845 GREASE FITTING		04	04	04	04
82	0502011170	FIXER		08	08	08	10
83	0502010929	TUBE FIXER SUPPORT		06	06	06	06
84	0503010010	1/4" X 2.1/2" COTTERPIN		01	01	01	01
85	0511017527	FRAME TUBE		01	00	00	00
86	0511017620	FRAME TUBE		00	01	00	00
87	0511017621	FRAME TUBE		00	00	01	00
88	0511017622	FRAME TUBE		00	00	00	01
89	0511017302	FLAT WASHER		02	02	02	02
90	0503010849	3/8" X 1-1/2" BOLT		00	00	04	00
91	0501042497	OPEN U ESTABILIZER	4	01	01	01	01
92	0521010572	0.9" X 2.9" COUPLING SHAFT		02	02	02	02
93	0503030085	LOCK PIN		02	02	02	02
94	0909094459	HEX AXLE ASSEMBLY	36	01	01	01	01




Item	Code	Description	See page	QT
01	0501066239	4" X 7.1" CYLINDER CASE		01
02	0501069014	HYDRAULIC CYLINDER TURNBUCKLE		01
03	0502010427	4" HEAD		01
04	0502010778	2" X 4.2" RING SUPPORT		01
05	0503010039	D-2000 SCRAPER RING		01
06	0503010991	1870-2000-375-B GASKET		01
07	0503010952	W2-2250-500 RING		01
08	0503011061	8-342 BACK-UP RING		01
09	0503010338	2-342 N 3006-9B O'RING		01
10	0503010345	2-218 N 3006-9B O'RING		01
11	0502010992	2.0" X 4.0" PISTON		01
12	0503010043	PACKING 3750-3250		02
13	0503010994	W2-4000-500 PK RING G.E		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503010003	1845 GREASE FITTING		01
16	0521010680	HYDRAULIC CYLINDER ROD STOP		01
17	0503030012	HAIR PIN		01
18	0501031799	HYDRAULIC CYLINDER REPAIR KIT		01




Item	Code	Description	See page	QT
01	0501068447	20.7" X 4.5" CYLINDER CASE		01
02	0501068448	HYDRAULIC CYLINDER TURNBUCKLE		01
03	0502011222	0.56" END CAP		01
04	0502011220	2" X 4.5" RING SUPPORT		01
05	0503010039	D-2000 SCRAPER RING		01
06	0503010991	1870-2000-375-B GASKET		01
07	0503010952	W2-2250-500 RING		01
08	0503011893	BACK-UP RING, 8-346		01
09	0503011892	O' RING, 2-346 N 3006-9B		01
10	0503010345	2-218 N 3006-9B O'RING		01
11	0502011221	2.0" X 4.5" PISTON		01
12	0503011890	3750-3750 GASKET		02
13	0503011891	W2-4500-500 RING G.E		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503010003	1845 GREASE FITTING		01
16	0501032513	HYDRAULIC CYLINDER REPAIR KIT		01



Item	Code	Description	See page	QT
01	0501110262	245 ADJUSTMENT NUT		01
02	0501061056	RH LOCKNUT WITH HANDLER		01
03	0501063937	LH TURNBUCKLE		01
04	0501063936	LH TURNBUCKLE		01
05	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0502020618	DEPHT WHEELS BOX		01
02	0503010269	6204 BALL BEARING		02
03	0503010689	SEAL 00763-BR		01
04	0521010489	SLEEVE SPACER		01
05	0602023084	16" X 0.2" NOTCHED DISC BLADE		01
06	0503010178	5/16" X 7/8" BOLT		04
07	0503010179	5/16" ZN SPRING WASHER		04
08	0503010337	5/16" NUT		04
09	0501068055	MARK DISC AXLE		01
10	0503010878	5/8" SELF ALIGNING NUT		01
11	0502020594	PROTECCION COVER		01
12	0503010691	1/4" GREASE FITTING		01
13	0503010023	3/4" SPRING WASHER		01
14	0503010014	3/4" NUT		01






PST2 - 08/09/10/12 LINES
TRANSMISSION SISTEM

Item	Code	Description	See page	08	09	10	12
27Bb	0503010694	INNER TIRE		02	02	02	04
27Bc	0503010072	0,18"X0,65"X5.12" WHEEL		02	02	02	04
28	0501019911	SUPPORT PLATE		04	04	04	08
29	0503030420	1" X 0.67" CASTLE NUT		04	04	04	08
30	0503010131	3/16" X 1-1/2" COTTERPIN		04	04	04	08
31	0501110025	AGRICULTURAL BEARING		03	03	03	04
32	0501110026	AXLE ARGRICULTURAL BEARING		03	03	03	04
33	0511010733	1-3/8" X 60" AXLE		02			
34	0511011250	1-3/8" X 73" AXLE			02		
35	0511010734	1-3/8" X 78" AXLE			02		
36	0511010735	1-3/8" X 98" AXLE				02	
37	0501018879	LEFT MOTOR AXLE BEARING SUPPORT		02	02	02	04
38	0501013556	BEARING SUPPORT CHOCK		02	02	02	04
39	0502011170	FIXER		02	02	02	04
40	0503010480	5/8" X 4.3/4" BOLT		04	04	04	08
41	0503010027	5/8" SPRING WASHER		04	04	04	08
42	0501012140	FLAT WASHER		04	04	04	04
43	0501051596	TRANSMISSION RIGHT DRIVING	8	02	02	02	04
44	0501067046	RATCHET RESET		02	02	02	04
45	0501065167	RATCHET PIVOT ARM		02	02	02	04
46	0501067048	RATCHET BAR DES.		02	02	02	04
47	0502011216	FASTENER		02	02	02	04
48	0503011082	C1/2" X 1.3/4" SCREW		02	02	02	04
49	0503010019	1/2" SPRING WASHER		06	06	06	08
50	0503010060	1/2" NUT		06	06	06	08
51	0503030198	0.6" X 2.4" X 0.1" EXTENSION SPRING		02	02	02	04
52	0503010010	1/4" X 2.1/2" COTTERPIN		02	02	02	02
53	0502011345	18Z P 1.25" RH1.3/8" GEAR		04	04	04	04
54	0503030417	1.7"X 1.4"X 0.14" RH TORSION SPRING		01	01	01	01
55	0503030394	1.7"X 1.4"X 0.14" LH TORSION SPRING		01	01	01	01
56	0501017558	5/8" HEX AXLE BEARING SUPPORT		02	02	02	02
57	0503010920	1/2" X 1.1/2" BOLT		04	04	04	04
58	0511017302	FLAT WASHER		04	04	04	04
59	0501110036	HEX AXLE RIGHT BEARING ASSY		01	01	01	01
60	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"		01	01	01	01
61	0503010363	5/16" X 1" BOLT		04	04	04	04
62	0503011176	5/16" SPRING WASHER		04	04	04	04
63	0503010337	5/16" NUT		04	04	04	04
64	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8		02	02	02	02
65	0501017440	5/8" X 60.4" HEX AXLE		01			
66	0501017441	5/8" X 69.3" HEX AXLE		01			
67	0511010749	5/8" X 71.8" HEX AXLE			01		
68	0511010750	5/8" X 79.1" HEX AXLE			01		
69	0501017442	5/8" X 76.1" HEX AXLE				01	
70	0501017443	5/8" X 85" HEX AXLE				01	
71	0501017432	5/8" X 95.8" HEX AXLE					01
72	0501017433	5/8" X 2660" HEX AXLE					01
73	0502011299	BUSHING GEAR		02	02	02	02
74	0502011314	8Z P 1.1/4" RH1.4" GEAR		02	02	02	02
75	0521010530	COUPLING SHAFT		04	04	04	04
76	0501041671	RIGHT TRANSM CHAIN TENSIONER		01	01	01	01
77	0501041672	LEFT CHAIN TENSIONER TRANSM		01	01	01	01
77A	0501062729	CHAIN TENSIONER SUPPORT		02	02	02	02
77B	0511018661	3/4" X 3.3" PIVOT SHAFT		02	02	02	02
77C	0503010292	0.2" X 1.6" SPRING PIN		02	02	02	02
78	0502010420	CENTRAL PULLEY		01	01	01	01
79	0502011231	CENTRAL PULLEY		01	01	01	01
80	0511011309	AXLE PULLEY		01	01	01	01
81	0503011393	CHAIN 2050 X 2.8" LINK + MENDING		02	02	02	04




PST2 - 08/09/10/12 LINES
TRANSMISSION SISTEM


Item	Code	Description	See page	08	09	10	12
82	0503010876	2050 CHAIN X 45 LINK + MENDING		02	02	02	02
83	0503010450	2050 CHAIN X 30 LINK + REDUCTION		02	02	02	02
84	0501042500	CHAIN TENSIONER ASSEMBLY		02	02	02	02
84A	0501064230	RIGHT CHAIN TENSIONER		02	02	02	02
85	0501065677	STRUT		02	02	02	02
86	0503010797	3/4" X 4" BOLT		08	08	08	16
87	0503010140	1/8" X 3/4" COTTERPIN		10	10	10	10
88	0503030418	TRACTION SPRING		02	02	02	02
89	0503011260	3/4" HEX NUT		02	02	02	02



Item	Code	Description	See page	QT
01	0502011284	CARRYING WHEEL HUB		01
02	0503010037	30207 ROLLER BEARING		02
03	0511015300	WHEELS AXLE		01
04	0503010590	00674-B SEAL		02
05	0503010370	502072 CLAMPING RING (FOR AXLE)		02
06	0502040663	ADJUSTMENT NUT		01
07	0502011339	15Z GEAR P 1.25"		01
08	0503010240	5/16" X 3/4" BOLT		06
09	0503010179	5/16" ZN SPRING WASHER		06
10	0501010127	9/16" X 1-7/8" LUG BOLT		06
11	0503013001	9/16" CONICAL NUT		06
12	0503010002	1800 GREASE FITTING		01
13	0521012190	AXLE LOCK		01
14	0503011167	M16 X 2 X 30 BOLT		01
15	0503010027	5/8" SPRING WASHER		01



Item	Code	Description	See page	QT
01	0501110220	MECHANICAL RATCHET AXLE		01
02	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
03	0501019735	FLAT WASHER		01
04	0502011329	14Z GEAR WITH RIGHT DRAGGER		01
05	0501019734	FLAT WASHER		02
06	0502010711	RIGHT CAM,LARGER		01
07	0502010710	RIGHT CAM, SMALLER		01
08	0502010708	RH DRIVING AXLE FOLLOWER		01
09	0503010060	1/2" NUT		01
10	0503011082	C1/2" X 1.3/4" SCREW		01
11	0503010003	1845 GREASE FITTING		02
12	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	08	09	10	12
01	0501065665	RIGHT FERTILIZER BOX		01			
02	0501065667	RIGHT FERTILIZER BOX			01		
03	0501065669	RIGHT FERTILIZER BOX				01	
04	0501065671	RIGHT FERTILIZER BOX					01
05	0501065666	LEFT FERTILIZER BOX		01			
06	0501065668	LEFT FERTILIZER BOX			01		
07	0501065670	LEFT FERTILIZER BOX				01	
08	0501065672	LEFT FERTILIZER BOX					01
09	0501050272	DISTRIBUTOR OF RIGHT FERTILIZER		03	02	04	05
10	0501050273	LH FERTILIZER METERING		03	03	04	05
11	0501050452	RIGHT FERTILIZER DISTRIBUTOR		01			
12	0501050453	LH FERTILIZER METERING		01			
13	0501050454	RIGHT ABONO DISTRIBUTOR			01		
14	0501050455	LH FERTILIZER METERING			01		
15	0501050456	RIGHT FERTILIZER DISTRIBUTOR				01	
16	0501050457	LH FERTILIZER METERING				01	
17	0501050458	RIGHT ABONO DISTRIBUTOR		01			
18	0501051714	LH FERTILIZER METERING		01			
19	0501050459	LH FERTILIZER METERING		01			
20	0501050460	RIGHT FERTILIZER DISTRIBUTOR		01			
20A	0501110120	FERTILIZER DISTRIBUTOR BODY		08	09	10	12
20Aa	0502010596	FERTILIZER DISTRIBUTOR BODY		08	09	10	12
20Ab	0511013789	FERTILIZER TUBE		08	09	10	12
20B	0503010571	1/4" X 1.1/2 COTTERPIN		16	19	20	24
20C	0501017391	3/4" X 14.3" SQUARE SHAFT		06	05	08	10
20D	0501017393	3/4" X 18.1"SQUARE SHAFT		02			
20E	0501017394	3/4" X 19.4" SQUARE SHAFT			02		
20F	0501017392	3/4" X 24.4"SQUARE SHAFT				02	
20G	0511011253	3/4" X 18.4" LH SQUARE SHAFT		02			
20H	0511011251	3/4" X 13.5" SQUARE SHAFT		01			
20I	0511011252	3/4" X 24.4"SQUARE SHAFT		01			




FERTILIZER BOX

0909091100

Item	Code	Description	See page	08	09	10	12
20J	0503030275	AGRICULTURAL BEARING		16	18	20	24
20K	0501013774	GREASE SEAL		08	09	10	12
20L	0503030303	SUPPORT WASHER		08	09	10	12
20M	0511017137	FLAT WASHER		16	18	20	24
20N	0503031164	RIGHT HELICAL CONDUTOR		04	05	05	06
20O	0503031165	LEFT HELICAL CONDUTOR		04	04	05	06
20P	0502011304	1.5" X 2.0" X 1.2" SLEEVE INTER		08	09	10	12
20Q	0503011962	GREASE FITTING		08	09	10	12
20R	0503010004	1890 GREASE FITTING		08	09	10	12
21	0501010942	3/8" X 1-1/4" BOLT		32	36	40	48
22	0503010025	3/8" SPRING WASHER		38	42	46	54
23	0503010026	3/8" NUT		36	40	44	52
24	0501050274	BOX BEARING ASSY		02	02	02	02
24A	0501110001	BOX BEARING ASSY		02	02	02	02
24B	0502040379	FERTILIZER BOX BEARINGREEL		02	02	02	02
24C	0503010372	501050 CLAMPING RING (FOR AXLE)		02	02	02	02
24D	0503010002	1800 GREASE FITTING		02	02	02	02
25	0501010161	1/2" X 1.1/4" BOLT		06	06	06	06
26	0503010019	1/2" SPRING WASHER		10	10	10	10
27	0503010060	1/2" NUT		10	10	10	10
28	0502011300	BUSHING GEAR		02	02	02	02
29	0502011314	8Z P 1.1/4" RH1.4" GEAR		02	02	02	02
30	0503010010	1/4" X 2.1/2" COTTERPIN		02	02	02	02
31	0501017476	DRAGING		06	07	08	10
32	0503010397	5/16" X 1-3/4" BOLT		06	07	08	10
33	0503010337	5/16" NUT		12	14	16	20
34	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04	04	04	04
35	0501010984	FLAT WASHER		08	08	08	08
36	0503010920	1/2" X 1.1/2" BOLT		04	04	04	04
37	0521010445	0.53" X 0.75" X 0.45" SLEEVE		04	04	04	04
38	0511017302	FLAT WASHER		04	04	04	04
39	0501065673	FERTILIZER BOX COVER		02			
40	0501065674	FERTILIZER BOX COVER			02		
41	0501065675	FERTILIZER BOX COVER				02	
42	0501065676	FERTILIZER BOX COVER					02
43	0501011742	MOBILE HINGE		04	06	06	06
44	0503011178	5/16" X 3/4" BOLT		12	18	18	18
45	0503011177	FLAT WASHER		04	06	06	06
46	0503011176	5/16" SPRING WASHER		12	18	18	18
47	0503011175	5/16" NICKEL-PLATED NUT		12	18	18	18
48	0511011015	FIXED HINGE		04	06	06	06
49	0521010528	0.3" X 1.6" COUPLING SHAFT		04	06	06	06
50	0503011174	1/8" X 3/4" COTTERPIN		04	06	06	06
51	0503010293	BAQUELITE MANIPULACION		02	02	02	02
52	0511013418	1/8" X 36 LINK CHAIN		02	02	02	02
53	0503010256	3/8" X 3/4" BOLT		02	02	02	02
54	0503010298	1/4" X 1/2" BOLT		02	02	02	02
55	0503010305	FLAT WASHER		02	02	02	02
56	0503010143	1/4" SPRING WASHER		02	02	02	02
57	0503010144	1/4" NUT		02	02	02	02
58	0503030655	0.5" X 0.3 PLUG		08	12	12	12




Item	Code	Description	See page	QT
00	0511043205	RH DDD SEED/FERTILIZER ROW		01
00A	0511043206	LH DDD SEED/FERTILIZER ROW		01
00B	0511043231	RH LONG SEED/FERTILIZER ROW ASSY		01
00C	0511043232	LH LONG SEED/FERTILIZER ROW ASSY		01
01	0501046504	RH DDD FERTILIZER ROW ASSY		01
02	0501046505	LH DDD FERTILIZER ROW ASSY		01
03	0501046500	MIDDLE RH DDD SEED ROW ASSY		01
04	0501046501	MIDDLE LH DDD FERTILIZER ROW ASSY		01
05	0501046506	LONG RH DDD SEED LINEA ASSY		01
06	0501046507	LH DDD LONG SEED ROW ASSY		01
07	0501051570	POINT RIGHT SCARIFIER ARM ASSY		01
08	0501051571	POINT LEFT SCARIFIER ARM ASSY		01
09	0501052767	SCARIFIER SPINDLE		01
10	0501052768	SCARIFIER SPINDLE		01




Item	Code	Description	See page	DIR	ESQ
00	0501046504	RH DDD FERTILIZER ROW ASSY		01	
00A	0501046505	LH DDD FERTILIZER ROW ASSY			01
01	0501064962	FERTILIZER ROW ARM		01	01
02	0502010912	FERTILIZER ROW SUPPORT		01	01
03	0501064938	BLADE DISC SUPPORT		01	01
04	0511016261	0.7" X 1" X 3.4" BUSHING		01	01
05	0501010164	3/4" X 7 BOLT		01	01
06	0511011858	0.7" X 1" X 0.6" BUSHING		02	02
07	0511017305	FLAT WASHER		01	01
08	0503010023	3/4" SPRING WASHER		02	02
09	0503010014	3/4" NUT		04	04
10	0502011170	FIXER		01	01
11	0503010480	5/8" X 4.3/4" BOLT		02	02
12	0501012140	FLAT WASHER		02	02
13	0503010027	5/8" SPRING WASHER		02	02
14	0503010013	5/8" NUT		02	02
15	0501062194	REGULATOR SPRING		01	01
16	0511011505	0.7" X 1" X 2" BUSHING		01	01
17	0501010216	3/4" X 4-1/2" BOLT		01	01
18	0503030110	2.3" X 5.5" X 0.4" COMPRESSION SPRING		01	01
19	0511011423	SPRING GUIDE BUSHING		01	01
20	0501064686	SPRING ROD		01	01
21	0511016400	FERTILIZER SPRING GUIDE FIXER PIN		01	01
22	0503010257	1/8" X 1" COTTERPIN		01	01
23	0501011090	FLAT WASHER		01	01
24	0503030960	1" X 15.7" X 0.1" COMPRESSION SPRING		01	01
25	0503030959	1.6" X 15.7" X 0.2" COMPRESSION SPRING		01	01
26	0503030958	2" X 15.7" X 0.3" COMPRESSION SPRING		01	01
27	0502040157	TRIP SPRING GUIDE LOCK BUSHING		02	02
28	0503010834	1/2 X 1 BOLT		02	02
29	0501050748	15" X 15" RIGHT FERT UNAL-DD ASSY		01	




Item	Code	Description	See page	DIR	ESQ
30	0501050749	15" X 15" LEFT FERT UNAL-DD ASSY			01
31	0503010547	1/2" X 4" BOLT		02	02
32	0503010019	1/2" SPRING WASHER		02	02
33	0503010060	1/2" NUT		04	04
34	0503030391	RIGHT FERTILIZER NOZZLE		01	
35	0503030392	LEFT FERTILIZER NOZZLE			01
36	0503030408	2X2X390 HOSE		01	01
37	0503030156	2" HOSE CLAMP		02	02
38	0502010890	SPRING ROD SUPPORT		01	01
39	0502010891	SPRING CHOCK SUPPORT VARON		01	01
40	0503010395	1/2" X 1-1/4" BOLT		01	01
41	0503010920	1/2" X 1.1/2" BOLT		01	01
42	0501040432	16" BLADE DISC ASSY		01	01
43	0503010361	SPRING PIN		01	01
44	0511013333	SPACING PLATE		02	02
45	0501050928	POINT RIGHT SCARIFIER SPINDLE		01	01
46	0501050940	POINT RIGHT SCARIFIER SPINDLE		01	01
46A	0501067996	RIGHT POINT SPINDLE		01	01
46B	0502070061	POINT SUBSOILER		01	01
46C	0503011373	0.4" X 1.1" SPRING PIN		01	01



Item	Code	Description	See page	QT
00	0501040432	16" BLADE DISC ASSY		01
00A	0501047686	18" BLADE DISC ASSY		01
01	0501051172	16 SHOT BLADE DISC	21	01
02	0501051174	18" SHOT BLADE DISC		01
02A	0603023009	16" X 0.2" FLAT PLAIN DISC		01
02B	0603025055	18" X 0.2" FLAT PALIN DISC		01
02C	0503010215	30205 BEARING		02
02D	0501068582	7/8" UNF WITH DUST CLOAK NUT		01
02E	0503010213	SEAL 30205		02
02F	0503010337	5/16" NUT		06
02G	0503010179	5/16" ZN SPRING WASHER		06
02H	0503010365	NUT		06
02I	0501068216	DUST CLOAK 3/4" DC AXLE		01
02J	0503010691	1/4" GREASE FITTING		01
02K	0502011279	DISC HUB		01
02L	0501013839	WASHER		01
03	0501068187	BLADE DISC SUPPORT		01
04	0511018481	BLADE DISC 3/4" AXLE LOCK		02
05	0503010023	3/4" SPRING WASHER		02
06	0503010014	3/4" NUT		02
07	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
00	0501050748	15" X 15" RIGHT FERT UNAL-DD ASSY		01
00A	0501050749	15" X 15" LEFT FERT UNAL-DD ASSY		01
01	0502011275	DOBLE DISC BOX		02
02	0503010598	30204 BALL BEARING		04
03	0511011344	3/4" UNC RIGHT DDD HUB AXLE		01
04	0511011345	3/4" UNC LH DDD HUB AXLE		01
05	0503011112	SEAL 02376-BRG		02
06	0511011927	DUST CLOAK		02
07	0503030282	3/4" CASTLE NUT		02
08	0503010140	1/8" X 3/4" COTTERPIN		02
09	0503030757	2.9" X 2" X 0.02" JOINT		02
10	0502011265	DD PROTECCION COVER		02
11	0503010519	1/4" X 5/8" BOLT		06
12	0503010143	1/4" SPRING WASHER		06
13	0603022042	13" X 0.12" PLAIN COULTER BLADE		02
14	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
15	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
16	0503010546	5/16" X 7/8" BOLT		12
17	0503010337	5/16" NUT		12
18	0501017541	RIGHT DOUBLE DISC SCRAPER		01
19	0501017542	LH DOUBLE DISC SCRAPER		01
20	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
21	0501010984	FLAT WASHER		02
22	0503010025	3/8" SPRING WASHER		01
23	0503010026	3/8" NUT		01
24	0511015098	FLAT WASHER		02
25	0502070062	SCRAPER		01
26	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	DIR	ESQ
00	0501052976	15 X 15 RIGHT FERT UNAL DOUB-DISC ASSY		01	00
00A	0501052977	DDD LEFT FERTILIZER 15 X 15 ASSY		00	01
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01	00
02	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		00	01
03	0502011930	DOUBLE DISC COULTER BOX		02	02
04	0503010598	30204 BALL BEARING		04	04
05	0503011112	SEAL 02376-BRG		02	02
06	0521019154	RIGHT DOUB DISC HUB		01	01
07	0521019148	LEFT DOUBLE DISC HUB		01	01
08	0503030282	3/4" CASTLE NUT		02	02
09	0503010257	1/8" X 1" COTTERPIN		02	02
10	0603022042	13" X 0.12" PLAIN COULTER BLADE		02	02
11	0503010546	5/16" X 7/8" BOLT		12	12
12	0503010337	5/16" NUT		02	02
13	0511015098	FLAT WASHER		06	06
14	0511011927	DUST CLOAK		02	02
15	0503030757	2.9" X 2" X 0.02" JOINT		02	02
16	0521019178	COVER DEPTH		02	02
17	0503014729	1/4" UNF X 1/2" BOLT		06	06
18	0503011441	SPRING WASHER		06	06
19	0501017541	RIGHT DOUBLE DISC SCRAPER		01	01
20	0501017542	LH DOUBLE DISC SCRAPER		01	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01	01
22	0501010984	FLAT WASHER		02	02
23	0503011443	3/8" SPRING WASHER		01	01
24	0503010026	3/8" NUT		01	01
25	0502070062	SCRAPER		01	01
26	0503011402	0.2" X 0.8" SPRING PIN		01	01


SCARIFIER SPINDLE




Item	Code	Description	See page	QT
00	0501051570	POINT RIGHT SCARIFIER ARM ASSY		01
00A	0501051571	POINT LEFT SCARIFIER ARM ASSY		01
01	0501068976	RIGHT SCARIFIER ARM		01
02.	0501068977	LEFT SCARIFIER ARM		01
03	0511017782	RIGHT SOCKET		01
04	0511017791	LEFT SOCKET		01
05	0502070061	POINT SUBSOILER		02
06	0503011373	0.4" X 1.1" SPRING PIN		02



Item	Code	Description	See page	QT
00	0501052767	SCARIFIER SPINDLE		01
00.	0501052768	SCARIFIER SPINDLE		01
01	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01
04	0511061769	RIGHT FERTILIZER CONDUCTOR WITH REGULATOR		01
05	0511061770	LEFT CONDUCTOR FERTILIZER WITH REGULATOR		01
06	0501010984	FLAT WASHER		04
07	0503010025	3/8" SPRING WASHER		02
08	0503010026	3/8" NUT		02
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
10	0503031050	CURVED CONDUCTOR		01
11	0503010246	CLAMP		01



Item	Code	Description	See page	QT
00	0511043209	RH SHORT SEED/FERTILIZER ROW ASSY		01
00A	0511043210	LH SHORT SEED/FERTILIZER ROW ASSY		01
00B	0511043211	LH LONG SEED/FERTILIZER ROW ASSY		01
00C	0511043214	RH SHORT SEED/FERTILIZER ROW ASSY		01
00D	0511043215	LH SHORT SEED/FERTILIZER ROW ASSY		01
00E	0511043212	RH LONG SEED/FERTILIZER ROW ASSY		01
00F	0511043213	LH LONG SEED/FERTILIZER ROW ASSY		01
01	0501047703	RH SHORT FERTILIZER ROW ASSY		01
02	0501047714	LH SHORT FERTILIZER ROW ASSY		01
03	0501047715	LH LONG FERTILIZER ROW ASSY		01
04	0501047271	RH SHORT DDD FERTILIZER ROW ASSY		01
05	0501047272	LH SHORT DDD FERTILIZER ROW ASSY		01
06	0501047273	LONG RIGHT DDD FERTILIZER ROW ASSY		01
07	0501047274	LH LONG DDD FERTILIZER ROW ASSY		01
08	0501046500	MIDDLE RH DDD SEED ROW ASSY		01
09	0501046501	MIDDLE LH DDD FERTILIZER ROW ASSY		01
10	0501046507	LH DDD LONG SEED ROW ASSY		01
11	0501052767	SCARIFIER SPINDLE		01
12	0501052768	SCARIFIER SPINDLE		01




Item	Code	Description	See page	08	09	10	12
00	0501047704	LONG RIGHT FERTILIZER ROW		01			
00A	0501047715	LH LONG FERTILIZER ROW ASSY			01		
00B	0501047703	RH SHORT FERTILIZER ROW ASSY				01	
00C	0501047714	LH SHORT FERTILIZER ROW ASSY					01
01	0501068002	ROW FIXER SUPPORT		01	01	01	01
02	0501068269	ROW LONG ARM		01	01		
03	0501068268	ROW SHORT ARM				01	01
04	0503011411	1/2" X 5-1/2" BOLT		03	03	03	03
05	0503010019	1/2" SPRING WASHER		04	04	04	04
06	0503010060	1/2" NUT		04	03	04	03
07	0503011399	M16 X 1,5 X 50 BOLT		02	02	02	02
08	0501010962	1" X 0.6" X 0.5" PIVOT BUSHING		02	02	02	02
09	0501010301	FLAT WASHER		04	04	04	04
10	0503011400	M16 X 0.6" NUT		02	02	02	02
11	0501050928	POINT RIGHT SCARIFIER SPINDLE		01	01		
12	0501050940	POINT RIGHT SCARIFIER SPINDLE				01	01
13	0511013333	SPACING PLATE		02	02	02	02
14	0503010547	1/2" X 4" BOLT		01	01	01	01
15	0511016400	FERTILIZER SPRING GUIDE FIXER PIN		01	01	01	01
16	0503010257	1/8" X 1" COTTERPIN		01	01	01	01
17	0501067365	PRING ROD		01	01	01	01
18	0501064686	SPRING ROD		01	01	01	01
19	0502040157	TRIP SPRING GUIDE LOCK BUSHING		02	02	02	02
20	0503010834	1/2 X 1 BOLT		04	04	04	04
21	0501011090	FLAT WASHER		02	02	02	02
22	0503030960	1"X15.7"X0.1" COMPRESSION SPRING		02	02	02	02
23	0503030959	1.6"X15.7"X0.2" COMPRESSION SPRING		02	02	02	02
24	0503030958	2"X15.7"X0.3" COMPRESSION SPRING		02	02	02	02
25	0503030408	2X2X390 HOSE		01	01	01	01
26	0503030156	2" HOSE CLAMP		01	01	01	01
27	0502010890	SPRING ROD SUPPORT		01	01	01	01



PST2 - 08/09/10/12 LINES
D 46/56 FERTILIZER ROW ASSEMBLY

Page 18
0909091104

Item	Code	Description	See page	08	09	10	12
28	0502010891	SPRING CHOCK SUPPORT VARON		01	01	01	01
29	0503010395	1/2" X 1-1/4" BOLT		02	02	02	02
30	0503010920	1/2" X 1.1/2" BOLT		02	02	02	02
31	0511018007	1" X 0.5" X 0.5" PIVOT BUSHING		02	02	02	02




Item	Code	Description	See page	08	09	10	12
00	0501047273	LONG RIGHT DDD FERTILIZER ROW ASSY		01			
00A	0501047274	LH LONG DDD FERTILIZER ROW ASSY			01		
00B	0501047271	RH SHORT DDD FERTILIZER ROW ASSY				01	
00C	0501047272	LH SHORT DDD FERTILIZER ROW ASSY					01
01	0501068002	ROW FIXER SUPPORT		01	01	01	01
02	0501068269	ROW LONG ARM		01	01		
03	0501068268	ROW SHORT ARM				01	01
04	0503011411	1/2" X 5-1/2" BOLT		03	03	03	03
05	0503010019	1/2" SPRING WASHER		04	04	04	04
06	0503010060	1/2" NUT		04	03	04	03
07	0503011399	M16 X 1,5 X 50 BOLT		02	02	02	02
08	0501010962	1" X 0.6" X 0.5" PIVOT BUSHING		02	02	02	02
09	0501010301	FLAT WASHER		04	04	04	04
10	0503011400	M16 X 0.6" NUT		02	02	02	02
11	0501050748	15" X 15" RIGHT FERT UNAL-DD ASSY		01	01		
12	0501050749	15" X 15" LEFT FERT UNAL-DD ASSY			01	01	
13	0503010547	1/2" X 4" BOLT		01	01	01	01
14	0511013333	SPACING PLATE		02	02	02	02
15	0511016400	FERTILIZER SPRING GUIDE FIXER PIN		01	01	01	01
16	0503010257	1/8" X 1" COTTERPIN		01	01	01	01
17	0501067365	PRING ROD		01	01	01	01
18	0501064686	SPRING ROD		01	01	01	01
19	0502040157	TRIP SPRING GUIDE LOCK BUSHING		02	02	02	02
20	0503010834	1/2 X 1 BOLT		04	04	04	04
21	0501011090	FLAT WASHER		02	02	02	02
22	0503030960	1"X15.7"X0.1" COMPRESSION SPRING		02	02	02	02
23	0503030959	1.6"X15.7"X0.2" COMPRESSION SPRING		02	02	02	02
24	0503030958	2"X15.7"X0.3" COMPRESSION SPRING		02	02	02	02
25	0503030408	2X2X390 HOSE		01	01	01	01
26	0503030156	2" HOSE CLAMP		01	01	01	01
27	0502010890	SPRING ROD SUPPORT		01	01	01	01




PST2 - 08/09/10/12 LINES
D 46A/56A FERTILIZER ROW ASSEMBLY


Item	Code	Description	See page	08	09	10	12
28	0502010891	SPRING CHOCK SUPPORT VARON		01	01	01	01
29	0503010395	1/2" X 1-1/4" BOLT		02	02	02	02
30	0503010920	1/2" X 1.1/2" BOLT		02	02	02	02
31	0511018007	1" X 0.5" X 0.5" PIVOT BUSHING		02	02	02	02
32	0503031050	CURVED CONDUCTOR		01	01	01	01
33	0503010246	CLAMP		01	01	01	01
34	0501051570	POINT RIGHT SCARIFIER ARM ASSY		01	01	01	01
35	0501051571	POINT LEFT SCARIFIER ARM ASSY		01	01	01	01



Item	Code	Description	See page	DIR.	ESQ.
00	0501046976	RIGHT 16" BLADE DISC ASSY		01	
00A	0501047718	LH 16" BLADE DISC ASSY			01
01	0502010804	RH BLADE DISC SUBSOILER SPINDLE SUP		01	
02	0502010620	LH BLADE DISC SUBSOILER SPINDLE SUP			01
03	0521010676	5/8" UNC X 6.4" FASTENER		01	01
04	0501010301	FLAT WASHER		02	02
05	0503010027	5/8" SPRING WASHER		02	02
06	0503010013	5/8" NUT		02	02
07	0502011474	BLADE DISC SUPPORT		01	01
08	0501011031	3/4" X 1-1/2" BOLT		01	01
09	0511018463	RIGHT SUPPORT ARM		01	01
10	0511018464	LEFT SUPPORT ARM		01	01
11	0503010038	3/16 X 2 COTTERPIN		02	02
12	0501067735	BLADE DISC REGULATOR ARM		01	01
13	0503010361	SPRING PIN		01	01
14	0503010002	1800 GREASE FITTING		01	01
15	0501067323	SPRING REGULATOR		01	01
16	0521010452	SLEEVE		01	01
17	0501010370	3/4" X 5-1/2" BOLT		01	01
18	0503010023	3/4" SPRING WASHER		03	03
19	0503010014	3/4" NUT		05	05
20	0502020393	SPRING UPPER SUPPORT		01	01
21	0503030478	2.7"X7.9"X0.5" COMPRESSION SPRING		01	01
22	0501051172	16 SHOT BLADE DISC	21	01	01
23	0511018481	BLADE DISC 3/4" AXLE LOCK		02	02



Item	Code	Description	See page	QT
00	0501051172	16 SHOT BLADE DISC	21	01
01	0603023009	16" X 0.2" FLAT PLAIN DISC		01
02	0503010215	30205 BEARING		02
03	0501068582	7/8" UNF WITH DUST CLOAK NUT		01
04	0503010213	SEAL 30205		02
05	0503010365	NUT		06
06	0503010179	5/16" ZN SPRING WASHER		06
07	0503010337	5/16" NUT		06
08	0501068216	DUST CLOAK 3/4" DC AXLE		01
09	0503010691	1/4" GREASE FITTING		01
10	0502011279	DISC HUB		01
11	0501013839	WASHER		01



Item	Code	Description	See page	08	09	10	12
00	0501046500	MIDDLE RH DDD SEED ROW ASSY		01			
00A	0501046501	MIDDLE LH DDD FERTILIZER ROW ASSY			01		
00B	0501046506	LONG RH DDD SEED LINEA ASSY				01	
00C	0501046507	LH DDD LONG SEED ROW ASSY					01
01	0501064390	MIDDLE ROW ARM		01	01		
02	0501064391	LONG ROW ARM				01	01
03	0511011982	RIGHT SIDE BASE		01	01		
04	0511013474	LEFT SIDE BASE		01	01		
05	0511014152	LONG RIGHT SIDE BASE				01	01
06	0511014151	LONG LEFT SIDE BASE				01	01
07	0503010752	1/2" X 3.1/2" BOLT		03	03	03	03
08	0503010019	1/2" SPRING WASHER		09	09	09	09
09	0503010060	1/2" NUT		11	11	11	11
10	0503010848	5/16" X 3.1/2" BOLT		02	02	02	02
11	0503010179	5/16" ZN SPRING WASHER		08	08	08	08
12	0503010337	5/16" NUT		07	07	07	07
13	0502011212	SEED BOX FIXING BASE		01	01	01	01
14	0503010849	3/8" X 1-1/2" BOLT		01	01	01	01
15	0503010025	3/8" SPRING WASHER		02	02	02	02
16	0503010026	3/8" NUT		01	01	01	01
17	0503010674	7/16" X 3-1/4" BOLT		01	01	01	01
18	0503010180	7/16" SPRING WASHER		03	03	03	03
19	0503010244	7/16" NUT		03	03	03	03
20	0502011261	LOCK SUPORT		01	01	01	01
21	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02	02	02	02
22	0501013354	FLAT WASHER		03	03	03	03
23	0502011413	18Z CONICAL GEAR		01	01	01	01
24	0511011293	1/2" X 52.3" AXLE HEX		01	01		
25	0511014145	1/2" X 65.8" HEX AXLE				01	01
26	0501013352	FLAT WASHER		02	02	02	02
27	0502011296	1/2 HEX AXLE BEARING SLEEVE		01	01	01	01




SEED ROW


0909091107

Item	Code	Description	See page	08	09	10	12
28	0502011505	18Z CONICAL GEAR		01	01	01	01
29	0502011411	10Z CONICAL GEAR		01	01	01	01
30	0503010257	1/8" X 1" COTTERPIN		01	01	01	01
31	0511017302	FLAT WASHER		01	01	01	01
32	0502010573	LOWER BEARING SEMI		01	01	01	01
33	0502010426	UPPER BEARING SEMI		02	02	02	02
34	0503010479	BOLT		04	04	04	04
35	0501051060	RIGHT 15" X 15" SEED UNAL DOUB-DISC ASSY		01	01		
36	0501051061	LH 15"X15" SEED UNAL DOUB-DISC ASSY			01	01	
37	0503010676	7/16" X 3-3/4" BOLT		01	01	01	01
38	0503010850	BOLT 7/16 UNC X 3 CS G.5 ZN		01	01	01	01
39	0521010672	5/8" X 4.9" X 4.4" FASTENER		01	01	01	01
40	0503010027	5/8" SPRING WASHER		02	02	02	02
41	0503010013	5/8" NUT		03	03	03	03
42	0501011752	5/16" X 3" BOLT		01	01	01	01
43	0501010694	8.5 X 18 X 1.5 FLAT WASHER		05	05	05	05
44	0503010499	5/16" UNC BUTTERFLY NUT		01	01	01	01
45	0501050076	SEED SISTEM	23	01	01	01	01
46	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01	01	01	01
47	0503010547	1/2" X 4" BOLT			01	01	
48	0501065652	DEPH WHEELS AXLE BEARING			01	01	
49	0501016909	PIVOT SUPPORT COVER		01	01	01	01
50	0503010298	1/4" X 1/2" BOLT		02	02	02	02
51	0503010143	1/4" SPRING WASHER		02	02	02	02
52	0501062628	SPINDLE GUIDE		01	01	01	01
53	0521010641	COUPLING SHAFT		01	01	01	01
54	0501011090	FLAT WASHER		01	01	01	01
55	0503030187	1" X 19" X 4" COMPRESSION SPRING		01	01	01	01
56	0503030184	1.6" X 19" X 6" COMPRESSION SPRING		01	01	01	01
57	0503030188	2" X 19" X 8" COMPRESSION SPRING		01	01	01	01
58	0502040725	SPRING BUSHING LOCK GUIDE		02	02	02	02
59	0503010834	1/2 X 1 BOLT		02	02	02	02
60	0503010004	1890 GREASE FITTING		02	02	02	02
61	0503010691	1/4" GREASE FITTING		02	02	02	02
62	0501050932	DEPTH CONTROL WHEELS ASSEMBLY		01	01	01	01
63	0503030482	SEED SOCKET		01	01	01	01
64	0502010890	SPRING ROD SUPPORT		01	01	01	01
65	0502010891	SPRING CHOCK SUPPORT VARON		01	01	01	01
66	0503010395	1/2" X 1-1/4" BOLT		03	03	03	03
67	0503010920	1/2" X 1.1/2" BOLT		01	01	01	01
68	0502010705	DEPTH WHEEL SUPPORT		01	01	01	01
69	0511011983	SOYBEAN ESTABILIZER BAR			01	01	
70	0501013714	STABILIZER BAR		01	01		
71	0511013243	SUPPLEMENT ESTABILIZER BAR		01	01	01	01
72	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01	01	01	01
75	0503010003	1845 GREASE FITTING		01	01	01	01
76	0501050927	PRESS WHEELS ASSEMBLY	28	01	01	01	01
77	0501050932	DEPTH CONTROL WHEELS ASSEMBLY		01	01	01	01


SEED SYSTEM




Item	Code	Description	See page	08	09	10	12
01	0503010179	5/16" ZN SPRING WASHER		08	08	08	08
02	0503010337	5/16" NUT		07	07	07	07
03	0503010025	3/8" SPRING WASHER		02	02	02	02
04	0502011418	40Z CONICAL GEAR		01	01	01	01
05	0511018700	AXLE		01	01	01	01
06	0501010694	8.5 X 18 X 1.5 FLAT WASHER		05	05	05	05
07	0502020324	SEED BOX SUPPORT		01	01	01	01
08	0503030407	SEED BOX ASSY		01	01	01	01
09	0503030406	SEED BOX COVER		01	01	01	01
10	0503010240	5/16" X 3/4" BOLT		04	04	04	04
11	0501050077	SEED DISTRIB ASSY W/ SIMPLE PULLEY		01	01	01	01
12	0501110266	FASTENER		01	01	01	01
13	0503010675	5/16" X 2.1/4" BOLT		01	01	01	01
14	0502010408	SEED DISC LOWER TRAIL		01	01	01	01
15	0521010536	0.3" X 3.8" COUPLING SHAFT		01	01	01	01
16	0503010257	1/8" X 1" COTTERPIN		02	02	02	02
17	0502020333	BEAN SEED DISC		01	01	01	01
18	0502020407	BEAN SEED DISC		01	01	01	01
19	0502020518	CORN DISC		01	01	01	01
20	0502020519	CORN DISC		01	01	01	01
21	0502020327	DISC WITHOUT HOLE		01	01	01	01
22	0502020329	SOYBEAN DISC		01	01	01	01
23	0501013355	DISC SEAT		01	01	01	01
24	0501013356	DISC SEAT		01	01	01	01
25	0511017897	DISC SEAT		01	01	01	01
26	0511013590	HEX STUD 3/8" X 3/8"		01	01	01	01
27	0511013494	DEFLECTOR		01	01	01	01
28	0503010209	3/8" UNC BUTTERFLY NUT		01	01	01	01
29	0511015098	FLAT WASHER		01	01	01	01



Item	Code	Description	See page	DIR.	ESQ.
00	0501051060	RIGHT 15" X 15" SEED UNAL DOUB-DISC ASSY		01	
00A	0501051061	LH 15"X15" SEED UNAL DOUB-DISC ASSY			01
01	0502011184	15" X 15" DOUBLE DISC SUPPORT		01	
02	0502011183	15"X15" LW SEED UNAL DOUB-DISC SUPP			01
03	0502011275	DOBLE DISC BOX		02	02
04	0503010598	30204 BALL BEARING		04	04
05	0511011344	3/4" UNC RIGHT DDD HUB AXLE		01	01
06	0511011345	3/4" UNC LH DDD HUB AXLE		01	01
07	0503011112	SEAL 02376-BRG		02	02
08	0511011927	DUST CLOAK		02	02
09	0503030282	3/4" CASTLE NUT		02	02
10	0503010140	1/8" X 3/4" COTTERPIN		02	02
11	0502011265	DD PROTECCION COVER		02	02
12	0603022042	13" X 0.12" PLAIN COULTER BLADE		02	02
13	0503010546	5/16" X 7/8" BOLT		12	12
14	0503010337	5/16" NUT		12	12
15	0501017541	RIGHT DOUBLE DISC SCRAPER		01	01
16	0501017542	LH DOUBLE DISC SCRAPER		01	01
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01	01
18	0501010984	FLAT WASHER		02	02
19	0503010025	3/8" SPRING WASHER		01	01
20	0503010026	3/8" NUT		01	01
21	0503030482	SEED SOCKET		01	01
22	0503010519	1/4" X 5/8" BOLT		06	06
23	0503010143	1/4" SPRING WASHER		06	06
24	0503030757	2.9" X 2" X 0.02" JOINT		02	02
25	0511015098	FLAT WASHER		02	02



Item	Code	Description	See page	QT
00	0501052978	RIGHT 15" X 15" DOUBLE DISC		01
00.	0501052979	LEFT 15" X 15" DOUBLE DISC		01
01	0502011184	15" X 15" DOUBLE DISC SUPPORT		01
02	0502011183	15"X15" LW SEED UNAL DOUB-DISC SUPP		01
03	0502011930	DOUBLE DISC COULTER BOX		02
04	0503010598	30204 BALL BEARING		04
05	0521019154	RIGHT DOUB DISC HUB		01
06	0521019148	LEFT DOUBLE DISC HUB		01
07	0503011112	SEAL 02376-BRG		02
08	0511011927	DUST CLOAK		02
09	0503030282	3/4" CASTLE NUT		02
10	0503010257	1/8" X 1" COTTERPIN		02
11	0521019178	COVER DEPTH		02
12	0603022042	13" X 0.12" PLAIN COULTER BLADE		02
13	0503010546	5/16" X 7/8" BOLT		12
14	0503010337	5/16" NUT		12
15	0501017541	RIGHT DOUBLE DISC SCRAPER		01
16	0501017542	LH DOUBLE DISC SCRAPER		01
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
18	0501010984	FLAT WASHER		02
19	0503010025	3/8" SPRING WASHER		01
20	0503010026	3/8" NUT		01
21	0503030482	SEED SOCKET		01
22	0503013758	1/4" X 1-1/2" BOLT		06
23	0503010143	1/4" SPRING WASHER		06
24	0503030757	2.9" X 2" X 0.02" JOINT		02
25	0511015098	FLAT WASHER		02




Item	Code	Description	See page	QT
00	0501051094	SEED DISTRIB ASSY WITH DOUB PULLEY		01
00A	0501050077	SEED DISTRIB ASSY W/ SIMPLE PULLEY		01
01	0503030381	SEED DISTRIBUTOR BOX		01
02	0502010447	TRIGGER		02
03	0501013467	KEY AXLE		01
04	0503030378	0.4" X 1.1" X 0.03" SPRING		03
05	0501013466	KEY LIMITER AXLE		01
06	0501051119	DOUBLE PULLEY ROCKER'S		01
06A	0503031129	DOUBLE PULLEY ROCKER ARM		01
06B	0503031128	5Z PLASTIC DOUB PULLEY FOR SOYBEAN		02
06C	0503031130	PIN OF THE PULLEY		01
06D	0503011853	503050 CLAMPING RING (FOR HOLE)		01
07	0501013468	ROCKER ARM AXLE, OF THE PULLEY		01
08	0503030377	SCRAPER		01
09	0501050120	LARGER WALKING BEAM ASSY		01
09A	0503030379	LARGER ROCKER ARM		01
09B	0502060001	PLASTIC PULLEY FOR MAIZE		01
09Ba	0503030558	PULLEY 4Z CORN PLASTIC		01
09C	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		01
09D	0503010669	FLAT WASHER		01
09E	0503010667	3/16" NUT		02
10	0502020584	BEAN SEED DISC 64 HOLE OBLONG		01
10A	0502020585	COTTON SEED DISC 64 HOLE OBLONG		01
11	0502020351	CORN SEED DISC 24 HOLE		01
11A	0502020366	CORN SEED DISC 24 HOLE		01
11B	0502020331	BEAN SEED DISC 26 HOLE OBLONG		01
11C	0502020408	BEAN SEED DISC 38 HOLE OBLONG		01
11D	0502020353	SORGO BEET SEED DISC 40 HOLE		01
11E	0502020346	RICE SEED DISC 40 OBLONG		01
11F	0502020560	SUNFLOWER SEED DISC 28 OBLONG		01
11G	0502020554	SUNFLOWER SEED DISC 28 OBLONG		01




PST2 - 08/09/10/12 LINES
SEED DISTRIBUTOR ASSEMBLY

Item	Code	Description	See page	QT
11H	0502020340	DISC WITHOUT HOLE		01
11I	0502020367	DISC WITHOUT HOLE		01
11J	0502020328	SOYBEAN SEED DISC 34 OBLONG		01
11K	0503031678	DISC WITHOUT HOLE		01
11L	0502020327	DISC WITHOUT HOLE		01
11M	0503031677	DISC WITHOUT HOLE		01
11N	0502020583	PEANUT SEED DISC 20		01
11O	0502020419	COTTON SEED DELINTED 40		01
11P	0502020407	BEAN SEED DISC		01
11Q	0502020333	BEAN SEED DISC		01
12	0511017897	DISC SEAT		01


DEPTH WHEEL




Item	Code	Description	See page	QT
01	0501050421	HUB DEPTH REGULATOR ASSY		01
02	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		02
03	0521010832	RIM FLANGE		04
04	0503010358	5/16" X 5/8" BOLT		08
05	0503010179	5/16" ZN SPRING WASHER		08
06	0503010337	5/16" NUT		08
07	0503010298	1/4" X 1/2" BOLT		10
08	0503010143	1/4" SPRING WASHER		10
09	0503010144	1/4" NUT		10



Item	Code	Description	See page	QT
00	0501050927	PRESS WHEELS ASSEMBLY	28	01
01	0501050882	PRESS WHEEL ASSY		02
01A	0501068827	PRESS RIM SEMI		02
01B	0501068828	PRESS RIM SEMI		02
01C	0511017891	V PRESS WHEEL AXLE		02
01D	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		02
01E	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		12
01F	0503010179	5/16" ZN SPRING WASHER		12
01G	0503010337	5/16" NUT		12
01H	0503010004	1890 GREASE FITTING		02
01I	0503011763	6203 BALL BEARING		04
01J	0503010272	SEAL 00715-BA		02
01K	0503011166	501017 CLAMPING RING (FOR AXLE)		02
02	0501064232	PRESS WHEELS FIXER ASSY		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		02
04	0501013798	LEFT ARM		01
05	0501013799	RIGHT ARM		01
06	0503010849	3/8" X 1-1/2" BOLT		02
07	0503010025	3/8" SPRING WASHER		02
08	0503010026	3/8" NUT		02
09	0501069979	SPRING REGULATOR		01
10	0521013310	0.5" X 3" COUPLING SHAFT		01
11	0503010300	5/32" X 1" COTTERPIN		01
12	0502040725	SPRING BUSHING LOCK GUIDE		02
13	0503030399	1"X5.1"X 0.2" COMPRESSION SPRING		01
14	0501018535	1/2 X 1 BOLT		02
15	0521010512	0.5" X 0.7" X 1.6" SLEEVE INTER		01
16	0503010479	BOLT		01
17	0503010019	1/2" SPRING WASHER		01
18	0503011336	1/2" HEX SELF ADJUSTING NUT		01



Item	Code	Description	See page	QT
00	0501050464	CONCAVE PRESS WHELL ASSEMBLY	29	01
01	0501050084	CONCAVE PRESS WHELL		01
01A	0502020140	HUB		02
01B	0503010272	SEAL 00715-BA		02
01C	0503010269	6204 BALL BEARING		02
01D	0501015883	COMPACT WHEEL AXLE		01
01E	0503030143	3.3" X 1.9" X 0.1" JOINT		02
01F	0503010691	1/4" GREASE FITTING		02
01G	0501015919	PRESS WHEEL RIM		02
01H	0503010743	1/4" X 1-1/4" BOLT		05
01I	0503010144	1/4" NUT		05
01J	0503030400	DEPTH CONTROL WHEEL RUBBER BAND		01
01K	0503010298	1/4" X 1/2" BOLT		05
01L	0503010143	1/4" SPRING WASHER		10
01M	0503013814	1/4" NC LOCKNUT		05
02	0501013655	RIGHT ARM		01
03	0501013656	LEFT ARM		01
04	0503010019	1/2" SPRING WASHER		05
05	0503010060	1/2" NUT		05
06	0501069979	SPRING REGULATOR		01
07	0521013310	0.5" X 3" COUPLING SHAFT		01
08	0503010071	3/16" X 1" COTTERPIN		01
09	0503010479	BOLT		01
10	0502040157	TRIP SPRING GUIDE LOCK BUSHING		02
11	0503030399	1"X5.1"X 0.2" COMPRESSION SPRING		01
12	0503010834	1/2 X 1 BOLT		02




Item	Code	Description	See page	QT
00	0501050932	DEPTH CONTROL WHEELS ASSEMBLY		01
01	0502010705	DEPTH WHEEL SUPPORT		01
02	0501050421	HUB DEPTH REGULATOR ASSY		01
02A	0501064772	DEPTH REGULATOR ARM		01
02B	0502011907	DEPTH CONTROL WHEEL HUB		02
02C	0503010269	6204 BALL BEARING		02
02D	0521010489	SLEEVE SPACER		02
02E	0503011105	SEAL RING		01
02F	0503010689	SEAL 00763-BR		02
02G	0503010878	5/8" SELF ALIGNING NUT		02
02H	0503030757	2.9" X 2" X 0.02" JOINT		02
02I	0521019178	COVER DEPTH		02
02J	0503010691	1/4" GREASE FITTING		03
03	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		02
04	0521010832	RIM FLANGE		04
05	0503010178	5/16" X 7/8" BOLT		08
06	0503010179	5/16" ZN SPRING WASHER		14
07	0503010337	5/16" NUT		08
08	0503010298	1/4" X 1/2" BOLT		16
09	0503010143	1/4" SPRING WASHER		16
10	0503010144	1/4" NUT		16
11	0501018535	1/2 X 1 BOLT		03
12	0501069979	SPRING REGULATOR		01
13	0521013310	0.5" X 3" COUPLING SHAFT		01
14	0503010300	5/32" X 1" COTTERPIN		01
15	0503010479	BOLT		01
16	0521010512	0.5" X 0.7" X 1.6" SLEEVE INTER		01
17	0503010019	1/2" SPRING WASHER		01
18	0503010060	1/2" NUT		01
19	0502040725	SPRING BUSHING LOCK GUIDE		02
20	0503030399	1"X5.1"X 0.2" COMPRESSION SPRING		01



PST2 - 08/09/10/12 LINES
DEPTH CONTROL WHEEL ASSEMBLY

Item	Code	Description	See page	QT
21	0501013798	LEFT ARM		01
22	0501013799	RIGHT ARM		01
23	0501064232	PRESS WHEELS FIXER ASSY		01
24	0503010571	1/4" X 1.1/2 COTTERPIN		02
25	0503010849	3/8" X 1-1/2" BOLT		02
26	0503010025	3/8" SPRING WASHER		02
27	0503010026	3/8" NUT		02
28	0501054883	PRESS WHEELS ASSY		02
28A	0501068827	PRESS RIM SEMI		01
28B	0503010272	SEAL 00715-BA		01
28C	0503011763	6203 BALL BEARING		02
28D	0541010382	PRESS AXLE WHEELS		01
28E	0503012136	NUT 1/2 NF		01
28F	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		02
28G	0511065018	PRESS WHEEL RIM		01
28H	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
28I	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	08	09	10	12
01	0501042497	OPEN U ESTABILIZER	4	01	01	01	01
02	0521010572	0.9" X 2.9" COUPLING SHAFT		02	02	02	02
03	0503030085	LOCK PIN		02	02	02	02
04	0501050647	ROW MARKER DISC ASSY	5	02	02	02	02
05	0501018501	ROW MARK TURNBUCKLE		02	02	02	02
06	0501067275	ROW MARK SUPPORT		02	02	02	02
07	0503010395	1/2" X 1-1/4" BOLT		04	04	04	04
08	0501040364	HOSE SUPPORT 3/4X640 ASSY		01	01	01	01
08A	0501060409	HOSE SOPPORT ASSY		01	01	01	01
08B	0503010014	3/4" NUT		02	02	02	02
08C	0503010023	3/4" SPRING WASHER		02	02	02	02
09	0501047881	AXIS JOINT ASSY		01	01	01	01
09A	0501068989	COUPLING SHAFT		01	01	01	01
09B	0503030012	HAIR PIN		01	01	01	01
10	0502011306	6Z P 1.2" RH 1.4" GEAR		04	04	04	04
11	0502011317	10Z P 1.2" RH 1.3/8" GEAR		04	04	04	04
12	0502011322	11Z P 1.2" RH 1.3/8" GEAR		04	04	04	04
13	0502011324	12Z P 1.2" RH 1.4" GEAR		06	06	06	06
14	0502011334	14Z P 1.2" RH 1.4" GEAR		04	04	04	04
15	0502011341	16Z P 1.2" RH 0.8" GEAR		04	04	04	04
16	0503010010	1/4" X 2.1/2" COTTERPIN		04	04	04	04
17	0501018652	CORN STABILIZER BAR		03	04	04	05
18	0501061485	GUTTER P/BOÎTE METALLIQUE		04	05	06	06
19	0501080471	3/8" X 110.24" TR-TM HOSE ASSY		02	02	02	02
20	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		02	02	02	02
20A	0503011114	QUICK COUPLING PUMP		02	02	02	02
21	0501047890	1/2"UNC X2.1" X1.6" FASTENER ASSY		04	04	04	04
21A	0521010621	1/2"UNC X2.1" X1.7" FASTENER ASSY		04	04	04	04
21B	0511017302	FLAT WASHER		08	08	08	08
21C	0503010019	1/2" SPRING WASHER		08	08	08	08
21D	0503010060	1/2" NUT		08	08	08	08




SEPARATE PARTS

0909091109

Item	Code	Description	See page	08	09	10	12
22	0501065677	STRUT		02	02	02	02
23	0503010951	REDUCTION		04	04	04	04
24	0503010780	N-2050 AMENDMENT		02	02	02	02
25	0501011432	1-1/2" AND 1-5/8 GANG BOLT WRENCH		01	01	01	01
26	0503030558	PULLEY 4Z CORN PLASTIC		08	09	10	12
27	0501051570	POINT RIGHT SCARIFIER ARM ASSY		04	05	05	06
28	0501051571	POINT LEFT SCARIFIER ARM ASSY		04	04	05	06
29	0511017969	0.1" SPACING PLATE		16	18	20	24
30	0503031050	CURVED CONDUCTOR		08	09	10	12
31	0503010246	CLAMP		08	09	10	12



Item	Code	Description	See page	08	09	10	12
00	0501048194	FRONT PLATFORM SET		01			
00A	0501048197	FRONT PLATFORM SET			01		
00B	0501048198	FRONT PLATFORM SET				01	
00C	0501048199	FRONT PLATFORM SET					01
01	0501068325	FRONT PLATFORM SUPPORT		04	06	06	06
02	0521010669	5/8" X 4.33" X 3.46" HOLDER		04	06	06	06
03	0503010027	5/8" SPRING WASHER		08	12	12	12
04	0503010013	5/8" NUT		08	12	12	12
05	0511018578	LOWER UPPER FRONT PLATFORM ASSY		04			
06	0511018580	LOWER UPPER FRONT PLATFORM ASSY			04		
07	0511018581	LOWER UPPER FRONT PLATFORM ASSY				04	
08	0511018583	LOWER UPPER FRONT PLATFORM ASSY					04
09	0503010237	3/8" X 1" BOLT		08	12	12	12
10	0503010025	3/8" SPRING WASHER		08	12	12	12
11	0503010026	3/8" NUT		08	12	12	12
12	0501069590	FRONT HANDRAIL		02			
13	0501069589	FRONT HANDRAIL			02		
14	0501069588	FRONT HANDRAIL				02	
15	0501069587	FRONT HANDRAIL					02
16	0503010363	5/16" X 1" BOLT		08	08	08	08
17	0503010179	5/16" ZN SPRING WASHER		08	08	08	08
18	0503010337	5/16" NUT		08	08	08	08




Item	Code	Description	See page	QT
00	0501043422	SEED COTTON SYSTEM ASSEMBLY	33	01
01	0502020375	BOX SUPPORT SEED LINTER COTTON		01
02	0501013829	TRANSMISSION AXLE LINTER COTTON		01
03	0502010466	COTTON LINTER BEARING SEMI		01
04	0503010179	5/16" ZN SPRING WASHER		03
05	0502010462	COTTON LINTER ROTOR		01
06	0502010467	CONICAL GEAR CILINDER COTTON LINTER		01
07	0503010585	0,24" X 1.18" SPRING PIN		02
08	0503010292	0.2" X 1.6" SPRING PIN		01
09	0501010941	FLAT WASHER		01
10	0502010465	LINTER COTTON RET CYL 18Z GEAR		01
11	0501013824	FLAT WASHER		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0502010463	CONICAL GEAR 40Z COTTON LINTER		01
14	0511010126	GEAR AXLE		01
15	0502010464	COTTON LINTER TRAIL		01
16	0502010461	COTTON LINTER DISC		01
17	0501013828	COTTON LINTER MEXEDOR		02
18	0503010025	3/8" SPRING WASHER		03
19	0503010256	3/8" X 3/4" BOLT		02
20	0503010357	8 X 20 X 1 FLAT WASHER		02
21	0503010137	5/16" X 1-1/4" BOLT		02
22	0511010127	SEED SWITCH PLATE		01
23	0503010386	CABLE		01
24	0501013831	LINTER COTTON RIGHT SIDE BASE		01
25	0501013830	LINTER COTTON LEFT SIDE BASE		01
26	0503010676	7/16" X 3-3/4" BOLT		01
27	0503010180	7/16" SPRING WASHER		01
28	0503010198	7/16" NUT		01
29	0501010324	3/8" X 1-1/4" BOLT		01
30	0501013518	FLAT WASHER		01




PST2 - 08/09/10/12 LINES
SEED COTTON SYSTEM ASSEMBLY

Page 33
0501043422

Item	Code	Description	See page	QT
31	0503010026	3/8" NUT		01
32	0503011098	1/4" GREASE FITTING		01
33	0503010691	1/4" GREASE FITTING		03
34	0503030484	COTTON LINTER SOCKET		01
35	0503010363	5/16" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0502020373	PEANUT DISH		01
02	0502020371	PEANUT ROTOR		01
03	0502020372	PEANUT ROTOR GUIDE		01
04	0503010179	5/16" ZN SPRING WASHER		01
05	0501013872	5/16" X 2-3/16" BOLT		01
06	0502020362	PEANUT SEED BOX SUPPORT		01
07	0502010408	SEED DISC LOWER TRAIL		01
08	0501013790	0.33" X 4.72" PIN		01
09	0503010257	1/8" X 1" COTTERPIN		01
10	0501110033	CLAMP		01
11	0503010011	5/16" X 1/2" BOLT		01
12	0501013787	COVER PEANUT		01
13	0501013789	PEANUT SEED PROTECTION		01
14	0503010668	3/16" SPRING WASHER		01
15	0503010722	3/16" X 5/8" BOLT		01
16	0501013788	PEANUT SEED PROTECTION		01



Item	Code	Description	See page	QT
00	0501044301	8 SUBSOILER ASSEMBLY	35	01
01	0502010804	RH BLADE DISC SUBSOILER SPINDLE SUP		01
02	0502010620	LH BLADE DISC SUBSOILER SPINDLE SUP		01
03	0501013692	5/8" UNC X 162 X 112 CLAMP		01
04	0501010301	FLAT WASHER		04
05	0503010027	5/8" SPRING WASHER		02
06	0503010013	5/8" NUT		02
07	0501050582	ENX SUBSOILER SPINDLE		01
07A	0501011025	SUBSOILER SPINDLE		01
07B	0501065309	POINT SUBSOILER		01
07C	0503010734	1/2" X 2-1/2" BOLT		01
07D	0503010905	1/2" X 2-1/4" BOLT		01
07E	0503010019	1/2" SPRING WASHER		02
07F	0503010060	1/2" NUT		02
07G	0620011001	8" X 3/16" POINT SUBSOILER		01
07H	0501011190	5/8" X 3-3/4" BOLT		01
07I	0501011026	FIXER		01
07J	0501018357	3/4" X 2" BOLT		01

HEX AXLE ASSEMBLY



Item	Code	Description	See page	08	09	10	12 L.
01	0501017440	5/8" X 60.4" HEX AXLE		01	00	00	00
01.	0501017441	5/8" X 69.3" HEX AXLE		01	00	00	00
02	0511010749	5/8" X 71.8" HEX AXLE		00	01	00	00
02.	0511010750	5/8" X 79.1" HEX AXLE		00	01	00	00
03	0501017442	5/8" X 76.1" HEX AXLE		00	00	01	00
03.	0501017443	5/8" X 85" HEX AXLE		00	00	01	00
04	0501017432	5/8" X 95.8" HEX AXLE		00	00	00	01
04.	0501017433	5/8" X 2660" HEX AXLE		00	00	00	01
05	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8		02	02	02	02
06	0501110036	HEX AXLE RIGHT BEARING ASSY		01	01	01	01
07	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"		01	01	01	01
08	0501053788	Q3/4" FASTENER AXLE ASSY		02	02	02	02
08A	0521010691	AXLE FASTENER		02	02	02	02
08B	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02	02	02	02
08C	0511017303	FLAT WASHER		02	02	02	02
08D	0503010143	1/4" SPRING WASHER		02	02	02	02
08E	0503010144	1/4" NUT		02	02	02	02
09	0503010363	5/16" X 1" BOLT		04	04	04	04
10	0503011176	5/16" SPRING WASHER		04	04	04	04
11	0503010337	5/16" NUT		04	04	04	04
12	0501017558	5/8" HEX AXLE BEARING SUPPORT		02	02	02	02
13	0503010920	1/2" X 1.1/2" BOLT		04	04	04	04
14	0511017302	FLAT WASHER		04	04	04	04
15	0503010019	1/2" SPRING WASHER		04	04	04	04
16	0503010060	1/2" NUT		04	04	04	04
17	0502011299	BUSHING GEAR		02	02	02	02
18	0502011314	8Z P 1.1/4" RH1.4" GEAR		02	02	02	02
19	0521010530	COUPLING SHAFT		02	02	02	02
20	0503010140	1/8" X 3/4" COTTERPIN		02	02	02	02



MARCHESAN

Technical Publications | Elaboration and Revision
JOSÉ DOMINGOS GASPARI

www.marchesan.com.br

