

PARTS CATALOG

SEEDERS

SDA RT

Code: 0501090846



Series: S-0407

Rev.: 00


Date Rev.: FEVEREIRO/2008

ORIGINAL PARTS
TATU



INDEX

0909093012	SEEDERS	1
0511046009	ESTABILIZER HYDRAULIC CYLINDER	2
0909093013	ROW MARKER FIXER ASSY SDART 17	3
0511040203	1.5" X 2.5" X 19" X 9" HYDRAULIC CYLINDER	4
0501054886	ROW MARKER DISC	5
0909093014	TRANSMISSION SDA RT S-0407	6
0511041210	1.75" X 3.4" X 17.6" X 7" HYDRAULIC CYLINDER	7
0909093015	RH/LH TRANSMISSION DRIVING	8
0501057728	GEAR BOX ASSY	9
0909093017	CARRYNG-WHEELS ASSY	10
0909093016	SEED FERTILIZER ROW ASSY	11
0909093018	DDD 15 X 15 RIGHT/LEFT F260	12
0909090136	IRON PRESS WHEEL	13
0511046173	BOX FERTILIZER SEED ASSY	14
0909093019	FINE SEED BOX ASSY SDA RT 17	15
0501057748	HECTARE ELECTRONIC SET	16
0909093020	HYDRAULIC CIRCUIT	17




Item	Code	Description	QT
01	0511068816	FRAME SDA RT17	01
02	0502020514	BLOCK 3.7" X 3.4" X 8.7"	13
03	0531010488	COUNTERBALANCE LATERAL COVER	02
04	0503010237	3/8" X 1" BOLT	04
05	0503010025	3/8 SPRING WASHER	19
06	0503010026	3/8" NUT	19
07	0511068787	RIGHT PLATFORM	01
08	0511068788	LEFT PLATFORM	01
09	0503010849	3/8" X 1-1/2" BOLT	10
10	0501010984	FLAT WASHER	16
11	0511068756	STAIR SUPPORT	01
12	0503010920	1/2" X 1.1/2" BOLT	14
13	0511017302	FLAT WASHER	06
14	0503010019	1/2" SPRING WASHER	14
15	0503010060	1/2" NUT	14
16	0511068812	LADDER	01
17	0531018627	0.5" X 1" X 0.2" SLEEVE	02
18	0511068758	LADDER LOCK	01
19	0503010257	1/8" X 1" COTTERPIN	01
20	0511068808	RIGHT HANDRAIL	01
21	0511068810	LEFT HANDRAIL	01
22	0503013220	REAR HEADLIGHT ASSY	02
23	0503010803	3/16" X 3/4" BOLT	04
24	0503010667	3/16" NUT	04
25	0503014630	ELECTRIC THREAD	01
26	0503014595	CONNECTOR 6 VIAS FEMALE / MALE	02
27	0511068842	HOIST SUPPORT	01
28	0501010100	5/8 UNC X 2 C S G.5 BOLT	04
29	0503010027	SPRING WASHER	04
30	0503010013	5/8" NUT	04
31	0503014251	HOIST	01
32	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	03
33	0503014275	LOCK RIBBON	01




SDA RT
SEEDERS


Item	Code	Description	QT
34	0501049704	DRAWBAR ASSY	01
34A	0511062123	DRAWBAR	01
34B	0511062245	TRACTOR HITCH ASSY	01
34C	0521010681	BUSHING COUPLING BODY	01
34D	0521010639	COUPLING SHAFT	01
34E	0503010571	1/4" X 1.1/2 COTTERPIN	01
34F	0503010002	1800 GREASE FITTING	01
34G	0541016440	DOOR HOSE	01
34H	0503010237	3/8" X 1" BOLT	02
35	0511014394	1.25" X 4.13" COUPLING SHAFT	02
36	0503030085	LOCK PIN	03
37	0551016178	CYLINDER LOCK	01
38	0511046009	ESTABILIZER HYDRAULIC CYLINDER	01
39	0551016177	COUPLING SHAFT	01
40	0531010490	AXLE 1.12" X 8"	01
41	0503010523	1/4" X 2" COTTERPIN	02
42	0511068744	PLOUGH SUPPORT	02
43	0501011075	PIN	02
44	0503030012	HAIR PIN	02
45	0503060100	HAND BOOK COMPARTMENT	01
46	0503010358	5/16" X 5/8" BOLT	01
47	0501010694	FLAT WASHER	02
48	0503010179	SPRING WASHER	01
49	0503010337	5/16" NUT	01
50	0503010267	NYLON CLAMP	01
51	0501047881	COUPLING SHAFT	01
51A	0501068989	COUPLING SHAFT	01
51B	0503031035	HAIR PIN	01
52	0501047884	0.98" ROD STOP	02
53	0501047885	ROD STOP	02
54	0501047886	ROD STOP	02
55	0501047887	ROD STOP	02
56	0501047888	ROD STOP	02
57	0501047889	1.96" ROD STOP	02




Item	Code	Description	QT
01	0511045996	HYDR CYLINDER	01
02	0511068781	CYLINDER CASE	01
03	0551016040	EXTENDING BODY	01
04	0502010993	DETACHABLE COVER	01
05	0502010781	RING SUPPORT	01
06	0503010761	D-1750 SCRAPER RING	01
07	0503010990	GASKET	01
08	0503010949	W2-2000-500 PK RING G.E	01
09	0503011060	8-336 BACK-UP RING	01
10	0503010976	2-336 N 3006-9B O'RING	01
11	0503010042	2-214 N 3006-9B O'RING	01
12	0502010843	1.8" X 3.4" PISTON	01
13	0503010170	PACKING 3120 2750	02
14	0503010948	W4-3346-590 PK RING G.E	01
15	0503010063	1" SELF-ALIGNING NUT	01
16	0501061056	RH LOCKNUT WITH HANDLER	01
17	0501110262	245 ADJUSTMENT NUT	01
18	0511068786	TURNBUCLE	01
19	0503010002	1800 GREASE FITTING	02




Item	Code	Description	QT
01	0511068745	RH ROW MARKER ARM SUPPORT	01
02	0511068746	LH ROW MARKER ARM SUPPORT	12
03	0501010098	HEX BOLT 3/4 UNC X 2 C S G.5 ZN	12
04	0503010023	SPRING WASHER	12
05	0503011255	3/4" LOCK NUT	12
06	0501069470	ROW MARKER ARM	02
07	0503011067	5/8" X 2-1/2" BOLT	04
08	0521010479	SLEEVE ARTICULATION	04
09	0501012140	FLAT WASHER	04
10	0503010027	SPRING WASHER	04
11	0503012795	5/8" HEX SELF ADJUSTING NUT	04
12	0511040203	1.5" X 2.5" X 19" X 9" HYDRAULIC CYLINDER	02
13	0521010574	C0.9" X 3.3" COUPLING SHAFT	02
14	0503010571	1/4" X 1.1/2" COTTERPIN	02
15	0511015779	1" X 4.2" AXLE	02
16	0503010523	1/4" X 2" COTTERPIN	02
17	0503011070	BEATER	02
18	0503010019	1/2" SPRING WASHER	02
19	0503010060	1/2" NUT	02
20	0501069643	890 TURNBUCKLE	02
21	0503011267	5/8" X 1.1/2" BOLT	04
22	0501054886	ROW MARKER DISC	02
23	0511017592	11.8" X 1.6" TRANSPORT LOCK	02
24	0501068994	0.3" X 3.1" LOCK PIN	02
25	0503030168	HAIR PIN	02



Item	Code	Description	QT
01	0511062810	2.5" X 15" CYLINDER CASE	01
02	0501065662	HYDRAULIC CYLINDER TURNBUCKLE	01
03	0502010471	MOBILE COVER	01
04	0502010780	RING SUPPORT	01
05	0503010163	D-1500 SCRAPER RING	01
06	0503010989	1870-1500-375-B GASKET	01
07	0503010970	W1-1650-500 PK O'RING G.E	01
08	0503011058	8-330 BACK-UP RING	01
09	0503010161	2-330 N 3006 9B O'RING	01
10	0503010285	2-222 N 3006-9B O'RING	01
11	0502010783	1.5" X 2.5" PISTON	01
12	0503010160	2500 2000 GASKET	02
13	0503010973	W2-2500-500 PK O'RING G.E	01
14	0503010063	1" SELF-ALIGNING NUT	01
15	0503030384	CON N-001 PLUG	02
16	0501032666	HYDRAULIC CYLINDER REPAIR KIT	01



Item	Code	Description	QT
01	0501066800	ROW MARKER DISC AXLE ASSY	01
02	0502011907	DEPTH CONTROL WHEEL HUB	01
03	0602023094	16" X 0.2" NOTCHED DISC BLADE	01
04	0503010269	6204 BALL BEARING	02
05	0501013636	SPACING SLEEVE	01
06	0503010689	SEAL 00763-BR	01
07	0503011105	SEAL RING	01
08	0503030757	2.9" X 2" X 0.02" JOINT	01
09	0521019178	COVER DEPTH	01
10	0503011441	SPRING WASHER	03
11	0503014729	1/4" UNF X 1/2" BOLT	03
12	0503010878	5/8" SELF ALIGNING NUT	01
13	0503010691	1/4" GREASE FITTING	01
14	0503010358	5/16" X 5/8" BOLT	04
15	0503011444	SPRING WASHER	04
16	0503010337	5/16" NUT	04
17	0503810023	PRESSURE WASHER	01
18	0503010014	3/4" NUT	01
19	0501069226	ROW MARKER ROD STOP	01
20	0501011778	3/8" X 2-1/2" BOLT	04
21	0503011443	SPRING WASHER	04
22	0503010026	3/8" NUT	04




Item	Code	Description	QT
01	0511062130	MIDDLEMAN BEARING RIGHT SUPPORT	01
02	0511062131	MIDDLEMAN BEARING LEFT SUPPORT	01
03	0531012149	CHOCK BEARING	04
04	0503010233	5/8" X 2-1/2" BOLT	08
05	0501012140	FLAT WASHER	12
06	0503010027	SPRING WASHER	12
07	0503010013	5/8" NUT	09
08	0551015770	CENTRAL SUPPORT BEARING	01
09	0503011082	C1/2" X 1.3/4" BOLT	05
10	0511017302	FLAT WASHER	10
11	0503010019	1/2" SPRING WASHER	15
12	0503010060	1/2" NUT	15
13	0501052968	AGRICULTURAL BEARING ASSY	05
14	0503010920	1/2" X 1.1/2" BOLT	10
15	0502011925	AXLE FIXER LOCK	02
16	0503010395	1/2" X 1-1/4" BOLT	02
17	0502011921	HYDRAULIC CYLINDER PIVOT SUPPORT	02
18	0503012334	3/4" UNC X 3.1/2" BOLT	02
19	0503010023	SPRING WASHER	02
20	0503010014	3/4" NUT	02
21	0511041210	1.75" X 3.4" X 17.6" X 7" HYDRAULIC CYLINDER	02
22	0521019210	1.25" X 10.15" AXLE	02
23	0503010523	1/4" X 2" COTTERPIN	04
24	0521019604	0.9" X 3.7" COUPLING SHAFT	02
25	0503010571	1/4" X 1.1/2" COTTERPIN	04
26	0521019208	TRANSPORT LOCK	02
27	0501068994	0.3" X 3.1" LOCK PIN	02
28	0503030168	HAIR PIN	02
29	0511068823	FRONT RATCHET CONTROL	01
30	0511068782	DISASSEMBLE RATCHET TUBE	01
31	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	11
32	0503010025	3/8 SPRING WASHER	07
33	0503010026	3/8" NUT	17




TRANSMISSION SDA RT S-0407

0909093014


Item	Code	Description	QT
34	0511068822	ROD DISASSEMBLE	01
35	0551015896	LIFT ROW AXLE	01
36	0511068825	RATCHET CONTROL SMALLER	01
37	0503010237	3/8" X 1" BOLT	03
38	0551016112	SQUARE SHAFT	01
39	0511019411	RH BEARING	02
40	0503010691	1/4" GREASE FITTING	02
41	0502010671	CENTRAL BEARING	02
42	0503010371	5/16" X 1" BOLT	04
43	0501010694	FLAT WASHER	06
44	0503010179	SPRING WASHER	04
45	0503010337	5/16" NUT	04
46	0521010691	AXLE FASTENER	02
47	0503010373	1/4" X 2" BOLT	02
48	0503010003	1845 GREASE FITTING	05
49	0503010143	SPRING WASHER	02
50	0503010144	1/4" NUT	02
51	0511068824	LARGER RATCHET CONTROL	02
52	0551016110	DISASSEMBLE RATCHET PLATE	06
53	0511045982	LH TRANSMISSION DRIVING ASSY	01
54	0551015899	GEAR BOX SEED DRIVER AXLE	01
55	0503010523	1/4" X 2" COTTERPIN	01
56	0501110292	AGRICULTURAL BEARING	04
57	0503010002	1800 GREASE FITTING	04
58	0503010300	5/32" X 1" COTTERPIN	04
59	0511068805	WHEEL TOOTH 17Z P1/2 SEM SDA RT17	01
60	0503010363	5/16" X 1" BOLT	01
61	0501057731	SEED CHAIN TENSIONER	02
61A	0551015928	CHAIN TIGHTENER AXLE	04
61B	0511068760	CHAIN TIGHTENER BODY	04
61C	0503012882	BALL BEARING	04
61D	0503012104	501015 CLAMPING RING (FOR AXLE)	04
61E	0503011945	503050 CLAMPING RING (FOR AXLE)	04
61F	0503012795	5/8" HEX SELF ADJUSTING NUT	04
62	0501057730	CHAIN TENSIONER FERTILIZER	02
62A	0551015921	RH PLATFORM BODY	02
63	0503014586	40-1 CHAIN X 174 LINK + REDECTION	01
64	0503014587	50-1 CHAIN X 75 LINK + MENDING	02
65	0501110537	FERTILIZER DRIVER AXLE	01
66	0511045981	RH TRANSMISSION DRIVING ASSY	01
67	0501057728	GEAR BOX ASSY	01
68	0501010984	FLAT WASHER	08
69	0503014585	40-1 X 189 CHAIN LINK + MENDING	01




Item	Code	Description	QT
01	0511064110	3.37" X 7" CYLINDER CASE	01
02	0521018426	1.7" X 13.7" TURNBUCLE	01
03	0502040493	CLEVIS 26,50 R41	01
04	0503011094	3/8" X 2" BOLT C C S I 12.9	01
05	0503010025	3/8" SPRING WASHER	01
06	0503010026	3/8" NUT	01
07	0502010993	DETACHABLE COVER	01
08	0502010781	RING SUPPORT	01
09	0503010761	D-1750 SCRAPER RING	01
10	0503010990	GASKET	01
11	0503010949	W2-2000-500 PK RING G.E	01
12	0503011060	8-336 BACK-UP RING	01
13	0503010976	2-336 N 3006-9B O'RING	01
14	0503010042	2-214 N 3006-9B O'RING	01
15	0502010843	1.8" X 3.4" PISTON	01
16	0503010170	PACKING 3120 2750	02
17	0503010948	W4-3346-590 PK RING G.E	01
18	0503010063	1" SELF-ALIGNING NUT	01
19	0503010003	1845 GREASE FITTING	01
20	0501031796	HYDRAULIC CYLINDER REPAIR KIT	01



Item	Code	Description	QT
00	0511045981	RH TRANSMISSION DRIVING ASSY	01
00A	0511045982	LH TRANSMISSION DRIVING ASSY	01
01	0502011996	SLLEVE FIXER	01
02	0521017590	GUIDE AXLE	01
03	0503030678	1/2"X1-1/2"BOLT	01
04	0503010060	1/2" NUT	01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING	01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER	01
07	0502011995	LH DRIVING AXLE FOLLOWER	01
08	0501019734	FLAT WASHER	02
09	0502010710	RIGHT CAM, SMALLER	01
10	0502010720	RIGHT CAM, SMALLER	01
11	0503010003	1845 GREASE FITTING	02
12	0502010711	RIGHT CAM,LARGER	01
13	0502010721	LEFT CAM,LARGER	01
14	0511068765	GEAR 24Z	01
15	0511068764	GEAR 24Z	01
16	0501019735	FLAT WASHER	01
17	0521017593	FLAT WASHER	01
18	0503010542	501045 CLAMPING RING (FOR AXLE)	01



Item	Code	Description	QT
01	0511068811	GEAR BOX SUPPORT	01
02	0551015894	DRIVEN AXLE	01
03	0551015895	DRIVEN AXLE	01
04	0511064680	FERTILIZER SIST AXLE CONE	02
05	0501056271	GEAR BOX CLOSE BEARINGONE	03
05A	0502012310	GEAR BOX CLOSE BEARING	03
05B	0503011410	ROLLER BEARING	04
06	0501056444	BEARING WITH BALL BEARING	01
06A	0502011697	BEARING OF THE GEAR BOX	01
06B	0503011105	SEAL RING	01
07	0511064536	28Z GEAR	01
08	0511060392	CHAIN TENSIONER	01
09	0501048790	AXLE WITH LINK ASSY	01
09A	0521012476	GEAR BOX LEVER AXLE	01
09B	0503031369	LINK	01
10	0503010292	0.2" X 1.6" SPRING PIN	05
11	0521018630	1.4" X SQUARE 0.8" WASHER	02
12	0503012389	1/2 BALL	02
13	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING	02
14	0503010002	1800 GREASE FITTING	01
15	0503011953	5/16" X 1" BOLT	08
16	0501010694	FLAT WASHER	08
17	0503010179	SPRING WASHER	08
18	0503010337	5/16" NUT	08
19	0503012204	40-1 CHAIN X 82 LINK + RED	01
20	0503012772	40-1 CHAIN X 80 LINK + REDECTION	01
21	0503010140	1/8" X 3/4" COTTERPIN	04
22	0503031805	11Z 1/2" GEAR	02
23	0511068757	GEAR BOX COVER	01
24	0551015918	ROD GEAR BOX LOCK SPRING	01
25	0511068759	GEAR BOX COVER SPRING	01
26	0502011758	REAR TENSIONER LEVER	01




Item	Code	Description	DIR ESQ
00	0511046142	RH CARRYING WHEELS ASSY	01 00
00A	0511046143	LH CARRYING WHEELS ASSY	00 01
01	0511068754	RH CARRYING WHEELS	01 00
02	0511068755	LEFT CARRYING WHEELS	00 01
03	0503013453	SKF 33011 ROLLER BEARING	02 02
04	0503010086	SEAL 0009B-B	02 02
05	0511069015	CARRYNG WELLS W/ FLANGE AXLE	01 01
06	0551015763	LOCK NUT M 50 X 1,5 X 25,5	01 01
07	0503014547	LOCK WASHER	01 01
08	0503014546	LOCK NUT	01 01
09	0503061680	WHEEL AND TIRE ASSY 12L	01 01
10	0511068806	WHEEL TOOTH 16Z P5/8 ROD SDA RT17	01 01
11	0503011877	0.3" X 2.4" SPRING PIN	01 01
12	0501010125	3/4" X 2-1/2" BOLT	12 12
13	0503010023	SPRING WASHER	12 12
14	0503010014	3/4" NUT	12 12
15	0511068784	DOUBLE GEAR	01 00
16	0511068783	DOUBLE GEAR	00 01
17	0503012846	6004 ROLLER BEARING	02 02
18	0503010258	501020 CLAMPING RING (FOR AXLE)	04 04
19	0501057732	CHAIN TENSIONER	01 01
19A	0551015744	CHAIN TIGHTENER AXLE	01 01
19B	0511068785	14Z GEAR	01 01
19C	0503012846	6004 ROLLER BEARING	01 01
19D	0503011184	502040 CLAMPING RING (FOR AXLE)	01 01
19E	0501012140	FLAT WASHER	01 01
19F	0503010027	SPRING WASHER	01 01
19G	0503012795	5/8" HEX SELF ADJUSTING NUT	01 01
20	0511068813	RH CHAIN COVER	01 00
21	0511068855	CHAIN COVER	00 01
22	0551016065	TENSIONER CHAIN	01 01
23	0503031806	9Z X P 5/8" GEAR	01 01
24	0503010302	501019 SEAL RING	01 01



SDA RT
CARRYNG-WHEELS ASSY

Item	Code	Description	DIR ESQ
25	0551016066	SQUARE NUT 38 R.1/2	01 01
26	0503010002	1800 GREASE FITTING	03 03
27	0503014588	50-1 CHAIN X 68 LINK + MENDING	01 00
28	0503014589	50-1 CHAIN X 65 LINK + MEDING	01 01
29	0503012655	5/8" X 2-3/8" WHEEL BOLT	08 08
30	0503010064	5/8 UNF CONIC NUT	08 08
31	0503010386	CABLE	08 08




Item	Code	Description	QT
00	0501057777	ROW LARGER SUPPORT	01
00A	0501057778	LH ROW LARGER SUPPORT	01
00B	0501057779	RH ROW SMALLER SUPPORT	01
00C	0501057780	LH ROW SMALLER SUPPORT	01
00D	0501057781	ROW LARGER SUPPORT	01
00E	0501057782	LH ROW LARGER SUPPORT	01
01	0511068707	TRIPLE DISC SUPPORT	01
02	0511064373	SMALLER TRIPLE DISC SUPPORT	01
03	0502010978	SUPPORT FIXER	01
04	0501017315	5/8" X 124 BOLT	01
05	0501012140	FLAT WASHER	01
06	0503010811	5/8" UNF SELF ADJUSTING NUT	01
07	0501057237	RIGHT 15 X 15 UNAL DOUBLE-DISC ASSY	01
08	0501057238	RIGHT 15 X 15 UNAL DOUBLE-DISC	01
09	0503010547	1/2" X 4" BOLT	02
10	0503011440	SPRING WASHER	02
11	0503010060	1/2" NUT	04
12	0511065789	FRONT PROTECTOR	01
13	0511068726	170 SPACER ROW	02
14	0511068725	170 SPACER ROW	01
15	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER	02
16	0501010937	FLAT WASHER	04
17	0502040190	SPRING FIXER SUPPORT	01
18	0521010666	5/8" UNC X 3.7" X 3" FASTENER	19
19	0503010027	SPRING WASHER	03
20	0503010013	5/8" NUT	03
21	0503010691	1/4" GREASE FITTING	01
22	0503030520	SEED SOCKET	01
23	0503030483	FERTILIZER SOCKET	01
24	0551011060	SOCKET LOCK FERTILIZER/SEED	01
25	0503014252	2" X 2" HOSE	02
26	0503031076	2" HOSE CLAMP	02
27	0503010246	CLAMP	02



SEED FERTILIZER ROW ASSY

0909093016


Item	Code	Description	QT
28	0501046839	RIGHT IRON PRESS WHEEL	01
29	0501046844	LEFT IRON PRESS WHEEL ASSY	01
30	0503010752	1/2" X 3.1/2" BOLT	01
31	0503010019	1/2" SPRING WASHER	02
32	0501056095	SPRING ROD	01
32A	0511063983	SPRING GUIDE	01
32B	0502040534	SPRING GUIDE BUSHING LOCK	02
32C	0501018535	1/2 X 1 BOLT	02
32D	0501011090	FLAT WASHER	01
32E	0503030642	1"X 27.5" X 0.2" COMPRESSION SPRING	01
32F	0503030643	1.6"X27.5"X 0.2" COMPRESSION SPRING	01
32G	0503031695	2.2"X27.5"X 0.3" COMPRESSION SPRING	01
32H	0502010228	SPRING UPPER GUIDE	01
33	0521010542	COUPLING SHAFT	01
34	0503010300	5/32" X 1" COTTERPIN	01
35	0502011929	SPRING GUIDE FIXER	01
36	0502011928	SPRING GUIDE FIXER LOCK	01
37	0503013089	1/2" X 3-1/2" BOLT	01
38	0503010168	62950-354-B GASKET	01
39	0502040376	ROW FASTENER	01
40	0501010163	5/8" X 4-1/2" BOLT	01



Item	Code	Description	DIR ESQ
00	0501057237	RIGHT 15 X 15 UNAL DOUBLE-DISC ASSY	01 00
00A	0501057238	RIGHT 15 X 15 UNAL DOUBLE-DISC	01 00
01	0502012114	15"X15" RIGHT DOUBLE DISC SUPPORT	01 00
02	0502012115	15"X15" LEFT DOUBLE DISC SUPPORT	00 01
03	0501054151	RIGHT DOUBLE DISC COULTER BOX	01 01
03A	0502011933	DOUBLE DISC COULTER BOX	01 00
03B	0503010598	30204 BALL BEARING	02 02
03C	0503011112	SEAL 02376-BRG	01 01
03D	0521019154	RIGHT DOUB DISC HUB	01 00
03E	0503030282	3/4" CASTLE NUT	01 01
03F	0503010257	1/8" X 1" COTTERPIN	01 01
03G	0603022024	15" X 0.2" C1,2 PLAIN COULTER BLADE	01 00
03H	0503010546	5/16" X 7/8" BOLT	09 09
03I	0503010337	5/16" NUT	09 06
04	0501054168	LEFT UNAL DOBLE-DISC BOX ASSY	01 01
04A	0502011930	DOUBLE DISC COULTER BOX	00 01
04B	0521019148	LEFT DOUBLE DISC HUB	00 01
04C	0603022042	13" X 0.12" PLAIN COULTER BLADE	00 01
05	0511015098	FLAT WASHER	02 02
06	0511011927	DUST CLOAK	02 02
07	0521019178	COVER DEPTH	02 02
08	0503030757	2.9" X 2" X 0.02" JOINT	02 02
09	0503014729	1/4" UNF X 1/2" BOLT	06 06
10	0503011441	SPRING WASHER	06 06
11	0502020574	ROD STOP	01 01
12	0503010256	3/8" X 3/4" BOLT	03 03
13	0503010025	3/8 SPRING WASHER	04 04
14	0531013568	RIGHT DOUBLE DISC SCRAPER	01 01
15	0531013569	LEFT DOUBLE-DISC SCRAPER	01 01
16	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01 01
17	0501010984	FLAT WASHER	02 02
18	0503010026	3/8" NUT	01 01
19	0501055387	RIGHT SCRAPER SUPPORTE	01 01



Item	Code	Description	DIR ESQ
19A	0511064172	LH SCRAPER SUPPORT	01 01
19B	0511064997	SCRAPER ROD STOP	02 02
19C	0503010834	1/2 X 1 BOLT	02 02
20	0501055386	LEFT SCRAPER	01 01
20A	0511064171	RH SCRAPER SUPPORT	01 01




Item	Code	Description	QT
00	0501046839	RIGHT IRON PRESS WHEEL	01
00.	0909090136	IRON PRESS WHEEL	
00..	0501046844	LEFT IRON PRESS WHEEL ASSY	01
01	0501053187	LEFT IRON PRESS WHEEL ASSY	01
01A	0502011970	IRON PRESS WHEEL	01
01B	0503010598	30204 BALL BEARING	02
01C	0503011112	SEAL 02376-BRG	01
02	0501053186	RIGHT IRON PRESS WHEEL ASSY	01
03	0521019148	LEFT DOUBLE DISC HUB	01
04	0521019154	RIGHT DOUB DISC HUB	01
05	0503030282	3/4" CASTLE NUT	02
06	0503010257	1/8" X 1" COTTERPIN	01
07	0503030757	2.9" X 2" X 0.02" JOINT	01
08	0521019178	COVER DEPTH	01
09	0503010143	SPRING WASHER	03
10	0503010298	1/4" X 1/2" BOLT	03
11	0511016896	DUST CLOAK	01
12	0502011066	PRESS WHEELS ARM SUPPORT	01
13	0502011067	LEFT PRESS WHEELS ARM SUPPORT	01
14	0503030883	RIGHT TORSION SPRING	01
15	0503030882	LEFT TORSION SPRING	01
16	0502011068	RIGHT ARM	01
17	0502011069	ARM,LEFT	01
18	0521010543	1" X 5" COUPLING SHAFT	01
19	0503010839	03"X 0.6" SPRING PIN	02
20	0503010691	1/4" GREASE FITTING	01
21	0502011155	RIGHT FIXER WHEEL	01
22	0502011156	LEFT FIXER WHEEL	01
23	0503010920	1/2" X 1.1/2" BOLT	02
24	0511017302	FLAT WASHER	02
25	0503010019	1/2" SPRING WASHER	03
26	0502012112	IRON WHELL SCRAPER SUPPORT	01
27	0531017237	IRON WHELL SCRAPER BODY	01



SDA RT
IRON PRESS WHEEL

Page 13
0909090136


Item	Code	Description	QT
28	0503010740	1/2" X 2" BOLT	01
29	0503010395	1/2" X 1-1/4" BOLT	01
30	0503010060	1/2" NUT	01



Item	Code	Description	QT
00	0511046173	BOX FERTILIZER SEED ASSY	01
01	0511068814	BOX FERTILIZER SEED	01
02	0551015853	BOX SEED AXLE	01
03	0503032990	SEED DISTRIBUTOR BOX	17
04	0503032421	1.3" X .8" X 0.1" SPRING	17
05	0541015361	FLAT WASHER	34
06	0503010257	1/8" X 1" COTTERPIN	34
07	0503011953	5/16" X 1" BOLT	68
08	0501010694	FLAT WASHER	100
09	0503010179	SPRING WASHER	84
10	0503010337	5/16" NUT	84
11	0501057733	BEARING SEED TRANSMISSION	01
11A	0501110359	OUTER BEARING ASSY	02
11B	0511068753	REEL	01
11C	0503010372	501050 CLAMPING RING (FOR AXLE)	02
12	0502012325	SEED REG BEARING	01
13	0503010691	1/4" GREASE FITTING	01
14	0503012882	BALL BEARING	02
15	0503011945	503050 CLAMPING RING (FOR AXLE)	01
16	0503012104	501015 CLAMPING RING (FOR AXLE)	01
17	0551015750	HANDLE SPINDLE	01
18	0502012456	BEARING	01
19	0503010002	1800 GREASE FITTING	05
20	0503010237	3/8" X 1" BOLT	04
21	0503010025	3/8 SPRING WASHER	80
22	0503010026	3/8" NUT	80
23	0503013434	SEED REGULACION HANDLE	01
24	0501011643	3/8 X 1"BOLT	68
25	0501043280	DISTRIBUTOR FERTILIZER	17
25A	0501047198	DISTRIBUTOR FERTILIZER ASSY	17
25Aa	0502020469	DISTRIBUTOR FERTILIZER	17
25Ab	0511013789	FERTILIZER TUBE	17
25Ac	0501019851	DISTRIBUTOR FERTILIZER AXLE	17

BOX FERTILIZER SEED ASSY

Item	Code	Description	QT
25Ad	0521010309	SLEEVE INTER	17
25Ae	0503030275	AGRICULTURAL BEARING	68
25Af	0503031166	LEFT CONDUTOR	17
25Ag	0503031163	LEFT CONDUTOR	17
25Ah	0511017137	FLAT WASHER	17
25Ai	0503030303	SUPPORT WASHER	17
25Aj	0501013774	GREASE SEAL	17
25Ak	0502011412	18Z CONICAL GEAR	51
25Al	0503010523	1/4" X 2" COTTERPIN	19
25Am	0503011962	GREASE FITTING	17
25An	0503012826	CREASE FITTING	34
26	0503013758	1/4" X 1-1/2" BOLT	20
27	0551015893	SQUARE SHAFT	01
28	0501054010	OUTER BEARING ASSY	02
28A	0501110359	OUTER BEARING ASSY	02
28B	0502040540	FERTILIZER BOX EXT BEARING REEL	03
29	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04
30	0511061759	22Z P12,70 FQ 3/4" GEAR	01
31	0521010691	AXLE FASTENER	01
32	0503010373	1/4" X 2" BOLT	01
33	0503010143	SPRING WASHER	21
34	0503010144	1/4" NUT	21
35	0503010849	3/8" X 1-1/2" BOLT	08
36	0541015240	SEMILLA SCALE SUPPORT	01
37	0503032423	LARGE DOSER	01
38	0503010561	SPRING PIN	01
39	0501051927	COVER PIVOT SHAFT ASSY	04
39A	0521011120	COVER PIVOT SHAFT	04
39B	0503010140	1/8" X 3/4" COTTERPIN	08
39C	0503031329	COMPRES SPRING	04
39D	0521011117	PIVOT SPRING AXLE	04
40	0501010984	FLAT WASHER	20
41	0511068747	FERTILIZER COVER BOX	02
42	0511068748	SEED BOX COVER	02
43	0503010421	5/16" X 1-1/2" BOLT	08
44	0521011116	COVER PIVOT BUSHING	08
45	0503011907	PMC 594-S NYLON LUG	04
46	0503010363	5/16" X 1" BOLT	08
47	0503030886	SCALE DOSER	01
48	0503010001	RIVET POP	02
49	0551015863	BOX COVER	04
50	0511068818	RIGHT FALSE BOTTOM	01
51	0511068819	LH BOTONN FALSE	01
52	0511068820	RIGHT SIDE FALSE BOTONN	01




Item	Code	Description	QT
01	0511068815	FINE SEED BOX	01
02	0501057734	BEARING TRANSMISSION FINE SEED	01
02A	0502010901	FINE SEED BOX AGRICULTURAL BEARING	01
02B	0511068807	REEL TRANSMISSION FINE SEED	01
02C	0503010004	1890 GREASE FITTING	01
03	0551016041	SEED BOX FINE AXLE	01
04	0502010901	FINE SEED BOX AGRICULTURAL BEARING	01
05	0503010002	1800 GREASE FITTING	01
06	0503010237	3/8" X 1" BOLT	04
07	0503010025	3/8 SPRING WASHER	10
08	0503010026	3/8" NUT	10
09	0502040795	SEED BOX BEARING REEL	01
10	0503010406	501025 CLAMPING RING (FOR AXLE)	02
11	0531015347	RIGHT SEED FINE REGULACION	01
12	0531015345	LEFT SEED FINE ADJUSTMENT	01
13	0502011081	3/8" Q AXLE PULLER SLEEVE	01
14	0503010838	0.1" X 0.8" SPRING PIN	01
15	0503011335	502024 CLAMPING RING (FOR AXLE)	01
16	0503060150	FINE SEED DISTRIBUTOR	17
17	0503010519	1/4" X 5/8" BOLT	68
18	0501010694	FLAT WASHER	76
19	0503010143	SPRING WASHER	70
20	0503010144	1/4" NUT	70
21	0503010140	1/8" X 3/4" COTTERPIN	34
22	0531018938	SEED FINE SCALE SUPPORT	01
23	0503010282	1/4" X 3/4" BOLT	02
24	0503032076	SMALLER DOSADOR	01
25	0503010838	0.1" X 0.8" SPRING PIN	01
26	0511068817	BOX COVER FINE SEED	02
27	0503010421	5/16" X 1-1/2" BOLT	04
28	0521011116	COVER PIVOT BUSHING	04
29	0503010179	SPRING WASHER	10
30	0503010337	5/16" NUT	10




FINE SEED BOX ASSY SDA RT 17

0909093019

Item	Code	Description	QT
31	0503011907	PMC 594-S NYLON LUG	02
32	0503010363	5/16" X 1" BOLT	06
33	0501057787	CHAIN TENSIONER FINE SEED ASSY	01
33A	0551016101	TIGHTENER AXLE CHAIN FINE SEED	01
33B	0511068760	CHAIN TIGHTENER BODY	01
33C	0503012882	BALL BEARING	01
33D	0503011945	503050 CLAMPING RING (FOR AXLE)	01
33E	0503012104	501015 CLAMPING RING (FOR AXLE)	01
33F	0501010984	FLAT WASHER	07
34	0501057798	CHAIN TENSIONER FINE SEED	01
34A	0551016105	CHAIN TENSIONER SEMILLA FINA	01
34B	0503031805	11Z 1/2" GEAR	01
34C	0503010302	501019 SEAL RING	01
35	0503013252	40-1 X CHAIN X 87 LINK + MENDING	01
36	0551016035	CHAIN COVER FINE SEED	01
37	0503050042	FINE SEED DISTR BOX INTER	17
38	0503030885	SEED DOSADOR SCALE	01
39	0503010001	RIVET POP	02
40	0503031808	0.8" X 0.8" X 23" HOSE	17
41	0503011342	3/4" TO 1 CLAMP	34
42	0511064167	ROW RH FINE SEED SOCKET	04
43	0511064168	ROW LH FINE SEED SOCKET	04
44	0511064169	ROW RH FINE SEED SOCKET	04
45	0511064170	ROW LH FINE SEED SOCKET	05
46	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04
47	0531015004	FINE SEED REGULATOR WRENCH	02



Item	Code	Description	QT
01	0501057748	HECTARE ELECTRONIC SET	01
01A	0503060718	ELECTRONIC BLADE HECTARE	01
01B	0551011947	FIXER COUNTER HECTARE	01
01C	0541012710	MAGNET FIXER BLADE HECTARE	01
01D	0503010267	NYLON CLAMP	02



Item	Code	Description	QT
01	0501057806	SEQUENCE VALVE	01
01A	0503060132	VDFS-002 T SEQUENCCEL VALVE	01
01B	0501010617	3/4" NIPPLE	02
01C	0503010190	2-114 N 3006-9B O'RING	02
01D	0501012109	3/4" X 9/16" NIPPLE	06
01E	0503011036	2-111 N 3006-9B O'RING	06
01F	0503011968	T ADAPTOR WITH GIRAT	02
02	0503010421	5/16" X 1-1/2" BOLT	02
03	0501010984	FLAT WASHER	06
04	0501010694	FLAT WASHER	02
05	0503010179	SPRING WASHER	02
06	0501080524	3/8 X 1100 TC-TC HOSE ASSY	02
07	0501081282	MANGUERA 3/8" X 1550 TC-TC	02
08	0501080393	3/8 X 2200 TC-TC HOSE	02
09	0501080747	3/8 X 2900 TC-TC HOSE ASSY	02
10	0501080473	3/8" X 120" TC-TM HOSE	02
11	0501080365	3/8" X 137" HOSE	02
12	0501053834	MALE QUICK COUPLING AGRICULTURAL WITH	04
12A	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT	04
12B	0503011882	QUICK CONNECTION COVER	04
13	0502010477	UPPER CLIP	04
14	0503010849	3/8" X 1-1/2" BOLT	04
15	0503010025	3/8 SPRING WASHER	04



MARCHESAN IMPLEMENTOS E MÁQUINAS AGRÍCOLAS TATU S.A.

AV. Marchesan, 1979 - Post office box, 131 - CEP 15994-900 - Matão - SP - Brazil

Phone +55 16.3382-8282

(FAX Parts) + 55 16.3382. 8297 - (Export) + 55 16.3382.1003

e.mail: tatu@marchesan.com.br www.marchesan.com.br

Technical Publications: Elaboration

JOSÉ DOMINGOS GASPARI

Technical Publications: Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

Contact Catálogo:

E-mail = jgaspari@marchesan.com.br

**ORIGINAL PARTS
TATU**

