

PARTS CATALOG

SEEDERS

SDA-I

Code: 0501090873



Series: S-0204

Rev.: 00


Date Rev.: FEVEREIRO/2004

ORIGINAL PARTS
TATU



INDEX

0909091541	FRAME	1
0909091288	LONGITUDIONAL TRANSPORT ASSY	2
0909091505	IRON PRESS WHEEL	3
0501057900	STUB SHAFT & HUB ASSY	4
0501057901	STUB SHAFT & HUB ASSY	5
0909091544	WHEEL SISTEM	6
0909091545	WHEEL SISTEM 21/29	7
0909091542	SDA-I TRANSMISSION	8
0909091546	TRANSMISSION DRIVING	9
0909091504	V PRESS SISTEM ASSY	10
0909091550	SEED/FERTILIZER BOX 19-21-23	11
0909091551	SEED/FERTILIZER BOX 27-29	12
0909091237	15X15 UNAL DOUBLE DISC	13
0909091547	SEED/FERTILIZER ROW ASSY	14
0909091548	21-27 SEED/FERTILIZER ROW ASSY	15
0909091549	SEED FERTILIZER ROW	16
0909091557	HIDRAULIC CIRCUIT	17
0511041210	1.75" X 3.4" X 17.6" X 7" HYDRAULIC CYLINDER	18
0909091543	HYDRAULIC CYLINDER	19




Item	Code	Description	19	21	23	27	29
01	0511069322	SDA-I 19 FRAME	01	00	00	00	00
02	0511069320	SDA-I 23 FRAME	00	01	01	00	00
03	0511069325	SDA-I 29 FRAME	00	00	00	01	01
04	0511069163	SDA-I 19 HANDRAIL	02	00	00	00	00
05	0511069122	SDA-I 23 HANDRAIL	00	02	02	00	00
06	0511069228	SDAI 29 HANDRAIL	00	00	00	02	02
07	0503010920	1/2" X 1.1/2" BOLT	10	10	10	10	10
08	0503010019	1/2" SPRING WASHER	10	10	10	10	10
09	0503010060	1/2" NUT	10	10	10	10	10
10	0511069166	LEFT REAR PLATFORM	01	00	00	00	00
11	0511069165	RIGHT REAR PLATFORM	01	00	00	00	00
12	0511069131	RIGHT REAR PLATFORM	00	01	01	00	00
13	0511069132	LEFT REAR PLATFORM	00	01	01	00	00
14	0511069231	RIGHT REAR PLATAFORM	00	00	00	01	01
15	0511069232	RIGHT REAR PLATAFORM	00	00	00	01	01
16	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	12	12	12	12	12
17	0501010984	FLAT WASHER	24	24	24	24	24
18	0503010025	3/8 SPRING WASHER	18	18	18	18	18
19	0503010026	3/8" NUT	16	16	16	16	16
20	0511069146	LADDER	01	01	01	01	01
21	0551017267	SLEEVE 13,50 X 25 X 9,00	02	02	02	02	02
22	0511069134	LADDER LOCK	01	01	01	01	01
23	0503010257	1/8" X 1" COTTERPIN	01	01	01	01	01
24	0511017302	FLAT WASHER	02	02	02	02	02
25	0511062112	25.6" PLOUGH SUPPORT	02	02	02	02	02
26	0501011075	PIN	02	02	02	02	02
27	0503030012	HAIR PIN	02	02	02	02	02
28	0501049704	DRAWBAR ASSY	01	01	01	01	01
28A	0511062123	DRAWBAR	01	01	01	01	01
28B	0511062245	TRACTOR HITCH ASSY	01	01	01	01	01
28C	0521010681	BUSHING COUPLING BODY	01	01	01	01	01
28D	0521010639	COUPLING SHAFT	01	01	01	01	01
28E	0541016440	DOOR HOSE	01	01	01	01	01



SDA-I
FRAME

Item	Code	Description	19	21	23	27	29
28F	0503010237	3/8" X 1" BOLT	04	04	04	04	04
28G	0503010571	1/4" X 1.1/2 COTTERPIN	01	01	01	01	01
29	0511014394	1.25" X 4.13" COUPLING SHAFT	02	02	02	02	02
30	0503030085	LOCK PIN	03	03	03	03	03
31	0501053168	ESTABILIZER DRAWBAR ASSY	01	01	01	01	01
31A	0501110262	245 ADJUSTMENT NUT	01	01	01	01	01
31B	0511062478	RIGHT TURNBUCKLE	01	01	01	01	01
31C	0501063936	LH TURNBUCKLE	01	01	01	01	01
31D	0501061056	RH LOCKNUT WITH HANDLER	01	01	01	01	01
31E	0503010002	1800 GREASE FITTING	03	03	03	03	03
32	0531010490	AXLE 1.12" X 8"	01	01	01	01	01
33	0503010523	1/4" X 2" COTTERPIN	02	02	02	02	02
34	0521010577	0.9" X 4.1" COUPLING SHAFT	01	01	01	01	01
35	0502020514	BLOCK 3.7" X 3.4" X 8.7"	18	18	18	21	21
36	0531010488	COUNTERBALANCE LATERAL COVER	02	02	02	02	02
37	0503011123	3/8" X 4-1/2" BOLT	02	02	02	02	02
38	0503010209	3/8" UNC BUTTERFLY NUT	02	02	02	02	02
39	0541016866	CLOAK MANUAL FIXER L	01	01	01	01	01
40	0503060100	HAND BOOK COMPARTMENT	01	01	01	01	01
41	0503010371	5/16" X 1" BOLT	01	01	01	01	01
42	0501010694	FLAT WASHER	02	02	02	02	02
43	0503010179	SPRING WASHER	01	01	01	01	01
44	0503010337	5/16" NUT	01	01	01	01	01
45	0503010267	NYLON CLAMP	01	01	01	01	01
46	0501047881	COUPLING SHAFT	01	01	01	01	01
46A	0501068989	COUPLING SHAFT	01	01	01	01	01
46B	0503031035	HAIR PIN	01	01	01	01	01




Item	Code	Description	QT
00	0511043758	LONGT TRANSP ASSY	01
00A	0511043759	LONGT TRANSP ASSY	01
01	0501047342	PIN LONGT TRANSP DAWBAR	01
01A	0501068348	LONGIT TRANSP DRAWBAR	01
01B	0502040733	CLEVIS	01
01C	0511018782	2.4" X 1.6" X 3" BUSHING	01
01D	0521014542	1-1/2" X 5.8" COUPLING SHAFT	01
01E	0521013910	1.1/2" UNC X 174 COUPLING SHAFT	01
01F	0511018879	FLAT WASHER	02
01G	0501010237	FLAT WASHER	01
01H	0521010580	COUPLING SHAFT	01
01I	0521010596	COUPLING SHAFT	02
01J	0503031035	HAIR PIN	04
02	0501054359	TIRE FRONT FORK	01
02A	0511064136	LONGIT TRANSP WHEEL FORNT FORK	01
02B	0501052192	LONGIT TRANSP STUB SHAFT & HUB ASSY	02
02Ba	0502011120	TRANSP WHEEL HUB	02
02Bb	0501010127	9/16" X 1-7/8" LUG BOLT	12
02Bc	0503010328	25590/25523 ROLLER BEARING	04
02Bd	0503010804	00547-B SEAL	04
02Be	0521013871	TRANSP WHEEL AXLE	02
02Bf	0511015949	LOCK NUT	02
02Bg	0503010329	LOCK WASHER	02
02Bh	0503010330	KM 9 LOCKNUT	02
02Bi	0503010035	9/16" CONIC NUT	12
02Bj	0503011052	1.1/4" X 0.77" CASTLE NUT	04
02Bk	0503010067	3/16" X 2.1/2" COTTER PIN	04
02C	0501010086	FLAT WASHER	02
02D	0503060091	L29.5"X0.63"-10L WHEEL AND	02
02Da	0503010893	WHEEL	01
02Db	0503010033	7.50 X 16 INNER TIRE	01
02Dc	0503010120	CANVAS TIRE	01
02E	0531015109	WHEEL AXLE LOCK	04




LONGITUDIONAL TRANSPORT ASSY

0909091288


Item	Code	Description	QT
02F	0503010002	1800 GREASE FITTING	06
03	0501054360	TIRE REAR FORK	01
03A	0511064137	LONGIT TRANSP WHEEL REAR FORK	01
04	0511060274	TRANSP WHEEL COUPLING SHAFT	02
05	0521013850	1.1/2" UNC X 2200 COUPLING SHAFT	02
06	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT	04
07	0503010010	1/4" X 2.1/2" COTTERPIN	04
08	0501055774	0.5"X0.4"X1.1" WHEEL AND TIRE ASSSY	02
08A	0503010379	TIRE 6L	02
08B	0503010380	INNER TIRE	01
08C	0511066015	OFFSETBAR BUSING WHEELS	02
08D	0502040223	DRAWBOLT	02
08E	0502040327	ANEL TRAVA ENGATE	02
08F	0521010578	COUPLING SHAFT	04
08G	0503010571	1/4" X 1.1/2 COTTERPIN	04
09	0503060238	TIRE WHEEL ASSY	02
09A	0503011316	TIRE 8	02
09B	0503011317	INNER TIRE	02
09C	0501051960	W-12 HOOP WHEEL	02
09Ca	0501068444	GEAR BUSHING WHEEL FLANGE	02
09Cb	0503030898	RIM FLANGE	02
09Cc	0503010383	5/8" X 3"LOCK BOLT	16
09Cd	0501011299	FLAT WASHER	16
09Ce	0503010129	5/8" NUT	16




Item	Code	Description	
00	0501046839	RIGHT IRON PRESS WHEEL	01
00A	0501046844	LEFT IRON PRESS WHEEL ASSY	01
01	0501053187	LEFT IRON PRESS WHEEL ASSY	01
01A	0502011970	IRON PRESS WHEEL	01
01B	0503010598	30204 BALL BEARING	02
01C	0503011112	SEAL 02376-BRG	01
02	0501053186	RIGHT IRON PRESS WHEEL ASSY	01
03	0521019148	LEFT DOUBLE DISC HUB	01
04	0521019154	RIGHT DOUB DISC HUB	01
05	0503030282	3/4" CASTLE NUT	01
06	0503010257	1/8" X 1" COTTERPIN	01
07	0503030757	2.9" X 2" X 0.02" JOINT	01
08	0521019178	COVER DEPTH	01
09	0503010143	SPRING WASHER	03
10	0503010298	1/4" X 1/2" BOLT	03
11	0511016896	DUST CLOAK	01
12	0502011066	PRESS WHEELS ARM SUPPORT	01
13	0502011067	LEFT PRESS WHEELS ARM SUPPORT	01
14	0503030883	RIGHT TORSION SPRING	01
15	0503030882	LEFT TORSION SPRING	01
16	0502011068	RIGHT ARM	01
17	0502011069	ARM,LEFT	01
18	0521010543	1" X 5" COUPLING SHAFT	01
19	0503010839	03"X 0.6" SPRING PIN	02
20	0503010691	1/4" GREASE FITTING	01
21	0502011155	RIGHT FIXER WHEEL	01
22	0502011156	LEFT FIXER WHEEL	01
23	0501019219	1/2" X 1-3/4" BOLT	02
24	0511017302	FLAT WASHER	02
25	0503011440	SPRING WASHER	02
26	0511015098	FLAT WASHER	02
27	0501066591	IRON PRESS WHEEL RIGHT SCRAPER	01
27.	0501066592	IRON PRESS WHEEL LEFT SCRAPER	01



Item	Code	Description	QT
01	0551017196	CARRYING WHEEL AXLE	01
02	0502011064	CARRYING WHEEL HUB	01
03	0503010008	ROLAMENTO 3780/37203	01
04	0503010328	25590/25523 ROLLER BEARING	01
05	0511069145	GEAR W/ FLANGE	01
06	0503010086	SEAL 0009B-B	01
07	0503010397	5/16" X 1-3/4" BOLT	08
08	0503010179	SPRING WASHER	12
09	0503012655	5/8" X 2-3/8" WHEEL BOLT	08
10	0501010630	1.1/2" CASTLE NUT	01
11	0503010010	1/4" X 2.1/2" COTTERPIN	01
12	0502020592	COVER	01
13	0503010295	5/16" X 5/8" BOLT	04
14	0503010002	1800 GREASE FITTING	01




Item	Code	Description	QT
01	0551017197	CARRYING WHEEL AXLE	01
02	0502040464	CARRYING WHEEL HUB	01
03	0503010059	33287/33462 ROLLER BEARING	01
04	0503010007	3982/3920 ROLLER BEARING	01
05	0511069164	GEAR W/ FLANGE	01
06	0503010086	SEAL 0009B-B	01
07	0503010365	NUT	08
08	0503010179	SPRING WASHER	14
09	0503014050	M22 X 1,5 BOLT	08
10	0501014048	REGULATOR BASE BODY	08
11	0502040080	2.1/2" UM FLANGE NUT	01
12	0503011345	1/4" X 3-1/2" COTTERPIN	01
13	0541013225	WHEEL BOX COVER	01
14	0503010240	5/16" X 3/4" BOLT	06
15	0503010002	1800 GREASE FITTING	01




Item	Code	Description	QT
01	0511069113	RIGHT ROCKER ARM	01
02	0511069116	LEFT ROCKER ARM	01
03	0551019425	3/4" X 1-1/2" BOLT	02
04	0551017190	CARRYING WHEELS AXLE	02
05	0551017264	FLAT WASHER	02
06	0521010750	CONICAL SLEEVE	02
07	0511015383	FLAT WASHER	02
08	0501010098	HEX BOLT 3/4 UNC X 2 C S G.5 ZN	02
09	0503010023	SPRING WASHER	15
10	0521010578	COUPLING SHAFT	02
11	0503030085	LOCK PIN	02
12	0511069133	DOBLE GEAR	02
13	0501068994	0.3" X 3.1" LOCK PIN	02
14	0503030168	HAIR PIN	02
15	0503010004	1890 GREASE FITTING	02
16	0501057900	STUB SHAFT & HUB ASSY	02
17	0503030678	1/2" X 1-1/2" BOLT	04
18	0503010060	1/2" NUT	12
19	0511046448	WHEEL AND TIRE ASSAY	02
19A	0503011316	TIRE 8	02
19B	0503011317	INNER TIRE	02
19C	0511068850	W-12 HOOP WHEEL	02
20	0501047357	2" X 4" X 20" X 2.3" HYDRAULIC CYLINDER	01
21	0501045409	2" X 4" X 20" X 2.3" HYDRAULIC CYLINDER	01
22	0521010582	COUPLING SHAFT	02
23	0503010571	1/4" X 1.1/2 COTTERPIN	06
24	0511062387	CYLINDER ROCKER ARM LOCK PIN	02
25	0511017302	FLAT WASHER	02
26	0503010019	1/2" SPRING WASHER	15
27	0503010834	1/2 X 1 BOLT	02
28	0511062130	MIDDLEMAN BEARING RIGHT SUPPORT	01
29	0511062131	MIDDLEMAN BEARING LEFT SUPPORT	01
30	0531012149	CHOCK BEARING	02

Item	Code	Description	QT
31	0503010233	5/8" X 2-1/2" BOLT	08
32	0501012140	FLAT WASHER	08
33	0503010027	SPRING WASHER	08
34	0501052968	AGRICULTURAL BEARING ASSY	04
35	0503010920	1/2" X 1.1/2" BOLT	08
36	0503010060	1/2" NUT	13
37	0503010002	1800 GREASE FITTING	07
38	0521019226	CENTRAL BEARING SUPPORT	01
39	0503011082	C1/2" X 1.3/4" BOLT	05
40	0521019239	AXLE AGRICULTURAL BEARING	01
41	0503012623	3/8" X 1-1/2" BOLT	03
42	0503012622	3/8" UNF HEX NUT	03
43	0531010504	RIGHT LIFT ROW AXLE	01
44	0531010499	LH LIFT ROW AXLE	01
45	0502011925	AXLE FIXER LOCK	02
46	0503010395	1/2" X 1-1/4" BOLT	02
47	0502011921	HYDRAULIC CYLINDER PIVOT SUPPORT	02
48	0503012334	3/4" UNC X 3.1/2" BOLT	02
49	0503010014	3/4" NUT	02
50	0511041210	1.75" X 3.4" X 17.6" X 7" HYDRAULIC CYLINDER	02
51	0521019210	1.25" X 10.15" AXLE	02
52	0503010523	1/4" X 2" COTTERPIN	04
53	0521019604	0.9" X 3.7" COUPLING SHAFT	02
54	0503010003	1845 GREASE FITTING	02
55	0521019208	TRANSPORT LOCK	02
56	0501047884	0.98" ROD STOP	02
57	0501047885	ROD STOP	02
58	0501047886	ROD STOP	02
59	0501047887	ROD STOP	02
60	0501047888	ROD STOP	02
61	0501047889	1.96" ROD STOP	02




Item	Code	Description	QT
01	0511069117	RIGHT ROCKER ARM	01
02	0511069118	LEFT ROCKER ARM	02
03	0551019425	3/4" X 1-1/2" BOLT	02
04	0551017190	CARRYING WHEELS AXLE	02
05	0551017264	FLAT WASHER	02
06	0521010750	CONICAL SLEEVE	02
07	0511015383	FLAT WASHER	02
08	0501010098	HEX BOLT 3/4 UNC X 2 C S G.5 ZN	02
09	0503010023	SPRING WASHER	04
10	0521010578	COUPLING SHAFT	02
11	0503030085	LOCK PIN	02
12	0511069133	DOBLE GEAR	02
13	0501068994	0.3" X 3.1" LOCK PIN	02
14	0503030168	HAIR PIN	02
15	0503010004	1890 GREASE FITTING	02
16	0501057901	STUB SHAFT & HUB ASSY	02
17	0503030678	1/2" X 1-1/2" BOLT	04
18	0503010060	1/2" NUT	12
19	0511046448	WHEEL AND TIRE ASSAY	02
19A	0503011316	TIRE 8	02
19B	0503011317	INNER TIRE	02
19C	0511068850	W-12 HOOP WHEEL	02
20	0501047357	2" X 4" X 20" X 2.3" HYDRAULIC CYLINDER	01
21	0501045409	2" X 4" X 20" X 2.3" HYDRAULIC CYLINDER	01
22	0521010582	COUPLING SHAFT	02
23	0503010571	1/4" X 1.1/2 COTTERPIN	06
24	0511062387	CYLINDER ROCKER ARM LOCK PIN	02
25	0511017302	FLAT WASHER	02
26	0503010019	1/2" SPRING WASHER	15
27	0503010834	1/2 X 1 BOLT	02
28	0511062130	MIDDLEMAN BEARING RIGHT SUPPORT	01
29	0511062131	MIDDLEMAN BEARING LEFT SUPPORT	01
30	0531012149	CHOCK BEARING	02

Item	Code	Description	QT
31	0503010233	5/8" X 2-1/2" BOLT	08
32	0501012140	FLAT WASHER	08
33	0503010027	SPRING WASHER	08
34	0501052968	AGRICULTURAL BEARING ASSY	04
35	0503010920	1/2" X 1.1/2" BOLT	08
36	0503010060	1/2" NUT	13
37	0503010002	1800 GREASE FITTING	07
38	0521019226	CENTRAL BEARING SUPPORT	01
39	0503011082	C1/2" X 1.3/4" BOLT	05
40	0521019239	AXLE AGRICULTURAL BEARING	01
41	0503012623	3/8" X 1-1/2" BOLT	03
42	0503012622	3/8" UNF HEX NUT	03
43	0531010495	RIGHT LIFT ROW AXLE	01
44	0531010496	LH LIFT ROW AXLE	01
45	0531010236	RIGHT LIFT ROW AXLE	01
46	0531010237	LH LIFT ROW AXLE	01
47	0502011925	AXLE FIXER LOCK	02
48	0503010395	1/2" X 1-1/4" BOLT	02
49	0502011921	HYDRAULIC CYLINDER PIVOT SUPPORT	02
50	0503012334	3/4" UNC X 3.1/2" BOLT	02
51	0503010014	3/4" NUT	02
52	0511041210	1.75" X 3.4" X 17.6" X 7" HYDRAULIC CYLINDER	02
53	0521019210	1.25" X 10.15" AXLE	02
54	0503010523	1/4" X 2" COTTERPIN	04




Item	Code	Description	QT
01	0511069119	PIVOT ARM	02
02	0501058046	TRANSMISSION RIGHT DRIVING	01
03	0501058047	TRANSMISSION LEFT DRIVING	01
04	0503010920	1/2" X 1.1/2" BOLT	02
05	0503010060	1/2" NUT	10
06	0502011922	RATCHET DRIVING	02
07	0503010395	1/2" X 1-1/4" BOLT	02
08	0521010773	0.37" X 1.18" COUPLING SHAFT	04
09	0501010984	FLAT WASHER	04
10	0503010257	1/8" X 1" COTTERPIN	08
11	0501067130	ADJUSTMENT BAR ASSY	02
12	0541015404	3/4" UNC 200 REGULACION	02
13	0503010014	3/4" NUT	04
14	0511069125	14Z X P 1.25" GEAR	02
15	0503030119	LOCK PIN	04
16	0511069128	26Z GEAR	02
17	0503012712	40-1 CHAIN X 81 LINK + MENDING	02
18	0503012719	40-1 CHAIN X 113 LINK + MENDING	02
19	0503011649	50-1 X CHAIN X 91 LINK + MENDING	02
20	0503012716	CHAIN 50-1 X 3.7" LINK + MENDING	02
21	0503014864	50-1 X 121 CHAIN LINK + MENDING	02
22	0501055914	FERTILIZER AXLE CHAIN TENSIONER	02
22A	0541015234	CHAIN TENSIONER	02
22B	0503031805	11Z 1/2" GEAR	08
22C	0503010302	501019 SEAL RING	12
22D	0511017302	FLAT WASHER	02
22E	0503010019	1/2" SPRING WASHER	08
23	0501067018	CHAIN TENSIONER	02
24	0503031804	5Z GEAR P31,75	02
25	0551016065	TENSIONER CHAIN	04
26	0503031806	9Z X P 5/8" GEAR	02
27	0501058073	FERTILIZER INNTER BEARING	02
27A	0502012031	HOUSING BEARING	02

Item	Code	Description	QT
27B	0503012861	6006 2RS BALL BEARING	04
27C	0511069120	FERTILIZER INNTER REEL	02
27D	0503012858	502075 CLAMPING RING (FOR HOLE)	02
27E	0503010707	501030 CLAMPING RING (FOR AXLE)	02
28	0501057942	SEED INNTER BEARING	02
28A	0551017194	SEED SLEEVE AXLE	02
28B	0503011410	ROLLER BEARING	08
28C	0511069147	DOUBLE WHEEL TOOTH 20Z X 32Z	02
28D	0503010406	501025 CLAMPING RING (FOR AXLE)	02
29	0511069171	END GEARING TENSIONER	02
30	0551017198	SPRING FIXER	02
31	0503030242	0.8" X 4.7" X 0.08" TRACTION SPRING	02
32	0511069143	LEFT RATCHET PIVOT	01
33	0511069142	RH RATCHET PIVOT	01
34	0551017193	CHAIN TENSIONER AXLE	02
35	0551017188	SUPPORT BODY RATCHET	02
36	0551017384	CHAIN COVER FIXER	02
37	0551017385	CHAIN COVER FIXER	02
38	0503010025	3/8 SPRING WASHER	12
39	0503010026	3/8" NUT	12
40	0551017374	RH CHAIN COVER	01
41	0551017375	LEFT CHAIN COVER	01
42	0503010386	CABLE	04
43	0503010023	SPRING WASHER	02
44	0503012163	5/16" X 1-1/2" BOLT	04
45	0501010694	FLAT WASHER	04
46	0503010179	SPRING WASHER	04
47	0503010337	5/16" NUT	04
48	0503010481	BOLT	04



Item	Code	Description	QT
00	0501058046	TRANSMISSION RIGHT DRIVING	01
00A	0501058047	TRANSMISSION LEFT DRIVING	01
01	0551017192	RATCHET AXLE	01
02	0501019735	FLAT WASHER	03
03	0501110237	RH RATCHET FOLLOWER	01
04	0501110236	LH RATCHET FOLLOWER	01
05	0501019734	FLAT WASHER	02
06	0502010710	RIGHT CAM, SMALLER	02
07	0502010720	RIGHT CAM, SMALLER	02
08	0501110560	RIGHT 28Z GEAR WITH DRAGGER	02
09	0501110561	LH 28Z GEAR WITH DRAGGER	02
10	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING	01
11	0503031800	2.3"X 2.5"X 0.2"COMPRESSION SPRING	01
12	0503010240	5/16" X 3/4" BOLT	06
13	0503010179	SPRING WASHER	06
14	0503010003	1845 GREASE FITTING	02




Item	Code	Description	QT
00	0501055213	RIGHT V PRESS SISTEM ASSY	01
00A	0501055214	LEFT V PRESS SISTEM ASSY	01
00B	0501054700	RIGHT V COMP SISTEM ASSY	01
00C	0501054701	LEFT V COMP SISTEM	01
01	0501056267	RH V PRESS SISTEM COMPL.	01
01A	0502011066	PRESS WHEELS ARM SUPPORT	01
01B	0503030883	RIGHT TORSION SPRING	01
01C	0502012021	WHELL RIGHT ARM ASSY	01
01D	0531017415	1" X 4.72" AXLE JOINT	02
01E	0503010839	03"X 0.6" SPRING PIN	02
01F	0503010002	1800 GREASE FITTING	02
02	0501056268	LF PRESS SISTEM ASSY	01
02A	0502011067	LEFT PRESS WHEELS ARM SUPPORT	01
02B	0503030882	LEFT TORSION SPRING	01
02C	0502012022	WHELL LEFT ARM ASSY	01
03	0501052908	PRESS WHEELS ASSY	02
03A	0502011919	PRESS WHEEL HUB	01
03B	0502011877	PRESS WHEEL HUB	01
03C	0502011877	PRESS WHEEL HUB	01
03D	0521018921	DUST CLOAK	01
03E	0521016316	DUST CLOAK	01
03F	0503012734	SEAL 01556 BR	02
03G	0503010269	6204 BALL BEARING	02
03H	0521018928	PRESS WHEEL RIM	02
03I	0503031421	DEPTH CONTROL WHEEL RUBBER BAND	01
03J	0503010295	5/16" X 5/8" BOLT	06
03K	0503010179	SPRING WASHER	09
03L	0503010337	5/16" NUT	09
03M	0503010178	5/16" X 7/8" BOLT	03
04	0503010691	1/4" GREASE FITTING	01
05	0502012353	PRESS WHEELS FIXER ASSY	01
06	0503010849	3/8" X 1-1/2" BOLT	02
07	0503010025	3/8 SPRING WASHER	02



SDA-I
V PRESS SISTEM ASSY

Item	Code	Description	QT
08	0503010026	3/8" NUT	02
09	0503010752	1/2" X 3.1/2" BOLT	01
10	0503013739	1/2" X 1" BOLT	01
11	0521014508	FLAT WASHER	04
12	0503010019	1/2" SPRING WASHER	02
13	0602021014	14" X 0,2 PLAIN COULTER BLADE	01
14	0503010479	1/2" X 3" BOLT	03
15	0521011316	0.4" X 0.5" X 0.6" SLEEVE	03



Item	Code	Description	19	21	23
00	0501058223	SILO SUPPORT ASSY	01	00	00
00A	0501058224	BEAM SUPPORT ASSY	00	00	01
00B	0501058035	BEAM SUPPORT ASSY	00	00	01
01	0511069327	SEED/FERTILIZER BOX SUPPORT	01	00	00
02	0511069287	SEED/FERTILIZER BOX SUPPORT	00	01	01
03	0501058071	SEED BOX BEARING ASSY	02	02	02
03A	0502012302	SEED BOX BEARING REEL	02	02	02
03B	0503010371	5/16" X 1" BOLT	12	12	12
03C	0503010337	5/16" NUT	96	108	120
03D	0551017689	W/HOLE 66 GEAR	02	02	02
03E	0501110250	BEARING BOX	02	02	02
03F	0503010372	501050 CLAMPING RING (FOR AXLE)	04	04	04
03G	0503010004	1890 GREASE FITTING	02	02	02
04	0503011087	3/8" X 1" BOLT	16	16	16
05	0503010025	3/8 SPRING WASHER	106	114	122
06	0503010026	3/8" NUT	106	114	122
07	0502012325	SEED REG BEARING	02	02	02
08	0503012882	BALL BEARING	04	04	04
09	0503011945	503050 CLAMPING RING (FOR AXLE)	02	02	02
10	0541015305	HANDLE SPINDLE	02	02	02
11	0501017157	WASHER SPACER	01	01	01
12	0501050031	SUPPORT LOCK	04	04	04
12A	0503030012	HAIR PIN	04	04	04
12B	0503010756	0.2" X 2.4" SPRING PIN	04	04	04
13	0511067989	SLEEVE HANDLE FIXER U	02	02	02
14	0503013434	SEED REGULACION HANDLE	02	00	00
15	0551019597	SEED REGULACION HANDLE	00	02	02
16	0551012708	RIGHT CHAIN PROTETION COVER	01	01	01
17	0551012709	LEFT CHAIN PROTETION COVER	01	01	01
18	0503010011	5/16" X 1/2" BOLT	06	06	06
19	0501010694	FLAT WASHER	82	90	102
20	0503010179	SPRING WASHER	90	102	114
21	0501043280	DISTRIBUTOR FERTILIZER	19	21	23




SEED/FERTILIZER BOX 19-21-23

0909091550

Item	Code	Description	19	21	23
21A	0501110143	TUBE FERTILIZER METERING BODY	19	21	23
21B	0501019851	DISTRIBUTOR FERTILIZER AXLE	19	21	23
21C	0521010309	SLEEVE INTER	19	21	23
21D	0503030275	AGRICULTURAL BEARING	76	84	92
21E	0503031166	LEFT CONDUCTOR	19	21	23
21F	0511017137	FLAT WASHER	19	21	23
21G	0503030303	SUPPORT WASHER	19	21	23
21H	0501013774	GREASE SEAL	19	21	23
21I	0502011412	18Z CONICAL GEAR	57	63	69
21J	0503010523	1/4" X 2" COTTERPIN	19	21	23
21K	0503011962	GREASE FITTING	19	21	23
21L	0503012826	CREASE FITTING	38	42	46
22	0501011643	3/8 X 1" BOLT	76	84	92
23	0501051798	AGRICULTURAL BEARING ASSY	02	02	02
23A	0501110250	BEARING BOX	02	02	02
23B	0521011127	AGRICULTURAL BEARING REEL	02	02	02
23C	0503010002	1800 GREASE FITTING	02	02	02
24	0521010691	AXLE FASTENER	04	04	04
25	0503010373	1/4" X 2" BOLT	04	04	04
26	0503010143	SPRING WASHER	04	04	04
27	0503010144	1/4" NUT	04	04	04
28	0511061759	22Z P12,70 FQ 3/4" GEAR	02	02	02
29	0551017377	SQUARE SHAFT	01	00	01
30	0551019419	SQUARE SHAFT	00	01	00
31	0551017376	SQUARE SHAFT	01	00	01
32	0551019420	SQUARE SHAFT	00	01	00
33	0541015238	SEED BEAN AXLE	02	02	02
34	0541015247	FLAT WASHER	02	02	02
35	0503012104	501015 CLAMPING RING (FOR AXLE)	02	02	02
36	0503032990	SEED DISTRIBUTOR BOX	19	21	23
36A	0503015222	BUSHING	19	21	23
36B	0503014540	M6 NUT	114	126	138
36C	0503015223	LARGER COVER	19	21	23
36D	0503015224	DISTRIBUTOR	19	21	23
36E	0503015225	SMALLER COVER	19	21	23
36F	0503011397	M5 X 0.3" NUT	57	63	69
36G	0503015226	REGULATOR FLOW	19	21	23
36H	0503015227	GRAPHITIZED RING	19	21	23
36I	0503015228	TOOTHED WASHER	19	21	23
36J	0503015229	TOOTH LOCKWASHER COVER	19	21	23
36K	0503015230	M5 BOLT	57	63	69
36L	0503015231	ROTOR	19	21	23
36M	0503015232	M 6 X 12 BOLT	114	126	138
36N	0503014540	M6 NUT	76	84	92
36P	0503015233	COVER	19	21	23
37	0503032421	1.3" X .8" X 0.1" SPRING	19	21	23
38	0541015361	FLAT WASHER	38	42	46
39	0503010257	1/8" X 1" COTTERPIN	38	42	46
40	0541015376	SEED BOX LOCK	01	01	01
41	0541015240	SEMILLA SCALE SUPPORT	02	02	02
42	0503032423	LARGE DOSER	02	02	02
43	0503010561	SPRING PIN	02	02	02
44	0503011953	5/16" X 1" BOLT	76	84	96
45	0503060784	SEED BOX ASSY	02	00	00
46	0503060783	FERTILIZER BOX ASSY	02	00	00
47	0503060782	SEED BOX ASSY	00	03	03
48	0503060781	FERTILIZER BOX ASSY	00	03	03
49	0503010849	3/8" X 1-1/2" BOLT	14	14	14
50	0501010984	FLAT WASHER	28	28	28
51	0541011709	SEED/ FERTILIZER BEAM LOCK	08	12	12
52	0503010240	5/16" X 3/4" BOLT	08	12	12
53	0503030886	SCALE DOSER	02	02	02



Item	Code	Description	19	21	23
54	0503010001	RIVET POP	04	04	04
55	0503032624	FERTILIZER BEAN LIP	14	17	17




Item	Code	Description	27 29
00	0501058432	SILO SUPPORT ASSY	01 01
01	0511069328	SEED/FERTILIZER BOX SUPPORT	01 01
02	0501056110	SEED BOX BEARING ASSY	02 02
02A	0502012302	SEED BOX BEARING REEL	02 02
02B	0541015252	34Z GEAR	02 02
02C	0503010371	5/16" X 1" BOLT	12 12
02D	0503010337	5/16" NUT	144 144
02E	0503010397	5/16" X 1-3/4" BOLT	12 12
02F	0541015348	0.3"X 0.6"X 0.6"SLEEVE	02 02
02G	0511013557	30Z P 0.5" RH1.2.9" GEAR	02 02
02H	0501110250	BEARING BOX	02 02
02I	0503010372	501050 CLAMPING RING (FOR AXLE)	04 04
02J	0503010004	1890 GREASE FITTING	02 02
03	0503011087	3/8" X 1" BOLT	16 16
04	0503010025	3/8 SPRING WASHER	138 146
05	0503010026	3/8" NUT	138 146
06	0502012325	SEED REG BEARING	02 02
07	0503012882	BALL BEARING	04 04
08	0503011945	503050 CLAMPING RING (FOR AXLE)	02 02
09	0541015305	HANDLE SPINDLE	02 02
10	0501017157	WASHER SPACER	01 01
11	0501050031	SUPPORT LOCK	04 04
11A	0503030012	HAIR PIN	04 04
11B	0503010756	0.2" X 2.4" SPRING PIN	04 04
12	0511066272	SLEEVE HANDLE FIXER U	02 02
13	0551019597	SEED REGULACION HANDLE	02 02
14	0501043280	DISTRIBUTOR FERTILIZER	27 29
14A	0501110143	TUBE FERTILIZER METERING BODY	27 29
14B	0501019851	DISTRIBUTOR FERTILIZER AXLE	27 29
14C	0521010309	SLEEVE INTER	27 29
14D	0503030275	AGRICULTURAL BEARING	108 116
14E	0503031166	LEFT CONDUTOR	27 29
14F	0511017137	FLAT WASHER	27 29



SEED/FERTILIZER BOX 27-29

0909091551

Item	Code	Description	27	29
14G	0503030303	SUPPORT WASHER	27	29
14H	0501013774	GREASE SEAL	27	29
14I	0502011412	18Z CONICAL GEAR	81	87
14J	0503010523	1/4" X 2" COTTERPIN	27	29
14K	0503011962	GREASE FITTING	27	29
14L	0503012826	CREASE FITTING	54	58
15	0501011643	3/8 X 1"BOLT	108	116
16	0501052990	AGRICULTURAL BEARING	02	02
16A	0501110250	BEARING BOX	02	02
16B	0502040154	BEARING REEL	02	02
16C	0503010003	1845 GREASE FITTING	02	02
17	0521010691	AXLE FASTENER	04	04
18	0503010373	1/4" X 2" BOLT	04	04
19	0503010143	SPRING WASHER	04	04
20	0503010144	1/4" NUT	04	04
21	0511061759	22Z P12,70 FQ 3/4" GEAR	02	02
22	0551019422	SQUARE SHAFT	01	01
23	0551019421	SQUARE SHAFT	01	01
24	0541015239	SEED BEAN AXLE	02	02
25	0541015247	FLAT WASHER	02	02
26	0503012104	501015 CLAMPING RING (FOR AXLE)	02	02
27	0503032990	SEED DISTRIBUTOR BOX	27	29
27A	0503015222	BUSHING	27	29
27B	0503014540	M6 NUT	162	174
27C	0503015223	LARGER COVER	27	29
27D	0503015224	DISTRIBUTOR	27	29
27E	0503015225	SMALLER COVER	27	29
27F	0503011397	M5 X 0.3" NUT	81	87
27G	0503015226	REGULATOR FLOW	27	29
27H	0503015227	GRAPHITIZED RING	27	29
27I	0503015228	TOOTHED WASHER	27	29
27J	0503015229	TOOTH LOCKWASHER COVER	27	29
27K	0503015230	M5 BOLT	81	87
27L	0503015231	ROTOR	27	29
27M	0503015232	M 6 X 12 BOLT	162	174
27N	0503014540	M6 NUT	108	116
27P	0503015233	COVER	27	29
28	0503032421	1.3" X .8" X 0.1" SPRING	27	29
29	0541015361	FLAT WASHER	54	58
30	0503010257	1/8" X 1" COTTERPIN	54	58
31	0541015376	SEED BOX LOCK	01	01
32	0503011953	5/16" X 1" BOLT	120	120
33	0501010694	FLAT WASHER	126	126
34	0503010179	SPRING WASHER	138	138
35	0503032423	LARGE DOSER	02	02
36	0503010561	SPRING PIN	02	02
37	0503060784	SEED BOX ASSY	03	03
38	0503060783	FERTILIZER BOX ASSY	03	03
39	0503010849	3/8" X 1-1/2" BOLT	14	14
40	0501010984	FLAT WASHER	28	28
41	0541011709	SEED/ FERTILIZER BEAM LOCK	12	12
42	0503010240	5/16" X 3/4" BOLT	12	12
43	0503030886	SCALE DOSER	43	43
44	0503010001	RIVET POP	44	44
45	0503032624	FERTILIZER BEAN LIP	22	22
46	0541015240	SEMILLA SCALE SUPPORT	01	01
47	0551012708	RIGHT CHAIN PROTETION COVER	01	01
48	0551012709	LEFT CHAIN PROTETION COVER	01	01
49	0503010011	5/16" X 1/2" BOLT	06	06




Item	Code	Description	QT
00	0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	01
00A	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	01
01	0502012114	15"X15" RIGHT DOUBLE DISC SUPPORT	01
02	0502012115	15"X15" LEFT DOUBLE DISC SUPPORT	01
03	0501054151	RIGHT DOUBLE DISC COULTER BOX	01
03A	0502011933	DOUBLE DISC COULTER BOX	01
03B	0503010598	30204 BALL BEARING	04
03C	0503011112	SEAL 02376-BRG	02
03D	0521019154	RIGHT DOUB DISC HUB	01
03E	0503030282	3/4" CASTLE NUT	02
03F	0503010257	1/8" X 1" COTTERPIN	02
03G	0603022024	15" X 0.2" C1,2 PLAIN COULTER BLADE	01
03H	0503010546	5/16" X 7/8" BOLT	15
03I	0503010337	5/16" NUT	15
04	0501054168	LEFT UNAL DOBLE-DISC BOX ASSY	01
04A	0502011930	DOUBLE DISC COULTER BOX	01
04B	0521019148	LEFT DOUBLE DISC HUB	01
04C	0603022042	13" X 0.12" PLAIN COULTER BLADE	01
05	0511015098	FLAT WASHER	02
06	0511011927	DUST CLOAK	02
07	0521019178	COVER DEPTH	02
08	0503030757	2.9" X 2" X 0.02" JOINT	02
09	0503010298	1/4" X 1/2" BOLT	06
10	0511015098	FLAT WASHER	06
11	0531013568	RIGHT DOUBLE DISC SCRAPER	01
12	0531013569	LEFT DOUBLE-DISC SCRAPER	01
13	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01
14	0501010984	FLAT WASHER	04
15	0503011443	SPRING WASHER	06
16	0503010026	3/8" NUT	06
17	0502020575	ROD STOP	01
18	0503010256	3/8" X 3/4" BOLT	03
19	0501056200	RIGHT ROD STOP SCRAPER COMPL.	01



15X15 UNAL DOUBLE DISC

0909091237

Item	Code	Description	QT
19A	0541016755	ROD STOP SCRAPER	01
19B	0541016756	L 41,50 X 58,50 X 6,30 SDA3	01
19C	0541016758	RIGHT SCRAPER SUPPORT	01
19D	0503010237	3/8" X 1" BOLT	02
20	0501056201	LEFT ROD STOP SCRAPER COMPL.	01
20A	0541016757	LEFT SCRAPER SUPPORT	01
21	0503010752	1/2" X 3.1/2" BOLT	02
22	0511017302	FLAT WASHER	02
23	0503010019	1/2" SPRING WASHER	02
24	0503010060	1/2" NUT	02
25	0502020662	ROD STOP	01




Item	Code	Description	19D	19E	23D	23E	29D	29E
00	0501056211	RH DDD ROW SMALLER SUPPORT	04	00	05	00	05	00
00A	0501056212	LH DDD ROW SMALLER SUPPORT	00	05	00	06	00	05
00B	0501056213	RH ROW DDD LARGER SUPPORT	04	00	05	00	04	00
00C	0501056214	LH ROW DDD LARGER SUPPORT	00	04	00	05	00	05
00D	0501056215	RH ROW LARGER SIDE SUPPORT	01	00	01	00	01	00
00E	0501056216	LH ROW LARGER SIDE SUPPORT	00	01	00	01	00	01
01	0511064373	SMALLER TRIPLE DISC SUPPORT	01	01	01	01	01	01
02	0511064374	LARGER TRIPLE DISC SUPPORT	02	02	02	02	02	02
03	0502010978	SUPPORT FIXER	03	03	03	03	03	03
04	0502040376	ROW FASTENER	03	03	03	03	03	03
05	0501017315	5/8" X 124 BOLT	03	03	03	03	03	03
06	0501012140	FLAT WASHER	03	03	03	03	03	03
07	0503010811	5/8" UNF SELF ADJUSTING NUT	03	03	03	03	03	03
08	0503010691	1/4" GREASE FITTING	03	03	03	03	03	03
09	0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	03	03	03	03	03	03
10	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	00	03	00	03	00	03
11	0511065789	FRONT PROTECTOR	03	03	03	03	03	03
12	0503010547	1/2" X 4" BOLT	06	06	06	06	06	06
13	0503010019	1/2" SPRING WASHER	30	30	30	30	30	30
14	0503010060	1/2" NUT	30	30	30	30	30	30
15	0541014450	158 SPACER ROW	05	04	05	04	05	04
16	0541014451	175 ROW SPACER	00	01	00	01	00	01
17	0511066111	RIGHT SIDE ROW SPACER	01	00	01	00	01	00
18	0511066112	LEFT SIDE ROW SPACER	00	01	00	01	00	01
19	0541014789	ROW SPACING SIDE SUPPORT	01	01	01	01	01	01
20	0541014458	R 1/2" UNC X 3" X 3.5" FASTERNER	06	06	06	06	06	06
21	0501010937	FLAT WASHER	12	12	12	12	12	12
22	0502040190	SPRING FIXER SUPPORT	02	02	02	02	02	02
23	0521010666	5/8" UNC X 3.7" X 3" FASTENER	03	03	03	03	03	03
24	0503010027	SPRING WASHER	09	09	09	09	09	09
25	0503010013	5/8" NUT	09	09	09	09	09	09
26	0501010163	5/8" X 4-1/2" BOLT	03	03	03	03	03	03
27	0503010920	1/2" X 1.1/2" BOLT	02	02	02	02	02	02



SEED/FERTILIZER ROW ASSY

0909091547

Item	Code	Description	19D	19E	23D	23E	29D	29E
28	0503030520	SEED SOCKET	03	03	03	03	03	03
29	0503030483	FERTILIZER SOCKET	03	03	03	03	03	03
30	0551011060	SOCKET LOCK FERTILIZER/SEED	06	06	06	06	06	06
31	0503031145	2" X 2" X 20" HOSE	06	06	06	06	06	06
32	0503031076	2" HOSE CLAMP	06	06	06	06	06	06
33	0503010246	CLAMP	06	06	06	06	06	06
34	0501055213	RIGHT V PRESS SISTEM ASSY	03	03	03	00	03	00
35	0501055214	LEFT V PRESS SISTEM ASSY	00	03	00	03	00	03
36	0503010752	1/2" X 3.1/2" BOLT	06	06	06	06	06	06
37	0511017302	FLAT WASHER	06	06	06	06	06	06
38	0501056095	SPRING ROD	03	03	03	03	03	03
38A	0511063983	SPRING GUIDE	03	03	03	03	03	03
38B	0502040534	SPRING GUIDE BUSHING LOCK	06	06	06	06	06	06
38C	0501018535	1/2 X 1 BOLT	06	06	06	06	06	06
38D	0501011090	FLAT WASHER	03	03	03	03	03	03
38E	0503030642	1"X 27.5" X 0.2" COMPRESSION SPRING	03	03	03	03	03	03
38F	0503030643	1.6"X27.5"X 0.2" COMPRESSION SPRING	03	03	03	03	03	03
38G	0503031695	2.2"X27.5"X 0.3" COMPRESSION SPRING	03	03	03	03	03	03
38H	0502010228	SPRING UPPER GUIDE	03	03	03	03	03	03
39	0521010542	COUPLING SHAFT	03	03	03	03	03	03
40	0503010300	5/32" X 1" COTTERPIN	03	03	03	03	03	03
41	0502011929	SPRING GUIDE FIXER	03	03	03	03	03	03
42	0502011928	SPRING GUIDE FIXER LOCK	03	03	03	03	03	03
43	0503013089	1/2" X 3-1/2" BOLT	06	06	06	06	06	06
44	0503030168	HAIR PIN	03	03	03	03	03	03




Item	Code	Description	21D	21E	21D	21E
00	0501056217	RH DDD ROW SMALLER SUPPORT	05	00	06	00
00A	0501056218	LH DDD SMALLER SUPPORT	00	05	00	07
00B	0501056219	RH ROW DDD LARGER SUPPORT	04	00	06	00
00C	0501056220	RH ROW DDD LARGER SUPPORT	00	05	00	06
00D	0501056221	RH SIDE ROW LARGER SUPPORT	01	00	01	00
00E	0501056222	LH SIDE ROW DDD LARGER SUPPORT	00	01	00	01
01	0511064373	SMALLER TRIPLE DISC SUPPORT	01	01	01	01
02	0511064374	LARGER TRIPLE DISC SUPPORT	02	02	02	02
03	0502010978	SUPPORT FIXER	03	03	03	03
04	0502040376	ROW FASTENER	03	03	03	03
05	0501017315	5/8" X 124 BOLT	03	03	03	03
06	0501012140	FLAT WASHER	03	03	03	03
07	0503010811	5/8" UNF SELF ADJUSTING NUT	03	03	03	03
08	0503010691	1/4" GREASE FITTING	03	03	03	03
09	0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	03	00	03	00
10	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	00	03	00	03
11	0511065789	FRONT PROTECTOR	03	03	03	03
12	0503010547	1/2" X 4" BOLT	06	06	06	06
13	0503011440	SPRING WASHER	32	32	32	32
14	0503010060	1/2" NUT	32	32	32	32
15	0541014451	175 ROW SPACER	06	06	06	06
16	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER	06	06	06	06
17	0501010937	FLAT WASHER	14	14	14	14
18	0511066111	RIGHT SIDE ROW SPACER	01	00	01	00
19	0511066112	LEFT SIDE ROW SPACER	00	01	00	01
20	0541014789	ROW SPACING SIDE SUPPORT	01	01	01	01
21	0502040190	SPRING FIXER SUPPORT	02	02	02	02
22	0521010666	5/8" UNC X 3.7" X 3" FASTENER	03	03	03	03
23	0503011445	SPRING WASHER	09	09	09	09
24	0503010013	5/8" NUT	09	09	09	09
25	0503010920	1/2" X 1.1/2" BOLT	02	02	02	02
26	0501010163	5/8" X 4-1/2" BOLT	03	03	03	03
27	0503030520	SEED SOCKET	03	03	03	03



21-27 SEED/FERTILIZER ROW ASSY

0909091548

Item	Code	Description	21D	21E	21D	21E
28	0503030483	FERTILIZER SOCKET	03	03	03	03
29	0551011060	SOCKET LOCK FERTILIZER/SEED	06	06	06	06
30	0503031145	2" X 2" X 20" HOSE	06	06	06	06
31	0503031076	2" HOSE CLAMP	06	06	06	06
32	0503010246	CLAMP	06	06	06	06
33	0501055213	RIGHT V PRESS SISTEM ASSY	03	00	03	00
34	0501055214	LEFT V PRESS SISTEM ASSY	00	03	00	03
35	0503010752	1/2" X 3.1/2" BOLT	06	06	06	06
36	0511017302	FLAT WASHER	06	06	06	06
37	0501056095	SPRING ROD	03	03	03	03
37A	0511063983	SPRING GUIDE	03	03	03	03
37B	0502040534	SPRING GUIDE BUSHING LOCK	06	06	06	06
37C	0501018535	1/2 X 1 BOLT	06	06	06	06
37D	0501011090	FLAT WASHER	03	03	03	03
37E	0503030642	1"X 27.5" X 0.2" COMPRESSION SPRING	03	03	03	03
37F	0503030643	1.6"X27.5"X 0.2" COMPRESSION SPRING	03	03	03	03
37G	0503031695	2.2"X27.5"X 0.3" COMPRESSION SPRING	03	03	03	03
37H	0502010228	SPRING UPPER GUIDE	03	03	03	03
38	0521010542	COUPLING SHAFT	03	03	03	03
39	0503010300	5/32" X 1" COTTERPIN	03	03	03	03
40	0502011929	SPRING GUIDE FIXER	03	03	03	03
41	0502011928	SPRING GUIDE FIXER LOCK	03	03	03	03
42	0503013089	1/2" X 3-1/2" BOLT	06	06	06	06
43	0503030168	HAIR PIN	03	03	03	03




Item	Code	Description	DIR ESQ
00	0501057398	RH DDD ROW SMALLER SUPPORT	05 00
00A	0501057399	LH DDD SMALLER SUPPORT	00 05
00B	0501057400	RH DDD LARGER SUPPORT	05 00
00C	0501057401	ROW LARGER SUPPOT DDD	00 06
01	0501064373	3130 RIGHT FRONT SIDE FRAME	01 01
02	0511064374	LARGER TRIPLE DISC SUPPORT	01 01
03	0502010978	SUPPORT FIXER	02 02
04	0501017315	5/8" X 124 BOLT	02 02
05	0501012140	FLAT WASHER	02 02
06	0503010811	5/8" UNF SELF ADJUSTING NUT	02 02
07	0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	02 00
08	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	00 02
09	0511065789	FRONT PROTECTOR	02 02
10	0503010691	1/4" GREASE FITTING	02 02
11	0503010547	1/2" X 4" BOLT	04 04
12	0503010019	1/2" SPRING WASHER	12 12
13	0503010060	1/2" NUT	12 12
14	0502011078	198 ROW SPACING SPRING FIXER	02 02
15	0521010666	5/8" UNC X 3.7" X 3" FASTENER	02 02
16	0503010027	SPRING WASHER	06 06
17	0503010013	5/8" NUT	06 06
18	0502040376	ROW FASTENER	02 02
19	0501010163	5/8" X 4-1/2" BOLT	02 02
20	0503030520	SEED SOCKET	02 02
21	0503030483	FERTILIZER SOCKET	02 02
22	0551011060	SOCKET LOCK FERTILIZER/SEED	04 04
23	0503031145	2" X 2" X 20" HOSE	04 04
24	0503031076	2" HOSE CLAMP	04 04
25	0503010246	CLAMP	04 04
26	0501055213	RIGHT V PRESS SISTEM ASSY	02 02
27	0501055214	LEFT V PRESS SISTEM ASSY	02 02
28	0503010752	1/2" X 3.1/2" BOLT	04 04
29	0511017302	FLAT WASHER	04 04



SDA-I
SEED FERTILIZER ROW

Page 16
0909091549


Item	Code	Description	DIR ESQ
30	0501056095	SPRING ROD	02 02
31	0521010542	COUPLING SHAFT	02 02
32	0503010300	5/32" X 1" COTTERPIN	02 02
33	0502011929	SPRING GUIDE FIXER	02 02
34	0502011928	SPRING GUIDE FIXER LOCK	02 02
35	0503013089	1/2" X 3-1/2" BOLT	04 04
36	0503030168	HAIR PIN	02 02




Item	Code	Description	19	21	23	27	29
01	0501068707	SIMPLE CONNECTION	01	01	01	01	01
02	0501068706	DOUBLE CONNECTION	01	01	01	01	01
03	0503010237	3/8" X 1" BOLT	04	04	04	04	04
04	0501010984	FLAT WASHER	06	06	06	06	06
05	0503010025	3/8 SPRING WASHER	06	06	06	06	06
06	0503010026	3/8" NUT	06	06	06	06	06
07	0501041997	VALVE ASSY	01	01	01	01	01
07A	0503060069	VALVE ASSY	01	01	01	01	01
07B	0511010111	7/8" NIPPLE	03	03	03	03	03
07C	0503010045	2-116 N 3006-9B O'RING	03	03	03	03	03
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	02	02	02	02	02
09	0501053834	MALE QUICK COUPLING AGRICULTURAL WITH	04	04	04	04	04
09A	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT	04	04	04	04	04
09B	0503011882	QUICK CONNECTION COVER	04	04	04	04	04
10	0502010477	UPPER CLIP	04	04	04	04	04
11	0503010849	3/8" X 1-1/2" BOLT	04	04	04	04	04
12	0501080221	3/8" X 25.6" TR-TR HOSE ASSY	01	01	01	01	01
13	0501080427	3/8" X 60" TR-TR HOSE ASSY	01	01	01	01	01
14	0501080550	3/8" X 55.12" TC-TM HOSE	01	01	01	01	01
15	0501080452	3/8" X 98" TR-TR HOSE ASSY	02	00	00	00	00
16	0501080048	3/8" X 78" TR-TR HOSE ASSY	00	00	00	01	01
17	0501080379	TR-TR HOSE ASSY	02	00	00	00	00
18	0501080435	3/8" X 141" TR-TC HOSE ASSY	02	02	02	00	00
19	0501080365	3/8" X 137" HOSE	03	03	03	03	03
20	0501080804	3/8" X 125" TR-TR HOSE ASSY	00	02	02	00	00
21	0501080298	3/8" X 124" TR-TR HOSE ASSY	00	00	00	02	02
22	0501080297	3/8" X 2800 TR-TR HOSE	00	02	02	00	00
23	0501080423	3/8" X 14" TR-TR HOSE ASSY	00	00	00	02	02
24	0501080715	3/8" X 177" TR-TC HOSE ASSY	00	00	00	02	02
25	0501047357	2"X 4" X 20" X 2.3" HYDRAULIC CYLINDER	01	01	01	01	01
26	0501045409	2"X 4" X 20" X 2.3" HYDRAULIC CYLINDER	01	01	01	01	01
27	0511041210	1.75" X 3.4" X 17.6" X 7" HYDRAULIC CYLINDER	02	02	02	02	02

1.75" X 3.4" X 17.6" X 7" HYDRAULIC CYLINDER

0511041210



Item	Code	Description	QT
01	0511064110	3.37" X 7" CYLINDER CASE	01
02	0521018426	1.7" X 13.7" TURNBUCLE	01
03	0502040493	CLEVIS 26,50 R41	01
04	0503011094	3/8" X 2" BOLT C C S I 12.9	01
05	0503010025	3/8" SPRING WASHER	01
06	0503010026	3/8" NUT	01
07	0502010993	DETACHABLE COVER	01
08	0502010781	RING SUPPORT	01
09	0503010761	D-1750 SCRAPER RING	01
10	0503010990	GASKET	01
11	0503010949	W2-2000-500 PK RING G.E	01
12	0503011060	8-336 BACK-UP RING	01
13	0503010976	2-336 N 3006-9B O'RING	01
14	0503010042	2-214 N 3006-9B O'RING	01
15	0502010843	1.8" X 3.4" PISTON	01
16	0503010170	PACKING 3120 2750	02
17	0503010948	W4-3346-590 PK RING G.E	01
18	0503010063	1" SELF-ALIGNING NUT	01
19	0503010003	1845 GREASE FITTING	01
20	0501031796	HYDRAULIC CYLINDER REPAIR KIT	01



Item	Code	Description	QT
01	0501068092	RH 4" X 2.4" CYLINDER CASE	01
02	0501066965	LH 4" X 2.4" CYLINDER CASE	01
03	0501066966	2" X 11.6" HYDRAULIC CYLINDER TURNBUCKLE	01
04	0502010017	4" HEAD	01
05	0502010778	2" X 4.2" RING SUPPORT	01
06	0503010039	D-2000 SCRAPER RING	01
07	0503010991	PACKING 1870-2000-375-B	01
08	0503010952	W2-2250-500 PK RING G.E	01
09	0503011061	8-342 BACK-UP RING	01
10	0503010338	2-342 N 3006-9B O'RING	01
11	0503010345	2-218 N 3006-9B O'RING	01
12	0502010992	2.0" X 4.0" PISTON	01
13	0503010994	W2-4000-500 PK RING G.E	01
14	0503010043	PACKING 3750-3250	02
15	0503010044	1-1/4" SELF-ADJUSTING NUT	01



MARCHESAN IMPLEMENTOS E MÁQUINAS AGRÍCOLAS TATU S.A.

AV. Marchesan, 1979 - Post office box, 131 - CEP 15994-900 - Matão - SP - Brazil

Phone +55 16.3382-8282

(FAX Parts) + 55 16.3382. 8297 - (Export) + 55 16.3382.1003

e.mail: tatu@marchesan.com.br www.marchesan.com.br

Technical Publications: Elaboration

ALESSANDRA PATRICIA KAWAHARA CARRILI

Technical Publications: Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

Contact Catálogo:

E-mail = jgaspari@marchesan.com.br

**ORIGINAL PARTS
TATU**

