

PARTS CATALOG

ROW CROP PLANTERS

PST3/PST3 SUPREMA

Code: 0501090918



Series: S-0604

Rev.: 02

Date Rev.: FEVEREIRO/2017

**ORIGINAL PARTS
TATU**



PRODUCTS


Code	Description
0111090122	PST3 8/ 4 D S-0604
0111090182	PST3 8/ 4 S/ SIST ADB S-0604
0111090123	PST3 8/ 5 D S-0604
0111090124	PST3 8/ 6 D S-0604
0111090125	PST3 8/ 7 D S-0604
0111090126	PST3 8/ 8 D S-0604
0111090127	PST3 9/ 4 D S-0604
0111090098	PST3 9/ 5 S-0604
0111090099	PST3 9/ 6 S-0604
0111090232	PST3 9/ 7 COBR ADB FER S-0604
0111090039	PST3 9/ 7 H S-0604
0111090101	PST3 9/ 8 S-0604
0111090234	PST3 9/ 8 RD S-0604
0111090102	PST3 9/ 9 S-0604
0111100153	PST3 SUPREMA 10/6 H S/ML S-0604
0111100002	PST3 SUPREMA 8/ 5 S-0400
0111100178	PST3 SUPREMA 10/5 RD D S/ML S-0604
0111100152	PST3 SUPREMA 10/5 RD H S/ML S-0604
0111100154	PST3 SUPREMA 10/6 RD H S/ML S-0604
0111100163	PST3 SUPREMA 12/10 H S/ML S-0604
0111100166	PST3 SUPREMA 8/4 D S/ML S-0604
0111100193	PST3 SUPREMA 8/5 C S/ML S-0604

ATTENTION: **IMPORTANT**

MARCHESAN S/A RESERVES THE RIGHT AT ANY TIME TO MAKE IMPROVEMENTS IN THE DESIGN, MATERIAL OR SPECIFICATIONS OF MACHINERY, EQUIPMENT OR PARTS WITHOUT THEREBY BECOMING LIABLE TO MAKE SIMILAR CHANGES IN MACHINERY, EQUIPMENT OR PARTS PREVIOUSLY SOLD.

INDEX


0909094336	FRAME PST3		1
0909094337	FRAME PST3 SUPREMA		2
0909092761	TURBINE ASSY FOR CARDAN		3
0501049849	2.0" X 4.5" X 25.8" HYDRAULIC CYLINDER		4
0511056536	SET LADDER		5
0501050633	DISC ASSY FOR ROW MARKER		6
0501054428	DRAWBAR TURNBUCKLE		7
0501051160	TRACTOR HITCH PIN		8
0501047881	COUPLING SHAFT		9
0511041364	DRIVE SHAFT		10
0511054971	SET PST3 P/ULTRA P		11
0501053834	FAST COUPLER AGRICULTURAL WITH COVER - 1/2 NPT		12
0909090985	TRANSMISSION		13
0511055018	WHEELSET WITH SPRING TRACTION		14
0501051818	WHEEL ARM ASSY		15
0501053877	WHEEL ARM ASSY		16
0511053874	WITHOUT WHEELS TIRE		17
0501058240	WHELL FASTENER		18
0501052560	AXLE MOTOR SLOW-MOVING ASSY		19
0501051577	STUB SHAFT HUB ASSY		20
0909090989	GEAR BOX ASSY		21
0501052236	CHAIN TENSIONER ASSY		22
0501052238	CHAIN TENSIONER ASSY		23
0501052237	CHAIN TENSIONER ASSY		24
0501052239	CHAIN TENSIONER ASSY		25
0501048790	AXLE WITH LINK ASSY		26
0501052759	BEARING OF THE GEAR BOX ASSY		27
0501054655	CHAIN TENSIONER ASSY		28
0501050274	BOX BEARING ASSY		29
0511040424	RH TRANSMISSION DRIVING ASSY		30
0909090977	FERTILIZER BOX		31
0909090978	PLASTIC FERTILIZER BOX		32
0501052810	TRANSMISSION CHAIN TENSIONER ASSY		33
0909090496	SEED FERTILIZER ROW		34
0909090973	SEED ROW		35
0909090004	15" X 15" SEED UNAL DOUB-DISC ASSY		36
0909090134	SEED DISTRIBUTOR ASSY		37
0501052945	DEPTH CONTROL WHEELS ASSY		38
0501052538	DEPTH CONTROL WHEEL RUBBER BAND	(OPTIONAL)	39
0501052935	PRESS WHEELS ASSY		40
0501052908	PRESS WHEELS ASSY		41
0909092764	ROW FERTILIZER ASSY		42
0501052976	15 X 15 RIGHT FERT UNAL DOUB-DISC ASSY		43
0501052977	15 X 15 LEF FERT UNAL DOUB-DISC ASSY		44
0909092926	BLADE DISC ASSY		45
0909091030	ROD SCARIFIER SPINDLE		46
0909090987	FERTILIZER SEED ROW SUPREMA ASSY		47
0909092763	SEED ROW ASSY		48
0909090053	15 X 15 SEED UNAL DOUB-DISC ASSY		49
0511048993	PNEUMATIC SEED DISTRIBUTOR		50
0501052710	SEED DISTRIBUTOR WITH DISC		51
0501044565	VDFS002 SEQUENCE VALVE		52
0511040203	1.5" X 2.5" X 19" X 9" HYDRAULIC CYLINDER	(OPTIONAL)	53
0501053080	IRON DEPTH CONTR. WHEEL	(OPTIONAL)	54
0501053037	IRON DEPTH CONTR. WHEEL ASSY	(OPTIONAL)	55
0909090984	ROW MARKER 08/09L	(OPTIONAL)	56
0909092767	HYDRAULIC ROW MARKER ASSY 10L	(OPTIONAL)	57
0909092765	HYDRAULIC CIRCUIT		58
0909090195	WHEEL PRESS FERTILIZER ASSY (CBRF)	(OPTIONAL)	59
0501052627	DEPHT WHEELS BOX	(OPTIONAL)	60
0501052297	DEPTH WHEELS REGULATOR ASSY	(OPTIONAL)	61
0501052957	IRON V PRESS WHEELS	(OPTIONAL)	62
0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	(OPTIONAL)	63
0511044585	20" COULTER BLADE ASSY FOR LONG ROW	(OPTIONAL)	64
0909094459	HEX AXLE ASSEMBLY		65



Item	Code	Description	08 09
001	0511065595	FRAME PST3 8 S-0604	01 00
002	0511065596	FRAME PST3 9 S-0604	00 01
003	0501049849	2.0" X 4.5" X 25.8" HYDRAULIC CYLINDER	01 01
004	0521012538	1.2" X 3.5" COUPLING SHAFT	01 01
005	0521012536	COUPLING SHAFT	01 01
006	0503010523	1/4" X 2" COTTERPIN	02 02
007	0503010003	1845 GREASE FITTING	05 05
008	0501043881	ROW MARKER PIVOT	01 01
008A	0501065640	ROW MARKER ROD GUIDE	02 02
008B	0503010238	1/2" X 1-3/4" BOLT	04 04
008C	0503010019	1/2" SPRING WASHER	15 15
008D	0503010060	1/2" NUT	15 15
008E	0501065644	ROW MARKER ARM/DISARMENT ROD	01 01
008F	0501064229	REGULATOR ARM/DISARMENT ROD	01 01
008G	0501062547	ROW MARKER BAR REGULATOR	01 01
008H	0511017302	FLAT WASHER	02 02
008I	0503010395	1/2" X 1-1/4" BOLT	07 07
008J	0521010454	0.83" X 1.25" X 0.79" SLEEVE	01 01
008K	0503010734	1/2" X 2-1/2" BOLT	01 01
008L	0521010539	0.3" X 1.2" COUPLING SHAFT	02 02
008M	0503010140	1/8" X 3/4" COTTERPIN	02 02
008N	0531010412	ROW MARKER ARM LOCK	02 02
008O	0502011231	CENTRAL PULLEY	01 01
008P	0511011309	AXLE PULLEY	01 01
008Q	0503010257	1/8" X 1" COTTERPIN	02 02
008R	0503030755	STEEL CABLE	01 01
008S	0501010096	3/8" X 2" BOLT	02 02
008T	0531010415	ROW MARKER ARM/DISARM GUIDE SLLEVE	04 04
008U	0503010025	3/8 SPRING WASHER	02 02
008V	0503010026	3/8" NUT	02 02
008W	0511011308	BOLT	02 02
008X	0501065642	ROW MARKER SUPPORT	01 01
008Y	0521010693	PULLEY FIXER PLATE	01 01

Item	Code	Description	08 09
008Z	0503010691	1/4" GREASE FITTING	02 02
008ZA	0503010232	5/8" X 1.3/4" BOLT	02 02
008ZB	0503010027	SPRING WASHER	02 02
008ZC	0503010013	5/8" NUT	02 02
009	0503011126	6,4 X 1000 CHAIN	02 00
010	0503011127	6,4 X 1260 CHAIN	00 02
011	0502011291	CHAIN SLEEVE	02 02
012	0503010683	0,2" X 1,2" SPRING PIN	02 02
013	0503011114	QUICK COUPLING PUMP	02 02
014	0502010421	SIDE PULLEY	02 02
015	0521010445	0.53" X 0.75" X 0.45" SLEEVE	02 02
016	0521010641	COUPLING SHAFT	02 02
017	0521013867	DRAWBAR TRANSPORT LOCK	01 01
018	0511011243	PROTECTION COVER ARM/DISARMMENT	01 00
019	0511011270	PROTECTION COVER ARM/DISARMMENT	00 01
020	0511011269	PROTECTION COVER ARM/DISARMMENT	01 00
021	0511011271	PROTECTION COVER ARM/DISARMMENT	00 01
022	0511017961	1/2" X 1-1/4" REB BOLT	02 02
023	0511060553	ROW MARKER SUPPORTE RIGHT	01 01
024	0511060554	ROW MARKER SUPPORTE LEFT	01 01
025	0503010769	5/8" X 2-1/4" BOLT	04 04
026	0521010479	SLEEVE ARTICULATION	04 04
027	0511062755	740 TURNBUCKLE	02 02
028	0521014411	1/2" X 2.76" X 1.54" FASTENER	04 04
029	0501069297	ROW MARKER LOCK RIGHT	01 01
030	0501069624	ROW MARKER LOCK LEFT	01 01
031	0521010577	0.9" X 4.1" COUPLING SHAFT	01 01
032	0501080510	3/8" X 137" TR-TR HOSE ASSY	02 02
033	0503010920	1/2" X 1.1/2" BOLT	04 04
034	0521061075	1550 HANDRAIL	01 00
035	0521061076	1800 HANDRAIL	00 01
036	0503010019	1/2" SPRING WASHER	25 25
037	0503010060	1/2" NUT	25 25
038	0521011235	62.60" REAR PLATFORM	02 00
039	0521011237	72.83" REAR PLATFORM	00 02
040	0521011300	REAR PLATFORM FIXER	04 04
041	0501010080	3/8" BOLT	04 04
042	0503010025	3/8 SPRING WASHER	10 10
043	0503010026	3/8" NUT	10 10
044	0503031376	RH CHAIN PROTECTION CAP	01 01
045	0503031377	LEFT CHAIN PROTECTION CAP	01 01
046	0511011417	HEX STUD 3/8" X 3/8" X 5.79"	04 04
047	0501069631	COVER FIXER	02 02
048	0501010984	FLAT WASHER	12 12
049	0503010209	3/8" UNC BUTTERFLY NUT	06 06
050	0511064808	DRAWBAR	01 01
051	0502012328	DRAWBAR SUPPORT FRONT FIXATION	01 01
052	0502012329	DRAWBAR FIXATION REAR SUPPORT	01 01
053	0502012330	SUPPORT FIXER PIVOT	01 01
054	0511056536	SET LADDER	02 02
055	0503011084	3/4" X 5" BOLT	01 01
056	0501010322	FLAT WASHER	01 01
057	0503010023	SPRING WASHER	01 01
058	0503010014	3/4" NUT	01 01
059	0561014393	COUPLING SHAFT	01 01
060	0503030119	LOCK PIN	01 01
061	0501054428	DRAWBAR TURNBUCKLE	01 01
062	0501050633	DISC ASSY FOR ROW MARKER	02 02
063	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	02 02
064	0502010477	UPPER CLIP	01 01
065	0501051160	TRACTOR HITCH PIN	01 01
066	0501047895	ROD STOP	01 01

Item	Code	Description	08 09
067	0501047896	1.18" ROD STOP	01 01
068	0501047897	1.38" ROD STOP	01 01
069	0501047898	1.57" ROD STOP	01 01
070	0501047881	COUPLING SHAFT	01 01
071	0511057239	SET DOOR HAND BOOK	01 01
071A	0503060100	HAND BOOK COMPARTMENT	01 01
071B	0503010267	NYLON CLAMP	01 01
071C	0503010363	5/16" X 1" BOLT	01 01
071D	0501010694	FLAT WASHER	01 01
071E	0503010179	SPRING WASHER	01 01
071F	0503010337	5/16" NUT	01 01
072	0541011767	HOSE FIXATION	01 01
073	0511054971	SET PST3 P/ULTRA P	02 02
074	0521010572	0.9" X 2.9" COUPLING SHAFT	01 01
075	0503030085	LOCK PIN	02 02
076	0503010257	1/8" X 1" COTTERPIN	02 02
077	0503010027	SPRING WASHER	02 02
078	0503010013	5/8" NUT	02 02
079	0503010140	1/8" X 3/4" COTTERPIN	02 02
080	0503010002	1800 GREASE FITTING	02 02
081	0501053834	FAST COUPLER AGRICULTURAL WITH COVER - 1/2	02 02
082	0909094459	HEX AXLE ASSEMBLY	01 01



Item	Code	Description	08 09 10 12
001	0511065595	FRAME PST3 8 S-0604	01 00 00 00
002	0511065596	FRAME PST3 9 S-0604	00 01 00 00
003	0511062558	FRAME	00 00 01 00
004	0511064816	FRAME	00 00 00 01
005	0503010967	5/8" X 5.1/2" BOLT	02 02 02 02
006	0503010523	1/4" X 2" COTTERPIN	02 02 02 02
007	0503010003	1845 GREASE FITTING	05 05 05 05
008	0501043881	ROW MARKER PIVOT	01 01 01 01
008A	0501065640	ROW MARKER ROD GUIDE	02 02 02 02
008B	0503010238	1/2" X 1-3/4" BOLT	04 04 04 04
008C	0503010019	1/2" SPRING WASHER	12 12 12 12
008D	0503010060	1/2" NUT	16 16 16 16
008E	0501065644	ROW MARKER ARM/DISARMENT ROD	01 01 01 01
008F	0501064229	REGULATOR ARM/DISARMENT ROD	01 01 01 01
008G	0501062547	ROW MARKER BAR REGULATOR	01 01 01 01
008H	0511017302	FLAT WASHER	11 11 11 11
008I	0503010395	1/2" X 1-1/4" BOLT	03 03 03 03
008J	0521010454	0.83" X 1.25" X 0.79" SLEEVE	02 02 02 02
008K	0503010734	1/2" X 2-1/2" BOLT	02 02 02 02
008L	0521010539	0.3" X 1.2" COUPLING SHAFT	02 02 02 02
008M	0503010140	1/8" X 3/4" COTTERPIN	02 02 02 02
008N	0531010412	ROW MARKER ARM LOCK	02 02 02 02
008O	0502011231	CENTRAL PULLEY	03 03 03 03
008P	0511011309	AXLE PULLEY	02 02 02 02
008Q	0503010257	1/8" X 1" COTTERPIN	10 10 10 10
008R	0503030755	STEEL CABLE	01 01 01 01
008S	0501010096	3/8" X 2" BOLT	02 02 02 02
008T	0531010415	ROW MARKER ARM/DISARM GUIDE SLLEVE	02 02 02 02
008U	0503010025	3/8 SPRING WASHER	21 21 21 21
008V	0503010026	3/8" NUT	20 20 20 20
008W	0511011308	BOLT	02 02 02 02
008X	0501065642	ROW MARKER SUPPORT	01 01 01 01
008Y	0521010693	PULLEY FIXER PLATE	01 01 01 01

Item	Code	Description	08 09 10 12
008Z	0503010691	1/4" GREASE FITTING	02 02 02 02
008Za	0503010232	5/8" X 1.3/4" BOLT	02 02 02 02
008Zb	0503010027	SPRING WASHER	12 12 12 12
008Zc	0503010013	5/8" NUT	12 12 12 12
009	0503011126	6,4 X 1000 CHAIN	02 00 00 00
009.	0503011127	6,4 X 1260 CHAIN	02 00 00 00
010	0503011128	6,4 X 1400 CHAIN	00 00 02 00
010.	0503011129	6,4 X 1900 CHAIN	00 00 00 02
011	0502011291	CHAIN SLEEVE	02 02 02 02
012	0503010683	0,2" X 1,2" SPRING PIN	02 02 02 02
013	0503011114	QUICK COUPLING PUMP	02 02 02 02
014	0502010421	SIDE PULLEY	02 02 02 02
015	0521010445	0.53" X 0.75" X 0.45" SLEEVE	02 02 02 02
016	0521010641	COUPLING SHAFT	02 02 02 02
017	0503010140	1/8" X 3/4" COTTERPIN	02 02 02 02
018	0511011243	PROTECTION COVER ARM/DISARMMENT	01 00 00 00
018.	0511011269	PROTECTION COVER ARM/DISARMMENT	01 00 00 00
019	0511011270	PROTECTION COVER ARM/DISARMMENT	00 01 00 00
019.	0511011270	PROTECTION COVER ARM/DISARMMENT	00 01 00 00
020	0511011272	PROTECTION COVER ARM/DISARMMENT	00 00 01 00
020.	0511011273	PROTECTION COVER ARM/DISARMMENT	00 00 01 00
021	0511011274	PROTECTION COVER ARM/DISARMMENT	00 00 00 01
021.	0511011275	PROTECTION COVER ARM/DISARMMENT	00 00 00 01
022	0521014441	HOSE HOLDER RIGHT SUPPORT	02 02 02 02
023	0521018535	HOSE HOLDER LEFT SUPPORT	02 02 02 02
024	0541014307	1/2 UNC X1.1/2 BOLT	02 02 02 02
025	0503031608	AIR DISTRIBUTOR	02 00 00 00
025.	0503031609	AIR DISTRIBUTOR	00 02 00 00
026	0503031610	AIR DISTRIBUTOR	00 00 02 00
026.	0503031611	AIR DISTRIBUTOR	00 00 00 02
027	0521014442	HOSE SUPPORT	04 04 04 04
028	0503010363	5/16" X 1" BOLT	08 08 08 08
029	0503010179	SPRING WASHER	09 09 09 09
030	0503010337	5/16" NUT	09 09 09 09
031	0511060553	ROW MARKER SUPPORTE RIGHT	01 01 01 01
032	0511060554	ROW MARKER SUPPORTE LEFT	01 01 01 01
033	0503010769	5/8" X 2-1/4" BOLT	04 04 04 04
034	0521010479	SLEEVE ARTICULATION	04 04 04 04
035	0501066949	1235 TURNBUCKLE	02 02 02 02
036	0521014411	1/2" X 2.76" X 1.54" FASTENER	04 04 04 04
037	0501069297	ROW MARKER LOCK RIGHT	01 01 01 01
038	0501069624	ROW MARKER LOCK LEFT	01 01 01 01
039	0501049849	2.0" X 4.5" X 25.8" HYDRAULIC CYLINDER	01 01 01 01
040	0503010920	1/2" X 1.1/2" BOLT	04 04 04 04
041	0501017432	5/8" X 95.8" HEX AXLE	01 01 01 01
042	0501017433	5/8" X 2660" HEX AXLE	01 01 01 01
043	0521061075	1550 HANDRAIL	01 00 00 00
044	0521061076	1800 HANDRAIL	00 01 00 00
045	0521061077	1950 HANDRAIL	00 00 01 00
046	0521061078	2470 HANDRAIL	00 00 00 01
047	0521011235	62.60" REAR PLATFORM	02 00 00 00
047.	0521011237	72.83" REAR PLATFORM	02 00 00 00
048	0521011241	REAR PLATFORM 1990 PST2 10 S-0498	00 00 02 00
048.	0521011244	REAR PLATFORM 2490 PST2 12 S-0498	00 00 00 02
049	0521011300	REAR PLATFORM FIXER	04 04 04 04
050	0501010080	3/8" BOLT	04 04 04 04
051	0551017438	LADDER RIGHT FIXER	01 01 01 01
052	0551017437	LADDER RIGHT FIXER	01 01 01 01
053	0503010237	3/8" X 1" BOLT	08 08 08 08
054	0511064807	STIRRUP	02 02 02 02
055	0503011372	102 TO 121 CLAMP	04 04 04 04
056	0501010096	3/8" X 2" BOLT	04 04 04 04


Item	Code	Description	08 09 10 12
057	0521018618	5" X 70" AIR CONDUCTOR	01 01 01 01
058	0503012724	121 TO 140 CLAMP	01 01 01 01
059	0531015603	HOSE FIXATION SUPPORT	01 01 01 01
060	0502010175	HITCH CLAMP	02 02 02 02
061	0501011543	5/8" X 4" BOLT	04 04 04 04
062	0501012140	FLAT WASHER	04 04 04 04
063	0511061835	PLOUGH SUPPORT	02 02 02 02
064	0501011075	PIN	02 02 02 02
065	0503030012	HAIR PIN	02 02 02 02
066	0501050633	DISC ASSY FOR ROW MARKER	02 02 02 02
067	0503031376	RH CHAIN PROTECTION CAP	01 01 01 01
068	0503031377	LEFT CHAIN PROTECTION CAP	01 01 01 01
069	0511011417	HEX STUD 3/8" X 3/8" X 5.79"	04 04 04 04
070	0501010984	FLAT WASHER	18 18 18 18
071	0503010209	3/8" UNC BUTTERFLY NUT	06 06 06 06
072	0501069631	COVER FIXER	02 02 02 02
073	0502012328	DRAWBAR SUPPORT FRONT FIXATION	02 02 02 02
074	0502012329	DRAWBAR FIXATION REAR SUPPORT	02 02 02 02
075	0502012330	SUPPORT FIXER PIVOT	04 04 04 04
076	0503011084	3/4" X 5" BOLT	08 08 08 08
077	0501010322	FLAT WASHER	08 08 08 08
078	0503010023	SPRING WASHER	08 08 08 08
079	0503010014	3/4" NUT	08 08 08 08
080	0531012336	1.4" X 5.35" COUPLING SHAFT	02 02 02 02
081	0503030119	LOCK PIN	02 02 02 02
082	0511064808	DRAWBAR	01 01 01 01
083	0501051984	TRACTOR HITCH ASSY	01 01 01 01
084	0501047881	COUPLING SHAFT	01 01 01 01
085	0501054428	DRAWBAR TURNBUCKLE	01 01 01 01
086	0521010572	0.9" X 2.9" COUPLING SHAFT	01 01 01 01
087	0521010577	0.9" X 4.1" COUPLING SHAFT	01 01 01 01
088	0503030085	LOCK PIN	02 02 02 02
089	0511057239	SET DOOR HAND BOOK	01 01 01 01
089A	0503060100	HAND BOOK COMPARTMENT	01 01 01 01
089B	0503010267	NYLON CLAMP	01 01 01 01
089C	0503010363	5/16" X 1" BOLT	01 01 01 01
089D	0501010694	FLAT WASHER	01 01 01 01
089E	0503010179	SPRING WASHER	01 01 01 01
089F	0503010337	5/16" NUT	01 01 01 01
090	0501065677	STRUT	02 02 02 02
091	0502010477	UPPER CLIP	01 01 01 01
092	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	03 03 03 03
093	0501047895	ROD STOP	01 01 01 01
094	0501047896	1.18" ROD STOP	01 01 01 01
095	0501047897	1.38" ROD STOP	01 01 01 01
096	0501047898	1.57" ROD STOP	01 01 01 01
097	0521013867	DRAWBAR TRANSPORT LOCK	01 01 01 01
098	0541011767	HOSE FIXATION	01 01 01 01
099	0503031436	AIR DITRIBUTOR PUMP	01 01 01 01
100	0511044704	TURBINE ASSY FOR CARDAN	01 01 01 01
101	0511041364	DRIVE SHAFT	01 01 01 01
102	0503010479	1/2" X 3" BOLT	01 01 01 01
103	0531016190	4" X 43" AIR CONDUCTOR	01 01 01 01
104	0531015603	HOSE FIXATION SUPPORT	01 01 01 01
105	0503013357	3/8" SELF-ADJUSTING NUT	04 04 04 04
106	0503010019	1/2" SPRING WASHER	04 04 04 04
107	0503010060	1/2" NUT	04 04 04 04
108	0503010025	3/8 SPRING WASHER	03 03 03 03
109	0503010026	3/8" NUT	03 03 03 03
110	0503010027	SPRING WASHER	04 04 04 04
111	0503010013	5/8" NUT	04 04 04 04
112	0511017302	FLAT WASHER	02 02 02 02



PST3/PST3 SUPREMA
FRAME PST3 SUPREMA


Page 2
0909094337

Item	Code	Description	08 09 10 12
113	0503010257	1/8" X 1" COTTERPIN	02 02 02 02
114	0503010395	1/2" X 1-1/4" BOLT	02 02 02 02
115	0503010002	1800 GREASE FITTING	03 03 03 03
116	0909094459	HEX AXLE ASSEMBLY	01 01 01 01




Item	Code	Description	QT
01	0511061094	TURBINE SUPPORT	01
02	0501053716	BEARING ASSY OF THE LARGER FAN	01
02A	0502012016	CHAIN TENSIONER SUPPOT	01
02B	0503012778	MIDDLE LARGER AXLE	01
02C	0531010881	INTERMEDIARY UPPER SLEEVE	01
02D	0503012689	6306 DDU BEARING	02
02E	0503010325	VCA-118 VALVE	03
03	0503010920	1/2" X 1.1/2" BOLT	02
04	0511017302	FLAT WASHER	02
05	0503010395	1/2" X 1-1/4" BOLT	02
06	0503011336	1/2" HEX SELF ADJUSTING NUT	04
07	0501053886	PULLEY ASSY WITH FREE ROT	01
07A	0502012020	PULLEY HOUSING BEARING	01
07B	0501053888	TURBINE PULLEY ASSY	01
07C	0503011081	6207 2RS BEARING	02
07D	0531014518	INTERMEDIARY LOWER BUSHING BEARING	01
07E	0531014519	FLAT WASHER	01
07F	0531014527	FLAT WASHER	01
07G	0503010301	0.3" X 1.8" SPRING PIN	01
07H	0503011855	0.2" X 1.8" SPRING PIN	01
08	0501011194	1/2" X 1-3/4" BOLT	04
09	0521018517	FLAT WASHER	04
10	0503010019	1/2" SPRING WASHER	05
11	0503010020	1/2"NUT	04
12	0503013030	5/8" X 3.1/4" BOLT	01
13	0501012140	FLAT WASHER	01
14	0503010013	5/8" NUT	01
15	0503012780	LARGER TURBINE BELT	01
16	0531017194	FRONT COVER	01
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04
18	0503010025	3/8 SPRING WASHER	04
19	0503010026	3/8" NUT	04
20	0511040440	17.3" MIDDLE FAN	01


Item	Code	Description	QT
21	0503011775	6 X 6 X 35 KEYWAY	01
22	0503011774	PULLEY	01
23	0503010179	SPRING WASHER	03
24	0503011257	M 8 X 1,25 X 30 BOLT	01
25	0503011807	M 8 X 1,25 X 10 BOLT	01
26	0501054272	RIBBON FOR COVER CLOSING ASSY	01
27	0503031776	TURBINE RIBBON SEAL	02
28	0531017195	REAR COVER	01
29	0503013031	1/4" X 3.1/4" BOLT	15
30	0503012880	1/4" UNC SELF ADJUSTING NUT	17
31	0511014024	10 X 13 X 15,5 SLEEVE	02
32	0503012721	1/4" X 4" BOLT	02
33	0511017303	FLAT WASHER	40
34	0531010771	WASHER GUIDE	01
35	0531010757	TURBINE FAN	01
36	0531010770	FLAT WASHER	01
37	0503010179	SPRING WASHER	01
38	0503011429	M 8 X 1,25 X 40 BOLT	01
39	0531012760	TURBINE REAR COVER	01
40	0503013758	1/4" X 1-1/2" BOLT	04
41	0521018267	LARGER TURBINE FRONTAL COVER CENTER	01
42	0503031649	CONECTOR CENTER	01
43	0503012722	0.16" X 0.4" BLIND RIVET	16
44	0501056495	TURBINE OUTPUT SOCKET	01
44A	0503031812	TURBINE OUTPUT SOCKET	01
44B	0541017539	BUTTERFLY VALVE	01
44C	0511066760	VALVE FIXATION SUPPORT	01
44D	0503013813	1/4" UNC X 7/8" BOLT	02
44E	0503010143	SPRING WASHER	02
44F	0503010144	1/4" NUT	02
44G	0501013519	FLAT WASHER	01
44H	0503010060	1/2" NUT	01
45	0503013096	5/16" X 4" BOLT	02
46	0501010694	FLAT WASHER	04
47	0503010499	5/16" UNC BUTTERFLY NUT	02
48	0531015571	CARDAN SLEEVE HITCH	01




Item	Code	Description	QT
01	0511065689	114,3 X 506 CYLINDER CASE	01
02	0511065690	50,8 X 413 TURNBUCLE	01
03	0502011222	0.56" MOBILE COVER	01
04	0502011220	2" X 4.5" RING SUPPORT	01
05	0503010039	D-2000 SCRAPER RING	01
06	0503010991	PACKING 1870-2000-375-B	01
07	0503010952	W2-2250-500 PK RING G.E	01
08	0503011893	8-346 BACK-UP RING	01
09	0503011892	2-346 N 3006-9B O'RING	01
10	0503010345	2-218 N 3006-9B O'RING	01
11	0502011221	2.0" X 4.5" PISTON	01
12	0503011890	3750-3750 GASKET	02
13	0503011891	W2-4500-500 RING G.E	01
14	0503010817	1-1/4" SELF-ADJUSTING NUT	01
15	0503010003	1845 GREASE FITTING	01




Item	Code	Description	QT
001	0502012742	FIXER SUPPORT LADDER	02
002	0503010237	3/8" X 1" BOLT	04
003	0503010025	3/8 SPRING WASHER	04
004	0503010026	3/8" NUT	04
005	0511069636	LADDER	01
006	0503011179	3/8" X 2-1/4" BOLT	02
007	0501010984	FLAT WASHER	02
008	0503013357	3/8" SELF-ADJUSTING NUT	02




Item	Code	Description	QT
01	0511053904	ROW MARKER DISC	01
02	0503010023	SPRING WASHER	01
03	0503010014	3/4" NUT	01




Item	Code	Description	QT
01	0501067353	508 PST3 TURNBUCKLE	01
02	0511062887	RIGHT TURNBUCKLE	01
03	0511062888	LH TURNBUCKLE	01
04	0501061056	RH LOCKNUT WITH HANDLER	01
05	0503010002	1800 GREASE FITTING	02




Item	Code	Description	QT
01	0521010681	BUSHING COUPLING BODY	01
02	0502040556	HITCH TURNER	01
03	0521010639	COUPLING SHAFT	01
04	0503010571	1/4" X 1.1/2 COTTERPIN	01




Item	Code	Description	QT
01	0501068989	COUPLING SHAFT	01
03	0503031035	HAIR PIN	01




Item	Code	Description	QT
01	0501055638	HOMO JOINT WITH FEMALE BUSHING	01
01A	0503012607	TRACTOR HOMOCINETIC TERMINAL	01
01Aa	0521010638	0.5" X 3.3" QUIC HITCH COUPL SHAFT	01
01Ab	0503030518	0.5"X1.0"X 0.1" COMPRESSION SPRING	01
01Ac	0503010140	1/8" X 3/4" COTTERPIN	01
01B	0503012605	CROSSPIECE	02
01C	0503012606	CENTER BODY	01
01D	0503012604	HOMO TERMINAL W/ FEMALE BUSHING	01
01E	0503012618	2.1" X 2.0" X 31" TRIAN FEMALE TUB	01
01F	0503010843	0.4" X 3.3" SPRING PIN	01
01G	0503011878	0.2" X 3.3" SPRING PIN	01
02	0501055639	UNIVERSAL JOINT	01
02A	0503013132	CC292 TERMINAL	01
02B	0503012096	CROSSPIECE	01
02C	0503013187	TERMINAL	01
02D	0503012619	1.8" X 1.7" X 31" TRIAN MALE TUB	01
02E	0503011069	0.4" X 2.8" SPRING PIN	01
02F	0503011805	0.2" X 2.8" SPRING PIN	01
03	0503013189	PROTECTION ASSY	01
04	0503012023	CHAIN FOR UNIV JOINT PROTECTION	01



Item	Code	Description	QT
001	0501011543	5/8" X 4" BOLT	02
002	0511061835	PLOUGH SUPPORT	01
003	0503030012	HAIR PIN	01
004	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	02
005	0501011075	PIN	01
006	0502010175	HITCH CLAMP	01
007	0502011530	SUPPORT	01



Item	Code	Description	QT
01	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT	01
02	0503011882	QUICK CONNECTION COVER	01




Item	Code	Description	08 09 10 12
01	0511062157	CARRYING-WHEELS PIVOT SHAFT	01 00 00 00
02	0511062158	CARRYING-WHEELS PIVOT SHAFT	00 01 00 00
03	0511062159	CARRYING-WHEELS PIVOT SHAFT	00 00 01 00
04	0511062160	CARRYING-WHEELS PIVOT SHAFT	00 00 00 01
05	0521010569	COUPLING SHAFT	04 04 04 04
06	0503010571	1/4" X 1.1/2 COTTERPIN	08 08 08 08
07	0501017440	5/8" X 60.4" HEX AXLE	01 00 00 00
08	0501017441	5/8" X 69.3" HEX AXLE	01 00 00 00
09	0511010749	5/8" X 71.8" HEX AXLE	00 01 00 00
10	0511010750	5/8" X 79.1" HEX AXLE	00 01 00 00
11	0501017442	5/8" X 76.1" HEX AXLE	00 00 01 00
12	0501017443	5/8" X 85" HEX AXLE	00 00 01 00
13	0501017432	5/8" X 95.8" HEX AXLE	00 00 01 00
14	0501017433	5/8" X 2660" HEX AXLE	00 00 01 00
15	0503010257	1/8" X 1" COTTERPIN	10 10 12 12
16	0502040723	5/8 HEX AXLE BEARING SLEEVE	02 02 02 02
17	0502011299	BUSHING GEAR	02 02 02 02
18	0502010411	10Z GEAR	02 02 02 02
19	0511055018	WHEELSET WITH SPRING TRACTION	02 02 02 02
20	0521010530	COUPLING SHAFT	04 04 04 04
21	0503010140	1/8" X 3/4" COTTERPIN	10 10 16 16
22	0502011231	CENTRAL PULLEY	01 01 01 01
23	0511011309	AXLE PULLEY	01 01 01 01
24	0503010523	1/4" X 2" COTTERPIN	06 06 06 06
25	0503010002	1800 GREASE FITTING	02 02 02 02
26	0501110292	AGRICULTURAL BEARING	01 01 01 01
27	0501110293	AGRICULTURAL BEARING	01 01 01 01
28	0501110025	AGRICULTURAL BEARING	04 04 06 06
29	0521012469	1-3/8" X 59.3" AXLE	02 00 00 00
30	0521012470	1-3/8" X 70.0" AXLE	00 02 00 00
31	0521012471	1-3/8" X 75.2" AXLE	00 02 00 00
32	0521012472	1-3/8" X 94.8" AXLE	00 00 02 00
33	0501018466	FLAT WASHER	10 10 10 10


TRANSMISSION

0909090985


Item	Code	Description	08	09	10	12
34	0501051596	TRANSMISSION RIGHT DRIVING	02	02	04	04
35	0501069585	17Z P5/8" GEAR ROUND HOLE 1.4"	02	02	02	02
36	0511060719	DISARMMENT/ARM PIVOT ARM	02	02	04	04
37	0501067046	RATCHET RESET	02	00	02	04
38	0521015800	REAR LEVER FASTENER	00	02	02	00
39	0503010025	3/8 SPRING WASHER	04	06	06	04
40	0503010026	3/8" NUT	04	06	06	04
41	0521015778	RATCHET PIVOT ARM	00	02	02	00
42	0503030198	0.6" X 2.4" X 0.1" EXTENSION SPRING	02	02	04	04
43	0501069850	RATCHET BAR DES.	02	02	04	04
44	0503011082	C1/2" X 1.3/4" BOLT	02	02	04	04
45	0503010060	1/2" NUT	14	14	20	20
46	0501052560	AXLE MOTOR SLOW-MOVING ASSY	02	02	02	02
47	0511060718	MOTOR AXLE BEARING SUPPORTE	02	02	04	04
48	0521014436	MOTOR CHOCK SUPPORT BEARING AXLE	06	06	12	12
49	0521014021	1/2" X 4.5" X 5.4" FASTENER	02	02	04	04
50	0511017302	FLAT WASHER	04	04	08	08
51	0503010019	1/2" SPRING WASHER	12	12	16	16
52	0501042500	CHAIN TENSIONER ASSY	02	02	02	02
52A	0501067694	CHAIN TENSIONER	02	02	02	02
52B	0503030402	PULLEY	02	02	02	02
52C	0503010302	501019 SEAL RING	02	02	02	02
53	0503010003	1845 GREASE FITTING	02	02	02	02
54	0503030418	TRACTION SPRING	02	02	02	02
55	0501110036	HEX AXLE RIGHT BEARING ASSY	01	01	01	01
56	0501110037	5/8" HEX AXLE LEFT BEARING ASSY	01	01	01	01
57	0503010363	5/16" X 1" BOLT	04	04	04	04
58	0501010694	FLAT WASHER	04	04	04	04
59	0909090989	GEAR BOX ASSY	01	01	01	01
60	0503010951	REDUCTION	04	04	04	04
61	0503010920	1/2" X 1.1/2" BOLT	08	08	08	08
62	0503012698	2050 CHAIN X 53 LINK + MENDING	02	02	02	02
63	0503011647	50-1 CHAIN X 42 LINK + REDUCTION	02	02	02	02
64	0503012125	2050 CHAIN X 49 LINK + MENDING	02	02	02	02
65	0501065677	STRUT	02	02	02	02
66	0501011432	1-1/2" AND 1-5/8 GANG BOLT WRENCH	01	01	01	01
67	0503010780	N-2050 AMENDMENT	02	02	02	02




Item	Code	Description	QT
01	0501051818	WHEEL ARM ASSY	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER	01
03	0501058240	WHEEL FASTENER	01
04	0503010797	3/4" X 4" BOLT	04
05	0503010023	SPRING WASHER	04
06	0503010014	3/4" NUT	04
07	0503015344		01
08	0501010322	FLAT WASHER	04




Item	Code	Description	QT
001	0501053877	WHEEL ARM ASSY	01
002	0511053874	WITHOUT WHEELS TIRE	01
003	0503060112	WHEEL AND TIRE ASSY - 16-10 L	01
004	0503011167	M16 X 2 X 30 BOLT	02
005	0503010027	SPRING WASHER	02
006	0521012190	AXLE LOCK	02




Item	Code	Description	QT
001	0501067549	WHEEL SUPPORT	01
002	0501067177	WHEEL RIGHT ARM	01
003	0501067178	WHEEL LEFT ARM	01
004	0521010648	1.2" X 2.2" COUPLING SHAFT	02
005	0503010523	1/4" X 2" COTTERPIN	02
006	0503030425	1" X 6" X 0.2" TRACTION SPRING	02
007	0501013491	5/8" TENSIONER SPRING	02
008	0503010013	5/8" NUT	04




Item	Code	Description	QT
001	0501110737	CARRYING WHEEL HUB	01
001A	0502011284	CARRYING WHEEL HUB	01
001B	0501010127	9/16" X 1-7/8" LUG BOLT	06
001C	0503010035	9/16" CONIC NUT	06
002	0503010037	30207 ROLLER BEARING	02
003	0503010590	00674-B SEAL	02
004	0503010370	502072 CLAMPING RING (FOR AXLE)	02
005	0511015300	WHEELS AXLE	01
006	0502040663	ADJUSTMENT NUT	01
007	0502011339	15Z GEAR P 1.25"	01
008	0503010240	5/16" X 3/4" BOLT	06
009	0503011444	SPRING WASHER	06
010	0503010002	1800 GREASE FITTING	01




Item	Code	Description	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER	01
02	0501013491	5/8" TENSIONER SPRING	01
03	0503010013	5/8" NUT	02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING	01
05	0511069417	REAR TENSIONER	01
06	0501058243	INTERM CHAIN TENSIONER	01
07	0501058244	FIXED CHAIN TENSIONER	01
08	0501058242	MOVIL CHAIN TENSIONER	01



Item	Code	Description	QT
001	0503031825	AXLE MOTOR SLOW-MOVING	02
002	0503010240	5/16" X 3/4" BOLT	02
003	0503010179	SPRING WASHER	02
004	0503010337	5/16" NUT	02




Item	Code	Description	QT
01	0502011284	CARRYING WHEEL HUB	01
02	0503010037	30207 ROLLER BEARING	02
03	0511015300	WHEELS AXLE	01
04	0503010590	00674-B SEAL	02
05	0503010370	502072 CLAMPING RING (FOR AXLE)	02
06	0502040663	ADJUSTMENT NUT	01
07	0502011339	15Z GEAR P 1.25"	01
08	0503010240	5/16" X 3/4" BOLT	06
09	0503010179	SPRING WASHER	06
10	0501010127	9/16" X 1-7/8" LUG BOLT	06
11	0503013001	9/16" CONICAL NUT	06
12	0503010002	1800 GREASE FITTING	01
13	0521012190	AXLE LOCK	01
14	0503011167	M16 X 2 X 30 BOLT	01
15	0503010027	SPRING WASHER	01




Item	Code	Description	QT
00	0501049365	RIGHT GEAR BOX ASSY	01
00.	0501049366	LEFT GEAR BOX ASSY	01
01	0511060682	FERTILIZER GEAR BOX RIGHT SUPPORT	01
02	0511060683	FERTILIZER GEAR BOX LEFT SUPPORT	01
03	0501052236	CHAIN TENSIONER ASSY	01
04	0501052238	CHAIN TENSIONER ASSY	01
05	0501052237	CHAIN TENSIONER ASSY	01
06	0501052239	CHAIN TENSIONER ASSY	01
07	0502011758	REAR TENSIONER LEVER	02
08	0501048790	AXLE WITH LINK ASSY	02
09	0503010292	0.2" X 1.6" SPRING PIN	08
10	0503010002	1800 GREASE FITTING	02
11	0521017618	SEEP CONE MOV. AXLE	01
12	0521014548	FERTILIZER CONE MOV. AXLE	01
13	0521014144	FERTILIZER/SEEP CONE MOV. AXLE	01
14	0501052759	BEARING OF THE GEAR BOX ASSY	08
15	0503011953	5/16" X 1" BOLT	16
16	0501010694	FLAT WASHER	16
17	0503011444	SPRING WASHER	16
18	0503010337	5/16" NUT	16
19	0503030303	SUPPORT WASHER	05
20	0511061668	SEED SYSTEM DRIVE AXLE, CONE	01
21	0511060396	DRIVE/DRIVEN AXLE CONE	02
22	0511061667	SEED SYSTEM DRIVEN AXLE, CONE	01
23	0503012389	1/2 BALL	04
24	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING	04
25	0503010395	1/2" X 1-1/4" BOLT	04
26	0503012390	40-1 CHAIN X 93 LINK + MENDING	01
27	0503012391	40-1 CHAIN X 83 LINK + MENDING	01
28	0501054655	CHAIN TENSIONER ASSY	02
29	0501069874	17Z P 0.6" GEAR SQUARE HOLE 3/4"	01
30	0521018630	1.4" X SQUARE 0.8" WASHER	01
31	0511061759	22Z P12,70 FQ 3/4" GEAR	01


Item	Code	Description	QT
32	0502011325	12Z P 1.2" GEAR	01
33	0521010691	AXLE FASTENER	04
34	0503010373	1/4" X 2" BOLT	04
35	0501010694	FLAT WASHER	04
36	0503010143	SPRING WASHER	04
37	0503010144	1/4" NUT	04




Item	Code	Description	QT
001	0511060392	CHAIN TENSIONER	01
002	0503031366	RH TORSION SPRING	01
003	0503031805	11Z 1/2" GEAR	02
004	0503010302	501019 SEAL RING	02




Item	Code	Description	QT
001	0511060393	CHAIN TENSIONER ASSY	01
002	0503031366	RH TORSION SPRING	01
003	0503031805	11Z 1/2" GEAR	02
004	0503010302	501019 SEAL RING	02




Item	Code	Description	QT
001	0511060392	CHAIN TENSIONER	01
002	0503031367	SPRING	01
003	0503031805	11Z 1/2" GEAR	02
004	0503010302	501019 SEAL RING	02




Item	Code	Description	QT
001	0511060393	CHAIN TENSIONER ASSY	01
002	0503031367	SPRING	01
003	0503031805	11Z 1/2" GEAR	02
004	0503010302	501019 SEAL RING	02




Item	Code	Description	QT
001	0521012476	GEAR BOX LEVER AXLE	01
002	0503031369	LINK	01




Item	Code	Description	QT
001	0502011697	BEARING OF THE GEAR BOX	01
002	0503011410	ROLLER BEARING	01
003	0503011105	SEAL RING	01




Item	Code	Description	QT
01	0531019479	AXLE CHAIN GEAR	01
02	0503031805	11Z 1/2" GEAR	01
03	0511017302	FLAT WASHER	01
04	0503010019	1/2" SPRING WASHER	01
05	0503010060	1/2" NUT	01



Item	Code	Description	QT
001	0501110001	BOX BEARING ASSY	01
002	0502040379	FERTILIZER BOX BEARINGREEL	01
003	0503010372	501050 CLAMPING RING (FOR AXLE)	01
004	0503010002	1800 GREASE FITTING	01



Item	Code	Description	QT
01	0521017590	GUIDE AXLE	01
02	0503010542	501045 CLAMPING RING (FOR AXLE)	01
03	0521017593	FLAT WASHER	01
04	0501019734	FLAT WASHER	02
05	0502011329	14Z GEAR WITH RIGHT DRAGGER	01
06	0503030553	2.3\"X 2.5\"X 0.2\"COMPRESSION SPRING	01
07	0501019735	FLAT WASHER	02
08	0502010710	RIGHT CAM, SMALLER	01
09	0502010711	RIGHT CAM,LARGER	01
10	0502012009	DRIVING AXLE RIGHT FOLLOWER	01
11	0502011996	SLLEVE FIXER	01
12	0503030678	1/2\"X1-1/2\"BOLT	01
13	0503010060	1/2\" NUT	01
14	0503010003	1845 GREASE FITTING	02




Item	Code	Description	08 09 10 12
01	0501069245	RIGHT BOX FERTILIZER	01 00 00 00
02	0501069247	RIGHT BOX FERTILIZER	00 01 00 00
03	0501069249	RIGHT BOX FERTILIZER	00 00 01 00
04	0501069251	RIGHT BOX FERTILIZER	00 00 00 01
05	0501069246	LEFT BOX FERTILIZER	01 00 00 00
06	0501069248	LEFT BOX FERTILIZER	00 01 00 00
07	0501069250	LEFT BOX FERTILIZER	00 00 01 00
08	0501069252	LEFT BOX FERTILIZER	00 00 00 01
09	0501050272	DISTRIBUTOR OF RIGHT FERTILIZER	03 02 04 05
09A	0501110120	FERTILIZER DISTRIBUTOR BODY	08 09 10 12
09Aa	0502010596	FERTILIZER DISTRIBUTOR BODY	08 09 10 12
09Ab	0511013789	FERTILIZER TUBE	08 09 10 12
09B	0503013155	1/4" X 1.1/4" COTTERPIN	16 18 20 24
09C	0501017391	3/4" X 14.3" SQUARE SHAFT	06 05 08 10
09D	0503030275	AGRICULTURAL BEARING	16 18 20 24
09E	0501013774	GREASE SEAL	08 09 10 12
09F	0503030303	SUPPORT WASHER	08 09 10 12
09G	0501010637	FLAT WASHER	08 09 10 12
09H	0511017137	FLAT WASHER	08 09 10 12
09I	0503031164	RIGHT HELICAL CONDUTOR	04 04 05 06
09J	0521010309	SLEEVE INTER	08 09 10 12
09K	0503012826	CREASE FITTING	08 09 10 12
09L	0503011962	GREASE FITTING	08 09 10 12
10	0501050452	RIGHT FERTILIZER DISTRIBUTOR	01 00 00 00
10A	0501017393	3/4" X 18.1" SQUARE SHAFT	02 00 00 00
11	0501050458	RIGHT ABONO DISTRIBUTOR	00 01 00 00
11A	0511011253	3/4" X 18.4" LH SQUARE SHAFT	00 02 00 00
12	0501050454	RIGHT ABONO DISTRIBUTOR	00 00 01 00
12A	0501017394	3/4" X 19.4" SQUARE SHAFT	00 00 02 00
13	0501050460	RIGHT FERTILIZER DISTRIBUTOR	00 01 00 00
13A	0511011252	3/4" X 24.4" SQUARE SHAFT	00 01 00 00
14	0501050456	RIGHT FERTILIZER DISTRIBUTOR	00 00 00 01
14A	0501017392	3/4" X 24.4" SQUARE SHAFT	00 00 00 02

FERTILIZER BOX


0909090977

Item	Code	Description	08	09	10	12
15	0501050459	LH FERTILIZER METERING	00	01	00	00
15A	0511062153	3/4" X 13.6"SQUARE SHAFT	00	01	00	00
16	0501050273	LH FERTILIZER METERING	03	03	04	05
16A	0503031165	LEFT HELICAL CONDUTOR	04	05	05	06
17	0501050453	LH FERTILIZER METERING	01	00	00	00
18	0501051714	LH FERTILIZER METERING	00	01	00	00
19	0501050455	LH FERTILIZER METERING	00	00	01	00
20	0501050457	LH FERTILIZER METERING	00	00	00	01
21	0501011643	3/8 X 1"BOLT	32	32	40	48
22	0503010025	3/8 SPRING WASHER	36	36	44	52
23	0503010026	3/8" NUT	40	40	48	48
24	0501050274	BOX BEARING ASSY	02	02	02	02
25	0501010161	1/2" X 1.1/4" BOLT	06	06	06	06
26	0503010019	1/2" SPRING WASHER	06	06	06	06
27	0503010060	1/2" NUT	06	06	06	06
28	0501017476	DRAGING	06	06	08	10
29	0503010397	5/16" X 1-3/4" BOLT	06	06	08	10
30	0503010337	5/16" NUT	24	24	28	32
31	0511016646	1" X 3/4" SQUARE SHAFT GUIDE	00	01	00	00
32	0521013058	3/4" SQUARE SHAFT 2" GUIDE	00	00	00	01
33	0511061759	22Z P12,70 FQ 3/4" GEAR	02	02	02	02
34	0521010691	AXLE FASTENER	02	02	02	02
35	0503010373	1/4" X 2" BOLT	02	02	02	02
36	0503010143	SPRING WASHER	02	02	02	02
37	0503010144	1/4" NUT	02	02	02	02
38	0503010834	1/2 X 1 BOLT	02	02	02	02
39	0501069259	FERTILIZER BOX COVER	02	00	00	00
40	0501069260	FERTILIZER BOX COVER	00	02	00	00
41	0501069261	FERTILIZER BOX COVER	00	00	02	00
42	0501069262	FERTILIZER BOX COVER	00	00	00	02
43	0503010421	5/16" X 1-1/2" BOLT	04	04	04	04
44	0521011116	COVER PIVOT BUSHING	04	04	04	04
45	0501010694	FLAT WASHER	18	18	18	18
46	0503010179	SPRING WASHER	04	04	04	04
47	0521011117	PIVOT SPRING AXLE	04	04	04	04
48	0501010984	FLAT WASHER	08	04	04	04
49	0521011120	COVER PIVOT SHAFT	04	04	04	04
50	0503010140	1/8" X 3/4" COTTERPIN	08	08	08	08
51	0503031329	COMPRES SPRING	04	04	04	04
52	0503011907	PMC 594-S NYLON LUG	02	02	02	02
53	0503011957	PMC 596-S NYLON LUG	02	02	02	02
54	0503010363	5/16" X 1" BOLT	08	08	08	08
55	0503031363	13 X 12 PLUG	08	08	08	08
56	0503031050	CURVED CONDUCTOR	04	04	04	04
57	0503010246	CLAMP	04	04	04	04
58	0503031900	FERTILIZER BEAN LIP	04	05	06	06
59	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04	04	04	04




Item	Code	Description	08	09	10	12
01	0511060965	FERTILIZER BEAN RIGHT SUPPORT	01	00	00	00
02	0511061067	FERTILIZER BEAN RIGHT SUPPORT	00	01	00	00
03	0511061019	FERTILIZER BEAN RIGHT SUPPORT	00	00	01	00
04	0511061062	FERTILIZER BEAN RIGHT SUPPORT	00	00	00	01
05	0511060966	FERTILIZER BEAN LEFT SUPPORT	01	00	00	00
06	0511061068	FERTILIZER BEAN LEFT SUPPORT	00	01	00	00
07	0511061020	FERTILIZER BEAN LEFT SUPPORT	00	00	01	00
08	0511061063	FERTILIZER BEAN LEFT SUPPORT	00	00	00	01
09	0501052423	LH FERTILIZER METERING	03	03	04	04
09A	0501110082	FERTILIZER DISTRIBUTOR BODY	08	09	10	12
09Aa	0511013789	FERTILIZER TUBE	08	09	10	12
09B	0503013155	1/4" X 1.1/4" COTTERPIN	16	18	20	24
09C	0501017391	3/4" X 14.3" SQUARE SHAFT	06	05	08	08
09D	0503030275	AGRICULTURAL BEARING	16	18	20	24
09E	0501013774	GREASE SEAL	08	09	10	12
09F	0503030303	SUPPORT WASHER	08	09	10	12
09G	0501010637	FLAT WASHER	08	09	10	12
09H	0511017137	FLAT WASHER	08	09	10	12
09I	0503031165	LEFT HELICAL CONDUTOR	04	05	05	06
09J	0521010309	SLEEVE INTER	08	09	10	12
09K	0503012826	CREASE FITTING	08	09	10	12
09L	0503011962	GREASE FITTING	08	09	10	12
10	0501052424	LH FERTILIZER METERING	01	00	00	00
10A	0501017393	3/4" X 18.1" SQUARE SHAFT	02	00	00	00
11	0501052467	LH FERTILIZER METERING	00	01	00	00
11A	0511011253	3/4" X 18.4" LH SQUARE SHAFT	00	02	00	00
12	0501052449	LH FERTILIZER METERING	00	00	01	02
12A	0501017394	3/4" X 19.4" SQUARE SHAFT	00	00	02	04
13	0501053701	LH FERTILIZER METERING	00	01	00	00
13A	0511062153	3/4" X 13.6" SQUARE SHAFT	00	01	00	00
14	0501052400	RIGHT FERTILIZER METERING	03	02	04	04
14A	0503031164	RIGHT HELICAL CONDUTOR	04	04	05	06
15	0501052465	RIGHT FERTILIZER DISTRIBUTOR	00	01	00	00


Item	Code	Description	08	09	10	12
15A	0511011252	3/4" X 24.4"SQUARE SHAFT	00	01	00	00
16	0501052421	RIGHT FERTILIZER METERING	01	00	00	00
17	0501052461	RIGHT FERTILIZER METERING	00	01	00	00
18	0501052448	RIGHT FERTILIZER METERING	00	00	01	02
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	36	44	48	56
20	0501011517	FLAT WASHER	56	60	64	72
21	0503010025	3/8 SPRING WASHER	40	44	48	56
22	0503010026	3/8" NUT	40	44	48	56
23	0501050274	BOX BEARING ASSY	02	02	02	02
24	0501010161	1/2" X 1.1/4" BOLT	06	06	06	06
25	0503010019	1/2" SPRING WASHER	06	06	06	06
26	0503010060	1/2" NUT	06	06	06	06
27	0501017476	DRAGING	06	07	08	10
28	0503010397	5/16" X 1-3/4" BOLT	06	07	08	10
29	0503010337	5/16" NUT	12	14	16	20
30	0503010004	1890 GREASE FITTING	02	02	02	03
31	0521013058	3/4" SQUARE SHAFT 2" GUIDE	00	00	03	00
32	0503010571	1/4" X 1.1/2 COTTERPIN	00	00	03	00
33	0511061759	22Z P12,70 FQ 3/4" GEAR	02	02	02	02
34	0521010691	AXLE FASTENER	02	02	02	02
35	0503010373	1/4" X 2" BOLT	02	02	02	02
36	0501010694	FLAT WASHER	02	02	02	02
37	0503010143	SPRING WASHER	02	02	02	02
38	0503010144	1/4" NUT	02	02	02	02
39	0503060636	COVER BOX RIGHT FERTILIZER	01	00	00	00
39A	0503031948	SILO RIGHT FERTILIZER	01	00	00	00
39B	0503031950	TUBE SILO FERTILIZER	01	00	00	00
40	0503060637	COVER BOX LEFT FERTILIZER	01	00	00	00
40A	0503031949	SILO LEFT FERTILIZER	01	00	00	00
40B	0503031950	TUBE SILO FERTILIZER	01	00	00	00
41	0503060638	COVER BOX RIGHT FERTILIZER	00	02	00	00
41A	0503031951		00	02	00	00
41B	0503031953		00	02	00	00
42	0503060639	COVER BOX LEFT FERTILIZER	00	02	00	00
42A	0503031952		00	02	00	00
42B	0503031953		00	02	00	00
43	0503060640	COVER BOX RIGHT FERTILIZER	00	00	01	00
43A	0503031954		00	00	01	00
43B	0503031956		00	00	01	00
44	0503060641	COVER BOX LEFT FERTILIZER	00	00	01	00
44A	0503031955		00	00	01	00
44B	0503031956		00	00	01	00
45	0503060642	COVER BOX RIGHT FERTILIZER	00	00	00	01
45A	0503031957		00	00	00	01
45B	0503031959		00	00	00	01
46	0503060643	COVER BOX LEFT FERTILIZER	00	00	00	01
46A	0503031958		00	00	00	01
46B	0503031959		00	00	00	01
47	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE	04	04	04	04
48	0503031900	FERTILIZER BEAN LIP	04	04	04	04
49	0503010849	3/8" X 1-1/2" BOLT	04	04	04	04
50	0511016646	1" X 3/4" SQUARE SHAFT GUIDE	00	01	00	00
51	0501052810	TRANSMISSION CHAIN TENSIONER ASSY	02	02	02	02



Item	Code	Description	QT
01	0541011713	TENSIONER CHAIN LOWER AXLE	01
02	0503031805	11Z 1/2" GEAR	01
03	0503010302	501019 SEAL RING	01
04	0511017302	FLAT WASHER	01
05	0503010019	1/2" SPRING WASHER	01
06	0503010060	1/2" NUT	01



Item	Code	Description	QT
01	0501049135	RH SHORT FERTILIZER ROW	01
02	0501048764	RH LONG FERTILIZER ROW ASSY	01
03	0511040056	RH SHORT SEEP ROW ASSY	01
04	0511040057	LH SHORT SEEP ROW ASSY	01
04.	0511040058	LONG SEEP ROW ASSY	01
05	0501049153	SPINDLE LONG FERT. ROW ASSY	01
06	0501049153	SPINDLE LONG FERT. ROW ASSY	01
07	0501052767	SCARIFIER SPINDLE	01
08	0501052768	SCARIFIER SPINDLE	01




Item	Code	Description	QT
00	0511040056	RH SHORT SEEP ROW ASSY	01
00.	0511040057	LH SHORT SEEP ROW ASSY	01
00..	0511040058	LONG SEEP ROW ASSY	01
01	0511061761	SHORT SEEP ROW ARM	01
02	0511061762	LONG SEEP ROW ARM	01
03	0502011830	ARTICULACION SUPPORT	01
04	0503010752	1/2" X 3.1/2" BOLT	04
05	0503011440	SPRING WASHER	08
06	0503010060	1/2" NUT	11
07	0502011561	BEARING SEMI	01
08	0502010426	UPPER BEARING SEMI	02
09	0503010479	1/2" X 3" BOLT	04
10	0501013354	FLAT WASHER	03
11	0502011400	18Z CONICAL GEAR	01
12	0502011296	1/2 HEX AXLE BEARING SLEEVE	01
13	0502011505	18Z CONICAL GEAR	01
14	0521018079	SEEP ROW DRAWBAR COVER	01
15	0503011441	SPRING WASHER	02
16	0503010298	1/4" X 1/2" BOLT	02
17	0501013413	RIGHT SIDE BASE	01
18	0501013414	LEFT SIDE BASE	01
19	0501052978	RIGHT 15" X 15" DOUBLE DISC	01
20	0501052979	LH 15" X 15" DOUBLE DISC	01
21	0503010723	7/16" X 4" BOLT	02
22	0503011446	SPRING WASHER	04
23	0503010244	7/16" NUT	05
24	0501052945	DEPTH CONTROL WHEELS ASSY	01
25	0503011195	7/16" X 1.3/4" BOLT	01
26	0503010180	7/16" SPRING WASHER	01
27	0503013233	7/16 NUT	01
28	0503010851	7/16" X 3.1/2" BOLT	01
29	0521018077	1/2" X 58.6" HEX AXLE	01
30	0521018078	1/2" X 66.5" HEX AXLE	01


SEED ROW

0909090973

Item	Code	Description	QT
31	0501013352	FLAT WASHER	02
32	0502011411	10Z CONICAL GEAR	01
33	0502011418	40Z CONICAL GEAR	01
34	0511018700	AXLE	01
35	0503010848	5/16" X 3.1/2" BOLT	02
36	0503011444	SPRING WASHER	07
37	0503010337	5/16" NUT	08
38	0503010850	7/16" X 3" BOLT	01
39	0503010002	1800 GREASE FITTING	02
40	0503011099	GREASE FITTING	02
41	0511060376	SEEP SPRING GUIDE	01
42	0521010542	COUPLING SHAFT	01
43	0503010257	1/8" X 1" COTTERPIN	02
44	0501013753	FLAT WASHER	01
45	0503031339	1" X 19" X 0.1" COMPRESSION SPRING	01
46	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING	01
47	0502040725	SPRING BUSHING LOCK GUIDE	02
48	0503010834	1/2 X 1 BOLT	02
49	0503010013	5/8" NUT	03
50	0502010890	SPRING ROD SUPPORT	01
51	0502010891	SPRING CHOCK SUPPORT VARON	01
52	0503010395	1/2" X 1-1/4" BOLT	01
53	0503010920	1/2" X 1.1/2" BOLT	01
54	0501052234	SEED SISTEM ASSY	01
54A	0502020324	SEED BOX SUPPORT	01
54B	0503031508	COVER GREEN BEAM SEED YELLOW	01
54C	0503010178	5/16" X 7/8" BOLT	04
54D	0501010694	FLAT WASHER	04
54E	0501051094	SEED DISTRIB ASSY WITH DOUB PULLEY	01
54F	0503030083	3/8" X 3/8" X 1.6" STUD	01
54G	0503010675	5/16" X 2.1/4" BOLT	01
54H	0502010408	SEED DISC LOWER TRAIL	01
54I	0521010536	0.3" X 3.8" COUPLING SHAFT	01
54J	0503010140	1/8" X 3/4" COTTERPIN	01
54K	0502020564	SOYBEAN DISC WITH 100 HOLES	01
54L	0502020565	SOYBEAN DISC WITH 90 HOLES	01
54M	0502020518	CORN DISC	01
54N	0502020519	CORN DISC	01
54O	0501013355	DISC SEAT	01
54P	0501013356	DISC SEAT	01
54Q	0511013590	HEX STUD 3/8" X 3/8"	01
54R	0511013494	DEFLECTOR	01
54S	0503010209	3/8" UNC BUTTERFLY NUT	02
55	0502011212	SEED BOX FIXING BASE	01
56	0501058015	FAST LOCK ASSY	01
57	0502012314	SEED BOX FIXING BASE	01
58	0501058009	FAST LOCK ASSY	01
59	0511017302	FLAT WASHER	01
60	0501013714	STABILIZER BAR	01
61	0501018652	CORN STABILIZER BAR	01
62	0503010019	1/2" SPRING WASHER	01
63	0521010505	13,50 X 19,00 X 21,50 SLEEVE	01
64	0502011567	FERTILIZER ROW SUPPORT	01
65	0503010762	5/8" X 3-12" BOLT	02
66	0503010027	SPRING WASHER	02
67	0503010740	1/2" X 2" BOLT	01




Item	Code	Description	QT
00	0501052978	RIGHT 15" X 15" DOUBLE DISC	01
00.	0501052979	LH 15" X 15" DOUBLE DISC	01
01	0502011184	15" X 15" DOUBLE DISC SUPPORT	01
02	0502011183	15"X15" LW SEED UNAL DOUB-DISC SUPP	01
03	0502011930	DOUBLE DISC COULTER BOX	02
04	0503010598	30204 BALL BEARING	04
05	0521019154	RIGHT DOUB DISC HUB	01
06	0521019148	LEFT DOUBLE DISC HUB	01
07	0503011112	SEAL 02376-BRG	02
08	0511011927	DUST CLOAK	02
09	0503030282	3/4" CASTLE NUT	02
10	0503010257	1/8" X 1" COTTERPIN	02
11	0521019178	COVER DEPTH	02
12	0603022042	13" X 0.12" PLAIN COULTER BLADE	02
13	0503010546	5/16" X 7/8" BOLT	12
14	0503010337	5/16" NUT	12
15	0501017541	RH DOUBLE DISC SCRAPER	01
16	0501017542	LH DOUBLE DISC SCRAPER	01
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01
18	0501010984	FLAT WASHER	02
19	0503010025	3/8 SPRING WASHER	01
20	0503010026	3/8" NUT	01
21	0503030482	SEED SOCKET	01
22	0503013758	1/4" X 1-1/2" BOLT	06
23	0503010143	SPRING WASHER	06
24	0503030757	2.9" X 2" X 0.02" JOINT	02
25	0511015098	FLAT WASHER	02




Item	Code	Description	QT
00	0501051094	SEED DISTRIB ASSY WITH DOUB PULLEY	01
00A	0501050077	SEED DISTRIB ASSY W/ SIMPLE PULLEY	01
01	0503030381	SEED DISTRIBUTOR BOX	01
02	0502010447	TRIGGER	02
03	0501013467	KEY AXLE	01
04	0503030378	0.4" X 1.1" X 0.03" SPRING	03
05	0501013466	KEY LIMITER AXLE	01
06	0501051119	DOUBLE PULLEY ROCKER'S	01
06A	0503031129	DOUBLE PULLEY ROCKER ARM	01
06B	0503031128	5Z PLASTIC DOUB PULLEY FOR SOYBEAN	02
06C	0503031130	PIN OF THE PULLEY	01
06D	0503011853	503050 CLAMPING RING (FOR HOLE)	01
07	0501013468	ROCKER ARM AXLE, OF THE PULLEY	01
08	0503030377	SCRAPER	01
09	0501050120	LARGER WALKING BEAM ASSY	01
09A	0503030379	LARGER ROCKER ARM	01
09B	0502060001	PLASTIC PULLEY FOR MAIZE	01
09Ba	0503030558	PLASTIC PULLEY FOR MAIZE	01
09C	0503010803	3/16" X 3/4" BOLT	01
09D	0503010669	FLAT WASHER	01
09E	0503010667	3/16" NUT	02
10	0502020584	BEAN SEED DISC 64 HOLE OBLONG	01
10A	0502020585	COTTON SEED DISC 64 HOLE OBLONG	01
11	0502020351	CORN SEED DISC 24 HOLE	01
11A	0502020366	CORN SEED DISC 24 HOLE	01
11B	0502020331	BEAN SEED DISC 26 HOLE OBLONG	01
11C	0502020408	BEAN SEED DISC 38 HOLE OBLONG	01
11D	0502020353	SORGO BEET SEED DISC 40 HOLE	01
11E	0502020346	RICE SEED DISC 40 OBLONG	01
11F	0502020560	SUNFLOWER SEED DISC 28 OBLONG	01
11G	0502020554	SUNFLOWER SEED DISC 28 OBLONG	01
11H	0502020340	DISC WITHOUT HOLE	01
11I	0502020367	DISC WITHOUT HOLE	01

Item	Code	Description	QT
11J	0502020328	SOYBEAN SEED DISC 34 OBLONG	01
11K	0503031678	DISC WITHOUT HOLE	01
11L	0502020327	DISC WITHOUT HOLE	01
11M	0503031677	DISC WITHOUT HOLE	01
11N	0502020583	PEANUT SEED DISC 20	01
11O	0502020419	COTTON SEED DELINTED 40	01
11P	0502020407	BEAN SEED DISC	01
11Q	0502020333	BEAN SEED DISC	01
12	0511017897	DISC SEAT	01




Item	Code	Description	QT
01	0502012086	DEPTH CONTROL SUPPORT	01
02	0511012244	DEPTH CONTROL WHEEL AXLE	01
03	0503010256	3/8" X 3/4" BOLT	01
04	0521015818	FLAT WASHER	04
05	0511017302	FLAT WASHER	02
06	0503010019	1/2" SPRING WASHER	02
07	0503010834	1/2 X 1 BOLT	02
08	0501052297	DEPTH WHEELS REGULATOR ASSY	01
08A	0502011689	1/8" DEPTH CONTROL LEVER	01
08B	0503030975	0.9" X 1.5" X 0.1" SPRING	01
08C	0502011688	SEED SIST CONTROL DEPTH LEVER	01
08D	0511015976	FLAT WASHER	01
08E	0503010257	1/8" X 1" COTTERPIN	01
08F	0511060699	DEPTH WHEEL STOP	01
08G	0503010071	3/16" X 1" COTTERPIN	01
09	0521019093	0.6" X 2.7" PIVOT SHAFT	01
10	0503010778	1/8" X 1.1/2" COTTERPIN	01
11	0502011699	RIGHT DEPTH WHEEL ARM	01
12	0502011698	LEFT DEPTH WHEEL ARM	01
13	0501052627	DEPHT WHEELS BOX	02
13A	0502011907	DEPTH CONTROL WHEEL HUB	02
13B	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK	02
13C	0503010269	6204 BALL BEARING	04
13D	0521010489	SLEEVE SPACER	02
13E	0503010689	SEAL 00763-BR	02
13F	0503011105	SEAL RING	02
13G	0503010878	5/8" SELF ALIGNING NUT	02
13H	0521019178	COVER DEPTH	02
13I	0503030757	2.9" X 2" X 0.02" JOINT	02
13J	0503010298	1/4" X 1/2" BOLT	16
13K	0503011441	SPRING WASHER	06
13L	0503010691	1/4" GREASE FITTING	02
14	0503010358	5/16" X 5/8" BOLT	08


Item	Code	Description	QT
15	0503010179	SPRING WASHER	08
16	0503013816	5/16" LOCKNUT	08
17	0501052538	DEPTH CONTROL WHEEL RUBBER BAND	02
17A	0503030551	DEPTH CONTROL WHEEL RUBBER BAND	02
17B	0521010832	RIM FLANGE	04
17C	0503010298	1/4" X 1/2" BOLT	10
17D	0503010143	SPRING WASHER	10
17E	0503010144	1/4" NUT	10
18	0503010740	1/2" X 2" BOLT	02
19	0503011440	SPRING WASHER	02
20	0503010060	1/2" NUT	02
21	0503010002	1800 GREASE FITTING	04
22	0501052935	PRESS WHEELS ASSY	01




Item	Code	Description	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND	01
02	0521010832	RIM FLANGE	02
03	0503010298	1/4" X 1/2" BOLT	05
04	0503010143	SPRING WASHER	05
05	0503010144	1/4" NUT	05



Item	Code	Description	QT
01	0501052908	PRESS WHEELS ASSY	02
02	0502011757	PRESS REGULATOR	01
03	0521014508	FLAT WASHER	10
04	0503010706	1/2" X 4.1/2" BOLT	02
05	0503011336	1/2" HEX SELF ADJUSTING NUT	02
06	0511060673	PRESS WHEELS REGULATOR	01
07	0503010849	3/8" X 1-1/2" BOLT	02
08	0503010025	3/8 SPRING WASHER	02
09	0503010026	3/8" NUT	02
10	0541016906	PRESS WHEELS REGULATOR BODY	01
11	0521010539	0.3" X 1.2" COUPLING SHAFT	01
12	0503010257	1/8" X 1" COTTERPIN	01
13	0503030805	1.6" X 6" X 0.2" TRACTION SPRING	01
14	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE	02



Item	Code	Description	QT
01	0502011919	PRESS WHEEL HUB	01
02	0502011877	PRESS WHEEL HUB	01
03	0503010269	6204 BALL BEARING	02
04	0521018922	PRESS WHEEL PASSANG AXLE	02
05	0503012734	SEAL 01556 BR	02
06	0521018921	DUST CLOAK	02
07	0503010691	1/4" GREASE FITTING	01
08	0521018928	PRESS WHEEL RIM	02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND	01
10	0503010011	5/16" X 1/2" BOLT	06
11	0503010358	5/16" X 5/8" BOLT	03
12	0503013816	5/16" LOCKNUT	03




Item	Code	Description	CT LG
00	0501049135	RH SHORT FERTILIZER ROW	01 00
00.	0501048763	LH SHORT FERTILIZER ROW	01 00
00..	0501048764	RH LONG FERTILIZER ROW ASSY	00 01
01	0501052430	LH SHORT FERTILIZER ROW ARM	01 00
01A	0503010060	1/2" NUT	03 03
01B	0501052977	15 X 15 LEF FERT UNAL DOUB-DISC ASSY	01 00
01C	0511018662	SPACING PLATE	04 04
01D	0503010547	1/2" X 4" BOLT	02 02
01E	0503011440	SPRING WASHER	02 02
02	0501052430	LH SHORT FERTILIZER ROW ARM	01 00
03	0501052287	LONG FERTILIZER ROW ARM	00 01
03A	0511064232	LONG FERTILIZER ROW ARM	00 01
03B	0501052976	15 X 15 RIGHT FERT UNAL DOUB-DISC ASSY	00 01
04	0501010066	3/4" X 9" BOLT	01 01
05	0521017831	SUPPORT SLEEVE SPACER	02 02
06	0511017232	FLAT WASHER	02 02
07	0503010023	SPRING WASHER	01 01
08	0503010014	3/4" NUT	01 01
09	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	00 01
10	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	01 00
11	0501069303	SPRING ROD	01 01
12	0521010642	FERT.SPRING GUIDE FIXER COUPL SHAFT	01 01
13	0503010257	1/8" X 1" COTTERPIN	01 01
14	0502040534	SPRING GUIDE BUSHING LOCK	01 01
15	0501018535	1/2 X 1 BOLT	01 01
16	0501013753	FLAT WASHER	01 01
17	0503031339	1" X 19" X 0.1" COMPRESSION SPRING	01 01
18	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING	01 01
19	0502011450	SPRING ROD SUPPORT	01 01
20	0502010891	SPRING CHOCK SUPPORT VARON	01 01
21	0503030679	1/2" X 1-1/4" BOLT	01 01
22	0503030678	1/2"X1-1/2"BOLT	01 01
23	0503030391	RIGHT FERTILIZER SOCKET	01 00




PST3/PST3 SUPREMA
ROW FERTILIZER ASSY

Page 42
0909092764


Item	Code	Description	CT LG
24	0503030392	LEFT FERTILIZER SOCKET	00 01
25	0503030408	10 X 2 X 390 HOSE	01 01
26	0503031076	2" HOSE CLAMP	02 02
27	0501110231	SCARIFIER SPINDLE	01 01
28	0511017969	0.1" SPACING PLATE	02 02



Item	Code	Description	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT	01
02	0502011930	DOUBLE DISC COULTER BOX	02
03	0503010598	30204 BALL BEARING	04
04	0503011112	SEAL 02376-BRG	02
05	0521019148	LEFT DOUBLE DISC HUB	01
06	0503030282	3/4" CASTLE NUT	02
07	0503010257	1/8" X 1" COTTERPIN	02
08	0603022042	13" X 0.12" PLAIN COULTER BLADE	02
09	0503010546	5/16" X 7/8" BOLT	12
10	0503010337	5/16" NUT	12
11	0511015098	FLAT WASHER	06
12	0511011927	DUST CLOAK	02
13	0503030757	2.9" X 2" X 0.02" JOINT	02
14	0521019178	COVER DEPTH	02
15	0503014729	1/4" UNF X 1/2" BOLT	06
16	0503011441	SPRING WASHER	06
17	0501017542	LH DOUBLE DISC SCRAPER	01
18	0501017541	RH DOUBLE DISC SCRAPER	01
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01
20	0501010984	FLAT WASHER	02
21	0503011443	SPRING WASHER	01
22	0503010026	3/8" NUT	01
23	0502070062	SCRAPER	01
24	0503011402	0.2" X 0.8" SPRING PIN	01
25	0521019154	RIGHT DOUB DISC HUB	01



Item	Code	Description	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT	01
02	0502011930	DOUBLE DISC COULTER BOX	02
03	0503010598	30204 BALL BEARING	04
04	0503011112	SEAL 02376-BRG	02
05	0521019148	LEFT DOUBLE DISC HUB	01
06	0503030282	3/4" CASTLE NUT	02
07	0503010257	1/8" X 1" COTTERPIN	02
08	0603022042	13" X 0.12" PLAIN COULTER BLADE	02
09	0503010546	5/16" X 7/8" BOLT	12
10	0503010337	5/16" NUT	12
11	0511015098	FLAT WASHER	06
12	0511011927	DUST CLOAK	02
13	0503030757	2.9" X 2" X 0.02" JOINT	02
14	0521019178	COVER DEPTH	02
15	0503014729	1/4" UNF X 1/2" BOLT	06
16	0503011441	SPRING WASHER	06
17	0501017542	LH DOUBLE DISC SCRAPER	01
18	0501017541	RH DOUBLE DISC SCRAPER	01
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01
20	0501010984	FLAT WASHER	02
21	0503011443	SPRING WASHER	01
22	0503010026	3/8" NUT	01
23	0502070062	SCRAPER	01
24	0503011402	0.2" X 0.8" SPRING PIN	01
25	0521019154	RIGHT DOUB DISC HUB	01




Item	Code	Description	CT LG
00	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	01 00
00.	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	00 01
01	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01 00
02	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE	00 01
03	0502012368	BLADE DISC SUPPORT AXLE	01 01
04	0503010361	SPRING PIN	01 01
05	0521014137	RIGHT ARM OF THE BLADE DISC	01 01
06	0521014138	SUPPORT ARM LEFT BALDE DISC	01 01
07	0501067323	SPRING REGULATOR	01 01
08	0521010452	SLEEVE	01 01
09	0503013185	3/4" X 5-1/2" BOLT	01 01
10	0503011442	3/4" SPRING WASHER	01 01
11	0503010014	3/4" NUT	03 03
12	0502020393	SPRING UPPER SUPPORT	01 01
13	0502020394	SPRING SUPPORT	01 01
14	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01 01
15	0521015376	DUST CLOAK	02 02
16	0502011562	DC PST ACT/ULTR BOX	01 01
17	0503010276	6206 BALL BEARING	02 02
18	0521013610	BLADE DISC HUB AXLE	01 01
19	0521013510	3/4" NUT	02 02
20	0503011438	SPRING WASHER	02 02
21	0511015346	FLAT WASHER	02 02
22	0503012417	SEAL	02 02
23	0503011800	SEAL RING	02 02
24	0503010691	1/4" GREASE FITTING	01 01
25	0603026013	PLAIN COULTER BLADE	01 01
26	0502020641	BLADE DISC FLANGE	01 01
27	0503010371	5/16" X 1" BOLT	06 06
28	0503011444	SPRING WASHER	06 06
29	0503010337	5/16" NUT	06 06
30	0503010003	1845 GREASE FITTING	01 01
31	0511016156	5/8" X 1.1/2" BOLT	02 02




PST3/PST3 SUPREMA
BLADE DISC ASSY

Page 45
0909092926


Item	Code	Description	CT LG
32	0541018684	FLAT WASHER	01 01



Item	Code	Description	QT
00	0501052767	SCARIFIER SPINDLE	01
00.	0501052768	SCARIFIER SPINDLE	01
01	0501110231	SCARIFIER SPINDLE	01
02	0502070061	POINT SUBSOILER	01
03	0503011373	0.4" X 1.1" SPRING PIN	01
04	0511061769	FERTILIZER CONDUCTOR RIGHT	01
05	0511061770	FERTILIZER CONDUCTOR LEFT	01
06	0501010984	FLAT WASHER	04
07	0503010025	3/8 SPRING WASHER	02
08	0503010026	3/8" NUT	02
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	02
10	0503031050	CURVED CONDUCTOR	01
11	0503010246	CLAMP	01



Item	Code	Description	QT
00	0511042460	RIGHT SHORT SEED FERT ROW ASSY	01
00.	0511042461	LEFT SHORT SEED FERT ROW ASSY	01
00B	0511042462	LEFT SHORT SEED FERT ROW ASSY	01
01	0501048763	LH SHORT FERTILIZER ROW	01
02	0501049135	RH SHORT FERTILIZER ROW	01
03	0501048764	RH LONG FERTILIZER ROW ASSY	01
04	0511040059	RIGHT SHORT SEED ROW ASSY	01
05	0511040060	LEFT SHORT SEED ROW ASSY	01
06	0511040061	LONG SEED ROW ASSY	01
07	0501049136	SPINDLE RIGHT SHORT FERT. ROW ASSY	01
08	0501049154	SPINDLE LEFT SHORT FERT. ROW ASSY	01
09	0501049153	SPINDLE LONG FERT. ROW ASSY	01
10	0501052767	SCARIFIER SPINDLE	01
11	0501052768	SCARIFIER SPINDLE	01



Item	Code	Description	CT LG
00	0511040059	RIGHT SHORT SEED ROW ASSY	01 00
00.	0511040060	LEFT SHORT SEED ROW ASSY	01 00
00..	0511040061	LONG SEED ROW ASSY	00 01
01	0511061761	SHORT SEEP ROW ARM	01 00
02	0511061762	LONG SEEP ROW ARM	00 01
03	0502011830	ARTICULACCION SUPPORT	01 01
04	0503010752	1/2" X 3.1/2" BOLT	03 03
05	0503011440	SPRING WASHER	11 11
06	0503010060	1/2" NUT	10 10
07	0502011561	BEARING SEMI	01 01
08	0502010426	UPPER BEARING SEMI	02 02
09	0503010479	1/2" X 3" BOLT	04 04
10	0501013354	FLAT WASHER	02 02
11	0502011400	18Z CONICAL GEAR	01 01
12	0502011296	1/2 HEX AXLE BEARING SLEEVE	01 01
13	0502011505	18Z CONICAL GEAR	01 01
14	0521018079	SEEP ROW DRAWBAR COVER	01 01
15	0503013758	1/4" X 1-1/2" BOLT	02 02
16	0503011441	SPRING WASHER	02 02
17	0511061876	SEED DISTRIBUTOR SUPPORT	01 01
18	0521018289	LEFT SIDE OF THE SEED DISTRIB SUPP	01 01
19	0503010752	1/2" X 3.1/2" BOLT	04 04
20	0909090053	15 X 15 SEED UNAL DOUB-DISC ASSY	01 00
21	0503031050	CURVED CONDUCTOR	07 07
22	0511018662	SPACING PLATE	04 04
23	0501017541	RH DOUBLE DISC SCRAPER	01 00
24	0501017542	LH DOUBLE DISC SCRAPER	00 01
25	0503010849	3/8" X 1-1/2" BOLT	01 01
26	0501010984	FLAT WASHER	03 03
27	0503010025	3/8 SPRING WASHER	06 06
28	0503010026	3/8" NUT	07 07
29	0503010848	5/16" X 3.1/2" BOLT	02 02
30	0503010179	SPRING WASHER	10 10

SEED ROW ASSY

0909092763


Item	Code	Description	CT	LG
31	0503010337	5/16" NUT	10	10
32	0521018077	1/2" X 58.6" HEX AXLE	01	00
33	0521018078	1/2" X 66.5" HEX AXLE	00	01
34	0501013352	FLAT WASHER	02	02
35	0501053538	SIDE BEARING	01	01
35A	0501053297	BEARING WITH DOUBLE BALL BEARING	02	02
35Aa	0502011971	HOUSING WITH DOUBLE BEARING	02	02
35Ab	0503011410	ROLLER BEARING	04	04
35Ac	0503011105	SEAL RING	02	02
35B	0511063004	DOUBLE BEARING AXLE	01	01
35C	0503010406	501025 CLAMPING RING (FOR AXLE)	02	02
35D	0503010365	NUT	04	04
35E	0501010694	FLAT WASHER	10	10
36	0502012254	18Z CONICAL GEAR HEX 1/2	01	01
37	0521018468	PROTECTION COVER	01	01
38	0503011099	GREASE FITTING	02	02
39	0503030150	BEND SOCKET	01	01
40	0521011744	0.3" X 3.1" COUPLING SHAFT	01	01
41	0503010140	1/8" X 3/4" COTTERPIN	01	01
42	0501052710	SEED DISTRIBUTOR WITH DISC	01	01
43	0503011371	CHAIN TR-081 X 1.8" LINK + MENDING	01	01
44	0501054144	SEED DISTRIBUTOR CHAIN TENSIONER	01	01
44A	0511063899	SEED DISTRIBUTOR CHAIN TENSIONER	01	01
44B	0531016202	PULLEY SEED DISTRIBUTOR CHAIN TENSIONER	01	01
44C	0503010302	501019 SEAL RING	01	01
45	0503010428	M12 X 1,75 X30 BOLT	03	03
46	0503031650	TUBE COP SUPREMA	01	01
47	0503011104	M6 X 1" BOLT	03	03
48	0511017303	FLAT WASHER	03	03
49	0503010143	SPRING WASHER	03	03
50	0521019455	2 X 76.6 AIR CONDUCTION	01	00
51	0521019456	2X 2100 AIR CONDUCTION	00	01
52	0503010246	CLAMP	02	02
53	0511062003	HOSE LARGE GUIDE	01	01
54	0502011760	SEED SILO SUPPORT	01	01
55	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04	04
56	0503031508	COVER GREEN BEAM SEED YELLOW	01	01
57	0503010358	5/16" X 5/8" BOLT	04	04
58	0531018349	SEED FLOW SWITCH PNEUMATIC SYSTEM	01	01
59	0501011643	3/8 X 1" BOLT	01	01
60	0503010209	3/8" UNC BUTTERFLY NUT	01	01
61	0511060376	SEEP SPRING GUIDE	01	01
62	0521010542	COUPLING SHAFT	01	01
63	0503010257	1/8" X 1" COTTERPIN	01	01
64	0501013753	FLAT WASHER	01	01
65	0503031339	1" X 19" X 0.1" COMPRESSION SPRING	01	00
66	0503031340	1.7" X 19" X 0.3" COMPRESSION SPRING	01	00
67	0502040534	SPRING GUIDE BUSHING LOCK	02	02
68	0503031359	1" X 15.75" X 0.15" COMPRESSION SPRING	00	01
69	0503031360	1.68" X 17.75" X 0.3" COMPRESSION SPRING	00	01
70	0503010834	1/2 X 1 BOLT	02	02
71	0503010013	5/8" NUT	03	03
72	0502011610	SPRING ROD GUIDE SUPPORT	01	01
73	0502010891	SPRING CHOCK SUPPORT VARON	01	01
74	0503010395	1/2" X 1-1/4" BOLT	01	01
75	0503010920	1/2" X 1-1/2" BOLT	01	01
76	0502011567	FERTILIZER ROW SUPPORT	01	01
77	0503010762	5/8" X 3-12" BOLT	02	02
78	0503010027	SPRING WASHER	02	02
79	0503010740	1/2" X 2" BOLT	01	01
80	0521010505	13,50 X 19,00 X 21,50 SLEEVE	01	01
81	0503010019	1/2" SPRING WASHER	02	02




PST3/PST3 SUPREMA
SEED ROW ASSY

Page 48
0909092763

Item	Code	Description	CT LG
82	0511017302	FLAT WASHER	01 01
83	0501013714	STABILIZER BAR	01 01
84	0501018652	CORN STABILIZER BAR	03 03
85	0501052945	DEPTH CONTROL WHEELS ASSY	07 07




Item	Code	Description	QT
00	0501052988	RIGHT 15" X 15" DOUBLE DISC	01
00.	0501052989	LH 15" X 15" DOUBLE DISC	01
01	0501068318	15"X15" RW SEED UNAL DOUB-DISC SUPP	01
02	0501068319	15"X15" LW SEED UNAL DOUB-DISC SUPP	01
03	0501054167	DOUBLE DISC HUB WITH 15" COULTER	01
04	0501054168	LEFT UNAL DOBLE-DISC BOX ASSY	01
04A	0502011930	DOUBLE DISC COULTER BOX	01
04B	0503010598	30204 BALL BEARING	02
04C	0503011112	SEAL 02376-BRG	01
04D	0521019154	RIGHT DOUB DISC HUB	01
04E	0521019148	LEFT DOUBLE DISC HUB	01
04F	0503030282	3/4" CASTLE NUT	01
04G	0503010257	1/8" X 1" COTTERPIN	01
04H	0603022042	13" X 0.12" PLAIN COULTER BLADE	01
04I	0503010546	5/16" X 7/8" BOLT	06
04J	0503010337	5/16" NUT	06
05	0511015098	FLAT WASHER	02
06	0511011927	DUST CLOAK	02
07	0503030757	2.9" X 2" X 0.02" JOINT	02
08	0521019178	COVER DEPTH	02
09	0503013758	1/4" X 1-1/2" BOLT	06
10	0503010143	SPRING WASHER	06
11	0501067170	UNALIGNED DISC SCRAPER	01
12	0503011402	0.2" X 0.8" SPRING PIN	01




Item	Code	Description	QT
01	0501110393	DISTRIBUTOR MINOR SIDE ASSY	01
01A	0502012217	MINOR SIDE	01
02	0503011295	M 8 X 1,25 X 25 BOLT	01
03	0503010427	METRIC M8 X P.0.5" NUT	01
04	0503011770	SEAL # V-75 A	01
05	0501067722	26Z GEAR WITH BUSHING	01
06	0503011771	6008 2RS BALL BEARING	01
07	0503010217	501040 CLAMPING RING (FOR AXLE)	01
08	0502050003	SUPPORT INTERNAL DISC SEED VULCANIZ	01
09	0503011378	M6 X 1" BOLT	06
10	0503010143	SPRING WASHER	02
11	0503033121	PNEUMATIC SWITCH	01
12	0503012849	2-129 N 3006 9B O'RING	01
13	0503013179	PNEUMATIC SEED DISTRIBUTOR VISOR	01
14	0503031660	SEED DISTRIBUTOR RUBBER BACKING	01
15	0503011817	UPPER SELECTOR	01
16	0502020559	UPPER SELECTOR ACTUATOR	01
17	0503011823	0.1" X 0.6" SPRING PIN	02
18	0531014481	0.2" X 0.6" AXLE	01
19	0503011821	CRINKLE WASHER	01
20	0503011820	CRINKLE WASHER	02
21	0503011813	M6 X 1.2" BOLT	01
22	0502012228	LARGE SIDE	01
23	0501110311	LOWER SELECTOR ASSY	01
24	0511016220	LOWER SELECTOR INDICATOR	01
25	0503011815	TOOTHED WASHER	01
26	0503012445	M6 C/ABA 1.20" BUTTERFLY NUT	04
27	0503011812	M6 X 1" BOLT	01
28	0511017303	FLAT WASHER	04
29	0503011776	M6 SELF ADJUSTINGNUT	01
30	0511017186	SEED LEVEL REGULATOR	01
31	0503011825	M4 X 8" BOLT	02
32	0503011828	FLAT WASHER	02

Item	Code	Description	QT
33	0503031058	UPPER SELECTOR SCALE	01
34	0501067818	SCALE INDICATOR WITH PIN	01
35	0511017219	SCALE INDICATOR GUIDE	01
36	0503011810	M6 X 1" BUTTERFLY BOLT	01
37	0503011827	504.100 CLAMPING RING (FOR HOLE)	01
38	0503011828	FLAT WASHER	01
39	0503011809	M12 KNOB	01
40	0503013020	SEED DRAINER COVER	01
41	0511015627	SEED DISC LEVER	01
42	0503011511	DISC 3245 OF THE SMALL CORN	01
43	0503011512	DISC 3255 LARGE CORN	01
44	0503011454	DISC 6445 LARGE SOYBEAN	01
45	0503011455	DISC 6450 LARGE SOYBEAN	01
46	0503011513	DISC 6430 SMALL SOYBEAN/COTTON	01
47	0503011437	DISC 6420 SORGHUM	01
48	0503011456	DISC 4820 SORGHUM	01
49	0503011391	DISC 3230 SUNFLOWER	01
50	0503011436	DISC 4845 MIDDLE BEAN	01
51	0503011392	DISC 4855 GREAT BEAN	01
52	0503011717	DISC 4835 DELINTED COTTON / BEAN	01
53	0503012574	DISC 6460 PEANUT P18 A 26	01
54	0503011889	DISC 7512 TOMATO	01
55	0503012576	DISC 3660 CORN	01
56	0503012577	DISC 3650 MIDDLE CORN	01
57	0503012578	DISC 3645 CORN	01
58	0503012579	DISC 3630 SUNFLOWER	01
59	0503012580	DISC 8440 MIDDLE SOYBEAN	01
60	0503012581	DISC 8045 LARGE SOYBEAN	01
61	0503012582	DISC 18016 RICE	01
62	0503012860	DISC 3240 POPCORN	01
63	0503012728	DISC WITHOUT HOLE	01




Item	Code	Description	QT
00	0511042211	PNEUMATIC SEED DISTRIBUTOR	01
00.	0501052710	SEED DISTRIBUTOR WITH DISC	
01	0501110393	DISTRIBUTOR MINOR SIDE ASSY	01
01A	0502012217	MINOR SIDE	01
02	0503011295	M 8 X 1,25 X 25 BOLT	01
03	0503010427	METRIC M8 X P.0.5" NUT	01
04	0503011770	SEAL # V-75 A	01
05	0501067722	26Z GEAR WITH BUSHING	01
06	0503011771	6008 2RS BALL BEARING	01
07	0503010217	501040 CLAMPING RING (FOR AXLE)	01
08	0502050028	DISC SUPPORT	01
09	0503011378	M6 X 1" BOLT	06
10	0503010143	SPRING WASHER	06
11	0511017229	1.6" X 2.5" X 0.7" BUSHING	01
12	0503011769	M8 X 0.5" BOLT	01
13	0501110309	PNEUMATIC SWITCH W/ SUPPORT	01
14	0503031060	PNEUMATIC SWITCH	01
15	0503011817	UPPER SELECTOR	01
16	0502020559	UPPER SELECTOR ACTUATOR	01
17	0503011823	0.1" X 0.6" SPRING PIN	02
18	0531014481	0.2" X 0.6" AXLE	01
19	0503011821	CRINKLE WASHER	01
20	0503011820	CRINKLE WASHER	02
21	0503011813	M6 X 1.2" BOLT	01
22	0502012228	LARGE SIDE	01
23	0501110311	LOWER SELECTOR ASSY	01
24	0511016220	LOWER SELECTOR INDICATOR	01
25	0503011815	TOOTHED WASHER	01
26	0503012445	M6 C/ABA 1.20" BUTTERFLY NUT	04
27	0503011812	M6 X 1" BOLT	01
28	0511017303	FLAT WASHER	04
29	0503011776	M6 SELF ADJUSTINGNUT	01
30	0511017186	SEED LEVEL REGULATOR	01


Item	Code	Description	QT
31	0503011825	M4 X 8" BOLT	02
32	0503011828	FLAT WASHER	02
33	0503031058	UPPER SELECTOR SCALE	01
34	0501067818	SCALE INDICATOR WITH PIN	01
35	0511017219	SCALE INDICATOR GUIDE	01
36	0503011810	M6 X 1" BUTTERFLY BOLT	01
37	0503011827	504.100 CLAMPING RING (FOR HOLE)	01
38	0503011828	FLAT WASHER	01
39	0503011809	M12 KNOB	01
40	0503013020	SEED DRAINER COVER	01
41	0503013179	PNEUMATIC SEED DISTRIBUTOR VISOR	01
42	0503011511	DISC 3245 OF THE SMALL CORN	01
43	0503011512	DISC 3255 LARGE CORN	01
44	0503011454	DISC 6445 LARGE SOYBEAN	01
45	0503011455	DISC 6450 LARGE SOYBEAN	01
46	0503011513	DISC 6430 SMALL SOYBEAN/COTTON	01
47	0503011437	DISC 6420 SORGHUM	01
48	0503011456	DISC 4820 SORGHUM	01
49	0503011391	DISC 3230 SUNFLOWER	01
50	0503011436	DISC 4845 MIDDLE BEAN	01
51	0503011392	DISC 4855 GREAT BEAN	01
52	0503011717	DISC 4835 DELINTED COTTON / BEAN	01
53	0503012574	DISC 6460 PEANUT P18 A 26	01
54	0503011889	DISC 7512 TOMATO	01
55	0503012576	DISC 3660 CORN	01
56	0503012577	DISC 3650 MIDDLE CORN	01
57	0503012578	DISC 3645 CORN	01
58	0503012579	DISC 3630 SUNFLOWER	01
59	0503012580	DISC 8440 MIDDLE SOYBEAN	01
60	0503012581	DISC 8045 LARGE SOYBEAN	01
61	0503012582	DISC 18016 RICE	01
62	0503012860	DISC 3240 POPCORN	01
63	0503012728	DISC WITHOUT HOLE	01
64	0511015627	SEED DISC LEVER	01
65	0503031660	SEED DISTRIBUTOR RUBBER BACKING	01




Item	Code	Description	QT
01	0501010617	3/4" NIPPLE	02
02	0503010190	2-114 N 3006-9B O'RING	02
03	0501012109	3/4" X 9/16" NIPPLE	06
04	0503011036	2-111 N 3006-9B O'RING	06
05	0503060132	VDFS-002 T SEQUENCCEL VALVE	01




Item	Code	Description	QT
01	0511062810	2.5" X 15" CYLINDER CASE	01
02	0501065662	HYDRAULIC CYLINDER TURNBUCKLE	01
03	0502010471	MOBILE COVER	01
04	0502010780	RING SUPPORT	01
05	0503010163	D-1500 SCRAPER RING	01
06	0503010989	1870-1500-375-B GASKET	01
07	0503010970	W1-1650-500 PK O'RING G.E	01
08	0503011058	8-330 BACK-UP RING	01
09	0503010161	2-330 N 3006 9B O'RING	01
10	0503010285	2-222 N 3006-9B O'RING	01
11	0502010783	1.5" X 2.5" PISTON	01
12	0503010160	2500 2000 GASKET	02
13	0503010973	W2-2500-500 PK O'RING G.E	01
14	0503010063	1" SELF-ALIGNING NUT	01
15	0503030384	CON N-001 PLUG	02
16	0501032666	HYDRAULIC CYLINDER REPAIR KIT	01




Item	Code	Description	QT
01	0502012086	DEPTH CONTROL SUPPORT	01
02	0511012244	DEPTH CONTROL WHEEL AXLE	01
03	0503010256	3/8" X 3/4" BOLT	01
04	0521015818	FLAT WASHER	04
05	0511017302	FLAT WASHER	02
06	0503010019	1/2" SPRING WASHER	02
07	0503010834	1/2 X 1 BOLT	02
08	0501052297	DEPTH WHEELS REGULATOR ASSY	01
09	0521019093	0.6" X 2.7" PIVOT SHAFT	01
10	0503010778	1/8" X 1.1/2" COTTERPIN	01
11	0502011699	RIGHT DEPTH WHEEL ARM	01
12	0502011698	LEFT DEPTH WHEEL ARM	01
13	0501052627	DEPHT WHEELS BOX	02
14	0503010358	5/16" X 5/8" BOLT	08
15	0503010179	SPRING WASHER	08
16	0503013816	5/16" LOCKNUT	08
17	0501052538	DEPTH CONTROL WHEEL RUBBER BAND	02
18	0503010740	1/2" X 2" BOLT	02
19	0503011440	SPRING WASHER	02
20	0503010060	1/2" NUT	02
21	0503010002	1800 GREASE FITTING	02
22	0501053037	IRON DEPTH CONTR. WHEEL ASSY	01




Item	Code	Description	QT
01	0501052957	IRON V PRESS WHEELS	02
02	0502011757	PRESS REGULATOR	01
03	0511060673	PRESS WHEELS REGULATOR	01
04	0503010849	3/8" X 1-1/2" BOLT	02
05	0503010025	3/8 SPRING WASHER	02
06	0503010026	3/8" NUT	02
07	0521013398	PRESS WHEELS REGULATOR BODY	01
08	0521010539	0.3" X 1.2" COUPLING SHAFT	01
09	0503010257	1/8" X 1" COTTERPIN	01
10	0503030805	1.6" X 6" X 0.2" TRACTION SPRING	01
11	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE	02



Item	Code	Description	QT
01	0511062982	RH LARGER SUPPORT	01
02	0511062983	LH LARGER SUPPORT	01
03	0521014021	1/2" X 4.5" X 5.4" FASTENER	02
04	0511017302	FLAT WASHER	04
05	0503010019	1/2" SPRING WASHER	04
06	0503010060	1/2" NUT	04
07	0511062984	ROW MARKER SMALLER SUPPORT	02
08	0502010175	HITCH CLAMP	04
09	0501010216	3/4" X 4-1/2" BOLT	08
10	0503010023	SPRING WASHER	08
11	0503010014	3/4" NUT	08
12	0501069470	ROW MARKER ARM	02
13	0521017686	5/8 UNF X 5/8 UNF X 335 PRISONER	02
14	0521010479	SLEEVE ARTICULATION	04
15	0521017687	SPACING SLEEVE	02
16	0501012140	FLAT WASHER	04
17	0503010027	SPRING WASHER	04
18	0503012795	5/8" HEX SELF ADJUSTING NUT	04
19	0511040203	1.5" X 2.5" X 19" X 9" HYDRAULIC CYLINDER	02
20	0521010574	C0.9" X 3.3" COUPLING SHAFT	02
21	0503010571	1/4" X 1.1/2 COTTERPIN	02
22	0511015779	1" X 4.2" AXLE	02
23	0503010523	1/4" X 2" COTTERPIN	02
24	0511017592	11.8" X 1.6" TRANSPORT LOCK	02
25	0501068994	0.3" X 3.1" LOCK PIN	02
26	0503030168	HAIR PIN	02
27	0511062755	740 TURNBUCKLE	02
28	0501050633	DISC ASSY FOR ROW MARKER	02
29	0503010962	5/8" X 1-1/4" BOLT	04




Item	Code	Description	QT
01	0511062982	RH LARGER SUPPORT	01
02	0511062983	LH LARGER SUPPORT	01
03	0521014021	1/2" X 4.5" X 5.4" FASTENER	02
04	0511017302	FLAT WASHER	04
05	0503010019	1/2" SPRING WASHER	04
06	0503010060	1/2" NUT	04
07	0511062984	ROW MARKER SMALLER SUPPORT	02
08	0502010175	HITCH CLAMP	04
09	0501010216	3/4" X 4-1/2" BOLT	08
10	0503010023	SPRING WASHER	08
11	0503010014	3/4" NUT	08
12	0501069470	ROW MARKER ARM	02
13	0521017686	5/8 UNF X 5/8 UNF X 335 PRISONER	02
14	0521010479	SLEEVE ARTICULATION	04
15	0521017687	SPACING SLEEVE	02
16	0501012140	FLAT WASHER	04
17	0503012795	5/8" HEX SELF ADJUSTING NUT	04
18	0511040203	1.5" X 2.5" X 19" X 9" HYDRAULIC CYLINDER	02
19	0521010574	C0.9" X 3.3" COUPLING SHAFT	02
20	0503010571	1/4" X 1.1/2 COTTERPIN	02
21	0511015779	1" X 4.2" AXLE	02
22	0503010523	1/4" X 2" COTTERPIN	02
23	0511017592	11.8" X 1.6" TRANSPORT LOCK	02
24	0501068994	0.3" X 3.1" LOCK PIN	02
25	0503030168	HAIR PIN	02
26	0501069643	890 TURNBUCKLE	02
27	0503010962	5/8" X 1-1/4" BOLT	04
28	0501050633	DISC ASSY FOR ROW MARKER	02




Item	Code	Description	08	09	10	12
01	0511011311	VALV. SUPPORT	01	01	01	01
02	0501044565	VDFS002 SEQUENCE VALVE	01	01	01	01
03	0503010256	3/8" X 3/4" BOLT	02	02	02	02
04	0503010025	3/8 SPRING WASHER	02	02	02	02
05	0501080464	3/8" X 37.4" TC-TC HOSE ASSY	02	02	02	02
06	0501080451	3/8" X 94.5" TR-TC HOSE ASSY	02	02	02	02
07	0501080401	3/8" X 106" TR-TC HOSE ASSY	00	02	00	00
08	0501080414	3/8" X 110.2" TR-TC HOSE ASSY	00	00	02	00
09	0501080392	3/8" X 3300 TR-TC HOSE	00	00	00	02
10	0501080382	3/8" X 102" TR-TC HOSE ASSY	02	00	00	00
11	0501080526	3/8" X 114" TR-TC HOSE ASSY	00	02	00	00
12	0501080397	3/8" X 120" TR-TC HOSE ASSY	00	00	02	00
13	0501080720	3/8" X 137" TR-TC HOSE ASSY	00	00	00	02
14	0501080553	3/8" X 126" TC-TM HOSE ASSY	02	02	00	00
15	0501080365	3/8" X 137" HOSE	00	00	02	02
16	0501053834	FAST COUPLER AGRICULTURAL WITH COVER - 1/2	02	02	02	02
17	0502010477	UPPER CLIP	04	04	04	04
18	0503010740	1/2" X 2" BOLT	04	04	04	04
19	0521011110	0.7" X .5" X 0.4" SPACER	04	04	04	04
20	0503010019	1/2" SPRING WASHER	04	04	04	04
21	0503010060	1/2" NUT	04	04	04	04
22	0511040203	1.5" X 2.5" X 19" X 9" HYDRAULIC CYLINDER	02	02	02	02
23	0501049849	2.0" X 4.5" X 25.8" HYDRAULIC CYLINDER	01	01	01	01
24	0503010232	5/8" X 1.3/4" BOLT	02	02	02	02
25	0503010027	SPRING WASHER	02	02	02	02
26	0503010013	5/8" NUT	02	02	02	02

WHEEL PRESS FERTILIZER ASSY (CBRF) (OPTIONAL)


0909090195




Item	Code	Description	QT
00	0501052735	IRON RIGHT PRESS WHEEL FERT UP	01
00.	0501052736	IRON LEFT PRESS WHEEL FERT UP	01
01	0501056289	IRON LEFT PRESS WHEEL FERT UP	01
02	0501056288	WHEEL COVER ROD FERRO	01
03	0501053186	RIGHT IRON PRESS WHEEL ASSY	01
03A	0502011970	IRON PRESS WHEEL	01
03B	0503010598	30204 BALL BEARING	02
03C	0503011112	SEAL 02376-BRG	01
03D	0521019148	LEFT DOUBLE DISC HUB	01
03E	0521019154	RIGHT DOUB DISC HUB	01
03F	0503010257	1/8" X 1" COTTERPIN	01
03G	0503030282	3/4" CASTLE NUT	01
03H	0503030757	2.9" X 2" X 0.02" JOINT	01
03I	0521019178	COVER DEPTH	01
03J	0503011441	SPRING WASHER	03
03K	0503013758	1/4" X 1-1/2" BOLT	03
03L	0511016896	DUST CLOAK	01
04	0502012348	RIGHT WHEEL ARM	01
05	0502011156	LEFT FIXER WHEEL	01
06	0502011155	RIGHT FIXER WHEEL	01
07	0503010920	1/2" X 1.1/2" BOLT	02
08	0503011440	SPRING WASHER	02
09	0502012347	LEFT WHEEL ARM SUPPORT	02
10	0501010163	5/8" X 4-1/2" BOLT	01
11	0531016207	0.6" X 1" X 2.8" SLEEVE	01
12	0503010027	SPRING WASHER	01
13	0503010013	5/8" NUT	01
14	0503010003	1845 GREASE FITTING	01




Item	Code	Description	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK	01
02	0502011907	DEPTH CONTROL WHEEL HUB	01
03	0503010269	6204 BALL BEARING	02
04	0501013636	SPACING SLEEVE	01
05	0503010689	SEAL 00763-BR	01
06	0503011105	SEAL RING	01
07	0503010878	5/8" SELF ALIGNING NUT	01
08	0521019178	COVER DEPTH	01
09	0503030757	2.9" X 2" X 0.02" JOINT	01
10	0503014729	1/4" UNF X 1/2" BOLT	03
11	0503011441	SPRING WASHER	03
12	0503010691	1/4" GREASE FITTING	01




Item	Code	Description	QT
01	0502011689	1/8" DEPTH CONTROL LEVER	01
02	0503030975	0.9" X 1.5" X 0.1" SPRING	01
03	0502011688	SEED SIST CONTROL DEPTH LEVER	01
04	0511015976	FLAT WASHER	01
05	0503010257	1/8" X 1" COTTERPIN	01
06	0511060699	DEPTH WHEEL STOP	01
07	0503010071	3/16" X 1" COTTERPIN	01




Item	Code	Description	QT
001	0502011932	IRON PRESS WHEELS	01
002	0503010269	6204 BALL BEARING	02
003	0503011105	SEAL RING	01
004	0503013848	5072-BR SEAL	02
005	0521019147	V COMPACT WHEELS AXLE	02
006	0511011927	DUST CLOAK	02
007	0503010691	1/4" GREASE FITTING	01



Item	Code	Description	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01
02	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01
03	0541018684	FLAT WASHER	01
04	0503010756	0.2" X 2.4" SPRING PIN	01
05	0503010361	SPRING PIN	01
06	0503010003	1845 GREASE FITTING	01
07	0521014137	RIGHT ARM OF THE BLADE DISC	01
08	0521014138	SUPPORT ARM LEFT BALDE DISC	01
09	0501067323	SPRING REGULATOR	01
10	0521010452	SLEEVE	01
11	0503013185	3/4" X 5-1/2" BOLT	01
12	0503011255	3/4" LOCK NUT	01
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01
14	0503011411	1/2" X 5-1/2" BOLT	01
15	0503011440	SPRING WASHER	01
16	0503010060	1/2" NUT	01
17	0502020393	SPRING UPPER SUPPORT	01
18	0502020394	SPRING SUPPORT	01
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01
20	0503010014	3/4" NUT	02
21	0501054887	20 BLADE DISC WITH FLAT PLAN DISC	01
22	0521015376	DUST CLOAK	02
23	0511015346	FLAT WASHER	06
24	0503011442	3/4" SPRING WASHER	02
25	0521013510	3/4" NUT	02
26	0511016156	5/8" X 1.1/2" BOLT	02



Item	Code	Description	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01
02	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE	01
03	0541018684	FLAT WASHER	01
04	0503010756	0.2" X 2.4" SPRING PIN	01
05	0503010361	SPRING PIN	01
06	0503010003	1845 GREASE FITTING	01
07	0521014137	RIGHT ARM OF THE BLADE DISC	01
08	0521014138	SUPPORT ARM LEFT BALDE DISC	01
09	0501067323	SPRING REGULATOR	01
10	0521010452	SLEEVE	01
11	0503013185	3/4" X 5-1/2" BOLT	01
12	0503011255	3/4" LOCK NUT	01
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01
14	0503011411	1/2" X 5-1/2" BOLT	01
15	0503011440	SPRING WASHER	01
16	0503010060	1/2" NUT	01
17	0502020393	SPRING UPPER SUPPORT	02
18	0502020394	SPRING SUPPORT	01
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01
20	0503010014	3/4" NUT	02
21	0501054887	20 BLADE DISC WITH FLAT PLAN DISC	01
22	0521015376	DUST CLOAK	02
23	0511015346	FLAT WASHER	06
24	0503011442	3/4" SPRING WASHER	02
25	0521013510	3/4" NUT	02
26	0511016156	5/8" X 1.1/2" BOLT	02



Item	Code	Description	08	09	10	12	L.
01	0501017440	5/8" X 60.4" HEX AXLE	01	00	00	00	
01.	0501017441	5/8" X 69.3" HEX AXLE	01	00	00	00	
02	0511010749	5/8" X 71.8" HEX AXLE	00	01	00	00	
02.	0511010750	5/8" X 79.1" HEX AXLE	00	01	00	00	
03	0501017442	5/8" X 76.1" HEX AXLE	00	00	01	00	
03.	0501017443	5/8" X 85" HEX AXLE	00	00	01	00	
04	0501017432	5/8" X 95.8" HEX AXLE	00	00	00	01	
04.	0501017433	5/8" X 2660" HEX AXLE	00	00	00	01	
05	0502040723	5/8 HEX AXLE BEARING SLEEVE	02	02	02	02	
06	0501110036	HEX AXLE RIGHT BEARING ASSY	01	01	01	01	
07	0501110037	5/8" HEX AXLE LEFT BEARING ASSY	01	01	01	01	
08	0501053788	Q3/4" FASTENER AXLE ASSY	02	02	02	02	
08A	0521010691	AXLE FASTENER	02	02	02	02	
08B	0503010373	1/4" X 2" BOLT	02	02	02	02	
08C	0511017303	FLAT WASHER	02	02	02	02	
08D	0503010143	SPRING WASHER	02	02	02	02	
08E	0503010144	1/4" NUT	02	02	02	02	
09	0503010363	5/16" X 1" BOLT	04	04	04	04	
10	0503011176	5/16" SPRING WASHER	04	04	04	04	
11	0503010337	5/16" NUT	04	04	04	04	
12	0501017558	5/8" HEX AXLE BEARING SUPPORT	02	02	02	02	
13	0503010920	1/2" X 1.1/2" BOLT	04	04	04	04	
14	0511017302	FLAT WASHER	04	04	04	04	
15	0503010019	1/2" SPRING WASHER	04	04	04	04	
16	0503010060	1/2" NUT	04	04	04	04	
17	0502011299	BUSHING GEAR	02	02	02	02	
18	0502011314	8Z P 1.1/4" RH1.4" GEAR	02	02	02	02	
19	0521010530	COUPLING SHAFT	02	02	02	02	
20	0503010140	1/8" X 3/4" COTTERPIN	02	02	02	02	

This image shows a single page from a notebook or ledger. The page is white with rounded corners and features horizontal ruling lines spaced evenly down its length. There are no vertical margin lines, and the page is completely blank except for the lines.





MARCHESAN IMPLEMENTOS E MÁQUINAS AGRÍCOLAS TATU S.A.

AV. Marchesan, 1979 - Post office box, 131 - CEP 15994-900 - Matão - SP - Brazil

Phone +55 16.3382-8282

(FAX Parts) + 55 16.3382. 8297 - (Export) + 55 16.3382.1003

e.mail: tatu@marchesan.com.br www.marchesan.com.br

Technical Publications: Elaboration

MASTER

Technical Publications: Revision

LUIZ CANDIDO

Contact Catálogo:

E-mail = jgaspari@marchesan.com.br

**ORIGINAL PARTS
TATU**

