

PARTS CATALOG

ROW CROP PLANTERS

PST4 FLEX SUPREMA

Code: 0501090941



Series: S-0211

Rev.: 01


Date Rev.: JUNHO/2011

**ORIGINAL PARTS
TATU**



INDEX


0909093374	FRAME ASSY PST4 FLEX SUP S-0211		1
0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER		2
0909093034	7 9 HYDRAULIC CIRCUIT		3
0909093375	FRAME ASSY ,ROW 11		4
0511041187	HYDRAULIC CYLINDER		5
0909093069	11 ROW HYDRAULIC CIRCUIT PST4 FLEX		6
0511041364	DRIVE SHAFT		7
0511041364(STU)			7
0909093352	TURBINE ASSY FOR CARDAN		8
0909093070	TRANSMISSION		9
0511046744	TRANSMISSION DRIVING ASSY		10
0909093036	SIDE TRANSMISSION DRIVING ASSY		11
0909093035	GEAR BOX ASSY		12
0909093071	WHEELS ASSY		13
0501053110	WHEEL TRAMMISSION WITHOUT TIRE		14
0909093072	FERTILIZER BEAM		15
0909093376	FERTILIZER ROW ASSY,PST4 FLEX SUPR		16
0501052976	15 X 15 RIGHT FERT UNAL DOUB-DISC ASSY		17
0501052977	DDD LEFT FERTILIZER 15 X 15 ASSY		18
0909093309	BLADE DISC ASSY 18"		19
0909093354	SEED ROW FRONT ASSY		20
0909093293	SEED ROW FRONT ASSY UNTIL (9/2011)		21
0511050073	SEED ROW TRANSMISSION HUB		22
0511051328	STELL CABLE WHIT UNIVERSAL JOINT		23
0909093377	REAR SEED ROW		24
0909093385	DEPTH CONTROL		25
0501052538	DEPTH BAND WITH ARMS		26
0909093297	PRESS WHEELS ASSY		27
0501052627	ASSY DEPTH WHEEL BOX		28
0909093298	15X15 SEED UNAL DOUB-DISC ASSY		29
0909093059	MECANIC ROW MARKER		30
0501050633	MARKER DISC ASSY LINE		31
0909093060	HIDRAULIC ROW MARKER		32
0909093054	MARKER HYDRAULIC CIRCUIT		33
0511040203	1.5" X 2.5" X 19" X 9" HYDRAULIC CYLINDER		34
0501054649	SEQUENTIAL VALVE ASSY		35
0909093082	ROD SCARIFIER SPINDLE ASSY		36
0909090495	"V" WHEEL SET COBRIDORA FERTILIZER		37




Item	Code	Description	See page	07 09
01	0511069615	PST4 7 S-1207 FRAME		01 00
02	0511069529	FRAME PST4 9 S-1207		00 01
03	0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	2	01 01
04	0503010003	1845 GREASE FITTING		01 01
05	0531019171	1.25" X 7" COUPLING SHAFT		01 01
06	0521012536	COUPLING SHAFT		01 01
07	0503010523	1/4" X 2" COTTERPIN		02 02
08	0511069635	HANDRAIL		02 00
09	0511069656	HANDRAIL COP FLEX 600 9		00 02
10	0503010920	1/2" X 1.1/2" BOLT		16 16
11	0503010019	1/2" SPRING WASHER		17 17
12	0503010060	1/2" NUT		17 17
13	0551019110	LADDER RIGHT FIXER		01 01
14	0551017438	LADDER RIGHT FIXER		01 01
15	0551019109	LADDER LEFT FIXER		01 01
16	0551017437	LADDER RIGHT FIXER		01 01
17	0503010237	3/8" X 1" BOLT		04 04
18	0503010025	3/8 SPRING WASHER		15 15
19	0503010026	3/8" NUT		14 14
20	0511069636	LADDER		02 02
21	0501010096	3/8" X 2" BOLT		06 06
22	0501010984	FLAT WASHER		23 23
23	0503013357	3/8" SELF-ADJUSTING NUT		06 06
24	0511069725	RIGHT PLATFORM		01 00
25	0511069665	PLATFORM RIGHT PST4 9		00 01
26	0521062318	LEFT PLATFORM		01 00
27	0521062323	PLATFORM LEFT PST4 9		00 01
28	0521061676	PLATFORM PROLONG		02 02
29	0511069664	PLATFORM EXTENSION LOCK		02 02
30	0503010257	1/8" X 1" COTTERPIN		06 06
31	0511069661	PLATFORM SUPPORT PIVOT		04 04

Item	Code	Description	See page	07 09
32	0503010849	3/8" X 1-1/2" BOLT		08 08
33	0521010549	COUPLING SHAFT		04 04
34	0551019127	PLATFORM RIGHT FIXER SUPPORT		01 01
35	0551019128	PLATFORM LEFT FIXER SUPPORT		01 01
36	0503011333	COVER FIXER		02 02
37	0503010274	5/32"X 2" COTTERPIN		02 02
38	0551019115	LOCK		02 02
39	0502011530	SUPPORT		02 02
40	0502010175	HITCH CLAMP		02 02
41	0501011543	5/8" X 4" BOLT		04 04
42	0503010027	SPRING WASHER		06 06
43	0503010013	5/8" NUT		06 06
44	0511061835	PLOUGH SUPPORT		02 02
45	0501011075	PIN		02 02
46	0503030012	HAIR PIN		02 02
47	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02 02
48	0502012330	SUPPORT FIXER PIVOT		04 04
49	0503011084	3/4" X 5" BOLT		08 08
50	0501010322	FLAT WASHER		08 08
51	0503010023	SPRING WASHER		08 08
52	0503010014	3/4" NUT		08 08
53	0502012329	DRAWBAR FIXATION REAR SUPPORT		02 02
54	0561014393	COUPLING SHAFT		02 02
55	0503030119	LOCK PIN		04 04
56	0511064808	DRAWBAR		01 01
57	0561019087	DRAWBAR TRANSPORT LOCK		01 01
58	0521010578	COUPLING SHAFT		01 01
59	0521010588	0.9" X 7.0" COUPLING SHAFT		01 01
60	0503030085	LOCK PIN		02 02
61	0503010002	1800 GREASE FITTING		03 03
62	0521014441	HOSE HOLDER RIGHT SUPPORT		02 02
63	0521018535	HOSE HOLDER LEFT SUPPORT		02 02
64	0503031608	AIR DISTRIBUTOR		02 00
65	0503031609	AIR DISTRIBUTOR		00 02
66	0521014442	HOSE SUPPORT		04 04
67	0503010365	NUT		09 09
68	0503010179	SPRING WASHER		11 11
69	0503010337	5/16" NUT		09 09
70	0503060100	HAND BOOK COMPARTMENT		01 01
71	0503010267	NYLON CLAMP		01 01
72	0501010694	FLAT WASHER		05 05
73	0501065677	STRUT		02 02
74	0501054258	DRAWBAR ESTABILIZER ASSY		01 01
74A	0501069529	653 TURNBUCKLE		01 01
74B	0511060558	RIGHT TURNBUCKLE		01 01
74C	0511060559	LEFT TURNBUCKLE		01 01
74D	0501061056	RH LOCKNUT WITH HANDLER		01 01
75	0501051160	TRACTOR HITCH PIN		01 01
75A	0502040556	HITCH TURNER		01 01
75B	0521010681	BUSHING COUPLING BODY		01 01
75C	0521010639	COUPLING SHAFT		01 01
75D	0503010571	1/4" X 1.1/2 COTTERPIN		01 01
76	0501047881	COUPLING SHAFT		01 01
76A	0501068989	COUPLING SHAFT		01 01
76B	0503031035	HAIR PIN		01 01
77	0521013022	TRANSPORT LOCK		01 01
78	0541011767	HOSE FIXATION		01 01
79	0501047895	ROD STOP		01 01
80	0501047885	ROD STOP		01 01


Item	Code	Description	See page	07 09
81	0501047886	ROD STOP		01 01
82	0501047887	ROD STOP		01 01
83	0502010477	UPPER CLIP		01 01
84	0503031436	AIR DITRIBUTOR PUMP		04 05
85	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		03 03
86	0511041364	DRIVE SHAFT	7	01 01
87	0503010479	1/2" X 3" BOLT		01 01
88	0511044704	TURBINE ASSY FOR CARDAN		01 01
89	0503010967	5/8" X 5.1/2" BOLT		02 02
90	0531016193	4" X 74" AIR CONDUCTOR		02 02
91	0503011372	102 TO 121 CLAMP		04 04
92	0521019552	5" X 188" AIR CONDUCTOR		01 01
93	0503012724	121 TO 140 CLAMP		01 01
94	0531015603	HOSE FIXATION SUPPORT		01 01
95	0501056495	TURBINE OUTPUT SOCKET		01 01
96	0503013096	5/16" X 4" BOLT		02 02
97	0503010499	5/16" UNC BUTTERFLY NUT		02 02
98	0501068994	0.3" X 3.1" LOCK PIN		01 01
99	0503030168	HAIR PIN		01 01



Item	Code	Description	See page	QT
01	0511064055	5" X 15" CYLINDER CASE		01
02	0511064056	BUSHING 2" X 14" TURNBUCLE		01
03	0502010382	5" HEAD		01
04	0502012227	50,80 X 127 RING SUPPORT		01
05	0503010039	D-2000 SCRAPER RING		01
06	0503010991	PACKING 1870-2000-375-B		01
07	0503010952	W2-2250-500 PK RING G.E		01
08	0503010351	2-425 N 3006-9B O'RING		01
09	0503011062	8-425 BACK-UP RING		01
10	0502010963	2.0" X 5.0" PISTON		01
11	0503010552	PACKING 3750-4250-625-B		02
12	0503010345	2-218 N 3006-9B O'RING		01
13	0503010974	W2-5000-500 PK RING G.E		01
14	0503010817	1-1/4" SELF-ADJUSTING NUT		01
15	0503010003	1845 GREASE FITTING		01
16	0503030385	CYLINDER PLUG N-002		02




Item	Code	Description	See page	07	09
01	0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	2	01	01 01
02	0501080422	3/8" X 157" TC-TM HOSE ASSY		01	01 01
03	0501080446	3/8" X 169" TC-TM HOSE ASSY		01	01 01
04	0501053834	MALE QUICK COUPLING AGRICULTURAL WITH COVER - 1/2 NPT		02	02 02
04A	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT		02	02 02
04B	0503011882	QUICK CONNECTION COVER		02	02 02




Item	Code	Description	See page	QT
01	0511069616	PST4 SUPREMA FRAME		01
02	0511041187	HYDRAULIC CYLINDER	5	02
03	0503010004	1890 GREASE FITTING		04
04	0521012538	1.2" X 3.5" COUPLING SHAFT		02
05	0521012536	COUPLING SHAFT		02
06	0503010523	1/4" X 2" COTTERPIN		04
07	0511069660	HANDRAIL COP FLEX 600 11		02
08	0503010920	1/2" X 1.1/2" BOLT		16
09	0503010019	1/2" SPRING WASHER		17
10	0503010060	1/2" NUT		17
11	0551019110	LADDER RIGHT FIXER		01
12	0551017438	LADDER RIGHT FIXER		01
13	0551019109	LADDER LEFT FIXER		01
14	0551017437	LADDER RIGHT FIXER		01
15	0503010237	3/8" X 1" BOLT		04
16	0503010025	3/8 SPRING WASHER		14
17	0503010026	3/8" NUT		14
18	0511069636	LADDER		02
19	0501010096	3/8" X 2" BOLT		06
20	0501010984	FLAT WASHER		22
21	0503013357	3/8" SELF-ADJUSTING NUT		06
22	0511069718	PLATFORM RIGHT PST4 11		01
23	0521062324	PLATFORM LEFT PST4 11		01
24	0521061676	PLATFORM PROLONG		02
25	0511069664	PLATFORM EXTENSION LOCK		02
26	0503010257	1/8" X 1" COTTERPIN		06
27	0511069661	PLATFORM SUPPORT PIVOT		04
28	0503010849	3/8" X 1-1/2" BOLT		08
29	0521010549	COUPLING SHAFT		04
30	0551019127	PLATFORM RIGHT FIXER SUPPORT		01
31	0551019128	PLATFORM LEFT FIXER SUPPORT		01

Item	Code	Description	See page	QT
32	0503011333	COVER FIXER		02
33	0503010274	5/32"X 2" COTTERPIN		02
34	0551019115	LOCK		02
35	0502011530	SUPPORT		02
36	0502010175	HITCH CLAMP		02
37	0501011543	5/8" X 4" BOLT		04
38	0503010027	SPRING WASHER		06
39	0503010013	5/8" NUT		06
40	0511061835	PLOUGH SUPPORT		02
41	0501011075	PIN		02
42	0503030012	HAIR PIN		02
43	0502012328	DRAWBAR SUPPORT FRONT FIXATION		04
44	0502012330	SUPPORT FIXER PIVOT		04
45	0503011084	3/4" X 5" BOLT		08
46	0501010322	FLAT WASHER		08
47	0503010023	SPRING WASHER		08
48	0503010014	3/4" NUT		08
49	0502012329	DRAWBAR FIXATION REAR SUPPORT		04
50	0561014393	COUPLING SHAFT		04
51	0503030119	LOCK PIN		08
52	0511064808	DRAWBAR		01
53	0561019087	DRAWBAR TRANSPORT LOCK		01
54	0521010578	COUPLING SHAFT		01
55	0521010588	0.9" X 7.0" COUPLING SHAFT		01
56	0503030085	LOCK PIN		02
57	0503010002	1800 GREASE FITTING		03
58	0521014441	HOSE HOLDER RIGHT SUPPORT		02
59	0521018535	HOSE HOLDER LEFT SUPPORT		02
60	0503031610	AIR DISTRIBUTOR		02
61	0521014442	HOSE SUPPORT		04
62	0503010365	NUT		09
63	0503010179	SPRING WASHER		11
64	0503010337	5/16" NUT		09
65	0503060100	HAND BOOK COMPARTMENT		01
66	0503010267	NYLON CLAMP		01
67	0501010694	FLAT WASHER		05
68	0511041364	DRIVE SHAFT	7	01
69	0503010479	1/2" X 3" BOLT		01
70	0511044704	TURBINE ASSY FOR CARDAN		01
71	0503010967	5/8" X 5.1/2" BOLT		02
72	0531016195	4" X 94" AIR CONDUCTOR		02
73	0503011372	102 TO 121 CLAMP		04
74	0521019552	5" X 188" AIR CONDUCTOR		01
75	0503012724	121 TO 140 CLAMP		01
76	0531015603	HOSE FIXATION SUPPORT		01
77	0501056495	TURBINE OUTPUT SOCKET		01
78	0503013096	5/16" X 4" BOLT		02
79	0503010499	5/16" UNC BUTTERFLY NUT		02
80	0501065677	STRUT		02
81	0501054258	DRAWBAR ESTABILIZER ASSY		01
81A	0501069529	653 TURNBUCKLE		01
81B	0511060558	RIGHT TURNBUCKLE		01
81C	0511060559	LEFT TURNBUCKLE		01
81D	0501061056	RH LOCKNUT WITH HANDLER		01
82	0501051160	TRACTOR HITCH PIN		01
82A	0502040556	HITCH TURNER		01
82B	0521010681	BUSHING COUPLING BODY		01
82C	0521010639	COUPLING SHAFT		01
82D	0503010571	1/4" X 1.1/2 COTTERPIN		01


Item	Code	Description	See page	QT
83	0501047881	COUPLING SHAFT		01
83A	0501068989	COUPLING SHAFT		01
83B	0503031035	HAIR PIN		01
84	0521013022	TRANSPORT LOCK		02
85	0541011767	HOSE FIXATION		01
86	0501047895	ROD STOP		02
87	0501047885	ROD STOP		02
88	0501047886	ROD STOP		02
89	0501047887	ROD STOP		02
90	0502010477	UPPER CLIP		01
91	0503031436	AIR DITRIBUTOR PUMP		06
92	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		03
93	0501068994	0.3" X 3.1"LOCK PIN		01
94	0503030168	HAIR PIN		01




Item	Code	Description	See page	QT
01	0511064052	4" X 12.1" CYLINDER CASE		01
02	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
03	0502010017	4" HEAD		01
04	0502010778	2" X 4.2" RING SUPPORT		01
05	0503010039	D-2000 SCRAPER RING		01
06	0503010991	PACKING 1870-2000-375-B		01
07	0503010952	W2-2250-500 PK RING G.E		01
08	0503030385	CYLINDER PLUG N-002		01
09	0503010338	2-342 N 3006-9B O'RING		01
10	0503010345	2-218 N 3006-9B O'RING		01
11	0502010992	2.0" X 4.0" PISTON		01
12	0503010043	PACKING 3750-3250		02
13	0503010994	W2-4000-500 PK RING G.E		01
14	0503010817	1-1/4" SELF-ADJUSTING NUT		01
15	0503010003	1845 GREASE FITTING		01






Item	Code	Description	See page
01	0511041187	HYDRAULIC CYLINDER	5
02	0511063404	"T" OIL CONDUCTOR	02
03	0502010477	UPPER CLIP	06
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	06
05	0501010984	FLAT WASHER	06
06	0503010025	3/8 SPRING WASHER	06
07	0501080449	3/8" X 1500 TC-TC HOSE	04
08	0501080361	3/8" X 157" TR-TM HOSE ASSY	02
09	0501053834	MALE QUICK COUPLING AGRICULTURAL WITH COVER - 1/2 NPT	02
09A	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT	02
09B	0503011882	QUICK CONNECTION COVER	02



Item	Code	Description	See page	QT
01	0501055638	HOMO JOINT WITH FEMALE BUSHING		01
01A	0503012607	TRACTOR HOMOCINETIC TERMINAL		01
01Aa	0521010638	0.5" X 3.3" QUIC HITCH COUPL SHAFT		01
01Ab	0503030518	0.5"X1.0"X 0.1" COMPRESSION SPRING		01
01Ac	0503010140	1/8" X 3/4" COTTERPIN		01
01B	0503012605	CROSSPIECE		02
01C	0503012606	CENTER BODY		01
01D	0503012604	HOMO TERMINAL W/ FEMALE BUSHING		01
01E	0503012618	2.1" X 2.0" X 31" TRIAN FEMALE TUB		01
01F	0503010843	0.4" X 3.3" SPRING PIN		01
01G	0503011878	0.2" X 3.3" SPRING PIN		01
02	0501055639	UNIVERSAL JOINT		01
02A	0503013132	CC292 TERMINAL		01
02B	0503012096	CROSSPIECE		01
02C	0503013187	TERMINAL		01
02D	0503012619	1.8" X 1.7" X 31" TRIAN MALE TUB		01
02E	0503011069	0.4" X 2.8" SPRING PIN		01
02F	0503011805	0.2" X 2.8" SPRING PIN		01
03	0503013189	PROTECTION ASSY		01
04	0503012023	CHAIN FOR UNIV JOINT PROTECTION		01




CARDAN (0501047952)




STU
CARDANS

Item	Code	Description	See page	QT
1	0511041364(STU)		7	1



Item	Code	Description	See page	QT
01	0511061094	TURBINE SUPPORT	01	
02	0501053716	BEARING ASSY OF THE LARGER FAN	01	
02A	0502012016	CHAIN TENSIONER SUPPOT	01	
02B	0503012778	MIDDLE LARGER AXLE	01	
02C	0531010881	INTERMEDIARY UPPER SLEEVE	01	
02D	0503012689	6306 DDU BEARING	02	
02E	0503010325	VCA-118 VALVE	03	
03	0503010920	1/2" X 1.1/2" BOLT	02	
04	0511017302	FLAT WASHER	02	
05	0503010395	1/2" X 1-1/4" BOLT	02	
06	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
07	0501053886	PULLEY ASSY WITH FREE ROT	01	
07A	0502012020	PULLEY HOUSING BEARING	01	
07B	0501053888	TURBINE PULLEY ASSY	01	
07C	0503011081	6207 2RS BEARING	02	
07D	0531014518	INTERMEDIARY LOWER BUSHING BEARING	01	
07E	0531014519	FLAT WASHER	01	
07F	0531014527	FLAT WASHER	01	
07G	0503010301	0.3" X 1.8" SPRING PIN	01	
07H	0503011855	0.2" X 1.8" SPRING PIN	01	
08	0501011194	1/2" X 1-3/4" BOLT	04	
09	0521018517	FLAT WASHER	04	
10	0503010019	1/2" SPRING WASHER	05	
11	0503010020	1/2"NUT	04	
12	0503013030	5/8" X 3.1/4" BOLT	01	
13	0501012140	FLAT WASHER	01	
14	0503010013	5/8" NUT	01	
15	0503012780	LARGER TURBINE BELT	01	
16	0531017194	FRONT COVER	01	
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04	
18	0503010025	3/8 SPRING WASHER	04	

Item	Code	Description	See page	QT
19	0503010026	3/8" NUT		04
20	0511040440	17.3" MIDDLE FAN		01
21	0503011775	6 X 6 X 35 KEYWAY		01
22	0503011774	PULLEY		01
23	0503010179	SPRING WASHER		03
24	0503011257	M 8 X 1,25 X 30 BOLT		01
25	0503011807	M 8 X 1,25 X 10 BOLT		01
26	0501054272	RIBBON FOR COVER CLOSING ASSY		01
27	0503031776	TURBINE RIBBON SEAL		02
28	0531017195	REAR COVER		01
29	0503013031	1/4" X 3.1/4" BOLT		15
30	0503012880	1/4" UNC SELF ADJUSTING NUT		17
31	0511014024	10 X 13 X 15,5 SLEEVE		02
32	0503012721	1/4" X 4" BOLT		02
33	0511017303	FLAT WASHER		40
34	0531010771	WASHER GUIDE		01
35	0531010757	TURBINE FAN		01
36	0531010770	FLAT WASHER		01
37	0503010179	SPRING WASHER		01
38	0503011429	M 8 X 1,25 X 40 BOLT		01
39	0531012760	TURBINE REAR COVER		01
40	0503013758	1/4" X 1-1/2" BOLT		04
41	0521018267	LARGER TURBINE FRONTAL COVER CENTER		01
42	0503031649	CONECTOR CENTER		01
43	0503012722	0.16" X 0.4" BLIND RIVET		16
44	0501056495	TURBINE OUTPUT SOCKET		01
44A	0503031812	TURBINE OUTPUT SOCKET		01
44B	0541017539	BUTTERFLY VALVE		01
44C	0511066760	VALVE FIXATION SUPPORT		01
44D	0503013813	1/4" UNC X 7/8" BOLT		02
44E	0503010143	SPRING WASHER		02
44F	0503010144	1/4" NUT		02
44G	0501013519	FLAT WASHER		01
44H	0503010060	1/2" NUT		01
45	0503013096	5/16" X 4" BOLT		02
46	0501010694	FLAT WASHER		04
47	0503010499	5/16" UNC BUTTERFLY NUT		02
48	0531015571	CARDAN SLEEVE HITCH		01
49	0561010635	SWITCH FIXER		01
50	0503013584	VACUUM GAUGE		01




Item	Code	Description	See page	07	09	11
01	0521013199	LOWER BEARING SEMI		04	04	06
02	0511069724	CARRYING-WHEELS PIVOT SHAFT		01	00	00
03	0511069682	CARRYING-WHEELS PIVOT SHAFT		00	01	00
04	0511069717	CARRYING-WHEELS PIVOT SHAFT		00	00	01
05	0503010899	5/8" X 2-1/4" BOLT		08	08	12
06	0501012140	FLAT WASHER		18	18	18
07	0531013922	0.6" X 0.8" X 1" SLEEVE		08	08	08
08	0503010027	SPRING WASHER		10	10	10
09	0503010013	5/8" NUT		10	10	10
10	0501110292	AGRICULTURAL BEARING		02	03	03
11	0501110293	AGRICULTURAL BEARING		02	03	03
12	0503010002	1800 GREASE FITTING		04	06	06
13	0503010257	1/8" X 1" COTTERPIN		06	08	08
14	0501110025	AGRICULTURAL BEARING		02	02	02
15	0503010691	1/4" GREASE FITTING		02	02	02
16	0551019114	MOTOR BEARING AXLE SUPPORT		02	04	04
17	0521014436	MOTOR CHOCK SUPPORT BEARING AXLE		02	04	04
18	0521014021	1/2" X 4.5" X 5.4" FASTENER		02	04	04
19	0511017302	FLAT WASHER		18	22	22
20	0503010019	1/2" SPRING WASHER		24	24	24
21	0503010060	1/2" NUT		18	22	22
22	0551019106	MOTOR SHAFT		02	00	00
23	0551019107	MOTOR SHAFT 1935 PST4 9		00	02	00
24	0551019108	2335 DRIVING AXLE		00	00	02
25	0501018466	FLAT WASHER		04	04	04
26	0503010523	1/4" X 2" COTTERPIN		02	02	02
27	0501052560	AXLE MOTOR SLOW-MOVING ASSY		02	02	02
27A	0503031825	AXLE MOTOR SLOW-MOVING		02	02	02
27B	0503010240	5/16" X 3/4" BOLT		02	02	02
27C	0503010179	SPRING WASHER		06	06	06
27D	0503010337	5/16" NUT		06	06	06

TRANSMISSION


0909093070

Item	Code	Description	See page	07	09	11
28	0511046744	TRANSMISSION DRIVING ASSY	10	02	04	04
29	0511047069	SIDE TRANSMISSION DRIVING		01	01	01
30	0511047070	LH SIDE TRANSMISSION DRIVING		01	01	01
31	0551019160	LEVER		02	02	02
32	0551019168	SLEEVE		02	02	02
33	0503010479	1/2" X 3" BOLT		02	02	02
34	0503014907	40-1 X 151 CHAIN LINK + MENDING		02	02	02
35	0503011750	AMENDMENT WITH LOCK		06	06	06
36	0503011751	REDUCTION		06	06	06
37	0551019167	SLEEVE UNION		02	02	02
38	0511069676	INNER LEVER		02	02	02
39	0503011172	1/2" X 2-1/2" BOLT		02	02	02
40	0501010984	FLAT WASHER		14	14	14
41	0503012718	40-1 CHAIN X 111 LINK + MENDING		02	02	02
42	0503010003	1845 GREASE FITTING		02	02	02
43	0503010140	1/8" X 3/4" COTTERPIN		06	06	06
44	0511069677	RH LOWER LEVER		01	01	01
45	0511069678	LH LOWER LEVER		01	01	01
46	0511069679	RH UPPER LEVER		02	02	02
47	0551019159	LEVER FIXER BODY		02	02	02
48	0501055112	MICRO GRANULATED CHAIN TENSIONER		02	02	02
48A	0531019479	AXLE CHAIN GEAR		02	02	02
48B	0503031805	11Z 1/2" GEAR		02	02	02
49	0501058265	STRETCHER LOWER CURRENT 21Z SEED		02	02	02
49A	0511062169	21Z P 1/2" GEAR		04	04	04
49B	0503011410	ROLLER BEARING		12	12	12
49C	0503011105	SEAL RING		06	06	06
49D	0531017086	50 AXLETIGHTENER		04	04	04
49E	0503010406	501025 CLAMPING RING (FOR AXLE)		10	10	10
49F	0501010197	5/8" X 3-1/2" BOLT		02	02	02
50	0501058254	UPPER SEED CHAIN TENSIONER		02	02	02
50A	0521018933	113 FERT CHAIN TENSIONER AXLE		02	02	02
50B	0503031805	11Z 1/2" GEAR		02	02	02
50C	0503010302	501019 SEAL RING		02	02	02
51	0501058266	BEARING WITH 21Z GEAR INNER		02	02	02
51A	0501011234	5/8" X 3" BOLT		02	02	02
51B	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		04	04	04
52	0501058267	DOUBLE BEARING WITH 17Z GEAR		02	02	02
52A	0551019175	DOUBLE GEAR AXLE		02	02	02
52B	0511069680	20Z X 28Z DOBLE GEAR		02	02	02
52C	0501010163	5/8" X 4-1/2" BOLT		02	02	02
53	0511047058	RIGHT GEAR BOX ASSY		01	01	01
54	0511047059	LH GEAR BOX ASSY		01	01	01
55	0501010243	1/2" X 1-1/2" BOLT		06	06	06
56	0503010920	1/2" X 1.1/2" BOLT		04	04	04
57	0503010020	1/2"NUT		06	06	06
58	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		02	02	02
59	0503030275	AGRICULTURAL BEARING		02	02	02
60	0501010637	FLAT WASHER		04	04	04
61	0503012522	40-1 CHAIN X 85 LINK + MENDING		02	02	02
62	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02	02	02
63	0503012719	40-1 CHAIN X 113 LINK + MENDING		02	02	02
64	0531016940	RIGHT 5/8" X 65" AXLE HEX		01	00	00
65	0531016941	LEFT 5/8" X 59" AXLE HEX		01	00	00
66	0531016942	5/8 X 2050 HEX AXLE		00	01	00
67	0531016943	5/8" X 75" AXLE HEX		00	01	00
68	0531016944	RIGHT 5/8" X 96" HEX AXLE		00	00	00
69	0531016945	LEFT 5/8" X 90" HEX AXLE		00	00	01
70	0501058270	BEARING WITH 20Z GEAR		02	02	02


Item	Code	Description	See page	07	09	11
70A	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8		02	02	02
70Aa	0502011987	DOUBLE HOUSING BEARING		02	02	02
70B	0511063106	20Z AXLE BEARING DOBLE		02	02	02
70C	0503010365	NUT		04	04	04
70D	0501010694	FLAT WASHER		08	08	08
71	0503011411	1/2" X 5-1/2" BOLT		04	04	04



Item	Code	Description	See page	QT
01	0511069659	RATCHET BODY		01
02	0551019044	14Z RATCHET GEAR		01
03	0551019100	LOCK RATCHET		02
04	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
05	0551019098	RATCHET SIDE SUPPORT		01
06	0551019099	RATCHET SIDE SUPPORT		01
07	0503010365	NUT		04
08	0503010179	SPRING WASHER		04
09	0503010337	5/16" NUT		04
10	0503010920	1/2" X 1.1/2" BOLT		01
11	0503010060	1/2" NUT		01
12	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	DR	ES
00	0511047069	SIDE TRANSMISSION DRIVING		01	00
00A	0511047070	LH SIDE TRANSMISSION DRIVING		00	01
01	0502011996	SLLEVE FIXER		01	01
02	0503030678	1/2"X1-1/2"BOLT		01	01
03	0503010060	1/2" NUT		01	01
04	0521017590	GUIDE AXLE		01	01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01	01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01	00
07	0502011995	LH DRIVING AXLE FOLLOWER		00	01
08	0501019734	FLAT WASHER		02	02
09	0502010710	RIGHT CAM, SMALLER		02	00
10	0502010720	RIGHT CAM, SMALLER		00	02
11	0503010003	1845 GREASE FITTING		02	02
12	0502012539	26Z P12,7 GEAR		01	00
13	0502012540	26Z P12,7 GEAR		00	01
14	0501019735	FLAT WASHER		01	01
15	0521017593	FLAT WASHER		01	01
16	0503010542	501045 CLAMPING RING (FOR AXLE)		01	01




Item	Code	Description	See page	DIR ESQ
00	0511047058	RIGHT GEAR BOX ASSY	01	00
00A	0511047059	LH GEAR BOX ASSY	00	01
01	0501058212	SEMI MOUNTED RIGHT CHANGE	01	00
01A	0511069565	LEFT GEAR BOX	01	00
01B	0502011758	REAR TENSIONER LEVER	02	02
01C	0503010292	0.2" X 1.6" SPRING PIN	07	07
01D	0511061794	CHAIN TENSIONER	01	01
01E	0503031367	SPRING	01	01
01F	0511061795	CHAIN TENSIONER	01	01
01G	0503031367	SPRING	01	01
02	0501058213	LH GEAR BOX	00	01
03	0503031805	11Z 1/2" GEAR	06	06
04	0503010302	501019 SEAL RING	04	04
05	0501048790	AXLE WITH LINK ASSY	02	02
05A	0521012476	GEAR BOX LEVER AXLE	02	02
05B	0503031369	LINK	02	02
06	0503010002	1800 GREASE FITTING	02	02
07	0551018209	DRIVING AXLE	01	01
08	0521018259	DRIVEN AXLE	01	01
09	0551018210	DRIVEN AXLE	01	01
10	0551018211	INTERM SHAFT	01	01
11	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	01	01
11A	0502011978	HOUSING CENTRAL BEARING	01	01
11B	0503013462	BEARING WITH BALL BEARING	07	07
11C	0503011953	5/16" X 1" BOLT	16	16
11D	0501010694	FLAT WASHER	16	16
11E	0503010179	SPRING WASHER	16	16
11F	0503010337	5/16" NUT	16	16
12	0503030303	SUPPORT WASHER	05	05
13	0501056443	BEARING ASSY GEAR BOX	02	02
13A	0501056444	BEARING WITH BALL BEARING	02	02

Item	Code	Description	See page	DIR ESQ
13Aa	0502011697	BEARING OF THE GEAR BOX		02 02
13Ab	0503011105	SEAL RING		07 07
14	0501056271	BEARING CLOSED		05 05
14A	0502012310	GEAR BOX CLOSE BEARING		05 05
15	0511060396	DRIVE/DRIVEN AXLE CONE		04 04
16	0503012389	1/2 BALL		04 04
17	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04 04
18	0503010060	1/2" NUT		06 06
19	0503010395	1/2" X 1-1/4" BOLT		04 04
20	0511061830	17Z P 0.5" GEAR SQUARE HOL		02 02
21	0511067501	26Z GEAR		01 01
22	0503012204	40-1 CHAIN X 82 LINK + RED		02 02
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01 01
24	0501054655	CHAIN TENSIONER ASSY		02 02
24A	0531019479	AXLE CHAIN GEAR		02 02
24B	0511017302	FLAT WASHER		02 02
24C	0503010019	1/2" SPRING WASHER		02 02
25	0501010984	FLAT WASHER		01 01
26	0503010025	3/8 SPRING WASHER		01 01
27	0503010256	3/8" X 3/4" BOLT		01 01
28	0521018630	1.4" X SQUARE 0.8" WASHER		01 01




Item	Code	Description	See page	QT
01	0501058182	WHEEL SUPPORT ASSY		01
01A	0511069398	WHEEL SUPPORT		01
02	0511069634	WHEEL ARM		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0501019757	EXTENSION GREASE FITTING		01
06	0503010003	1845 GREASE FITTING		01
07	0511061747	WHEEL SPRING REGULATOR		01
08	0521010575	C0.9" X 3.3" COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0521010510	SPRING SLEEVE GUIDES		02
11	0503030110	2.3"X 5.5"X 0.4" COMPRESSION SPRING		01
12	0521011158	SPRING LOCKNUT		01
13	0521018575	REGULATOR SPINDLE 100		01
14	0501058238	WELL AND TIRE ASSY		01
14A	0503061753	WELL AND TIRE ASSY		01
14B	0501053110	WHEEL TRANSMISSION WITHOUT TIRE	14	01
14C	0503010035	9/16" CONIC NUT		06
15	0521012190	AXLE LOCK		02
16	0503010027	SPRING WASHER		02
17	0503010027	SPRING WASHER		02
18	0501058241	TENSIONER CHAIN SUPPORT		01
18A	0541011713	TENSIONER CHAIN LOWER AXLE		01
18B	0541016454	PULLEY		01
18C	0503010302	501019 SEAL RING		01
18D	0503010019	1/2" SPRING WASHER		01
18E	0503010060	1/2" NUT		01
19	0501058240	WHEEL FASTENER WITH STRETCHER		01
19A	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
19B	0511069417	REAR TENSIONER		01
19C	0501058243	STRETCHER INTERMEDIATE ROD CURRENT		01

Item	Code	Description	See page	QT
19Ca	0501058239	CHAIN TENSIONER BEARING		03
19Cb	0502012018	CHAIN TIGHTENER BEARING		03
19Cc	0503012882	BALL BEARING		03
19Cd	0503011945	503050 CLAMPING RING (FOR AXLE)		03
19Ce	0551018245	CHAIN TENSIONER AXLE		01
19Cf	0551018241	SLEEVE 16,30 X 30 X 8		03
19Cg	0551018239	SLEEVE 19 X 13,50 X 45		01
19Ch	0503010019	1/2" SPRING WASHER		03
19Ci	0503010060	1/2" NUT		03
19D	0501058244	STRETCHER FIXED CURRENT		01
19Da	0551018252	CHAIN TIGHTENER AXLE		01
19E	0501058242	MOVIL CHAIN TENSIONER		01
19Ea	0551018244	CHAIN UPPER AXLE		01
19F	0501013491	5/8" TENSIONER SPRING		01
19G	0503010060	1/2" NUT		02
19H	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
20	0502011308	WHELL FASTENER		01
21	0503011118	7/8" X 5-1/2" BOLT		04
22	0501014251	FLAT WASHER		04
23	0503010408	7/8" SPRING WASHER		04
24	0503010417	7/8" NUT		04
25	0503014887	2050 CHAIN X 80 LINK + REDUCTION		01
26	0503010780	N-2050 AMENDMENT		02
27	0503010951	REDUCTION		04




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
02	0503010660	25590 CONE		02
03	0503010637	25523 CAP		02
04	0503010804	00547-B SEAL		02
05	0521012185	TRANSM AXLE CARRYING-WHEEL		01
06	0502011339	15Z GEAR P 1.25"		01
07	0503012550	5/16" X 3/4" BOLT		06
08	0511015949	LOCK NUT		01
09	0503010329	LOCK WASHER		01
10	0503010330	KM 9 LOCKNUT		01
13	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	07 09 11
00	0501058202	RH BEAM SUPPORT & METERING		01 00 00
00A	0501058203	LH BEAM SUPPORT & METERING		01 00 00
00B	0501058204	RH BEAM SUPPORT		00 01 01
00C	0501058205	LH BEAM SUPPORT		00 01 00
00D	0501058206	FERTILIZER BEAM SUPPORT		00 00 01
00E	0501058207	LH FERTILIZER BEAM SUPPORT		00 00 01
01	0511069617	RH BEAM SUPPORT		01 00 00
02	0511069618	LH BEAM SUPPORT		01 00 00
03	0511069534	RH BEAM SUPPORT		00 01 00
04	0511069535	LH BEAM SUPPORT		00 01 00
05	0511069619			00 00 01
06	0511069620			00 00 01
07	0501057951	DISTRIBUTOR FERTILIZER		07 09 12
07A	0511010553	RH FRAME BRACKET		07 09 12
07B	0501019851	DISTRIBUTOR FERTILIZER AXLE		07 09 12
07C	0521010309	SLEEVE INTER		07 09 12
07D	0503030275	AGRICULTURAL BEARING		14 18 24
07E	0503031165	LEFT HELICAL CONDUTOR		07 09 12
07F	0511017137	FLAT WASHER		07 09 12
07G	0503030303	SUPPORT WASHER		09 11 14
07H	0501013774	GREASE SEAL		07 09 12
07I	0502011412	18Z CONICAL GEAR		14 18 24
07J	0503010523	1/4" X 2" COTTERPIN		07 09 12
07K	0503011962	GREASE FITTING		07 09 12
07L	0503010003	1845 GREASE FITTING		14 18 24
07M	0503012826	CREASE FITTING		04 05 06
08	0501010942	3/8" X 1-1/4" BOLT		32 40 48
09	0503010025	3/8 SPRING WASHER		40 48 56
10	0503010026	3/8" NUT		40 48 56
11	0511061759	22Z P12,70 FQ 3/4" GEAR		02 02 02
12	0521014167	CONE LOCK		08 08 08
13	0551018055	22,65 X 60 SLEEVE		01 01 01

Item	Code	Description	See page	07 09 11
14	0551017677	3/4" X 1380 SQUARE SHAFT		01 00 00
15	0501018700	3/4" X 58" SQUARE SHAFT		01 00 00
16	0501018697	3/4" X 69" SQUARE SHAFT		00 01 00
17	0551018213	3/4" X 1830 SQUARE SHAFT		00 01 00
18	0511014265	3/4" X 86" SQUARE SHAFT		00 00 01
19	0551018198	SQUARE SHAFT		00 00 01
20	0521010691	AXLE FASTENER		04 04 04
21	0503010373	1/4" X 2" BOLT		04 04 04
22	0501010694	FLAT WASHER		16 16 16
23	0503011441	SPRING WASHER		04 04 04
24	0503010144	1/4" NUT		04 04 04
25	0501110392	SILO SUPPORT BEARING		02 02 02
26	0521012485	GEAR BOX BEARING AGRICUTURAL		02 02 02
27	0503011953	5/16" X 1" BOLT		08 08 08
28	0503010179	SPRING WASHER		08 08 08
29	0503010337	5/16" NUT		08 08 08
30	0503010003	1845 GREASE FITTING		02 02 02
31	0503010849	3/8" X 1-1/2" BOLT		08 08 08
32	0501010984	FLAT WASHER		16 16 16
33	0551019117	FERTILIZER DISTRIBUTOR COVER		08 10 12
34	0503010257	1/8" X 1" COTTERPIN		08 10 12
35	0503060636	COVER BOX RIGHT FERTILIZER		01 00 00
36	0503060637	COVER BOX LEFT FERTILIZER		01 00 00
37	0503060640	COVER BOX RIGHT FERTILIZER		00 01 00
38	0503060641	COVER BOX LEFT FERTILIZER		00 01 00
39	0503060642	COVER BOX RIGHT FERTILIZER		00 00 01
40	0503060643	COVER BOX LEFT FERTILIZER		00 00 01
41	0511062099	FERTILIZER BEAM CLAMP		04 04 04
42	0511061886	FERTILIZER BEAM LOCK		04 04 04
43	0503010019	1/2" SPRING WASHER		04 04 04
44	0503010060	1/2" NUT		04 04 04
45	0551019156	GEAR BOX LEVER LOCK		02 02 02
46	0503032624	FERTILIZER BEAN LIP		04 04 04




Item	Code	Description	See page	07 09 11
01	0502011567	FERTILIZER ROW SUPPORT		07 09 11
02	0502010175	HITCH CLAMP		07 09 11
03	0501011543	5/8" X 4" BOLT		14 18 22
04	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		14 18 22
05	0501054239	ARM SHORT LINE WITH FERTILIZER DDD LEFT		04 05 06
05A	0521061121	SHORT FERTILIZER ROW ARM		04 05 06
05B	0511018662	SPACING PLATE		28 36 44
05C	0501052977	DDD LEFT FERTILIZER 15 X 15 ASSY	18	04 05 06
05D	0503010547	1/2" X 4" BOLT		14 18 22
05E	0503011440	SPRING WASHER		14 18 22
05F	0503010060	1/2" NUT		14 18 22
06	0501054240	ARM LONG FERTILIZER LINE WITH DDD RIGHT		03 04 05
06A	0521061153	LONG FERTILIZER ROW ARM		03 04 05
06B	0501052976	15 X 15 RIGHT FERT UNAL DOUB-DISC ASSY	17	03 04 05
07	0501010066	3/4" X 9" BOLT		07 09 11
08	0521017831	SUPPORT SLEEVE SPACER		14 18 22
09	0511017232	FLAT WASHER		14 18 22
10	0503011255	3/4" LOCK NUT		07 09 11
11	0501058423	FERTILIZER ROD SPRING ROW		07 09 11
11A	0511069645	FERTILIZER SPRING ROD		07 09 11
11B	0502012196	SPRING GUIDE BEARING LOCK		14 18 22
11C	0501018535	1/2 X 1 BOLT		14 18 22
11D	0502012184	FERTILIZER SPRING GUIDE		07 09 11
11E	0503031910	1.7" X 22.8" X 0.3" SPRING		07 09 11
11F	0502012510	SPRING ROD SUPPORT		07 09 11
11G	0503030679	1/2" X 1-1/4" BOLT		07 09 11
11H	0503030678	1/2"X1-1/2"BOLT		07 09 11
11I	0502010891	SPRING CHOCK SUPPORT VARON		07 09 11
11J	0503010014	3/4" NUT		07 09 11
11K	0561014471	COUPLING SHAFT		07 09 11
11L	0511017302	FLAT WASHER		07 09 11


Item	Code	Description	See page	07 09 11
11M	0503010257	1/8" X 1" COTTERPIN		07 09 11
12	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW		04 05 06
13	0511044573	18" COULTER BLADE ASSY FOR LONG ROW		03 04 05
14	0503030391	RIGHT FERTILIZER SOCKET		04 05 06
15	0503030392	LEFT FERTILIZER SOCKET		03 04 05
16	0503031050	CURVED CONDUCTOR		10 14 18
17	0503010246	CLAMP		10 14 18
18	0503031145	2" X 2" X 20" HOSE		07 09 11
19	0503031076	2" HOSE CLAMP		14 18 22
20	0501110231	SCARIFIER HEAD WITH SPIKE 0061		07 09 11
20A	0511061768	FERTILIZER SCARIFIER SPINDLE		07 09 11
20B	0502070061	POINT SUBSOILER		07 09 11
20C	0503011373	0.4" X 1.1" SPRING PIN		07 09 11
21	0511061852	ADJUSTAMENT CONDUCTOR FERTILIZER		07 09 11
22	0511017969	0.1" SPACING PLATE		14 18 22
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		14 18 22
24	0501010984	FLAT WASHER		28 36 44
25	0503010025	3/8 SPRING WASHER		14 18 22
26	0503010026	3/8" NUT		14 18 22
27	0511016156	5/8" X 1.1/2" BOLT		14 18 22



Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT	01	
02	0502011930	DOUBLE DISC COULTER BOX	02	
03	0503010598	30204 BALL BEARING	04	
04	0503011112	SEAL 02376-BRG	02	
05	0521019148	LEFT DOUBLE DISC HUB	01	
06	0503030282	3/4" CASTLE NUT	02	
07	0503010257	1/8" X 1" COTTERPIN	02	
08	0603022042	13" X 0.12" PLAIN COULTER BLADE	02	
09	0503010546	5/16" X 7/8" BOLT	12	
10	0503010337	5/16" NUT	12	
11	0511015098	FLAT WASHER	06	
12	0511011927	DUST CLOAK	02	
13	0503030757	2.9" X 2" X 0.02" JOINT	02	
14	0521019178	COVER DEPTH	02	
15	0503014729	1/4" UNF X 1/2" BOLT	06	
16	0503011441	SPRING WASHER	06	
17	0501017542	LH DOUBLE DISC SCRAPER	01	
18	0501017541	RH DOUBLE DISC SCRAPER	01	
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	
20	0501010984	FLAT WASHER	02	
21	0503011443	SPRING WASHER	01	
22	0503010026	3/8" NUT	01	
23	0502070062	SCRAPER	01	
24	0503011402	0.2" X 0.8" SPRING PIN	01	
25	0521019154	RIGHT DOUB DISC HUB	01	




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT	01	
02	0502011930	DOUBLE DISC COULTER BOX	02	
03	0503010598	30204 BALL BEARING	04	
04	0503011112	SEAL 02376-BRG	02	
05	0521019148	LEFT DOUBLE DISC HUB	01	
06	0503030282	3/4" CASTLE NUT	02	
07	0503010257	1/8" X 1" COTTERPIN	02	
08	0603022042	13" X 0.12" PLAIN COULTER BLADE	02	
09	0503010546	5/16" X 7/8" BOLT	12	
10	0503010337	5/16" NUT	12	
11	0511015098	FLAT WASHER	06	
12	0511011927	DUST CLOAK	02	
13	0503030757	2.9" X 2" X 0.02" JOINT	02	
14	0521019178	COVER DEPTH	02	
15	0503014729	1/4" UNF X 1/2" BOLT	06	
16	0503011441	SPRING WASHER	06	
17	0501017542	LH DOUBLE DISC SCRAPER	01	
18	0501017541	RH DOUBLE DISC SCRAPER	01	
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	
20	0501010984	FLAT WASHER	02	
21	0503011443	SPRING WASHER	01	
22	0503010026	3/8" NUT	01	
23	0502070062	SCRAPER	01	
24	0503011402	0.2" X 0.8" SPRING PIN	01	
25	0521019154	RIGHT DOUB DISC HUB	01	




Item	Code	Description	See page	CT LG
00	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW		01 00
00A	0511044573	18" COULTER BLADE ASSY FOR LONG ROW		00 01
01	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE		01 00
02	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE		00 01
03	0502012368	BLADE DISC SUPPORT AXLE		01 01
04	0511016156	5/8" X 1.1/2" BOLT		02 02
05	0503010756	0.2" X 2.4" SPRING PIN		01 01
06	0503010361	SPRING PIN		01 01
07	0541018684	FLAT WASHER		01 01
08	0521014137	RIGHT ARM OF THE BLADE DISC		01 01
09	0521014138	SUPPORT ARM LEFT BALDE DISC		01 01
10	0501067323	SPRING REGULATOR		01 01
11	0521010452	SLEEVE		01 01
12	0503013185	3/4" X 5-1/2" BOLT		01 01
13	0503011255	3/4" LOCK NUT		01 01
14	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01 01
15	0503011411	1/2" X 5-1/2" BOLT		01 01
16	0503011440	SPRING WASHER		01 01
17	0503010060	1/2" NUT		01 01
18	0502020393	SPRING UPPER SUPPORT		01 01
19	0502020394	SPRING SUPPORT		01 01
20	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01 01
21	0503010014	3/4" NUT		02 02
22	0521015376	DUST CLOAK		02 02
23	0502011562	DC PST ACT/ULTR BOX		01 01
24	0503010276	6206 BALL BEARING		02 02
25	0521013610	BLADE DISC HUB AXLE		01 01
26	0503030832	FLAT WASHER		02 02
27	0503012417	SEAL		02 02
28	0503011800	SEAL RING		02 02
29	0503010691	1/4" GREASE FITTING		01 01

Item	Code	Description	See page	CT LG
30	0603026013	PLAIN COULTER BLADE		01 01
31	0502020641	BLADE DISC FLANGE		01 01
32	0503010371	5/16" X 1" BOLT		06 06
33	0503011444	SPRING WASHER		06 06
34	0503010337	5/16" NUT		06 06
35	0511015346	FLAT WASHER		02 02
36	0503011442	3/4" SPRING WASHER		02 02
37	0521013510	3/4" NUT		02 02
38	0503010003	1845 GREASE FITTING		01 01




Item	Code	Description	See page	CT LG
00	0501059837	SHORT SEED ROW FRONT		01 00
00A	0501059838	SHORT SEED ROW FRONT		01 00
00B	0501059839	LONG FRONT SEED ROW		00 01
00C	0501059840	LONG FRONT SEED ROW		00 01
01	0502010175	HITCH CLAMP		02 02
02	0521061238	RH SEED ROW SUPPORT FRONT		01 00
03	0521061237	LH SEED ROW SUPPORT FRONT		01 00
04	0521061425	RH SEED ROW SUPPORT FRONT		00 01
05	0521061426	LH SEED ROW SUPPORT FRONT		00 01
06	0501010163	5/8" X 4-1/2" BOLT		04 04
07	0501012140	FLAT WASHER		04 04
08	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		04 04
09	0503012882	BALL BEARING		04 04
10	0503011945	503050 CLAMPING RING (FOR AXLE)		04 04
11	0561017947	17Z GEAR WITH HEX HOLE		02 02
12	0511050073	SEED ROW TRANSMISSION HUB	22	02 02
13	0561014904	TRANSMISSION AXLE FRAME LINE		02 02
14	0511050609	BEARING WITH 17Z GEAR ASSY		02 02
14A	0511050617	FRONT SEED ROW BEARING		02 02
14Aa	0502011697	BEARING OF THE GEAR BOX		02 02
14Ab	0503011105	SEAL RING		06 06
14Ac	0503011953	5/16" X 1" BOLT		04 04
14Ad	0501010694	FLAT WASHER		04 04
14Ae	0503010179	SPRING WASHER		04 04
14Af	0503010337	5/16" NUT		04 04
14Ag	0503011410	ROLLER BEARING		02 02
14B	0561017909	17Z GEAR WITH HEX HOLE		02 02
14C	0503010406	501025 CLAMPING RING (FOR AXLE)		02 02
15	0511050610	SEED ROW CHAIN TENSIONER ASSY		02 02
15A	0531019479	AXLE CHAIN GEAR		02 02
15B	0541016454	PULLEY		02 02


Item	Code	Description	See page	CT LG
15C	0521014188	FLAT WASHER		02 02
15D	0503010019	1/2" SPRING WASHER		02 02
15E	0503010060	1/2" NUT		02 02
16	0502012666	SEDD ROW LOWER ARM		02 02
17	0503010003	1845 GREASE FITTING		08 08
18	0561015858	SPACER LOWER SLEEVE		02 02
19	0531015151	0.6" X 1" X 2.4" SLEEVE		14 14
20	0531015184	FLAT WASHER		16 16
21	0501010422	5/8" X 6-1/2" BOLT		08 08
22	0502012350	SEED ROW UPPER ARM		02 02
23	0521061427	SHORT SEED ROW FRAME		02 02
24	0502012568	UPPER ROCKER ARM		02 02
25	0561019032	SEED FERTIL ROW LOCK		02 02
26	0501011388	COUPLING SHAFT		04 04
27	0503010071	3/16" X 1" COTTERPIN		02 02
28	0503030168	HAIR PIN		02 02
29	0521061850	SPRING UPPER FIXER		02 02
30	0521010773	0.37" X 1.18" COUPLING SHAFT		02 02
31	0503010140	1/8" X 3/4" COTTERPIN		02 02
32	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		04 04
33	0511051328	STELL CABLE WHIT UNIVERSAL JOINT	23	02 02
34	0503016014	40-1 CHAIN X 92 LINK + RUDUCTION		02 02




Item	Code	Description	See page	QT
13E	0503010060	1/2" NUT		02
14	0503016014	40-1 CHAIN X 92 LINK + RUDUCTION		02
15	0502012666	SEDD ROW LOWER ARM		02
16	0503010003	1845 GREASE FITTING		08
17	0561015858	SPACER LOWER SLEEVE		02
18	0531015151	0.6" X 1" X 2.4" SLEEVE		14
19	0531015184	FLAT WASHER		16
20	0501010422	5/8" X 6-1/2" BOLT		08
21	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		08
22	0502012350	SEED ROW UPPER ARM		02
23	0521061427	SHORT SEED ROW FRAME		02
24	0502012568	UPPER ROCKER ARM		02
25	0561019032	SEED FERTIL ROW LOCK		02
26	0501011388	COUPLING SHAFT		04
27	0503010071	3/16" X 1" COTTERPIN		02
28	0503030168	HAIR PIN		02
29	0521061850	SPRING UPPER FIXER		02
30	0521010773	0.37" X 1.18" COUPLING SHAFT		02
31	0503010140	1/8" X 3/4" COTTERPIN		02
32	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		04
33	0511050611	5/8" HEX AXLE BEARING		02
33A	0501059363	5/8" HEX AXLE BEARING		02
33Aa	0502011697	BEARING OF THE GEAR BOX		02
33Ab	0561014911	AXLE SLEVE GUIDES HEX		02
33B	0503011953	5/16" X 1" BOLT		04
34	0501059326	UNIVERSAL JOINT AXLE		02
34A	0561014794	350 AXLE HEX		02
34B	0501056296	UNIVERSAL JOINT ASSY		02
34C	0561016322	5/8" HEX AXLE		02
34D	0503011855	0.2" X 1.8" SPRING PIN		04
35	0521061238	RH SEED ROW SUPPORT FRONT		01
36	0521061426	LH SEED ROW SUPPORT FRONT		00



Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0503011410	ROLLER BEARING		02
03	0561016713	PINION CONICAL PLASTIC		01
04	0503010707	501030 CLAMPING RING (FOR AXLE)		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0561016712	16Z CONICAL GEAR PLASTIC		01
07	0502012464	BOX TRANSMISSION COVER		01
08	0503012861	6006 2RS BALL BEARING		02
09	0503011945	503050 CLAMPING RING (FOR AXLE)		01
10	0503011378	M6 X 1" BOLT		03
11	0503010143	SPRING WASHER		03
12	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
00	0511051328	STELL CABLE WHIT UNIVERSAL JOINT	23	
01	0521062650	CABLE TRANSMISSION		01
02	0503010300	5/32" X 1" COTTERPIN		01
03	0561019877	UNIVERSAL JOINT		01
04	0561019872	5/8" X 350 HEX AXLE		01
05	0503015356	SPRING PIN		02
06	0511051332	BEARING WITH SLEEVE		01
06A	0503011410	ROLLER BEARING		01
06B	0503011105	SEAL RING		01
06C	0501010694	FLAT WASHER		02
06D	0503010179	SPRING WASHER		02
06E	0503010337	5/16" NUT		02
06F	0503010371	5/16" X 1" BOLT		02
06G	0561019880	BEARING OF THE GEAR BOX		01
06H	0561019881	FIXING THE CABLE SLEEVE STEEL		01
06I	0561019882	TRANSMISSION SLEEVE FIXER		01
06J	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0502012648	10Z CONICAL GEAR		01
08	0502012681	CABLE STEEL BEARING SUPPORT		01
09	0502012682	CABLE STEEL BEARING		01
10	0503010363	5/16" X 1" BOLT		02
11	0501010984	FLAT WASHER		02
12	0503010179	SPRING WASHER		02
13	0503010337	5/16" NUT		01




Item	Code	Description	See page	07 09 11
00	0521040109	REAR RIGHT SEED ROW		01 01 01
00A	0521040112	REAR LEFT SEED ROW		01 01 01
00B	0521040111	DEP CONT WHEELS PRESS WHEELS ASSY		01 01 01
01	0511051447	CONTROL DEPTH ASSY		01 01 01
02	0501052538	DEPTH BAND WITH ARMS	26	02 02 02
03	0503010358	5/16" X 5/8" BOLT		08 08 08
04	0503013816	5/16" LOCKNUT		08 08 08
05	0501052908	COMPACTOR WHEEL WITH BEARING		02 02 02
06	0503010706	1/2" X 4.1/2" BOLT		02 02 02
07	0521014508	FLAT WASHER		12 12 12
08	0503011336	1/2" HEX SELF ADJUSTING NUT		02 02 02
09	0503033124	SOCKET SEED		01 01 01
10	0511048674	PNEUMATIC SEED DISTRIBUTOR		01 01 01
11	0503011404	3/8" X 1-3/4" BOLT		04 04 04
12	0503010025	3/8 SPRING WASHER		11 11 11
13	0503010026	3/8" NUT		10 10 10
14	0511050809	SEMIFINISHED FAST CLOSING SET		01 01 01
14A	0541016855	SPEED ??LOCK LEVER ASSY		01 01 01
14B	0561019318	PRISONER CLOSING FAST		01 01 01
14C	0551018050	FAST BOLT GUIDE AXLE		01 01 01
14D	0503010257	1/8" X 1" COTTERPIN		02 02 02
14E	0561019270	FAST BOLT ADJUSTMENT		01 01 01
15	0521060631	FIXING BASE BOX		01 01 01
16	0502011760	SEED SILO SUPPORT		01 01 01
17	0501010942	3/8" X 1-1/4" BOLT		04 04 04
18	0531018349	SEED FLOW SWITCH PNEUMATIC SYSTEM		01 01 01
19	0501011643	3/8 X 1"BOLT		01 01 01
20	0501010984	FLAT WASHER		20 20 20
21	0503010209	3/8" UNC BUTTERFLY NUT		01 01 01
22	0503031508	COVER GREEN BEAM SEED YELLOW		01 01 01
23	0531010631	SEED BEAM CLAMP		04 04 04

Item	Code	Description	See page	07 09 11
24	0503010371	5/16" X 1" BOLT		04 04 04
25	0503010179	SPRING WASHER		04 04 04
26	0503010337	5/16" NUT		04 04 04
27	0561019420	2 X 2700 HOSE ASSY		01 00 00
28	0501081509	2" X 2800 HOSE ASSY		00 01 00
29	0551019400	2" X 3000 HOSE ASSY		00 01 01
30	0551015618	2" X 2900 HOSE ASSY		00 00 01
31	0511063282	HOSE HOLDER		01 01 01
32	0511050819	DISC 2440 CORN		01 01 01
33	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02 02 02




Item	Code	Description	See page
00	0511051447	CONTROL DEPTH ASSY	01
01	0502012282	DEPTH CONTROL SUPPORT	01
02	0531010765	DEPTH WHEEL AXLE	01
03	0503010256	3/8" X 3/4" BOLT	01
04	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE	02
05	0511015346	FLAT WASHER	04
06	0511069633	PRESS WHEELS COMPACTOR	01
07	0501058576	RIGHT WHEEL ARM	01
07A	0502012553	DEPTH WHEEL RIGHT ARM	01
07B	0501052627	ASSY DEPTH WHEEL BOX	28 01
07C	0503015021	6871-GA SEAL RING	02
07D	0503010002	1800 GREASE FITTING	01
07E	0503010740	1/2" X 2" BOLT	02
07F	0503011440	SPRING WASHER	04
07G	0503010060	1/2" NUT	02
08	0501058577	RIGHT ARM DEPTH CONTROL WHEEL	01
08A	0502012552	LH ARM DEPTH CONTROL WHEEL	01
09	0503010834	1/2 X 1 BOLT	02
10	0511017302	FLAT WASHER	02
11	0501052297	DEPTH WHEELS REGULATOR ASSY	01
11A	0502011689	1/8" DEPTH CONTROL LEVER	01
11B	0503030975	0.9" X 1.5" X 0.1" SPRING	01
11C	0511015976	FLAT WASHER	01
11D	0502011688	SEED SIST CONTROL DEPTH LEVER	01
11E	0511060699	DEPTH WHEEL STOP	01
11F	0503010257	1/8" X 1" COTTERPIN	02
11G	0503010071	3/16" X 1" COTTERPIN	01
12	0521019093	0.6" X 2.7" PIVOT SHAFT	01
13	0502012116	PRESS WHEEL ADJUSTER	01
14	0503010849	3/8" X 1-1/2" BOLT	02
15	0503011443	SPRING WASHER	02


Item	Code	Description	See page
16	0503010026	3/8" NUT	02
17	0541016906	PRESS WHEELS REGULATOR BODY	01
18	0521010539	0.3" X 1.2" COUPLING SHAFT	01
19	0503010140	1/8" X 3/4" COTTERPIN	01
20	0503030805	1.6" X 6" X 0.2"TRACTION SPRING	01
21	0501059631	DDD SEED 15" X 15" RIGHT	01
22	0501059632	DDD SEED 15X15 LEFT	01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	SPRING WASHER		05
05	0503010144	1/4" NUT		05



Item	Code	Description	See page
01	0501052908	COMPACTOR WHEEL WITH BEARING	01
01A	0502011919	PRESS WHEEL HUB	01
01B	0502011877	PRESS WHEEL HUB	01
01C	0521018922	PRESS WHEEL PASSANG AXLE	02
01D	0521018921	DUST CLOAK	01
01E	0521016316	DUST CLOAK	01
01F	0503012734	SEAL 01556 BR	02
01G	0503010269	6204 BALL BEARING	02
01H	0521018928	PRESS WHEEL RIM	02
01I	0503031421	DEPTH CONTROL WHEEL RUBBER BAND	01
01J	0503010295	5/16" X 5/8" BOLT	06
01K	0503010179	SPRING WASHER	06
01L	0503010337	5/16" NUT	06
01M	0503010371	5/16" X 1" BOLT	03
02	0502012116	PRESS WHEEL ADJUSTER	01
03	0503010706	1/2" X 4.1/2" BOLT	02
04	0521014508	FLAT WASHER	12
05	0503011336	1/2" HEX SELF ADJUSTING NUT	02
06	0503010691	1/4" GREASE FITTING	02
07	0511069633	PRESS WHEELS COMPACTOR	01
08	0503010849	3/8" X 1-1/2" BOLT	02
09	0503011443	SPRING WASHER	02
10	0503010026	3/8" NUT	02
11	0541016906	PRESS WHEELS REGULATOR BODY	01
12	0521010539	0.3" X 1.2" COUPLING SHAFT	01
13	0503010140	1/8" X 3/4" COTTERPIN	01
14	0503030805	1.6" X 6" X 0.2" TRACTION SPRING	01



Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	COVER DEPTH		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	DIR	ESQ
00	0501059631	DDD SEED 15" X 15" RIGHT		01	00
00A	0501059632	DDD SEED 15X15 LEFT		00	01
01	0511052301	SUPPORT DDD 15 RIGHT		01	00
01A	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01	00
01B	0571012491	SOCKET SEED GUIDE		01	01
01C	0503010838	0.1" X 0.8" SPRING PIN		02	02
02	0511052302	LH SUPPORT DDD GUIDE		00	01
02A	0561015592	15" X 15" RIGHT DOUBLE DISC SUPPORT		00	01
03	0511015098	FLAT WASHER		06	06
04	0511011927	DUST CLOAK		02	02
05	0501054167	BOX DDD ASSY DPL 15 RIGHT		01	00
05A	0502011930	DOUBLE DISC COULTER BOX		02	02
05B	0503010598	30204 BALL BEARING		04	04
05C	0503011112	SEAL 02376-BRG		02	02
05D	0521019154	RIGHT DOUB DISC HUB		01	00
05E	0503030282	3/4" CASTLE NUT		02	02
05F	0503010257	1/8" X 1" COTTERPIN		02	02
05G	0603022042	13" X 0.12" PLAIN COULTER BLADE		02	02
05H	0503010546	5/16" X 7/8" BOLT		12	12
05I	0503010337	5/16" NUT		12	12
06	0501054168	BOX DDD ASSY DPL 15 LEFT		00	01
06A	0521019148	LEFT DOUBLE DISC HUB		00	01
07	0503030757	2.9" X 2" X 0.02" JOINT		02	02
08	0521019178	COVER DEPTH		02	02
09	0503014729	1/4" UNF X 1/2" BOLT		06	06
10	0503011441	SPRING WASHER		06	06
11	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01	01
12	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01	01
13	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01	01
14	0501010984	FLAT WASHER		02	02
15	0503011443	SPRING WASHER		01	01



PST4 FLEX SUPREMA
15X15 SEED UNAL DOUB-DISC ASSY


Page 29
0909093298

Item	Code	Description	See page	DIR	ESQ
16	0503010026	3/8" NUT		01	01




Item	Code	Description	See page	07	09	11
00	0511047234	MEC ROW MARKER ASSY PST4/FLEX SUP 7		02	00	00
00.	0511047122	MEC ROW MARKER ASSY PST4/FLEX SUP 9		00	02	00
00..	0511047207	MEC ROW MARKER ASSY PST4/FLEX SUP11		00	00	02
01	0511069621	MECANIC ROW MARK SUPPORT		02	02	02
02	0503012407	5/8" X 1-1/2" BOLT		08	08	08
03	0503010027	SPRING WASHER		15	15	15
04	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		13	13	13
05	0551018204	RIGHT ROW MARKER FIXER		01	01	01
06	0551018205	LH ROW MARKER FIXER		01	01	01
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		06	06	06
08	0501010984	FLAT WASHER		12	12	12
09	0503010025	3/8 SPRING WASHER		08	08	08
10	0503010026	3/8" NUT		08	08	08
11	0521010549	COUPLING SHAFT		02	02	02
12	0503030168	HAIR PIN		02	02	02
13	0511060475	ROW MARKER ARM		01	01	01
14	0511060576	LH ROW MARKER ARM		01	01	01
15	0503010769	5/8" X 2-1/4" BOLT		04	04	04
16	0521010479	SLEEVE ARTICULATION		04	04	04
17	0501066949	1235 TURNBUCKLE		02	02	02
18	0511016156	5/8" X 1.1/2" BOLT		04	04	04
19	0502010421	SIDE PULLEY		02	02	02
20	0521010445	0.53" X 0.75" X 0.45" SLEEVE		02	02	02
21	0521010641	COUPLING SHAFT		02	02	02
22	0503010140	1/8" X 3/4" COTTERPIN		04	04	04
23	0501058313	ROW MARKER PIVOT		01	01	01
23A	0501065640	ROW MARKER ROD GUIDE		02	02	02
23B	0503010238	1/2" X 1-3/4" BOLT		02	02	02
23C	0503010740	1/2" X 2" BOLT		02	02	02
23D	0511017302	FLAT WASHER		06	06	06
23E	0503010019	1/2" SPRING WASHER		13	13	13

Item	Code	Description	See page	07	09	11
23F	0503010060	1/2" NUT		11	11	11
23G	0501065644	ROW MARKER ARM/DISARMMENT ROD		01	01	01
23H	0501064229	REGULATOR ARM/DISARMMENT ROD		01	01	01
23I	0501062547	ROW MARKER BAR REGULATOR		01	01	01
23J	0503010395	1/2" X 1-1/4" BOLT		01	01	01
23K	0521010454	0.83" X 1.25" X 0.79" SLEEVE		01	01	01
23L	0503010734	1/2" X 2-1/2" BOLT		01	01	01
23M	0521010539	0.3" X 1.2" COUPLING SHAFT		02	02	02
23N	0503010013	5/8" NUT		02	02	02
23O	0531010412	ROW MARKER ARM LOCK		02	02	02
23P	0503032995	STEEL CABLE		01	01	01
23Q	0501010096	3/8" X 2" BOLT		02	02	02
23R	0531010415	ROW MARKER ARM/DISARM GUIDE SLLEVE		04	04	04
23S	0501065642	ROW MARKER SUPPORT		01	01	01
23T	0502011231	CENTRAL PULLEY		03	03	03
23U	0521010693	PULLEY FIXER PLATE		01	01	01
23V	0511011308	BOLT		02	02	02
23W	0503010691	1/4" GREASE FITTING		02	02	02
23X	0503010232	5/8" X 1.3/4" BOLT		02	02	02
24	0503010762	5/8" X 3-12" BOLT		01	01	01
25	0503011129	6,4 X 1900 CHAIN		02	02	02
26	0502011291	CHAIN SLEEVE		02	02	02
27	0503010683	0,2" X 1,2" SPRING PIN		02	02	02
28	0551019266	RIGHT PROTECTION COVER		01	01	01
29	0551019267	LEFT PROTECTION COVER		01	01	01
30	0503010920	1/2" X 1.1/2" BOLT		02	02	02
31	0551018955	1/2" X 1-1/2" BOLT		02	02	02
32	0501050633	MARKER DISC ASSY LINE	31	02	02	02
33	0521013164	PROTRACTOR TURNBUCKLE		02	02	02
34	0501011310	FIXER LOCK		02	02	02
35	0503010706	1/2" X 4.1/2" BOLT		02	02	02




Item	Code	Description	See page	QT
01	0511053904	DISC LINE MARKER		01
02	0503010023	SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	07 09 11
00	0511047235	HYDR ROW MARK ASSY PST4/FLEX SUP 7		01
00B	0511047101	HYDR ROW MARK ASSY PST4/FLEX SUP 9		01
00C	0511047214	HYDR ROW MARK ASSY PST4/FLEX SUP11		01
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	5/8" X 2" BOLT		08
03	0503010027	SPRING WASHER		08
04	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		08
05	0503011070	BEATER		02
06	0551019213	FLAT WASHER		02
07	0503011336	1/2" HEX SELF ADJUSTING NUT		02
08	0501069470	ROW MARKER ARM		02
09	0521017686	5/8 UNF X 5/8 UNF X 335 PRISONER		02
10	0521017687	SPACING SLEEVE		02
11	0521010479	SLEEVE ARTICULATION		04
12	0501012140	FLAT WASHER		04
13	0503012795	5/8" HEX SELF ADJUSTING NUT		04
14	0511040203	1.5" X 2.5" X 19" X 9" HYDRAULIC CYLINDER	34	02
15	0521010574	C0.9" X 3.3" COUPLING SHAFT		02
16	0503010523	1/4" X 2" COTTERPIN		04
17	0511015779	1" X 4.2" AXLE		02
18	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
19	0501068994	0.3" X 3.1" LOCK PIN		02
20	0503030168	HAIR PIN		02
21	0501066949	1235 TURNBUCKLE		02
22	0511016156	5/8" X 1.1/2" BOLT		04
23	0502010477	UPPER CLIP		06
24	0501010096	3/8" X 2" BOLT		02
25	0501010984	FLAT WASHER		04
26	0503010025	3/8 SPRING WASHER		10
27	0503010026	3/8" NUT		10
28	0503010740	1/2" X 2" BOLT		04


Item	Code	Description	See page	07 09 11
29	0521010445	0.53" X 0.75" X 0.45" SLEEVE		04
30	0503010019	1/2" SPRING WASHER		08
31	0503010060	1/2" NUT		08
32	0551019266	RIGHT PROTECTION COVER		01
33	0551019267	LEFT PROTECTION COVER		01
34	0503010920	1/2" X 1.1/2" BOLT		02
35	0551018955	1/2" X 1-1/2" BOLT		02
36	0501050633	MARKER DISC ASSY LINE	31	02
37	0521013164	PROTRACTOR TURNBUCKLE		02
38	0501011778	3/8" X 2-1/2" BOLT		04
39	0503011443	SPRING WASHER		04
40	0501069226	ROW MARKER ROD STOP		02




Item	Code	Description	See page	07 09 11
01	0511011311	VALV. SUPPORT		01 01 01
02	0503010232	5/8" X 1.3/4" BOLT		02 02 02
03	0503010027	SPRING WASHER		02 02 02
04	0503010013	5/8" NUT		02 02 02
05	0501054649	SEQUENTIAL VALVE ASSY	35	01 01 01
06	0503010365	NUT		02 02 02
07	0503010179	SPRING WASHER		02 02 02
08	0501010694	FLAT WASHER		02 02 02
09	0501080452	3/8" X 98" TR-TR HOSE ASSY		02 00 00
10	0501080401	3/8" X 106" TR-TC HOSE ASSY		02 00 00
11	0501080422	3/8" X 157" TC-TM HOSE ASSY		02 02 02
12	0501081727	TR-TR HOSE ASSY		00 02 00
13	0501080447	3/8" X 122" TR-TC HOSE ASSY		00 02 00
14	0501080343	TR-TR HOSE ASSY		00 00 02
15	0501080720	3/8" X 137" TR-TC HOSE ASSY		00 00 02
16	0501053834	MALE QUICK COUPLING AGRICULTURAL WITH COVER - 1/2 NPT		02 02 02
16A	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT		02 02 02
16B	0503011882	QUICK CONNECTION COVER		02 02 02




Item	Code	Description	See page	QT
01	0511062810	2.5" X 15" CYLINDER CASE		01
02	0501065662	HYDRAULIC CYLINDER TURNBUCKLE		01
03	0502010471	MOBILE COVER		01
04	0502010780	RING SUPPORT		01
05	0503010163	D-1500 SCRAPER RING		01
06	0503010989	1870-1500-375-B GASKET		01
07	0503010970	W1-1650-500 PK O'RING G.E		01
08	0503011058	8-330 BACK-UP RING		01
09	0503010161	2-330 N 3006 9B O'RING		01
10	0503010285	2-222 N 3006-9B O'RING		01
11	0502010783	1.5" X 2.5" PISTON		01
12	0503010160	2500 2000 GASKET		02
13	0503010973	W2-2500-500 PK O'RING G.E		01
14	0503010063	1" SELF-ALIGNING NUT		01
15	0503030384	CON N-001 PLUG		02
16	0501032666	HYDRAULIC CYLINDER REPAIR KIT		01



Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02



Item	Code	Description	See page	DIR ESQ
00	0511046364	RH FERTILIZER SCARIFIER SPINDLE		01 00
00A	0511046365	LH FERTILIZER SCARIFIER SPINDLE		00 01
01	0501110559	SCARIFIER SPINDLE W/POINT		01 01
01A	0511069285	ROD SCARIFIER SPINDLE		01 01
01B	0502070061	POINT SUBSOILER		01 01
01C	0503011373	0.4" X 1.1" SPRING PIN		01 01
02	0511069242	RIGHT ADJUSTMENT CONDUCTOR FERTILIZER		01 00
03	0511069243	LEFT ADJUSTMENT CONDUCTOR FERTILIZER		00 01
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02 02
05	0501010984	FLAT WASHER		04 04
06	0503010025	3/8 SPRING WASHER		02 02
07	0503010026	3/8" NUT		02 02
08	0511069286	VERTICAL SPINDLE DESASSEMBEL		01 01
09	0503031593	SPRING		01 01
10	0511069284	550 SPRING ROD GUIDE		01 01
11	0521017831	SUPPORT SLEEVE SPACER		01 01
12	0502012496	SPRING ROD ROCKER ARM		01 01
13	0502012500	SPRING ROD LARGER BUSHING		01 01
14	0551017716	SLEEVE 16,5 X 28,58 X 40,0/39,9		01 01
15	0503010013	5/8" NUT		05 05
16	0551017724	PIN 12,7 X 38 PST3		01 01
17	0503010362	1/8" X 1.1/4" COTTERPIN		01 01
18	0551018814	SLEEVE 31,75 X 17 X 40		01 01
19	0551017811	5/8" UNC X 3.1/2" BOLT		01 01
20	0503010027	SPRING WASHER		01 01
21	0503010002	1800 GREASE FITTING		01 01



Item	Code	Description	See page	QT
00	0501054292	V RIGHT WHEEL PRESS FERTILIZER ASSY		01
00A	0501054293	V LEFT WHEEL PRESS FERTILIZER ASSY		01
01	0521062253	RIGHT PRESS WHEEL FERT UP SUPPORT		01
01.	0521062254	LEFT PRESS WHEEL FERT UPPER SUPPORT		01
02	0511064128	PRESS SUPPORT LOWWER WHEEL		01
03	0503010752	1/2" X 3.1/2" BOLT		01
04	0531013272	0.5" X 1" X 2.2" SLEEVE		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0501013491	5/8" TENSIONER SPRING		01
08	0503010013	5/8" NUT		02
09	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
10	0503010002	1800 GREASE FITTING		01
11	0503010849	3/8" X 1-1/2" BOLT		02
12	0503010025	3/8 SPRING WASHER		02
13	0503010026	3/8" NUT		02
14	0502011757	PRESS REGULATOR		01
15	0511054333	COMPACT WHEEL RIGHT WITH BEARING		01
16	0511054334	COMPACT WHEEL LEFT WITH BEARING		01
17	0503010795	5/8" X 7" BOLT		01
18	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		01

This image shows a single page from a notebook or ledger. The page is white with rounded corners and features horizontal ruling lines spaced evenly down its length. There are no margins, text, or other markings on the page.





MARCHESAN IMPLEMENTOS E MÁQUINAS AGRÍCOLAS TATU S.A.

AV. Marchesan, 1979 - Post office box, 131 - CEP 15994-900 - Matão - SP - Brazil

Phone +55 16.3382-8282

(FAX Parts) + 55 16.3382. 8297 - (Export) + 55 16.3382.1003

e.mail: tatu@marchesan.com.br www.marchesan.com.br

Technical Publications: Elaboration
JOSÉ DOMINGOS GASPARI

Contact Catálogo:
E-mail = jgaspari@marchesan.com.br

**ORIGINAL PARTS
TATU**

