


PARTS CATALOG

ROW CROP PLANTERS

PST DUO SUPREMA

Code: 0501091017



Series: S-0114

Rev.: 00

Date Rev.: AGOSTO/2014

**ORIGINAL PARTS
TATU**



PRODUCTS

Code	Description
0111320001	PST DUO SUP 11/11 MH MTH S-0114
0111320002	PST DUO SUP 13/13 MH MTH S-0114

ATTENTION: **IMPORTANT**


MARCHESAN S/A RESERVES THE RIGHT AT ANY TIME TO MAKE IMPROVEMENTS IN THE DESIGN, MATERIAL OR SPECIFICATIONS OF MACHINERY, EQUIPMENT OR PARTS WITHOUT THEREBY BECOMING LIABLE TO MAKE SIMILAR CHANGES IN MACHINERY, EQUIPMENT OR PARTS PREVIOUSLY SOLD.

INDEX

0909091655	ROW 11 E 13 FRAME	1
0511054340	CHASSIS WITH ARTICULATION	2
0511054339	LEFT CHASSIS WITH ER	3
0511054338	CHASSIS IZQUIERDA CON ER	4
0511054407	CHASSIS WITH ARTICULATION	5
0511054409	LEFT CHASSIS WITH ER	6
0511054408	CHASSI RIGHT WITH ER	7
0511056529	CYLINDER SET	8
0521043934	CARRYING WHEELS SPRING TRACTION	9
0501058240	WHELL FASTENER	10
0501059909	CARRYING WHEELS SUPPORT	11
0501059910	CARRYING WHEELS SUPPORT	12
0501058243	INTERM CHAIN TENSIONER	13
0501058244	FIXED CHAIN TENSIONER	14
0501058242	MOVIL CHAIN TENSIONER	15
0501058241	TENSIONER CHAIN SUPPORT	16
0503062159	WHEEL	17
0511052769	PRY TIRE WHEEL TREANSMISSION	18
0909094291	LEFT TRANSMISSION ASSY	19
0909094292	LEFT TRANSMISSION ASSY	20
0909094290	LEFT TRANSMISSION ASSY	21
0511051434	TRANSMISSION DRIVING ASSY	22
0511047069	SIDE TRANSMISSION DRIVING	23
0511047070	LH SIDE TRANSMISSION DRIVING	24
0511056533	SET FERTILIZER SILO	25
0511056792	SET FERTILIZER SILO	26
0511056350	RH BEAM SUPPORT PST DUO/F 11E500	27
0511051741	RH BEAM SUPPORT	28
0511056351	LH BEAM SUPPORT PST DUO/F 11E500	29
0511051742	LH BEAM SUPPORT	30
0511051932	RH BEAM SUPPORT	31
0511051933	LH BEAM SUPPORT	32
0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2 - PHP 7	33
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2 - PHP 7	34
0511056745	LATFORM SET	35
0511056793	PLATFORM SET	36
0521050259	SET HANDRAIL	37
0511058734	HANDRAIL SET PST DUO/F 5950 MTH	38
0511056536	SET LADDER	39
0909094295	HEADER ASSY	40
0511054601	TRACTOR HITCH	41
0511054327	RIGHT TURNBUCKLE	42
0511054328	LEFT TURNBUCKLE	43
0511052311	3 POINT TURNBUCKLE	44
0909094296	SET TURBINE	45
0521041587	TURBINE MOTOR HYDRAULIC ASSY	46
0503031610	AIR DISTRIBUTOR	47
0503031611	AIR DISTRIBUTOR	48
0511056598	SET DOOR HAND BOOK	49
0909091659	SEED AND FERTILIZER ROW ASSY	50
0511053252	LH SHORT FERT. ROW W/DDD ASSY	51
0511053253	RH LONG FERT. ROW W/DDD ASSY	52
0511053250	LH SHORT ARM ROW FERTILIZER	53
0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	54
0501058423	FERTILIZER ROD SPRING ROW	55
0511053251	RH LONG ARM ROW FERTILIZER	56
0511053209	LEFT 15 X 15 UNAL DOUBLE-DISC	57
0511053208	RIGHT 15 X 15 UNAL DOUBLE-DISC	58
0511053172	RIGHT HUB LOWR Y/DISC	59
0511053173	LH HUB LOWR Y/DISC	60
0511053099	RH SHORT SEED ROW	61
0511053101	ARM SEED SHORT LINE	62
0511053857	FAST CLOSING SET	63
0521042715	PNEUMATIC SEED DISTRIBUTOR	64
0511052324	CARDAN TRANSMISSION BEARING	65
0501059631	RIGHT 15" X 15" SEED UNAL DOUB-DISC	66


INDEX

0501054167	DOUBLE DISC HUB WITH 15" COULTER		67
0501054168	LEFT UNAL DOBLE-DISC BOX ASSY		68
0511053100	LH LONG SEED ROW		69
0511053102	ARM SEED SHORT LINE		70
0501059632	LH 15"X15"SEED UNAL DOUBLE DISC		71
0521040111	DEP CONT WHEELS PRESS WHEELS ASSY		72
0501058576	RIGHT WHEEL ARM		73
0501058577	RIGHT ARM DEPTH CONTROL WHEEL		74
0501052297	DEPTH WHEELS REGULATOR ASSY		75
0501052627	DEPHT WHEELS BOX		76
0501052538	DEPTH CONTROL WHEEL RUBBER BAND		77
0511054333	COMPACT WHEEL RIGHT C/ BEARING		78
0501052908	PRESS WHEELS ASSY		79
0511054334	COMPACT WHEEL LEFT C/ BEARING		80
0511044573	18" COULTER BLADE ASSY FOR LONG ROW		81
0909091662	MARKER HYDRAULIC		82
0511040203	1.5" X 2.5" X 19" X 9" HYDRAULIC CYLINDER		83
0501050633	DISC ASSY FOR ROW MARKER		84
0909091663	MARKER HYDRAULIC CIRCUIT		85
0501054649	SEQUENTIAL VALVE ASSY		86
0511054971	SET PST3 P/ULTRA P		87
0511054682	HEX AXLE ASSEMBLY		88
0909094298	HEX AXLE ASSEMBLY		89
0909094301	SET SYSTEM HYDRAULIC		90




Item	Code	Description	11 13
01	0511054340	CHASSIS WITH ARTICULATION	01 00
02	0511054407	CHASSIS WITH ARTICULATION	00 01
03	0511050681	TRACTION SPRING	06 06
03A	0503031681	2.1" X 7.78" EXTENSION SPRING	06 06
03B	0561016062	SPRING HITCH	12 12
04	0503013030	5/8" X 3.1/4" BOLT	12 12
05	0511056529	CYLINDER SET	02 02
06	0503010002	1800 GREASE FITTING	02 02
07	0503010003	1845 GREASE FITTING	05 05
08	0521043934	CARRYING WHEELS SPRING TRACTION	04 04
09	0511048532	CARRYING WHEELS SPRING ASSY	00 02
10	0909094291	LEFT TRANSMISSION ASSY	01 00
11	0909094292	LEFT TRANSMISSION ASSY	01 00
12	0909094290	LEFT TRANSMISSION ASSY	00 01
13	0909094293	RIGHT TRANSMISSION ASSY	00 01
14	0511056533	SET FERTILIZER SILO	01 00
15	0511056792	SET FERTILIZER SILO	00 01
16	0511056745	LATFORM SET	01 00
17	0511056793	PLATFORM SET	00 01
18	0521050259	SET HANDRAIL	01 00
19	0511058734	HANDRAIL SET PST DUO/F 5950 MTH	00 00
20	0511056536	SET LADDER	02 02
21	0909094295	HEADER ASSY	01 01
22	0909094296	SET TURBINE	01 01
23	0511056598	SET DOOR HAND BOOK	01 01
24	0909091659	SEED AND FERTILIZER ROW ASSY	11 13
25	0909091662	MARKER HYDRAULIC	01 01
26	0511054971	SET PST3 P/ULTRA P	04 04
27	0501065677	STRUT	02 02
28	0541015451	2.3/8" X 2.3/4" WRENCH	01 01
29	0521013022	TRANSPORT LOCK	02 02
30	0501068994	0.3" X 3.1" LOCK PIN	02 02
31	0503030168	HAIR PIN	02 02


Item	Code	Description	11 13
32	0501047895	ROD STOP	02 02
33	0501047885	ROD STOP	02 02
34	0501047886	ROD STOP	02 02
35	0501047887	ROD STOP	02 02
36	0511054682	HEX AXLE ASSEMBLY	01 00
37	0909094298	HEX AXLE ASSEMBLY	00 01
38	0909094301	SET SYSTEM HYDRAULIC	01 01




Item	Code	Description	QT
001	0511054339	LEFT CHASSIS WITH ER	01
002	0501110683	ARTICULACION HUB WITH SLEEVES	02
003	0501010100	5/8 UNC X 2 C S G.5 BOLT	08
004	0511054338	CHASIS IZQUIERDA CON ER	01
005	0571010094	SLEEVE FLANGE	03
006	0521063921	ARTICULATION	01
007	0502012698	CLAMP	02
008	0503010363	5/16" X 1" BOLT	02
009	0503011444	SPRING WASHER	02
010	0571013510	LOCK AXLE	01
011	0503031035	HAIR PIN	01
012	0571010095	FLAT WASHER	01
013	0503011442	3/4" SPRING WASHER	01
014	0501010098	HEX BOLT 3/4 UNC X 2 C S G.5 ZN	01
015	0521063003	LOCK PIN	01
016	0571010969	LOCK SLEEVE FRAME	01
017	0503013627	1.1/2 SPRING WASHER	01
018	0503011445	SPRING WASHER	08
019	0501010110	1.1/2" NUT	01




Item	Code	Description	QT
001	0521064422	LEFT FRAME	01
002	0521063929	CARRYING-WHEELS PIVOT SHAFT	01
003	0521013199	LOWER BEARING SEMI	03
004	0503010899	5/8" X 2-1/4" BOLT	06
005	0531013922	0.6" X 0.8" X 1" SLEEVE	06
006	0503010013	5/8" NUT	06
007	0503011445	SPRING WASHER	06
008	0501012140	FLAT WASHER	12




Item	Code	Description	QT
001	0521064421	RIGHT FRAME	01
002	0521063930	PIVOT SHAFT	01
003	0521013199	LOWER BEARING SEMI	03
004	0503010899	5/8" X 2-1/4" BOLT	06
005	0531013922	0.6" X 0.8" X 1" SLEEVE	06
006	0503010013	5/8" NUT	06
007	0503011445	SPRING WASHER	06
008	0501012140	FLAT WASHER	12




Item	Code	Description	QT
001	0511054409	LEFT CHASSIS WITH ER	01
002	0501110683	ARTICULACION HUB WITH SLEEVES	02
003	0501010100	5/8 UNC X 2 C S G.5 BOLT	08
004	0511054408	CHASSI RIGHT WITH ER	01
005	0571010094	SLEEVE FLANGE	03
006	0521063921	ARTICULATION	01
007	0502012698	CLAMP	02
008	0503010363	5/16" X 1" BOLT	02
009	0503011444	SPRING WASHER	02
010	0571013510	LOCK AXLE	01
011	0503031035	HAIR PIN	01
012	0571010095	FLAT WASHER	01
013	0503011442	3/4" SPRING WASHER	01
014	0501010098	HEX BOLT 3/4 UNC X 2 C S G.5 ZN	01
015	0521063003	LOCK PIN	01
016	0571010969	LOCK SLEEVE FRAME	01
017	0503013627	1.1/2 SPRING WASHER	01
018	0503011445	SPRING WASHER	08
019	0501010110	1.1/2" NUT	01




Item	Code	Description	QT
001	0521064424	LEFT FRAME	01
002	0521063937	PIVOT SHAFT	01
003	0521013199	LOWER BEARING SEMI	03
004	0503010899	5/8" X 2-1/4" BOLT	06
005	0531013922	0.6" X 0.8" X 1" SLEEVE	06
006	0503010013	5/8" NUT	06
007	0503011445	SPRING WASHER	06
008	0503011445	SPRING WASHER	06
009	0501012140	FLAT WASHER	12




Item	Code	Description	QT
001	0521064423	RIGHT FRAME	01
002	0521063938	CARRYING-WHEELS PIVOT SHAFT	01
003	0521013199	LOWER BEARING SEMI	03
004	0503010899	5/8" X 2-1/4" BOLT	06
005	0531013922	0.6" X 0.8" X 1" SLEEVE	06
006	0503010013	5/8" NUT	06
007	0503011445	SPRING WASHER	06
008	0501012140	FLAT WASHER	12




Item	Code	Description	QT
001	0511058406	HYDRAULIC CYLINDER	02
002	0521012538	1.2" X 3.5" COUPLING SHAFT	02
003	0521012536	COUPLING SHAFT	02
004	0503010523	1/4" X 2" COTTERPIN	04
005	0531012565	0.6" X 1.2" X 3.5" SLEEVE	02
006	0503010967	5/8" X 5.1/2" BOLT	02
007	0503010027	SPRING WASHER	02
008	0503010013	5/8" NUT	02




Item	Code	Description	QT
001	0501058240	WHELL FASTENER	01
002	0503011119	7/8" X 6" BOLT	04
003	0501014251	FLAT WASHER	04
004	0503011254	7/8" HEX SELF ADJUSTING NUT	04
005	0501059909	CARRYING WHEELS SUPPORT	01
006	0503014887	2050 CHAIN X 80 LINK + REDUCTION	01
007	0502010584	CARRYING-WHEELS SUPPORT FIXER	01




Item	Code	Description	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER	01
02	0501013491	5/8" TENSIONER SPRING	01
03	0503010013	5/8" NUT	02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING	01
05	0511069417	REAR TENSIONER	01
06	0501058243	INTERM CHAIN TENSIONER	01
07	0501058244	FIXED CHAIN TENSIONER	01
08	0501058242	MOVIL CHAIN TENSIONER	01




Item	Code	Description	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT	01
02	0531016887	CARRYING WHEEL AXLE ARM	01
03	0503010523	1/4" X 2" COTTERPIN	01
04	0503010003	1845 GREASE FITTING	01
05	0511050681	TRACTION SPRING	01
05A	0503031681	2.1" X 7.78" EXTENSION SPRING	01
05B	0561016062	SPRING HITCH	02
06	0501010100	5/8 UNC X 2 C S G.5 BOLT	01
07	0503010027	SPRING WASHER	04
08	0503013030	5/8" X 3.1/4" BOLT	01
09	0551017715	FLAT WASHER	02
10	0511052770	WHEEL	01
11	0581011124	WHEELED COVER	01
12	0521012190	AXLE LOCK	01
13	0503011167	M16 X 2 X 30 BOLT	02
14	0501058241	TENSIONER CHAIN SUPPORT	01
15	0521061565	WHEEL SUPPORT ARM	01




Item	Code	Description	QT
001	0521061565	WHEEL SUPPORT ARM	01
002	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT	01
003	0531016887	CARRYING WHEEL AXLE ARM	01
004	0503010523	1/4" X 2" COTTERPIN	01
005	0503010003	1845 GREASE FITTING	01
006	0511052770	WHEEL	01
007	0521012190	AXLE LOCK	02
008	0503010027	SPRING WASHER	02
009	0503011167	M16 X 2 X 30 BOLT	02




Item	Code	Description	QT
01	0551018245	CHAIN TENSIONER AXLE	01
02	0501058239	CHAIN TENSIONER BEARING	01
02A	0503012882	BALL BEARING	01
02B	0503011945	503050 CLAMPING RING (FOR AXLE)	01
02C	0502012853	07Z GEAR	01
03	0551018241	SLEEVE 16,30 X 30 X 8	01
04	0503010019	1/2" SPRING WASHER	01
05	0503010060	1/2" NUT	01
06	0551018239	SLEEVE 19 X 13,50 X 45	01




Item	Code	Description	QT
01	0551018252	CHAIN TIGHTENER AXLE	01
02	0501058239	CHAIN TENSIONER BEARING	01
02A	0503012882	BALL BEARING	01
02B	0503011945	503050 CLAMPING RING (FOR AXLE)	01
02C	0502012853	07Z GEAR	01
03	0551018241	SLEEVE 16,30 X 30 X 8	01
04	0503010019	1/2" SPRING WASHER	01
05	0503010060	1/2" NUT	01




Item	Code	Description	QT
01	0551018244	CHAIN UPPER AXLE	01
02	0501058239	CHAIN TENSIONER BEARING	01
02A	0503012882	BALL BEARING	01
02B	0503011945	503050 CLAMPING RING (FOR AXLE)	01
02C	0502012853	07Z GEAR	01
03	0551018240	SLEEVE	01
04	0503010019	1/2" SPRING WASHER	01
05	0503010060	1/2" NUT	01




Item	Code	Description	QT
001	0541016454	PULLEY	01
002	0521018933	113 FERT CHAIN TENSIONER AXLE	01
003	0511015098	FLAT WASHER	01
004	0503010302	501019 SEAL RING	01
005	0503010019	1/2" SPRING WASHER	01
006	0503010060	1/2" NUT	01



Item	Code	Description	QT
001	0503012113	PLY TIRE	01
002	0503016517	WHEEL EI	01
003	0503012114	7.00 X 16 INNER TIRE	01




Item	Code	Description	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS	01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION	01
01B	0501010186	PARAFUSO ROD 5/8UNF X 2.1/8CR	06
01C	0503016516	5/8 UNF CONIC NUT	06
02	0503012550	5/16" X 3/4" BOLT	06
03	0502011339	15Z GEAR P 1.25"	01
04	0503010328	25590/25523 ROLLER BEARING	02
05	0503010804	00547-B SEAL	02
06	0521012185	TRANSM AXLE CARRYING-WHEEL	01
07	0511015949	LOCK NUT	01
08	0503010329	LOCK WASHER	01
09	0503010330	KM 9 LOCKNUT	01
10	0503010002	1800 GREASE FITTING	01




Item	Code	Description	QT
001	0501110639	AGRIC BEARING	04
002	0503011099	GREASE FITTING	04
003	0503010300	5/32" X 1" COTTERPIN	04
004	0551019114	MOTOR BEARING AXLE SUPPORT	02
005	0521014021	1/2" X 4.5" X 5.4" FASTENER	02
006	0511017302	FLAT WASHER	04
007	0503010019	1/2" SPRING WASHER	04
008	0503010060	1/2" NUT	04
009	0571011442	MOTOR SHAFT	01
010	0501018466	FLAT WASHER	02
011	0511015961	LOCK BUSHING	02
012	0503030679	1/2" X 1-1/4" BOLT	02
013	0503010060	1/2" NUT	02
014	0501052560	AXLE MOTOR SLOW-MOVING ASSY	01
014A	0503031825	AXLE MOTOR SLOW-MOVING	02
014B	0503010240	5/16" X 3/4" BOLT	02
014C	0503010179	SPRING WASHER	02
014D	0503010337	5/16" NUT	02
015	0511051434	TRANSMISSION DRIVING ASSY	02
016	0511047069	SIDE TRANSMISSION DRIVING	01
017	0521043456	RIGHT GEAR BOX ASSY	01
018	0501010243	1/2" X 1-1/2" BOLT	03
019	0503010920	1/2" X 1.1/2" BOLT	02
020	0511017302	FLAT WASHER	04
021	0503010019	1/2" SPRING WASHER	05
022	0503012682	1/2" BSW NUT	03
023	0503010060	1/2" NUT	02
024	0521064449	36Z P1/2 SH 3/4 GEAR	01
025	0503030275	AGRICULTURAL BEARING	01
026	0501010637	FLAT WASHER	02
027	0501010984	FLAT WASHER	01
028	0503010025	3/8 SPRING WASHER	01
029	0503010256	3/8" X 3/4" BOLT	01

Item	Code	Description	QT
030	0511054363	CHAIN TENSIONER	01
030A	0531019398	AXLE TENSIONER CHAIN GEAR BOX	01
030B	0503031805	11Z 1/2" GEAR	01
030C	0511017302	FLAT WASHER	02
030D	0503010019	1/2" SPRING WASHER	01
030E	0503010060	1/2" NUT	01
031	0501058265	LOWER CHAIN TENSIONER ASSY	01
031A	0511062169	21Z P 1/2" GEAR	01
031B	0503011410	ROLLER BEARING	01
031C	0503011105	SEAL RING	01
031D	0531017086	50 AXLETIGHTENER	01
031E	0503010406	501025 CLAMPING RING (FOR AXLE)	01
031F	0503010762	5/8" X 3-12" BOLT	01
031G	0501012140	FLAT WASHER	01
031H	0503010027	SPRING WASHER	01
031I	0503010013	5/8" NUT	01
032	0501058254	UPPER SEED CHAIN TENSIONER	01
032A	0503031805	11Z 1/2" GEAR	01
032B	0503010302	501019 SEAL RING	01
032C	0511017302	FLAT WASHER	01
032D	0503010019	1/2" SPRING WASHER	01
032E	0503010060	1/2" NUT	01
032F	0521018933	113 FERT CHAIN TENSIONER AXLE	01
033	0501058266	BEARING WITH 21Z GEAR INNER	01
033A	0511062169	21Z P 1/2" GEAR	01
033B	0503011410	ROLLER BEARING	01
033C	0503011105	SEAL RING	01
033D	0531017086	50 AXLETIGHTENER	01
033E	0503010406	501025 CLAMPING RING (FOR AXLE)	01
033F	0501011234	5/8" X 3" BOLT	01
033G	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	01
034	0501058267	DOUBLE BEARING WITH 17Z GEAR	01
034A	0511069680	20Z X 28Z DOBLE GEAR	01
034B	0503011410	ROLLER BEARING	02
034C	0551019175	DOUBLE GEAR AXLE	01
034D	0503010406	501025 CLAMPING RING (FOR AXLE)	01
034E	0503016460	5/8" X 4.1/2" BOLT	01
034F	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	01
035	0503012522	40-1 CHAIN X 85 LINK + MENDING	01
036	0503012707	40-1 CHAIN X 96 LINK + REDUCTION	01
037	0503012719	40-1 CHAIN X 113 LINK + MENDING	01
038	0503014907	40-1 X 151 CHAIN LINK + MENDING	01




Item	Code	Description	QT
001	0501110639	AGRIC BEARING	04
002	0503011099	GREASE FITTING	04
003	0503010300	5/32" X 1" COTTERPIN	04
004	0551019114	MOTOR BEARING AXLE SUPPORT	02
005	0521014021	1/2" X 4.5" X 5.4" FASTENER	02
006	0511017302	FLAT WASHER	04
007	0503010019	1/2" SPRING WASHER	04
008	0503010060	1/2" NUT	04
009	0571011442	MOTOR SHAFT	01
010	0501018466	FLAT WASHER	02
011	0511015961	LOCK BUSHING	02
012	0503030679	1/2" X 1-1/4" BOLT	02
013	0503010060	1/2" NUT	02
014	0501052560	AXLE MOTOR SLOW-MOVING ASSY	01
014A	0503031825	AXLE MOTOR SLOW-MOVING	02
014B	0503010240	5/16" X 3/4" BOLT	02
014C	0503010179	SPRING WASHER	02
014D	0503010337	5/16" NUT	02
015	0511051434	TRANSMISSION DRIVING ASSY	02
016	0511047070	LH SIDE TRANSMISSION DRIVING	01
017	0521043457	LEFT GEAR BOX ASSY	01
018	0501010243	1/2" X 1-1/2" BOLT	03
019	0503010920	1/2" X 1.1/2" BOLT	02
020	0511017302	FLAT WASHER	04
021	0503010019	1/2" SPRING WASHER	05
022	0503012682	1/2" BSW NUT	03
023	0503010060	1/2" NUT	02
024	0521064449	36Z P1/2 SH 3/4 GEAR	01
025	0503030275	AGRICULTURAL BEARING	01
026	0501010637	FLAT WASHER	02
027	0501010984	FLAT WASHER	01
028	0503010025	3/8 SPRING WASHER	01
029	0503010256	3/8" X 3/4" BOLT	01

Item	Code	Description	QT
030	0511054363	CHAIN TENSIONER	01
030A	0531019398	AXLE TENSIONER CHAIN GEAR BOX	01
030B	0503031805	11Z 1/2" GEAR	01
030C	0511017302	FLAT WASHER	02
030D	0503010019	1/2" SPRING WASHER	01
030E	0503010060	1/2" NUT	01
031	0501058265	LOWER CHAIN TENSIONER ASSY	01
031A	0511062169	21Z P 1/2" GEAR	01
031B	0503011410	ROLLER BEARING	01
031C	0503011105	SEAL RING	01
031D	0531017086	50 AXLETIGHTENER	01
031E	0503010406	501025 CLAMPING RING (FOR AXLE)	01
031F	0503010762	5/8" X 3-12" BOLT	01
031G	0501012140	FLAT WASHER	01
031H	0503010027	SPRING WASHER	01
031I	0503010013	5/8" NUT	01
032	0501058254	UPPER SEED CHAIN TENSIONER	01
032A	0503031805	11Z 1/2" GEAR	01
032B	0503010302	501019 SEAL RING	01
032C	0511017302	FLAT WASHER	01
032D	0503010019	1/2" SPRING WASHER	01
032E	0503010060	1/2" NUT	01
032F	0521018933	113 FERT CHAIN TENSIONER AXLE	01
033	0501058266	BEARING WITH 21Z GEAR INNER	01
033A	0511062169	21Z P 1/2" GEAR	01
033B	0503011410	ROLLER BEARING	01
033C	0503011105	SEAL RING	01
033D	0531017086	50 AXLETIGHTENER	01
033E	0503010406	501025 CLAMPING RING (FOR AXLE)	01
033F	0501011234	5/8" X 3" BOLT	01
033G	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	01
034	0501058267	DOUBLE BEARING WITH 17Z GEAR	01
034A	0511069680	20Z X 28Z DOBLE GEAR	01
034B	0503011410	ROLLER BEARING	02
034C	0551019175	DOUBLE GEAR AXLE	01
034D	0503010406	501025 CLAMPING RING (FOR AXLE)	01
034E	0503016460	5/8" X 4.1/2" BOLT	01
034F	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	01
035	0503012522	40-1 CHAIN X 85 LINK + MENDING	01
036	0503012707	40-1 CHAIN X 96 LINK + REDUCTION	01
037	0503012719	40-1 CHAIN X 113 LINK + MENDING	01
038	0503014907	40-1 X 151 CHAIN LINK + MENDING	01




Item	Code	Description	QT
001	0501110639	AGRIC BEARING	04
002	0503011099	GREASE FITTING	04
003	0503010300	5/32" X 1" COTTERPIN	04
004	0551019114	MOTOR BEARING AXLE SUPPORT	02
005	0521014021	1/2" X 4.5" X 5.4" FASTENER	02
006	0511017302	FLAT WASHER	04
007	0503010019	1/2" SPRING WASHER	04
008	0503010060	1/2" NUT	04
009	0561016876	MOTOR SHAFT	01
010	0501018466	FLAT WASHER	02
011	0511015961	LOCK BUSHING	02
012	0503030679	1/2" X 1-1/4" BOLT	02
013	0503010060	1/2" NUT	02
014	0501052560	AXLE MOTOR SLOW-MOVING ASSY	01
014A	0503031825	AXLE MOTOR SLOW-MOVING	02
014B	0503010240	5/16" X 3/4" BOLT	02
014C	0503010179	SPRING WASHER	02
014D	0503010337	5/16" NUT	02
015	0511051434	TRANSMISSION DRIVING ASSY	02
016	0511047070	LH SIDE TRANSMISSION DRIVING	01
017	0521043457	LEFT GEAR BOX ASSY	01
018	0501010243	1/2" X 1-1/2" BOLT	03
019	0503010920	1/2" X 1.1/2" BOLT	02
020	0511017302	FLAT WASHER	04
021	0503010019	1/2" SPRING WASHER	05
022	0503012682	1/2" BSW NUT	03
023	0503010060	1/2" NUT	02
024	0521064449	36Z P1/2 SH 3/4 GEAR	01
025	0503030275	AGRICULTURAL BEARING	01
026	0501010637	FLAT WASHER	02
027	0501010984	FLAT WASHER	01
028	0503010025	3/8 SPRING WASHER	01
029	0503010256	3/8" X 3/4" BOLT	01


Item	Code	Description	QT
030	0511054363	CHAIN TENSIONER	01
030A	0531019398	AXLE TENSIONER CHAIN GEAR BOX	01
030B	0503031805	11Z 1/2" GEAR	01
030C	0511017302	FLAT WASHER	02
030D	0503010019	1/2" SPRING WASHER	01
030E	0503010060	1/2" NUT	01
031	0501058265	LOWER CHAIN TENSIONER ASSY	01
031A	0511062169	21Z P 1/2" GEAR	01
031B	0503011410	ROLLER BEARING	01
031C	0503011105	SEAL RING	01
031D	0531017086	50 AXLETIGHTENER	01
031E	0503010406	501025 CLAMPING RING (FOR AXLE)	01
031F	0503010762	5/8" X 3-12" BOLT	01
031G	0501012140	FLAT WASHER	01
031H	0503010027	SPRING WASHER	01
031I	0503010013	5/8" NUT	01
032	0501058254	UPPER SEED CHAIN TENSIONER	01
032A	0503031805	11Z 1/2" GEAR	01
032B	0503010302	501019 SEAL RING	01
032C	0511017302	FLAT WASHER	01
032D	0503010019	1/2" SPRING WASHER	01
032E	0503010060	1/2" NUT	01
032F	0521018933	113 FERT CHAIN TENSIONER AXLE	01
033	0501058266	BEARING WITH 21Z GEAR INNER	01
033A	0511062169	21Z P 1/2" GEAR	01
033B	0503011410	ROLLER BEARING	01
033C	0503011105	SEAL RING	01
033D	0531017086	50 AXLETIGHTENER	01
033E	0503010406	501025 CLAMPING RING (FOR AXLE)	01
033F	0501011234	5/8" X 3" BOLT	01
033G	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	01
034	0501058267	DOUBLE BEARING WITH 17Z GEAR	01
034A	0511069680	20Z X 28Z DOBLE GEAR	01
034B	0503011410	ROLLER BEARING	02
034C	0551019175	DOUBLE GEAR AXLE	01
034D	0503010406	501025 CLAMPING RING (FOR AXLE)	01
034E	0503016460	5/8" X 4.1/2" BOLT	01
034F	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	01
035	0503012522	40-1 CHAIN X 85 LINK + MENDING	01
036	0503012707	40-1 CHAIN X 96 LINK + REDUCTION	01
037	0503012719	40-1 CHAIN X 113 LINK + MENDING	01
038	0503014907	40-1 X 151 CHAIN LINK + MENDING	01




Item	Code	Description	QT
01	0502012696	RIGHT RATCHET HANDLE BODY	01
02	0571010151	GRAGGER RATCHET BODY	01
03	0561019923	RATCHET PULLER GEAR	01
04	0551019100	LOCK RATCHET	02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING	02
06	0503010365	NUT	04
07	0503013816	5/16" LOCKNUT	04
08	0571010164	SEAT SIDE OF RATCHET	01
09	0503010004	1890 GREASE FITTING	01
10	0503030678	1/2"X1-1/2"BOLT	01
11	0503010060	1/2" NUT	01
12	0571010763	FLANGE WASHER	02



Item	Code	Description	QT
01	0502011996	SLLEVE FIXER	01
02	0503030678	1/2"X1-1/2"BOLT	01
03	0503010060	1/2" NUT	01
04	0521017590	GUIDE AXLE	01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING	01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER	01
07	0501019734	FLAT WASHER	02
08	0502010710	RIGHT CAM, SMALLER	02
09	0503010003	1845 GREASE FITTING	02
10	0502012539	26Z P12,7 GEAR	01
11	0501019735	FLAT WASHER	01
12	0521017593	FLAT WASHER	01
13	0503010542	501045 CLAMPING RING (FOR AXLE)	01




Item	Code	Description	QT
01	0502011996	SLLEVE FIXER	01
02	0503030678	1/2"X1-1/2"BOLT	01
03	0503010060	1/2" NUT	01
04	0521017590	GUIDE AXLE	01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING	01
06	0502011995	LH DRIVING AXLE FOLLOWER	01
07	0501019734	FLAT WASHER	02
08	0502010720	RIGHT CAM, SMALLER	02
09	0503010003	1845 GREASE FITTING	02
10	0502012540	26Z P12,7 GEAR	01
11	0501019735	FLAT WASHER	01
12	0521017593	FLAT WASHER	01
13	0503010542	501045 CLAMPING RING (FOR AXLE)	01




Item	Code	Description	QT
001	0511056350	RH BEAM SUPPORT PST DUO/F 11E500	01
001.	0511051741	RH BEAM SUPPORT	01
002	0511056351	LH BEAM SUPPORT PST DUO/F 11E500	01
002.	0511051742	LH BEAM SUPPORT	01
003	0503010849	3/8" X 1-1/2" BOLT	12
004	0501010984	FLAT WASHER	24
005	0503010025	3/8 SPRING WASHER	12
006	0503010026	3/8" NUT	12
007	0503034396	FERTILIZER SIDE COVER	12
008	0503010362	1/8" X 1.1/4" COTTERPIN	12
009	0503060642	COVER BOX RIGHT FERTILIZER	02
009.	0503060643	COVER BOX LEFT FERTILIZER	02
010	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE	04
011	0503010849	3/8" X 1-1/2" BOLT	08
012	0501010984	FLAT WASHER	16
013	0503010025	3/8 SPRING WASHER	08
014	0503010026	3/8" NUT	08
015	0551019156	GEAR BOX LEVER LOCK	02
016	0503011953	5/16" X 1" BOLT	04
017	0501010694	FLAT WASHER	04
018	0503010179	SPRING WASHER	04
019	0503010337	5/16" NUT	04
020	0503010847	1/2" X 3.1/4" BOLT	02
021	0551019168	SLEEVE	02
022	0551019160	LEVER	02
023	0511017302	FLAT WASHER	02
024	0503010019	1/2" SPRING WASHER	02
025	0503010060	1/2" NUT	02
026	0551019167	SLEEVE UNION	02
027	0511069676	INNER LEVER	02
028	0511017302	FLAT WASHER	02
029	0503011172	1/2" X 2-1/2" BOLT	02
030	0511017302	FLAT WASHER	02


Item	Code	Description	QT
031	0503010019	1/2" SPRING WASHER	02
032	0503010060	1/2" NUT	02
033	0501013518	FLAT WASHER	02
034	0503010140	1/8" X 3/4" COTTERPIN	02
035	0511069678	LH LOWER LEVER	02
036	0503013357	3/8" SELF-ADJUSTING NUT	02
037	0503010140	1/8" X 3/4" COTTERPIN	04
038	0551019159	LEVER FIXER BODY	02
039	0561016468	FASTENER	02
040	0503011336	1/2" HEX SELF ADJUSTING NUT	04
041	0551019115	LOCK	02
042	0501010096	3/8" X 2" BOLT	02
043	0501010984	FLAT WASHER	02




Item	Code	Description	QT
001	0511051932	RH BEAM SUPPORT	01
002	0511051933	LH BEAM SUPPORT	01
003	0503010849	3/8" X 1-1/2" BOLT	28
004	0501010984	FLAT WASHER	60
005	0503010025	3/8 SPRING WASHER	28
006	0503010026	3/8" NUT	28
007	0503062018	FERTILIZER SILO SUPORT ASSY	02
008	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS	02
009	0503010362	1/8" X 1.1/4" COTTERPIN	14
010	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE	08
011	0551019156	GEAR BOX LEVER LOCK	02
012	0503011953	5/16" X 1" BOLT	04
013	0501010694	FLAT WASHER	04
014	0503010847	1/2" X 3.1/4" BOLT	02
015	0551019168	SLEEVE	02
016	0551019160	LEVER	02
017	0511017302	FLAT WASHER	06
018	0503010060	1/2" NUT	04
019	0551019167	SLEEVE UNION	02
020	0511069676	INNER LEVER	02
021	0503011172	1/2" X 2-1/2" BOLT	02
022	0501013518	FLAT WASHER	02
023	0503010179	SPRING WASHER	04
024	0503010337	5/16" NUT	04
025	0503010019	1/2" SPRING WASHER	04
026	0503013357	3/8" SELF-ADJUSTING NUT	02
027	0501010096	3/8" X 2" BOLT	02
028	0551019115	LOCK	02
029	0503011336	1/2" HEX SELF ADJUSTING NUT	04
030	0511069679	RH UPPER LEVER	02
031	0503010140	1/8" X 3/4" COTTERPIN	06
032	0511069678	LH LOWER LEVER	01
033	0511069677	RH LOWER LEVER	01

Item	Code	Description	QT
034	0561016468	FASTENER	02
035	0503034396	FERTILIZER SIDE COVER	14







Item	Code	Description	QT
001	0521063405	RH BEAM SUPPORT	01
002	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2 -	04
003	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2 -	02
004	0501010942	3/8" X 1-1/4" BOLT	24
005	0503011443	SPRING WASHER	24
006	0503010026	3/8" NUT	24
007	0511061759	22Z P12,70 FQ 3/4" GEAR	01
008	0521014167	CONE LOCK	01
009	0503030275	AGRICULTURAL BEARING	06
010	1902010685	18Z CONICAL GEAR	06
011	0571012299	SQUARE SHAFT	01
012	0521010691	AXLE FASTENER	02
013	0503010373	1/4" X 2" BOLT	02
014	0501010694	FLAT WASHER	02
015	0503011441	SPRING WASHER	02
016	0503010144	1/4" NUT	02
017	0501110392	SILO SUPPORT BEARING	01
018	0521012485	GEAR BOX BEARING AGRICUTURAL	01
019	0503011953	5/16" X 1" BOLT	02
020	0501010694	FLAT WASHER	02
021	0521011039	FLAT WASHER	02
022	0503011444	SPRING WASHER	02
023	0503010337	5/16" NUT	02
024	0551018055	22,65 X 60 SLEEVE	01
025	0503010003	1845 GREASE FITTING	01




Item	Code	Description	QT
001	0521065375	LH FERTILIZER BEAM SUPPORT	01
002	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2 -	04
003	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2 -	02
004	0571017426	HEX AXLE	01
005	0501010942	3/8" X 1-1/4" BOLT	24
006	0503011443	SPRING WASHER	24
007	0503010026	3/8" NUT	24
008	0511061759	22Z P12,70 FQ 3/4" GEAR	01
009	0521014167	CONE LOCK	01
010	0503030275	AGRICULTURAL BEARING	06
011	1902010685	18Z CONICAL GEAR	06
012	0521010691	AXLE FASTENER	02
013	0503010373	1/4" X 2" BOLT	02
014	0501010694	FLAT WASHER	04
015	0503011441	SPRING WASHER	02
016	0503010144	1/4" NUT	02
017	0501110392	SILO SUPPORT BEARING	01
018	0521012485	GEAR BOX BEARING AGRICUTURAL	01
019	0503011953	5/16" X 1" BOLT	02
020	0521011039	FLAT WASHER	02
021	0503011444	SPRING WASHER	02
022	0503010337	5/16" NUT	02
023	0551018055	22,65 X 60 SLEEVE	01
024	0503010003	1845 GREASE FITTING	01




Item	Code	Description	QT
001	0521063406	LH BEAM SUPPORT	01
002	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2 -	02
003	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2 -	04
004	0501010942	3/8" X 1-1/4" BOLT	24
005	0503011443	SPRING WASHER	24
006	0503010026	3/8" NUT	24
007	0511061759	22Z P12,70 FQ 3/4" GEAR	01
008	0521014167	CONE LOCK	01
009	0503030275	AGRICULTURAL BEARING	06
010	1902010685	18Z CONICAL GEAR	06
011	0571012299	SQUARE SHAFT	01
012	0521010691	AXLE FASTENER	02
013	0503010373	1/4" X 2" BOLT	02
014	0501010694	FLAT WASHER	02
015	0503011441	SPRING WASHER	02
016	0503010144	1/4" NUT	02
017	0501110392	SILO SUPPORT BEARING	01
018	0521012485	GEAR BOX BEARING AGRICUTURAL	01
019	0503011953	5/16" X 1" BOLT	02
020	0501010694	FLAT WASHER	02
021	0521011039	FLAT WASHER	02
022	0503011444	SPRING WASHER	02
023	0503010337	5/16" NUT	02
024	0551018055	22,65 X 60 SLEEVE	01
025	0503010003	1845 GREASE FITTING	01




Item	Code	Description	QT
01	0521063171	RH FERTILIZER BOX SUPPORT	01
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2 -	04
03	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2 -	03
04	0501010942	3/8" X 1-1/4" BOLT	28
05	0503011443	SPRING WASHER	28
06	0503010026	3/8" NUT	28
07	0511061759	22Z P12,70 FQ 3/4" GEAR	01
08	0571011428	SQUARE SHAFT	01
09	0501053788	Q3/4" FASTENER AXLE ASSY	02
09.	0503010144	1/4" NUT	01
09A	0521010691	AXLE FASTENER	01
09B	0503010373	1/4" X 2" BOLT	01
09C	0511017303	FLAT WASHER	02
09D	0503010143	SPRING WASHER	01
10	0501110392	SILO SUPPORT BEARING	01
11	0521012485	GEAR BOX BEARING AGRICUTURAL	01
12	0503011953	5/16" X 1" BOLT	02
13	0501010694	FLAT WASHER	02
14	0503011444	SPRING WASHER	02
15	0503010337	5/16" NUT	02
16	0551018055	22,65 X 60 SLEEVE	01
17	0503010003	1845 GREASE FITTING	01
18	0521014167	CONE LOCK	01
19	0503030275	AGRICULTURAL BEARING	07
20	0503030303	SUPPORT WASHER	01
21	1902010685	18Z CONICAL GEAR	07




Item	Code	Description	QT
001	0521063172	LH FERTILIZER BOX SUPPORT	01
002	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2 -	03
003	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2 -	04
004	0501010942	3/8" X 1-1/4" BOLT	28
005	0503011443	SPRING WASHER	28
006	0503010026	3/8" NUT	28
007	0511061759	22Z P12,70 FQ 3/4" GEAR	01
008	0571011428	SQUARE SHAFT	01
009	0501053788	Q3/4" FASTENER AXLE ASSY	02
009A	0521010691	AXLE FASTENER	01
009B	0503010373	1/4" X 2" BOLT	01
009C	0511017303	FLAT WASHER	02
009D	0503010143	SPRING WASHER	01
009E	0503010144	1/4" NUT	01
010	0501110392	SILO SUPPORT BEARING	01
011	0521012485	GEAR BOX BEARING AGRICUTURAL	01
012	0503011953	5/16" X 1" BOLT	02
013	0501010694	FLAT WASHER	02
014	0503011444	SPRING WASHER	02
015	0503010337	5/16" NUT	02
016	0551018055	22,65 X 60 SLEEVE	01
017	0503010003	1845 GREASE FITTING	01
018	0521014167	CONE LOCK	01
019	0503030275	AGRICULTURAL BEARING	07
020	0503030303	SUPPORT WASHER	01
021	1902010685	18Z CONICAL GEAR	07




Item	Code	Description	QT
01	0501110682	FERTILZER DISTRIBUTOR	01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR	01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE	01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE	01
03	0521010309	SLEEVE INTER	01
04	0503030275	AGRICULTURAL BEARING	02
05	0503031164	RIGHT HELICAL CONDUTOR	01
06	0501010637	FLAT WASHER	01
07	0503030303	SUPPORT WASHER	01
08	0501013774	GREASE SEAL	01
09	0502011412	18Z CONICAL GEAR	01
10	0503010523	1/4" X 2" COTTERPIN	01
11	0503011962	GREASE FITTING	01
12	0503010003	1845 GREASE FITTING	01
13	0503012826	CREASE FITTING	01




Item	Code	Description	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR	01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR	01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE	01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE	01
03	0521010309	SLEEVE INTER	01
04	0503030275	AGRICULTURAL BEARING	02
05	0503031165	LEFT HELICAL CONDUCTOR	01
06	0501010637	FLAT WASHER	01
07	0503030303	SUPPORT WASHER	01
08	0501013774	GREASE SEAL	01
09	0502011412	18Z CONICAL GEAR	01
10	0503010523	1/4" X 2" COTTERPIN	01
11	0503011962	GREASE FITTING	01
12	0503010003	1845 GREASE FITTING	01
13	0503012826	CREASE FITTING	01




Item	Code	Description	QT
001	0511069661	PLATFORM SUPPORT PIVOT	04
002	0503010849	3/8" X 1-1/2" BOLT	08
003	0501010984	FLAT WASHER	16
004	0503010025	3/8 SPRING WASHER	08
005	0503010026	3/8" NUT	08
006	0521062991	RIGHT PLATFORM	01
007	0521062992	LEFT PLATFORM PST DUO 11/F	01
008	0503011172	1/2" X 2-1/2" BOLT	04
009	0503011336	1/2" HEX SELF ADJUSTING NUT	04
010	0503011333	COVER FIXER	02
011	0503010274	5/32"X 2" COTTERPIN	02
012	0502012740	PLATFORM RIGHT FIXER SUPPORT	01
013	0502012739	PLATFORM LEFT FIXER SUPPORT	01
014	0571017990	PLATFORM ENHANCEMENT PROTECTION	01
015	0501010942	3/8" X 1-1/4" BOLT	02
016	0501010984	FLAT WASHER	02
017	0503010025	3/8 SPRING WASHER	02
018	0503010026	3/8" NUT	02




Item	Code	Description	QT
001	0511069661	PLATFORM SUPPORT PIVOT	04
002	0503010849	3/8" X 1-1/2" BOLT	08
003	0501010984	FLAT WASHER	18
004	0503010025	3/8 SPRING WASHER	10
005	0503010026	3/8" NUT	10
006	0521063178	RIGHT PLATFORM	01
007	0521063179	LEFT PLATFORM PST DUO 13/F	01
008	0503011336	1/2" HEX SELF ADJUSTING NUT	04
009	0503011333	COVER FIXER	02
010	0503010274	5/32"X 2" COTTERPIN	02
011	0571017990	PLATFORM ENHANCEMENT PROTECTION	01
012	0501010942	3/8" X 1-1/4" BOLT	02
013	0503011172	1/2" X 2-1/2" BOLT	04
014	0502012740	PLATFORM RIGHT FIXER SUPPORT	01
015	0502012739	PLATFORM LEFT FIXER SUPPORT	01




Item	Code	Description	QT
001	0521062988	HANDRAIL	02
002	0503014007	1/2" X 1-1/4" BOLT	04
003	0503010740	1/2" X 2" BOLT	02
004	0503010905	1/2" X 2-1/4" BOLT	02
005	0503010019	1/2" SPRING WASHER	08
006	0503010060	1/2" NUT	08
007	0503034094	22 TWISTED CHAIN	02
008	0571017991	FIXADOR CORRENTE CORRIMÃO	04
009	0551019884	45 X 50 X 3/8 FASTENER	04
010	0503013357	3/8" SELF-ADJUSTING NUT	08




Item	Code	Description	QT
001	0521063175	HANDRAIL	02
002	0503014007	1/2" X 1-1/4" BOLT	04
003	0503010740	1/2" X 2" BOLT	02
004	0503010905	1/2" X 2-1/4" BOLT	02
005	0503010019	1/2" SPRING WASHER	08
006	0503010060	1/2" NUT	08
007	0503034094	22 TWISTED CHAIN	02
008	0571017991	FIXADOR CORRENTE CORRIMÃO	04
009	0551019884	45 X 50 X 3/8 FASTENER	04
010	0503013357	3/8" SELF-ADJUSTING NUT	08




Item	Code	Description	QT
001	0502012742	FIXER SUPPORT LADDER	02
002	0503010237	3/8" X 1" BOLT	04
003	0503010025	3/8 SPRING WASHER	04
004	0503010026	3/8" NUT	04
005	0511069636	LADDER	01
006	0503011179	3/8" X 2-1/4" BOLT	02
007	0501010984	FLAT WASHER	02
008	0503013357	3/8" SELF-ADJUSTING NUT	02




Item	Code	Description	QT
01	0521064257	DRAWBAR	01
02	0511054601	TRACTOR HITCH	01
03	0571014769	SLEEVE HITCH ARTICULATION 1.1/2	01
04	0511053179	TRACTOR HITCH AXLE	01
04A	0521064036	TRACTOR HITCH AXLE	01
04B	0503030012	HAIR PIN	01
05	0521063529	LOCK AXLE	01
06	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT	01
07	0503010010	1/4" X 2.1/2" COTTERPIN	01
08	0521063528	EXTENDING FIXER	01
09	0521062916	LEFT FRENCH HAND	01
10	0501010171	PARAFUSO 1 UNC X 3.1/2 C S G.5	02
11	0503010012	1" SPRING WASHER	02
12	0501010059	1.5/8 NUT	02
13	0521010585	0.9" X 5.9" COUPLING SHAFT	01
14	0503030085	LOCK PIN	01
15	0521064203	EAR PIVOT DRAWBAR	01
16	0571010661	PIVOT SHAFT	01
17	0503010010	1/4" X 2.1/2" COTTERPIN	01
18	0511054327	RIGHT TURNBUCKLE	01
19	0511054328	LEFT TURNBUCKLE	01
20	0501010500	3/4"X3"BOLT	02
21	0503010023	SPRING WASHER	02
22	0503010014	3/4" NUT	02
23	0571019949	JUNCTION SHAFT	02
24	0503030119	LOCK PIN	02
25	0521010572	0.9" X 2.9" COUPLING SHAFT	01
26	0503030085	LOCK PIN	03
27	0511052311	3 POINT TURNBUCKLE	01
28	0521012532	0.9" X 3.9" COUPLING SHAFT	01
29	0521010582	COUPLING SHAFT	01




Item	Code	Description	QT
001	0503010002	1800 GREASE FITTING	01
002	0503016482	BOLT	02
003	0502040846	U TRACTOR HITCH	01
004	0571012612	PIVOT SHAFT	01
005	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT	01
006	0503010010	1/4" X 2.1/2" COTTERPIN	01
007	0521010681	BUSHING COUPLING BODY	01
008	0521010639	COUPLING SHAFT	01
009	0503010571	1/4" X 1.1/2 COTTERPIN	01
010	0503033731	COMPRESSION SPRING LEFT	02
011	0503010396	501060 CLAMPING RING (FOR AXLE)	01
012	0503011331	3/8 BALL	02
013	0501110778	TRACTOR HITCH	01




Item	Code	Description	QT
01	0521064425	POINT FIXER EXTENDING RIGHT	01
02	0501078990	TURNBUCKLE AXLE	01
03	0561019879	LOCK ATTACHMENT BAR	01
04	0521063917	POINT REVOLVING EXTENDING	01
05	0503010002	1800 GREASE FITTING	02




Item	Code	Description	QT
01	0521064426	POINT FIXER EXTENDING LEFT	01
02	0501078990	TURNBUCKLE AXLE	01
03	0561019879	LOCK ATTACHMENT BAR	01
04	0521063917	POINT REVOLVING EXTENDING	01
05	0503010002	1800 GREASE FITTING	02



Item	Code	Description	QT
01	0511052311	3 POINT TURNBUCKLE	01
01A	0502011237	ESTABILIZER BODY	01
01B	0571012279	JACK RIGHT	01
01C	0571012280	JACK LEFT	01
01D	0511061880	SIDE RIGHT RATCHET	01
01E	0531010264	SIDE RATCHET	01
01F	0511061881	RATCHET FOLLOWER	01
01G	0521018920	0.4" X 0.5" X 0.2" SLEEVE	03
01H	0503011179	3/8" X 2-1/4" BOLT	05
01I	0503011443	SPRING WASHER	05
01J	0503010026	3/8" NUT	05
01K	0503010002	1800 GREASE FITTING	02
01L	0503030012	HAIR PIN	01




Item	Code	Description	11	13
01	0521041587	TURBINE MOTOR HYDRAULIC ASSY	01	01
02	0503010967	5/8" X 5.1/2" BOLT	02	02
03	0503010027	SPRING WASHER	02	02
04	0503010013	5/8" NUT	02	02
05	0503031610	AIR DISTRIBUTOR	02	00
06	0503031611	AIR DISTRIBUTOR	00	02
07	0531016195	4" X 94" AIR CONDUCTOR	02	02
08	0503011372	102 TO 121 CLAMP	04	04
09	0521019552	5" X 188" AIR CONDUCTOR	01	01
10	0503012724	121 TO 140 CLAMP	01	01
11	0501056495	TURBINE OUTPUT SOCKET	01	01
12	0531015603	HOSE FIXATION SUPPORT	01	01
13	0503013096	5/16" X 4" BOLT	02	02
14	0501010694	FLAT WASHER	04	04
15	0503010179	SPRING WASHER	02	02
16	0503010499	5/16" UNC BUTTERFLY NUT	02	02
17	0521014441	HOSE HOLDER RIGHT SUPPORT	02	02
18	0521014442	HOSE SUPPORT	04	04
19	0521018535	HOSE HOLDER LEFT SUPPORT	02	02
20	0503010371	5/16" X 1" BOLT	08	08
21	0503010179	SPRING WASHER	08	08
22	0503010337	5/16" NUT	08	08
23	0503014007	1/2" X 1-1/4" BOLT	04	04
24	0503010019	1/2" SPRING WASHER	04	04
25	0503010060	1/2" NUT	04	04




Item	Code	Description	QT
01	0511065675	HIDRAULIC TURBINE SUPPORT	01
02	0531018715	CONTROL VALVE SUPPORT TURBINE	01
03	0503010920	1/2" X 1.1/2" BOLT	02
04	0503010019	1/2" SPRING WASHER	03
05	0503010060	1/2" NUT	05
06	0501054577	BLOCK COMMAND	01
06A	0503012291	BLOCK COMMAND	01
06B	0501010590	7/8" REDUCTION NIPPLE	04
06C	0503010045	2-116 N 3006-9B O'RING	04
06D	0541011066	3/4" UNF X 43.5 NIPPLE	01
06E	0503010190	2-114 N 3006-9B O'RING	01
07	0503010206	3/8" X 1/2" BOLT	02
08	0503010025	3/8 SPRING WASHER	08
09	0503010237	3/8" X 1" BOLT	04
10	0503010026	3/8" NUT	04
11	0501054983	NIPPLE HIDRAULIC MOTOR	01
11A	0503012871	HYDRAULIC MOTOR	01
11B	0531018770	R 3/4"UNF X R 1/4"BSP ELBOW	01
11C	0561016941	3/4" NUT	01
11D	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE	02
11E	0541011065	3/4"UNF X R1/4BSP19FPP X43.5 NIPPLE	01
12	0571012636	FRONT COVER	01
13	0521041542	FAN 480 X 44 HIDRAULIC	01
14	0531018764	FLAT WASHER	01
15	0503010143	SPRING WASHER	01
16	0503011104	M6 X 1" BOLT	01
17	0501054272	RIBBON FOR COVER CLOSING ASSY	01
17A	0531017193	RIBBON FOR COVER CLOSING	01
17B	0521018401	SEGMENT COVER	15
18	0503031776	TURBINE RIBBON SEAL	02
19	0571012630	REAR COVER	01
20	0503031649	CONECTOR CENTER	01
21	0503012722	0.16" X 0.4" BLIND RIVET	08


Item	Code	Description	QT
22	0503013031	1/4" X 3.1/4" BOLT	13
23	0503012880	1/4" UNC SELF ADJUSTING NUT	15
24	0503012721	1/4" X 4" BOLT	02
25	0511014024	10 X 13 X 15,5 SLEEVE	02
26	0501056495	TURBINE OUTPUT SOCKET	01
26A	0503031812	TURBINE OUTPUT SOCKET	01
26B	0541017539	BUTTERFLY VALVE	01
26C	0511066760	VALVE FIXATION SUPPORT	01
26D	0503013813	1/4" UNC X 7/8" BOLT	02
26E	0503010143	SPRING WASHER	02
26F	0503010144	1/4" NUT	02
26G	0501013519	FLAT WASHER	01
27	0511017303	FLAT WASHER	06
28	0503013096	5/16" X 4" BOLT	02
29	0501010694	FLAT WASHER	02
30	0503010499	5/16" UNC BUTTERFLY NUT	02
31	0501080927	3/8" X 14" TR-TR HOSE ASSY	01
32	0501080928	1/2" X 14" TR-TR HOSE ASSY	02
33	0501080553	3/8" X 126" TC-TM HOSE ASSY	01
34	0501080044	1/2" X 110" TC-TM HOSE ASSY	02
35	0501053834	QUICK CONECTION (MALE) 1/2	03
35A	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT	03
35B	0503011882	QUICK CONNECTION COVER	03
36	0531012760	TURBINE REAR COVER	01
37	0503013758	1/4" X 1-1/2" BOLT	04
38	0561010635	SWITCH FIXER	04
39	0503013584	VACUUM GAUGE	01
40	0503015062	TUBE	1/2"MT.
41	0503010849	3/8" X 1-1/2" BOLT	02




Item	Code	Description	QT
001	0521018441	OIL DISTRIBUTOR BODY	01
002	0521018442	OIL DISTRIBUTOR BODY	01
003	0503031102	SUPREME AIR DISTRIBUTOR	01
004	0503012566	COVER KAP 110 YELLOW	02
005	3504107571	SILICONE FLEXITE	00
006	3114103062	COLA	00
007	0503031943	SOCKET	06
008	0503012856	REBITE POP	12




Item	Code	Description	QT
001	0521018442	OIL DISTRIBUTOR BODY	01
002	0531012264	OIL DISTRIBUTOR BODY	01
003	0503031102	SUPREME AIR DISTRIBUTOR	01
004	0503012566	COVER KAP 110 YELLOW	02
005	3504107571	SILICONE FLEXITE	00
006	3114103062	COLA	00
007	0503031943	SOCKET	07
008	0503012856	REBITE POP	14




Item	Code	Description	QT
001	0503060100	HAND BOOK COMPARTMENT	01
002	0511031563	BAG WITH MANUAL	01
003	0503010267	NYLON CLAMP	01
004	0503010363	5/16" X 1" BOLT	01
005	0501010694	FLAT WASHER	01
006	0503010179	SPRING WASHER	01
007	0503010337	5/16" NUT	01




Item	Code	Description	11 13
01	0511053252	LH SHORT FERT. ROW W/DDD ASSY	06 07
02	0511053253	RH LONG FERT. ROW W/DDD ASSY	05 06
03	0511053099	RH SHORT SEED ROW	06 07
04	0511053100	LH LONG SEED ROW	05 06
05	0521040111	DEP CONT WHEELS PRESS WHEELS ASSY	11 13
06	0501110231	SCARIFIER SPINDLE	11 13
07	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	00 07
08	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	05 06
09	0511053209	LEFT 15 X 15 UNAL DOUBLE-DISC	06 07
10	0511053208	RIGHT 15 X 15 UNAL DOUBLE-DISC	05 06
11	0501059631	RIGHT 15" X 15" SEED UNAL DOUB-DISC	06 07
12	0501059632	LH 15"X15"SEED UNAL DOUBLE DISC	05 06
13	0503010246	CLAMP	10 12
14	0511017969	0.1" SPACING PLATE	20 30
15	0511061769	FERTILIZER CONDUCTOR RIGHT	11 13
16	0511061770	FERTILIZER CONDUCTOR LEFT	11 13
17	0503031050	CURVED CONDUCTOR	11 13
18	0503032624	FERTILIZER BEAN LIP	07 08
19	0503013162	DISC 2450 CORN	11 13
20	0511069907	HOSE HOLDER	11 13
21	0541010235	2" X 98" HOSE ASSY	11 13
22	0511015627	SEED DISC LEVER	01 01



Item	Code	Description	QT
001	0511053250	LH SHORT ARM ROW FERTILIZER	01
002	0501010066	3/4" X 9" BOLT	01
003	0521017831	SUPPORT SLEEVE SPACER	02
004	0511017232	FLAT WASHER	02
005	0503011255	3/4" LOCK NUT	01
006	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	01
007	0501058423	FERTILIZER ROD SPRING ROW	01
008	0503030391	RIGHT FERTILIZER SOCKET	01
009	0503031145	2" X 2" X 20" HOSE	01
010	0503031076	2" HOSE CLAMP	02




Item	Code	Description	QT
001	0511053251	RH LONG ARM ROW FERTILIZER	01
002	0501010066	3/4" X 9" BOLT	01
003	0521017831	SUPPORT SLEEVE SPACER	02
004	0511017232	FLAT WASHER	02
005	0503011255	3/4" LOCK NUT	01
006	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	01
007	0501058423	FERTILIZER ROD SPRING ROW	01
008	0503030392	LEFT FERTILIZER SOCKET	01
009	0503031145	2" X 2" X 20" HOSE	01
010	0503031076	2" HOSE CLAMP	02



Item	Code	Description	QT
001	0511018662	SPACING PLATE	04
002	0503010547	1/2" X 4" BOLT	02
003	0503011440	SPRING WASHER	02
004	0503010060	1/2" NUT	02
005	0521061121	SHORT FERTILIZER ROW ARM	01
006	0511053209	LEFT 15 X 15 UNAL DOUBLE-DISC	01

18" COULTER BLADE ASSY FOR SHORT ROW

0511044549




Item	Code	Description	QT
01	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01
02	0502012368	BLADE DISC SUPPORT AXLE	01
03	0503010756	0.2" X 2.4" SPRING PIN	01
04	0503010361	SPRING PIN	01
05	0541018684	FLAT WASHER	01
06	0521014137	RIGHT ARM OF THE BLADE DISC	01
07	0521014138	SUPPORT ARM LEFT BALDE DISC	01
08	0501067323	SPRING REGULATOR	01
09	0521010452	SLEEVE	01
10	0503013185	3/4" X 5-1/2" BOLT	01
11	0503011255	3/4" LOCK NUT	01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01
13	0503011411	1/2" X 5-1/2" BOLT	01
14	0503011440	SPRING WASHER	01
15	0503010060	1/2" NUT	01
16	1902020393	SPRING UPPER SUPPORT	01
17	0502020394	SPRING SUPPORT	01
18	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01
19	0503010014	3/4" NUT	02
20	0521015376	DUST CLOAK	02
21	0502011562	DC PST ACT/ULTR BOX	01
22	0503010276	6206 BALL BEARING	02
23	0521013610	BLADE DISC HUB AXLE	01
24	0503030832	FLAT WASHER	02
25	0503012417	SEAL	02
26	0503011800	SEAL RING	02
27	0503010691	1/4" GREASE FITTING	01
28	0603026013	PLAIN COULTER BLADE	01
29	0502020641	BLADE DISC FLANGE	01
30	0503010371	5/16" X 1" BOLT	06
31	0503011444	SPRING WASHER	06
32	0503010337	5/16" NUT	06
33	0511815346	FLAT WASHER	02




18" COULTER BLADE ASSY FOR SHORT ROW

0511044549


Item	Code	Description	QT
34	0503011442	3/4" SPRING WASHER	02
35	0521813510	R3/4UNC NUT	02
36	0503010003	1845 GREASE FITTING	01




Item	Code	Description	QT
001	0511069645	FERTILIZER SPRING ROD	01
002	0502040534	SPRING GUIDE BUSHING LOCK	02
003	0502012184	FERTILIZER SPRING GUIDE	02
004	0503031910	1.7" X 22.8" X 0.3" SPRING	01
005	0502012510	SPRING ROD SUPPORT	01
006	0503030679	1/2" X 1-1/4" BOLT	01
007	0501018535	1/2 X 1 BOLT	02
008	0503030678	1/2"X1-1/2"BOLT	01
009	0503010060	1/2" NUT	02
010	1902010891	SPRING CHOCK SUPPORT VARON	01
011	0503010014	3/4" NUT	01
012	0561014471	COUPLING SHAFT	01
013	0511017302	FLAT WASHER	01
014	0503010257	1/8" X 1" COTTERPIN	01




Item	Code	Description	QT
001	0511018662	SPACING PLATE	04
002	0503010547	1/2" X 4" BOLT	02
003	0503011440	SPRING WASHER	02
004	0503010060	1/2" NUT	02
005	0521061153	LONG FERTILIZER ROW ARM	01
006	0511053208	RIGHT 15 X 15 UNAL DOUBLE-DISC	01




Item	Code	Description	QT
01	0511053172	RIGHT HUB LOWR Y/DISC	01
02	0511053173	LH HUB LOWR Y/DISC	01
03	0511011927	DUST CLOAK	02
04	0503014679	2-134 O'RING	02
05	0571011152	DOUBLE DISC CAP	02
06	0503015081	502052 CLAMPING RING (FOR AXLE)	02
07	0511015098	FLAT WASHER	02
08	0502011161	15\"X15\" LEFT DOUBLE DISC SUPPORT	01
09	0501017542	LH DOUBLE DISC SCRAPER	01
10	0501017541	RH DOUBLE DISC SCRAPER	01
11	0503010751	C3/8\" X 1.1/4\" HEX BOLT G.5	01
12	0501010984	FLAT WASHER	02
13	0503010026	3/8\" NUT	01
14	0503011443	SPRING WASHER	01
15	0502070062	SCRAPER	01
16	0503011402	0.2\" X 0.8\" SPRING PIN	01




Item	Code	Description	QT
01	0511053173	LH HUB LOWR Y/DISC	01
02	0511053172	RIGHT HUB LOWR Y/DISC	01
03	0511011927	DUST CLOAK	02
04	0503014679	2-134 O'RING	02
05	0571011152	DOUBLE DISC CAP	02
06	0503015081	502052 CLAMPING RING (FOR AXLE)	02
07	0511015098	FLAT WASHER	02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT	01
09	0501017542	LH DOUBLE DISC SCRAPER	01
10	0501017541	RH DOUBLE DISC SCRAPER	01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01
12	0501010984	FLAT WASHER	02
13	0503011443	SPRING WASHER	01
14	0503010026	3/8" NUT	01
15	0502070062	SCRAPER	01
16	0503011402	0.2" X 0.8" SPRING PIN	01



Item	Code	Description	QT
001	0503062300	EVA-F8 ESF2CARR BALL BEARING	01
002	0571011151	LEFT DOUBLE DISC HUB	01
003	0603022042	13" X 0.12" PLAIN COULTER BLADE	01
004	0503010546	5/16" X 7/8" BOLT	06
005	0503010337	5/16" NUT	06
006	0502012736	HUB LOWR DDD	01




Item	Code	Description	QT
001	0503062300	EVA-F8 ESF2CARR BALL BEARING	01
002	0571011150	RIGHT DOUB DISC - HUB	01
003	0603022042	13" X 0.12" PLAIN COULTER BLADE	01
004	0503010546	5/16" X 7/8" BOLT	06
005	0503010337	5/16" NUT	06
006	0502012736	HUB LOWR DDD	01




Item	Code	Description	QT
001	0511053101	ARM SEED SHORT LINE	01
002	0511053857	FAST CLOSING SET	01
003	0521042715	PNEUMATIC SEED DISTRIBUTOR	01
004	0503011404	3/8" X 1-3/4" BOLT	04
005	0503010025	3/8 SPRING WASHER	04
006	0503010026	3/8" NUT	04
007	0521062824	SPINDLE GUIDE	01
008	0521010542	COUPLING SHAFT	01
009	0503010257	1/8" X 1" COTTERPIN	01
010	0502040534	SPRING GUIDE BUSHING LOCK	01
011	0531019915	FLAT WASHER	01
012	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING	01
013	0521062825	LOCK VARON GUIDE	01
014	0501018535	1/2 X 1 BOLT	03
015	0571013566	SPRING ROD SUPPORT	01
016	0521014021	1/2" X 4.5" X 5.4" FASTENER	01
017	0503011336	1/2" HEX SELF ADJUSTING NUT	02
018	0503010014	3/4" NUT	01
019	0511050083	SEED BOX	01
019A	0502011760	SEED SILO SUPPORT	01
019B	0521060631	FIXING BASE BOX	01
019C	0501010942	3/8" X 1-1/4" BOLT	04
019D	0503010025	3/8 SPRING WASHER	04
019E	0503010026	3/8" NUT	04
019F	0531018349	SEED FLOW SWITCH PNEUMATIC SYSTEM	01
019G	0501011643	3/8 X 1"BOLT	01
019H	0501010984	FLAT WASHER	01
019I	0503010025	3/8 SPRING WASHER	01
019J	0503010209	3/8" UNC BUTTERFLY NUT	01
019K	0503031508	COVER GREEN BEAM SEED YELLOW	01
019L	0503010358	5/16" X 5/8" BOLT	04
019M	0501010694	FLAT WASHER	04
019N	0503010179	SPRING WASHER	04


Item	Code	Description	QT
019O	0503010337	5/16" NUT	04
020	0511058212	SET LINE SUPPORT FERTILIZER	01
020A	0502011567	FERTILIZER ROW SUPPORT	01
020B	0511016156	5/8" X 1.1/2" BOLT	02
021	0503010762	5/8" X 3-12" BOLT	02
022	0503010740	1/2" X 2" BOLT	01
023	0511017302	FLAT WASHER	01
024	0521010505	13,50 X 19,00 X 21,50 SLEEVE	01
025	0503010019	1/2" SPRING WASHER	01
026	0503010060	1/2" NUT	01
027	0541010235	2" X 98" HOSE ASSY	01
028	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	02
029	0503033124	SOCKET SEED	01
030	0501018652	CORN STABILIZER BAR	03
031	0503013162	DISC 2450 CORN	07



Item	Code	Description	QT
001	0502011561	BEARING SEMI	01
002	0571010152	ROW SEED SUPPORT ARTICULACION	01
003	0503010003	1845 GREASE FITTING	02
004	0502010426	UPPER BEARING SEMI	02
005	0503010479	1/2" X 3" BOLT	04
006	0503011440	SPRING WASHER	04
007	0503010060	1/2" NUT	04
008	0521063935	SHORT SEED ROW ARM	01
009	0503010752	1/2" X 3.1/2" BOLT	02
010	0503011440	SPRING WASHER	02
011	0503010060	1/2" NUT	02
012	0502011400	18Z CONICAL GEAR	01
013	0502011296	1/2 HEX AXLE BEARING SLEEVE	01
014	0501013824	FLAT WASHER	02
015	0502011505	18Z CONICAL GEAR	01
016	0571013524	1/2 X 1365 AXLE HEX	01
017	0501013352	FLAT WASHER	01
018	0521018079	SEEP ROW DRAWBAR COVER	01
019	0503014729	1/4" UNF X 1/2" BOLT	02
020	0503011441	SPRING WASHER	02
021	0511052324	CARDAN TRANSMISSION BEARING	01
022	0501059631	RIGHT 15" X 15" SEED UNAL DOUB-DISC	01




Item	Code	Description	QT
01	0502012744	SPEED LOCK LEVER ASSY	01
02	0502012743	FAST BOLT ASSY	01
03	0571014534	FAST BOLT ADJUSTMENT	01
04	0571014024	FAST BOLT GUIDE AXLE	02
05	0503010257	1/8" X 1" COTTERPIN	02




Item	Code	Description	QT
01	0511050075	PNEUMATIC DISTRIBUTOR SUPPORT	01
01A	0501110649	INNER SUPPORT NEUMATIC SEED DISTR	01
01Aa	0502012599	PNEUMATIC SEED DISTRIBUTOR SUPPORT	01
01Ab	0503011770	SEAL # V-75 A	01
01Ac	0502012649	18Z CONICAL GEAR 34 TEETH	01
01Ad	0503011771	6008 2RS BALL BEARING	01
01B	0502050003	SUPPORT INTERNAL DISC SEED VULCANIZ	01
01C	0503011378	M6 X 1" BOLT	03
01D	0503010143	SPRING WASHER	03
01E	0503012849	2-129 N 3006 9B O'RING	02
01F	0503010217	501040 CLAMPING RING (FOR AXLE)	01
01G	0503033121	PNEUMATIC SWITCH	01
01H	0503011295	M 8 X 1,25 X 25 BOLT	01
01I	0503010427	METRIC M8 X P.0.5" NUT	01
02	0503033800	PNEUMATIC JOINT SEALING	03
03	0511053062	DRIVE SHAFT	01
04	0503011294	M 8 X 1,25 X 20 BOLT	03
05	0503010025	3/8 SPRING WASHER	03
06	0503011370	DISC 6440 MIDDLE SOYBEAN	01
07	0501058950	SEED SYSTEM SIDE	01
07A	0561012486	LATERAL COVER	01
08	0511017186	SEED LEVEL REGULATOR	01
09	0511017303	FLAT WASHER	04
10	0503011776	M6 SELF ADJUSTINGNUT	01
11	0503014141	M6 X 1 X 20 BOLT	01
12	0503011817	UPPER SELECTOR	01
13	0502020559	UPPER SELECTOR ACTUATOR	01
14	0531014481	0.2" X 0.6" AXLE	01
15	0503011821	CRINKLE WASHER	01
16	0503011823	0.1" X 0.6" SPRING PIN	02
17	0511017219	SCALE INDICATOR GUIDE	01
18	0503011378	M6 X 1" BOLT	03
19	0503010143	SPRING WASHER	03


Item	Code	Description	QT
20	0503011810	M6 X 1" BUTTERFLY BOLT	01
21	0503031058	UPPER SELECTOR SCALE	01
22	0503011825	M4 X 8" BOLT	02
23	0503011840	FLAT WASHER	02
24	0501110311	LOWER SELECTOR ASSY	01
25	0503011813	M6 X 1.2" BOLT	01
26	0511016220	LOWER SELECTOR INDICATOR	01
27	0503011815	TOOTHED WASHER	01
28	0503012445	M6 C/ABA 1.20" BUTTERFLY NUT	04
29	0503013179	PNEUMATIC SEED DISTRIBUTOR VISOR	01
30	0561012741	SEED DRAINER COVER	01
31	0503011809	M12 KNOB	01
32	0503011828	FLAT WASHER	01
33	0503011827	504.100 CLAMPING RING (FOR HOLE)	01
34	0503011104	M6 X 1" BOLT	02
35	0503011820	CRINKLE WASHER	02
36	0511017199	PST SUP AXLE	01
37	0511017198	SCALE INDICATOR	01
38	0503015536	M6 X 1" SELF ADJUSTING NUT	01
39	0511015627	SEED DISC LEVER	01




Item	Code	Description	QT
001	0571012290	BEARIN BODY	01
002	0571012289	SLLEVE FIXER AXLE	01
003	0503011410	ROLLER BEARING	01
004	0503011105	SEAL RING	01
005	0503010406	501025 CLAMPING RING (FOR AXLE)	01
006	0503010371	5/16" X 1" BOLT	02
007	0501010694	FLAT WASHER	04
008	0503010337	5/16" NUT	02
009	0503010179	SPRING WASHER	02
010	0571012288	HEX AXLE	01
011	0503015356	SPRING PIN	01




Item	Code	Description	QT
01	0511015098	FLAT WASHER	02
02	0511011927	DUST CLOAK	02
03	0501054167	DOUBLE DISC HUB WITH 15" COULTER	01
04	0501054168	LEFT UNAL DOBLE-DISC BOX ASSY	01
05	0503030757	2.9" X 2" X 0.02" JOINT	02
06	0521019178	COVER DEPTH	02
07	0503014729	1/4" UNF X 1/2" BOLT	06
08	0503011441	SPRING WASHER	06
09	0561010264	RH DOUBLE DISC SCRAPER	01
10	0561010265	LH DOUBLE DISC SCRAPER	01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01
12	0501010984	FLAT WASHER	02
13	0503011443	SPRING WASHER	01
14	0503010026	3/8" NUT	01
15	0511052301	DOBLE DISC SUPPORT W/GUIDE	01
15A	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT	01
15B	0571012491	SOCKET SEED GUIDE	01
15C	0503010838	0.1" X 0.8" SPRING PIN	02



Item	Code	Description	QT
001	0502011930	DOUBLE DISC COULTER BOX	01
002	0503010598	30204 BALL BEARING	02
003	0503011112	SEAL 02376-BRG	01
004	0521019154	RIGHT DOUB DISC HUB	01
005	0503030282	3/4" CASTLE NUT	01
006	0503010257	1/8" X 1" COTTERPIN	01
007	0603022042	13" X 0.12" PLAIN COULTER BLADE	01
008	0503010546	5/16" X 7/8" BOLT	06
009	0503010337	5/16" NUT	06




Item	Code	Description	QT
001	0502011930	DOUBLE DISC COULTER BOX	01
002	0503010598	30204 BALL BEARING	02
003	0503011112	SEAL 02376-BRG	01
004	0521019148	LEFT DOUBLE DISC HUB	01
005	0503030282	3/4" CASTLE NUT	01
006	0503010257	1/8" X 1" COTTERPIN	01
007	0603022042	13" X 0.12" PLAIN COULTER BLADE	01
008	0503010546	5/16" X 7/8" BOLT	06
009	0503010337	5/16" NUT	06




Item	Code	Description	QT
001	0511053102	ARM SEED SHORT LINE	01
002	0511053857	FAST CLOSING SET	01
003	0521042715	PNEUMATIC SEED DISTRIBUTOR	01
004	0503011404	3/8" X 1-3/4" BOLT	04
005	0503010025	3/8 SPRING WASHER	04
006	0503010026	3/8" NUT	04
007	0521062824	SPINDLE GUIDE	01
008	0521010542	COUPLING SHAFT	01
009	0503010257	1/8" X 1" COTTERPIN	01
010	0502040534	SPRING GUIDE BUSHING LOCK	01
011	0531019915	FLAT WASHER	01
012	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING	01
013	0521062825	LOCK VARON GUIDE	01
014	0501018535	1/2 X 1 BOLT	03
015	0571013566	SPRING ROD SUPPORT	01
016	0521014021	1/2" X 4.5" X 5.4" FASTENER	01
017	0503011336	1/2" HEX SELF ADJUSTING NUT	02
018	0503010014	3/4" NUT	01
019	0511050083	SEED BOX	01
019A	0502011760	SEED SILO SUPPORT	01
019B	0521060631	FIXING BASE BOX	01
019C	0501010942	3/8" X 1-1/4" BOLT	04
019D	0503010025	3/8 SPRING WASHER	04
019E	0503010026	3/8" NUT	04
019F	0531018349	SEED FLOW SWITCH PNEUMATIC SYSTEM	01
019G	0501011643	3/8 X 1"BOLT	01
019H	0501010984	FLAT WASHER	01
019I	0503010025	3/8 SPRING WASHER	01
019J	0503010209	3/8" UNC BUTTERFLY NUT	01
019K	0503031508	COVER GREEN BEAM SEED YELLOW	01
019L	0503010358	5/16" X 5/8" BOLT	04
019M	0501010694	FLAT WASHER	04
019N	0503010179	SPRING WASHER	04


Item	Code	Description	QT
019O	0503010337	5/16" NUT	04
020	0511058212	SET LINE SUPPORT FERTILIZER	01
020A	0502011567	FERTILIZER ROW SUPPORT	01
020B	0511016156	5/8" X 1.1/2" BOLT	02
021	0503010762	5/8" X 3-12" BOLT	02
022	0503010740	1/2" X 2" BOLT	01
023	0511017302	FLAT WASHER	01
024	0521010505	13,50 X 19,00 X 21,50 SLEEVE	01
025	0503010019	1/2" SPRING WASHER	01
026	0503010060	1/2" NUT	01
027	0541010235	2" X 98" HOSE ASSY	01
028	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	02
029	0503033124	SOCKET SEED	01
030	0501018652	CORN STABILIZER BAR	03
031	0503013162	DISC 2450 CORN	07




Item	Code	Description	QT
001	0502011561	BEARING SEMI	01
002	0571010152	ROW SEED SUPPORT ARTICULACION	01
003	0503010003	1845 GREASE FITTING	02
004	0502010426	UPPER BEARING SEMI	02
005	0503010479	1/2" X 3" BOLT	04
006	0503011440	SPRING WASHER	04
007	0503010060	1/2" NUT	04
008	0521063934	LONG SEEP ROW ARM	01
009	0503010752	1/2" X 3.1/2" BOLT	02
010	0503011440	SPRING WASHER	02
011	0503010060	1/2" NUT	02
012	0502011400	18Z CONICAL GEAR	01
013	0502011296	1/2 HEX AXLE BEARING SLEEVE	01
014	0501013824	FLAT WASHER	02
015	0502011505	18Z CONICAL GEAR	01
016	0571013523	1/2 X 1565 HEX AXLE	01
017	0501013352	FLAT WASHER	01
018	0521018079	SEEP ROW DRAWBAR COVER	01
019	0503014729	1/4" UNF X 1/2" BOLT	02
020	0503011441	SPRING WASHER	02
021	0511052324	CARDAN TRANSMISSION BEARING	01
022	0501059632	LH 15"X15"SEED UNAL DOUBLE DISC	01




Item	Code	Description	QT
01	0511015098	FLAT WASHER	02
02	0511011927	DUST CLOAK	02
03	0501054167	DOUBLE DISC HUB WITH 15" COULTER	01
04	0501054168	LEFT UNAL DOBLE-DISC BOX ASSY	01
05	0503030757	2.9" X 2" X 0.02" JOINT	02
06	0521019178	COVER DEPTH	02
07	0503014729	1/4" UNF X 1/2" BOLT	06
08	0503011441	SPRING WASHER	06
09	0561010264	RH DOUBLE DISC SCRAPER	01
10	0561010265	LH DOUBLE DISC SCRAPER	01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01
12	0501010984	FLAT WASHER	02
13	0503011443	SPRING WASHER	01
14	0503010026	3/8" NUT	01
15	0511052302	LH SUPPORT DDD W/ GUIDE	01
15A	0561015592	15" X 15" RIGHT DOUBLE DISC SUPPORT	01
15B	0571012491	SOCKET SEED GUIDE	01
15C	0503010838	0.1" X 0.8" SPRING PIN	02




Item	Code	Description	QT
001	0511051447	CONTROL DEPTH ASSY	01
002	0501052538	DEPTH CONTROL WHEEL RUBBER BAND	02
003	0503010358	5/16" X 5/8" BOLT	08
004	0503013816	5/16" LOCKNUT	08
005	0511054333	COMPACT WHEEL RIGHT C/ BEARING	01
006	0511054334	COMPACT WHEEL LEFT C/ BEARING	01
007	0503010179	SPRING WASHER	08
008	0503033942	COVER REGULATORY WHEEL	01




Item	Code	Description	QT
001	0502012553	DEPTH WHEEL RIGHT ARM	01
002	0503015021	6871-GA SEAL RING	02
003	0501052627	DEPHT WHEELS BOX	01
004	0503010740	1/2" X 2" BOLT	01
005	0503011440	SPRING WASHER	01
006	0503010060	1/2" NUT	01
007	0503010002	1800 GREASE FITTING	01




Item	Code	Description	QT
001	0502012552	LH ARM DEPTH CONTROL WHEEL	01
002	0503015021	6871-GA SEAL RING	02
003	0501052627	DEPHT WHEELS BOX	01
004	0503010740	1/2" X 2" BOLT	01
005	0503011440	SPRING WASHER	01
006	0503010060	1/2" NUT	01
007	0503010002	1800 GREASE FITTING	01




Item	Code	Description	QT
01	0502011689	1/8" DEPTH CONTROL LEVER	01
02	0503030975	0.9" X 1.5" X 0.1" SPRING	01
03	0502011688	SEED SIST CONTROL DEPTH LEVER	01
04	0511015976	FLAT WASHER	01
05	0503010257	1/8" X 1" COTTERPIN	01
06	0511060699	DEPTH WHEEL STOP	01
07	0503010071	3/16" X 1" COTTERPIN	01




Item	Code	Description	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK	01
02	0502011907	DEPTH CONTROL WHEEL HUB	01
03	0503010269	6204 BALL BEARING	02
04	0501013636	SPACING SLEEVE	01
05	0503010689	SEAL 00763-BR	01
06	0503011105	SEAL RING	01
07	0503010878	5/8" SELF ALIGNING NUT	01
08	0521019178	COVER DEPTH	01
09	0503030757	2.9" X 2" X 0.02" JOINT	01
10	0503014729	1/4" UNF X 1/2" BOLT	03
11	0503011441	SPRING WASHER	03
12	0503010691	1/4" GREASE FITTING	01




Item	Code	Description	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND	01
02	0521010832	RIM FLANGE	02
03	0503010298	1/4" X 1/2" BOLT	05
04	0503010143	SPRING WASHER	05
05	0503010144	1/4" NUT	05




Item	Code	Description	QT
01	0501052908	PRESS WHEELS ASSY	01
02	0503016449	1/2 X 4 BOLT	01
03	0521014508	FLAT WASHER	03
04	0503012136	1 X 9 BOLT	01



Item	Code	Description	QT
01	0502011919	PRESS WHEEL HUB	01
02	0502011877	PRESS WHEEL HUB	01
03	0503010269	6204 BALL BEARING	02
04	0521018922	PRESS WHEEL PASSANG AXLE	02
05	0503012734	SEAL 01556 BR	02
06	0521018921	DUST CLOAK	02
07	0503010691	1/4" GREASE FITTING	01
08	0521018928	PRESS WHEEL RIM	02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND	01
10	0503010011	5/16" X 1/2" BOLT	06
11	0503010358	5/16" X 5/8" BOLT	03
12	0503013816	5/16" LOCKNUT	03



Item	Code	Description	QT
001	0501052908	PRESS WHEELS ASSY	01
002	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT	01
003	0521014508	FLAT WASHER	03
004	0503016864	LH 1/2" LOCK NUT	01




Item	Code	Description	QT
01	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE	01
02	0502012368	BLADE DISC SUPPORT AXLE	01
03	0503010756	0.2" X 2.4" SPRING PIN	01
04	0503010361	SPRING PIN	01
05	0541018684	FLAT WASHER	01
06	0521014137	RIGHT ARM OF THE BLADE DISC	01
07	0521014138	SUPPORT ARM LEFT BALDE DISC	01
08	0501067323	SPRING REGULATOR	01
09	0521010452	SLEEVE	01
10	0503013185	3/4" X 5-1/2" BOLT	01
11	0503011255	3/4" LOCK NUT	01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01
13	0503011411	1/2" X 5-1/2" BOLT	01
14	0503011440	SPRING WASHER	01
15	0503010060	1/2" NUT	01
16	0502020393	SPRING UPPER SUPPORT	01
17	0502020394	SPRING SUPPORT	01
18	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01
19	0503010014	3/4" NUT	02
20	0521015376	DUST CLOAK	02
21	0502011562	DC PST ACT/ULTR BOX	01
22	0503010276	6206 BALL BEARING	02
23	0521013610	BLADE DISC HUB AXLE	01
24	0503030832	FLAT WASHER	02
25	0503012417	SEAL	02
26	0503011800	SEAL RING	02
27	0503010691	1/4" GREASE FITTING	01
28	0603026013	PLAIN COULTER BLADE	01
29	0502020641	BLADE DISC FLANGE	01
30	0503010371	5/16" X 1" BOLT	06
31	0503010179	SPRING WASHER	06
32	0503010337	5/16" NUT	06
33	0511015346	FLAT WASHER	02




18" COULTER BLADE ASSY FOR LONG ROW

0511044573


Item	Code	Description	QT
34	0503010023	SPRING WASHER	02
35	0521013510	3/4" NUT	02
36	0503010003	1845 GREASE FITTING	01




Item	Code	Description	11 13
00	0511054556	HIDRAULIC ROW MARKER ASSY	01 00
00A	0511054555	MARKER CYLINDER	00 01
01	0511069622	ROW MARKER ARM SUPPORT	02 02
02	0503012699	5/8" X 2" BOLT	08 08
03	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	10 10
04	0503011070	BEATER	02 02
05	0503010019	1/2" SPRING WASHER	02 02
06	0501069470	ROW MARKER ARM	02 00
07	0521061655	BOLT 5/8 UNC X 320	02 02
08	0521010479	SLEEVE ARTICULATION	04 04
09	0501012140	FLAT WASHER	04 04
10	0511040203	1.5" X 2.5" X 19" X 9" HYDRAULIC CYLINDER	02 02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT	02 02
12	0503010523	1/4" X 2" COTTERPIN	04 04
13	0511015779	1" X 4.2" AXLE	02 02
14	0511017592	11.8" X 1.6" TRANSPORT LOCK	02 02
15	0501068994	0.3" X 3.1" LOCK PIN	02 02
16	0503030168	HAIR PIN	02 02
17	0501066949	1235 TURNBUCKLE	02 02
18	0511016156	5/8" X 1.1/2" BOLT	04 04
19	0501050633	DISC ASSY FOR ROW MARKER	02 02
20	0521013164	PROTRACTOR TURNBUCKLE	02 02
21	0501011310	FIXER LOCK	08 08
22	0503010740	1/2" X 2" BOLT	02 02
23	0551019213	FLAT WASHER	02 02
24	0503010706	1/2" X 4.1/2" BOLT	08 08
25	0503010019	1/2" SPRING WASHER	08 08
26	0503010060	1/2" NUT	08 08
27	0511061811	ROW MARKER ARM	00 02
28	0909091663	MARKER HYDRAULIC CIRCUIT	01 01
29	0501054649	SEQUENTIAL VALVE ASSY	01 01




Item	Code	Description	QT
01	0511062810	2.5" X 15" CYLINDER CASE	01
02	0501065662	HYDRAULIC CYLINDER TURNBUCKLE	01
03	0502010471	MOBILE COVER	01
04	0502010780	RING SUPPORT	01
05	0503010163	D-1500 SCRAPER RING	01
06	0503010989	1870-1500-375-B GASKET	01
07	0503010970	W1-1650-500 PK O'RING G.E	01
08	0503011058	8-330 BACK-UP RING	01
09	0503010161	2-330 N 3006 9B O'RING	01
10	0503010285	2-222 N 3006-9B O'RING	01
11	0502010783	1.5" X 2.5" PISTON	01
12	0503010160	2500 2000 GASKET	02
13	0503010973	W2-2500-500 PK O'RING G.E	01
14	0503010063	1" SELF-ALIGNING NUT	01
15	0503030384	CON N-001 PLUG	02
16	0501032666	HYDRAULIC CYLINDER REPAIR KIT	01




Item	Code	Description	QT
01	0511053904	ROW MARKER DISC	01
02	0503010023	SPRING WASHER	01
03	0503010014	3/4" NUT	01




Item	Code	Description	11 13
01	0501054649	SEQUENTIAL VALVE ASSY	01 01
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	02 02
03	0501010984	FLAT WASHER	02 02
04	0503010025	3/8 SPRING WASHER	02 02
05	0501081800	3/8" X 122" TR-TR HOSE ASSY	01 00
06	0501080343	TR-TR HOSE ASSY	01 00
07	0501081803	3/8" X 3750 TR-TC HOSE ASSY	01 00
08	0501080605	3/8" X 160" TR-TC HOSE ASSY	02 02
09	0501080361	3/8" X 157" TR-TM HOSE ASSY	02 02
10	0501053834	QUICK CONECTION (MALE) 1/2	02 02
10A	0501053834	QUICK CONECTION (MALE) 1/2	02 02
10B	0503011882	QUICK CONNECTION COVER	02 02
11	0502012702	BODY SUPPORT CLAMP	06 06
12	0531011180	UPPER BODY CLIP	06 06
13	0503012555	7/16" X 2" BOLT	04 04
14	0503010180	7/16" SPRING WASHER	06 06
15	0503011103	7/16" X 2-1/2" BOLT	02 02
16	0501012803	FLAT WASHER	02 02
17	0503010244	7/16" NUT	02 02
18	0501081793	HOSE	00 01
19	0501081794	TR-TC HOSE ASSY	00 01
20	0501080388	3/8 X 4300 TR-TC HOSE ASSY	00 01
21	0501081797	HOSE ASSY	00 01




Item	Code	Description	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE	01
02	0501010617	3/4" NIPPLE	02
03	0503010190	2-114 N 3006-9B O'RING	02
04	0501012109	3/4" X 9/16" NIPPLE	04
05	0503011036	2-111 N 3006-9B O'RING	06
06	0531019339	9/16" UNF X 12 PUMP	02




Item	Code	Description	QT
001	0501011543	5/8" X 4" BOLT	02
002	0511061835	PLOUGH SUPPORT	01
003	0503030012	HAIR PIN	01
004	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	02
005	0501011075	PIN	01
006	0502010175	HITCH CLAMP	01
007	0502011530	SUPPORT	01



Item	Code	Description	QT
001	0521013430	5/8" X 101.57" HEX AXLE	01
002	0521013434	5/8" X 90" HEX AXLE	01
003	0501053608	BEARING ASSY WITH GEAR 20Z & 5/8" HEX AXLE	02
003A	0501053609	5/8 DOUB BEARING OF THE SEED TRANSM	01
003AA	0502011987	DOUBLE HOUSING BEARING	01
003AB	0503011410	ROLLER BEARING	02
003AC	0503011105	SEAL RING	01
003B	0511063106	20Z AXLE BEARING DOBLE	01
003C	0503010406	501025 CLAMPING RING (FOR AXLE)	02
003D	0503010365	NUT	02
003E	0501010694	FLAT WASHER	04
003F	0503010179	SPRING WASHER	02
003G	0503010337	5/16" NUT	02
004	0561014215	BEARING COVER LOWER ROW FRAME	02
005	0502040534	SPRING GUIDE BUSHING LOCK	04
006	0503010237	3/8" X 1" BOLT	04



Item	Code	Description	QT
001	0541019101	HEX AXLE	01
002	0541019102	HEX AXLE	01
003	0501053608	BEARING ASSY WITH GEAR 20Z & 5/8" HEX AXLE	02
003A	0501053609	5/8 DOUB BEARING OF THE SEED TRANSM	01
003AA	0502011987	DOUBLE HOUSING BEARING	01
003AB	0503011410	ROLLER BEARING	02
003AC	0503011105	SEAL RING	01
003B	0511063106	20Z AXLE BEARING DOBLE	01
003C	0503010406	501025 CLAMPING RING (FOR AXLE)	02
003D	0503010365	NUT	02
003E	0501010694	FLAT WASHER	04
003F	0503010179	SPRING WASHER	02
003G	0503010337	5/16" NUT	02
004	0561014215	BEARING COVER LOWER ROW FRAME	02
005	0502040534	SPRING GUIDE BUSHING LOCK	04
006	0503010237	3/8" X 1" BOLT	04



Item	Code	Description	QT
00	0511056742	SET SYSTEM HYDRAULIC	01
01	0571017027	SOPORTE VALV	01
02	0503010920	1/2" X 1.1/2" BOLT	02
03	0511017302	FLAT WASHER	02
04	0503010019	1/2" SPRING WASHER	02
05	0503010060	1/2" NUT	02
06	0501054694	FLOW DIVIDING VALVE ASSY	01
06A	0503012481	FLOW DIVIDING VALVE	01
06B	0501011460	7/8 NF REDUCTION NIPPLE	03
06C	0503010190	2-114 N 3006-9B O'RING	03
07	0503010373	1/4" X 2" BOLT	02
08	0503010143	SPRING WASHER	02
09	0503010144	1/4" NUT	02
10	0541012166	NIPPLE 3/4" UNF X 7/8"	01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT	01
12	0503011968	T ADAPTOR WITH GIRAT	01
13	0501080026	3/8 X 950 TR-TC HOSE	01
14	0501081792	3/8 X 950 TC-TC HOSE	01
15	0501081796	3/8" X 1650 TR-TC HOSE	01
16	0501081795	3/8" X 1650 TC-TC HOSE	01
17	0501081073	1/2" X 4200 TC-TM HOSE	02
18	0501053834	QUICK CONECTION (MALE) 1/2	02
18A	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT	02
18B	0503011882	QUICK CONNECTION COVER	02
19	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM	02
20	0571017774	SPRING PROTECTION QUICK HOSE	01
21	0502012702	BODY SUPPORT CLAMP	03
22	0503010180	7/16" SPRING WASHER	03
23	0503012555	7/16" X 2" BOLT	03
24	0503013100	NYLON CLAMP	02

[illegible]



MARCHESAN IMPLEMENTOS E MÁQUINAS AGRÍCOLAS TATU S.A.

AV. Marchesan, 1979 - Post office box, 131 - CEP 15994-900 - Matão - SP - Brazil

Phone +55 16.3382-8282

(FAX Parts) + 55 16.3382. 8297 - (Export) + 55 16.3382.1003

e.mail: tatu@marchesan.com.br www.marchesan.com.br

Technical Publications: Elaboration

JOSÉ DOMINGOS GASPARI

Technical Publications: Revision

LUIZ CANDIDO

Contact Catálogo:

E-mail = jgaspari@marchesan.com.br

**ORIGINAL PARTS
TATU**

