

ROW CROP PLANTERS

PST TRIO FLEX SUPREMA P.P - FRAME 7450 - CSU - APT

Code: 0501091088
Series: S-1214
Revision: 00
Date Revision: SETEMBRO/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111360007	PST TRIO FLEX SUP PP 15 E500 ESPECIAL S-1214

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX


0909091276	FRAME ASSY	1
0511053196	FRAME WITH ARTICULATION 7450	2
0511053188	RIGHT FRAME WITH WHEELED AXLE 7450	3
0511053189	LEFT FRAME WITH WHEELED AXLE 7450	4
0511053190	CENTRAL FRAME WITH WHEELED AXLE 6450/7285/7450/8460	5
0511058406	HYDRAULIC CYLINDER	6
0521043312	HUB SPINDLE ASSY	7
0521043313	WHEELED WITH SPRING TRACTION WITHOUT TRANSMISSION	8
0501058241	WHEEL SUPPORT CHAIN TENSIONER	9
0511052770	WHEEL WITH TIRE	10
0503062159	WHEEL WITH TIRE	11
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	12
0501058240	WHEEL FASTENER WITH TENSIONER	13
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	14
0501058244	WHEEL FIXED CHAIN TENSIONER	15
0501058242	WHEEL MOBILE CHAIN TENSIONER	16
0501058239	WHEEL CHAIN TENSIONER BEARING	17
0511054336	SUPPORT WHEELED WITHOUT TRANSMISSION	18
0521051801	WHEEL WITH TIRE 7.00X16 WHEELED BOX WITHOUT TRANSMISSION	19
0521051800	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	20
0511053065	TRIPLE VALVE	21
0511057092	HOSE KIT SYSTEM HYDRAULIC	22
0501053834	MALE QUICK COUPLER	23
0511053194	HYDRAULIC MARKER	24
0511058449	HYDRAULIC CYLINDER	25
0501054649	HBM SEQUENTIAL VALVE	26
0511053191	RIGHTH BEAM SUPPORT WITH DISTRIBUTOR	27
0511053192	LEFT BEAM SUPPORT WITH DISTRIBUTOR	28
0511053193	SUPPORT CENTER BEAM WITH DISTRIBUTOR	29
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	30
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	31
0503062208	CARDAN TERMINAL	32
0511052885	ASSEMBLY CSU	33
0511053073	TURNBUCKLE SIDE ASSY	34
0511053074	TURNBUCKLE SIDE LEFT	35
0511053075	3 POINT TURNBUCKLE	36
0511053076	TURNBUCKLE SIDE UPPER	37
0511054601	HITCH ARTICULATED TRACTOR	38
0511053179	TRACTOR COUPLING SHAFT	39
0909096885	ASSY TURBINE	40
0521044703	TURBINE	41
0501054983	NIPPLE HIDRAULIC MOTOR	42
0521044613	480 X 50 FAN (HIDRAULIC)	43
0501054272	RIBBON FOR COVER CLOSING ASSY	44
0501056495	TURBINE OUTPUT SOCKET	45
0511056197	RIGHT SIDE AIR DISTRIBUTOR	46
0511056196	CENTRAL AIR DISTRIBUTOR	47
0503062206	CARDAN TERMINAL	48
0501058972	ASSEMBLY SENSOR ELECTRONIC	49
0511056238	RADIATOR COMPLETE WITH BRACKET	50
0501050633	ROW MARKER DISC ASSEMBLY	51
0511053904	ROW MARKER DISC	52
0909092988	SEED/FERTILIZER COMPLETE ROW	53

INDEX

0511057243	LEFT SHORT SEED ROW FRONT		54
0511057246	RIGHT LONG SEED ROW FRONT		55
0511057244	RIGTH SHORT SEED ROW FRONT		56
0511057247	LEFT LONG SEED ROW FRONT		57
0511054635	BEARING AXLE BODY		58
0511057159	TRANSMISSION HOPPER SEED ROW		59
0511050609	BEARING WITH 17Z GEAR ASSY		60
0511050617	FRONT SEED ROW BEARING		61
0511055260	SEED ROW CHAIN TENSIONER		62
0511052426	TRANSMISSION CARDAN ASSY		63
0511052389	BEARING DOUBLE FRONT ROW SEED		64
0501052769	BEARING WITH 17Z GEAR		65
0511057607	REAR RIGHT ROW SEED		66
0511057608	REAR LEFT ROW SEED		67
0511057606	PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX		68
0511057154	RIGHT DDD		69
0511057502	SET PRECISION PLANTING		70
0511057155	PRECISION PLANTING LEFT TRANSMISSION HOPPER		71
0511057153	DDD LEFT		72
0511053172	LEFT LOW HUB WITH 15 DISC		73
0511053173	RIGHT LOW HUB WITH 15 DISC		74
0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC		75
0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC		76
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR		77
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR		78
0511044549	18" COULTER BLADE ASSY FOR SHORT ROW		79
0511044573	18" COULTER BLADE ASSY FOR LONG ROW		80
0521054686	18" DISC BLADE HUB		81
0521054679	DISC BLADE HUB		82
0501058423	FERTILIZER ROD SPRING ROW		83
0511058212	FERTILIZER ROW SUPPORT ASSY		84
0501110231	SCARIFIER ROD WITH TIP		85
0521052549	CLAMP		86
0531050237	3" RIGHT SEED CONDUCTOR FIXER		87

FRAME ASSY

0909091276



Item	Code	Description	See page	QT
001	0511053196	FRAME WITH ARTICULATION 7450	2	01
002	0521064285	LOCK LOWER FRAME		02
003	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		02
004	0503010002	1800 GREASE FITTING		02
005	0503010003	1845 GREASE FITTING		12
006	0511058406	HYDRAULIC CYLINDER	6	03
007	0521012538	1.2" X 3.5" COUPLING SHAFT		03
008	0521012536	COUPLING SHAFT		03
009	0503010523	1/4" X 2" SPLIT PIN		06
010	0531012565	SLEEVE 16,3X 30 X 88		03
011	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		03
012	0503010027	5/8 SPRING WASHER		03
013	0503010013	5/8 NUT		03
014	0521043312	HUB SPINDLE ASSY	7	04
015	0521043313	WHEELED WITH SPRING TRACTION WITHOUT 8 TRANSMISSION		02
016	0571013472	FIXER BODY VALVE		01
017	0511053065	TRIPLE VALVE	21	01
018	0503010371	5/16" X 1" BOLT		02
019	0503010421	5/16" X 1-1/2" BOLT		02
020	0501010694	FLAT WASHER		04
021	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
022	0503010337	5/16" NUT		04
023	0502012701	LOWER BODY CLIP		02
024	0521063909	DUCT SEAL OIL		01
025	0531013922	0.6" X 0.8" X 1" SLEEVE		02
026	0531011180	UPPER BODY CLIP		02
027	0511057092	HOSE KIT SYSTEM HYDRAULIC	22	01
028	0501053834	MALE QUICK COUPLER	23	02
029	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
030	0502012702	BODY SUPPORT CLAMP		08
031	0503010180	7/16" SPRING WASHER		08

FRAME ASSY

0909091276

Item	Code	Description	See page	QT
032	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		08
033	0511053194	HYDRAULIC MARKER	24	01
034	0511053191	RIGTH BEAM SUPPORT WITH DISTRIBUITOR	27	01
035	0511053192	LEFT BEAM SUPPORT WITH DISTRIBUITOR	28	01
036	0511053193	SUPPORT CENTER BEAM WITH DISTRIBUITOR	29	01
037	0503010849	3/8" X 1-1/2" BOLT		16
038	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
039	0503010025	3/8 SPRING WASHER		16
040	0503010026	3/8" NUT		16
041	0503034396	FERTILIZER SIDE COVER		15
042	0503010362	1/8" X 1.1/4" SPLIT PIN		15
043	0503060640	COVER BOX RIGHT FERTILIZER		01
044	0503060641	LEFT FERTILIZER HOPPER WITH LID		01
045	0503060643	COVER BOX LEFT FERTILIZER		01
046	0511062099	FERTILIZER BEAM CLAMP		06
047	0511061886	FERTILIZER BEAM LOCK		06
048	0503010019	1/2" SPRING WASHER		06
049	0503010060	1/2 UNC G.5 ZN HEX NUT		06
050	0503062208	CARDAN TERMINAL	32	02
051	0503011855	0.2" X 1.8" SPRING PIN		04
052	0503030331	1.2" X 1.2" X 12.2" HOSE		02
053	0503010243	CLAMP		04
054	0551018055	22,65 X 60 SLEEVE		02
055	0511069661	PLATFORM SUPPORT PIVOT		06
056	0503010849	3/8" X 1-1/2" BOLT		10
057	0501010984	10,50 X 27 X 3,00 FLAT WASHER		20
058	0503010025	3/8 SPRING WASHER		10
059	0503010026	3/8" NUT		10
060	0521064015	PLATFORM RIGHT SIDE		01
061	0521064016	PLATFORM LEFT SIDE		01
062	0521064017	PLATFORM CENTER		01
063	0521010549	COUPLING SHAFT		06
064	0503010257	1/8" X 1" SPLIT PIN		06
065	0503011333	COVER FIXER		03
066	0503010274	5/32" X 2" SPLIT PIN		03
067	0502012740	PLATFORM RIGHT FIXER SUPPORT		02
068	0502012739	PLATFORM LEFT FIXER SUPPORT		01
069	0503011082	C1/2" X 1.3/4" SCREW		08
070	0503010019	1/2" SPRING WASHER		08
071	0503010060	1/2 UNC G.5 ZN HEX NUT		08
072	0502012742	FIXER SUPPORT LADDER		04
073	0503010237	3/8" X 1" BOLT		08
074	0503010025	3/8 SPRING WASHER		08
075	0503010026	3/8" NUT		08
076	0511069636	LADDER		02
077	0503011179	3/8" X 2-1/4" BOLT		04
078	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
079	0503013357	3/8 SELF-ADJUSTING NUT		04
080	0571013471	PLATFORM FIXER LOCK		03
081	0501010096	3/8" X 2" BOLT		03
082	0501010984	10,50 X 27 X 3,00 FLAT WASHER		03
083	0503013357	3/8 SELF-ADJUSTING NUT		03
084	0502011530	SUPPORT		02
085	0502010175	HITCH CLAMP		02
086	0501010163	5/8" X 4-1/2" BOLT		04
087	0503010027	5/8 SPRING WASHER		04
088	0503010013	5/8 NUT		04
089	0511061835	PLOUGH SUPPORT		02
090	0501011075	PIN		02

FRAME ASSY


0909091276

Item	Code	Description	See page	QT
091	0503030012	HITCH PIN CLIP		02
092	0503013100	NYLON CLAMP		02
093	0503060100	INSTRUCTIONS MANUAL CANISTER		01
094	0511030764	BAG WITH INSTRUCTION MANUAL		01
095	0503010267	NYLON CLAMP		01
096	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
097	0501010694	FLAT WASHER		01
098	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
099	0503010337	5/16" NUT		01
100	0503034056	ADHESIVE LABEL PST TRIO FLEX SUPREMA		03
101	0503033854	ADHESIVE LABEL		03
102	0503033853	ADHESIVE LABEL		02
103	0503033415	ADHESIVE LABEL		02
104	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
105	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER		01
106	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER		04
107	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM		03
108	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM		02
109	0503033981	ADHESIVE LABEL		01
110	0503031428	READ MANUAL DECAL		01
111	0503031942	ADHESIVE LABEL		01
112	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		02
113	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
114	0503031565	ADHESIVE LABEL CARE		02
115	0503031566	ADHESIVE LABEL		02
116	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
117	0503031425	ADHESIVE LABEL ATTENTION		02
118	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
119	0503032930	ADHESIVE LABEL DANGER		08
120	0503031087	AUTO CONTROL APPROVED DECAL		01
121	0503034003	61 X 118 SERIAL NUMBER TAG		01
122	0503010001	3.2 X 5.5 RIVET		04
123	0511052885	ASSEMBLY CSU	33	01
124	0521063882	DRAWBAR		01
125	0521064024	DRAWBAR INTERMEDIARY		01
126	0511061021	SUPPORT FASTENER		04
127	0502010175	HITCH CLAMP		06
128	0501010163	5/8" X 4-1/2" BOLT		16
129	0501012140	FLAT WASHER		16
130	0503010027	5/8 SPRING WASHER		16
131	0503010013	5/8 NUT		16
132	0571019949	JUNCTION SHAFT		06
133	0503030085	LOCK PIN		06
134	0511053073	TURNBUCKLE SIDE ASSY	34	01
135	0511053074	TURNBUCKLE SIDE LEFT	35	01
136	0511053075	3 POINT TURNBUCKLE	36	01
137	0511053076	TURNBUCKLE SIDE UPPER	37	02
138	0521018501	TURNBUCKLE LEVER		01
139	0521010588	0.9" X 7.0" COUPLING SHAFT		02
140	0503010523	1/4" X 2" SPLIT PIN		04
141	0521010571	COUPLING SHAFT		02
142	0521010780	1.2" X 4.5" COUPLING SHAFT		02
143	0503030119	LOCK PIN		02
144	0511063282	HOSE HOLDER		15
145	0511054601	HITCH ARTICULATED TRACTOR	38	01
146	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
147	0511053179	TRACTOR COUPLING SHAFT	39	01
148	0521013022	TRANSPORT LOCK		03


FRAME ASSY

0909091276


Item	Code	Description	See page	QT
149	0501068994	8,30 X 78 LOCK PIN		03
150	0503030168	HITCH PIN CLIP		03
151	0501047895	25 ROD STOP		03
152	0501047885	30 ROD STOP		03
153	0501047886	35 ROD STOP		03
154	0501047887	40 ROD STOP		03
155	0909096885	ASSY TURBINE	40	01
156	0571013724	5/8 X 1250 HEX AXLE		01
157	0571013726	5/8 X 800 HEX AXLE		01
158	0571013725	5/8 X 2190 HEX AXLE		02
159	0503062206	CARDAN TERMINAL	48	02
160	0503011855	0.2" X 1.8" SPRING PIN		04
161	0511055636	PLANTING ISOBUS SET		01
162	0511055166	PLANTING ISO SET		01
163	0501058972	ASSEMBLY SENSOR ELECTRONIC	49	01
164	0511056233	MECHANICAL SET		01
165	0511056238	RADIATOR COMPLETE WITH BRACKET	50	01
166	0511057643	HOSE GAME		01
166A	0501081958	HOSE 3/8 X 8200 TC-TM		01
166B	0501081959	HOSE 1/2 X 7800 TC-TM		02
167	0541015451	FIXED KEY 2.3/8 X 2.3/4		01
168	0501050633	ROW MARKER DISC ASSEMBLY	51	02
169	0521013164	EXTENDER		02
170	0501011310	FIXER LOCK		08
171	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		08
172	0503010019	1/2" SPRING WASHER		08
173	0503010060	1/2 UNC G.5 ZN HEX NUT		08
174	0909092988	SEED/FERTILIZER COMPLETE ROW	53	01




Item	Code	Description	See page	QT
01	0511053188	RIGHT FRAME WITH WHEELED AXLE 7450	3	01
02	0511053189	LEFT FRAME WITH WHEELED AXLE 7450	4	01
03	0511053190	CENTRAL FRAME WITH WHEELED AXLE 6450/7285/7450/8460	5	01
04	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		04
05	0503011442	3/4" SPRING WASHER		18
06	0501010098	3/4" UNC BOLT		18
07	0571010094	SLEEVE FLANGE		06
08	0521063912	PIVOT SHAFT		02
09	0571013510	LOCK AXLE		02
10	0503030085	LOCK PIN		02
11	0571010095	FLAT WASHER		02
12	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
13	0503011444	SPRING WASHER		04
14	0502012698	CLAMP		04
15	0501011643	3/8 X 1" BOLT		14
16	0503010025	3/8 SPRING WASHER		14
17	0503010026	3/8" NUT		14
18	0521063003	LOCK PIN		02
19	0571010969	LOCK SLEEVE FRAME		02
20	0503013627	1.1/2 SPRING WASHER		02
21	0501010110	1.1/2" NUT		02
22	0581018018	TROUGH 24 X 50 X 1255		02
23	0581018019	TROUGH 24 X 50 X 1070		02
24	0581015857	GUTTER 24 X 50 X 1080		02




Item	Code	Description	See page	QT
01	0521064009	RIGHT FRAME		01
02	0521064023	ARTICLES AXLE RIGHT ROLLED		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06



Item	Code	Description	See page	QT
01	0521064010	LEFT FRAME		01
02	0521064021	ARTICLES AXLE LEFT ROLLED		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
01	0521064011	CENTRAL FRAME		01
02	0521064022	CENTRAL ARTICLES AXLE ROLLED		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8 UNC X 2.1/4 BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8 NUT		08




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCKLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01

HUB SPINDLE ASSY


0521043312




Item	Code	Description	See page	QT
01	0511054335	WHEEL SUPPORT ASSY		01
01A	0521061566	CARRYING WHEEL ARM TRACTION		01
01B	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
01C	0531016887	CARRYING WHEEL AXLE ARM		01
01D	0503010523	1/4" X 2" SPLIT PIN		01
01E	0503010003	1845 GREASE FITTING		01
01F	0511050681	TRACTION SPRING		01
01FA	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01FB	0561016062	SPRING HITCH		02
01G	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
01H	0503010027	5/8 SPRING WASHER		01
01I	0503013030	5/8" X 3.1/4" BOLT		01
01J	0551017715	FLAT WASHER		02
01K	0511052770	WHEEL WITH TIRE	10	01
01KA	0503062159	WHEEL WITH TIRE	11	01
01KB	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	12	01
01L	0521012190	AXLE LOCK		02
01M	0503010027	5/8 SPRING WASHER		02
01N	0503011167	M16 X 2 X 30 BOLT		02
01O	0501058241	WHEEL SUPPORT CHAIN TENSIONER	9	01
01P	0501012140	FLAT WASHER		01
02	0501058240	WHEEL FASTENER WITH TENSIONER	13	01
03	0502011308	WHELL FASTENER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0511054336	SUPPORT WHEELED WITHOUT TRANSMISSION	18	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8 SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	11	01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	12	01




Item	Code	Description	See page	QT
01	0503012113	TIRE 7.00 X 16 10 CANVAS		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8 NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	14	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	15	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	16	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	17	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	17	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	17	01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0521061566	CARRYING WHEEL ARM TRACTION		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0503018981	BOLT		02
07	0503010027	5/8 SPRING WASHER		02
08	0521012190	AXLE LOCK		02
09	0521051801	WHEEL WITH TIRE 7.00X16 WHEELED BOX 19 WITHOUT TRANSMISSION		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	11	01
02	0521051800	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	20	01




Item	Code	Description	See page	QT
01	0503010328	25590/25523 ROLLER BEARING		02
02	0503010804	00547-B SEAL		02
03	0521012185	TRANSMISSION WHEEL AXLE		01
04	0503010330	KM 9 LOCKNUT		01
05	0511015949	LOCK NUT		01
06	0503010329	LOCK WASHER		01
07	0503010002	1800 GREASE FITTING		01
08	0501110721	WHEEL HUB WITH SCREW / NUTS		01
08A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
08B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
08C	0503016516	5/8 UNF CONIC NUT		06




Item	Code	Description	See page	QT
01	0503016524	DIVIDER VALVE		01
02	0551012400	7/8" UNF NIPPLE		01
03	0501011460	7/8 NF REDUCTION NIPPLE		03
04	0503010190	2-114 N 3006-9B O'RING		04



Item	Code	Description	See page	QT
01	0501080406	3/8" X 23" TR-TC HOSE		01
02	0501080150	3/8 X 800 TR-TC HOSE		01
03	0501081930	HOSE		01
04	0501081646	TC-TC HOSE ASSY		03
05	0521052275	HOSE		01
05A	0501081073	HOSE 1/2 X 4200 TC-TM		01
05B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
05C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
05D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
06	0521052276	HOSE		01
06A	0501081073	HOSE 1/2 X 4200 TC-TM		01
06B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
06C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
06D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503011336	1/2" HEX SELF ADJUSTING NUT		02
05	0511061811	ROW MARKER ARM		02
06	0521061655	BOLT 5/8 UNC X 320 MM		02
07	0521010479	SLEEVE ARTICULATION		04
08	0511058449	HYDRAULIC CYLINDER	25	02
09	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
10	0503010523	1/4" X 2" SPLIT PIN		02
11	0511015779	1" X 4.2" AXLE		02
12	0503010523	1/4" X 2" SPLIT PIN		02
13	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
14	0501068994	8,30 X 78 LOCK PIN		02
15	0503030168	HITCH PIN CLIP		02
16	0501066949	1235 TURNBUCKLE		02
17	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
18	0501054649	HBM SEQUENTIAL VALVE	26	01
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
20	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
21	0503010025	3/8 SPRING WASHER		02
22	0511057094	HYDRAULIC HOSE MARKER ASSY 6450		01
22A	0501081804	HOSE ASSY 3/8 X 4600 TR-TC		02
22B	0501081093	3/8" X 188.9" TR-TC HOSE ASSY		02
22C	0501080878	3/8 X 4200 TC-TM HOSE ASSY		02
23	0501053834	MALE QUICK COUPLER	23	02
23A	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
23B	0503011882	MALE QUICK COUPLER CAP		01
24	0502012702	BODY SUPPORT CLAMP		02
25	0531011180	UPPER BODY CLIP		08
26	0503010180	7/16" SPRING WASHER		02


HYDRAULIC MARKER

0511053194


Item	Code	Description	See page	QT
27	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		02
28	0503012412	5/8" UNC SELF LOCKING NUT		08
29	0501012140	FLAT WASHER		04
30	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
31	0503010019	1/2" SPRING WASHER		02



Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0521066219	FERTILIZER BEAN RIGHT SUPPORT		01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	30	01
03	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	31	04
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		05
10	0502012990	CONICA 14Z SQUARE GEAR		05
11	0571019663	SQUARE SHAFT		01
12	0571015966	LOCK AXLE		01
13	0503010421	5/16" X 1-1/2" BOLT		02
14	0503011444	SPRING WASHER		02
15	0503010337	5/16" NUT		02
16	0501110392	HOPPER SUPPORT BEARING		01
17	0521012485	GEAR BOX BEARING AGRICUTURAL		01
18	0503010003	1845 GREASE FITTING		01
19	0503011953	5/16" X 1" BOLT		02
20	0501010694	FLAT WASHER		02
21	0521011039	FLAT WASHER		02
22	0503011444	SPRING WASHER		02
23	0503010337	5/16" NUT		02

LEFT BEAM SUPPORT WITH DISTRIBUTOR


0511053192




Item	Code	Description	See page	QT
01	0521066220	FERTILIZER BEAN LEFT SUPPORT		01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	30	04
03	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	31	01
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		05
10	0502012990	CONICA 14Z SQUARE GEAR		05
11	0571019663	SQUARE SHAFT		01
12	0571015966	LOCK AXLE		01
13	0503010421	5/16" X 1-1/2" BOLT		02
14	0503011444	SPRING WASHER		02
15	0503010337	5/16" NUT		02
16	0501110392	HOPPER SUPPORT BEARING		01
17	0521012485	GEAR BOX BEARING AGRICUTURAL		01
18	0503010003	1845 GREASE FITTING		01
19	0503011953	5/16" X 1" BOLT		02
20	0501010694	FLAT WASHER		02
21	0521011039	FLAT WASHER		02
22	0503011444	SPRING WASHER		02
23	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521065393	CENTER FERTILIZER BEAM SUPPORT		01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	30	03
03	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	31	02
04	0511062163	FERTILIZER BEAM LOWER COVER		01
05	0501010942	3/8" X 1-1/4" BOLT		24
06	0503011443	3/8" SPRING WASHER		24
07	0503010026	3/8" NUT		24
08	0521014167	CONE LOCK		04
09	0503030275	AGRICULTURAL BEARING		05
10	0502012990	CONICA 14Z SQUARE GEAR		05
11	0581010699	SQUARE SHAFT		01
12	0581010700	SQUARE SHAFT		01
13	0571015966	LOCK AXLE		02
14	0503010421	5/16" X 1-1/2" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" SPLIT PIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" SPLIT PIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0503062208	CARDAN TERMINAL	32	01



Item	Code	Description	See page	QT
01	0501012140	FLAT WASHER	12	
02	0511056184	SET CSU 3 BOX 6 B C/15	01	
02A	0521063065	SEED SILO SUPPORT	03	
02B	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER	03	
02C	0521063401	FIXING LOCK	06	
02D	0501010984	10,50 X 27 X 3,00 FLAT WASHER	21	
02E	0503010025	3/8 SPRING WASHER	57	
02F	0503010026	3/8" NUT	42	
02G	0571011148	FIXING PLATE	15	
02H	0571011149	INTERMEDIARY PLATE	15	
02I	0521063076	CONDUCTOR SEED OUTLET NOZZLE	15	
02J	0571011147	SEED OUTPUT CAP	15	
02K	0501010942	3/8" X 1-1/4" BOLT	30	
02L	0501011643	3/8 X 1"BOLT	21	
02M	0503010209	3/8" UNC BUTTERFLY NUT	13	
02N	0571017205	SINGLE SEED BOX SUPPORT CAP	03	
03	0521063064	SEED HOPPER SUPPORT TOWER	06	
04	0501010942	3/8" X 1-1/4" BOLT	12	
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER	12	
06	0503010025	3/8 SPRING WASHER	12	
07	0503010026	3/8" NUT	12	
08	0502010175	HITCH CLAMP	06	
09	0501011543	5/8" X 4" BOLT	12	
10	0503012412	5/8" UNC SELF LOCKING NUT	12	




Item	Code	Description	See page	QT
001	0521063911	TURNBUCKLE RIGHT SIDE		01
002	0501078990	TURNBUCKLE AXLE		01
003	0561019879	LOCK ATTACHMENT BAR		01
004	0521063917	POINT REVOLVING EXTENDING		01
005	0511017907	1/8" BSPT X 6 PLUG		02
006	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521063910	TURNBUCKLE LEFT SIDE		01
02	0501078990	TURNBUCKLE AXLE		01
03	0561019879	LOCK ATTACHMENT BAR		01
04	0521063917	POINT REVOLVING EXTENDING		01
05	0503010002	1800 GREASE FITTING		02

3 POINT TURNBUCKLE


0511053075




Item	Code	Description	See page	QT
01	0502011237	ESTABILIZER BODY		01
02	0521063913	JACKET LEFT		01
03	0521063914	JACKET RIGHT		01
04	0511061880	SIDE RIGHT RATCHET		01
05	0531010264	SIDE RATCHET		01
06	0511061881	RATCHET FOLLOWER		01
07	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
08	0503011179	3/8" X 2-1/4" BOLT		05
09	0503011443	3/8" SPRING WASHER		05
10	0503010026	3/8" NUT		05
11	0503010002	1800 GREASE FITTING		05
12	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0502011195	ADJUSTMENT NUT BODY		02
02	0521063884	LEFT TURNBUCKLE		02
03	0521063883	RIGHT TURNBUCKLE		02
04	0541018673	COUNTERNUT		02
05	0541018672	COUNTERNUT		02
06	0503010002	1800 GREASE FITTING		04



Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2" SPLIT PIN		01
10	0503033731	LEFT COMPRESSION SPRING		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01



Item	Code	Description	See page	QT
01	0521044703	TURBINE	41	01
02	0521065248	TURBINE REAR SUPPORT		01
03	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503010232	5/8" X 1.3/4" BOLT		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010013	5/8 NUT		02
09	0511056231	AIR CONDUCTOR SUPPORT		06
09A	0571017211	AIR CONDUCTOR SUPPORT		01
09B	0521018402	AIR CONDUCTOR CLAMP		01
09C	0503010371	5/16" X 1" BOLT		02
09D	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
09E	0503010337	5/16" NUT		02
10	0501010942	3/8" X 1-1/4" BOLT		12
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		12
12	0503010025	3/8 SPRING WASHER		12
13	0503010026	3/8" NUT		12
14	0511056197	RIGHT SIDE AIR DISTRIBUTOR	46	02
15	0511056196	CENTRAL AIR DISTRIBUTOR	47	01
16	0551015245	4 X 1150 HOSE		01
17	0531016193	4" X 74" AIR CONDUCTOR		02
18	0503011372	102 TO 121 CLAMP		06
19	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		15

TURBINE

0521044703




Item	Code	Description	See page	QT
01	0521060122	TURBINE SUPPORT		01
02	0503010849	3/8" X 1-1/2" BOLT		02
03	0503010025	3/8 SPRING WASHER		10
04	0503010026	3/8" NUT		02
05	0501054983	NIPPLE HIDRAULIC MOTOR	42	01
06	0571012636	FRONT COVER		01
07	0503010237	3/8" X 1" BOLT		06
08	0503010026	3/8" NUT		06
09	0521044613	480 X 50 FAN (HIDRAULIC)	43	01
10	0531018764	FLAT WASHER		01
11	0503010143	1/4" SPRING WASHER		01
12	0503011104	M6 X 1" BOLT		01
13	0501054272	RIBBON FOR COVER CLOSING ASSY	44	01
14	0503031776	TURBINE RIBBON SEAL		02
15	0571012630	REAR COVER		01
16	0521065249	TURBINE AIR DISTRIBUTOR		01
17	0503012722	0.16" X 0.4" BLIND RIVET		08
18	0501052451	ELBOW		03
18A	0503031576	ELBOW		01
18B	0521016430	4" X 200 PVC TUBE		01
19	0503013031	1/4" X 3.1/4" BOLT		14
20	0503012721	1/4" X 4" BOLT		01
21	0503012880	1/4" UNC SELF ADJUSTING NUT		15
22	0511017303	FLAT WASHER		01
23	0511014024	10 X 13 X 15,5 SLEEVE		01
24	0501056495	TURBINE OUTPUT SOCKET	45	01
25	0503013096	5/16" X 4" BOLT		02
26	0501010694	FLAT WASHER		02
27	0503010499	5/16 UNC BUTTERFLY NUT		02
28	0561010634	VALVE SUPPORT ASSY		01
29	0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE		01


TURBINE

0521044703


Item	Code	Description	See page	QT
30	0503010206	3/8 X 1/2 BOLT		02
31	0501080125	HOSE 1/2 X 500 TR TR		02
32	0501080635	3/8" X 19" TR-TR HOSE		01



Item	Code	Description	See page	QT
01	0503012871	HYDRAULIC MOTOR		01
02	0531018770	R 3/4"UNF X R 1/4"BSP ELBOW		01
03	0561016941	3/4" NUT		01
04	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
05	0541011065	3/4"UNF X R1/4BSP19FPP X43.5 NIPPLE		01
06	3914103037	TEFLON		0,001RI




Item	Code	Description	See page	QT
01	0571016947	DISC FRONT TURBINE		01
02	0571016949	DISC REAR TURBINE		01
03	0521065171	HUB FLANGE		01
04	0571016950	DISC STRENGTHENING TURBINE		01
05	0571016951	FLIP TURBINE		10
06	0503012651	M6 X 1" BOLT		05
07	0503010143	1/4" SPRING WASHER		05
08	0503011776	M6 SELF ADJUSTINGNUT		05




Item	Code	Description	See page	QT
01	0531017193	RIBBON FOR COVER CLOSING		01
02	0521018401	SEGMENT COVER		15

TURBINE OUTPUT SOCKET


0501056495




Item	Code	Description	See page	QT
01	0503031812	TURBINE OUTPUT SOCKET		01
02	0541017539	BUTTERFLY VALVE		01
03	0511066760	VALVE FIXATION SUPPORT		01
04	0503013813	1/4" UNC X 7/8" BOLT		02
05	0511017303	FLAT WASHER		02
06	0503010143	1/4" SPRING WASHER		02
07	0503010144	1/4" NUT		02
08	0501013519	FLAT WASHER		01
09	0503010019	1/2" SPRING WASHER		01
10	0503010060	1/2 UNC G.5 ZN HEX NUT		01
11	0503032599	ADHESIVE LABELS TURBINE AIR OUTLET		01




Item	Code	Description	See page	QT
01	0571017214	SIDE AIR DISTRIBUTOR BODY		01
02	0503012566	COVER KAP 110 YELLOW		01
03	0503031943	SOCKET		05
04	0503012856	POP RIVET		10
05	0571017215	AIR DISTRIBUTOR SOCKET		01
06	0503031576	ELBOW		01



Item	Code	Description	See page	QT
01	0571017212	AIR DISTRIBUTOR BODY		01
02	0503031943	SOCKET		05
03	0503012856	POP RIVET		10
04	0503031102	SUPREME AIR DISTRIBUTOR		01
05	0503012566	COVER KAP 110 YELLOW		02
06	0571017213	AIR DISTRIBUTOR BODY		01




Item	Code	Description	See page	QT
01	0503062206	CARDAN TERMINAL	48	01



Item	Code	Description	See page	QT
01	0503015218	SENSOR FOTOELE PM 400		01
02	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		03

RADIATOR COMPLETE WITH BRACKET


0511056238



Item	Code	Description	See page	QT
01	0571017235	RADIATOR SUPPORT		01
02	0503016377	HEAT EXCHANGER HYDRAULIC 3083370		01
03	0503016512	THERMOSTAT FOR HEAT EXCHANGE		01
04	0571016604	NIPLE 1.1/16 UNC		01
05	0541018940	7/8 NF X R 1 BSPT X 55 NIPPLE		01
06	0503016736	PANEL COMUTADOR		01
07	0503011953	5/16" X 1" BOLT		04
08	0503010337	5/16" NUT		04
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
10	0501010694	FLAT WASHER		04
11	0501011643	3/8 X 1"BOLT		06
12	0501013518	FLAT WASHER		06
13	0503010025	3/8 SPRING WASHER		06
14	0503010026	3/8" NUT		06
15	0503013534	ADAPTER T TEE		01
16	0503010060	1/2 UNC G.5 ZN HEX NUT		04
17	0503010019	1/2" SPRING WASHER		04
18	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
19	0571016237	1/2"UNC X2.1" X1.6" FASTENER ASSY		02
20	0521064978	BOX SUPPORT		02

ROW MARKER DISC ASSEMBLY


0501050633




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	52	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01

ROW MARKER DISC

0511053904



Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0511057243	LEFT SHORT SEED ROW FRONT	54	01
02	0511057246	RIGHT LONG SEED ROW FRONT	55	01
03	0511057244	RIGTH SHORT SEED ROW FRONT	56	01
04	0511057247	LEFT LONG SEED ROW FRONT	57	01
05	0511057607	REAR RIGHT ROW SEED	66	01
06	0511057608	REAR LEFT ROW SEED	67	01
07	0521052836	WHEEL SYSTEM DEPTH/COMPACTOR		01
08	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT 75		01
09	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT 76		01
10	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	79	01
11	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	80	01
12	0501058423	FERTILIZER ROD SPRING ROW	83	01
13	0511058212	FERTILIZER ROW SUPPORT ASSY	84	01
14	0502010175	HITCH CLAMP		01
15	0501011543	5/8" X 4" BOLT		01
16	0503012412	5/8" UNC SELF LOCKING NUT		01
17	0501010066	3/4" X 9" BOLT		01
18	0521017831	SUPPORT SLEEVE SPACER		01
19	0511017232	FLAT WASHER		01
20	0503011255	3/4" LOCK NUT		01
21	0503030331	1.2" X 1.2" X 12.2" HOSE		01
22	0503010243	CLAMP		01
23	0503030391	RIGHT FERTILIZER NOZZLE		01
24	0503030392	LEFT FERTILIZER NOZZLE		01
25	0503031050	CURVED CONDUCTOR		01
26	0503010246	CLAMP		01
27	0503031145	2" X 2" X 20" HOSE		01
28	0503031076	2" HOSE CLAMP		01
29	0531013600	PRESS ADJUSTMENT LEVER		01

Item	Code	Description	See page	QT
30	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
31	0501110231	SCARIFIER ROD WITH TIP	85	01
32	0511017969	0.1" SPACING PLATE		01
33	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
34	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
35	0503010025	3/8 SPRING WASHER		01
36	0503010026	3/8" NUT		01
37	0511061852	ADJUSTAMENT CONDUCTOR FERTILIZER		01
38	0521052549	CLAMP	86	01
39	0531050237	3" RIGHT SEED CONDUCTOR FIXER	87	01
40	0521062354	RECEIVER OF SEEDS PNEUMATIC		01
41	0503011953	5/16" X 1" BOLT		01
42	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
43	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
44	0503010337	5/16" NUT		01

LEFT SHORT SEED ROW FRONT


0511057243



Item	Code	Description	See page	QT
01	0521064651	LEFT SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	58	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION HOPPER SEED ROW	59	01
12	0561014904	TRANSMISSION AXLE FRAME ROW		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	60	01
14	0511055260	SEED ROW CHAIN TENSIONER	62	01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521065847	SHORT TIRE SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" SPLIT PIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" SPLIT PIN		01
31	0503034580	TRACTION SPRING		02




Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY	63	01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04



Item	Code	Description	See page	QT
01	0521064652	RH SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	58	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION HOPPER SEED ROW	59	01
12	0561814904	ROW FRAME TRANSMISSION AXLE		01
13	0501052769	BEARING WITH 17Z GEAR	65	01
14	0511055260	SEED ROW CHAIN TENSIONER	62	01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521065847	SHORT TIRE SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" SPLIT PIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" SPLIT PIN		01
31	0503034580	TRACTION SPRING		02




Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY	63	01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04



Item	Code	Description	See page	QT
01	0521064653	RIGH SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	58	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION HOPPER SEED ROW	59	01
12	0561014904	TRANSMISSION AXLE FRAME ROW		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	60	01
14	0511055260	SEED ROW CHAIN TENSIONER	62	01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521065847	SHORT TIRE SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" SPLIT PIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" SPLIT PIN		01
31	0503034580	TRACTION SPRING		02




Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY	63	01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064650	LEFT SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	58	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION HOPPER SEED ROW	59	01
12	0561014904	TRANSMISSION AXLE FRAME ROW		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	60	01
14	0511055260	SEED ROW CHAIN TENSIONER	62	01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521065847	SHORT TIRE SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" SPLIT PIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" SPLIT PIN		01
31	0503034580	TRACTION SPRING		02




Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY	63	01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04



Item	Code	Description	See page	QT
01	0502012718	ROW BEARING		01
02	0503012882	BEARING		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01
17	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0511050617	FRONT SEED ROW BEARING	61	01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0502012819	17Z GEAR WITH HEX HOLE		01

FRONT SEED ROW BEARING


0511050617




Item	Code	Description	See page	QT
01	0502011697	GEARBOX SUPPORT		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511052389	BEARING DOUBLE FRONT ROW SEED	64	01
02	0551017559	BEARING AXLE BODY		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0551017540	5/8" X 73 AXLE HEX		01
05	0501056296	UNIVERSAL JOINT		01
06	0503011855	0.2" X 1.8" SPRING PIN		03
07	0571012412	HEX AXLE		01
08	0561014778	HEX UNIVERSAL JOINT		01
09	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0502011971	HOUSING WITH DOUBLE BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0503010406	501025 CLAMPING RING (FOR AXLE)		01
02	0502011697	GEARBOX SUPPORT		01
03	0503011410	ROLLER BEARING		01
04	0503011105	SEAL RING		01
05	0503011953	5/16" X 1" BOLT		02
06	0501010694	FLAT WASHER		02
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
08	0503010337	5/16" NUT		02
09	0502012819	17Z GEAR WITH HEX HOLE		01



Item	Code	Description	See page	QT
01	0511057606	PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX	68	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	RIGHT DDD	69	01




Item	Code	Description	See page	QT
01	0511057606	PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX	68	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT	72	01




Item	Code	Description	See page	QT
01	0511057502	SET PRECISION PLANTING	70	01
02	0502012807	SUPPORT HOPPER PRECISION PLANTING		01
03	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
04	0503037390	PACKING FOR PLANTING		01
05	0571017899	PIN LOCK		01
06	0503030190	0.5" X 1.6" X 0.05" SPRING		01
07	0571014024	FAST BOLT GUIDE AXLE		02
08	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
09	0502012786	FAST LOCK PRECISION PLANTING		01
10	0511057155	PRECISION PLANTING LEFT TRANSMISSION 71 HOPPER		01
10A	0502050053	RIGHT SIDE TRANSMISSION HOPPER PP		01
10B	0502050052	LEFT SIDE TRANSMISSION HOPPER PP		01
10C	0503033975	24Z GEAR PNEUMATIC		01
10D	0571017898	BODY GEAR TRANSMISSION		01
10E	0503011410	ROLLER BEARING		02
10F	0503033976	GEAR 6Z PNEUMATIC 2014		01
10G	0503011182	6203 ROLLER BEARING		02
10H	0571016187	PINION AXLE 6Z PNEUMATIC		01
10I	0503011184	502040 CLAMPING RING (FOR AXLE)		01
10J	0571017655	FIXER SLEEVE		01
10K	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
10L	0503010144	1/4" NUT		03
11	0571017894	PIN DRAG PRECISION PLANTING		01
12	0503013357	3/8 SELF-ADJUSTING NUT		01
13	0503015752	3/8" X 2" BOLT		01
14	0501013518	FLAT WASHER		02
15	0503015356	SPRING PIN		01
16	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
17	0571017895	PIN FIXER CONDUCTOR P.P		01
18	0503011776	M6 SELF ADJUSTINGNUT		03
19	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02

Item	Code	Description	See page	QT
20	0503010293	CLAMP KNOB		01
21	0503010140	1/8" X 3/4" SPLIT PIN		03
22	0503010131	3/16" X 1.1/2" SPLIT PIN		01
23	0503010025	3/8 SPRING WASHER		01
24	0571011803	PRISONER CLOSE FAST		01
25	0571019491	SLUICE PNEUMATIC		01
26	0501011643	3/8 X 1"BOLT		01
27	0503010209	3/8" UNC BUTTERFLY NUT		01
28	0503012721	1/4" X 4" BOLT		01
29	0503012880	1/4" UNC SELF ADJUSTING NUT		01
30	0571011804	FAST BOLT ADJUSTMENT		01
31	0571019489	CLAMP PRECISION PLANTING		01
32	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
33	0503011855	0.2" X 1.8" SPRING PIN		02
34	0561014778	HEX UNIVERSAL JOINT		01
35	0503013958	1/4" X 1" BOLT		02
36	0503011855	0.2" X 1.8" SPRING PIN		01
37	0503818139	BOLT		03
38	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
39	0503015110	M06 SPRING WASHER		02
40	0501056296	UNIVERSAL JOINT		01
41	0571012452	HEX AXLE		01
42	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC		01
42A	0503062405	SEED DISTRIBUTOR		01
42B	0503062407	SET SOYBEAN DISTRIBUTION		01
42B-01	0503062417	KIT CORN DISTRIBUTION		01
42B-02	0503062471	DISTRIBUTION ASSY (SORGHUM / MILLET)		01
42B-03	0503062577	DISTRIBUTION ASSY (LARGE CORN / SUNFLOWER)		01
42B-04	0503062578	DISTRIBUTION ASSY (LARGE CORN)		01
42B-05	0503062579	DISTRIBUTION ASSY (CORN / SUNFLOWER)		01
42B-06	0503062580	DISTRIBUTION ASSY (POPCORN / COTTON)		01
42B-07	0503062581	DISTRIBUTION ASSY (SMALL CORN / POP CORN)		01
42B-08	0503062573	CONVERSATION SET FOR DISTRIBUTION (LARGE BEAN)		01
42B-09	0503062574	CONVERSATION SET FOR DISTRIBUTION (SMALL BEET)		01
42B-10	0503062564	CONVERSATION SET FOR DISTRIBUTION (SOYBEAN / BEAN)		01
42C	0571019613	STRAW PRECISION PLANTING SHIELD		01



Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	73	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	RIGHT LOW HUB WITH 15 DISC	74	01
04	0503810026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501810984	FLAT WASHER		02
07	0503810751	3/8 UNC X 1.1/4 C S G.5 - SCREW		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012780	SUPPORT DDD RIGHT		01
11	0511815098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0502012807	SUPPORT HOPPER PRECISION PLANTING		01
01A	1902012807	SEED HOPPER SUPPORT		01
02	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
03	0571017899	PIN LOCK		01
04	0503030190	0.5" X 1.6" X 0.05" SPRING		01
05	0571014024	FAST BOLT GUIDE AXLE		02
06	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
07	0581011225	FIXER P PLANTING CONTR CPRA		01
08	0511057155	PRECISION PLANTING LEFT TRANSMISSION 71 HOPPER		01
09	0571017894	PIN DRAG PRECISION PLANTING		01
10	0503013357	3/8 SELF-ADJUSTING NUT		01
11	0503015752	3/8" X 2" BOLT		01
12	0501013518	FLAT WASHER		02
13	0503015356	SPRING PIN		01
14	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
15	0571017895	PIN FIXER CONDUCTOR P.P		01
16	0503011776	M6 SELF ADJUSTINGNUT		03
17	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
18	0503010293	CLAMP KNOB		01
19	0503010140	1/8" X 3/4" SPLIT PIN		03
20	0503010131	3/16" X 1.1/2" SPLIT PIN		01
21	0503010025	3/8 SPRING WASHER		01
22	0503037390	PACKING FOR PLANTING		01
23	0571019491	SLUICE PNEUMATIC		01
24	0501011643	3/8 X 1" BOLT		01
25	0503010209	3/8" UNC BUTTERFLY NUT		01
26	0503012721	1/4" X 4" BOLT		01
27	0503012880	1/4" UNC SELF ADJUSTING NUT		01
28	0581011226	FIXER CLOSING P. PLANTING CONTROL CPRA		01
29	0571019489	CLAMP PRECISION PLANTING		01


SET PRECISION PLANTING

0511057502


Item	Code	Description	See page	QT
30	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
31	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC		01
31A	0503062405	SEED DISTRIBUTOR		01
31B	0503062407	SET SOYBEAN DISTRIBUTION		01
31B-01	0503062417	KIT CORN DISTRIBUTION		01
31B-02	0503062471	DISTRIBUTION ASSY (SORGHUM / MILLET)		01
31B-03	0503062577	DISTRIBUTION ASSY (LARGE CORN / SUNFLOWER)		01
31B-04	0503062578	DISTRIBUTION ASSY (LARGE CORN)		01
31B-05	0503062579	DISTRIBUTION ASSY (CORN / SUNFLOWER)		01
31B-06	0503062580	DISTRIBUTION ASSY (POPCORN / COTTON)		01
31B-07	0503062581	DISTRIBUTION ASSY (SMALL CORN / POP CORN)		01
31B-08	0503062573	CONVERSATION SET FOR DISTRIBUTION (LARGE BEAN)		01
31B-09	0503062574	CONVERSATION SET FOR DISTRIBUTION (SMALL BEET)		01
31B-10	0503062564	CONVERSATION SET FOR DISTRIBUTION (SOYBEAN / BEAN)		01
32	0561014778	HEX UNIVERSAL JOINT		01
33	0503013958	1/4" X 1" BOLT		02
34	0503818139	BOLT		03
35	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
36	0503015110	M06 SPRING WASHER		02




Item	Code	Description	See page	QT
01	0502050052	LEFT SIDE TRANSMISSION HOPPER PP		01
02	0502050053	RIGHT SIDE TRANSMISSION HOPPER PP		01
03	0503011410	ROLLER BEARING		02
04	0503011182	6203 ROLLER BEARING		02
05	0503011184	502040 CLAMPING RING (FOR AXLE)		01
06	0571017655	FIXER SLEEVE		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
08	0503010144	1/4" NUT		03
09	0511057504	JOIN GEAR		01
09A	0571017898	BODY GEAR TRANSMISSION		01
09B	0503011769	M8 X 0.5" BOLT		01
10	0581011222	PINION AXLE 6Z PNEUMATIC		01
11	0503034340	PINION AXLE 6Z PNEUMATIC		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	73	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	RIGHT LOW HUB WITH 15 DISC	74	01
04	0503810026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501810984	FLAT WASHER		02
07	0503810751	3/8 UNC X 1.1/4 C S G.5 - SCREW		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012781	SUPPORT DDD LEFT		01
11	0511815098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O-RING		02
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUBLE DISC AXLE		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	77	01



Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061153	FERTILIZER ROW LONG ARM		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	78	01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	73	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	74	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8 SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511053173	RIGHT LOW HUB WITH 15 DISC	74	01
02	0511053172	LEFT LOW HUB WITH 15 DISC	73	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010025	3/8 SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02

18" COULTER BLADE ASSY FOR SHORT ROW


0511044549



Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0503010003	1845 GREASE FITTING		01
03	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE		01
04	0521014137	RIGHT ARM BLADE DISC		01
05	0521014138	LEFT DISC BLADE ARM		01
06	0521054686	18" DISC BLADE HUB	81	01
07	0503010756	0.2" X 2.4" SPRING PIN		01
08	0503010361	SPRING PIN		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503011255	3/4" LOCK NUT		01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
13	1902020394	SPRING SUPPORT		01
14	1902020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0503010014	3/4" HEX NUT		02
17	0541018684	FLAT WASHER		01
18	0503013185	3/4" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01
21	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0503010003	1845 GREASE FITTING		01
03	0511067044	LONG DISC BLADE FIXING AXIS		01
04	0521014137	RIGHT ARM BLADE DISC		01
05	0521014138	LEFT DISC BLADE ARM		01
06	0521054686	18" DISC BLADE HUB	81	01
07	0503010756	0.2" X 2.4" SPRING PIN		01
08	0503010361	SPRING PIN		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503011255	3/4" LOCK NUT		01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
13	1902020394	SPRING SUPPORT		01
14	1902020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0503010014	3/4" HEX NUT		02
17	0541018684	FLAT WASHER		01
18	0503013185	3/4" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01
21	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0521054679	DISC BLADE HUB	82	01
02	0603026013	PLAIN COULTER BLADE		01

DISC BLADE HUB


0521054679




Item	Code	Description	See page	QT
01	0502011562	DISC BLADE HUB		01
02	0502020641	BLADE DISC FLANGE		01
03	0503010276	6206 BALL BEARING		02
04	0521013610	BLADE DISC HUB AXLE		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
06	0503012417	SEAL		02
07	0503011800	SEAL RING		02
08	0503010691	1/4" GREASE FITTING		01
09	0521015376	DUST CLOAK		02
10	0503030832	FLAT WASHER		02
11	0511015346	FLAT WASHER		02
12	0521013510	3/4" NUT		02
13	0503010012	1" SPRING WASHER		02
14	0503010371	5/16" X 1" BOLT		06
15	0503010337	5/16" NUT		06



Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD		01
02	0502040534	SPRING GUIDE BUSHING LOCK		02
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502012510	SPRING ROD SUPPORT		01
06	0503010257	1/8" X 1" SPLIT PIN		01
07	0501018535	1/2 X 1 BOLT		02
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02
10	1902010891	SPRING CHOCK SUPPORT VARON		01
11	0503010014	3/4" HEX NUT		01
12	0561014471	COUPLING SHAFT		01
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02




Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER ROD		01
02	1902070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01

CLAMP


0521052549



Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01



Item	Code	Description	See page	QT
01	0503013759	NUT		02
02	0501010694	FLAT WASHER		02
03	0502012979	CLAMP 3 RIGHT CSU		02
04	0503010421	5/16" X 1-1/2" BOLT		02



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

