

ROW CROP PLANTERS

PST DUO - FRAME 4880/5340/5950 - CSU

Code: 0501091188
Series: S-0115
Revision: 00
Date Revision: SETEMBRO/2019

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111230129	PST DUO 4880/11E450 D/HDA S-0115
0111230101	PST DUO 4880/11E450 H MH S-0115
0111230125	PST DUO 4880/11E450 HDA CPRA DC20 CSU CEAC S-0115
0111230126	PST DUO 5340/11E500 MH CSU CEAC S-0115
0111230124	PST DUO 5950/13E450 HDA MH DC20 S-0115
0111230116	PST DUO 5950/13E450 MH CSU S-0115
0111230131	PST DUO 5950/13E450 MH DC20 CBR S-0115
0111230127	PST DUO 5950/13E450 MH DC20 CPF S-0115
0111230128	PST DUO 5950/13E450 RAIAD S-0115

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909098654	ASSY FRAME	1
0511056545	CHASSI COM ARTICULATION	2
0511056787	FRAME WHIT ARTICULATION	3
0511058667	SPRING FLOW ENSEMBLY	4
0511056529	CYLINDER ASSY	5
0511058406	HYDRAULIC CYLINDER	6
0511059265	WHEELED WITH SPRING TRACTION WITH TRANSMISSION	7
0511059262	WHEEL SUPPORT ASSY	8
0501058240	WHEEL FASTENER WITH TENSIONER	9
0521043934	CARRYING WHEELS SPRING TRACTION	10
0501059909	CARRYING WHEELS SUPPORT	11
0511048532	WHEELS SPRING WITHOUT TRANSMISSION	12
0501059910	WHEELED SUPPORT WITHOUT TRANSMISSION	13
0521043313	WHEELED WITH SPRING TRACTION WITHOUT TRANSMISSION	14
0511052770	WHEEL WITH TIRE	15
0503062159	WHEEL WITH TIRE	16
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	17
0511054336	SUPPORT WHEELED WITHOUT TRANSMISSION	18
0501058241	WHEEL SUPPORT CHAIN TENSIONER	19
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	20
0501058244	WHEEL FIXED CHAIN TENSIONER	21
0501058242	WHEEL MOBILE CHAIN TENSIONER	22
0521043312	HUB SPINDLE ASSY	23
0521051801	WHEEL WITH TIRE 7.00X16 WHEELED BOX WITHOUT TRANSMISSION	24
0521051800	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	25
0521050851	RIGHT TRANSMISSION ASSY SUPREME PP 5340	26
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	27
0521050183	RIGHT GEAR BOX ASSY	28
0501058212	SEMI MOUNTED RIGHT CHANGE	29
0511059266	CLOSED BEARING	30
0501056271	GEARBOX CLOSED BEARING	31
0501056443	GEAR HOUSING BEARING	32
0501056444	SUPPORT WITH ROLLER BEARING	33
0501048790	AXLE WITH RING	34
0501054655	CHAIN TENSIONER ASSY	35
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	36
0521051266	RIGHT TRANSMISSION 5950	37
0521050185	5950 RIGHT TRANSMISSION ASSEMBLY	38
0501052560	MOTOR AXLE SIGNAL	39
0501058265	STRETCHER LOWER CURRENT 21Z SEED	40
0501058254	UPPER SEED CHAIN TENSIONER	41
0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42
0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43
0521050295	LEFT TRANSMISSION ASSY - 4880	44
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	45
0521050184	EXCHANGE LEFT ASSY	46
0501058213	LH GEAR BOX	47
0521050852	LEFT TRANSMISSION ASSY SUPREME PP 5340	48
0511054363	CHAIN TENSIONER	49
0521051267	LEFT TRANSMISSION	50
0521050186	5950 LEFT TRANSMISSION ASSEMBLY	51
0511056744	SET FERTILIZER SILO	52
0511056747	RH BEAM SUPPORT	53



MARCHESAN

INDEX

0511056748	LH BEAM SUPPORT	54
0511056533	SET FERTILIZER SILO	55
0511056350	RH BEAM SUPPORT PST DUO/F 11E500	56
0511056351	LH BEAM SUPPORT PST DUO/F 11E500	57
0511051741	RH BEAM SUPPORT	58
0511051742	LH BEAM SUPPORT	59
0511056792	SET FERTILIZER SILO	60
0511051932	RH BEAM SUPPORT	61
0511051933	LH BEAM SUPPORT	62
0511056810	SET FERTILIZER SILO	63
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	64
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	65
0511056745	LATFORM SET	66
0511056793	PLATFORM SET	67
0511056534	PLATFORM ASSY	68
0521050259	SET HANDRAIL	69
0521050853	HANDRAIL ASSY	70
0511058734	HANDRAIL SET PST DUO/F 5950 MTH	71
0511056536	LADDER ASSEMBLY	72
0909094295	HEADER ASSY	73
0511054601	HITCH ARTICULATED TRACTOR	74
0511054327	RIGHT TURNBUCKLE	75
0511054328	LEFT TURNBUCKLE	76
0511052311	3 POINT TURNBUCKLE	77
0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	78
0501054694	COMPLETE FLOW DIVIDER VALVE	79
0501053834	MALE QUICK COUPLER	80
0511056532	ASSY SYSTEM HYDRAULIC 5340	81
0511056743	SEMI MOUNTED HYDRAULIC MARKER 4880	82
0511056735	SEMI MOUNTED HYDRAULIC MARKER 5340	83
0511056789	SEMI MOUNTED HYDRAULIC MARKER 5720/5950	84
0511058449	HYDRAULIC CYLINDER	85
0511054971	JACK ASSEMBLY	86
0511057518	ASSY PORT MANUAL INSTRUCCION	87
0511059792	CSU C3 SEMI-ASSEMBLED ASSY 4045/4495 8	88
0511059585	ASSEMBLY CSU C3 SEMI MOUNTED 4880	89
0511059584	2 HOPPERS WITH 10 CONDUCTORS SET	90
0521052687	RIGHT SUPPORT TOWER WITH BOLT	91
0521051931	LEFT SUPPORT TOWER WITH BOLT	92
0521051927	TOWER SUPPORT HOPPER	93
0511059072	ASSEMBLY CSU C3 SEMI MOUNTED 5340	94
0511057919	2 HOPPERS WITH 11 CONDUCTORS SET	95
0511058723	ASSEMBLY CSU C3 SEMI MOUNTED 5950	96
0511058724	2 HOPPERS WITH 12 CONDUCTORS ASSEMBLY	97
0521050006	ASSEMBLY CSU PST DUO/F SUP 5950/13	98
0511058802	2 HOPPERS WITH 13 CONDUCTORS ASSEMBLY	99
0909091818	AXLE ASSEMBLY LEFT	100
0511054682	HEX AXLE ASSEMBLY - 4845	101
0909094322	HEX AXLE ASSEMBLY	102
0909091820	SEED/FERTILIZER ROW ASSY	112
0909098650	SEED/FERTILIZER ROW ASSY CSU	113
0511056554	SHORT SEED ROW FRONT	114
0511056560	SHORT SEED ROW	115
0511056555	LONG SEED ROW FRONT	116
0511056561	LONG SEED ROW	117



MARCHESAN

INDEX

0511058212	FERTILIZER ROW SUPPORT ASSY	118
0511057017	SEED SYSTEM ASSY	119
0511059023	SEED SYSTEM ASSY	120
0501051094	ASSY SEED DISTRIBUTOR	121
0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	122
0511056586	15 X 15 SEED DDD LEFT	123
0521045198	PRESS WHEELS	124
0521042327	DEPTH CONTROL & PRESS WHEEL ASSY	125
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	126
0511058650	SEMI-MOUNTED DEPTH CONTROL	127
0511058652	LEFT DEPTH WHEEL ARM WITH HUB	128
0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	129
0501052627	ASSY DEPTH WHEEL HUB	130
0501052297	DEPTH WHEELS REGULATOR ASSY	131
0501052538	DEPTH BAND WITH ARMS	132
0521044538	DEPTH WHIT REGULACION ANGLE COMPACT CONTROL	133
0511052971	SEMI-ASSEMBLED DEPTH CONTROL WITH THREAD	134
0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	135
0511059325	LEFT ARM COVERED WHEEL ASSEMBLED	136
0511059324	RIGHT ARM COVERED WHEEL ASSEMBLED	137
0511051546	RIGHT DEPTH CONTROL HUB	138
0511051547	LEFT DEPTH CONTROL HUB	139
0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB	140
0501052908	COMPACTOR WHEEL WITH BEARING	141
0511055819	DEPTH BAND WITH RIM	142
0511054333	COMPACT WHEEL RIGHT WITH BEARING	143
0511054334	COMPACT WHEEL LEFT WITH BEARING	144
0511054837	RH IRON PRESS WHEEL	145
0511054838	LH IRON PRESS WHEEL	146
0909091616	RIGHT/LEFT COMPACTOR WHEEL WITH BEARING	147
0511050077	WHEEL STRIPED	148
0511052287	DEPTH WHEEL HUB ASSY	149
0909091821	LONG FERTILIZER LINE RIGHT	150
0909091822	SHORT LINE FERTILIZER LEFT	151
0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	152
0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	153
0511058618	DISC CUT 18 LONG LINE	154
0511056910	HUB WITH 18" DISC BLADE	155
0511056909	DISC BLADE HUB WITHOUT DISC	156
0501058423	FERTILIZER ROD SPRING ROW	157
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	158
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	159
0511053172	LEFT LOW HUB WITH 15 DISC	160
0511053173	RIGHT LOW HUB WITH 15 DISC	161
0511044573	18" COULTER BLADE ASSY FOR LONG ROW	162
0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	163
0909091049	FERTILIZER RUBBER V PRESS WHEEL	164
0511044585	20" COULTER BLADE ASSY FOR LONG ROW	165
0511059410	HDA BC	166
0511052339	CEAC ASSY 13L	167
0909091823	11 LINES TRANSMISSION	168
0909091824	TRANSMISSION 13 LINEAS	169
0909091825	RIGHT / LEFT GEAR BOX ASSY	170
0909093036	SIDE TRANSMISSION DRIVING ASSY	171
0511051434	TRANSMISSION ACTUATOR	172




MARCHESAN

INDEX

0909091826	SET HYDRAULIC SYSTEM		173
0909091827	ROW MARKER		174
0501050633	ROW MARKER DISC ASSEMBLY		175
0909091828	ROW MARKER HYDRAULIC CIRCUIT		176
0501054649	HBM SEQUENTIAL VALVE		177

ASSY FRAME

0909098654




Item	Code	Description	See page	10	11	12	13	15L
01	0511056545	CHASSI COM ARTICULATION	2	01	01	00	00	00
02	0511056737	ARTICULATED FRAME - FRAME 5340		00	00	00	00	01
02.	0511056787	FRAME WHIT ARTICULATION	3	00	00	01	01	00
03	0521064285	LOCK LOWER FRAME		01	01	01	01	01
04	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		01	01	01	01	01
05	0511058667	SPRING FLOW ENSEMBLY	4	01	01	01	01	01
06	0503010002	1800 GREASE FITTING		01	01	01	01	01
07	0503010003	1845 GREASE FITTING		05	05	02	02	02
08	0503010004	1890 GREASE FITTING		02	02	02	02	02
09	0511056529	CYLINDER ASSY	5	01	01	01	01	01
10	0511059265	WHEELED WITH SPRING TRACTION WITH 7 TRANSMISSION		04	04	00	04	04
11	0521043312	HUB SPINDLE ASSY	23	00	00	04	00	00
12	0521043313	WHEELED WITH SPRING TRACTION WITHOUT 14 TRANSMISSION		00	00	00	02	02
13	0521050294	RIGHT TRANSMISSION ASSY - 4880		01	01	00	00	00
13.	0521050851	RIGHT TRANSMISSION ASSY SUPREME PP 5340	26	00	00	01	00	00
13..	0521051266	RIGHT TRANSMISSION 5950	37	00	00	00	01	00
13...	0521050185	5950 RIGHT TRANSMISSION ASSEMBLY	38	00	00	00	00	01
14	0521050295	LEFT TRANSMISSION ASSY - 4880	44	01	01	00	00	00
14.	0521050852	LEFT TRANSMISSION ASSY SUPREME PP 5340	48	00	00	01	00	00
14..	0521051267	LEFT TRANSMISSION	50	00	00	00	01	00
14...	0521050186	5950 LEFT TRANSMISSION ASSEMBLY	51	00	00	00	00	01
15	0511056744	SET FERTILIZER SILO	52	01	01	00	00	00
15.	0511056792	SET FERTILIZER SILO	60	00	00	00	01	01
15..	0511056533	SET FERTILIZER SILO	55	00	00	01	00	00
16	0511056745	LATFORM SET	66	01	01	00	00	00
16.	0511056793	PLATFORM SET	67	00	00	00	01	01
16..	0511056534	PLATFORM ASSY	68	00	00	01	00	00
17	0521050259	SET HANDRAIL	69	01	01	00	00	00
17.	0521050853	HANDRAIL ASSY	70	00	00	01	00	00
17..	0511058734	HANDRAIL SET PST DUO/F 5950 MTH	71	00	00	00	01	01


ASSY FRAME

0909098654


Item	Code	Description	See page	10	11	12	13	15L
18	0511056536	LADDER ASSEMBLY	72	02	02	02	02	02
19	0909094295	HEADER ASSY	73	01	01	01	01	01
20	0501047895	25 ROD STOP		02	02	02	02	02
21	0501047885	30 ROD STOP		02	02	02	02	02
22	0501047886	35 ROD STOP		02	02	02	02	02
23	0501047887	40 ROD STOP		02	02	02	02	02
24	0521013022	TRANSPORT LOCK		02	02	02	02	02
25	0501068994	8,30 X 78 LOCK PIN		02	02	02	02	02
26	0503030168	HITCH PIN CLIP		02	02	02	02	02
27	0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	78	01	01	00	01	01
27.	0511056532	ASSY SYSTEM HYDRAULIC 5340	81	00	00	01	00	00
28	0511056743	SEMI MOUNTED HYDRAULIC MARKER 4880	82	01	01	00	00	00
28.	0511056735	SEMI MOUNTED HYDRAULIC MARKER 5340	83	00	00	01	00	00
28..	0511056789	SEMI MOUNTED HYDRAULIC MARKER 5720/5950	84	00	00	00	01	01
29	0511054971	JACK ASSEMBLY	86	04	04	04	04	04
30	0511057518	ASSY PORT MANUAL INSTRUCCION	87	01	01	01	01	01
31	0511059792	CSU C3 SEMI-ASSEMBLED ASSY 4045/4495 8	88	01	00	00	00	00
32	0511059585	ASSEMBLY CSU C3 SEMI MOUNTED 4880	89	00	01	00	00	00
33	0511059072	ASSEMBLY CSU C3 SEMI MOUNTED 5340	94	00	00	01	00	00
34	0511058723	ASSEMBLY CSU C3 SEMI MOUNTED 5950	96	00	00	00	01	00
35	0521050006	ASSEMBLY CSU PST DUO/F SUP 5950/13	98	00	00	00	00	01
36	0909091820	SEED/FERTILIZER ROW ASSY	112	08	10	11	12	13
37	0501065677	STRUT		02	02	02	02	02
38	0503032624	FERTILIZER HOPPER GUTTER		06	06	06	06	06
39	0501050633	ROW MARKER DISC ASSEMBLY	175	02	02	02	02	02
40	0541015451	FIXED KEY 2.3/8 X 2.3/4		01	01	01	01	01
41	0511054682	HEX AXLE ASSEMBLY - 4845	101	01	01	00	01	00
42	0909094322	HEX AXLE ASSEMBLY	102	00	00	01	00	00
43	0909091818	AXLE ASSEMBLY LEFT	100	00	00	00	00	01
44	0909098654	ASSY FRAME	1	00	00	11	00	13




Item	Code	Description	See page	QT
001	0511056546	RIGHT FRAME WITH WHEEL AXLE - FRAME 4880	01	
002	0511056738	LEFT FRAME WITH WHEEL AXLE - FRAME 4880	01	
003	0501110791	FRONT ARTICULATOR HUB WITH SLEEVES	01	
004	0501110683	REAR HUB ARTICULATOR WITH SLEEVES	01	
005	0503011442	3/4" SPRING WASHER	09	
006	0501010098	3/4" UNC BOLT	09	
007	0571010094	SLEEVE FLANGE	02	
008	0521065616	ARTICULATION	01	
009	0502012698	CLAMP	02	
010	0503011444	SPRING WASHER	02	
011	0571013510	LOCK AXLE	01	
012	0503030085	LOCK PIN	01	
013	0571010095	FLAT WASHER	01	
014	0521063003	LOCK PIN	01	
015	0571010969	LOCK SLEEVE FRAME	01	
016	0503013627	1.1/2 SPRING WASHER	01	
017	0501010110	1.1/2" NUT	01	
018	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN	02	
019	0501018059	3/4" X 2-1/4" BOLT	03	
020	0503011255	3/4" LOCK NUT	03	




Item	Code	Description	See page	QT
001	0511056786	RIGHT FRAME WITH WHEEL AXLE - FRAME 5950	01	
002	0511056785	LEFT FRAME WITH WHEEL AXLE - FRAME 5950	01	
003	0501110791	FRONT ARTICULATOR HUB WITH SLEEVES	01	
004	0501110683	REAR HUB ARTICULATOR WITH SLEEVES	01	
005	0503011442	3/4" SPRING WASHER	09	
006	0501010098	3/4" UNC BOLT	09	
007	0571010094	SLEEVE FLANGE	02	
008	0521065616	ARTICULATION	01	
009	0502012698	CLAMP	02	
010	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN	02	
011	0503011444	SPRING WASHER	02	
012	0571013510	LOCK AXLE	01	
013	0503030085	LOCK PIN	01	
014	0571010095	FLAT WASHER	01	
015	0521063003	LOCK PIN	01	
016	0571010969	LOCK SLEEVE FRAME	01	
017	0503013627	1.1/2 SPRING WASHER	01	
018	0501010110	1.1/2" NUT	01	




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		06
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		12
03	0501012140	FLAT WASHER		24




Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	6	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521012536	COUPLING SHAFT		02
04	0503010523	1/4" X 2" SPLIT PIN		04
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010013	5/8 NUT		02




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCKLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O'RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O'RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0511059262	WHEEL SUPPORT ASSY	8	01
02	0501058240	WHEEL FASTENER WITH TENSIONER	9	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0531062422	WHEEL ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0501058241	WHEEL SUPPORT CHAIN TENSIONER	19	01
07	0511052770	WHEEL WITH TIRE	15	01
08	0503018981	BOLT		02
09	0503010027	5/8 SPRING WASHER		04
10	0591010589	BODY LOCK WHEEL		01
11	0521069983	WHEEL COVER		01
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
13	0551017715	FLAT WASHER		02
14	0503013030	5/8" X 3.1/4" BOLT		01
15	0511050681	TRACTION SPRING		01
15A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
15B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8 NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	20	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	21	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	22	01




Item	Code	Description	See page	QT
01	0501058240	WHEEL FASTENER WITH TENSIONER	9	01
02	0503011119	7/8" X 6" BOLT		04
03	0501014251	FLAT WASHER		04
04	0503011254	7/8" HEX SELF ADJUSTING NUT		04
05	0501059909	CARRYING WHEELS SUPPORT	11	01
06	0503014887	2050 CHAIN X 80 LINK + REDUCTION		01
07	0502010584	CARRYING-WHEELS SUPPORT FIXER		01




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0531016887	CARRYING WHEEL AXLE ARM		01
03	0503010523	1/4" X 2" SPLIT PIN		01
04	0503010003	1845 GREASE FITTING		01
05	0511050681	TRACTION SPRING		01
05A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
05B	0561016062	SPRING HITCH		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8 SPRING WASHER		04
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0511052770	WHEEL WITH TIRE	15	01
11	0501058241	WHEEL SUPPORT CHAIN TENSIONER	19	01
12	0521061565	WHEEL SUPPORT ARM		01
13	0503018981	BOLT		02
14	0521069983	WHEEL COVER		01
15	0591010589	BODY LOCK WHEEL		01




Item	Code	Description	See page	QT
01	0501059910	WHEELED SUPPORT WITHOUT TRANSMISSION	13	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521061565	WHEEL SUPPORT ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511052770	WHEEL WITH TIRE	15	01
07	0521012190	AXLE LOCK		02
08	0503010027	5/8 SPRING WASHER		02
09	0503011167	M16 X 2 X 30 BOLT		02







Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	16	01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	17	01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521061566	CARRYING WHEEL ARM TRACTION		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0503018981	BOLT		02
07	0503010027	5/8 SPRING WASHER		02
08	0521012190	AXLE LOCK		02
09	0521051801	WHEEL WITH TIRE 7.00X16 WHEELED BOX 24 WITHOUT TRANSMISSION		01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01

HUB SPINDLE ASSY


0521043312




Item	Code	Description	See page	QT
01	0511054335	WHEEL SUPPORT ASSY		01
01A	0521061566	CARRYING WHEEL ARM TRACTION		01
01B	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
01C	0531016887	CARRYING WHEEL AXLE ARM		01
01D	0503010523	1/4" X 2" SPLIT PIN		01
01E	0503010003	1845 GREASE FITTING		01
01F	0511050681	TRACTION SPRING		01
01FA	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01FB	0561016062	SPRING HITCH		02
01G	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
01H	0503010027	5/8 SPRING WASHER		01
01I	0503013030	5/8" X 3.1/4" BOLT		01
01J	0551017715	FLAT WASHER		02
01K	0511052770	WHEEL WITH TIRE	15	01
01KA	0503062159	WHEEL WITH TIRE	16	01
01KB	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	17	01
01L	0521012190	AXLE LOCK		02
01M	0503010027	5/8 SPRING WASHER		02
01N	0503011167	M16 X 2 X 30 BOLT		02
01O	0501058241	WHEEL SUPPORT CHAIN TENSIONER	19	01
01P	0501012140	FLAT WASHER		01
02	0501058240	WHEEL FASTENER WITH TENSIONER	9	01
03	0502011308	WHELL FASTENER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01



Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	16	01
02	0521051800	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	25	01




Item	Code	Description	See page	QT
01	0503010328	25590/25523 ROLLER BEARING	02	
02	0503010804	00547-B SEAL	02	
03	0521012185	TRANSMISSION WHEEL AXLE	01	
04	0503010330	KM 9 LOCKNUT	01	
05	0511015949	LOCK NUT	01	
06	0503010329	LOCK WASHER	01	
07	0503010002	1800 GREASE FITTING	01	
08	0501110721	WHEEL HUB WITH SCREW / NUTS	01	
08A	0571012990	CARRYING WHEEL HUB TRANSMISSION	01	
08B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR	06	
08C	0503016516	5/8 UNF CONIC NUT	06	



Item	Code	Description	See page	QT
001	0501110639	BEARING		04
002	0503011099	GREASE FITTING		04
003	0503010300	5/32" X 1" SPLIT PIN		04
004	0551019114	MOTOR BEARING AXLE SUPPORT		02
005	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
006	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
007	0503010019	1/2" SPRING WASHER		04
008	0503010060	1/2 UNC G.5 ZN HEX NUT		04
009	0571017428	MOTOR SHAFT		01
010	0501018466	FLAT WASHER		02
011	0511015961	LOCK BUSHING		02
012	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
013	0503010060	1/2 UNC G.5 ZN HEX NUT		02
014	0501052560	MOTOR AXLE SIGNAL	39	01
014A	0503031825	AXLE MOTOR SLOW-MOVING		02
014B	0503010240	BOLT		02
014C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
014D	0503010337	5/16" NUT		02
015	0511051434	TRANSMISSION ACTUATOR	172	02
016	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	27	01
017	0521050183	RIGHT GEAR BOX ASSY	28	01
018	0501010243	1/2" X 1-1/2" BOLT		03
019	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
020	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
021	0503010019	1/2" SPRING WASHER		05
022	0503012682	1/2" BSW NUT		03
023	0503010060	1/2 UNC G.5 ZN HEX NUT		02
024	0521064449	36Z P1/2 SH 3/4 GEAR		01
025	0503030275	AGRICULTURAL BEARING		01
026	0501010637	FLAT WASHER		02
027	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01


Item	Code	Description	See page	QT
028	0503010025	3/8 SPRING WASHER		01
029	0503010256	3/8" X 3/4" BOLT		01
030	0511054363	CHAIN TENSIONER	49	01
030A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
030B	0503031805	11Z 1/2" GEAR		01
030C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
030D	0503010019	1/2" SPRING WASHER		01
030E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
031	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01
031A	0511062169	21Z P 1/2" GEAR		01
031B	0503011410	ROLLER BEARING		01
031C	0503011105	SEAL RING		01
031D	0531017086	50 AXLETIGHTENER		01
031E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
031F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
031G	0501012140	FLAT WASHER		01
031H	0503010027	5/8 SPRING WASHER		01
031I	0503010013	5/8 NUT		01
032	0501058254	UPPER SEED CHAIN TENSIONER	41	01
032A	0503031805	11Z 1/2" GEAR		01
032B	0503010302	501019 SEAL RING		01
032C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
032D	0503010019	1/2" SPRING WASHER		01
032E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
032F	0521018933	CHAIN TENSIONER AXLE		01
033	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
033A	0511062169	21Z P 1/2" GEAR		01
033B	0503011410	ROLLER BEARING		01
033C	0503011105	SEAL RING		01
033D	0531017086	50 AXLETIGHTENER		01
033E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
033F	0501011234	5/8" X 3" BOLT		01
033G	0503012412	5/8" UNC SELF LOCKING NUT		01
034	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
034A	0511069680	20Z X 28Z DOUBLE GEAR		01
034B	0503011410	ROLLER BEARING		02
034C	0551019175	DOUBLE GEAR AXLE		01
034D	0503010406	501025 CLAMPING RING (FOR AXLE)		01
034E	0503016460	5/8" X 4.1/2" BOLT		01
034F	0503012412	5/8" UNC SELF LOCKING NUT		01
035	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
036	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
037	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
038	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0521017590	GUIDE AXLE		01
03	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
04	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
05	0501019734	FLAT WASHER		02
06	0502010710	RIGHT CAM, SMALLER		02
07	0503010003	1845 GREASE FITTING		02
08	0502012539	26Z P12,7 GEAR		01
09	0501019735	FLAT WASHER		01
10	0521017593	FLAT WASHER		01
11	0503010542	501045 CLAMPING RING (FOR AXLE)		01
12	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01

RIGHT GEAR BOX ASSY


0521050183




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	29	01
02	0511059266	CLOSED BEARING	30	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	32	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	34	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	35	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	36	01
23	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01
30	0511065209	20Z GEAR		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX	01	
02	0502011758	REAR TIGHTENER LEVER	02	
03	0503010292	701164 6 X 40 SPRING PIN	02	
04	0511061794	CHAIN TENSIONER	01	
05	0503031367	SPRING	01	
06	0511060392	CHAIN TENSIONER	01	
07	0503031366	RIGHT TWISTED SPRING	01	




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	31	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	SUPPORT WITH ROLLER BEARING	33	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	GEARBOX SUPPORT		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01



Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011978	CENTRAL BEARING GEARBOX		01
02	0503013462	6005 2RS1 ROLLER BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
001	0501110639	BEARING		04
002	0503011099	GREASE FITTING		04
003	0503010300	5/32" X 1" SPLIT PIN		04
004	0551019114	MOTOR BEARING AXLE SUPPORT		02
005	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
006	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
007	0503010019	1/2" SPRING WASHER		04
008	0503010060	1/2 UNC G.5 ZN HEX NUT		04
009	0571011442	MOTOR SHAFT		01
010	0501018466	FLAT WASHER		02
011	0511015961	LOCK BUSHING		02
012	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
013	0503010060	1/2 UNC G.5 ZN HEX NUT		02
014	0501052560	MOTOR AXLE SIGNAL	39	01
014A	0503031825	AXLE MOTOR SLOW-MOVING		02
014B	0503010240	BOLT		02
014C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
014D	0503010337	5/16" NUT		02
015	0511051434	TRANSMISSION ACTUATOR	172	02
016	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	27	01
017	0521050183	RIGHT GEAR BOX ASSY	28	01
018	0501010243	1/2" X 1-1/2" BOLT		03
019	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
020	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
021	0503010019	1/2" SPRING WASHER		05
022	0503012682	1/2" BSW NUT		03
023	0503010060	1/2 UNC G.5 ZN HEX NUT		02
024	0521064449	36Z P1/2 SH 3/4 GEAR		01
025	0503030275	AGRICULTURAL BEARING		01
026	0501010637	FLAT WASHER		02
027	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01

Item	Code	Description	See page	QT
028	0503010025	3/8 SPRING WASHER		01
029	0503010256	3/8" X 3/4" BOLT		01
030	0511054363	CHAIN TENSIONER	49	01
030A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
030B	0503031805	11Z 1/2" GEAR		01
030C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
030D	0503010019	1/2" SPRING WASHER		01
030E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
031	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01
031A	0511062169	21Z P 1/2" GEAR		01
031B	0503011410	ROLLER BEARING		01
031C	0503011105	SEAL RING		01
031D	0531017086	50 AXLETIGHTENER		01
031E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
031F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
031G	0501012140	FLAT WASHER		01
031H	0503010027	5/8 SPRING WASHER		01
031I	0503010013	5/8 NUT		01
032	0501058254	UPPER SEED CHAIN TENSIONER	41	01
032A	0503031805	11Z 1/2" GEAR		01
032B	0503010302	501019 SEAL RING		01
032C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
032D	0503010019	1/2" SPRING WASHER		01
032E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
032F	0521018933	CHAIN TENSIONER AXLE		01
033	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
033A	0511062169	21Z P 1/2" GEAR		01
033B	0503011410	ROLLER BEARING		01
033C	0503011105	SEAL RING		01
033D	0531017086	50 AXLETIGHTENER		01
033E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
033F	0501011234	5/8" X 3" BOLT		01
033G	0503012412	5/8" UNC SELF LOCKING NUT		01
034	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
034A	0511069680	20Z X 28Z DOUBLE GEAR		01
034B	0503011410	ROLLER BEARING		02
034C	0551019175	DOUBLE GEAR AXLE		01
034D	0503010406	501025 CLAMPING RING (FOR AXLE)		01
034E	0503016460	5/8" X 4.1/2" BOLT		01
034F	0503012412	5/8" UNC SELF LOCKING NUT		01
035	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
036	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0571011442	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPP G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	39	01
15	0511051434	TRANSMISSION ACTUATOR	172	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	27	01
17	0521050183	RIGHT GEAR BOX ASSY	28	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	49	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01


Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
35	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8 SPRING WASHER		01
09	0503010013	5/8 NUT		01




Item	Code	Description	See page	QT
01	0521018933	CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501011234	5/8" X 3" BOLT		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOUBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019175	DOUBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503016460	5/8" X 4.1/2" BOLT		01
06	0503012412	5/8" UNC SELF LOCKING NUT		01



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	39	01
14A	0503031825	AXLE MOTOR SLOW-MOVING		02
14B	0503010240	BOLT		02
14C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
14D	0503010337	5/16" NUT		02
15	0511051434	TRANSMISSION ACTUATOR	172	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	45	01
17	0521050184	EXCHANGE LEFT ASSY	46	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01


Item	Code	Description	See page	QT
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	49	01
30A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
30B	0503031805	11Z 1/2" GEAR		01
30C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
30D	0503010019	1/2" SPRING WASHER		01
30E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01
31A	0511062169	21Z P 1/2" GEAR		01
31B	0503011410	ROLLER BEARING		01
31C	0503011105	SEAL RING		01
31D	0531017086	50 AXLETIGHTENER		01
31E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
31F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
31G	0501012140	FLAT WASHER		01
31H	0503010027	5/8 SPRING WASHER		01
31I	0503010013	5/8 NUT		01
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
32A	0503031805	11Z 1/2" GEAR		01
32B	0503010302	501019 SEAL RING		01
32C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
32D	0503010019	1/2" SPRING WASHER		01
32E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
32F	0521018933	CHAIN TENSIONER AXLE		01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
33A	0511062169	21Z P 1/2" GEAR		01
33B	0503011410	ROLLER BEARING		01
33C	0503011105	SEAL RING		01
33D	0531017086	50 AXLETIGHTENER		01
33E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
33F	0501011234	5/8" X 3" BOLT		01
33G	0503012412	5/8" UNC SELF LOCKING NUT		01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
34A	0511069680	20Z X 28Z DOUBLE GEAR		01
34B	0503011410	ROLLER BEARING		02
34C	0551019175	DOUBLE GEAR AXLE		01
34D	0503010406	501025 CLAMPING RING (FOR AXLE)		01
34E	0503016460	5/8" X 4.1/2" BOLT		01
34F	0503012412	5/8" UNC SELF LOCKING NUT		01
35	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

EXCHANGE LEFT ASSY


0521050184



Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	47	01
02	0511059266	CLOSED BEARING	30	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	32	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	34	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	35	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	36	01
23	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01
30	0511065209	20Z GEAR		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01



Item	Code	Description	See page	QT
001	0501110639	BEARING		04
002	0503011099	GREASE FITTING		04
003	0503010300	5/32" X 1" SPLIT PIN		04
004	0551019114	MOTOR BEARING AXLE SUPPORT		02
005	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
006	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
007	0503010019	1/2" SPRING WASHER		04
008	0503010060	1/2 UNC G.5 ZN HEX NUT		04
009	0571017428	MOTOR SHAFT		01
010	0501018466	FLAT WASHER		02
011	0511015961	LOCK BUSHING		02
012	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
013	0503010060	1/2 UNC G.5 ZN HEX NUT		02
014	0501052560	MOTOR AXLE SIGNAL	39	01
014A	0503031825	AXLE MOTOR SLOW-MOVING		02
014B	0503010240	BOLT		02
014C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
014D	0503010337	5/16" NUT		02
015	0511051434	TRANSMISSION ACTUATOR	172	02
016	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	45	01
017	0521050184	EXCHANGE LEFT ASSY	46	01
018	0501010243	1/2" X 1-1/2" BOLT		03
019	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
020	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
021	0503010019	1/2" SPRING WASHER		05
022	0503012682	1/2" BSW NUT		03
023	0503010060	1/2 UNC G.5 ZN HEX NUT		02
024	0521064449	36Z P1/2 SH 3/4 GEAR		01
025	0503030275	AGRICULTURAL BEARING		01
026	0501010637	FLAT WASHER		02
027	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01


Item	Code	Description	See page	QT
028	0503010025	3/8 SPRING WASHER		01
029	0503010256	3/8" X 3/4" BOLT		01
030	0511054363	CHAIN TENSIONER	49	01
031	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01
031A	0511062169	21Z P 1/2" GEAR		01
031B	0503011410	ROLLER BEARING		01
031C	0503011105	SEAL RING		01
031D	0531017086	50 AXLETIGHTENER		01
031E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
031F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
031G	0501012140	FLAT WASHER		01
031H	0503010027	5/8 SPRING WASHER		01
031I	0503010013	5/8 NUT		01
032	0501058254	UPPER SEED CHAIN TENSIONER	41	01
032A	0503031805	11Z 1/2" GEAR		01
032B	0503010302	501019 SEAL RING		01
032C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
032D	0503010019	1/2" SPRING WASHER		01
032E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
032F	0521018933	CHAIN TENSIONER AXLE		01
033	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
033A	0511062169	21Z P 1/2" GEAR		01
033B	0503011410	ROLLER BEARING		01
033C	0503011105	SEAL RING		01
033D	0531017086	50 AXLETIGHTENER		01
033E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
033F	0501011234	5/8" X 3" BOLT		01
033G	0503012412	5/8" UNC SELF LOCKING NUT		01
034	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
034A	0511069680	20Z X 28Z DOUBLE GEAR		01
034B	0503011410	ROLLER BEARING		02
034C	0551019175	DOUBLE GEAR AXLE		01
034D	0503010406	501025 CLAMPING RING (FOR AXLE)		01
034E	0503016460	5/8" X 4.1/2" BOLT		01
034F	0503012412	5/8" UNC SELF LOCKING NUT		01
035	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
036	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
037	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
038	0503014907	40-1 X 151 CHAIN LINK + MENDING		01



Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01

LEFT TRANSMISSION

0521051267




Item	Code	Description	See page	QT
001	0501110639	BEARING		04
002	0503011099	GREASE FITTING		04
003	0503010300	5/32" X 1" SPLIT PIN		04
004	0551019114	MOTOR BEARING AXLE SUPPORT		02
005	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
006	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
007	0503010019	1/2" SPRING WASHER		04
008	0503010060	1/2 UNC G.5 ZN HEX NUT		04
009	0571011442	MOTOR SHAFT		01
010	0501018466	FLAT WASHER		02
011	0511015961	LOCK BUSHING		02
012	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
013	0503010060	1/2 UNC G.5 ZN HEX NUT		02
014	0501052560	MOTOR AXLE SIGNAL	39	01
014A	0503031825	AXLE MOTOR SLOW-MOVING		02
014B	0503010240	BOLT		02
014C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
014D	0503010337	5/16" NUT		02
015	0511051434	TRANSMISSION ACTUATOR	172	02
016	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	45	01
017	0521050184	EXCHANGE LEFT ASSY	46	01
018	0501010243	1/2" X 1-1/2" BOLT		03
019	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
020	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
021	0503010019	1/2" SPRING WASHER		05
022	0503012682	1/2" BSW NUT		03
023	0503010060	1/2 UNC G.5 ZN HEX NUT		02
024	0521064449	36Z P1/2 SH 3/4 GEAR		01
025	0503030275	AGRICULTURAL BEARING		01
026	0501010637	FLAT WASHER		02
027	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01

LEFT TRANSMISSION


0521051267

Item	Code	Description	See page	QT
028	0503010025	3/8 SPRING WASHER		01
029	0503010256	3/8" X 3/4" BOLT		01
030	0511054363	CHAIN TENSIONER	49	01
030A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
030B	0503031805	11Z 1/2" GEAR		01
030C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
030D	0503010019	1/2" SPRING WASHER		01
030E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
031	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01
031A	0511062169	21Z P 1/2" GEAR		01
031B	0503011410	ROLLER BEARING		01
031C	0503011105	SEAL RING		01
031D	0531017086	50 AXLETIGHTENER		01
031E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
031F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
031G	0501012140	FLAT WASHER		01
031H	0503010027	5/8 SPRING WASHER		01
031I	0503010013	5/8 NUT		01
032	0501058254	UPPER SEED CHAIN TENSIONER	41	01
032A	0503031805	11Z 1/2" GEAR		01
032B	0503010302	501019 SEAL RING		01
032C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
032D	0503010019	1/2" SPRING WASHER		01
032E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
032F	0521018933	CHAIN TENSIONER AXLE		01
033	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
033A	0511062169	21Z P 1/2" GEAR		01
033B	0503011410	ROLLER BEARING		01
033C	0503011105	SEAL RING		01
033D	0531017086	50 AXLETIGHTENER		01
033E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
033F	0501011234	5/8" X 3" BOLT		01
033G	0503012412	5/8" UNC SELF LOCKING NUT		01
034	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
034A	0511069680	20Z X 28Z DOUBLE GEAR		01
034B	0503011410	ROLLER BEARING		02
034C	0551019175	DOUBLE GEAR AXLE		01
034D	0503010406	501025 CLAMPING RING (FOR AXLE)		01
034E	0503016460	5/8" X 4.1/2" BOLT		01
034F	0503012412	5/8" UNC SELF LOCKING NUT		01
035	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
036	0503014907	40-1 X 151 CHAIN LINK + MENDING		01



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0571011442	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPP G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	39	01
15	0511051434	TRANSMISSION ACTUATOR	172	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	45	01
17	0521050184	EXCHANGE LEFT ASSY	46	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	49	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
35	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
001	0511056747	RH BEAM SUPPORT	53	01
002	0511056748	LH BEAM SUPPORT	54	01
003	0503010849	3/8" X 1-1/2" BOLT		12
004	0501010984	10,50 X 27 X 3,00 FLAT WASHER		24
005	0503010025	3/8 SPRING WASHER		12
006	0503010026	3/8" NUT		12
007	0503034396	FERTILIZER SIDE COVER		12
008	0503010362	1/8" X 1.1/4" SPLIT PIN		12
009	0503062169	ASSEMBLED FERTILIZER HOPPER		02
010	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
011	0503010849	3/8" X 1-1/2" BOLT		08
012	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
013	0503010025	3/8 SPRING WASHER		08
014	0503010026	3/8" NUT		08
015	0551019156	GEAR BOX LEVER LOCK		02
016	0503011953	5/16" X 1" BOLT		04
017	0501010694	FLAT WASHER		04
018	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
019	0503010337	5/16" NUT		04
020	0503010847	1/2" X 3.1/4" BOLT		02
021	0551019168	SLEEVE		02
022	0551019160	LEVER		02
023	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
024	0503010019	1/2" SPRING WASHER		02
025	0503010060	1/2 UNC G.5 ZN HEX NUT		02
026	0551019167	SLEEVE UNION		02
027	0511069676	INNER LEVER		02
028	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
029	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
030	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
031	0503010019	1/2" SPRING WASHER		02


SET FERTILIZER SILO

0511056744


Item	Code	Description	See page	QT
032	0503010060	1/2 UNC G.5 ZN HEX NUT		02
033	0501013518	FLAT WASHER		02
034	0503010140	1/8" X 3/4" SPLIT PIN		02
035	0511069678	LH LOWER LEVER		02
036	0503013357	3/8 SELF-ADJUSTING NUT		02
037	0503010140	1/8" X 3/4" SPLIT PIN		04
038	0551019159	LEVER FIXER BODY		02
039	0561016468	FASTENER		02
040	0503011336	1/2" HEX SELF ADJUSTING NUT		04
041	0551019115	LOCKING PLATFORM FIXATION		02
042	0501010096	3/8" X 2" BOLT		02
043	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02



Item	Code	Description	See page	QT
001	0521065561	FERTILIZER BEAN RIGHT SUPPORT		01
002	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	64	04
003	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	65	02
004	0511061759	22Z P12,70 FQ 3/4" GEAR		01
005	0521014167	CONE LOCK		01
006	0503030275	AGRICULTURAL BEARING		06
007	1902010685	18Z CONICAL GEAR		06
008	0521010691	AXLE FASTENER		02
009	0501010694	FLAT WASHER		04
010	0503011441	SPRING WASHER		02
011	0503010144	1/4" NUT		02
012	0501110392	HOPPER SUPPORT BEARING		01
013	0551018055	22,65 X 60 SLEEVE		01
014	0571012299	SQUARE SHAFT		01
015	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
016	0521012485	GEAR BOX BEARING AGRICUTURAL		01
017	0503011953	5/16" X 1" BOLT		02
018	0521011039	FLAT WASHER		02
019	0503011444	SPRING WASHER		02
020	0503010337	5/16" NUT		02
021	0503010003	1845 GREASE FITTING		01
022	0501010942	3/8" X 1-1/4" BOLT		24
023	0503011443	3/8" SPRING WASHER		24
024	0503010026	3/8" NUT		24



Item	Code	Description	See page	QT
001	0521065562	LH FERTILIZER BOX SUPPORT		01
002	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	65	04
003	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	64	02
004	0571012299	SQUARE SHAFT		01
005	0501010942	3/8" X 1-1/4" BOLT		24
006	0503011443	3/8" SPRING WASHER		24
007	0503010026	3/8" NUT		24
008	0511061759	22Z P12,70 FQ 3/4" GEAR		01
009	0521014167	CONE LOCK		01
010	0503030275	AGRICULTURAL BEARING		06
011	1902010685	18Z CONICAL GEAR		06
012	0521010691	AXLE FASTENER		02
013	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
014	0501010694	FLAT WASHER		04
015	0503011441	SPRING WASHER		02
016	0503010144	1/4" NUT		02
017	0501110392	HOPPER SUPPORT BEARING		01
018	0521012485	GEAR BOX BEARING AGRICUTURAL		01
019	0503011953	5/16" X 1" BOLT		02
020	0521011039	FLAT WASHER		02
021	0503011444	SPRING WASHER		02
022	0503010337	5/16" NUT		02
023	0551018055	22,65 X 60 SLEEVE		01
024	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
001	0511056350	RH BEAM SUPPORT PST DUO/F 11E500	56	01
002	0511056351	LH BEAM SUPPORT PST DUO/F 11E500	57	01
003	0503010849	3/8" X 1-1/2" BOLT		12
004	0501010984	10,50 X 27 X 3,00 FLAT WASHER		24
005	0503010025	3/8 SPRING WASHER		12
006	0503010026	3/8" NUT		12
007	0503034396	FERTILIZER SIDE COVER		12
008	0503010362	1/8" X 1.1/4" SPLIT PIN		12
009	0503060642	COVER BOX RIGHT FERTILIZER		02
009.	0503060643	COVER BOX LEFT FERTILIZER		02
010	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
011	0503010849	3/8" X 1-1/2" BOLT		08
012	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
013	0503010025	3/8 SPRING WASHER		08
014	0503010026	3/8" NUT		08
015	0551019156	GEAR BOX LEVER LOCK		02
016	0503011953	5/16" X 1" BOLT		04
017	0501010694	FLAT WASHER		04
018	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
019	0503010337	5/16" NUT		04
020	0503010847	1/2" X 3.1/4" BOLT		02
021	0551019168	SLEEVE		02
022	0551019160	LEVER		02
023	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
024	0503010019	1/2" SPRING WASHER		02
025	0503010060	1/2 UNC G.5 ZN HEX NUT		02
026	0551019167	SLEEVE UNION		02
027	0511069676	INNER LEVER		02
028	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
029	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
030	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02


SET FERTILIZER SILO

0511056533


Item	Code	Description	See page	QT
031	0503010019	1/2" SPRING WASHER		02
032	0503010060	1/2 UNC G.5 ZN HEX NUT		02
033	0501013518	FLAT WASHER		02
034	0503010140	1/8" X 3/4" SPLIT PIN		02
035	0511069678	LH LOWER LEVER		02
036	0503013357	3/8 SELF-ADJUSTING NUT		02
037	0503010140	1/8" X 3/4" SPLIT PIN		04
038	0551019159	LEVER FIXER BODY		02
039	0561016468	FASTENER		02
040	0503011336	1/2" HEX SELF ADJUSTING NUT		04
041	0551019115	LOCKING PLATFORM FIXATION		02
042	0501010096	3/8" X 2" BOLT		02
043	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02




Item	Code	Description	See page	QT
001	0521065374	RH FERTILIZER BEAN SUPPORT PST DUO/F 11E500		01
002	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	64	04
003	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	65	02
004	0511061759	22Z P12,70 FQ 3/4" GEAR		01
005	0521014167	CONE LOCK		01
006	0503030275	AGRICULTURAL BEARING		06
007	1902010685	18Z CONICAL GEAR		06
008	0521010691	AXLE FASTENER		02
009	0501010694	FLAT WASHER		04
010	0503011441	SPRING WASHER		02
011	0503010144	1/4" NUT		02
012	0501110392	HOPPER SUPPORT BEARING		01
013	0551018055	22,65 X 60 SLEEVE		01
014	0571017429	SQUARE SHAFT		01
015	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
016	0521012485	GEAR BOX BEARING AGRICUTURAL		01
017	0503011953	5/16" X 1" BOLT		02
018	0521011039	FLAT WASHER		02
019	0503011444	SPRING WASHER		02
020	0503010337	5/16" NUT		02
021	0503010003	1845 GREASE FITTING		01
022	0501010942	3/8" X 1-1/4" BOLT		24
023	0503011443	3/8" SPRING WASHER		24
024	0503010026	3/8" NUT		24




Item	Code	Description	See page	QT
001	0521065375	LH FERTILIZER BEAM SUPPORT		01
002	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	64	04
003	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	65	02
004	0571017426	HEX AXLE		01
005	0501010942	3/8" X 1-1/4" BOLT		24
006	0503011443	3/8" SPRING WASHER		24
007	0503010026	3/8" NUT		24
008	0511061759	22Z P12,70 FQ 3/4" GEAR		01
009	0521014167	CONE LOCK		01
010	0503030275	AGRICULTURAL BEARING		06
011	1902010685	18Z CONICAL GEAR		06
012	0521010691	AXLE FASTENER		02
013	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
014	0501010694	FLAT WASHER		04
015	0503011441	SPRING WASHER		02
016	0503010144	1/4" NUT		02
017	0501110392	HOPPER SUPPORT BEARING		01
018	0521012485	GEAR BOX BEARING AGRICUTURAL		01
019	0503011953	5/16" X 1" BOLT		02
020	0521011039	FLAT WASHER		02
021	0503011444	SPRING WASHER		02
022	0503010337	5/16" NUT		02
023	0551018055	22,65 X 60 SLEEVE		01
024	0503010003	1845 GREASE FITTING		01



Item	Code	Description	See page	QT
001	0521063405	RH BEAM SUPPORT		01
002	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	64	04
003	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	65	02
004	0501010942	3/8" X 1-1/4" BOLT		24
005	0503011443	3/8" SPRING WASHER		24
006	0503010026	3/8" NUT		24
007	0511061759	22Z P12,70 FQ 3/4" GEAR		01
008	0521014167	CONE LOCK		01
009	0503030275	AGRICULTURAL BEARING		06
010	1902010685	18Z CONICAL GEAR		06
011	0571012299	SQUARE SHAFT		01
012	0521010691	AXLE FASTENER		02
013	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
014	0501010694	FLAT WASHER		02
015	0503011441	SPRING WASHER		02
016	0503010144	1/4" NUT		02
017	0501110392	HOPPER SUPPORT BEARING		01
018	0521012485	GEAR BOX BEARING AGRICUTURAL		01
019	0503011953	5/16" X 1" BOLT		02
020	0501010694	FLAT WASHER		02
021	0521011039	FLAT WASHER		02
022	0503011444	SPRING WASHER		02
023	0503010337	5/16" NUT		02
024	0551018055	22,65 X 60 SLEEVE		01
025	0503010003	1845 GREASE FITTING		01



Item	Code	Description	See page	QT
001	0521063406	LH BEAM SUPPORT		01
002	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	64	02
003	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	65	04
004	0501010942	3/8" X 1-1/4" BOLT		24
005	0503011443	3/8" SPRING WASHER		24
006	0503010026	3/8" NUT		24
007	0511061759	22Z P12,70 FQ 3/4" GEAR		01
008	0521014167	CONE LOCK		01
009	0503030275	AGRICULTURAL BEARING		06
010	1902010685	18Z CONICAL GEAR		06
011	0571012299	SQUARE SHAFT		01
012	0521010691	AXLE FASTENER		02
013	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
014	0501010694	FLAT WASHER		02
015	0503011441	SPRING WASHER		02
016	0503010144	1/4" NUT		02
017	0501110392	HOPPER SUPPORT BEARING		01
018	0521012485	GEAR BOX BEARING AGRICUTURAL		01
019	0503011953	5/16" X 1" BOLT		02
020	0501010694	FLAT WASHER		02
021	0521011039	FLAT WASHER		02
022	0503011444	SPRING WASHER		02
023	0503010337	5/16" NUT		02
024	0551018055	22,65 X 60 SLEEVE		01
025	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
001	0511051932	RH BEAM SUPPORT	61	01
002	0511051933	LH BEAM SUPPORT	62	01
003	0503010849	3/8" X 1-1/2" BOLT		28
004	0501010984	10,50 X 27 X 3,00 FLAT WASHER		60
005	0503010025	3/8 SPRING WASHER		28
006	0503010026	3/8" NUT		28
007	0503062018	ASSEMBLED FERTILIZER HOPPER		02
008	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		02
009	0503010362	1/8" X 1.1/4" SPLIT PIN		14
010	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		08
011	0551019156	GEAR BOX LEVER LOCK		02
012	0503011953	5/16" X 1" BOLT		04
013	0501010694	FLAT WASHER		04
014	0503010847	1/2" X 3.1/4" BOLT		02
015	0551019168	SLEEVE		02
016	0551019160	LEVER		02
017	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
018	0503010060	1/2 UNC G.5 ZN HEX NUT		04
019	0551019167	SLEEVE UNION		02
020	0511069676	INNER LEVER		02
021	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
022	0501013518	FLAT WASHER		02
023	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
024	0503010337	5/16" NUT		04
025	0503010019	1/2" SPRING WASHER		04
026	0503013357	3/8 SELF-ADJUSTING NUT		02
027	0501010096	3/8" X 2" BOLT		02
028	0551019115	LOCKING PLATFORM FIXATION		02
029	0503011336	1/2" HEX SELF ADJUSTING NUT		04
030	0511069679	RH UPPER LEVER		02
031	0503010140	1/8" X 3/4" SPLIT PIN		06


SET FERTILIZER SILO

0511056792


Item	Code	Description	See page	QT
032	0511069678	LH LOWER LEVER		01
033	0511069677	RH LOWER LEVER		01
034	0561016468	FASTENER		02
035	0503034396	FERTILIZER SIDE COVER		14



Item	Code	Description	See page	QT
01	0521063171	RH FERTILIZER BOX SUPPORT		01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	64	04
03	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	65	03
04	0501010942	3/8" X 1-1/4" BOLT		28
05	0503011443	3/8" SPRING WASHER		28
06	0503010026	3/8" NUT		28
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571011428	SQUARE SHAFT		01
09	0501053788	3/4" SQUARE AXLE FASTENER		02
09.	0503010144	1/4" NUT		01
09A	0521010691	AXLE FASTENER		01
09B	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
09C	0511017303	FLAT WASHER		02
09D	0503010143	1/4" SPRING WASHER		01
10	0501110392	HOPPER SUPPORT BEARING		01
11	0521012485	GEAR BOX BEARING AGRICUTURAL		01
12	0503011953	5/16" X 1" BOLT		02
13	0501010694	FLAT WASHER		02
14	0503011444	SPRING WASHER		02
15	0503010337	5/16" NUT		02
16	0551018055	22,65 X 60 SLEEVE		01
17	0503010003	1845 GREASE FITTING		01
18	0521014167	CONE LOCK		01
19	0503030275	AGRICULTURAL BEARING		07
20	0503030303	SUPPORT WASHER		01
21	1902010685	18Z CONICAL GEAR		07



Item	Code	Description	See page	QT
001	0521063172	LH FERTILIZER BOX SUPPORT		01
002	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	64	03
003	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	65	04
004	0501010942	3/8" X 1-1/4" BOLT		28
005	0503011443	3/8" SPRING WASHER		28
006	0503010026	3/8" NUT		28
007	0511061759	22Z P12,70 FQ 3/4" GEAR		01
008	0571011428	SQUARE SHAFT		01
009	0501053788	3/4" SQUARE AXLE FASTENER		02
009A	0521010691	AXLE FASTENER		01
009B	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
009C	0511017303	FLAT WASHER		02
009D	0503010143	1/4" SPRING WASHER		01
009E	0503010144	1/4" NUT		01
010	0501110392	HOPPER SUPPORT BEARING		01
011	0521012485	GEAR BOX BEARING AGRICUTURAL		01
012	0503011953	5/16" X 1" BOLT		02
013	0501010694	FLAT WASHER		02
014	0503011444	SPRING WASHER		02
015	0503010337	5/16" NUT		02
016	0551018055	22,65 X 60 SLEEVE		01
017	0503010003	1845 GREASE FITTING		01
018	0521014167	CONE LOCK		01
019	0503030275	AGRICULTURAL BEARING		07
020	0503030303	SUPPORT WASHER		01
021	1902010685	18Z CONICAL GEAR		07




Item	Code	Description	See page	QT
00	0511056810	SET FERTILIZER SILO	63	01
01	0511053210	RH BEAM SUPPORT		01
01A	0521064031	RH BEAM SUPPORT		01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	64	07
02A	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		07
02B	0501019851	DISTRIBUTOR FERTILIZER AXLE		14
02C	0521010309	SLEEVE INTER		14
02D	0503030275	AGRICULTURAL BEARING		42
02E	0503031164	RIGHT HELICOID CONDUCTOR		07
02F	0501010637	FLAT WASHER		14
02G	0503030303	SUPPORT WASHER		14
02H	0501013774	GREASE SEAL		14
02I	0502011412	18Z CONICAL GEAR		14
02J	0503010523	1/4" X 2" SPLIT PIN		14
02K	0503011962	GREASE FITTING		14
02L	0503010003	1845 GREASE FITTING		14
02M	0503012826	CREASE FITTING		14
03	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	65	07
03A	0501110676	SIDE FERTILIZER DISTRIBUTOR		07
03B	0503031165	LEFT HELICOID CONDUCTOR		07
04	0501010942	3/8" X 1-1/4" BOLT		56
05	0503011443	3/8" SPRING WASHER		56
06	0503010026	3/8" NUT		56
07	0511061759	22Z P12,70 FQ 3/4" GEAR		02
08	0521014167	CONE LOCK		02
09	0502010685	18Z CONICAL GEAR		14
10	0571013742	3/4" X 2920 SQUARE SHAFT		02
11	0521010691	AXLE FASTENER		04
12	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		04
13	0501010694	FLAT WASHER		04
14	0503011441	SPRING WASHER		04


SET FERTILIZER SILO

0511056810


Item	Code	Description	See page	QT
15	0503010144	1/4" NUT		04
16	0501110392	HOPPER SUPPORT BEARING		02
17	0521012485	GEAR BOX BEARING AGRICUTURAL		02
18	0503011953	5/16" X 1" BOLT		08
19	0501010694	FLAT WASHER		08
20	0521011039	FLAT WASHER		04
21	0503011444	SPRING WASHER		04
22	0503010337	5/16" NUT		08
23	0551018055	22,65 X 60 SLEEVE		02
24	0503010003	1845 GREASE FITTING		02
25	0511053211	LH BEAM SUPPORT & METERING		01
25A	0521064032	SILO FERTILIZER SUPPORT WITH DISTRIBUTOR		01
26	0503010849	3/8" X 1-1/2" BOLT		28
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		56
28	0503010025	3/8 SPRING WASHER		28
29	0503010026	3/8" NUT		28
30	0571010590	FERTILIZER SIDE COVER		14
31	0503010362	1/8" X 1.1/4" SPLIT PIN		14
32	0503062169	ASSEMBLED FERTILIZER HOPPER		02
33	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		08
34	0551019156	GEAR BOX LEVER LOCK		02
35	0503011953	5/16" X 1" BOLT		04
36	0501010694	FLAT WASHER		02
37	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
38	0503010337	5/16" NUT		02
39	0503010847	1/2" X 3.1/4" BOLT		06
40	0551019168	SLEEVE		04
41	0551019160	LEVER		04
42	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
43	0503010019	1/2" SPRING WASHER		02
44	0503010060	1/2 UNC G.5 ZN HEX NUT		02
45	0551019167	SLEEVE UNION		04
46	0511069676	INNER LEVER		06
47	0511069677	RH LOWER LEVER		01
48	0511069678	LH LOWER LEVER		01
49	0511069679	RH UPPER LEVER		02
50	0561016468	FASTENER		02
51	0503011336	1/2" HEX SELF ADJUSTING NUT		04
52	0551019115	LOCKING PLATFORM FIXATION		02
53	0501010096	3/8" X 2" BOLT		02
54	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
55	0503013357	3/8 SELF-ADJUSTING NUT		02
56	0503032624	FERTILIZER HOPPER GUTTER		07
57	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		02




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" SPLIT PIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" SPLIT PIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
001	0511069661	PLATFORM SUPPORT PIVOT	04	
002	0503010849	3/8" X 1-1/2" BOLT	08	
003	0501010984	10,50 X 27 X 3,00 FLAT WASHER	16	
004	0503010025	3/8 SPRING WASHER	08	
005	0503010026	3/8" NUT	08	
006	0521062991	RIGHT PLATFORM	01	
007	0521062992	LEFT PLATFORM PST DUO 11/F	01	
008	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
009	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
010	0503011333	COVER FIXER	02	
011	0503010274	5/32" X 2" SPLIT PIN	02	
012	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
013	0502012739	PLATFORM LEFT FIXER SUPPORT	01	
014	0571017990	PLATFORM ENHANCEMENT PROTECTION	01	
015	0501010942	3/8" X 1-1/4" BOLT	02	
016	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
017	0503010025	3/8 SPRING WASHER	02	
018	0503010026	3/8" NUT	02	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT		04
02	0503010849	3/8" X 1-1/2" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		18
04	0503010025	3/8 SPRING WASHER		10
05	0503010026	3/8" NUT		10
06	0521063178	RIGHT PLATFORM		01
07	0521063179	LEFT PLATFORM PST DUO 13/F		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		04
09	0503011333	COVER FIXER		02
10	0503010274	5/32" X 2" SPLIT PIN		02
11	0571017990	PLATFORM ENHANCEMENT PROTECTION		01
12	0501010942	3/8" X 1-1/4" BOLT		02
13	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
14	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
15	0502012739	PLATFORM LEFT FIXER SUPPORT		01




Item	Code	Description	See page	QT
001	0511069661	PLATFORM SUPPORT PIVOT		04
002	0503010849	3/8" X 1-1/2" BOLT		08
003	0501010984	10,50 X 27 X 3,00 FLAT WASHER		18
004	0503010025	3/8 SPRING WASHER		10
005	0503010026	3/8" NUT		10
006	0521065381	RIGHT PLATFORM PST DUO/F 11 E500 S-0614		01
007	0521065382	LEFT PLATFORM PST DUO/F 11 E500 S-0614		01
008	0503011336	1/2" HEX SELF ADJUSTING NUT		04
009	0503011333	COVER FIXER		02
010	0503010274	5/32" X 2" SPLIT PIN		02
011	0571017990	PLATFORM ENHANCEMENT PROTECTION		01
012	0501010942	3/8" X 1-1/4" BOLT		02
013	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
014	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
015	0502012739	PLATFORM LEFT FIXER SUPPORT		01




Item	Code	Description	See page	QT
001	0521062988	HANDRAIL		02
002	0503014007	1/2" X 1-1/4" BOLT		04
003	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
004	0503010905	1/2" X 2-1/4" BOLT		02
005	0503010019	1/2" SPRING WASHER		08
006	0503010060	1/2 UNC G.5 ZN HEX NUT		08
007	0503034094	22 TWISTED CHAIN		02
008	0571017991	CHAIN FIXER HANDRAIL		04
009	0551019884	45 X 50 X 3/8 FASTENER		04
010	0503013357	3/8 SELF-ADJUSTING NUT		08



Item	Code	Description	See page	QT
001	0521065384	HANDRAIL		02
002	0503014007	1/2" X 1-1/4" BOLT		04
003	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
004	0503010905	1/2" X 2-1/4" BOLT		02
005	0503010019	1/2" SPRING WASHER		08
006	0503010060	1/2 UNC G.5 ZN HEX NUT		08
007	0503034094	22 TWISTED CHAIN		02
008	0571017991	CHAIN FIXER HANDRAIL		04
009	0551019884	45 X 50 X 3/8 FASTENER		04
010	0503013357	3/8 SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
001	0521063175	HANDRAIL		02
002	0503014007	1/2" X 1-1/4" BOLT		04
003	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
004	0503010905	1/2" X 2-1/4" BOLT		02
005	0503010019	1/2" SPRING WASHER		08
006	0503010060	1/2 UNC G.5 ZN HEX NUT		08
007	0503034094	22 TWISTED CHAIN		02
008	0571017991	CHAIN FIXER HANDRAIL		04
009	0551019884	45 X 50 X 3/8 FASTENER		04
010	0503013357	3/8 SELF-ADJUSTING NUT		08



Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8 SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
08	0503013357	3/8 SELF-ADJUSTING NUT	02	

HEADER ASSY

0909094295




Item	Code	Description	See page	4880	5340	5950	6850
01	0521065557	CABEÇALHO		001	001	001	001
02	0511054601	HITCH ARTICULATED TRACTOR	74	001	001	001	001
03	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		001	001	001	001
04	0511053179	TRACTOR COUPLING SHAFT		001	001	001	001
04A	0521064036	TRACTOR HITCH AXLE		001	001	001	001
04B	0503030012	HITCH PIN CLIP		001	001	001	001
05	0521063529	LOCK AXLE		001	001	001	001
06	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		001	001	001	001
07	0503010010	1/4" X 2.1/2" SPLIT PIN		001	001	001	001
08	0521063528	EXTENDING FIXER		001	001	001	001
09	0521062916	LEFT FRENCH HAND		001	001	001	001
10	0501010171	BOLT 1 UNC X 3.1/2 C S G.5		002	002	002	002
11	0503010012	1" SPRING WASHER		002	002	002	002
12	0501010059	1.5/8 NUT		002	002	002	002
13	0521010585	0.9" X 5.9" COUPLING SHAFT		001	001	001	001
14	0503030085	LOCK PIN		001	001	001	001
15	0521064203	EAR PIVOT DRAWBAR		001	001	001	001
16	0571010661	PIVOT SHAFT		001	001	001	001
17	0503010010	1/4" X 2.1/2" SPLIT PIN		001	001	001	001
18	0521053311	RIGHT EXTENSOR DRAWBAR 36,00 - 4880/5720/5950	-	001	000	001	000
18.	0521053312	RIGHT EXTENSOR DRAWBAR 36,00 - 5340		000	001	000	000
18..	0521053319	RIGHT EXTENSOR DRAWBAR 36,00 - 6850		000	000	000	001
19	0521053310	LEFT EXTENSION DRAWBAR 36.00 - 4880/5720/5950	-	001	000	001	000
19.	0521053313	LEFT EXTENSION DRAWBAR 36.00 - 5340		000	001	000	000
19..	0521053318	LEFT EXTENSION DRAWBAR 36.00 - 6850		000	000	000	001
20	0501010500	3/4" X 3" BOLT		002	002	002	002
21	0503010023	3/4" SPRING WASHER		002	002	002	002
22	0503010014	3/4" HEX NUT		002	002	002	002
23	0571019949	JUNCTION SHAFT		002	002	002	002
24	0503030119	LOCK PIN		002	002	002	002




HEADER ASSY

0909094295

Item	Code	Description	See page	4880	5340	5950	6850
25	0521010572	0.9" X 2.9" COUPLING SHAFT		001	001	001	001
26	0503030085	LOCK PIN		003	003	003	003
27	0511052311	3 POINT TURNBUCKLE	77	001	001	001	001
28	0521012532	0.9" X 3.9" COUPLING SHAFT		001	001	001	001
29	0521010582	COUPLING SHAFT		001	001	001	001
30	0511056736	HOSE SUPPORT		001	001	001	001




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2" SPLIT PIN		01
10	0503033731	LEFT COMPRESSION SPRING		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521064425	POINT FIXER EXTENDING RIGHT		01
02	0501078990	TURNBUCKLE AXLE		01
03	0561019879	LOCK ATTACHMENT BAR		01
04	0521063917	POINT REVOLVING EXTENDING		01
05	0503010002	1800 GREASE FITTING		02

LEFT TURNBUCKLE


0511054328



Item	Code	Description	See page	QT
01	0521064426	POINT FIXER EXTENDING LEFT		01
02	0501078990	TURNBUCKLE AXLE		01
03	0561019879	LOCK ATTACHMENT BAR		01
04	0521063917	POINT REVOLVING EXTENDING		01
05	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0571012279	JACK RIGHT		01
03	0571012280	JACK LEFT		01
04	0531010264	SIDE RATCHET		02
05	0521018500	SHAFT LEVER EXTENSOR		01
06	0511061881	RATCHET FOLLOWER		01
07	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
08	0503011179	3/8" X 2-1/4" BOLT		05
09	0503010025	3/8 SPRING WASHER		05
10	0503010026	3/8" NUT		05
11	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0571017027	VALVE SUPPORT		01
02	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0501054452	FLOW DIVIDING VALVE		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER	80	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		02
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057089	HOSE KIT SYSTEM HYDRAULIC		01
19A	0501080045	3/8" X 850 TR-TR HOSE		01
19B	0501080999	3/8" X 39" TC-TC HOSE		01
19C	0501081987	HOSE 3/8 X 1550 TR-TC		01
19D	0501081986	HOSE 3/8 X 1550 TC-TC		01
19E	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
19EA	0501080185	HOSE 1/2 X 4000 TR-TM		01
19EB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
19EC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
19ED	0503018952	PLASTIC BOLT		06
19F	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
19FA	0501080185	HOSE 1/2 X 4000 TR-TM		01
19FB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01




PST DUO - FRAME 4880/5340/5950 - CSU
ASSY SYSTEM HYDRAULIC 4880/5720/5950

Page 78
0511056742


Item	Code	Description	See page	QT
19FC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
19FD	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0503012481	FLOW DIVIDING VALVE		01
02	0503030923	3/4" UNF X 13/16UN OFS X 40 NIPPLE		03
03	0503010190	2-114 N 3006-9B O'RING		03




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0571017027	VALVE SUPPORT		01
02	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0501054694	COMPLETE FLOW DIVIDER VALVE	79	01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER	80	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		01
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057104	HOSE KIT SYSTEM HYDRAULIC		01
19A	0501080104	3/8 X 900 TR-TR HOSE		01
19B	0501080963	3/8 X 1050 TC-TC 90G LEFT OSE		01
19C	0501080714	3/8 X 1600 TR-TC HOSE		01
19D	0501081994	3/8 X 1600 TC-TC 180G HOSE		01
20	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
20A	0501080185	HOSE 1/2 X 4000 TR-TM		01
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
20C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
20D	0503018952	PLASTIC BOLT		06
21	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
21A	0501080185	HOSE 1/2 X 4000 TR-TM		01
21B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01

Item	Code	Description	See page	QT
21C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21D	0503018952	PLASTIC BOLT		06
22	0503013100	NYLON CLAMP		02




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	85	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" SPLIT PIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	177	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
23	0503010025	3/8 SPRING WASHER		02
24	0511057090	HYDRAULIC MARKER HAND SET		01
24A	0501081728	HOSE 3/8 X 3100 TR-TR		01
24B	0501080392	3/8 X 3300 TR-TC HOSE		01
24C	0501081988	3/8" X 145.6" TR-TC HOSE		01
24D	0501081682	TC-TC HOSE ASSY		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	80	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8" UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	85	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" SPLIT PIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	177	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
23	0503010025	3/8 SPRING WASHER		02
24	0511057101	HYDRAULIC MARKER HANDLE SET		01
24A	0501081330	HOSE		01
24B	0501081718	HOSE		01
24C	0501081799	HOSE		01
24D	0501081995	HOSE		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	80	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8" UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	85	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" SPLIT PIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	177	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
23	0503010025	3/8 SPRING WASHER		02
24	0511057091	HYDRAULIC MARKER HANDLE SET		01
24A	0501081793	HOSE		01
24B	0501081967	3/8" X 151" TR-TC HOSE		01
24C	0501081996	HOSE		01
24D	0501081997	HOSE		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01


Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	80	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8" UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
001	0503060100	INSTRUCTIONS MANUAL CANISTER		01
002	0511031808	BAG WITH MANUAL		01
003	0503010267	NYLON CLAMP		01
004	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
005	0501010694	FLAT WASHER		01
006	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
007	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0511059790	CSU C3 SET - 02 HOPPERS 06 NOZZLES - 08 CONDUCTORS		01
02	0521066208	HOPPER SUPPORT TOWER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
05	0503010025	3/8 SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0501010453	FLAT WASHER		08
10	0503012412	5/8" UNC SELF LOCKING NUT		08




Item	Code	Description	See page	QT
01	0511059584	2 HOPPERS WITH 10 CONDUCTORS SET	90	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RIGHT SUPPORT TOWER WITH BOLT	91	01
07	0521051931	LEFT SUPPORT TOWER WITH BOLT	92	01
08	0521051927	TOWER SUPPORT HOPPER	93	02




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03	0503010025	3/8 SPRING WASHER		52
04	0503010026	3/8" NUT		52
05	0511057690	3" ARTICULATED SEED CONDUCTOR		10
06	0571015773	SUPPORT SEED		02
07	0501011643	3/8 X 1"BOLT		08
08	0501010942	3/8" X 1-1/4" BOLT		40
09	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		02
10	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		02




Item	Code	Description	See page	QT
01	0521066206	RIGHT HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066207	LEFT HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066208	HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0511057919	2 HOPPERS WITH 11 CONDUCTORS SET	95	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RIGHT SUPPORT TOWER WITH BOLT	91	01
07	0521051931	LEFT SUPPORT TOWER WITH BOLT	92	01
08	0521051927	TOWER SUPPORT HOPPER	93	02




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03	0503010025	3/8 SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	3" ARTICULATED SEED CONDUCTOR		11
06	0571015773	SUPPORT SEED		03
07	0501011643	3/8 X 1"BOLT		12
08	0501010942	3/8" X 1-1/4" BOLT		44
09	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
10	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02




Item	Code	Description	See page	QT
01	0511058724	2 HOPPERS WITH 12 CONDUCTORS ASSEMBLY	97	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521051931	LEFT SUPPORT TOWER WITH BOLT	92	02
07	0521051927	TOWER SUPPORT HOPPER	93	02



Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03	0503010025	3/8 SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	3" ARTICULATED SEED CONDUCTOR		12
06	0571015773	SUPPORT SEED		02
07	0501011643	3/8 X 1"BOLT		08
08	0501010942	3/8" X 1-1/4" BOLT		48
09	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
10	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02




Item	Code	Description	See page	QT
001	0511058802	2 HOPPERS WITH 13 CONDUCTORS ASSEMBLY	99	01
002	0521066208	HOPPER SUPPORT TOWER		04
003	0501010942	3/8" X 1-1/4" BOLT		08
004	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
005	0503010025	3/8 SPRING WASHER		08
006	0503010026	3/8" NUT		08
007	0502010175	HITCH CLAMP		04
008	0501011543	5/8" X 4" BOLT		08
009	0501010453	FLAT WASHER		08
010	0503012412	5/8" UNC SELF LOCKING NUT		08



Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03	0503010025	3/8 SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	3" ARTICULATED SEED CONDUCTOR		13
06	0571015773	SUPPORT SEED		01
07	0501011643	3/8 X 1"BOLT		04
08	0501010942	3/8" X 1-1/4" BOLT		52
09	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
10	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02


Item	Code	Description	See page	QT
001	0571013469	5/8 X 700 HEX AXLE		01
002	0571013470	5/8 X 1100 HEX AXLE		01
003	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE		02
003A	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8		01
003AA	0502011987	DOUBLE HOUSING BEARING		01
003AB	0503011410	ROLLER BEARING		02
003AC	0503011105	SEAL RING		01
003B	0511063106	20Z AXLE BEARING DOUBLE		01
003C	0503010406	501025 CLAMPING RING (FOR AXLE)		02
003D	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
003E	0501010694	FLAT WASHER		04
003F	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
003G	0503010337	5/16" NUT		02
004	0561014215	BEARING COVER LOWER ROW FRAME		02
005	0502040534	SPRING GUIDE BUSHING LOCK		04
006	0503010237	3/8" X 1" BOLT		04




Item	Code	Description	See page	QT
001	0521013430	HEX AXLE 5/8 X 2580		01
002	0521013434	HEX AXLE 5/8 X 2300		01
003	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE		02
003A	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8		01
003AA	0502011987	DOUBLE HOUSING BEARING		01
003AB	0503011410	ROLLER BEARING		02
003AC	0503011105	SEAL RING		01
003B	0511063106	20Z AXLE BEARING DOUBLE		01
003C	0503010406	501025 CLAMPING RING (FOR AXLE)		02
003D	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
003E	0501010694	FLAT WASHER		04
003F	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
003G	0503010337	5/16" NUT		02
004	0561014215	BEARING COVER LOWER ROW FRAME		02
005	0502040534	SPRING GUIDE BUSHING LOCK		04
006	0503010237	3/8" X 1" BOLT		04

HEX AXLE ASSEMBLY


0909094322




Item	Code	Description	See page	QT
001	0561018502	SHAFT AXIS 5/8 X 3000	01	
002	0571011980	5/8 X 2810 HEX AXLE	01	
003	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	02	
003A	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8	01	
003AA	0502011987	DOUBLE HOUSING BEARING	01	
003AB	0503011410	ROLLER BEARING	02	
003AC	0503011105	SEAL RING	01	
003B	0511063106	20Z AXLE BEARING DOUBLE	01	
003C	0503010406	501025 CLAMPING RING (FOR AXLE)	02	
003D	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN	02	
003E	0501010694	FLAT WASHER	04	
003F	0503010179	LOCK WASHER 5/16 ZN 1K01528	02	
003G	0503010337	5/16" NUT	02	
004	0561014215	BEARING COVER LOWER ROW FRAME	02	
005	0502040534	SPRING GUIDE BUSHING LOCK	04	
006	0503010237	3/8" X 1" BOLT	04	




Item	Code	Description	See page	QT
01	0511058786	SHORT SEED LINE		01
02	0511058787	LONG SEED LINE		01
03	0511058796	SHORT LEFT FERTILIZER LINE DDD		01
03.	0511058798	SHORT LEFT FERTILIZER LINE DDD/DC20		01
03..	0511059586	SHORT LEFT FERTILIZER LINE		01
03...	0521051211	SHORT LEFT FERTILIZER LINE DDD DOC20		01
03....	0521050473	SHORT FERTILIZER LINE DPLC17		01
04	0511058797	RIGHT LONG FERTILIZER LINE DDD		01
04.	0511058799	RIGHT LONG FERTILIZER LINE DDD DC20		01
04..	0511059587	RIGHT LONG FERTILIZER LINE		01
04...	0521051212	RIGHT LONG FERTILIZER LINE DOC20		01
04....	0521050474	LONG FERTILIZER LINE DPLC17		01
05	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	126	01
05.	0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	133	01




Item	Code	Description	See page	QT
01	0511056560	SHORT SEED ROW	115	06 07
02	0511056561	LONG SEED ROW	117	05 06
03	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	126	11 13
04	0511053253	FERTILIZER LONG ROW WITH RIGHT DDD/18" DC		05 06
05	0511053252	FERTILIZER SHORT ROW WITH LEFT DDD/18" DC		06 07




Item	Code	Description	See page	QT
01	0511056600	RIGHT DDD SHORT SEED ROW FRONT		01
02	0511058212	FERTILIZER ROW SUPPORT ASSY	118	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0511060376	SEED SPRING GUIDE		01
06	0502012538	SPRING VARON SUPPORT		01
07	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
09	0503011336	1/2" HEX SELF ADJUSTING NUT		02
10	0521010542	COUPLING SHAFT		01
11	0503010257	1/8" X 1" SPLIT PIN		01
12	0502040534	SPRING GUIDE BUSHING LOCK		02
13	0501018535	1/2 X 1 BOLT		02
14	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
15	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
16	0501013753	FLAT WASHER		01
17	0503010013	5/8 NUT		01
18	0511052024	FAST CLOSING SET		01
19	0511057017	SEED SYSTEM ASSY	119	01
20	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
22	0503010019	1/2" SPRING WASHER		01
23	0503010060	1/2 UNC G.5 ZN HEX NUT		01
24	0503011099	GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511056600	RIGHT DDD SHORT SEED ROW FRONT		01
02	0511058212	FERTILIZER ROW SUPPORT ASSY	118	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0511060376	SEED SPRING GUIDE		01
06	0521010542	COUPLING SHAFT		01
07	0503010257	1/8" X 1" SPLIT PIN		01
08	0502040534	SPRING GUIDE BUSHING LOCK		01
09	0501018535	1/2 X 1 BOLT		02
10	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
11	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
12	0502040534	SPRING GUIDE BUSHING LOCK		01
13	0501013753	FLAT WASHER		01
14	0501018535	1/2 X 1 BOLT		01
15	0503010013	5/8 NUT		01
16	0511052024	FAST CLOSING SET		01
17	0511059023	SEED SYSTEM ASSY	120	01
18	0503011099	GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511056601	LONG SEED ROW FRONT DDD LEFT		01
02	0511058212	FERTILIZER ROW SUPPORT ASSY	118	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8\" UNC SELF LOCKING NUT		02
05	0511060376	SEED SPRING GUIDE		01
06	0502012538	SPRING VARON SUPPORT		01
07	0521014021	1/2\" X 4.5\" X 5.4\" FASTENER		01
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
09	0503011336	1/2\" HEX SELF ADJUSTING NUT		02
10	0521010542	COUPLING SHAFT		01
11	0503010257	1/8\" X 1\" SPLIT PIN		01
12	0502040534	SPRING GUIDE BUSHING LOCK		02
13	0501018535	1/2 X 1 BOLT		02
14	0503031340	1.7\"X 19\" X 0.3\" COMPRESSION SPRING		01
15	0503031339	1\" X 19\" X 0.1\" COMPRESSION SPRING		01
16	0501013753	FLAT WASHER		01
17	0503010013	5/8 NUT		01
18	0511052024	FAST CLOSING SET		01
19	0511057017	SEED SYSTEM ASSY	119	01
20	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
22	0503010019	1/2\" SPRING WASHER		01
23	0503010060	1/2 UNC G.5 ZN HEX NUT		01
24	0503011099	GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511056601	LONG SEED ROW FRONT DDD LEFT		01
02	0511058212	FERTILIZER ROW SUPPORT ASSY	118	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0511060376	SEED SPRING GUIDE		01
06	0521010542	COUPLING SHAFT		01
07	0503010257	1/8" X 1" SPLIT PIN		01
08	0502040534	SPRING GUIDE BUSHING LOCK		01
09	0501018535	1/2 X 1 BOLT		02
10	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
11	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
12	0502040534	SPRING GUIDE BUSHING LOCK		01
13	0501013753	FLAT WASHER		01
14	0501018535	1/2 X 1 BOLT		01
15	0503010013	5/8 NUT		01
16	0511052024	FAST CLOSING SET		01
17	0511059023	SEED SYSTEM ASSY	120	01
18	0503011099	GREASE FITTING		02




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02




Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016219	RING TO SOYBEANS		01
03	0503010025	3/8 SPRING WASHER		04
04	0503010209	3/8" UNC BUTTERFLY NUT		03
05	0503016283	M8 NUT HEX		01
06	0502020693	SUPPORT SEED BOX		01
07	0502012721	SEED DISC LOWER TRAIL		01
08	0503030083	3/8" X 3/8" X 1.6" STUD		02
09	0503016282	ALLEN BOLT		01
10	0503010675	5/16" X 2.1/4" BOLT		01
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
12	0503010337	5/16" NUT		01
13	0501010694	FLAT WASHER		04
14	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
15	0501051094	ASSY SEED DISTRIBUTOR	121	01
16	0503031508	COVER GREEN BEAM SEED YELLOW		01
17	0571018536	HEX PRISONER		01
18	0501013518	FLAT WASHER		02
19	0503034131	DEFLECTOR		01




Item	Code	Description	See page	QT
01	0502020693	SUPPORT SEED BOX		01
02	0502012721	SEED DISC LOWER TRAIL		01
03	0503034131	DEFLECTOR		01
04	0503010025	3/8 SPRING WASHER		03
05	0503010209	3/8" UNC BUTTERFLY NUT		03
06	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
07	0571018536	HEX PRISONER		01
08	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
09	0503010337	5/16" NUT		01
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
11	0503062582	DEPOSIT SEED		01
12	0581011346	ADAPTER DEPOSIT		01
13	0501010694	FLAT WASHER		04
14	0503016282	ALLEN BOLT		01
15	0503016283	M8 NUT HEX		01
16	0501051094	ASSY SEED DISTRIBUTOR	121	01
17	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
18	0503016219	RING TO SOYBEANS		01
19	0503010675	5/16" X 2.1/4" BOLT		01
20	0503030083	3/8" X 3/8" X 1.6" STUD		02




Item	Code	Description	See page	QT
01	0503030381	SEED DISTRIBUTOR BOX		01
02	0502010447	TRIGGER		02
03	0501013467	KEY AXLE		01
04	0503030378	0.4" X 1.1" X 0.03" SPRING		03
05	0501013466	KEY LIMITER AXLE		01
06	0501051119	DOUBLE PULLEY ROCKER'S		01
07	0501013468	ROCKER ARM AXLE, OF THE PULLEY		01
08	0503030377	SCRAPER		01



Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT		01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	161	01
03	0511053172	LEFT LOW HUB WITH 15 DISC	160	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O-RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02



Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE		01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	161	01
03	0511053172	LEFT LOW HUB WITH 15 DISC	160	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511056691	CONTROL DEPTH SUPPORT		01
01A	0502012282	DEPTH CONTROL SUPPORT		01
02	0571016886	DEPTH WHEEL AXLE		01
03	0503810256	SCREW		01
04	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
05	0503033942	COMPACTOR WHEEL REGULATOR LID		01
06	0521064073	REGULACION WHEEL COMPACTOR		01
07	0511056692	DEPTH WHEEL RIGHT ARM		01
07A	0501110796	DEPTH CONTROL RIGHT ARM		01
07Aa	0502012769	DEPTH WHEEL RIGHT ARM		01
07Ab	0571016883	36,04 X 25,62 X 85 NYLON SLEEVE		01
07B	0501052627	ASSY DEPTH WHEEL HUB	130	02
07Ba	0502011907	DEPTH CONTROL WHEEL HUB		02
07Bb	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		02
07Bc	0503010269	6204 BALL BEARING		04
07Bd	0501013636	SPACING SLEEVE		02
07Be	0503010689	SEAL 00763-BR		02
07Bf	0503011105	SEAL RING		02
07Bg	0503010878	5/8" SELF ALIGNING NUT		02
07Bh	0521019178	PROTECTION LID		02
07bi	0503030757	2.9" X 2" X 0.02" JOINT		02
07Bj	0503014729	1/4" UNF X 1/2" BOLT		06
07Bk	0503011441	SPRING WASHER		06
07Bl	0503010691	1/4" GREASE FITTING		02
07C	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07D	0503011440	SPRING WASHER		02
07E	0503010060	1/2 UNC G.5 ZN HEX NUT		02
07F	0503010002	1800 GREASE FITTING		02
08	0511056693	LH ARM DEPTH CONTROL WHEEL		01
08A	0501110797	LEFT ARM WITH SLEEVE		01
08Aa	0502012770	DEPTH WHEEL LEFT ARM		01


PRESS WHEELS

0521045198


Item	Code	Description	See page	QT
08Ab	0571016883	36,04 X 25,62 X 85 NYLON SLEEVE		01
09	0571017749	FLAT WASHER		02
10	0503011440	SPRING WASHER		02
11	0503010311	1/2" X 1-1/4" BOLT		02
12	0501052297	DEPTH WHEELS REGULATOR ASSY	131	01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010257	1/8" X 1" SPLIT PIN		01
15	0502012116	PRESS WHEEL ADJUSTER		01
16	0503010849	3/8" X 1-1/2" BOLT		02
17	0503011443	3/8" SPRING WASHER		02
18	0503010026	3/8" NUT		02
19	0541016906	PRESS WHEELS REGULATOR BODY		01
20	0521010539	0.3" X 1.2" COUPLING SHAFT		01
21	0503010140	1/8" X 3/4" SPLIT PIN		01
22	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
23	0501052538	DEPTH BAND WITH ARMS	132	02
24	0503010358	5/16" X 5/8" BOLT		08
25	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
26	0503013816	5/16" LOCKNUT		08
27	0511054333	COMPACT WHEEL RIGHT WITH BEARING	143	01
28	0511054334	COMPACT WHEEL LEFT WITH BEARING	144	01




Item	Code	Description	See page	QT
01	0511053550	DEPTH CONTROL ASSY		01
02	0511050077	WHEEL STRIPED	148	02
03	0511054333	COMPACT WHEEL RIGHT WITH BEARING	143	01
04	0511054334	COMPACT WHEEL LEFT WITH BEARING	144	01
05	0503033942	COMPACTOR WHEEL REGULATOR LID		01




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	127	01
02	0501052538	DEPTH BAND WITH ARMS	132	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	143	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	144	01
07	0503033942	COMPACTOR WHEEL REGULATOR LID		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT DEPTH WHEEL ARM WITH HUB	128	01
07	0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	129	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	131	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" SPLIT PIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	3/8 UNC X 3/4 BOLT		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL HUB	130	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL HUB	130	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	PROTECTION LID		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" SPLIT PIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0511052971	SEMI-ASSEMBLED DEPTH CONTROL WITH THREAD	134	01
02	0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	135	01
03	0501052908	COMPACTOR WHEEL WITH BEARING	141	02
04	0503010019	1/2" SPRING WASHER		06
05	0503010752	1/2" X 3.1/2" BOLT		01
06	0503013739	1/2" X 1" BOLT		01
07	0503010479	BOLT		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503030012	HITCH PIN CLIP		01
10	0571013222	FIXING CHOCK		01
11	0503010741	1/2" X 2-3/4" BOLT		02
12	0511055819	DEPTH BAND WITH RIM	142	02
13	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
14	0503013816	5/16" LOCKNUT		08




Item	Code	Description	See page	QT
01	0521063808	DEPTH CONTROL INNER COLUMN CONTROL WITH SCREW		01
02	0521063809	DEPTH CONTROL EXTERNAL COLUMN CONTROL WITH SCREW		01
03	0571013194	REGULATOR SPINDLE		01
04	0551010616	ROD HEX		01
05	0503010683	0,2" X 1,2" SPRING PIN		01
06	0571013202	COVERING WHEEL REGULATOR AXLE		01
07	0521063812	REGULATOR LEVER ALXE		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		01
09	0511065308	LOCK REGULATOR		01
10	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
11	0541011627	FLAT WASHER		01
12	0503010140	1/8" X 3/4" SPLIT PIN		01
13	0511059325	LEFT ARM COVERED WHEEL ASSEMBLED	136	01
14	0511059324	RIGHT ARM COVERED WHEEL ASSEMBLED	137	01
15	0571014709	SLEEVE LOCK CONTROL ARM		02
16	0503011440	SPRING WASHER		03
17	0503819099	BOLT		02
18	0511051546	RIGHT DEPTH CONTROL HUB	138	01
19	0511051547	LEFT DEPTH CONTROL HUB	139	01
20	0503011442	3/4" SPRING WASHER		02
21	0571013189	SLEEVE SUPPORT BEATER		01
22	0521063813	WHEEL PRESS BEATER		01
23	0501010937	13,50 X 28 X 3,00 FLAT WASHER		01
24	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		01




Item	Code	Description	See page	QT
01	0502012850	PRESS WHEELS ARM	01	01
02	0503030883	RIGHT TORSION SPRING	01	01
03	0502011066	PRESS WHEELS ARM SUPPORT	01	01
04	0531017415	1" X 4.72" AXLE JOINT	01	01
05	0503010839	03"X 0.6" SPRING PIN	01	01
06	0521063841	REGULATOR RIGHT COMPACTOR	01	01
07	0521063842	REGULATOR LEFT COMPACTOR	01	01
08	0503811404	BOLT	02	02
09	0503011443	3/8" SPRING WASHER	02	02
10	0503010026	3/8" NUT	02	02
11	0571013295	ALXE REGULATOR COMPACTOR	01	01
12	0521063812	REGULATOR LEVER ALXE	01	01
13	0503011336	1/2" HEX SELF ADJUSTING NUT	02	02
14	0511065308	LOCK REGULATOR	01	01
15	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING	01	01
16	0541011627	FLAT WASHER	01	01
17	0503010140	1/8" X 3/4" SPLIT PIN	01	01
18	0571013293	SLEEVE LOCK COMPACTOR V CONTROL WITH SCREW	01	01
19	0503811172	BOLT	01	01
20	0503010002	1800 GREASE FITTING	01	01
21	0581013744	PROTECTION CASE	01	01
22	0503813096	BOLT	01	01
23	0503013816	5/16" LOCKNUT	0	0




Item	Code	Description	See page	QT
01	0502012844	LEFT ARM WHEELS		01
02	0581011340	ARM CASE		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	COVERING WHEEL ARM SUPPORT SLEEVE		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012843	RIGHT WHEEL ARM		01
02	0581011340	ARM CASE		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	COVERING WHEEL ARM SUPPORT SLEEVE		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB	140	01
02	0511066638	RIGHT AXLE WITH DUST CLOAK		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	PROTECTION LID		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB	140	01
02	0511066637	LEFT AXLE WITH DUST CLOAK		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	PROTECTION LID		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0502011907	DEPTH CONTROL WHEEL HUB		01
02	0503010269	6204 BALL BEARING		02
03	0501013636	SPACING SLEEVE		01
04	0503010689	SEAL 00763-BR		01
05	0503011105	SEAL RING		01
06	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503013758	1/4" X 1-1/2" BOLT		05
04	0503013814	1/4" NC LOCKNUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	141	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	141	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0501052957	IRON V PRESS WHEELS		01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		05
04	0503012136	NUT 1/2 NF		01



Item	Code	Description	See page	QT
01	0501052957	IRON V PRESS WHEELS		01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		05
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	DIR	ESQ
01	0511054333	COMPACT WHEEL RIGHT WITH BEARING	143	01	00
02	0511054334	COMPACT WHEEL LEFT WITH BEARING	144	00	01
03	0501052908	COMPACTOR WHEEL WITH BEARING	141	01	01
03A	0502011919	PRESS WHEEL HUB		01	01
03B	0502011877	PRESS WHEEL HUB		01	01
03C	0503010269	6204 BALL BEARING		02	02
03D	0521018922	PRESS WHEEL PASSANG AXLE		02	02
03E	0503012734	SEAL 01556 BR		02	02
03F	0521018921	DUST CLOAK		02	02
03G	0503010691	1/4" GREASE FITTING		01	01
03H	0521018928	PRESS WHEEL RIM		02	02
03I	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01	01
03J	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06	06
03K	0503010179	LOCK WASHER 5/16 ZN 1K01528		09	09
03L	0503010337	5/16" NUT		06	06
03M	0503010371	5/16" X 1" BOLT		03	03
03N	0503013816	5/16" LOCKNUT		03	03
04	0503016449	1/2 X 4 BOLT		01	00
05	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		00	01
06	0521014508	FLAT WASHER		03	03
07	0503012136	NUT 1/2 NF		01	00
08	0503016864	LH 1/2" LOCK NUT		00	01




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	149	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
07	0503010337	5/16" NUT		06

DEPTH WHEEL HUB ASSY


0511052287




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEEL HUB		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	153	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		02
06	0511058618	DISC CUT 18 LONG LINE	154	01
07	0501058423	FERTILIZER ROD SPRING ROW	157	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02
11	0503031050	CURVED CONDUCTOR		01
12	0503010246	CLAMP		01
13	0511061769	RIGHT FERTILIZER CONDUCTOR WITH REGULATOR		01
14	0501110231	SCARIFIER ROD WITH TIP		01
15	0511017969	0.1" SPACING PLATE		02
16	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
17	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
18	0503010025	3/8 SPRING WASHER		02
19	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT 152	152	01
02	0501010066	DOUBLE DISC		01
03	0521017831	3/4" X 9" BOLT		02
04	0511017232	SUPPORT SLEEVE SPACER		02
05	0503011255	FLAT WASHER		02
06	0503011255	3/4" LOCK NUT		02
07	0511058617	DISC CUT 18 SHORT LINE		01
08	0501058423	FERTILIZER ROD SPRING ROW	157	01
09	0503030392	LEFT FERTILIZER NOZZLE		01
10	0503031145	2" X 2" X 20" HOSE		01
11	0503031076	2" HOSE CLAMP		02
12	0503031050	CURVED CONDUCTOR		01
13	0503010246	CLAMP		01
14	0511061770	LEFT CONDUCTOR FERTILIZER WITH REGULATOR		01
15	0501110231	SCARIFIER ROD WITH TIP		01
16	0511017969	0.1" SPACING PLATE		02
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
18	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
19	0503010025	3/8 SPRING WASHER		02
19	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	158	01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061153	FERTILIZER ROW LONG ARM		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	159	01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0503010003	1845 GREASE FITTING		01
03	0571019976	LEFT BRACELET CUTTING DISC		01
04	0503011411	1/2" X 5-1/2" BOLT		01
05	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
06	0503011440	SPRING WASHER		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01
08	0502020394	SPRING SUPPORT		01
09	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
10	0502020393	SPRING UPPER SUPPORT		01
11	0521010452	SLEEVE		01
12	0503013185	3/4" X 5-1/2" BOLT		01
13	0501067323	SPRING REGULATOR		01
14	0511056910	HUB WITH 18" DISC BLADE	155	01
15	0502012824	DISC BLADE FIXED AXLE		01
16	0503011255	3/4" LOCK NUT		02
17	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
18	0581011111	THRUST WASHER		01
19	0503034319	LOCK PIN		01




Item	Code	Description	See page	QT
01	0511056909	DISC BLADE HUB WITHOUT DISC	156	01
02	0603026013	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0502012793	DISC HUB		01
02	0571018047	DISC BLADE HUB AXLE		01
03	0503017755	NUT		01
04	0502020641	BLADE DISC FLANGE		01
05	0503013816	5/16" LOCKNUT		06
06	0571018048	BACKREST WASHER		02
07	0521065882	NILOS SEALING RING		02
08	0571018049	DUST CLOAK		02
09	0581010575	7/8" X 145 BOLT		01
10	0503018825	5/16 UNC UNC BOLT		06
11	0501010694	FLAT WASHER		06
12	0503016061	BEARING		02
13	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD		01
02	0502040534	SPRING GUIDE BUSHING LOCK		02
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502012510	SPRING ROD SUPPORT		01
06	0503010257	1/8" X 1" SPLIT PIN		01
07	0501018535	1/2 X 1 BOLT		02
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02
10	1902010891	SPRING CHOCK SUPPORT VARON		01
11	0503010014	3/4" HEX NUT		01
12	0561014471	COUPLING SHAFT		01
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	160	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	161	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8 SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511053173	RIGHT LOW HUB WITH 15 DISC	161	01
02	0511053172	LEFT LOW HUB WITH 15 DISC	160	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010025	3/8 SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUBLE DISC AXLE		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01



Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	
02	0503010003	1845 GREASE FITTING	01	
03	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE	01	
04	0521014137	RIGHT ARM BLADE DISC	01	
05	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
06	0521054686	18" DISC BLADE HUB	01	
07	0503010756	0.2" X 2.4" SPRING PIN	01	
08	0503010361	SPRING PIN	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503011255	3/4" LOCK NUT	01	
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
13	1902020394	SPRING SUPPORT	01	
14	1902020393	SPRING UPPER SUPPORT	01	
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
16	0503010014	3/4" HEX NUT	02	
17	0541018684	FLAT WASHER	01	
18	0503013185	3/4" X 5-1/2" BOLT	01	
19	0503010019	1/2" SPRING WASHER	01	
20	0503010060	1/2 UNC G.5 ZN HEX NUT	01	
21	0503011411	1/2" X 5-1/2" BOLT	01	




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	
02	0503010003	1845 GREASE FITTING	01	
03	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01	
04	0521014137	RIGHT ARM BLADE DISC	01	
05	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
06	0521054686	18" DISC BLADE HUB	01	
07	0503010756	0.2" X 2.4" SPRING PIN	01	
08	0503010361	SPRING PIN	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503011255	3/4" LOCK NUT	01	
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
13	1902020394	SPRING SUPPORT	01	
14	1902020393	SPRING UPPER SUPPORT	01	
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
16	0503010014	3/4" HEX NUT	02	
17	0541018684	FLAT WASHER	01	
18	0503013185	3/4" X 5-1/2" BOLT	01	
19	0503010019	1/2" SPRING WASHER	01	
20	0503010060	1/2 UNC G.5 ZN HEX NUT	01	
21	0503011411	1/2" X 5-1/2" BOLT	01	




Item	Code	Description	See page	QT
00	0501052936	COVERING WHEEL FERTILIZER V RIGHT RUBBER		01
00A	0501052937	COVERING WHEEL FERTILIZER V LEFT RUBBER		01
01	0511062081	RH SUPPORT		01
02	0511062082	LH SUPPORT		01
03	0511064765	SMALLER WHEEL PRESS FERTILIZER ARM		01
04	0521019067	0.9" X 2.5" COUPLING SHAFT		01
05	0503010571	1/4" X 1.1/2" SPLIT PIN		01
06	0503010002	1800 GREASE FITTING		01
07	0511062095	TENSIONER SPRING		01
08	0503010013	5/8 NUT		01
09	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
10	0502011757	PRESS REGULATOR		01
11	0503010849	3/8" X 1-1/2" BOLT		02
12	0503010025	3/8 SPRING WASHER		02
13	0503010026	3/8" NUT		02
14	0501052908	COMPACTOR WHEEL WITH BEARING	141	02
14A	0502011919	PRESS WHEEL HUB		01
14Aa	0502011877	PRESS WHEEL HUB		01
14B	0521018922	PRESS WHEEL PASSANG AXLE		02
14C	0521018921	DUST CLOAK		01
14D	0521016316	DUST CLOAK		01
14E	0503012734	SEAL 01556 BR		02
14F	0503010269	6204 BALL BEARING		02
14G	0521018928	PRESS WHEEL RIM		02
14H	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
14I	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
14J	0503010179	LOCK WASHER 5/16 ZN 1K01528		09
14K	0503010337	5/16" NUT		06
14L	0503010178	5/16" X 7/8" BOLT		03
14M	0503010691	1/4" GREASE FITTING		01
15	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02




Item	Code	Description	See page	QT
16	0521014508	FLAT WASHER		02
17	0503010060	1/2 UNC G.5 ZN HEX NUT		02



Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	01
02	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE	01	01
03	0541018684	FLAT WASHER	01	01
04	0503010756	0.2" X 2.4" SPRING PIN	01	01
05	0503010361	SPRING PIN	01	01
06	0503010003	1845 GREASE FITTING	01	01
07	0521014137	RIGHT ARM BLADE DISC	01	01
08	0521014138	SUPPORT ARM LEFT BALDE DISC	01	01
09	0501067323	SPRING REGULATOR	01	01
10	0521010452	SLEEVE	01	01
11	0503013185	3/4" X 5-1/2" BOLT	01	01
12	0503011255	3/4" LOCK NUT	01	01
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	01
14	0503011411	1/2" X 5-1/2" BOLT	01	01
15	0503010019	1/2" SPRING WASHER	01	01
16	0503010060	1/2 UNC G.5 ZN HEX NUT	01	01
17	0502020393	SPRING UPPER SUPPORT	02	01
18	0502020394	SPRING SUPPORT	01	01
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	01
20	0503010014	3/4" HEX NUT	02	01
21	0521054680	20" DISC BLADE HUB	01	01




Item	Code	Description	See page	QT
01	0521067063	SPRING HUB		01
02	0511059396	SCARIFIER SPINDLE WITH POINT		01
03	0581812084	LARGE BUSHING		01
04	0503012795	5/8" HEX SELF ADJUSTING NUT		01
05	0581812082	BOLT FIXER		01
06	0503810417	NUT		01
07	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
08	0503034106	80 X 230 X 16,50 COMPRESSSION SPRING		01
09	0503010691	1/4" GREASE FITTING		01
10	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
11	0571018541	BODY SOCKET FERTILIZER		01
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
13	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
14	0503010026	3/8" NUT		02
15	0503010025	3/8 SPRING WASHER		02
16	0503010384	1/2" X 5" BOLT		02
17	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
18	0503010547	1/2" X 4" BOLT		02
19	0503011336	1/2" HEX SELF ADJUSTING NUT		04
20	0571019462	SUPPORT GUIDE PRING		01
21	0581812081	SMALLER BUSHING		01
22	0581012094	SUPPORT WASHER		01



Item	Code	Description	See page	QT
01	0521063492	SUPPORT RIGHT ACTUATOR	01	
02	0521063493	SUPPORT LEFT ACTUATOR	01	
03	0503016360	LINEAR ACTUATOR	02	
04	0503010420	BOLT	02	
05	0503012880	1/4" UNC SELF ADJUSTING NUT	04	
06	0521063491	PIVOT ARM	02	
07	0503010733	1/4" X 1-3/4" BOLT	02	
08	0571012352	AXLE FIXER	02	
09	0501010984	10,50 X 27 X 3,00 FLAT WASHER	04	
10	0503010025	3/8 SPRING WASHER	02	
11	0503010026	3/8" NUT	02	
12	0503010257	1/8" X 1" SPLIT PIN	02	
13	0511052438	COUNTERWEIGHT BOX	01	
14	0503014045	CABLE CORD PLASTIC	7 MT	
15	0503014591	RING CONNECTOR	02	
16	3505151602	TUBE	0.100 MT	
17	0571012359	RH CHAIN PROTECTION	01	
18	0571012360	LH CHAIN PROTECTION CAP	01	
19	0503013527	CLAMP ZIPER	20	
20	0503011953	5/16" X 1" BOLT	02	
21	0503010179	LOCK WASHER 5/16 ZN 1K01528	02	
22	0503010499	5/16 UNC BUTTERFLY NUT	02	
23	3505151603	TUBE	0.500 MT	
24	0503015905	TWO-WAY FEMALE MALE CONNECTOR	03	
25	0503015906	TWO-WAY MALE CONNECTOR	03	
26	0503016371	CONNECTOR FEMALE 4 VIAS	01	
27	0503016372	CONNECTOR FEMALE 5 VIAS	01	
28	0503014043	TERMINAL	04	
29	0503014044	TPP-22-L TERMINAL	02	
30	0503015497	CABLE PP	5.500 MT	
31	0503014745	2 X 2,5 MM ELECTRIC CABLE	5.000 MT	


Item	Code	Description	See page	QT
32	0503016454	10 AMPERES FUSE		01
33	0503016455	SUPPORT FUSE		01
34	0503015907	MALE TERMINAL		10
35	0503015908	FEMALE TERMINAL		10
36	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		04
37	0501012140	FLAT WASHER		04
38	0503012412	5/8" UNC SELF LOCKING NUT		04
39	0503015911	CABLE SEAL		16



Item	Code	Description	See page	450	500
01	0501110639	BEARING		08	08
02	0503011099	GREASE FITTING		08	08
03	0503010300	5/32" X 1" SPLIT PIN		08	08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04	04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04	04
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		12	12
07	0503010019	1/2" SPRING WASHER		12	12
08	0503010060	1/2 UNC G.5 ZN HEX NUT		16	16
09	0561016876	MOTOR SHAFT		02	00
10	0571017428	MOTOR SHAFT		00	02
11	0501018466	FLAT WASHER		04	04
12	0511015961	LOCK BUSHING		04	04
13	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04	04
14	0501052560	MOTOR AXLE SIGNAL	39	02	02
14A	0503031825	AXLE MOTOR SLOW-MOVING		04	04
14B	0503010240	BOLT		04	04
14C	0503010179	LOCK WASHER 5/16 ZN 1K01528		04	04
14D	0503010337	5/16" NUT		04	04
15	0511051434	TRANSMISSION ACTUATOR	172	04	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	27	01	01
17	0521043316	RIGHT GEAR BOX ASSY		01	01
18	0501010243	1/2" X 1-1/2" BOLT		06	06
19	0503010019	1/2" SPRING WASHER		10	10
20	0503012682	1/2" BSW NUT		06	06
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04	04
22	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08	08
23	0503010060	1/2 UNC G.5 ZN HEX NUT		04	04
24	0521062072	33Z GEAR		02	02
25	0503030303	SUPPORT WASHER		06	06
26	0501010637	FLAT WASHER		02	02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08	08

Item	Code	Description	See page	450	500
28	0503010025	3/8 SPRING WASHER		02	02
29	0503010256	3/8" X 3/4" BOLT		02	02
30	0511054363	CHAIN TENSIONER	49	02	02
30A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		02	02
30B	0503031805	11Z 1/2" GEAR		02	02
31	0501058234	LOWER CHAIN TENSIONER		02	02
31A	0511062169	21Z P 1/2" GEAR		02	02
31B	0503011410	ROLLER BEARING		08	08
31C	0503011105	SEAL RING		04	04
31D	0551019171	CHAIN TIGHTENER AXLE		04	04
31E	0503010406	501025 CLAMPING RING (FOR AXLE)		06	06
31F	0501010163	5/8" X 4-1/2" BOLT		04	04
31G	0501012140	FLAT WASHER		02	02
31H	0503010027	5/8 SPRING WASHER		02	02
31I	0503010013	5/8 NUT		02	02
32	0501058235	STRETCHER CURRENT TOP SEED 17Z		02	02
32A	0502012367	17Z X P 1/2" GEAR INTERM		02	02
32B	0503012882	BEARING		02	02
32C	0503011945	503050 CLAMPING RING (FOR AXLE)		02	02
32D	0551019173	CHAIN SLEEVE TENSIONER		02	02
32E	0503011411	1/2" X 5-1/2" BOLT		02	02
32F	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02	02
33	0501058236	BEARING WITH 21Z GEAR		02	02
33A	0511062169	21Z P 1/2" GEAR		02	02
33B	0503012412	5/8" UNC SELF LOCKING NUT		04	04
34	0501058237	16Z GEAR BEARING		02	02
34A	0511069680	20Z X 28Z DOUBLE GEAR		02	02
34B	0551019174	DOUBLE GEAR AXLE		02	02
34C	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02	02
35	0503012391	40-1 CHAIN X 83 LINK + MENDING		02	02
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02	02
37	0503012718	40-1 CHAIN X 111 LINK + MENDING		02	02
38	0503012719	40-1 CHAIN X 113 LINK + MENDING		02	02
39	0521043317	LEFT GEAR BOX ASSY		01	01
40	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	45	01	01
41	0521013434	HEX AXLE 5/8 X 2300		01	00
42	0521013430	HEX AXLE 5/8 X 2580		01	00
43	0571017424	5/8" X 2530 HEX AXLE		00	01
44	0571017426	HEX AXLE		00	01
45	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"		02	02
46	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8		02	02
47	0503010003	1845 GREASE FITTING		02	02
48	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04	04
49	0501010694	FLAT WASHER		08	08
50	0503010179	LOCK WASHER 5/16 ZN 1K01528		04	04
51	0503010337	5/16" NUT		04	04
52	0511015098	FLAT WASHER		02	02
53	0511017305	FLAT WASHER		04	04
54	0511065562	20Z GEAR		02	02
55	0502011299	BUSHING GEAR		02	02
56	0503010571	1/4" X 1.1/2" SPLIT PIN		02	02
57	0503010010	1/4" X 2.1/2" SPLIT PIN		02	02
58	0521063929	CARRYING-WHEELS PIVOT SHAFT		01	00
59	0521063930	PIVOT SHAFT		01	00
60	0521013199	LOWER BEARING SEMI		06	06
61	0503010899	5/8 UNC X 2.1/4 BOLT		12	12
62	0501012140	FLAT WASHER		24	24
63	0531013922	0.6" X 0.8" X 1" SLEEVE		12	12
64	0503010013	5/8 NUT		12	12


Item	Code	Description	See page	450	500
65	0503011445	SPRING WASHER		24	24
66	0521065392	PIVOT SHAFT		00	01
67	0521065391	CARRYING-WHEELS PIVOT SHAFT		00	01
68	0503011750	AMENDMENT WITH LOCK		06	06
69	0503011751	REDUCTION		06	06



Item	Code	Description	See page	450	500
01	0501110639	BEARING		08	08
02	0503011099	GREASE FITTING		08	08
03	0503010300	5/32" X 1" SPLIT PIN		08	08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04	04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04	04
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		12	12
07	0503010019	1/2" SPRING WASHER		12	12
08	0503010060	1/2 UNC G.5 ZN HEX NUT		16	16
09	0571013750	MOTOR AXLE 3060		00	02
10	0571011442	MOTOR SHAFT		02	00
11	0501018466	FLAT WASHER		04	04
12	0511015961	LOCK BUSHING		04	04
13	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04	04
14	0501052560	MOTOR AXLE SIGNAL	39	02	02
14A	0503031825	AXLE MOTOR SLOW-MOVING		04	04
14B	0503010240	BOLT		04	04
14C	0503010179	LOCK WASHER 5/16 ZN 1K01528		04	04
14D	0503010337	5/16" NUT		04	04
15	0511051434	TRANSMISSION ACTUATOR	172	04	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	27	01	01
17	0521043316	RIGHT GEAR BOX ASSY		01	01
18	0501010243	1/2" X 1-1/2" BOLT		06	06
19	0503010019	1/2" SPRING WASHER		10	10
20	0503012682	1/2" BSW NUT		06	06
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04	04
22	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08	08
23	0503010060	1/2 UNC G.5 ZN HEX NUT		04	04
24	0521062072	33Z GEAR		02	02
25	0503030303	SUPPORT WASHER		06	06
26	0501010637	FLAT WASHER		02	02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08	08


Item	Code	Description	See page	450	500
28	0503010025	3/8 SPRING WASHER		02	02
29	0503010256	3/8" X 3/4" BOLT		02	02
30	0511054363	CHAIN TENSIONER	49	02	02
30A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		02	02
30B	0503031805	11Z 1/2" GEAR		02	02
31	0501058234	LOWER CHAIN TENSIONER		02	02
31A	0511062169	21Z P 1/2" GEAR		02	02
31B	0503011410	ROLLER BEARING		07	08
31C	0503011105	SEAL RING		04	04
31D	0551019171	CHAIN TIGHTENER AXLE		04	04
31E	0503010406	501025 CLAMPING RING (FOR AXLE)		06	06
31F	0501010163	5/8" X 4-1/2" BOLT		04	04
31G	0501012140	FLAT WASHER		02	02
31H	0503010027	5/8 SPRING WASHER		02	02
31I	0503010013	5/8 NUT		02	02
32	0501058235	STRETCHER CURRENT TOP SEED 17Z		02	02
32A	0502012367	17Z X P 1/2" GEAR INTERM		02	02
32B	0503012882	BEARING		02	02
32C	0503011945	503050 CLAMPING RING (FOR AXLE)		02	02
32D	0551019173	CHAIN SLEEVE TENSIONER		02	02
32E	0503011411	1/2" X 5-1/2" BOLT		02	02
32F	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02	02
33	0501058236	BEARING WITH 21Z GEAR		02	02
33A	0511062169	21Z P 1/2" GEAR		02	02
33B	0503012412	5/8" UNC SELF LOCKING NUT		04	04
34	0501058237	16Z GEAR BEARING		02	02
34A	0511069680	20Z X 28Z DOUBLE GEAR		02	02
34B	0551019174	DOUBLE GEAR AXLE		02	02
34C	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02	02
35	0503012391	40-1 CHAIN X 83 LINK + MENDING		02	02
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02	02
37	0503012718	40-1 CHAIN X 111 LINK + MENDING		02	02
38	0503012719	40-1 CHAIN X 113 LINK + MENDING		02	02
39	0521043317	LEFT GEAR BOX ASSY		01	01
40	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	45	01	01
41	0541019102	HEX AXLE 5/8 X 2830		01	00
42	0541019101	HEX AXLE 5/8 X 3110		01	00
43	0521013431	5/8" X 3030" AXLE HEX		00	01
44	0571013736	HEX AXLE		00	01
45	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"		02	02
46	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8		02	02
47	0503010003	1845 GREASE FITTING		02	02
48	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04	04
49	0501010694	FLAT WASHER		08	08
50	0503010179	LOCK WASHER 5/16 ZN 1K01528		04	04
51	0503010337	5/16" NUT		04	04
52	0511015098	FLAT WASHER		02	02
53	0511017305	FLAT WASHER		04	04
54	0511065562	20Z GEAR		02	02
55	0502011299	BUSHING GEAR		02	02
56	0503010571	1/4" X 1.1/2" SPLIT PIN		02	02
57	0503010010	1/4" X 2.1/2" SPLIT PIN		02	02
58	0521063937	PIVOT SHAFT		01	00
59	0521063938	CARRYING-WHEELS PIVOT SHAFT		01	00
60	0521013199	LOWER BEARING SEMI		06	06
61	0503010899	5/8 UNC X 2.1/4 BOLT		12	12
62	0501012140	FLAT WASHER		24	24
63	0531013922	0.6" X 0.8" X 1" SLEEVE		12	12
64	0503010013	5/8 NUT		12	12

Item	Code	Description	See page	450	500
65	0503011445	SPRING WASHER		24	24
66	0521063922	CARRYING-WHEELS PIVOT SHAFT		00	01
67	0521064033	LH CARRYING-WHEELS PIVOT SHAFT		00	01
68	0503011750	AMENDMENT WITH LOCK		06	06
69	0503011751	REDUCTION		06	06




Item	Code	Description	See page	DR	ES
00	0521043316	RIGHT GEAR BOX ASSY		01	00
00A	0521043317	LEFT GEAR BOX ASSY		00	01
01	0501058212	SEMI MOUNTED RIGHT CHANGE	29	01	00
01A	0511069565	LEFT GEAR BOX		01	00
01B	0502011758	REAR TIGHTENER LEVER		02	02
01C	0503010292	701164 6 X 40 SPRING PIN		09	09
01D	0511061794	CHAIN TENSIONER		01	01
01E	0503031367	SPRING		01	01
01F	0511060392	CHAIN TENSIONER		01	01
01G	0503031366	RIGHT TWISTED SPRING		01	01
02	0501058213	LH GEAR BOX	47	00	01
02A	0501069566	FRAME SPACER		00	01
03	0503031805	11Z 1/2" GEAR		06	06
04	0503010302	501019 SEAL RING		04	04
05	0501048790	AXLE WITH RING	34	02	02
05A	0521012476	GEAR BOX LEVER AXLE		02	02
05B	0503031369	LINK		02	02
06	0503010002	1800 GREASE FITTING		02	02
07	0551018209	DRIVING AXLE		01	01
08	0521018259	DRIVEN AXLE		01	01
09	0551018210	DRIVEN AXLE		01	01
10	0551018211	INTERM SHAFT		01	01
11	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	36	01	01
12	0503011953	5/16" X 1" BOLT		16	16
13	0501010694	FLAT WASHER		16	16
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		16	16
15	0503010337	5/16" NUT		16	16
16	0503030303	SUPPORT WASHER		05	05
17	0501056443	GEAR HOUSING BEARING	32	02	02
18	0501056271	GEARBOX CLOSED BEARING	31	05	05
19	0511060396	DRIVE/DRIVEN SHAFT		04	04


Item	Code	Description	See page	DR	ES
20	0503012389	1/2 BALL		04	04
21	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04	04
22	0503010060	1/2 UNC G.5 ZN HEX NUT		06	06
23	0503010834	1/2 X 1 BOLT		04	04
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02	02
25	0511067501	26Z GEAR		02	02
26	0503012204	40-1 CHAIN X 82 LINK + RED		02	02
27	0503012713	40-1 CHAIN X 45 LINK + MEN		01	01
28	0501054655	CHAIN TENSIONER ASSY	35	02	02
28A	0531019479	AXLE CHAIN GEAR		02	02
28B	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02	02
28C	0503010019	1/2" SPRING WASHER		02	02
29	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01	01
30	0503010025	3/8 SPRING WASHER		01	01
31	0503010256	3/8" X 3/4" BOLT		01	01
32	0503030275	AGRICULTURAL BEARING		01	01
33	0521018630	1.4" X SQUARE 0.8" WASHER		03	03



Item	Code	Description	See page	DR	ES
00	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	27	01	00
00A	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	45	00	01
01	0502011996	SLEEVE FIXER		01	01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01	01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01	01
04	0521017590	GUIDE AXLE		01	01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01	01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01	00
07	0502011995	LH DRIVING AXLE FOLLOWER		00	01
08	0501019734	FLAT WASHER		02	02
09	0502010710	RIGHT CAM, SMALLER		02	00
10	0502010720	RIGHT CAM, SMALLER		00	02
11	0503010003	1845 GREASE FITTING		02	02
12	0502012539	26Z P12,7 GEAR		01	00
13	0502012540	26Z P12,7 GEAR		00	01
14	0501019735	FLAT WASHER		01	01
15	0521017593	FLAT WASHER		01	01
16	0503010542	501045 CLAMPING RING (FOR AXLE)		01	01



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	10	11	13	15
00	0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	78	01	00	01	00
00A	0511056532	ASSY SYSTEM HYDRAULIC 5340	81	00	01	00	00
00B	0511056808	ASSY SYSTEM HYDRAULIC 6350		00	00	00	01
01	0571017027	VALVE SUPPORT		01	01	01	01
02	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02	02	02	02
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02	02	02	02
04	0503010019	1/2" SPRING WASHER		02	02	02	02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02	02	02	02
06	0501054694	COMPLETE FLOW DIVIDER VALVE	79	01	01	01	01
06A	0503012481	FLOW DIVIDING VALVE		01	01	01	01
06B	0501011460	7/8 NF REDUCTION NIPPLE		03	03	03	03
06C	0503010190	2-114 N 3006-9B O'RING		03	03	03	03
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02	02	02	02
08	0503010143	1/4" SPRING WASHER		02	02	02	02
09	0503010144	1/4" NUT		02	02	02	02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01	01	01	01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01	01	01	01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01	01	01	01
13	0501080045	3/8" X 850 TR-TR HOSE		01	00	01	00
14	0501080999	3/8" X 39" TC-TC HOSE		01	00	01	00
15	0501081987	HOSE 3/8 X 1550 TR-TC		01	00	01	00
16	0501081986	HOSE 3/8 X 1550 TC-TC		01	00	01	00
17	0501080185	HOSE 1/2 X 4000 TR-TM		02	02	02	02
18	0501080104	3/8 X 900 TR-TR HOSE		00	01	00	00
19	0501080963	3/8 X 1050 TC-TC 90G LEFT OSE		00	01	00	00
20	0501080714	3/8 X 1600 TR-TC HOSE		00	01	00	00
21	0501081994	3/8 X 1600 TC-TC 180G HOSE		00	01	00	00
22	0501080127	3/8" X 45,2" TR-TR HOSE		00	00	00	01
23	0501081998	HOSE 3/8 X 1300 TC-TC		00	00	00	01
24	0501082001	TR-TC HOSE ASSY		00	00	00	01
25	0501082000	TC-TC HOSE ASSY		00	00	00	01


SET HYDRAULIC SYSTEM

0909091826


Item	Code	Description	See page	10	11	13	15
26	0501053834	MALE QUICK COUPLER	80	02	02	02	02
26A	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		02	02	02	02
26B	0503011882	MALE QUICK COUPLER CAP		02	02	02	02
27	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02	02	02	02
28	0571017774	SPRING PROTECTION QUICK HOSE		01	01	01	01
29	0502012702	BODY SUPPORT CLAMP		03	03	03	03
30	0503010180	7/16" SPRING WASHER		03	03	03	03
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03	03	03	03
32	0503013100	NYLON CLAMP		02	02	02	02



Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT	02	02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548	08	08
03	0503012412	5/8" UNC SELF LOCKING NUT	08	08
04	0503011070	BEATER	02	02
05	0503010019	1/2" SPRING WASHER	02	02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	02	02
07	0551019213	FLAT WASHER	02	02
08	0511061811	ROW MARKER ARM	02	02
09	0511017592	11.8" X 1.6" TRANSPORT LOCK	02	02
10	0521061655	BOLT 5/8 UNC X 320 MM	02	02
11	0521010479	SLEEVE ARTICULATION	04	04
12	0501012140	FLAT WASHER	04	04
13	0503012412	5/8" UNC SELF LOCKING NUT	02	02
14	0511058449	HYDRAULIC CYLINDER	85	02
15	0521010575	C0.9" X 3.3" COUPLING SHAFT	02	02
16	0503010523	1/4" X 2" SPLIT PIN	04	04
17	0511015779	1" X 4.2" AXLE	02	02
18	0501068994	8,30 X 78 LOCK PIN	02	02
19	0503030168	HITCH PIN CLIP	02	02
20	0501066949	1235 TURNBUCKLE	02	02
21	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN	04	04
22	0501050633	ROW MARKER DISC ASSEMBLY	175	02
23	0521013164	EXTENDER	00	02
24	0501011310	FIXER LOCK	00	08
25	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN	00	08
26	0503010019	1/2" SPRING WASHER	00	08
27	0503010060	1/2 UNC G.5 ZN HEX NUT	00	08




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	10	11	13	15
01	0501054649	HBM SEQUENTIAL VALVE	177	01	01	01	01
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02	02	02	02
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02	02	02	02
04	0503010025	3/8 SPRING WASHER		02	02	02	02
05	0501081728	HOSE 3/8 X 3100 TR-TR		01	00	00	00
06	0501081330	HOSE		00	01	00	00
07	0501081793	HOSE		00	00	01	00
08	0501081794	TR-TC HOSE ASSY		00	00	00	01
09	0501080392	3/8 X 3300 TR-TC HOSE		01	00	00	00
10	0501081718	HOSE		00	01	00	00
11	0501081967	3/8" X 151" TR-TC HOSE		00	00	01	00
12	0501081999	3/8 X 4050 TR-TC HOSE ASSY		00	00	00	01
13	0501081988	3/8" X 145.6" TR-TC HOSE		01	00	00	00
14	0501081799	HOSE		00	01	00	00
15	0501081996	HOSE		00	00	01	00
16	0501080612	HOSE 3/8 X 4450 TR-TC		00	00	00	01
17	0501081682	TC-TC HOSE ASSY		01	00	00	00
18	0501081995	HOSE		00	01	00	00
19	0501081997	HOSE		00	00	01	00
20	0501082002	3/8 X 4650 TC-TC HOSE ASSY		00	00	00	01
21	0501080361	3/8" X 157" TR-TM HOSE		02	02	02	02
22	0501053834	MALE QUICK COUPLER	80	02	02	02	02
22A	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		02	02	02	02
22B	0503011882	MALE QUICK COUPLER CAP		02	02	02	02
23	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02	02	02	02
24	0502012702	BODY SUPPORT CLAMP		06	06	06	06
25	0531011180	UPPER BODY CLIP		04	04	04	04
26	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04	04	04	04
27	0503011103	7/16" X 2-1/2" BOLT		02	02	02	02
28	0501012803	FLAT WASHER		02	02	02	02
29	0503010180	7/16" SPRING WASHER		06	06	06	06



Item	Code	Description	See page	10	11	13	15
30	0503010244	7/16" NUT		02	02	02	02



Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCIAL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02



MARCHESAN

Technical Publications | Elaboration and Revision

MARINA PEREZ NIZA

www.marchesan.com.br

