

PARTS CATALOGUE



ROW CROP PLANTERS

Code:

0501091308

Product:

USAP SUPREMA



Series:

S-0114

Revision:

00

Date Revision:

JANEIRO/2014

PRODUCTS

Code	Description
0111440064	USAP SUP 20E450 MH DPLO S-0114
0111440044	USAP SUP 30E500 MH S-0114
0111440026	USAP SUP 42 E-500 S-0612
0111440085	USAP SUP PP 26E500 MH MS SPCRR S-0114
0111440076	USAP SUP PP 28E500 MH MS S-1214
0111440088	USAP SUP PP 30E500 MH SPA MTHPP APT S-1214
0111440071	USAP SUP PP 34E450 APT S-1214
0111440081	USAP SUP PP 36E450 APT S-1214

ATTENTION: IMPORTANT


Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.



MARCHESAN

INDEX


0909091595	FRAME 18A28 LINE	1
0909092406	CH CENT USAP SUP PP 18A46 L	2
0909092431	CH CENT USAP SUP PP 18A46 L	3
0909092415	CH LAT D USAP PP 18A46 L	4
0909092416	CH LAT ESQ USAP PP 18A46 L	5
0909092192	COMPLETE TELESCOPIC HEADER	6
0909091596	ACCESSORIES	7
0511043675	HYDRAULIC CYLINDER	8
0521043416	HYDRAULIC CYLINDER	9
0511049549	CYLINDER HEADER HYDRAULIC	10
0909091597	CENTRAL FERTILIZER BOX	11
0909091598	BOX FERTILIZER SIDE	12
0909091599	GEAR BOX CENTRAL	13
0909091600	GEAR BOX CENTRAL ASSY	14
0909091601	RIGHT / LEFT GEAR BOX ASSY	15
0909093334	DRIVE SHAFT	16
0909091602	DEVIATION GREATER ASSY	17
0909091603	DEVIATION LOWER REAR	18
0909091604	WHEELS CENTER AND TRANSMISSION	19
0909091605	WHEELS CENTER S/TRANSMISSION	20
0909091606	WHEELS RIGHT/LEFT TRANSMISSION	21
0909091607	CARRYING WHEELS SIDE S/TRANSMISSION	22
0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	23
0511054491	WHEEL WITHOUT TIRE WITH 27Z GEAR	24
0511054492	STUB SHAFT HUB	25
0521044061	HYDRAULIC CYLINDER	26
0511054499	TRANSMISSION OF LARGER CENTRAL EXCHANGE	27
0511054501	TRANSMISSION CAMBIO LEFT	28
0511054500	TRANSMISSION EXCHANGE RIGHT	29
0501048409	DRIVE SHAFT	30
0501048409(STU)	DRIVE SHAFT	31
0909091609	HYDRAULIC CIRCUIT ARTICULATION	32
0511053313	BLOCK COMMAND	33
0909091610	HYDRAULIC CIRCUIT	34
0511047164	DISC BLADE ASSY	35
0511052299	BLADE DISC	36
0909090721	FRONT SEED ROW	37
0909090778	FRONT SEED ROW	38
0909090720	REAR SEED ROW ASSY	39
0511050077	WHEEL STRIPED	40
0909091615	DEPTH CONTROL	41
0909091616	RUEDA COMPACT DER IZL V C/ ROL	42
0909093298	15X15 SEED UNAL DOUB-DISC ASSY	43
0521042711	SEED DISTRIBUTOR ASSY	44
0909094479	ROW MARKER ASSY	45
0511043513	HYDRAULIC MARKER CYLINDER	46
0909091611	ROW MARKER HYDRAULIC CIRCUIT	47
0511042494	ROW MARKER DISC ASSY	48
0501058486	TRANSPORT SUPPORT ASSY	49
0909090718	PNEUMATIC TURBINE CIRCUIT	50
0909093265	TURBINE HYDRAULIC CIRCUIT	51



Item	Code	Description	See page	18	19	20	22	24	25	26	27	28	L.
032	0503010060	1/2" NUT		16	16	16	16	16	16	16	16	16	
033	0511069820	PLATFORM 2380 USAP		02	02	00	00	00	00	00	00	00	
034	0521061799	PLATFORM CENTER		00	00	02	02	00	00	00	00	00	
035	0521062334	PLATFORM CENTER		00	00	00	00	02	02	02	02	02	
036	0501010160	1/2" X 3" BOLT		04	04	04	04	04	04	04	04	04	
037	0511017302	FLAT WASHER		04	04	04	04	04	04	04	04	04	
038	0503010019	1/2" SPRING WASHER		04	04	04	04	04	04	04	04	04	
039	0503010060	1/2" NUT		04	04	04	04	04	04	04	04	04	
040	0501010942	3/8" X 1-1/4" BOLT		02	02	02	02	02	02	02	02	02	
041	0501013518	FLAT WASHER		02	02	02	02	02	02	02	02	02	
042	0503010025	3/8" SPRING WASHER		02	02	02	02	02	02	02	02	02	
043	0503010026	3/8" NUT		02	02	02	02	02	02	02	02	02	
044	0511052544	SET DUCT UPPER SEED		02	02	02	02	02	02	02	02	02	
045	0521044028	CENTRAL WHEEL WITH TRANSMISSION 8940		01	00	01	01	00	00	00	00	00	
046	0521043437	CENTRAL / SIDE WHEEL WITHOUT TRANSMISSION		01	02	01	01	00	00	00	00	00	
047	0521043436	WHEELS CENTER TRANSMISSION		00	00	00	00	03	03	03	03	03	
048	0521045325	CENTER WHELLS		00	00	00	00	01	00	00	00	01	
049	0521043440	WHEELS CENTER AND TRANSMISSION		00	00	00	00	00	01	01	01	00	
050	0511058903	SHORT SEED ROW FRONT		01	05	01	05	05	05	05	05	05	
051	0511058904	LONG FRONT SEED ROW		04	05	04	05	05	06	06	06	06	
052	0909092137	REAR RIGHT SEED ROW ASSY		05	05	05	05	05	05	05	05	05	
052.	0909092138	REAR RIGHT / LEFT OF SEED LINE		05	05	05	05	05	05	05	05	05	
053	0909092147	REAR RIGHT / LEFT OF SEED LINE		06	06	06	06	06	06	06	06	06	
053.	0909092148	REAR RIGHT / LEFT OF SEED LINE		06	06	06	06	06	06	06	06	06	
054	0571012013	TRANSPORT LOCK		05	05	05	05	05	05	05	05	05	
055	0571012014	TRANSPORT LOCK		06	06	06	06	06	06	06	06	06	
056	0511047164	DISC BLADE ASSY	35	10	11	10	10	10	10	10	10	10	
057	0521044322	20 BLADE DISC ASSY		10	11	10	10	00	00	00	00	00	
058	0521041803	20 BLADE DISC ASSY		10	11	10	10	11	10	10	10	10	
059	0571013341	HEX AXLE		02	02	02	02	00	00	00	01	00	
060	0561016761	3/4 X 1900 HEX AXLE		00	00	00	00	01	00	01	00	00	
061	0531013215	3/4" X 113" HEX AXLE		00	00	00	00	01	00	01	00	00	
062	0571013341	HEX AXLE		00	00	00	00	00	01	00	00	00	
063	0561018821	HEX AXLE 3/4 X 2600		00	00	00	00	00	01	00	01	00	
064	0561016762	3/4 X 2390 HEX AXLE		00	00	00	00	00	00	00	00	02	
065	0511053648	GEAR		01	01	01	01	01	01	01	01	01	
065A	0521063774	GEAR ASSY		01	01	01	01	01	01	01	01	01	
065B	0503016587	CHAIN LINK + MENDING		01	01	01	01	01	01	01	01	01	
066	0561015837	SLEEVE 31,75		01	01	01	01	01	01	01	01	01	
067	0503010523	1/4" X 2" COTTERPIN		01	01	01	01	01	01	01	01	01	
068	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		26	26	26	26	26	28	28	28	28	
068A	0502012699	LATCH GLOVE BOX TRANSMISSION		26	26	26	26	26	28	28	28	28	
068B	0503010256	3/8" X 3/4" BOLT		26	26	26	26	26	28	28	28	28	
069	0511053030	SET HIDRAULICO		01	01	01	01	00	00	00	00	00	
070	0511054606	SET HIDRAULICO		00	00	00	00	01	01	00	00	00	
071	0511054604	SET HIDRAULICO		00	00	00	00	00	00	01	01	01	
072	0571013314	GUTTER 25 X 58 X 1500		01	01	00	00	00	00	00	00	01	
073	0571014668	GUTTER		01	01	01	01	00	01	00	01	01	
074	0571014383	GUTTER		00	00	01	01	00	01	00	01	00	
075	0571013991	GUTTER 25 X 38 X 2650 USAP APT		00	00	00	00	01	00	00	00	00	
076	0571013990	GUTTER		00	00	00	00	01	00	00	00	00	
077	0571013313	GUTTER 25 X 58 X 2150 USAP		00	00	00	00	00	00	02	00	00	
078	0511053343	ELECTRIC ASSEMBLY C		01	01	01	01	01	01	01	01	01	
079	0511052080	ISOBUS ELECTRICAL ASSEMBLY		01	01	01	01	01	01	01	01	01	
080	0501058958	ISOBUS USAP SET WITH SEED		01	01	01	01	01	01	01	01	01	
081	0511051738	SET OF PARTS USAP APT ISOB (12910/17890		01	01	01	01	01	01	01	01	01	
082	0511052388	REST GREATER ASSY		01	01	01	01	01	01	01	01	01	


Item	Code	Description	See page	18	19	20	22	24	25	26	27	28	L.
083	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01	01	01	01	01	01	01	01	01	
084	0511054270	TENSIONER SPRING		01	01	01	01	01	01	01	01	01	
084A	0511069520	TELESC LOCK SPRING TENSIONER		01	01	01	01	01	01	01	01	01	
084B	0503010013	5/8" NUT		02	02	02	02	02	02	02	02	02	
085	0571011596	FIXER HOSE		01	01	01	01	01	01	01	01	01	
086	0511054276	REAR AXLE		02	02	02	02	02	02	02	02	02	
086A	0521063962	PIVOT SHAFT		02	02	02	02	02	02	02	02	02	
086B	0503010027	5/8" SPRING WASHER		02	02	02	02	02	02	02	02	02	
086C	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02	02	02	02	02	02	02	02	02	
086D	0551019529	FLAT WASHER		02	02	02	02	02	02	02	02	02	
087	0511054277	ATTACHMENT BAR REAR AXLE		02	02	02	02	02	02	02	02	02	
088	0551018312	TRANSPORT LOCK		04	04	04	04	04	04	04	04	04	
089	0501068994	0.3" X 3.1"LOCK PIN		04	04	04	04	04	04	04	04	04	
090	0503030168	HAIR PIN		04	04	04	04	04	04	04	04	04	
091	0561016793	FIXED WRENCH		01	01	01	01	01	01	01	01	01	
092	0501047885	ROD STOP		04	04	04	04	04	04	06	06	06	
093	0511052321	HOSE HOLDER		01	01	01	01	01	01	01	01	01	
093A	0511067334	HOSE SOPPORT ASSY		01	01	01	01	01	01	01	01	01	
093B	0503010014	3/4" NUT		02	02	02	02	02	02	02	02	02	
094	0503014120	CHAIN		01	01	01	01	01	01	01	01	01	
095	0503014321	CABLE STEEL SHACKLE		02	02	02	02	02	02	02	02	02	
096	0561017063	HOLDER TUBE		02	02	02	02	02	02	02	02	02	
097	0511054280	HITCH AXLE		01	01	01	01	01	01	01	01	01	
097A	0511069466	HITCH AXLE		01	01	01	01	01	01	01	01	01	
097B	0503030012	HAIR PIN		01	01	01	01	01	01	01	01	01	
098	0511069471	PLOUGH SUPPORT		02	02	02	02	02	02	02	02	02	
099	0511053349	ELECTRICAL SYSTEM KIT EMBEDDED USAP		01	01	01	01	01	01	01	01	01	
100	0501059876	ROTATING LEFT AXIS EXTENSOR		01	01	01	01	01	01	01	01	01	
101	0511051299	ROTATING RIGHT AXIS EXTENSOR		01	01	01	01	01	01	01	01	01	
102	0511054256	COROT WATER		01	01	01	01	01	01	01	01	01	
103	0511054502	GEAR BOX CENTRAL ASSY		01	01	01	01	01	01	01	01	01	
104	0511055452	ROW MONITOR ASSY		01	00	00	00	00	00	00	00	00	
105	0511055453	ROW MONITOR ASSY		00	01	00	00	00	00	00	00	00	
106	0511055454	ROW MONITOR ASSY		00	00	01	00	00	00	00	00	00	
107	0511055459	ROW MONITOR ASSY		00	00	00	01	00	00	00	00	00	
108	0511055461	ROW MONITOR ASSY		00	00	00	00	01	00	00	00	00	
109	0511055462	ROW MONITOR ASSY		00	00	00	00	00	01	00	00	00	
110	0511055463	ROW MONITOR ASSY		00	00	00	00	00	00	01	00	00	
111	0511055464	ROW MONITOR ASSY		00	00	00	00	00	00	00	01	00	
112	0511055465	ROW MONITOR ASSY		00	00	00	00	00	00	00	00	01	

Item	Code	Description	See page	18	22	25	26	28	30	32	34	36	38	45	46	L
089	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		20	24	27	28	30	34	36	36	38	40	48	50	
089A	0502012699	LATCH GLOVE BOX TRANSMISSION		20	24	27	28	30	34	36	36	38	40	48	50	
089B	0503010256	3/8" X 3/4" BOLT		20	24	27	28	30	34	36	36	38	40	48	50	
090	0511053648	GEAR		01	01	01	01	01	01	01	01	01	01	01	01	
090A	0521063774	GEAR ASSY		01	01	01	01	01	01	01	01	01	01	01	01	
090B	0503016587	CHAIN LINK + MENDING		01	01	01	01	01	01	01	01	01	01	01	01	
091	0501058617	DRIVER AIR		01	01	01	00	01	01	01	01	00	00	00	00	
092	0521050389	DRIVER AIR		00	00	00	01	00	00	00	00	00	00	00	00	
093	0511050979	OF THE AIR CENTRAL TUBE		00	00	00	00	00	00	00	00	01	00	01	01	
094	0511055259	DRIVER AIR		00	00	00	00	00	00	00	00	00	01	00	00	
095	0581010572	AIR CONDUCTOR 1.1/2 X 1300 USAP SUP PP		18	22	25	26	28	30	32	34	36	38	45	46	
096	0571019716	ADAPTER		18	22	25	26	28	30	32	34	36	38	45	46	
097	0503031436	AIR DITRIBUTOR PUMP		02	02	02	02	04	04	04	04	04	04	04	04	
098	0503010243	CLAMP		36	44	50	52	56	60	64	68	72	76	90	92	
099	0571012769	DRIVER AIR LEFT		02	02	02	02	02	02	02	02	02	02	02	02	
100	0571012770	CONDUCTOR OF AIR LAW		02	02	02	02	02	02	02	02	02	02	02	02	
101	0503011087	3/8" X 1" BOLT		06	06	06	06	06	06	06	06	06	06	06	06	
102	0503010849	3/8" X 1-1/2" BOLT		02	02	02	02	02	02	02	02	02	02	02	02	
103	0503010025	3/8" SPRING WASHER		08	08	08	08	08	08	08	08	08	08	08	08	
104	0503010026	3/8" NUT		08	08	08	08	08	08	08	08	08	08	08	08	
105	0521018402	AIR CONDUCTOR CLAMP		04	04	04	04	04	04	04	04	04	04	04	04	
106	0503010371	5/16" X 1" BOLT		08	08	08	08	08	08	08	08	08	08	08	08	
107	0503010179	5/16" ZN SPRING WASHER		08	08	08	08	08	08	08	08	08	08	08	08	
108	0503010337	5/16" NUT		08	08	08	08	08	08	08	08	08	08	08	08	
109	0503010232	5/8" X 1.3/4" BOLT		00	00	00	00	00	00	00	02	02	02	02	02	
110	0503012412	5/8 UNC SELF LOCKING NUT		00	00	00	00	00	00	00	02	02	02	02	02	
111	0511059406	TURBINE P.P MOUNTED		01	01	01	01	01	01	01	01	01	01	01	01	
112	0521045398	TURBINE HYDRAULIQUE		01	01	01	01	01	01	01	01	01	01	01	01	
113	0571013314	GUTTER 25 X 58 X 1500		01	01	00	01	01	01	01	01	00	00	00	00	
114	0571014668	GUTTER		01	01	00	01	01	01	01	00	00	00	00	00	
115	0571013991	GUTTER 25 X 38 X 2650 USAP APT		00	00	01	00	00	00	00	01	01	00	00	00	
116	0571013990	GUTTER		00	00	01	00	00	00	00	00	00	00	00	00	
117	0571014383	GUTTER		00	00	00	00	00	00	00	00	01	01	01	01	
118	0571013958	CALHA		00	00	00	00	00	00	00	00	00	01	00	00	
119	0571014668	GUTTER		00	00	00	00	00	00	00	00	00	00	01	01	
120	0501058763	TURBINE HOSES SET		01	01	01	01	01	01	01	01	01	01	01	01	
120A	0501081523	HOSE 1/2 X 7000 TC-TC		01	01	01	01	01	01	01	01	01	01	01	01	
120B	0501081746	HOSE 1/2 X 3200 TR-TM		02	02	02	02	02	02	02	02	02	02	02	02	
120C	0501081747	HOSE 3/8 X 3200 TR-TR		01	01	01	01	01	01	01	01	01	01	01	01	
120D	0501081524	HOSE 3/8		02	02	02	02	02	02	02	02	02	02	02	02	
121	0561016720	MALE TERMINAL		01	01	01	01	01	01	01	01	01	01	01	01	
122	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT		02	02	02	02	02	02	02	02	02	02	02	02	
123	0503010045	O'RING		02	02	02	02	02	02	02	02	02	02	02	02	
124	0541010080	TERMINAL R.1 / 2 NPT		02	02	02	02	02	02	02	02	02	02	02	02	
125	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		02	02	02	02	02	02	02	02	02	02	02	02	
126	0581013729	NIPLE 1 / 2NPT		02	02	02	02	02	02	02	02	02	02	02	02	
127	0551018312	TRANSPORT LOCK		04	04	04	04	04	04	04	04	04	04	04	04	
128	0501068994	0.3" X 3.1" LOCK PIN		04	04	04	04	04	04	04	04	04	04	04	04	
129	0503030168	HAIR PIN		04	04	04	04	04	04	04	04	04	04	04	04	
130	0511053692	HOSE SUPPORT COMPLETE		18	22	25	26	28	30	32	34	36	38	45	46	
130A	0511053282	ROD SUBSOILER		18	22	25	26	28	30	32	34	36	38	45	46	
130B	0503010237	3/8" X 1" BOLT		18	22	25	26	28	30	32	34	36	38	45	46	
130C	0503010025	3/8" SPRING WASHER		18	22	25	26	28	30	32	34	36	38	45	46	
130D	0503010026	3/8" NUT		18	22	25	26	28	30	32	34	36	38	45	46	



Item	Code	Description	See page	18	22	25	26	28	30	32	34	36	38	45	46	L
001	0511067764	CENTRAL FRAME		01	00	00	00	00	00	00	00	00	00	00	00	00
002	0521064537	CENTRAL FRAME		00	01	01	01	01	01	00	00	00	00	00	00	00
003	0521067521	CENTRAL CHASSIS		00	00	00	00	00	00	01	00	00	00	00	00	00
004	0521065326	CENTRAL FRAME		00	00	00	00	00	00	00	01	00	00	00	00	00
005	0521064539	CENTRAL FRAME		00	00	00	00	00	00	00	00	01	00	00	00	00
006	0521064538	CENTRAL FRAME		00	00	00	00	00	00	00	00	01	00	00	00	00
007	0521063741	CENTRAL FRAME		00	00	00	00	00	00	00	00	00	01	00	00	00
008	0521063805	CENTRAL FRAME		00	00	00	00	00	00	00	00	00	00	01	00	00
009	0521063760	CENTRAL FRAME		00	00	00	00	00	00	00	00	00	00	00	01	00
010	0503014120	CHAIN		01	01	01	01	01	01	01	01	01	01	01	01	01
011	0561017061	TUBE ADJUSTMENT PLATE		02	00	00	00	00	00	00	00	00	02	02	02	02
012	0501010161	1/2" X 1.1/4" BOLT		16	00	00	00	00	00	00	00	00	16	16	16	16
013	0503010019	1/2" SPRING WASHER		16	00	00	00	00	00	00	00	00	16	16	16	16
014	0511053377	COVER ASSY		02	02	02	02	02	02	02	02	02	02	02	02	02
015	0511051389	CAP SET USAP		02	02	02	02	02	02	02	02	02	02	02	02	02
016	0511051402	SET DUCT UPPER SEED RIGHT		03	03	03	03	00	00	00	00	00	00	00	00	00
017	0511051401	SET DUCT UPPER SEED LEDT		03	03	03	03	00	00	00	00	00	00	00	00	00
018	0511051501	SET DUCT UPPER SEED LEDT		04	04	04	04	04	04	04	04	04	04	04	04	04
019	0511051500	SET DUCT UPPER SEED RIGHT		00	00	00	00	04	04	04	04	04	04	04	04	04
020	0511053030	SET HIDRAULICO		01	01	00	00	00	00	00	00	00	00	00	00	00
021	0511054604	SET HIDRAULICO		00	00	01	00	01	01	00	00	00	00	00	00	00
022	0521050508	SET HIDRAULICO		00	00	00	01	00	00	00	00	00	00	00	00	00
023	0501058375	SET HIDRAULICO		00	00	00	00	00	00	01	00	00	00	00	00	00
024	0511057521	SET HIDRAULICO		00	00	00	00	00	00	00	01	00	00	00	00	00
025	0511054716	SET HIDRAULICO		00	00	00	00	00	00	00	00	01	00	00	00	00
026	0511055206	SET HIDRAULICO		00	00	00	00	00	00	00	00	00	01	00	00	00
027	0511053762	SET HIDRAULICO		00	00	00	00	00	00	00	00	00	00	01	01	01
028	0511053343	ELECTRIC ASSEMBLY C		01	01	00	00	00	00	00	00	00	00	00	00	00
029	0511053343	ELECTRIC ASSEMBLY C		00	00	01	01	01	01	01	00	00	00	00	00	00
030	0511052080	ISOBUS ELECTRICAL ASSEMBLY		00	00	00	00	00	00	00	01	00	00	00	00	00
031	0511053344	ELECTRIC ASSEMBLY C		00	00	00	00	00	00	00	00	01	00	00	00	00

Item	Code	Description	See page	18	22	25	26	28	30	32	34	36	38	45	46	L
032	0511052081	ISOBUS ELECTRICAL ASSEMBLY		00	00	00	00	00	00	00	00	00	01	00	00	
033	0511053345	ELECTRIC ASSEMBLY C MAIOR		00	00	00	00	00	00	00	00	00	00	01	01	
034	0501058958	ISOBUS USAP SET WITH SEED		01	01	01	01	01	01	01	01	01	01	01	01	
035	0511053725	SET OF PARTS USAP APT ISOB (20900)		01	01	01	01	01	01	01	01	01	01	01	01	
036	0551019397	CENTRAL HANDRAIL CHOCK		04	04	04	04	04	04	04	04	04	04	04	04	
037	0501059876	ROTATING LEFT AXIS EXTENSOR		01	01	01	01	01	01	01	01	01	01	01	01	
038	0511051299	ROTATING RIGHT AXIS EXTENSOR		01	01	01	01	01	01	01	01	01	01	01	01	
039	0511054256	COROT WATER		01	01	01	01	01	01	01	01	01	01	01	01	
040	0503014774	HFB0709111 CONTROL VALVE		01	01	01	01	01	01	01	01	01	01	01	01	
041	0521060118	"T" TERMINAL		01	01	01	01	01	01	01	01	01	01	01	01	
042	0511053696	SUPPORT VACUUM		02	02	02	02	02	02	02	02	02	02	02	02	
043	0503015062	TUBE		02	02	02	02	02	02	02	02	02	02	02	02	
044	0511053692	HOSE SUPPORT COMPLETE		18	22	25	26	28	30	32	34	36	38	45	46	
044A	0511063282	HOSE HOLDER		18	22	25	26	28	30	32	34	36	38	45	46	
044B	0503010237	3/8" X 1" BOLT		18	22	25	26	28	30	32	34	36	38	45	46	
044C	0503010025	3/8" SPRING WASHER		18	22	25	26	28	30	32	34	36	38	45	46	
044D	0503010026	3/8" NUT		18	22	25	26	28	30	32	34	36	38	45	46	
045	0511053659	HOSE HOLDER		18	22	25	26	28	30	32	34	36	38	45	46	
045A	0521064230	HOSE HOLDER		18	22	25	26	28	30	32	34	36	38	45	46	
045B	0503010920	1/2" X 1.1/2" BOLT		18	22	25	26	28	30	32	34	36	38	45	46	
045C	0503010019	1/2" SPRING WASHER		18	22	15	16	28	30	32	34	36	38	45	46	
045D	0503010060	1/2" NUT		18	22	15	16	28	30	32	34	36	38	45	46	
046	0511052388	REST GREATER ASSY		01	01	01	01	01	01	01	01	01	01	01	01	
047	0521064540	TELESCOPIC LOCK		01	01	01	01	01	01	01	01	01	01	01	01	
048	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01	01	01	01	01	01	01	01	01	01	01	01	
049	0511054270	TENSIONER SPRING		01	01	01	01	01	01	01	01	01	01	01	01	
050	0571011596	FIXER HOSE		01	01	01	01	01	01	01	01	01	01	01	01	
051	0511054276	REAR AXLE		02	02	02	02	02	02	02	02	02	02	02	02	
051A	0521063962	PIVOT SHAFT		02	02	02	02	02	02	02	02	02	02	02	02	
051B	0503010027	5/8" SPRING WASHER		02	02	02	02	02	02	02	02	02	02	02	02	
051C	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02	02	02	02	02	02	02	02	02	02	02	02	
051D	0551019529	FLAT WASHER		02	02	02	02	02	02	02	02	02	02	02	02	
052	0511054277	ATTACHMENT BAR REAR AXLE		02	02	02	02	02	02	02	02	02	02	02	02	
053	0511053122	TOOLS BOX ASSY		01	01	01	01	01	01	01	01	01	01	01	01	
054	0503062417	KIT CORN DISTRIBUTION		18	22	25	26	28	30	32	34	36	38	45	46	
055	0561016793	FIXED WRENCH		01	01	01	01	01	01	01	01	01	01	01	01	
056	0511052321	HOSE HOLDER		01	01	01	01	01	01	01	01	01	01	01	01	
056A	0511067334	HOSE SOPPORT ASSY		01	01	01	01	01	01	01	01	01	01	01	01	
056B	0503010014	3/4" NUT		01	01	01	01	01	01	01	01	01	01	01	01	
057	0503014321	CABLE STEEL SHACKLE		02	02	02	02	02	02	02	02	02	02	02	02	
058	0561017063	HOLDER TUBE		02	02	02	02	02	02	02	02	02	02	02	02	
059	0511054502	GEAR BOX CENTRAL ASSY		01	01	01	01	01	01	01	01	01	01	01	00	00
060	0511052767	GREATER FULL CENTRAL CHANGE		00	00	00	00	00	00	00	00	00	00	01	01	
061	0501058994	ISOBUS USAP SET WITH SEED MONITOR		01	00	00	00	00	00	00	00	00	00	00	00	
062	0501058998	ISOBUS USAP SET		00	01	00	00	00	00	00	00	00	00	00	00	
063	0501059001	ISOBUS USAP SET		00	00	01	00	00	00	00	00	00	00	00	00	
064	0501059002	ISOBUS USAP SET		00	00	00	01	00	00	00	00	00	00	00	00	
065	0501059004	ISOBUS USAP SET		00	00	00	00	01	00	00	00	00	00	00	00	
066	0501059006	ISOBUS USAP SET		00	00	00	00	00	01	00	00	00	00	00	00	
067	0501059008	ISOBUS USAP SET		00	00	00	00	00	00	01	00	00	00	00	00	
068	0511051405	ISOBUS USAP SET		00	00	00	00	00	00	00	01	00	00	00	00	
069	0511051407	ISOBUS USAP SET		00	00	00	00	00	00	00	00	01	00	00	00	
070	0511051651	ISOBUS USAP SET		00	00	00	00	00	00	00	00	00	01	00	00	
071	0511051658	ISOBUS USAP SET		00	00	00	00	00	00	00	00	00	00	01	00	
072	0511051659	ISOBUS USAP SET WITH SEED		00	00	00	00	00	00	00	00	00	00	00	01	
073	0511054514	ROW MARKER SET		01	01	01	00	00	00	00	00	00	00	00	00	
074	0511051726	ROW MARK SET		00	00	00	01	01	01	00	00	00	00	00	00	
075	0511051148	ROW MARK SET		00	00	00	00	00	00	01	01	01	00	00	00	
076	0511051187	ROW MARK SET COP 19		00	00	00	00	00	00	00	00	00	01	01	01	




Item	Code	Description	See page	18	22	25	26	28	30	32	34	36	38	45	46	L
001	0521050128	CH LAT D USAP		01	01	00	00	00	00	00	00	00	00	00	00	
001A	0521061784	(1980)RH SIDE FRAME		01	01	00	00	00	00	00	00	00	00	00	00	
001B	0571011825	BUSHING		02	02	02	02	02	02	02	02	02	02	02	02	
002	0511057742	CH LAT D USAP		00	00	01	00	00	00	00	00	00	00	00	00	
002A	0521065027	CH LAT DIR 3630		00	00	01	00	00	00	00	00	00	00	00	00	
003	0521050505	CH LAT D USAP SUP PP 26E500		00	00	00	01	00	00	00	00	00	00	00	00	
003A	0521064363	RIGHT SIDE FRAME		00	00	00	01	00	00	00	00	00	00	00	00	
004	0511057746	CH LAT D USAP SUP PP 28E500		00	00	00	00	01	00	00	00	00	00	00	00	
004A	0521064362	RIGHT SIDE FRAME		00	00	00	00	01	00	00	00	00	00	00	00	
005	0511056345	CH LAT D USAP S 30E50 MH		00	00	00	00	00	01	00	00	00	00	00	00	
005A	0511069812	RIGHT SIDE FRAME		00	00	00	00	00	01	00	00	00	00	00	00	
006	0511053741	CH LAT D SM USAP 30E50		00	00	00	00	00	00	01	00	00	00	00	00	
006A	0521066212	RIGHT FRAME		00	00	00	00	00	00	01	00	00	00	00	00	
007	0511057557	CH LAT D USAP SUP PP 34E450		00	00	00	00	00	00	00	01	00	00	00	00	
007A	0521062351	(5430) RH SIDE FRAME		00	00	00	00	00	00	00	01	00	00	00	00	
008	0511057654	CH LAT D USAP SUP PP 36E450		00	00	00	00	00	00	00	00	01	00	00	00	
008A	0521063019	RIGHT SIDE FRAME		00	00	00	00	00	00	00	00	01	01	00	00	
009	0501110704	RIGHT SIDE FRAME		00	00	00	00	00	00	00	00	00	01	01	00	
009A	0521063019	RIGHT SIDE FRAME		00	00	00	00	00	00	00	00	00	01	01	00	
010	0521063760	CENTRAL FRAME		00	00	00	00	00	00	00	00	00	00	00	00	
010A	0521046753	CH LAT D USAP SUP PP 46E450		00	00	00	00	00	00	00	00	00	00	00	00	
011	0521060930	FERTILIZER BEAM SUPPORT FIXER		04	04	04	04	04	04	06	00	03	00	00	00	
012	0521065318	DEPTH SUPPORT		00	00	00	00	00	00	00	00	05	00	00	00	
013	0521063052	LOWER FIXER		00	00	00	00	00	00	00	00	00	00	04	04	
014	0551015037	5/8" UNC X 210 X 198 FASTENER		08	04	06	06	06	06	12	10	06	00	00	00	
015	0571011070	5/8" UNC FASTENER		00	00	00	00	00	00	00	00	00	00	08	08	
016	0503010027	5/8" SPRING WASHER		16	08	12	12	12	12	12	20	06	16	16	16	
017	0503010013	5/8" NUT		16	08	12	12	12	12	12	20	06	16	16	16	
018	0511050400	CENTRAL RIGHT BOX FERTILIZER		01	00	00	00	00	00	00	00	00	00	00	00	
019	0501058806	RH SEED BOX LATERAL SUPPORT ASSY		00	01	00	01	00	00	00	00	00	00	00	00	
020	0511055650	LH SEED BOX SIDE SUPPORT ASSY		00	00	02	00	00	00	00	00	00	00	00	00	


Item	Code	Description	See page	18	22	25	26	28	30	32	34	36	38	45	46	L
021	0501058359	RH SEED BOX LATERAL SUPPORT ASSY		00	00	00	00	02	02	00	00	00	00	00	00	
022	0501059750	CENTRAL RIGHT BOX FERTILIZER		00	00	00	00	00	00	01	00	00	00	00	00	
023	0511057568	SEED BOX ASSY		00	00	00	00	00	00	00	01	00	00	00	00	
024	0511057569	BOX SEED		00	00	00	00	00	00	00	01	00	00	00	00	
025	0501058801	RH SEED BOX LATERAL SUPPORT ASSY		00	00	00	00	00	00	00	00	01	00	00	00	
026	0511051064	SUPPORT WITH DISTRIBUITOR		00	00	00	00	00	00	00	00	01	00	00	00	
027	0501059964	RH SEED BOX LATERAL SUPPORT ASSY		00	00	00	00	00	00	00	00	00	03	03	02	
028	0511051063	SUPPORT WITH DISTRIBUITOR		00	00	00	00	00	00	00	00	00	00	00	01	
029	0501010161	1/2" X 1.1/4" BOLT		04	04	04	08	08	08	08	08	08	08	08	08	
030	0503010920	1/2" X 1.1/2" BOLT		18	18	18	18	18	18	18	18	18	18	18	18	
031	0501013518	FLAT WASHER		18	18	18	18	18	18	18	18	18	18	18	18	
032	0503010019	1/2" SPRING WASHER		22	22	22	22	22	22	22	22	22	22	22	22	
033	0503010060	1/2" NUT		22	22	22	22	22	22	22	22	22	22	22	22	
034	0511051389	CAP SET USAP		12	12	12	12	12	12	12	12	12	12	12	12	
035	0511053377	COVER ASSY		06	06	06	06	06	06	06	06	06	06	06	06	
036	0511069800	SIDE HANDRAIL		01	01	00	00	00	00	00	00	00	00	00	00	
037	0521065022	REAR SIDE HANDRAIL		00	00	02	00	00	00	00	00	00	00	00	00	
038	0511069800	SIDE HANDRAIL		00	00	00	02	00	00	00	00	00	00	00	00	
039	0521064096	LEFT HANDRAIL		00	00	00	00	02	02	02	00	00	00	00	00	
040	0521065323	SIDE HANDRAIL		00	00	00	00	00	00	00	01	00	00	00	00	
041	0521062433	RIGHT HANDRAIL		00	00	00	00	00	00	00	01	00	00	00	00	
042	0521063823	HANDRAIL INTERMEDIARY		00	00	00	00	00	00	00	00	01	00	00	00	
043	0521064096	LEFT HANDRAIL		00	00	00	00	00	00	00	00	00	02	02	02	
044	0521063307	HANDRAIL INTERMEDIARIO		00	00	00	00	00	00	00	00	00	01	00	00	
045	0521062403	HANDRAIL INTERMEDIARY		00	00	00	00	00	00	00	00	00	00	01	01	
046	0561014688	RH PLATFORM SUPPORT		01	01	01	01	01	01	01	01	01	01	01	01	
047	0501010161	1/2" X 1.1/4" BOLT		04	04	04	04	04	04	04	04	04	04	04	04	
048	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04	04	04	04	04	04	04	04	04	04	04	04	
049	0503010019	1/2" SPRING WASHER		08	08	08	08	08	08	08	08	08	08	08	08	
050	0503010060	1/2" NUT		08	08	08	08	08	08	08	08	08	08	08	08	
051	0511053323	NYLON LUG ASSY		02	02	02	02	02	02	02	02	02	02	02	02	
051A	0503011957	NYLON LUG		02	02	02	02	02	02	02	02	02	02	02	02	
051B	0503010371	5/16" X 1" BOLT		04	04	04	04	04	04	04	04	04	04	04	04	
051C	0503010179	5/16" ZN SPRING WASHER		04	04	04	04	04	04	04	04	04	04	04	04	
051D	0503010337	5/16" NUT		04	04	04	04	04	04	04	04	04	04	04	04	
052	0511053320	ASSY SIDE LADDER		01	01	01	01	01	01	01	01	01	01	01	01	
052A	0511069819	SIDE LADDER		01	01	01	01	01	01	01	01	01	01	01	01	
052B	0502012742	FIXER SUPPORT LADDER		02	02	02	02	02	02	02	02	02	02	02	02	
052C	0503013357	3/8" SELF-ADJUSTING NUT		02	02	02	02	02	02	02	02	02	02	02	02	
052D	0501010984	FLAT WASHER		02	02	02	02	02	02	02	02	02	02	02	02	
052E	0503011179	3/8" X 2-1/4" BOLT		02	02	02	02	02	02	02	02	02	02	02	02	
052F	0503010237	3/8" X 1" BOLT		04	04	04	04	04	04	04	04	04	04	04	04	
052G	0503010025	3/8" SPRING WASHER		04	04	04	04	04	04	04	04	04	04	04	04	
052H	0503010026	3/8" NUT		04	04	04	04	04	04	04	04	04	04	04	04	
053	0511069802	PLATFORM 1880 USAP		01	01	00	01	00	00	00	00	00	00	00	00	
054	0521064093	PLATFORM		00	00	01	00	00	00	00	00	00	00	00	00	
055	0521063632	PLATLFORM		00	00	00	01	00	00	00	00	00	00	00	00	
056	0511069820	PLATFORM 2380 USAP		00	00	00	00	02	00	00	00	00	02	02	01	
057	0521062334	PLATFORM CENTER		00	00	00	00	00	00	01	00	00	00	01	01	
058	0521061799	PLATFORM CENTER		00	00	00	00	00	00	00	01	00	00	00	00	
059	0521066164	PLATFORM CENTER		00	00	00	00	00	00	00	01	00	00	00	00	
060	0521062333	PLATFORM SIDE		00	00	00	00	00	00	00	00	01	01	01	01	
061	0521062402	COMPLETE PLATFORM		00	00	00	00	00	00	00	00	01	00	00	00	
062	0501010942	3/8" X 1-1/4" BOLT		04	04	04	04	06	06	06	06	08	08	08	08	
063	0501013518	FLAT WASHER		04	04	04	04	06	06	06	06	08	08	08	08	
064	0503010025	3/8" SPRING WASHER		04	04	04	04	06	06	06	06	08	08	08	08	
065	0503010026	3/8" NUT		04	04	04	04	06	06	06	06	08	08	08	08	
066	0501010161	1/2" X 1.1/4" BOLT		08	08	08	08	08	08	08	08	08	08	08	08	
067	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		08	08	08	08	08	08	08	08	08	08	08	08	

Item	Code	Description	See page	18	22	25	26	28	30	32	34	36	38	45	46	L
068	0501010160	1/2" X 3" BOLT		06	06	06	06	08	08	08	08	10	10	10	10	
069	0501013519	FLAT WASHER		12	12	12	12	14	14	14	14	20	20	20	20	
070	0503010019	1/2" SPRING WASHER		22	22	22	22	22	22	22	22	22	22	22	22	
071	0503010060	1/2" NUT		22	22	22	22	22	22	22	22	22	22	22	22	
072	0501012140	FLAT WASHER		04	04	04	04	06	06	06	06	08	08	08	08	
073	0521043442	WHEELS RIGHT WITH TRANSMISSION		01	01	01	01	01	01	01	00	00	01	00	00	00
074	0521043437	CENTRAL / SIDE WHEEL WITHOUT TRANSMISSION		01	01	01	01	01	01	01	00	02	01	00	00	00
075	0511049949	WHEELED SET RIGHT WITHOUT TRANSMISSION		00	00	00	00	00	00	01	00	00	00	00	00	
076	0511049948	WHEELED LEFT SET OF TRANSMISSION		00	00	00	00	00	00	01	00	00	00	00	00	
077	0521043454	CARRYING WHEELS SIDE S/TRANSMISSION		00	00	00	00	00	00	00	00	00	02	01	01	
078	0521043452	WHEELS RIGHT TRANSMISSION		00	00	00	00	00	00	00	00	00	00	01	01	
079	0909092412	ROW ASSY		18	22	25	26	28	30	32	34	36	38	45	46	
080	0571012013	TRANSPORT LOCK		05	05	06	06	07	07	08	08	09	09	10	12	
081	0571012014	TRANSPORT LOCK		05	05	06	06	07	07	08	08	09	09	10	12	
082	0561016761	3/4 X 1900 HEX AXLE		01	01	00	02	00	00	00	00	00	00	00	00	
083	0561018836	3/4" X 3060 HEX AXLE		00	00	01	00	00	00	00	00	00	00	00	00	
084	0561016762	3/4 X 2390 HEX AXLE		00	00	00	00	02	02	01	00	00	00	00	00	
085	0561018821	HEX AXLE 3/4 X 2600		00	00	00	00	00	00	00	02	02	00	00	00	
086	0551019082	3/4 X 3750 HEX AXLE		00	00	00	00	00	00	00	00	00	02	00	00	
087	0571013244	HEX AXLE		00	00	00	00	00	00	00	00	00	00	01	01	
088	0571013243	HEX AXLE		00	00	00	00	00	00	00	00	00	00	01	01	
089	0561015837	SLEEVE 31,75		01	01	01	01	01	01	01	01	01	01	01	01	
090	0503010523	1/4" X 2" COTTERPIN		01	01	01	01	01	01	01	01	01	01	01	01	
091	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		16	16	20	22	24	26	28	30	32	36	38	40	
091A	0502012699	LATCH GLOVE BOX TRANSMISSION		16	16	20	22	24	26	28	30	32	36	38	40	
091B	0503010256	3/8" X 3/4" BOLT		16	16	20	22	24	26	28	30	32	36	38	40	
092	0511053648	GEAR		01	01	01	01	01	01	01	01	01	01	01	01	
092A	0521063774	GEAR ASSY		01	01	01	01	01	01	01	01	01	01	01	01	
092B	0503016587	CHAIN LINK + MENDING		01	01	01	01	01	01	01	01	01	01	01	01	
093	0511051500	SET DUCT UPPER SEED RIGHT		05	05	04	04	09	10	10	12	12	14	17	17	
094	0511050507	DRIVER AIR		01	00	00	00	00	00	00	00	00	00	00	00	
095	0511056154	DRIVER AIR		00	01	00	00	00	00	00	00	00	00	00	00	
096	0511056318	DRIVER AIR		00	00	01	00	00	00	00	00	00	00	00	00	
097	0511052539	AIR CONDUCTOR LAT 07 BOCAS		00	00	00	01	00	00	00	00	00	00	00	00	
098	0501059953	DRIVER AIR		00	00	00	00	01	01	01	01	00	00	00	00	
099	0511050025	DRIVER SIDE AIR		00	00	00	00	00	00	00	00	01	00	00	00	
100	0511051786	DRIVER AIR		00	00	00	00	00	00	00	00	00	01	00	00	
101	0511055151	DRIVER AIR		00	00	00	00	00	00	00	00	00	00	01	01	
102	0581010572	AIR CONDUCTOR 1.1/2 X 1300 USAP SUP PP		18	22	25	26	28	30	32	34	36	38	45	46	
103	0571019716	ADAPTER		18	22	25	26	28	30	32	34	36	38	45	46	
104	0503031436	AIR DITRIBUTOR PUMP		01	01	01	01	01	02	02	02	02	03	03	03	
105	0571012769	DRIVER AIR LEFT		02	02	02	02	02	02	02	02	02	02	02	02	
106	0571012770	CONDUCTOR OF AIR LAW		02	02	02	02	02	02	02	02	02	02	02	02	
107	0503011087	3/8" X 1" BOLT		06	06	06	06	06	06	06	06	06	06	06	06	
108	0503010849	3/8" X 1-1/2" BOLT		02	02	02	02	02	02	02	02	02	02	02	02	
109	0503010025	3/8" SPRING WASHER		08	08	08	08	08	08	08	08	08	08	08	08	
110	0503010026	3/8" NUT		08	08	08	08	08	08	08	08	08	08	08	08	
111	0521018402	AIR CONDUCTOR CLAMP		04	04	04	04	04	04	04	04	04	04	04	04	
112	0503010371	5/16" X 1" BOLT		08	08	08	08	08	08	08	08	08	08	08	08	
113	0503010179	5/16" ZN SPRING WASHER		08	08	08	08	08	08	08	08	08	08	08	08	
114	0503010337	5/16" NUT		08	08	08	08	08	08	08	08	08	08	08	08	
115	0511059406	TURBINE P.P MOUNTED		01	01	01	01	01	01	01	01	01	01	01	01	
116	0521045398	TURBINE HYDRAULIQUE		01	01	01	01	01	01	01	01	01	01	01	01	
117	0571012406	FIXER MOVEL TURBINE		01	01	01	01	01	01	01	01	01	01	01	01	
118	0571011070	5/8" UNC FASTENER		02	02	02	02	02	02	02	02	02	02	02	02	
119	0503010232	5/8" X 1.3/4" BOLT		02	02	02	02	02	02	02	02	02	02	02	02	
120	0503012412	5/8 UNC SELF LOCKING NUT		02	02	02	02	02	02	02	02	02	02	02	02	

Item	Code	Description	See page	18	22	25	26	28	30	32	34	36	38	45	46	L
121	0551019056	SIDE PLATFORM SUPPORT		06	06	06	06	06	06	06	06	06	06	06	06	06
122	0511051807	HOSE HOLDER ASSY		02	02	02	02	02	02	02	02	02	02	02	02	02
122A	0571011154	SUPPORT FIXING BASE		02	02	02	02	02	02	02	02	02	02	02	02	02
122B	0501010984	FLAT WASHER		02	02	02	02	02	02	02	02	02	02	02	02	02
122C	0521063079	HOSE HOLDER ASSY		02	02	02	02	02	02	02	02	02	02	02	02	02
122D	0503010025	3/8" SPRING WASHER		04	04	04	04	04	04	04	04	04	04	04	04	04
122E	0503010026	3/8" NUT		04	04	04	04	04	04	04	04	04	04	04	04	04
122F	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04	04	04	04	04	04	04	04	04	04	04	04	04
122G	0571011070	5/8" UNC FASTENER		02	02	02	02	02	02	02	02	02	02	02	02	02
122H	0503012412	5/8 UNC SELF LOCKING NUT		04	04	04	04	04	04	04	04	04	04	04	04	04
123	0511053030	SET HIDRAULICO		01	01	00	00	00	00	00	00	00	00	00	00	00
124	0511055703	SET HIDRAULICO		00	00	01	00	00	00	00	00	00	00	00	00	00
125	0511053338	SET HIDRAULICO		00	00	00	01	00	00	00	00	00	00	00	00	00
126	0511053487	SET HIDRAULICO		00	00	00	00	01	01	00	00	00	00	00	00	00
127	0511053703	SET HIDRAULICO		00	00	00	00	00	00	01	00	00	00	00	00	00
128	0511057558	SET HIDRAULICO		00	00	00	00	00	00	00	01	00	00	00	00	00
129	0511056911	SET HIDRAULICO		00	00	00	00	00	00	00	00	01	00	00	00	00
130	0511053652	SET HIDRAULICO		00	00	00	00	00	00	00	00	00	01	01	01	01




Item	Code	Description	See page	18	22	25	26	28	30	32	34	36	38	45	46	L
021	0501058805	LH SEED BOX SIDE SUPPORT ASSY		00	00	00	00	02	02	00	00	00	00	00	00	00
021.	0501058358	LH SEED BOX SIDE SUPPORT ASSY		00	00	00	00	02	02	00	00	00	00	00	00	00
022	0501059751	LH CENTRAL BOX FERTILIZER		00	00	00	00	00	00	01	00	00	00	00	00	00
023	0511057568	SEED BOX ASSY		00	00	00	00	00	00	00	01	00	00	00	00	00
024	0511057569	BOX SEED		00	00	00	00	00	00	00	01	00	00	00	00	00
025	0501058800	LH SEED BOX SIDE SUPPORT ASSY		00	00	00	00	00	00	00	00	01	00	00	00	00
026	0511051063	SUPPORT WITH DISTRIBUITOR		00	00	00	00	00	00	00	00	01	00	00	00	00
027	0501059963	LH SEED BOX SIDE SUPPORT ASSY		00	00	00	00	00	00	00	00	00	03	03	02	
028	0511051064	SUPPORT WITH DISTRIBUITOR		00	00	00	00	00	00	00	00	00	00	00	01	
029	0501010161	1/2" X 1.1/4" BOLT		04	04	04	08	08	08	08	08	08	08	08	08	08
030	0503010920	1/2" X 1.1/2" BOLT		18	18	18	18	18	18	18	18	18	18	18	18	18
031	0501013518	FLAT WASHER		18	18	18	18	18	18	18	18	18	18	18	18	18
032	0503010019	1/2" SPRING WASHER		22	22	22	22	22	22	22	22	22	22	22	22	22
033	0503010060	1/2" NUT		22	22	22	22	22	22	22	22	22	22	22	22	22
034	0511051389	CAP SET USAP		12	12	12	12	12	12	12	12	12	12	12	12	12
035	0511053377	COVER ASSY		06	06	06	06	06	06	06	06	06	06	06	06	06
036	0511069800	SIDE HANDRAIL		01	01	00	00	00	00	00	00	00	00	00	00	00
037	0521065022	REAR SIDE HANDRAIL		00	00	02	00	00	00	00	00	00	00	00	00	00
038	0511069800	SIDE HANDRAIL		00	00	00	02	00	00	00	00	00	00	00	00	00
039	0521064096	LEFT HANDRAIL		00	00	00	00	02	02	02	00	00	00	00	00	00
040	0521065323	SIDE HANDRAIL		00	00	00	00	00	00	00	01	00	00	00	00	00
041	0521062433	RIGHT HANDRAIL		00	00	00	00	00	00	00	01	00	00	00	00	00
042	0521063823	HANDRAIL INTERMEDIARY		00	00	00	00	00	00	00	00	01	00	00	00	00
043	0521064096	LEFT HANDRAIL		00	00	00	00	00	00	00	00	00	02	02	02	02
044	0521063307	HANDRAIL INTERMEDIARIO		00	00	00	00	00	00	00	00	00	01	00	00	00
045	0521062403	HANDRAIL INTERMEDIARY		00	00	00	00	00	00	00	00	00	00	01	01	01
046	0561014688	RH PLATFORM SUPPORT		01	01	01	01	01	01	01	01	01	01	01	01	01
047	0501010161	1/2" X 1.1/4" BOLT		04	04	04	04	04	04	04	04	04	04	04	04	04
048	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04	04	04	04	04	04	04	04	04	04	04	04	04
049	0503010019	1/2" SPRING WASHER		08	08	08	08	08	08	08	08	08	08	08	08	08
050	0503010060	1/2" NUT		08	08	08	08	08	08	08	08	08	08	08	08	08
051	0511053323	NYLON LUG ASSY		02	02	02	02	02	02	02	02	02	02	02	02	02
051A	0503011957	NYLON LUG		02	02	02	02	02	02	02	02	02	02	02	02	02
051B	0503010371	5/16" X 1" BOLT		04	04	04	04	04	04	04	04	04	04	04	04	04
051C	0503010179	5/16" ZN SPRING WASHER		04	04	04	04	04	04	04	04	04	04	04	04	04
051D	0503010337	5/16" NUT		04	04	04	04	04	04	04	04	04	04	04	04	04
052	0511053320	ASSY SIDE LADDER		01	01	01	01	01	01	01	01	01	01	01	01	01
052A	0511069819	SIDE LADDER		01	01	01	01	01	01	01	01	01	01	01	01	01
052B	0502012742	FIXER SUPPORT LADDER		02	02	02	02	02	02	02	02	02	02	02	02	02
052C	0503013357	3/8" SELF-ADJUSTING NUT		02	02	02	02	02	02	02	02	02	02	02	02	02
052D	0501010984	FLAT WASHER		02	02	02	02	02	02	02	02	02	02	02	02	02
052E	0503011179	3/8" X 2-1/4" BOLT		02	02	02	02	02	02	02	02	02	02	02	02	02
052F	0503010237	3/8" X 1" BOLT		04	04	04	04	04	04	04	04	04	04	04	04	04
052G	0503010025	3/8" SPRING WASHER		04	04	04	04	04	04	04	04	04	04	04	04	04
052H	0503010026	3/8" NUT		04	04	04	04	04	04	04	04	04	04	04	04	04
053	0511069802	PLATFORM 1880 USAP		01	01	00	01	00	00	00	00	00	00	00	00	00
054	0521064093	PLATFORM		00	00	01	00	00	00	00	00	00	00	00	00	00
055	0521063632	PLATLFORM		00	00	00	01	00	00	00	00	00	00	00	00	00
056	0511069820	PLATFORM 2380 USAP		00	00	00	00	02	02	00	00	00	02	02	01	
057	0521062334	PLATFORM CENTER		00	00	00	00	00	00	01	00	00	00	01	01	
058	0521061799	PLATFORM CENTER		00	00	00	00	00	00	00	01	00	00	00	00	00
059	0521066164	PLATFORM CENTER		00	00	00	00	00	00	00	01	00	00	00	00	00
060	0521062333	PLATFORM SIDE		00	00	00	00	00	00	00	00	01	01	01	01	01
061	0521062402	COMPLETE PLATFORM		00	00	00	00	00	00	00	00	01	00	00	00	00
062	0501010942	3/8" X 1-1/4" BOLT		04	04	04	04	06	06	06	06	08	08	08	08	08
063	0501013518	FLAT WASHER		04	04	04	04	06	06	06	06	08	08	08	08	08
064	0503010025	3/8" SPRING WASHER		04	04	04	04	06	06	06	06	08	08	08	08	08
065	0503010026	3/8" NUT		04	04	04	04	06	06	06	06	08	08	08	08	08
066	0501010161	1/2" X 1.1/4" BOLT		08	08	08	08	08	08	08	08	08	08	08	08	08




Item	Code	Description	See page	18	22	25	26	28	30	32	34	36	38	45	46	L
067	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		08	08	08	08	08	08	08	08	08	08	08	08	08
068	0501010160	1/2" X 3" BOLT		06	06	06	06	08	08	08	08	10	10	10	10	10
069	0501013519	FLAT WASHER		12	12	12	12	14	14	14	14	20	20	20	20	20
070	0503010019	1/2" SPRING WASHER		22	22	22	22	22	22	22	22	22	22	22	22	22
071	0503010060	1/2" NUT		22	22	22	22	22	22	22	22	22	22	22	22	22
072	0501012140	FLAT WASHER		04	04	04	04	06	06	06	06	08	08	08	08	08
073	0521043442	WHEELS RIGHT WITH TRANSMISSION		01	01	01	01	01	01	01	00	00	01	00	00	00
074	0521043437	CENTRAL / SIDE WHEEL WITHOUT TRANSMISSION		01	01	01	01	01	01	01	00	02	01	00	00	00
075	0511049949	WHEELED SET RIGHT WITHOUT TRANSMISSION		00	00	00	00	00	00	01	00	00	00	00	00	00
076	0511049948	WHEELED LEFT SET OF TRANSMISSION		00	00	00	00	00	00	01	00	00	00	00	00	00
077	0521043454	CARRYING WHEELS SIDE S/TRANSMISSION		00	00	00	00	00	00	00	00	00	02	01	01	01
078	0521043452	WHEELS RIGHT TRANSMISSION		00	00	00	00	00	00	00	00	00	00	01	01	01
079	0909092412	ROW ASSY		18	22	25	26	28	30	32	34	36	38	45	46	46
080	0571012013	TRANSPORT LOCK		05	05	06	06	07	07	08	08	09	09	10	12	12
081	0571012014	TRANSPORT LOCK		05	05	06	06	07	07	08	08	09	09	10	12	12
082	0561016761	3/4 X 1900 HEX AXLE		01	01	00	02	00	00	00	00	00	00	00	00	00
083	0561018836	3/4" X 3060 HEX AXLE		00	00	01	00	00	00	00	00	00	00	00	00	00
084	0561016762	3/4 X 2390 HEX AXLE		00	00	00	00	02	02	01	00	00	00	00	00	00
085	0561018821	HEX AXLE 3/4 X 2600		00	00	00	00	00	00	00	02	02	00	00	00	00
086	0551019082	3/4 X 3750 HEX AXLE		00	00	00	00	00	00	00	00	00	02	00	00	00
087	0571013244	HEX AXLE		00	00	00	00	00	00	00	00	00	00	01	01	01
088	0571013243	HEX AXLE		00	00	00	00	00	00	00	00	00	00	01	01	01
089	0561015837	SLEEVE 31,75		01	01	01	01	01	01	01	01	01	01	01	01	01
090	0503010523	1/4" X 2" COTTERPIN		01	01	01	01	01	01	01	01	01	01	01	01	01
091	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		16	16	20	22	24	26	28	30	32	36	38	40	40
091A	0502012699	LATCH GLOVE BOX TRANSMISSION		16	16	20	22	24	26	28	30	32	36	38	40	40
091B	0503010256	3/8" X 3/4" BOLT		16	16	20	22	24	26	28	30	32	36	38	40	40
092	0511053648	GEAR		01	01	01	01	01	01	01	01	01	01	01	01	01
092A	0521063774	GEAR ASSY		01	01	01	01	01	01	01	01	01	01	01	01	01
092B	0503016587	CHAIN LINK + MENDING		01	01	01	01	01	01	01	01	01	01	01	01	01
093	0511051501	SET DUCT UPPER SEED LEDT		05	05	04	04	09	10	10	12	12	14	17	17	17
094	0511050507	DRIVER AIR		01	00	00	00	00	00	00	00	00	00	00	00	00
095	0511056154	DRIVER AIR		00	01	00	00	00	00	00	00	00	00	00	00	00
096	0511056318	DRIVER AIR		00	00	01	00	00	00	00	00	00	00	00	00	00
097	0511052539	AIR CONDUCTOR LAT 07 BOCAS		00	00	00	01	00	00	00	00	00	00	00	00	00
098	0501059953	DRIVER AIR		00	00	00	00	01	01	01	01	00	00	00	00	00
099	0511050025	DRIVER SIDE AIR		00	00	00	00	00	00	00	00	01	00	00	00	00
100	0511051786	DRIVER AIR		00	00	00	00	00	00	00	00	00	01	00	00	00
101	0511055151	DRIVER AIR		00	00	00	00	00	00	00	00	00	00	01	01	01
102	0581010572	AIR CONDUCTOR 1.1/2 X 1300 USAP SUP PP		18	22	25	26	28	30	32	34	36	38	45	46	46
103	0571019716	ADAPTER		18	22	25	26	28	30	32	34	36	38	45	46	46
104	0503031436	AIR DITRIBUTOR PUMP		01	01	01	01	01	02	02	02	02	03	03	03	03
105	0571012769	DRIVER AIR LEFT		02	02	02	02	02	02	02	02	02	02	02	02	02
106	0571012770	CONDUCTOR OF AIR LAW		02	02	02	02	02	02	02	02	02	02	02	02	02
107	0503011087	3/8" X 1" BOLT		06	06	06	06	06	06	06	06	06	06	06	06	06
108	0503010849	3/8" X 1-1/2" BOLT		02	02	02	02	02	02	02	02	02	02	02	02	02
109	0503010025	3/8" SPRING WASHER		08	08	08	08	08	08	08	08	08	08	08	08	08
110	0503010026	3/8" NUT		08	08	08	08	08	08	08	08	08	08	08	08	08
111	0521018402	AIR CONDUCTOR CLAMP		04	04	04	04	04	04	04	04	04	04	04	04	04
112	0503010371	5/16" X 1" BOLT		08	08	08	08	08	08	08	08	08	08	08	08	08
113	0503010179	5/16" ZN SPRING WASHER		08	08	08	08	08	08	08	08	08	08	08	08	08
114	0503010337	5/16" NUT		08	08	08	08	08	08	08	08	08	08	08	08	08
115	0511059406	TURBINE P.P MOUNTED		01	01	01	01	01	01	01	01	01	01	01	01	01
116	0521045398	TURBINE HYDRAULIQUE		01	01	01	01	01	01	01	01	01	01	01	01	01
117	0571012406	FIXER MOVEL TURBINE		01	01	01	01	01	01	01	01	01	01	01	01	01
118	0571011070	5/8" UNC FASTENER		02	02	02	02	02	02	02	02	02	02	02	02	02
119	0503010232	5/8" X 1.3/4" BOLT		02	02	02	02	02	02	02	02	02	02	02	02	02

Item	Code	Description	See page	18	22	25	26	28	30	32	34	36	38	45	46	L
120	0503012412	5/8 UNC SELF LOCKING NUT		02	02	02	02	02	02	02	02	02	02	02	02	02
121	0551019056	SIDE PLATFORM SUPPORT		06	06	06	06	06	06	06	06	06	06	06	06	06
122	0511051807	HOSE HOLDER ASSY		02	02	02	02	02	02	02	02	02	02	02	02	02
122A	0571011154	SUPPORT FIXING BASE		02	02	02	02	02	02	02	02	02	02	02	02	02
122B	0501010984	FLAT WASHER		02	02	02	02	02	02	02	02	02	02	02	02	02
122C	0521063079	HOSE HOLDER ASSY		02	02	02	02	02	02	02	02	02	02	02	02	02
122D	0503010025	3/8" SPRING WASHER		04	04	04	04	04	04	04	04	04	04	04	04	04
122E	0503010026	3/8" NUT		04	04	04	04	04	04	04	04	04	04	04	04	04
122F	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04	04	04	04	04	04	04	04	04	04	04	04	04
122G	0571011070	5/8" UNC FASTENER		02	02	02	02	02	02	02	02	02	02	02	02	02
122H	0503012412	5/8 UNC SELF LOCKING NUT		04	04	04	04	04	04	04	04	04	04	04	04	04
123	0511053030	SET HIDRAULICO		01	01	00	00	00	00	00	00	00	00	00	00	00
124	0511055703	SET HIDRAULICO		00	00	01	00	00	00	00	00	00	00	00	00	00
125	0511053338	SET HIDRAULICO		00	00	00	01	00	00	00	00	00	00	00	00	00
126	0511053487	SET HIDRAULICO		00	00	00	00	01	01	00	00	00	00	00	00	00
127	0511053703	SET HIDRAULICO		00	00	00	00	00	00	01	00	00	00	00	00	00
128	0511057558	SET HIDRAULICO		00	00	00	00	00	00	00	01	00	00	00	00	00
129	0511056911	SET HIDRAULICO		00	00	00	00	00	00	00	00	01	00	00	00	00
130	0511053652	SET HIDRAULICO		00	00	00	00	00	00	00	00	00	01	01	01	01




Item	Code	Description	See page	32	33	34	35	36	37	39	40	42	45	46	L.
26	0501012140	FLAT WASHER		08	08	08	08	08	08	08	08	08	08	08	08
27	0503010027	5/8" SPRING WASHER		04	04	04	04	04	04	04	04	04	04	04	04
28	0503010013	5/8" NUT		04	04	04	04	04	04	04	04	04	04	04	04
29	0511054315	FRENCH MÃO DIREITA		01	00	00	01	00	00	00	00	00	00	00	00
29.	0511053635	FRENCH HAND		00	00	01	00	01	01	01	00	00	00	00	00
29..	0511053759	FRENCH HAND		00	00	00	00	00	00	00	01	01	01	01	01
29A	0521063865	FRENCH HAND		01	00	00	01	00	00	00	00	00	00	00	00
29A.	0521062246	(5780) LEFT ATTACHMENT BAR		00	01	01	00	01	01	01	00	00	00	00	00
29A..	0521063013	FRENCH HAND		00	00	00	00	00	00	00	01	01	01	01	01
29B	0502012702	BODY SUPPORT CLAMP		08	00	08	08	08	08	08	16	16	16	16	16
29C	0503011135	BOLT		08	00	08	08	08	08	08	16	16	16	16	16
29D	0503010180	7/16" SPRING WASHER		08	00	08	08	08	08	08	16	16	16	16	16
29E	0521062283	OIL TUBE		00	00	02	00	00	00	00	00	00	00	00	00
29E.	0521063057	OIL TUBE		00	00	00	00	00	00	00	05	05	05	05	05
29F	0521062284	OIL TUBE		00	00	02	00	00	00	00	00	00	00	00	00
29F.	0521063313	OIL TUBE		00	00	00	00	00	00	00	02	02	02	02	02
30	0511054316	FRENCH LEFT HAND		01	00	00	01	00	00	00	00	00	00	00	00
30.	0511053518	LEFT ATTACHMENT BAR		00	01	01	00	01	01	01	00	00	00	00	00
30..	0511053758	LEFT FRENCH HAND		00	00	00	00	00	00	00	01	01	01	01	01
30A	0521063865	FRENCH HAND		01	00	00	01	00	00	00	00	00	00	00	00
30A.	0521062335	(5780) LEFT FRENCH HAND		00	01	01	00	01	01	01	00	00	00	00	00
30A..	0521063015	LEFT FRENCH HAND		00	00	00	00	00	00	00	01	01	01	01	01
30B	0571014676	GUTTER 20 X 38 X 2020 USAP		01	00	00	01	00	00	00	00	00	00	00	00
30B.	0571010035	CALHA 20 X 38 X 2340		00	02	02	00	02	02	02	00	00	00	00	00
30B..	0571013212	GUTTER 20 X 38 X 2020 USAP		00	00	00	00	00	00	00	03	03	03	03	03
30C	0571013213	GUTTER CHASSI LAT 20X38X2400 USAP		01	00	00	01	00	00	00	00	00	00	00	00
30D	0571011891	GUIDE RAIL		01	01	01	01	01	01	01	00	00	00	00	00
30D.	0571011891	GUIDE RAIL		00	00	00	00	00	00	00	02	02	02	02	02
30E	0503011952	5/16" X 3/4" BOLT		02	02	02	02	02	02	02	04	04	04	04	04
30F	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02	02	02	02	02	02	04	04	04	04	04
30G	0503010179	5/16" ZN SPRING WASHER		02	02	02	02	02	02	02	04	04	04	04	04
30H	0503010337	5/16" NUT		02	02	02	02	02	02	02	04	04	04	04	04
30I	0502012702	BODY SUPPORT CLAMP		04	05	05	04	05	05	05	16	16	16	16	16
30J	0503010355	7/16" X 1" BOLT		04	04	04	04	04	04	04	16	16	16	16	16
30K	0503011135	BOLT		04	05	05	04	05	05	05	16	16	16	16	16
30L	0501012803	FLAT WASHER		04	04	04	04	04	04	04	04	04	04	04	04
30M	0503010180	7/16" SPRING WASHER		08	09	09	08	09	09	09	16	16	16	16	16
30N	0521062283	OIL TUBE		00	00	02	00	02	02	02	00	00	00	00	00
30N.	0521063057	OIL TUBE		00	00	00	00	00	00	00	05	05	05	05	05
30O	0521063313	OIL TUBE		00	00	00	00	00	00	00	02	02	02	02	02
31	0511053773	SET HIDRAULICO		02	02	00	02	00	00	00	00	00	00	00	00
32	0511055025	SET HIDRAULICO		00	00	02	00	00	02	00	00	00	00	00	00
33	0511053618	SET HIDRAULICO		00	00	00	00	02	00	02	00	00	00	00	00
34	0511053652	SET HIDRAULICO		00	00	00	00	00	00	00	02	02	02	02	02
35	0511048176	HITCH ASSY		01	01	01	01	01	01	01	00	00	00	00	00
35A	0511069472	DRAWBAR		01	01	01	01	01	01	01	00	00	00	00	00
35B	0551018417	AXLE HITCH		02	02	02	02	02	02	02	00	00	00	00	00
35C	0503030012	HAIR PIN		02	02	02	02	02	02	02	00	00	00	00	00
35D	0561013456	GUIDE DRAWBAR ASSY		02	02	02	02	02	02	02	00	00	00	00	00
35E	0501010276	BOLT		04	04	04	04	04	04	04	00	00	00	00	00
35F	0501010059	1.5/8 NUT		04	04	04	04	04	04	04	00	00	00	00	00
35G	0503010012	1" SPRING WASHER		04	04	04	04	04	04	04	00	00	00	00	00
35H	0521012533	COUPLING SHAFT		01	01	01	01	01	01	01	00	00	00	00	00
35I	0561017306	COUPLING SHAFT		01	01	01	01	01	01	01	00	00	00	00	00
35J	0503030119	LOCK PIN		02	02	02	02	02	02	02	00	00	00	00	00
36	0511052794	HITCH ASSY		00	00	00	00	00	00	00	01	01	01	01	01
36A	0521063768	HITCH ASSY		00	00	00	00	00	00	00	01	01	01	01	01
36B	0571012835	AXLE LOWER		00	00	00	00	00	00	00	02	02	02	02	02
36C	0503030119	LOCK PIN		00	00	00	00	00	00	00	02	02	02	02	02


[illegible]




Item	Code	Description	See page	QT
01	0511054256	COROT WATER		01
01A	0503014820	COROTE BLACK WATER		01
01B	0571014702	SLEEVE CONDUTOR SUPPORT COROT		02
02	0511053122	TOOLS BOX ASSY		01
02A	0521063661	BOX OF TOOLS		01
02B	0551018356	BOX OF TOOLS COVER ASSY		01
02C	0521010528	0.3" X 1.6" COUPLING SHAFT		02
02D	0503010140	1/8" X 3/4" COTTERPIN		02
02E	0503011907	PMC 594-S NYLON LUG		01
02F	0503010358	5/16" X 5/8" BOLT		02
02G	0503010179	5/16" ZN SPRING WASHER		02
02H	0503010337	5/16" NUT		02
03	0571012879	PRISONER 1/2 X 190		02
04	0511017302	FLAT WASHER		04
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
00	0511043675	HYDRAULIC CYLINDER	8	01
01	0511069504	101,6 X 557 CYLINDER CASE		01
02	0502011222	0.56" END CAP		01
03	0551018552	50,8 X 685 ROD		01
04	0503010817	1.1/4" SELF LOCKING NUT		01
05	0502040747	32.54 CLEVIS CLAMP		01
06	0503011094	3/8" X 2" BOLT		01
07	0503010025	3/8" SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0502011220	2" X 4.5" RING SUPPORT		01
10	0502011221	2.0" X 4.5" PISTON		01
11	0503011890	3750-3750 GASKET		02
12	0503011891	W2-4500-500 RING G.E		01
13	0503010039	D-2000 SCRAPER RING		01
14	0503010991	1870-2000-375-B GASKET		01
15	0503011893	BACK-UP RING, 8-346		01
16	0503011892	O' RING, 2-346 N 3006-9B		01
17	0503010952	W2-2250-500 RING		01
18	0503010345	2-218 N 3006-9B O'RING		01
19	0503030384	CON PLUG N-001		02



Item	Code	Description	See page	QT
00	0521043416	HYDRAULIC CYLINDER	9	01
01	0521062972	63,50 X 257 CYLINDER CASE		01
02	0521012130	1.5" X 13" SHAFT		01
03	0502010783	1.5" X 2.5" PISTON		01
04	0502010780	RING SUPPORT		01
05	0502010471	MOBILE COVER		01
06	0503010063	1" SELF-ALIGNING NUT		01
07	0503010160	2500 2000 GASKET		02
08	0503010285	2-222 N 3006-9B O'RING		01
09	0503010973	W2-2500-500 PK O'RING G.E		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503011058	8-330 BACK-UP RING		01
12	0503010989	1870-1500-375-B GASKET		01
13	0503010161	2-330 N 3006 9B O'RING		01
14	0503010970	W1-1650-500 PK O'RING G.E		01
15	0511070058	GUIDE HIDRAULIC		01




Item	Code	Description	See page	QT
00	0511049549	CYLINDER HEADER HYDRAULIC	10	01
01	0521062362	CYLINDER CASE		01
02	0521062361	ROD CILINDER DRAWBAR HYDRAULIC		01
03	0502010382	5" END CAP		01
04	0503010817	1.1/4" SELF LOCKING NUT		01
05	0503010552	PACKING 3750-4250-625-B		02
06	0503010952	W2-2250-500 RING		01
07	0503010991	1870-2000-375-B GASKET		01
08	0502010963	2.0" X 5.0" PISTON		01
09	0503010345	2-218 N 3006-9B O'RING		01
10	0503010351	2-425 N 3006-9B O'RING		01
11	0503011062	8-425 BACK-UP RING		01
12	0502012227	50.80 X 127 RING SUPPORT		01
13	0503010974	W2-5000-500 RING		01
14	0503010039	D-2000 SCRAPER RING		01
15	0503010002	1800 GREASE FITTING		02
16	0501047885	ROD STOP		04
17	0501047887	ROD STOP		01
18	0501010617	3/4" NIPPLE		02
19	0503010190	2-114 N 3006-9B O'RING		02




Item	Code	Description	See page	DIR ESQ
01	0501058351	RIGHT CENTRAL BOX FERTILIZER		01 00
01A	0511069816	RH SEED SILO CENTRAL SUPPORT		01 00
01B	0503060642	COVER BOX RIGHT FERTILIZER		01 00
01C	0511061886	FERTILIZER BEAM LOCK		02 02
01D	0503010019	1/2" SPRING WASHER		24 24
01E	0503010060	1/2" NUT		18 18
01F	0511062099	FERTILIZER BEAM CLAMP		02 02
02	0501058352	LH BOX FERTILIZER ASSY		00 01
02A	0511069815	LR SEED SILO CENTRAL SUPPORT		00 01
02B	0503060643	COVER BOX LEFT FERTILIZER		00 01
03	0511053377	COVER ASSY		02 01
03A	0502012732	DUCT BODY		07 05
03B	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		28 20
03C	0501010984	FLAT WASHER		28 20
03D	0503010025	3/8" SPRING WASHER		29 21
03E	0503010026	3/8" NUT		29 21
03F	0571013983	SEED CONDUCTOR COVER		02 01
03G	0503011087	3/8" X 1" BOLT		14 10
03H	0501013518	FLAT WASHER		14 10
03I	0503010025	3/8" SPRING WASHER		14 10
03J	0503010026	3/8" NUT		14 10
04	0511052544	SET DUCT UPPER SEED		05 04
04A	0551017635	UPPER TUBE COVER		05 04
04B	0503013029	3/8" X 3/4" BOLT		05 04
04C	0503010209	3/8" UNC BUTTERFLY NUT		05 04
04D	0521064045	CONDUCTOR WITH FLANGED		05 04
05	0551019557	FLASHLIGHT SUPPORT		01 01
06	0551019056	SIDE PLATFORM SUPPORT		02 02
07	0511069817	2315 CENTRAL HANDRAIL		01 01
08	0521062334	PLATFORM CENTER		01 01
09	0501010160	1/2" X 3" BOLT		02 02

Item	Code	Description	See page	DIR ESQ
10	0511017302	FLAT WASHER		02 02
11	0511053321	RH PLATFORM SUPPORT		01 00
11A	0561014688	RH PLATFORM SUPPORT		01 00
11B	0503010239	1/2" X 1-1/2" BOLT		02 02
12	0511053322	LH PLATFORM SUPPORT		00 01
12A	0561014687	LH PLATFORM SUPPORT		00 01
13	0503010905	1/2" X 2-1/4" BOLT		02 02
14	0511017302	FLAT WASHER		06 06
15	0503011336	1/2" HEX SELF ADJUSTING NUT		06 06
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04 04
17	0503010920	1/2" X 1.1/2" BOLT		02 02
18	0503010395	1/2" X 1-1/4" BOLT		02 02
19	0503010920	1/2" X 1.1/2" BOLT		07 07
20	0503010920	1/2" X 1.1/2" BOLT		01 01
21	0501010942	3/8" X 1-1/4" BOLT		01 01
22	0501013518	FLAT WASHER		01 01




Item	Code	Description	See page	DIR ESQ
01	0501058358	LH SEED BOX SIDE SUPPORT ASSY		01 01
01A	0511069816	RH SEED SILO CENTRAL SUPPORT		01 01
01B	0503060643	COVER BOX LEFT FERTILIZER		01 01
01C	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02 02
01D	0503010849	3/8" X 1-1/2" BOLT		04 04
01E	0501010984	FLAT WASHER		56 56
01F	0503010025	3/8" SPRING WASHER		82 82
01G	0503010026	3/8" NUT		82 82
02	0501058359	RH SEED BOX LATERAL SUPPORT ASSY		01 01
02A	0511069813	RH SEED BOX SIDE SUPPORT		01 01
02B	0503060642	COVER BOX RIGHT FERTILIZER		01 01
03	0511053377	COVER ASSY		03 03
03A	0502012732	DUCT BODY		12 12
03B	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		48 48
03C	0503011087	3/8" X 1" BOLT		24 24
03D	0501013518	FLAT WASHER		24 24
03E	0571013983	SEED CONDUCTOR COVER		03 03
04	0511052544	SET DUCT UPPER SEED		09 09
04A	0551017635	UPPER TUBE COVER		09 09
04B	0503013029	3/8" X 3/4" BOLT		09 09
04C	0503010209	3/8" UNC BUTTERFLY NUT		09 09
04D	0521064045	CONDUCTOR WITH FLANGED		09 09
05	0521060930	FERTILIZER BEAM SUPPORT FIXER		03 03
06	0551015037	5/8" UNC X 210 X 198 FASTENER		06 06
07	0503012412	5/8 UNC SELF LOCKING NUT		12 12
08	0551019056	SIDE PLATFORM SUPPORT		04 04
09	0501010161	1/2" X 1.1/4" BOLT		08 08
10	0501013519	FLAT WASHER		12 12
11	0503010019	1/2" SPRING WASHER		29 29
12	0503010060	1/2" NUT		29 29
13	0501013519	FLAT WASHER		04 04

Item	Code	Description	See page	DIR ESQ
14	0551019397	CENTRAL HANDRAIL CHOCK		02 02
15	0511053323	NYLON LUG ASSY		01 01
15A	0503011957	NYLON LUG		01 01
15B	0503010371	5/16" X 1" BOLT		02 02
15C	0503010179	5/16" ZN SPRING WASHER		02 02
15D	0503010337	5/16" NUT		02 02
16	0511053320	ASSY SIDE LADDER		01 01
16A	0511069819	SIDE LADDER		01 01
16B	0551017438	LADDER RIGHT FIXER		01 01
16C	0551017437	LADDER RIGHT FIXER		01 01
16D	0571012771	LADDER UPPER SUPPORT		01 01
16E	0503011088	3/8" X 1-1/4" BOLT		04 04
16F	0503011179	3/8" X 2-1/4" BOLT		02 02
16G	0501010984	FLAT WASHER		02 02
16H	0503013357	3/8" SELF-ADJUSTING NUT		02 02
17	0511069820	PLATFORM 2380 USAP		02 02
18	0501010160	1/2" X 3" BOLT		04 04
19	0501010937	13.5 X 28 X 3 FLAT WASHER		04 04
20	0501010942	3/8" X 1-1/4" BOLT		02 02
21	0501013518	FLAT WASHER		02 02
22	0521064096	LEFT HANDRAIL		02 02
23	0503010920	1/2" X 1.1/2" BOLT		02 02
24	0503010395	1/2" X 1-1/4" BOLT		02 02
25	0503010920	1/2" X 1.1/2" BOLT		12 12
26	0501010937	13.5 X 28 X 3 FLAT WASHER		09 09
27	0511017302	FLAT WASHER		03 03




Item	Code	Description	See page	QT
01	0511054502	GEAR BOX CENTRAL ASSY		01
02	0511053326	CLUTCH		01
02A	0503062231	CLUTCH		01
02B	0511049053	DRIVE SHAFT		01
02C	0503011141	3/8" X 2-3/4" BOLT		02
02D	0503013357	3/8" SELF-ADJUSTING NUT		02
03	0503010172	M10 X 1,5 X 25 BOLT		04
04	0503013542	M10 SPRING WASHER		04
05	0511069512	20Z GEAR		01




Item	Code	Description	See page	QT
01	0521064562	CENTRAL GEAR BOX SUPPORT	01	
02	0501056271	BEARING CLOSED	04	
02A	0502012310	GEAR BOX CLOSE BEARING	04	
02B	0503013462	BEARING WITH BALL BEARING	06	
02C	0503011105	SEAL RING	05	
03	0571015170	CENTRAL GEAR BOX DRIVER AXLE	01	
04	0521063460	20Z GEAR	03	
05	0503030303	SUPPORT WASHER	04	
06	0571015169	FLANGE WASHER	02	
07	0511052432	DOUBLE BEARING WITH ASSY FLANGE	01	
07A	0521063461	BEARING DOUBLE WITH FLANGE	01	
08	0571015171	CENTRAL GEAR BOX DRIVEN AXLE	01	
09	0511054476	RIGHT TENSIONER CENTRAL EXCHANGE	01	
09A	0501056573	17Z GEAR ASSY	02	
09Aa	0502012367	17Z X P 1/2" GEAR INTERM	02	
09Ab	0503012882	BEARING	02	
09Ac	0503011945	503050 CLAMPING RING (FOR AXLE)	02	
09B	0571015168	SLEEVE NYLON Ø21 X Ø31,75 X 20	01	
09C	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	01	
09D	0503010019	1/2" SPRING WASHER	06	
09E	0503010060	1/2" NUT	08	
09F	0501010937	13.5 X 28 X 3 FLAT WASHER	02	
10	0511054489	LEFT TENSIONER CENTRAL EXCHANGE	01	
10A	0571015167	SLEEVE NYLON Ø21 X Ø31,75 X 36,50	01	
10B	0503010479	BOLT	01	
11	0551018585	CENTRAL GEAR BOX COVER SLEEVE	02	
12	0571015172	CENTRAL GEAR BOX COVER	01	
13	0503010179	5/16" ZN SPRING WASHER	13	
14	0503010337	5/16" NUT	13	
15	0503010371	5/16" X 1" BOLT	02	
16	0501010984	FLAT WASHER	04	

Item	Code	Description	See page	QT
17	0503011953	5/16" X 1" BOLT		08
18	0501010694	8.5 X 18 X 1.5 FLAT WASHER		10
19	0503010395	1/2" X 1-1/4" BOLT		02
20	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		02
21	0503012389	1/2 BALL		02
22	0501052778	CHAIN TENSIONER ASSY		01
22A	0511061794	CHAIN TENSIONER		01
22B	0503031367	SPRING		01
22C	0503031805	11Z 1/2" GEAR		02
22D	0503010302	501019 SEAL RING		02
23	0502011758	REAR TENSIONER LEVER		01
24	0503010002	1800 GREASE FITTING		01
25	0501048790	AXLE WITH LINK ASSY		01
25A	0521012476	GEAR BOX LEVER AXLE		01
25B	0503031369	LINK		01
26	0503010683	0,2" X 1,2" SPRING PIN		01
27	0511064536	28Z GEAR		01
28	0503012204	40-1 CHAIN X 82 LINK + RED		01
29	0503012390	40-1 CHAIN X 93 LINK + MENDING		01
30	0503011082	C1/2" X 1.3/4" SCREW		04
31	0511017302	FLAT WASHER		08
32	0503010386	CABLE		01
33	0503010292	0.2" X 1.6" SPRING PIN		05
34	0511060396	DRIVE/DRIVEN AXLE CONE		02
35	0551011728	3770 PULLER AXLE SEED ROW		01
36	0521014167	CONE LOCK		01
37	0503010365	NUT		02
38	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		02
39	0503010025	3/8" SPRING WASHER		03
40	0503011268	3/8" X 2-1/2" BOLT		01
41	0503010026	3/8" NUT		01




Item	Code	Description	See page	DIR ESQ
01	0501059729	RIGHT GEAR BOX ASSY		01 00
02	0501059728	LH GEAR BOX ASSY		00 01
03	0521061420	SIDE GEAR BOX SUPPORT		01 00
04	0521061419	LEFT GEAR BOX SUPPORT		00 01
05	0503010027	5/8" SPRING WASHER		04 04
06	0503010013	5/8" NUT		04 04
07	0501056271	BEARING CLOSED		03 03
07A	0502012310	GEAR BOX CLOSE BEARING		03 03
07B	0503013462	BEARING WITH BALL BEARING		03 03
07C	0503011105	SEAL RING		03 03
08	0551018627	SIDE GEAR BOX DRIVER AXLE		01 01
09	0551018581	CENTRAL GEAR BOX DRIVEN AXLE		01 01
10	0503010292	0.2" X 1.6" SPRING PIN		05 05
11	0501056444	BEARING WITH BALL BEARING		01 01
11A	0502011697	BEARING OF THE GEAR BOX		01 01
12	0502011758	REAR TENSIONER LEVER		01 01
13	0501052776	CHAIN TENSIONER RIGHT ASSY GREATEST		01 00
13A	0511061794	CHAIN TENSIONER		01 01
13B	0503031366	RIGHT TWISTED SPRING RECAMBIO		01 00
13C	0503031805	11Z 1/2" GEAR		02 02
13D	0503010302	501019 SEAL RING		02 02
14	0501052778	CHAIN TENSIONER ASSY		00 01
14A	0503031367	SPRING		00 01
15	0503012204	40-1 CHAIN X 82 LINK + RED		01 01
16	0503010002	1800 GREASE FITTING		01 01
17	0503030303	SUPPORT WASHER		04 04
18	0511060396	DRIVE/DRIVEN AXLE CONE		02 02
19	0503010395	1/2" X 1-1/4" BOLT		02 02
20	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		02 02
21	0503012389	1/2 BALL		02 02
22	0503010060	1/2" NUT		04 04

Item	Code	Description	See page	DIR ESQ
23	0511064536	28Z GEAR		01 01
24	0503014854	40-1 CHAIN X 135 LINK + MENDING		01 01
25	0521014167	CONE LOCK		01 01
26	0501054221	SEED BEARING INTERM LINE		02 02
26A	0502012367	17Z X P 1/2" GEAR INTERM		02 02
26B	0503012882	BEARING		02 02
26C	0503011945	503050 CLAMPING RING (FOR AXLE)		02 02
26D	0521010454	0.83" X 1.25" X 0.79" SLEEVE		02 02
26E	0503010905	1/2" X 2-1/4" BOLT		02 02
26F	0503010019	1/2" SPRING WASHER		02 02
27	0551018630	CARDAN SHAFT GUIDES SLEEVE		01 01
28	0551011625	PROTECTION COVER		01 01
29	0503010386	CABLE		01 01
30	0503010179	5/16" ZN SPRING WASHER		09 09
31	0503010337	5/16" NUT		09 09
32	0551018629	GEAR BOX COVER FIXER ROD		01 01
33	0501010984	FLAT WASHER		02 02
34	0503010257	1/8" X 1" COTTERPIN		02 02
35	0501048790	AXLE WITH LINK ASSY		01 01
35A	0521012476	GEAR BOX LEVER AXLE		01 01
35B	0503031369	LINK		01 01
36	0551015037	5/8" UNC X 210 X 198 FASTENER		02 02
37	0503011953	5/16" X 1" BOLT		08 08
38	0501010694	8.5 X 18 X 1.5 FLAT WASHER		08 08




Item	Code	Description	See page	QT
00	0511049053	DRIVE SHAFT		01
01	0511050733	UNIVERSAL JOINT		01
02	0511050731	UNIVERSAL JOINT		01
03	0501051718	UNIVERSAL JOINT		01
04	0502010558	4-20 TERMINAL WITH ROLES		01
05	0503010835	CARDAN CROSSPIECE		01
06	0502011426	2-20 TERMINAL		01
07	0561018214	SQUARE SLEEVE		01
08	0503010839	03"X 0.6" SPRING PIN		01
09	0511050734	UNIVERSAL JOINT WITH AXLE		01
10	0511050732	UNIVERSAL JOINT WITH AXLE		01
11	0502011427	3-20 TERMINAL		01
12	0561018215	SQUARE AXLE		01
13	0503010301	0.3" X 1.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0511053043	DEVIATION GREATER ASSY	01	
01A	0521063899	DEVIATION GREATER CENTRAL CHAIN	01	
02	0501056271	BEARING CLOSED	01	
02A	0502012310	GEAR BOX CLOSE BEARING	01	
02B	0503013462	BEARING WITH BALL BEARING	01	
02C	0503011105	SEAL RING	01	
03	0551018612	3/4" SQUARE SHAFT	01	
04	0501056444	BEARING WITH BALL BEARING	01	
04A	0502011697	BEARING OF THE GEAR BOX	01	
04B	0503013462	BEARING WITH BALL BEARING	01	
04C	0503011105	SEAL RING	01	
05	0503030303	SUPPORT WASHER	03	
06	0511065209	20Z GEAR	02	
07	0511053050	CHAIN TENSIONER	01	
07A	0571013442	TIGHTENER AXLE	01	
07B	0503031806	9Z X P 5/8" GEAR	01	
07C	0503010002	1800 GREASE FITTING	01	
07D	0503010019	1/2" SPRING WASHER	01	
07E	0503010060	1/2" NUT	01	
08	0501010984	FLAT WASHER	01	
09	0503010025	3/8" SPRING WASHER	01	
10	0503010237	3/8" X 1" BOLT	01	
11	0511046518	CENTRAL GEAR BOX CHAIN TENSIONER	01	
11A	0502012367	17Z X P 1/2" GEAR INTERM	01	
11B	0503012882	BEARING	01	
11C	0503011945	503050 CLAMPING RING (FOR AXLE)	01	
11D	0551018562	21 X 31,75 X 26,5 SLEEVE	01	
11E	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	01	
11F	0503011440	SPRING WASHER	01	
11G	0503010060	1/2" NUT	01	
12	0503011953	5/16" X 1" BOLT	04	

Item	Code	Description	See page	QT
13	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
14	0503010179	5/16" ZN SPRING WASHER		04
15	0503010337	5/16" NUT		04
16	0551015037	5/8" UNC X 210 X 198 FASTENER		02
17	0503012412	5/8 UNC SELF LOCKING NUT		04
18	0503010292	0.2" X 1.6" SPRING PIN		02
19	0503013254	40-1X CHAINX 138 LINK + MENDING + REDUCION		01




Item	Code	Description	See page	QT
01	0511054252	DEVIATION LOWER REAR		01
01A	0521062840	DEVIATION CHAIN LOWER REAR		01
02	0511053045	TENSIONER REAR OFFSET HIGHER		03
02A	0501056573	17Z GEAR ASSY		01
02Aa	0502012367	17Z X P 1/2" GEAR INTERM		01
02Ab	0503012882	BEARING		01
02Ac	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02B	0521010454	0.83" X 1.25" X 0.79" SLEEVE		01
02C	0503010905	1/2" X 2-1/4" BOLT		01
02D	0503010019	1/2" SPRING WASHER		01
02E	0503010060	1/2" NUT		01
03	0511053050	CHAIN TENSIONER		01
03A	0571013442	TIGHTENER AXLE		01
03B	0503031806	9Z X P 5/8" GEAR		01
03C	0503010002	1800 GREASE FITTING		01
03D	0503010019	1/2" SPRING WASHER		01
03E	0503010060	1/2" NUT		01
04	0503033709	CATCH HEAD LINSEED SEEDS		01
05	0503010027	5/8" SPRING WASHER		02
06	0503010013	5/8" NUT		02
07	0503013369	40-1 X 62 CHAIN LINK + REDUCTION		01




Item	Code	Description	See page	QT
00	0521043440	WHEELS CENTER AND TRANSMISSION		01
01	0521064554	LEFT WHEEL FORK		01
02	0521064543	WHEEL SUPPORT		01
03	0511068422	WHEEL GEAR DOBLE		01
04	0551018571	FLAT WASHER		01
05	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
06	0501010630	1.1/2" CASTLE NUT		01
07	0561019929	FLAT WASHER		01
08	0503011345	1/4" X 3-1/2" COTTERPIN		01
09	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
10	0503011052	1.1/4" X 0.77" CASTLE NUT		01
11	0501017779	32 X 60 X 4.75 FLAT WASHER		02
12	0551014508	FLAT WASHER		01
13	0503010010	1/4" X 2.1/2" COTTERPIN		02
14	0571015147	PIVOT SHAFT		01
15	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
16	0521044061	HYDRAULIC CYLINDER	26	01
17	0503010920	1/2" X 1.1/2" BOLT		04
18	0503010019	1/2" SPRING WASHER		08
19	0503010060	1/2" NUT		08
20	0551014565	CILINDER FORK SLEVE GUIDES		01
21	0503010067	3/16" X 2.1/2" COTTER PIN		01
22	0502012731	WHEEL HOLDER		02
23	0501010322	FLAT WASHER		04
24	0503010014	3/4" NUT		04
25	0501010195	3/4" X 3-1/2" BOLT		04
26	0503010002	1800 GREASE FITTING		04
27	0511054499	TRANSMISSION OF LARGER CENTRAL EXCHANGE	27	01
28	0503016419	50-1 CHAIN X 128 LINK + REDUCION		01
29	0571015153	COVER PROTECTION WHEELED LARGER		01
30	0501013518	FLAT WASHER		02

Item	Code	Description	See page	QT
31	0503010025	3/8" SPRING WASHER		02
32	0503010209	3/8" UNC BUTTERFLY NUT		02
33	0503010849	3/8" X 1-1/2" BOLT		02
34	0511054492	STUB SHAFT HUB	25	01
35	0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE		01
36	0571012483	FIXER SENSOR WHEEL		01
37	0501010063	1/2" X 1-1/2" BOLT		02
38	0571015148	PLATE SENSIBLES		01
39	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
40	0511054463	WHEEL TENSIONER SUPORT CENTRAL		01
40A	0511054462	17Z GEAR		03
40Aa	0503011410	ROLLER BEARING		03
40Ab	0503011105	SEAL RING		03
40Ac	0511061836	17Z GEAR		03
40B	0571015149	TIGHTENER AXLE		01
40C	0503010406	501025 CLAMPING RING (FOR AXLE)		01
40D	0501010163	5/8" X 4-1/2" BOLT		01
40E	0503010027	5/8" SPRING WASHER		01
40F	0503010013	5/8" NUT		01
41	0503015030	50-1 X 115 CHAIN LINK + MENDING		01
42	0511054464	WHEEL FORK TENSIONER		02
42A	0571015150	SLEEVE TENSIONER WHEEL		02
42B	0503010406	501025 CLAMPING RING (FOR AXLE)		02
42C	0503010027	5/8" SPRING WASHER		02
42D	0503010013	5/8" NUT		02
42E	0501012140	FLAT WASHER		02
42F	0503010752	1/2" X 3.1/2" BOLT		02
43	0551018312	TRANSPORT LOCK		01
44	0501068994	0.3" X 3.1" LOCK PIN		01
45	0503030168	HAIR PIN		01




Item	Code	Description	See page	QT
00	0521043436	WHEELS CENTER TRANSMISSION		01
01	0521064554	LEFT WHEEL FORK		01
02	0521064543	WHEEL SUPPORT		01
03	0551018571	FLAT WASHER		01
04	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
05	0501010630	1.1/2" CASTLE NUT		01
06	0561019929	FLAT WASHER		01
07	0503011345	1/4" X 3-1/2" COTTERPIN		01
08	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
09	0503011052	1.1/4" X 0.77" CASTLE NUT		02
10	0501017779	32 X 60 X 4.75 FLAT WASHER		02
11	0551014508	FLAT WASHER		01
12	0503010010	1/4" X 2.1/2" COTTERPIN		02
13	0571015147	PIVOT SHAFT		01
14	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
15	0521044061	HYDRAULIC CYLINDER	26	01
16	0503010920	1/2" X 1.1/2" BOLT		04
17	0503010019	1/2" SPRING WASHER		04
18	0503010060	1/2" NUT		04
19	0551014565	CILINDER FORK SLEVE GUIDES		01
20	0503010067	3/16" X 2.1/2" COTTER PIN		01
21	0502012731	WHEEL HOLDER		02
22	0501010322	FLAT WASHER		04
23	0503010014	3/4" NUT		04
24	0501010195	3/4" X 3-1/2" BOLT		04
25	0503010002	1800 GREASE FITTING		03
26	0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE		01
27	0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	23	01
28	0551018312	TRANSPORT LOCK		01
29	0501068994	0.3" X 3.1" LOCK PIN		01
30	0503030168	HAIR PIN		01




Item	Code	Description	See page	DIR ESQ
01	0521043441	WHEELS LEFT TRANSMISSION		00 01
02	0521043442	WHEELS RIGHT WITH TRANSMISSION		01 00
03	0521064543	WHEEL SUPPORT		01 01
04	0511068422	WHEEL GEAR DOBLE		01 01
05	0551018571	FLAT WASHER		01 01
06	0501010630	1.1/2" CASTLE NUT		01 01
07	0561019929	FLAT WASHER		01 01
08	0503011345	1/4" X 3-1/2" COTTERPIN		01 01
09	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02 02
10	0503011052	1.1/4" X 0.77" CASTLE NUT		02 02
11	0501017779	32 X 60 X 4.75 FLAT WASHER		02 02
12	0551014508	FLAT WASHER		01 01
13	0503010010	1/4" X 2.1/2" COTTERPIN		02 02
14	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02 02
15	0521044061	HYDRAULIC CYLINDER	26	01 01
16	0503010920	1/2" X 1.1/2" BOLT		04 04
17	0503010019	1/2" SPRING WASHER		04 08
18	0503010060	1/2" NUT		04 08
19	0551014565	CILINDER FORK SLEVE GUIDES		01 01
20	0503010067	3/16" X 2.1/2" COTTER PIN		01 01
21	0502012731	WHEEL HOLDER		02 02
22	0501010322	FLAT WASHER		04 04
23	0503010014	3/4" NUT		04 04
24	0501010195	3/4" X 3-1/2" BOLT		04 04
25	0503010002	1800 GREASE FITTING		03 03
26	0501013518	FLAT WASHER		02 02
27	0503010025	3/8" SPRING WASHER		02 02
28	0503010209	3/8" UNC BUTTERFLY NUT		02 02
29	0503010849	3/8" X 1-1/2" BOLT		02 02
30	0521064550	CARRYING-WHEELS FORK		01 01
31	0503061624	WHEEL AND TIRE ASSY 13.0/55-16/12LO		01 01


Item	Code	Description	See page	DIR ESQ
32	0571015194	Ø34,93 X 490 USAP AXLE		01 01
33	0561019941	RIGHT PROTECTIVE CAP WHEELS		01 01
34	0503014857	50-1 X CHAIN X 122 LINK + REDUCION		01 01
35	0511054500	TRANSMISSION EXCHANGE RIGHT	29	01 00
36	0503014086	50-1 X 123 CHAIN LINK + MENDING		01 01
37	0511054491	WHEEL WITHOUT TIRE WITH 27Z GEAR	24	01 01
38	0521064558	CARRYING-WHEELS PIVOT SHAFT		01 01
39	0511054464	WHEEL FORK TENSIONER		02 02
39A	0511054462	17Z GEAR		02 02
39Aa	0503011410	ROLLER BEARING		02 02
39Ab	0503011105	SEAL RING		02 02
39Ac	0511061836	17Z GEAR		02 02
39B	0571015150	SLEEVE TENSIONER WHEEL		02 02
39C	0503010406	501025 CLAMPING RING (FOR AXLE)		02 02
39D	0503010027	5/8" SPRING WASHER		02 02
39E	0503010013	5/8" NUT		02 02
39F	0503010752	1/2" X 3.1/2" BOLT		02 02
39G	0503010752	1/2" X 3.1/2" BOLT		02 02
40	0511054501	TRANSMISSION CAMBIO LEFT	28	00 01
41	0571015148	PLATE SENSIBLES		00 01
42	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		00 02
43	0571012485	FERTILIZER BEAM CLAMP		00 01
44	0501010063	1/2" X 1-1/2" BOLT		00 02




Item	Code	Description	See page	QT
00	0521043437	CENTRAL / SIDE WHEEL WITHOUT TRANSMISSION		01
01	0521064543	WHEEL SUPPORT		01
02	0501010630	1.1/2" CASTLE NUT		01
03	0561019929	FLAT WASHER		01
04	0503011345	1/4" X 3-1/2" COTTERPIN		01
05	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
06	0503011052	1.1/4" X 0.77" CASTLE NUT		02
07	0501017779	32 X 60 X 4.75 FLAT WASHER		02
08	0551014508	FLAT WASHER		01
09	0503010010	1/4" X 2.1/2" COTTERPIN		02
10	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
11	0521044061	HYDRAULIC CYLINDER	26	01
12	0503010920	1/2" X 1.1/2" BOLT		04
13	0503010019	1/2" SPRING WASHER		04
14	0503010060	1/2" NUT		04
15	0551014565	CILINDER FORK SLEVE GUIDES		01
16	0503010067	3/16" X 2.1/2" COTTER PIN		01
17	0502012731	WHEEL HOLDER		02
18	0501010322	FLAT WASHER		04
19	0503010014	3/4" NUT		04
20	0501010195	3/4" X 3-1/2" BOLT		04
21	0503010002	1800 GREASE FITTING		03
22	0521064550	CARRYING-WHEELS FORK		01
23	0503061624	WHEEL AND TIRE ASSY 13.0/55-16/12LO		01
24	0571015194	Ø34,93 X 490 USAP AXLE		01
25	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
26	0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	23	01




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503010007	3982/3920 ROLLER BEARING		01
04	0503010059	33287/33462 ROLLER BEARING		01
05	0503010009	RETAINER 00573-B		01
06	0503010086	SEAL 0009B-B		01
07	0551014473	GLOVE		01
08	0503012702	KM-12 NUT		02
09	0503012703	LOCK WASHER		01
10	0503010002	1800 GREASE FITTING		01
11	0503011444	SPRING WASHER		04
12	0503011339	M22 X 1,5 X 72 BOLT		08
13	0503014048	22 X 1.5 HEX NUT		08
14	0503010363	5/16" X 1" BOLT		04
15	0511068415	PFFP-3770 SEAL GUIDE		01




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503013633	BEARING 33287/33462		01
04	0503010009	RETAINER 00573-B		01
05	0503010086	SEAL 0009B-B		01
06	0551014473	GLOVE		01
07	0503012702	KM-12 NUT		02
08	0503012703	LOCK WASHER		01
09	0503010002	1800 GREASE FITTING		01
10	0503011444	SPRING WASHER		08
11	0503014048	22 X 1.5 HEX NUT		08
12	0503010363	5/16" X 1" BOLT		08
13	0521064563	27Z GEAR		01
14	0503014050	22 X 1.5 BOLT		08
15	0503013496	3982/3920 ROLLER BEARING		01
16	1882970002	GREASE SOAP		01




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503010007	3982/3920 ROLLER BEARING		01
04	0503010059	33287/33462 ROLLER BEARING		01
05	0503010009	RETAINER 00573-B		01
06	0503010086	SEAL 0009B-B		01
07	0551014473	GLOVE		01
08	0503012702	KM-12 NUT		02
09	0503012703	LOCK WASHER		01
10	0503010002	1800 GREASE FITTING		01
11	0503011444	SPRING WASHER		08
12	0503011339	M22 X 1,5 X 72 BOLT		08
13	0503014048	22 X 1.5 HEX NUT		08
14	0503010363	5/16" X 1" BOLT		08
15	0521064564	30Z GEAR		01




Item	Code	Description	See page	QT
00	0521044061	HYDRAULIC CYLINDER	26	01
01	0511069438	101,60 X 336,50 CYLINDER CASE		01
02	0571015628	TURNBUCLE BODY		01
03	0571015629	CILINDER SPINDLE FORK		01
04	0502010017	4" HEAD		01
05	0503010817	1.1/4" SELF LOCKING NUT		01
06	0503010345	2-218 N 3006-9B O'RING		01
07	0503011094	3/8" X 2" BOLT		01
08	0503010026	3/8" NUT		01
09	0503010025	3/8" SPRING WASHER		01
10	0503030385	CYLINDER PLUG N-002		02
11	0561016387	PISTON BODY		01
12	0503015633	SELEMASTER SEALING		01
13	0561016389	PISTON BODY		01
14	0502012642	SUPPORT OF THE RINGS		01
15	0503011061	8-342 BACK-UP RING		01
16	0503010338	2-342 N 3006-9B O'RING		01
17	0503015636	SCRAPER SEAL		01
18	0503015635	U-CUP SEAL		01
19	0503015634	RING SLYDRING		01




Item	Code	Description	See page	QT
01	0521064557	SUPPORT SET TRANSMISSION WHEEL SIDE	01	
02	0571015141	FIXER CENTRAL TRANSMISSION	04	
03	0571015151	SUPPORT BEARING	01	
04	0521061795	27Z GEAR	01	
05	0501053654	DOUBLE BEARING TRANSMISSION SEED 3/4	01	
06	0503010025	3/8" SPRING WASHER	08	
07	0503010026	3/8" NUT	08	
08	0503010019	1/2" SPRING WASHER	03	
09	0503010060	1/2" NUT	03	
10	0503010337	5/16" NUT	02	
11	0503011953	5/16" X 1" BOLT	02	
12	0503010179	5/16" ZN SPRING WASHER	02	
13	0503010707	501030 CLAMPING RING (FOR AXLE)	02	
14	0503010741	1/2" X 2-3/4" BOLT	03	
15	0511054461	STRETCHER TOP TRANSMISSION SWIRLED	02	



Item	Code	Description	See page	QT
01	0521064556	SUPPORT SET TRANSMISSION WHEEL SIDE		01
02	0503010025	3/8" SPRING WASHER		13
03	0503010026	3/8" NUT		11
04	0503010019	1/2" SPRING WASHER		03
05	0503010060	1/2" NUT		03
06	0503010741	1/2" X 2-3/4" BOLT		03
07	0503062231	CLUTCH		01
08	0571015139	FIXER PLATE		01
09	0571015138	CHOCK FRICÇÃO		01
10	0511054461	STRETCHER TOP TRANSMISSION SWIRLED		02
11	0503011268	3/8" X 2-1/2" BOLT		01
12	0503013542	M10 SPRING WASHER		04
13	0503010188	M10 X 1,5 X 30 BOLT		01
14	0511069511	27Z GEAR		02
15	0571015152	FIXER TRANSMISSION SIDE LEFT		04
16	0571015154	PROTECTION TRANSMISSION LEFT		04




Item	Code	Description	See page	QT
01	0521064556	SUPPORT SET TRANSMISSION WHEEL SIDE	01	
02	0503010025	3/8" SPRING WASHER	13	
03	0503010026	3/8" NUT	11	
04	0503010019	1/2" SPRING WASHER	03	
05	0503010060	1/2" NUT	03	
06	0503010741	1/2" X 2-3/4" BOLT	03	
07	0521064555	27Z GEAR	01	
08	0503062231	CLUTCH	01	
09	0571015139	FIXER PLATE	01	
10	0571015138	CHOCK FRICÇÃO	01	
11	0571015141	FIXER CENTRAL TRANSMISSION	04	
12	0511054461	STRETCHER TOP TRANSMISSION SWIRLED	02	
13	0503011268	3/8" X 2-1/2" BOLT	01	
14	0571015142	USAP FIXER	02	
15	0571015143	RIGHT PROTECTION SUPPORT WHEEL	01	
16	0503010209	3/8" UNC BUTTERFLY NUT	02	
17	0503013542	M10 SPRING WASHER	04	
18	0503010188	M10 X 1,5 X 30 BOLT	04	




Item	Code	Description	See page	QT
01	0501052160	SLEEVE UNIVERSAL JOINT	01	01
02	0501051718	UNIVERSAL JOINT	01	01
03	0502010558	4-20 TERMINAL WITH ROLES	02	02
04	0502011426	2-20 TERMINAL	01	01
05	0521013797	0.9"X1.1"X31.5" SQUARE SLEEVE	01	01
06	0503010835	CARDAN CROSSPICE	02	02
07	0503010839	03"X 0.6" SPRING PIN	01	01
08	0501052161	UNIVERSAL JOINT WITH AXLE	01	01
09	0501051720	UNIVERSAL JOINT	01	01
10	0502011427	3-20 TERMINAL	01	01
11	0521013794	0.9" X 31.5 SQUARE SHAFT	01	01
12	0503010301	0.3" X 1.8" SPRING PIN	01	01
13	0501052162	PROT/SLEEVE UNIVERSAL JOINT	01	01
14	0501052163	PROT/AXLE UNIVERSAL JOINT	01	01
15	0503012268	PROTECTION ASSY	01	01
16	0503012269	PROTECTION FOR UNIV JOINT SLEEVE	01	01
17	0503012270	PROTECTION FOR UNIV JOINT AND AXLE	01	01
18	0503012023	CHAIN FOR PROTECTION	01	01


Item	Code	Description	See page	QT
1	0501048409(STU)	DRIVE SHAFT	31	



Item	Code	Description	See page	QT
01	0501058100	ARTICULATE VALVE		02
01A	0503012481	FLOW DIVIDING VALVE		02
01B	0501010617	3/4" NIPPLE		06
01C	0503010190	2-114 N 3006-9B O'RING		06
01D	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		02
02	0521043416	HYDRAULIC CYLINDER	9	01
03	0511043675	HYDRAULIC CYLINDER	8	02
04	0511049549	CYLINDER HEADER HYDRAULIC	10	01
05	0501081855	HOSE 3/8 X 14500 TR-TM USAP		02
06	0501081813	HOSE 1/2 X 1400 TC-TC USAP		01
07	0501081814	HOSE 1/2 X 900 TC-TC USAP		03
08	0501081815	HOSE 3/8 X 1500 TC-TC USAP		01
09	0501081812	HOSE 3/8 X 1370 TC-TC USAP		01
10	0501081848	HOSE 3/8 X 3200 TR-TM USAP		02
11	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		04
12	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
13	0503010143	1/4" SPRING WASHER		04
14	0503010144	1/4" NUT		04




Item	Code	Description	See page	QT
00	0511053313	BLOCK COMMAND	33	01
01	0503016332	BLOCK COMMAND		01
02	0503010190	2-114 N 3006-9B O'RING		04
03	0501010617	3/4" NIPPLE		04
04	0503010045	O'RING		03
05	0501010590	NIPPLE		01
06	0511010111	7/8" NIPPLE		02
07	0503010371	5/16" X 1" BOLT		03
08	0503010179	5/16" ZN SPRING WASHER		03




Item	Code	Description	See page	QT
01	0503015906	TWO-WAY MALE CONNECTOR	03	
02	0503015908	FEMALE TERMINAL	06	
03	0503016127	RING IDENTIFICATION	01	
04	0503016128	RING IDENTIFICATION	01	
05	0503016129	RING IDENTIFICATION	01	
06	0503014013	PROTECTION SPRING	03MT	
07	3505152099	ELECTRIC CABLE	15MT	
08	0503013527	CLAMP ZIPER	50	
09	0503032811	FLASHLIGHT	02	
10	0503032812	1141 12V LAMP	04	
11	0503032813	67 12V 5W LAMP	02	
12	0503014278	MP100 PLASTIC PROTECTION SPRING FOR 3/4 HOSE	1.500MT	
13	0571012483	FIXER SENSOR WHEEL	01	
14	0503010239	1/2" X 1-1/2" BOLT	02	
15	0503010060	1/2" NUT	04	
16	0503011440	SPRING WASHER	04	
17	0571012484	PLATE SENSIBLES	01	
18	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN	02	
19	0561016352	ELECTRICAL BOX PLATE FIXING	01	
20	0503016476	WHIP COMMAND OUT	04	
21	0503016477	SENSOR CAPACITIVE SPIRALED	01	
22	0503016474	CONTROL PANEL	01	
23	0503016469	WHIP COMMAND MACHINE	01	
24	0503016466	WHIP FEEDING MACHINE	01	
25	0571012531	BOX SUPPORT RELE	01	
26	0503016475	CONTROL PANEL	01	
27	0503062231	CLUTCH	03	
28	0503016472	WHIP FEEDING TRACTOR	01	
29	0503016473	WHIP COMMAND TRACTOR	01	
30	0503013758	1/4" X 1-1/2" BOLT	04	
31	0503010143	1/4" SPRING WASHER	04	


Item	Code	Description	See page	QT
32	0503010144	1/4" NUT		04
33	0571013314	GUTTER 25 X 58 X 1500		01
34	0571013313	GUTTER 25 X 58 X 2150 USAP		01
35	0571013315	GUTTER 25 X 38 X 2420 USAP		04
36	0571011892	GUTTER 20 X 38 X 3000 USAP		01
37	0561019643	GUTTER 25 X 58 X 1000		02



Item	Code	Description	See page	QT
00	0511047164	DISC BLADE ASSY	35	01
01	0502012470	UPPER SUPPORT		01
02	0503010232	5/8" X 1.3/4" BOLT		04
03	0503012412	5/8 UNC SELF LOCKING NUT		04
04	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		01
05	0501058374	BOTTOM BRACKET		01
05A	0502012713	BOTTOM BRACKET		01
06	0503010002	1800 GREASE FITTING		02
07	0561014164	SUPPORT DISC AXLE		01
08	0503010361	SPRING PIN		01
09	0571012371	SLEEVE 20 X 34,93 X 130		01
10	0521063500	RIGHT ARM OF THE BLADE DISC		01
11	0521063499	LH ARM BLADE DISC		01
12	0501013475	3/4 UNC X 7.1/2 C S G.5 ZNBOLT		01
13	0503011442	3/4" SPRING WASHER		02
14	0503010014	3/4" NUT		01
15	0501011541	5/8" X 3" BOLT		02
16	0511068751	SPRING REGULACION		02
17	0501010301	FLAT WASHER		02
18	0503011445	SPRING WASHER		02
19	0503010013	5/8" NUT		02
20	0503031575	2.5"X 12" X 0.5" COMPRESSION SPRING		02
21	0551015883	SPRING GUIDES SLEVE		02
22	0503010014	3/4" NUT		04
23	0571012370	PROTECTION FRONT		01
24	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		02
25	0503011444	SPRING WASHER		02
26	0511052299	BLADE DISC	36	01
27	0571012224	DUST CLOAK		02
28	0503016485	BOLT 3/4		01
29	0503010335	3/4"NUT		01



Item	Code	Description	See page	QT
00	0511052299	BLADE DISC	36	01
01	0502011562	DC BOX		01
02	0503010276	6206 BALL BEARING		02
03	0571012223	BEARING CUBE		01
04	0503030832	FLAT WASHER		02
05	0503012417	SEAL		02
06	0503011800	SEAL RING		02
07	0503010691	1/4" GREASE FITTING		01
08	0603027851	20" X 0.2" FLAT PLAIN DISC		01
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0503011444	SPRING WASHER		06
12	0503010337	5/16" NUT		06




Item	Code	Description	See page	LG	LC
000A	0501059258	LONG SEED ROW FRONT		00	01
000B	0501059259	SHORT SEED ROW FRONT		01	01
001	0521061015	SEED ROW SUPPORT FRONT		01	00
001.	0511065881	SEED ROW SUPPORT FRONT		00	01
002	0502012709	LARGER LOWER ARM		01	00
002.	0502012710	SMALLER LOWER ARM		00	01
003	0503010003	1845 GREASE FITTING		02	02
004	0531016194	0.6" X 1" X 2.6" SLEEVE		04	04
005	0503013077	5/8" X 8" BOLT		03	03
006	0503014636	5/8" UNC X 9 BOLT		01	01
007	0503010027	5/8" SPRING WASHER		02	02
008	0503012412	5/8 UNC SELF LOCKING NUT		08	08
009	0503033709	CATCH HEAD LINSEED SEEDS		02	02
010	0501012140	FLAT WASHER		01	01
011	0502012750	SEED ARM SUPPORT ROW		01	00
011.	0502012749	SEED ARM SUPPORT ROW		00	01
012	0521063442	ROW SEED FRAME		01	01
013	0501057684	SIDE BEARING FRONT SUPPORT SEED LINE		01	01
014	0571012310	ROW LOCK BODY		01	01
015	0503010233	5/8" X 2-1/2" BOLT		02	02
016	0551015826	SEED ROW LOCK GUIDE SLEEV		01	01
017	0503010013	5/8" NUT		01	01
018	0561015844	3/4 X 2190 HEX AXLE		02	02
019	0531015948	3/4" X 98" HEX AXLE		02	02
020	0502012699	LATCH GLOVE BOX TRANSMISSION		36	36
021	0503010256	3/8" X 3/4" BOLT		72	72
022	0561015837	SLEEVE 31,75		03	03
023	0511054884	TRANSMISSION BOX		01	01
024	0511052480	TRANSMISSÃO LONGA COM SHAFT		01	01
024.	0511052479	TRANSMISSAO CURTA COM CARDAN		01	01
025	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		02	02



USAP SUPREMA
FRONT SEED ROW


Page 37
0909090721

Item	Code	Description	See page	LG	LC
026	0503033728	FIXED SPRING PIN		01	01
027	0571014704	UPPER AXLE		01	01
028	0503030168	HAIR PIN		02	02
029	1902012568	UPPER ROCKER ARM		01	01
030	0511052300	CONDUCTOR SUPPORT ASSY SEED		01	01
031	0503010523	1/4" X 2" COTTERPIN		03	03
032	0503030285	HAIR PIN		01	01
033	0561014215	BEARING COVER LOWER ROW FRAME		01	01
034	0503010071	3/16" X 1" COTTERPIN		01	01




Item	Code	Description	See page	LG CT
000	0511057467	FRONT LINE SEED		01 00
000A	0511057468	FRONT LINE SEED		00 01
001	0521061015	SEED ROW SUPPORT FRONT		01 00
001.	0511065881	SEED ROW SUPPORT FRONT		00 01
002	0502012709	LARGER LOWER ARM		01 00
002.	0502012710	SMALLER LOWER ARM		00 01
003	0503010003	1845 GREASE FITTING		04 04
004	0531016194	0.6" X 1" X 2.6" SLEEVE		08 08
005	0503013077	5/8" X 8" BOLT		04 04
006	0502012699	LATCH GLOVE BOX TRANSMISSION		36 36
007	0503010027	5/8" SPRING WASHER		04 04
008	0503012412	5/8 UNC SELF LOCKING NUT		08 08
009	0503033709	CATCH HEAD LINSEED SEEDS		02 02
010	0501012140	FLAT WASHER		01 01
011	0502012750	SEED ARM SUPPORT ROW		01 00
011.	0502012749	SEED ARM SUPPORT ROW		00 01
012	0521066168	FRAME SEED LINE		01 01
013	0501057684	SIDE BEARING FRONT SUPPORT SEED LINE		01 01
014	0571012310	ROW LOCK BODY		01 01
015	0503010232	5/8" X 1.3/4" BOLT		01 01
016	0551015826	SEED ROW LOCK GUIDE SLEEV		02 02
017	0503010013	5/8" NUT		01 01
018	0561016761	3/4 X 1900 HEX AXLE		01 01
019	0561016762	3/4 X 2390 HEX AXLE		01 01
020	0561018836	3/4" X 3060 HEX AXLE		02 02
021	0503030285	HAIR PIN		01 01
022	0561016764	3/4 X 2645 HEX AXLE		02 02
023	0511054884	TRANSMISSION BOX		01 01
024	0511057482	5/8" AXLE		01 00
024.	0511057483	5/8" AXLE		00 01
025	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01 01


Item	Code	Description	See page	LG	CT
026	0503033728	FIXED SPRING PIN		01	02
027	0571014704	UPPER AXLE		01	00
028	0503030168	HAIR PIN		02	02
029	0502012568	UPPER ROCKER ARM		01	01
030	0511052300	CONDUCTOR SUPPORT ASSY SEED		01	01
031	0571013341	HEX AXLE		01	01
032	0503010523	1/4" X 2" COTTERPIN		01	02
033	0503010256	3/8" X 3/4" BOLT		36	36
034	0561015837	SLEEVE 31,75		01	02
035	0561014215	BEARING COVER LOWER ROW FRAME		01	01
036	0561018836	3/4" X 3060 HEX AXLE		02	02
037	0561016764	3/4 X 2645 HEX AXLE		01	01
038	0561018836	3/4" X 3060 HEX AXLE		01	01
039	0561018821	HEX AXLE 3/4 X 2600		01	01
040	0531013215	3/4" X 113" HEX AXLE		01	01
041	0561016761	3/4 X 1900 HEX AXLE		01	01
042	0561015842	3/4 X 1745 HEX AXLE		02	02
043	0571011099	HEX AXLE 3/4 X 2886		01	01
044	0551019082	3/4 X 3750 HEX AXLE		02	02
045	0561018840	HEX AXLE		02	02
046	0561010268	3/4 X 3390 HEX AXLE		01	01
047	0571013243	HEX AXLE		01	01
048	0571013244	HEX AXLE		01	01
049	0561015844	3/4 X 2190 HEX AXLE		01	01



Item	Code	Description	See page	QT
00	0521042418	REAR RIGHT LINE SEED		01
00A	0521042419	REAR LEFT LINE SEED		01
01	0521042327	DEPTH CONTROL & PRESS WHEEL ASSY		02
02	0521065999	FRONT SHIELD		02
03	0511050077	WHEEL STRIPED	40	02
04	0511054333	COMPACT WHEEL RIGHT WITH BEARING		01
05	0511054334	COMPACT WHEEL LEFT WITH BEARING		01
06	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
07	0521014508	FLAT WASHER		02
08	0503011336	1/2" HEX SELF ADJUSTING NUT		02
09	0503033124	SOCKET SEED		01
10	0521042711	SEED DISTRIBUTOR ASSY	44	01
11	0531018227	2" X 200 HOSE ASSY		01
12	0503010246	CLAMP		02
13	0521060931	LOWER CONDUCTOR		01
14	0521060631	FIXING BASE BOX		01
15	0561013856	COVER GUIDE		01
16	0561016392	SUPPORT FIXER LEVER LOWER		01
17	0501010942	3/8" X 1-1/4" BOLT		05
18	0503010025	3/8" SPRING WASHER		09
19	0503010026	3/8" NUT		08
20	0503010209	3/8" UNC BUTTERFLY NUT		01
21	0501059631	DDD SEED 15" X 15" RIGHT		01
22	0521012663	SPRING SLEEVE FIXER		01
23	0503010905	1/2" X 2-1/4" BOLT		04
24	0503011440	SPRING WASHER		04
25	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY		01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	5/16" ZN SPRING WASHER		06
07	0503010337	5/16" NUT		06



Item	Code	Description	See page	QT
00	0511053550	DEPTH CONTROL ASSY		01
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0501056769	DEPTH WHEELS REGULATOR ASSY		01
02A	0502011689	1/8" DEPTH CONTROL LEVER		01
02B	0503030975	0.9" X 1.5" X 0.1" SPRING		01
02C	0502011688	SEED SIST CONTROL DEPTH LEVER		01
02D	0511015976	FLAT WASHER		01
02E	0503010257	1/8" X 1" COTTERPIN		01
02F	0511065582	DEPTH WHEEL STOP		01
02G	0503010071	3/16" X 1" COTTERPIN		01
03	0521064073	REGULACION WHEEL COMPACTOR		01
04	0521019093	0.6" X 2.7" PIVOT SHAFT		01
05	0503010257	1/8" X 1" COTTERPIN		01
06	0571013054	DEPTH CONTROL WHEEL AXLE		01
07	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
08	0511015346	FLAT WASHER		04
09	0541016906	PRESS WHEELS REGULATOR BODY		01
10	0503033942	COVER REGULATORY WHEEL		01
11	0521010539	0.3" X 1.2" COUPLING SHAFT		01
12	0503010140	1/8" X 3/4" COTTERPIN		01
13	0503010311	1/2" X 1-1/4" BOLT		02
14	0503011440	SPRING WASHER		04
15	0511017302	FLAT WASHER		02
16	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
17	0503010256	3/8" X 3/4" BOLT		01
18	0502012116	PRESS WHEEL ADJUSTER		01
19	0503010849	3/8" X 1-1/2" BOLT		02
20	0503011443	3/8" SPRING WASHER		02
21	0503010026	3/8" NUT		02
22	0501110720	ARM LEFT		01
23	0501110719	DEPTH CONTROL RIGHT ARM		01


Item	Code	Description	See page	QT
24	0503015021	6871-GA SEAL RING		04
25	0503016453	1/2" X 2.1/2 BOLT		02
26	0503010028	1/2" NUT		02
27	0503010002	1800 GREASE FITTING		02
28	0502012663	EXTENSION		01
29	0503010905	1/2" X 2-1/4" BOLT		01
30	0503010019	1/2" SPRING WASHER		02
31	0503010060	1/2" NUT		02



Item	Code	Description	See page	DIR	ESQ
01	0511054333	COMPACT WHEEL RIGHT WITH BEARING	01	00	
02	0511054334	COMPACT WHEEL LEFT WITH BEARING	00	01	
03	0501052908	COMPACTOR WHEEL WITH BEARING	01	01	
03A	0502011919	PRESS WHEEL HUB	01	01	
03B	0502011877	PRESS WHEEL HUB	01	01	
03C	0503010269	6204 BALL BEARING	02	02	
03D	0521018922	PRESS WHEEL PASSANG AXLE	02	02	
03E	0503012734	SEAL 01556 BR	02	02	
03F	0521018921	DUST CLOAK	02	02	
03G	0503010691	1/4" GREASE FITTING	01	01	
03H	0521018928	PRESS WHEEL RIM	02	02	
03I	0503031421	DEPTH CONTROL WHEEL RUBBER BAND	01	01	
03J	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN	06	06	
03K	0503010179	5/16" ZN SPRING WASHER	09	09	
03L	0503010337	5/16" NUT	06	06	
03M	0503010371	5/16" X 1" BOLT	03	03	
03N	0503013816	5/16" LOCKNUT	03	03	
04	0503016449	1/2 X 4 BOLT	01	00	
05	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT	00	01	
06	0521014508	FLAT WASHER	03	03	
07	0503012136	NUT 1/2 NF	01	00	
08	0503016864	LH 1/2" LOCK NUT	00	01	

15X15 SEED UNAL DOUB-DISC ASSY


0909093298



Item	Code	Description	See page	DIR	ESQ
00	0501059631	DDD SEED 15" X 15" RIGHT		01	00
00A	0501059632	DDD SEED 15X15 LEFT		00	01
01	0511052301	SUPPORT DDD 15 RIGHT		01	00
01A	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01	00
01B	0571012491	SOCKET SEED GUIDE		01	01
01C	0503010838	0.1" X 0.8" SPRING PIN		02	02
02	0511052302	LH SUPPORT DDD GUIDE		00	01
02A	0561015592	LEFT DOUBLE DISC SUPPORT		00	01
03	0511015098	FLAT WASHER		06	06
04	0511011927	DUST CLOAK		02	02
05	0501054167	BOX DDD ASSY DPL 15 RIGHT		01	00
05A	0502011930	DOUBLE DISC COULTER BOX		02	02
05B	0503010598	30204 BALL BEARING		04	04
05C	0503011112	SEAL 02376-BRG		02	02
05D	0521019154	RIGHT DOUB DISC HUB		01	00
05E	0503030282	3/4" CASTLE NUT		02	02
05F	0503010257	1/8" X 1" COTTERPIN		02	02
05G	0603022042	13" X 0.12" PLAIN COULTER BLADE		02	02
05H	0503010546	5/16" X 7/8" BOLT		12	12
05I	0503010337	5/16" NUT		12	12
06	0501054168	BOX DDD ASSY DPL 15 LEFT		00	01
06A	0521019148	LEFT DOUBLE DISC HUB		00	01
07	0503030757	2.9" X 2" X 0.02" JOINT		02	02
08	0521019178	COVER DEPTH		02	02
09	0503014729	1/4" UNF X 1/2" BOLT		06	06
10	0503011441	SPRING WASHER		06	06
11	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01	01
12	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01	01
13	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01	01
14	0501010984	FLAT WASHER		02	02
15	0503011443	3/8" SPRING WASHER		01	01




Item	Code	Description	See page	DIR	ESQ
16	0503010026	3/8" NUT		01	01




Item	Code	Description	See page	QT
00	0521042711	SEED DISTRIBUTOR ASSY	44	01
01	0501110615	SOPORTE SUPERIOR SISTEMA DE SEMILLA		01
01A	0502012580	SEED SYSTEM UPPER SUPPORT		01
01Aa	0503011770	SEAL # V-75 A		01
01Ab	0502012649	18Z CONICAL GEAR 34 TEETH		01
01Ac	0503011771	6008 2RS BALL BEARING		01
01B	0502050003	SUPPORT INTERNAL DISC SEED VULCANIZ		01
01C	0503011378	M6X1X16 C S 8.8 ZN BOLT		01
01D	0503010143	1/4" SPRING WASHER		01
01E	0503012849	2-129 N 3006 9B O'RING		01
01F	0503033121	PNEUMATIC SWITCH		01
01G	0503011295	M 8 X 1,25 X 25 BOLT		01
01H	0503010427	METRIC M8 X P.0.5" NUT		01
01I	0503010217	501040 CLAMPING RING (FOR AXLE)		01
02	0503033800	PNEUMATIC JOINT SEALING		03
03	0511053902	CARDAN WHIT SUPPORT		01
04	0503011294	M 8 X 1,25 X 20 BOLT		03
05	0503010025	3/8" SPRING WASHER		03
06	0503011370	DISC 6440 MIDDLE SOYBEAN		01
07	0501058950	SEED SYSTEM SIDE		01
07A	0561012486	LATERAL COVER		01
08	0511017186	SEED LEVEL REGULATOR		01
09	0511017303	FLAT WASHER		04
10	0503011776	M6 SELF ADJUSTINGNUT		01
11	0503014141	M6 X 1 X 20 BOLT		01
12	0503011817	UPPER SELECTOR		01
13	0502020559	UPPER SELECTOR ACTUATOR		01
14	0531014481	0.2" X 0.6" AXLE		01
15	0503011821	CRINKLE WASHER		01
16	0503011823	0.1" X 0.6" SPRING PIN		02
17	0511017219	SCALE INDICATOR GUIDE		01

Item	Code	Description	See page	QT
18	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
19	0503010143	1/4" SPRING WASHER		03
20	0503011810	M6 X 1" BUTTERFLY BOLT		01
21	0503031058	UPPER SELECTOR SCALE		01
22	0503011825	M4 X 8" BOLT		02
23	0503011840	FLAT WASHER		02
24	0501110311	LOWER SELECTOR ASSY		01
25	0503011813	M6 X 1.2" BOLT		01
26	0511016220	LOWER SELECTOR INDICATOR		01
27	0503011815	TOOTHED WASHER		01
28	0503012445	M6 C/ABA 1.20" BUTTERFLY NUT		04
29	0503013179	PNEUMATIC SEED DISTRIBUTOR VISOR		01
30	0561012741	SEED DRAINER COVER		01
31	0503011809	M12 KNOB		01
32	0503011828	FLAT WASHER		01
33	0503011827	504.100 CLAMPING RING (FOR HOLE)		01
34	0503011104	M6 X 1" BOLT		02
35	0503011820	CRINKLE WASHER		02
36	0511017199	PST SUP AXLE		01
37	0511017198	SCALE INDICATOR		01
38	0503015536	M6 X 1" SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
00	0511051187	ROW MARK SET COP 19		01
01	0541012195	ARM BEFORE ARTICULICION AXLE		02
02	0521062492	RIGHT SUPPORT SMALLER		01
03	0521062493	LEFT SUPPORT		01
04	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		08
05	0503010027	5/8" SPRING WASHER		08
06	0503010013	5/8" NUT		08
07	0503011052	1.1/4" X 0.77" CASTLE NUT		06
08	0503010067	3/16" X 2.1/2" COTTER PIN		06
09	0511065479	BEFORE ARM (ROW MARKER)		02
10	0511043513	HYDRAULIC MARKER CYLINDER	46	02
11	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
12	0541015714	CYLINDER ARTICULACCION ALXE		02
13	0551016251	PIVOT SHAFT		02
14	0511065476	LARGER LEVER		02
15	0511065480	RIGHT INTERMEDIATE ARM		01
16	0511065481	LEFT INTERMEDIATE ARM		01
17	0541012194	INTERMEDIATE ARM ARTIC ALXE		02
18	0511065484	ROW MARK ARM		02
19	0541012193	MARK ARM ARTICULACCION ALXE		02
20	0511065487	REGULATOR SPINDLE		02
21	0511065475	ADJUSTMENT ROD		02
22	0541012196	SMALLER LEVER		02
23	0511065477	2000 TURNBUCKLE		02
24	0541015917	MARK ARM GUIDE		02
25	0511042494	ROW MARKER DISC ASSY	48	02
26	0501014063	25 X 55 COUPLING SHAFT		10
27	0503030085	LOCK PIN		10
28	0501011445	FLAT WASHER		10
29	0503010002	1800 GREASE FITTING		06
30	0501019435	32 X 50 X 1.5 FLAT WASHER		08


Item	Code	Description	See page	QT
31	0501068994	0.3" X 3.1" LOCK PIN		02
32	0503030168	HAIR PIN		02
33	0503010060	1/2" NUT		02
34	0503010019	1/2" SPRING WASHER		02
35	0503010523	1/4" X 2" COTTERPIN		08
36	0503011070	BEATER		02
37	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04




Item	Code	Description	See page	QT
00	0511043513	HYDRAULIC MARKER CYLINDER	46	01
01	0511065493	2.9" X 203" CYLINDER CASE		01
02	0511065492	38,10 ROD		01
03	0502010783	1.5" X 2.5" PISTON		01
04	0503010973	W2-2500-500 PK O'RING G.E		01
05	0503010160	2500 2000 GASKET		02
06	0503010285	2-222 N 3006-9B O'RING		01
07	0503010063	1" SELF-ALIGNING NUT		01
08	0502010780	RING SUPPORT		01
09	0503010970	W1-1650-500 PK O'RING G.E		01
10	0503010989	1870-1500-375-B GASKET		01
11	0503010163	D-1500 SCRAPER RING		01
12	0503010161	2-330 N 3006 9B O'RING		01
13	0503011058	8-330 BACK-UP RING		01
14	0502010471	MOBILE COVER		01
15	0503010002	1800 GREASE FITTING		02
16	0551016274	HYDRAULIC CYLINDER ADAPTER		02
17	0501035500	HYDRAULIC CYLINDER REPAIR KIT		01




Item	Code	Description	See page	QT
01	0501081853	HOSE 3/8		04
02	0501054649	SEQUENTIAL VALVE ASSY		01
02A	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02B	0501010617	3/4" NIPPLE		02
02C	0503010190	2-114 N 3006-9B O'RING		01
02D	0501012109	3/4" X 9/16" NIPPLE		04
02E	0503011036	2-111 N 3006-9B O'RING		06
02F	0531017427	3/4" X 06" PUMP		02
03	0501081851	HOSE 3/8		02
04	0501081820	HOSE 3/8		02
05	0501081856	HOSE 3/8		02
06	0511043513	HYDRAULIC MARKER CYLINDER	46	02
07	0511068881	1000 OIL TUBE		04
08	0501081816	HOSE 3/8		04
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
10	0501010984	FLAT WASHER		02
11	0511069733	4485 OIL TUBE		04
12	0503010025	3/8" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0502011907	DEPTH CONTROL WHEEL HUB		01
02	0503010269	6204 BALL BEARING		02
03	0503010689	SEAL 00763-BR		01
04	0503011105	SEAL RING		01
05	0501013636	SPACING SLEEVE		01
06	0602023110	DR16X3 NOTCHED DISC BLADE		01
07	0503010358	5/16" X 5/8" BOLT		04
08	0503010179	5/16" ZN SPRING WASHER		04
09	0503010337	5/16" NUT		04
10	0511065478	ROW MARKER DISC AXLE		01
11	0503010878	5/8" SELF ALIGNING NUT		01
12	0521019178	COVER DEPTH		01
13	0503030757	2.9" X 2" X 0.02" JOINT		01
14	0503814729	BOLT		03
15	0503011441	SPRING WASHER		03
16	0503010691	1/4" GREASE FITTING		01
17	0501069226	ROW MARKER ROD STOP		01
18	0501011778	3/8" X 2-1/2" BOLT		04
19	0503010025	3/8" SPRING WASHER		04
20	0503010026	3/8" NUT		04
21	0503010023	3/4" SPRING WASHER		01
22	0503010014	3/4" NUT		01



Item	Code	Description	See page	QT
00	0501058486	TRANSPORT SUPPORT ASSY	49	01
01	0521060025	TRANSPORT SUPPORT		03
02	0521062623	STAND		01
03	0521062624	STAND		02
04	0561019801	LOCK PIN		02
05	0561010272	L 76,20 X 1300 WITH HOLE		06
06	0501018652	CORN STABILIZER BAR		12
07	0501010098	3/4" UNC BOLT		24
08	0503010023	3/4" SPRING WASHER		24
09	0503010014	3/4" NUT		24
10	0503012410	5/8" X 7.1/2" BOLT		02
11	0551015037	5/8" UNC X 210 X 198 FASTENER		06
12	0503010027	5/8" SPRING WASHER		12
13	0503010013	5/8" NUT		12
14	0521063556	EASEL HIGHER		02



Item	Code	Description	See page	24	27	30	32
01	0501059954	DRIVER AIR		02	02	00	00
01.	0501059953	DRIVER AIR		00	00	02	02
02	0501058617	DRIVER AIR		01	01	01	01
03	0571012769	DRIVER AIR LEFT		01	01	01	01
03.	0571012770	CONDUCTOR OF AIR LAW		01	01	01	01
04	0503010237	3/8" X 1" BOLT		28	28	28	28
05	0503010025	3/8" SPRING WASHER		28	28	28	28
06	0503010026	3/8" NUT		28	28	28	28
07	0521018402	AIR CONDUCTOR CLAMP		12	12	12	12
08	0503010371	5/16" X 1" BOLT		24	24	24	24
09	0503010179	5/16" ZN SPRING WASHER		24	24	24	24
10	0503010337	5/16" NUT		24	24	24	24
11	0561018848	HOSE FIXER ASSY		04	04	04	04
12	0521041589	TURBINA MTH USAP COMPL V480 S-0113		00	00	02	02
13	0503031576	ELBOW		04	04	04	04
14	0521016430	4" X 200 PVC TUBE		04	04	04	04
15	0503011372	102 TO 121 CLAMP		04	04	04	04
16	0511056318	DRIVER AIR		02	02	02	02
17	0501059953	DRIVER AIR		02	02	02	02



Item	Code	Description	See page	QT
01	0521060122	TURBINE SUPPORT	01	
02	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN	06	
03	0503010027	5/8" SPRING WASHER	06	
04	0503010013	5/8" NUT	06	
05	0571012636	FRONT COVER	01	
06	0503010237	3/8" X 1" BOLT	04	
07	0503010025	3/8" SPRING WASHER	04	
08	0503010026	3/8" NUT	04	
09	0501054983	NIPPLE HIDRAULIC MOTOR	01	
09A	0503012871	HYDRAULIC MOTOR	01	
09B	0531018770	R 3/4"UNF X R 1/4"BSP ELBOW	01	
09C	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE	02	
09D	0541011065	3/4"UNF X R1/4BSP19FPP X43.5 NIPPLE	01	
09E	0561016941	3/4" NUT	01	
10	0503010849	3/8" X 1-1/2" BOLT	02	
11	0561010634	VALVE SUPPORT ASSY	01	
12	0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE	01	
12A	0503012291	BLOCK COMMAND	01	
12B	0501010590	NIPPLE	04	
12C	0503010045	O'RING	04	
12D	0541011066	3/4" UNF X 43.5 NIPPLE	01	
12E	0503010190	2-114 N 3006-9B O'RING	01	
13	0503010206	3/8" X 1/2" BOLT	02	
14	0501080125	HOSE 1/2 X 500 TR TR	01	
15	0501080635	3/8" X 19" TR-TR HOSE	02	
16	0501080569	3/8" X 67" TR-TM HOSE ASSY	01	
17	0501080485	3/8" X 1100 TR-TC HOSE	02	
18	0501080436	HOSE 3/8 X 1500 TR-TC	01	
19	0501080076	1/2" X 2500 TR-TM HOSE ASSY	02	
20	0501080825	1/2" X 1100 TR-TC HOSE	04	
21	0501080275	1/2" X 1500 TR-TC HOSE ASSY	02	

Item	Code	Description	See page	QT
22	0521044613	FAN 480X50 (HIDRAULIC)		01
23	0503013031	1/4" X 3.1/4" BOLT		15
24	0531018764	FLAT WASHER		01
25	0503010143	1/4" SPRING WASHER		01
26	0503011104	M6 X 1" BOLT		01
27	0501054272	RIBBON FOR COVER CLOSING ASSY		01
28	0503031776	TURBINE RIBBON SEAL		02
29	0571012630	REAR COVER		01
30	0503010499	5/16" UNC BUTTERFLY NUT		02
31	0511014024	10 X 13 X 15,5 SLEEVE		02
32	0503012721	1/4" X 4" BOLT		02
33	0511017303	FLAT WASHER		34
34	0503012880	1/4" UNC SELF ADJUSTING NUT		17
35	0501056495	TURBINE OUTPUT SOCKET		01
36	0503013096	5/16" X 4" BOLT		02
37	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
38	0503010179	5/16" ZN SPRING WASHER		02
39	0502012272	FAN CENTER		01
40	0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE		01
41	0561010634	VALVE SUPPORT ASSY		01
42	0521060118	"T" TERMINAL		01
43	0561010635	SWITCH FIXER		01
44	0503013584	VACUUM GAUGE		02
45	0503015062	TUBE		0,5MT
46	0561016720	MALE TERMINAL		01
47	0521062284	OIL TUBE		06
48	0521062283	OIL TUBE		06
49	0521041589	TURBINA MTH USAP COMPL V480 S-0113		01



www.marchesan.com.br



Technical Publications | Elaboration and Revision
JOSÉ DOMINGOS GASPARI