

ROW CROP PLANTERS

PST4 - FRAME 4845

(FROM 05/2023)

Code: 0501091408
Series: S-0116
Revision: 00
Date Revision: SETEMBRO/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111151268	PST4 4845/10E500 CI MH DC20 S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.

INDEX


0909096888	ASSY FRAME - 4845	1
0501058196	WHEEL AXLE FRAME - 4845	2
0511056529	CYLINDER ASSY	3
0511058406	HYDRAULIC CYLINDER	4
0521043934	CARRYING WHEELS SPRING TRACTION	5
0501058240	WHEEL FASTENER WITH TENSIONER	6
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	7
0501058239	WHEEL CHAIN TENSIONER BEARING	8
0501058244	WHEEL FIXED CHAIN TENSIONER	9
0501058242	WHEEL MOBILE CHAIN TENSIONER	10
0511056740	RIGHT TRANSMISSION ASSY - 4880	11
0501052560	MOTOR AXLE SIGNAL	12
0511051434	TRANSMISSION ACTUATOR	13
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	14
0521043316	RIGHT GEAR BOX ASSY	15
0501058212	SEMI MOUNTED RIGHT CHANGE	16
0511059266	CLOSED BEARING	17
0501056271	GEARBOX CLOSED BEARING	18
0501056443	GEAR HOUSING BEARING	19
0501056444	SUPPORT WITH ROLLER BEARING	20
0501048790	AXLE WITH RING	21
0501054655	CHAIN TENSIONER ASSY	22
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	23
0511054363	CHAIN TENSIONER	24
0501058234	LOWER CHAIN TENSIONER	25
0521055207	TOP CURRENT STRETCHER	26
0501058236	BEARING WITH 21Z GEAR	27
0501058237	16Z GEAR BEARING	28
0501055112	MICRO GRANULATED CHAIN TENSIONER	29
0511056741	LEFT TRANSMISSION ASSEMBLY - 4880	30
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	31
0521043317	LEFT GEAR BOX ASSY	32
0501058213	LH GEAR BOX	33
0511057146	HYDRAULIC SYSTEM ASSY - 4845/5345	34
0501053834	MALE QUICK COUPLER	35
0501058172	SEMI-ASSEMBLED HYDRAULIC MARKER 4845	36
0511058449	HYDRAULIC CYLINDER	37
0501054649	HBM SEQUENTIAL VALVE	38
0531056603	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4845	39
0531056604	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 4845	40
0531055319	ALPHA II FERTILIZER METERING	41
0531055863	ASSY TRANSMISSION HUB	42
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	43
0531059139	ASSY COLLECTOR	44
0531055273	ALPHA FERTILIZER METERING CLAMP	45
0501053788	3/4" SQUARE AXLE FASTENER	46
0531057911	22Z GEAR SIDE BEARING ASSEMBLY	47
0531057901	GEAR	48
0531056605	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 4845	49
0511057650	PLATFORM ASSY - 4845	50
0511057651	HANDRAIL ASSY - 4845	51
0511056536	LADDER ASSEMBLY	52
0511054971	JACK ASSEMBLY	53
0511057150	DRAWBAR ASSEMBLY - 4845/5345	54



MARCHESAN


INDEX

0511057131	MANUAL CANISTER ASSY	55
0531057770	LABEL SET - 4845	56
0501054258	DRAWBAR ESTABILIZER ASSY	57
0511054601	HITCH ARTICULATED TRACTOR	58
0511053179	TRACTOR COUPLING SHAFT	59
0511056736	HOSE SUPPORT	60
0531059620	KIT WITH ALPHA COMPONENTS - 10 ROWS	61
0909095145	ASSY HEX AXLE	62
0501050633	ROW MARKER DISC ASSEMBLY	63
0511053904	ROW MARKER DISC	64
0909096889	ASSY SEED/FERTILIZER ROW	65
0511053254	FERTILIZER SHORT ROW WITH LEFT DDD/20" DC	66
0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	67
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	68
0511053172	LEFT LOW HUB WITH 15 DISC	69
0511053173	RIGHT LOW HUB WITH 15 DISC	70
0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	71
0521054680	20" DISC BLADE HUB	72
0521054679	DISC BLADE HUB	73
0501058423	FERTILIZER ROD SPRING ROW	74
0511053255	FERTILIZER LONG ROW WITH RIGHT DDD/20" DC	75
0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	76
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	77
0511044585	20" COULTER BLADE ASSY FOR LONG ROW	78
0531054087	SIGMA LONG SEED ROW	79
0511056601	LONG SEED ROW FRONT DDD LEFT	80
0511051693	BASE FIXING SYSTEM	81
0511056586	15 X 15 SEED DDD LEFT	82
0511052302	LH SUPPORT DDD GUIDE	83
0511058212	FERTILIZER ROW SUPPORT ASSY	84
0511052024	FAST CLOSING SET	85
0531053925	SIGMA SOY INDIVIDUAL SEED SYSTEM	86
0531054088	SIGMA LONG SEED ROW	87
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	88
0511056600	RIGHT DDD SHORT SEED ROW FRONT	89
0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	90
0511052301	SUPPORT DDD 15 RIGHT	91
0503063647	SIGMA CORN DISC SET	92
0503063648	SIGMA SOY DISC SET	93



Item	Code	Description	See page	QT
01	0501058196	WHEEL AXLE FRAME - 4845	2	01
02	0511056529	CYLINDER ASSY	3	01
03	0521043934	CARRYING WHEELS SPRING TRACTION	5	04
04	0511056740	RIGHT TRANSMISSION ASSY - 4880	11	01
05	0511056741	LEFT TRANSMISSION ASSEMBLY - 4880	30	01
06	0511057146	HYDRAULIC SYSTEM ASSY - 4845/5345	34	01
07	0501058172	SEMI-ASSEMBLED HYDRAULIC MARKER 4845	36	01
08	0531056603	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4845	39	01
09	0511057650	PLATFORM ASSY - 4845	50	01
10	0511057651	HANDRAIL ASSY - 4845	51	01
11	0511056536	LADDER ASSEMBLY	52	02
12	0511054971	JACK ASSEMBLY	53	02
13	0511057150	DRAWBAR ASSEMBLY - 4845/5345	54	01
14	0511057131	MANUAL CANISTER ASSY	55	01
15	0531057770	LABEL SET - 4845	56	01
16	0501047886	35 ROD STOP		02
17	0501047887	40 ROD STOP		02
18	0501047895	25 ROD STOP		02
19	0501047885	30 ROD STOP		02
20	0521013164	EXTENDER		02
21	0501011310	FIXER LOCK		08
22	0501065677	STRUT		02
23	0501054258	DRAWBAR ESTABILIZER ASSY	57	01
24	0511054601	HITCH ARTICULATED TRACTOR	58	01
25	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
26	0511053179	TRACTOR COUPLING SHAFT	59	01
27	0521013022	TRANSPORT LOCK		02
28	0511056736	HOSE SUPPORT	60	01
29	0503014120	CHAIN		01
30	0503014321	CABLE STEEL SHACKLE		02
31	0531059620	KIT WITH ALPHA COMPONENTS - 10 ROWS	61	01


Item	Code	Description	See page	QT
32	0503010003	1845 GREASE FITTING		06
33	0909095145	ASSY HEX AXLE	62	01
34	0501068994	8,30 X 78 LOCK PIN		02
35	0503030168	HITCH PIN CLIP		02
36	0503010780	N-2050 AMENDMENT		02
37	0503010951	REDUCTION		04
38	0503011750	AMENDMENT WITH LOCK		06
39	0503011751	REDUCTION		06
40	0501050633	ROW MARKER DISC ASSEMBLY	63	02
41	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		08
42	0503010019	1/2" SPRING WASHER		08
43	0503010060	1/2 UNC G.5 ZN HEX NUT		08
44	0909096889	ASSY SEED/FERTILIZER ROW	65	01




Item	Code	Description	See page	QT
01	0511069616	FRAME		01
02	0511069717	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8 UNC X 2.1/4 BOLT		12
05	0501012140	FLAT WASHER		24
06	0531013922	0.6" X 0.8" X 1" SLEEVE		12
07	0503011445	SPRING WASHER		12
08	0503010013	5/8 NUT		12

CYLINDER ASSY


0511056529




Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	4	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521012536	COUPLING SHAFT		02
04	0503010523	1/4" X 2" SPLIT PIN		04
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010013	5/8 NUT		02




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCKLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O'RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O'RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0501058240	WHEEL FASTENER WITH TENSIONER	6	01
02	0503011119	7/8" X 6" BOLT		04
03	0501014251	FLAT WASHER		04
04	0503011254	7/8" HEX SELF ADJUSTING NUT		04
05	0501059909	CARRYING WHEELS SUPPORT		01
06	0503014887	2050 CHAIN X 80 LINK + REDUCTION		01
07	0502010584	CARRYING-WHEELS SUPPORT FIXER		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8 NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	7	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	9	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	10	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	8	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01



Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	8	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	8	01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	12	01
15	0511051434	TRANSMISSION ACTUATOR	13	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	14	01
17	0521043316	RIGHT GEAR BOX ASSY	15	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	24	01
26	0501058234	LOWER CHAIN TENSIONER	25	01
27	0521055207	TOP CURRENT STRETCHER	26	01
28	0501058236	BEARING WITH 21Z GEAR	27	01
29	0501058237	16Z GEAR BEARING	28	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	29	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01




Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02



Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0521017590	GUIDE AXLE		01
03	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
04	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
05	0501019734	FLAT WASHER		02
06	0502010710	RIGHT CAM, SMALLER		02
07	0503010003	1845 GREASE FITTING		02
08	0502012539	26Z P12,7 GEAR		01
09	0501019735	FLAT WASHER		01
10	0521017593	FLAT WASHER		01
11	0503010542	501045 CLAMPING RING (FOR AXLE)		01
12	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01

RIGHT GEAR BOX ASSY


0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	16	01
02	0511059266	CLOSED BEARING	17	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	19	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	21	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	22	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	23	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX	01	
02	0502011758	REAR TIGHTENER LEVER	02	
03	0503010292	701164 6 X 40 SPRING PIN	02	
04	0511061794	CHAIN TENSIONER	01	
05	0503031367	SPRING	01	
06	0511060392	CHAIN TENSIONER	01	
07	0503031366	RIGHT TWISTED SPRING	01	




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	18	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	SUPPORT WITH ROLLER BEARING	20	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	GEARBOX SUPPORT		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011978	CENTRAL BEARING GEARBOX		01
02	0503013462	6005 2RS1 ROLLER BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8 SPRING WASHER		01
09	0503010013	5/8 NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503019355	BEARING 6202 2RS1		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0551019173	CHAIN SLEEVE TENSIONER		01
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01
08	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01



Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOUBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019174	DOUBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
06	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	12	01
15	0511051434	TRANSMISSION ACTUATOR	13	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	31	01
17	0521043317	LEFT GEAR BOX ASSY	32	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	24	01
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	29	01
27	0501058234	LOWER CHAIN TENSIONER	25	01
28	0521055207	TOP CURRENT STRETCHER	26	01
29	0501058236	BEARING WITH 21Z GEAR	27	01
30	0501058237	16Z GEAR BEARING	28	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01


Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	33	01
02	0511059266	CLOSED BEARING	17	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	19	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	21	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	22	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	23	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LH GEAR BOX


0501058213




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01



Item	Code	Description	See page	QT
01	0511063404	"T" OIL CONDUCTOR		02
02	0581010091	SPRING PROTECTION PLASTIC HOSE		01
03	0503013100	NYLON CLAMP		02
04	0502012702	BODY SUPPORT CLAMP		02
05	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		02
06	0503010180	7/16" SPRING WASHER		02
07	0501053834	MALE QUICK COUPLER	35	02
08	0511057068	HOSE KIT SYSTEM HYDRAULIC		01
08A	0501080449	3/8" X 1500 TC-TC HOSE		04
09	0521052334	3/8 X 4000 TR-TM HOSE BLACK / BLUE		01
09A	0501080361	3/8" X 157" TR-TM HOSE		01
09B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
09C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
09D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
10	0521052333	3/8 X 4000 TR-TM HOSE BLACK / RED		01
10A	0501080361	3/8" X 157" TR-TM HOSE		01
10B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
10C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
10D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8" UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503011082	C1/2" X 1.3/4" SCREW		02
07	0501069470	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0501012140	FLAT WASHER		04
11	0503012412	5/8" UNC SELF LOCKING NUT		02
12	0511058449	HYDRAULIC CYLINDER	37	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" SPLIT PIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501066949	1235 TURNBUCKLE		02
21	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
22	0511011311	VALVE SUPPORT		01
23	0503010232	5/8" X 1.3/4" BOLT		02
24	0503010027	5/8 SPRING WASHER		02
25	0503010013	5/8 NUT		02
26	0501054649	HBM SEQUENTIAL VALVE	38	01
27	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
28	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
29	0503010025	3/8 SPRING WASHER		02
30	0502012702	BODY SUPPORT CLAMP		06
31	0503011103	7/16" X 2-1/2" BOLT		06


Item	Code	Description	See page	QT
32	0501012803	FLAT WASHER		02
33	0503010180	7/16" SPRING WASHER		06
34	0503010244	7/16" NUT		06
35	0501053834	MALE QUICK COUPLER	35	02
36	0511057069	HYDRAULIC HOSE MARKER ASSY		01
36A	0501080343	TR-TR HOSE ASSY		02
36B	0501080720	HOSE 3/8 X 3500 TR-TC		02
37	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
37A	0501080422	HOSE 3/8 X 4000 TC-TM		01
37B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
37C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
37D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
38	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
38A	0501080422	HOSE 3/8 X 4000 TC-TM		01
38B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
38C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
38D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06

HYDRAULIC CYLINDER


0511058449




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCIAL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0531056604	RIGHT HOPPER SUPPORT WITH FERTILIZER 40 METERING - 4845		01
02	0531056605	LEFT HOPPER SUPPORT WITH FERTILIZER 49 METERING - 4845		01
03	0503062169	ASSEMBLED FERTILIZER HOPPER		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		20
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		40
07	0503010025	3/8 SPRING WASHER		20
08	0503010026	3/8" NUT		20
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0501010694	FLAT WASHER		04
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" SPLIT PIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531064717	RIGHT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	41	06
03	0501053788	3/4" SQUARE AXLE FASTENER	46	03
04	0503031527	AGRICULTURAL BEARING		03
05	0501218487	3/4 X 390 AXLE		05
06	0531057908	SLEEVE 1/4 X 2		06
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	47	01
08	0501218676	3/4 X 125 AXLE WITH HOLE		01
09	0501218674	3/4 X 290 AXLE		01



Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	ASSY TRANSMISSION HUB	42	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	43	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0503035931	FERTILIZER METERING SEAL		01
12	0513011173	NUT 3/8 UNC X 1		04
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
14	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
15	0513011170	ALLEN SCREW 1/4 UNC X 7/8 CCSI STAINLESS STEEL		04
16	0513011171	1/4 NC HEX NUT		08
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0501310211	FRONT LID		01
19	0503036177	LID CORD		01
20	0531059139	ASSY COLLECTOR	44	01
21	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
22	0503035797	FRONT COLLECTOR FIXER		02
23	0501111195	GRANULATED FERTILIZER COATING		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO ADHESIVE LABEL 41.5 X 29		01
15	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT FERTILIZER METERING LID GUIDE		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT SAFETY LOCK SLEEVE		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT SAFETY LOCK SLEEVE		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01

ASSY COLLECTOR


0531059139




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	45	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007		02
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0503010337	5/16" NUT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0502013067	SIDE BEARING AXLE FERTILIZER HOPPER SUPPORT		01
06	0531057901	GEAR	48	01
07	0503010845	501035 CLAMPING RING (FOR AXLE)		01
08	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531065402	GEAR		01
02	0503013958	1/4" X 1" BOLT		02



Item	Code	Description	See page	QT
01	0531064718	LEFT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	41	06
03	0501053788	3/4" SQUARE AXLE FASTENER	46	03
04	0503031527	AGRICULTURAL BEARING		03
05	0501218487	3/4 X 390 AXLE		05
06	0531057908	SLEEVE 1/4 X 2		06
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	47	01
08	0501218676	3/4 X 125 AXLE WITH HOLE		01
09	0501218674	3/4 X 290 AXLE		01




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT		04
02	0503010849	3/8" X 1-1/2" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0511069718	PLATFORM RIGHT		01
07	0521062324	PLATFORM LEFT		01
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
09	0503011336	1/2" HEX SELF ADJUSTING NUT		04
10	0503011333	COVER FIXER		02
11	0503010274	5/32" X 2" SPLIT PIN		02
12	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
13	0502012739	PLATFORM LEFT FIXER SUPPORT		01



Item	Code	Description	See page	QT
01	0511069660	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08

LADDER ASSEMBLY


0511056536




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8 SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
08	0503013357	3/8 SELF-ADJUSTING NUT	02	

JACK ASSEMBLY


0511054971




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	1902012329	REAR SUPPORT FIXING DRAWBAR	04	
02	1902012330	FIXER SUPPORT ARTICULATED	08	
03	0503011084	3/4" X 5" BOLT	16	
04	0503010023	3/4" SPRING WASHER	16	
05	0503010014	3/4" HEX NUT	16	
06	1902012328	FIXED FRONT SUPPORT DRAWBAR	04	
07	0561014393	COUPLING SHAFT	04	
08	0503030119	LOCK PIN	08	
09	0511064808	DRAWBAR	01	
10	0561019087	DRAWBAR TRANSPORT LOCK	01	
11	0521010588	0.9" X 7.0" COUPLING SHAFT	01	
12	0521010578	COUPLING SHAFT	01	
13	0503030085	LOCK PIN	02	
14	0503010002	1800 GREASE FITTING	01	
15	0501010322	FLAT WASHER	16	




Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0503010267	NYLON CLAMP		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
06	0503033422	ADHESIVE LABEL	02	
07	0503033008	ADHESIVE LABEL	02	
08	0503031428	READ MANUAL DECAL	01	
09	0503031942	ADHESIVE LABEL	01	
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27	02	
11	0503031565	ADHESIVE LABEL CARE	02	
12	0503031566	ADHESIVE LABEL	02	
13	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
14	0503031425	ADHESIVE LABEL ATTENTION	02	
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER	02	
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503032930	ADHESIVE LABEL DANGER	06	
19	0503031087	AUTO CONTROL APPROVED DECAL	01	
20	0503034078	LIFTING POINTS DECAL	03	
21	0503034003	61 X 118 SERIAL NUMBER TAG	01	
22	0503010001	3.2 X 5.5 RIVET	04	
23	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
24	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0511062887	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING	01	
02	0503016482	BOLT	02	
03	0502040846	U TRACTOR HITCH	01	
04	0581019654	ASSY BOLT	01	
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT	01	
06	0503010010	1/4" X 2.1/2" SPLIT PIN	01	
07	0521010681	BUSHING COUPLING BODY	01	
08	0521010639	COUPLING SHAFT	01	
09	0503010571	1/4" X 1.1/2" SPLIT PIN	01	
10	0503033731	LEFT COMPRESSION SPRING	02	
11	0503010396	501060 CLAMPING RING (FOR AXLE)	01	
12	0503011331	3/8 BALL	02	
13	0501110778	TRACTOR HITCH	01	



Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		10
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		10
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01

ASSY HEX AXLE

0909095145




Item	Code	Description	See page	3245	4045	4845
01	0521013432	5/8" X 59" AXLE HEX		01	00	00
01.	0521013429	AXLE HEX 5/8 X 2180		00	01	00
01..	0521013430	HEX AXLE 5/8 X 2580		00	00	01
02	0521013428	HEX AXLE		01	00	00
02.	0521013433	5/8" X 75" AXLE HEX		00	01	00
02..	0521013434	HEX AXLE 5/8 X 2300		00	00	01
03	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"		02	02	02
04	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8		02	02	02
05	0503010003	1845 GREASE FITTING		02	02	02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04	04	04
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04	04	04
08	0501010694	FLAT WASHER		08	08	08
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		04	04	04
10	0503010337	5/16" NUT		04	04	04
11	0511815098	FLAT WASHER		02	02	02
12	0511017305	FLAT WASHER		04	04	04
13	0511065562	20Z GEAR		02	02	02
14	0502011299	BUSHING GEAR		02	02	02
15	0503010571	1/4" X 1.1/2" SPLIT PIN		02	02	02
16	0503010010	1/4" X 2.1/2" SPLIT PIN		02	02	02




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	64	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01

ROW MARKER DISC


0511053904




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0511053254	FERTILIZER SHORT ROW WITH LEFT DDD/20" DC	66	01
02	0511053255	FERTILIZER LONG ROW WITH RIGHT DDD/20" DC	75	01
03	0531054087	SIGMA LONG SEED ROW	79	01
04	0531054088	SIGMA LONG SEED ROW	87	01
05	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	88	01
06	0501013714	STABILIZER BAR		01
07	0503031050	CURVED CONDUCTOR		01
08	0503010246	CLAMP		01
09	0501018652	CORN STABILIZER BAR		01
10	0501110231	SCARIFIER ROD WITH TIP		01
11	0511017969	0.1" SPACING PLATE		01
12	0521069124	PIVOTED FERTILIZER ROW NOZZLE		01
13	0503063647	SIGMA CORN DISC SET	92	01
14	0503063648	SIGMA SOY DISC SET	93	01
15	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
16	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
17	0503010025	3/8 SPRING WASHER		01
18	0503010026	3/8" NUT		01
19	0503010905	1/2" X 2-1/4" BOLT		01
20	0503010019	1/2" SPRING WASHER		01
21	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT 67 DOUBLE DISC		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	71	01
07	0501058423	FERTILIZER ROD SPRING ROW	74	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	68	01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	69	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	70	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8 SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01



Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUBLE DISC AXLE		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE		01
03	0541018684	FLAT WASHER		01
04	0503010756	0.2" X 2.4" SPRING PIN		01
05	0503010361	SPRING PIN		01
06	0503010003	1845 GREASE FITTING		01
07	0521014137	RIGHT ARM BLADE DISC		01
08	0521014138	LEFT DISC BLADE ARM		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0503011255	3/4" LOCK NUT		01
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
14	0503011411	1/2" X 5-1/2" BOLT		01
15	0503010019	1/2" SPRING WASHER		01
16	0503010060	1/2 UNC G.5 ZN HEX NUT		01
17	0502020393	SPRING UPPER SUPPORT		01
18	0502020394	SPRING SUPPORT		01
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
20	0503010014	3/4" HEX NUT		02
21	0521054680	20" DISC BLADE HUB	72	01




Item	Code	Description	See page	QT
01	0521054679	DISC BLADE HUB	73	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01

DISC BLADE HUB


0521054679




Item	Code	Description	See page	QT
01	0502011562	DISC BLADE HUB		01
02	0502020641	BLADE DISC FLANGE		01
03	0503010276	6206 BALL BEARING		02
04	0521013610	BLADE DISC HUB AXLE		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
06	0503012417	SEAL		02
07	0503011800	SEAL RING		02
08	0503010691	1/4" GREASE FITTING		01
09	0521015376	DUST CLOAK		02
10	0503030832	FLAT WASHER		02
11	0511015346	FLAT WASHER		02
12	0521013510	3/4" NUT		02
13	0503010012	1" SPRING WASHER		02
14	0503010371	5/16" X 1" BOLT		06
15	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD		01
02	0502040534	SPRING GUIDE BUSHING LOCK		02
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502012510	SPRING ROD SUPPORT		01
06	0503010257	1/8" X 1" SPLIT PIN		01
07	0501018535	1/2 X 1 BOLT		02
08	0503030678	BOLT 1/2 UNC X 1.1/2 C50P G.5 ZN		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02
10	1902010891	SPRING CHOCK SUPPORT VARON		01
11	0503010014	3/4" HEX NUT		01
12	0561014471	COUPLING SHAFT		01
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	76	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	78	01
07	0501058423	FERTILIZER ROD SPRING ROW	74	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061153	FERTILIZER ROW LONG ARM		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	77	01




Item	Code	Description	See page	QT
01	0511053173	RIGHT LOW HUB WITH 15 DISC	70	01
02	0511053172	LEFT LOW HUB WITH 15 DISC	69	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010025	3/8 SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0511067044	LONG DISC BLADE FIXING AXIS		01
03	0541018684	FLAT WASHER		01
04	0503010756	0.2" X 2.4" SPRING PIN		01
05	0503010361	SPRING PIN		01
06	0503010003	1845 GREASE FITTING		01
07	0521014137	RIGHT ARM BLADE DISC		01
08	0521014138	LEFT DISC BLADE ARM		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0503011255	3/4" LOCK NUT		01
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
14	0503011411	1/2" X 5-1/2" BOLT		01
15	0503010019	1/2" SPRING WASHER		01
16	0503010060	1/2 UNC G.5 ZN HEX NUT		01
17	0502020393	SPRING UPPER SUPPORT		02
18	0502020394	SPRING SUPPORT		01
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
20	0503010014	3/4" HEX NUT		02
21	0521054680	20" DISC BLADE HUB	72	01




Item	Code	Description	See page	QT
01	0511056601	LONG SEED ROW FRONT DDD LEFT	80	01
02	0511058212	FERTILIZER ROW SUPPORT ASSY	84	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0502012538	SPRING VARON SUPPORT		01
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
07	0503011336	1/2" HEX SELF ADJUSTING NUT		02
08	0511060376	SEED SPRING GUIDE		01
09	0521010542	COUPLING SHAFT		01
10	0503010257	1/8" X 1" SPLIT PIN		01
11	0502040534	SPRING GUIDE BUSHING LOCK		01
12	0501018535	1/2 X 1 BOLT		01
13	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
14	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
15	0502040534	SPRING GUIDE BUSHING LOCK		01
16	0501013753	FLAT WASHER		01
17	0501018535	1/2 X 1 BOLT		01
18	0503010013	5/8 NUT		01
19	0511052024	FAST CLOSING SET	85	01
20	0531053925	SIGMA SOY INDIVIDUAL SEED SYSTEM	86	01
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
22	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
23	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
24	0503010019	1/2" SPRING WASHER		01
25	0503010060	1/2 UNC G.5 ZN HEX NUT		01
26	0503011099	GREASE FITTING		02
27	0503012412	5/8" UNC SELF LOCKING NUT		02




Item	Code	Description	See page	QT
01	0521062184	LONG SEED ROW ARM		01
02	0502011830	ARTICULATION SUPPORT		01
03	0521018079	SEED ROW DRAWBAR LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		02
05	0503011441	SPRING WASHER		02
06	0503010752	1/2" X 3.1/2" BOLT		02
07	0503011440	SPRING WASHER		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		02
09	0502011561	BEARING SEMI		01
10	0502010426	UPPER BEARING SEMI		02
11	0503010479	BOLT		04
12	0503011440	SPRING WASHER		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0501013354	FLAT WASHER		02
15	0502011400	18Z CONICAL GEAR		01
16	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
17	0502011505	18Z CONICAL GEAR		01
18	0521018078	1/2" X 66.5" HEX AXLE		01
19	0501013352	FLAT WASHER		04
20	0503033672	NOZZLE WITHOUT TITANIUM		01
21	0511051693	BASE FIXING SYSTEM	81	01
22	0503015920	3/8" UNC X 1.3/4" BOLT		04
23	0503011443	3/8" SPRING WASHER		04
24	0503010026	3/8" NUT		04
25	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
26	0503011440	SPRING WASHER		02
27	0503010060	1/2 UNC G.5 ZN HEX NUT		02
28	0511056586	15 X 15 SEED DDD LEFT	82	01




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502011411	10Z CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	83	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	70	01
03	0511053172	LEFT LOW HUB WITH 15 DISC	69	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" SPLIT PIN		02




Item	Code	Description	See page	QT
01	0531051514	SIGMA SOY SEED SYSTEM		01
02	0503063602	SEMI-ASSEMBLED SIGMA INDIVIDUAL SEED HOPPER		01
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
04	0501010694	FLAT WASHER		04
05	0503010240	BOLT		04
06	0503035691	ADHESIVE LABEL		02




Item	Code	Description	See page	QT
01	0511056600	RIGHT DDD SHORT SEED ROW FRONT	89	01
02	0511058212	FERTILIZER ROW SUPPORT ASSY	84	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0502012538	SPRING VARON SUPPORT		01
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
07	0503011336	1/2" HEX SELF ADJUSTING NUT		02
08	0511060376	SEED SPRING GUIDE		01
09	0521010542	COUPLING SHAFT		01
10	0503010257	1/8" X 1" SPLIT PIN		01
11	0502040534	SPRING GUIDE BUSHING LOCK		01
12	0501018535	1/2 X 1 BOLT		01
13	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
14	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
15	0502040534	SPRING GUIDE BUSHING LOCK		01
16	0501013753	FLAT WASHER		01
17	0501018535	1/2 X 1 BOLT		01
18	0503010013	5/8 NUT		01
19	0511052024	FAST CLOSING SET	85	01
20	0531053925	SIGMA SOY INDIVIDUAL SEED SYSTEM	86	01
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
22	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
23	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
24	0503010019	1/2" SPRING WASHER		01
25	0503010060	1/2 UNC G.5 ZN HEX NUT		01
26	0503011099	GREASE FITTING		02
27	0503012412	5/8" UNC SELF LOCKING NUT		02




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	01	
02	0501052538	DEPTH BAND WITH ARMS	02	
03	0503010358	5/16" X 5/8" BOLT	08	
04	0503013816	5/16" LOCKNUT	08	
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	01	
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	01	
07	0503033942	COMPACTOR WHEEL REGULATOR LID	01	




Item	Code	Description	See page	QT
01	0521062183	SHORT SEED ROW ARM		01
02	0502011830	ARTICULATION SUPPORT		01
03	0521018079	SEED ROW DRAWBAR LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		02
05	0503011441	SPRING WASHER		02
06	0503010752	1/2" X 3.1/2" BOLT		02
07	0503011440	SPRING WASHER		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		02
09	0502011561	BEARING SEMI		01
10	0502010426	UPPER BEARING SEMI		02
11	0503010479	BOLT		04
12	0503011440	SPRING WASHER		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0501013354	FLAT WASHER		02
15	0502011400	18Z CONICAL GEAR		01
16	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
17	0502011505	18Z CONICAL GEAR		01
18	0521018077	1/2" X 58.6" HEX AXLE		01
19	0501013352	FLAT WASHER		04
20	0503033672	NOZZLE WITHOUT TITANIUM		01
21	0511051693	BASE FIXING SYSTEM	81	01
22	0503015920	3/8" UNC X 1.3/4" BOLT		04
23	0503011443	3/8" SPRING WASHER		04
24	0503010026	3/8" NUT		04
25	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
26	0503011440	SPRING WASHER		02
27	0503010060	1/2 UNC G.5 ZN HEX NUT		02
28	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	90	01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	91	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	70	01
03	0511053172	LEFT LOW HUB WITH 15 DISC	69	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02



Item	Code	Description	See page	QT
01	0513010117	SOCIDISCO CORN DISC 28 HOLES 9,0 AMC9R-002130	01	01
02	0513010118	SOCIDISCO CORN DISC 28 HOLES 9,5 VLD9.5R-002115	01	01
03	0513010119	SOCIDISCO CORN DISC 28 HOLES 10 SAL10R-002619	01	01
04	0513010120	SOCIDISCO CORN DISC 28 HOLES 10,5 RSP10.5R-002133	01	01
05	0513010121	SOCIDISCO CORN DISC 28 HOLES 11 LRA11R-002134	01	01
06	0513010122	SOCIDISCO CORN DISC 28 HOLES 11,5 MAG11.5R-002620	01	01
07	0513010123	SOCIDISCO CORN DISC 28 HOLES 12 VDA12R-002621	01	01
08	0513010124	SOCIDISCO CORN DISC 28 HOLES 12,5 AMP12.5R-002131	01	01
09	0513010125	SOCIDISCO CORN DISC 28 HOLES 13 VMV13R-002132	01	01
10	0513010126	SOCIDISCO CORN DISC 28 HOLES 13,5 RXR13.5R-002136	01	01
11	0513010187	SOCIDISCO CORN DISC 28 HOLES 14,8 X 10 VM4-002581	01	01
12	0513010188	SOCIDISCO CORN DISC 28 HOLES 11 X 8 BR8.1-002589	01	01
13	0513010189	SOCIDISCO CORN DISC 28 HOLES 12,5 X 8,5 AZ8.2-002587	01	01
14	0513010164	SOCIDISCO FLAT RING FOR CORN AMFOSLISO-002127	01	01
15	0513010159	SOCIDISCO RING FOR CORN 0,8MM LRFOSSR08-002120	01	01
16	0513010160	SOCIDISCO RING FOR CORN 1,4MM VMFOSR1.4-002245	01	01
17	0513010163	SOCIDISCO RING FOR CORN 2,0MM VDFOSR2-002116	01	01
18	0503063413	4Z CORN SEED DISTRIBUTOR CAP - 001798	01	01



Item	Code	Description	See page	QT
01	0513010136	SOCIDISCO SOY DISC 62 HOLES 7,5 LRA62.75-002357		01
02	0513010137	SOCIDISCO SOY DISC 62 HOLES 8,0 RSP62.80-002358		01
03	0513010138	SOCIDISCO SOY DISC 62 HOLES 8,5 RXR62.85-002359		01
04	0513010139	SOCIDISCO SOY DISC 62 HOLES 9,0 AZM62.90-002360		01
05	0513010141	SOCIDISCO SOY DISC 90 HOLES 8,0 RSP90.80-002287		01
06	0513010142	SOCIDISCO SOY DISC 90 HOLES 8,5 RXR90.85-002317		01
07	0513010143	SOCIDISCO SOY DISC 90 HOLES 9,0 AZM90.90-002288		01
08	0513010158	SOCIDISCO FLAT RING FOR SOY AZMSOJALISO-002243		01
09	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461		01
10	0513010162	SOCIDISCO RING FOR SOY 1,5MM RSPSOJASR1,5-002244		01
11	0503063412	4Z SOY/BEAN SEED DISTRIBUTOR CAP - 001804		01



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

