

PARTS CATALOGUE



ROW CROP PLANTERS

Code:

0501091484

Product:

PST4 FLEX SUPREMA



Series:

S-0115

Revision:

02

Date Revision:

OUTUBRO/2015

PRODUCTS



Code	Description
0111290112	PST4 FLEX SUP 3245/5E700 D MH S-0115
0111290110	PST4 FLEX SUP 3245/7E450 D/HDA MH S-0115
0111290111	PST4 FLEX SUP 4045/8E500 MH S-0115
0111290115	PST4 FLEX SUP 4495/9E500 MH DC20 PM400 CSU S-0115
0111290116	PST4 FLEX SUP PP 4495/9E500 MH MTH S-0115
0111290113	PST4 FLEX SUP PP 4495/9E500 MH S-0115
0111290114	PST4 FLEX SUP PP 4495/9E500MH DC20 CSU PM400 S0115

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.



MARCHESAN

INDEX


0909091905	07 / 09 / 10 FRAME	1
0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	2
0501058194	FRAME WITH AXLE WHEEL - 3245	3
0501058195	FRAME WITH AXLE WHEEL - 4045	4
0511050836	WHEEL AXLE FRAME - 4495	5
0909091906	PEÇAS TURBINA	6
0521041586	TURBINE ASSY FOR CARDAN	7
0511041364	DRIVE SHAFT	8
0511048528	HUB SPINDLE ASSY	9
0511052769	WHEEL TRANSMISSION WITHOUT TIRE	10
0909091907	TRANSMISSÃO SUPREMA 3245 / 4045 / 4495	11
0511051434	TRANSMISSION DRIVING ASSY	12
0511047070	LH SIDE TRANSMISSION DRIVING	13
0511047069	SIDE TRANSMISSION DRIVING	14
0511047058	RIGHT GEAR BOX ASSY	15
0511047059	LH GEAR BOX ASSY	16
0511057235	SET SUPPORT RIGHT LEFT	17
0511057128	SET SUPPORT RIGHT LEFT	18
0511057564	SET SUPPORT RIGHT LEFT	19
0909091908	SEED FERTILIZER ROW ASSY G2	20
0909091909	SEED ROW ASSY G2	21
0909091910	SEED FERTILIZER ROW W/ HDA ASSY	22
0909091911	SEED ROW W/ HDA ASSY	23
0909091912	SEED FERTILIZER ROW W/ PP ASSY	24
0909091913	SEED ROW PP	25
0511057244	RIGH SHORT SEED ROW FRONT	26
0511057243	LEFT SHORT SEED ROW FRONT	27
0511057246	RIGHT LONG SEED ROW FRONT	28
0511057247	LEFT LONG SEED ROW FRONT	29
0511054884	TRANSMISSION BOX	30
0909090849	REAR RIGHT SEED ROW SUPREMA	31
0909090850	REAR LEFT SEED ROW SUPREMA	32
0511057607	REAR RIGHT ROW SEED	33
0511057608	REAR LEFT ROW SEED	34
0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	35
0511056586	15 X 15 SEED DDD LEFT	36
0511057154	DDD RITGH SUPREMA PRECISION PLANTING	37
0511057153	DDD LEFT SUPREMA PRECISION PLANTING	38
0521042710	PNEUMATIC SEED DISTRIBUTOR	39
0511053902	CARDAN WHIT SUPPORT	40
0511057606	PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX	41
0511057491	PRECISION PLANTING SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	42
0511057248	SEED DEPOSIT ASSY PNEUMATIC - G2	43
0511057509	SEED RESERVOIR PNEUMATIC ASSY	44
0521045198	PRESS WHEELS	45
0909091616	RUEDA COMPACT DER IZL V C/ ROL	46
0511054835	HDA	47
0909091899	FERTILIZER ROW WITH DDD & 18"/20" COULTER BLADE	48
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	49
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	50
0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	51
0511044573	18" COULTER BLADE ASSY FOR LONG ROW	52
0909091901	HYDRAULIC MEC ROW MARKER 07/09/10	53
0501050633	MARKER DISC ASSY LINE	54



MARCHESAN

INDEX


0511040203	1.5" X 2.5" X 19" X 9" HYDRAULIC CYLINDER		55
0501054649	SEQUENTIAL VALVE ASSY		56




Item	Code	Description	See page	07	09	10
01	0501058194	FRAME WITH AXLE WHEEL - 3245	3	01	00	00
02	0501058195	FRAME WITH AXLE WHEEL - 4045	4	00	01	00
03	0511050836	WHEEL AXLE FRAME - 4495	5	00	00	01
04	0511057124	CYLINDER ASSY		01	01	01
04A	0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	2	01	01	01
04B	0531019171	1.25" X 7" COUPLING SHAFT		01	01	01
04C	0521012536	COUPLING SHAFT		01	01	01
04D	0503010523	1/4" X 2" COTTERPIN		02	02	02
04E	0531012565	SLEEVE 16,3X 30 X 88		02	02	02
04F	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02	02	02
04G	0503010027	5/8" SPRING WASHER		02	02	02
04H	0503010013	5/8" NUT		02	02	02
05	0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495		01	01	01
05A	0511057070	HOSE KIT HYDRAULIC		01	01	01
05Aa	0501080422	HOSE 3/8 X 4000 TC-TM		01	01	01
05Ab	0501080446	3/8 X" 169" TC-TM HOSE ASSY		01	01	01
05B	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT		02	02	02
05Ba	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		02	02	02
05Bb	0503011882	MALE QUICK COUPLER CAP		02	02	02
05C	0503013100	NYLON CLAMP		02	02	02
06	0511057237	PLATFORM ASSY - 3245		01	00	00
06A	0511069661	PLATFORM SUPPORT PIVOT		04	04	04
06B	0503010849	3/8" X 1-1/2" BOLT		08	08	08
06C	0501010984	FLAT WASHER		16	16	16
06D	0503010025	3/8" SPRING WASHER		08	08	08
06E	0503010026	3/8" NUT		08	08	08
06F	0511069725	RIGHT PLATFORM		01	00	00
06G	0521062318	LEFT PLATFORM		01	00	00
06H	0521010549	COUPLING SHAFT		04	04	04
06I	0503010257	1/8" X 1" COTTERPIN		06	06	06
06J	0503011333	COVER FIXER		02	02	02

Item	Code	Description	See page	07	09	10
06K	0503010274	5/32"X 2" COTTERPIN		02	02	02
06L	0521061676	PLATFORM PROLONG		02	02	02
06M	0511069664	PLATFORM EXTENSION LOCK		02	02	02
06N	0502012740	PLATFORM RIGHT FIXER SUPPORT		01	01	01
06O	0502012739	PLATFORM LEFT FIXER SUPPORT		01	01	01
07	0511057129	PLATFORM ASSY - 4045		00	01	00
07A	0511069665	PLATFORM RIGHT PST4 9		00	01	00
07B	0521062323	PLATFORM LEFT PST4 9		00	01	00
08	0511057236	HANDRAIL ASSY - 3245		01	00	00
08A	0511069635	HANDRAIL		02	00	00
08B	0503014007	1/2" X 1-1/4" BOLT		04	04	04
08C	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04	04	04
08D	0503010019	1/2" SPRING WASHER		08	08	08
08E	0503010060	1/2" NUT		08	08	08
09	0511057130	HANDRAIL ASSY - 4045		00	01	00
09A	0511069656	HANDRAIL COP FLEX 600 9		00	02	00
10	0511056536	ASSEMBLY LADDER		02	02	02
11	0511054971	RESTING ASSEMBLY		02	02	02
12	0511057142	ASSY HEADER - 3245/3695/4045/4495		01	01	01
12A	0502012329	DRAWBAR FIXATION REAR SUPPORT		02	02	02
12B	0502012330	SUPPORT FIXER PIVOT		04	04	04
12C	0503011084	3/4" X 5" BOLT		08	08	08
12D	0501010322	FLAT WASHER		08	08	08
12E	0503010023	3/4" SPRING WASHER		08	08	08
12F	0503010014	3/4" NUT		08	08	08
12G	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02	02	02
12H	0503030119	LOCK PIN		04	04	04
12I	0561014393	COUPLING SHAFT		02	02	02
12J	0511064808	DRAWBAR		01	01	01
12K	0561019087	DRAWBAR TRANSPORT LOCK		01	01	01
12L	0521010578	COUPLING SHAFT		01	01	01
12M	0521010588	0.9" X 7.0" COUPLING SHAFT		01	01	01
12N	0503030085	LOCK PIN		02	02	02
12O	0503010002	1800 GREASE FITTING		01	01	01
13	0511057239	MANUAL CANISTER ASSY		01	01	01
13A	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01	01	01
13B	0503010267	NYLON CLAMP		01	01	01
13C	0503010363	5/16" X 1" BOLT		01	01	01
13D	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01	01	01
13E	0503010179	5/16" ZN SPRING WASHER		01	01	01
13F	0503010337	5/16" NUT		01	01	01
14	0501065677	STRUT		02	02	02
15	0501054258	DRAWBAR ESTABILIZER ASSY		01	01	01
16	0511054601	FULL ARTICULATED TRACTOR HITCH		01	01	01
17	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01	01	01
18	0511053179	TRACTOR HITCH AXLE		01	01	01
18A	0521064036	TRACTOR HITCH AXLE		01	01	01
18B	0503030012	HAIR PIN		01	01	01
19	0521013022	TRANSPORT LOCK		01	01	01
20	0501068994	0.3" X 3.1" LOCK PIN		01	01	01
21	0503030168	HAIR PIN		01	01	01
22	0521066247	SUPPORT HOSE CARDAN		01	01	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02	02	02
24	0503010025	3/8" SPRING WASHER		02	02	02
25	0503010026	3/8" NUT		02	02	02
26	0503032624	SILO FERTILIZER GUTTER		04	05	05
27	0502012702	BODY SUPPORT CLAMP		01	01	01
28	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		01	01	01
29	0503010180	7/16" SPRING WASHER		01	01	01


Item	Code	Description	See page	07	09	10
30	0501047895	ROD STOP		01	01	01
31	0501047885	ROD STOP		01	01	01
32	0501047886	ROD STOP		01	01	01
33	0501047887	ROD STOP		01	01	01
34	0503010780	N-2050 AMENDMENT		02	02	02
35	0503010951	REDUCTION		04	04	04
36	0503010003	1845 GREASE FITTING		04	04	04
37	0511057565	PLATFORM ASSY - 4495		00	00	01
37A	0521062237	RIGHT PLATAFORM		00	00	01
37B	0521062238	LEFT PLATAFORM		00	00	01
38	0511057566	HANDRAIL ASSY - 4495		00	00	01
38A	0521062239	HANDRAIL		00	00	02
39	0909094592	HEX AXLE ASSEMBLY		01	01	01




Item	Code	Description	See page	QT
01	0511064055	5" X 15" CYLINDER CASE		01
02	0511064056	BUSHING 2" X 14" TURNBUCLE		01
03	0502010382	5" END CAP		01
04	0502012227	50.80 X 127 RING SUPPORT		01
05	0503010039	D-2000 SCRAPER RING		01
06	0503010991	1870-2000-375-B GASKET		01
07	0503010952	W2-2250-500 RING		01
08	0503010351	2-425 N 3006-9B O'RING		01
09	0503011062	8-425 BACK-UP RING		01
10	0502010963	2.0" X 5.0" PISTON		01
11	0503010552	PACKING 3750-4250-625-B		02
12	0503010345	2-218 N 3006-9B O'RING		01
13	0503010974	W2-5000-500 RING		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503010003	1845 GREASE FITTING		01
16	0503030385	CYLINDER PLUG N-002		02




Item	Code	Description	See page	QT
01	0511069615	PST4 7 S-1207 FRAME		01
02	0511069724	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08



Item	Code	Description	See page	QT
01	0511069529	FRAME PST4 9 S-1207		01
02	0511069682	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0521062243	FRAME		01
02	0521062242	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08



Item	Code	Description	See page	07	08	10
01	0511057238	KIT DISTRIBUTOR		01	00	00
01A	0503031608	AIR DISTRIBUTOR		02	00	00
01B	0521014441	HOSE HOLDER RIGHT SUPPORT		02	02	02
01C	0521014442	LOWER AIR DISTRIBUTOR SUPPORT		04	04	04
01D	0521018535	HOSE HOLDER LEFT SUPPORT		02	02	02
01E	0503010371	5/16" X 1" BOLT		08	08	08
01F	0503010179	5/16" ZN SPRING WASHER		08	08	08
01G	0503010337	5/16" NUT		08	08	08
01H	0503014007	1/2" X 1-1/4" BOLT		04	04	04
01I	0503010019	1/2" SPRING WASHER		04	04	04
01J	0503010060	1/2" NUT		04	04	04
02	0511057252	KIT DISTRIBUTOR		00	01	01
02A	0503031609	AIR DISTRIBUTOR		00	02	02
03	0511041364	DRIVE SHAFT	8	01	01	01
04	0503010479	1/2" X 3" BOLT		01	01	01
05	0503010019	1/2" SPRING WASHER		01	01	01
06	0503010060	1/2" NUT		01	01	01
07	0521041586	TURBINE ASSY FOR CARDAN	7	01	01	01
08	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02	02	02
09	0503010027	5/8" SPRING WASHER		02	02	02
10	0503010013	5/8" NUT		02	02	02
11	0531016193	4" X 74" AIR CONDUCTOR		02	02	00
12	0531016195	4" X 94" AIR CONDUCTOR		00	00	02
13	0503011372	102 TO 121 CLAMP		04	04	04
14	0521019552	5" X 188" AIR CONDUCTOR		01	01	01
15	0503012724	121 TO 140 CLAMP		01	01	01
16	0531015603	HOSE FIXATION SUPPORT		01	01	01
17	0501056495	TURBINE OUTPUT SOCKET		01	01	01
18	0503013096	5/16" X 4" BOLT		02	02	02
19	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04	04	04
20	0503010179	5/16" ZN SPRING WASHER		02	02	02




Item	Code	Description	See page	07	08	10
21	0503010499	5/16" UNC BUTTERFLY NUT		02	02	02
22	0503031436	AIR DITRIBUTOR PUMP		04	05	05




Item	Code	Description	See page	QT
01	0511061094	TURBINE SUPPORT	01	
02	0501053716	BEARING ASSY OF THE LARGER FAN	01	
02A	0502012016	CHAIN TENSIONER SUPPOT	01	
02B	0503012778	MIDDLE LARGER AXLE	01	
02C	0531010881	INTERMEDIARY UPPER SLEEVE	01	
02D	0503012689	6306 DDU BEARING	02	
02E	0503010325	VCA-118 VALVE	01	
03	0503010920	1/2" X 1.1/2" BOLT	02	
04	0501056495	TURBINE OUTPUT SOCKET	01	
04A	0503031812	TURBINE OUTPUT SOCKET	01	
04B	0541017539	BUTTERFLY VALVE	01	
04C	0511066760	VALVE FIXATION SUPPORT	01	
04D	0503013813	1/4" UNC X 7/8" BOLT	02	
04E	0511017303	FLAT WASHER	02	
04F	0503010143	1/4" SPRING WASHER	02	
04G	0503010144	1/4" NUT	02	
04H	0501013519	FLAT WASHER	01	
04I	0503010019	1/2" SPRING WASHER	01	
04J	0503010060	1/2" NUT	01	
05	0503010395	1/2" X 1-1/4" BOLT	02	
06	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
07	0501053886	PULLEY ASSY WITH FREE ROT	01	
08	0501011194	1/2" X 1-3/4" BOLT	04	
09	0521018517	FLAT WASHER	04	
10	0503010019	1/2" SPRING WASHER	04	
11	0503010020	1/2"NUT	04	
12	0503013030	5/8" X 3.1/4" BOLT	01	
13	0501012140	FLAT WASHER	01	
14	0503010013	5/8" NUT	01	
15	0503012780	LARGER TURBINE BELT	01	
16	0571012629	FRONT COVER	01	

Item	Code	Description	See page	QT
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
18	0503010025	3/8" SPRING WASHER		04
19	0503010026	3/8" NUT		04
20	0521044612	FAN		01
21	0503011775	6 X 6 X 35 KEYWAY		01
22	0503011774	PULLEY		01
23	0503010179	5/16" ZN SPRING WASHER		01
24	0503011257	M 8 X 1,25 X 30 BOLT		01
25	0503013096	5/16" X 4" BOLT		02
26	0501054272	RIBBON FOR COVER CLOSING ASSY		01
26A	0531017193	RIBBON FOR COVER CLOSING		01
26B	0521018401	SEGMENT COVER		15
27	0503031776	TURBINE RIBBON SEAL		02
28	0571012630	REAR COVER		01
29	0503013031	1/4" X 3.1/4" BOLT		13
30	0503012880	1/4" UNC SELF ADJUSTING NUT		15
31	0511014024	10 X 13 X 15,5 SLEEVE		02
32	0503012721	1/4" X 4" BOLT		02
33	0511017303	FLAT WASHER		04
34	0503031649	CONECTOR CENTER		01
35	0503012722	0.16" X 0.4" BLIND RIVET		08
36	0531012760	TURBINE REAR COVER		01
37	0503013758	1/4" X 1-1/2" BOLT		04
38	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
39	0503010499	5/16" UNC BUTTERFLY NUT		02
40	0561010635	SWITCH FIXER		01
41	0503013584	VACUUM GAUGE		01
42	0503015062	TUBE		0.500




Item	Code	Description	See page	QT
01	0501055638	HOMO JOINT WITH FEMALE BUSHING		01
01A	0503012607	TRACTOR HOMOCINETIC TERMINAL		01
01Aa	0521010638	0.5" X 3.3" QUIC HITCH COUPL SHAFT		01
01Ab	0503030518	0.5"X1.0"X 0.1" COMPRESSION SPRING		01
01Ac	0503010140	1/8" X 3/4" COTTERPIN		01
01B	0503012605	CROSSPIECE		02
01C	0503012606	CENTER BODY		01
01D	0503012604	HOMO TERMINAL W/ FEMALE BUSHING		01
01E	0503012618	2.1" X 2.0" X 31" TRIAN FEMALE TUB		01
01F	0503010843	0.4" X 3.3" SPRING PIN		01
01G	0503011878	0.2" X 3.3" SPRING PIN		01
02	0501055639	UNIVERSAL JOINT		01
02A	0503013132	CC292 TERMINAL		01
02B	0503012096	CROSSPIECE		01
02C	0503013187	TERMINAL		01
02D	0503012619	1.8" X 1.7" X 31" TRIAN MALE TUB		01
02E	0503011069	0.4" X 2.8" SPRING PIN		01
02F	0503011805	0.2" X 2.8" SPRING PIN		01
03	0503013189	PROTECTION ASSY		01
04	0503012023	CHAIN FOR PROTECTION		01




Item	Code	Description	See page	QT
01	0511048528	HUB SPINDLE ASSY	9	01
01A	0501059907	HUB SUPPORT		01
01Aa	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0521061566	CARRYING WHEEL ARM TRACTION		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511050681	TRACTION SPRING		01
06A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
06B	0561016062	SPRING HITCH		02
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
08	0503010027	5/8" SPRING WASHER		03
09	0501012140	FLAT WASHER		01
10	0503013030	5/8" X 3.1/4" BOLT		01
11	0551017715	FLAT WASHER		02
12	0511052772	650X16 WHEEL AND TIRE ASSY		01
12A	0503062160	650 X 16-10L WHEEL AND TIRE ASSY		01
12Aa	0503011101	CANVAS TIRE		01
12Ab	0503016517	WHEEL EI		01
12Ac	0503010694	INNER TIRE		01
12B	0511052769	WHEEL TRANSMISSION WITHOUT TIRE	10	01
13	0521012190	AXLE LOCK		02
14	0503011167	M16 X 2 X 30 BOLT		02
15	0501058241	TENSIONER CHAIN SUPPORT		01
15A	0541011713	TENSIONER CHAIN LOWER AXLE		01
15B	0541016454	PULLEY		01
15C	0503010302	501019 SEAL RING		01
15D	0503010019	1/2" SPRING WASHER		04
15E	0503010060	1/2" NUT		04
16	0501058240	WHELL FASTENER WITH STRETCHER		01
16A	0502012416	CARRYING-WHEELS SUPPORT FIXER		01

Item	Code	Description	See page	QT
16B	0511069417	REAR TENSIONER		01
16C	0501058243	STRETCHER INTERMEDIATE RODE CURRENT		01
16Ca	0501058239	CHAIN TENSIONER BEARING		03
16Cb	0502012018	CHAIN TIGHTENER BEARING		03
16Cc	0503012882	BEARING		03
16Cd	0503011945	503050 CLAMPING RING (FOR AXLE)		03
16Ce	0551018245	CHAIN TENSIONER AXLE		01
16Cf	0551018241	SLEEVE 16,30 X 30 X 8		02
16Cg	0551018239	SLEEVE 19 X 13,50 X 45		01
16D	0501058244	STRETCHER FIXED CURRENT		01
16Da	0551018252	CHAIN TIGHTENER AXLE		01
16E	0501058242	MOVIL CHAIN TENSIONER		01
16Ea	0551018244	CHAIN UPPER AXLE		01
16Eb	0551018240	SLEEVE		01
16F	0501013491	5/8" TENSIONER SPRING		01
16G	0503010013	5/8" NUT		02
16H	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
17	0502011308	WHELL FASTENER		01
18	0503011119	7/8" X 6" BOLT		04
19	0501014251	FLAT WASHER		04
20	0503011254	7/8" HEX SELF ADJUSTING NUT		04
21	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSM AXLE CARRYING-WHEEL		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511069682	CARRYING-WHEELS PIVOT SHAFT		00 01 00
02	0521013199	LOWER BEARING SEMI		04 04 04
03	0503010899	5/8" X 2-1/4" BOLT		08 08 08
04	0501012140	FLAT WASHER		16 16 16
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08 08 08
06	0503010013	5/8" NUT		08 08 08
07	0503011445	SPRING WASHER		16 16 16
08	0501110639	BEARING		06 08 08
09	0503011099	GREASE FITTING		06 08 08
10	0503010300	5/32" X 1" COTTERPIN		06 08 08
11	0551019114	MOTOR BEARING AXLE SUPPORT		04 04 04
12	0521014021	1/2" X 4.5" X 5.4" FASTENER		04 04 04
13	0511017302	FLAT WASHER		08 08 08
14	0503010019	1/2" SPRING WASHER		18 18 18
15	0503010060	1/2" NUT		16 16 16
16	0531016940	5/8 X 1650 RIGHT HEX AXLE		01 00 00
17	0501018466	FLAT WASHER		04 04 04
18	0511015961	LOCK BUSHING		04 04 04
19	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04 04 04
20	0501052560	AXLE MOTOR SLOW-MOVING ASSY		02 02 02
20A	0503031825	AXLE MOTOR SLOW-MOVING		04 04 04
20B	0503010240	5/16" X 3/4" BOLT		04 04 04
20C	0503010179	5/16" ZN SPRING WASHER		04 04 04
20D	0503010337	5/16" NUT		04 04 04
21	0511051434	TRANSMISSION DRIVING ASSY	12	04 04 04
22	0511047069	SIDE TRANSMISSION DRIVING	14	01 01 01
23	0511047070	LH SIDE TRANSMISSION DRIVING	13	01 01 01
24	0511047058	RIGHT GEAR BOX ASSY	15	01 01 01
25	0511047059	LH GEAR BOX ASSY	16	01 01 01
26	0501010243	1/2" X 1-1/2" BOLT		06 06 06
27	0503012682	1/2" BSW NUT		06 06 06

Item	Code	Description	See page	QT
28	0503010920	1/2" X 1.1/2" BOLT	04	04 04
29	0511017302	FLAT WASHER	08	08 08
30	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"	02	02 02
31	0531016941	LEFT 5/8" X 59" AXLE HEX	01	00 00
32	0503030275	AGRICULTURAL BEARING	02	02 02
33	0501010637	FLAT WASHER	04	04 04
34	0501010984	FLAT WASHER	02	02 02
35	0503010025	3/8" SPRING WASHER	02	02 02
36	0503010256	3/8" X 3/4" BOLT	02	02 02
37	0501055112	MICRO GRANULATED CHAIN TENSIONER	02	02 02
37A	0531019479	AXLE CHAIN GEAR	02	02 02
37B	0503031805	11Z 1/2" GEAR	02	02 02
37C	0511017302	FLAT WASHER	04	04 04
37D	0503010019	1/2" SPRING WASHER	02	02 02
37E	0503010060	1/2" NUT	02	02 02
38	0501058265	STRETCHER LOWER CURRENT 21Z SEED	02	02 02
38A	0511062169	21Z P 1/2" GEAR	02	02 02
38B	0503011410	ROLLER BEARING	02	02 02
38C	0503011105	SEAL RING	02	02 02
38D	0531017086	50 AXLETIGHTENER	02	02 02
38E	0503010406	501025 CLAMPING RING (FOR AXLE)	02	02 02
38F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN	02	02 02
38G	0501012140	FLAT WASHER	02	02 02
38H	0503010027	5/8" SPRING WASHER	02	02 02
38I	0503010013	5/8" NUT	02	02 02
39	0501058254	UPPER SEED CHAIN TENSIONER	02	02 02
39A	0503031805	11Z 1/2" GEAR	02	02 02
39B	0503010302	501019 SEAL RING	02	02 02
39C	0521018933	113 FERT CHAIN TENSIONER AXLE	02	02 02
39D	0511017302	FLAT WASHER	02	02 02
39E	0503010019	1/2" SPRING WASHER	02	02 02
39F	0503010060	1/2" NUT	02	02 02
40	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	02	02 02
40A	0511062169	21Z P 1/2" GEAR	02	02 02
40B	0503011410	ROLLER BEARING	02	02 02
40C	0503011105	SEAL RING	02	02 02
40D	0531017086	50 AXLETIGHTENER	02	02 02
40E	0503010406	501025 CLAMPING RING (FOR AXLE)	02	02 02
40F	0501011234	5/8" X 3" BOLT	02	02 02
40G	0503012412	5/8 UNC SELF LOCKING NUT	02	02 02
41	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	02	02 02
41A	0511069680	20Z X 28Z DOBLE GEAR	02	02 02
41B	0503011410	ROLLER BEARING	04	04 04
41C	0551019175	DOUBLE GEAR AXLE	02	02 02
41D	0503010406	501025 CLAMPING RING (FOR AXLE)	02	02 02
41E	0501010163	5/8" X 4-1/2" BOLT	02	02 02
41F	0503012412	5/8 UNC SELF LOCKING NUT	02	02 02
42	0503012204	40-1 CHAIN X 82 LINK + RED	02	02 02
43	0503012707	40-1 CHAIN X 96 LINK + REDUCTION	02	02 02
44	0503016111	40-1 CHAIN X 109 LINK + MENDING	02	02 02
45	0503014907	40-1 X 151 CHAIN LINK + MENDING	02	02 02
46	0561016882	1535 MOTOR SHAFT	02	00 00
47	0511069724	CARRYING-WHEELS PIVOT SHAFT	01	00 00
48	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	02	02 02
48A	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8	02	02 02
48Aa	0502011987	DOUBLE HOUSING BEARING	02	02 02
48Ab	0503011410	ROLLER BEARING	04	04 04
48Ac	0503011105	SEAL RING	02	02 02
48B	0511063106	20Z AXLE BEARING DOBLE	02	02 02


Item	Code	Description	See page	QT
48C	0503010406	501025 CLAMPING RING (FOR AXLE)	04	04 04
48D	0503010365	NUT	04	04 04
48E	0501010694	8.5 X 18 X 1.5 FLAT WASHER	08	08 08
48F	0503010179	5/16" ZN SPRING WASHER	04	04 04
48G	0503010337	5/16" NUT	04	04 04
49	0561014215	BEARING COVER LOWER ROW FRAME	02	02 02
50	0502040534	SPRING GUIDE BUSHING LOCK	04	04 04
51	0501018535	1/2 X 1 BOLT	04	04 04
52	0503011750	AMENDMENT WITH LOCK	06	06 06
53	0503011751	REDUCTION	06	06 06
54	0561016881	MOTOR SHAFT	00	02 00
55	0531016942	RIGHT HEX AXLE 5/8 X 2050	00	01 00
56	0531016943	LEFT HEX AXLE 5/8 X 1900	00	01 00
57	0521062242	CARRYING-WHEELS PIVOT SHAFT	00	00 01
58	0561018351	2155 MOTOR SHAFT	00	00 02
59	0561019199	5/8" X 2275 AXLE HEX	00	00 01
60	0561019200	5/8" X 2125 AXLE HEX	00	00 01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02



Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	01	
02	0503031805	11Z 1/2" GEAR	04	
03	0503010302	501019 SEAL RING	04	
04	0501048790	AXLE WITH LINK ASSY	02	
05	0503010002	1800 GREASE FITTING	02	
06	0551018209	DRIVING AXLE	01	
07	0521018259	DRIVEN AXLE	01	
08	0551018210	DRIVEN AXLE	01	
09	0551018211	INTERM SHAFT	01	
10	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	01	
11	0503030303	SUPPORT WASHER	05	
12	0501056443	BEARING ASSY GEAR BOX	02	
13	0501056271	BEARING CLOSED	05	
14	0503011953	5/16" X 1" BOLT	10	
15	0501010694	8.5 X 18 X 1.5 FLAT WASHER	10	
16	0503010179	5/16" ZN SPRING WASHER	10	
17	0503010337	5/16" NUT	10	
18	0502040868	GEAR CONE REPLACEMENT	04	
19	0503012389	1/2 BALL	04	
20	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING	04	
21	0503010060	1/2" NUT	04	
22	0503010834	1/2 X 1 BOLT	04	
23	0511061822	25Z P0.5" GEAR SQUARE HOL	01	
24	0511061830	17Z P 0.5" GEAR SQUARE HOL	02	
25	0511067501	26Z GEAR	01	
26	0503010292	0.2" X 1.6" SPRING PIN	07	
27	0503012204	40-1 CHAIN X 82 LINK + RED	02	
28	0503012713	40-1 CHAIN X 45 LINK + MEN	01	
29	0501054655	CHAIN TENSIONER ASSY	02	
30	0501010984	FLAT WASHER	01	
31	0503010025	3/8" SPRING WASHER	01	



PST4 FLEX SUPREMA
RIGHT GEAR BOX ASSY

Page 15
0511047058

Item	Code	Description	See page	QT
32	0503010256	3/8" X 3/4" BOLT		01
33	0503030275	AGRICULTURAL BEARING		01
34	0521018630	1.4" X SQUARE 0.8" WASHER		03




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	01	
02	0503031805	11Z 1/2" GEAR	04	
03	0503010302	501019 SEAL RING	04	
04	0501048790	AXLE WITH LINK ASSY	02	
05	0503010002	1800 GREASE FITTING	02	
06	0551018209	DRIVING AXLE	01	
07	0521018259	DRIVEN AXLE	01	
08	0551018210	DRIVEN AXLE	01	
09	0551018211	INTERM SHAFT	01	
10	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	01	
11	0503030303	SUPPORT WASHER	05	
12	0501056443	BEARING ASSY GEAR BOX	02	
13	0501056271	BEARING CLOSED	05	
14	0503011953	5/16" X 1" BOLT	10	
15	0501010694	8.5 X 18 X 1.5 FLAT WASHER	10	
16	0503010179	5/16" ZN SPRING WASHER	10	
17	0503010337	5/16" NUT	10	
18	0511060396	DRIVE/DRIVEN AXLE CONE	04	
19	0503012389	1/2 BALL	04	
20	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING	04	
21	0503010060	1/2" NUT	04	
22	0503010834	1/2 X 1 BOLT	04	
23	0511061822	25Z P0.5" GEAR SQUARE HOL	01	
24	0511061830	17Z P 0.5" GEAR SQUARE HOL	02	
25	0511067501	26Z GEAR	01	
26	0503010292	0.2" X 1.6" SPRING PIN	07	
27	0503012204	40-1 CHAIN X 82 LINK + RED	02	
28	0503012713	40-1 CHAIN X 45 LINK + MEN	01	
29	0501054655	CHAIN TENSIONER ASSY	02	
30	0501010984	FLAT WASHER	01	
31	0503010025	3/8" SPRING WASHER	01	



PST4 FLEX SUPREMA
LH GEAR BOX ASSY


Page 16
0511047059

Item	Code	Description	See page	QT
32	0503010256	3/8" X 3/4" BOLT		01
33	0503030275	AGRICULTURAL BEARING		01
34	0521018630	1.4" X SQUARE 0.8" WASHER		03




Item	Code	Description	See page	DIR	ESQ
01	0511052419	RH BEAM SUPPORT	01	00	
01A	0521063542	FERTILIZER BEAN RIGHT SUPPORT	01	00	
02	0511052420	LH BEAM SUPPORT & METERING	00	01	
02A	0521063543	FERTILIZER BEAN LEFT SUPPORT	00	01	
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	00	04	
03A	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET	00	04	
03B	0501019851	DISTRIBUTOR FERTILIZER AXLE	04	04	
03C	0521010309	SLEEVE INTER	04	04	
03D	0503030275	AGRICULTURAL BEARING	16	16	
03E	0503031164	RIGHT HELICAL CONDUCTOR	04	04	
03F	0501010637	FLAT WASHER	04	04	
03G	0503030303	SUPPORT WASHER	04	04	
03H	0501013774	GREASE SEAL	04	04	
03I	0502011412	18Z CONICAL GEAR	04	04	
03J	0503010523	1/4" X 2" COTTERPIN	04	04	
03K	0503011962	GREASE FITTING	04	04	
03L	0503010003	1845 GREASE FITTING	04	04	
03M	0503012826	CREASE FITTING	04	04	
04	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	04	00	
04A	0501110676	SIDE FERTILIZER DISTRIBUTOR	04	00	
04B	0503031165	LEFT HELICAL CONDUCTOR	04	04	
05	0501010942	3/8" X 1-1/4" BOLT	16	16	
06	0503011443	3/8" SPRING WASHER	16	16	
07	0503010026	3/8" NUT	16	16	
08	0511061759	22Z P12,70 FQ 3/4" GEAR	01	01	
09	0521014167	CONE LOCK	01	01	
10	0503030275	AGRICULTURAL BEARING	04	04	
11	0502010685	18Z CONICAL GEAR	04	04	
12	0561018362	SQUARE SHAFT	01	01	
13	0521010691	AXLE FASTENER	02	02	
14	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN	02	02	

Item	Code	Description	See page	DIR	ESQ
15	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02
16	0503011441	SPRING WASHER		02	02
17	0503010144	1/4" NUT		02	02
18	0501110392	SILO SUPPORT BEARING		01	01
19	0521012485	GEAR BOX BEARING AGRICUTURAL		01	01
20	0503011953	5/16" X 1" BOLT		02	02
21	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02
22	0521011039	FLAT WASHER		02	02
23	0503011444	SPRING WASHER		02	02
24	0503010337	5/16" NUT		02	02
25	0551018055	22,65 X 60 SLEEVE		02	02
26	0503010003	1845 GREASE FITTING		01	01
27	0503010849	3/8" X 1-1/2" BOLT		08	08
28	0501010984	FLAT WASHER		17	17
29	0503010025	3/8" SPRING WASHER		08	08
30	0503010026	3/8" NUT		08	08
31	0571010590	FERTILIZER SIDE COVER		04	04
32	0503010362	1/8" X 1.1/4" COTTERPIN		04	04
33	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		01	01
34	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02	02
35	0551019156	GEAR BOX LEVER LOCK		01	01
36	0503011953	5/16" X 1" BOLT		02	02
37	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02
38	0503010179	5/16" ZN SPRING WASHER		02	02
39	0503010337	5/16" NUT		02	02
40	0503010847	1/2" X 3.1/4" BOLT		01	01
41	0551019168	SLEEVE		01	01
42	0551019160	LEVER		01	01
43	0511017302	FLAT WASHER		03	03
44	0503010019	1/2" SPRING WASHER		02	02
45	0503010060	1/2" NUT		01	01
46	0551019167	SLEEVE UNION		01	01
47	0511069676	INNER LEVER		01	01
48	0501013518	FLAT WASHER		02	02
49	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01	01
50	0503010140	1/8" X 3/4" COTTERPIN		03	03
51	0511069678	LH LOWER LEVER		02	02
52	0503011336	1/2" HEX SELF ADJUSTING NUT		02	02
53	0551019115	LOCKING PLATFORM FIXATION		01	01
54	0501010096	3/8" X 2" BOLT		01	01
55	0503013357	3/8" SELF-ADJUSTING NUT		01	01
56	0551019159	LEVER FIXER BODY		01	01
57	0561016468	FASTENER		01	01




Item	Code	Description	See page	DIR	ESQ
01	0511052253	RH BEAM SUPPORT & METERING	01	00	
01A	0521063436	FERTILIZER BEAN RIGHT SUPPORT	01	00	
02	0511052254	LH BEAM SUPPORT & METERING	00	01	
02A	0521063437	FERTILIZER BEAN LEFT SUPPORT	00	01	
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	00	05	
03A	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET	00	05	
03B	0501019851	DISTRIBUTOR FERTILIZER AXLE	05	05	
03C	0521010309	SLEEVE INTER	05	05	
03D	0503030275	AGRICULTURAL BEARING	10	10	
03E	0503031164	RIGHT HELICAL CONDUCTOR	05	05	
03F	0501010637	FLAT WASHER	05	05	
03G	0503030303	SUPPORT WASHER	05	05	
03H	0501013774	GREASE SEAL	05	05	
03I	0502011412	18Z CONICAL GEAR	05	05	
03J	0503010523	1/4" X 2" COTTERPIN	05	05	
03K	0503011962	GREASE FITTING	05	05	
03L	0503010003	1845 GREASE FITTING	05	05	
03M	0503012826	CREASE FITTING	05	05	
04	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	05	00	
04A	0501110676	SIDE FERTILIZER DISTRIBUTOR	05	00	
04B	0503031165	LEFT HELICAL CONDUCTOR	05	05	
05	0501010942	3/8" X 1-1/4" BOLT	20	20	
06	0503011443	3/8" SPRING WASHER	20	20	
07	0503010026	3/8" NUT	20	20	
08	0511061759	22Z P12,70 FQ 3/4" GEAR	01	01	
09	0521014167	CONE LOCK	01	01	
10	0503030275	AGRICULTURAL BEARING	05	05	
11	0502010685	18Z CONICAL GEAR	05	05	
12	0551018213	3/4" X 1830 SQUARE SHAFT	01	01	
13	0521010691	AXLE FASTENER	02	02	
14	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN	02	02	

Item	Code	Description	See page	DIR	ESQ
15	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02
16	0503011441	SPRING WASHER		02	02
17	0503010144	1/4" NUT		02	02
18	0501110392	SILO SUPPORT BEARING		01	01
19	0521012485	GEAR BOX BEARING AGRICUTURAL		01	01
20	0503011953	5/16" X 1" BOLT		02	02
21	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02
22	0521011039	FLAT WASHER		02	02
23	0503011444	SPRING WASHER		02	02
24	0503010337	5/16" NUT		02	02
25	0551018055	22,65 X 60 SLEEVE		01	01
26	0503010003	1845 GREASE FITTING		01	01
27	0503010849	3/8" X 1-1/2" BOLT		08	08
28	0501010984	FLAT WASHER		17	17
29	0503010025	3/8" SPRING WASHER		08	08
30	0503010026	3/8" NUT		08	08
31	0571010590	FERTILIZER SIDE COVER		05	05
32	0503010362	1/8" X 1.1/4" COTTERPIN		05	05
33	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		01	01
34	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02	02
35	0551019156	GEAR BOX LEVER LOCK		01	01
36	0503011953	5/16" X 1" BOLT		02	02
37	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02
38	0503010179	5/16" ZN SPRING WASHER		02	02
39	0503010337	5/16" NUT		02	02
40	0503010847	1/2" X 3.1/4" BOLT		01	01
41	0551019168	SLEEVE		01	01
42	0551019160	LEVER		01	01
43	0511017302	FLAT WASHER		03	03
44	0503010019	1/2" SPRING WASHER		02	02
45	0503010060	1/2" NUT		02	02
46	0551019167	SLEEVE UNION		01	01
47	0511069676	INNER LEVER		01	01
48	0501013518	FLAT WASHER		02	02
49	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01	01
50	0503010140	1/8" X 3/4" COTTERPIN		03	03
51	0511069678	LH LOWER LEVER		02	02
52	0503011336	1/2" HEX SELF ADJUSTING NUT		02	02
53	0551019115	LOCKING PLATFORM FIXATION		01	01
54	0501010096	3/8" X 2" BOLT		01	01
55	0503013357	3/8" SELF-ADJUSTING NUT		01	01
56	0551019159	LEVER FIXER BODY		01	01
57	0561016468	FASTENER		01	01




Item	Code	Description	See page	DIR	ESQ
01	0511053240	RIGHT SILO SUPPORT WITH DISTRIBUTOR 10	01	00	
02	0511053241	LEFT SILO SUPPORT WITH DISTRIBUTOR 10	00	01	
03	0503010849	3/8" X 1-1/2" BOLT	08	08	
04	0501010984	FLAT WASHER	17	17	
05	0503010025	3/8" SPRING WASHER	08	08	
06	0503010026	3/8" NUT	08	08	
07	0571010590	FERTILIZER SIDE COVER	05	05	
08	0503010362	1/8" X 1.1/4" COTTERPIN	05	05	
09	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS	01	01	
10	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE	02	02	
11	0551019156	GEAR BOX LEVER LOCK	01	01	
12	0503011953	5/16" X 1" BOLT	02	02	
13	0501010694	8.5 X 18 X 1.5 FLAT WASHER	02	02	
14	0503010179	5/16" ZN SPRING WASHER	02	02	
15	0503010337	5/16" NUT	02	02	
16	0503010847	1/2" X 3.1/4" BOLT	01	01	
17	0551019168	SLEEVE	01	01	
18	0551019160	LEVER	01	01	
19	0511017302	FLAT WASHER	03	03	
20	0503010019	1/2" SPRING WASHER	02	02	
21	0503010060	1/2" NUT	02	02	
22	0551019167	SLEEVE UNION	01	01	
23	0511069676	INNER LEVER	01	01	
24	0501013518	FLAT WASHER	02	02	
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	01	01	
26	0503010140	1/8" X 3/4" COTTERPIN	03	03	
27	0511069678	LH LOWER LEVER	02	02	
28	0503011336	1/2" HEX SELF ADJUSTING NUT	02	02	
29	0551019115	LOCKING PLATFORM FIXATION	01	01	
30	0501010096	3/8" X 2" BOLT	01	01	
31	0503013357	3/8" SELF-ADJUSTING NUT	01	01	


Item	Code	Description	See page	DIR	ESQ
32	0551019159	LEVER FIXER BODY		01	01
33	0561016468	FASTENER		01	01




Item	Code	Description	See page	CT	LG
01	0909091909	SEED ROW ASSY G2	21	01	01
02	0909091822	SHORT LINE FERTILIZER LEFT		01	00
03	0909091821	LONG FERTILIZER LINE RIGHT		00	01
04	0511058618	DISC CUT 18 LONG LINE		00	01
05	0511058617	DISC CUT 18 SHORT LINE		01	00
06	0531013600	PRESS ADJUSTMENT LEVER		01	01
07	0909092391	SEED END FERTILIZER ROW		01	01



Item	Code	Description	See page	CT	LG
01	0511057243	LEFT SHORT SEED ROW FRONT	27	01	00
02	0511057246	RIGHT LONG SEED ROW FRONT	28	00	01
03	0511056623	RIGHT REAR LINE SEED		01	01
04	0511056624	LEFT REAR LINE SEED		01	01
05	0511057248	SEED DEPOSIT ASSY PNEUMATIC - G2	43	01	01
06	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02	02
07	0503010019	1/2" SPRING WASHER		04	04
08	0503010060	1/2" NUT		04	04
09	0521046122	DEPTH SYSTEM / COMPACTOR ASSY		01	01
10	0503010905	1/2" X 2-1/4" BOLT		02	02
11	0571016221	CORN DISC PNEUMATIC		01	01




Item	Code	Description	See page	CT	LG
01	0909092390	SEED ROW ASSY G1		01	01
02	0511053250	SHORT ARM FERTILIZER LINE WITH DDD LEFT		01	00
03	0511053251	ARM LONG FERTILIZER LINE WITH DDD RIGHT		00	01
04	0511058617	DISC CUT 18 SHORT LINE		01	00
05	0511058618	DISC CUT 18 LONG LINE		00	01
06	0561019420	2 X 2700 HOSE ASSY		01	01
07	0503010246	CLAMP		02	02
08	0511063282	HOSE HOLDER		01	01
09	0503010237	3/8" X 1" BOLT		01	01
10	0503010025	3/8" SPRING WASHER		01	01
11	0503010026	3/8" NUT		01	01
12	0511057542	HDA		01	01
13	0531013600	PRESS ADJUSTMENT LEVER		01	01




Item	Code	Description	See page	CT	LG
01	0511057243	LEFT SHORT SEED ROW FRONT	27	01	00
02	0511057246	RIGHT LONG SEED ROW FRONT	28	00	01
03	0511057244	RIGTH SHORT SEED ROW FRONT	26	01	00
04	0511057247	LEFT LONG SEED ROW FRONT	29	00	01
05	0511056624	LEFT REAR LINE SEED		01	01
06	0511056623	RIGHT REAR LINE SEED		01	01
07	0511057248	SEED DEPOSIT ASSY PNEUMATIC - G2	43	01	01
08	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02	02
09	0503010019	1/2" SPRING WASHER		04	04
10	0503010060	1/2" NUT		04	04
11	0521045198	PRESS WHEELS	45	01	01
12	0503010905	1/2" X 2-1/4" BOLT		02	02
13	0571016221	CORN DISC PNEUMATIC		01	01

OPCIONAIS




Item	Code	Description	See page	CT	LG
01	0511057243	LEFT SHORT SEED ROW FRONT	27	01	00
02	0511057246	RIGHT LONG SEED ROW FRONT	28	00	01
03	0511057244	RIGTH SHORT SEED ROW FRONT	26	01	00
04	0511057247	LEFT LONG SEED ROW FRONT	29	00	01
05	0511057607	REAR RIGHT ROW SEED	33	01	01
06	0511057608	REAR LEFT ROW SEED	34	01	01
07	0511053250	SHORT ARM FERTILIZER LINE WITH DDD LEFT		01	00
08	0511053251	ARM LONG FERTILIZER LINE WITH DDD RIGHT		00	01
09	0511058617	DISC CUT 18 SHORT LINE		01	00
10	0511058618	DISC CUT 18 LONG LINE		00	01
11	0521042327	DEPTH CONTROL & PRESS WHEEL ASSY		01	01
12	0521045198	PRESS WHEELS	45	01	01
13	0521044460	SYSTEM DEPTH / COMPACTOR		01	01
14	0521044269	PRESS WHEELS/DEPTH ASSY		01	01
15	0521046501	DEPTH CONTROL AND PRESS WHEEL WITH FAST ADJUSTING		01	01
15.	0521051424	WHEEL SYSTEM DEPTH / COMPACTOR QUICK ADJUSTMENT		01	01
16	0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL		01	01
17	0511057509	SEED RESERVOIR PNEUMATIC ASSY	44	01	01
18	0571019716	ADAPTER		01	01
19	0571019714	AIR CONDUCTOR		01	00
20	0571019715	AIR CONDUCTOR		00	01
21	0503010243	CLAMP		02	02
22	0511051144	ASTA ESCARIFICADORA		01	01
23	0511054835	HDA	47	01	01
24	0511063282	HOSE HOLDER		01	01
25	0531013600	PRESS ADJUSTMENT LEVER		01	00
26	0503010237	3/8" X 1" BOLT		01	01
27	0503010025	3/8" SPRING WASHER		03	03
28	0503010026	3/8" NUT		03	03

Item	Code	Description	See page	CT	LG
29	0521055064	WHEEL SYSTEM DEPTH/ASSY COMPACTOR		01	01
30	0521050193	STEM FUSE WITH CONDUCTOR		01	01
31	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01	01
32	0511017969	0.1" SPACING PLATE		01	01
33	0511058747	RIGHT REAR SUPREME SEED LINE P.P CSU		01	01
34	0511058748	LEFT REAR SUPREME SEED LINE P.P CSU		01	01
35	0521069127	BOTTOM NOZZLE FERTILIZER		01	01
36	0503030483	FERTILIZER SOCKET		01	01
37	0503031050	CURVED CONDUCTOR		01	01
38	0511058212	ASSY LINE SUPPORT FERTILIZER		01	01
39	0571017368	SUPPORT GUTTER		01	01
40	0571019131	GUTTER		02	02
41	0561019643	GUTTER 25 X 58 X 1000		02	02
42	0501011643	3/8 X 1"BOLT		02	02
43	0501010984	FLAT WASHER		02	02
44	0503010025	3/8" SPRING WASHER		02	02
45	0503010026	3/8" NUT		02	02
46	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW		01	01
47	0511044585	20" COULTER BLADE ASSY FOR LONG ROW		01	01
48	0503030391	RIGHT FERTILIZER NOZZLE		01	01
49	0503030392	LEFT FERTILIZER NOZZLE		01	01
50	0503010246	CLAMP		01	01
51	0503031145	2" X 2" X 20" HOSE		01	01
52	0503031076	2" HOSE CLAMP		02	02
53	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		01	01
54	0521052549	CLAMP		02	02
55	0521057957	FIXED ROD EXTENSION WITH FIXATION		01	01
56	0503032624	SILO FERTILIZER GUTTER		01	01
57	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01	01



Item	Code	Description	See page	QT
01	0511057243	LEFT SHORT SEED ROW FRONT	27	01 00
02	0511057246	RIGHT LONG SEED ROW FRONT	28	00 01
03	0511057244	RIGTH SHORT SEED ROW FRONT	26	01 00
04	0511057247	LEFT LONG SEED ROW FRONT	29	00 01
05	0511057607	REAR RIGHT ROW SEED	33	01 01
06	0511057608	REAR LEFT ROW SEED	34	01 01
07	0511057509	SEED RESERVOIR PNEUMATIC ASSY	44	01 01
08	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02 02
09	0503010019	1/2" SPRING WASHER		04 04
10	0503010060	1/2" NUT		04 04
11	0521045198	PRESS WHEELS	45	01 01
12	0503010905	1/2" X 2-1/4" BOLT		02 02
13	0503062417	KIT CORN DISTRIBUTION		01 01
13A	0503018160	CORN PLASTIC DISC		01 01
13B	0503062472	SELECTOR SEED CORN		01 01
13C	0503062474	EJECTOR CORN SEED SET		01 01




Item	Code	Description	See page	QT
01	0521064653	RIGTH SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8 UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER	04	
08	0503010179	5/16" ZN SPRING WASHER	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION BOX SEED LINE	01	
12	0561014904	TRANSMISSION AXLE FRAME LINE	01	
13	0511050609	BEARING WITH 17Z GEAR ASSY	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEDD ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521065847	SHORT TIRE SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" COTTERPIN	01	
27	0503030168	HAIR PIN	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" COTTERPIN	01	
31	0503034580	TRACTION SPRING	02	



PST4 FLEX SUPREMA
RIGTH SHORT SEED ROW FRONT

Page 26
0511057244

Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY		01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064651	LEFT SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8 UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER	04	
08	0503010179	5/16" ZN SPRING WASHER	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION BOX SEED LINE	01	
12	0561014904	TRANSMISSION AXLE FRAME LINE	01	
13	0511050609	BEARING WITH 17Z GEAR ASSY	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEDD ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521065847	SHORT TIRE SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" COTTERPIN	01	
27	0503030168	HAIR PIN	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" COTTERPIN	01	
31	0503034580	TRACTION SPRING	02	



PST4 FLEX SUPREMA
LEFT SHORT SEED ROW FRONT

Page 27
0511057243

Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY		01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064652	RH SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8 UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER	04	
08	0503010179	5/16" ZN SPRING WASHER	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION BOX SEED LINE	01	
12	0561014904	TRANSMISSION AXLE FRAME LINE	01	
13	0501052769	BEARING WITH 17Z GEAR	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEDD ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521065847	SHORT TIRE SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" COTTERPIN	01	
27	0503030168	HAIR PIN	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" COTTERPIN	01	
31	0503034580	TRACTION SPRING	02	



PST4 FLEX SUPREMA
RIGHT LONG SEED ROW FRONT

Page 28
0511057246

Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY		01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064650	LEFT SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8 UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER	04	
08	0503010179	5/16" ZN SPRING WASHER	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION BOX SEED LINE	01	
12	0561014904	TRANSMISSION AXLE FRAME LINE	01	
13	0511050609	BEARING WITH 17Z GEAR ASSY	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEDD ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521065847	SHORT TIRE SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" COTTERPIN	01	
27	0503030168	HAIR PIN	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" COTTERPIN	01	
31	0503034580	TRACTION SPRING	02	




PST4 FLEX SUPREMA
LEFT LONG SEED ROW FRONT

Page 29
0511057247


Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY		01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	BOX TRANSMISSION COVER		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0502040857	CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503010003	1845 GREASE FITTING		01
13	0503011409	6005 Z BALL BEARING		01
14	0503017008	SEAL RING		01
15	0503017007	SEAL RING		02
16	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
00	0511056623	RIGHT REAR LINE SEED		01
01	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	35	01
02	0521042710	PNEUMATIC SEED DISTRIBUTOR	39	01
03	0503011404	BOLT		04
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503033124	SOCKET SEED		01




Item	Code	Description	See page	QT
00	0511056624	LEFT REAR LINE SEED		01
01	0511056586	15 X 15 SEED DDD LEFT	36	01
02	0521042710	PNEUMATIC SEED DISTRIBUTOR	39	01
03	0503011404	BOLT		04
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503033124	SOCKET SEED		01




Item	Code	Description	See page	QT
01	0511057606	PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX	41	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	DDD RITGH SUPREMA PRECISION PLANTING	37	01




Item	Code	Description	See page	QT
01	0511057606	PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX	41	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	38	01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT		01
02	0511053173	CUBE LOW RIGHT WITH DISC 15		01
03	0511053172	LEFT LOW CUBE WITH DISC 15		01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511015098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O-RING		02
14	0511011927	DUST CLOAK		02




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE		01
02	0511053173	CUBE LOW RIGHT WITH DISC 15		01
03	0511053172	LEFT LOW CUBE WITH DISC 15		01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER		02
08	0503011443	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511015098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02



Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15		01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15		01
04	0503010026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501010984	FLAT WASHER		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012780	SUPPORT DDD RIGHT		01
11	0511015098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15		01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15		01
04	0503010026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501010984	FLAT WASHER		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012781	SUPPORT DDD LEFT		01
11	0511015098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02




Item	Code	Description	See page	QT
01	0511050075	PNEUMATIC DISTRIBUTOR SUPPORT		01
01A	0501110649	INNER SUPPORT NEUMATIC SEED DISTR		01
01Aa	0502012599	PNEUMATIC SEED DISTRIBUTOR SUPPORT		01
01Ab	0503011770	SEAL # V-75 A		01
01Ac	0502012649	18Z CONICAL GEAR 34 TEETH		01
01Ad	0503011771	6008 2RS BALL BEARING		01
01B	0502050003	SUPPORT INTERNAL DISC SEED VULCANIZ		01
01C	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
01D	0503010143	1/4" SPRING WASHER		03
01E	0503012849	2-129 N 3006 9B O'RING		02
01F	0503010217	501040 CLAMPING RING (FOR AXLE)		01
01G	0503033121	PNEUMATIC SWITCH		01
01H	0503011295	M 8 X 1,25 X 25 BOLT		01
01I	0503010427	METRIC M8 X P.0.5" NUT		01
02	0503015536	M6 X 1" SELF ADJUSTING NUT		01
03	0503033800	PNEUMATIC JOINT SEALING		03
04	0511053902	CARDAN WHIT SUPPORT	40	01
05	0503011294	M 8 X 1,25 X 20 BOLT		03
06	0503010025	3/8" SPRING WASHER		03
07	0503011370	DISC 6440 MIDDLE SOYBEAN		01
08	0501058950	SEED SYSTEM SIDE		01
08A	0561012486	LATERAL COVER		01
09	0511017186	SEED LEVEL REGULATOR		01
10	0511017303	FLAT WASHER		04
11	0503011776	M6 SELF ADJUSTINGNUT		01
12	0503014141	M6 X 1 X 20 BOLT		01
13	0503011817	UPPER SELECTOR		01
14	0502020559	UPPER SELECTOR ACTUATOR		01
15	0531014481	0.2" X 0.6" AXLE		01
16	0503011821	CRINKLE WASHER		01
17	0503011823	0.1" X 0.6" SPRING PIN		02

Item	Code	Description	See page	QT
18	0511017219	SCALE INDICATOR GUIDE		01
19	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
20	0503010143	1/4" SPRING WASHER		03
21	0503011810	M6 X 1" BUTTERFLY BOLT		01
22	0503031058	UPPER SELECTOR SCALE		01
23	0503011825	M4 X 8" BOLT		02
24	0503011840	FLAT WASHER		02
25	0501110311	LOWER SELECTOR ASSY		01
26	0503011813	M6 X 1.2" BOLT		01
27	0511016220	LOWER SELECTOR INDICATOR		01
28	0503011815	TOOTHED WASHER		01
29	0503012445	M6 C/ABA 1.20" BUTTERFLY NUT		04
30	0503013179	PNEUMATIC SEED DISTRIBUTOR VISOR		01
31	0561012741	SEED DRAINER COVER		01
32	0503011809	M12 KNOB		01
33	0503011828	FLAT WASHER		01
34	0503011827	504.100 CLAMPING RING (FOR HOLE)		01
35	0503011104	M6 X 1" BOLT		02
36	0503011820	CRINKLE WASHER		02
37	0511017199	PST SUP AXLE		01
38	0511017198	SCALE INDICATOR		01




Item	Code	Description	See page	QT
01	0502012738	SUPPORT CARDAN		01
02	0571012413	POINT TRANSMISSION		01
03	0502012648	10Z CONICAL GEAR		01
04	0503015356	SPRING PIN		01
05	0501056296	UNIVERSAL JOINT		01
06	0571012411	HEX AXLE		01
07	0503011855	0.2" X 1.8" SPRING PIN		02
08	0503010002	1800 GREASE FITTING		01



PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX


0511057606

Item	Code	Description	See page	QT
20	0503010293	BAQUELITE MANIPULACION		01
21	0503010140	1/8" X 3/4" COTTERPIN		03
22	0503010131	3/16" X 1-1/2" COTTERPIN		01
23	0503010025	3/8" SPRING WASHER		01
24	0571011803	PRISONER CLOSE FAST		01
25	0571019491	SLUICE PNEUMATIC PRECISION PLANTING		01
26	0501011643	3/8 X 1"BOLT		01
27	0503010209	3/8" UNC BUTTERFLY NUT		01
28	0503012721	1/4" X 4" BOLT		01
29	0503012880	1/4" UNC SELF ADJUSTING NUT		01
30	0571011804	FAST BOLT ADJUSTMENT		01
31	0571019489	CLAMP PRECISION PLANTING		01
32	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
33	0503011855	0.2" X 1.8" SPRING PIN		02
34	0561014778	HEX UNIVERSAL JOINT		01
35	0503013958	1/4" X 1" BOLT		02
36	0503011855	0.2" X 1.8" SPRING PIN		01
37	0503818139	M6 BOLT		03
38	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
39	0503015110	M06 SPRING WASHER		02
40	0501056296	UNIVERSAL JOINT		01
41	0571012452	HEX AXLE		01
42	0511057491	PRECISION PLANTING SEED ASSY SEED 42 DISTRIBUTOR WITH CORN DISC		01
42A	0503062405	SEED DISTRIBUTOR		01
42B	0503062407	SET SOYBEAN DISTRIBUTION		01
42B-01	0503062417	KIT CORN DISTRIBUTION		01
42B-02	0503062471	DISTRIBUTION ASSY (SORGHUM / MILLET)		01
42B-03	0503062577	DISTRIBUTION ASSY (LARGE CORN / SUNFLOWER)		01
42B-04	0503062578	DISTRIBUTION ASSY (LARGE CORN)		01
42B-05	0503062579	DISTRIBUTION ASSY (CORN / SUNFLOWER)		01
42B-06	0503062580	DISTRIBUTION ASSY (POPCORN / COTTON)		01
42B-07	0503062581	DISTRIBUTION ASSY (SMALL CORN / POP CORN)		01
42B-08	0503062573	CONVERSATION SET FOR DISTRIBUTION (LARGE BEAN)		01
42B-09	0503062574	CONVERSATION SET FOR DISTRIBUTION (SMALL BEET)		01
42B-10	0503062564	CONVERSATION SET FOR DISTRIBUTION (SOYBEAN / BEAN)		01
42C	0571019613	STRAW PRECISION PLANTING SHIELD		01




Item	Code	Description	See page	QT
01	0503062405	SEED DISTRIBUTOR		01
01A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
01AA	0503018908	BODY FIXED BASE DISTRIBUTOR SEED		01
01AB	0503018909	COVER CONDUCTOR DISTRIBUTOR SEED		01
01AC	0503062652	SEED INPUT DEFLECTOR		01
01AD	0503062653	FULL COVER		01
01AE	0503018910	RIVETS LARGEST		01
01AF	0503018911	SPACING BUSHING		01
01AG	0503018912	BOLT		03
01AH	0503018476	SPRING		01
01AI	0503018474	LOWER BRUSH		01
01AJ	0503018475	TOP BRUSH		01
01AK	0503018157	RUBBER		01
01AL	0503018477	LOCK SPRING		01
01B	0503062568	FIXER MOBILE		01
01BA	0503018919	BASE		01
01BB	0503018913	RIVET		01
01BC	0503018914	WASHER		01
01BD	0503018915	BEARING		02
01BE	0503062654	BEARING		01
01BF	0503018916	ADJUSTMENT CHOCK		03
01BG	0503018917	RING		01
01BH	0503018918	CHOCK		02
01BI	0503019288	RUBBER SEAL PP 730518		01
01BJ	0503018478	SPRING		01
01BK	0503018920	SEALING		01
01BL	0503018479	TUBE		01
01BM	0503018735	PROTECTIVE COVER		01
01BN	0503018921	BOLT		06
01BO	0503018922	BOLT		02
01BP	0503018480	REGULATOR PIN		01


Item	Code	Description	See page	QT
01BQ	0503018923	ADAPTER		01
01BR	0503018924	SPRING PIN		01
02	0503062417	KIT CORN DISTRIBUTION		01
02A	0503018160	CORN PLASTIC DISC		01
02B	0503062472	SELECTOR SEED CORN		01
02C	0503062474	EJECTOR CORN SEED SET		01
03	0571019613	STRAW PRECISION PLANTING SHIELD		01
03A	0503017957	PROTECTIVE COVER AIR INPUT		01



Item	Code	Description	See page	QT
01	0503031508	COVER GREEN BEAM SEED YELLOW		01
02	0502012798	SUPPORT BOX SEED		01
03	0521065830	SUPPORT BASE SYSTEM PNEUMATIC		01
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
05	0503010025	3/8" SPRING WASHER		05
06	0503010026	3/8" NUT		04
07	0571018513	SLUICE PNEUMATIC		01
08	0571018512	GUIDE SLUICE PNEUMATIC		01
09	0501011643	3/8 X 1"BOLT		01
10	0501010984	FLAT WASHER		01
11	0503010209	3/8" UNC BUTTERFLY NUT		01
12	0503010358	5/16" X 5/8" BOLT		04
13	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
14	0503010179	5/16" ZN SPRING WASHER		04
15	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0502012798	SUPPORT BOX SEED	01	
02	0581012694	COMPACT PROTECTION	01	
03	0503010849	3/8" X 1-1/2" BOLT	03	
04	0501010096	3/8" X 2" BOLT	01	
05	0503010025	3/8" SPRING WASHER	04	
06	0503010026	3/8" NUT	04	
07	0503031508	COVER GREEN BEAM SEED YELLOW	01	
08	0503010358	5/16" X 5/8" BOLT	04	
09	0501010694	8.5 X 18 X 1.5 FLAT WASHER	04	
10	0503010179	5/16" ZN SPRING WASHER	04	
11	0503010337	5/16" NUT	04	




Item	Code	Description	See page	QT
01	0511056691	CONTROL DEPTH SUPPORT		01
01A	0502012282	DEPTH CONTROL SUPPORT		01
02	0571016886	DEPTH WHEEL AXLE		01
03	0503810256	SCREW		01
04	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
05	0503033942	COVER REGULATORY WHEEL		01
06	0521064073	REGULACION WHEEL COMPACTOR		01
07	0511056692	DEPTH WHEEL RIGHT ARM		01
07A	0501110796	DEPTH CONTROL RIGHT ARM		01
07Aa	0502012769	BRACO DIR RODA PROF		01
07Ab	0571016883	GLOVE NYLON		01
07B	0501052627	ASSY DEPTH WHEEL BOX		02
07Ba	0502011907	DEPTH CONTROL WHEEL HUB		02
07Bb	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		02
07Bc	0503010269	6204 BALL BEARING		04
07Bd	0501013636	SPACING SLEEVE		02
07Be	0503010689	SEAL 00763-BR		02
07Bf	0503011105	SEAL RING		02
07Bg	0503010878	5/8" SELF ALIGNING NUT		02
07Bh	0521019178	COVER DEPTH		02
07bi	0503030757	2.9" X 2" X 0.02" JOINT		02
07Bj	0503014729	1/4" UNF X 1/2" BOLT		06
07Bk	0503011441	SPRING WASHER		06
07Bl	0503010691	1/4" GREASE FITTING		02
07C	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07D	0503011440	SPRING WASHER		02
07E	0503010060	1/2" NUT		02
07F	0503010002	1800 GREASE FITTING		02
08	0511056693	LH ARM DEPTH CONTROL WHEEL		01
08A	0501110797	ARM LEFT GLOVE WITH DEPTH CONTROL		01
08Aa	0502012770	LEFT ARM WHEEL DEPTH		01


Item	Code	Description	See page	QT
08Ab	0571016883	GLOVE NYLON		01
09	0571017749	FLAT WASHER		02
10	0503011440	SPRING WASHER		02
11	0503010311	1/2" X 1-1/4" BOLT		02
12	0501052297	DEPTH WHEELS REGULATOR ASSY		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010257	1/8" X 1" COTTERPIN		01
15	0502012116	PRESS WHEEL ADJUSTER		01
16	0503010849	3/8" X 1-1/2" BOLT		02
17	0503011443	3/8" SPRING WASHER		02
18	0503010026	3/8" NUT		02
19	0541016906	PRESS WHEELS REGULATOR BODY		01
20	0521010539	0.3" X 1.2" COUPLING SHAFT		01
21	0503010140	1/8" X 3/4" COTTERPIN		01
22	0503030805	1.6" X 6" X 0.2" TRACTION SPRING		01
23	0501052538	DEPTH BAND WITH ARMS		02
24	0503010358	5/16" X 5/8" BOLT		08
25	0503010179	5/16" ZN SPRING WASHER		08
26	0503013816	5/16" LOCKNUT		08
27	0511054333	COMPACT WHEEL RIGHT WITH BEARING		01
28	0511054334	COMPACT WHEEL LEFT WITH BEARING		01




Item	Code	Description	See page	DIR	ESQ
01	0511054333	COMPACT WHEEL RIGHT WITH BEARING	01	00	
02	0511054334	COMPACT WHEEL LEFT WITH BEARING	00	01	
03	0501052908	COMPACTOR WHEEL WITH BEARING	01	01	
03A	0502011919	PRESS WHEEL HUB	01	01	
03B	0502011877	PRESS WHEEL HUB	01	01	
03C	0503010269	6204 BALL BEARING	02	02	
03D	0521018922	PRESS WHEEL PASSANG AXLE	02	02	
03E	0503012734	SEAL 01556 BR	02	02	
03F	0521018921	DUST CLOAK	02	02	
03G	0503010691	1/4" GREASE FITTING	01	01	
03H	0521018928	PRESS WHEEL RIM	02	02	
03I	0503031421	DEPTH CONTROL WHEEL RUBBER BAND	01	01	
03J	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN	06	06	
03K	0503010179	5/16" ZN SPRING WASHER	09	09	
03L	0503010337	5/16" NUT	06	06	
03M	0503010371	5/16" X 1" BOLT	03	03	
03N	0503013816	5/16" LOCKNUT	03	03	
04	0503016449	1/2 X 4 BOLT	01	00	
05	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT	00	01	
06	0521014508	FLAT WASHER	03	03	
07	0503012136	NUT 1/2 NF	01	00	
08	0503016864	LH 1/2" LOCK NUT	00	01	




Item	Code	Description	See page	QT
01	0571015538	SLEEVE 37 X 28,3 X 16,70	01	
02	0503012412	5/8 UNC SELF LOCKING NUT	01	
03	0503010691	1/4" GREASE FITTING	01	
04	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
05	0511017302	FLAT WASHER	04	
06	0503010384	1/2" X 5" BOLT	02	
07	0503010547	1/2" X 4" BOLT	02	
08	0503010417	7/8" NUT	01	
09	0503033624	35 X 215 X 7,14 COMPRES SPRING	01	
10	0521064736	FERTILIZER SOCKET	01	
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	02	
12	0501010984	FLAT WASHER	04	
13	0503010025	3/8" SPRING WASHER	02	
14	0503010026	3/8" NUT	02	
15	0521064739	ROD SUPPORT	01	
16	0571015616	GUIDE SPRING SUPPORT	01	
17	0571015552	BOLT FIXER	01	
18	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN	01	
19	0503034106	80 X 230 X 16,50 HDA COMPRESSSION SPRING	01	
20	0511058935	ROD WITH POINT FLANGE WASHER SPRING HDA	01	



Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0502010175	HITCH CLAMP		01
03	0501011543	5/8" X 4" BOLT		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0511053250	SHORT ARM FERTILIZER LINE WITH DDD LEFT		01
06	0511053251	ARM LONG FERTILIZER LINE WITH DDD RIGHT		00
07	0501010066	3/4" X 9" BOLT		01
08	0521017831	SUPPORT SLEEVE SPACER		02
09	0511017232	FLAT WASHER		02
10	0503011255	3/4" LOCK NUT		01
11	0501058423	FERTILIZER ROD SPRING ROW		01
12	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	51	01
13	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	52	00
14	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW		01
15	0511044585	20" COULTER BLADE ASSY FOR LONG ROW		01
16	0503030391	RIGHT FERTILIZER NOZZLE		01
17	0503030392	LEFT FERTILIZER NOZZLE		00
18	0503031050	CURVED CONDUCTOR		01
19	0503010246	CLAMP		01
20	0503031145	2" X 2" X 20" HOSE		01
21	0503031076	2" HOSE CLAMP		02
22	0521044545	20 WAVY COULTER BLADE ASSY FOR SHORT ROW		04
23	0521044546	DISCO WAVY CURVED 20 LONG		03
24	0909092327	FERTILIZER LINE WITH STEM		




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15		01
02	0511053172	LEFT LOW CUBE WITH DISC 15		01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RH DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01



Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15		01
02	0511053173	CUBE LOW RIGHT WITH DISC 15		01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RH DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503011443	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01

18" COULTER BLADE ASSY FOR SHORT ROW

0511044549



Item	Code	Description	See page	QT
01	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE		01
02	0502012368	BLADE DISC SUPPORT AXLE		01
03	0503010756	0.2" X 2.4" SPRING PIN		01
04	0503010361	SPRING PIN		01
05	0541018684	FLAT WASHER		01
06	0521014137	RIGHT ARM OF THE BLADE DISC		01
07	0521014138	SUPPORT ARM LEFT BALDE DISC		01
08	0501067323	SPRING REGULATOR		01
09	0521010452	SLEEVE		01
10	0503013185	3/4" X 5-1/2" BOLT		01
11	0503011255	3/4" LOCK NUT		01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
13	0503011411	1/2" X 5-1/2" BOLT		01
14	0503011440	SPRING WASHER		01
15	0503010060	1/2" NUT		01
16	1902020393	SPRING UPPER SUPPORT		01
17	0502020394	SPRING SUPPORT		01
18	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
19	0503010014	3/4" NUT		02
20	0521015376	DUST CLOAK		02
21	0502011562	DC PST ACT/ULTR BOX		01
22	0503010276	6206 BALL BEARING		02
23	0521013610	BLADE DISC HUB AXLE		01
24	0503030832	FLAT WASHER		02
25	0503012417	SEAL		02
26	0503011800	SEAL RING		02
27	0503010691	1/4" GREASE FITTING		01
28	0603026013	PLAIN COULTER BLADE		01
29	0502020641	BLADE DISC FLANGE		01
30	0503010371	5/16" X 1" BOLT		06
31	0503011444	SPRING WASHER		06


**18" COULTER BLADE ASSY FOR SHORT ROW**

0511044549

Item	Code	Description	See page	QT
32	0503010337	5/16" NUT		06
33	0511815346	FLAT WASHER		02
34	0503011442	3/4" SPRING WASHER		02
35	0521813510	R3/4UNC NUT		02
36	0503010003	1845 GREASE FITTING		01

18" COULTER BLADE ASSY FOR LONG ROW

0511044573




Item	Code	Description	See page	QT
01	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE		01
02	0502012368	BLADE DISC SUPPORT AXLE		01
03	0503010756	0.2" X 2.4" SPRING PIN		01
04	0503010361	SPRING PIN		01
05	0541018684	FLAT WASHER		01
06	0521014137	RIGHT ARM OF THE BLADE DISC		01
07	0521014138	SUPPORT ARM LEFT BALDE DISC		01
08	0501067323	SPRING REGULATOR		01
09	0521010452	SLEEVE		01
10	0503013185	3/4" X 5-1/2" BOLT		01
11	0503011255	3/4" LOCK NUT		01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
13	0503011411	1/2" X 5-1/2" BOLT		01
14	0503011440	SPRING WASHER		01
15	0503010060	1/2" NUT		01
16	0502020393	SPRING UPPER SUPPORT		01
17	0502020394	SPRING SUPPORT		01
18	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
19	0503010014	3/4" NUT		02
20	0521015376	DUST CLOAK		02
21	0502011562	DC PST ACT/ULTR BOX		01
22	0503010276	6206 BALL BEARING		02
23	0521013610	BLADE DISC HUB AXLE		01
24	0503030832	FLAT WASHER		02
25	0503012417	SEAL		02
26	0503011800	SEAL RING		02
27	0503010691	1/4" GREASE FITTING		01
28	0603026013	PLAIN COULTER BLADE		01
29	0502020641	BLADE DISC FLANGE		01
30	0503010371	5/16" X 1" BOLT		06
31	0503010179	5/16" ZN SPRING WASHER		06

**18" COULTER BLADE ASSY FOR LONG ROW**


0511044573

Item	Code	Description	See page	QT
32	0503010337	5/16" NUT		06
33	0511015346	FLAT WASHER		02
34	0503010023	3/4" SPRING WASHER		02
35	0521013510	3/4" NUT		02
36	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	07	09	10
01	0511069622	ROW MARKER ARM SUPPORT		02	02	02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08	08	08
03	0503012412	5/8 UNC SELF LOCKING NUT		08	08	08
04	0503011070	BEATER		02	02	02
05	0503010019	1/2" SPRING WASHER		02	02	02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02	02	02
07	0551019213	FLAT WASHER		02	02	02
08	0501069470	ROW MARKER ARM		02	02	02
09	0521061655	BOLT 5/8 UNC X 320 MM		02	02	02
10	0521010479	SLEEVE ARTICULATION		04	04	04
11	0501012140	FLAT WASHER		04	04	04
12	0511058449	HYDRAULIC CYLINDER		02	02	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02	02	02
14	0503010523	1/4" X 2" COTTERPIN		04	04	04
15	0511015779	1" X 4.2" AXLE		02	02	02
16	0511017592	11.8" X 1.6" TRANSPORT LOCK		02	02	02
17	0501068994	0.3" X 3.1" LOCK PIN		02	02	02
18	0503030168	HAIR PIN		02	02	02
19	0501069643	890 TURNBUCKLE		02	02	02
20	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04	04	04
21	0511011311	VALVE SUPPORT		01	01	01
22	0503010232	5/8" X 1.3/4" BOLT		02	02	02
23	0503010027	5/8" SPRING WASHER		02	02	02
24	0503010013	5/8" NUT		02	02	02
25	0501054649	SEQUENTIAL VALVE ASSY	56	01	01	01
26	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02	02	02
27	0501010984	FLAT WASHER		02	02	02
28	0503010025	3/8" SPRING WASHER		02	02	02
29	0501080452	3/8" X 98" TR-TR HOSE		02	00	00
30	0501080401	3/8" X 106" TR-TC HOSE		02	00	00
31	0501080422	HOSE 3/8 X 4000 TC-TM		02	02	02


Item	Code	Description	See page	07	09	10
32	0501081727	TR-TR HOSE ASSY		00	02	00
33	0501080447	3/8" X 122" TR-TC HOSE ASSY		00	02	00
34	0501081729	HOSE 3/8 X 3125 TR-TR		00	00	02
35	0501081639	HOSE		00	00	02
36	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT		02	02	02
37	0502012702	BODY SUPPORT CLAMP		04	04	04
38	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04	04	04
39	0503010180	7/16" SPRING WASHER		04	04	04
40	0503010244	7/16" NUT		04	04	04
41	0501050633	MARKER DISC ASSY LINE	54	02	02	02
42	0501012803	FLAT WASHER		02	02	02



Item	Code	Description	See page	QT
01	0511053904	DISC LINE MARKER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01



Item	Code	Description	See page	QT
01	0511062810	2.5" X 15" CYLINDER CASE		01
02	0501065662	HYDRAULIC CYLINDER TURNBUCKLE		01
03	0502010471	MOBILE COVER		01
04	0502010780	RING SUPPORT		01
05	0503010163	D-1500 SCRAPER RING		01
06	0503010989	1870-1500-375-B GASKET		01
07	0503010970	W1-1650-500 PK O'RING G.E		01
08	0503011058	8-330 BACK-UP RING		01
09	0503010161	2-330 N 3006 9B O'RING		01
10	0503010285	2-222 N 3006-9B O'RING		01
11	0502010783	1.5" X 2.5" PISTON		01
12	0503010160	2500 2000 GASKET		02
13	0503010973	W2-2500-500 PK O'RING G.E		01
14	0503010063	1" SELF-ALIGNING NUT		01
15	0503030384	CON PLUG N-001		02
16	0501032666	HYDRAULIC CYLINDER REPAIR KIT		01



Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCIAL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02



www.marchesan.com.br



Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI