

PARTS CATALOG

ROW CROP PLANTERS

COP FLEX 600 SUPREMA

Code: 0501091560



Series: S-0713

Rev.: 00

Date Rev.: FEVEREIRO/2016

**ORIGINAL PARTS
TATU**



PRODUCTS

Code	Description
0111200185	COP FLEX 600 SUP 13/12MH MTH S0713
0111200155	COP FLEX 600 SUP 11/10 MTH MS S0213
0111200222	COP FLEX 600 SUP 11/10ESPECIAL S713
0111200102	COP FLEX 600 SUP 11/11 S-0213
0111200267	COP FLEX 600 SUP 11/11 ESP S-1014
0111200261	COP FLEX 600 SUP 11/11 ESPEC S-0713
0111200175	COP FLEX 600 SUP 11/11 MH S-0713
0111200174	COP FLEX 600 SUP 11/11 MH CSU S0713
0111200268	COP FLEX 600 SUP 11/11 MH CSU S1014
0111200154	COP FLEX 600 SUP 11/11 MH MTH S0213
0111200172	COP FLEX 600 SUP 11/11 MH MTH S0713
0111200100	COP FLEX 600 SUP 11/6 S-0213
0111200177	COP FLEX 600 SUP 11/6 MH S-0713
0111200178	COP FLEX 600 SUP 11/6 MH MTH S-0713
0111200129	COP FLEX 600 SUP 11/6 MTH S-0213
0111200101	COP FLEX 600 SUP 11/8 S-0213
0111200179	COP FLEX 600 SUP 11/8 MH S-0713
0111200180	COP FLEX 600 SUP 11/8 MH MTH S-0713
0111200130	COP FLEX 600 SUP 11/8 MTH S-0213
0111200262	COP FLEX 600 SUP 12/11ESPECIAL S713
0111200106	COP FLEX 600 SUP 13/10 S-0213
0111200135	COP FLEX 600 SUP 13/10 MTH S-0213
0111200093	COP FLEX 600 SUP 13/11 DC20MTH CXSF
0111200170	COP FLEX 600 SUP 13/12 MH MTH S0213
0111200259	COP FLEX 600 SUP 13/12ESPECIAL S713
0111200157	COP FLEX 600 SUP 13/12MH MTH H DC20
0111200092	COP FLEX 600 SUP 13/13 MH S-0213
0111200181	COP FLEX 600 SUP 13/13 MH S-0713
0111200167	COP FLEX 600 SUP 13/13 MH APT MSA
0111200136	COP FLEX 600 SUP 13/13 MH MTH S0213
0111200160	COP FLEX 600 SUP 13/13 MTH CSU CXSF

ATTENTION: **IMPORTANT**

MARCHESAN S/A RESERVES THE RIGHT AT ANY TIME TO MAKE IMPROVEMENTS IN THE DESIGN, MATERIAL OR SPECIFICATIONS OF MACHINERY, EQUIPMENT OR PARTS WITHOUT THEREBY BECOMING LIABLE TO MAKE SIMILAR CHANGES IN MACHINERY, EQUIPMENT OR PARTS PREVIOUSLY SOLD.

PRODUCTS

0111201113	COP FLEX 600 SUP 13/13 MTH EE APT S-1214
0111200182	COP FLEX 600 SUP 13/13MH CSU S-0713
0111200164	COP FLEX 600 SUP 13/13MH DC20MTH MS
0111200161	COP FLEX 600 SUP 13/13MH MTH CSU MS
0111200158	COP FLEX 600 SUP 13/13MTH RAIAD CBR
0111200131	COP FLEX 600 SUP 13/5 MTH S-0213
0111200103	COP FLEX 600 SUP 13/6 S-0213
0111200132	COP FLEX 600 SUP 13/6 MTH S-0213
0111200104	COP FLEX 600 SUP 13/7 S-0213
0111200133	COP FLEX 600 SUP 13/7 MTH S-0213
0111200105	COP FLEX 600 SUP 13/8 S-0213
0111200134	COP FLEX 600 SUP 13/8 MTH S-0213
0111200109	COP FLEX 600 SUP 15/10 S-0213
0111200139	COP FLEX 600 SUP 15/10 MTH S-0213
0111200110	COP FLEX 600 SUP 15/11 S-0213
0111200140	COP FLEX 600 SUP 15/11 MTH S-0213
0111200111	COP FLEX 600 SUP 15/12 S-0213
0111200197	COP FLEX 600 SUP 15/12MH MTH S-0713
0111200141	COP FLEX 600 SUP 15/12MTH E550 S213
0111200085	COP FLEX 600 SUP 15/15 MH S-0213
0111200193	COP FLEX 600 SUP 15/15 MH S-0713
0111200194	COP FLEX 600 SUP 15/15 MH CSU S0713
0111200142	COP FLEX 600 SUP 15/15 MH MTH S0213
0111200196	COP FLEX 600 SUP 15/15 MH MTH S0713
0111200090	COP FLEX 600 SUP 15/15DC20 AFR S213
0111200198	COP FLEX 600 SUP 15/15MH DC20 S0713
0111200107	COP FLEX 600 SUP 15/7 S-0213
0111200137	COP FLEX 600 SUP 15/7 MTH S-0213
0111200108	COP FLEX 600 SUP 15/8 S-0213
0111200138	COP FLEX 600 SUP 15/8 MTH S-0213
0111200088	COP FLEX 600 SUP 15/8MH PN11L15 AFR
0111200089	COP FLEX 600 SUP 15/8MTH P11L15 AFR

ATTENTION: **IMPORTANT**

MARCHESAN S/A RESERVES THE RIGHT AT ANY TIME TO MAKE IMPROVEMENTS IN THE DESIGN, MATERIAL OR SPECIFICATIONS OF MACHINERY, EQUIPMENT OR PARTS WITHOUT THEREBY BECOMING LIABLE TO MAKE SIMILAR CHANGES IN MACHINERY, EQUIPMENT OR PARTS PREVIOUSLY SOLD.

PRODUCTS

0111200112	COP FLEX 600 SUP 17/10 S-0213
0111200143	COP FLEX 600 SUP 17/10 MTH S-0213
0111200113	COP FLEX 600 SUP 17/11 S-0213
0111200144	COP FLEX 600 SUP 17/11 MTH S-0213
0111200114	COP FLEX 600 SUP 17/12 S-0213
0111200145	COP FLEX 600 SUP 17/12 MTH S-0213
0111200115	COP FLEX 600 SUP 17/13 S-0213
0111200146	COP FLEX 600 SUP 17/13 MTH S-0213
0111200116	COP FLEX 600 SUP 17/14 S-0213
0111200147	COP FLEX 600 SUP 17/14 MTH S-0213
0111200117	COP FLEX 600 SUP 17/17 S-0213
0111200203	COP FLEX 600 SUP 17/17 S-0713
0111200199	COP FLEX 600 SUP 17/17 MH S-0713
0111200200	COP FLEX 600 SUP 17/17 MH CSU S0713
0111200202	COP FLEX 600 SUP 17/17 MH MTH S0713
0111200148	COP FLEX 600 SUP 17/17 MTH S-0213
0111200204	COP FLEX 600 SUP 17/17 MTH S-0713
0111200091	COP FLEX 600 SUP 19/10 MH S-0213
0111200209	COP FLEX 600 SUP 19/10 MH S-0713
0111200149	COP FLEX 600 SUP 19/10 MTH S-0213
0111200118	COP FLEX 600 SUP 19/12 MH S-0213
0111200150	COP FLEX 600 SUP 19/12 MTH S-0213
0111200119	COP FLEX 600 SUP 19/13 MH S-0213
0111200151	COP FLEX 600 SUP 19/13 MTH S-0213
0111200120	COP FLEX 600 SUP 19/14 MH S-0213
0111200152	COP FLEX 600 SUP 19/14 MTH S-0213
0111200121	COP FLEX 600 SUP 19/15 MH S-0213
0111200153	COP FLEX 600 SUP 19/15 MH MTH S0213
0111200122	COP FLEX 600 SUP 19/19 MH S-0213
0111200205	COP FLEX 600 SUP 19/19 MH S-0713
0111200208	COP FLEX 600 SUP 19/19 MH MTH S0713
0111200206	COP FLEX 600 SUP 19/19MH CSU S-0713

ATTENTION: **IMPORTANT**

MARCHESAN S/A RESERVES THE RIGHT AT ANY TIME TO MAKE IMPROVEMENTS IN THE DESIGN, MATERIAL OR SPECIFICATIONS OF MACHINERY, EQUIPMENT OR PARTS WITHOUT THEREBY BECOMING LIABLE TO MAKE SIMILAR CHANGES IN MACHINERY, EQUIPMENT OR PARTS PREVIOUSLY SOLD.

PRODUCTS

0111200265	COP FLEX 600 SUP 4045/9E450 E
0111200263	COP FLEX 600 SUP 4045/9E450 MH
0111200269	COP FLEX 600 SUP 4845/10E500 E
0111200266	COP FLEX 600 SUP 4845/11E450 E
0111200283	COP FLEX 600 SUP 5345/11E450 E
0111200284	COP FLEX 600 SUP 5345/11E450 E
0111200274	COP FLEX 600 SUP 5745/12E500 E
0111200275	COP FLEX 600 SUP 5745/12E500 E
0111200270	COP FLEX 600 SUP 5745/13E450 E
0111200271	COP FLEX 600 SUP 5745/13E450 E
0111200273	COP FLEX 600 SUP 5745/13E450 E
0111200272	COP FLEX 600 SUP 5745/13E450MH
0111200277	COP FLEX 600 SUP 6645/15E450 E
0111200278	COP FLEX 600 SUP 6645/15E450 E
0111200276	COP FLEX 600 SUP 6645/15E450MH
0111200156	COP FLEX 600 SUP 7/4 MH S/H CPF AFR
0111200258	COP FLEX 600 SUP 7/6 ESPECIAL S0713
0111200094	COP FLEX 600 SUP 7/7 S-0213
0111200123	COP FLEX 600 SUP 7/7 MTH S-0213
0111200280	COP FLEX 600 SUP 7545/17E450 E
0111200279	COP FLEX 600 SUP 7545/17E450MH
0111200282	COP FLEX 600 SUP 8445/19E450 E
0111200281	COP FLEX 600 SUP 8445/19E450MH
0111200095	COP FLEX 600 SUP 9/4 S-0213
0111200124	COP FLEX 600 SUP 9/4 MH MTH S-0213
0111200214	COP FLEX 600 SUP 9/4 MH MTH S-0713
0111200096	COP FLEX 600 SUP 9/5 MH S-0213
0111200215	COP FLEX 600 SUP 9/5 MH S-0713
0111200125	COP FLEX 600 SUP 9/5 MH MTH S-0213
0111200216	COP FLEX 600 SUP 9/5 MH MTH S-0713
0111200097	COP FLEX 600 SUP 9/6 S-0213
0111200126	COP FLEX 600 SUP 9/6 MH MTH S-0213

ATTENTION: **IMPORTANT**

MARCHESAN S/A RESERVES THE RIGHT AT ANY TIME TO MAKE IMPROVEMENTS IN THE DESIGN, MATERIAL OR SPECIFICATIONS OF MACHINERY, EQUIPMENT OR PARTS WITHOUT THEREBY BECOMING LIABLE TO MAKE SIMILAR CHANGES IN MACHINERY, EQUIPMENT OR PARTS PREVIOUSLY SOLD.

PRODUCTS


0111200217	COP FLEX 600 SUP 9/6 MH MTH S-0713
0111200098	COP FLEX 600 SUP 9/7 S-0213
0111200127	COP FLEX 600 SUP 9/7 MH MTH S-0213
0111200218	COP FLEX 600 SUP 9/7 MH MTH S-0713
0111200219	COP FLEX 600 SUP 9/8 H MH S-0713
0111200162	COP FLEX 600 SUP 9/8 MH S/DDD S0213
0111200099	COP FLEX 600 SUP 9/9 S-0213
0111200257	COP FLEX 600 SUP 9/9 ESPECIAL S0713
0111200210	COP FLEX 600 SUP 9/9 MH S-0713
0111200211	COP FLEX 600 SUP 9/9 MH CSU S-0713
0111200128	COP FLEX 600 SUP 9/9 MH MTH S-0213
0111200213	COP FLEX 600 SUP 9/9 MH MTH S-0713
0111200212	COP FLEX 600 SUP 9/9MH CSU MTH S713
0111200221	COP FLEX 600 SUP11/10 ESPECIAL S713
0111200253	COP FLEX 600 SUP13/12 ESPECIAL S713
0111201112	COP FLEX 600 SUP13/13 ESPECIAL 713
0111200254	COP FLEX 600 SUP13/13 ESPECIAL S713
0111200223	COP FLEX 600 SUP15/12 ESPECIAL S713

ATTENTION: **IMPORTANT**

MARCHESAN S/A RESERVES THE RIGHT AT ANY TIME TO MAKE IMPROVEMENTS IN THE DESIGN, MATERIAL OR SPECIFICATIONS OF MACHINERY, EQUIPMENT OR PARTS WITHOUT THEREBY BECOMING LIABLE TO MAKE SIMILAR CHANGES IN MACHINERY, EQUIPMENT OR PARTS PREVIOUSLY SOLD.

INDEX


0909094610	FRAME COP FLEX 600 7/9/11/13	1
0909094623	FRAME COP FLEX 600 15/17/19	2
0909094611	RIGHT AND LEFT WHEELS ASSY	3
0909094629	WITHOUT TRANSMIS RIGHT WHEEL ASSY	4
0511043969	44,45 X 101,6 HYDRAULIC CYLINDER	5
0511051434	TRANSMISSION DRIVING ASSY	6
0909094624	HYDRAULIC CIRCUIT 17 ROW	7
0909094612	HYDRAULIC CIRCUIT 09 AND 11 ROW	8
0909094625	HYDRAULIC CIRCUIT 13 AND 15 ROW	9
0909094626	HYDRAULIC CIRCUIT 17 AND 19 ROW	10
0909094613	ASSY TRANSMISSION	11
0909093036	SIDE TRANSMISSION DRIVING ASSY	12
0909094044	GEAR BOX RIGHT AND LEFT ASSY	13
0909094614	FERTILIZER BOX ASSY	14
0521042755	LONG FERTIL ROW	15
0511053023	LONG FERTILIZER LINE	16
0909094615	SMALLER 15" X 15" FERT UNAL DOUB-DISC ASSY	16
0521042754	SHORT ROW FERTILIZER	17
0511053024	FERTILIZER SHORT LINE	18
0511051818	18" BLADE DISC ASSY	19
0501052139	18 BLADE DISC WITH FLAT PLAN DISC	20
0511051819	20 BLADE DISC ASSY	21
0501054887	20 BLADE DISC WITH FLAT PLAN DISC	22
0909094571	ENSEMBLE BOX UNIQUE SEED	23
0909094616	MARKER CYLINDER	24
0501050633	DISC LINE MARKER	25
0909094617	CIRCUIT MARKER HIDRAULICO	26
0511040203	1.5" X 2.5" X 19" X 9" HYDRAULIC CYLINDER	27
0909094627	MARKER HIDRAULICO	28
0909094628	CIRCUIT MARKER HIDRAULICO	29
0501045149	1.5"X2.5"X30"X18"RH HYDRAULICCYLINDER	30
0501046485	1.5"X 2.5"X 30"X 18"LEFT HYDRAULIC CYLINDER	31
0909094630	PARTS SUPREMA TURBINE WITH CARDAN	32
0521041586	TURBINE ASSY FOR CARDAN	33
0511041364	DRIVE SHAFT	34
0521041587	TURBINE MOTOR HYDRAULIC ASSY	34
0909094638	PARTS HYDRAULIC TURBINE	35
0909094631	TRANSMISSION	36
0909094632	GEAR BOX RIGHT LEFT ASSY	37
0909094633	FERTILIZER SEED ROW ASSY	38
0909094634	FRONT SEED ROW WITH CARDAN	39
0511054318	TRANSMISSION HUB	40
0909094635	REAR SEED ROW	41
0909094636	PNEUMATIC SEED DISTRIBUTOR	42
0511053903	DRIVE SHAFT	43
0909094637	PRESS WHEELS BALL BEARING	44



Item	Code	Description	See page	07	09	11	13
01	0521061841	FRAME 11		00	00	01	00
02	0511053393	DRAWBAR		01	01	01	00
02A	0511064808	DRAWBAR		01	01	04	04
02B	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02	02	04	04
02C	0502012329	DRAWBAR FIXATION REAR SUPPORT		02	02	04	04
02D	0561014393	COUPLING SHAFT		02	02	04	04
02E	0503030119	LOCK PIN		02	02	04	04
02F	0502012330	SUPPORT FIXER PIVOT		04	04	08	08
02G	0503011084	3/4" X 5" BOLT		08	08	16	16
02H	0501010322	FLAT WASHER		04	04	08	08
02I	0503010023	SPRING WASHER		04	04	08	08
02J	0503010014	3/4" NUT		04	04	08	08
02K	0503010002	1800 GREASE FITTING		04	04	04	04
02L	0561019087	DRAWBAR TRANSPORT LOCK		01	01	01	01
02M	0521018532	1.4" X 12" COUPLING SHAFT		01	01	01	01
02N	0521010578	COUPLING SHAFT		01	01	01	01
02O	0503030085	LOCK PIN		03	03	03	03
03	0511052492	TRACTOR HITCH ASSY		01	01	01	01
03A	0571012608	TRACTOR HITCH		01	01	01	01
03B	0502040846	U TRACTOR HITCH		01	01	01	01
03C	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01	01	01	01
03D	0503010010	1/4" X 2.1/2" COTTERPIN		01	01	01	01
03E	0503010571	1/4" X 1.1/2 COTTERPIN		01	01	01	01
03F	0521010681	BUSHING COUPLING BODY		01	01	01	01
03G	0521010639	COUPLING SHAFT		01	01	01	01
03H	0503016482	BOLT		02	02	02	02
03I	0571012612	PIVOT SHAFT		01	01	01	01
03J	0503033731	COMPRESSION SPRING LEFT		02	02	02	02
03K	0503011331	3/8 BALL		02	02	02	02
04	0511053179	TRACTOR HITCH AXLE		01	01	01	01
04A	0521064036	TRACTOR HITCH AXLE		01	01	01	01

Item	Code	Description	See page	07	09	11	13
04B	0503030012	HAIR PIN		03	03	03	03
05	0502011530	SUPPORT		02	02	02	02
06	0502010175	HITCH CLAMP		02	02	02	02
07	0501011543	5/8" X 4" BOLT		04	04	04	04
08	0503010013	5/8" NUT		04	04	04	04
09	0511061835	PLOUGH SUPPORT		02	02	02	02
10	0501011075	PIN		02	02	02	02
11	0503060100	HAND BOOK COMPARTMENT		01	01	01	01
12	0503010358	5/16" X 5/8" BOLT		01	01	01	01
13	0503010179	SPRING WASHER		01	01	01	01
14	0503010337	5/16" NUT		01	01	01	01
15	0503010267	NYLON CLAMP		01	01	01	01
16	0511052332	SET SUPPORT RIGHT FIXER CHANGE		01	01	01	01
16A	0561019899	RIGHT SUPPORT FIXER RECAMBIO		01	01	01	01
16B	0521010718	5/8" U BOLT		02	02	02	02
16C	0501012140	FLAT WASHER		08	08	08	08
16D	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		04	04	04	04
17	0511052333	SET SUPPORT LEFT FIXER CHANGE		01	01	01	01
17A	0561019898	LEFT SUPPORT FIXER RECAMBIO		01	01	01	01
18	0521010549	COUPLING SHAFT		04	04	04	04
19	0511053356	SET LADDER		01	01	01	01
19A	0551017437	LADDER RIGHT FIXER		04	04	04	04
19B	0503010237	3/8" X 1" BOLT		08	08	08	08
19C	0503010025	3/8 SPRING WASHER		18	18	18	18
19D	0503010026	3/8" NUT		18	18	18	18
19E	0511069636	LADDER		02	02	02	02
19F	0501010096	3/8" X 2" BOLT		06	06	06	06
19G	0501010984	FLAT WASHER		22	22	22	22
19H	0503013357	3/8" SELF-ADJUSTING NUT		06	06	06	06
20	0511053388	JOINT HANDRAIL SET		00	00	01	00
20A	0511069660	HANDRAIL COP FLEX 600 11		00	00	02	00
20B	0521018290	RANDRAIL HOLDER		02	02	02	02
20C	0503010395	1/2" X 1-1/4" BOLT		04	04	04	04
20D	0503010019	1/2" SPRING WASHER		08	08	08	08
20E	0503010060	1/2" NUT		08	08	08	08
21	0551019115	LOCK		02	02	02	02
22	0521062324	PLATFORM LEFT PST4 11		00	00	01	00
23	0511069718	PLATFORM RIGHT PST4 11		00	00	01	00
24	0521061861	PLATFORM FIXER		02	02	02	02
25	0521062061	CENTRAL ARTICULACION		01	01	01	01
26	0521062062	CENTRAL ARTICULACION		01	01	01	01
27	0503010849	3/8" X 1-1/2" BOLT		08	08	08	08
28	0521061676	PLATFORM PROLONG		02	02	02	02
29	0511069664	PLATFORM EXTENSION LOCK		02	02	02	02
30	0503010257	1/8" X 1" COTTERPIN		06	06	06	06
31	0502012740	PLATFORM RIGHT FIXER SUPPORT		01	01	01	01
32	0502012739	PLATFORM LEFT FIXER SUPPORT		01	01	01	01
33	0503010740	1/2" X 2" BOLT		04	04	04	04
34	0511050906	DRAWBAR TURNBUCKLE		01	01	01	01
34A	0501069529	653 TURNBUCKLE		01	01	01	01
34B	0521062278	RIGHT TURNBUCKLE		01	01	01	01
34C	0511062888	LH TURNBUCKLE		01	01	01	01
34D	0501061056	RH LOCKNUT WITH HANDLER		01	01	01	01
35	0502012702	BODY SUPPORT CLAMP		01	01	01	01
36	0531011180	UPPER BODY CLIP		01	01	01	01
37	0503012555	7/16" X 2" BOLT		01	01	01	01
38	0503010180	7/16" SPRING WASHER		01	01	01	01
39	0541011767	HOSE FIXATION		01	01	01	01
40	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01	01	01	01


Item	Code	Description	See page	07	09	11	13
41	0503011333	COVER FIXER		02	02	02	02
42	0503010274	5/32"X 2" COTTERPIN		02	02	02	02
43	0521061931	FRAME 7		01	00	00	00
44	0521061932	FRAME 9		00	01	00	00
45	0521061933	FRAME 13		00	00	00	01
46	0511053436	DRAWBAR ASSY		01	01	00	00
47	0511053289	DRAWBAR		00	00	00	01
47A	0511062824	DRAWBAR		00	00	00	01
48	0503010027	SPRING WASHER		04	04	04	04
49	0511053668	JOINT HANDRAIL SET		01	00	00	00
49A	0511069635	HANDRAIL		02	00	00	00
50	0511053431	JOINT HANDRAIL SET		00	01	00	00
50A	0511069656	HANDRAIL COP FLEX 600 9		00	02	00	00
51	0511053339	PLATFORM SET		00	00	00	01
51A	0521061171	HANDRAIL COP FLEX 600 13		00	00	00	02
52	0511069725	RIGHT PLATFORM		01	00	00	00
53	0521062318	LEFT PLATFORM		01	00	00	00
54	0511069665	PLATFORM RIGHT PST4 9		00	01	00	00
55	0521062323	PLATFORM LEFT PST4 9		00	01	00	00
56	0521062091	PLATFORM LEFT COP FLEX 13		00	00	00	01
57	0521062092	PLATFORM RIGHT COP FLEX 13		00	00	00	01
58	0503010523	1/4" X 2" COTTERPIN		04	04	04	04
59	0501012803	FLAT WASHER		01	01	01	01
60	0511050906	DRAWBAR TURNBUCKLE		01	01	01	01
61	0521018532	1.4" X 12" COUPLING SHAFT		01	01	01	01
62	0521010578	COUPLING SHAFT		01	01	01	01
63	0503030085	LOCK PIN		02	02	02	02



Item	Code	Description	See page	15	17	19
01	0521061934	FRAME COP FLEX 15		01	00	00
02	0511050644	DRAWBAR ASSY		01	01	01
02A	0521062074	DRAWBAR		01	01	01
02B	0501069632	TRACTOR HITCH		01	01	01
02C	0521010681	BUSHING COUPLING BODY		01	01	01
02D	0521010639	COUPLING SHAFT		01	01	01
02E	0503010571	1/4" X 1.1/2 COTTERPIN		01	01	01
02F	0503010002	1800 GREASE FITTING		07	07	07
02G	0511043137	TOOLS BOX ASSY		02	02	02
02Ga	0511065471	BOX OF TOOLS		02	02	02
02Gb	0503010293	BAQUELITE MANIPULACION		02	02	02
02Gc	0503011334	3/8" X 3/4" BOLT		02	02	02
02Gd	0503010025	3/8 SPRING WASHER		02	02	02
02Ge	0503030012	HAIR PIN		04	04	04
03	0501047881	COUPLING SHAFT		01	01	01
03A	0501068989	COUPLING SHAFT		01	01	01
03B	0503031035	HAIR PIN		01	01	01
04	0521061935	FRAME COP FLEX 17		00	01	00
05	0521061936	FRAME COP FLEX 19		00	00	01
06	0502011530	SUPPORT		02	02	02
07	0501011543	5/8" X 4" BOLT		04	04	04
08	0501012140	FLAT WASHER		04	04	04
09	0503010027	SPRING WASHER		04	04	04
10	0503010013	5/8" NUT		04	04	04
11	0511061835	PLOUGH SUPPORT		02	02	02
12	0501011075	PIN		02	02	02
13	0502010175	HITCH CLAMP		02	02	02
14	0503060100	HAND BOOK COMPARTMENT		01	01	01
15	0503010358	5/16" X 5/8" BOLT		01	01	01
16	0503010179	SPRING WASHER		01	01	01
17	0503010337	5/16" NUT		01	01	01

Item	Code	Description	See page	15	17	19
18	0503010267	NYLON CLAMP		01	01	01
19	0511052332	SET SUPPORT RIGHT FIXER CHANGE		01	01	01
19A	0561019899	RIGHT SUPPORT FIXER RECAMBIO		01	01	01
19B	0521010718	5/8" U BOLT		02	02	02
19C	0501012140	FLAT WASHER		04	04	04
19D	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		04	04	04
20	0511052333	SET SUPPORT LEFT FIXER CHANGE		01	01	01
20A	0561019898	LEFT SUPPORT FIXER RECAMBIO		01	01	01
21	0511053085	SET FIXER HEADER		01	00	00
21A	0502012329	DRAWBAR FIXATION REAR SUPPORT		04	06	06
21B	0502012330	SUPPORT FIXER PIVOT		04	06	06
21C	0503011084	3/4" X 5" BOLT		08	12	12
21D	0501010322	FLAT WASHER		08	12	12
21E	0503010023	SPRING WASHER		16	24	24
21F	0503010014	3/4" NUT		16	24	24
21G	0511065418	DRAWBAR SUPPORT FRONT FIXATION		04	06	06
21H	0561014393	COUPLING SHAFT		04	06	06
21I	0503010523	1/4" X 2" COTTERPIN		04	06	06
21J	0501012916	FLAT WASHER 38,50 X 66 X 4,75 ZN		08	12	12
21K	0503030119	LOCK PIN		04	12	12
21L	0511065419	DRAWBAR FIXER CLAMP		04	06	06
21M	0501010066	3/4" X 9" BOLT		08	12	12
22	0511053482	SET FIXER HEADER		00	01	01
23	0561019087	DRAWBAR TRANSPORT LOCK		01	01	01
24	0501054605	DRAWBAR TURNBUCKLE		01	01	01
24A	0502011237	ESTABILIZER BODY		01	01	01
24B	0511061878	RH SCREW ARBOR		01	01	01
24C	0511064650	LH SCREW ARBOR		01	01	01
24D	0511061880	SIDE RIGHT RATCHET		01	01	01
24E	0531010264	SIDE RATCHET		01	01	01
24F	0511061881	RATCHET FOLLOWER		01	01	01
24G	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03	03	03
24H	0503011179	3/8" X 2-1/4" BOLT		05	05	05
25	0501054428	DRAWBAR TURNBUCKLE		02	02	02
25A	0501067353	508 PST3 TURNBUCKLE		02	02	02
25B	0511060558	RIGHT TURNBUCKLE		02	02	02
25C	0511060559	LEFT TURNBUCKLE		02	02	02
25D	0501061056	RH LOCKNUT WITH HANDLER		04	04	04
26	0541011767	HOSE FIXATION		01	01	01
27	0521018532	1.4" X 12" COUPLING SHAFT		01	01	01
28	0503030085	LOCK PIN		08	08	08
29	0521018531	1.4" X 4.5" COUPLING SHAFT		01	01	01
30	0521010573	0.9" X 3.1" COUPLING SHAFT		04	04	04
31	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02	02	02
32	0503010025	3/8 SPRING WASHER		02	02	02
33	0503010026	3/8" NUT		02	02	02
34	0502012702	BODY SUPPORT CLAMP		02	02	02
35	0531011180	UPPER BODY CLIP		02	02	02
36	0503012555	7/16" X 2" BOLT		02	02	02
37	0503010180	7/16" SPRING WASHER		02	02	02
38	0501012803	FLAT WASHER		02	02	02
39	0511053453	PLATFORM SET		01	00	00
39A	0521061861	PLATFORM FIXER		02	02	02
39B	0521062061	CENTRAL ARTICULACION		01	01	01
39C	0521062062	CENTRAL ARTICULACION		01	01	01
39D	0503010849	3/8" X 1-1/2" BOLT		08	08	08
39E	0501010984	FLAT WASHER		22	22	22
39F	0503010025	3/8 SPRING WASHER		21	21	21
39G	0503010026	3/8" NUT		21	21	21


Item	Code	Description	See page	15	17	19
39H	0521062059	LEFT PLATFORM COP FLEX 15		01	00	00
39I	0521062058	RIGHT PLATFORM COP FLEX 15		01	00	00
39J	0503010300	5/32" X 1" COTTERPIN		04	04	04
39K	0521010549	COUPLING SHAFT		04	04	04
39L	0503011333	COVER FIXER		02	02	02
39M	0503010274	5/32"X 2" COTTERPIN		02	02	02
39N	0551019115	LOCK		02	02	02
39O	0501010096	3/8" X 2" BOLT		06	06	06
39P	0503013357	3/8" SELF-ADJUSTING NUT		06	06	06
39Q	0521061676	PLATFORM PROLONG		02	02	02
39R	0511069664	PLATFORM EXTENSION LOCK		02	02	02
39S	0503010257	1/8" X 1" COTTERPIN		02	02	02
39T	0502012740	PLATFORM RIGHT FIXER SUPPORT		01	01	01
39U	0502012739	PLATFORM LEFT FIXER SUPPORT		01	01	01
39V	0503010740	1/2" X 2" BOLT		04	04	04
39W	0503010019	1/2" SPRING WASHER		12	12	12
39X	0503010060	1/2" NUT		12	12	12
40	0511053477	PLATFORM SET		00	01	00
40A	0521062089	LEFT PLATFORM COP FLEX 17		00	01	00
40B	0521062087	RIGHT PLATFORM		00	01	00
41	0511053496	PLATFORM SET		00	00	01
41A	0521062090	LEFT PLATFORM COP FLEX 19		00	00	01
41B	0521062088	RIGHT PLATFORM		00	00	01
42	0511053356	SET LADDER		01	01	01
42A	0551017437	LADDER RIGHT FIXER		04	04	04
42B	0503010237	3/8" X 1" BOLT		08	08	08
42C	0511069636	LADDER		02	02	02
43	0511053454	JOINT HANDRAILSET		01	00	00
43A	0521064080	CENTRAL CHAIN		02	02	02
43B	0521064101	SIDE CHAIN (1850)		02	00	00
43C	0521018290	RANDRAIL HOLDER		06	06	06
43D	0503010395	1/2" X 1-1/4" BOLT		04	04	04
44	0511053476	JOINT HANDRAIL SET		00	01	00
44A	0521064079	SIDE HANDRAIL		00	02	00
44B	0503010734	1/2" X 2-1/2" BOLT		04	04	04
45	0511053495	JOINT HANDRAIL SET		00	00	01
45A	0521064100	SIDE CHAIN (2750)		00	00	02



Item	Code	Description	See page	DIR ESQ
01	0521063678	WHEEL SUPPORT	01	01
02	0501048672	CHAIN TENSIONER ASSY	02	02
02A	0531017202	AXLE CHAIN TIGHTENER	02	02
02B	0503030402	PULLEY	02	02
02C	0503010302	501019 SEAL RING	02	02
02D	0503010019	1/2" SPRING WASHER	20	20
02E	0503010060	1/2" NUT	02	02
02F	0511017302	FLAT WASHER	04	04
02G	0503010004	1890 GREASE FITTING	04	04
03	0511064744	WHEEL FORK	01	00
04	0511065842	LEFT WHEEL FORK	00	01
05	0501110625	WHEEL PIVOT BEARING	02	02
06	0503013232	1/2" UNF X 1" BOLT	08	08
07	0503010026	3/8" NUT	02	02
08	0561013021	BEARING INNER LOK	02	02
09	0561013022	BEARING EXTERNAL LOCK	02	02
10	0503010398	501082 CLAMPING RING (FOR AXLE)	02	02
11	0561013020	KM 12 NUT	02	02
12	0511052768	REQUIRES TIRE	01	01
12A	0511052766	CARRYING WHEEL HUB ASSY	01	01
12Aa	0571012990	CARRYING WHEEL HUB TRANSMISSION	01	01
12Ab	0503010328	25590/25523 ROLLER BEARING	02	02
12Ac	0503010804	00547-B SEAL	02	02
12Ad	0521018363	00547-B SEAL	01	01
12Ae	0511062015	14Z GEAR WITH FLANGE	01	01
12Af	0501010186	PARAFUSO ROD 5/8UNF X 2.1/8CR	06	06
12Ag	0503016516	5/8 UNF CONIC NUT	06	06
12Ah	0503010421	5/16" X 1-1/2" BOLT	06	06
12Ai	0503011444	SPRING WASHER	06	06
12Aj	0511015949	LOCK NUT	01	01
12Ak	0503010329	LOCK WASHER	01	01


Item	Code	Description	See page	DIR ESQ
12Al	0503010330	KM 9 LOCKNUT		01 01
12Am	0503010002	1800 GREASE FITTING		01 01
12B	0503062158	REQUIRES TIRE		01 01
12Ba	0503012113	PLY TIRE		01 01
12Bb	0503016518	RUEDA		01 01
12Bc	0503012114	7.00 X 16 INNER TIRE		01 01
13	0521012190	AXLE LOCK		02 02
14	0503010027	SPRING WASHER		02 02
15	0503011188	M16 X 2 X 50 BOLT		02 02
16	0511061808	15Z GEAR WITH AXLE,		01 01
17	0511061809	15Z GEAR WITH COUPLING		01 01
18	0503011103	7/16" X 2-1/2" BOLT		01 01
19	0503010180	7/16" SPRING WASHER		01 01
20	0503010244	7/16" NUT		01 01
21	0501010984	FLAT WASHER		02 02
22	0531018654	CHAIN TIGHTENER SUPPORT		01 00
23	0531018653	CHAIN TIGHTENER MINOR SUPPORT		01 01
24	0541012098	LEFT CHAIN TIGHTENER LARGER SUPPOT		00 01
25	0511014513	1" X 0.6" X 0.4" ARTICULAT SLEEVE		02 02
26	0531016916	SLEEVE BEARING SUPPORT		02 02
27	0503010899	5/8" X 2-1/4" BOLT		01 01
28	0503010027	SPRING WASHER		01 01
29	0503010013	5/8" NUT		03 03
30	0501013491	5/8" TENSIONER SPRING		01 01
31	0501010096	3/8" X 2" BOLT		01 01
32	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01 01
33	0501053522	WHEEL CHAIN TENSIONER		01 01
33A	0551018252	CHAIN TIGHTENER AXLE		01 01
33B	0502012018	CHAIN TIGHTENER BEARING		01 01
33C	0503012882	BALL BEARING		01 01
33D	0503011945	503050 CLAMPING RING (FOR AXLE)		01 01
33E	0511017302	FLAT WASHER		01 01
33F	0503010060	1/2" NUT		04 04
34	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01 01
35	0501018466	FLAT WASHER		02 02
36	0531016051	CARRY-WHEEL CHAIN PROTECTION CAP		01 00
37	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		00 01
38	0503010847	1/2" X 3.1/4" BOLT		02 02
39	0561016797	SLEEVE UNION LEVER ARM/DESARM		01 01
40	0502010584	CARRYING-WHEELS SUPPORT FIXER		02 02
41	0501010452	5/8" X 5" BOLT		04 04
42	0501012140	FLAT WASHER		08 08
43	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		08 08
44	0511053375	CHAIN DEVIATION		01 01
44A	0551018252	CHAIN TIGHTENER AXLE		01 01
44B	0521010479	SLEEVE ARTICULATION		01 01
44C	0501058239	CHAIN TENSIONER BEARING		01 01
44Ca	0502012018	CHAIN TIGHTENER BEARING		01 01
44Cb	0503012882	BALL BEARING		01 01
44Cc	0503011945	503050 CLAMPING RING (FOR AXLE)		01 01
44D	0503011336	1/2" HEX SELF ADJUSTING NUT		01 01
45	0511066351	FLANGE CYLINDER HYDRAULIC FIXER		02 02
46	0503010834	1/2 X 1 BOLT		04 04
47	0511043969	44,45 X 101,6 HYDRAULIC CYLINDER	5	01 01
48	0521010546	1.2" X 5.7" COUPLING SHAFT		01 01
49	0501017779	FLAT WASHER		02 02
50	0503010523	1/4" X 2" COTTERPIN		01 01
51	0521013022	TRANSPORT LOCK		01 01
52	0501047885	ROD STOP		01 01

Item	Code	Description	See page	DIR ESQ
53	0501047886	ROD STOP		01 01
54	0501047887	ROD STOP		01 01
55	0501068994	0.3" X 3.1" LOCK PIN		01 01
56	0503030168	HAIR PIN		01 01
57	0561017269	MOTOR AXLE BEARING SUPPORT		01 01
58	0503011082	C1/2" X 1.3/4" BOLT		02 02
59	0511017302	FLAT WASHER		04 04
60	0503011082	C1/2" X 1.3/4" BOLT		01 01
61	0511017302	FLAT WASHER		02 02
62	0501110639	AGRIC BEARING		02 02
63	0503010300	5/32" X 1" COTTERPIN		02 02
64	0503011099	GREASE FITTING		02 02
65	0561016876	MOTOR SHAFT		01 01
66	0571012792	LOWER LEVER		01 01
67	0511015961	LOCK BUSHING		01 01
68	0503030679	1/2" X 1-1/4" BOLT		01 01
69	0503030679	1/2" X 1-1/4" BOLT		01 01
70	0511051434	TRANSMISSION DRIVING ASSY	6	01 01
71	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01 01
72	0502012720	FIXER THE RODEIRO SUPPORT		01 01
73	0501011543	5/8" X 4" BOLT		04 04
74	0503010179	SPRING WASHER		02 02
75	0503010337	5/16" NUT		02 02
76	0511014218	3/4" X 28.7" SQUARE SHAFT		01 01
77	0521010691	AXLE FASTENER		02 02
78	0503010373	1/4" X 2" BOLT		02 02
79	0511017303	FLAT WASHER		02 02
80	0503010143	SPRING WASHER		02 02
81	0503010144	1/4" NUT		02 02
82	0503030303	SUPPORT WASHER		02 02
83	0501056444	BEARING WITH BALL BEARING		01 01
83A	0502011697	BEARING OF THE GEAR BOX		01 01
83B	0503013462	BEARING WITH BALL BEARING		01 01
83C	0503011105	SEAL RING		01 01
84	0503011953	5/16" X 1" BOLT		02 02
85	0501010694	FLAT WASHER		02 02
86	0521061847	AXLE ADRIVING ASSY		01 01
87	0503010780	N-2050 AMENDMENT		03 03




Item	Code	Description	See page	DIR ESQ
01	0521063678	WHEEL SUPPORT	01	01
02	0511064744	WHEEL FORK	01	00
03	0511065842	LEFT WHEEL FORK	00	01
04	0501110625	WHEEL PIVOT BEARING	02	02
05	0503013232	1/2" UNF X 1" BOLT	08	08
06	0503010019	1/2" SPRING WASHER	12	12
07	0561013021	BEARING INNER LOK	02	02
08	0561013022	BEARING EXTERNAL LOCK	02	02
09	0503010398	501082 CLAMPING RING (FOR AXLE)	02	02
10	0561013020	KM 12 NUT	02	02
11	0511052768	REQUIRES TIRE	01	01
11A	0511052766	CARRYING WHEEL HUB ASSY	01	01
11Aa	0571012990	CARRYING WHEEL HUB TRANSMISSION	01	01
11Ab	0503010328	25590/25523 ROLLER BEARING	02	02
11Ac	0503010804	00547-B SEAL	02	02
11Ad	0521018363	00547-B SEAL	01	01
11Ae	0511062015	14Z GEAR WITH FLANGE	01	01
11Af	0501010186	PARAFUSO ROD 5/8UNF X 2.1/8CR	06	06
11Ag	0503016516	5/8 UNF CONIC NUT	06	06
11Ah	0503010421	5/16" X 1-1/2" BOLT	06	06
11Ai	0503011444	SPRING WASHER	06	06
11Aj	0511015949	LOCK NUT	01	01
11Ak	0503010329	LOCK WASHER	01	01
11Al	0503010330	KM 9 LOCKNUT	01	01
11Am	0503010002	1800 GREASE FITTING	01	01
11B	0503062158	REQUIRES TIRE	01	01
11Ba	0503012113	PLY TIRE	01	01
11Bb	0503016518	RUEDA	01	01
11Bc	0503012114	7.00 X 16 INNER TIRE	01	01
12	0521012190	AXLE LOCK	02	02
13	0503010027	SPRING WASHER	02	02


Item	Code	Description	See page	DIR ESQ
14	0503011188	M16 X 2 X 50 BOLT		02 02
15	0502010584	CARRYING-WHEELS SUPPORT FIXER		02 02
16	0501010452	5/8" X 5" BOLT		04 04
17	0501012140	FLAT WASHER		08 08
18	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		08 08
19	0502012720	FIXER THE RODEIRO SUPPORT		01 01
20	0501011543	5/8" X 4" BOLT		04 04
21	0511043969	44,45 X 101,6 HYDRAULIC CYLINDER	5	01 01
22	0511066351	FLANGE CYLINDER HYDRAULIC FIXER		02 02
23	0503010834	1/2 X 1 BOLT		04 04
24	0521010546	1.2" X 5.7" COUPLING SHAFT		01 01
25	0501017779	FLAT WASHER		02 02
26	0503010523	1/4" X 2" COTTERPIN		01 01
27	0521013022	TRANSPORT LOCK		01 01
28	0501068994	0.3" X 3.1" LOCK PIN		01 01
29	0503030168	HAIR PIN		01 01
30	0501047885	ROD STOP		01 01
31	0501047886	ROD STOP		01 01
32	0501047887	ROD STOP		01 01




Item	Code	Description	See page
01	0511043969	44,45 X 101,6 HYDRAULIC CYLINDER	5
01A	0511066774	2.5" X 28" CYLINDER CASE	
02	0503030385	CYLINDER PLUG N-002	
03	0541017674	TURNBUCLE BODY	
04	0503011094	3/8" X 2" BOLT C C S I 12.9	
05	0503010025	3/8 SPRING WASHER	
06	0503010026	3/8" NUT	
07	0503010043	PACKING 3750-3250	
08	0503010994	W2-4000-500 PK RING G.E	
09	0503010761	D-1750 SCRAPER RING	
10	0503010990	GASKET	
11	0503011061	8-342 BACK-UP RING	
12	0503010338	2-342 N 3006-9B O'RING	
13	0503010949	W2-2000-500 PK RING G.E	
14	0503010345	2-218 N 3006-9B O'RING	
15	0502010841	RING OF SUPPORT	
16	0502010793	1.7" X 4" PISTON	
17	0503010817	1-1/4" SELF-ADJUSTING NUT	
18	0502010017	4" HEAD	
19	0511064408	FORK COP	



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	1/2"X1-1/2"BOLT		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page
01	0571010596	SUPPORT VALVE 50/50	01
02	0503010371	5/16" X 1" BOLT	02
03	0501010694	FLAT WASHER	02
04	0503010179	SPRING WASHER	02
05	0503010337	5/16" NUT	02
06	0503013791	DOUBLE MOTOR	01
07	0541018940	7/8 NF X R 1 BSPT X 55 NIPPLE	01
08	0551012463	1/2" BSPT X 3/4" UNF X 51 NIPPLE	02
09	0503011968	T ADAPTOR WITH GIRAT	01
10	0561017277	OIL CONDUCTOR FIXER PLATE	02
11	0521010718	5/8" U BOLT	02
12	0501012140	FLAT WASHER	04
13	0503010027	SPRING WASHER	04
14	0503010013	5/8" NUT	04
15	0502012702	BODY SUPPORT CLAMP	02
16	0503010851	7/16" X 3.1/2" BOLT	02
17	0503010180	7/16" SPRING WASHER	02
18	0503010244	7/16" NUT	02
19	0511043969	44,45 X 101,6 HYDRAULIC CYLINDER	5 02
20	0501080644	3/8" X 78.7" TC-TC HOSE ASSY	01
21	0501080359	3/8" X 78.7" TR-TC HOSE ASSY	03
22	0501053834	MALE QUICK COUPLING AGRICULTURAL WITH COVER - 1/2 NPT	02
22A	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT	02
22B	0503011882	QUICK CONNECTION COVER	02
23	0501081073	1/2" X 4200 TC-TM HOSE	02
24	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT	01
25	0541012166	NIPPLE 3/4" UNF X 7/8"	01
26	0503015075	M10 SPRING WASHER	04
27	0501010984	FLAT WASHER	04
28	0503011051	M10 X 0.6" NUT	04




Item	Code	Description	See page	09 11
01	0571010596	SUPPORT VALVE 50/50	01 01	
02	0503010371	5/16" X 1" BOLT	02 02	
03	0501010694	FLAT WASHER	02 02	
04	0503010179	SPRING WASHER	02 02	
05	0503010337	5/16" NUT	02 02	
06	0503013791	DOUBLE MOTOR	01 01	
07	0541018940	7/8 NF X R 1 BSPT X 55 NIPPLE	01 01	
08	0551012463	1/2" BSPT X 3/4" UNF X 51 NIPPLE	02 02	
09	0503011968	T ADAPTOR WITH GIRAT	01 01	
10	0501068706	DOUBLE CONNECTION	02 02	
11	0501080760	3/8" X 500 TC-TC HOSE	04 04	
12	0501080436	TR-TC HOSE	00 02	
13	0501080714	3/8" X 63" TR-TC HOSE ASSY	02 02	
14	0501081073	1/2" X 4200 TC-TM HOSE	02 02	
15	0501080348	TR-TC HOSE ASSY	00 01	
16	0501080321	3/8" X 47" TR-TR HOSE ASSY	00 03	
17	0503010237	3/8" X 1" BOLT	04 04	
18	0501010984	FLAT WASHER	04 04	
19	0503010025	3/8 SPRING WASHER	04 04	
20	0503010026	3/8" NUT	04 04	
21	0561017277	OIL CONDUCTOR FIXER PLATE	04 04	
22	0521010718	5/8" U BOLT	04 04	
23	0501012140	FLAT WASHER	08 08	
24	0503010027	SPRING WASHER	08 08	
25	0503010013	5/8" NUT	08 08	
26	0541012166	NIPPLE 3/4" UNF X 7/8"	01 01	
27	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT	01 01	
28	0503015075	M10 SPRING WASHER	04 04	
29	0501010984	FLAT WASHER	04 04	
30	0503011051	M10 X 0.6" NUT	04 04	
31	0502012702	BODY SUPPORT CLAMP	02 02	

Item	Code	Description	See page	09 11
32	0503010851	7/16" X 3.1/2" BOLT		02 02
33	0503010180	7/16" SPRING WASHER		02 02
34	0503010244	7/16" NUT		02 02
35	0501053834	MALE QUICK COUPLING AGRICULTURAL WITH COVER - 1/2 NPT		02 02
35A	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT		02 02
35B	0503011882	QUICK CONNECTION COVER		02 02
36	0511043969	44,45 X 101,6 HYDRAULIC CYLINDER	5	04 04
37	0501080027	3/8" X 1000 TR-TR HOSE ASSY		03 00
38	0501080055	3/8" X 1000 TR-TC HOSE		01 00
39	0501080302	TR-TC HOSE ASSY		02 00




Item	Code	Description	See page	13	15
01	0571010596	SUPPORT VALVE 50/50	01	01	
02	0503010371	5/16" X 1" BOLT	02	02	
03	0501010694	FLAT WASHER	02	02	
04	0503010179	SPRING WASHER	02	02	
05	0503010337	5/16" NUT	02	02	
06	0503013791	DOUBLE MOTOR	01	01	
07	0541018940	7/8 NF X R 1 BSPT X 55 NIPPLE	01	01	
08	0551012463	1/2" BSPT X 3/4" UNF X 51 NIPPLE	02	02	
09	0503011968	T ADAPTOR WITH GIRAT	01	01	
10	0501068706	DOUBLE CONNECTION	04	04	
11	0501080760	3/8" X 500 TC-TC HOSE	08	08	
12	0501080055	3/8" X 1000 TR-TC HOSE	02	00	
13	0501080381	3/8" X 1250 TR-TR HOSE ASSY	00	04	
14	0501081073	1/2" X 4200 TC-TM HOSE	02	02	
15	0503011103	7/16" X 2-1/2" BOLT	00	06	
16	0501080348	TR-TC HOSE ASSY	00	02	
17	0503010237	3/8" X 1" BOLT	06	06	
18	0501010984	FLAT WASHER	06	06	
19	0503010025	3/8 SPRING WASHER	06	06	
20	0503010026	3/8" NUT	06	06	
21	0561017277	OIL CONDUCTOR FIXER PLATE	04	06	
22	0521010718	5/8" U BOLT	04	06	
23	0501012140	FLAT WASHER	08	12	
24	0503010027	SPRING WASHER	08	12	
25	0503010013	5/8" NUT	08	12	
26	0541012166	NIPPLE 3/4" UNF X 7/8"	01	01	
27	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT	01	01	
28	0503015075	M10 SPRING WASHER	04	04	
29	0501010984	FLAT WASHER	04	04	
30	0503011051	M10 X 0.6" NUT	04	04	
31	0502012702	BODY SUPPORT CLAMP	02	10	

Item	Code	Description	See page	13	15
32	0503010851	7/16" X 3.1/2" BOLT		02	02
33	0503010180	7/16" SPRING WASHER		02	08
34	0503010244	7/16" NUT		06	08
35	0501053834	MALE QUICK COUPLING AGRICULTURAL WITH COVER - 1/2 NPT		02	02
35A	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT		02	02
36	0511043969	44,45 X 101,6 HYDRAULIC CYLINDER	5	06	06
37	0501080352	3/8" X 1400 TR-TR HOSE ASSY		03	03
38	0501080025	TR-TC HOSE ASSY		01	01
39	0501080302	TR-TC HOSE ASSY		00	02
40	0501080124	3/8" X 35.4" TR-TC HOSE ASSY		02	00
41	0501080321	3/8" X 47" TR-TR HOSE ASSY		04	00



Item	Code	Description	See page	17	19
01	0571010596	SUPPORT VALVE 50/50		01	01
02	0503010371	5/16" X 1" BOLT		02	02
03	0501010694	FLAT WASHER		02	02
04	0503010179	SPRING WASHER		02	02
05	0503010337	5/16" NUT		02	02
06	0503013791	DOUBLE MOTOR		01	01
07	0541018940	7/8 NF X R 1 BSPT X 55 NIPPLE		01	01
08	0551012463	1/2" BSPT X 3/4" UNF X 51 NIPPLE		02	02
09	0503011968	T ADAPTOR WITH GIRAT		01	01
10	0501068706	DOUBLE CONNECTION		04	06
11	0503015075	M10 SPRING WASHER		04	04
12	0501010984	FLAT WASHER		04	04
13	0503011051	M10 X 0.6" NUT		04	04
14	0541012166	NIPPLE 3/4" UNF X 7/8"		01	01
15	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01	01
16	0561017277	OIL CONDUCTOR FIXER PLATE		08	08
17	0521010718	5/8" U BOLT		08	08
18	0501012140	FLAT WASHER		16	16
19	0503010027	SPRING WASHER		16	16
20	0503010013	5/8" NUT		16	16
21	0503010237	3/8" X 1" BOLT		04	06
22	0501010984	FLAT WASHER		04	06
23	0503010025	3/8 SPRING WASHER		04	06
24	0503010026	3/8" NUT		04	06
25	0502012702	BODY SUPPORT CLAMP		06	06
26	0503011103	7/16" X 2-1/2" BOLT		06	06
27	0503010180	7/16" SPRING WASHER		06	06
28	0503010244	7/16" NUT		06	06
29	0511043969	44,45 X 101,6 HYDRAULIC CYLINDER	5	08	08
30	0501081073	1/2" X 4200 TC-TM HOSE		02	02
31	0501080104	3/8 X 900 TR-TR HOSE		08	08


Item	Code	Description	See page	17	19
32	0501080321	3/8" X 47" TR-TR HOSE ASSY		03	03
33	0501080348	TR-TC HOSE ASSY		01	01
34	0501080302	TR-TC HOSE ASSY		02	02
35	0501080714	3/8" X 63" TR-TC HOSE ASSY		02	02
36	0501080760	3/8" X 500 TC-TC HOSE		12	12




Item	Code	Description	See page	07	09	11	13	15	17	19
01	0561016876	MOTOR SHAFT		00	00	02	00	00	00	00
02	0511047069	SIDE TRANSMISSION DRIVING		01	01	01	01	01	01	01
03	0511047070	LH SIDE TRANSMISSION DRIVING		01	01	01	01	01	01	01
04	0501110639	AGRIC BEARING		02	02	02	02	02	02	02
05	0503010300	5/32" X 1" COTTERPIN		02	02	02	02	02	02	02
06	0503011099	GREASE FITTING		02	02	02	02	02	02	02
07	0511014218	3/4" X 28.7" SQUARE SHAFT		02	02	02	02	02	02	02
08	0521061852	LEVER RATCHET		02	02	02	02	02	02	02
09	0521061846	CARRYING-WHEELS SUPPORT		02	02	02	02	02	02	02
10	0503010140	1/8" X 3/4" COTTERPIN		08	08	08	08	08	08	08
11	0501056271	GEAR BOX CLOSE BEARINGONE		02	02	02	02	02	02	02
11A	0502012310	GEAR BOX CLOSE BEARING		02	02	02	02	02	02	02
11B	0503013462	BEARING WITH BALL BEARING		02	02	02	02	02	02	02
11C	0503011105	SEAL RING		02	02	02	02	02	02	02
12	0501058236	BEARING WITH 21Z GEAR		02	02	02	02	02	02	02
12A	0511062169	21Z P 1/2" GEAR		08	08	08	08	08	08	08
12B	0503011410	ROLLER BEARING		14	14	14	14	14	14	14
12C	0503011105	SEAL RING		10	10	10	10	10	10	10
12D	0551019171	CHAIN TIGHTENER AXLE		02	02	02	02	02	02	02
12E	0503010406	501025 CLAMPING RING (FOR AXLE)		12	12	12	12	12	12	12
12F	0501010163	5/8" X 4-1/2" BOLT		02	02	02	02	02	02	02
12G	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		02	02	02	02	02	02	02
13	0501058265	LOWER CHAIN TENSIONER ASSY		02	02	02	02	02	02	02
13A	0531017086	50 AXLETIGHTENER		02	02	02	02	02	02	02
13B	0501010197	5/8" X 3-1/2" BOLT		02	02	02	02	02	02	02
13C	0501012140	FLAT WASHER		02	02	02	02	02	02	02
13D	0503010027	SPRING WASHER		02	02	02	02	02	02	02
13E	0503010013	5/8" NUT		02	02	02	02	02	02	02
14	0561018212	ARTICULAT SLEEVE		02	02	02	02	02	02	02
15	0503010547	1/2" X 4" BOLT		02	02	02	02	02	02	02
16	0511017302	FLAT WASHER		02	02	02	02	02	02	02

Item	Code	Description	See page	07	09	11	13	15	17	19
17	0503010019	1/2" SPRING WASHER		02	02	02	02	02	02	02
18	0503010060	1/2" NUT		02	02	02	02	02	02	02
19	0561017281	ARTICULACION ARM		02	02	02	02	02	02	02
20	0511050385	BEARING WITH		02	02	02	02	02	02	02
20A	0521061843	20Z DOBLE GEAR		02	02	02	02	02	02	02
20B	0551019175	DOUBLE GEAR AXLE		02	02	02	02	02	02	02
20C	0501010163	5/8" X 4-1/2" BOLT		02	02	02	02	02	02	02
20D	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		06	06	06	06	06	06	06
21	0511050127	CHAIN TENSIONER SUPPORT		02	02	02	02	02	02	02
21A	0561015677	CHAIN TIGHTENER AXLE		02	02	02	02	02	02	02
21B	0501010452	5/8" X 5" BOLT		02	02	02	02	02	02	02
21C	0501012140	FLAT WASHER		04	04	04	04	04	04	04
22	0501053126	FERTILIZER CHAIN TENSIONER ASSY		02	02	02	02	02	02	02
22A	0501011541	5/8" X 3" BOLT		02	02	02	02	02	02	02
22B	0521018415	TIGHTENER AXLE		02	02	02	02	02	02	02
23	0561017275	LEVER FIXER		02	02	02	02	02	02	02
24	0503010237	3/8" X 1" BOLT		06	06	06	06	06	06	06
25	0503010025	3/8 SPRING WASHER		06	06	06	06	06	06	06
26	0503010026	3/8" NUT		06	06	06	06	06	06	06
27	0561017280	LH LEVER DISASSEMBLE (COP 11)		01	01	01	01	01	01	01
28	0561017279	RH LEVER DISASSEMBLE (COP 11)		01	01	01	01	01	01	01
29	0503030093	TRACTION SPRING		02	02	02	02	02	02	02
30	0561017273	FIXER SPRING		02	02	02	02	02	02	02
31	0561017282	LOWER LEVER		02	02	02	02	02	02	02
32	0561016797	SLEEVE UNION LEVER ARM/DESARM		02	02	02	02	02	02	02
33	0503011082	C1/2" X 1.3/4" BOLT		02	02	02	02	02	02	02
34	0511017302	FLAT WASHER		04	04	04	04	04	04	04
35	0503010019	1/2" SPRING WASHER		04	04	04	04	04	04	04
36	0503010060	1/2" NUT		04	04	04	04	04	04	04
37	0521010773	0.37" X 1.18" COUPLING SHAFT		04	04	04	04	04	04	04
38	0501010984	FLAT WASHER		04	04	04	04	04	04	04
39	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		02	02	02	02	02	02	02
40	0503012717	40-1 CHAIN X 101 LINK + MENDING		02	02	02	02	02	02	02
41	0503016737	40-1 X 114 CHAIN LINK + REDUCION		02	02	02	02	02	02	02
42	0503011721	40-1 CHAIN X 122 LINK + REDUCTION		02	02	02	02	02	02	02
43	0511053366	CHAIN TENSIONER		02	02	02	02	02	02	02
43A	0531019479	AXLE CHAIN GEAR		02	02	02	02	02	02	02
43B	0503031805	11Z 1/2" GEAR		02	02	02	02	02	02	02
43C	0503010302	501019 SEAL RING		02	02	02	02	02	02	02
43D	0511017302	FLAT WASHER		04	04	04	04	04	04	04
44	0501053608	BEARING ASSY WITH GEAR 20Z & 5/8" HEX AXLE		02	02	02	02	02	02	02
44A	0501053609	5/8 DOUB BEARING OF THE SEED TRANSM		02	02	02	02	02	02	02
44Aa	0502011987	DOUBLE HOUSING BEARING		02	02	02	02	02	02	02
44B	0511063106	20Z AXLE BEARING DOBLE		02	02	02	02	02	02	02
44C	0503010365	NUT		04	04	04	04	04	04	04
45	0531016944	RIGHT 5/8" X 96" HEX AXLE		00	00	01	00	00	00	00
46	0531016945	LEFT 5/8" X 90" HEX AXLE		00	00	01	00	00	00	00
47	0511063123	BUSHING WITH NUT		04	04	04	04	04	04	04
48	0503010834	1/2 X 1 BOLT		04	04	04	04	04	04	04
49	0503030679	1/2" X 1-1/4" BOLT		04	04	04	04	04	04	04
50	0511048939	RIGHT GEAR BOX ASSY		01	01	01	01	01	01	01
51	0511048940	LEFT GEAR BOX ASSY		01	01	01	01	01	01	01
52	0503011953	5/16" X 1" BOLT		04	04	04	04	04	04	04
53	0501010694	FLAT WASHER		12	12	12	12	12	12	12
54	0503010179	SPRING WASHER		08	08	08	08	08	08	08
55	0503010337	5/16" NUT		08	08	08	08	08	08	08
56	0561014215	BEARING COVER LOWER ROW FRAME		02	02	02	02	02	02	02
57	0503011751	REDUCTION		06	06	06	06	06	06	06
58	0503011750	AMENDMENT WITH LOCK		06	06	06	06	06	06	06

Item	Code	Description	See page	07	09	11	13	15	17	19
59	0561016882	1535 MOTOR SHAFT		02						
60	0561016881	MOTOR SHAFT		00	02	00	00	02	02	02
61	0561016795	2775 MOTOR SHAFT		00	00	00	02	00	00	00
62	0521013432	5/8" X 59" AXLE HEX		01						
63	0521013428	HEX AXLE		01						
64	0531016942	5/8 X 2050 HEX AXLE		01						
65	0531016943	5/8" X 75" AXLE HEX		01						
66	0531016946	5/8" X 114" AXLE HEX				01				
67	0531016947	LEFT 5/8" X 108" AXLE HEX				01				
68	0531016948	RIGHT 5/8" X 131" AXLE HEX					01			
69	0531016949	LEFT 5/8" X 125" AXLE HEX					01			
70	0541012845	5/8" X 3800 AXLE HEX						01		
71	0541012846	5/8" X 3650 AXLE HEX						01		
72	0561018617	5/8" X 4250 AXLE HEX							01	
73	0561018616	5/8" X 4100 AXLE HEX							01	




Item	Code	Description	See page	DR	ES
00	0511047069	SIDE TRANSMISSION DRIVING		01	00
00A	0511047070	LH SIDE TRANSMISSION DRIVING		00	01
01	0502011996	SLLEVE FIXER		01	01
02	0503030678	1/2"X1-1/2"BOLT		01	01
03	0503010060	1/2" NUT		01	01
04	0521017590	GUIDE AXLE		01	01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01	01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01	00
07	0502011995	LH DRIVING AXLE FOLLOWER		00	01
08	0501019734	FLAT WASHER		02	02
09	0502010710	RIGHT CAM, SMALLER		02	00
10	0502010720	RIGHT CAM, SMALLER		00	02
11	0503010003	1845 GREASE FITTING		02	02
12	0502012539	26Z P12,7 GEAR		01	00
13	0502012540	26Z P12,7 GEAR		00	01
14	0501019735	FLAT WASHER		01	01
15	0521017593	FLAT WASHER		01	01
16	0503010542	501045 CLAMPING RING (FOR AXLE)		01	01




Item	Code	Description	See page
00	0511048939	RIGHT GEAR BOX ASSY	01 01
00A	0511048940	LEFT GEAR BOX ASSY	01 01
01	0501058212	RH GEAR	01 01
01A	0511069565	LEFT GEAR BOX	01 01
01B	0502011758	REAR TENSIONER LEVER	02 02
01C	0503010292	0.2" X 1.6" SPRING PIN	07 07
01D	0511061794	CHAIN TENSIONER	01 01
01E	0503031367	SPRING	01 01
01F	0511060392	CHAIN TENSIONER	01 01
01G	0503031366	RH TORSION SPRING	01 01
02	0501058213	LH GEAR BOX	01 01
02A	0511069566	LEFT GEAR BOX	01 01
03	0501056443	BEARING ASSY GEAR BOX	02 02
03A	0501056444	BEARING WITH BALL BEARING	01 01
03Aa	0502011697	BEARING OF THE GEAR BOX	01 01
03Ab	0503011105	SEAL RING	06 06
03Ac	0503013462	BEARING WITH BALL BEARING	01 01
04	0503011953	5/16" X 1" BOLT	14 14
05	0501010694	FLAT WASHER	14 14
06	0503010179	SPRING WASHER	14 14
07	0503010337	5/16" NUT	14 14
08	0501056447	CENTRAL BEARING GEAR BOX	01 01
08A	0502011978	HOUSING CENTRAL BEARING	01 01
08B	0503013462	BEARING WITH BALL BEARING	02 02
09	0503031805	11Z 1/2" GEAR	06 06
10	0503010302	501019 SEAL RING	04 04
11	0501048790	AXLE WITH LINK ASSY	02 02
11A	0521012476	GEAR BOX LEVER AXLE	02 02
11B	0503031369	LINK	02 02
12	0503010002	1800 GREASE FITTING	02 02
13	0551018209	DRIVING AXLE	01 01

Item	Code	Description	See page
14	0521018259	DRIVEN AXLE	01 01
15	0551018210	DRIVEN AXLE	01 01
16	0551018211	INTERM SHAFT	01 01
17	0503030303	SUPPORT WASHER	05 05
18	0501056271	GEAR BOX CLOSE BEARINGONE	05 05
18A	0502012310	GEAR BOX CLOSE BEARING	05 05
19	0511060396	DRIVE/DRIVEN AXLE CONE	04 04
20	0503012389	1/2 BALL	04 04
21	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING	04 04
22	0503010060	1/2" NUT	02 02
23	0503010395	1/2" X 1-1/4" BOLT	04 04
24	0511061822	25Z P0.5" GEAR SQUARE HOL	04 04
25	0511061830	17Z P 0.5" GEAR SQUARE HOL	02 02
26	0511067501	26Z GEAR	01 01
27	0503012204	40-1 CHAIN X 82 LINK + RED	02 02
28	0503012713	40-1 CHAIN X 45 LINK + MEN	01 01
29	0501054655	CHAIN TENSIONER ASSY	02 02
29A	0531019479	AXLE CHAIN GEAR	02 02
29B	0511017302	FLAT WASHER	02 02
29C	0503010019	1/2" SPRING WASHER	02 02
29D	0503031805	11Z 1/2" GEAR	01 01
30	0501010984	FLAT WASHER	01 01
31	0503010025	3/8 SPRING WASHER	01 01
32	0503010256	3/8" X 3/4" BOLT	01 01
33	0503030275	AGRICULTURAL BEARING	01 01
34	0521018630	1.4" X SQUARE 0.8" WASHER	01 01
35	0511061759	22Z P12,70 FQ 3/4" GEAR	01
35.	0521062072	33Z GEAR	01




Item	Code	Description	See page	07	09	11	13	15	17	19
01	0511050392	BOX SUPPORT RIGHT FERTILIZER		01						
01A	0521061871	RH FERTILIZER SILO SUPORT ASSY		01						
02	0511050391	FERTILIZER LEFT BOX SUPPORT		02						
02A	0521061872	LH FERTILIZER SILO SUPORT ASSY		01						
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2		04	05	06	07	08	09	10
03A	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		04	05	06	07	08	09	10
03B	0501019851	DISTRIBUTOR FERTILIZER AXLE		08	10	12	14	16	18	20
03C	0521010309	SLEEVE INTER		08	10	12	14	16	18	20
03D	0503030275	AGRICULTURAL BEARING		16	20	24	28	32	36	40
03E	0503031166	LEFT CONDUTOR		04	05	06	07	08	09	10
03F	0511017137	FLAT WASHER		08	10	12	14	16	18	20
03G	0503030303	SUPPORT WASHER		10	12	14	16	18	20	22
03H	0501013774	GREASE SEAL		08	10	12	14	16	18	20
03I	0502011412	18Z CONICAL GEAR		08	10	12	14	16	18	20
03J	0503010523	1/4" X 2" COTTERPIN		08	10	12	14	16	18	20
03K	0503011962	GREASE FITTING		16	20	24	28	32	36	40
03L	0503010003	1845 GREASE FITTING		08	10	12	14	16	18	20
04	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2		04	05	06	07	08	09	10
04A	0501110676	SIDE FERTILIZER DISTRIBUTOR		04	05	06	07	08	09	10
04B	0503031165	LEFT HELICAL CONDUTOR		04	05	06	07	08	09	10
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		32	40	48	56	64	72	80
06	0501010984	FLAT WASHER		56	64	72	80	70	120	128
07	0503011443	SPRING WASHER		32	40	48	56	64	72	80
08	0503010026	3/8" NUT		48	56	72	52	88	96	104
09	0511061759	22Z P12,70 FQ 3/4" GEAR		02	02	02	02	02	02	02
10	0521014167	CONE LOCK		04	04	04	04	04	04	04
11	0551018055	22,65 X 60 SLEEVE		04	04	04	04	04	04	04
12	0551018198	SQUARE SHAFT		00	00	02	00	00	00	00
13	0501053788	Q3/4" FASTENER AXLE ASSY		04	04	04	04	04	04	04
13A	0521010691	AXLE FASTENER		04	04	04	04	04	04	04
13B	0503010373	1/4" X 2" BOLT		04	04	04	04	04	04	04

Item	Code	Description	See page	07	09	11	13	15	17	19
13C	0501010694	FLAT WASHER		04	04	04	04	04	04	04
13D	0503010143	SPRING WASHER		04	04	04	04	04	04	04
13E	0503010144	1/4" NUT		04	04	04	04	04	04	04
14	0501110294	BEARING OF THE GEAR RIGHT BOX		01	01	01	01	01	01	01
15	0521012485	GEAR BOX BEARING AGRICUTURAL		02	02	02	02	02	02	02
16	0503010363	5/16" X 1" BOLT		04	04	04	04	04	04	04
17	0503011444	SPRING WASHER		04	04	04	04	04	04	04
18	0503010337	5/16" NUT		04	04	04	04	04	04	04
19	0571010590	FERTILIZER SIDE COVER		07	10	12	14	15	18	20
20	0503010257	1/8" X 1" COTTERPIN		07	10	12	14	15	18	20
21	0503010849	3/8" X 1-1/2" BOLT		16	16	16	16	24	24	24
22	0503010025	3/8 SPRING WASHER		16	16	16	16	24	24	24
23	0503060663	FERTILIZER HOPPER WITH 4 TRUNNELS		02	03	01	04	02		
24	0571013223	ANGLE BAR		04	04	02	02	04	04	04
25	0503032624	FERTILIZER BEAN LIP		03	04	07	07	07	09	09
26	0503031050	CURVED CONDUCTOR		07	09	11	13	15	17	19
27	0503010246	CLAMP		07	09	11	13	15	17	19
28	0571013224	STRINGER FIXING CASH FERTILIZER		02						
29	0503011957	PMC 596-S NYLON LUG		02	02	02	02	02	02	02
30	0503010371	5/16" X 1" BOLT		04	04	04	04	04	04	04
31	0503010179	SPRING WASHER		04	04	04	04	04	04	04
32	0503010337	5/16" NUT		04	04	04	04	04	04	04
33	0511050936	BOX SUPPORT RIGHT FERTILIZER		01						
33A	0521062290	RH FERTILIZER SILO SUPORT ASSY		01						
34	0511050935	FERTILIZER LEFT BOX SUPPORT		01						
34A	0521062291	LH FERTILIZER SILO SUPORT ASSY		01						
35	0503060664	FERTILIZER HOPPER WITH 5 TRUNNELS		02	02	02	04			
36	0511050891	BOX SUPPORT RIGHT FERTILIZER		01						
36A	0521062274	RH FERTILIZER SILO SUPORT ASSY		01						
37	0511050892	FERTILIZER LEFT BOX SUPPORT		01						
37A	0521062273	LH FERTILIZER SILO SUPORT ASSY		01						
38	0571013225	STRINGER FIXING CASH FERTILIZER		02	02	02	02			
39	0511050641	RH FERTILIZER BOX SUPPORT		01						
39A	0521062052	RH FERTILIZER SILO SUPORT ASSY		01						
40	0511050642	LEFT FERTILIZER BOX SUPPORT		01						
40A	0521062051	LH FERTILIZER SILO SUPORT ASSY		01						
41	0511050896	LEFT FERTILIZER BEAM SUPPORT		01						
41A	0521062102	RH FERTILIZER SILO SUPORT ASSY		01						
42	0511050897	FERTILIZER BEAM SUPPORT		01						
42A	0521062104	LH FERTILIZER SILO SUPORT ASSY		01						
43	0511050903	RH FERTILIZER BOX SUPPORT		01						
43A	0521062103	RH FERTILIZER SILO SUPORT ASSY		01						
44	0511050904	FERTILIZER BOX SUPPORT		01						
44A	0521062105	LH FERTILIZER SILO SUPORT ASSY		01						
45	0551018213	3/4" X 1830 SQUARE SHAFT		01						
46	0561018365	SQUARE SHAFT		01						
47	0501110295	BEARING OF THE GEAR LEFT BOX		01	01	01	01	01	01	01
48	0561018585	SQUARE SHAFT		02						
49	0551018200	SQUARE SHAFT		02						
50	0551014132	SQUARE SHAFT		02						
51	0561018618	SQUARE SHAFT		02						
52	0511050960	BOX SUPPORT DROIT ENGRAIS		01						
52A	0521062311	FERTILIZER BEAM SUPPORT		01						
53	0511050961	FERTILIZER LEFT BOX SUPPORT		01						
53A	0521062310	FERTILIZER BEAM SUPPORT		01						
54	0561018740	SQUARE SHAFT		01						
55	0561018739	SQUARE SHAFT		01						




Item	Code	Description	See page	
001	0511053023	LONG FERTILIZER LINE	16	01
002	0511051818	18" BLADE DISC ASSY	19	01
003	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
004	0511065843	FERT CONDUCTOR WITH REGULATOR		01
005	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
006	0501010984	FLAT WASHER		04
007	0503010025	3/8 SPRING WASHER		02
008	0503010026	3/8" NUT		02
009	0503031050	CURVED CONDUCTOR		01
010	0503010246	CLAMP		01




Item	Code	Description	See page	QT
001	0521063759	ROW FERTILIZER SUPPORT	01	
002	0511053223	FERTILIZER ROW SUPPORT	01	
002A	0502012727	BLADE DISC SUPPORT	01	
002B	0511016156	5/8" X 1.1/2" BOLT	02	
003	0503017855	BOLT 3/4	02	
004	0503010152	3/4" UNF SELF ADJUSTING NUT	02	
005	0521063504	FERTILIZER ROW LOWER SUPPORT	01	
006	0503010233	5/8" X 2-1/2" BOLT	02	
007	0511015098	FLAT WASHER	06	
008	0561017928	FERTILIZER ROW ARTICULAT SLEEVE	02	
009	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	02	
010	0511063862	FERTILIZER ROW UPPER SUPPORT	01	
011	0501010163	5/8" X 4-1/2" BOLT	01	
012	0531015184	FLAT WASHER	01	
013	0531016031	1/2" SPRING WASHER	01	
014	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	01	
015	0531016207	0.6" X 1" X 2.8" SLEEVE	01	
016	0521061855	FERTILIZER ROW REAR SUPPORT	01	
017	0501010452	5/8" X 5" BOLT	02	
018	0531016031	1/2" SPRING WASHER	04	
019	0531016207	0.6" X 1" X 2.8" SLEEVE	02	
020	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	02	
021	0521062073	SPRING GUIDE	01	
022	0521016057	COUP SHA OF THE CARRY-W SPRING GUI	01	
023	0503030168	HAIR PIN	01	
024	1902020393	SPRING UPPER SUPPORT	01	
025	0503031450	2.7" X 9.2" X 0.03" SPRING	01	
026	1902020393	SPRING UPPER SUPPORT	01	
027	0521011158	SPRING LOCKNUT	01	
028	0521018575	REGULATOR SPINDLE 100	01	
029	0502012724	FERTILIZER ROW FIXER	01	


Item	Code	Description	See page	QT
030	0503017960	5/8" X 3-12" BOLT		04
031	0503010811	5/8" UNF SELF ADJUSTING NUT		04
032	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR		01
033	0502012352	DOUBLE-DISC SPACING PLATE		01
034	0541013035	5.55" X 4.0" X 0.38" PLATE		01
035	0503010740	1/2" X 2" BOLT		02
036	0503010019	1/2" SPRING WASHER		02
037	0503010060	1/2" NUT		02
038	0503010752	1/2" X 3.1/2" BOLT		02
039	0503010019	1/2" SPRING WASHER		02
040	0503010060	1/2" NUT		02
041	0503030520	SEED SOCKET		01
042	0503031145	2" X 2" X 20" HOSE		01
043	0503031076	2" HOSE CLAMP		02
044	0503010003	1845 GREASE FITTING		02
045	0503010004	1890 GREASE FITTING		01



Item	Code	Description	See page	DIR.ESQ.
01	0511053172	LEFT LOW CUBE WITH DISC 15	01	01
01A	0502012736	HUB LOWR DDD	01	01
01B	0503016354	EVA-F8N ESF2CARR BALL BEARING	01	01
01C	0571011151	LEFT DOUBLE DISC HUB	00	01
01D	0603022042	13" X 0.12" PLAIN COULTER BLADE	01	01
01E	0503010546	5/16" X 7/8" BOLT	06	06
01F	0503011444	SPRING WASHER	06	06
01G	0503010337	5/16" NUT	06	06
02	0511053173	CUBE LOW RIGHT WITH DISC 15	01	01
02A	0571011150	RIGHT DOUB DISC - HUB	01	00
03	0511011927	DUST CLOAK	02	02
04	0503014679	2-134 O-RING	02	02
05	0571011152	DOUBLE DISC CAP	02	02
06	0503015081	502052 CLAMPING RING (FOR AXLE)	02	02
07	0511015098	FLAT WASHER	02	02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT	00	01
09	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT	01	00
10	0501017542	LH DOUBLE DISC SCRAPER	01	01
11	0501017541	RH DOUBLE DISC SCRAPER	01	01
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	01
13	0501010984	FLAT WASHER	02	02
14	0503010026	3/8" NUT	01	01
15	0503011443	SPRING WASHER	01	01
16	0502070062	SCRAPER	01	01
17	0503011402	0.2" X 0.8" SPRING PIN	01	01



Item	Code	Description	See page	
001	0511053024	FERTILIZER SHORT LINE	18	01
002	0511051818	18" BLADE DISC ASSY	19	01
003	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
003A	0511061768	FERTILIZER SCARIFIER SPINDLE		01
003B	1902070061	POINT SUBSOILER		01
003C	0503011373	0.4" X 1.1" SPRING PIN		01
004	0511063823	FERT CONDUCTOR WITH REGULATOR		01
005	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
006	0501010984	FLAT WASHER		04
007	0503010025	3/8 SPRING WASHER		02
008	0503010026	3/8" NUT		02
009	0503031050	CURVED CONDUCTOR		01
010	0503010246	CLAMP		01




Item	Code	Description	See page
01	0511053024	FERTILIZER SHORT LINE	18
01A	0502012728	ROW FERTILIZER SUPPORT	
02	0511053223	FERTILIZER ROW SUPPORT	
02A	0502012727	BLADE DISC SUPPORT	
02B	0511016156	5/8" X 1.1/2" BOLT	
03	0503017856	BOLT 3/4	
04	0501010322	FLAT WASHER	
05	0503011255	3/4" LOCK NUT	
06	0511065857	FERTILIZER ROW LOWER SUPPORT	
07	0561017928	FERTILIZER ROW ARTICULAT SLEEVE	
08	0511015098	FLAT WASHER	
09	0503010233	5/8" X 2-1/2" BOLT	
10	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	
11	0511063862	FERTILIZER ROW UPPER SUPPORT	
12	0501010452	5/8" X 5" BOLT	
13	0531016207	0.6" X 1" X 2.8" SLEEVE	
14	0521061855	FERTILIZER ROW REAR SUPPORT	
15	0501010452	5/8" X 5" BOLT	
16	0531016031	1/2" SPRING WASHER	
17	0531016207	0.6" X 1" X 2.8" SLEEVE	
18	0521062073	SPRING GUIDE	
19	0521016057	COUP SHA OF THE CARRY-W SPRING GUI	
20	0503030168	HAIR PIN	
21	1902020393	SPRING UPPER SUPPORT	
22	0503031450	2.7" X 9.2" X 0.03" SPRING	
23	0521011158	SPRING LOCKNUT	
24	0521018575	REGULATOR SPINDLE 100	
25	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	
26	0502012352	DOUBLE-DISC SPACING PLATE	
27	0541013035	5.55" X 4.0" X 0.38" PLATE	
28	0503010740	1/2" X 2" BOLT	




COP FLEX 600 SUPREMA
FERTILIZER SHORT LINE

Page 18
0511053024


Item	Code	Description	See page
29	0503010019	1/2" SPRING WASHER	04
30	0503010060	1/2" NUT	04
31	0503010752	1/2" X 3.1/2" BOLT	02
32	0503031145	2" X 2" X 20" HOSE	01
33	0503031076	2" HOSE CLAMP	02
34	0503010003	1845 GREASE FITTING	03
35	0503030520	SEED SOCKET	01




Item	Code	Description	See page
01	0511051818	18" BLADE DISC ASSY	19
02	0521062962	BLADE DISC AXLE	01
03	0502012369	BLADE DISC SUPPORT	01
04	0541018684	FLAT WASHER	01
05	0503010361	SPRING PIN	01
06	0503010756	0.2" X 2.4" SPRING PIN	01
07	0503010003	1845 GREASE FITTING	01
08	0521018935	RIGHT ARM OF THE BLADE DISC	01
09	0521018936	LEFT ARM OF THE BLADE DISC	01
10	0501067323	SPRING REGULATOR	01
11	0521010452	SLEEVE	01
12	0503013185	3/4" X 5-1/2" BOLT	01
13	0503011255	3/4" LOCK NUT	01
14	0502020393	SPRING UPPER SUPPORT	01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01
16	0502020394	SPRING SUPPORT	01
17	0503010014	3/4" NUT	2
18	0501052139	18 BLADE DISC WITH FLAT PLAN DISC	20
19	0521015376	DUST CLOAK	02
20	0511015346	FLAT WASHER	02
21	0503011438	SPRING WASHER	02
22	0521013510	3/4" NUT	02
23	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01
24	0503011411	1/2" X 5-1/2" BOLT	01
25	0503011440	SPRING WASHER	01
26	0503010060	1/2" NUT	01




Item	Code	Description	See page	QT
01	0502011562	DC PST ACT/ULTR BOX		01
02	0503010276	6206 BALL BEARING		02
03	0521013610	BLADE DISC HUB AXLE		01
04	0503030832	FLAT WASHER		02
05	0503012417	SEAL		02
06	0503011800	SEAL RING		02
07	0503010691	1/4" GREASE FITTING		01
08	0603026013	PLAIN COULTER BLADE		01
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0503011444	SPRING WASHER		06
12	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0521062962	BLADE DISC AXLE		01
02	0502012369	BLADE DISC SUPPORT		01
03	0541018684	FLAT WASHER		01
04	0503010361	SPRING PIN		01
05	0503010756	0.2" X 2.4" SPRING PIN		01
06	0503010003	1845 GREASE FITTING		01
07	0521018935	RIGHT ARM OF THE BLADE DISC		01
08	0521018936	LEFT ARM OF THE BLADE DISC		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503016525	3/4" X 6" BOLT		01
12	0503011442	3/4" SPRING WASHER		01
13	0503010014	3/4" NUT		01
14	0502020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0502020394	SPRING SUPPORT		01
17	0503010014	3/4" NUT		02
18	0501054887	20 BLADE DISC WITH FLAT PLAN DISC	22	01
19	0521015376	DUST CLOAK		02
20	0511015346	FLAT WASHER		02
21	0503011438	SPRING WASHER		02
22	0521013510	3/4" NUT		02
23	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
24	0503011411	1/2" X 5-1/2" BOLT		01
25	0503011440	SPRING WASHER		01
26	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011562	DC PST ACT/ULTR BOX		01
02	0503010276	6206 BALL BEARING		02
03	0521013610	BLADE DISC HUB AXLE		01
04	0503030832	FLAT WASHER		02
05	0503012417	SEAL		02
06	0503011800	SEAL RING		02
07	0503010691	1/4" GREASE FITTING		01
08	0603027851	20" X 0.2" FLAT PLAIN DISC		01
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0503011444	SPRING WASHER		06
12	0503010337	5/16" NUT		06




Item	Code	Description	See page	09 11 13 15 17
00	0511058101	C3 SEMI MOUNTED ASSEMBLY CSU		01 00 00 00 00
00A	0511058691	C2 ASSEMBLY CSU SEMI MOUNTED		00 01 00 00 00
00B	0511058698	C2 ASSEMBLY CSU 2 SEMI MOUNTED		00 00 01 00 00
00C	0511058716	C2 ASSEMBLY CSU SEMI MOUNTED		00 00 00 01 00
00D	0511058365	C3 ASSEMBLY CSU SEMI MOUNTED		00 00 00 00 01
01	0511058100	ENSEMBLE BOX UNIQUE SEED C3 2CX 6B C/9 C		01 00 00 00 00
02	0511056683	ENSEMBLE BOX UNIQUE SEED C2 2CX 7B C/11 C		00 01 00 00 00
03	0511059753	ENSEMBLE BOX UNIQUE SEED C2 2CX 5B + 1CX 6B C/13 C		00 00 01 00 00
04	0511056230	ENSEMBLE BOX UNIQUE SEED C2 3CX 6B C/15 C		00 00 00 01 00
05	0511058364	ENSEMBLE BOX UNIQUE SEED C3 2CX 5B + 2CX 6B C/17 C		00 00 00 00 01
06	0521066208	SUPPORT TOWER SILO		04 04 06 06 08
07	0501010942	3/8" X 1-1/4" BOLT		08 08 12 12 16
08	0501010984	FLAT WASHER		08 08 12 12 16
09	0503010025	3/8 SPRING WASHER		08 08 12 12 16
10	0503010026	3/8" NUT		08 08 12 12 16
11	0502010175	HITCH CLAMP		04 04 06 06 08
12	0501011543	5/8" X 4" BOLT		08 08 12 12 16
13	0501012140	FLAT WASHER		08 08 12 12 16
14	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		08 08 12 12 16



Item	Code	Description	See page	QT
01	0511065449	ROW MARKER ARM SUPPORT		02
02	0501018059	3/4" X 2-1/4" BOLT		08
03	0503010023	SPRING WASHER		08
04	0503011255	3/4" LOCK NUT		08
05	0501069470	ROW MARKER ARM		02
06	0503011067	5/8" X 2-1/2" BOLT		04
07	0521010479	SLEEVE ARTICULATION		04
08	0501012140	FLAT WASHER		04
09	0503012795	5/8" HEX SELF ADJUSTING NUT		04
10	0511040203	1.5" X 2.5" X 19" X 9" HYDRAULIC CYLINDER	27	02
11	0521010574	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010571	1/4" X 1.1/2 COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	HAIR PIN		02
18	0501069643	890 TURNBUCKLE		02
19	0503010962	5/8" X 1-1/4" BOLT		04
20	0503011070	BEATER		02
21	0503010740	1/2" X 2" BOLT		02
22	0503010019	1/2" SPRING WASHER		02
23	0501050633	DISC LINE MARKER	25	02
24	0521013164	PROTRACTOR TURNBUCKLE		02
25	0501011310	FIXER LOCK		08
26	0503010706	1/2" X 4.1/2" BOLT		08
27	0503010060	1/2" NUT		08



Item	Code	Description	See page	QT
01	0511053904	DISC LINE MARKER		01
02	0503010023	SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	07	09	10	11	13	15	L
01	0501054649	SEQUENTIAL VALVE ASSY		01	01	01	01	01	01	
01A	0503060132	VDFS-002 T SEQUENCEL VALVE		01	01	01	01	01	01	
01B	0501010617	3/4" NIPPLE		02	02	02	02	02	02	
01C	0503010190	2-114 N 3006-9B O'RING		02	02	02	02	02	02	
01D	0501012109	3/4" X 9/16" NIPPLE		04	04	04	04	04	04	
01E	0503011036	2-111 N 3006-9B O'RING		06	06	06	06	06	06	
01F	0531019339	9/16" UNF X 12 PUMP		02	02	02	02	02	02	
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02	02	02	02	02	02	
03	0501010984	FLAT WASHER		02	02	02	02	02	02	
04	0503010025	3/8 SPRING WASHER		02	02	02	02	02	02	
05	0541012165	3/4" NIPPLE		04	04	04	04	04	04	
06	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		04	04	04	04	04	04	
07	0501080635	3/8" X 19" TR-TR HOSE		02	02	02	02	02	02	
08	0501080105	TR-TR HOSE ASSY		02	02	02	02	02	02	
09	0501080750	3/8" X 149" TC-TC HOSE ASSY		00	04	00	00	00	00	
10	0501080878	3/8 X 4200 TC-TM HOSE ASSY		02	02	02	02	02	02	
11	0501053834	MALE QUICK COUPLING AGRICULTURAL WITH COVER - 1/2 NPT		02	02	02	02	02	02	
11A	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT		02	02	02	02	02	02	
11B	0503011882	QUICK CONNECTION COVER		02	02	02	02	02	02	
12	0561017277	OIL CONDUCTOR FIXER PLATE		02	02	02	02	02	02	
13	0521010718	5/8" U BOLT		02	02	02	02	02	02	
14	0501012140	FLAT WASHER		04	04	04	04	04	04	
15	0503010027	SPRING WASHER		04	04	04	04	04	04	
16	0503010013	5/8" NUT		04	04	04	04	04	04	
17	0502012702	BODY SUPPORT CLAMP		04	04	04	04	04	04	
18	0503011103	7/16" X 2-1/2" BOLT		04	04	04	04	04	04	
19	0503010180	7/16" SPRING WASHER		04	04	04	04	04	04	
20	0503010244	7/16" NUT		04	04	04	04	04	04	
21	0501081646	TC-TC HOSE ASSY		04	00	00	00	00	00	
22	0501081644	HOSE 3/8 X 3350 TC-TC USAP		00	04	00	00	00	00	
23	0501080750	3/8" X 149" TC-TC HOSE ASSY		00	00	04	00	00	00	




COP FLEX 600 SUPREMA
CIRCUIT MARKER HIDRAULICO

Page 26
0909094617


Item	Code	Description	See page	07	09	10	11	13	15	L
24	0501081639	HOSE		00	00	00	04	00	00	
25	0501080611	3/8" X 17.8" TR-TR HOSE ASSY		00	00	00	00	04	00	
26	0501080753	3/8" X 185" TC-TC HOSE ASSY		00	00	00	00	00	04	




Item	Code	Description	See page	QT
01	0511062810	2.5" X 15" CYLINDER CASE		01
02	0501065662	HYDRAULIC CYLINDER TURNBUCKLE		01
03	0502010471	MOBILE COVER		01
04	0502010780	RING SUPPORT		01
05	0503010163	D-1500 SCRAPER RING		01
06	0503010989	1870-1500-375-B GASKET		01
07	0503010970	W1-1650-500 PK O'RING G.E		01
08	0503011058	8-330 BACK-UP RING		01
09	0503010161	2-330 N 3006 9B O'RING		01
10	0503010285	2-222 N 3006-9B O'RING		01
11	0502010783	1.5" X 2.5" PISTON		01
12	0503010160	2500 2000 GASKET		02
13	0503010973	W2-2500-500 PK O'RING G.E		01
14	0503010063	1" SELF-ALIGNING NUT		01
15	0503030384	CON N-001 PLUG		02
16	0501032666	HYDRAULIC CYLINDER REPAIR KIT		01




Item	Code	Description	See page	17/19 L
01	0511061022	ROW MARKER SUPPORT		02
02	0511066119	MARKER SUPP FIXER FASTENER		04
03	0502010175	HITCH CLAMP		08
04	0501010216	3/4" X 4-1/2" BOLT		16
05	0503010023	SPRING WASHER		16
06	0503010014	3/4" NUT		16
07	0511060013	ROW MARKER ARM		02
08	0501050633	DISC LINE MARKER	25	02
09	0521013347	1.1/4" X 8.4" AXLE		02
10	0501019435	FLAT WASHER		04
11	0503010523	1/4" X 2" COTTERPIN		16
12	0511060014	ROW MARKER ARM		02
13	0503010004	1890 GREASE FITTING		04
14	0503010003	1845 GREASE FITTING		02
15	0521011142	1.1/4" X 7.5" AXLE		04
16	0521011141	1.1/4" X 6.5" AXLE		02
17	0511060010	1400 TURNBUCKLE		02
18	0521012324	1/2" X 3.2" X 2.54" FASTENER		04
19	0511017302	FLAT WASHER		08
20	0503010019	1/2" SPRING WASHER		08
21	0503010060	1/2" NUT		08
22	0501045149	1.5"X2.5"X30"X18"RH HYDRAULIC CYLINDER	30	01
23	0501046485	1.5"X 2.5"X 30"X 18"LEFT HYDRAULIC CYLINDER	31	01
24	0511015573	2.07" X 1.6" TRANSPORT LOCK		02
25	0501068994	0.3" X 3.1" LOCK PIN		02
26	0503030168	HAIR PIN		02




Item	Code	Description	See page	17 19 LINHAS
01	0501054649	SEQUENTIAL VALVE ASSY		01 01
01A	0503060132	VDFS-002 T SEQUENCEL VALVE		01 01
01B	0501010617	3/4" NIPPLE		06 06
01C	0503010190	2-114 N 3006-9B O'RING		06 06
01D	0501012109	3/4" X 9/16" NIPPLE		04 04
01E	0503011036	2-111 N 3006-9B O'RING		06 06
01F	0531019339	9/16" UNF X 12 PUMP		02 02
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02 02
03	0501010984	FLAT WASHER		02 02
04	0503010025	3/8 SPRING WASHER		02 02
05	0541012165	3/4" NIPPLE		04 04
06	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		04 04
07	0501080056	3/8" X 1700 TR-TC HOSE ASSY		04
08	0501080025	TR-TC HOSE ASSY		02
09	0501081642	HOSE 3/8 X 5600 TC-TC USAP		04
10	0501081653	HOSE 3/8 X 5150 TC-TC USAP		04
11	0501080878	3/8 X 4200 TC-TM HOSE ASSY		02 02
12	0501053834	MALE QUICK COUPLING AGRICULTURAL WITH COVER - 1/2 NPT		02 02
12A	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT		02 02
12B	0503011882	QUICK CONNECTION COVER		02 02
13	0561017277	OIL CONDUCTOR FIXER PLATE		02 02
14	0521010718	5/8" U BOLT		02 02
15	0501012140	FLAT WASHER		04 04
16	0503010027	SPRING WASHER		04 04
17	0503010013	5/8" NUT		04 04
18	0502012702	BODY SUPPORT CLAMP		04 04
19	0503011103	7/16" X 2-1/2" BOLT		04 04
20	0503010180	7/16" SPRING WASHER		04 04
21	0503010244	7/16" NUT		04 04
22	0501080714	3/8" X 63" TR-TC HOSE ASSY		02



Item	Code	Description	See page	QT
01	0501045149	1.5"X2.5"X30"X18"RH HYDRAULICCYLINDER	30	01
01A	0501067104	2.5" X 25" CYLINDER CASE		01
02	0501069883	26.5" X 1.5" H CYLINDER TURNBUCKLE		01
03	0502010471	MOBILE COVER		01
04	0502010780	RING SUPPORT		01
05	0503010163	D-1500 SCRAPER RING		01
06	0503010989	1870-1500-375-B GASKET		01
07	0503010970	W1-1650-500 PK O'RING G.E		01
08	0503011058	8-330 BACK-UP RING		01
09	0503010161	2-330 N 3006 9B O'RING		01
10	0503010285	2-222 N 3006-9B O'RING		01
11	0502010783	1.5" X 2.5" PISTON		01
12	0503010973	W2-2500-500 PK O'RING G.E		01
13	0503010160	2500 2000 GASKET		02
14	0503010063	1" SELF-ALIGNING NUT		01
15	0503030384	CON N-001 PLUG		02



Item	Code	Description	See page
01	0501046485	1.5"X 2.5"X 30"X 18"LEFT HYDRAULIC CYLINDER	31
01A	0501067700	2.5" X 25" CYLINDER CASE	
02	0501069883	26.5" X 1.5" H CYLINDER TURNBUCKLE	
03	0502010471	MOBILE COVER	
04	0502010780	RING SUPPORT	
05	0503010163	D-1500 SCRAPER RING	
06	0503010989	1870-1500-375-B GASKET	
07	0503010970	W1-1650-500 PK O'RING G.E	
08	0503011058	8-330 BACK-UP RING	
09	0503010161	2-330 N 3006 9B O'RING	
10	0503010285	2-222 N 3006-9B O'RING	
11	0502010783	1.5" X 2.5" PISTON	
12	0503010973	W2-2500-500 PK O'RING G.E	
13	0503010160	2500 2000 GASKET	
14	0503010063	1" SELF-ALIGNING NUT	
15	0503030384	CON N-001 PLUG	




Item	Code	Description	See page	09	11	13	15	17	19
01	0511053563	SET DUCT AIR		01	00	00	00	00	00
01A	0571013800	SUPPORT AIR CONDUCTION		04	04	04	00	00	00
01B	0521018402	AIR CONDUCTOR CLAMP		04	04	04	00	00	00
01C	0521010718	5/8" U BOLT		04	04	04	00	00	00
01D	0503031610	AIR DISTRIBUTOR		02	02	00	00	00	00
01E	0503010013	5/8" NUT		10	10	10	10	10	10
01F	0503010371	5/16" X 1" BOLT		08	08	08	08	08	08
01G	0503010337	5/16" NUT		08	08	08	08	08	08
01H	0503010179	SPRING WASHER		10	10	10	10	10	10
02	0511053502	SET DUCT AIR		00	01	00	00	00	00
03	0511053501	SET DUCT AIR		00	00	01	00	00	00
03A	0503031611	AIR DISTRIBUTOR		00	00	02	00	00	00
04	0511053534	SET DUCT AIR		00	00	00	00	01	00
04A	0503031613	AIR DISTRIBUTOR		00	00	00	00	02	00
05	0511053560	SET DUCT AIR		00	00	00	00	00	01
05A	0503031885	AIR DISTRIBUIDOR		00	00	00	00	00	02
06	0511041364	DRIVE SHAFT	34	01	01	01	01	01	01
07	0503010479	1/2" X 3" BOLT		01	01	01	01	01	01
08	0503010019	1/2" SPRING WASHER		01	01	01	01	01	01
09	0503010060	1/2" NUT		01	01	01	01	01	01
10	0521041586	TURBINE ASSY FOR CARDAN	33	01	01	01	01	01	01
11	0503010967	5/8" X 5.1/2" BOLT		02	02	02	02	02	02
12	0503010027	SPRING WASHER		02	02	02	02	02	02
13	0531016195	4" X 94" AIR CONDUCTOR		02	02	02	02	02	02
14	0503011372	102 TO 121 CLAMP		04	04	04	04	04	04
15	0521018618	5" X 70" AIR CONDUCTOR		01	00	00	00	00	00
16	0521019552	5" X 188" AIR CONDUCTOR		00	01	01	01	01	01
17	0503012724	121 TO 140 CLAMP		01	01	01	01	01	01
18	0531015603	HOSE FIXATION SUPPORT		01	01	01	01	01	01
19	0501056495	TURBINE OUTPUT SOCKET		01	01	01	01	01	01
20	0503013096	5/16" X 4" BOLT		02	02	02	02	02	02



COP FLEX 600 SUPREMA
PARTS SUPREMA TURBINE WITH CARDAN


Page 32
0909094630

Item	Code	Description	See page	09 11 13 15 17 19
21	0501010694	FLAT WASHER		04 04 04 04 04 04
22	0503010499	5/16" UNC BUTTERFLY NUT		02 02 02 02 02 02
23	0503031436	AIR DITRIBUTOR PUMP		05 06 07 08 09 10
24	0511053527	SET DUCT AIR		00 00 00 01 00 00
24A	0503031612	AIR DISTRIBUTOR		00 00 00 02 00 00




Item	Code	Description	See page	QT
01	0511061094	TURBINE SUPPORT	01	01
02	0501053716	BEARING ASSY OF THE LARGER FAN	01	01
02A	0502012016	CHAIN TENSIONER SUPPOT	01	01
02B	0503012778	MIDDLE LARGER AXLE	01	01
02C	0531010881	INTERMEDIARY UPPER SLEEVE	01	01
02D	0503012689	6306 DDU BEARING	02	02
02E	0503010325	VCA-118 VALVE	01	01
03	0503010920	1/2" X 1.1/2" BOLT	02	02
04	0501056495	TURBINE OUTPUT SOCKET	01	01
04A	0503031812	TURBINE OUTPUT SOCKET	01	01
04B	0541017539	BUTTERFLY VALVE	01	01
04C	0511066760	VALVE FIXATION SUPPORT	01	01
04D	0503013813	1/4" UNC X 7/8" BOLT	02	02
04E	0511017303	FLAT WASHER	02	02
04F	0503010143	SPRING WASHER	02	02
04G	0503010144	1/4" NUT	02	02
04H	0501013519	FLAT WASHER	01	01
04I	0503010019	1/2" SPRING WASHER	01	01
04J	0503010060	1/2" NUT	01	01
05	0503010395	1/2" X 1-1/4" BOLT	02	02
06	0503011336	1/2" HEX SELF ADJUSTING NUT	04	04
07	0501053886	PULLEY ASSY WITH FREE ROT	01	01
08	0501011194	1/2" X 1-3/4" BOLT	04	04
09	0521018517	FLAT WASHER	04	04
10	0503010019	1/2" SPRING WASHER	04	04
11	0503010020	1/2"NUT	04	04
12	0503013030	5/8" X 3.1/4" BOLT	01	01
13	0501012140	FLAT WASHER	01	01
14	0503010013	5/8" NUT	01	01
15	0503012780	LARGER TURBINE BELT	01	01
16	0571012629	FRONT COVER	01	01

Item	Code	Description	See page	QT
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
18	0503010025	3/8 SPRING WASHER		04
19	0503010026	3/8" NUT		04
20	0521044612	FAN		01
21	0503011775	6 X 6 X 35 KEYWAY		01
22	0503011774	PULLEY		01
23	0503010179	SPRING WASHER		01
24	0503011257	M 8 X 1,25 X 30 BOLT		01
25	0503013096	5/16" X 4" BOLT		02
26	0501054272	RIBBON FOR COVER CLOSING ASSY		01
26A	0531017193	RIBBON FOR COVER CLOSING		01
26B	0521018401	SEGMENT COVER		15
27	0503031776	TURBINE RIBBON SEAL		02
28	0571012630	REAR COVER		01
29	0503013031	1/4" X 3.1/4" BOLT		13
30	0503012880	1/4" UNC SELF ADJUSTING NUT		15
31	0511014024	10 X 13 X 15,5 SLEEVE		02
32	0503012721	1/4" X 4" BOLT		02
33	0511017303	FLAT WASHER		04
34	0503031649	CONECTOR CENTER		01
35	0503012722	0.16" X 0.4" BLIND RIVET		08
36	0531012760	TURBINE REAR COVER		01
37	0503013758	1/4" X 1-1/2" BOLT		04
38	0501010694	FLAT WASHER		02
39	0503010499	5/16" UNC BUTTERFLY NUT		02
40	0561010635	SWITCH FIXER		01
41	0503013584	VACUUM GAUGE		01
42	0503015062	TUBE		0.500




Item	Code	Description	See page	QT
01	0501055638	HOMO JOINT WITH FEMALE BUSHING		01
01A	0503012607	TRACTOR HOMOCINETIC TERMINAL		01
01Aa	0521010638	0.5" X 3.3" QUIC HITCH COUPL SHAFT		01
01Ab	0503030518	0.5"X1.0"X 0.1" COMPRESSION SPRING		01
01Ac	0503010140	1/8" X 3/4" COTTERPIN		01
01B	0503012605	CROSSPIECE		02
01C	0503012606	CENTER BODY		01
01D	0503012604	HOMO TERMINAL W/ FEMALE BUSHING		01
01E	0503012618	2.1" X 2.0" X 31" TRIAN FEMALE TUB		01
01F	0503010843	0.4" X 3.3" SPRING PIN		01
01G	0503011878	0.2" X 3.3" SPRING PIN		01
02	0501055639	UNIVERSAL JOINT		01
02A	0503013132	CC292 TERMINAL		01
02B	0503012096	CROSSPIECE		01
02C	0503013187	TERMINAL		01
02D	0503012619	1.8" X 1.7" X 31" TRIAN MALE TUB		01
02E	0503011069	0.4" X 2.8" SPRING PIN		01
02F	0503011805	0.2" X 2.8" SPRING PIN		01
03	0503013189	PROTECTION ASSY		01
04	0503012023	CHAIN FOR UNIV JOINT PROTECTION		01




Item	Code	Description	See page	QT
01	0511065675	HIDRAULIC TURBINE SUPPORT	01	
02	0531018715	CONTROL VALVE SUPPORT TURBINE	01	
03	0503010920	1/2" X 1.1/2" BOLT	02	
04	0503010019	1/2" SPRING WASHER	03	
05	0503010060	1/2" NUT	05	
06	0501054577	BLOCK COMMAND	01	
06A	0503012291	BLOCK COMMAND	01	
06B	0501010590	7/8" REDUCTION NIPPLE	04	
06C	0503010045	2-116 N 3006-9B O'RING	04	
06D	0541011066	3/4" UNF X 43.5 NIPPLE	01	
06E	0503010190	2-114 N 3006-9B O'RING	01	
07	0503010206	3/8" X 1/2" BOLT	02	
08	0503010025	3/8 SPRING WASHER	08	
09	0503010237	3/8" X 1" BOLT	04	
10	0503010026	3/8" NUT	04	
11	0501054983	NIPPLE HIDRAULIC MOTOR	01	
11A	0503012871	HYDRAULIC MOTOR	01	
11B	0531018770	R 3/4"UNF X R 1/4"BSP ELBOW	01	
11C	0561016941	3/4" NUT	01	
11D	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE	02	
11E	0541011065	3/4"UNF X R1/4BSP19FPP X43.5 NIPPLE	01	
12	0571012636	FRONT COVER	01	
13	0521041542	FAN 480 X 44 HIDRAULIC	01	
14	0531018764	FLAT WASHER	01	
15	0503010143	SPRING WASHER	01	
16	0503011104	M6 X 1" BOLT	01	
17	0501054272	RIBBON FOR COVER CLOSING ASSY	01	
17A	0531017193	RIBBON FOR COVER CLOSING	01	
17B	0521018401	SEGMENT COVER	15	
18	0503031776	TURBINE RIBBON SEAL	02	
19	0571012630	REAR COVER	01	

Item	Code	Description	See page	QT
20	0503031649	CONECTOR CENTER		01
21	0503012722	0.16" X 0.4" BLIND RIVET		08
22	0503013031	1/4" X 3.1/4" BOLT		13
23	0503012880	1/4" UNC SELF ADJUSTING NUT		15
24	0503012721	1/4" X 4" BOLT		02
25	0511014024	10 X 13 X 15,5 SLEEVE		02
26	0501056495	TURBINE OUTPUT SOCKET		01
26A	0503031812	TURBINE OUTPUT SOCKET		01
26B	0541017539	BUTTERFLY VALVE		01
26C	0511066760	VALVE FIXATION SUPPORT		01
26D	0503013813	1/4" UNC X 7/8" BOLT		02
26E	0503010143	SPRING WASHER		02
26F	0503010144	1/4" NUT		02
26G	0501013519	FLAT WASHER		01
27	0511017303	FLAT WASHER		06
28	0503013096	5/16" X 4" BOLT		02
29	0501010694	FLAT WASHER		02
30	0503010499	5/16" UNC BUTTERFLY NUT		02
31	0501080927	3/8" X 14" TR-TR HOSE ASSY		01
32	0501080928	1/2" X 14" TR-TR HOSE ASSY		02
33	0501080553	3/8" X 126" TC-TM HOSE ASSY		01
34	0501080044	1/2" X 110" TC-TM HOSE ASSY		02
35	0501053834	MALE QUICK COUPLING AGRICULTURAL WITH COVER - 1/2 NPT		03
35A	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT		03
35B	0503011882	QUICK CONNECTION COVER		03
36	0531012760	TURBINE REAR COVER		01
37	0503013758	1/4" X 1-1/2" BOLT		04
38	0561010635	SWITCH FIXER		04
39	0503013584	VACUUM GAUGE		01
40	0503015062	TUBE		1/2"MT.
41	0503010849	3/8" X 1-1/2" BOLT		02



Item	Code	Description	See page	09	11	13	15	17	19
01	0521064027	REAR TURBINE SUPPORT		01	01	01	01	01	01
02	0551019213	FLAT WASHER		02	02	02	02	02	02
03	0503010740	1/2" X 2" BOLT		02	02	02	02	02	02
04	0503010019	1/2" SPRING WASHER		10	10	10	10	10	10
05	0503010060	1/2" NUT		10	10	10	10	10	10
06	0521042078	TURBINE MOTOR HYDRAULIC ASSY		01	01	01	01	01	01
07	0503010967	5/8" X 5.1/2" BOLT		02	02	02	02	02	02
08	0503010027	SPRING WASHER		03	03	03	03	03	03
09	0503010013	5/8" NUT		03	03	03	03	03	03
10	0503015062	TUBE		03	03	03	03	03	03mt.
11	0503031576	ELBOW		04	04	04	04	04	04
12	0521018615	"4 X 1300" AIR CONDUCTOR		02	02	02	02	02	02
13	0503011372	102 TO 121 CLAMP		04	04	04	04	04	04
14	0571012664	HOSE HOLDER ASSY		04	04	04	04	04	04
15	0521014021	1/2" X 4.5" X 5.4" FASTENER		04	04	04	04	04	04
16	0501013519	FLAT WASHER		08	08	08	08	08	08
17	0521014442	HOSE SUPPORT		04	04	04	04	04	04
18	0503010371	5/16" X 1" BOLT		08	08	08	08	08	08
19	0503010179	SPRING WASHER		10	10	10	10	10	10
20	0503010337	5/16" NUT		10	10	10	10	10	10
21	0503031613	AIR DISTRIBUTOR		02	02				
22	0502012702	BODY SUPPORT CLAMP		02	02	02	02	02	02
23	0503010481	BOLT		01	01	01	01	01	01
24	0503010025	3/8 SPRING WASHER		01	01	01	01	01	01
25	0503010026	3/8" NUT		01	01	01	01	01	01
26	0571013731	VACUUM GAUGE SUPPORT		01	01	01	01	01	01
27	0503010371	5/16" X 1" BOLT		02	02	02	02	02	02
28	0501010984	FLAT WASHER		02	02	02	02	02	02
29	0501010694	FLAT WASHER		02	02	02	02	02	02
30	0503013584	VACUUM GAUGE		01	01	01	01	01	01
31	0521063404	SUPPORT FIXER HOSE		01	01	01	01	01	01


Item	Code	Description	See page	09	11	13	15	17	19
32	0501010452	5/8" X 5" BOLT		01	01	01	01	01	01
33	0501081811	3/8 X 7100 TC-TM HOSE ASSY		01	01	01	01	01	01
34	0501081810	HOSE		02	02	02	02	02	02
35	0501060409	HOSE SOPPORT ASSY		01	01	01	01	01	01
36	0503011255	3/4" LOCK NUT		01	01	01	01	01	01
37	0503031611	AIR DISTRIBUTOR						02	
38	0503031612	AIR DISTRIBUTOR						02	
39	0503031613	AIR DISTRIBUTOR						02	
40	0503031885	AIR DISTRIBUIDOR						02	
41	0503031436	AIR DITRIBUTOR PUMP		05	06	07	08	09	10



Item	Code	Description	See page	09	11	13	15	17	19
01	0561016876	MOTOR SHAFT		02					
02	0511047069	SIDE TRANSMISSION DRIVING		01	01	01	01	01	01
03	0511047070	LH SIDE TRANSMISSION DRIVING		01	01	01	01	01	01
04	0501110639	AGRIC BEARING		02	02	02	02	02	02
05	0503010300	5/32" X 1" COTTERPIN		02	02	02	02	02	02
06	0503011099	GREASE FITTING		02	02	02	02	02	02
07	0511014218	3/4" X 28.7" SQUARE SHAFT		02	02	02	02	02	02
08	0521061852	LEVER RATCHET		02	02	02	02	02	02
09	0521061849	DISASSEMBLE LEVER		02	02	02	02	02	02
10	0503010140	1/8" X 3/4" COTTERPIN		08	08	08	08	08	08
11	0501056271	GEAR BOX CLOSE BEARINGONE		02	02	02	02	02	02
11A	0502012310	GEAR BOX CLOSE BEARING		02	02	02	02	02	02
11B	0503013462	BEARING WITH BALL BEARING		02	02	02	02	02	02
11C	0503011105	SEAL RING		02	02	02	02	02	02
12	0501058236	BEARING WITH 21Z GEAR		02	02	02	02	02	02
12A	0511062169	21Z P 1/2" GEAR		08	08	08	08	08	08
12B	0503011410	ROLLER BEARING		14	14	14	14	14	14
12C	0503011105	SEAL RING		10	10	10	10	10	10
12D	0551019171	CHAIN TIGHTENER AXLE		02	02	02	02	02	02
12E	0503010406	501025 CLAMPING RING (FOR AXLE)		12	12	12	12	12	12
12F	0501010163	5/8" X 4-1/2" BOLT		02	02	02	02	02	02
12G	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		02	02	02	02	02	02
13	0501058265	LOWER CHAIN TENSIONER ASSY		02	02	02	02	02	02
13A	0531017086	50 AXLETIGHTENER		02	02	02	02	02	02
13B	0501010197	5/8" X 3-1/2" BOLT		02	02	02	02	02	02
13C	0501012140	FLAT WASHER		02	02	02	02	02	02
13D	0503010027	SPRING WASHER		02	02	02	02	02	02
13E	0503010013	5/8" NUT		02	02	02	02	02	02
14	0561018212	ARTICULAT SLEEVE		02	02	02	02	02	02
15	0503010547	1/2" X 4" BOLT		02	02	02	02	02	02
16	0511017302	FLAT WASHER		02	02	02	02	02	02


Item	Code	Description	See page	09	11	13	15	17	19
17	0503010019	1/2" SPRING WASHER		02	02	02	02	02	02
18	0503010060	1/2" NUT		02	02	02	02	02	02
19	0561017281	ARTICULACION ARM		02	02	02	02	02	02
20	0511050385	BEARING WITH		02	02	02	02	02	02
20A	0521061843	20Z DOBLE GEAR		02	02	02	02	02	02
20B	0551019175	DOUBLE GEAR AXLE		02	02	02	02	02	02
20C	0501010163	5/8" X 4-1/2" BOLT		02	02	02	02	02	02
20D	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		06	06	06	06	06	06
21	0511050127	CHAIN TENSIONER SUPPORT		02	02	02	02	02	02
21A	0561015677	CHAIN TIGHTENER AXLE		02	02	02	02	02	02
21B	0501010452	5/8" X 5" BOLT		02	02	02	02	02	02
21C	0501012140	FLAT WASHER		04	04	04	04	04	04
22	0501053126	FERTILIZER CHAIN TENSIONER ASSY		02	02	02	02	02	02
22A	0501011234	5/8" X 3" BOLT		01					
22B	0521018415	TIGHTENER AXLE		01					
23	0561017275	LEVER FIXER		02	02	02	02	02	02
24	0503010237	3/8" X 1" BOLT		06	06	06	06	06	06
25	0503010025	3/8 SPRING WASHER		06	06	06	06	06	06
26	0503010026	3/8" NUT		06	06	06	06	06	06
27	0561017280	LH LEVER DISASSEMBLE (COP 11)		01	01	01	01	01	01
28	0561017279	RH LEVER DISASSEMBLE (COP 11)		01	01	01	01	01	01
29	0503030093	TRACTION SPRING		02	02	02	02	02	02
30	0561017273	FIXER SPRING		02	02	02	02	02	02
31	0561017282	LOWER LEVER		02	02	02	02	02	02
32	0561016797	SLEEVE UNION LEVER ARM/DESARM		02	02	02	02	02	02
33	0503011082	C1/2" X 1.3/4" BOLT		02	02	02	02	02	02
34	0511017302	FLAT WASHER		04	04	04	04	04	04
35	0503010019	1/2" SPRING WASHER		04	04	04	04	04	04
36	0503010060	1/2" NUT		04	04	04	04	04	04
37	0521010773	0.37" X 1.18" COUPLING SHAFT		04	04	04	04	04	04
38	0501010984	FLAT WASHER		04	04	04	04	04	04
39	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		02	02	02	02	02	02
40	0503012717	40-1 CHAIN X 101 LINK + MENDING		02	02	02	02	02	02
41	0503016737	40-1 X 114 CHAIN LINK + REDUCION		02	02	02	02	02	02
42	0503011721	40-1 CHAIN X 122 LINK + REDUCTION		02	02	02	02	02	02
43	0511053366	CHAIN TENSIONER		02	02	02	02	02	02
43A	0531019479	AXLE CHAIN GEAR		02	02	02	02	02	02
43B	0503031805	11Z 1/2" GEAR		02	02	02	02	02	02
43C	0503010302	501019 SEAL RING		02	02	02	02	02	02
43D	0511017302	FLAT WASHER		04	04	04	04	04	04
44	0501053608	BEARING ASSY WITH GEAR 20Z & 5/8" HEX AXLE		02	02	02	02	02	02
44A	0501053609	5/8 DOUB BEARING OF THE SEED TRANSM		02	02	02	02	02	02
44Aa	0502011987	DOUBLE HOUSING BEARING		02	02	02	02	02	02
44B	0511063109	UPER FIXING BASE		02	02	02	02	02	02
44C	0503010365	NUT		04	04	04	04	04	04
45	0531016944	RIGHT 5/8" X 96" HEX AXLE		01					
46	0531016945	LEFT 5/8" X 90" HEX AXLE		01					
47	0511063123	BUSHING WITH NUT		04	04	04	04	04	04
48	0503010834	1/2 X 1 BOLT		04	04	04	04	04	04
49	0503030679	1/2" X 1-1/4" BOLT		04	04	04	04	04	04
50	0511050639	RIGHT GEAR BOX ASSY		01	01	01	01	01	01
51	0511050640	LEFT GEAR BOX ASSY		01	01	01	01	01	01
52	0503011953	5/16" X 1" BOLT		04	04	04	04	04	04
53	0501010694	FLAT WASHER		12	12	12	12	12	12
54	0503010179	SPRING WASHER		08	08	08	08	08	08
55	0503010337	5/16" NUT		08	08	08	08	08	08
56	0561014215	BEARING COVER LOWER ROW FRAME		02	02	02	02	02	02
57	0503011751	REDUCTION		06	06	06	06	06	06
58	0503011750	AMENDMENT WITH LOCK		06	06	06	06	06	06

Item	Code	Description	See page	09	11	13	15	17	19
59	0541012846	5/8" X 3650 AXLE HEX					01		
60	0561016881	MOTOR SHAFT		02		02	02	02	
61	0561016795	2775 MOTOR SHAFT			02				
62	0561018617	5/8" X 4250 AXLE HEX					01		
63	0561018616	5/8" X 4100 AXLE HEX					01		
64	0531016942	5/8 X 2050 HEX AXLE		01					
65	0531016943	5/8" X 75" AXLE HEX		01					
66	0531016946	5/8" X 114" AXLE HEX			01				
67	0531016947	LEFT 5/8" X 108" AXLE HEX			01				
68	0531016948	RIGHT 5/8" X 131" AXLE HEX				01			
69	0531016949	LEFT 5/8" X 125" AXLE HEX				01			
70	0541012845	5/8" X 3800 AXLE HEX					01		




Item	Code	Description	See page	DIR/ESQ
00	0511050639	RIGHT GEAR BOX ASSY		01
00A	0511050640	LEFT GEAR BOX ASSY		01
01	0501058212	RH GEAR		01
01A	0511069565	LEFT GEAR BOX		01
01B	0502011758	REAR TENSIONER LEVER		02 02
01C	0503010292	0.2" X 1.6" SPRING PIN		09 09
01D	0511061794	CHAIN TENSIONER		01 01
01E	0503031367	SPRING		01 01
01F	0511060392	CHAIN TENSIONER		01 01
01G	0503031366	RH TORSION SPRING		01 01
02	0501058213	LH GEAR BOX		01
02A	0511069566	LEFT GEAR BOX		01
03	0501056443	BEARING ASSY GEAR BOX		02 02
03A	0501056444	BEARING WITH BALL BEARING		02 02
03Aa	0502011697	BEARING OF THE GEAR BOX		02 02
03Ab	0503011105	SEAL RING		07 07
04	0503011953	5/16" X 1" BOLT		16 16
05	0501010694	FLAT WASHER		16 16
06	0503010179	SPRING WASHER		16 16
07	0503010337	5/16" NUT		16 16
08	0501056447	CENTRAL BEARING GEAR BOX		01 01
08A	0502011978	HOUSING CENTRAL BEARING		01 01
08B	0503013462	BEARING WITH BALL BEARING		09 09
09	0503031805	11Z 1/2" GEAR		06 06
10	0503010302	501019 SEAL RING		04 04
11	0501048790	AXLE WITH LINK ASSY		02 02
11A	0521012476	GEAR BOX LEVER AXLE		02 02
11B	0503031369	LINK		02 02
12	0503010002	1800 GREASE FITTING		02 02
13	0551018209	DRIVING AXLE		01 01
14	0521018259	DRIVEN AXLE		01 01

Item	Code	Description	See page	DIR/ESQ
15	0551018210	DRIVEN AXLE		01 01
16	0551018211	INTERM SHAFT		01 01
17	0503030303	SUPPORT WASHER		05 05
18	0501056271	GEAR BOX CLOSE BEARINGONE		05 05
18A	0502012310	GEAR BOX CLOSE BEARING		05 05
19	0511060396	DRIVE/DRIVEN AXLE CONE		04 04
20	0503012389	1/2 BALL		04 04
21	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04 04
22	0503010060	1/2" NUT		06 06
23	0503010395	1/2" X 1-1/4" BOLT		04 04
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02 02
25	0511067501	26Z GEAR		01 01
26	0503012204	40-1 CHAIN X 82 LINK + RED		02 02
27	0503012713	40-1 CHAIN X 45 LINK + MEN		01 01
28	0501054655	CHAIN TENSIONER ASSY		02 02
28A	0531019479	AXLE CHAIN GEAR		02 02
28B	0511017302	FLAT WASHER		02 02
28C	0503010019	1/2" SPRING WASHER		02 02
29	0501010984	FLAT WASHER		01 01
30	0503010025	3/8 SPRING WASHER		01 01
31	0503010256	3/8" X 3/4" BOLT		01 01
32	0521062072	33Z GEAR		01 01
33	0503030275	AGRICULTURAL BEARING		01 01
34	0521018630	1.4" X SQUARE 0.8" WASHER		03 03




Item	Code	Description	See page	09 11 13 15 17 19
01	0511054323	FRONT SEED SHORT ROW WITH CARDAN		04 05 06 05 08 09
02	0511054324	FRONT SEED LONG ROW WITH CARDAN		05 06 07 06 09 10
03	0521041901	REAR RIGHT SEED ROW		05 06 07 08 09 10
04	0521041902	REAR LEFT SEED ROW		04 05 06 07 08 09
05	0511053023	LONG FERTILIZER LINE	16	04 05 06 07 08 09
06	0511053024	FERTILIZER SHORT LINE	18	05 06 07 08 09 10
07	0511051818	18" BLADE DISC ASSY	19	09 11 13 15 17 19
08	0511051819	20 BLADE DISC ASSY	21	09 11 13 15 17 19
09	0501052976	15 X 15 RIGHT FERT UNAL DOUB-DISC ASSY		04 05 06 07 08 09
10	0501052977	15 X 15 LEF FERT UNAL DOUB-DISC ASSY		05 06 07 08 09 10
11	0501110231	SCARIFIER HEAD WITH SPIKE 0061		09 11 13 15 17 19




Item	Code	Description	See page	CT.LG.
00	0511054323	FRONT SEED SHORT ROW WITH CARDAN		01
00A	0511054324	FRONT SEED LONG ROW WITH CARDAN		01
01	0521063525	SHORT SEED ROW FRONT		01
02	0521063531	SEED ROW ARM		02 02
03	0521063526	SEED LINE REAR FRAME		01 01
04	0571012444	SCRAPER COURSE LINE		01 01
05	0571012443	COUPLING SHAFT		01 01
06	0571012442	COUPLING SHAFT		03 03
07	0521063522	PRESS ROWL ADJUSTMENT LEVER		01 01
08	0521063523	ADJUSTMENT LOCK		01 01
09	0511052412	SEED ROW SIDE BEARING		02 02
09A	0502012718	BEARIN BODY		02 02
09B	0503012882	BALL BEARING		02 02
09C	0503011105	SEAL RING		02 02
10	0571012441	TRANSMISSION AXLE		01 01
11	0511054318	TRANSMISSION HUB	40	01 01
12	0511052393	BEARING FOLLOWER ROW ASSY		01 01
12A	0521063532	BEARING FOLLOWER ROW ASSY		01 01
12B	0503011410	ROLLER BEARING		01 01
12C	0503011105	SEAL RING		01 01
12D	0571012450	COP FLEX AXLE		01 01
12E	0571012459	COP FLEX AXLE		01 01
12F	0503010406	501025 CLAMPING RING (FOR AXLE)		02 02
12G	0503015356	SPRING PIN		01 01
12H	0503010691	1/4" GREASE FITTING		01 01
13	0521041482	BEARING ROW SEED ASSY		01 01
13A	0511052413	ROW SEED BEARING		01 01
13Aa	0521063530	ROW BEARING		01 01
13Ab	0503011410	ROLLER BEARING		02 02
13Ac	0503011105	SEAL RING		01 01
13Ad	0551017559	BEARING AXLE BODY		01 01

Item	Code	Description	See page	CT.LG.
13Ae	0503010406	501025 CLAMPING RING (FOR AXLE)		02 02
13B	0501056296	UNIVERSAL JOINT ASSY		01 01
13C	0551017540	5/8" X 73 AXLE HEX		01 01
13D	0561014778	HEX UNIVERSAL JOINT		01 01
13E	0503011855	0.2" X 1.8" SPRING PIN		03 03
13F	0503013958	1/4" X 1" BOLT		01 01
13G	0571012452	HEX AXLE		01 01
13H	0503032984	HOOD HEX AXLE ROW		01 01
13I	0503013100	NYLON CLAMP		01 01
14	0531019479	AXLE CHAIN GEAR		01 01
15	0541016454	PULLEY		01 01
16	0503011828	FLAT WASHER		01 01
17	0503010019	1/2" SPRING WASHER		01 01
18	0503010060	1/2" NUT		01 01
19	0521063524	FRAME FRONT LINE SEED		01
20	0561017947	17Z GEAR WITH HEX HOLE		01 01
21	0503030024	1.7" X10.2" X 0.2" EXTENSION SPRING		02 02
22	0511050609	BEARING WITH 17Z GEAR ASSY		01 01
22A	0502011697	BEARING OF THE GEAR BOX		01 01
22B	0503011410	ROLLER BEARING		01 01
22C	0503011105	SEAL RING		01 01
22D	0503010406	501025 CLAMPING RING (FOR AXLE)		01 01
22E	0561017909	17Z GEAR WITH HEX HOLE		01 01
23	1902010175	HITCH CLAMP		01 01
24	0503016460	5/8" X 4.1/2" BOLT		02 02
25	0501012140	FLAT WASHER		02 02
26	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S		06 06
27	0571012448	LOCK SLEEVE AXLE REGULATION		01 01
28	0571012449	CONTROL AXLE		01 01
29	0531015151	0.6" X 1" X 2.4" SLEEVE		08 08
30	0531015184	FLAT WASHER		08 08
31	0501010422	5/8" X 6-1/2" BOLT		04 04
32	0503030168	HAIR PIN		04 04
33	0503011953	5/16" X 1" BOLT		10 10
34	0501010694	FLAT WASHER		10 10
35	0503010179	SPRING WASHER		10 10
36	0503010337	5/16" NUT		10 10
37	0503010131	3/16" X 1-1/2" COTTERPIN		01 01
38	0503016502	40-1 CHAIN X 61 LINK + REDUCTION		01 01
39	0503011378	M6 X 1" BOLT		02 02
40	0503015110	M06 SPRING WASHER		02 02
41	0503010002	1800 GREASE FITTING		04 04




Item	Code	Description	See page	QT
00	0511054318	TRANSMISSION HUB	40	01
01	0571014728	TRANSMISSION HUB		01
02	1902012464	BOX TRANSMISSION COVER		01
03	0503012861	6006 2RS BALL BEARING		02
04	0503011410	ROLLER BEARING		02
05	0503010143	SPRING WASHER		03
06	0503011378	M6 X 1" BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0502040857	CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503010004	1890 GREASE FITTING		01



Item	Code	Description	See page	Dir/Esq.
00	0521041901	REAR RIGHT SEED ROW		01
00A	0521041902	REAR LEFT SEED ROW		01
01	0521040111	DEP CONT WHEELS PRESS WHEELS ASSY		01 01
02	0501052538	DEPTH CONTROL WHEEL RUBBER BAND		02 02
03	0511054333	COMPACT WHEEL RIGHT WITH BEARING		01 01
04	0511054334	COMPACT WHEEL LEFT WITH BEARING		01 01
05	0503032124	ADHESIVE LABEL		01 01
06	0521042714	PNEUMATIC SEED DISTRIBUTOR		01 01
07	0503011404	3/8" X 1-3/4" BOLT		04 04
08	0503010025	3/8 SPRING WASHER		09 09
09	0503010026	3/8" NUT		08 08
10	0501056143	SEED SYSTEM ASSY		01 01
10A	0503031508	COVER GREEN BEAM SEED YELLOW		01 01
10B	0502011760	SEED SILO SUPPORT		01 01
10C	0531010631	SEED BEAM CLAMP		04 04
10D	0503010371	5/16" X 1" BOLT		04 04
10E	0501010694	FLAT WASHER		04 04
10F	0503010179	SPRING WASHER		04 04
10G	0503010337	5/16" NUT		04 04
11	0503013162	DISC 2450 CORN		01 01
12	0511050809	SEMIFINISHED FAST CLOSING SET		01 01
12A	0541016855	SPEED ??LOCK LEVER ASSY		01 01
12B	0561019318	PRISONER CLOSING FAST		01 01
12C	0551018050	FAST BOLT GUIDE AXLE		02 02
12D	0503010257	1/8" X 1" COTTERPIN		02 02
12E	0561019270	FAST BOLT ADJUSTMENT		01 01
13	0521064369	HOSE HOLDER		01 01
14	0521060631	FIXING BASE BOX		01 01
15	0501010942	3/8" X 1-1/4" BOLT		04 04
16	0531018349	SEED FLOW SWITCH PNEUMATIC SYSTEM		01 01
17	0501011643	3/8 X 1"BOLT		01 01




Item	Code	Description	See page	Dir/Esq.
18	0501010984	FLAT WASHER		01 01
19	0503010209	3/8" UNC BUTTERFLY NUT		01 01
20	0561017939	AIR CONDUCTOR		01 01




Item	Code	Description	See page	QT
00	0521042714	PNEUMATIC SEED DISTRIBUTOR		01
01	0561012486	LATERAL COVER		01
02	0511017186	SEED LEVEL REGULATOR		01
03	0511017303	FLAT WASHER		01
04	0503014141	M6 X 1 X 20 BOLT		01
05	0503011776	M6 SELF ADJUSTINGNUT		01
06	0503011817	UPPER SELECTOR		01
07	0502020559	UPPER SELECTOR ACTUATOR		01
08	0531014481	0.2" X 0.6" AXLE		01
09	0503011821	CRINKLE WASHER		01
10	0501067818	SCALE INDICATOR WITH PIN		01
11	0503011820	CRINKLE WASHER		02
12	0503011823	0.1" X 0.6" SPRING PIN		02
13	0511017219	SCALE INDICATOR GUIDE		01
14	0503011378	M6 X 1" BOLT		02
15	0511017303	FLAT WASHER		02
16	0503010143	SPRING WASHER		02
17	0503011810	M6 X 1" BUTTERFLY BOLT		01
18	0511017303	FLAT WASHER		01
19	0503031058	UPPER SELECTOR SCALE		01
20	0503011825	M4 X 8" BOLT		02
21	0503011840	FLAT WASHER		02
22	0501110311	LOWER SELECTOR ASSY		01
23	0503011813	M6 X 1.2" BOLT		01
24	0511016220	LOWER SELECTOR INDICATOR		01
25	0503011815	TOOTHED WASHER		01
26	0503012445	M6 C/ABA 1.20" BUTTERFLY NUT		01
27	0503011104	M6 X 1" BOLT		03
28	0503013179	PNEUMATIC SEED DISTRIBUTOR VISOR		01
29	0503012445	M6 C/ABA 1.20" BUTTERFLY NUT		03
30	0561012741	SEED DRAINER COVER		01

Item	Code	Description	See page	QT
31	0503011370	DISC 6440 MIDDLE SOYBEAN		01
32	0503011809	M12 KNOB		01
33	0503011828	FLAT WASHER		01
34	0503011827	504.100 CLAMPING RING (FOR HOLE)		01
35	0511050075	PNEUMATIC DISTRIBUTOR SUPPORT		01
35A	0501110649	INNER SUPPORT NEUMATIC SEED DISTR		01
35Aa	0502012599	PNEUMATIC SEED DISTRIBUTOR SUPPORT		01
35Ab	0503011771	6008 2RS BALL BEARING		01
35Ac	0502012649	18Z CONICAL GEAR 34 TEETH		01
35Ad	0503011770	SEAL # V-75 A		01
35B	0503012849	2-129 N 3006 9B O'RING		02
35C	0503010217	501040 CLAMPING RING (FOR AXLE)		01
35D	0503033121	PNEUMATIC SWITCH		01
35E	0502050003	SUPPORT INTERNAL DISC SEED VULCANIZ		01
35F	0503011295	M 8 X 1,25 X 25 BOLT		01
35G	0503010427	METRIC M8 X P.0.5" NUT		01
36	0511015627	SEED DISC LEVER		01
37	0511053903	DRIVE SHAFT	43	01



Item	Code	Description	See page	QT
00	0511053903	DRIVE SHAFT	43	01
01	0502012738	SUPPORT CARDAN		01
02	0503033800	PNEUMATIC JOINT SEALING		03
03	0503011294	M 8 X 1,25 X 20 BOLT		03
04	0503010025	3/8 SPRING WASHER		03
05	0571012413	POINT TRANSMISSION		01
06	0502012648	10Z CONICAL GEAR		01
07	0503015356	SPRING PIN		01
08	0501056296	UNIVERSAL JOINT ASSY		01
09	0571012458	HEX AXLE		01
10	0503011855	0.2" X 1.8" SPRING PIN		02
11	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	DIR/ESQ.
00	0511054333	COMPACT WHEEL RIGHT WITH BEARING		01
00A	0511054334	COMPACT WHEEL LEFT WITH BEARING		01
01	0501052908	COMPACTOR WHEEL WITH BEARING		01 01
01A	0502011919	PRESS WHEEL HUB		01 01
01B	0502011877	PRESS WHEEL HUB		01 01
01C	0521018922	PRESS WHEEL PASSANG AXLE		02 02
01D	0521018921	DUST CLOAK		02 02
01E	0503010691	1/4" GREASE FITTING		01 01
01F	0503012734	SEAL 01556 BR		02 02
01G	0503010269	6204 BALL BEARING		02 02
01H	0521018928	PRESS WHEEL RIM		02 02
01I	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01 01
01J	0503010295	5/16" X 5/8" BOLT		09 09
01K	0503010179	SPRING WASHER		09 09
01L	0503010337	5/16" NUT		06 06
01M	0503010371	5/16" X 1" BOLT		03 03
01N	0503013816	5/16" LOCKNUT		03 03
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03 03
04	0503012136	1 X 9 BOLT		01
05	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
06	0503016864	LH 1/2" LOCK NUT		01

This image shows a single page from a notebook or ledger. The page is white with rounded corners and features horizontal ruling lines spaced evenly down its length. There are no margins, text, or other markings on the page.





MARCHESAN IMPLEMENTOS E MÁQUINAS AGRÍCOLAS TATU S.A.

AV. Marchesan, 1979 - Post office box, 131 - CEP 15994-900 - Matão - SP - Brazil

Phone +55 16.3382-8282

(FAX Parts) + 55 16.3382. 8297 - (Export) + 55 16.3382.1003

e.mail: tatu@marchesan.com.br www.marchesan.com.br

Technical Publications: Elaboration

LUIZ CANDIDO

Contact Catálogo:

E-mail = jgaspari@marchesan.com.br

Technical Publications: Revision

JOSÉ DOMINGOS GASPARI

**ORIGINAL PARTS
TATU**

