

PARTS CATALOG

ROW CROP PLANTERS

PST4 SUPREMA

Code: 0501091601



Series: S-0713

Rev.: 03

Date Rev.: JANEIRO/2017

**ORIGINAL PARTS
TATU**



PRODUCTS

Code	Description	
0111160744	PST4 SUP 10/9	S-0713
0111160743	PST4 SUP 10/9 D	S-0713
0111160749	PST4 SUP 10/9 D MH	S-0713
0111160746	PST4 SUP 10/9 D MM	S-0713
0111160742	PST4 SUP 10/9 H	S-0713
0111160748	PST4 SUP 10/9 H MH	S-0713
0111160745	PST4 SUP 10/9 H MM	S-0713
0111160750	PST4 SUP 10/9 MH	S-0713
0111160751	PST4 SUP 10/9 MH MTH	S-0713
0111160747	PST4 SUP 10/9 MM	S-0713
0111160793	PST4 SUP 10/9 MM DC20 MTH	S-0713
0111160794	PST4 SUP 11/10 MM DC20 MTH	S-0713
0111160796	PST4 SUP 11/11 MH	S-0713
0111160795	PST4 SUP 11/6 MH	S-0713
0111160792	PST4 SUP 11/6 MM	S-0713
0111160790	PST4 SUP 11/7 D MH	S-0713
0111160791	PST4 SUP 11/8 D MH	S-0713
0111160733	PST4 SUP 7/4	S-0713
0111160734	PST4 SUP 7/4 D	S-0713
0111160735	PST4 SUP 7/4 D MH	S-0713
0111160736	PST4 SUP 7/4 D MM	S-0713
0111160737	PST4 SUP 7/4 H	S-0713
0111160738	PST4 SUP 7/4 H MH	S-0713
0111160739	PST4 SUP 7/4 H MM	S-0713
0111160741	PST4 SUP 7/4 MH	S-0713
0111160756	PST4 SUP 7/4 MH CBRF	S-0713
0111160757	PST4 SUP 7/4 MM	S-0713
0111160758	PST4 SUP 7/5 D MH	S-0713
0111160759	PST4 SUP 7/5 MH	S-0713
0111160760	PST4 SUP 7/5 MM	S-0713
0111160761	PST4 SUP 7/6	S-0713

ATTENTION: **IMPORTANT**

MARCHESAN S/A RESERVES THE RIGHT AT ANY TIME TO MAKE IMPROVEMENTS IN THE DESIGN, MATERIAL OR SPECIFICATIONS OF MACHINERY, EQUIPMENT OR PARTS WITHOUT THEREBY BECOMING LIABLE TO MAKE SIMILAR CHANGES IN MACHINERY, EQUIPMENT OR PARTS PREVIOUSLY SOLD.

PRODUCTS


0111160762	PST4 SUP 7/6 MH	S-0713
0111160797	PST4 SUP 7/6 MH MTH	S-0713
0111160763	PST4 SUP 7/6 MM	S-0713
0111160764	PST4 SUP 7/7	S-0713
0111160784	PST4 SUP 7/7 D MH	S-0513
0111160786	PST4 SUP 7/7 D MH	S-0713
0111160766	PST4 SUP 7/7 MH	S-0713
0111160767	PST4 SUP 7/7 MM	S-0713
0111160768	PST4 SUP 8/7 MM	S-0713
0111160769	PST4 SUP 9/5	S-0713
0111160770	PST4 SUP 9/5 MH	S-0713
0111160771	PST4 SUP 9/5 MM	S-0713
0111160772	PST4 SUP 9/6 D MH	S-0713
0111160773	PST4 SUP 9/6 MH	S-0713
0111160774	PST4 SUP 9/6 MM	S-0713
0111160775	PST4 SUP 9/7	S-0713
0111160776	PST4 SUP 9/7 D MH	S-0713
0111160798	PST4 SUP 9/7 MH MTH	S-0713
0111160777	PST4 SUP 9/8	S-0713
0111160787	PST4 SUP 9/8 H DC20	S-0713
0111160778	PST4 SUP 9/8 MH	S-0713
0111160788	PST4 SUP 9/8 MH MTH	S-0513
0111160789	PST4 SUP 9/8 MH MTH	S-0713
0111160779	PST4 SUP 9/9	S-0713
0111160780	PST4 SUP 9/9 D MH	S-0713
0111160781	PST4 SUP 9/9 H MH	S-0713
0111160782	PST4 SUP 9/9 MH	S-0713
0111160783	PST4 SUP 9/9 MM	S-0713

ATTENTION: **IMPORTANT**

MARCHESAN S/A RESERVES THE RIGHT AT ANY TIME TO MAKE IMPROVEMENTS IN THE DESIGN, MATERIAL OR SPECIFICATIONS OF MACHINERY, EQUIPMENT OR PARTS WITHOUT THEREBY BECOMING LIABLE TO MAKE SIMILAR CHANGES IN MACHINERY, EQUIPMENT OR PARTS PREVIOUSLY SOLD.

INDEX


0909093338	FRAME PST4 SUPREMA		1
0909093339	ROW 11 FRAME ,PST4 SUPREMA		2
0511058449	HYDRAULIC CYLINDER		3
0511041187	HYDRAULIC CYLINDER		4
0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER		5
0511041364	DRIVE SHAFT		6
0909092761	TURBINE ASSY FOR CARDAN		7
0511052769	PRY TIRE WHEEL TREANSMISSION		8
0909093037	WHEELS ASSY		9
0909093058	FERTILIZER BEAM		10
0909093033	07/09/11 TRANSMISSION		11
0909093036	SIDE TRANSMISSION DRIVING ASSY		12
0511051434	TRANSMISSION DRIVING ASSY		13
0909093035	GEAR BOX ASSY		14
0909094696	SEED END FERTILIZER ROW ASSAY PST4 SUPREMA		15
0511053099	RH SHORT SEED ROW		16
0511053101	ARM SEED SHORT LINE		17
0501059631	RIGHT 15" X 15" SEED UNAL DOUB-DISC		18
0511053100	LH LONG SEED ROW		19
0511053102	ARM SEED SHORT LINE		20
0501059632	LH 15"X15"SEED UNAL DOUBLE DISC		21
0521042715	PNEUMATIC SEED DISTRIBUTOR		22
0521040111	DEP CONT WHEELS PRESS WHEELS ASSY		23
0511051447	CONTROL DEPTH ASSY		24
0511054333	COMPACT WHEEL RIGHT C/ BEARING		25
0511054334	COMPACT WHEEL LEFT C/ BEARING		26
0501058190	LH SHORT FERT. ROW W/DDD ASSY		27
0501058191	RH LONG FERT. ROW W/DDD ASSY		28
0511044573	18" COULTER BLADE ASSY FOR LONG ROW		29
0909094698	SEED END FERTILIZER ROW (PST4 SUPREMA)		30
0909093080	MECANIC ROW MARKER		31
0501050633	DISC ASSY FOR ROW MARKER		32
0909093103	7-9 HYDRAULIC CIRCUIT		33
0501054649	SEQUENTIAL VALVE ASSY		34
0909093054	MARKER HYDRAULIC CIRCUIT		35
0909093055	11 HYDRAULIC CIRCUIT		36
0909094592	HEX AXLE ASSEMBLY		37



Item	Code	Description	07 09
001	0511069615	PST4 7 S-1207 FRAME	07 08
002	0511069529	FRAME PST4 9 S-1207	01 01
003	0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	01 01
004	0531019171	1.25" X 7" COUPLING SHAFT	01 01
005	0521012536	COUPLING SHAFT	01 01
006	0503010523	1/4" X 2" COTTERPIN	02 02
007	0511069635	HANDRAIL	02 02
008	0511069656	HANDRAIL COP FLEX 600 9	00 02
009	0503010920	1/2" X 1.1/2" BOLT	12 12
010	0503010019	1/2" SPRING WASHER	13 13
011	0503010060	1/2" NUT	13 13
012	0551019110	LADDER RIGHT FIXER	01 01
013	0551017438	LADDER RIGHT FIXER	01 01
014	0551019109	LADDER LEFT FIXER	01 01
015	0551017437	LADDER RIGHT FIXER	01 01
016	0503010237	3/8" X 1" BOLT	04 04
017	0503010025	3/8 SPRING WASHER	15 15
018	0503010026	3/8" NUT	14 14
019	0511069636	LADDER	02 02
020	0501010096	3/8" X 2" BOLT	06 06
021	0501010984	FLAT WASHER	23 23
022	0503013357	3/8" SELF-ADJUSTING NUT	06 06
023	0503031608	AIR DISTRIBUTOR	02 00
024	0503031609	AIR DISTRIBUTOR	00 02
025	0503010365	NUT	08 08
026	0521014441	HOSE HOLDER RIGHT SUPPORT	02 02
027	0521014442	HOSE SUPPORT	04 04
028	0521018535	HOSE HOLDER LEFT SUPPORT	02 02
029	0511069725	RIGHT PLATFORM	02 00
030	0511069665	PLATFORM RIGHT PST4 9	00 02
031	0521061676	PLATFORM PROLONG	02 02
032	0511069664	PLATFORM EXTENSION LOCK	02 02
033	0503010257	1/8" X 1" COTTERPIN	06 06

Item	Code	Description	07 09
034	0511069661	PLATFORM SUPPORT PIVOT	04 02
035	0503010849	3/8" X 1-1/2" BOLT	08 08
036	0521010549	COUPLING SHAFT	04 04
037	0551019127	PLATFORM RIGHT FIXER SUPPORT	01 01
038	0551019128	PLATFORM LEFT FIXER SUPPORT	01 01
039	0503011333	COVER FIXER	02 02
040	0503010274	5/32"X 2" COTTERPIN	02 02
041	0551019115	LOCK	02 02
042	0502011530	SUPPORT	02 02
043	0502010175	HITCH CLAMP	02 02
044	0501011543	5/8" X 4" BOLT	04 04
045	0503010027	SPRING WASHER	06 06
046	0503010013	5/8" NUT	06 06
047	0511061835	PLOUGH SUPPORT	02 02
048	0501011075	PIN	02 02
049	0503030012	HAIR PIN	02 02
050	0502012328	DRAWBAR SUPPORT FRONT FIXATION	02 02
051	0502012330	SUPPORT FIXER PIVOT	04 04
052	0503011084	3/4" X 5" BOLT	08 08
053	0501010322	FLAT WASHER	08 08
054	0503010023	SPRING WASHER	08 08
055	0503010014	3/4" NUT	08 08
056	0502012329	DRAWBAR FIXATION REAR SUPPORT	02 02
057	0561014393	COUPLING SHAFT	02 02
058	0503030119	LOCK PIN	02 02
059	0511064808	DRAWBAR	01 01
060	0561019087	DRAWBAR TRANSPORT LOCK	01 01
061	0521010578	COUPLING SHAFT	01 01
062	0521010588	0.9" X 7.0" COUPLING SHAFT	01 01
063	0503030085	LOCK PIN	02 02
064	0503010002	1800 GREASE FITTING	03 03
065	0503060100	HAND BOOK COMPARTMENT	01 01
066	0503010267	NYLON CLAMP	01 01
067	0503010365	NUT	01 01
068	0501010694	FLAT WASHER	05 05
069	0503010179	SPRING WASHER	11 11
070	0503010337	5/16" NUT	09 09
071	0501065677	STRUT	02 02
072	0501054258	DRAWBAR ESTABILIZER ASSY	01 01
072A	0501069529	653 TURNBUCKLE	01 01
072B	0511062887	RIGHT TURNBUCKLE	01 01
072C	0511062888	LH TURNBUCKLE	01 01
072D	0501061056	RH LOCKNUT WITH HANDLER	01 01
073	0511052492	TRACTOR HITCH ASSY	01 01
073A	0571012608	TRACTOR HITCH	01 01
073B	0502040846	U TRACTOR HITCH	01 01
073C	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT	01 01
073D	0503010010	1/4" X 2.1/2" COTTERPIN	01 01
073E	0503010571	1/4" X 1.1/2 COTTERPIN	01 01
073F	0521010681	BUSHING COUPLING BODY	01 01
073G	0521010639	COUPLING SHAFT	01 01
073H	0503010002	1800 GREASE FITTING	01 01
073I	0503016482	BOLT	02 02
073J	0571012612	PIVOT SHAFT	01 01
073K	0503033731	COMPRESSION SPRING LEFT	02 02
073L	0503011331	3/8 BALL	02 02
073M	0501812916	FLAT WASHER	01 01
074	0511053179	TRACTOR HITCH AXLE	01 01
074A	0521064036	TRACTOR HITCH AXLE	01 01
074B	0503031035	HAIR PIN	01 01
075	0521013022	TRANSPORT LOCK	01 01
076	0501068994	0.3" X 3.1"LOCK PIN	01 01


Item	Code	Description	07 09
077	0503030168	HAIR PIN	01 01
078	0541011767	HOSE FIXATION	01 01
079	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	03 03
080	0501047895	ROD STOP	01 02
081	0501047885	ROD STOP	01 02
082	0501047886	ROD STOP	01 02
083	0501047887	ROD STOP	01 02
084	0502012702	BODY SUPPORT CLAMP	01 01
085	0521041586	TURBINE ASSY FOR CARDAN	01 01
086	0511041364	DRIVE SHAFT	01 01
087	0503010479	1/2" X 3" BOLT	01 01
088	0531016193	4" X 74" AIR CONDUCTOR	02 02
089	0521019552	5" X 188" AIR CONDUCTOR	01 01
090	0503011372	102 TO 121 CLAMP	04 04
091	0503012724	121 TO 140 CLAMP	01 01
092	0531015603	HOSE FIXATION SUPPORT	01 01
093	0503010967	5/8" X 5.1/2" BOLT	02 02
094	0501056495	TURBINE OUTPUT SOCKET	01 01
095	0503013096	5/16" X 4" BOLT	02 02
096	0503010499	5/16" UNC BUTTERFLY NUT	02 02
097	0503031436	AIR DISTRIBUTOR PUMP	06 06
098	0521062318	LEFT PLATFORM	01 01
099	0521062323	PLATFORM LEFT PST4 9	01 01
100	0503012555	7/16" X 2" BOLT	04 04
101	0503010180	7/16" SPRING WASHER	04 04
102	0909094592	HEX AXLE ASSEMBLY	01 01




Item	Code	Description	QT
01	0511069616	PST4 SUPREMA FRAME	01
02	0511041187	HYDRAULIC CYLINDER	02
03	0521012538	1.2" X 3.5" COUPLING SHAFT	02
04	0521012536	COUPLING SHAFT	02
05	0503010523	1/4" X 2" COTTERPIN	04
06	0511069660	HANDRAIL COP FLEX 600 11	02
07	0503010920	1/2" X 1.1/2" BOLT	12
08	0503010019	1/2" SPRING WASHER	13
09	0503010060	1/2" NUT	13
10	0551019110	LADDER RIGHT FIXER	01
11	0551017438	LADDER RIGHT FIXER	01
12	0551019109	LADDER LEFT FIXER	01
13	0551017437	LADDER RIGHT FIXER	01
14	0503010237	3/8" X 1" BOLT	07
15	0503010025	3/8 SPRING WASHER	14
16	0503010026	3/8" NUT	12
17	0511069636	LADDER	02
18	0501010096	3/8" X 2" BOLT	06
19	0501010984	FLAT WASHER	06
20	0503013357	3/8" SELF-ADJUSTING NUT	06
21	0511069718	PLATFORM RIGHT PST4 11	02
22	0521061676	PLATFORM PROLONG	02
23	0511069664	PLATFORM EXTENSION LOCK	02
24	0503010257	1/8" X 1" COTTERPIN	02
25	0511069661	PLATFORM SUPPORT PIVOT	04
26	0503010849	3/8" X 1-1/2" BOLT	08
27	0521010549	COUPLING SHAFT	04
28	0503010257	1/8" X 1" COTTERPIN	04
29	0502012740	PLATFORM RIGHT FIXER SUPPORT	01
30	0502012739	PLATFORM LEFT FIXER SUPPORT	01
31	0503011333	COVER FIXER	02
32	0503010274	5/32"X 2" COTTERPIN	02
33	0551019115	LOCK	02

Item	Code	Description	QT
34	0502011530	SUPPORT	02
35	0502010175	HITCH CLAMP	02
36	0501011543	5/8" X 4" BOLT	04
37	0503010027	SPRING WASHER	06
38	0503010013	5/8" NUT	06
39	0511061835	PLOUGH SUPPORT	02
40	0501011075	PIN	02
41	0503030012	HAIR PIN	02
42	0502012328	DRAWBAR SUPPORT FRONT FIXATION	04
43	0502012330	SUPPORT FIXER PIVOT	08
44	0503011084	3/4" X 5" BOLT	16
45	0501010322	FLAT WASHER	16
46	0503010023	SPRING WASHER	16
47	0503010014	3/4" NUT	16
48	0502012329	DRAWBAR FIXATION REAR SUPPORT	04
49	0561014393	COUPLING SHAFT	04
50	0503030119	LOCK PIN	04
51	0511064808	DRAWBAR	01
52	0561019087	DRAWBAR TRANSPORT LOCK	01
53	0521010578	COUPLING SHAFT	01
54	0521010588	0.9" X 7.0" COUPLING SHAFT	01
55	0503030085	LOCK PIN	02
56	0503010002	1800 GREASE FITTING	03
57	0521014441	HOSE HOLDER RIGHT SUPPORT	02
58	0521018535	HOSE HOLDER LEFT SUPPORT	02
59	0503031610	AIR DISTRIBUTOR	02
60	0521014442	HOSE SUPPORT	04
61	0503010365	NUT	08
62	0503060100	HAND BOOK COMPARTMENT	01
63	0503010267	NYLON CLAMP	01
64	0503010365	NUT	01
65	0501010694	FLAT WASHER	01
66	0503010179	SPRING WASHER	01
67	0503010337	5/16" NUT	01
68	0521041586	TURBINE ASSY FOR CARDAN	01
69	0511041364	DRIVE SHAFT	01
70	0503010479	1/2" X 3" BOLT	01
71	0531016193	4" X 74" AIR CONDUCTOR	02
72	0521019552	5" X 188" AIR CONDUCTOR	01
73	0503011372	102 TO 121 CLAMP	04
74	0503012724	121 TO 140 CLAMP	01
75	0531015603	HOSE FIXATION SUPPORT	01
76	0503010967	5/8" X 5.1/2" BOLT	02
77	0501054258	DRAWBAR ESTABILIZER ASSY	01
77A	0501069529	653 TURNBUCKLE	01
77B	0511062887	RIGHT TURNBUCKLE	01
77C	0511062886	CONNECTION T	01
77D	0501061056	RH LOCKNUT WITH HANDLER	01
78	0511054601	TRACTOR HITCH	01
78A	0503010002	1800 GREASE FITTING	01
78B	0503016482	BOLT	02
78C	0502040846	U TRACTOR HITCH	01
78D	0571012612	PIVOT SHAFT	01
78E	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT	01
78F	0503010010	1/4" X 2.1/2" COTTERPIN	01
78G	0521010681	BUSHING COUPLING BODY	01
78H	0521010639	COUPLING SHAFT	01
78I	0503010571	1/4" X 1.1/2 COTTERPIN	01
78J	0503033731	COMPRESSION SPRING LEFT	02
78K	0503010396	501060 CLAMPING RING (FOR AXLE)	01
78L	0503011331	3/8 BALL	02
78M	0501110778	TRACTOR HITCH	01


Item	Code	Description	QT
79	0511053179	TRACTOR HITCH AXLE	01
79A	0521064036	TRACTOR HITCH AXLE	01
79B	0503031035	HAIR PIN	01
80	0521013022	TRANSPORT LOCK	02
81	0501068994	0.3" X 3.1"LOCK PIN	02
82	0503030168	HAIR PIN	02
83	0541011767	HOSE FIXATION	01
84	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	03
85	0501047895	ROD STOP	02
86	0501047885	ROD STOP	02
87	0501047886	ROD STOP	02
88	0501047887	ROD STOP	02
89	0502012702	BODY SUPPORT CLAMP	01
90	0503031436	AIR DITRIBUTOR PUMP	06
91	0501056495	TURBINE OUTPUT SOCKET	01
92	0503013096	5/16" X 4" BOLT	02
93	0503010499	5/16" UNC BUTTERFLY NUT	02
94	0521062324	PLATFORM LEFT PST4 11	01
95	0501065677	STRUT	02
96	0503012555	7/16" X 2" BOLT	04
97	0503010180	7/16" SPRING WASHER	04
98	0909094592	HEX AXLE ASSEMBLY	01




Item	Code	Description	QT
01	0521066635	TURNBUCKLE	01
02	0511062810	2.5" X 15"CYLINDER CASE	01
03	0503030385	PLUG	02
04	0502012837	PISTON	01
05	0503011109	2-119 N 3006-9B O'RING	01
06	0503018005	RING	01
07	0503018003	GASKET	01
08	0502010471	MOBILE COVER	01
09	0581010668	RING SUPPORT	01
10	0503010163	D-1500 SCRAPER RING	01
11	0503018004	RING	01
12	0503018163	BACK-UP RING	02
13	0503018162	O'RING	02




Item	Code	Description	QT
01	0511064052	4" X 12.1" CYLINDER CASE	01
02	0511064053	SLEEVE 2" X 14" TURNBUCLE	01
03	0502010017	4" HEAD	01
04	0502010778	2" X 4.2" RING SUPPORT	01
05	0503010039	D-2000 SCRAPER RING	01
06	0503010991	PACKING 1870-2000-375-B	01
07	0503010952	W2-2250-500 PK RING G.E	01
08	0503030385	PLUG	01
09	0503010338	2-342 N 3006-9B O'RING	01
10	0503010345	2-218 N 3006-9B O'RING	01
11	0502010992	2.0" X 4.0" PISTON	01
12	0503010043	PACKING 3750-3250	02
13	0503010994	W2-4000-500 PK RING G.E	01
14	0503010817	1-1/4" SELF-ADJUSTING NUT	01
15	0503010003	1845 GREASE FITTING	01



Item	Code	Description	QT
01	0511064055	5" X 15" CYLINDER CASE	01
02	0511064056	BUSHING 2" X 14" TURNBUCLE	01
03	0502010382	5" HEAD	01
04	0502012227	50,80 X 127 RING SUPPORT	01
05	0503010039	D-2000 SCRAPER RING	01
06	0503010991	PACKING 1870-2000-375-B	01
07	0503010952	W2-2250-500 PK RING G.E	01
08	0503010351	2-425 N 3006-9B O-RING	01
09	0503011062	8-425 BACK-UP RING	01
10	0502010963	2.0" X 5.0" PISTON	01
11	0503010552	PACKING 3750-4250-625-B	02
12	0503010345	2-218 N 3006-9B O-RING	01
13	0503010974	W2-5000-500 PK RING G.E	01
14	0503010817	1-1/4" SELF-ADJUSTING NUT	01
15	0503010003	1845 GREASE FITTING	01
16	0503030385	PLUG	02




Item	Code	Description	QT
01	0501055638	HOMO JOINT WITH FEMALE BUSHING	01
01A	0503012607	TRACTOR HOMOCINETIC TERMINAL	01
01Aa	0521010638	0.5" X 3.3" QUIC HITCH COUPL SHAFT	01
01Ab	0503030518	0.5"X1.0"X 0.1" COMPRESSION SPRING	01
01Ac	0503010140	1/8" X 3/4" COTTERPIN	01
01B	0503012605	CROSSPIECE	02
01C	0503012606	CENTER BODY	01
01D	0503012604	HOMO TERMINAL W/ FEMALE BUSHING	01
01E	0503012618	2.1" X 2.0" X 31" TRIAN FEMALE TUB	01
01F	0503010843	0.4" X 3.3" SPRING PIN	01
01G	0503011878	0.2" X 3.3" SPRING PIN	01
02	0501055639	UNIVERSAL JOINT	01
02A	0503013132	CC292 TERMINAL	01
02B	0503012096	CROSSPIECE	01
02C	0503013187	TERMINAL	01
02D	0503012619	1.8" X 1.7" X 31" TRIAN MALE TUB	01
02E	0503011069	0.4" X 2.8" SPRING PIN	01
02F	0503011805	0.2" X 2.8" SPRING PIN	01
03	0503013189	PROTECTION ASSY	01
04	0503012023	CHAIN FOR UNIV JOINT PROTECTION	01




Item	Code	Description	QT
01	0511061094	TURBINE SUPPORT	01
02	0501053716	BEARING ASSY OF THE LARGER FAN	01
02A	0502012016	CHAIN TENSIONER SUPPOT	01
02B	0503012778	MIDDLE LARGER AXLE	01
02C	0531010881	INTERMEDIARY UPPER SLEEVE	01
02D	0503012689	6306 DDU BEARING	02
02E	0503010325	VCA-118 VALVE	03
03	0503010920	1/2" X 1.1/2" BOLT	02
04	0511017302	FLAT WASHER	02
05	0503010395	1/2" X 1-1/4" BOLT	02
06	0503011336	1/2" HEX SELF ADJUSTING NUT	04
07	0501053886	PULLEY ASSY WITH FREE ROT	01
07A	0502012020	PULLEY HOUSING BEARING	01
07B	0501053888	TURBINE PULLEY ASSY	01
07C	0503011081	6207 2RS BEARING	02
07D	0531014518	INTERMEDIARY LOWER BUSHING BEARING	01
07E	0531014519	FLAT WASHER	01
07F	0531014527	FLAT WASHER	01
07G	0503010301	0.3" X 1.8" SPRING PIN	01
07H	0503011855	0.2" X 1.8" SPRING PIN	01
08	0501011194	1/2" X 1-3/4" BOLT	04
09	0521018517	FLAT WASHER	04
10	0503010019	1/2" SPRING WASHER	05
11	0503010020	1/2"NUT	04
12	0503013030	5/8" X 3.1/4" BOLT	01
13	0501012140	FLAT WASHER	01
14	0503010013	5/8" NUT	01
15	0503012780	LARGER TURBINE BELT	01
16	0531017194	FRONT COVER	01
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04
18	0503010025	3/8 SPRING WASHER	04
19	0503010026	3/8" NUT	04
20	0511040440	17.3" MIDDLE FAN	01

Item	Code	Description	QT
21	0503011775	6 X 6 X 35 KEYWAY	01
22	0503011774	PULLEY	01
23	0503010179	SPRING WASHER	03
24	0503011257	M 8 X 1,25 X 30 BOLT	01
25	0503011807	M 8 X 1,25 X 10 BOLT	01
26	0501054272	RIBBON FOR COVER CLOSING ASSY	01
27	0503031776	TURBINE RIBBON SEAL	02
28	0531017195	REAR COVER	01
29	0503013031	1/4" X 3.1/4" BOLT	15
30	0503012880	1/4" UNC SELF ADJUSTING NUT	17
31	0511014024	10 X 13 X 15,5 SLEEVE	02
32	0503012721	1/4" X 4" BOLT	02
33	0511017303	FLAT WASHER	40
34	0531010771	WASHER GUIDE	01
35	0531010757	TURBINE FAN	01
36	0531010770	FLAT WASHER	01
37	0503010179	SPRING WASHER	01
38	0503011429	M 8 X 1,25 X 40 BOLT	01
39	0531012760	TURBINE REAR COVER	01
40	0503013758	1/4" X 1-1/2" BOLT	04
41	0521018267	LARGER TURBINE FRONTAL COVER CENTER	01
42	0503031649	CONECTOR CENTER	01
43	0503012722	0.16" X 0.4" BLIND RIVET	16
44	0501056495	TURBINE OUTPUT SOCKET	01
44A	0503031812	TURBINE OUTPUT SOCKET	01
44B	0541017539	BUTTERFLY VALVE	01
44C	0511066760	VALVE FIXATION SUPPORT	01
44D	0503013813	1/4" UNC X 7/8" BOLT	02
44E	0503010143	SPRING WASHER	02
44F	0503010144	1/4" NUT	02
44G	0501013519	FLAT WASHER	01
44H	0503010060	1/2" NUT	01
45	0503013096	5/16" X 4" BOLT	02
46	0501010694	FLAT WASHER	04
47	0503010499	5/16" UNC BUTTERFLY NUT	02
48	0531015571	CARDAN SLEEVE HITCH	01




Item	Code	Description	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS	01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION	01
01B	0501010186	PARAFUSO ROD 5/8UNF X 2.1/8CR	06
01C	0503016516	5/8 UNF CONIC NUT	06
02	0503012550	5/16" X 3/4" BOLT	06
03	0502011339	15Z GEAR P 1.25"	01
04	0503010328	25590/25523 ROLLER BEARING	02
05	0503010804	00547-B SEAL	02
06	0521012185	TRANSM AXLE CARRYING-WHEEL	01
07	0511015949	LOCK NUT	01
08	0503010329	LOCK WASHER	01
09	0503010330	KM 9 LOCKNUT	01
10	0503010002	1800 GREASE FITTING	01




Item	Code	Description	QT
01	0501059908	CARRYING WHEEL SUPPORT	01
01A	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT	01
02	0521061565	WHEEL SUPPORT ARM	01
03	0531016887	CARRYING WHEEL AXLE ARM	01
04	0503010523	1/4" X 2" COTTERPIN	01
05	0501019757	EXTENSION GREASE FITTING	01
06	0503010003	1845 GREASE FITTING	01
07	0503010951	REDUCTION	04
08	0511050681	TRACTION SPRING	01
08A	0503031681	2.1" X 7.78" EXTENSION SPRING	01
08B	0561016062	SPRING HITCH	02
08C	0501010100	5/8 UNC X 2 C S G.5 BOLT	01
08D	0503010027	SPRING WASHER	01
08E	0503013030	5/8" X 3.1/4" BOLT	01
08F	0551017715	FLAT WASHER	02
08G	0501012140	FLAT WASHER	01
09	0511052772	650X16 WHEEL AND TIRE ASSY	01
10	0511052769	PRY TIRE WHEEL TREANSMISSION	01
11	0521012190	AXLE LOCK	02
12	0503010027	SPRING WASHER	02
13	0503011167	M16 X 2 X 30 BOLT	02
14	0501058241	TENSIONER CHAIN SUPPORT	01
14A	0541011713	TENSIONER CHAIN LOWER AXLE	01
14B	0541016454	PULLEY	01
14C	0503010302	501019 SEAL RING	01
14D	0503010019	1/2" SPRING WASHER	01
14E	0503010060	1/2" NUT	01
15	0501058240	WHELL FASTENER	01
15A	0502012416	CARRYING-WHEELS SUPPORT FIXER	01
15B	0511069417	REAR TENSIONER	01
15C	0501058243	INTERM CHAIN TENSIONER	01
15Ca	0501058239	CHAIN TENSIONER BEARING	03
15Cb	0502012018	CHAIN TIGHTENER BEARING	03

Item	Code	Description	QT
15Cc	0503012882	BALL BEARING	03
15Cd	0503011945	503050 CLAMPING RING (FOR AXLE)	03
15Ce	0551018245	CHAIN TENSIONER AXLE	01
15Cf	0551018241	SLEEVE 16,30 X 30 X 8	03
15Cg	0551018239	SLEEVE 19 X 13,50 X 45	01
15Ch	0503010019	1/2" SPRING WASHER	03
15Ci	0503010060	1/2" NUT	03
15D	0501058244	FIXED CHAIN TENSIONER	01
15Da	0551018252	CHAIN TIGHTENER AXLE	01
15E	0501058242	MOVIL CHAIN TENSIONER	01
15Ea	0551018244	CHAIN UPPER AXLE	01
15F	0501013491	5/8" TENSIONER SPRING	01
15G	0503010060	1/2" NUT	02
15H	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING	01
16	0502011308	WHELL FASTENER	01
17	0503011118	7/8" X 5-1/2" BOLT	04
18	0501014251	FLAT WASHER	04
19	0503010408	7/8" SPRING WASHER	04
20	0503010417	7/8" NUT	04
21	0503014887	2050 CHAIN X 80 LINK + REDUCTION	01
22	0503010780	N-2050 AMENDMENT	02



Item	Code	Description	07D	07E	09D	09E	11D	11E
00	0511052419	RH BEAM SUPPORT	01	00	00	00	00	00
00A	0511052420	LH BEAM SUPPORT & METERING	00	01	00	00	00	00
00B	0511052253	RH BEAM SUPPORT & METERING	00	00	01	00	00	00
00C	0511052254	LH BEAM SUPPORT & METERING	00	00	00	01	00	00
00D	0501058206	FERTILIZER BEAM SUPPORT	00	00	00	00	01	00
00E	0501058207	LH FERTILIZER BEAM SUPPORT	00	00	00	00	00	01
01	0521063542	FERTILIZER BEAN RIGHT SUPPORT	01	00	00	00	00	00
02	0521063543	FERTILIZER BEAN LEFT SUPPORT	00	01	00	00	00	00
03	0521063436	FERTILIZER BEAN RIGHT SUPPORT	00	00	01	00	00	00
04	0521063437	FERTILIZER BEAN LEFT SUPPORT	00	00	00	01	00	00
05	0521066242	FERTILIZER BEAN RIGHT SUPPORT	00	00	00	00	01	00
06	0521066241	FERTILIZER BEAN LEFT SUPPORT	00	00	00	00	00	01
07	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2 -	02	02	02	03	03	03
07A	0501110682	FERTILIZER DISTRIBUTOR	02	02	03	03	03	03
07A.	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2 -	02	02	03	03	03	03
07B	0501019851	DISTRIBUTOR FERTILIZER AXLE	04	04	05	05	06	06
07C	0521010309	SLEEVE INTER	04	04	04	04	04	04
07D	0503030275	AGRICULTURAL BEARING	08	08	10	10	12	12
07E	0503031164	RIGHT HELICAL CONDUTOR	02	02	03	03	06	06
07E.	0503031164	RIGHT HELICAL CONDUTOR	02	02	02	02	06	06
07F	0501010637	FLAT WASHER	04	04	05	05	12	12
07G	0503030303	SUPPORT WASHER	05	05	06	06	13	13
07H	0501013774	GREASE SEAL	04	04	05	05	12	12
07I	0502011412	18Z CONICAL GEAR	08	08	10	10	12	12
07J	0503010523	1/4" X 2" COTTERPIN	04	04	05	05	06	06
07K	0503011962	GREASE FITTING	04	04	05	05	06	06
07L	0503010003	1845 GREASE FITTING	04	04	05	05	06	06
07M	0503012826	CREASE FITTING	04	04	05	05	06	06
08	0501010942	3/8" X 1-1/4" BOLT	16	16	20	20	24	24
09	0503011443	SPRING WASHER	20	20	24	24	30	30
10	0503010026	3/8" NUT	20	20	24	24	28	28
11	0511061759	22Z P12,70 FQ 3/4" GEAR	01	01	01	01	01	01
12	0521014167	CONE LOCK	04	04	04	04	04	04

Item	Code	Description	07D	07E	09D	09E	11D	11E
13	0561018362	SQUARE SHAFT	01	01	00	00	00	00
14	0551018213	3/4" X 1830 SQUARE SHAFT	00	00	01	01	00	00
15	0511014265	3/4" X 86" SQUARE SHAFT	00	00	00	00	01	01
16	0521010691	AXLE FASTENER	02	02	02	02	02	02
17	0503010373	1/4" X 2" BOLT	02	02	02	02	02	02
18	0501010694	FLAT WASHER	08	08	08	08	08	08
19	0503011441	SPRING WASHER	02	02	02	02	02	02
20	0503010144	1/4" NUT	02	02	02	02	02	02
21	0501110392	SILO SUPPORT BEARING	01	01	01	01	01	01
22	0521012485	GEAR BOX BEARING AGRICUTURAL	01	01	01	01	01	01
23	0551018055	22,65 X 60 SLEEVE	00	01	00	01	00	01
24	0503011953	5/16" X 1" BOLT	04	04	04	04	04	04
25	0503011444	SPRING WASHER	04	04	04	04	04	04
26	0503010337	5/16" NUT	04	04	04	04	04	04
27	0503010003	1845 GREASE FITTING	01	01	01	01	01	01
28	0503010849	3/8" X 1-1/2" BOLT	04	04	04	04	04	04
29	0501010984	FLAT WASHER	08	08	08	08	08	08
30	0551019117	FERTILIZER DISTRIBUTOR COVER	04	04	05	05	06	06
31	0503010257	1/8" X 1" COTTERPIN	04	04	05	05	06	06
32	0503060636	COVER BOX RIGHT FERTILIZER	01	00	00	00	00	00
33	0503060637	COVER BOX LEFT FERTILIZER	00	00	00	00	00	00
34	0503060640	COVER BOX RIGHT FERTILIZER	00	00	01	00	00	00
35	0503060641	COVER BOX LEFT FERTILIZER	00	00	00	01	00	00
36	0503060642	COVER BOX RIGHT FERTILIZER	00	00	00	00	01	00
37	0503060643	COVER BOX LEFT FERTILIZER	00	00	00	00	00	01
38	0511062099	FERTILIZER BEAM CLAMP	02	02	02	02	02	02
39	0511061886	FERTILIZER BEAM LOCK	02	02	02	02	02	02
40	0503010019	1/2" SPRING WASHER	02	02	02	02	02	02
41	0503010060	1/2" NUT	02	02	02	02	02	02
42	0551019156	GEAR BOX LEVER LOCK	01	01	01	01	01	01
43	0503032624	FERTILIZER BEAN LIP	04	04	05	05	06	06



Item	Code	Description	07 09 11
01	0521013199	LOWER BEARING SEMI	04 04 06
02	0511069724	CARRYING-WHEELS PIVOT SHAFT	01 00 00
03	0511069682	CARRYING-WHEELS PIVOT SHAFT	00 01 01
04	0511069717	CARRYING-WHEELS PIVOT SHAFT	00 00 01
05	0503010899	5/8" X 2-1/4" BOLT	08 08 12
06	0501012140	FLAT WASHER	18 18 26
07	0531013922	0.6" X 0.8" X 1" SLEEVE	08 08 12
08	0503011445	SPRING WASHER	10 10 14
09	0503010013	5/8" NUT	10 10 14
10	0503010002	1800 GREASE FITTING	04 06 04
11	0503010257	1/8" X 1" COTTERPIN	06 08 08
12	0501110639	AGRIC BEARING	02 02 02
13	0503010691	1/4" GREASE FITTING	02 02 02
14	0551019114	MOTOR BEARING AXLE SUPPORT	02 04 04
15	0521014021	1/2" X 4.5" X 5.4" FASTENER	02 04 04
16	0511017302	FLAT WASHER	12 20 20
17	0503010019	1/2" SPRING WASHER	22 26 26
18	0503010060	1/2" NUT	16 22 22
19	0561016882	1535 MOTOR SHAFT	02 00 00
20	0561016881	MOTOR SHAFT	00 02 00
21	0561016876	MOTOR SHAFT	00 00 02
22	0501018466	FLAT WASHER	04 04 04
23	0503010523	1/4" X 2" COTTERPIN	02 02 02
24	0501052560	AXLE MOTOR SLOW-MOVING ASSY	02 02 02
24A	0503031825	AXLE MOTOR SLOW-MOVING	02 02 02
24B	0503010240	5/16" X 3/4" BOLT	02 02 02
24C	0503010179	SPRING WASHER	10 10 10
24D	0503010337	5/16" NUT	10 10 10
25	0511051434	TRANSMISSION DRIVING ASSY	02 04 04
26	0511047069	SIDE TRANSMISSION DRIVING	01 01 01
27	0511047070	LH SIDE TRANSMISSION DRIVING	01 01 01
28	0501058235	UPPER CHAIN TENSIONER	02 02 02
28A	0502012367	17Z X P 1/2" GEAR INTERM	02 02 02


Item	Code	Description	07 09 11
28B	0503012882	BALL BEARING	02 02 02
28C	0503011945	503050 CLAMPING RING (FOR AXLE)	02 02 02
28D	0551019173	CHAIN SLEEVE TENSIONER	02 02 02
28E	0503011411	1/2" X 5-1/2" BOLT	06 06 06
29	0501058234	LOWER CHAIN TENSIONER	02 02 02
29A	0511062169	21Z P 1/2" GEAR	04 04 04
29B	0503011410	ROLLER BEARING	06 06 06
29C	0503011105	SEAL RING	04 04 04
29D	0551019171	CHAIN TIGHTENER AXLE	04 04 04
29E	0503010406	501025 CLAMPING RING (FOR AXLE)	06 06 06
29F	0501010163	5/8" X 4-1/2" BOLT	04 04 04
30	0501058236	BEARING WITH 21Z GEAR	02 02 02
30A	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	04 04 04
31	0501058237	16Z GEAR BEARING	02 02 02
31A	0511069680	20Z X 28Z DOBLE GEAR	02 02 02
31B	0551019174	DOBLE GEAR AXLE	02 02 02
31C	0503010967	5/8" X 5.1/2" BOLT	02 02 02
32	0511047058	RIGHT GEAR BOX ASSY	01 01 01
33	0511047059	LH GEAR BOX ASSY	01 01 01
34	0501010243	1/2" X 1-1/2" BOLT	06 06 06
35	0503010920	1/2" X 1.1/2" BOLT	04 04 04
36	0503010020	1/2"NUT	06 06 06
37	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"	02 02 02
38	0503030303	SUPPORT WASHER	04 04 04
39	0501010637	FLAT WASHER	08 08 08
40	0503012522	40-1 CHAIN X 85 LINK + MENDING	02 02 02
41	0503012707	40-1 CHAIN X 96 LINK + REDUCTION	02 02 02
42	0503012718	40-1 CHAIN X 111 LINK + MENDING	02 02 02
43	0503016111	40-1 CHAIN X 109 LINK + MENDING	02 02 02
44	0511069679	RH UPPER LEVER	02 02 02
45	0521013432	5/8" X 59" AXLE HEX	01 00 00
46	0521013428	HEX AXLE	01 00 00
47	0521013433	5/8" X 75" AXLE HEX	00 01 00
48	0521013429	LEFT 5/8" X 50.4" AXLE HEX	00 01 00
49	0521013434	5/8" X 90" HEX AXLE	00 00 01
50	0521013430	5/8" X 101.57" HEX AXLE	00 00 01
51	0501110037	5/8" HEX AXLE LEFT BEARING ASSY	02 02 02
52	0502040723	5/8 HEX AXLE BEARING SLEEVE	02 02 03
53	0503010003	1845 GREASE FITTING	06 06 06
54	0503010365	NUT	04 04 04
55	0501010984	FLAT WASHER	14 14 14
56	0501010694	FLAT WASHER	08 08 08
57	0511017305	FLAT WASHER	04 04 04
58	0511065562	20Z GEAR	02 02 02
59	0502011299	BUSHING GEAR	02 02 02
60	0503010010	1/4" X 2.1/2" COTTERPIN	02 02 02
61	0501055112	MICRO GRANULATED CHAIN TENSIONER	02 02 02
61A	0531019479	AXLE CHAIN GEAR	02 02 02
61B	0503031805	11Z 1/2" GEAR	02 02 02
62	0551019159	LEVER FIXER BODY	02 02 02
63	0503011751	REDUCTION	06 06 06
64	0503011750	AMENDMENT WITH LOCK	06 06 06
65	0503010547	1/2" X 4" BOLT	02 02 02
66	0551019168	SLEEVE	02 02 02
67	0551019160	LEVER	02 02 02
68	0511017302	FLAT WASHER	02 02 02
69	0503010019	1/2" SPRING WASHER	02 02 02
70	0503010060	1/2" NUT	02 02 02
71	0551019167	SLEEVE UNION	02 02 02
72	0511069676	INNER LEVER	02 02 02
73	0503011268	3/8" X 2-1/2" BOLT	02 02 02
74	0503010025	3/8 SPRING WASHER	02 02 02




PST4 SUPREMA
07/09/11 TRANSMISSION

Page 11
0909093033


Item	Code	Description	07 09 11
75	0503010026	3/8" NUT	02 02 02
76	0503010140	1/8" X 3/4" COTTERPIN	06 06 06
77	0511069677	RH LOWER LEVER	01 01 01
78	0511069678	LH LOWER LEVER	01 01 01



Item	Code	Description		
00	0511047069	SIDE TRANSMISSION DRIVING	01	00
00A	0511047070	LH SIDE TRANSMISSION DRIVING	00	01
01	0502011996	SLLEVE FIXER	01	01
02	0503030678	1/2"X1-1/2" BOLT	01	01
03	0503010060	1/2" NUT	01	01
04	0521017590	GUIDE AXLE	01	01
05	0503030553	2.3"X 2.5"X 0.2" COMPRESSION SPRING	01	01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER	01	00
07	0502011995	LH DRIVING AXLE FOLLOWER	00	01
08	0501019734	FLAT WASHER	02	02
09	0502010710	RIGHT CAM, SMALLER	02	00
10	0502010720	RIGHT CAM, SMALLER	00	02
11	0503010003	1845 GREASE FITTING	02	02
12	0502012539	26Z P12,7 GEAR	01	00
13	0502012540	26Z P12,7 GEAR	00	01
14	0501019735	FLAT WASHER	01	01
15	0521017593	FLAT WASHER	01	01
16	0503010542	501045 CLAMPING RING (FOR AXLE)	01	01




Item	Code	Description	QT
01	0502012696	RIGHT RATCHET HANDLE BODY	01
02	0571010151	GRAGGER RATCHET BODY	01
03	0561019923	RATCHET PULLER GEAR	01
04	0551019100	LOCK RATCHET	02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING	02
06	0503010365	NUT	04
07	0503013816	5/16" LOCKNUT	04
08	0571010164	SEAT SIDE OF RATCHET	01
09	0503010004	1890 GREASE FITTING	01
10	0503030678	1/2"X1-1/2"BOLT	01
11	0503010060	1/2" NUT	01
12	0571010763	FLANGE WASHER	02




Item	Code	Description	DIR ESQ
00	0511047058	RIGHT GEAR BOX ASSY	01 00
00A	0511047059	LH GEAR BOX ASSY	00 01
01	0501058212	RH GEAR	01 00
01A	0511069565	LEFT GEAR BOX	01 00
01B	0502011758	REAR TENSIONER LEVER	02 02
01C	0503010292	0.2" X 1.6" SPRING PIN	07 07
01D	0511061794	CHAIN TENSIONER	01 01
01E	0503031367	SPRING	01 01
01F	0511061795	CHAIN TENSIONER	01 01
01G	0503031367	SPRING	01 01
02	0501058213	LH GEAR BOX	00 01
03	0503031805	11Z 1/2" GEAR	06 06
04	0503010302	501019 SEAL RING	04 04
05	0501048790	AXLE WITH LINK ASSY	02 02
05A	0521012476	GEAR BOX LEVER AXLE	02 02
05B	0503031369	LINK	02 02
06	0503010002	1800 GREASE FITTING	02 02
07	0551018209	DRIVING AXLE	01 01
08	0521018259	DRIVEN AXLE	01 01
09	0551018210	DRIVEN AXLE	01 01
10	0551018211	INTERM SHAFT	01 01
11	0501056447	CENTRAL BEARING GEAR BOX	01 01
11A	0502011978	HOUSING CENTRAL BEARING	01 01
11B	0503013462	BEARING WITH BALL BEARING	07 07
11C	0503011953	5/16" X 1" BOLT	16 16
11D	0501010694	FLAT WASHER	16 16
11E	0503010179	SPRING WASHER	16 16
11F	0503010337	5/16" NUT	16 16
12	0503030303	SUPPORT WASHER	05 05
13	0501056443	BEARING ASSY GEAR BOX	02 02
13A	0501056444	BEARING WITH BALL BEARING	02 02
13Aa	0502011697	BEARING OF THE GEAR BOX	02 02
13Ab	0503011105	SEAL RING	07 07

Item	Code	Description	DIR ESQ
14	0501056271	GEAR BOX CLOSE BEARINGONE	05 05
14A	0502012310	GEAR BOX CLOSE BEARING	05 05
15	0511060396	DRIVE/DRIVEN AXLE CONE	04 04
16	0503012389	1/2 BALL	04 04
17	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING	04 04
18	0503010060	1/2" NUT	06 06
19	0503010395	1/2" X 1-1/4" BOLT	04 04
20	0511061830	17Z P 0.5" GEAR SQUARE HOL	02 02
21	0511067501	26Z GEAR	01 01
22	0503012204	40-1 CHAIN X 82 LINK + RED	02 02
23	0503012713	40-1 CHAIN X 45 LINK + MEN	01 01
24	0501054655	CHAIN TENSIONER ASSY	02 02
24A	0531019479	AXLE CHAIN GEAR	02 02
24B	0511017302	FLAT WASHER	02 02
24C	0503010019	1/2" SPRING WASHER	02 02
25	0501010984	FLAT WASHER	01 01
26	0503010025	3/8 SPRING WASHER	01 01
27	0503010256	3/8" X 3/4" BOLT	01 01
28	0521018630	1.4" X SQUARE 0.8" WASHER	01 01




Item	Code	Description	11 13
01	0511053099	RH SHORT SEED ROW	06 07
02	0511053100	LH LONG SEED ROW	05 06
03	0521040111	DEP CONT WHEELS PRESS WHEELS ASSY	11 13
04	0501058190	LH SHORT FERT. ROW W/DDD ASSY	06 07
05	0501058191	RH LONG FERT. ROW W/DDD ASSY	05 06
06	0909094698	SEED END FERTILIZER ROW (PST4 SUPREMA)	05 06
07	0909094698	SEED END FERTILIZER ROW (PST4 SUPREMA)	05 06
08	0503010246	CLAMP	22 22
09	0511069907	HOSE HOLDER	02 02




Item	Code	Description	QT
001	0511053101	ARM SEED SHORT LINE	01
002	0511053857	FAST CLOSING SET	01
003	0521042715	PNEUMATIC SEED DISTRIBUTOR	01
004	0503011404	3/8" X 1-3/4" BOLT	04
005	0503010025	3/8 SPRING WASHER	04
006	0503010026	3/8" NUT	04
007	0521062824	SPINDLE GUIDE	01
008	0521010542	COUPLING SHAFT	01
009	0503010257	1/8" X 1" COTTERPIN	01
010	0502040534	SPRING GUIDE BUSHING LOCK	01
011	0531019915	FLAT WASHER	01
012	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING	01
013	0521062825	LOCK VARON GUIDE	01
014	0501018535	1/2 X 1 BOLT	03
015	0571013566	SPRING ROD SUPPORT	01
016	0521014021	1/2" X 4.5" X 5.4" FASTENER	01
017	0503011336	1/2" HEX SELF ADJUSTING NUT	02
018	0503010014	3/4" NUT	01
019	0511050083	SEED BOX	01
019A	0502011760	SEED SILO SUPPORT	01
019B	0521060631	FIXING BASE BOX	01
019C	0501010942	3/8" X 1-1/4" BOLT	04
019D	0503010025	3/8 SPRING WASHER	04
019E	0503010026	3/8" NUT	04
019F	0531018349	SEED FLOW SWITCH PNEUMATIC SYSTEM	01
019G	0501011643	3/8 X 1"BOLT	01
019H	0501010984	FLAT WASHER	01
019I	0503010025	3/8 SPRING WASHER	01
019J	0503010209	3/8" UNC BUTTERFLY NUT	01
019K	0503031508	COVER GREEN BEAM SEED YELLOW	01
019L	0503010358	5/16" X 5/8" BOLT	04
019M	0501010694	FLAT WASHER	04
019N	0503010179	SPRING WASHER	04


Item	Code	Description	QT
019O	0503010337	5/16" NUT	04
020	0511058212	SET LINE SUPPORT FERTILIZER	01
020A	0502011567	FERTILIZER ROW SUPPORT	01
020B	0511016156	5/8" X 1.1/2" BOLT	02
021	0503010762	5/8" X 3-12" BOLT	02
022	0503010740	1/2" X 2" BOLT	01
023	0511017302	FLAT WASHER	01
024	0521010505	13,50 X 19,00 X 21,50 SLEEVE	01
025	0503010019	1/2" SPRING WASHER	01
026	0503010060	1/2" NUT	01
027	0541010235	2" X 98" HOSE ASSY	01
028	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	02
029	0503033124	SOCKET SEED	01
030	0501018652	CORN STABILIZER BAR	03
031	0503013162	DISC 2450 CORN	07



Item	Code	Description	QT
001	0502011561	BEARING SEMI	01
002	0571010152	ROW SEED SUPPORT ARTICULACION	01
003	0503010003	1845 GREASE FITTING	02
004	0502010426	UPPER BEARING SEMI	02
005	0503010479	1/2" X 3" BOLT	04
006	0503011440	SPRING WASHER	04
007	0503010060	1/2" NUT	04
008	0521063935	SHORT SEED ROW ARM	01
009	0503010752	1/2" X 3.1/2" BOLT	02
010	0503011440	SPRING WASHER	02
011	0503010060	1/2" NUT	02
012	0502011400	18Z CONICAL GEAR	01
013	0502011296	1/2 HEX AXLE BEARING SLEEVE	01
014	0501013824	FLAT WASHER	02
015	0502011505	18Z CONICAL GEAR	01
016	0571013524	1/2 X 1365 AXLE HEX	01
017	0501013352	FLAT WASHER	01
018	0521018079	SEEP ROW DRAWBAR COVER	01
019	0503014729	1/4" UNF X 1/2" BOLT	02
020	0503011441	SPRING WASHER	02
021	0511052324	CARDAN TRANSMISSION BEARING	01
022	0501059631	RIGHT 15" X 15" SEED UNAL DOUB-DISC	01




Item	Code	Description	QT
01	0511015098	FLAT WASHER	02
02	0511011927	DUST CLOAK	02
03	0501054167	DOUBLE DISC HUB WITH 15" COULTER	01
04	0501054168	LEFT UNAL DOBLE-DISC BOX ASSY	01
05	0503030757	2.9" X 2" X 0.02" JOINT	02
06	0521019178	COVER DEPTH	02
07	0503014729	1/4" UNF X 1/2" BOLT	06
08	0503011441	SPRING WASHER	06
09	0561010264	RH DOUBLE DISC SCRAPER	01
10	0561010265	LH DOUBLE DISC SCRAPER	01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01
12	0501010984	FLAT WASHER	02
13	0503011443	SPRING WASHER	01
14	0503010026	3/8" NUT	01
15	0511052301	DOBLE DISC SUPPORT W/GUIDE	01
15A	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT	01
15B	0571012491	SOCKET SEED GUIDE	01
15C	0503010838	0.1" X 0.8" SPRING PIN	02




Item	Code	Description	QT
001	0511053102	ARM SEED SHORT LINE	01
002	0511053857	FAST CLOSING SET	01
003	0521042715	PNEUMATIC SEED DISTRIBUTOR	01
004	0503011404	3/8" X 1-3/4" BOLT	04
005	0503010025	3/8 SPRING WASHER	04
006	0503010026	3/8" NUT	04
007	0521062824	SPINDLE GUIDE	01
008	0521010542	COUPLING SHAFT	01
009	0503010257	1/8" X 1" COTTERPIN	01
010	0502040534	SPRING GUIDE BUSHING LOCK	01
011	0531019915	FLAT WASHER	01
012	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING	01
013	0521062825	LOCK VARON GUIDE	01
014	0501018535	1/2 X 1 BOLT	03
015	0571013566	SPRING ROD SUPPORT	01
016	0521014021	1/2" X 4.5" X 5.4" FASTENER	01
017	0503011336	1/2" HEX SELF ADJUSTING NUT	02
018	0503010014	3/4" NUT	01
019	0511050083	SEED BOX	01
019A	0502011760	SEED SILO SUPPORT	01
019B	0521060631	FIXING BASE BOX	01
019C	0501010942	3/8" X 1-1/4" BOLT	04
019D	0503010025	3/8 SPRING WASHER	04
019E	0503010026	3/8" NUT	04
019F	0531018349	SEED FLOW SWITCH PNEUMATIC SYSTEM	01
019G	0501011643	3/8 X 1"BOLT	01
019H	0501010984	FLAT WASHER	01
019I	0503010025	3/8 SPRING WASHER	01
019J	0503010209	3/8" UNC BUTTERFLY NUT	01
019K	0503031508	COVER GREEN BEAM SEED YELLOW	01
019L	0503010358	5/16" X 5/8" BOLT	04
019M	0501010694	FLAT WASHER	04
019N	0503010179	SPRING WASHER	04


Item	Code	Description	QT
019O	0503010337	5/16" NUT	04
020	0511058212	SET LINE SUPPORT FERTILIZER	01
020A	0502011567	FERTILIZER ROW SUPPORT	01
020B	0511016156	5/8" X 1.1/2" BOLT	02
021	0503010762	5/8" X 3-12" BOLT	02
022	0503010740	1/2" X 2" BOLT	01
023	0511017302	FLAT WASHER	01
024	0521010505	13,50 X 19,00 X 21,50 SLEEVE	01
025	0503010019	1/2" SPRING WASHER	01
026	0503010060	1/2" NUT	01
027	0541010235	2" X 98" HOSE ASSY	01
028	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	02
029	0503033124	SOCKET SEED	01
030	0501018652	CORN STABILIZER BAR	03
031	0503013162	DISC 2450 CORN	07



Item	Code	Description	QT
001	0502011561	BEARING SEMI	01
002	0571010152	ROW SEED SUPPORT ARTICULACION	01
003	0503010003	1845 GREASE FITTING	02
004	0502010426	UPPER BEARING SEMI	02
005	0503010479	1/2" X 3" BOLT	04
006	0503011440	SPRING WASHER	04
007	0503010060	1/2" NUT	04
008	0521063934	LONG SEEP ROW ARM	01
009	0503010752	1/2" X 3.1/2" BOLT	02
010	0503011440	SPRING WASHER	02
011	0503010060	1/2" NUT	02
012	0502011400	18Z CONICAL GEAR	01
013	0502011296	1/2 HEX AXLE BEARING SLEEVE	01
014	0501013824	FLAT WASHER	02
015	0502011505	18Z CONICAL GEAR	01
016	0571013523	1/2 X 1565 HEX AXLE	01
017	0501013352	FLAT WASHER	01
018	0521018079	SEEP ROW DRAWBAR COVER	01
019	0503014729	1/4" UNF X 1/2" BOLT	02
020	0503011441	SPRING WASHER	02
021	0511052324	CARDAN TRANSMISSION BEARING	01
022	0501059632	LH 15"X15"SEED UNAL DOUBLE DISC	01




Item	Code	Description	QT
01	0511015098	FLAT WASHER	02
02	0511011927	DUST CLOAK	02
03	0501054167	DOUBLE DISC HUB WITH 15" COULTER	01
04	0501054168	LEFT UNAL DOBLE-DISC BOX ASSY	01
05	0503030757	2.9" X 2" X 0.02" JOINT	02
06	0521019178	COVER DEPTH	02
07	0503014729	1/4" UNF X 1/2" BOLT	06
08	0503011441	SPRING WASHER	06
09	0561010264	RH DOUBLE DISC SCRAPER	01
10	0561010265	LH DOUBLE DISC SCRAPER	01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01
12	0501010984	FLAT WASHER	02
13	0503011443	SPRING WASHER	01
14	0503010026	3/8" NUT	01
15	0511052302	LH SUPPORT DDD W/ GUIDE	01
15A	0561015592	15" X 15" RIGHT DOUBLE DISC SUPPORT	01
15B	0571012491	SOCKET SEED GUIDE	01
15C	0503010838	0.1" X 0.8" SPRING PIN	02




Item	Code	Description	QT
01	0511050075	PNEUMATIC DISTRIBUTOR SUPPORT	01
01A	0501110649	INNER SUPPORT NEUMATIC SEED DISTR	01
01Aa	0502012599	PNEUMATIC SEED DISTRIBUTOR SUPPORT	01
01Ab	0503011770	SEAL # V-75 A	01
01Ac	0502012649	18Z CONICAL GEAR 34 TEETH	01
01Ad	0503011771	6008 2RS BALL BEARING	01
01B	0502050003	SUPPORT INTERNAL DISC SEED VULCANIZ	01
01C	0503011378	M6 X 1" BOLT	03
01D	0503010143	SPRING WASHER	03
01E	0503012849	2-129 N 3006 9B O'RING	02
01F	0503010217	501040 CLAMPING RING (FOR AXLE)	01
01G	0503033121	PNEUMATIC SWITCH	01
01H	0503011295	M 8 X 1,25 X 25 BOLT	01
01I	0503010427	METRIC M8 X P.0.5" NUT	01
02	0503033800	PNEUMATIC JOINT SEALING	03
03	0511053062	DRIVE SHAFT	01
04	0503011294	M 8 X 1,25 X 20 BOLT	03
05	0503010025	3/8 SPRING WASHER	03
06	0503011370	DISC 6440 MIDDLE SOYBEAN	01
07	0501058950	SEED SYSTEM SIDE	01
07A	0561012486	LATERAL COVER	01
08	0511017186	SEED LEVEL REGULATOR	01
09	0511017303	FLAT WASHER	04
10	0503011776	M6 SELF ADJUSTINGNUT	01
11	0503014141	M6 X 1 X 20 BOLT	01
12	0503011817	UPPER SELECTOR	01
13	0502020559	UPPER SELECTOR ACTUATOR	01
14	0531014481	0.2" X 0.6" AXLE	01
15	0503011821	CRINKLE WASHER	01
16	0503011823	0.1" X 0.6" SPRING PIN	02
17	0511017219	SCALE INDICATOR GUIDE	01
18	0503011378	M6 X 1" BOLT	03
19	0503010143	SPRING WASHER	03


Item	Code	Description	QT
20	0503011810	M6 X 1" BUTTERFLY BOLT	01
21	0503031058	UPPER SELECTOR SCALE	01
22	0503011825	M4 X 8" BOLT	02
23	0503011840	FLAT WASHER	02
24	0501110311	LOWER SELECTOR ASSY	01
25	0503011813	M6 X 1.2" BOLT	01
26	0511016220	LOWER SELECTOR INDICATOR	01
27	0503011815	TOOTHED WASHER	01
28	0503012445	M6 C/ABA 1.20" BUTTERFLY NUT	04
29	0503013179	PNEUMATIC SEED DISTRIBUTOR VISOR	01
30	0561012741	SEED DRAINER COVER	01
31	0503011809	M12 KNOB	01
32	0503011828	FLAT WASHER	01
33	0503011827	504.100 CLAMPING RING (FOR HOLE)	01
34	0503011104	M6 X 1" BOLT	02
35	0503011820	CRINKLE WASHER	02
36	0511017199	PST SUP AXLE	01
37	0511017198	SCALE INDICATOR	01
38	0503015536	M6 X 1" SELF ADJUSTING NUT	01
39	0511015627	SEED DISC LEVER	01




Item	Code	Description	QT
001	0511051447	CONTROL DEPTH ASSY	01
002	0501052538	DEPTH CONTROL WHEEL RUBBER BAND	02
003	0503010358	5/16" X 5/8" BOLT	08
004	0503013816	5/16" LOCKNUT	08
005	0511054333	COMPACT WHEEL RIGHT C/ BEARING	01
006	0511054334	COMPACT WHEEL LEFT C/ BEARING	01
007	0503010179	SPRING WASHER	08
008	0503033942	COVER REGULATORY WHEEL	01




Item	Code	Description	QT
001	0502012282	DEPTH CONTROL SUPPORT	01
002	0531010765	DEPTH WHEEL AXLE	01
003	0503010256	3/8" X 3/4" BOLT	01
004	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE	02
005	0511015346	FLAT WASHER	04
006	0521064073	REGULACION WHEEL COMPACTOR	01
007	0501058576	RIGHT WHEEL ARM	01
008	0501058577	RIGHT ARM DEPTH CONTROL WHEEL	01
009	0511017302	FLAT WASHER	02
010	0503011440	SPRING WASHER	02
011	0503010311	1/2" X 1-1/4" BOLT	02
012	0501052297	DEPTH WHEELS REGULATOR ASSY	01
013	0521019093	0.6" X 2.7" PIVOT SHAFT	01
014	0503010257	1/8" X 1" COTTERPIN	01
015	0502012116	PRESS WHEEL ADJUSTER	01
016	0503010849	3/8" X 1-1/2" BOLT	02
017	0503011443	SPRING WASHER	02
018	0503010026	3/8" NUT	02
019	0541016906	PRESS WHEELS REGULATOR BODY	01
020	0521010539	0.3" X 1.2" COUPLING SHAFT	01
021	0503010140	1/8" X 3/4" COTTERPIN	01
022	0503030805	1.6" X 6" X 0.2" TRACTION SPRING	01




Item	Code	Description	QT
01	0501052908	PRESS WHEELS ASSY	01
02	0503016449	1/2 X 4 BOLT	01
03	0521014508	FLAT WASHER	03
04	0503012136	1 X 9 BOLT	01



Item	Code	Description	QT
001	0501052908	PRESS WHEELS ASSY	01
002	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT	01
003	0521014508	FLAT WASHER	03
004	0503016864	LH 1/2" LOCK NUT	01




Item	Code	Description	QT
001	0501058185	LH FERTILIZER W/DDD ROW ARM	01
001A	0521061121	SHORT FERTILIZER ROW ARM	01
001B	0501052977	15 X 15 LEF FERT UNAL DOUB-DISC ASSY	01
001C	0511018662	SPACING PLATE	04
001D	0503010547	1/2" X 4" BOLT	02
001E	0503011440	SPRING WASHER	02
001F	0503010060	1/2" NUT	02
002	0501010066	3/4" X 9" BOLT	01
003	0521017831	SUPPORT SLEEVE SPACER	02
004	0511017232	FLAT WASHER	02
005	0503011255	3/4" LOCK NUT	01
006	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	01
007	0501058423	FERTILIZER ROD SPRING ROW	01
007A	0511069645	FERTILIZER SPRING ROD	01
007B	0502040534	SPRING GUIDE BUSHING LOCK	02
007C	0502012184	FERTILIZER SPRING GUIDE	02
007D	0503031910	1.7" X 22.8" X 0.3" SPRING	01
007E	0502012510	SPRING ROD SUPPORT	01
007F	0503030679	1/2" X 1-1/4" BOLT	01
007G	0501018535	1/2 X 1 BOLT	02
007H	0503030678	1/2"X1-1/2"BOLT	01
007I	0503010060	1/2" NUT	02
007J	1902010891	SPRING CHOCK SUPPORT VARON	01
007K	0503010014	3/4" NUT	01
007L	0561014471	COUPLING SHAFT	01
007M	0511017302	FLAT WASHER	01
007N	0503010257	1/8" X 1" COTTERPIN	01
008	0503030391	RIGHT FERTILIZER SOCKET	01
009	0503031145	2" X 2" X 20" HOSE	01
010	0503031076	2" HOSE CLAMP	02



Item	Code	Description	QT
001	0501058186	RH FERTILIZER W/DDD LONG ROW ARM	01
001A	0521061153	LONG FERTILIZER ROW ARM	01
001B	0501052976	15 X 15 RIGHT FERT UNAL DOUB-DISC ASSY	01
001C	0511018662	SPACING PLATE	04
001D	0503010547	1/2" X 4" BOLT	02
001E	0503011440	SPRING WASHER	02
001F	0503010060	1/2" NUT	02
002	0501010066	3/4" X 9" BOLT	01
003	0521017831	SUPPORT SLEEVE SPACER	02
004	0511017232	FLAT WASHER	02
005	0503011255	3/4" LOCK NUT	01
006	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	01
007	0501058423	FERTILIZER ROD SPRING ROW	01
007A	0511069645	FERTILIZER SPRING ROD	01
007B	0502040534	SPRING GUIDE BUSHING LOCK	02
007C	0502012184	FERTILIZER SPRING GUIDE	02
007D	0503031910	1.7" X 22.8" X 0.3" SPRING	01
007E	0502012510	SPRING ROD SUPPORT	01
007F	0503030679	1/2" X 1-1/4" BOLT	01
007G	0501018535	1/2 X 1 BOLT	02
007H	0503030678	1/2"X1-1/2"BOLT	01
007I	0503010060	1/2" NUT	02
007J	1902010891	SPRING CHOCK SUPPORT VARON	01
007K	0503010014	3/4" NUT	01
007L	0561014471	COUPLING SHAFT	01
007M	0511017302	FLAT WASHER	01
007N	0503010257	1/8" X 1" COTTERPIN	01
008	0503030392	LEFT FERTILIZER SOCKET	01
009	0503031145	2" X 2" X 20" HOSE	01
010	0503031076	2" HOSE CLAMP	02

18" COULTER BLADE ASSY FOR LONG ROW

0511044573




Item	Code	Description	QT
01	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE	01
02	0502012368	BLADE DISC SUPPORT AXLE	01
03	0503010756	0.2" X 2.4" SPRING PIN	01
04	0503010361	SPRING PIN	01
05	0541018684	FLAT WASHER	01
06	0521014137	RIGHT ARM OF THE BLADE DISC	01
07	0521014138	SUPPORT ARM LEFT BALDE DISC	01
08	0501067323	SPRING REGULATOR	01
09	0521010452	SLEEVE	01
10	0503013185	3/4" X 5-1/2" BOLT	01
11	0503011255	3/4" LOCK NUT	01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01
13	0503011411	1/2" X 5-1/2" BOLT	01
14	0503011440	SPRING WASHER	01
15	0503010060	1/2" NUT	01
16	0502020393	SPRING UPPER SUPPORT	01
17	0502020394	SPRING SUPPORT	01
18	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01
19	0503010014	3/4" NUT	02
20	0521015376	DUST CLOAK	02
21	0502011562	DC PST ACT/ULTR BOX	01
22	0503010276	6206 BALL BEARING	02
23	0521013610	BLADE DISC HUB AXLE	01
24	0503030832	FLAT WASHER	02
25	0503012417	SEAL	02
26	0503011800	SEAL RING	02
27	0503010691	1/4" GREASE FITTING	01
28	0603026013	PLAIN COULTER BLADE	01
29	0502020641	BLADE DISC FLANGE	01
30	0503010371	5/16" X 1" BOLT	06
31	0503010179	SPRING WASHER	06
32	0503010337	5/16" NUT	06
33	0511015346	FLAT WASHER	02




18" COULTER BLADE ASSY FOR LONG ROW

0511044573

Item	Code	Description	QT
34	0503010023	SPRING WASHER	02
35	0521013510	3/4" NUT	02
36	0503010003	1845 GREASE FITTING	01




Item	Code	Description	QT
01	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	01
02	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	01
03	0521061121	SHORT FERTILIZER ROW ARM	01
04	0521061153	LONG FERTILIZER ROW ARM	01
05	0511051144	ASTA ESCARIFICADORA	01
06	0503031076	2" HOSE CLAMP	02
07	0503031145	2" X 2" X 20" HOSE	01
08	0511016156	5/8" X 1.1/2" BOLT	01
09	0501010066	3/4" X 9" BOLT	01
10	0521017831	SUPPORT SLEEVE SPACER	02
11	0511017232	FLAT WASHER	02
12	0503011255	3/4" LOCK NUT	01
13	0503010547	1/2" X 4" BOLT	02
14	0503011440	SPRING WASHER	02
15	0503010060	1/2" NUT	02
16	0501058423	FERTILIZER ROD SPRING ROW	01
16A	0511069645	FERTILIZER SPRING ROD	01
16B	0502040534	SPRING GUIDE BUSHING LOCK	02
16C	0502012184	FERTILIZER SPRING GUIDE	02
16D	0503031910	1.7" X 22.8" X 0.3" SPRING	01
16E	0502012510	SPRING ROD SUPPORT	01
16F	0503030679	1/2" X 1-1/4" BOLT	01
16G	0501018535	1/2 X 1 BOLT	02
16H	0503030678	1/2"X1-1/2"BOLT	01
16I	0503010060	1/2" NUT	02
16J	1902010891	SPRING CHOCK SUPPORT VARON	01
16K	0503010014	3/4" NUT	01
16L	0561014471	COUPLING SHAFT	01
16M	0511017302	FLAT WASHER	01
16N	0503010257	1/8" X 1" COTTERPIN	01




Item	Code	Description	07 09 11
00	0501058164	MECANIC ROW MARK	01 00 00
00A	0501058169	MECANIC ROW MARK	00 01 00
00B	0501058171	MECANIC ROW MARK	00 00 01
01	0511069621	MECANIC ROW MARK SUPPORT	02 02 02
02	0503012407	5/8" X 1-1/2" BOLT	08 08 08
03	0503010027	SPRING WASHER	15 15 15
04	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	13 13 13
05	0551018204	RIGHT ROW MARKER FIXER	01 01 01
06	0551018205	LH ROW MARKER FIXER	01 01 01
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	06 06 06
08	0501010984	FLAT WASHER	12 12 12
09	0503010025	3/8 SPRING WASHER	08 08 08
10	0503010026	3/8" NUT	08 08 08
11	0521010549	COUPLING SHAFT	02 02 02
12	0503030168	HAIR PIN	02 02 02
13	0511060475	ROW MARKER ARM	01 01 01
14	0511060576	LH ROW MARKER ARM	01 01 01
15	0503010769	5/8" X 2-1/4" BOLT	04 04 04
16	0521010479	SLEEVE ARTICULATION	04 04 04
17	0501069643	890 TURNBUCKLE	02 02 02
18	0501066949	1235 TURNBUCKLE	00 00 02
19	0511016156	5/8" X 1.1/2" BOLT	04 04 04
20	0502010421	SIDE PULLEY	02 02 02
21	0521010445	0.53" X 0.75" X 0.45" SLEEVE	02 02 02
22	0521010641	COUPLING SHAFT	02 02 02
23	0503010140	1/8" X 3/4" COTTERPIN	04 04 04
24	0501058197	ROW MARKER PIVOT	01 01 01
24A	0501065640	ROW MARKER ROD GUIDE	02 02 02
24B	0503010238	1/2" X 1-3/4" BOLT	02 02 02
24C	0503010740	1/2" X 2" BOLT	02 02 02
24D	0511017302	FLAT WASHER	06 06 06
24E	0503010019	1/2" SPRING WASHER	11 13 21
24F	0503010060	1/2" NUT	10 12 20


Item	Code	Description	07 09 11
24G	0501065644	ROW MARKER ARM/DISARMMENT ROD	01 01 01
24H	0501064229	REGULATOR ARM/DISARMMENT ROD	01 01 01
24I	0501062547	ROW MARKER BAR REGULATOR	01 01 01
24J	0503010395	1/2" X 1-1/4" BOLT	01 01 01
24K	0521010454	0.83" X 1.25" X 0.79" SLEEVE	01 01 01
24L	0503010734	1/2" X 2-1/2" BOLT	01 01 01
24M	0521010539	0.3" X 1.2" COUPLING SHAFT	02 02 02
24N	0503010013	5/8" NUT	02 02 02
24O	0521062281	ROW MARK ARM LOCK	02 02 02
24P	0503032995	STEEL CABLE	02 02 02
24Q	0501010096	3/8" X 2" BOLT	02 02 02
24R	0531010415	ROW MARKER ARM/DISARM GUIDE SLLEVE	04 04 04
24S	0501065642	ROW MARKER SUPPORT	01 01 01
24T	0502011231	CENTRAL PULLEY	03 03 03
24U	0521010693	PULLEY FIXER PLATE	01 01 01
24V	0511011308	BOLT	02 02 02
24W	0503010691	1/4" GREASE FITTING	02 02 02
24X	0503010232	5/8" X 1.3/4" BOLT	02 02 02
25	0503010762	5/8" X 3-12" BOLT	01 01 01
26	0503011126	6,4 X 1000 CHAIN	02 00 00
27	0503011128	6,4 X 1400 CHAIN	00 02 00
28	0503011129	6,4 X 1900 CHAIN	00 00 02
29	0502011291	CHAIN SLEEVE	02 02 02
30	0503010683	0,2" X 1,2" SPRING PIN	02 02 02
31	0551019268	RIGHT COVER PROTECTION	01 00 00
32	0551019269	LEFT COVER PROTECTION	01 00 00
33	0551018206	LEFT COVER ARM/DISARMMENT	00 01 00
34	0551018207	LEFT COVER PROTECTION	00 01 00
35	0551019266	RIGHT PROTECTION COVER	00 00 01
36	0551019267	LEFT PROTECTION COVER	00 00 01
37	0503010920	1/2" X 1.1/2" BOLT	04 04 04
38	0501050633	DISC ASSY FOR ROW MARKER	02 02 02
39	0521013164	PROTRACTOR TURNBUCKLE	00 00 02
40	0501011310	FIXER LOCK	00 00 08
41	0503010706	1/2" X 4.1/2" BOLT	00 00 08
42	0551018955	1/2" X 1-1/2" BOLT	02 04 04




Item	Code	Description	QT
01	0511053904	ROW MARKER DISC	01
02	0503010023	SPRING WASHER	01
03	0503010014	3/4" NUT	01




Item	Code	Description	07 09
01	0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	07 09
02	0501080422	3/8" X 157" TC-TM HOSE ASSY	01 01
03	0501080446	3/8 X" 169" TC-TM HOSE ASSY	01 01
04	0501053834	FAST COUPLER AGRICULTURAL WITH COVER - 1/2	02 02
04A	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT	02 02
04B	0503011882	QUICK CONNECTION COVER	02 02




Item	Code	Description	QT
01	0503060132	VDFS-002 T SEQUENCIAL VALVE	01
02	0501010617	3/4" NIPPLE	02
03	0503010190	2-114 N 3006-9B O'RING	02
04	0501012109	3/4" X 9/16" NIPPLE	04
05	0503011036	2-111 N 3006-9B O'RING	06
06	0531019339	9/16" UNF X 12 PUMP	02



Item	Code	Description	07 09 11
01	0511011311	VALV. SUPPORT	01 01 01
02	0503010232	5/8" X 1.3/4" BOLT	02 02 02
03	0503010027	SPRING WASHER	02 02 02
04	0503010013	5/8" NUT	02 02 02
05	0501054649	SEQUENTIAL VALVE ASSY	01 01 01
06	0503010365	NUT	02 02 02
07	0503010179	SPRING WASHER	02 02 02
08	0501010694	FLAT WASHER	02 02 02
09	0501080452	3/8" X 98" TR-TR HOSE ASSY	02 00 00
10	0501080401	3/8" X 106" TR-TC HOSE ASSY	02 00 00
11	0501080422	3/8" X 157" TC-TM HOSE ASSY	02 02 02
12	0501081727	TR-TR HOSE ASSY	00 02 00
13	0501080447	3/8" X 122" TR-TC HOSE ASSY	00 02 00
14	0501080343	TR-TR HOSE ASSY	00 00 02
15	0501080720	3/8" X 137" TR-TC HOSE ASSY	00 00 02
16	0501053834	FAST COUPLER AGRICULTURAL WITH COVER - 1/2	02 02 02
16A	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT	02 02 02
16B	0503011882	QUICK CONNECTION COVER	02 02 02



Item	Code	Description	QT
01	0511041187	HYDRAULIC CYLINDER	02
02	0511063404	"T" OIL CONDUCTOR	02
03	0502012702	BODY SUPPORT CLAMP	06
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	06
05	0501010984	FLAT WASHER	06
06	0503010025	3/8 SPRING WASHER	06
07	0501080449	3/8" X 1500 TC-TC HOSE	04
08	0501080361	3/8" X 157" TR-TM HOSE ASSY	02
09	0501053834	FAST COUPLER AGRICULTURAL WITH COVER - 1/2	02
09A	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT	02
09B	0503011882	QUICK CONNECTION COVER	02



Item	Code	Description	07 09 11 L.
01	0521013432	5/8" X 59" AXLE HEX	01 00 00
02	0521013428	HEX AXLE	01 00 00
03	0521013433	5/8" X 75" AXLE HEX	00 01 00
04	0521013429	LEFT 5/8" X 50.4" AXLE HEX	00 01 00
05	0521013434	5/8" X 90" HEX AXLE	00 00 01
06	0521013430	5/8" X 101.57" HEX AXLE	00 00 01
07	0511015098	FLAT WASHER	02 02 02
08	0502040723	5/8 HEX AXLE BEARING SLEEVE	00 02 02
09	0501110037	5/8" HEX AXLE LEFT BEARING ASSY	02 00 02
10	0503010003	1845 GREASE FITTING	02 02 02
11	0503010365	NUT	04 04 04
12	0501010984	FLAT WASHER	04 04 04
13	0501010694	FLAT WASHER	08 08 08
14	0503010179	SPRING WASHER	04 04 04
15	0503010337	5/16" NUT	04 04 04
16	0511017305	FLAT WASHER	04 04 04
17	0511065562	20Z GEAR	02 02 02
18	0502011299	BUSHING GEAR	02 02 02
19	0503010010	1/4" X 2.1/2" COTTERPIN	02 02 02

[illegible]



MARCHESAN IMPLEMENTOS E MÁQUINAS AGRÍCOLAS TATU S.A.

AV. Marchesan, 1979 - Post office box, 131 - CEP 15994-900 - Matão - SP - Brazil

Phone +55 16.3382-8282

(FAX Parts) + 55 16.3382. 8297 - (Export) + 55 16.3382.1003

e.mail: tatu@marchesan.com.br www.marchesan.com.br

Technical Publications: Elaboration

ALESSANDRA PATRICIA KAWAHARA CARRILI

Technical Publications: Revision

LUIZ CANDIDO

Contact Catálogo:

E-mail = jgaspari@marchesan.com.br

**ORIGINAL PARTS
TATU**

