

PARTS CATALOGUE



ROW CROP PLANTERS

Code:

0501091658

Product:

COP TRIO SUPREME - FRAME 5750/6850



Series:

S-0415

Revision:

00

Date Revision:

ABRIL/2016

PRODUCTS



Code	Description
0111460004	COP TRIO 5750/13E450 D/HDA CSU TIT S-0415
0111460002	COP TRIO 5750/13E450 D/HDA MH S-0415
0111460013	COP TRIO 5750/13E450 D/IAPAR MH S-0415
0111460006	COP TRIO 5750/13E450 D/IAPAR MH CSU TIT S-0415
0111460001	COP TRIO 5750/13E450 D/IAPAR MH PM400 TIT S-0415
0111460009	COP TRIO 5750/13E450 MH CSU PM400 S-0415
0111460008	COP TRIO 6350/13E500 IAPAR MH DPLE20 CPRA TIT S415
0111460005	COP TRIO 6850/15E450 HDA MH CEAC S-0415
0111460007	COP TRIO 6850/15E450 MH CSU TIT PM100 S-0415
0111460014	COP TRIO 7655/17E450 MH CSU TIT S-0415
0111460010	COP TRIO 8450/17E500 MH CSU S-0415
0111420008	COP TRIO SUP PP 5750/13E450 MTH CSU S-0415
0111420006	COP TRIO SUP PP 6850/15E450 ESPECIAL S-0415

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.



MARCHESAN

INDEX


0909091763	FRAME COP TRIO SUP 5750/13 L.	1
0909092772	FRAME COP TRIO SUP 6850/15 L.	2
0511058123	RIGHT WHEEL ASSY	3
0511050439	RIGHT WHEEL ASSY	4
0511058124	WHEELED ASSEMBLY LEFT	5
0511050440	WHITH LEFT WHEEL ASSY	6
0511050444	WHITH LEFT WHEEL ASSY WITHOUT TRANSMISSION	7
0511050443	WHITH RIGHT WHEEL ASSY WITHOUT TRANSMISSION	8
0521045756	HYDRAULIC CYLINDER	9
0511058449	HYDRAULIC CYLINDER	10
0511058125	MOTOR SHAFT ASSEMBLY 5750	11
0511057797	MOTOR SHAFT ASSEMBLY	12
0511047069	SIDE TRANSMISSION DRIVING	13
0511047070	LH SIDE TRANSMISSION DRIVING	14
0501052560	AXLE MOTOR SLOW-MOVING ASSY	15
0511051434	TRANSMISSION DRIVING ASSY	16
0511058126	ASSY HEX AXLE	17
0511057798	ASSY HEX AXLE	18
0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	19
0503062206	CARDAN TERMINAL	20
0511058128	HYDRAULIC ASSY	21
0511057844	HYDRAULIC ASSY	22
0511057842	VALVE ASSY	23
0511058127	OIL 5750 CONDUCTOR ASSY	24
0511057843	OIL CONDUCTOR ASSY	25
0511053368	HYDRAULIC CYLINDER ASSEMBLY	26
0511057838	HOSE HYDRAULIC PLAY	27
0511058411	HYDRAULIC CYLINDER	28
0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	29
0511052333	ASSY SUPPORT LEFT FIXER CHANGE	30
0511050639	RIGHT GEAR BOX ASSY	31
0511050640	LEFT GEAR BOX ASSY	32
0511057815	RIGHT TRANSMISSION ASSY	33
0511058262	HYDRAULIC MARKER	34
0511057801	HYDRAULIC MARKER	35
0501050633	MARKER DISC ASSY LINE	36
0511058129	ASSY SILO FERTILIZER RIGHT/LEFT/CENTRAL - 5750	37
0511057811	SET FERTILIZER SILO	38
0511058130	LEFT FERTILIZER BOX SUPPORT 5750	39
0511058131	RIGHT FERTILIZER BOX SUPPORT 5750	40
0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	41
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	42
0511058132	CENTRAL FERTILIZER BOX SUPPORT 5750	43
0503062391	SILO FERTILIZER 5 MOUTHS	44
0503062362	BEAN FERTILIZER ASSY	45
0503062476	CARDAN TERMINAL	46
0511057813	RIGHT FERTILIZER BOX SUPPORT 7655	47
0511057812	LEFT FERTILIZER BOX SUPPORT 7655	48
0511057814	CENTER FERTILIZER SILO SUPPORT	49
0503062208	CARDAN TERMINAL	50
0511058133	PLATFORM ASSEMBLY 5750	51
0511057799	PLATFORM SET	52
0511053356	ASSY LADDER	53
0511058134	HANDRAIL ASSEMBLY 5750	54
0511057800	JOINT HANDRAILSET	55



MARCHESAN


INDEX

0511054971	RESTING ASSEMBLY	56
0511057803	ASSY PORT MANUAL INSTRUCCION	57
0511058579	ASSEMBLY CSU C3 SEMI MOUNTED 5750	58
0511057821	ASSY CSU C3	59
0511058580	ASSEMBLY CSU C3 2 BOXES 5/4 - 1 BOX 5/5 5750	60
0511057822	ASSY CSU	61
0511057823	ASSY CSU	62
0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	63
0909090895	FERTILIZER SEED ROW ASSY	64
0511057243	LEFT SHORT SEED ROW FRONT	65
0511057244	RIGTH SHORT SEED ROW FRONT	66
0511057246	RIGHT LONG SEED ROW FRONT	67
0511057247	LEFT LONG SEED ROW FRONT	68
0909094635	REAR SEED ROW	69
0511053023	LONG FERTILIZER LINE	70
0511053024	FERTILIZER SHORT LINE	71
0511051818	DISC CUT 18 SEMI MOUNTED	72
0511051819	DC 20 SEMI MOUNTED	73
0501052976	15 X 15 RIGHT FERT UNAL DOUB-DISC ASSY	74
0501052977	DDD LEFT FERTILIZER 15 X 15 ASSY	75
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	76
0511058650	SEMI-MOUNTED DEPTH CONTROL	77
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	78
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	79
0501052297	DEPTH WHEELS REGULATOR ASSY	80
0501052538	DEPTH BAND WITH ARMS	81
0511054334	COMPACT WHEEL LEFT WITH BEARING	82
0511054333	COMPACT WHEEL RIGHT WITH BEARING	83
0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	84
0511052971	CONTROL DEPTH WITH SEMI MOUNTED THREAD	85
0511055819	DEPTH WHIT AROS BAND	86
0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	87
0511058756	RIGHT REAR SUPREME SEED LINE P.P PM400 CSU	88
0511057606	PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX	89
0511057491	PRECISION PLANTING SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	90
0511057154	DDD RITGH SUPREMA PRECISION PLANTING	91
0511058755	LEFT REAR SUPREME SEED LINE P.P PM400 CSU	92
0511057153	DDD LEFT SUPREMA PRECISION PLANTING	93
0511056623	RIGHT REAR LINE SEED	94
0511056624	LEFT REAR LINE SEED	95
0511058615	LEFT REAR	96
0511057249	PNEUMATIC SEAL DISTRIBUTOR WITH AXIS STATION	97
0511058616	SEED DISTRIBUTOR	98
0909090912	CENTRAL COMMAND CEAC COP F 600 ATE 15L	99
0511058612	REAR TURBINE ASSY	100
0511057657	TURBINE	101
0501054983	NIPPLE HIDRAULIC MOTOR	102
0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE	103
0511057658	DISTRIBUTOR AIR 03 EXITS	104
0909090900	SET OF PLANTING MONITORING 13/15 SEED LINES AND FERTILIZER	105
0561016747	2 X 1500 AIR CONDUCTOR	106
0571019712	AIR CONDUCTOR	107
0511053342	SQUARE AXLE ASSEMBLY (730)	108



Item	Code	Description	See page	13E450
01	0521066475	RIGHT SIDE FRAME ASSY	01	
02	0521066476	RIGHT SIDE FRAME ASSY	01	
03	0521066293	CENTRAL CHASSIS	01	
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES	04	
05	0503011445	SPRING WASHER	16	
06	0501010098	3/4" UNC BOLT	16	
07	0571010094	SLEEVE FLANGE	12	
08	0521066298	ARTICULATOR	04	
09	0571013510	LOCK AXLE	08	
10	0503030085	LOCK PIN	04	
11	0571010095	FLAT WASHER	04	
12	0503011442	3/4" SPRING WASHER	04	
13	0501010098	3/4" UNC BOLT	04	
14	0521063003	LOCK PIN	02	
15	0571010969	LOCK SLEEVE FRAME	02	
16	0503013627	1.1/2 SPRING WASHER	02	
17	0501010110	1.1/2" NUT	02	
18	0521064285	LOCK LOWER FRAME	02	
19	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN	02	
20	0503010002	1800 GREASE FITTING	04	
21	0503010003	1845 GREASE FITTING	03	
22	0521045756	HYDRAULIC CYLINDER	9	01
23	0511057653	HYDRAULIC CYLINDER		01
24	0521010779	31.75 X 95 COUPLING SHAFT		01
25	0521010581	0.9" X 4.9" COUPLING SHAFT		01
26	0531016049	FLAT WASHER		02
27	0503030085	LOCK PIN		02
28	0511054971	RESTING ASSEMBLY	56	02
29	0511061021	SUPPORT FASTENER		04
30	1902010175	HITCH CLAMP		08
31	0511010736	5/8" X 5-1/4" BOLT		16

Item	Code	Description	See page	13E450
32	0501013753	FLAT WASHER		16
33	0503010811	5/8" UNF SELF ADJUSTING NUT		16
34	0511057825	SIDE EXTENSOR		02
35	0571019951	JUNCTION SHAFT		02
36	0503010523	1/4" X 2" COTTERPIN		04
37	0503030119	LOCK PIN		10
38	0571019949	JUNCTION SHAFT		02
39	0511057816	EXTENSOR 3 POINTS		01
40	0521018532	1.4" X 12" COUPLING SHAFT		01
41	0571019950	COUPLING SHAFT		01
42	0511057656	INTERMEDIATE HEADER EXTENSOR		02
43	0521010571	COUPLING SHAFT		04
44	0521066290	INTERMEDIATE HEAD 5750/6850/7860/8160		01
45	0521066289	FRONT HEADER 5750/7350		01
46	0571019949	JUNCTION SHAFT		04
47	0511057817	SUPPORT HOSE		01
48	0521066303	HOSE GUIDE		01
49	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		02
50	0503013816	5/16" LOCKNUT		02
51	0511055096	TRACTOR HITCH		01
52	0501047881	AXIS JOINT ASSY		01
52A	0501068989	COUPLING SHAFT		01
52B	0503031035	HAIR PIN		01
53	0511053356	ASSY LADDER	53	02
54	0511058262	HYDRAULIC MARKER	34	02
55	0521013022	TRANSPORT LOCK		06
56	0501068994	0.3" X 3.1" LOCK PIN		06
57	0503030168	HAIR PIN		06
58	0501047885	ROD STOP		06
59	0501047886	ROD STOP		06
60	0501047887	ROD STOP		06
61	0541015451	FIXED KEY 2.3/8 X 2.3/4		01
62	0511058133	PLATFORM ASSEMBLY 5750	51	01
63	0511058134	HANDRAIL ASSEMBLY 5750	54	01
64	0502012702	BODY SUPPORT CLAMP		12
65	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		12
66	0503010180	7/16" SPRING WASHER		12
67	0511058126	ASSY HEX AXLE	17	01




Item	Code	Description	See page	6850/15 L.
01	0521066292	RIGHT SIDE FRAME		01
02	0521066294	LEFT SIDE FRAME		01
03	0521066293	CENTRAL CHASSIS		01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0503011445	SPRING WASHER		16
06	0501010098	3/4" UNC BOLT		16
07	0571010094	SLEEVE FLANGE		12
08	0521066298	ARTICULATOR		04
09	0571013510	LOCK AXLE		08
10	0503030085	LOCK PIN		04
11	0571010095	FLAT WASHER		04
12	0503011442	3/4" SPRING WASHER		04
13	0501010098	3/4" UNC BOLT		04
14	0521063003	LOCK PIN		02
15	0571010969	LOCK SLEEVE FRAME		02
16	0503013627	1.1/2 SPRING WASHER		02
17	0501010110	1.1/2" NUT		02
18	0521064285	LOCK LOWER FRAME		02
19	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		02
20	0503010002	1800 GREASE FITTING		04
21	0503010003	1845 GREASE FITTING		03
22	0521045756	HYDRAULIC CYLINDER	9	01
23	0511057653	HYDRAULIC CYLINDER		01
24	0521010779	31.75 X 95 COUPLING SHAFT		01
25	0521010581	0.9" X 4.9" COUPLING SHAFT		01
26	0531016049	FLAT WASHER		02
27	0503030085	LOCK PIN		02
28	0511054971	RESTING ASSEMBLY	56	02
29	0511061021	SUPPORT FASTENER		04
30	1902010175	HITCH CLAMP		08
31	0511010736	5/8" X 5-1/4" BOLT		16

Item	Code	Description	See page	6850/15 L.
32	0501013753	FLAT WASHER		16
33	0503010811	5/8" UNF SELF ADJUSTING NUT		16
34	0511057825	SIDE EXTENSOR		02
35	0571019951	JUNCTION SHAFT		02
36	0503010523	1/4" X 2" COTTERPIN		04
37	0503030119	LOCK PIN		10
38	0571019949	JUNCTION SHAFT		02
39	0511057816	EXTENSOR 3 POINTS		01
40	0521018532	1.4" X 12" COUPLING SHAFT		01
41	0571019950	COUPLING SHAFT		01
42	0511057656	INTERMEDIATE HEADER EXTENSOR		02
43	0521010571	COUPLING SHAFT		04
44	0521066290	INTERMEDIATE HEAD 5750/6850/7860/8160		01
45	0521066289	FRONT HEADER 5750/7350		01
46	0571019949	JUNCTION SHAFT		04
47	0511057817	SUPPORT HOSE		01
48	0521066303	HOSE GUIDE		01
49	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		02
50	0503013816	5/16" LOCKNUT		02
51	0511055096	TRACTOR HITCH		
52	0501047881	AXIS JOINT ASSY		01
52A	0501068989	COUPLING SHAFT		01
52B	0503031035	HAIR PIN		01
53	0511053356	ASSY LADDER	53	02
54	0511057801	HYDRAULIC MARKER	35	02
55	0521013022	TRANSPORT LOCK		06
56	0501068994	0.3" X 3.1" LOCK PIN		06
57	0503030168	HAIR PIN		06
58	0501047885	ROD STOP		06
59	0501047886	ROD STOP		06
60	0501047887	ROD STOP		06
61	0541015451	FIXED KEY 2.3/8 X 2.3/4		01
62	0511057799	PLATFORM SET	52	01
63	0511057800	JOINT HANDRAILSET	55	01
64	0502012702	BODY SUPPORT CLAMP		12
65	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		12
66	0503010180	7/16" SPRING WASHER		12
67	0511057798	ASSY HEX AXLE	18	01

RIGHT WHEEL ASSY

0511058123



Item	Code	Description	See page	QT
01	0521066480	RH WHEELS SUPPORT	01	
02	0501054284	STRETCHER CURRENT TRANSMISSION SIDE	01	
03	0511064744	WHEEL FORK	01	
04	0501110625	BEARING ARTICULATION WHEEL	02	
05	0503013232	1/2" BOLT	08	
06	0503010019	1/2" SPRING WASHER	08	
07	0561013021	BEARING INNER LOK	02	
08	0561013022	BEARING EXTERNAL LOCK	02	
09	0503010398	501082 CLAMPING RING (FOR AXLE)	02	
10	0561013020	KM 12 NUT	02	
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX	01	
12	0521012190	AXLE LOCK	02	
13	0503010027	5/8" SPRING WASHER	02	
14	0503011167	M16 X 2 X 30 BOLT	02	
15	0511061808	15Z GEAR WITH AXLE,	01	
16	0501018466	FLAT WASHER	01	
17	0511061809	15Z GEAR WITH COUPLING	01	
18	0503011103	7/16" X 2-1/2" BOLT	01	
19	0503010180	7/16" SPRING WASHER	01	
20	0503010244	7/16" NUT	01	
21	0503010004	1890 GREASE FITTING	02	
22	0541012098	LEFT CHAIN TIGHTENER LARGER SUPPORT	01	
23	0531018653	CHAIN TIGHTENER MINOR SUPPORT	01	
24	0531016916	SLEEVE BEARING SUPPORT	02	
25	0503010899	5/8" X 2-1/4" BOLT	01	
26	0503010027	5/8" SPRING WASHER	01	
27	0503010013	5/8" NUT	01	
28	0501013491	5/8" TENSIONER SPRING	01	
29	0503010013	5/8" NUT	02	
30	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING	01	
31	0501053522	WHEEL CHAIN TENSIONER	01	


RIGHT WHEEL ASSY

0511058123

Item	Code	Description	See page	QT
32	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
33	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
34	0511053375	CURRENT DEVIATION ASSY WHEEL		01
35	0531016051	CARRY-WHEEL CHAIN PROTECTION CAP		01
36	0503010834	1/2 X 1 BOLT		02
37	0511017302	FLAT WASHER		02
38	0503010019	1/2" SPRING WASHER		02
39	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
40	0511010736	5/8" X 5-1/4" BOLT		04
41	0501013753	FLAT WASHER		04
42	0503010811	5/8" UNF SELF ADJUSTING NUT		04
43	0502012720	WHEEL SUPPORT FIXER		01
44	0503017857	BOLT 5/8 UNF 4		04
45	0503010811	5/8" UNF SELF ADJUSTING NUT		04
46	0501012140	FLAT WASHER		04

RIGHT WHEEL ASSY

0511050439




Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0501054284	STRETCHER CURRENT TRANSMISSION SIDE		01
03	0511064744	WHEEL FORK		01
04	0501110625	BEARING ARTICULATION WHEEL		02
05	0503013232	1/2" BOLT		08
06	0503010019	1/2" SPRING WASHER		08
07	0561013021	BEARING INNER LOK		02
08	0561013022	BEARING EXTERNAL LOCK		02
09	0503010398	501082 CLAMPING RING (FOR AXLE)		02
10	0561013020	KM 12 NUT		02
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX		01
12	0521012190	AXLE LOCK		02
13	0503010027	5/8" SPRING WASHER		02
14	0503011167	M16 X 2 X 30 BOLT		02
15	0511061808	15Z GEAR WITH AXLE,		01
16	0501018466	FLAT WASHER		01
17	0511061809	15Z GEAR WITH COUPLING		01
18	0503011103	7/16" X 2-1/2" BOLT		01
19	0503010180	7/16" SPRING WASHER		01
20	0503010244	7/16" NUT		01
21	0503010004	1890 GREASE FITTING		02
22	0541012098	LEFT CHAIN TIGHTENER LARGER SUPPORT		01
23	0531018653	CHAIN TIGHTENER MINOR SUPPORT		01
24	0531016916	SLEEVE BEARING SUPPORT		02
25	0503010899	5/8" X 2-1/4" BOLT		01
26	0503010027	5/8" SPRING WASHER		01
27	0503010013	5/8" NUT		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8" NUT		02
30	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
31	0501053522	WHEEL CHAIN TENSIONER		01

RIGHT WHEEL ASSY

0511050439

Item	Code	Description	See page	QT
32	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
33	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
34	0511053375	CURRENT DEVIATION ASSY WHEEL		01
35	0531016051	CARRY-WHEEL CHAIN PROTECTION CAP		01
36	0503010834	1/2 X 1 BOLT		02
37	0511017302	FLAT WASHER		02
38	0503010019	1/2" SPRING WASHER		02
39	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
40	0511010736	5/8" X 5-1/4" BOLT		04
41	0501013753	FLAT WASHER		04
42	0503010811	5/8" UNF SELF ADJUSTING NUT		04
43	0502012720	WHEEL SUPPORT FIXER		01
44	0503017857	BOLT 5/8 UNF 4		04
45	0503010811	5/8" UNF SELF ADJUSTING NUT		04
46	0501012140	FLAT WASHER		04
47	0501047888	ROD STOP		01




Item	Code	Description	See page	QT
01	0521066479	RH WHEELS SUPPORT	01	
02	0501054284	STRETCHER CURRENT TRANSMISSION SIDE	01	
03	0511065842	LEFT WHEEL FORK	01	
04	0501110625	BEARING ARTICULATION WHEEL	02	
05	0503013232	1/2" BOLT	08	
06	0503010019	1/2" SPRING WASHER	08	
07	0561013021	BEARING INNER LOK	02	
08	0561013022	BEARING EXTERNAL LOCK	02	
09	0503010398	501082 CLAMPING RING (FOR AXLE)	02	
10	0561013020	KM 12 NUT	02	
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX	01	
12	0521012190	AXLE LOCK	02	
13	0503010027	5/8" SPRING WASHER	02	
14	0503011167	M16 X 2 X 30 BOLT	02	
15	0511061808	15Z GEAR WITH AXLE,	01	
16	0501018466	FLAT WASHER	01	
17	0511061809	15Z GEAR WITH COUPLING	01	
18	0503011103	7/16" X 2-1/2" BOLT	01	
19	0503010180	7/16" SPRING WASHER	01	
20	0503010244	7/16" NUT	01	
21	0503010004	1890 GREASE FITTING	02	
22	0531018654	CHAIN TIGHTENER SUPPORT	01	
23	0531018653	CHAIN TIGHTENER MINOR SUPPORT	01	
24	0531016916	SLEEVE BEARING SUPPORT	02	
25	0503010899	5/8" X 2-1/4" BOLT	01	
26	0503010027	5/8" SPRING WASHER	01	
27	0503010013	5/8" NUT	01	
28	0501013491	5/8" TENSIONER SPRING	01	
29	0503010013	5/8" NUT	02	
30	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING	01	
31	0501053522	WHEEL CHAIN TENSIONER	01	

WHEELED ASSEMBLY LEFT

0511058124

Item	Code	Description	See page	QT
32	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
33	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
34	0511053375	CURRENT DEVIATION ASSY WHEEL		01
35	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		01
36	0503010834	1/2 X 1 BOLT		02
37	0511017302	FLAT WASHER		02
38	0503010019	1/2" SPRING WASHER		02
39	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
40	0511010736	5/8" X 5-1/4" BOLT		04
41	0501013753	FLAT WASHER		04
42	0503010811	5/8" UNF SELF ADJUSTING NUT		04
43	0502012720	WHEEL SUPPORT FIXER		01
44	0503017857	BOLT 5/8 UNF 4		04
45	0503010811	5/8" UNF SELF ADJUSTING NUT		04
46	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT	01	
02	0501054284	STRETCHER CURRENT TRANSMISSION SIDE	01	
03	0511065842	LEFT WHEEL FORK	01	
04	0501110625	BEARING ARTICULATION WHEEL	02	
05	0503013232	1/2" BOLT	08	
06	0503010019	1/2" SPRING WASHER	08	
07	0561013021	BEARING INNER LOK	02	
08	0561013022	BEARING EXTERNAL LOCK	02	
09	0503010398	501082 CLAMPING RING (FOR AXLE)	02	
10	0561013020	KM 12 NUT	02	
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX	01	
12	0521012190	AXLE LOCK	02	
13	0503010027	5/8" SPRING WASHER	02	
14	0503011167	M16 X 2 X 30 BOLT	02	
15	0511061808	15Z GEAR WITH AXLE,	01	
16	0501018466	FLAT WASHER	01	
17	0511061809	15Z GEAR WITH COUPLING	01	
18	0503011103	7/16" X 2-1/2" BOLT	01	
19	0503010180	7/16" SPRING WASHER	01	
20	0503010244	7/16" NUT	01	
21	0503010004	1890 GREASE FITTING	02	
22	0531018654	CHAIN TIGHTENER SUPPORT	01	
23	0531018653	CHAIN TIGHTENER MINOR SUPPORT	01	
24	0531016916	SLEEVE BEARING SUPPORT	02	
25	0503010899	5/8" X 2-1/4" BOLT	01	
26	0503010027	5/8" SPRING WASHER	01	
27	0503010013	5/8" NUT	01	
28	0501013491	5/8" TENSIONER SPRING	01	
29	0503010013	5/8" NUT	02	
30	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING	01	
31	0501053522	WHEEL CHAIN TENSIONER	01	


WHITH LEFT WHEEL ASSY

0511050440


Item	Code	Description	See page	QT
32	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
33	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
34	0511053375	CURRENT DEVIATION ASSY WHEEL		01
35	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		01
36	0503010834	1/2 X 1 BOLT		02
37	0511017302	FLAT WASHER		02
38	0503010019	1/2" SPRING WASHER		02
39	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
40	0511010736	5/8" X 5-1/4" BOLT		04
41	0501013753	FLAT WASHER		04
42	0503010811	5/8" UNF SELF ADJUSTING NUT		04
43	0502012720	WHEEL SUPPORT FIXER		01
44	0503017857	BOLT 5/8 UNF 4		04
45	0503010811	5/8" UNF SELF ADJUSTING NUT		04
46	0501012140	FLAT WASHER		04
47	0501047888	ROD STOP		01




Item	Code	Description	See page	5750/6850
01	0521063678	WHEEL SUPPORT	01	
02	0503011167	M16 X 2 X 30 BOLT	02	
03	0511065842	LEFT WHEEL FORK	01	
04	0501110625	BEARING ARTICULATION WHEEL	02	
05	0503013232	1/2" BOLT	08	
06	0503010019	1/2" SPRING WASHER	08	
07	0561013021	BEARING INNER LOK	02	
08	0561013022	BEARING EXTERNAL LOCK	02	
09	0503010398	501082 CLAMPING RING (FOR AXLE)	02	
10	0561013020	KM 12 NUT	02	
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX	01	
12	0521012190	AXLE LOCK	02	
13	0503010027	5/8" SPRING WASHER	02	
14	0502010584	CARRYING-WHEELS SUPPORT FIXER	02	
15	0511010736	5/8" X 5-1/4" BOLT	04	
16	0501013753	FLAT WASHER	04	
17	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
18	0503017857	BOLT 5/8 UNF 4	04	
19	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
20	0501012140	FLAT WASHER	04	
21	0502012720	WHEEL SUPPORT FIXER	01	
22	0501047888	ROD STOP	01	




Item	Code	Description	See page	5750/6850
01	0521063678	WHEEL SUPPORT	01	
02	0503011167	M16 X 2 X 30 BOLT	02	
03	0511064744	WHEEL FORK	01	
04	0501110625	BEARING ARTICULATION WHEEL	02	
05	0503013232	1/2" BOLT	08	
06	0503010019	1/2" SPRING WASHER	08	
07	0561013021	BEARING INNER LOK	02	
08	0561013022	BEARING EXTERNAL LOCK	02	
09	0503010398	501082 CLAMPING RING (FOR AXLE)	02	
10	0561013020	KM 12 NUT	02	
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX	01	
12	0521012190	AXLE LOCK	02	
13	0503010027	5/8" SPRING WASHER	02	
14	0502010584	CARRYING-WHEELS SUPPORT FIXER	02	
15	0511010736	5/8" X 5-1/4" BOLT	04	
16	0501013753	FLAT WASHER	04	
17	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
18	0502012720	WHEEL SUPPORT FIXER	01	
19	0503017857	BOLT 5/8 UNF 4	04	
20	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
21	0501012140	FLAT WASHER	04	
22	0501047888	ROD STOP	01	




Item	Code	Description	See page	QT
01	0511057653	HYDRAULIC CYLINDER		01
02	0501053835	FEMALE QUICK COUPLER		02




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02




Item	Code	Description	See page	QT
01	0561017269	MOTOR AXLE BEARING SUPPORT		04
02	0503011082	C1/2" X 1.3/4" SCREW		08
03	0511017302	FLAT WASHER		16
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0501110639	BEARING		08
07	0503010300	5/32" X 1" COTTERPIN		08
08	0503011099	GREASE FITTING		08
09	0581010468	MOTOR SHAFT ASSEMBLY		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0511047069	SIDE TRANSMISSION DRIVING	13	01
15	0511047070	LH SIDE TRANSMISSION DRIVING	14	01
16	0511051434	TRANSMISSION DRIVING ASSY	16	04
17	0501052560	AXLE MOTOR SLOW-MOVING ASSY	15	02




Item	Code	Description	See page	QT
01	0561017269	MOTOR AXLE BEARING SUPPORT		04
02	0503011082	C1/2" X 1.3/4" SCREW		08
03	0511017302	FLAT WASHER		16
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0501110639	BEARING		08
07	0503010300	5/32" X 1" COTTERPIN		08
08	0503011099	GREASE FITTING		08
09	0571014441	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 C50P G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0511047069	SIDE TRANSMISSION DRIVING	13	01
15	0511047070	LH SIDE TRANSMISSION DRIVING	14	01
16	0511051434	TRANSMISSION DRIVING ASSY	16	04
17	0501052560	AXLE MOTOR SLOW-MOVING ASSY	15	02




Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	5/16" X 3/4" BOLT		02
03	0503010179	5/16" ZN SPRING WASHER		02
04	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02



Item	Code	Description	See page	QT
001	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	19	02
002	0581010472	HEX AXLE		02
003	0571013470	5/8 X 1100 HEX AXLE		01
004	0571013469	5/8 X 700 HEX AXLE		01
005	0502040534	SPRING GUIDE BUSHING LOCK		08
006	0503010834	1/2 X 1 BOLT		08
007	0561014215	BEARING COVER LOWER ROW FRAME		02
008	0503062206	CARDAN TERMINAL	20	02
009	0503011855	0.2" X 1.8" SPRING PIN		04
010	0503030331	1.2" X 1.2" X 12.2" HOSE		02
011	0503010243	CLAMP		04




Item	Code	Description	See page	QT
001	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	19	02
002	0571013468	5/8 X 2040 HEX AXLE		02
003	0571013470	5/8 X 1100 HEX AXLE		01
004	0571013469	5/8 X 700 HEX AXLE		01
005	0502040534	SPRING GUIDE BUSHING LOCK		08
006	0503010834	1/2 X 1 BOLT		08
007	0561014215	BEARING COVER LOWER ROW FRAME		02
008	0503062206	CARDAN TERMINAL	20	02
009	0503011855	0.2" X 1.8" SPRING PIN		04
010	0503030331	1.2" X 1.2" X 12.2" HOSE		02
011	0503010243	CLAMP		04




Item	Code	Description	See page	QT
01	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8		01
02	0511063106	20Z AXLE BEARING DOBLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0503010365	NUT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02

CARDAN TERMINAL


0503062206



Item	Code	Description	See page	QT
01	0503062206	CARDAN TERMINAL	20	01




Item	Code	Description	See page	QT
001	0511057842	VALVE ASSY	23	01
002	0511058127	OIL 5750 CONDUCTOR ASSY	24	01
003	0511053368	HYDRAULIC CYLINDER ASSEMBLY	26	01
004	0581010324	HOSE PROTECTOR		01
005	0503010358	5/16" X 5/8" BOLT		02
006	0503010179	5/16" ZN SPRING WASHER		02
007	0503010337	5/16" NUT		02
008	0511057838	HOSE HYDRAULIC PLAY	27	01
009	0581010729	SPRING PROTECTION PLASTIC HOSE 3/4 X 3800MM		01
010	0501053835	FEMALE QUICK COUPLER		02




Item	Code	Description	See page	QT
001	0511057842	VALVE ASSY	23	01
002	0511057843	OIL CONDUCTOR ASSY	25	01
002A	0561017277	OIL CONDUCTOR FIXER PLATE		08
002B	0521010718	5/8" U BOLT		08
002C	0503010027	5/8" SPRING WASHER		16
002D	0503010013	5/8" NUT		16
002E	0521065258	HYDRAULIC MARKER 9/450 OIL CONDUCTOR		04
002F	0521066421	CONDUCTOR OIL DRUM 1072 WHEELED 6850		04
002G	0521066305	OIL CONDUCTOR		04
002H	0521066306	OIL CONDUCTOR		04
002I	0502012702	BODY SUPPORT CLAMP		16
002J	0503011268	3/8" X 2-1/2" BOLT		16
002K	0503010025	3/8" SPRING WASHER		16
002L	0503010026	3/8" NUT		16
002M	0501012140	FLAT WASHER		16
003	0511053368	HYDRAULIC CYLINDER ASSEMBLY	26	01
004	0581010324	HOSE PROTECTOR		01
005	0503010358	5/16" X 5/8" BOLT		02
006	0503010179	5/16" ZN SPRING WASHER		02
007	0503010337	5/16" NUT		02
008	0511057838	HOSE HYDRAULIC PLAY	27	01
008A	0501080760	3/8" X 500 TC-TC HOSE		08
008B	0501080599	3/8" X 650 TC-TR HOSE		02
008C	0501080328	3/8" X 29" TR-TC HOSE		02
008D	0501080105	TR-TR HOSE ASSY		04
008E	0501080150	TR-TC HOSE ASSY		01
008F	0501080055	3/8" X 1000 TR-TC HOSE		03
008G	0501081929	HOSE 1/2 X 4500 TM-TM		02
009	0581010729	SPRING PROTECTION PLASTIC HOSE 3/4 X 3800MM		01
010	0501053835	FEMALE QUICK COUPLER		02

VALVE ASSY


0511057842




Item	Code	Description	See page	QT
001	0571010596	SUPPORT VALVE 50/50		01
002	0503010365	NUT		02
003	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
004	0503010179	5/16" ZN SPRING WASHER		02
005	0503010337	5/16" NUT		02
006	0503013791	DOUBLE MOTOR		01
007	0571019851	NIPLE R 3/4 UNF X R 1/2 NPT X 60		01
008	0551012463	1/2" BSPT X 3/4" UNF X 51 NIPPLE		02
009	0503015075	M10 SPRING WASHER		04
010	0501010984	FLAT WASHER		04
011	0503011051	M10 X 0.6" NUT		04
012	0571019850	NIPLE R 1/2 NPT X R 1 BSPT X 66		01
013	0503012341	T 7/8" ADAPOR GIRAT NUT		01
014	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
015	0501053835	FEMALE QUICK COUPLER		02




Item	Code	Description	See page	QT
01	0561017277	OIL CONDUCTOR FIXER PLATE		06
02	0521010718	5/8" U BOLT		06
03	0503010027	5/8" SPRING WASHER		12
04	0503010013	5/8" NUT		12
05	0502012702	BODY SUPPORT CLAMP		12
06	0521066483	OIL CONDUCTOR		04
07	0521066484	OIL CONDUCTOR		04
08	0521066306	OIL CONDUCTOR		04
09	0521066305	OIL CONDUCTOR		04
10	0503011268	3/8" X 2-1/2" BOLT		12
11	0503010025	3/8" SPRING WASHER		12
12	0503010026	3/8" NUT		12
13	0501012140	FLAT WASHER		12



Item	Code	Description	See page	QT
001	0561017277	OIL CONDUCTOR FIXER PLATE		08
002	0521010718	5/8" U BOLT		08
003	0503010027	5/8" SPRING WASHER		16
004	0503010013	5/8" NUT		16
005	0502012702	BODY SUPPORT CLAMP		16
006	0521066305	OIL CONDUCTOR		04
007	0521066421	CONDUCTOR OIL DRUM 1072 WHEELED 6850		04
008	0521065258	HYDRAULIC MARKER 9/450 OIL CONDUCTOR		04
009	0521066306	OIL CONDUCTOR		04
010	0503011268	3/8" X 2-1/2" BOLT		12
011	0503010025	3/8" SPRING WASHER		12
012	0503010026	3/8" NUT		12
013	0501012140	FLAT WASHER		12




Item	Code	Description	See page	QT
01	0511066351	FLANGE CYLINDER HYDRAULIC FIXER		12
02	0503010834	1/2 X 1 BOLT		24
03	0503010019	1/2" SPRING WASHER		24
04	0511058411	HYDRAULIC CYLINDER	28	06
05	0521010546	1.2" X 5.7" COUPLING SHAFT		06
06	0501017779	32 X 60 X 4.75 FLAT WASHER		12
07	0503010523	1/4" X 2" COTTERPIN		06




Item	Code	Description	See page	QT
001	0501080760	3/8" X 500 TC-TC HOSE		08
002	0501080599	3/8 X 650 TC-TR HOSE		02
003	0501080328	3/8" X 29" TR-TC HOSE		02
004	0501080105	TR-TR HOSE ASSY		04
005	0501080055	3/8" X 1000 TR-TC HOSE		04
006	0501080881	HOSE		02

HYDRAULIC CYLINDER


0511058411




Item	Code	Description	See page	QT
01	0511066774	2.5" X 28" CYLINDER CASE		01
02	0541017674	TURNBUCLE BODY		01
03	0503030385	CYLINDER PLUG N-002		02
04	0511064408	FORK COP		01
05	0503011094	3/8" X 2" BOLT		01
06	0503010025	3/8" SPRING WASHER		01
07	0503010026	3/8" NUT		01
08	0581010302	RING OF SUPPORT		01
09	0502012822	101.60 END CAP		01
10	0503011061	8-342 BACK-UP RING		02
11	0503010338	2-342 N 3006-9B O'RING		02
12	0503017936	RING		01
13	0503017938	RING GUIDE		01
14	0503017937	GASKET		01
15	0503010761	D-1750 SCRAPER RING		01
16	0581010837	PISTON		01
17	0503010817	1.1/4" SELF LOCKING NUT		01
18	0503015633	SELEMASTER SEALING		01
19	0503018029	2-217 O'RING		01



Item	Code	Description	See page	QT
01	0561019899	RIGHT SUPPORT FIXER RECAMBIO		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0501012140	FLAT WASHER		02



Item	Code	Description	See page	QT
01	0561019898	LEFT SUPPORT FIXER RECAMBIO		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0501012140	FLAT WASHER		02




Item	Code	Description	See page	QT
001	0511050639	RIGHT GEAR BOX ASSY	31	01
001A	0501058212	SEMI MOUNTED RIGHT CHANGE		01
002	0503031805	11Z 1/2" GEAR		04
003	0503010302	501019 SEAL RING		04
004	0501048790	AXLE WITH LINK ASSY		02
005	0503010002	1800 GREASE FITTING		02
006	0551018209	DRIVING AXLE		01
007	0521018259	DRIVEN AXLE		01
008	0551018210	DRIVEN AXLE		01
009	0551018211	INTERM SHAFT		01
010	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE		01
011	0503030303	SUPPORT WASHER		05
012	0501056443	BEARING ASSY GEAR BOX		02
013	0501056271	BEARING CLOSED		05
014	0503010256	3/8" X 3/4" BOLT		01
015	0503030275	AGRICULTURAL BEARING		01
016	0521018630	1.4" X SQUARE 0.8" WASHER		03
017	0511061822	25Z P0.5" GEAR SQUARE HOL		01
018	0502040868	GEAR CONE REPLACEMENT		04
019	0503012389	1/2 BALL		04
020	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
021	0503010060	1/2" NUT		04
022	0503010395	1/2" X 1-1/4" BOLT		04
023	0521062072	33Z GEAR		01
024	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
025	0511067501	26Z GEAR		01
026	0503010292	0.2" X 1.6" SPRING PIN		07
027	0503012204	40-1 CHAIN X 82 LINK + RED		02
028	0503012713	40-1 CHAIN X 45 LINK + MEN		01
029	0501054655	CHAIN TENSIONER ASSY		02
030	0501010984	FLAT WASHER		01



Item	Code	Description	See page	QT
031	0503010025	3/8" SPRING WASHER		01

LEFT GEAR BOX ASSY

0511050640




Item	Code	Description	See page	QT
001	0511050640	LEFT GEAR BOX ASSY	32	01
001A	0501058213	LH GEAR BOX		01
002	0503031805	11Z 1/2" GEAR		04
003	0503010302	501019 SEAL RING		04
004	0501048790	AXLE WITH LINK ASSY		02
005	0503010002	1800 GREASE FITTING		02
006	0551018209	DRIVING AXLE		01
007	0521018259	DRIVEN AXLE		01
008	0551018210	DRIVEN AXLE		01
009	0551018211	INTERM SHAFT		01
010	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE		01
011	0503030303	SUPPORT WASHER		05
012	0501056443	BEARING ASSY GEAR BOX		02
013	0501056271	BEARING CLOSED		05
014	0503010256	3/8" X 3/4" BOLT		01
015	0503030275	AGRICULTURAL BEARING		01
016	0521018630	1.4" X SQUARE 0.8" WASHER		03
017	0511061822	25Z P0.5" GEAR SQUARE HOL		01
018	0502040868	GEAR CONE REPLACEMENT		04
019	0503012389	1/2 BALL		04
020	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
021	0503010060	1/2" NUT		04
022	0503010395	1/2" X 1-1/4" BOLT		04
023	0521062072	33Z GEAR		01
024	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
025	0511067501	26Z GEAR		01
026	0503010292	0.2" X 1.6" SPRING PIN		07
027	0503012204	40-1 CHAIN X 82 LINK + RED		02
028	0503012713	40-1 CHAIN X 45 LINK + MEN		01
029	0501054655	CHAIN TENSIONER ASSY		02
030	0501010984	FLAT WASHER		01



LEFT GEAR BOX ASSY

0511050640

Item	Code	Description	See page	QT
031	0503010025	3/8" SPRING WASHER		01




Item	Code	Description	See page	5750/6850
001	0561018212	ARTICULAT SLEEVE	02	
002	0503010547	1/2" X 4" BOLT	02	
003	0511017302	FLAT WASHER	02	
004	0503010019	1/2" SPRING WASHER	02	
005	0503010060	1/2" NUT	02	
006	0561017281	ARTICULACION ARM	02	
007	0511053366	CHAIN TENSIONER EXCHANGE	02	
007A	0531019479	AXLE CHAIN GEAR	02	
007B	0503031805	11Z 1/2" GEAR	02	
007C	0503010302	501019 SEAL RING	02	
007D	0511017302	FLAT WASHER	04	
008	0511050385	BEARING DOUBLE GEAR	02	
008A	0521061843	20Z DOBLE GEAR	02	
008B	0551019175	DOUBLE GEAR AXLE	02	
008C	0501010163	5/8" X 4-1/2" BOLT	02	
008D	0503012412	5/8 UNC SELF LOCKING NUT	06	
009	0501058265	STRETCHER LOWER CURRENT 21Z SEED	02	
009A	0511062169	21Z P 1/2" GEAR	01	
009B	0503011410	ROLLER BEARING	01	
009C	0503011105	SEAL RING	01	
009D	0531017086	50 AXLETIGHTENER	01	
009E	0503010406	501025 CLAMPING RING (FOR AXLE)	01	
009F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN	01	
009G	0501012140	FLAT WASHER	01	
009H	0503010027	5/8" SPRING WASHER	01	
009I	0503010013	5/8" NUT	01	
010	0511056387	INTERMEDIATE BEARING SEED WITH GEAR 21Z	02	
010A	0511062169	21Z P 1/2" GEAR	01	
010B	0503011410	ROLLER BEARING	01	
010C	0503011105	SEAL RING	01	
010D	0531017086	50 AXLETIGHTENER	01	

RIGHT TRANSMISSION ASSY

0511057815

Item	Code	Description	See page	5750/6850
010E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
010F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
010G	0503012412	5/8 UNC SELF LOCKING NUT		01
011	0511057852	SILO SUPPORT CHAIN DEVIATION		02
011A	0571019832	SLEEVE CHAIN DEVIATION		02
011B	0502012367	17Z X P 1/2" GEAR INTERM		02
011C	0503012882	BEARING		02
011D	0503011945	503050 CLAMPING RING (FOR AXLE)		02
011E	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
011F	0503010019	1/2" SPRING WASHER		02
011G	0503010060	1/2" NUT		02
012	0501053126	FERTILIZER CHAIN TENSIONER ASSY		02
012A	0501011541	5/8" X 3" BOLT		01
012B	0511062169	21Z P 1/2" GEAR		01
012C	0503011410	ROLLER BEARING		01
012D	0503011105	SEAL RING		01
012E	0521018415	TIGHTENER AXLE		01
012F	0503010406	501025 CLAMPING RING (FOR AXLE)		01
012G	0503012412	5/8 UNC SELF LOCKING NUT		01
013	0571019829	LEVER FIXER		02
014	0503010237	3/8" X 1" BOLT		02
015	0503010025	3/8" SPRING WASHER		02
016	0503010026	3/8" NUT		02
017	0571019830	LEVER FIXER		02
018	0503011312	ROTATIVE CABLE		02
019	0503030093	TRACTION SPRING		02
020	0561017273	FIXER SPRING		02
021	0503010237	3/8" X 1" BOLT		02
022	0503010025	3/8" SPRING WASHER		02
023	0503010026	3/8" NUT		02
024	0561017282	LOWER LEVER		02
025	0561016797	SLEEVE UNION LEVER ARM/DESARM		02
026	0503011082	C1/2" X 1.3/4" SCREW		02
027	0511017302	FLAT WASHER		04
028	0503010019	1/2" SPRING WASHER		02
029	0503010060	1/2" NUT		02
030	0521010773	0.37" X 1.18" COUPLING SHAFT		04
031	0501010984	FLAT WASHER		02
032	0503010140	1/8" X 3/4" COTTERPIN		04
033	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		02
034	0503012717	40-1 CHAIN X 101 LINK + MENDING		02
035	0503015124	40-1 X 5" CHAIN LINK + MENDING		02
036	0503011721	40-1 CHAIN X 122 LINK + REDUCTION		02


DISCO MARCADOR DE LINHA



Item	Code	Description	See page	QT
001	0511065449	ROW MARKER ARM SUPPORT		02
002	0501010098	3/4" UNC BOLT		08
003	0503011255	3/4" LOCK NUT		08
004	0511061811	ROW MARKER ARM		02
005	0503011067	5/8" X 2-1/2" BOLT		04
006	0521010479	SLEEVE ARTICULATION		04
007	0501012140	FLAT WASHER		04
008	0503012795	5/8" HEX SELF ADJUSTING NUT		04
009	0511058449	HYDRAULIC CYLINDER	10	02
010	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
011	0503010571	1/4" X 1.1/2 COTTERPIN		02
012	0511015779	1" X 4.2" AXLE		02
013	0503010523	1/4" X 2" COTTERPIN		02
014	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
015	0501068994	0.3" X 3.1" LOCK PIN		02
016	0503030168	HAIR PIN		02
017	0501066949	1235 TURNBUCKLE		02
018	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
019	0501054649	SEQUENTIAL VALVE ASSY		01
020	0503010256	3/8" X 3/4" BOLT		02
021	0501010984	FLAT WASHER		02
022	0503010025	3/8" SPRING WASHER		02
023	0541012165	3/4" NIPPLE		04
024	0511018387	3/4" X 0.3 ADJUSTMENT VALVE NUT		04
025	0511058261	HOSE KIT HYDRAULIC MARKER		01
025A	0501080635	3/8" X 19" TR-TR HOSE		02
025B	0501080413	3/8" X 27" TR-TC HOSE		02
025C	0501080150	TR-TC HOSE ASSY		04
025D	0501080105	TR-TR HOSE ASSY		04
025E	0501080301	HOSE 3/8 X 1300 TC-TC		04
025F	0501080875	3/8" X 153" TC-TM HOSE ASSY		02

Item	Code	Description	See page	QT
026	0581010090	SPRING PROTECTION PLASTIC HOSE		04
027	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT		02
028	0502012702	BODY SUPPORT CLAMP		02
029	0503010677	7/16" X 2-3/4" BOLT		02
030	0511017302	FLAT WASHER		04
031	0503010180	7/16" SPRING WASHER		02
032	0503010244	7/16" NUT		02
033	0503011070	BEATER		02
034	0503010019	1/2" SPRING WASHER		02
035	0503011082	C1/2" X 1.3/4" SCREW		02

DISCO MARCADOR DE LINHA




Item	Code	Description	See page	QT
001	0511065449	ROW MARKER ARM SUPPORT		02
002	0501010098	3/4" UNC BOLT		08
003	0503011255	3/4" LOCK NUT		08
004	0511061811	ROW MARKER ARM		02
005	0503011067	5/8" X 2-1/2" BOLT		04
006	0521010479	SLEEVE ARTICULATION		04
007	0501012140	FLAT WASHER		04
008	0503012795	5/8" HEX SELF ADJUSTING NUT		04
009	0511058449	HYDRAULIC CYLINDER	10	02
010	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
011	0503010571	1/4" X 1.1/2 COTTERPIN		02
012	0511015779	1" X 4.2" AXLE		02
013	0503010523	1/4" X 2" COTTERPIN		02
014	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
015	0501068994	0.3" X 3.1" LOCK PIN		02
016	0503030168	HAIR PIN		02
017	0501066949	1235 TURNBUCKLE		02
018	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
019	0501054649	SEQUENTIAL VALVE ASSY		01
020	0503010256	3/8" X 3/4" BOLT		02
021	0501010984	FLAT WASHER		02
022	0503010025	3/8" SPRING WASHER		02
023	0541012165	3/4" NIPPLE		04
024	0511018387	3/4" X 0.3 ADJUSTMENT VALVE NUT		04
025	0511057839	HOSE KIT HYDRAULIC MARKER		01
025A	0501080635	3/8" X 19" TR-TR HOSE		02
025B	0501080413	3/8" X 27" TR-TC HOSE		02
025C	0501080150	TR-TC HOSE ASSY		04
025D	0501080105	TR-TR HOSE ASSY		04
025E	0501080675	HOSE 3/8 X 1000 TC-TC 180G		04
025F	0501080875	3/8" X 153" TC-TM HOSE ASSY		02


HYDRAULIC MARKER

0511057801


Item	Code	Description	See page	QT
026	0581010090	SPRING PROTECTION PLASTIC HOSE		04
027	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT		02
028	0502012702	BODY SUPPORT CLAMP		02
029	0503010677	7/16" X 2-3/4" BOLT		02
030	0503010180	7/16" SPRING WASHER		02
031	0503010244	7/16" NUT		02
032	0503011070	BEATER		02
033	0503010019	1/2" SPRING WASHER		02
034	0503011082	C1/2" X 1.3/4" SCREW		02
035	0521013164	EXTENSOR		02
036	0501011310	FIXER LOCK		08
037	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		08
038	0503010019	1/2" SPRING WASHER		08
039	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0511053904	DISC LINE MARKER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0511058131	RIGHT FERTILIZER BOX SUPPORT 5750	40	01
02	0511058132	CENTRAL FERTILIZER BOX SUPPORT 5750	43	01
03	0511058130	LEFT FERTILIZER BOX SUPPORT 5750	39	01
04	0503034396	FERTILIZER SIDE COVER		13
05	0503010362	1/8" X 1.1/4" COTTERPIN		13
06	0503010849	3/8" X 1-1/2" BOLT		16
07	0501010984	FLAT WASHER		32
08	0503010025	3/8" SPRING WASHER		16
09	0503010026	3/8" NUT		16
10	0503062391	SILO FERTILIZER 5 MOUTHS	44	01
11	0503062362	BEAN FERTILIZER ASSY	45	02
12	0571019051	FIXER BOX WASHER		20
13	0503013751	3/8 UNC X 1.1/4 BOLT		20
14	0503012535	3/8" SPRING WASHER		20
15	0503012531	3/8" INOX NUT		20
16	0503011957	PMC 596-S NYLON LUG		02
17	0503010371	5/16" X 1" BOLT		04
18	0503010179	5/16" ZN SPRING WASHER		04
19	0503010337	5/16" NUT		04
20	0503062476	CARDAN TERMINAL	46	02
21	0503011855	0.2" X 1.8" SPRING PIN		04
22	0503030331	1.2" X 1.2" X 12.2" HOSE		02
23	0503010243	CLAMP		04




Item	Code	Description	See page	QT
001	0511057813	RIGHT FERTILIZER BOX SUPPORT 7655	47	01
002	0511057812	LEFT FERTILIZER BOX SUPPORT 7655	48	01
003	0511057814	CENTER FERTILIZER SILO SUPPORT	49	01
004	0571010590	FERTILIZER SIDE COVER		15
005	0503010362	1/8" X 1.1/4" COTTERPIN		15
006	0503010849	3/8" X 1-1/2" BOLT		12
007	0501010984	FLAT WASHER		24
008	0503010025	3/8" SPRING WASHER		12
009	0503010026	3/8" NUT		12
010	0503062391	SILO FERTILIZER 5 MOUTHS	44	03
011	0571019051	FIXER BOX WASHER		24
012	0503013751	3/8 UNC X 1.1/4 BOLT		24
013	0503012535	3/8" SPRING WASHER		24
014	0503012531	3/8" INOX NUT		24
015	0503011957	PMC 596-S NYLON LUG		02
016	0503010371	5/16" X 1" BOLT		04
017	0503010179	5/16" ZN SPRING WASHER		04
018	0503010337	5/16" NUT		04
019	0503011855	0.2" X 1.8" SPRING PIN		04
020	0503030331	1.2" X 1.2" X 12.2" HOSE		02
021	0503010243	CLAMP		04
022	0503062208	CARDAN TERMINAL	50	02




Item	Code	Description	See page	QT
01	0521066471	FERTILIZER SUPPORT LEFT BEAM		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	42	01
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	41	03
04	0501010942	3/8" X 1-1/4" BOLT		18
05	0503010025	3/8" SPRING WASHER		18
06	0503010026	3/8" NUT		18
07	0501056271	BEARING CLOSED		01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	5/16" ZN SPRING WASHER		02
11	0503010337	5/16" NUT		02
12	0581010469	SQUARE SHAFT		01
13	0571019828	LOCK AXLE		01
14	0503010365	NUT		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521014167	CONE LOCK		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	Q3/4" FASTENER AXLE ASSY		01
20	0503030275	AGRICULTURAL BEARING		04
21	1902010685	18Z CONICAL GEAR		04




Item	Code	Description	See page	QT
01	0521066472	FERTILIZER BEAN RIGHT SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	42	01
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	41	03
04	0501010942	3/8" X 1-1/4" BOLT		16
05	0503010025	3/8" SPRING WASHER		16
06	0503010026	3/8" NUT		16
07	0501056271	BEARING CLOSED		01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	5/16" ZN SPRING WASHER		02
11	0503010337	5/16" NUT		02
12	0581010469	SQUARE SHAFT		01
13	0571019828	LOCK AXLE		01
14	0503010365	NUT		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521014167	CONE LOCK		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	Q3/4" FASTENER AXLE ASSY		01
20	0503030275	AGRICULTURAL BEARING		04
21	1902010685	18Z CONICAL GEAR		04




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0521066296	SEED SILO CENTRAL SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	42	03
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	41	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0571019828	LOCK AXLE		02
08	0503010365	NUT		04
09	0503013816	5/16" LOCKNUT		04
10	0581010471	SQUARE SHAFT		01
11	0581010470	SQUARE SHAFT		01
12	1902010685	18Z CONICAL GEAR		05
13	0503030275	AGRICULTURAL BEARING		05




Item	Code	Description	See page	QT
001	0503034127	FERTILIZER BEAM COVER		01
002	0503034129	LOWER COVER		01
003	0503034128	UPPER COVER		01
004	0503034130	PLATE		01
005	0503032053	BOLT C.A.S.I		04
006	0503034220	FLAT WASHER		04
007	0503034087	TUBE COVER PIVOT		04
008	0503034088	WASHER		08
009	0503010131	3/16" X 1-1/2" COTTERPIN		08




Item	Code	Description	See page	QT
001	0503034085	BEAN FERTILIZER ASSY		01
002	0503034086	BOX COVER		01
003	0503034087	TUBE COVER PIVOT		02
004	0503034088	WASHER		04
005	0503010131	3/16" X 1-1/2" COTTERPIN		04
006	0503034130	PLATE		01
007	0503032053	BOLT C.A.S.I		04
008	0503034220	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0503062476	CARDAN TERMINAL	46	01




Item	Code	Description	See page	QT
01	0521066295	FERTILIZER BEAM RIGHT SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	42	02
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	41	03
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0501056271	BEARING CLOSED		01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	5/16" ZN SPRING WASHER		02
11	0503010337	5/16" NUT		02
12	0571019827	SQUARE SHAFT		01
13	0571019828	LOCK AXLE		01
14	0503010365	NUT		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521014167	CONE LOCK		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	Q3/4" FASTENER AXLE ASSY		01
20	0503030275	AGRICULTURAL BEARING		05
21	1902010685	18Z CONICAL GEAR		05




Item	Code	Description	See page	QT
01	0521066297	FERTILIZER SUPPORT LEFT BEAM		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	42	03
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	41	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0501056271	BEARING CLOSED		01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	5/16" ZN SPRING WASHER		02
11	0503010337	5/16" NUT		02
12	0571019827	SQUARE SHAFT		01
13	0571019828	LOCK AXLE		01
14	0503010365	NUT		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521014167	CONE LOCK		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	Q3/4" FASTENER AXLE ASSY		01
20	0503030275	AGRICULTURAL BEARING		05
21	1902010685	18Z CONICAL GEAR		05



Item	Code	Description	See page	QT
001	0521066296	SEED SILO CENTRAL SUPPORT		01
002	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	41	02
003	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	42	03
004	0501010942	3/8" X 1-1/4" BOLT		20
005	0503011443	3/8" SPRING WASHER		20
006	0503010026	3/8" NUT		20
007	0571019828	LOCK AXLE		02
008	0503010365	NUT		04
009	0503013816	5/16" LOCKNUT		04
010	0571019826	SQUARE SHAFT		01
011	0571019825	SQUARE SHAFT		01
012	1902010685	18Z CONICAL GEAR		01
013	0503030275	AGRICULTURAL BEARING		01




Item	Code	Description	See page	QT
01	0503062208	CARDAN TERMINAL	50	01




Item	Code	Description	See page	QT
01	0521061861	PLATFORM FIXER	02	
02	0511069661	PLATFORM SUPPORT PIVOT	04	
03	0503010849	3/8" X 1-1/2" BOLT	12	
04	0501010984	FLAT WASHER	24	
05	0503010025	3/8" SPRING WASHER	12	
06	0503010026	3/8" NUT	12	
07	0521066487	SIDE PLATFORM	01	
08	0521066486	RIGHT PLATAFORM	01	
09	0521063870	PLATFORM CENTER	01	
10	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	06	
11	0503011336	1/2" HEX SELF ADJUSTING NUT	06	
12	0503011333	COVER FIXER	03	
13	0503010274	5/32"X 2" COTTERPIN	03	
14	0551019115	LOCKING PLATFORM FIXATION	03	
15	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	
16	0501010096	3/8" X 2" BOLT	02	
17	0571019831	X 0.2" SLEEVE	02	
18	0501010984	FLAT WASHER	03	
19	0503013357	3/8" SELF-ADJUSTING NUT	03	
20	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
21	0502012739	PLATFORM LEFT FIXER SUPPORT	02	
22	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	02	
23	0503010019	1/2" SPRING WASHER	02	
24	0503010060	1/2" NUT	02	
25	0571017990	PLATFORM ENHANCEMENT PROTECTION	02	
26	0501010942	3/8" X 1-1/4" BOLT	04	
27	0501010984	FLAT WASHER	04	
28	0503010025	3/8" SPRING WASHER	04	
29	0503010026	3/8" NUT	04	

PLATFORM SET


0511057799




Item	Code	Description	See page	QT
001	0521061861	PLATFORM FIXER	02	
002	0511069661	PLATFORM SUPPORT PIVOT	04	
003	0503010849	3/8" X 1-1/2" BOLT	12	
004	0501010984	FLAT WASHER	24	
005	0503010025	3/8" SPRING WASHER	12	
006	0503010026	3/8" NUT	12	
007	0521063868	SIDE PLATFORM	01	
008	0521063869	RIGHT PLATFORM	01	
009	0521063870	PLATFORM CENTER	01	
010	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	06	
011	0503011336	1/2" HEX SELF ADJUSTING NUT	06	
012	0503011333	COVER FIXER	03	
013	0503010274	5/32"X 2" COTTERPIN	03	
014	0551019115	LOCKING PLATFORM FIXATION	03	
015	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	
016	0501010096	3/8" X 2" BOLT	02	
017	0571019831	X 0.2" SLEEVE	02	
018	0501010984	FLAT WASHER	03	
019	0503013357	3/8" SELF-ADJUSTING NUT	03	
020	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
021	0502012739	PLATFORM LEFT FIXER SUPPORT	02	
022	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	06	
023	0503010019	1/2" SPRING WASHER	06	
024	0503010060	1/2" NUT	06	
025	0571017990	PLATFORM ENHANCEMENT PROTECTION	02	
026	0501010942	3/8" X 1-1/4" BOLT	04	
027	0501010984	FLAT WASHER	04	
028	0503010025	3/8" SPRING WASHER	04	
029	0503010026	3/8" NUT	04	




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		04
02	0503010237	3/8" X 1" BOLT		08
03	0503010025	3/8" SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0511069636	LADDER		02
06	0503011179	3/8" X 2-1/4" BOLT		04
07	0501010984	FLAT WASHER		04
08	0503013357	3/8" SELF-ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521066485	FRONT SIDE CORRÍMAO		02
02	0521063875	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2" NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
07	0503011082	C1/2" X 1.3/4" SCREW		04
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8" SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
001	0521063871	SIDE HANDRAIL	02	
002	0521063875	CENTRAL HANDRAIL	01	
003	0503010395	1/2" X 1-1/4" BOLT	04	
004	0503011082	C1/2" X 1.3/4" SCREW	04	
005	0503010019	1/2" SPRING WASHER	08	
006	0503010060	1/2" NUT	08	
007	0503034094	22 TWISTED CHAIN	04	
008	0571017991	CHAIN FIXER HANDRAIL	08	
009	0551019884	45 X 50 X 3/8 FASTENER	08	
010	0503013357	3/8" SELF-ADJUSTING NUT	16	




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
05	0503010179	5/16" ZN SPRING WASHER		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0511058580	ASSEMBLY CSU C3 2 BOXES 5/4 - 1 BOX 5/5 5750	60	01
02	0521063064	SUPPORT TOWER SILO SEED CSU		06
03	0501010942	3/8" X 1-1/4" BOLT		12
04	0501010984	FLAT WASHER		12
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12
07	0502010175	HITCH CLAMP		06
08	0501011543	5/8" X 4" BOLT		12
09	0501012140	FLAT WASHER		12
10	0503012412	5/8 UNC SELF LOCKING NUT		12




Item	Code	Description	See page	QT
001	0511057822	ASSY CSU	61	02
002	0511057823	ASSY CSU	62	01
003	0521063064	SUPPORT TOWER SILO SEED CSU		06
004	0501010942	3/8" X 1-1/4" BOLT		12
005	0501010984	FLAT WASHER		12
006	0503010025	3/8" SPRING WASHER		12
007	0503010026	3/8" NUT		12
008	0502010175	HITCH CLAMP		06
009	0501011543	5/8" X 4" BOLT		12
010	0503012412	5/8 UNC SELF LOCKING NUT		12
011	0501012140	FLAT WASHER		12




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		06
02	0501010984	FLAT WASHER		06
03	0503010025	3/8" SPRING WASHER		66
04	0503010026	3/8" NUT		66
05	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	63	13
06	0501010942	3/8" X 1-1/4" BOLT		52
07	0571015773	CAP SUPPORT SEED BOX ONLY		02
08	0501011643	3/8 X 1" BOLT		08
09	0521064748	07 MOUTHS CSU SUPPORT		03
10	0503061987	SILO FERTILIZER 05 MOUTHS FRONT MOUNTED		03




Item	Code	Description	See page	QT
001	0521064748	07 MOUTHS CSU SUPPORT		01
002	0503061987	SILO FERTILIZER 05 MOUTHS FRONT MOUNTED		01
003	0521063401	SEED BOX ONLY FIXING LOCK		02
004	0501010984	FLAT WASHER		02
005	0503010025	3/8" SPRING WASHER		02
006	0503010026	3/8" NUT		02
007	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	63	05
008	0501010942	3/8" X 1-1/4" BOLT		20
009	0503010025	3/8" SPRING WASHER		20
010	0503010026	3/8" NUT		20




Item	Code	Description	See page	QT
001	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		01
002	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		01
003	0521063401	SEED BOX ONLY FIXING LOCK		02
004	0501010984	FLAT WASHER		02
005	0503010025	3/8" SPRING WASHER		02
006	0503010026	3/8" NUT		02
007	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	63	05
008	0501010942	3/8" X 1-1/4" BOLT		20
009	0503010025	3/8" SPRING WASHER		20
010	0503010026	3/8" NUT		20
011	0571015773	CAP SUPPORT SEED BOX ONLY		02
012	0501011643	3/8 X 1"BOLT		08
013	0503010025	3/8" SPRING WASHER		08
014	0503010026	3/8" NUT		08



Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
09	0503010179	5/16" ZN SPRING WASHER		02
10	0503010337	5/16" NUT		02
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT		01




Item	Code	Description	See page	13-5750/15-6850
01	0511057243	LEFT SHORT SEED ROW FRONT	65	06 07
02	0511057244	RIGTH SHORT SEED ROW FRONT	66	06 07
03	0511057246	RIGHT LONG SEED ROW FRONT	67	06 07
04	0511057247	LEFT LONG SEED ROW FRONT	68	06 07
05	0521041901	REAR RIGHT SEED ROW		06 07
06	0521041902	REAR LEFT SEED ROW		06 07
07	0511053023	LONG FERTILIZER LINE	70	06 07
08	0511053024	FERTILIZER SHORT LINE	71	06 07
09	0511051818	DISC CUT 18 SEMI MOUNTED	72	06 07
10	0511051819	DC 20 SEMI MOUNTED	73	06 07
11	0501052976	15 X 15 RIGHT FERT UNAL DOUB-DISC ASSY	74	06 07
12	0501052977	DDD LEFT FERTILIZER 15 X 15 ASSY	75	06 07
13	0501110231	SCARIFIER HEAD WITH SPIKE 0061		06 07



Item	Code	Description	See page	QT
01	0521064651	LEFT SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8 UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER	04	
08	0503010179	5/16" ZN SPRING WASHER	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION BOX SEED LINE	01	
12	0561014904	TRANSMISSION AXLE FRAME LINE	01	
13	0511050609	BEARING WITH 17Z GEAR ASSY	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEDD ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521065847	SHORT TIRE SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" COTTERPIN	01	
27	0503030168	HAIR PIN	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" COTTERPIN	01	
31	0503034580	TRACTION SPRING	02	




Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY		01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04



Item	Code	Description	See page	QT
01	0521064653	RIGTH SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8 UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER	04	
08	0503010179	5/16" ZN SPRING WASHER	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION BOX SEED LINE	01	
12	0561014904	TRANSMISSION AXLE FRAME LINE	01	
13	0511050609	BEARING WITH 17Z GEAR ASSY	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEDD ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521065847	SHORT TIRE SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" COTTERPIN	01	
27	0503030168	HAIR PIN	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" COTTERPIN	01	
31	0503034580	TRACTION SPRING	02	




Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY		01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04



Item	Code	Description	See page	QT
01	0521064652	RH SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8 UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER	04	
08	0503010179	5/16" ZN SPRING WASHER	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION BOX SEED LINE	01	
12	0561014904	TRANSMISSION AXLE FRAME LINE	01	
13	0501052769	BEARING WITH 17Z GEAR	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEDD ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521065847	SHORT TIRE SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" COTTERPIN	01	
27	0503030168	HAIR PIN	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" COTTERPIN	01	
31	0503034580	TRACTION SPRING	02	




Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY		01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04



Item	Code	Description	See page	QT
01	0521064650	LEFT SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8 UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER	04	
08	0503010179	5/16" ZN SPRING WASHER	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION BOX SEED LINE	01	
12	0561014904	TRANSMISSION AXLE FRAME LINE	01	
13	0511050609	BEARING WITH 17Z GEAR ASSY	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEDD ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521065847	SHORT TIRE SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" COTTERPIN	01	
27	0503030168	HAIR PIN	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" COTTERPIN	01	
31	0503034580	TRACTION SPRING	02	



Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY		01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	Dir/Esq.
00	0521041901	REAR RIGHT SEED ROW		01
00A	0521041902	REAR LEFT SEED ROW		01
01	0521040111	DEP CONT WHEELS PRESS WHEELS ASSY		01 01
02	0501052538	DEPTH BAND WITH ARMS	81	02 02
03	0511054333	COMPACT WHEEL RIGHT WITH BEARING	83	01 01
04	0511054334	COMPACT WHEEL LEFT WITH BEARING	82	01 01
05	0503033124	SOCKET SEED		01 01
06	0521042714	PNEUMATIC SEED DISTRIBUTOR		01 01
07	0503011404	BOLT		04 04
08	0503010025	3/8" SPRING WASHER		09 09
09	0503010026	3/8" NUT		08 08
10	0501056143	SEED SYSTEM ASSY		01 01
10A	0503031508	COVER GREEN BEAM SEED YELLOW		01 01
10B	0502011760	SEED SILO SUPPORT		01 01
10C	0531010631	SEED BEAM CLAMP		04 04
10D	0503010371	5/16" X 1" BOLT		04 04
10E	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04 04
10F	0503010179	5/16" ZN SPRING WASHER		04 04
10G	0503010337	5/16" NUT		04 04
11	0503013162	DISC 2450 CORN		01 01
12	0511050809	SEMIFINISHED FAST CLOSING SET		01 01
12A	0541016855	SPEED ??LOCK LEVER ASSY		01 01
12B	0561019318	PRISONER CLOSING FAST		01 01
12C	0551018050	FAST BOLT GUIDE AXLE		02 02
12D	0503010257	1/8" X 1" COTTERPIN		02 02
12E	0561019270	FAST BOLT ADJUSTMENT		01 01
13	0521064369	HOSE HOLDER		01 01
14	0521060631	FIXING BASE BOX		01 01
15	0501010942	3/8" X 1-1/4" BOLT		04 04
16	0531018349	SEED FLOW SWITCH PNEUMATIC SYSTEM		01 01
17	0501011643	3/8 X 1"BOLT		01 01

**REAR SEED ROW**


0909094635

Item	Code	Description	See page	Dir/Esq.
18	0501010984	FLAT WASHER		01 01
19	0503010209	3/8" UNC BUTTERFLY NUT		01 01
20	0561017939	AIR CONDUCTOR		01 01



Item	Code	Description	See page	QT
01	0521063759	ROW FERTILIZER SUPPORT	01	
02	0511053223	FERTILIZER ROW SUPPORT WITH SCREW	01	
03	0503017855	3/4" BOLT	02	
04	0503010152	3/4" SELF LOCKING NUT	02	
05	0521063504	FERTILIZER ROW LOWER SUPPORT	01	
06	0503010233	5/8" X 2-1/2" BOLT	02	
07	0511015098	FLAT WASHER	06	
08	0561017928	FERTILIZER ROW ARTICULAT SLEEVE	02	
09	0503012412	5/8 UNC SELF LOCKING NUT	02	
10	0511063862	FERTILIZER ROW UPPER SUPPORT	01	
11	0501010163	5/8" X 4-1/2" BOLT	01	
12	0531015184	FLAT WASHER	01	
13	0531016031	1/2" SPRING WASHER	01	
14	0503012412	5/8 UNC SELF LOCKING NUT	01	
15	0531016207	0.6" X 1" X 2.8" SLEEVE	01	
16	0521061855	FERTILIZER ROW REAR SUPPORT	01	
17	0501010452	5/8" X 5" BOLT	02	
18	0531016031	1/2" SPRING WASHER	04	
19	0531016207	0.6" X 1" X 2.8" SLEEVE	02	
20	0503012412	5/8 UNC SELF LOCKING NUT	02	
21	0521062073	SPRING GUIDE	01	
22	0521016057	COUP SHA OF THE CARRY-W SPRING GUI	01	
23	0503030168	HAIR PIN	01	
24	1902020393	SPRING UPPER SUPPORT	01	
25	0503031450	2.7" X 9.2" X 0.03" SPRING	01	
26	1902020393	SPRING UPPER SUPPORT	01	
27	0521011158	SPRING LOCKNUT	01	
28	0521018575	REGULATOR SPINDLE 100	01	
29	0502012724	FERTILIZER ROW FIXER	01	
30	0503017960	5/8" X 3-12" BOLT	04	
31	0503010811	5/8" UNF SELF ADJUSTING NUT	04	

Item	Code	Description	See page	QT
32	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR		01
33	0502012352	DOUBLE-DISC SPACING PLATE		01
34	0541013035	5.55" X 4.0" X 0.38" PLATE		01
35	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
36	0503010019	1/2" SPRING WASHER		02
37	0503010060	1/2" NUT		02
38	0503010752	1/2" X 3.1/2" BOLT		02
39	0503010019	1/2" SPRING WASHER		02
40	0503010060	1/2" NUT		02
41	0503030520	SEED SOCKET		01
42	0503031145	2" X 2" X 20" HOSE		01
43	0503031076	2" HOSE CLAMP		02
44	0503010003	1845 GREASE FITTING		02
45	0503010004	1890 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511053223	FERTILIZER ROW SUPPORT WITH SCREW		01
02	0502012728	ROW FERTILIZER SUPPORT		01
03	0503017856	BOLT 3/4		02
04	0503010152	3/4" SELF LOCKING NUT		02
05	0521063504	FERTILIZER ROW LOWER SUPPORT		01
06	0561017928	FERTILIZER ROW ARTICULAT SLEEVE		02
07	0511015098	FLAT WASHER		06
08	0503010233	5/8" X 2-1/2" BOLT		02
09	0503012412	5/8 UNC SELF LOCKING NUT		02
10	0511063862	FERTILIZER ROW UPPER SUPPORT		01
11	0501010452	5/8" X 5" BOLT		01
12	0531016207	0.6" X 1" X 2.8" SLEEVE		01
13	0503012412	5/8 UNC SELF LOCKING NUT		01
14	0521061855	FERTILIZER ROW REAR SUPPORT		01
15	0501010452	5/8" X 5" BOLT		02
16	0531016031	1/2" SPRING WASHER		04
17	0531016207	0.6" X 1" X 2.8" SLEEVE		02
18	0503012412	5/8 UNC SELF LOCKING NUT		02
19	0521062073	SPRING GUIDE		01
20	0521016057	COUP SHA OF THE CARRY-W SPRING GUI		01
21	0503030168	HAIR PIN		01
22	1902020393	SPRING UPPER SUPPORT		01
23	0503031450	2.7" X 9.2" X 0.03" SPRING		01
24	1902020393	SPRING UPPER SUPPORT		01
25	0521011158	SPRING LOCKNUT		01
26	0521018575	REGULATOR SPINDLE 100		01
27	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR		01
28	0502012352	DOUBLE-DISC SPACING PLATE		01
29	0541013035	5.55" X 4.0" X 0.38" PLATE		01
30	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
31	0503010019	1/2" SPRING WASHER		02


**FERTILIZER SHORT LINE**

0511053024


Item	Code	Description	See page	QT
32	0503010060	1/2" NUT		02
33	0503010752	1/2" X 3.1/2" BOLT		02
34	0503010019	1/2" SPRING WASHER		02
35	0503010060	1/2" NUT		02
36	0503030520	SEED SOCKET		01
37	0503031145	2" X 2" X 20" HOSE		01
38	0503031076	2" HOSE CLAMP		02
39	0503010003	1845 GREASE FITTING		03




Item	Code	Description	See page	QT
01	0502012369	BLADE DISC SUPPORT	01	
02	0501067323	SPRING REGULATOR	01	
03	0521010452	SLEEVE	01	
04	0521015376	DUST CLOAK	02	
05	0521013510	3/4" NUT	02	
06	0503011438	SPRING WASHER	02	
07	0503034498	SPRING	01	
08	0521067844	RIGHT ARM	01	
09	0521067843	LEFT ARM	01	
10	0503011255	3/4" LOCK NUT	02	
11	0581014407	FLAT WASHER 36.5 X 65.00 X 3.00	01	
12	0503030430	7/16 X 2" PIN LOCK	01	
13	0503010003	1845 GREASE FITTING	01	
14	0501052139	18 BLADE DISC WITH FLAT PLAN DISC	01	
15	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
16	0521062962	BLADE DISC AXLE	01	
17	0581014524	SPRING SUPPORT WASHER	01	
18	0503011411	1/2" X 5-1/2" BOLT	01	
19	0503010060	1/2" NUT	01	
20	0503011440	SPRING WASHER	01	
21	0503013185	3/4" X 5-1/2" BOLT	01	




Item	Code	Description	See page	QT
01	0521062962	BLADE DISC AXLE	01	
02	0502012369	BLADE DISC SUPPORT	01	
03	0541018684	FLAT WASHER	01	
04	0503010361	SPRING PIN	01	
05	0503010756	0.2" X 2.4" SPRING PIN	01	
06	0503010003	1845 GREASE FITTING	01	
07	0521018935	RIGHT ARM OF THE BLADE DISC	01	
08	0521018936	LEFT ARM OF THE BLADE DISC	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503016525	3/4" X 6" BOLT	01	
12	0503011442	3/4" SPRING WASHER	01	
13	0503010014	3/4" NUT	01	
14	0502020393	SPRING UPPER SUPPORT	01	
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
16	0502020394	SPRING SUPPORT	01	
17	0503010014	3/4" NUT	02	
18	0501054887	20 BLADE DISC WITH FLAT PLAN DISC	01	
19	0521015376	DUST CLOAK	02	
20	0511015346	FLAT WASHER	02	
21	0503011438	SPRING WASHER	02	
22	0521013510	3/4" NUT	02	
23	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
24	0503011411	1/2" X 5-1/2" BOLT	01	
25	0503011440	SPRING WASHER	01	
26	0503010060	1/2" NUT	01	




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT	01	
02	0502011930	DOUBLE DISC COULTER BOX	02	
03	0503010598	30204 BALL BEARING	04	
04	0503011112	SEAL 02376-BRG	02	
05	0521019148	LEFT DOUBLE DISC HUB	01	
06	0503030282	3/4" CASTLE NUT	02	
07	0503010257	1/8" X 1" COTTERPIN	02	
08	0603022042	13" X 0.12" PLAIN COULTER BLADE	02	
09	0503010546	5/16" X 7/8" BOLT	12	
10	0503010337	5/16" NUT	12	
11	0511015098	FLAT WASHER	06	
12	0511011927	DUST CLOAK	02	
13	0503030757	2.9" X 2" X 0.02" JOINT	02	
14	0521019178	COVER DEPTH	02	
15	0503014729	1/4" UNF X 1/2" BOLT	06	
16	0503011441	SPRING WASHER	06	
17	0501017542	LH DOUBLE DISC SCRAPER	01	
18	0501017541	RH DOUBLE DISC SCRAPER	01	
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	
20	0501010984	FLAT WASHER	02	
21	0503011443	3/8" SPRING WASHER	01	
22	0503010026	3/8" NUT	01	
23	0502070062	SCRAPER	01	
24	0503011402	0.2" X 0.8" SPRING PIN	01	
25	0521019154	RIGHT DOUB DISC HUB	01	




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT	01	
02	0502011930	DOUBLE DISC COULTER BOX	02	
03	0503010598	30204 BALL BEARING	04	
04	0503011112	SEAL 02376-BRG	02	
05	0521019148	LEFT DOUBLE DISC HUB	01	
06	0503030282	3/4" CASTLE NUT	02	
07	0503010257	1/8" X 1" COTTERPIN	02	
08	0603022042	13" X 0.12" PLAIN COULTER BLADE	02	
09	0503010546	5/16" X 7/8" BOLT	12	
10	0503010337	5/16" NUT	12	
11	0511015098	FLAT WASHER	06	
12	0511011927	DUST CLOAK	02	
13	0503030757	2.9" X 2" X 0.02" JOINT	02	
14	0521019178	COVER DEPTH	02	
15	0503014729	1/4" UNF X 1/2" BOLT	06	
16	0503011441	SPRING WASHER	06	
17	0501017542	LH DOUBLE DISC SCRAPER	01	
18	0501017541	RH DOUBLE DISC SCRAPER	01	
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	
20	0501010984	FLAT WASHER	02	
21	0503011443	3/8" SPRING WASHER	01	
22	0503010026	3/8" NUT	01	
23	0502070062	SCRAPER	01	
24	0503011402	0.2" X 0.8" SPRING PIN	01	
25	0521019154	RIGHT DOUB DISC HUB	01	




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	77	01
02	0501052538	DEPTH BAND WITH ARMS	81	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	83	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	82	01
07	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	78	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	79	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	80	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2" TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	SCREWEW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL BOX		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL BOX		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0511015976	FLAT WASHER		01
05	0503010257	1/8" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503010071	3/16" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING		01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING		01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0511052971	CONTROL DEPTH WITH SEMI MOUNTED THREAD	85	01
02	0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	87	01
03	0501052908	COMPACTOR WHEEL WITH BEARING		02
04	0503010019	1/2" SPRING WASHER		06
05	0503010752	1/2" X 3.1/2" BOLT		01
06	0503013739	1/2" X 1" BOLT		01
07	0503010479	1/2" X 3" BOLT		02
08	0503010060	1/2" NUT		04
09	0503030012	HAIR PIN		01
10	0571013222	FIXING CHOCK		01
11	0503010741	1/2" X 2-3/4" BOLT		02
12	0511055819	DEPTH WHIT AROS BAND	86	02
13	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
14	0503013816	5/16" LOCKNUT		08




Item	Code	Description	See page	QT
01	0521063808	DEPTH CONTROL INNER COLUMN CONTROL WITH SCREW		01
02	0521063809	DEPTH CONTROL EXTERNAL COLUMN CONTROL WITH SCREW		01
03	0571013194	REGULATOR SPINDLE		01
04	0551010616	ROD HEX		01
05	0503010683	0,2" X 1,2" SPRING PIN		01
06	0571013202	REGULATOR AXLE WHEELS COBRIDORA		01
07	0521063812	REGULATOR LEVER ALXE		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		01
09	0511065308	LOCK REGULATOR		01
10	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
11	0541011627	FLAT WASHER		01
12	0503010140	1/8" X 3/4" COTTERPIN		01
13	0511059325	LEFT ARM WHEELS		01
14	0511059324	RIGHT ARM COATING WHEEL MOUNTED		01
15	0571014709	SLEEVE LOCK CONTROL ARM		02
16	0503011440	SPRING WASHER		03
17	0503819099	BOLT		02
18	0511051546	CUBE RIGHT CONTROL DEPTH		01
19	0511051547	LEFT CUBE CONTROL DEPTH		01
20	0503011442	3/4" SPRING WASHER		02
21	0571013189	SLEEVE SUPPORT BEATER		01
22	0521063813	WHEEL PRESS BEATER		01
23	0501010937	13.5 X 28 X 3 FLAT WASHER		01
24	0503010920	1/2" X 1.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0502012850	PRESS WHEELS ARM		01
02	0503030883	RIGHT TORSION SPRING		01
03	0502011066	PRESS WHEELS ARM SUPPORT		01
04	0531017415	1" X 4.72" AXLE JOINT		01
05	0503010839	03"X 0.6" SPRING PIN		01
06	0521063841	REGULATOR RIGHT COMPACTOR		01
07	0521063842	REGULATOR LEFT COMPACTOR		01
08	0503811404	BOLT		02
09	0503011443	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0571013295	ALXE REGULATOR COMPACTOR		01
12	0521063812	REGULATOR LEVER ALXE		01
13	0503011336	1/2" HEX SELF ADJUSTING NUT		02
14	0511065308	LOCK REGULATOR		01
15	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
16	0541011627	FLAT WASHER		01
17	0503010140	1/8" X 3/4" COTTERPIN		01
18	0571013293	SLEEVE LOCK COMPACTOR V CONTROL WITH SCREW		01
19	0503811172	BOLT		01
20	0503010002	1800 GREASE FITTING		01
21	0581013744	PROTECTION COVER - CPRA		01
22	0503813096	BOLT		01
23	0503013816	5/16" LOCKNUT		0



Item	Code	Description	See page	QT
001	0511057606	PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX	89	01
002	0503015920	3/8" UNC X 1.3/4" BOLT		04
003	0503010025	3/8" SPRING WASHER		04
004	0503010026	3/8" NUT		04
005	0503062403	TUBE SEED P.P		01
006	0511057154	DDD RITGH SUPREMA PRECISION PLANTING	91	01
007	0501058972	ASSEMBLY SENSOR ELECTRONIC		01
008	0521066707	FEEDER		01
009	0503011953	5/16" X 1" BOLT		04
010	0503010179	5/16" ZN SPRING WASHER		04
011	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
20	0503010293	BAQUELITE MANIPULACION		01
21	0503010140	1/8" X 3/4" COTTERPIN		03
22	0503010131	3/16" X 1-1/2" COTTERPIN		01
23	0503010025	3/8" SPRING WASHER		01
24	0571011803	PRISONER CLOSE FAST		01
25	0571019491	SLUICE PNEUMATIC PRECISION PLANTING		01
26	0501011643	3/8 X 1"BOLT		01
27	0503010209	3/8" UNC BUTTERFLY NUT		01
28	0503012721	1/4" X 4" BOLT		01
29	0503012880	1/4" UNC SELF ADJUSTING NUT		01
30	0571011804	FAST BOLT ADJUSTMENT		01
31	0571019489	CLAMP PRECISION PLANTING		01
32	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
33	0503011855	0.2" X 1.8" SPRING PIN		02
34	0561014778	HEX UNIVERSAL JOINT		01
35	0503013958	1/4" X 1" BOLT		02
36	0503011855	0.2" X 1.8" SPRING PIN		01
37	0503818139	M6 BOLT		03
38	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
39	0503015110	M06 SPRING WASHER		02
40	0501056296	UNIVERSAL JOINT		01
41	0571012452	HEX AXLE		01
42	0511057491	PRECISION PLANTING SEED ASSY SEED 90 DISTRIBUTOR WITH CORN DISC		01
42A	0503062405	SEED DISTRIBUTOR		01
42B	0503062407	SET SOYBEAN DISTRIBUTION		01
42B-01	0503062417	KIT CORN DISTRIBUTION		01
42B-02	0503062471	DISTRIBUTION ASSY (SORGHUM / MILLET)		01
42B-03	0503062577	DISTRIBUTION ASSY (LARGE CORN / SUNFLOWER)		01
42B-04	0503062578	DISTRIBUTION ASSY (LARGE CORN)		01
42B-05	0503062579	DISTRIBUTION ASSY (CORN / SUNFLOWER)		01
42B-06	0503062580	DISTRIBUTION ASSY (POPCORN / COTTON)		01
42B-07	0503062581	DISTRIBUTION ASSY (SMALL CORN / POP CORN)		01
42B-08	0503062573	CONVERSATION SET FOR DISTRIBUTION (LARGE BEAN)		01
42B-09	0503062574	CONVERSATION SET FOR DISTRIBUTION (SMALL BEET)		01
42B-10	0503062564	CONVERSATION SET FOR DISTRIBUTION (SOYBEAN / BEAN)		01
42C	0571019613	STRAW PRECISION PLANTING SHIELD		01




Item	Code	Description	See page	QT
01	0503062405	SEED DISTRIBUTOR		01
01A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
01AA	0503018908	BODY FIXED BASE DISTRIBUTOR SEED		01
01AB	0503018909	COVER CONDUCTOR DISTRIBUTOR SEED		01
01AC	0503062652	SEED INPUT DEFLECTOR		01
01AD	0503062653	FULL COVER		01
01AE	0503018910	RIVETS LARGEST		01
01AF	0503018911	SPACING BUSHING		01
01AG	0503018912	BOLT		03
01AH	0503018476	SPRING		01
01AI	0503018474	LOWER BRUSH		01
01AJ	0503018475	TOP BRUSH		01
01AK	0503018157	RUBBER		01
01AL	0503018477	LOCK SPRING		01
01B	0503062568	FIXER MOBILE		01
01BA	0503018919	BASE		01
01BB	0503018913	RIVET		01
01BC	0503018914	WASHER		01
01BD	0503018915	BEARING		02
01BE	0503062654	BEARING		01
01BF	0503018916	ADJUSTMENT CHOCK		03
01BG	0503018917	RING		01
01BH	0503018918	CHOCK		02
01BI	0503019288	RUBBER SEAL PP 730518		01
01BJ	0503018478	SPRING		01
01BK	0503018920	SEALING		01
01BL	0503018479	TUBE		01
01BM	0503018735	PROTECTIVE COVER		01
01BN	0503018921	BOLT		06
01BO	0503018922	BOLT		02
01BP	0503018480	REGULATOR PIN		01


Item	Code	Description	See page	QT
01BQ	0503018923	ADAPTER		01
01BR	0503018924	SPRING PIN		01
02	0503062417	KIT CORN DISTRIBUTION		01
02A	0503018160	CORN PLASTIC DISC		01
02B	0503062472	SELECTOR SEED CORN		01
02C	0503062474	EJECTOR CORN SEED SET		01
03	0571019613	STRAW PRECISION PLANTING SHIELD		01
03A	0503017957	PROTECTIVE COVER AIR INPUT		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15		01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15		01
04	0503010026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501010984	FLAT WASHER		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012780	SUPPORT DDD RIGHT		01
11	0511015098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02




Item	Code	Description	See page	QT
001	0511057606	PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX	89	01
002	0503015920	3/8" UNC X 1.3/4" BOLT		04
003	0503010025	3/8" SPRING WASHER		04
004	0503010026	3/8" NUT		04
005	0503062403	TUBE SEED P.P		01
006	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	93	01
007	0501058972	ASSEMBLY SENSOR ELECTRONIC		01
008	0521066707	FEEDER		01
009	0503011953	5/16" X 1" BOLT		04
010	0503010179	5/16" ZN SPRING WASHER		04
011	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15		01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15		01
04	0503010026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501010984	FLAT WASHER		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012781	SUPPORT DDD LEFT		01
11	0511015098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02




Item	Code	Description	See page	QT
01	0511057249	PNEUMATIC SEAL DISTRIBUTOR WITH AXIS 97 STATION		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062390	SEED CONDUCTOR		01
06	0511057154	DDD RITGH SUPREMA PRECISION PLANTING	91	01




Item	Code	Description	See page	QT
01	0511057249	PNEUMATIC SEAL DISTRIBUTOR WITH AXIS 97		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062390	SEED CONDUCTOR		01
06	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	93	01



Item	Code	Description	See page	QT
001	0511058616	SEED DISTRIBUTOR	98	01
002	0503015920	3/8" UNC X 1.3/4" BOLT		04
003	0503010025	3/8" SPRING WASHER		04
004	0503010026	3/8" NUT		04
005	0503062390	SEED CONDUCTOR		01
006	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	93	01



Item	Code	Description	See page	QT
01	0511055633	PNEUMATIC DISTRIBUTOR 2014 USAP G2 APOS 05/15		01
02	0501056296	UNIVERSAL JOINT		01
03	0571018555	170 HEX AXLE SEED		01
04	0503011855	0.2" X 1.8" SPRING PIN		02




Item	Code	Description	See page	QT
001	0511055633	PNEUMATIC DISTRIBUTOR 2014 USAP G2 APOS 05/15		01
002	0501056296	UNIVERSAL JOINT		01
003	0581010584	SIDE SEX SIDE AXLE		01
004	0503011855	0.2" X 1.8" SPRING PIN		02



Item	Code	Description	See page	QT
001	0503030011	PLASTIC BAG		01
002	0503017847	CENTRAL COMMAND		01
003	0503017849	CHICOTE FEEDING		01
004	0503017850	WHIPPING COMMAND TRACTOR		01
005	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		03
006	0501010984	FLAT WASHER		03
007	0503010026	3/8" NUT		03

REAR TURBINE ASSY


0511058612




Item	Code	Description	See page	QT
001	0521065282			01
002	0571017282	FIXER SUPPORT TURBINE		02
003	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
004	0503010019	1/2" SPRING WASHER		06
005	0503010060	1/2" NUT		06
006	0511057657	TURBINE	101	01
007	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		02
008	0503012412	5/8 UNC SELF LOCKING NUT		02
009	0503015062	TUBE		03
010	0571019921	AIR SUPPORT FIXATION		06
011	0503010237	3/8" X 1" BOLT		12
012	0501010984	FLAT WASHER		12
013	0503010025	3/8" SPRING WASHER		12
014	0503010026	3/8" NUT		12
015	0571019403	STAPLE FIXER		06
016	0511057678	CENTRAL AIR DISTRIBUTOR		01
017	0511057349	DISTRIBUTOR VACUUM 4045/4395		02
018	0503031576	ELBOW		02
019	0501010984	FLAT WASHER		12
020	0503010025	3/8" SPRING WASHER		12
021	0503010026	3/8" NUT		12
022	0531016193	4" X 74" AIR CONDUCTOR		02
023	0511015569	HOSE		01
024	0503011372	102 TO 121 CLAMP		06
025	0571013731	VACUUM GAUGE SUPPORT		01
026	0503013584	VACUUM GAUGE		01
027	0511057840	ASSY TURBINE HOSE REAR		01
027A	0501080877	3/8" X 6000 TM-TM HOSE ASSY		01
027B	0501081247	HOSE 1/2 X 7012 TC-TM		02
028	0503013100	NYLON CLAMP		04
029	0501012140	FLAT WASHER		02

TURBINE


0511057657




Item	Code	Description	See page	QT
001	0501054983	NIPPLE HIDRAULIC MOTOR	102	01
002	0503010025	3/8" SPRING WASHER		12
003	0503010026	3/8" NUT		10
004	0521044613	FAN 480 X 50 S (HIDRAULIC)		01
005	0503010143	1/4" SPRING WASHER		01
006	0503010849	3/8" X 1-1/2" BOLT		02
007	0531018764	FLAT WASHER		01
008	0503011104	M6 X 1" BOLT		01
009	0503012722	0.16" X 0.4" BLIND RIVET		20
010	0521066237	SNAIL MECHANICAL TURBINE HIDRAULIC		01
011	0521065858	TURBIN SUPPORT		01
012	0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC 103 TURBINE		01
013	0561010634	VALVE SUPPORT ASSY		01
014	0503010237	3/8" X 1" BOLT		08
015	0503010206	3/8" X 1/2" BOLT		02
016	0571018577	COVER SNAIL TURBINE		01
017	0541013274	LISA WASHER 10 X 38 X 4.75		02
018	0511057658	DISTRIBUTOR AIR 03 EXITS	104	01
019	0501080709	3/8" X 21.6" TR-TR HOSE		01
020	0501080091	1/2" X 550 TR-TR HOSE		02




Item	Code	Description	See page	QT
01	0503012871	HYDRAULIC MOTOR		01
02	0531018770	R 3/4"UNF X R 1/4"BSP ELBOW		01
03	0561016941	3/4" NUT		01
04	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
05	0541011065	3/4"UNF X R1/4BSP19FPP X43.5 NIPPLE		01




Item	Code	Description	See page	QT
01	0503012291	BLOCK COMMAND		01
02	0501010590	7/8" REDUCTION NIPPLE		04
03	0503010045	2-116 N 3006-9B O'RING		04
04	0541011066	3/4" UNF X 43.5 NIPPLE		01
05	0503010190	2-114 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
001	0521065249			01
002	0503031576	ELBOW		03
003	0571019849	TUBE		03




Item	Code	Description	See page	13/15 L.
01	0511056396	13L SEED OR FERTILIZER PLANT MONITORING ASSEMBLY PM400	01	00
01A	0503016559	13 ROW SIMPLE CABLE MONITORING	01	00
01B	0503017577	CAB UNIC PM400	01	01
01C	0503017602	MONITOR PLANT PM400	01	01
01D	0503016234	TRIMBLE FIXING WINDOW	01	01
01E	0503016452	FIXING SUPPORT AG500 TRIMBLE	01	01
01F	0571012196	MOUNTING BRACKET PM 400	01	01
01G	0503017443	ANTENNA GPS PM 400	01	01
01H	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP	01	01
02	0511056398	PLANTACIÓN DE SEGUIMIENTO DE MONTAJE	00	01
02.	0503016561	15 ROW SIMPLE MONITOR CABLE	00	01
02..	0501058973	CONJ SENSOR ELECTRIC SENSOR Ø25MM	13	15
02A	0503015219	CONJ SENSOR ELECTRIC SENSOR Ø25MM	13	15
02B	0503013100	NYLON CLAMP	39	45
02C	0503034030	MANGO	13	15
02D	0503010368	1.1/2" X 2" X 12.2" HOSE	13	15
02E	0571013891	CONVEYOR FIXING GLOVE	13	15
02F	0503010243	CLAMP	13	15
03	0501058972	ASSEMBLY SENSOR ELECTRONIC	13	15
03A	0503015218	SENSOR FOTOELE PM 400	13	15
03B	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP	39	45
04	0561019643	GUTTER 25 X 58 X 1000	02	02
05	0571019693	GUN 25 X 58 X 800	02	02
06	0571013314	GUTTER 25 X 58 X 1500	00	02
07	0571017368	SUPPORT GUTTER	08	08
08	0501011643	3/8 X 1" BOLT	08	08
09	0501010984	FLAT WASHER	08	08
10	0503010025	3/8" SPRING WASHER	08	08
11	0503010026	3/8" NUT	08	08



Item	Code	Description	See page	QT
001	1163920002	2" FLEX HOSE SPIRAL		02



Item	Code	Description	See page	QT
001	1164920007	HOSE		13
002	0571019716	ADAPTER		13



Item	Code	Description	See page	QT
01	0501056271	BEARING CLOSED	02	
02	0501056444	BEARING WITH BALL BEARING	02	
03	0503011953	5/16" X 1" BOLT	08	
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER	08	
05	0503010179	5/16" ZN SPRING WASHER	08	
06	0503010337	5/16" NUT	08	
07	0511014218	3/4" X 28.7"SQUARE SHAFT	02	
08	0521010691	AXLE FASTENER	04	
09	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN	04	
10	0511017303	FLAT WASHER	04	
11	0503010143	1/4" SPRING WASHER	04	
12	0503010144	1/4" NUT	04	
13	0503030303	SUPPORT WASHER	04	
14	0521061852	LEVER RATCHET	02	
15	0521061847	AXLE ADRIVING ASSY	02	
16	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN	04	
17	0521061849	DISASSEMBLE LEVER	02	
18	0503010140	1/8" X 3/4" COTTERPIN	04	
19	0571012792	LOWER LEVER	02	
20	0503011082	C1/2" X 1.3/4" SCREW	02	
21	0511017302	FLAT WASHER	04	
22	0503010019	1/2" SPRING WASHER	02	
23	0503010060	1/2" NUT	02	
24	0561016797	SLEEVE UNION LEVER ARM/DESARM	02	
25	0501010096	3/8" X 2" BOLT	02	
26	0501010984	FLAT WASHER	04	
27	0503010026	3/8" NUT	04	



www.marchesan.com.br



Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI