

PARTS CATALOGUE



ROW CROP PLANTERS

Code:

0501091786

Product:

PST4 FLEX SUPREMA P.P - FRAME 3245/3695/4045/4845 - CSU



Series:

S-0116

Revision:

00

Date Revision:

JANEIRO/2017

PRODUCTS



Code	Description
0111290118	PST4 FLEX SUP 4045/5E900 MH S-0116
0111290119	PST4 FLEX SUP 4845/6E900 MH S-0116
0111290121	PST4 FLEX SUP G1 4045/5E900 MH S-0116
0111290124	PST4 FLEX SUP PP 3245/7E450 ESPECIAL S-0116
0111290125	PST4 FLEX SUP PP 3245/8E450 ESPECIAL S-0116
0111290120	PST4 FLEX SUP PP 3695/7E500 MH MTH S-0116
0111290123	PST4 FLEX SUP PP 4045/5E800 ESPECIAL S-0116
0111290122	PST4 FLEX SUP PP 4045/6E700 MH MTH S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.



MARCHESAN

INDEX

0909091905	07 / 09 / 10 FRAME		1
0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER		2
0511056536	ASSEMBLY LADDER		3
0511054971	RESTING ASSEMBLY		4
0501054258	DRAWBAR ESTABILIZER ASSY		5
0511054601	FULL ARTICULATED TRACTOR HITCH		6
0909091906	PEÇAS TURBINA		7
0521041586	TURBINE ASSY FOR CARDAN		8
0501053886	PULLEY ASSY WITH FREE ROT		9
0521044612	FAN		10
0511041364	DRIVE SHAFT		11
0521043312	HUB SPINDLE ASSY		12
0501058240	WHELL FASTENER WITH STRETCHER		13
0501058241	TENSIONER CHAIN SUPPORT		14
0511052769	WHEEL TRANSMISSION WITHOUT TIRE		15
0909092204	SUPREME TRANSMISSION 07 / 09 / 10		16
0501052560	AXLE MOTOR SLOW-MOVING ASSY		17
0511051434	TRANSMISSION DRIVING ASSY		18
0511047070	LH SIDE TRANSMISSION DRIVING		19
0511047069	SIDE TRANSMISSION DRIVING		20
0501058254	UPPER SEED CHAIN TENSIONER		21
0511047059	LH GEAR BOX ASSY		22
0511047058	RIGHT GEAR BOX ASSY		23
0501058213	LH GEAR BOX		24
0501058212	SEMI MOUNTED RIGHT CHANGE		25
0521050184	EXCHANGE LEFT ASSY	(OPTIONAL)	26
0521050183	RIGHT GEAR BOX ASSY	(OPTIONAL)	27
0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE		28
0501056443	BEARING ASSY GEAR BOX		29
0501056271	BEARING CLOSED		30
0511059266	CLOSED BEARING	(OPTIONAL)	31
0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE		32
0501054655	CHAIN TENSIONER ASSY		33
0501048790	AXLE WITH LINK ASSY		34
0511057235	SET SUPPORT RIGHT LEFT		35
0511057128	SET SUPPORT RIGHT LEFT		36
0511057564	SET SUPPORT RIGHT LEFT		37
0909091908	SEED FERTILIZER ROW ASSY G2		38
0909091909	SEED ROW ASSY G2		39
0909091910	SEED FERTILIZER ROW W/ HDA ASSY	(OPTIONAL)	40
0909091911	SEED ROW W/ HDA ASSY	(OPTIONAL)	41
0909091912	SEED FERTILIZER ROW W/ PP ASSY	(OPTIONAL)	42
0909092205	SEED ROW PP	(OPTIONAL)	43
0511057244	RIGH SHORT SEED ROW FRONT		44
0511057243	LEFT SHORT SEED ROW FRONT		45
0511057246	RIGHT LONG SEED ROW FRONT		46
0511057247	LEFT LONG SEED ROW FRONT		47
0511054884	TRANSMISSION BOX		48
0511052426	TRANSMISSION CARDAN ASSY		49
0909090849	REAR RIGHT SEED ROW SUPREMA		50
0909090850	REAR LEFT SEED ROW SUPREMA		51
0511057607	REAR RIGHT ROW SEED	(OPTIONAL)	52
0511057608	REAR LEFT ROW SEED	(OPTIONAL)	53
0511056623	RIGHT REAR LINE SEED	(OPTIONAL)	54
0511056624	LEFT REAR LINE SEED	(OPTIONAL)	55




MARCHESAN

INDEX

0511056585	RIGHT 15" X 15" DOUBLE DISC SEED		56
0511056586	15 X 15 SEED DDD LEFT		57
0511057154	DDD RITGH SUPREMA PRECISION PLANTING	(OPTIONAL)	58
0511057153	DDD LEFT SUPREMA PRECISION PLANTING	(OPTIONAL)	59
0511053172	LEFT LOW CUBE WITH DISC 15		60
0511053173	CUBE LOW RIGHT WITH DISC 15		61
0521042710	PNEUMATIC SEED DISTRIBUTOR		62
0511057606	PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX	(OPTIONAL)	63
0511057491	PRECISION PLANTING SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	(OPTIONAL)	64
0511057249	PNEUMATIC SEAL DISTRIBUTOR WITH AXIS STATION	(OPTIONAL)	65
0511055633	PNEUMATIC DISTRIBUTOR 2014 USAP G2 APOS 05/15		66
0511055631	SUPPORT PNEUMATIC		67
0511055624	COVER SYTEM PNEUMATIC		68
0511055632	BOX TRANSMISSION PNEUMATIC		69
0511057502	SET PRECISION PLANTING		70
0511053902	CARDAN WHIT SUPPORT		71
0511057248	SEED DEPOSIT ASSY PNEUMATIC - G2		72
0511057509	SEED RESERVOIR PNEUMATIC ASSY	(OPTIONAL)	73
0521045198	PRESS WHEELS		74
0521046122	DEPTH SYSTEM / COMPACTOR ASSY		75
0511058650	SEMI-MOUNTED DEPTH CONTROL		76
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE		77
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE		78
0511053250	SHORT ARM FERTILIZER LINE WITH DDD LEFT		79
0511053251	ARM LONG FERTILIZER LINE WITH DDD RIGHT		80
0501052627	ASSY DEPTH WHEEL BOX		81
0909091616	RUEDA COMPACT DER IZL V C/ ROL		82
0909091821	LONG FERTILIZER LINE RIGHT		83
0909091822	SHORT LINE FERTILIZER LEFT		84
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR		85
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR		86
0511054835	HDA	(OPTIONAL)	87
0511044549	18" COULTER BLADE ASSY FOR SHORT ROW		88
0511044573	18" COULTER BLADE ASSY FOR LONG ROW		89
0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	(OPTIONAL)	90
0511044585	20" COULTER BLADE ASSY FOR LONG ROW	(OPTIONAL)	91
0501058423	FERTILIZER ROD SPRING ROW		92
0511058839	LINE DOC 20 TURBO C CT	(OPTIONAL)	93
0511058840	LINE DOC 20 TURBO C LG	(OPTIONAL)	94
0909093059	MECANIC ROW MARKER		95
0909091901	HYDRAULIC MEC ROW MARKER 07/09/10	(OPTIONAL)	96
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT		97
0501050633	MARKER DISC ASSY LINE		98
0511058449	HYDRAULIC CYLINDER	(OPTIONAL)	99
0501054649	SEQUENTIAL VALVE ASSY	(OPTIONAL)	100
0511058101	ASSEMBLY CSU C3 SEMI MOUNTED 4045/4495	(OPTIONAL)	101
0511058100	ENSEMBLE BOX UNIQUE SEED C3	(OPTIONAL)	102
0511058838	DC TURBO BOX 20 TURBO	(OPTIONAL)	103
0511056909	DISC BOX CUT WITHOUT THE DISC	(OPTIONAL)	104
0511058182	FIXING ASSEMBLY + REAR TURBINE	(OPTIONAL)	105
0511057700	HYDRAULIC TURBINE	(OPTIONAL)	106
0501054983	NIPPLE HIDRAULIC MOTOR	(OPTIONAL)	107
0521044613	FAN 480 X 50 S (HYDRAULIC)	(OPTIONAL)	108
0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE	(OPTIONAL)	109

INDEX


0511057348	DISTRIBUTOR VACUUM	(OPTIONAL)	110
0521050482	TURBINE ASSEMBLY MTH P.P CSU 3245/7 - 3695	(OPTIONAL)	111
0511059406	TURBINE PRECISION PLANTING MOUNTED	(OPTIONAL)	112
0521050261	DISTRIBUTOR AIR CENTER 08 MOUTHS - 19 A 21	(OPTIONAL)	113
0511059319	AIR FIXING SUPPORT	(OPTIONAL)	114
0501054292	V RIGHT WHEEL PRESS FERTILIZER ASSY	(OPTIONAL)	115
0511054333	COMPACT WHEEL RIGHT WITH BEARING	(OPTIONAL)	116
0501052908	COMPACTOR WHEEL WITH BEARING	(OPTIONAL)	117
0511054334	COMPACT WHEEL LEFT WITH BEARING	(OPTIONAL)	118
0501054293	V LEFT WHEEL PRESS FERTILIZER ASSY	(OPTIONAL)	119
0501055267	"V" RIGHT WHEEL PRESS FERTILIZER ASSY	(OPTIONAL)	120
0511054837	RH IRON PRESS WHEEL	(OPTIONAL)	121
0501052957	IRON V PRESS WHEELS	(OPTIONAL)	122
0511054838	LH IRON PRESS WHEEL	(OPTIONAL)	123
0501055268	"V" LEFT WHEEL PRESS FERTILIZER ASSY	(OPTIONAL)	124
0909092323	SEED AND FERTILIZATION MONITORING SET PM400	(OPTIONAL)	125
0521050169	DAOC 18 RIGHT WITH NOZZLE	(OPTIONAL)	126
0521050170	DAOC 18 LEFT WITH NOZZLE	(OPTIONAL)	127
0511059219	LEFT SUPPORT	(OPTIONAL)	128
0511059218	RIGHT SUPPORT	(OPTIONAL)	129
0511059230	BOX WITH DOC 18 TURBO LEFT	(OPTIONAL)	130
0511059229	BOX WITH DOC 18 TURBO RIGHT	(OPTIONAL)	131
0521050168	MOUNTED FERTILIZER CONDUCTOR	(OPTIONAL)	132
0909094592	HEX AXLE ASSEMBLY		133



Item	Code	Description	See page	07	09	10
01	0501058194	FRAME WITH AXLE WHEEL - 3245		01	00	00
02	0501058195	FRAME WITH AXLE WHEEL - 4045		00	01	00
03	0511050836	WHEEL AXLE FRAME - 4495		00	00	01
04	0511057124	CYLINDER ASSY		01	01	01
04A	0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	2	01	01	01
04B	0531019171	1.25" X 7" COUPLING SHAFT		01	01	01
04C	0521012536	COUPLING SHAFT		01	01	01
04D	0503010523	1/4" X 2" COTTERPIN		02	02	02
04E	0531012565	SLEEVE 16,3X 30 X 88		02	02	02
04F	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02	02	02
04G	0503010027	5/8" SPRING WASHER		02	02	02
04H	0503010013	5/8" NUT		02	02	02
05	0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495		01	01	01
05A	0511057070	HOSE KIT HYDRAULIC		01	01	01
05Aa	0501080422	HOSE 3/8 X 4000 TC-TM		01	01	01
05Ab	0501080446	3/8 X" 169" TC-TM HOSE ASSY		01	01	01
05B	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	97	02	02	02
05Ba	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		02	02	02
05Bb	0503011882	MALE QUICK COUPLER CAP		02	02	02
05C	0503013100	NYLON CLAMP		02	02	02
06	0511057237	PLATFORM ASSY - 3245		01	00	00
06A	0511069661	PLATFORM SUPPORT PIVOT		04	04	04
06B	0503010849	3/8" X 1-1/2" BOLT		08	08	08
06C	0501010984	FLAT WASHER		16	16	16
06D	0503010025	3/8" SPRING WASHER		08	08	08
06E	0503010026	3/8" NUT		08	08	08
06F	0511069725	RIGHT PLATFORM		01	00	00
06G	0521062318	LEFT PLATFORM		01	00	00
06H	0521010549	COUPLING SHAFT		04	04	04
06I	0503010257	1/8" X 1" COTTERPIN		06	06	06
06J	0503011333	COVER FIXER		02	02	02

Item	Code	Description	See page	07	09	10
06K	0503010274	5/32"X 2" COTTERPIN		02	02	02
06L	0521061676	PLATFORM PROLONG		02	02	02
06M	0511069664	PLATFORM EXTENSION LOCK		02	02	02
06N	0502012740	PLATFORM RIGHT FIXER SUPPORT		01	01	01
06O	0502012739	PLATFORM LEFT FIXER SUPPORT		01	01	01
07	0511057129	PLATFORM ASSY - 4045		00	01	00
07A	0511069665	PLATFORM RIGHT PST4 9		00	01	00
07B	0521062323	PLATFORM LEFT PST4 9		00	01	00
08	0511057236	HANDRAIL ASSY - 3245		01	00	00
08A	0511069635	HANDRAIL		02	00	00
08B	0503014007	1/2" X 1-1/4" BOLT		04	04	04
08C	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04	04	04
08D	0503010019	1/2" SPRING WASHER		08	08	08
08E	0503010060	1/2" NUT		08	08	08
09	0511057130	HANDRAIL ASSY - 4045		00	01	00
09A	0511069656	HANDRAIL COP FLEX 600 9		00	02	00
10	0511056536	ASSEMBLY LADDER	3	02	02	02
11	0511054971	RESTING ASSEMBLY	4	02	02	02
12	0511057142	ASSY HEADER - 3245/3695/4045/4495		01	01	01
12A	0502012329	DRAWBAR FIXATION REAR SUPPORT		02	02	02
12B	0502012330	SUPPORT FIXER PIVOT		04	04	04
12C	0503011084	3/4" X 5" BOLT		08	08	08
12D	0501010322	FLAT WASHER		08	08	08
12E	0503010023	3/4" SPRING WASHER		08	08	08
12F	0503010014	3/4" NUT		08	08	08
12G	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02	02	02
12H	0503030119	LOCK PIN		04	04	04
12I	0561014393	COUPLING SHAFT		02	02	02
12J	0511064808	DRAWBAR		01	01	01
12K	0561019087	DRAWBAR TRANSPORT LOCK		01	01	01
12L	0521010578	COUPLING SHAFT		01	01	01
12M	0521010588	0.9" X 7.0" COUPLING SHAFT		01	01	01
12N	0503030085	LOCK PIN		02	02	02
12O	0503010002	1800 GREASE FITTING		01	01	01
13	0511057239	MANUAL CANISTER ASSY		01	01	01
13A	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01	01	01
13B	0503010267	NYLON CLAMP		01	01	01
13C	0503010363	5/16" X 1" BOLT		01	01	01
13D	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01	01	01
13E	0503010179	5/16" ZN SPRING WASHER		01	01	01
13F	0503010337	5/16" NUT		01	01	01
14	0501065677	STRUT		02	02	02
15	0501054258	DRAWBAR ESTABILIZER ASSY	5	01	01	01
16	0511054601	FULL ARTICULATED TRACTOR HITCH	6	01	01	01
17	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01	01	01
18	0511053179	TRACTOR HITCH AXLE		01	01	01
18A	0521064036	TRACTOR HITCH AXLE		01	01	01
18B	0503030012	HAIR PIN		01	01	01
19	0521013022	TRANSPORT LOCK		01	01	01
20	0501068994	0.3" X 3.1" LOCK PIN		01	01	01
21	0503030168	HAIR PIN		01	01	01
22	0521066247	SUPPORT HOSE CARDAN		01	01	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02	02	02
24	0503010025	3/8" SPRING WASHER		02	02	02
25	0503010026	3/8" NUT		02	02	02
26	0503032624	SILO FERTILIZER GUTTER		04	05	05
27	0502012702	BODY SUPPORT CLAMP		01	01	01
28	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		01	01	01
29	0503010180	7/16" SPRING WASHER		01	01	01


Item	Code	Description	See page	07	09	10
30	0501047895	ROD STOP		01	01	01
31	0501047885	ROD STOP		01	01	01
32	0501047886	ROD STOP		01	01	01
33	0501047887	ROD STOP		01	01	01
34	0503010780	N-2050 AMENDMENT		02	02	02
35	0503010951	REDUCTION		04	04	04
36	0503010003	1845 GREASE FITTING		04	04	04
37	0511057565	PLATFORM ASSY - 4495		00	00	01
37A	0521062237	RIGHT PLATAFORM		00	00	01
37B	0521062238	LEFT PLATAFORM		00	00	01
38	0511057566	HANDRAIL ASSY - 4495		00	00	01
38A	0521062239	HANDRAIL		00	00	02
39	0909094592	HEX AXLE ASSEMBLY	133	01	01	01



Item	Code	Description	See page	QT
01	0511064055	5" X 15" CYLINDER CASE		01
02	0511064056	BUSHING 2" X 14" TURNBUCLE		01
03	0502010382	5" END CAP		01
04	0502012227	50.80 X 127 RING SUPPORT		01
05	0503010039	D-2000 SCRAPER RING		01
06	0503010991	1870-2000-375-B GASKET		01
07	0503010952	W2-2250-500 RING		01
08	0503010351	2-425 N 3006-9B O'RING		01
09	0503011062	8-425 BACK-UP RING		01
10	0502010963	2.0" X 5.0" PISTON		01
11	0503010552	PACKING 3750-4250-625-B		02
12	0503010345	2-218 N 3006-9B O'RING		01
13	0503010974	W2-5000-500 RING		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503010003	1845 GREASE FITTING		01
16	0503030385	CYLINDER PLUG N-002		02

ASSEMBLY LADDER


0511056536




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	

RESTING ASSEMBLY

0511054971




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
001	0501069529	653 TURNBUCKLE		01
002	0511062887	RIGHT TURNBUCKLE		01
003	0511062888	LH TURNBUCKLE		01
004	0501061056	RH LOCKNUT WITH HANDLER		01
005	0503010002	1800 GREASE FITTING		02

FULL ARTICULATED TRACTOR HITCH

0511054601



Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0571012612	PIVOT SHAFT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01



Item	Code	Description	See page	07	08	10
01	0511057238	KIT DISTRIBUTOR		01	00	00
01A	0503031608	AIR DISTRIBUTOR		02	00	00
01B	0521014441	HOSE HOLDER RIGHT SUPPORT		02	02	02
01C	0521014442	LOWER AIR DISTRIBUTOR SUPPORT		04	04	04
01D	0521018535	HOSE HOLDER LEFT SUPPORT		02	02	02
01E	0503010371	5/16" X 1" BOLT		08	08	08
01F	0503010179	5/16" ZN SPRING WASHER		08	08	08
01G	0503010337	5/16" NUT		08	08	08
01H	0503014007	1/2" X 1-1/4" BOLT		04	04	04
01I	0503010019	1/2" SPRING WASHER		04	04	04
01J	0503010060	1/2" NUT		04	04	04
02	0511057252	KIT DISTRIBUTOR		00	01	01
02A	0503031609	AIR DISTRIBUTOR		00	02	02
03	0511041364	DRIVE SHAFT	11	01	01	01
04	0503010479	1/2" X 3" BOLT		01	01	01
05	0503010019	1/2" SPRING WASHER		01	01	01
06	0503010060	1/2" NUT		01	01	01
07	0521041586	TURBINE ASSY FOR CARDAN	8	01	01	01
08	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02	02	02
09	0503010027	5/8" SPRING WASHER		02	02	02
10	0503010013	5/8" NUT		02	02	02
11	0531016193	4" X 74" AIR CONDUCTOR		02	02	00
12	0531016195	4" X 94" AIR CONDUCTOR		00	00	02
13	0503011372	102 TO 121 CLAMP		04	04	04
14	0521019552	5" X 188" AIR CONDUCTOR		01	01	01
15	0503012724	121 TO 140 CLAMP		01	01	01
16	0531015603	HOSE FIXATION SUPPORT		01	01	01
17	0501056495	TURBINE OUTPUT SOCKET		01	01	01
18	0503013096	5/16" X 4" BOLT		02	02	02
19	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04	04	04
20	0503010179	5/16" ZN SPRING WASHER		02	02	02




PEÇAS TURBINA

0909091906

Item	Code	Description	See page	07	08	10
21	0503010499	5/16" UNC BUTTERFLY NUT		02	02	02
22	0503031436	AIR DITRIBUTOR PUMP		04	05	05

TURBINE ASSY FOR CARDAN

0521041586



Item	Code	Description	See page	QT
01	0511061094	TURBINE SUPPORT		01
02	0501053716	BEARING ASSY OF THE LARGER FAN		01
02A	0502012016	CHAIN TENSIONER SUPPOT		01
02B	0503012778	MIDDLE LARGER AXLE		01
02C	0531010881	INTERMEDIARY UPPER SLEEVE		01
02D	0503012689	6306 DDU BEARING		02
02E	0503010325	VCA-118 VALVE		01
03	0503010920	1/2" X 1.1/2" BOLT		02
04	0501056495	TURBINE OUTPUT SOCKET		01
04A	0503031812	TURBINE OUTPUT SOCKET		01
04B	0541017539	BUTTERFLY VALVE		01
04C	0511066760	VALVE FIXATION SUPPORT		01
04D	0503013813	1/4" UNC X 7/8" BOLT		02
04E	0511017303	FLAT WASHER		02
04F	0503010143	1/4" SPRING WASHER		02
04G	0503010144	1/4" NUT		02
04H	0501013519	FLAT WASHER		01
04I	0503010019	1/2" SPRING WASHER		01
04J	0503010060	1/2" NUT		01
05	0503010395	1/2" X 1-1/4" BOLT		02
06	0503011336	1/2" HEX SELF ADJUSTING NUT		04
07	0501053886	PULLEY ASSY WITH FREE ROT	9	01
08	0501011194	1/2" X 1-3/4" BOLT		04
09	0521018517	FLAT WASHER		04
10	0503010019	1/2" SPRING WASHER		04
11	0503010020	1/2"NUT		04
12	0503013030	5/8" X 3.1/4" BOLT		01
13	0501012140	FLAT WASHER		01
14	0503010013	5/8" NUT		01
15	0503012780	LARGER TURBINE BELT		01
16	0571012629	FRONT COVER		01


TURBINE ASSY FOR CARDAN

0521041586


Item	Code	Description	See page	QT
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
18	0503010025	3/8" SPRING WASHER		04
19	0503010026	3/8" NUT		04
20	0521044612	FAN	10	01
21	0503011775	6 X 6 X 35 KEYWAY		01
22	0503011774	PULLEY		01
23	0503010179	5/16" ZN SPRING WASHER		01
24	0503011257	M 8 X 1,25 X 30 BOLT		01
25	0503013096	5/16" X 4" BOLT		02
26	0501054272	RIBBON FOR COVER CLOSING ASSY		01
26A	0531017193	RIBBON FOR COVER CLOSING		01
26B	0521018401	SEGMENT COVER		15
27	0503031776	TURBINE RIBBON SEAL		02
28	0571012630	REAR COVER		01
29	0503013031	1/4" X 3.1/4" BOLT		13
30	0503012880	1/4" UNC SELF ADJUSTING NUT		15
31	0511014024	10 X 13 X 15,5 SLEEVE		02
32	0503012721	1/4" X 4" BOLT		02
33	0511017303	FLAT WASHER		04
34	0503031649	CONECTOR CENTER		01
35	0503012722	0.16" X 0.4" BLIND RIVET		08
36	0531012760	TURBINE REAR COVER		01
37	0503013758	1/4" X 1-1/2" BOLT		04
38	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
39	0503010499	5/16" UNC BUTTERFLY NUT		02
40	0561010635	SWITCH FIXER		01
41	0503013584	VACUUM GAUGE		01
42	0503015062	TUBE		0.500

PULLEY ASSY WITH FREE ROT

0501053886




Item	Code	Description	See page	QT
001	0502012020	PULLEY HOUSING BEARING		01
002	0501053888	TURBINE PULLEY ASSY		01
002A	0502012055	TURBINE PULLEY ASSY		01
002B	0503031732	RATCHET TURBINE PULLEY AXLE		01
002C	0503011081	6207 2RS BEARING		02
002D	0531014520	WASHER RATCHET		01
002E	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		06
002F	0501010649	RATCHET CLICK		03
002G	0503031731	RATCHET PULLEY TURBINE		01
002H	0503012950	5/16" X 2-1/2" BOLT		03
003	0503011081	6207 2RS BEARING		02
004	0531014518	INTERMEDIARY LOWER BUSHING BEARING		01
005	0531014519	FLAT WASHER		01
006	0531014527	FLAT WASHER		01
007	0503010301	0.3" X 1.8" SPRING PIN		01
008	0503011855	0.2" X 1.8" SPRING PIN		01
009	0503010325	VCA-118 VALVE		01



Item	Code	Description	See page	QT
01	0571016947	DISC FRONT TURBINE		01
02	0571016949	DISC REAR TURBINE		01
03	0521065170	HUB FAN		01
04	0571016950	DISC STRENGTHENING TURBINE		01
05	0571016951	FLIP TURBINE		10
06	0503012651	M6 X 1" BOLT		05
07	0503010143	1/4" SPRING WASHER		05
08	0503011776	M6 SELF ADJUSTINGNUT		05

DRIVE SHAFT


0511041364




Item	Code	Description	See page	QT
01	0501055638	HOMO JOINT WITH FEMALE BUSHING		01
01A	0503012607	TRACTOR HOMOCINETIC TERMINAL		01
01Aa	0521010638	0.5" X 3.3" QUIC HITCH COUPL SHAFT		01
01Ab	0503030518	0.5"X1.0"X 0.1" COMPRESSION SPRING		01
01Ac	0503010140	1/8" X 3/4" COTTERPIN		01
01B	0503012605	CROSSPIECE		02
01C	0503012606	CENTER BODY		01
01D	0503012604	HOMO TERMINAL W/ FEMALE BUSHING		01
01E	0503012618	2.1" X 2.0" X 31" TRIAN FEMALE TUB		01
01F	0503010843	0.4" X 3.3" SPRING PIN		01
01G	0503011878	0.2" X 3.3" SPRING PIN		01
02	0501055639	UNIVERSAL JOINT		01
02A	0503013132	CC292 TERMINAL		01
02B	0503012096	CROSSPIECE		01
02C	0503013187	TERMINAL		01
02D	0503012619	1.8" X 1.7" X 31" TRIAN MALE TUB		01
02E	0503011069	0.4" X 2.8" SPRING PIN		01
02F	0503011805	0.2" X 2.8" SPRING PIN		01
03	0503013189	PROTECTION ASSY		01
04	0503012023	CHAIN FOR PROTECTION		01

HUB SPINDLE ASSY


0521043312




Item	Code	Description	See page	QT
01	0511054335	WHEEL SUPPORT ASSY		01
01A	0521061566	CARRYING WHEEL ARM TRACTION		01
01B	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
01C	0531016887	CARRYING WHEEL AXLE ARM		01
01D	0503010523	1/4" X 2" COTTERPIN		01
01E	0503010003	1845 GREASE FITTING		01
01F	0511050681	TRACTION SPRING		01
01FA	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01FB	0561016062	SPRING HITCH		02
01G	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
01H	0503010027	5/8" SPRING WASHER		01
01I	0503013030	5/8" X 3.1/4" BOLT		01
01J	0551017715	FLAT WASHER		02
01K	0511052770	WHEEL WITH TIRE 7.00X16 ASSY WHEELED BOX		01
01KA	0503062159	WHEEL		01
01KB	0511052769	WHEEL TRANSMISSION WITHOUT TIRE	15	01
01L	0521012190	AXLE LOCK		02
01M	0503010027	5/8" SPRING WASHER		02
01N	0503011167	M16 X 2 X 30 BOLT		02
01O	0501058241	TENSIONER CHAIN SUPPORT	14	01
01P	0501012140	FLAT WASHER		01
02	0501058240	WHELL FASTENER WITH STRETCHER	13	01
03	0502011308	WHELL FASTENER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	STRETCHER INTERMEDIATE RODE CURRENT		01
07	0501058244	STRETCHER FIXED CURRENT		01
08	0501058242	MOVIL CHAIN TENSIONER		01



Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	113 FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSM AXLE CARRYING-WHEEL		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	07	09	10
01	0511069682	CARRYING-WHEELS PIVOT SHAFT		00	01	00
02	0521013199	LOWER BEARING SEMI		04	04	04
03	0503010899	5/8" X 2-1/4" BOLT		08	08	08
04	0501012140	FLAT WASHER		16	16	16
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08	08	08
06	0503010013	5/8" NUT		08	08	08
07	0503011445	SPRING WASHER		16	16	16
08	0501110639	BEARING		06	08	08
09	0503011099	GREASE FITTING		06	08	08
10	0503010300	5/32" X 1" COTTERPIN		06	08	08
11	0551019114	MOTOR BEARING AXLE SUPPORT		04	04	04
12	0521014021	1/2" X 4.5" X 5.4" FASTENER		04	04	04
13	0511017302	FLAT WASHER		08	08	08
14	0503010019	1/2" SPRING WASHER		18	18	18
15	0503010060	1/2" NUT		16	16	16
16	0531016940	5/8 X 1650 RIGHT HEX AXLE		01	00	00
17	0501018466	FLAT WASHER		04	04	04
18	0511015961	LOCK BUSHING		04	04	04
19	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04	04	04
20	0501052560	AXLE MOTOR SLOW-MOVING ASSY	17	02	02	02
21	0511051434	TRANSMISSION DRIVING ASSY	18	04	04	04
22	0511047069	SIDE TRANSMISSION DRIVING	20	01	01	01
23	0511047070	LH SIDE TRANSMISSION DRIVING	19	01	01	01
24	0521050183	RIGHT GEAR BOX ASSY	27	01	01	01
25	0521050184	EXCHANGE LEFT ASSY	26	01	01	01
26	0501010243	1/2" X 1-1/2" BOLT		06	06	06
27	0503012682	1/2" BSW NUT		06	06	06
28	0503010920	1/2" X 1.1/2" BOLT		04	04	04
29	0511017302	FLAT WASHER		08	08	08
30	0521064449	36Z P1/2 SH 3/4 GEAR		02	02	02
31	0531016941	LEFT 5/8" X 59" AXLE HEX		01	00	00


Item	Code	Description	See page	07	09	10
32	0503030275	AGRICULTURAL BEARING		02	02	02
33	0501010637	FLAT WASHER		04	04	04
34	0501010984	FLAT WASHER		02	02	02
35	0503010025	3/8" SPRING WASHER		02	02	02
36	0503010256	3/8" X 3/4" BOLT		02	02	02
37	0511054363	CHAIN TENSIONER		02	02	02
37A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		02	02	02
37B	0503031805	11Z 1/2" GEAR		02	02	02
37C	0511017302	FLAT WASHER		04	04	04
37D	0503010019	1/2" SPRING WASHER		02	02	02
37E	0503010060	1/2" NUT		02	02	02
38	0501058265	STRETCHER LOWER CURRENT 21Z SEED		02	02	02
38A	0511062169	21Z P 1/2" GEAR		02	02	02
38B	0503011410	ROLLER BEARING		02	02	02
38C	0503011105	SEAL RING		02	02	02
38D	0531017086	50 AXLETIGHTENER		02	02	02
38E	0503010406	501025 CLAMPING RING (FOR AXLE)		02	02	02
38F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02	02	02
38G	0501012140	FLAT WASHER		02	02	02
38H	0503010027	5/8" SPRING WASHER		02	02	02
38I	0503010013	5/8" NUT		02	02	02
39	0501058254	UPPER SEED CHAIN TENSIONER	21	02	02	02
40	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED		02	02	02
40A	0511062169	21Z P 1/2" GEAR		02	02	02
40B	0503011410	ROLLER BEARING		02	02	02
40C	0503011105	SEAL RING		02	02	02
40D	0531017086	50 AXLETIGHTENER		02	02	02
40E	0503010406	501025 CLAMPING RING (FOR AXLE)		02	02	02
40F	0501011234	5/8" X 3" BOLT		02	02	02
40G	0503012412	5/8 UNC SELF LOCKING NUT		02	02	02
41	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED		02	02	02
41A	0511069680	20Z X 28Z DOBLE GEAR		02	02	02
41B	0503011410	ROLLER BEARING		04	04	04
41C	0551019175	DOUBLE GEAR AXLE		02	02	02
41D	0503010406	501025 CLAMPING RING (FOR AXLE)		02	02	02
41E	0501010163	5/8" X 4-1/2" BOLT		02	02	02
41F	0503012412	5/8 UNC SELF LOCKING NUT		02	02	02
42	0503012204	40-1 CHAIN X 82 LINK + RED		02	02	02
43	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02	02	02
44	0503016111	40-1 CHAIN X 109 LINK + MENDING		02	02	02
45	0503014907	40-1 X 151 CHAIN LINK + MENDING		02	02	02
46	0561016882	1535 MOTOR SHAFT		02	00	00
47	0511069724	CARRYING-WHEELS PIVOT SHAFT		01	00	00
48	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	32	02	02	02
49	0561014215	BEARING COVER LOWER ROW FRAME		02	02	02
50	0502040534	SPRING GUIDE BUSHING LOCK		04	04	04
51	0501018535	1/2 X 1 BOLT		04	04	04
52	0503011750	AMENDMENT WITH LOCK		06	06	06
53	0503011751	REDUCTION		06	06	06
54	0561016881	MOTOR SHAFT		00	02	00
55	0531016942	RIGHT HEX AXLE 5/8 X 2050		00	01	00
56	0531016943	LEFT HEX AXLE 5/8 X 1900		00	01	00
57	0521062242	CARRYING-WHEELS PIVOT SHAFT		00	00	01
58	0561018351	2155 MOTOR SHAFT		00	00	02
59	0561019199	5/8" X 2275 AXLE HEX		00	00	01
60	0561019200	5/8" X 2125 AXLE HEX		00	00	01
61	0501010694	8.5 X 18 X 1.5 FLAT WASHER		08	08	08
62	0503010179	5/16" ZN SPRING WASHER		04	04	04
63	0503010337	5/16" NUT		04	04	04




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	5/16" X 3/4" BOLT		02
03	0503010179	5/16" ZN SPRING WASHER		02
04	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02



Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0521018933	113 FERT CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01

LH GEAR BOX ASSY

0511047059



Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	24	01
02	0503031805	11Z 1/2" GEAR		04
03	0503010302	501019 SEAL RING		04
04	0501048790	AXLE WITH LINK ASSY	34	02
05	0503010002	1800 GREASE FITTING		02
06	0551018209	DRIVING AXLE		01
07	0521018259	DRIVEN AXLE		01
08	0551018210	DRIVEN AXLE		01
09	0551018211	INTERM SHAFT		01
10	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	28	01
11	0503030303	SUPPORT WASHER		05
12	0501056443	BEARING ASSY GEAR BOX	29	02
13	0501056271	BEARING CLOSED	30	05
14	0503011953	5/16" X 1" BOLT		10
15	0501010694	8.5 X 18 X 1.5 FLAT WASHER		10
16	0503010179	5/16" ZN SPRING WASHER		10
17	0503010337	5/16" NUT		10
18	0511060396	DRIVE/DRIVEN AXLE CONE		04
19	0503012389	1/2 BALL		04
20	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
21	0503010060	1/2" NUT		04
22	0503010834	1/2 X 1 BOLT		04
23	0511061822	25Z P0.5" GEAR SQUARE HOL		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0511067501	26Z GEAR		01
26	0503010292	0.2" X 1.6" SPRING PIN		07
27	0503012204	40-1 CHAIN X 82 LINK + RED		02
28	0503012713	40-1 CHAIN X 45 LINK + MEN		01
29	0501054655	CHAIN TENSIONER ASSY	33	02
30	0501010984	FLAT WASHER		01
31	0503010025	3/8" SPRING WASHER		01




LH GEAR BOX ASSY

0511047059

Item	Code	Description	See page	QT
32	0503010256	3/8" X 3/4" BOLT		01
33	0503030275	AGRICULTURAL BEARING		01
34	0521018630	1.4" X SQUARE 0.8" WASHER		03

RIGHT GEAR BOX ASSY

0511047058




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	25	01
02	0503031805	11Z 1/2" GEAR		04
03	0503010302	501019 SEAL RING		04
04	0501048790	AXLE WITH LINK ASSY	34	02
05	0503010002	1800 GREASE FITTING		02
06	0551018209	DRIVING AXLE		01
07	0521018259	DRIVEN AXLE		01
08	0551018210	DRIVEN AXLE		01
09	0551018211	INTERM SHAFT		01
10	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	28	01
11	0503030303	SUPPORT WASHER		05
12	0501056443	BEARING ASSY GEAR BOX	29	02
13	0501056271	BEARING CLOSED	30	05
14	0503011953	5/16" X 1" BOLT		10
15	0501010694	8.5 X 18 X 1.5 FLAT WASHER		10
16	0503010179	5/16" ZN SPRING WASHER		10
17	0503010337	5/16" NUT		10
18	0502040868	GEAR CONE REPLACEMENT		04
19	0503012389	1/2 BALL		04
20	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
21	0503010060	1/2" NUT		04
22	0503010834	1/2 X 1 BOLT		04
23	0511061822	25Z P0.5" GEAR SQUARE HOL		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0511067501	26Z GEAR		01
26	0503010292	0.2" X 1.6" SPRING PIN		07
27	0503012204	40-1 CHAIN X 82 LINK + RED		02
28	0503012713	40-1 CHAIN X 45 LINK + MEN		01
29	0501054655	CHAIN TENSIONER ASSY	33	02
30	0501010984	FLAT WASHER		01
31	0503010025	3/8" SPRING WASHER		01




RIGHT GEAR BOX ASSY

0511047058

Item	Code	Description	See page	QT
32	0503010256	3/8" X 3/4" BOLT		01
33	0503030275	AGRICULTURAL BEARING		01
34	0521018630	1.4" X SQUARE 0.8" WASHER		03




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01



Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01

EXCHANGE LEFT ASSY (OPTIONAL)


0521050184




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	24	01
02	0511059266	CLOSED BEARING	31	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	BEARING ASSY GEAR BOX	29	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH LINK ASSY	34	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	33	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	28	01
23	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

RIGHT GEAR BOX ASSY (OPTIONAL)


0521050183




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	25	01
02	0511059266	CLOSED BEARING	31	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	BEARING ASSY GEAR BOX	29	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH LINK ASSY	34	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	33	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	28	01
23	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
05	0503010179	5/16" ZN SPRING WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH BALL BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056271	BEARING CLOSED	30	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8		01
02	0511063106	20Z AXLE BEARING DOBLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0503010365	NUT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02

CHAIN TENSIONER ASSY


0501054655



Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	1 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	DIR	ESQ
01	0511052419	RH BEAM SUPPORT	01	00	
01A	0521063542	FERTILIZER BEAN RIGHT SUPPORT	01	00	
02	0511052420	LH BEAM SUPPORT & METERING	00	01	
02A	0521063543	FERTILIZER BEAN LEFT SUPPORT	00	01	
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	00	04	
03A	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET	00	04	
03B	0501019851	DISTRIBUTOR FERTILIZER AXLE	04	04	
03C	0521010309	SLEEVE INTER	04	04	
03D	0503030275	AGRICULTURAL BEARING	16	16	
03E	0503031164	RIGHT HELICAL CONDUCTOR	04	04	
03F	0501010637	FLAT WASHER	04	04	
03G	0503030303	SUPPORT WASHER	04	04	
03H	0501013774	GREASE SEAL	04	04	
03I	0502011412	18Z CONICAL GEAR	04	04	
03J	0503010523	1/4" X 2" COTTERPIN	04	04	
03K	0503011962	GREASE FITTING	04	04	
03L	0503010003	1845 GREASE FITTING	04	04	
03M	0503012826	CREASE FITTING	04	04	
04	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	04	00	
04A	0501110676	SIDE FERTILIZER DISTRIBUTOR	04	00	
04B	0503031165	LEFT HELICAL CONDUCTOR	04	04	
05	0501010942	3/8" X 1-1/4" BOLT	16	16	
06	0503011443	3/8" SPRING WASHER	16	16	
07	0503010026	3/8" NUT	16	16	
08	0511061759	22Z P12,70 FQ 3/4" GEAR	01	01	
09	0521014167	CONE LOCK	01	01	
10	0503030275	AGRICULTURAL BEARING	04	04	
11	0502010685	18Z CONICAL GEAR	04	04	
12	0561018362	SQUARE SHAFT	01	01	
13	0521010691	AXLE FASTENER	02	02	
14	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN	02	02	

SET SUPPORT RIGHT LEFT

0511057235

Item	Code	Description	See page	DIR	ESQ
15	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02
16	0503011441	SPRING WASHER		02	02
17	0503010144	1/4" NUT		02	02
18	0501110392	SILO SUPPORT BEARING		01	01
19	0521012485	GEAR BOX BEARING AGRICUTURAL		01	01
20	0503011953	5/16" X 1" BOLT		02	02
21	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02
22	0521011039	FLAT WASHER		02	02
23	0503011444	SPRING WASHER		02	02
24	0503010337	5/16" NUT		02	02
25	0551018055	22,65 X 60 SLEEVE		02	02
26	0503010003	1845 GREASE FITTING		01	01
27	0503010849	3/8" X 1-1/2" BOLT		08	08
28	0501010984	FLAT WASHER		17	17
29	0503010025	3/8" SPRING WASHER		08	08
30	0503010026	3/8" NUT		08	08
31	0571010590	FERTILIZER SIDE COVER		04	04
32	0503010362	1/8" X 1.1/4" COTTERPIN		04	04
33	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		01	01
34	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02	02
35	0551019156	GEAR BOX LEVER LOCK		01	01
36	0503011953	5/16" X 1" BOLT		02	02
37	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02
38	0503010179	5/16" ZN SPRING WASHER		02	02
39	0503010337	5/16" NUT		02	02
40	0503010847	1/2" X 3.1/4" BOLT		01	01
41	0551019168	SLEEVE		01	01
42	0551019160	LEVER		01	01
43	0511017302	FLAT WASHER		03	03
44	0503010019	1/2" SPRING WASHER		02	02
45	0503010060	1/2" NUT		01	01
46	0551019167	SLEEVE UNION		01	01
47	0511069676	INNER LEVER		01	01
48	0501013518	FLAT WASHER		02	02
49	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01	01
50	0503010140	1/8" X 3/4" COTTERPIN		03	03
51	0511069678	LH LOWER LEVER		02	02
52	0503011336	1/2" HEX SELF ADJUSTING NUT		02	02
53	0551019115	LOCKING PLATFORM FIXATION		01	01
54	0501010096	3/8" X 2" BOLT		01	01
55	0503013357	3/8" SELF-ADJUSTING NUT		01	01
56	0551019159	LEVER FIXER BODY		01	01
57	0561016468	FASTENER		01	01




Item	Code	Description	See page	DIR	ESQ
01	0511052253	RH BEAM SUPPORT & METERING	01	00	
01A	0521063436	FERTILIZER BEAN RIGHT SUPPORT	01	00	
02	0511052254	LH BEAM SUPPORT & METERING	00	01	
02A	0521063437	FERTILIZER BEAN LEFT SUPPORT	00	01	
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	00	05	
03A	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET	00	05	
03B	0501019851	DISTRIBUTOR FERTILIZER AXLE	05	05	
03C	0521010309	SLEEVE INTER	05	05	
03D	0503030275	AGRICULTURAL BEARING	10	10	
03E	0503031164	RIGHT HELICAL CONDUTOR	05	05	
03F	0501010637	FLAT WASHER	05	05	
03G	0503030303	SUPPORT WASHER	05	05	
03H	0501013774	GREASE SEAL	05	05	
03I	0502011412	18Z CONICAL GEAR	05	05	
03J	0503010523	1/4" X 2" COTTERPIN	05	05	
03K	0503011962	GREASE FITTING	05	05	
03L	0503010003	1845 GREASE FITTING	05	05	
03M	0503012826	CREASE FITTING	05	05	
04	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	05	00	
04A	0501110676	SIDE FERTILIZER DISTRIBUTOR	05	00	
04B	0503031165	LEFT HELICAL CONDUTOR	05	05	
05	0501010942	3/8" X 1-1/4" BOLT	20	20	
06	0503011443	3/8" SPRING WASHER	20	20	
07	0503010026	3/8" NUT	20	20	
08	0511061759	22Z P12,70 FQ 3/4" GEAR	01	01	
09	0521014167	CONE LOCK	01	01	
10	0503030275	AGRICULTURAL BEARING	05	05	
11	0502010685	18Z CONICAL GEAR	05	05	
12	0551018213	3/4" X 1830 SQUARE SHAFT	01	01	
13	0521010691	AXLE FASTENER	02	02	
14	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN	02	02	

SET SUPPORT RIGHT LEFT

0511057128

Item	Code	Description	See page	DIR	ESQ
15	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02
16	0503011441	SPRING WASHER		02	02
17	0503010144	1/4" NUT		02	02
18	0501110392	SILO SUPPORT BEARING		01	01
19	0521012485	GEAR BOX BEARING AGRICUTURAL		01	01
20	0503011953	5/16" X 1" BOLT		02	02
21	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02
22	0521011039	FLAT WASHER		02	02
23	0503011444	SPRING WASHER		02	02
24	0503010337	5/16" NUT		02	02
25	0551018055	22,65 X 60 SLEEVE		01	01
26	0503010003	1845 GREASE FITTING		01	01
27	0503010849	3/8" X 1-1/2" BOLT		08	08
28	0501010984	FLAT WASHER		17	17
29	0503010025	3/8" SPRING WASHER		08	08
30	0503010026	3/8" NUT		08	08
31	0571010590	FERTILIZER SIDE COVER		05	05
32	0503010362	1/8" X 1.1/4" COTTERPIN		05	05
33	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		01	01
34	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02	02
35	0551019156	GEAR BOX LEVER LOCK		01	01
36	0503011953	5/16" X 1" BOLT		02	02
37	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02
38	0503010179	5/16" ZN SPRING WASHER		02	02
39	0503010337	5/16" NUT		02	02
40	0503010847	1/2" X 3.1/4" BOLT		01	01
41	0551019168	SLEEVE		01	01
42	0551019160	LEVER		01	01
43	0511017302	FLAT WASHER		03	03
44	0503010019	1/2" SPRING WASHER		02	02
45	0503010060	1/2" NUT		02	02
46	0551019167	SLEEVE UNION		01	01
47	0511069676	INNER LEVER		01	01
48	0501013518	FLAT WASHER		02	02
49	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01	01
50	0503010140	1/8" X 3/4" COTTERPIN		03	03
51	0511069678	LH LOWER LEVER		02	02
52	0503011336	1/2" HEX SELF ADJUSTING NUT		02	02
53	0551019115	LOCKING PLATFORM FIXATION		01	01
54	0501010096	3/8" X 2" BOLT		01	01
55	0503013357	3/8" SELF-ADJUSTING NUT		01	01
56	0551019159	LEVER FIXER BODY		01	01
57	0561016468	FASTENER		01	01




Item	Code	Description	See page	DIR	ESQ
01	0511053240	RIGHT SILO SUPPORT WITH DISTRIBUTOR 10		01	00
02	0511053241	LEFT SILO SUPPORT WITH DISTRIBUTOR 10		00	01
03	0503010849	3/8" X 1-1/2" BOLT		08	08
04	0501010984	FLAT WASHER		17	17
05	0503010025	3/8" SPRING WASHER		08	08
06	0503010026	3/8" NUT		08	08
07	0571010590	FERTILIZER SIDE COVER		05	05
08	0503010362	1/8" X 1.1/4" COTTERPIN		05	05
09	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		01	01
10	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02	02
11	0551019156	GEAR BOX LEVER LOCK		01	01
12	0503011953	5/16" X 1" BOLT		02	02
13	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02
14	0503010179	5/16" ZN SPRING WASHER		02	02
15	0503010337	5/16" NUT		02	02
16	0503010847	1/2" X 3.1/4" BOLT		01	01
17	0551019168	SLEEVE		01	01
18	0551019160	LEVER		01	01
19	0511017302	FLAT WASHER		03	03
20	0503010019	1/2" SPRING WASHER		02	02
21	0503010060	1/2" NUT		02	02
22	0551019167	SLEEVE UNION		01	01
23	0511069676	INNER LEVER		01	01
24	0501013518	FLAT WASHER		02	02
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01	01
26	0503010140	1/8" X 3/4" COTTERPIN		03	03
27	0511069678	LH LOWER LEVER		02	02
28	0503011336	1/2" HEX SELF ADJUSTING NUT		02	02
29	0551019115	LOCKING PLATFORM FIXATION		01	01
30	0501010096	3/8" X 2" BOLT		01	01
31	0503013357	3/8" SELF-ADJUSTING NUT		01	01




SET SUPPORT RIGHT LEFT

0511057564


Item	Code	Description	See page	DIR	ESQ
32	0551019159	LEVER FIXER BODY		01	01
33	0561016468	FASTENER		01	01




Item	Code	Description	See page	CT	LG
01	0909091909	SEED ROW ASSY G2	39	01	01
02	0909091822	SHORT LINE FERTILIZER LEFT	84	01	00
03	0909091821	LONG FERTILIZER LINE RIGHT	83	00	01
04	0511058618	DISC CUT 18 LONG LINE		00	01
05	0511058617	DISC CUT 18 SHORT LINE		01	00
06	0531013600	PRESS ADJUSTMENT LEVER		01	01
07	0909092391	SEED END FERTILIZER ROW		01	01




Item	Code	Description	See page	CT	LG
01	0511057243	LEFT SHORT SEED ROW FRONT	45	01	00
02	0511057246	RIGHT LONG SEED ROW FRONT	46	00	01
03	0511056623	RIGHT REAR LINE SEED	54	01	01
04	0511056624	LEFT REAR LINE SEED	55	01	01
05	0511057248	SEED DEPOSIT ASSY PNEUMATIC - G2	72	01	01
06	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02	02
07	0503010019	1/2" SPRING WASHER		04	04
08	0503010060	1/2" NUT		04	04
09	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	75	01	01
10	0503010905	1/2" X 2-1/4" BOLT		02	02
11	0571016221	CORN DISC PNEUMATIC		01	01



Item	Code	Description	See page	CT	LG
01	0909092390	SEED ROW ASSY G1		01	01
02	0511053250	SHORT ARM FERTILIZER LINE WITH DDD LEFT	79	01	00
03	0511053251	ARM LONG FERTILIZER LINE WITH DDD RIGHT	80	00	01
04	0511058617	DISC CUT 18 SHORT LINE		01	00
05	0511058618	DISC CUT 18 LONG LINE		00	01
06	0561019420	2 X 2700 HOSE ASSY		01	01
07	0503010246	CLAMP		02	02
08	0511063282	HOSE HOLDER		01	01
09	0503010237	3/8" X 1" BOLT		01	01
10	0503010025	3/8" SPRING WASHER		01	01
11	0503010026	3/8" NUT		01	01
12	0511057542	HDA		01	01
13	0531013600	PRESS ADJUSTMENT LEVER		01	01




Item	Code	Description	See page	CT	LG
01	0511057243	LEFT SHORT SEED ROW FRONT	45	01	00
02	0511057246	RIGHT LONG SEED ROW FRONT	46	00	01
03	0511057244	RIGTH SHORT SEED ROW FRONT	44	01	00
04	0511057247	LEFT LONG SEED ROW FRONT	47	00	01
05	0511056624	LEFT REAR LINE SEED	55	01	01
06	0511056623	RIGHT REAR LINE SEED	54	01	01
07	0511057248	SEED DEPOSIT ASSY PNEUMATIC - G2	72	01	01
08	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02	02
09	0503010019	1/2" SPRING WASHER		04	04
10	0503010060	1/2" NUT		04	04
11	0521045198	PRESS WHEELS	74	01	01
12	0503010905	1/2" X 2-1/4" BOLT		02	02
13	0571016221	CORN DISC PNEUMATIC		01	01


OPCIONAIS


Item	Code	Description	See page	CT	LG
01	0511057243	LEFT SHORT SEED ROW FRONT	45	01	00
02	0511057246	RIGHT LONG SEED ROW FRONT	46	00	01
03	0511057244	RIGTH SHORT SEED ROW FRONT	44	01	00
04	0511057247	LEFT LONG SEED ROW FRONT	47	00	01
05	0511057607	REAR RIGHT ROW SEED	52	01	01
06	0511057608	REAR LEFT ROW SEED	53	01	01
07	0511053250	SHORT ARM FERTILIZER LINE WITH DDD LEFT	79	01	00
08	0511053251	ARM LONG FERTILIZER LINE WITH DDD RIGHT	80	00	01
09	0511058617	DISC CUT 18 SHORT LINE		01	00
10	0511058618	DISC CUT 18 LONG LINE		00	01
11	0521042327	DEPTH CONTROL & PRESS WHEEL ASSY		01	01
12	0521045198	PRESS WHEELS	74	01	01
13	0521044460	SYSTEM DEPTH / COMPACTOR		01	01
14	0521044269	PRESS WHEELS/DEPTH ASSY		01	01
15	0521046501	DEPTH CONTROL AND PRESS WHEEL WITH FAST ADJUSTING		01	01
15.	0521051424	WHEEL SYSTEM DEPTH / COMPACTOR QUICK ADJUSTMENT		01	01
16	0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL		01	01
17	0511057509	SEED RESERVOIR PNEUMATIC ASSY	73	01	01
18	0571019716	ADAPTER		01	01
19	0571019714	AIR CONDUCTOR		01	00
20	0571019715	AIR CONDUCTOR		00	01
21	0503010243	CLAMP		02	02
22	0511051144	ASTA ESCARIFICADORA		01	01
23	0511054835	HDA	87	01	01
24	0511063282	HOSE HOLDER		01	01
25	0531013600	PRESS ADJUSTMENT LEVER		01	00
26	0503010237	3/8" X 1" BOLT		01	01
27	0503010025	3/8" SPRING WASHER		03	03
28	0503010026	3/8" NUT		03	03

Item	Code	Description	See page	CT	LG
29	0521055064	WHEEL SYSTEM DEPTH/ASSY COMPACTOR		01	01
30	0521050193	STEM FUSE WITH CONDUCTOR		01	01
31	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01	01
32	0511017969	0.1" SPACING PLATE		01	01
33	0511058747	RIGHT REAR SUPREME SEED LINE P.P CSU		01	01
34	0511058748	LEFT REAR SUPREME SEED LINE P.P CSU		01	01
35	0521069127	BOTTOM NOZZLE FERTILIZER		01	01
36	0503030483	FERTILIZER SOCKET		01	01
37	0503031050	CURVED CONDUCTOR		01	01
38	0511058212	ASSY LINE SUPPORT FERTILIZER		01	01
39	0571017368	SUPPORT GUTTER		01	01
40	0571019131	GUTTER		02	02
41	0561019643	GUTTER 25 X 58 X 1000		02	02
42	0501011643	3/8 X 1"BOLT		02	02
43	0501010984	FLAT WASHER		02	02
44	0503010025	3/8" SPRING WASHER		02	02
45	0503010026	3/8" NUT		02	02
46	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	90	01	01
47	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	91	01	01
48	0503030391	RIGHT FERTILIZER NOZZLE		01	01
49	0503030392	LEFT FERTILIZER NOZZLE		01	01
50	0503010246	CLAMP		01	01
51	0503031145	2" X 2" X 20" HOSE		01	01
52	0503031076	2" HOSE CLAMP		02	02
53	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		01	01
54	0521052549	CLAMP		02	02
55	0521057957	FIXED ROD EXTENSION WITH FIXATION		01	01
56	0503032624	SILO FERTILIZER GUTTER		01	01
57	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01	01



Item	Code	Description	See page	CT	LG
01	0511057243	LEFT SHORT SEED ROW FRONT	45	01	00
02	0511057246	RIGHT LONG SEED ROW FRONT	46	00	01
03	0511057244	RIGTH SHORT SEED ROW FRONT	44	01	00
04	0511057247	LEFT LONG SEED ROW FRONT	47	00	01
05	0511057607	REAR RIGHT ROW SEED	52	01	01
06	0511057608	REAR LEFT ROW SEED	53	01	01
07	0511057509	SEED RESERVOIR PNEUMATIC ASSY	73	01	01
08	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02	02
09	0503010019	1/2" SPRING WASHER		04	04
10	0503010060	1/2" NUT		04	04
11	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	75	01	01
12	0503010905	1/2" X 2-1/4" BOLT		02	02
13	0503062417	KIT CORN DISTRIBUTION		01	01
13A	0503018160	CORN PLASTIC DISC		01	01
13B	0503062472	SELECTOR SEED CORN		01	01
13C	0503062474	EJECTOR CORN SEED SET		01	01




Item	Code	Description	See page	QT
01	0521064653	RIGH SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8 UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER	04	
08	0503010179	5/16" ZN SPRING WASHER	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION BOX SEED LINE	01	
12	0561014904	TRANSMISSION AXLE FRAME LINE	01	
13	0511050609	BEARING WITH 17Z GEAR ASSY	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEDD ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521065847	SHORT TIRE SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" COTTERPIN	01	
27	0503030168	HAIR PIN	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" COTTERPIN	01	
31	0503034580	TRACTION SPRING	02	



Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY	49	01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04

LEFT SHORT SEED ROW FRONT

0511057243




Item	Code	Description	See page	QT
01	0521064651	LEFT SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8 UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER	04	
08	0503010179	5/16" ZN SPRING WASHER	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION BOX SEED LINE	01	
12	0561014904	TRANSMISSION AXLE FRAME LINE	01	
13	0511050609	BEARING WITH 17Z GEAR ASSY	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEDD ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521065847	SHORT TIRE SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" COTTERPIN	01	
27	0503030168	HAIR PIN	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" COTTERPIN	01	
31	0503034580	TRACTION SPRING	02	



LEFT SHORT SEED ROW FRONT

0511057243

Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY	49	01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064652	RH SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8 UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER	04	
08	0503010179	5/16" ZN SPRING WASHER	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION BOX SEED LINE	01	
12	0561014904	TRANSMISSION AXLE FRAME LINE	01	
13	0501052769	BEARING WITH 17Z GEAR	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEDD ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521065847	SHORT TIRE SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" COTTERPIN	01	
27	0503030168	HAIR PIN	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" COTTERPIN	01	
31	0503034580	TRACTION SPRING	02	



Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY	49	01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04

LEFT LONG SEED ROW FRONT

0511057247



Item	Code	Description	See page	QT
01	0521064650	LEFT SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8 UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER	04	
08	0503010179	5/16" ZN SPRING WASHER	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION BOX SEED LINE	01	
12	0561014904	TRANSMISSION AXLE FRAME LINE	01	
13	0511050609	BEARING WITH 17Z GEAR ASSY	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEDD ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521065847	SHORT TIRE SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" COTTERPIN	01	
27	0503030168	HAIR PIN	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" COTTERPIN	01	
31	0503034580	TRACTION SPRING	02	


**LEFT LONG SEED ROW FRONT**

0511057247


Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY	49	01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04

TRANSMISSION BOX


0511054884




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	BOX TRANSMISSION COVER		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0502040857	CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503010003	1845 GREASE FITTING		01
13	0503011409	6005 Z BALL BEARING		01
14	0503017008	SEAL RING		01
15	0503017007	SEAL RING		02
16	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0511052390	BEARING WITH AXLE ASSY FRONT ROW SEED		01
01A	0511052389	BEARING DOUBLE FRONT ROW SEED		01
01B	0551017559	BEARING AXLE BODY		01
01C	0503010406	501025 CLAMPING RING (FOR AXLE)		02
01D	0551017540	5/8" X 73 AXLE HEX		01
01E	0501056296	UNIVERSAL JOINT		01
01F	0503011855	0.2" X 1.8" SPRING PIN		03
01G	0571012412	HEX AXLE		01
01H	0561014778	HEX UNIVERSAL JOINT		01
01I	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
00	0511056623	RIGHT REAR LINE SEED	54	01
01	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	56	01
02	0521042710	PNEUMATIC SEED DISTRIBUTOR	62	01
03	0503011404	BOLT		04
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503033124	SOCKET SEED		01




Item	Code	Description	See page	QT
00	0511056624	LEFT REAR LINE SEED	55	01
01	0511056586	15 X 15 SEED DDD LEFT	57	01
02	0521042710	PNEUMATIC SEED DISTRIBUTOR	62	01
03	0503011404	BOLT		04
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503033124	SOCKET SEED		01




Item	Code	Description	See page	QT
01	0511057606	PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX	63	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	DDD RITGH SUPREMA PRECISION PLANTING	58	01




Item	Code	Description	See page	QT
01	0511057606	PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX	63	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	59	01




Item	Code	Description	See page	QT
01	0511057249	PNEUMATIC SEAL DISTRIBUTOR WITH AXIS 65 STATION		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062390	SEED CONDUCTOR		01
06	0511057154	DDD RITGH SUPREMA PRECISION PLANTING	58	01




Item	Code	Description	See page	QT
01	0511057249	PNEUMATIC SEAL DISTRIBUTOR WITH AXIS 65 STATION		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062390	SEED CONDUCTOR		01
06	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	59	01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT		01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	61	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	60	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511015098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE		01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	61	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	60	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER		02
08	0503011443	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511015098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O-RING		02
14	0511011927	DUST CLOAK		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	60	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15	61	01
04	0503010026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501010984	FLAT WASHER		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012780	SUPPORT DDD RIGHT		01
11	0511015098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O-RING		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	60	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15	61	01
04	0503010026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501010984	FLAT WASHER		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012781	SUPPORT DDD LEFT		01
11	0511015098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02



Item	Code	Description	See page	QT
01	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01



Item	Code	Description	See page	QT
01	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0511050075	PNEUMATIC DISTRIBUTOR SUPPORT		01
01A	0501110649	INNER SUPPORT NEUMATIC SEED DISTR		01
01Aa	0502012599	PNEUMATIC SEED DISTRIBUTOR SUPPORT		01
01Ab	0503011770	SEAL # V-75 A		01
01Ac	0502012649	18Z CONICAL GEAR 34 TEETH		01
01Ad	0503011771	6008 2RS BALL BEARING		01
01B	0502050003	SUPPORT INTERNAL DISC SEED VULCANIZ		01
01C	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
01D	0503010143	1/4" SPRING WASHER		03
01E	0503012849	2-129 N 3006 9B O'RING		02
01F	0503010217	501040 CLAMPING RING (FOR AXLE)		01
01G	0503033121	PNEUMATIC SWITCH		01
01H	0503011295	M 8 X 1,25 X 25 BOLT		01
01I	0503010427	METRIC M8 X P.0.5" NUT		01
02	0503015536	M6 X 1" SELF ADJUSTING NUT		01
03	0503033800	PNEUMATIC JOINT SEALING		03
04	0511053902	CARDAN WHIT SUPPORT	71	01
05	0503011294	M 8 X 1,25 X 20 BOLT		03
06	0503010025	3/8" SPRING WASHER		03
07	0503011370	DISC 6440 MIDDLE SOYBEAN		01
08	0501058950	SEED SYSTEM SIDE		01
08A	0561012486	LATERAL COVER		01
09	0511017186	SEED LEVEL REGULATOR		01
10	0511017303	FLAT WASHER		04
11	0503011776	M6 SELF ADJUSTINGNUT		01
12	0503014141	M6 X 1 X 20 BOLT		01
13	0503011817	UPPER SELECTOR		01
14	0502020559	UPPER SELECTOR ACTUATOR		01
15	0531014481	0.2" X 0.6" AXLE		01
16	0503011821	CRINKLE WASHER		01
17	0503011823	0.1" X 0.6" SPRING PIN		02

PNEUMATIC SEED DISTRIBUTOR

0521042710

Item	Code	Description	See page	QT
18	0511017219	SCALE INDICATOR GUIDE		01
19	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
20	0503010143	1/4" SPRING WASHER		03
21	0503011810	M6 X 1" BUTTERFLY BOLT		01
22	0503031058	UPPER SELECTOR SCALE		01
23	0503011825	M4 X 8" BOLT		02
24	0503011840	FLAT WASHER		02
25	0501110311	LOWER SELECTOR ASSY		01
26	0503011813	M6 X 1.2" BOLT		01
27	0511016220	LOWER SELECTOR INDICATOR		01
28	0503011815	TOOTHED WASHER		01
29	0503012445	M6 C/ABA 1.20" BUTTERFLY NUT		04
30	0503013179	PNEUMATIC SEED DISTRIBUTOR VISOR		01
31	0561012741	SEED DRAINER COVER		01
32	0503011809	M12 KNOB		01
33	0503011828	FLAT WASHER		01
34	0503011827	504.100 CLAMPING RING (FOR HOLE)		01
35	0503011104	M6 X 1" BOLT		02
36	0503011820	CRINKLE WASHER		02
37	0511017199	PST SUP AXLE		01
38	0511017198	SCALE INDICATOR		01




Item	Code	Description	See page	QT
01	0511057502	SET PRECISION PLANTING	70	01
02	0502012807	SUPPORT BOX PRECISION PLANTING		01
03	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
04	0503037390	PACKING FOR PLANTING		01
05	0571017899	PIN LOCK PP		01
06	0503030190	0.5" X 1.6" X 0.05" SPRING		01
07	0571014024	FAST BOLT GUIDE AXLE		02
08	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
09	0502012786	FAST LOCK PRECISION PLANTING		01
10	0511057155	PRECISION PLANTING LEFT TRANSMISSION BOX		01
10A	0502050053	RIGHT SIDE TRANSMISSION BOX PP		01
10B	0502050052	LEFT SIDE TRANSMISSION BOX PP		01
10C	0503033975	24Z GEAR PNEUMATIC		01
10D	0571017898	BODY GEAR TRANSMISSION		01
10E	0503011410	ROLLER BEARING		02
10F	0503033976	GEAR 6Z PNEUMATIC 2014		01
10G	0503011182	6203 ROLLER BEARING		02
10H	0571016187	PINION AXLE 6Z PNEUMATIC		01
10I	0503011184	502040 CLAMPING RING (FOR AXLE)		01
10J	0571017655	SLEEVE FIXER HITCH PNEUMATIC		01
10K	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
10L	0503010144	1/4" NUT		03
11	0571017894	PIN DRAG PRECISION PLANTING		01
12	0503013357	3/8" SELF-ADJUSTING NUT		01
13	0503015752	3/8" X 2" BOLT		01
14	0501013518	FLAT WASHER		02
15	0503015356	SPRING PIN		01
16	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
17	0571017895	PIN FIXER CONDUCTOR P.P		01
18	0503011776	M6 SELF ADJUSTINGNUT		03
19	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02

PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX



0511057606

Item	Code	Description	See page	QT
20	0503010293	BAQUELITE MANIPULACION		01
21	0503010140	1/8" X 3/4" COTTERPIN		03
22	0503010131	3/16" X 1-1/2" COTTERPIN		01
23	0503010025	3/8" SPRING WASHER		01
24	0571011803	PRISONER CLOSE FAST		01
25	0571019491	SLUICE PNEUMATIC PRECISION PLANTING		01
26	0501011643	3/8 X 1"BOLT		01
27	0503010209	3/8" UNC BUTTERFLY NUT		01
28	0503012721	1/4" X 4" BOLT		01
29	0503012880	1/4" UNC SELF ADJUSTING NUT		01
30	0571011804	FAST BOLT ADJUSTMENT		01
31	0571019489	CLAMP PRECISION PLANTING		01
32	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
33	0503011855	0.2" X 1.8" SPRING PIN		02
34	0561014778	HEX UNIVERSAL JOINT		01
35	0503013958	1/4" X 1" BOLT		02
36	0503011855	0.2" X 1.8" SPRING PIN		01
37	0503818139	M6 BOLT		03
38	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
39	0503015110	M06 SPRING WASHER		02
40	0501056296	UNIVERSAL JOINT		01
41	0571012452	HEX AXLE		01
42	0511057491	PRECISION PLANTING SEED ASSY SEED 64 DISTRIBUTOR WITH CORN DISC		01
42A	0503062405	SEED DISTRIBUTOR		01
42B	0503062407	SET SOYBEAN DISTRIBUTION		01
42B-01	0503062417	KIT CORN DISTRIBUTION		01
42B-02	0503062471	DISTRIBUTION ASSY (SORGHUM / MILLET)		01
42B-03	0503062577	DISTRIBUTION ASSY (LARGE CORN / SUNFLOWER)		01
42B-04	0503062578	DISTRIBUTION ASSY (LARGE CORN)		01
42B-05	0503062579	DISTRIBUTION ASSY (CORN / SUNFLOWER)		01
42B-06	0503062580	DISTRIBUTION ASSY (POPCORN / COTTON)		01
42B-07	0503062581	DISTRIBUTION ASSY (SMALL CORN / POP CORN)		01
42B-08	0503062573	CONVERSATION SET FOR DISTRIBUTION (LARGE BEAN)		01
42B-09	0503062574	CONVERSATION SET FOR DISTRIBUTION (SMALL BEET)		01
42B-10	0503062564	CONVERSATION SET FOR DISTRIBUTION (SOYBEAN / BEAN)		01
42C	0571019613	STRAW PRECISION PLANTING SHIELD		01




Item	Code	Description	See page	QT
01	0503062405	SEED DISTRIBUTOR	01	
01A	0503062567	FIXED BASE SEEDS DISTRIBUTOR	01	
01AA	0503018908	BODY FIXED BASE DISTRIBUTOR SEED	01	
01AB	0503018909	COVER CONDUCTOR DISTRIBUTOR SEED	01	
01AC	0503062652	SEED INPUT DEFLECTOR	01	
01AD	0503062653	FULL COVER	01	
01AE	0503018910	RIVETS LARGEST	01	
01AF	0503018911	SPACING BUSHING	01	
01AG	0503018912	BOLT	03	
01AH	0503018476	SPRING	01	
01AI	0503018474	LOWER BRUSH	01	
01AJ	0503018475	TOP BRUSH	01	
01AK	0503018157	RUBBER	01	
01AL	0503018477	LOCK SPRING	01	
01B	0503062568	FIXER MOBILE	01	
01BA	0503018919	BASE	01	
01BB	0503018913	RIVET	01	
01BC	0503018914	WASHER	01	
01BD	0503018915	BEARING	02	
01BE	0503062654	BEARING	01	
01BF	0503018916	ADJUSTMENT CHOCK	03	
01BG	0503018917	RING	01	
01BH	0503018918	CHOCK	02	
01BI	0503019288	RUBBER SEAL PP 730518	01	
01BJ	0503018478	SPRING	01	
01BK	0503018920	SEALING	01	
01BL	0503018479	TUBE	01	
01BM	0503018735	PROTECTIVE COVER	01	
01BN	0503018921	BOLT	06	
01BO	0503018922	BOLT	02	
01BP	0503018480	REGULATOR PIN	01	


Item	Code	Description	See page	QT
01BQ	0503018923	ADAPTER		01
01BR	0503018924	SPRING PIN		01
02	0503062417	KIT CORN DISTRIBUTION		01
02A	0503018160	CORN PLASTIC DISC		01
02B	0503062472	SELECTOR SEED CORN		01
02C	0503062474	EJECTOR CORN SEED SET		01
03	0571019613	STRAW PRECISION PLANTING SHIELD		01
03A	0503017957	PROTECTIVE COVER AIR INPUT		01




Item	Code	Description	See page	QT
01	0511055633	PNEUMATIC DISTRIBUTOR 2014 USAP G2 APOS 66 05/15	66	01
02	0501056296	UNIVERSAL JOINT		01
03	0571018555	170 HEX AXLE SEED		01
04	0503011855	0.2" X 1.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0511055631	SUPPORT PNEUMATIC	67	01
02	0511055624	COVER SYTEM PNEUMATIC	68	01
03	0511058626	SOYBEAN DISC 7040		01
04	0503033839	STIRRER SEED PNEUMATIC DISTRIBUTOR		01
05	0503017375	1/2" X 1-1/4" BOLT		01




Item	Code	Description	See page	QT
001	0503011183	6007 ROLLER BEARING		01
002	0503010246	CLAMP		01
003	0503017374	M6 X 1" BOLT		03
004	0502012761	SUPPORT PNEUMATIC		01
005	0503033978	FASTENER JOINT RUBBER		02
006	0503033977	GASKET PNEUMATIC		01
007	0503033958	PROTECTION COVER SOCKET PNEUMATIC		01
008	0502050020	SUPPORT DISC PNEUMATIC		01
009	0503033974	ELBOW SUCTION PNEUMATIC		01
010	0503017372	BOLT M6 X 1 X 65		03
011	0511055632	BOX TRANSMISSION PNEUMATIC	69	01
012	0503017373	BOLT		01
013	0521065278	STRAW SHIELD PNEUMATIC		01
014	0503017868	BOLT		01
015	0503012722	0.16" X 0.4" BLIND RIVET		02
016	0503010179	5/16" ZN SPRING WASHER		04
017	0571014024	FAST BOLT GUIDE AXLE		02
018	0502012744	SPEED LOCK LEVER ASSY		01
019	0571011804	FAST BOLT ADJUSTMENT		01
020	0571011803	PRISONER CLOSE FAST		01
021	0503010140	1/8" X 3/4" COTTERPIN		04
022	0503010025	3/8" SPRING WASHER		01
023	0503010849	3/8" X 1-1/2" BOLT		01
024	0571018506	SLEEVE SUPPORT		01
025	0571018508	SEED BOX BASE AXLE		01
026	0571018507	FIXER OF PROTECTION		01



Item	Code	Description	See page	QT
001	0501110311	LOWER SELECTOR ASSY		01
002	0502050051	COVER KIT PNEUMATIC		01
003	0503033959	SELECTOR PNEUMATIC		01
004	0503033957	DISPLAY		01
005	0503033960	DRAINER PNEUMATIC		01
006	0571016191	SLUICE DOSER PNEUMATIC		01
007	0571016189	REGULATOR PNEUMATIC		01
008	0571016188	ADJUSTMENT AXLE SELECTOR PNEUMATIC		01
009	0503010846	0.31" X 0.55" 701179 SPRING PIN		02
010	0503011776	M6 SELF ADJUSTINGNUT		01
011	0571016520	FIXER SLUICE VALVE PNEUMATIC		01
012	0571016202	DISPLAY REGULATOR		01
013	0503015536	M6 X 1" SELF ADJUSTING NUT		02
014	0571017273	REGULATOR SELECTOR PNEUMATIC		01
015	0571017267	POSITIONER RADIUS PNEUMATIC		01
016	0503012722	0.16" X 0.4" BLIND RIVET		04
017	0571018556	DISPLAY REGULATOR		01
018	0503017868	BOLT		01
019	0503017869	M6 X 1" BOLT		01
020	0503017374	M6 X 1" BOLT		03



Item	Code	Description	See page	QT
01	0503011183	6007 ROLLER BEARING	01	
02	0503011182	6203 ROLLER BEARING	02	
03	0502050050	BOX TRANSMISSION	01	
04	0503033975	24Z GEAR PNEUMATIC	01	
05	0503033976	GEAR 6Z PNEUMATIC 2014	01	
06	0571016187	PINION AXLE 6Z PNEUMATIC	01	
07	0503011184	502040 CLAMPING RING (FOR AXLE)	01	
08	0503010845	501035 CLAMPING RING (FOR AXLE)	02	
09	0571017655	SLEEVE FIXER HITCH PNEUMATIC	01	



Item	Code	Description	See page	QT
01	0502012807	SUPPORT BOX PRECISION PLANTING		01
01A	1902012807	SEED BOX SUPPORT		01
02	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
03	0571017899	PIN LOCK PP		01
04	0503030190	0.5" X 1.6" X 0.05" SPRING		01
05	0571014024	FAST BOLT GUIDE AXLE		02
06	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
07	0581011225	FIXER P PLANTING CONTR CPRA		01
08	0511057155	PRECISION PLANTING LEFT TRANSMISSION BOX		01
09	0571017894	PIN DRAG PRECISION PLANTING		01
10	0503013357	3/8" SELF-ADJUSTING NUT		01
11	0503015752	3/8" X 2" BOLT		01
12	0501013518	FLAT WASHER		02
13	0503015356	SPRING PIN		01
14	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
15	0571017895	PIN FIXER CONDUCTOR P.P		01
16	0503011776	M6 SELF ADJUSTINGNUT		03
17	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
18	0503010293	BAQUELITE MANIPULACION		01
19	0503010140	1/8" X 3/4" COTTERPIN		03
20	0503010131	3/16" X 1-1/2" COTTERPIN		01
21	0503010025	3/8" SPRING WASHER		01
22	0503037390	PACKING FOR PLANTING		01
23	0571019491	SLUICE PNEUMATIC PRECISION PLANTING		01
24	0501011643	3/8 X 1"BOLT		01
25	0503010209	3/8" UNC BUTTERFLY NUT		01
26	0503012721	1/4" X 4" BOLT		01
27	0503012880	1/4" UNC SELF ADJUSTING NUT		01
28	0581011226	FIXER CLOSING P PLANTING CONTR CPRA		01
29	0571019489	CLAMP PRECISION PLANTING		01
30	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01


SET PRECISION PLANTING

0511057502


Item	Code	Description	See page	QT
31	0511057491	PRECISION PLANTING SEED ASSY SEED 64 DISTRIBUTOR WITH CORN DISC		01
31A	0503062405	SEED DISTRIBUTOR		01
31B	0503062407	SET SOYBEAN DISTRIBUTION		01
31B-01	0503062417	KIT CORN DISTRIBUTION		01
31B-02	0503062471	DISTRIBUTION ASSY (SORGHUM / MILLET)		01
31B-03	0503062577	DISTRIBUTION ASSY (LARGE CORN / SUNFLOWER)		01
31B-04	0503062578	DISTRIBUTION ASSY (LARGE CORN)		01
31B-05	0503062579	DISTRIBUTION ASSY (CORN / SUNFLOWER)		01
31B-06	0503062580	DISTRIBUTION ASSY (POPCORN / COTTON)		01
31B-07	0503062581	DISTRIBUTION ASSY (SMALL CORN / POP CORN)		01
31B-08	0503062573	CONVERSATION SET FOR DISTRIBUTION (LARGE BEAN)		01
31B-09	0503062574	CONVERSATION SET FOR DISTRIBUTION (SMALL BEET)		01
31B-10	0503062564	CONVERSATION SET FOR DISTRIBUTION (SOYBEAN / BEAN)		01
32	0561014778	HEX UNIVERSAL JOINT		01
33	0503013958	1/4" X 1" BOLT		02
34	0503818139	M6 BOLT		03
35	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
36	0503015110	M06 SPRING WASHER		02

CARDAN WHIT SUPPORT


0511053902



Item	Code	Description	See page	QT
01	0502012738	SUPPORT CARDAN		01
02	0571012413	POINT TRANSMISSION		01
03	0502012648	10Z CONICAL GEAR		01
04	0503015356	SPRING PIN		01
05	0501056296	UNIVERSAL JOINT		01
06	0571012411	HEX AXLE		01
07	0503011855	0.2" X 1.8" SPRING PIN		02
08	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503031508	COVER GREEN BEAM SEED YELLOW		01
02	0502012798	SUPPORT BOX SEED		01
03	0521065830	SUPPORT BASE SYSTEM PNEUMATIC		01
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
05	0503010025	3/8" SPRING WASHER		05
06	0503010026	3/8" NUT		04
07	0571018513	SLUICE PNEUMATIC		01
08	0571018512	GUIDE SLUICE PNEUMATIC		01
09	0501011643	3/8 X 1"BOLT		01
10	0501010984	FLAT WASHER		01
11	0503010209	3/8" UNC BUTTERFLY NUT		01
12	0503010358	5/16" X 5/8" BOLT		04
13	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
14	0503010179	5/16" ZN SPRING WASHER		04
15	0503010337	5/16" NUT		04



Item	Code	Description	See page	QT
01	0502012798	SUPPORT BOX SEED		01
02	0581012694	COMPACT PROTECTION		01
03	0503010849	3/8" X 1-1/2" BOLT		03
04	0501010096	3/8" X 2" BOLT		01
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0503031508	COVER GREEN BEAM SEED YELLOW		01
08	0503010358	5/16" X 5/8" BOLT		04
09	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
10	0503010179	5/16" ZN SPRING WASHER		04
11	0503010337	5/16" NUT		04

PRESS WHEELS

0521045198




Item	Code	Description	See page	QT
01	0511056691	CONTROL DEPTH SUPPORT		01
01A	0502012282	DEPTH CONTROL SUPPORT		01
02	0571016886	DEPTH WHEEL AXLE		01
03	0503810256	SCREW		01
04	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
05	0503033942	COVER REGULATORY WHEEL		01
06	0521064073	REGULACION WHEEL COMPACTOR		01
07	0511056692	DEPTH WHEEL RIGHT ARM		01
07A	0501110796	DEPTH CONTROL RIGHT ARM		01
07Aa	0502012769	BRACO DIR RODA PROF		01
07Ab	0571016883	GLOVE NYLON		01
07B	0501052627	ASSY DEPTH WHEEL BOX	81	02
07Ba	0502011907	DEPTH CONTROL WHEEL HUB		02
07Bb	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		02
07Bc	0503010269	6204 BALL BEARING		04
07Bd	0501013636	SPACING SLEEVE		02
07Be	0503010689	SEAL 00763-BR		02
07Bf	0503011105	SEAL RING		02
07Bg	0503010878	5/8" SELF ALIGNING NUT		02
07Bh	0521019178	COVER DEPTH		02
07bi	0503030757	2.9" X 2" X 0.02" JOINT		02
07Bj	0503014729	1/4" UNF X 1/2" BOLT		06
07Bk	0503011441	SPRING WASHER		06
07Bl	0503010691	1/4" GREASE FITTING		02
07C	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07D	0503011440	SPRING WASHER		02
07E	0503010060	1/2" NUT		02
07F	0503010002	1800 GREASE FITTING		02
08	0511056693	LH ARM DEPTH CONTROL WHEEL		01
08A	0501110797	ARM LEFT GLOVE WITH DEPTH CONTROL		01
08Aa	0502012770	LEFT ARM WHEEL DEPTH		01


PRESS WHEELS

0521045198


Item	Code	Description	See page	QT
08Ab	0571016883	GLOVE NYLON		01
09	0571017749	FLAT WASHER		02
10	0503011440	SPRING WASHER		02
11	0503010311	1/2" X 1-1/4" BOLT		02
12	0501052297	DEPTH WHEELS REGULATOR ASSY		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010257	1/8" X 1" COTTERPIN		01
15	0502012116	PRESS WHEEL ADJUSTER		01
16	0503010849	3/8" X 1-1/2" BOLT		02
17	0503011443	3/8" SPRING WASHER		02
18	0503010026	3/8" NUT		02
19	0541016906	PRESS WHEELS REGULATOR BODY		01
20	0521010539	0.3" X 1.2" COUPLING SHAFT		01
21	0503010140	1/8" X 3/4" COTTERPIN		01
22	0503030805	1.6" X 6" X 0.2" TRACTION SPRING		01
23	0501052538	DEPTH BAND WITH ARMS		02
24	0503010358	5/16" X 5/8" BOLT		08
25	0503010179	5/16" ZN SPRING WASHER		08
26	0503013816	5/16" LOCKNUT		08
27	0511054333	COMPACT WHEEL RIGHT WITH BEARING	116	01
28	0511054334	COMPACT WHEEL LEFT WITH BEARING	118	01




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	76	01
02	0501052538	DEPTH BAND WITH ARMS		02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	116	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	118	01
07	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	77	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	78	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY		01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2"TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	SCREWEW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL BOX	81	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL BOX	81	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503011440	SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	86	01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503011440	SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521061153	LONG ARM FERTILIZER LINE		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	85	01



Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	COVER DEPTH		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	DIR	ESQ
01	0511054333	COMPACT WHEEL RIGHT WITH BEARING	116	01	00
02	0511054334	COMPACT WHEEL LEFT WITH BEARING	118	00	01
03	0501052908	COMPACTOR WHEEL WITH BEARING	117	01	01
03A	0502011919	PRESS WHEEL HUB		01	01
03B	0502011877	PRESS WHEEL HUB		01	01
03C	0503010269	6204 BALL BEARING		02	02
03D	0521018922	PRESS WHEEL PASSANG AXLE		02	02
03E	0503012734	SEAL 01556 BR		02	02
03F	0521018921	DUST CLOAK		02	02
03G	0503010691	1/4" GREASE FITTING		01	01
03H	0521018928	PRESS WHEEL RIM		02	02
03I	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01	01
03J	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06	06
03K	0503010179	5/16" ZN SPRING WASHER		09	09
03L	0503010337	5/16" NUT		06	06
03M	0503010371	5/16" X 1" BOLT		03	03
03N	0503013816	5/16" LOCKNUT		03	03
04	0503016449	1/2 X 4 BOLT		01	00
05	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		00	01
06	0521014508	FLAT WASHER		03	03
07	0503012136	NUT 1/2 NF		01	00
08	0503016864	LH 1/2" LOCK NUT		00	01




Item	Code	Description	See page	QT
01	0511053251	ARM LONG FERTILIZER LINE WITH DDD RIGHT	80	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		02
06	0511058618	DISC CUT 18 LONG LINE		01
07	0501058423	FERTILIZER ROD SPRING ROW	92	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02
11	0503031050	CURVED CONDUCTOR		01
12	0503010246	CLAMP		01
13	0511061769	RIGHT FERTILIZER CONDUCTOR WITH REGULATOR		01
14	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
15	0511017969	0.1" SPACING PLATE		02
16	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
17	0501010984	FLAT WASHER		04
18	0503010025	3/8" SPRING WASHER		02
19	0503010026	3/8" NUT		02

SHORT LINE FERTILIZER LEFT


0909091822




Item	Code	Description	See page	QT
01	0511053250	SHORT ARM FERTILIZER LINE WITH DDD LEFT	79	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		02
06	0511058617	DISC CUT 18 SHORT LINE		01
07	0501058423	FERTILIZER ROD SPRING ROW	92	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02
11	0503031050	CURVED CONDUCTOR		01
12	0503010246	CLAMP		01
13	0511061770	LEFT CONDUCTOR FERTILIZER WITH REGULATOR		01
14	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
15	0511017969	0.1" SPACING PLATE		02
16	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
17	0501010984	FLAT WASHER		04
18	0503010025	3/8" SPRING WASHER		02
19	0503010026	3/8" NUT		02



Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	61	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	60	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RH DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	60	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	61	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RH DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503011443	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01



Item	Code	Description	See page	QT
01	0571015538	SLEEVE 37 X 28,3 X 16,70	01	
02	0503012412	5/8 UNC SELF LOCKING NUT	01	
03	0503010691	1/4" GREASE FITTING	01	
04	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
05	0511017302	FLAT WASHER	04	
06	0503010384	1/2" X 5" BOLT	02	
07	0503010547	1/2" X 4" BOLT	02	
08	0503010417	7/8" NUT	01	
09	0503033624	35 X 215 X 7,14 COMPRES SPRING	01	
10	0521064736	FERTILIZER SOCKET	01	
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	02	
12	0501010984	FLAT WASHER	04	
13	0503010025	3/8" SPRING WASHER	02	
14	0503010026	3/8" NUT	02	
15	0521064739	ROD SUPPORT	01	
16	0571015616	GUIDE SPRING SUPPORT	01	
17	0571015552	BOLT FIXER	01	
18	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN	01	
19	0503034106	80 X 230 X 16,50 HDA COMPRESSION SPRING	01	
20	0511058935	ROD WITH POINT FLANGE WASHER SPRING HDA	01	

18" COULTER BLADE ASSY FOR SHORT ROW

0511044549



Item	Code	Description	See page	QT
01	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01	
02	0502012368	BLADE DISC SUPPORT AXLE	01	
03	0503010756	0.2" X 2.4" SPRING PIN	01	
04	0503010361	SPRING PIN	01	
05	0541018684	FLAT WASHER	01	
06	0521014137	RIGHT ARM OF THE BLADE DISC	01	
07	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
08	0501067323	SPRING REGULATOR	01	
09	0521010452	SLEEVE	01	
10	0503013185	3/4" X 5-1/2" BOLT	01	
11	0503011255	3/4" LOCK NUT	01	
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
13	0503011411	1/2" X 5-1/2" BOLT	01	
14	0503011440	SPRING WASHER	01	
15	0503010060	1/2" NUT	01	
16	1902020393	SPRING UPPER SUPPORT	01	
17	0502020394	SPRING SUPPORT	01	
18	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
19	0503010014	3/4" NUT	02	
20	0521015376	DUST CLOAK	02	
21	0502011562	DC PST ACT/ULTR BOX	01	
22	0503010276	6206 BALL BEARING	02	
23	0521013610	BLADE DISC HUB AXLE	01	
24	0503030832	FLAT WASHER	02	
25	0503012417	SEAL	02	
26	0503011800	SEAL RING	02	
27	0503010691	1/4" GREASE FITTING	01	
28	0603026013	PLAIN COULTER BLADE	01	
29	0502020641	BLADE DISC FLANGE	01	
30	0503010371	5/16" X 1" BOLT	06	
31	0503011444	SPRING WASHER	06	


**18" COULTER BLADE ASSY FOR SHORT ROW**

0511044549

Item	Code	Description	See page	QT
32	0503010337	5/16" NUT		06
33	0511815346	FLAT WASHER		02
34	0503011442	3/4" SPRING WASHER		02
35	0521813510	R3/4UNC NUT		02
36	0503010003	1845 GREASE FITTING		01

18" COULTER BLADE ASSY FOR LONG ROW

0511044573




Item	Code	Description	See page	QT
01	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE	01	
02	0502012368	BLADE DISC SUPPORT AXLE	01	
03	0503010756	0.2" X 2.4" SPRING PIN	01	
04	0503010361	SPRING PIN	01	
05	0541018684	FLAT WASHER	01	
06	0521014137	RIGHT ARM OF THE BLADE DISC	01	
07	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
08	0501067323	SPRING REGULATOR	01	
09	0521010452	SLEEVE	01	
10	0503013185	3/4" X 5-1/2" BOLT	01	
11	0503011255	3/4" LOCK NUT	01	
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
13	0503011411	1/2" X 5-1/2" BOLT	01	
14	0503011440	SPRING WASHER	01	
15	0503010060	1/2" NUT	01	
16	0502020393	SPRING UPPER SUPPORT	01	
17	0502020394	SPRING SUPPORT	01	
18	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
19	0503010014	3/4" NUT	02	
20	0521015376	DUST CLOAK	02	
21	0502011562	DC PST ACT/ULTR BOX	01	
22	0503010276	6206 BALL BEARING	02	
23	0521013610	BLADE DISC HUB AXLE	01	
24	0503030832	FLAT WASHER	02	
25	0503012417	SEAL	02	
26	0503011800	SEAL RING	02	
27	0503010691	1/4" GREASE FITTING	01	
28	0603026013	PLAIN COULTER BLADE	01	
29	0502020641	BLADE DISC FLANGE	01	
30	0503010371	5/16" X 1" BOLT	06	
31	0503010179	5/16" ZN SPRING WASHER	06	




18" COULTER BLADE ASSY FOR LONG ROW

0511044573

Item	Code	Description	See page	QT
32	0503010337	5/16" NUT		06
33	0511015346	FLAT WASHER		02
34	0503010023	3/4" SPRING WASHER		02
35	0521013510	3/4" NUT		02
36	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	
02	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01	
03	0541018684	FLAT WASHER	01	
04	0503010756	0.2" X 2.4" SPRING PIN	01	
05	0503010361	SPRING PIN	01	
06	0503010003	1845 GREASE FITTING	01	
07	0521014137	RIGHT ARM OF THE BLADE DISC	01	
08	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503013185	3/4" X 5-1/2" BOLT	01	
12	0503011255	3/4" LOCK NUT	01	
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
14	0503011411	1/2" X 5-1/2" BOLT	01	
15	0503011440	SPRING WASHER	01	
16	0503010060	1/2" NUT	01	
17	0502020393	SPRING UPPER SUPPORT	01	
18	0502020394	SPRING SUPPORT	01	
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
20	0503010014	3/4" NUT	02	
21	0501054887	20 BLADE DISC WITH FLAT PLAN DISC	01	
22	0521015376	DUST CLOAK	02	
23	0511015346	FLAT WASHER	06	
24	0503011442	3/4" SPRING WASHER	02	
25	0521013510	3/4" NUT	02	
26	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN	02	




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	
02	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE	01	
03	0541018684	FLAT WASHER	01	
04	0503010756	0.2" X 2.4" SPRING PIN	01	
05	0503010361	SPRING PIN	01	
06	0503010003	1845 GREASE FITTING	01	
07	0521014137	RIGHT ARM OF THE BLADE DISC	01	
08	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503013185	3/4" X 5-1/2" BOLT	01	
12	0503011255	3/4" LOCK NUT	01	
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
14	0503011411	1/2" X 5-1/2" BOLT	01	
15	0503011440	SPRING WASHER	01	
16	0503010060	1/2" NUT	01	
17	0502020393	SPRING UPPER SUPPORT	02	
18	0502020394	SPRING SUPPORT	01	
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
20	0503010014	3/4" NUT	02	
21	0501054887	20 BLADE DISC WITH FLAT PLAN DISC	01	
22	0521015376	DUST CLOAK	02	
23	0511015346	FLAT WASHER	06	
24	0503011442	3/4" SPRING WASHER	02	
25	0521013510	3/4" NUT	02	
26	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN	02	

FERTILIZER ROD SPRING ROW


0501058423



Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD		01
02	0502040534	SPRING GUIDE BUSHING LOCK		02
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502012510	SPRING ROD SUPPORT		01
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		01
07	0501018535	1/2 X 1 BOLT		02
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
09	0503010060	1/2" NUT		02
10	1902010891	SPRING CHOCK SUPPORT VARON		01
11	0503010014	3/4" NUT		01
12	0561014471	COUPLING SHAFT		01
13	0511017302	FLAT WASHER		01
14	0503010257	1/8" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0511058838	DC TURBO BOX 20 TURBO	103	01
02	0502012816	CUTTING DISC SUPPORT		01
03	0503010002	1800 GREASE FITTING		01
04	0571019976	LEFT BRACELET CUTTING DISC		01
05	0503011411	1/2" X 5-1/2" BOLT		01
06	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2" NUT		01
09	0502020394	SPRING SUPPORT		01
10	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
11	0502020393	SPRING UPPER SUPPORT		01
12	0503011255	3/4" LOCK NUT		02
13	0581011111	WASHER BRACKET AXIS DC PST		01
14	0503034319	LOCK PIN		01
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01
17	0501067323	SPRING REGULATOR		01
18	0521010452	SLEEVE		01
19	0503013185	3/4" X 5-1/2" BOLT		01



Item	Code	Description	See page	QT
01	0511058838	DC TURBO BOX 20 TURBO	103	01
02	0502012816	CUTTING DISC SUPPORT		01
03	0503010002	1800 GREASE FITTING		01
04	0571019976	LEFT BRACELET CUTTING DISC		01
05	0503011411	1/2" X 5-1/2" BOLT		01
06	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2" NUT		01
09	0502020394	SPRING SUPPORT		01
10	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
11	0502020393	SPRING UPPER SUPPORT		01
12	0503011255	3/4" LOCK NUT		02
13	0581011111	WASHER BRACKET AXIS DC PST		01
14	0503034319	LOCK PIN		01
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0502012824	FIXING SHAFT DISC CUT LINE		01
17	0501067323	SPRING REGULATOR		01
18	0521010452	SLEEVE		01
19	0503013185	3/4" X 5-1/2" BOLT		01

MECANIC ROW MARKER

0909093059




Item	Code	Description	See page	07	09	11
00	0511047234	MEC ROW MARKER ASSY PST4/FLEX SUP 7	02	00	00	
00.	0511047122	MEC ROW MARKER ASSY PST4/FLEX SUP 9	00	02	00	
00..	0511047207	MEC ROW MARKER ASSY PST4/FLEX SUP11	00	00	02	
01	0511069621	MECANIC ROW MARK SUPPORT	02	02	02	
02	0503012407	5/8" X 1-1/2" BOLT	08	08	08	
03	0503010027	5/8" SPRING WASHER	15	15	15	
04	0503012412	5/8 UNC SELF LOCKING NUT	13	13	13	
05	0551018204	RIGHT ROW MARKER FIXER	01	01	01	
06	0551018205	LH ROW MARKER FIXER	01	01	01	
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	06	06	06	
08	0501010984	FLAT WASHER	12	12	12	
09	0503010025	3/8" SPRING WASHER	08	08	08	
10	0503010026	3/8" NUT	08	08	08	
11	0521010549	COUPLING SHAFT	02	02	02	
12	0503030168	HAIR PIN	02	02	02	
13	0511060475	ROW MARKER ARM	01	01	01	
14	0511060576	LH ROW MARKER ARM	01	01	01	
15	0503010769	5/8" X 2-1/4" BOLT	04	04	04	
16	0521010479	SLEEVE ARTICULATION	04	04	04	
17	0501066949	1235 TURNBUCKLE	02	02	02	
18	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN	04	04	04	
19	0502010421	SIDE PULLEY	02	02	02	
20	0521010445	0.53" X 0.75" X 0.45" SLEEVE	02	02	02	
21	0521010641	COUPLING SHAFT	02	02	02	
22	0503010140	1/8" X 3/4" COTTERPIN	04	04	04	
23	0501058313	ROW MARKER PIVOT	01	01	01	
23A	0501065640	ROW MARKER ROD GUIDE	02	02	02	
23B	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN	02	02	02	
23C	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	02	02	02	
23D	0511017302	FLAT WASHER	06	06	06	
23E	0503010019	1/2" SPRING WASHER	13	13	13	

MECANIC ROW MARKER


0909093059

Item	Code	Description	See page	07	09	11
23F	0503010060	1/2" NUT		11	11	11
23G	0501065644	ROW MARKER ARM/DISARMENT ROD		01	01	01
23H	0501064229	REGULATOR ARM/DISARMENT ROD		01	01	01
23I	0501062547	ROW MARKER BAR REGULATOR		01	01	01
23J	0503010395	1/2" X 1-1/4" BOLT		01	01	01
23K	0521010454	0.83" X 1.25" X 0.79" SLEEVE		01	01	01
23L	0503010734	1/2" X 2-1/2" BOLT		01	01	01
23M	0521010539	0.3" X 1.2" COUPLING SHAFT		02	02	02
23N	0503010013	5/8" NUT		02	02	02
23O	0531010412	ROW MARKER ARM LOCK		02	02	02
23P	0503032995	STEEL CABLE		01	01	01
23Q	0501010096	3/8" X 2" BOLT		02	02	02
23R	0531010415	ROW MARKER ARM/DISARM GUIDE SLLEVE		04	04	04
23S	0501065642	ROW MARKER SUPPORT		01	01	01
23T	0502011231	CENTRAL PULLEY		03	03	03
23U	0521010693	PULLEY FIXER PLATE		01	01	01
23V	0511011308	BOLT		02	02	02
23W	0503010691	1/4" GREASE FITTING		02	02	02
23X	0503010232	5/8" X 1.3/4" BOLT		02	02	02
24	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01	01	01
25	0503011129	6,4 X 1900 CHAIN		02	02	02
26	0502011291	CHAIN SLEEVE		02	02	02
27	0503010683	0,2" X 1,2" SPRING PIN		02	02	02
28	0551019266	RIGHT PROTECTION COVER		01	01	01
29	0551019267	LEFT PROTECTION COVER		01	01	01
30	0503010920	1/2" X 1.1/2" BOLT		02	02	02
31	0551018955	1/2" X 1-1/2" BOLT		02	02	02
32	0501050633	MARKER DISC ASSY LINE	98	02	02	02
33	0521013164	EXTENSOR		02	02	02
34	0501011310	FIXER LOCK		02	02	02
35	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02	02	02




Item	Code	Description	See page	07	09	10
01	0511069622	ROW MARKER ARM SUPPORT		02	02	02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08	08	08
03	0503012412	5/8 UNC SELF LOCKING NUT		08	08	08
04	0503011070	BEATER		02	02	02
05	0503010019	1/2" SPRING WASHER		02	02	02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02	02	02
07	0551019213	FLAT WASHER		02	02	02
08	0501069470	ROW MARKER ARM		02	02	02
09	0521061655	BOLT 5/8 UNC X 320 MM		02	02	02
10	0521010479	SLEEVE ARTICULATION		04	04	04
11	0501012140	FLAT WASHER		04	04	04
12	0511058449	HYDRAULIC CYLINDER	99	02	02	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02	02	02
14	0503010523	1/4" X 2" COTTERPIN		04	04	04
15	0511015779	1" X 4.2" AXLE		02	02	02
16	0511017592	11.8" X 1.6" TRANSPORT LOCK		02	02	02
17	0501068994	0.3" X 3.1" LOCK PIN		02	02	02
18	0503030168	HAIR PIN		02	02	02
19	0501069643	890 TURNBUCKLE		02	02	02
20	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04	04	04
21	0511011311	VALVE SUPPORT		01	01	01
22	0503010232	5/8" X 1.3/4" BOLT		02	02	02
23	0503010027	5/8" SPRING WASHER		02	02	02
24	0503010013	5/8" NUT		02	02	02
25	0501054649	SEQUENTIAL VALVE ASSY	100	01	01	01
26	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02	02	02
27	0501010984	FLAT WASHER		02	02	02
28	0503010025	3/8" SPRING WASHER		02	02	02
29	0501080452	3/8" X 98" TR-TR HOSE		02	00	00
30	0501080401	3/8" X 106" TR-TC HOSE		02	00	00
31	0501080422	HOSE 3/8 X 4000 TC-TM		02	02	02


Item	Code	Description	See page	07	09	10
32	0501081727	TR-TR HOSE ASSY		00	02	00
33	0501080447	3/8" X 122" TR-TC HOSE ASSY		00	02	00
34	0501081729	HOSE 3/8 X 3125 TR-TR		00	00	02
35	0501081639	HOSE		00	00	02
36	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	97	02	02	02
37	0502012702	BODY SUPPORT CLAMP		04	04	04
38	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04	04	04
39	0503010180	7/16" SPRING WASHER		04	04	04
40	0503010244	7/16" NUT		04	04	04
41	0501050633	MARKER DISC ASSY LINE	98	02	02	02
42	0501012803	FLAT WASHER		02	02	02




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0511053904	DISC LINE MARKER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
001	0511058100	ENSEMBLE BOX UNIQUE SEED C3	102	01
002	0521066208	SUPPORT TOWER SILO		04
003	0501010942	3/8" X 1-1/4" BOLT		08
004	0501010984	FLAT WASHER		08
005	0503010025	3/8" SPRING WASHER		08
006	0503010026	3/8" NUT		08
007	0502010175	HITCH CLAMP		04
008	0501011543	5/8" X 4" BOLT		08
009	0501012140	FLAT WASHER		08
010	0503012412	5/8 UNC SELF LOCKING NUT		08




Item	Code	Description	See page	QT
001	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS	02	
002	0503061899	REAR BEAN FERTILIZER ASSY	02	
003	0521063401	SEED BOX ONLY FIXING LOCK	04	
004	0501010984	FLAT WASHER	04	
005	0503010025	3/8" SPRING WASHER	04	
006	0503010026	3/8" NUT	04	
007	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	09	
008	0501010942	3/8" X 1-1/4" BOLT	36	
009	0503010025	3/8" SPRING WASHER	36	
010	0503010026	3/8" NUT	36	
011	0571015773	CAP SUPPORT SEED BOX ONLY	03	
012	0501011643	3/8 X 1"BOLT	12	
013	0503010025	3/8" SPRING WASHER	12	
014	0503010026	3/8" NUT	12	



Item	Code	Description	See page	QT
01	0511056909	DISC BOX CUT WITHOUT THE DISC	104	01
02	0607026025	DPLO20X4,5		01




Item	Code	Description	See page	QT
01	0502012793	DC PST		01
02	0571018049	DOOR DUST		02
03	0571018047	AXLE DISC		01
04	0503017755	NUT		01
05	0502020641	BLADE DISC FLANGE		01
06	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
07	0503018441	5/16" X 1-1/4" BOLT		06
08	0503013816	5/16" LOCKNUT		06
09	0503010691	1/4" GREASE FITTING		01
10	0571018048	WASHER		02
11	0521065882	SEAL RING		02
12	0503010816	6207 RS ROLLER BEARING		02
13	0581010575	7/8" X 145 BOLT		01




Item	Code	Description	See page	QT
01	0511057700	HYDRAULIC TURBINE	106	01
02	0511057348	DISTRIBUTOR VACUUM	110	02
03	0503011372	102 TO 121 CLAMP		04
04	0521018615	HOSE 4 X 1300		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0503013584	VACUUM GAUGE		01
07	0503015062	TUBE		03
08	0571019978	SHAFT FIXER BODY		01
09	0571019979	SHAFT FIXER BODY		01
10	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
11	0503010019	1/2" SPRING WASHER		04
12	0503010060	1/2" NUT		04
13	0571012663	VACUUM GAUGE SUPPORT		01
14	0501013519	FLAT WASHER		08
15	0503010019	1/2" SPRING WASHER		08
16	0503010060	1/2" NUT		08
17	0571019963	AIR DISTRIBUTOR SUPPORT		04
18	0521014442	LOWER AIR DISTRIBUTOR SUPPORT		04
19	0503010363	5/16" X 1" BOLT		04
20	0503010179	5/16" ZN SPRING WASHER		04
21	0503010337	5/16" NUT		04
22	0571016669	CONECTOR CAPE		01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	FLAT WASHER		02
25	0503010025	3/8" SPRING WASHER		02
26	0503010026	3/8" NUT		02
27	0511057840	ASSY TURBINE HOSE REAR		02
27A	0501080477	HOSE 3/8 X 7012 TC-TM		01
27B	0501081247	HOSE 1/2 X 7012 TC-TM		02
28	0503031576	ELBOW		04
29	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02




Item	Code	Description	See page	QT
30	0501012140	FLAT WASHER		02
31	0503012412	5/8 UNC SELF LOCKING NUT		02




Item	Code	Description	See page	QT
01	0501054983	NIPPLE HIDRAULIC MOTOR	107	01
02	0503010025	3/8" SPRING WASHER		10
03	0503010026	3/8" NUT		08
04	0521044613	FAN 480 X 50 S (HIDRAULIC)	108	01
05	0503010143	1/4" SPRING WASHER		01
06	0503010849	3/8" X 1-1/2" BOLT		02
07	0531018764	FLAT WASHER		01
08	0503011104	M6 X 1" BOLT		01
09	0503012722	0.16" X 0.4" BLIND RIVET		20
10	0521065858	TURBIN SUPPORT		01
11	0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE	109	01
12	0561010634	VALVE SUPPORT ASSY		01
13	0503010237	3/8" X 1" BOLT		06
14	0503010206	3/8" X 1/2" BOLT		02
15	0571018577	COVER SNAIL TURBINE		01
16	0521066237	SNAIL MECHANICAL TURBINE HIDRAULIC		01
17	0503010358	5/16" X 5/8" BOLT		02
18	0503010179	5/16" ZN SPRING WASHER		02
19	0503010337	5/16" NUT		02
20	0501080125	HOSE 1/2 X 500 TR TR		02
21	0501080635	3/8" X 19" TR-TR HOSE		01
22	0521018517	FLAT WASHER		02
23	0503031649	CONECTOR CENTER		01




Item	Code	Description	See page	QT
01	0503012871	HYDRAULIC MOTOR		01
02	0531018770	R 3/4"UNF X R 1/4"BSP ELBOW		01
03	0561016941	3/4" NUT		01
04	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
05	0541011065	3/4"UNF X R1/4BSP19FPP X43.5 NIPPLE		01




Item	Code	Description	See page	QT
001	0571016947	DISC FRONT TURBINE		01
002	0571016949	DISC REAR TURBINE		01
003	0521065171	HUB FLANGE		01
004	0571016950	DISC STRENGTHENING TURBINE		01
005	0571016951	FLIP TURBINE		10
006	0503012651	M6 X 1" BOLT		05
007	0503010143	1/4" SPRING WASHER		05
008	0503011776	M6 SELF ADJUSTINGNUT		05




Item	Code	Description	See page	QT
01	0503012291	BLOCK COMMAND		01
02	0501010590	7/8" REDUCTION NIPPLE		04
03	0503010045	2-116 N 3006-9B O'RING		04
04	0541011066	3/4" UNF X 43.5 NIPPLE		01
05	0503010190	2-114 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0571017215	SOCKET DISTRIBUTOR AR		01
02	0503012566	COVER KAP 110 YELLOW		01
03	0503031943	SOCKET		05
04	0503012856	REBITE POP		10
05	0571019405	BODY DISTRIBUTOR VACUUM 4845/5345		01




Item	Code	Description	See page	QT
01	0511059406	TURBINE PRECISION PLANTING MOUNTED	112	01
02	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02
03	0501012140	FLAT WASHER		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0581011414	BODY RIGHT SUPPORT TURBINE		01
06	0581011413	SOPORTE IZQUIERDO CUERPO DE LA TURBINA		01
07	0581011415	SUPPORTER FIXING BAR		01
08	0503011239	1/2" X 2" BOLT		04
09	0511017302	FLAT WASHER		08
10	0503010019	1/2" SPRING WASHER		04
11	0503010060	1/2" NUT		04
12	0581012166	HOSE		02
13	0503011372	102 TO 121 CLAMP		02
14	0521050261	DISTRIBUTOR AIR CENTER 08 MOUTHS - 19 A 21	113	01
15	0511059319	AIR FIXING SUPPORT	114	04
16	0511057906	HOSE ASSY		01
16A	0511057840	ASSY TURBINE HOSE REAR		01
16AA	0501081247	HOSE 1/2 X 7012 TC-TM		02
16AB	0501080477	HOSE 3/8 X 7012 TC-TM		01
16B	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	97	02
16C	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
16D	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN		01
17	0571013731	VACUUM GAUGE SUPPORT		01
18	0503013584	VACUUM GAUGE		01
19	0571019716	ADAPTER		07
20	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		07
21	0503031436	AIR DITRIBUTOR PUMP		01
22	0503010246	CLAMP		01




Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE		01
02	0501011460	7/8 NF REDUCTION NIPPLE		04
03	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
04	0503010392	2-046 N 3006 9B O'RING		01
05	0581012096	ROUND SLEEVE		02
06	0503015420	VALVE ANTI-CAVITACAO CV10208TN5		01
07	0521050154	TURBINE PRECISION PLANTING WITH HOLE		01
08	0503011372	102 TO 121 CLAMP		02
09	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
10	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
11	0503010143	1/4" SPRING WASHER		02
12	0503010144	1/4" NUT		02
13	0503010190	2-114 N 3006-9B O'RING		04
14	0501081235	1/2 X 650 TR- TC HOSE		01




Item	Code	Description	See page	QT
01	0571018559	WHITE PVC TUBE		02
02	0503031943	SOCKET		08
03	0503012856	REBITE POP		16
04	0503012567	T-JOIN FOR TUBE 110		02
05	0521015543	DUTO 110 X 55		02
06	0503012566	COVER KAP 110 YELLOW		02
07	0571019406	BODY DISTRIBUTOR VACUUM		01
08	0561017670	BODY DISTRIBUTOR AR		02




Item	Code	Description	See page	QT
01	0571019403	STAPLE FIXER		01
02	0503010025	3/8" SPRING WASHER		04
03	0503010026	3/8" NUT		04
04	0501013518	FLAT WASHER		02
05	0571019921	AIR SUPPORT FIXATION		01
06	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0521062253	RIGHT PRESS WHEEL FERT UP SUPPORT		01
02	0511064128	PRESS SUPPORT LOWWER WHEEL		01
03	0503010752	1/2" X 3.1/2" BOLT		01
04	0531013272	0.5" X 1" X 2.2" SLEEVE		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0501013491	5/8" TENSIONER SPRING		01
08	0503010013	5/8" NUT		02
09	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
10	0503010002	1800 GREASE FITTING		01
11	0503010849	3/8" X 1-1/2" BOLT		02
12	0503010025	3/8" SPRING WASHER		02
13	0503010026	3/8" NUT		02
14	0503010795	5/8" X 7" BOLT		01
15	0503012412	5/8 UNC SELF LOCKING NUT		01
16	0502011757	PRESS REGULATOR		01
17	0511054333	COMPACT WHEEL RIGHT WITH BEARING	116	01
18	0511054334	COMPACT WHEEL LEFT WITH BEARING	118	01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	117	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	117	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0521062254	LEFT PRESS WHEEL FERT UPPER SUPPORT		01
02	0511064128	PRESS SUPPORT LOWWER WHEEL		01
03	0503010752	1/2" X 3.1/2" BOLT		01
04	0531013272	0.5" X 1" X 2.2" SLEEVE		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0501013491	5/8" TENSIONER SPRING		01
08	0503010013	5/8" NUT		02
09	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
10	0503010002	1800 GREASE FITTING		01
11	0503010849	3/8" X 1-1/2" BOLT		02
12	0503010025	3/8" SPRING WASHER		02
13	0503010026	3/8" NUT		02
14	0503010795	5/8" X 7" BOLT		01
15	0503012412	5/8 UNC SELF LOCKING NUT		01
16	0502011757	PRESS REGULATOR		01
17	0511054333	COMPACT WHEEL RIGHT WITH BEARING	116	01
18	0511054334	COMPACT WHEEL LEFT WITH BEARING	118	01




Item	Code	Description	See page	QT
01	0521062253	RIGHT PRESS WHEEL FERT UP SUPPORT		01
02	0511064128	PRESS SUPPORT LOWWER WHEEL		01
03	0503010752	1/2" X 3.1/2" BOLT		01
04	0531013272	0.5" X 1" X 2.2" SLEEVE		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0501013491	5/8" TENSIONER SPRING		01
08	0503010013	5/8" NUT		02
09	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
10	0503010002	1800 GREASE FITTING		01
11	0503010849	3/8" X 1-1/2" BOLT		02
12	0503010025	3/8" SPRING WASHER		02
13	0503010026	3/8" NUT		02
14	0503010795	5/8" X 7" BOLT		01
15	0503012412	5/8 UNC SELF LOCKING NUT		01
16	0502011757	PRESS REGULATOR		01
17	0511054837	RH IRON PRESS WHEEL	121	01
18	0511054838	LH IRON PRESS WHEEL	123	01




Item	Code	Description	See page	QT
01	0501052957	IRON V PRESS WHEELS	122	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		05
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0502011932	IRON PRESS WHEELS		01
02	0503010269	6204 BALL BEARING		02
03	0503011105	SEAL RING		01
04	0503013848	5072-BR SEAL		02
05	0521019147	V COMPACT WHEELS AXLE		02
06	0511011927	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052957	IRON V PRESS WHEELS	122	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		05
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0521062254	LEFT PRESS WHEEL FERT UPPER SUPPORT		01
02	0511064128	PRESS SUPPORT LOWWER WHEEL		01
03	0503010752	1/2" X 3.1/2" BOLT		01
04	0531013272	0.5" X 1" X 2.2" SLEEVE		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0501013491	5/8" TENSIONER SPRING		01
08	0503010013	5/8" NUT		02
09	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
10	0503010002	1800 GREASE FITTING		01
11	0503010849	3/8" X 1-1/2" BOLT		02
12	0503010025	3/8" SPRING WASHER		02
13	0503010026	3/8" NUT		02
14	0503010795	5/8" X 7" BOLT		01
15	0503012412	5/8 UNC SELF LOCKING NUT		01
16	0502011757	PRESS REGULATOR		01
17	0511054837	RH IRON PRESS WHEEL	121	01
18	0511054838	LH IRON PRESS WHEEL	123	01




Item	Code	Description	See page	QT
00	0511056413	SET MONITOR 9L SEED AND FERTILIZER	01	
01	0503017602	MONITOR PLANT PM400	01	
02	0503016568	DOUBLE CABLE MONITORING 9 ROW	01	
03	0503017577	CAB UNIC PM400	01	
04	0503016234	TRIMBLE FIXING WINDOW	01	
05	0503016452	FIXING SUPPORT AG500 TRIMBLE	01	
06	0571012196	MOUNTING BRACKET PM 400	01	
07	0503017443	ANTENNA GPS PM 400	01	
08	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP	100	
09	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN	02	
10	0503010669	FLAT WASHER	02	
11	0503010668	3/16" SPRING WASHER	02	
12	0503010667	3/16" NUT	02	
13	0501058973	CONJ SENSOR ELECTRIC SENSOR Ø25MM	01	
13A	0503015219	CONJ SENSOR ELECTRIC SENSOR Ø25MM	01	
13B	0503013100	NYLON CLAMP	05	
13C	0503034030	MANGO	01	
13D	0503010368	1.1/2" X 2" X 12.2" HOSE	01	
13E	0571013891	CONVEYOR FIXING GLOVE	02	
13F	0503010243	CLAMP	02	
14	0501058972	ASSEMBLY SENSOR ELECTRONIC	01	
14A	0503015218	SENSOR FOTOELE PM 400	01	
14B	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP	03	




Item	Code	Description	See page	QT
001	0511059218	RIGHT SUPPORT	129	01
002	0521050168	MOUNTED FERTILIZER CONDUCTOR	132	01




Item	Code	Description	See page	QT
001	0511059219	LEFT SUPPORT	128	01
002	0521050168	MOUNTED FERTILIZER CONDUCTOR	132	01




Item	Code	Description	See page	QT
01	0521066977	ARM BLADE DISC		01
02	0581011838	SLEVE GUIDES		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0521015376	DUST CLOAK		01
05	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02
08	0503012417	SEAL		01
09	0503011800	SEAL RING		01
10	0503010276	6206 BALL BEARING		01
11	0503030832	FLAT WASHER		01
12	0511059230	BOX WITH DOC 18 TURBO LEFT	130	01




Item	Code	Description	See page	QT
01	0521066977	ARM BLADE DISC		01
02	0581011838	SLEVE GUIDES		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0521015376	DUST CLOAK		01
05	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02
08	0503012417	SEAL		01
09	0503011800	SEAL RING		01
10	0503010276	6206 BALL BEARING		01
11	0503030832	FLAT WASHER		01
12	0511059229	BOX WITH DOC 18 TURBO RIGHT	131	01



Item	Code	Description	See page	QT
01	0502011562	DC PST ACT/ULTR BOX		01
02	0503011800	SEAL RING		01
03	0503012417	SEAL		01
04	0503010276	6206 BALL BEARING		01
05	0503030832	FLAT WASHER		01
06	0503011444	SPRING WASHER		06
07	0503010691	1/4" GREASE FITTING		01
08	0503010337	5/16" NUT		06
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0607025032	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0502011562	DC PST ACT/ULTR BOX		01
02	0503011800	SEAL RING		01
03	0503012417	SEAL		01
04	0503010276	6206 BALL BEARING		01
05	0503030832	FLAT WASHER		01
06	0503011444	SPRING WASHER		06
07	0503010691	1/4" GREASE FITTING		01
08	0503010337	5/16" NUT		06
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0607025032	PLAIN COULTER BLADE		01



Item	Code	Description	See page	QT
01	0581013298	SUPPORT		01
02	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
03	0521018517	FLAT WASHER		01
04	0503010060	1/2" NUT		01
05	0503010019	1/2" SPRING WASHER		01
06	0503030483	FERTILIZER SOCKET		01
07	0503031050	CURVED CONDUCTOR		01
08	0503010246	CLAMP		01

HEX AXLE ASSEMBLY

0909094592



Item	Code	Description	See page	07	09	11 L.
01	0521013432	5/8" X 59" AXLE HEX		01	00	00
02	0521013428	HEX AXLE		01	00	00
03	0521013433	5/8" X 75" AXLE HEX		00	01	00
04	0521013429	AXLE HEX 5/8 X 2180		00	01	00
05	0521013434	HEX AXLE 5/8 X 2300		00	00	01
06	0521013430	HEX AXLE 5/8 X 2580		00	00	01
07	0511015098	FLAT WASHER		02	02	02
08	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8		00	02	02
09	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"		02	00	02
10	0503010003	1845 GREASE FITTING		02	02	02
11	0503010365	NUT		04	04	04
12	0501010984	FLAT WASHER		04	04	04
13	0501010694	8.5 X 18 X 1.5 FLAT WASHER		08	08	08
14	0503010179	5/16" ZN SPRING WASHER		04	04	04
15	0503010337	5/16" NUT		04	04	04
16	0511017305	FLAT WASHER		04	04	04
17	0511065562	20Z GEAR		02	02	02
18	0502011299	BUSHING GEAR		02	02	02
19	0503010010	1/4" X 2.1/2" COTTERPIN		02	02	02



www.marchesan.com.br



Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI