

ROW CROP PLANTERS

USAP TITANIUM - FRAME 14520 - CSU/TCE/APT ISOBUS/MH/MS

Code: 0501091793
Series: S-0419
Revision: 00
Date Revision: FEVEREIRO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111140454	USAP 14520/32E450 CSU CM TIT DT ESPECIAL S-0419

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909095440	FRAME ASSY	1
0909095450	FRAME RIGHT SIDE ASSY	2
0909095451	ASSY CENTRAL FRAME	3
0909095452	LEFT SIDE FRAME ASSY	4
0521059311	SIDE HEX SHAFT TCE/APT/SEED	5
0521055326	RIGHT WHEEL WITH TRANSMISSION	6
0521055325	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	7
0521054953	HYDRAULIC CYLINDER 50,80 X 127,00 X 205	8
0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	9
0511054491	WHEEL WITHOUT TIRE WITH 27Z GEAR	10
0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	11
0511054463	WHEEL TENSIONER SUPORT CENTRAL	12
0511054464	WHEEL FORK TENSIONER	13
0511054500	TRANSMISSION EXCHANGE RIGHT	14
0511054461	STRETCHER TOP TRANSMISSION SWIRLED	15
0521057490	CHAIN STRETCHER WITH ASSY HOLE 13	16
0521056865	EXCHANGE RIGHT ASSY FERTILIZER	17
0521056866	RIGHT SEMI-ASSEMBLED EXCHANGE	18
0501056444	BEARING WITH ROLLING	19
0501056271	BEARING CLOSED	20
0501052776	CHAIN TENSIONER RIGHT ASSY GREATEST	21
0501048790	AXLE WITH LINK ASSY	22
0511053337	DRIVE SHAFT	23
0501048409	DRIVE SHAFT	24
0521053068	MOTOR SUPPORT APT ASSY	25
0511052600	STRETCHER HYDRAULIC MOTOR SUPPORT	26
0521059119	SUPPORT SILO SIDE 6 MOUTH 2377/2433 ASSY FERTILIZER	27
0521059124	RIGHT SUPPORT 5 MOUTH 1602X2033 ASSY	28
0521059259	RIGHT SIDE SUPPORT SILO FERTILIZER 11 MOUTH	29
0521059125	SUPPORT SILO SIDE FERTILIZER 6 MOUTH RIGHT 2433	30
0521059126	RIGHT SUPPORT SILO FERTILIZER 5 MOUTH	31
0521050525	FIXER FERTILIZER CONDUCTOR	32
0521055365	SEED CONDUCTOR	33
0521051407	FIXER SILO FERTILIZER	34
0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	35
0521054282	BEARING	36
0501053788	Q3/4" FASTENER AXLE ASSY	37
0521054290	ASSY SIDE SUPPORT	38
0521059123	DOUBLE SHOE SUPPORT ASSY SIDE SILO	39
0521053054	ASSY SIDE HANDLE	40
0521059308	SIDE FERTILIZER PLATFORM	41
0521054279	PLATFORM FIXER	42
0521054272	LADDER ASSY	43
0521059309	SIDE GUTTER ASSEMBLY 32E450 APT/SEED	44
0521055102	BIGGEST FULL GUTTER SUPPORT	45
0521059322	RIGHT SIDE DUCT ASSEMBLY	46
0511059928	SIDE DUTY SUPPORT	47
0521059312	SIDE ADHESIVE LABEL ASSY	48
0909095453	SEED LINE/ASSY FERTILIZER	49
0521058534	FRONT LINE SEED LONG TCE/CM	50
0521058533	FRONT SEED SHORT LINE TCE/CM	51
0521058612	FRONT SUPER LONG SEED LINE TCE	52
0521059045	BEARING WITH CURRENT ENCAPSULATED	53
0521058611	FRAME SEMI MOUNTED SUPER LONG CM/TCE	54
0521050096	SEED DEPOSIT SYSTEM (CSU)	55



MARCHESAN

INDEX

0511052058	SEED SYSTEM TITANIUM	56
0521055346	20 BLADE DISC ASSY	57
0521055344	LOWER SUPPORT	58
0521054844	DPLO 20 CUTTING DISK BOX	59
0521053697	CUTTING DISK BOX	60
0521058588	REAR WITH LEFT DDD SPICRR TITANIUM TCE	61
0521058586	REAR WITH RIGHT DDD SPICRR TITANIUM TCE	62
0521058085	REAR WITH DDD LEFT SPICRR	63
0521058084	REAR WITH RIGHT DDD SPICRR	64
0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	65
0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	66
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	67
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	68
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	69
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	70
0521056632	DEPTH CONTROL	71
0521056633	MOUNTED RIGHT ARM	72
0521056631	MOUNTED LEFT ARM	73
0521055059	WHEEL RAYED ASSY SPA WITHOUT LUBRICATION	74
0521055093	BODY COMPACTOR	75
0521055073	ASSEMBLY DEPTH WHEEL BOX	76
0521054990	LEFT COMPACTOR WHEEL	77
0521055017	RIGHT COMPACTOR WHEEL	78
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	79
0531050193	DOSING ASSY TITANIUM/TATU	80
0521056639	SEED ROW TRANSMISSION	81
0511052024	FAST CLOSING SET	82
0521054262	RIGHT FERTILIZER CONDUCTOR	83
0521056855	ASSY SHORT FERTILIZER CONDUCTOR	84
0521056854	ASSY LONG FERTILIZER CONDUCTOR	85
0503062066	DISC SET WITH CORN RING	86
0503062067	DISC SET / RING SOY 90F TITANIUM	87
0521059255	RIGHT SEMI-ASSEMBLED MARKER	88
0511058227	HYDRAULIC CYLINDER 38,10 X 63,50 X 608 X 290	89
0511042494	ROW MARKER DISC ASSY	90
0521056890	CENTRAL FRAME 4500 FIXATION/TELESCOPIC LATCH	91
0521050019	TIGHTENING PLATE WITH FIXING INTERNAL	92
0521052189	38,10 X 63,50 X 386 X 148 HYDRAULIC CYLINDER	93
0521059314	CENTRAL HEX AXLE 32E450 TCE/APT	94
0521055329	CENTRAL WHEEL WITH TRANSMISSION	95
0521055328	CENTRAL WHEEL WITHOUT TRANSMISSION	96
0511054492	STUB SHAFT HUB	97
0511054499	TRANSMISSION OF LARGER CENTRAL EXCHANGE	98
0501053654	DOUBLE BEARING TRANSMISSION SEED 3/4	99
0521056860	ASSY CENTRAL FERTILIZER EXCHANGE	100
0501052778	CHAIN TENSIONER ASSY	101
0511054489	LEFT TENSIONER CENTRAL EXCHANGE	102
0501056573	17Z GEAR ASSY	103
0511056179	CLUTCH WITH CARDAN CENTRAL	104
0501056443	BEARING ASSY GEAR BOX	105
0521056856	ECU BOX WITH ASSY SUPPORT	106
0521056857	ECU APT / TVT BOX WITH EXCHANGE	107
0521055366	RIGHT SEED BOX ASSY	108
0521055367	ASSY LEFT CENTRAL SEED BOX	109
0521056896	CENTRAL SUPPORT SILO 10 MOUTH	110



MARCHESAN

INDEX


0521056858	ASSY 5 MOUTH LEFT CENTRAL SUPPORT	111
0521056859	CENTRAL SUPPORT RIGHT 5 MOUTH ASSY	112
0511059491	AXLE HOLDER	113
0521056861	CENTRAL EXCHANGE STRETCHER FERTILIZER	114
0521054339	CENTRAL PLATFORM ASSY	115
0521055357	CENTRAL HANDRAIL	116
0511059383	INTERNAL FIXER ASSY HANDLE	117
0521057207	ELECTRIC ASSEMBLY BCE (EMB) APT	118
0521051707	ASSY PANEL FIXER PLATE	119
0521052149	ARTICULATION ARM LEFT ASSY	120
0521052147	ARTICULATION ARM RIGHT ASSY	121
0521052353	ASSEMBLY CYLINDER ARTICULATED ARM	122
0511058241	HYDRAULIC CYLINDER 50,80 X 114,30 X 964 X 638	123
0521059315	HYDRAULIC ASSY FERTILIZER/APT/SEED	124
0521059316	CENTRAL DUCT ASSY FERTILIZER/SEED/APT	125
0521053537	CENTRAL REAR DUCT SUPPORT	126
0521057013	TRIPLE DIVISER VALVE BRP00079 WITH NIPLES	127
0531050057	MH SEQUENTIAL VALVE SUPPORT WITH FIXATION	128
0531050058	SUPPORT ASSY BLOCK/VALVES	129
0521052155	SEQUENTIAL VALVE ASSY	130
0531050098	HOSE ASSY ARTICULATION FERTILIZER/SEED	131
0531050097	ASSY HOSE LIFTING FERTILIZER/SEED	132
0521058634	HOSE KIT	133
0521055402	HOSE KIT MH/CH 12910	134
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	135
0521059317	CENTRAL FERTILIZER/SEED/APT ASSY	136
0521059323	ISOBUS ASSY 32L45/50	137
0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	138
0511056972	FILTER HYDAC	139
0521059318	ELECTRICAL ASSY 15MT/5F LED	140
0521054283	HEADLIGHT WITH SUPPORT	141
0521059116	LIGHTHOUSE WITH LARGER SUPPORT	142
0521059393	LED FLASHLIGHT WITH FIXATION SUPPORT	143
0521055426	ASSY ELECTRICAL BOX SUPPORT	144
0521052143	CLUTCH INDUCTIVE SENSOR ASSEMBLY	145
0521058330	SENSOR SUPPORT	146
0521058331	DRIVE HYDRAULIC ASSEMBLY	147
0521058667	ADHESIVE LABEL ASSY APT	148
0511059814	TELESCOPIC LOCK ASSY	149
0521053296	AXIS ARTICULATOR	150
0521055327	LEFT WHEEL WITH TRANSMISSION	151
0511054501	TRANSMISSION CAMBIO LEFT	152
0521056864	ASSY LEFT EXCHANGE FERTILIZER	153
0521056867	SEMI-ASSEMBLED LEFT EXCHANGE	154
0521054349	FILTER SUPPORT	155
0521059307	LEFT SIDE SUPPORT SILO FERTILIZER 11 MOUTH	156
0521059121	SUPPORT SILO SIDE FERTILIZER 6 MOUTH LEFT 2433	157
0521059122	LEFT SUPPORT SILO FERTILIZER 5 MOUTH 2033	158
0521054313	CLOSED BEARING	159
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	160
0521059120	LEFT SUPPORT 5 MOUTH 1602 X 2033 ASSY	161
0521059310	SIDE DUCT ASSEMBLY	162
0521059256	SEMI-ASSEMBLED LEFT MARKER	163
0521057792	PANTOGRAPHY HEADER	164
0521057786	HYDRAULIC CYLINDER HEAD PANTOGRAPH	165




MARCHESAN

INDEX

0521059241	TELESCOPIO WITH INTERMEDIARY TUBE 2000/3225 ASSY		166
0521059242	FRENCH HAND 1725 X 1800 X 4737 ASSY RIGHT		167
0521058645	FRENCH HAND 1725 X 1800 X 4737 LEFT ASSY		168
0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT		169
0521058088	ROTULA WITH EXTENSOR AXIS 2		170
0511053121	GREATER TOOL BOX ASSY		171
0511052052	SUPPORT WITH FIXATION		172
0521057815	HYDRAULIC HOSE SUPPORT WITH FIXATION		173
0521058344	WATER RESERVOIR WITH SOAP		174
0521057773	SEMI-ASSEMBLED REST		175




Item	Code	Description	See page	QT
01	0909095450	FRAME RIGHT SIDE ASSY	2	01
02	0521059255	RIGHT SEMI-ASSEMBLED MARKER	88	01
03	0909095451	ASSY CENTRAL FRAME	3	01
04	0909095452	LEFT SIDE FRAME ASSY	4	01
05	0521059256	SEMI-ASSEMBLED LEFT MARKER	163	01
06	0521057792	PANTOGRAPHY HEADER	164	01
07	0521059241	TELESCOPIO WITH INTERMEDIARY TUBE 2000/3225 ASSY	166	01
08	0521059242	FRENCH HAND 1725 X 1800 X 4737 ASSY RIGHT	167	01
09	0521058645	FRENCH HAND 1725 X 1800 X 4737 LEFT ASSY	168	01
10	0521069072	TRANSPORT LOCK		01
11	0521058345	SAFETY CHAIN WITH SHACKLE		01
11A	0503014120	CHAIN		01
11B	0503014321	CABLE STEEL SHACKLE		02
12	0511053121	GREATER TOOL BOX ASSY	171	01
13	0511052052	SUPPORT WITH FIXATION	172	04
14	0503018829	NYLON CLAMP		20
15	0521057815	HYDRAULIC HOSE SUPPORT WITH FIXATION	173	01
16	0521058344	WATER RESERVOIR WITH SOAP	174	01
17	0521057773	SEMI-ASSEMBLED REST	175	01



Item	Code	Description	See page	QT
01	0531061327	RIGHT SIDE FRAME		01
02	0581012179	SLEEVE		02
03	0503010002	1800 GREASE FITTING		01
04	0521059311	SIDE HEX SHAFT TCE/APT/SEED	5	01
05	0521055326	RIGHT WHEEL WITH TRANSMISSION	6	01
06	0521055325	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	7	01
07	0511057868	ASSY CURRENT STRETCHER 79		01
08	0521056865	EXCHANGE RIGHT ASSY FERTILIZER	17	01
09	0511053337	DRIVE SHAFT	23	01
10	0521053068	MOTOR SUPPORT APT ASSY	25	01
11	0521059119	SUPPORT SILO SIDE 6 MOUTH 2377/2433 ASSY FERTILIZER	27	01
12	0521059124	RIGHT SUPPORT 5 MOUTH 1602X2033 ASSY	28	01
13	0521059259	RIGHT SIDE SUPPORT SILO FERTILIZER MOUTH	11 29	01
14	0521054290	ASSY SIDE SUPPORT	38	02
15	0521059123	DOUBLE SHOE SUPPORT ASSY SIDE SILO	39	01
16	0521053054	ASSY SIDE HANDLE	40	02
17	0521059308	SIDE FERTILIZER PLATFORM	41	01
18	0521054272	LADDER ASSY	43	01
19	0521059309	SIDE GUTTER ASSEMBLY 32E450 APT/SEED	44	01
20	0521059322	RIGHT SIDE DUCT ASSEMBLY	46	01
21	0521059312	SIDE ADHESIVE LABEL ASSY	48	01
22	0909095453	SEED LINE/ASSY FERTILIZER	49	11

ASSY CENTRAL FRAME

0909095451



Item	Code	Description	See page	QT
01	0521056890	CENTRAL FRAME 4500 FIXATION/TELESCOPIC LATCH	91	01
02	0521059314	CENTRAL HEX AXLE 32E450 TCE/APT	94	01
03	0521055329	CENTRAL WHEEL WITH TRANSMISSION	95	01
04	0521055328	CENTRAL WHEEL WITHOUT TRANSMISSION	96	03
05	0521056860	ASSY CENTRAL FERTILIZER EXCHANGE	100	01
06	0521056856	ECU BOX WITH ASSY SUPPORT	106	01
07	0521053068	MOTOR SUPPORT APT ASSY	25	01
08	0521055366	RIGHT SEED BOX ASSY	108	01
09	0521055367	ASSY LEFT CENTRAL SEED BOX	109	01
10	0521056896	CENTRAL SUPPORT SILO 10 MOUTH	110	01
11	0521054339	CENTRAL PLATFORM ASSY	115	01
12	0521055357	CENTRAL HANDRAIL	116	02
13	0521057207	ELECTRIC ASSEMBLY BCE (EMB) APT	118	01
14	0521059540	ASSY TRACTOR HITCH AXLE		01
14A	0521068010	HITCH AXLE		01
14B	0503030119	LOCK PIN		01
15	0521052149	ARTICULATION ARM LEFT ASSY	120	01
16	0521052147	ARTICULATION ARM RIGHT ASSY	121	01
17	0521052353	ASSEMBLY CYLINDER ARTICULATED ARM	122	01
18	0521059315	HYDRAULIC ASSY FERTILIZER/APT/SEED	124	01
19	0521059317	CENTRAL FERTILIZER/SEED/APT ASSY	136	01
20	0581018202	SUPPORT AIR CONDUCTION		02
21	0521059323	ISOBUS ASSY 32L45/50	137	01
22	0521059318	ELECTRICAL ASSY 15MT/5F LED	140	01
23	0521058330	SENSOR SUPPORT	146	01
24	0521058331	DRIVE HYDRAULIC ASSEMBLY	147	01
25	0521058667	ADHESIVE LABEL ASSY APT	148	01
26	1164920006	BLACK LIGHT SUCTION HOSE		23
27	1164920013	FLEX HOSE SPIRAL		43,5mts
28	0511059814	TELESCOPIC LOCK ASSY	149	01
29	0521055637	ASSY TRANSPORT LOCK		04


ASSY CENTRAL FRAME

0909095451


Item	Code	Description	See page	QT
29A	0551018312	TRANSPORT LOCK		01
29B	0501068994	0.3" X 3.1"LOCK PIN		01
29C	0503030168	HAIR PIN		01
30	0561016793	FIXED WRENCH		01
31	0501047885	ROD STOP		08
32	0561017063	HOLDER TUBE		02
33	0521053296	AXIS ARTICULATOR	150	01
34	0581019559	AXIS		01
35	0909095453	SEED LINE/ASSY FERTILIZER	49	10

LEFT SIDE FRAME ASSY

0909095452




Item	Code	Description	See page	QT
01	0531061326	LEFT SIDE FRAME		01
02	0581012179	SLEEVE		02
03	0503010002	1800 GREASE FITTING		01
04	0521059311	SIDE HEX SHAFT TCE/APT/SEED	5	01
05	0521055327	LEFT WHEEL WITH TRANSMISSION	151	01
06	0521055325	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	7	01
07	0511057868	ASSY CURRENT STRETCHER 79		01
08	0521056864	ASSY LEFT EXCHANGE FERTILIZER	153	01
09	0511053337	DRIVE SHAFT	23	01
10	0521053068	MOTOR SUPPORT APT ASSY	25	01
11	0521054349	FILTER SUPPORT	155	01
12	0521059119	SUPPORT SILO SIDE 6 MOUTH 2377/2433 ASSY FERTILIZER	27	01
13	0521059120	LEFT SUPPORT 5 MOUTH 1602 X 2033 ASSY	161	01
14	0521059307	LEFT SIDE SUPPORT SILO FERTILIZER 11 MOUTH	156	01
15	0521054290	ASSY SIDE SUPPORT	38	02
16	0521059123	DOUBLE SHOE SUPPORT ASSY SIDE SILO	39	01
17	0521053054	ASSY SIDE HANDLE	40	02
18	0521059308	SIDE FERTILIZER PLATFORM	41	01
19	0521054272	LADDER ASSY	43	01
20	0521059309	SIDE GUTTER ASSEMBLY 32E450 APT/SEED	44	01
21	0521059310	SIDE DUCT ASSEMBLY	162	01
22	0521059312	SIDE ADHESIVE LABEL ASSY	48	01
23	0909095453	SEED LINE/ASSY FERTILIZER	49	11



Item	Code	Description	See page	QT
01	0561015843	3/4 X 2070 HEX AXLE		01
02	0561018821	HEX AXLE 3/4 X 2600		01
03	0561015837	SLEEVE 31,75		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		04
05A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
05B	0503010256	3/8" X 3/4" BOLT		01

RIGHT WHEEL WITH TRANSMISSION

0521055326




Item	Code	Description	See page	QT
01	0521064543	WHEEL SUPPORT		01
02	0561019929	FLAT WASHER		01
03	0503010523	1/4" X 2" COTTERPIN		03
04	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
05	0551014508	FLAT WASHER		01
06	0503010571	1/4" X 1.1/2 COTTERPIN		02
07	0521069575	FLANGE CYLINDER HYDRAULIC FIXER		02
08	0521054953	HYDRAULIC CYLINDER 50,80 X 127,00 X 205	8	01
09	0503010920	1/2" X 1.1/2" BOLT		04
10	0503010019	1/2" SPRING WASHER		04
11	0503010060	1/2" NUT		04
12	0502012731	WHEEL HOLDER		02
13	0581017245	AXLE BODY		01
14	0503011075	3/4" UNC NUT		04
15	0503012334	3/4" UNC X 3.1/2" BOLT		04
16	0503010002	1800 GREASE FITTING		04
17	0521064550	CARRYING-WHEELS FORK		01
18	0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	9	01
19	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
20	0511054491	WHEEL WITHOUT TIRE WITH 27Z GEAR	10	01
21	0531012874	FLAT WASHER		02
22	0511068422	WHEEL GEAR DOBLE		01
23	0551018571	FLAT WASHER		02
24	0511054463	WHEEL TENSIONER SUPORT CENTRAL	12	01
25	0511054464	WHEEL FORK TENSIONER	13	02
26	0561019941	RIGHT PROTECTIVE CAP WHEELS		01
27	0503010849	3/8" X 1-1/2" BOLT		02
28	0501013518	FLAT WASHER		02
29	0503010025	3/8" SPRING WASHER		02
30	0503010209	3/8" UNC BUTTERFLY NUT		02
31	0503016419	50-1 CHAIN X 128 LINK + REDUCION		01


RIGHT WHEEL WITH TRANSMISSION

0521055326


Item	Code	Description	See page	QT
32	0501010630	1.1/2" CASTLE NUT		01
33	0501017779	32 X 60 X 4.75 FLAT WASHER		02
34	0503011052	1.1/4" X 0.77" CASTLE NUT		02
35	0503014857	50-1 X CHAIN X 122 LINK + REDUCION		01
36	0511054500	TRANSMISSION EXCHANGE RIGHT	14	01
37	0503033335	CURRENT 6 X 21 ELOS		01
38	0503010882	BOLT		01
39	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
40	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0521064543	WHEEL SUPPORT		01
02	0561019929	FLAT WASHER		01
03	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
04	0551014508	FLAT WASHER		01
05	0521069575	FLANGE CYLINDER HYDRAULIC FIXER		02
06	0503010920	1/2" X 1.1/2" BOLT		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0502012731	WHEEL HOLDER		02
10	0503010002	1800 GREASE FITTING		03
11	0521064550	CARRYING-WHEELS FORK		01
12	0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	9	01
13	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
14	0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	11	01
15	0501010630	1.1/2" CASTLE NUT		01
16	0501017779	32 X 60 X 4.75 FLAT WASHER		02
17	0503011052	1.1/4" X 0.77" CASTLE NUT		02
18	0503010882	BOLT		01
19	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
20	0503010337	5/16" NUT		01
21	0503033335	CURRENT 6 X 21 ELOS		01
22	0581017245	AXLE BODY		01
23	0531012874	FLAT WASHER		02
24	0521054953	HYDRAULIC CYLINDER 50,80 X 127,00 X 205	8	01
25	0503010523	1/4" X 2" COTTERPIN		03
26	0503010571	1/4" X 1.1/2 COTTERPIN		02
27	0503012334	3/4" UNC X 3.1/2" BOLT		04
28	0503011075	3/4" UNC NUT		04




Item	Code	Description	See page	QT
01	0521069562	5" X 17" CYLINDER CASE		01
02	0503010345	2-218 N 3006-9B O'RING		01
03	0503010817	1.1/4" SELF LOCKING NUT		01
04	0581010353	RING SUPPORT		01
05	0581010354	PISTON		01
06	0503018150	RING GUIDE		01
07	0503018151	RING BS		02
08	0503018026	1870-2000-375 B GASKET		01
09	0503011453	O'RING		02
10	0503018152	O'RING		02
11	0503018024	RING BS		01
12	0503018025	RING GUIDE		01
13	0581019464	TURNBUCLE BODY		01
14	0571015629	CILINDER SPINDLE FORK		01
15	0503011094	3/8" X 2" BOLT		01
16	0503010026	3/8" NUT		01
17	0503010025	3/8" SPRING WASHER		01
18	0503010039	D-2000 SCRAPER RING		01
19	0502040876	COVER		01
20	0503030385	CYLINDER PLUG N-002		02




Item	Code	Description	See page	QT
01	0503033713	TIRE 12 X 16,5/12L TR SK 900		01
02	0503015029	WHEEL		01
03	0503015355	INNER TIRE		01



Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503013633	BEARING 33287/33462		01
04	0503010009	RETAINER 00573-B		01
05	0503010086	SEAL 0009B-B		01
06	0551014473	GLOVE		01
07	0503012702	KM-12 NUT		02
08	0503012703	LOCK WASHER		01
09	0503010002	1800 GREASE FITTING		01
10	0503011444	SPRING WASHER		08
11	0503014048	22 X 1.5 HEX NUT		08
12	0503010363	5/16" X 1" BOLT		08
13	0521064563	27Z GEAR		01
14	0503014050	22 X 1.5 BOLT		08
15	0503013496	3982/3920 ROLLER BEARING		01
16	1882970002	GREASE SOAP		01




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503010007	3982/3920 ROLLER BEARING		01
04	0503010059	33287/33462 ROLLER BEARING		01
05	0503010009	RETAINER 00573-B		01
06	0503010086	SEAL 0009B-B		01
07	0551014473	GLOVE		01
08	0503012702	KM-12 NUT		02
09	0503012703	LOCK WASHER		01
10	0503010002	1800 GREASE FITTING		01
11	0503011444	SPRING WASHER		04
12	0503010363	5/16" X 1" BOLT		04
13	0503014048	22 X 1.5 HEX NUT		08
14	0503014050	22 X 1.5 BOLT		08
15	0511068415	PFFP-3770 SEAL GUIDE		01




Item	Code	Description	See page	QT
01	0511054462	17Z GEAR		01
01A	0511061836	17Z GEAR		01
01B	0503011410	ROLLER BEARING		01
01C	0503011105	SEAL RING		01
02	0571015149	TIGHTENER AXLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0501010163	5/8" X 4-1/2" BOLT		01
05	0503010027	5/8" SPRING WASHER		01
06	0503010013	5/8" NUT		01

WHEEL FORK TENSIONER


0511054464




Item	Code	Description	See page	QT
01	0511054462	17Z GEAR		01
01A	0511061836	17Z GEAR		01
01B	0503011410	ROLLER BEARING		01
01C	0503011105	SEAL RING		01
02	0571015150	SLEEVE TENSIONER WHEEL		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0503010027	5/8" SPRING WASHER		01
05	0503010013	5/8" NUT		01
06	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
07	0501012140	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521064556	SUPPORT ASSY TRANSMISSION WHEEL SIDE		01
02	0503010025	3/8" SPRING WASHER		13
03	0503010026	3/8" NUT		11
04	0503010019	1/2" SPRING WASHER		03
05	0503010060	1/2" NUT		03
06	0503010741	1/2" X 2-3/4" BOLT		03
07	0521064555	27Z GEAR		01
08	0503062231	CLUTCH		01
09	0571015139	FIXER PLATE		01
10	0571015138	SIDE CLUTCH CHOCK		01
11	0571015141	FIXER CENTRAL TRANSMISSION		04
12	0511054461	STRETCHER TOP TRANSMISSION SWIRLED	15	02
13	0503011268	3/8" X 2-1/2" BOLT		01
14	0571015142	FIXER		02
15	0571015143	RIGHT PROTECTION SUPPORT WHEEL		01
16	0503010209	3/8" UNC BUTTERFLY NUT		02
17	0503013542	M10 SPRING WASHER		04
18	0503010188	M10 X 1,5 X 30 BOLT		04




Item	Code	Description	See page	QT
01	0521055499	GEAR WITH NATIONAL BEARING		01
01A	0511061836	17Z GEAR		01
01B	0503019356	BEARING 6005 2RS1		01
01C	0503011105	SEAL RING		01
02	0571015146	TIGHTENER AXLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0501011541	5/8" X 3" BOLT		01
05	0501012140	FLAT WASHER		01
06	0503010027	5/8" SPRING WASHER		01
07	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0591012478	HOLE TRANSMISSION STRETCHER AXLE 13		01
03	0503011410	ROLLER BEARING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503011105	SEAL RING		01
06	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		01
07	0511017302	FLAT WASHER		01
08	0503010060	1/2" NUT		01
09	0503010019	1/2" SPRING WASHER		01




Item	Code	Description	See page	QT
01	0551011625	PROTECTION COVER		01
02	0503010386	CABLE		01
03	0551015037	5/8" UNC X 210 X 198 FASTENER		02
04	0551018630	CARDAN SHAFT GUIDES SLEEVE		01
05	0551018629	GEAR BOX COVER FIXER ROD		01
06	0503010257	1/8" X 1" COTTERPIN		02
07	0503010179	5/16" ZN SPRING WASHER		01
08	0503010337	5/16" NUT		01
09	0501013518	FLAT WASHER		02
10	0521056866	RIGHT SEMI-ASSEMBLED EXCHANGE	18	01
11	0503012412	5/8 UNC SELF LOCKING NUT		04
12	0501012140	FLAT WASHER		04
13	0503011268	3/8" X 2-1/2" BOLT		01
14	0503013357	3/8" SELF-ADJUSTING NUT		01
15	0503034417	LETTER ADHESIVE LABEL		01
16	0503032987	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	19	02
02	0502011758	REAR TENSIONER LEVER		01
03	0551018627	SIDE GEAR BOX DRIVER AXLE		01
04	0503030303	SUPPORT WASHER		05
05	0501056271	BEARING CLOSED	20	02
06	0503010292	0.2" X 1.6" SPRING PIN		05
07	0503010002	1800 GREASE FITTING		01
08	0503010395	1/2" X 1-1/4" BOLT		02
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		02
10	0503012389	1/2 BALL		02
11	0503010060	1/2" NUT		02
12	0503011953	5/16" X 1" BOLT		08
13	0501010694	8.5 X 18 X 1.5 FLAT WASHER		08
14	0503010179	5/16" ZN SPRING WASHER		08
15	0503010337	5/16" NUT		08
16	0501052776	CHAIN TENSIONER RIGHT ASSY GREATEST	21	01
17	0501048790	AXLE WITH LINK ASSY	22	01
18	0503012204	40-1 CHAIN X 82 LINK + RED		01
19	0531060361	RIGHT SIDE EXCHANGE SUPPORT		01
20	0511060396	DRIVE/DRIVEN AXLE CONE		02
21	0591011683	MOVED AXIS		01
22	0511067501	26Z GEAR		01
23	0501010984	FLAT WASHER		01
24	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		01
25	0503010025	3/8" SPRING WASHER		01
26	0503019312	40-1 X 51 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01



Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0511061794	CHAIN TENSIONER		01
02	0503031367	SPRING		01
03	0503031805	11Z 1/2" GEAR		02
04	0503010302	501019 SEAL RING		02
05	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01

DRIVE SHAFT


0511053337




Item	Code	Description	See page	QT
001	0501048409	DRIVE SHAFT	24	01
002	0503011141	3/8" X 2-3/4" BOLT		02
003	0503013357	3/8" SELF-ADJUSTING NUT		02

DRIVE SHAFT


0501048409




Item	Code	Description	See page	QT
01	0501052160	SLEEVE UNIVERSAL JOINT	01	01
02	0501051718	UNIVERSAL JOINT	01	01
03	0502010558	4-20 TERMINAL WITH ROLES	02	02
04	0502011426	2-20 TERMINAL	01	01
05	0521013797	0.9"X1.1"X31.5" SQUARE SLEEVE	01	01
06	0503010835	CARDAN CROSSPICE	02	02
07	0503010839	03"X 0.6" SPRING PIN	01	01
08	0501052161	UNIVERSAL JOINT WITH AXLE	01	01
09	0501051720	UNIVERSAL JOINT	01	01
10	0502011427	3-20 TERMINAL	01	01
11	0521013794	0.9" X 31.5 SQUARE SHAFT	01	01
12	0503010301	0.3" X 1.8" SPRING PIN	01	01
13	0501052162	PROT/SLEEVE UNIVERSAL JOINT	01	01
14	0501052163	PROT/AXLE UNIVERSAL JOINT	01	01
15	0503012268	PROTECTION ASSY	01	01
16	0503012269	PROTECTION FOR UNIV JOINT SLEEVE	01	01
17	0503012270	PROTECTION FOR UNIV JOINT AND AXLE	01	01
18	0503012023	CHAIN FOR PROTECTION	01	01




Item	Code	Description	See page	QT
01	0521063601	SUPPORT HYDRAULIC MOTOR		01
02	0521062807	17Z GEAR WITH SLEEVE		01
03	0511052600	STRETCHER HYDRAULIC MOTOR SUPPORT	26	01
04	0571012677	WASHER GUIDE		01
05	0501010937	13.5 X 28 X 3 FLAT WASHER		02
06	0503010060	1/2" NUT		02
07	0503010019	1/2" SPRING WASHER		02
08	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
09	0571012684	FIXING SHAFT		01
10	0571012680	FLAT WASHER		01
11	0503010179	5/16" ZN SPRING WASHER		01
12	0503010025	3/8" SPRING WASHER		01
13	0503010026	3/8" NUT		01
14	0503013758	1/4" X 1-1/2" BOLT		01
15	0503010237	3/8" X 1" BOLT		01
16	0502012768	LINE SUPPORT CLAMP		01
17	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		02
18	0503010811	5/8" UNF SELF ADJUSTING NUT		02
19	0503017392	40-1 X 67 CHAIN LINK + MENDING		01
20	0521063774	GEAR ASSY		01
21	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		02
21A	0502012699	LATCH GLOVE BOX TRANSMISSION		02
21B	0503010256	3/8" X 3/4" BOLT		02




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503012882	BEARING		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0571012703	SLEEVE FLANGE		01
05	0503010479	BOLT		01
06	0511017302	FLAT WASHER		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0531061329	SIDE SUPPORT		01
02	0503062963	SILO FERTILIZER 06 MOUTHS		01
03	0521050525	FIXER FERTILIZER CONDUCTOR	32	06
04	0521055365	SEED CONDUCTOR	33	06
05	0521051407	FIXER SILO FERTILIZER	34	10




Item	Code	Description	See page	QT
01	0531061335	SIDE SUPPORT 5 MOUTH 1602 RIGHT		01
02	0521055365	SEED CONDUCTOR	33	05
03	0503062962	SILO SEED 05 ASSY MOUTH		01
04	0521050525	FIXER FERTILIZER CONDUCTOR	32	05
05	0521051407	FIXER SILO FERTILIZER	34	08




Item	Code	Description	See page	QT
01	0521059125	SUPPORT SILO SIDE FERTILIZER 6 MOUTH RIGHT 2433	30	01
02	0521059126	RIGHT SUPPORT SILO FERTILIZER 5 MOUTH	31	01
03	0503062391	SILO FERTILIZER 05 MOUTHS		01
04	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		01
05	0503010010	1/4" X 2.1/2" COTTERPIN		01
06	0591015230	SQUARE GLOVE 19.3 X 36 X 130		01
07	0521051407	FIXER SILO FERTILIZER	34	18



Item	Code	Description	See page	QT
01	0531061328	SIDE SUPPORT WITH 6 MOUTH BACKGROUND		01
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	35	06
03	0501010942	3/8" X 1-1/4" BOLT		24
04	0503010025	3/8" SPRING WASHER		24
05	0503010026	3/8" NUT		24
06	0503030275	AGRICULTURAL BEARING		06
07	1902010685	18Z CONICAL GEAR		06
08	0521054313	CLOSED BEARING	159	01
09	0521054282	BEARING	36	01
10	0503030303	SUPPORT WASHER		03
11	0501053788	Q3/4" FASTENER AXLE ASSY	37	02
12	0571018899	SQUARE SHAFT 3/4 X 2565		01
13	0503034396	FERTILIZER SIDE COVER		06
14	0503010362	1/8" X 1.1/4" COTTERPIN		06




Item	Code	Description	See page	QT
01	0531061334	SUPPORT RIGHT WITH BACKGROUND 5 MOUTHS		01
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	35	05
03	0503030275	AGRICULTURAL BEARING		05
04	1902010685	18Z CONICAL GEAR		05
05	0501010942	3/8" X 1-1/4" BOLT		20
06	0503010025	3/8" SPRING WASHER		20
07	0503010026	3/8" NUT		20
08	0503030303	SUPPORT WASHER		04
09	0521054282	BEARING	36	02
10	0501053788	Q3/4" FASTENER AXLE ASSY	37	04
11	0511061759	22Z P12,70 FQ 3/4" GEAR		01
12	0571018896	SQUARE SHAFT		01
13	0503034396	FERTILIZER SIDE COVER		05
14	0503010362	1/8" X 1.1/4" COTTERPIN		05




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010365	NUT		02

SEED CONDUCTOR


0521055365



Item	Code	Description	See page	QT
01	0521069705	CONDUCTOR FIXER		01
02	0503010358	5/16" X 5/8" BOLT		02
03	0503010337	5/16" NUT		02
04	0503010179	5/16" ZN SPRING WASHER		03
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
06	0503010499	5/16" UNC BUTTERFLY NUT		01
07	0503011953	5/16" X 1" BOLT		01
08	0503013759	NUT		04
09	0581019780	COVER		01
10	0502012899	DUCT BODY		01
11	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		04
12	0503034859	JOIN		01




Item	Code	Description	See page	QT
01	0503012531	3/8" INOX NUT		01
02	0503012535	3/8" SPRING WASHER		01
03	0571019051	FIXER BOX WASHER		01
04	0503013751	3/8 UNC X 1.1/4 BOLT		01




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01

BEARING

0521054282




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	19	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01

ASSY SIDE SUPPORT


0521054290




Item	Code	Description	See page	QT
01	0521069333	DEPTH SUPPORT		01
02	0551015037	5/8" UNC X 210 X 198 FASTENER		02
03	0541012939	5/8 UNC X 141 X 120 FASTENER		02
04	0501012140	FLAT WASHER		08
05	0503013389	5/8" SELF LOCKING NUT		08
06	0503010920	1/2" X 1.1/2" BOLT		06
07	0503010060	1/2" NUT		06
08	0511017302	FLAT WASHER		12
09	0503010019	1/2" SPRING WASHER		06

DOUBLE SHOE SUPPORT ASSY SIDE SILO


0521059123




Item	Code	Description	See page	QT
01	0531061332	DOUBLE SHOE SUPPORT SIDE SILO		01
02	0551015037	5/8" UNC X 210 X 198 FASTENER		02
03	0541012939	5/8 UNC X 141 X 120 FASTENER		02
04	0501012140	FLAT WASHER		08
05	0503013389	5/8" SELF LOCKING NUT		08
06	0503010920	1/2" X 1.1/2" BOLT		12
07	0511017302	FLAT WASHER		12
08	0503010589	1/2" UNC SELF ADJUSTING NUT		12



Item	Code	Description	See page	QT
01	0521068962	HANDLE		01
02	0503013357	3/8" SELF-ADJUSTING NUT		02
03	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0591011211	PLATFORM		01
02	0591015134	PLATFORM 2430		01
03	0521054279	PLATFORM FIXER	42	04
04	0591014695	INTERMEDIATE PLATFORM SUPPORT		01




Item	Code	Description	See page	QT
01	0581018560	PLATFORM SUPPORT		01
02	0503010395	1/2" X 1-1/4" BOLT		02
03	0503010589	1/2" UNC SELF ADJUSTING NUT		03
04	0511017302	FLAT WASHER		01
05	0501010063	1/2" X 1-1/2" BOLT		01

LADDER ASSY


0521054272



Item	Code	Description	See page	QT
01	0521069329	ASSY SIDE LADDER		01
02	0502012742	FIXER SUPPORT LADDER		02
03	0503013357	3/8" SELF-ADJUSTING NUT		02
04	0501010984	FLAT WASHER		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0503010237	3/8" X 1" BOLT		04
07	0503010025	3/8" SPRING WASHER		04
08	0503010026	3/8" NUT		04
09	0503030403	1.85" X 2.87" BEATER		02




Item	Code	Description	See page	QT
01	0591015135	GUTTERS 30 X 55 X 2110		02
02	0521055102	BIGGEST FULL GUTTER SUPPORT	45	04




Item	Code	Description	See page	QT
01	0581019560	SUPPORT CONDUCTOR		01
02	0503010025	3/8" SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0503013029	3/8" X 3/4" BOLT		01
05	0501011643	3/8 X 1"BOLT		01

RIGHT SIDE DUCT ASSEMBLY


0521059322



Item	Code	Description	See page	QT
01	0511059943	SUPPORT FASTENER ASSY		03
01A	0581011417	DUTO HOLDER SUPPORT		01
01B	0503010237	3/8" X 1" BOLT		02
01C	0503010025	3/8" SPRING WASHER		02
01D	0503010026	3/8" NUT		02
02	0511059928	SIDE DUTY SUPPORT	47	02
03	0581018407	BODY FASTENER 2 DUCTS		02
04	0581018409	FASTENER BODY		08
05	0531061333	OIL DUCT 3 OUTPUTS		02
06	0521069280	OIL DUCT 16 X 22 X 2180		04
07	0503011268	3/8" X 2-1/2" BOLT		09
08	0503010025	3/8" SPRING WASHER		09
09	0503010026	3/8" NUT		09
10	0501082190	HOSE 3/8 X 160 TR-TR		02




Item	Code	Description	See page	QT
01	0581013094	DUTO HOLDER SUPPORT		01
02	0571019756	FASTENER 1/2 UNC X 220 X 198 ZN		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2" NUT		02



01

0503034679



02

0503032986



03

0503031546



04

0503033621

0503033621



05

0503033424



06

0503033417



07

0503033419



08


0503031827




09

0503031565


Item	Code	Description	See page	QT
01	0503034679	ADHESIVE LABEL		01
02	0503032986	ADHESIVE LABEL		01
03	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		01
04	0503033621	ADHESIVE LABEL		01
05	0503033424	DIRECT PLANTIO ADHESIVE LABEL		01
06	0503033417	ADHESIVE LABEL		01
07	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		01
08	0503031827	LUBRICATE AND RETIGHTEN DAILY DECAL		01
09	0503031565	ADHESIVE LABEL CARE		01




Item	Code	Description	See page	QT
01	0521058534	FRONT LINE SEED LONG TCE/CM	50	01
02	0521058533	FRONT SEED SHORT LINE TCE/CM	51	01
03	0521058612	FRONT SUPER LONG SEED LINE TCE	52	01
04	0521058611	FRAME SEMI MOUNTED SUPER LONG CM/TCE	54	01
05	0521050096	SEED DEPOSIT SYSTEM (CSU)	55	01
06	0521055346	20 BLADE DISC ASSY	57	01
06.	0521055341	CUTTING DISC		01
07	0521058588	REAR WITH LEFT DDD SPICRR TITANIUM TCE	61	01
08	0521058586	REAR WITH RIGHT DDD SPICRR TITANIUM TCE	62	01
08.	0521055053	DEEP WHEEL/COMPACTOR SYSTEM		01
09	0521054262	RIGHT FERTILIZER CONDUCTOR	83	01
10	0521056855	ASSY SHORT FERTILIZER CONDUCTOR	84	01
11	0521056854	ASSY LONG FERTILIZER CONDUCTOR	85	01
12	0503019222	BRACELET TYPE WIRE 3.2MM X 48 X 63 MM		01
13	0591011691	TOP GLOVE CONDUCTOR FERTILIZER		01
14	0503031050	CURVED CONDUCTOR		01
15	0503062066	DISC SET WITH CORN RING	86	01
16	0503062067	DISC SET / RING SOY 90F TITANIUM	87	01
17	0531013600	PRESS ADJUSTMENT LEVER		01
18	0521068982	KEY CASH DISC CUTTING		01
19	0511052024	FAST CLOSING SET	82	01
20	0521050525	FIXER FERTILIZER CONDUCTOR	32	01
21	0531060941	PROTECTION		01
22	0503014234	BOLT 1/2 UNF X 1.3/4 CS G.5 ZN		01
23	0503012136	NUT 1/2 NF		01
24	0591014600	ENCAPSULATED CURRENT FIXER		01
25	0561016889	STRIPED CAP WHEEL DEPTH		01




Item	Code	Description	See page	QT
01	0531060948	SEED LINE FRAME		01
02	0571012310	ROW LOCK BODY		01
03	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
04	0503010232	5/8" X 1.3/4" BOLT		01
05	0503030168	HAIR PIN		04
06	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
07	0503033728	FIXED SPRING PIN		02
08	0571014704	UPPER AXLE		01
09	0502012768	LINE SUPPORT CLAMP		02
10	0581018676	SLEEVE ARM LINE SEED		08
11	0503010811	5/8" UNF SELF ADJUSTING NUT		04
12	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
13	0581019795	SEED ARM SUPPORT ROW		01
14	0581019796	LOWER ARM LARGER		01
15	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
16	0521068452	UP SUPPORT		01
17	0503010878	5/8" SELF ALIGNING NUT		04
18	0503019273	SLEEVE		06
19	0503010045	O'RING		08
20	0502012568	UPPER ROCKER ARM		01
21	0591014726	ENCAPSULATED CURRENT GUIDE		01
22	0503013357	3/8" SELF-ADJUSTING NUT		01
23	0503010237	3/8" X 1" BOLT		01
24	0503013389	5/8" SELF LOCKING NUT		01
25	0501012140	FLAT WASHER		01
26	0521059045	BEARING WITH CURRENT ENCAPSULATED	53	01
27	0503063190	ENCAPSULATED CURRENT MAHM LONG 1060		01
28	0503018829	NYLON CLAMP		01
29	0503010179	5/16" ZN SPRING WASHER		02
30	0503019284	M8 X BOLT		02




Item	Code	Description	See page	QT
01	0531060948	SEED LINE FRAME		01
02	0571012310	ROW LOCK BODY		01
03	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
04	0503010232	5/8" X 1.3/4" BOLT		01
05	0503030168	HAIR PIN		04
06	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
07	0503033728	FIXED SPRING PIN		02
08	0571014704	UPPER AXLE		01
09	0502012768	LINE SUPPORT CLAMP		02
10	0503010811	5/8" UNF SELF ADJUSTING NUT		04
11	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
12	0581019793	LOWER UPPER ARM WITHOUT LUBRICATION		01
13	0581019794	LOWER LOWER ARM WITHOUT LUBRICATION		01
14	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
15	0521068448	FRONT SUPPORT SHORT SEED LINE		01
16	0503010878	5/8" SELF ALIGNING NUT		04
17	0503019273	SLEEVE		08
18	0581018676	SLEEVE ARM LINE SEED		08
19	0503010045	O'RING		08
20	0502012568	UPPER ROCKER ARM		01
21	0503013389	5/8" SELF LOCKING NUT		01
22	0501012140	FLAT WASHER		01
23	0591014726	ENCAPSULATED CURRENT GUIDE		01
24	0503013357	3/8" SELF-ADJUSTING NUT		01
25	0503010237	3/8" X 1" BOLT		01
26	0521059045	BEARING WITH CURRENT ENCAPSULATED	53	01
27	0503063191	ENCAPSULATED CURRENT MAHM SHORT 895		01
28	0503018829	NYLON CLAMP		01
29	0503010179	5/16" ZN SPRING WASHER		02
30	0503019284	M8 X BOLT		02




Item	Code	Description	See page	QT
01	0581018676	SLEEVE ARM LINE SEED		08
02	0503010811	5/8" UNF SELF ADJUSTING NUT		02
03	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		02
04	0503030168	HAIR PIN		03
05	0503033728	FIXED SPRING PIN		02
06	0571014704	UPPER AXLE		01
07	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
08	0502012768	LINE SUPPORT CLAMP		02
09	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
10	0581019795	SEED ARM SUPPORT ROW		01
11	0581019796	LOWER ARM LARGER		01
12	0503010878	5/8" SELF ALIGNING NUT		04
13	0503019273	SLEEVE		08
14	0503010045	O'RING		08
15	0502012568	UPPER ROCKER ARM		01
16	0521069981	FRONT SUPPORT LONG SUPER SEED LINE		01
17	0503018829	NYLON CLAMP		03
18	0521059045	BEARING WITH CURRENT ENCAPSULATED	53	01
19	0503063189	SUPER LONG MAHM ENCAPSULATED CHAIN		01
20	0503010179	5/16" ZN SPRING WASHER		02
21	0503011295	M 8 X 1,25 X 25 BOLT		02




Item	Code	Description	See page	QT
01	0531061301	ENCAPSULATED CURRENT BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0511017303	FLAT WASHER		04
04	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
05	0503012880	1/4" UNC SELF ADJUSTING NUT		02
06	0503013759	NUT		02
07	0503019373	6006 2RS1 NATIONAL BEARING		01
08	0503012858	502075 CLAMPING RING (FOR HOLE)		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01
10	0581019823	BEARING AXLE BODY WITHOUT LUBRICATION		01




Item	Code	Description	See page	QT
01	0531060948	SEED LINE FRAME		01
02	0503010811	5/8" UNF SELF ADJUSTING NUT		02
03	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		02
04	0571012310	ROW LOCK BODY		01
05	0551015826	SEED ROW LOCK GUIDE SLEEV		01
06	0503010232	5/8" X 1.3/4" BOLT		01
07	0503030168	HAIR PIN		01
08	0501012140	FLAT WASHER		01
09	0503013389	5/8" SELF LOCKING NUT		01
10	0591014726	ENCAPSULATED CURRENT GUIDE		01
11	0503010237	3/8" X 1" BOLT		01
12	0503013357	3/8" SELF-ADJUSTING NUT		01



Item	Code	Description	See page	QT
01	0521050118	DEPOSIT SEED BOCAL		01
02	0581014295	FIXING GLOVE		01
03	0511052058	SEED SYSTEM TITANIUM	56	01
04	0503010358	5/16" X 5/8" BOLT		05
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		05
06	0503010179	5/16" ZN SPRING WASHER		05
07	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0503062031	BASE SET		01
02	0503062032	NECK TITANIUM ASSY		01
03	0503062033	OPPOSITE BASE SET		01
04	0503062034	CENTRAL ADAPTER SET		01
05	0503062035	SET FALSE ADAPT CENTER		01
06	0503062036	SUBSET ASSY LOCK BASE		01
07	0503062037	SUBSET ESCOVAFLEX ASSY		01
08	0503062038	ASSY ANTI-LEAP		01
09	0503062039	POLIFLOW TITANIUM ASSY		01
09.	0503016279	POLIFLOW TITANIUM ASSY		01
10	0503062040	DISPLAY ASSY TITANIUM 1050010		01
11	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
12	0503062042	SET BOLT ARTICULADOR		01
13	0503062043	ASSY LIMIT WEIGHT		01
14	0503062044	ASSY MOUNT BOX FOR SEED		01
14A	0503016285	BOLT		05
14B	0503016286	HEX NUT		05
14C	0503016287	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012470	UPPER SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
03	0503012798	5/8" X 2" BOLT		04
04	0503010878	5/8" SELF ALIGNING NUT		04
05	0521055344	LOWER SUPPORT	58	01

LOWER SUPPORT

0521055344




Item	Code	Description	See page	QT
01	0503019277	SLEEVE LUBRICATION SYSTEM		03
02	0503019278	LUBRICANT GLOVE		02
03	0581018679	SLEEVE		01
04	0581018677	SUPPORT DISC AXLE		01
05	0503010361	SPRING PIN		01
06	0551015883	SPRING GUIDES SLEVE		02
07	0503031575	2.5"X 12" X 0.5" COMPRESSION SPRING		02
08	0521068189	SPRING REGULACION		02
09	0501012140	FLAT WASHER		02
10	0503010152	3/4" SELF LOCKING NUT		01
11	0503010806	5/8" X 3" BOLT		02
12	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT		01
13	0503011075	3/4" UNC NUT		02
14	0503010878	5/8" SELF ALIGNING NUT		02
15	0521054844	DPLO 20 CUTTING DISK BOX	59	01
16	0521069351	RIGHT ARM		01
17	0521069350	LEFT ARM		01
18	0503010410	RING		02
19	0502012898	BOTTOM BRACKET		01
20	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		02
21	0503010179	5/16" ZN SPRING WASHER		02
22	0571012370	PROTECTION FRONT		01
23	0581018678	FLANGE WASHER		01




Item	Code	Description	See page	QT
01	0521053697	CUTTING DISK BOX	60	01
02	0607026025	DPLO20X4,5		01

CUTTING DISK BOX


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4	01	
02	0502040872	REGULATORY NUT	01	
03	0503010370	502072 CLAMPING RING (FOR AXLE)	02	
04	0503010590	00674-B SEAL	02	
05	0503019285	RING	02	
06	0503012170	30207 ROLLER BEARING	02	
07	0502020641	BLADE DISC FLANGE	01	
08	0502012862	CUTTING DISK BOX	01	
09	0502040873	CUTTING DISC AXLE	01	
10	0503017755	NUT	01	
11	0503018825	5/16 UNC UNC BOLT	06	
12	0501010694	8.5 X 18 X 1.5 FLAT WASHER	06	
13	0503013816	5/16" LOCKNUT	06	
14	0511017907	1/8" BSPT X 6 PLUG	02	




Item	Code	Description	See page	QT
01	0521058085	REAR WITH DDD LEFT SPICRR	63	01
02	0531050193	DOSING ASSY TITANIUM/TATU	80	01
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04




Item	Code	Description	See page	QT
01	0521058084	REAR WITH RIGHT DDD SPICRR	64	01
02	0531050193	DOSING ASSY TITANIUM/TATU	80	01
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04




Item	Code	Description	See page	QT
01	0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	65	01
02	0502012923	BEATER		01
03	0521056632	DEPTH CONTROL	71	01
04	0591011323	AXLE ARTICULATION WHEEL DEPTH		02
05	0502012920	SUPPORT ADJUSTING		01
06	0502012611	DEPTH CONTROL AXLE		01
07	0591011309	ADJUSTMENT BUSHING		02
08	0591011310	ADJUSTMENT BAR		02
09	0503019275	SLEEVE LUBRICATION SYSTEM		01
10	0581019473	ARTICULATED GLOVE		02
11	0503010045	O'RING		02
12	0503013357	3/8" SELF-ADJUSTING NUT		02
13	0501010984	FLAT WASHER		04
14	0591011326	LOCK PIN		01
15	0571015326	ARTICULATION SLEEVE HANDLE		01
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2" NUT		02
18	0503010019	1/2" SPRING WASHER		04
19	0591011324	SMALLER AXLE		01
20	0591011325	LARGER AXLE		01
21	0511017302	FLAT WASHER		02
22	0503030012	HAIR PIN		02
23	0501011445	FLAT WASHER		04
24	0521056633	MOUNTED RIGHT ARM	72	01
25	0521056631	MOUNTED LEFT ARM	73	01
26	0503012556	1/2" X 1" BOLT		02
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
28	0591011306	ADJUSTMENT LOCK		02
29	0521055093	BODY COMPACTOR	75	01
30	0521054990	LEFT COMPACTOR WHEEL	77	01
31	0521055017	RIGHT COMPACTOR WHEEL	78	01




Item	Code	Description	See page	QT
01	0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	66	01
02	0502012923	BEATER		01
03	0521056632	DEPTH CONTROL	71	01
04	0591011323	AXLE ARTICULATION WHEEL DEPTH		02
05	0502012920	SUPPORT ADJUSTING		01
06	0502012611	DEPTH CONTROL AXLE		01
07	0591011309	ADJUSTMENT BUSHING		02
08	0591011310	ADJUSTMENT BAR		02
09	0503019275	SLEEVE LUBRICATION SYSTEM		01
10	0581019473	ARTICULATED GLOVE		02
11	0503010045	O'RING		02
12	0503013357	3/8" SELF-ADJUSTING NUT		02
13	0501010984	FLAT WASHER		04
14	0591011326	LOCK PIN		01
15	0571015326	ARTICULATION SLEEVE HANDLE		01
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2" NUT		02
18	0503010019	1/2" SPRING WASHER		04
19	0591011324	SMALLER AXLE		01
20	0591011325	LARGER AXLE		01
21	0511017302	FLAT WASHER		02
22	0503030012	HAIR PIN		02
23	0501011445	FLAT WASHER		04
24	0521056633	MOUNTED RIGHT ARM	72	01
25	0521056631	MOUNTED LEFT ARM	73	01
26	0503012556	1/2" X 1" BOLT		02
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
28	0591011306	ADJUSTMENT LOCK		02
29	0521055093	BODY COMPACTOR	75	01
30	0521054990	LEFT COMPACTOR WHEEL	77	01
31	0521055017	RIGHT COMPACTOR WHEEL	78	01




Item	Code	Description	See page	QT
01	0502012928	LEFT EXTENSOR		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0501010984	FLAT WASHER		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 67 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 68 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0502012929	BODY RIGHT		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0501010984	FLAT WASHER		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 67 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 68 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	69	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	70	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01



Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	LOW CUBE FERTILIZER / SEED BOX		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	5/16" ZN SPRING WASHER		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUB DISC - HUB		01
02	0502012896	LOW CUBE FERTILIZER / SEED BOX		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	5/16" ZN SPRING WASHER		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01



Item	Code	Description	See page	QT
01	0502012925	ADJUSTMENT BODY		01
02	0511015976	FLAT WASHER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0503010581	RING		01
05	0502012892	DEPTH CONTROL HANDLE		01
06	0581019526	ARTICULATED AXLE LEVER DEPTH		01
07	0503010302	501019 SEAL RING		01

MOUNTED RIGHT ARM


0521056633




Item	Code	Description	See page	QT
01	0502012926	RIGHT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT GLOVE		02
04	0521055059	WHEEL RAYED ASSY SPA WITHOUT 74 LUBRICATION		01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01

MOUNTED LEFT ARM

0521056631




Item	Code	Description	See page	QT
01	0502012927	LEFT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT GLOVE		02
04	0521055059	WHEEL RAYED ASSY SPA WITHOUT 74 LUBRICATION		01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503030891	RUBBER BAND		01
03	0503010365	NUT		06
04	0503010179	5/16" ZN SPRING WASHER		06
05	0503010337	5/16" NUT		06
06	0521055073	ASSEMBLY DEPTH WHEEL BOX	76	01

BODY COMPACTOR

0521055093




Item	Code	Description	See page	QT
01	0501011753	5/16" X 1-3/4" BOLT	02	
02	0503013816	5/16" LOCKNUT	04	
03	0581015855	SLEEVE	02	
04	0502012877	PRESS WHEEL ADJUSTMENT LEVER	01	
05	0521068661	LEVER	01	
06	0503030878	LEVER CRANK	01	
07	0503031393	1.57" X 5.98" X 0.2"TRACTION SPRING	01	
08	0581019520	AXIS	01	
09	0571812442	COUPLING SHAFT	01	
10	0503010257	1/8" X 1" COTTERPIN	01	
11	0581019511	COVER	01	
12	0503010848	5/16" X 3.1/2" BOLT	02	
13	0503010752	1/2" X 3.1/2" BOLT	01	
14	0503011336	1/2" HEX SELF ADJUSTING NUT	01	
15	0503030190	0.5" X 1.6" X 0.05" SPRING	01	
16	0581019510	AXIS	01	
17	0581019512	PLATE TOP	01	
18	0503019351	LUBRICANT GLOVE	02	
19	0521069591	LEFT SIDE	01	
20	0581019548	RIGHT SIDE BODY	01	




Item	Code	Description	See page	QT
01	0581019528	BOX WHEEL DEPTH SPA WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
11	0581019529	DEPTH REGULATOR SHAFT		01

LEFT COMPACTOR WHEEL


0521054990




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	79	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	79	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521056639	SEED ROW TRANSMISSION	81	01
02	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
03	0502012921	BASE FIXING SYSTEM		01
04	0591014600	ENCAPSULATED CURRENT FIXER		01
05	0503014876	NUT PARLOCK 1/4"		02
06	0503010461	1/4" X 1" BOLT		02
07	0511052024	FAST CLOSING SET	82	01




Item	Code	Description	See page	QT
01	0502012932	MINOR SIDE	01	
02	0503017046	BEARING	02	
03	0503011410	ROLLER BEARING	02	
04	0591011321	AXLE GEAR	01	
05	0591011322	SPACER	01	
06	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50	01	
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	
08	0503010025	3/8" SPRING WASHER	01	
09	0503010179	5/16" ZN SPRING WASHER	04	
10	0503011945	503050 CLAMPING RING (FOR AXLE)	01	
11	0503010420	BOLT	02	
12	0503011053	5/16" X 3" C S 6.5 ZN BOLT	04	
13	0502012919	GRAGGER	01	
14	0502012933	LARGER SIDE	01	
15	0502012930	CONICAL GEAR	01	
16	0502012931	CONICAL GEAR	01	
17	0503010585	0,24" X 1.18" SPRING PIN	01	



Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0521069328	RIGHT FERTILIZER CONDUCTOR		01
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0591011713	SHORT SUPPORT BODY CONDUCTOR FERTILIZER		01
02	0531060359	FERTILIZER CONDUCTOR		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
04	0511017302	FLAT WASHER		02
05	0503011336	1/2" HEX SELF ADJUSTING NUT		02
06	0503010589	1/2" UNC SELF ADJUSTING NUT		02
07	0503014007	1/2" X 1-1/4" BOLT		02

ASSY LONG FERTILIZER CONDUCTOR


0521056854



Item	Code	Description	See page	QT
01	0591011676	BODY LONG CONDUCTOR FERTILIZER		01
02	0531060359	FERTILIZER CONDUCTOR		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
04	0511017302	FLAT WASHER		02
05	0503011336	1/2" HEX SELF ADJUSTING NUT		02
06	0503010589	1/2" UNC SELF ADJUSTING NUT		02
07	0503014007	1/2" X 1-1/4" BOLT		02




Item	Code	Description	See page	QT
01	0503016204	CORN DISK 12 ORANGE		01
02	0503016398	TITANIUM RING CORN / SOY (YELLOW FLAT)		01
03	0503016399	TITANIUM RING CORN (GREEN)		01
04	0503016400	TITANIUM RING CORN (GREY)		01
05	0503016401	TITANIUM RING CORN (BLUE)		01



Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016218	DISC OF SOYBEAN		01
03	0503016403	TITANIUM RING FOR SOYBEAN (LILAC)		01
04	0503016404	TITANIUM RING FOR SOYBEAN (PURPLE)		01
05	0503016406	TITANIUM RING FOR SOYBEAN (ORANGE)		01
06	0503016407	TITANIUM RING FOR SOYBEAN		01


RIGHT SEMI-ASSEMBLED MARKER

0521059255



Item	Code	Description	See page	QT
01	0521062492	RIGHT SUPPORT SMALLER		01
02	0531061364	FOREARM		01
03	0541012195	ARM BEFORE ARTICULICION AXLE		01
04	0503011052	1.1/4" X 0.77" CASTLE NUT		03
05	0503010038	3/16 X 2 COTTERPIN		07
06	0541012194	INTERMEDIATE ARM ARTIC ALXE		01
07	0511065480	RIGHT INTERMEDIATE ARM		01
08	0531061365	HIGHER LEVER		01
09	0501011445	FLAT WASHER		05
10	0501014063	25 X 55 COUPLING SHAFT		05
11	0503010523	1/4" X 2" COTTERPIN		05
12	0521064440	MARKER ARM LINE 1000		01
13	0541012193	MARK ARM ARTICULACCION ALXE		01
14	0531061366	EXTENSOR 1390		01
15	0541015917	MARK ARM GUIDE		01
16	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
17	0541012196	SMALLER LEVER		01
18	0511065487	REGULATOR SPINDLE		01
19	0511065475	ADJUSTMENT ROD		01
20	0511058227	HYDRAULIC CYLINDER 38,10 X 63,50 X 608 X 290	89	01
21	0541015714	CYLINDER ARTICULACCION ALXE		01
22	0501019435	32 X 50 X 1.5 FLAT WASHER		04
23	0551016251	PIVOT SHAFT		01
24	0511017592	11.8" X 1.6" TRANSPORT LOCK		01
25	0501068994	0.3" X 3.1" LOCK PIN		01
26	0503030168	HAIR PIN		01
27	0503010027	5/8" SPRING WASHER		05
28	0503010013	5/8" NUT		04
29	0503010233	5/8" X 2-1/2" BOLT		04
30	0511042494	ROW MARKER DISC ASSY	90	01
31	0503010002	1800 GREASE FITTING		03


Item	Code	Description	See page	QT
32	0501081900	HOSE 3/8 X 1800 TR-TC		01
33	0501082092	HOSE 3/8 X 1250 TR-TR		01
34	0503011070	BEATER		01
35	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
36	0551019213	FLAT WASHER		01




Item	Code	Description	See page	QT
001	0521066554	SHIRT 72.85 X 522		01
002	0521066555	ROD 38,10 X 480		01
003	0503010002	1800 GREASE FITTING		02
004	0551016274	HYDRAULIC CYLINDER ADAPTER		02
005	0581010669	EMBOLUS 63.50 X 40 USAP		01
006	0503018005	RING		01
007	0503010558	7/8" NUT		01
008	0503010605	O'RING		01
009	0503010163	D-1500 SCRAPER RING		01
010	0502010471	MOBILE COVER		01
011	0581010668	RING SUPPORT		01
012	0503018004	RING		01
013	0503018003	GASKET		01
014	0503018163	BACK-UP RING		02
015	0503018162	O'RING		02
016	0503030385	CYLINDER PLUG N-002		02

ROW MARKER DISC ASSY


0511042494




Item	Code	Description	See page	QT
01	0502011907	DEPTH CONTROL WHEEL HUB		01
02	0503010269	6204 BALL BEARING		02
03	0503010689	SEAL 00763-BR		01
04	0503011105	SEAL RING		01
05	0501013636	SPACING SLEEVE		01
06	0602023110	DR16X3 NOTCHED DISC BLADE		01
07	0503010358	5/16" X 5/8" BOLT		04
08	0503010179	5/16" ZN SPRING WASHER		04
09	0503010337	5/16" NUT		04
10	0511065478	ROW MARKER DISC AXLE		01
11	0503010878	5/8" SELF ALIGNING NUT		01
12	0521019178	COVER DEPTH		01
13	0503030757	2.9" X 2" X 0.02" JOINT		01
14	0503814729	BOLT		03
15	0503011441	SPRING WASHER		03
16	0503010691	1/4" GREASE FITTING		01
17	0501069226	ROW MARKER ROD STOP		01
18	0501011778	3/8" X 2-1/2" BOLT		04
19	0503010025	3/8" SPRING WASHER		04
20	0503010026	3/8" NUT		04
21	0503010023	3/4" SPRING WASHER		01
22	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0531060357	CENTRAL FRAME		01
02	0521050019	TIGHTENING PLATE WITH FIXING INTERNAL	92	02
03	0503010131	3/16" X 1-1/2" COTTERPIN		01
04	0521011132	FLAT WASHER		01
05	0521052189	38,10 X 63,50 X 386 X 148 HYDRAULIC CYLINDER	93	01
06	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0571015217	TUBE ADJUSTMENT PLATE		01
02	0503010027	5/8" SPRING WASHER		08
03	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		08




Item	Code	Description	See page	QT
01	0521068383	CYLINDER CASE		01
02	0581010670	CORPO HASTE 38,10 X 345		01
03	0511070058	GUIDE HIDRAULIC		01
04	0503010163	D-1500 SCRAPER RING		01
05	0502010471	MOBILE COVER		01
06	0581010668	RING SUPPORT		01
07	0503018004	RING		01
08	0503018003	GASKET		01
09	0503018163	BACK-UP RING		02
10	0503018162	O'RING		02
11	0503030385	CYLINDER PLUG N-002		02
12	0502012837	PISTON		01
13	0503018005	RING		01
14	0503011109	2-119 N 3006-9B O'RING		01
15	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01



Item	Code	Description	See page	QT
01	0571013341	HEX AXLE		02
02	0561015837	SLEEVE 31,75		01
03	0503010523	1/4" X 2" COTTERPIN		01
04	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		04
04A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
04B	0503010256	3/8" X 3/4" BOLT		01

CENTRAL WHEEL WITH TRANSMISSION

0521055329




Item	Code	Description	See page	QT
01	0521064554	LEFT WHEEL FORK		01
02	0521064543	WHEEL SUPPORT		01
03	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
04	0561019929	FLAT WASHER		01
05	0503010523	1/4" X 2" COTTERPIN		02
06	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
07	0551014508	FLAT WASHER		01
08	0503010010	1/4" X 2.1/2" COTTERPIN		01
09	0521069575	FLANGE CYLINDER HYDRAULIC FIXER		02
10	0503010920	1/2" X 1.1/2" BOLT		04
11	0503010019	1/2" SPRING WASHER		04
12	0503010060	1/2" NUT		04
13	0502012731	WHEEL HOLDER		02
14	0503010571	1/4" X 1.1/2 COTTERPIN		02
15	0503011075	3/4" UNC NUT		04
16	0503012334	3/4" UNC X 3.1/2" BOLT		04
17	0511054492	STUB SHAFT HUB	97	01
18	0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE		01
19	0503011052	1.1/4" X 0.77" CASTLE NUT		02
20	0501017779	32 X 60 X 4.75 FLAT WASHER		02
21	0501010630	1.1/2" CASTLE NUT		01
22	0503010003	1845 GREASE FITTING		03
23	0503010882	BOLT		01
24	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
25	0503033458	CURRENT 6 X 17 ELOS		01
26	0503010337	5/16" NUT		01
27	0511068422	WHEEL GEAR DOBLE		01
28	0551018571	FLAT WASHER		02
29	0503010002	1800 GREASE FITTING		01
30	0571015153	COVER PROTECTION WHEELED LARGER		01
31	0503010849	3/8" X 1-1/2" BOLT		02

CENTRAL WHEEL WITH TRANSMISSION

0521055329


Item	Code	Description	See page	QT
32	0503010209	3/8" UNC BUTTERFLY NUT		02
33	0503010025	3/8" SPRING WASHER		02
34	0501010984	FLAT WASHER		02
35	0511054463	WHEEL TENSIONER SUPORT CENTRAL	12	01
36	0511054464	WHEEL FORK TENSIONER	13	02
37	0511054499	TRANSMISSION OF LARGER CENTRAL EXCHANGE	98	01
38	0503016419	50-1 CHAIN X 128 LINK + REDUCION		01
39	0503014507	CHAIN LINK + MENDING		01
40	0581017245	AXLE BODY		01
41	0531012874	FLAT WASHER		02
42	0521054953	HYDRAULIC CYLINDER 50,80 X 127,00 X 205	8	01




Item	Code	Description	See page	QT
01	0521064554	LEFT WHEEL FORK		01
02	0521064543	WHEEL SUPPORT		01
03	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
04	0561019929	FLAT WASHER		01
05	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
06	0551014508	FLAT WASHER		01
07	0521069575	FLANGE CYLINDER HYDRAULIC FIXER		02
08	0503010920	1/2" X 1.1/2" BOLT		04
09	0503010019	1/2" SPRING WASHER		04
10	0503010060	1/2" NUT		04
11	0502012731	WHEEL HOLDER		02
12	0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	11	01
13	0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE		01
14	0503011052	1.1/4" X 0.77" CASTLE NUT		02
15	0501017779	32 X 60 X 4.75 FLAT WASHER		02
16	0501010630	1.1/2" CASTLE NUT		01
17	0503010003	1845 GREASE FITTING		03
18	0503010882	BOLT		01
19	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
20	0503033458	CURRENT 6 X 17 ELOS		01
21	0503010337	5/16" NUT		01
22	0581017245	AXLE BODY		01
23	0531012874	FLAT WASHER		02
24	0521054953	HYDRAULIC CYLINDER 50,80 X 127,00 X 205	8	01
25	0503010571	1/4" X 1.1/2 COTTERPIN		02
26	0503010523	1/4" X 2" COTTERPIN		03
27	0503012334	3/4" UNC X 3.1/2" BOLT		04
28	0503011075	3/4" UNC NUT		04

STUB SHAFT HUB


0511054492



Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB	01	
02	0571015180	WHEEL AXLE	01	
03	0503010007	3982/3920 ROLLER BEARING	01	
04	0503010059	33287/33462 ROLLER BEARING	01	
05	0503010009	RETAINER 00573-B	01	
06	0503010086	SEAL 0009B-B	01	
07	0551014473	GLOVE	01	
08	0503012702	KM-12 NUT	02	
09	0503012703	LOCK WASHER	01	
10	0503010002	1800 GREASE FITTING	01	
11	0503011444	SPRING WASHER	08	
12	0503011339	M22 X 1,5 X 72 BOLT	08	
13	0503014048	22 X 1.5 HEX NUT	08	
14	0503010363	5/16" X 1" BOLT	08	
15	0521064564	30Z GEAR	01	




Item	Code	Description	See page	QT
01	0521064557	SUPPORT SET TRANSMISSION WHEEL SIDE		01
02	0571015141	FIXER CENTRAL TRANSMISSION		04
03	0571015151	SUPPORT BEARING		01
04	0521061795	27Z GEAR		01
05	0501053654	DOUBLE BEARING TRANSMISSION SEED 3/4	99	01
06	0503010025	3/8" SPRING WASHER		08
07	0503010026	3/8" NUT		08
08	0503010019	1/2" SPRING WASHER		03
09	0503010060	1/2" NUT		03
10	0503010337	5/16" NUT		02
11	0503011953	5/16" X 1" BOLT		02
12	0503010179	5/16" ZN SPRING WASHER		02
13	0503010707	501030 CLAMPING RING (FOR AXLE)		02
14	0503010741	1/2" X 2-3/4" BOLT		03
15	0511054461	STRETCHER TOP TRANSMISSION SWIRLED	15	02



Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		02
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01


ASSY CENTRAL FERTILIZER EXCHANGE

0521056860




Item	Code	Description	See page	QT
01	0521064562	CENTRAL GEAR BOX SUPPORT		01
02	0501056271	BEARING CLOSED	20	03
03	0571015170	CENTRAL GEAR BOX DRIVER AXLE		01
04	0503030303	SUPPORT WASHER		04
05	0591011682	CENTRAL EXCHANGE MOVED AXIS		01
06	0503010179	5/16" ZN SPRING WASHER		09
07	0503010337	5/16" NUT		09
08	0501010984	FLAT WASHER		03
09	0503011953	5/16" X 1" BOLT		06
10	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
11	0503010292	0.2" X 1.6" SPRING PIN		04
12	0503010395	1/2" X 1-1/4" BOLT		02
13	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		02
14	0503012389	1/2 BALL		02
15	0503010060	1/2" NUT		06
16	0502011758	REAR TENSIONER LEVER		01
17	0503010002	1800 GREASE FITTING		01
18	0503010025	3/8" SPRING WASHER		05
19	0503010683	0.2" X 1.2" SPRING PIN		01
20	0501048790	AXLE WITH LINK ASSY	22	01
21	0503012204	40-1 CHAIN X 82 LINK + RED		01
22	0501052778	CHAIN TENSIONER ASSY	101	01
23	0521018630	1.4" X SQUARE 0.8" WASHER		08
24	0511065209	20Z GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0511054489	LEFT TENSIONER CENTRAL EXCHANGE	102	01
27	0511060396	DRIVE/DRIVEN AXLE CONE		02
28	0571015172	CENTRAL GEAR BOX COVER		01
29	0551018585	CENTRAL GEAR BOX COVER SLEEVE		02
30	0503010371	5/16" X 1" BOLT		02
31	0503010386	CABLE		01


Item	Code	Description	See page	QT
32	0511056179	CLUTCH WITH CARDAN CENTRAL	104	01
33	0503010172	M10 X 1,5 X 25 BOLT		04
34	0511069512	20Z GEAR		01
35	0503011268	3/8" X 2-1/2" BOLT		01
36	0503013357	3/8" SELF-ADJUSTING NUT		01
37	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
38	0511017302	FLAT WASHER		08
39	0503010019	1/2" SPRING WASHER		04
40	0503011082	C1/2" X 1.3/4" SCREW		04
41	0503011321	40-1 CHAIN X 94 LINK + REDUCTION		01
42	0511067501	26Z GEAR		01
43	0501056443	BEARING ASSY GEAR BOX	105	01
44	0503010256	3/8" X 3/4" BOLT		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503010302	501019 SEAL RING		02
03	0503031805	11Z 1/2" GEAR		02
04	0503031367	SPRING		01
05	0511061794	CHAIN TENSIONER		01




Item	Code	Description	See page	QT
01	0501056573	17Z GEAR ASSY	103	01
01A	0502012367	17Z X P 1/2" GEAR INTERM		01
01B	0503012882	BEARING		01
01C	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02	0503010019	1/2" SPRING WASHER		01
03	0503010060	1/2" NUT		01
04	0571015167	SLEEVE NYLON Ø21 X Ø31,75 X 36,50		01
05	0503010479	BOLT		01
06	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503019355	BEARING 6202 2RS1		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0503062231	CLUTCH		01
02	0503062272	CARDAN WITHOUT PROTECTION		01
03	0503013357	3/8" SELF-ADJUSTING NUT		02
04	0503011268	3/8" X 2-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	19	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0531060360	BOX SUPPORT		01
02	0521056857	ECU APT / TVT BOX WITH EXCHANGE	107	01
03	0503010589	1/2" UNC SELF ADJUSTING NUT		04
04	0511017302	FLAT WASHER		04
05	0561016468	FASTENER		02




Item	Code	Description	See page	QT
01	0503010257	1/8" X 1" COTTERPIN		02
02	0503010026	3/8" NUT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010144	1/4" NUT		08
05	0503010143	1/4" SPRING WASHER		08
06	0503010237	3/8" X 1" BOLT		04
07	0521068017	BOX BODY APT/TVT		01
08	0571017090	ROD BOX		01
09	0521068016	BOX COVER		01
10	0503018171	FAST LOCK ASSY		02
11	0503010461	1/4" X 1" BOLT		04
12	0503010282	1/4" X 3/4" BOLT		04




Item	Code	Description	See page	QT
01	0521069723	RH SEED SILO CENTRAL SUPPORT		01
02	0503062962	SILO SEED 05 ASSY MOUTH		01
03	0521051407	FIXER SILO FERTILIZER	34	08
04	0511017302	FLAT WASHER		06
05	0503010920	1/2" X 1.1/2" BOLT		06
06	0521050525	FIXER FERTILIZER CONDUCTOR	32	05
07	0521055365	SEED CONDUCTOR	33	05
08	0503010589	1/2" UNC SELF ADJUSTING NUT		06

ASSY LEFT CENTRAL SEED BOX


0521055367




Item	Code	Description	See page	QT
01	0521069724	SUPPORT CENTER		01
02	0503062962	SILO SEED 05 ASSY MOUTH		01
03	0521055365	SEED CONDUCTOR	33	05
04	0511017302	FLAT WASHER		06
05	0503010920	1/2" X 1.1/2" BOLT		06
06	0521051407	FIXER SILO FERTILIZER	34	08
07	0521050525	FIXER FERTILIZER CONDUCTOR	32	05
08	0503010589	1/2" UNC SELF ADJUSTING NUT		06



Item	Code	Description	See page	QT
01	0503062391	SILO FERTILIZER 05 MOUTHS		02
02	0521056858	ASSY 5 MOUTH LEFT CENTRAL SUPPORT	111	01
03	0521056859	CENTRAL SUPPORT RIGHT 5 MOUTH ASSY	112	01
04	0511017302	FLAT WASHER		12
05	0503010589	1/2" UNC SELF ADJUSTING NUT		12
06	0503010920	1/2" X 1.1/2" BOLT		12
07	0521051407	FIXER SILO FERTILIZER	34	16
08	0503010010	1/4" X 2.1/2" COTTERPIN		01
09	0502012007	SQUARE SLEEVE		01
10	0503034396	FERTILIZER SIDE COVER		10
11	0503010362	1/8" X 1.1/4" COTTERPIN		10




Item	Code	Description	See page	QT
01	0521054282	BEARING	36	02
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	160	01
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	35	04
04	0581019781	AXE CARRÉ		01
05	0503030275	AGRICULTURAL BEARING		05
06	1902010685	18Z CONICAL GEAR		05
07	0503030303	SUPPORT WASHER		02
08	0511059491	AXLE HOLDER	113	02
09	0521069706	SUPPORT CENTER		01
10	0503010026	3/8" NUT		20
11	0503010025	3/8" SPRING WASHER		20
12	0501010942	3/8" X 1-1/4" BOLT		20




Item	Code	Description	See page	QT
01	0521069707	SUPPORT CENTER		01
02	0521054282	BEARING	36	03
03	0503030303	SUPPORT WASHER		04
04	0511059491	AXLE HOLDER	113	04
05	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	160	04
06	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	35	01
07	0503030275	AGRICULTURAL BEARING		05
08	1902010685	18Z CONICAL GEAR		05
09	0581019786	SQUARE SHAFT		01
10	0503010025	3/8" SPRING WASHER		20
11	0501010942	3/8" X 1-1/4" BOLT		20
12	0503010026	3/8" NUT		20
13	0521056861	CENTRAL EXCHANGE STRETCHER FERTILIZER	114	01
14	0511061759	22Z P12,70 FQ 3/4" GEAR		01

AXLE HOLDER


0511059491




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
03	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
04	0503011441	SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0501056573	17Z GEAR ASSY	103	01
02	0591011681	STRETCHER SPACER GLOVE		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0511017302	FLAT WASHER		01
06	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0581017801	PLATFORM ASSY		02
02	0521054279	PLATFORM FIXER	42	04




Item	Code	Description	See page	QT
01	0521069356	HANDRAIL BODY		02
02	0511059383	INTERNAL FIXER ASSY HANDLE	117	04
03	0581019811	TUBE		02
04	0581012718	HANDRAIL		02
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0503010237	3/8" X 1" BOLT		04



Item	Code	Description	See page	QT
01	0502012857	EXTERNAL FIXER HANDRAIL		01
02	0502012858	INTERNAL FIXER HANDRAIL		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		01
04	0503015490	SELF-LOCKING NUT 7/16		01




Item	Code	Description	See page	QT
01	0503019303	CONTROL PANEL		01
02	0503019305	WHIP		01
03	0503019307	CABLE TRACTOR HEADLIGHT		01
04	0503019304	WIRES BLOCK COMMAND TRACTOR		01
05	0521051707	ASSY PANEL FIXER PLATE	119	01
06	0503016234	TRIMBLE FIXING WINDOW		01
07	0503016452	FIXING SUPPORT AG500 TRIMBLE		01




Item	Code	Description	See page	QT
01	0581015186	ELECTRIC PANEL FIXING PLATE		01
02	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
03	0503010669	FLAT WASHER		02
04	0503010667	3/16" NUT		02
05	0503010668	3/16" SPRING WASHER		02

ARTICULATION ARM LEFT ASSY


0521052149




Item	Code	Description	See page	QT
01	0521068342	ARM PIVOT		01
02	0571017893	HORIZONTAL ARTICULATION SHAFT		01
03	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
04	0571011767	LISA WASHER 125 X 88 X 4.76		01
05	0503010002	1800 GREASE FITTING		01
06	0503010408	7/8" SPRING WASHER		01
07	0503015322	BOLT 7/8		01
08	0503032042	SHEET POLYETHYLENE		01
09	0503010814	5/16 BOLT		14
10	0503011198	C3/4" X 6" SCREW		01
11	0571011825	BUSHING		02
12	0503010004	1890 GREASE FITTING		01
13	0503011255	3/4" LOCK NUT		01




Item	Code	Description	See page	QT
01	0521063778	RELATION AVEC AXE VERTICAL LATCH	01	
02	0571011767	LISA WASHER 125 X 88 X 4.76	01	
03	0503010408	7/8" SPRING WASHER	01	
04	0503015322	BOLT 7/8	01	
05	0571017893	HORIZONTAL ARTICULATION SHAFT	01	
06	0503011198	C3/4" X 6" SCREW	01	
07	0503011255	3/4" LOCK NUT	01	
08	0503010004	1890 GREASE FITTING	01	
09	0503032042	SHEET POLYETHYLENE	01	
10	0503010814	5/16 BOLT	14	
11	0503010002	1800 GREASE FITTING	01	
12	0521068343	ARM PIVOT	01	
13	0571011825	BUSHING	02	




Item	Code	Description	See page	QT
01	0511058241	HYDRAULIC CYLINDER 50,80 X 114,30 X 964 X 638	123	02
02	0521017351	1-1/4" X 8" BOLT		02
03	0503013321	SCREW 1.1/4 UNF X 7 C S G.8 ZN		02
04	0503010817	1.1/4" SELF LOCKING NUT		04




Item	Code	Description	See page	QT
01	0521066625	SHIRT 114.30 X 851	01	
02	0521066559	EXTENSOR 876 X 50.80 (2)	01	
03	0503010002	1800 GREASE FITTING	03	
04	0503030385	CYLINDER PLUG N-002	02	
05	0581010658	PISTON 50,80 X 114,30	01	
06	0503018164	GASKET 2500-4000-375 B (1150 AGEL)	02	
07	0503018165	GUIDE RING W2-4500-590	01	
08	0503010290	SELF ADJUSTING 1.1/2" UNF NUT	01	
09	0503010141	2-226 N 3006-9B O'RING	01	
10	0502011222	0.56" END CAP	01	
11	0503010952	W2-2250-500 RING	01	
12	0581010659	2" X 4" RING SUPPORT	01	
13	0503010039	D-2000 SCRAPER RING	01	
14	0503018026	1870-2000-375 B GASKET	01	
15	0503018024	RING BS	01	
16	0503011892	O' RING, 2-346 N 3006-9B	02	
17	0503011893	BACK-UP RING, 8-346	02	




Item	Code	Description	See page	QT
01	0521059316	CENTRAL DUCT ASSY FERTILIZER/SEED/APT	125	01
02	0503063242	COMMAND BLOCK		01
03	0521057013	TRIPLE DIVISER VALVE BRP00079 WITH NIPLES	127	01
04	0531050057	MH SEQUENTIAL VALVE SUPPORT WITH FIXATION	128	01
05	0531050058	SUPPORT ASSY BLOCK/VALVES	129	01
06	0521052155	SEQUENTIAL VALVE ASSY	130	01
07	0531050098	HOSE ASSY ARTICULATION FERTILIZER/SEED	131	01
08	0521055274	HEAD HOSE ASSY		01
09	0531050097	ASSY HOSE LIFTING FERTILIZER/SEED	132	01
10	0521058634	HOSE KIT	133	01
11	0521055402	HOSE KIT MH/CH 12910	134	01
12	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	135	02
13	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0521069163	OIL TUBE		02
02	0521069164	OIL PIPE R.7/8		10
03	0521069009	OIL DUCT		01
04	0521069275	OIL TUBE		02
05	0581018407	BODY FASTENER 2 DUCTS		04
06	0581012746	CENTRAL DUTY FASTENER		08
07	0521069157	OIL TUBE		02
08	0521053537	CENTRAL REAR DUCT SUPPORT	126	04
09	0503010237	3/8" X 1" BOLT		12
10	0503011268	3/8" X 2-1/2" BOLT		04
11	0503010481	BOLT		04
12	0503010025	3/8" SPRING WASHER		20
13	0503010026	3/8" NUT		20
14	0591010127	SUPPORT LEFT DISTRIBUTOR		02
15	0581014867	SIDE DUTY SUPPORT		02




Item	Code	Description	See page	QT
01	0571019615	FITTING 1/2 UNC 130 X 198 ZN		01
02	0511017302	FLAT WASHER		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0503010025	3/8" SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581017885	SUPPORT BODY		01
08	0503011141	3/8" X 2-3/4" BOLT		01
09	0581018407	BODY FASTENER 2 DUCTS		01




Item	Code	Description	See page	QT
01	0503019426	TRIPLE FLOW DIVISING VALVE		01
02	0581013111	NIPLE R 1.1/6 UN X 1.5/16 12 WIRES		01
03	0503014724	2-215 N 3006-9B O'RING		01
04	0501010984	FLAT WASHER		04
05	0503010045	O'RING		03
06	0511010111	7/8" NIPPLE		02
07	0503013357	3/8" SELF-ADJUSTING NUT		04
08	0503010237	3/8" X 1" BOLT		04
09	0501012520	1-1/16" X 7/8" NIPPLE		01




Item	Code	Description	See page	QT
01	0591016361	VALVE SUPPORT		01
02	0501010984	FLAT WASHER		02
03	0503010237	3/8" X 1" BOLT		02
04	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0591016376	VALVE SUPPORT		01
02	0503010172	M10 X 1,5 X 25 BOLT		03
03	0503010025	3/8" SPRING WASHER		03
04	0511017302	FLAT WASHER		02
05	0591016360	BLOCK SUPPORT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		02
07	0503011082	C1/2" X 1.3/4" SCREW		02



Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501012109	3/4" X 9/16" NIPPLE		04
03	0501010617	3/4" NIPPLE		02
04	0503010190	2-114 N 3006-9B O'RING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02
07	0501010984	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		02
09	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0501080437	3/8 X 1900 TC-TC HOSE		01
02	0501080968	3/8 X 1800 TC-TC HOSE		01
03	0501080514	3/8 X 1700 TC-TC HOSE		02
04	0501080931	3/8" X 39" TC-TC HOSE ASSY		01
05	0501080370	TC-TC HOSE ASSY		01




Item	Code	Description	See page	QT
01	0501081837	3/8 X 700 TR-TC HOSE	04	
02	0501080700	3/8 X 650 TC-TC HOSE	02	
03	0501080599	3/8 X 650 TR-TC HOSE	02	
04	0501081838	3/8 X 1000 TR-TC HOSE	04	
05	0501080065	3/8 X 1200 TC-TC HOSE	01	
06	0501080675	3/8 X 1000 TC-TC 180G HOSE	03	
07	0501080105	3/8 X 700 TR-TR HOSE	04	
08	0501080302	TR-TC HOSE ASSY	01	
09	0501080714	3/8 X 1600 TR-TC HOSE	01	
10	0501082204	3/4 X 2750 TR-TR HOSE	02	
11	0501081288	3/4 X 500 TR-TC HOSE	01	
12	0521053712	3/4 X 5900 TR-TM BLACK/RED HOSE	01	
12A	0501082205	3/4 X 5900 TR-TM HOSE	01	
12B	0503034492	HYDRAULIC HOSE GRIP (BLACK)	01	
12C	0503034495	HYDRAULIC HOSE GRIP (RED)	01	
12D	0503018952	PLASTIC BOLT	06	
13	0521053707	3/4 X 5900 TR-TM BLACK/BLUE HOSE	01	
13A	0501082205	3/4 X 5900 TR-TM HOSE	01	
13B	0503034492	HYDRAULIC HOSE GRIP (BLACK)	01	
13C	0503034494	HYDRAULIC HOSE GRIP (BLUE)	01	
13D	0503018952	PLASTIC BOLT	06	
14	0501080485	3/8 X 1100 TR-TC HOSE	02	
15	0501080200	3/4 X 1600 TR-TC HOSE	01	
16	0501080150	3/8 X 800 TR-TC HOSE	02	
17	0501080023	3/4 X 1700 TR-TC HOSE	02	
18	0501081160	HOSE 3/4 X 1350 TR-TC	01	

HOSE KIT


0521058634




Item	Code	Description	See page	QT
01	0501080094	1/2 X 1800 TR-TC HOSE		01
02	0501081834	1/2 X 1500 TR-TC HOSE		02
03	0501080272	1/2 X 2700 TR-TC HOSE		01
04	0501081041	1/2 X 2400 TR-TC HOSE		02
05	0501081349	1/2 X 1050 TC-TC 180G 1G138646 HOSE		01
06	0521052567	1/2 X 5900 TR-TM GRAY/RED HOSE		01
06A	0501081841	1/2 X 5900 TR-TM HOSE		01
06B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
06C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
06D	0503018952	PLASTIC BOLT		06
07	0521052566	1/2 X 5900 TR-TM GRAY/BLUE HOSE		01
07A	0501081841	1/2 X 5900 TR-TM HOSE		01
07B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
07C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
07D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0501081820	3/8 X 1700 TR-TC HOSE		02
02	0501081851	3/8 X 1400 TR-TC HOSE		02
03	0501080105	3/8 X 700 TR-TR HOSE		04
04	0501080352	3/8 X 1400 TR-TR HOSE		04
05	0501081975	3/8 X 1450 TR-TC HOSE		02
06	0501080297	3/8 X 2800 TR-TR HOSE		02
07	0521052592	3/8 X 5900 TR-TM PURPLE/BLUE HOSE		01
07A	0501082100	3/8 X 5900 TR-TM HOSE		01
07B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
07C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
07D	0503018952	PLASTIC BOLT		01
08	0521052593	3/8 X 5900 TR-TM PURPLE/RED HOSE		01
08A	0501082100	3/8 X 5900 TR-TM HOSE		01
08B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
08C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
08D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01



Item	Code	Description	See page	QT
01	0581017745	TROUGH 30 X 55 X 2420		01
02	0581017744	GUTTER 30 X 55 X 1530		01
03	0581017967	GUTTER 24 X 46 X 1200		02
04	0521055102	BIGGEST FULL GUTTER SUPPORT	45	04




Item	Code	Description	See page	QT
01	0503063228	KIT INTELLIAG 32L 45/50		01
01A	0503015065	MASTER CONTROL MODULE		01
01B	0503015066	CABLE CONTROL MASTER MODULE		01
01C	0503015209	MODULES WSMB 18L ISOBUS 4679811100S1		01
01D	0503015210	CABLE MODULO WSMB ISOBUS 467981200		01
01E	0503016322	SIMPLE MONITOR CABLE		01
01F	0503015071	CONCTOR		01
01G	0503062533	MONITORING CABLE		01
01H	0503017443	ANTENNA GPS PM 400		01
01I	0503017031	CLEANING BRUSH		01
01J	0503015218	SENSOR FOTOELE PM 400		32
02	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	138	03
03	0511056972	FILTER HYDAC	139	01
04	0503019291	SUPPORT SENSOR		01
05	0503013100	NYLON CLAMP		96
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		480




Item	Code	Description	See page	QT
01	0503018768	MOTOR OMP 80		01
02	0503018769	MOTOR SPEED SENSOR		01
03	0503010045	O'RING		02
04	0503019320	VALVE		01
05	0501010590	NIPPLE		02

FILTER HYDAC


0511056972




Item	Code	Description	See page	QT
01	0503016376	FILTER SPRING		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8"NF UNF NIPPLE		02
04	0503012341	T 7/8" ADAPOR GIRAT NUT		01
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521054283	HEADLIGHT WITH SUPPORT	141	03
02	0521059116	LIGHTHOUSE WITH LARGER SUPPORT	142	02
03	0521059393	LED FLASHLIGHT WITH FIXATION SUPPORT	143	02
04	0521057880	ELECTRIC ASSEMBLY BCE (ASSEMBLED) MEC 15MT/5F-L		01
04A	0503019329	COMMAND PANEL		01
04B	0503019061	WHIP		01
04C	0503019060	WHIP		01
04D	0503019390	WHIP BLOCK COMMAND IMPLEMENT		01
04E	0503019330	WHIP		01
04F	0503019694	LED LANTERN EXTENSOR WHIP 15M 4320.8 BCE		01
05	0503018829	NYLON CLAMP		20
06	0503019902	NYLON CLAMP 7,8X1,8X225 MM		100
07	0521055426	ASSY ELECTRICAL BOX SUPPORT	144	01
08	0521052143	CLUTCH INDUCTIVE SENSOR ASSEMBLY	145	01
09	0503013029	3/8" X 3/4" BOLT		04
10	0503013357	3/8" SELF-ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0581018571	REAR HEADLIGHT SUPPORT		01
02	0503018738	LIGHTHOUSE		01
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010358	5/16" X 5/8" BOLT		02
05	0503013759	NUT		02
06	0503010025	3/8" SPRING WASHER		02
07	0503010026	3/8" NUT		02
08	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0591015132	BIGGEST REAR HEADLIGHT SUPPORT		01
02	0503018738	LIGHTHOUSE		01
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010358	5/16" X 5/8" BOLT		02
05	0503013759	NUT		02
06	0503010025	3/8" SPRING WASHER		02
07	0503010026	3/8" NUT		02
08	0503010237	3/8" X 1" BOLT		02



Item	Code	Description	See page	QT
01	0591013259	LED FLASHLIGHT SUPPORT		01
02	0503019579	LED LANTERN		01
03	0503013357	3/8" SELF-ADJUSTING NUT		02
04	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0581014432	ELECTRIC BOX SUPPORT		01
02	0503010019	1/2" SPRING WASHER		02
03	0503010060	1/2" NUT		02
04	0503014007	1/2" X 1-1/4" BOLT		02




Item	Code	Description	See page	QT
01	0581016487	SENSOR SUPPORT		01
02	0501010063	1/2" X 1-1/2" BOLT		02
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0503019085	INDUCTIVE SENSOR		01
06	0571015148	PLATE SENSIBLES		01
07	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02

SENSOR SUPPORT

0521058330




Item	Code	Description	See page	QT
01	0591014387	SENSOR SUPPORT		01
02	0501010942	3/8" X 1-1/4" BOLT		03
03	0503010026	3/8" NUT		03
04	0503010025	3/8" SPRING WASHER		03
05	0503013356	RIVET POP 3,2 X 10,0		01




Item	Code	Description	See page	QT
01	0591014389	LIFTING SENSOR DRIVING BODY		01
02	0521058332	FIXER BODY CONTROL		01
02A	0591014388	LIFT ACTUATOR FIXER		01
02B	0503019412	RIVET SCREW INTERNAL		02
03	0503010143	1/4" SPRING WASHER		02
04	0503010420	BOLT		02



Item	Code	Description	See page	QT
01	0503034003	SERIAL NUMBER TAG 61 X 118		01
02	0503010001	3.2 X 5.5 RIVET		04
03	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 MOUTH)		08
04	0503034563	ADHESIVE LABEL		04
05	0503034114	ADHESIVE LABEL LOGO TATU BOX 190 X 530		04
06	0503034566	ADHESIVE LABEL		04
07	0503033853	ADHESIVE LABEL		02
08	0503031425	ADHESIVE LABEL ATTENTION		02
09	0503034679	ADHESIVE LABEL		01
10	0503033597	ADHESIVE		02
11	0503031087	ADHESIVE LABEL		01
12	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM		02
13	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER		04
14	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM		02
15	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER		01
16	0503034471	ADHESIVE LABEL		01
17	0503034651	ADHESIVE LABEL		02
18	0503034683	ADHESIVE LABEL		02
19	0503034534	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0571015072	LOCK AXLE		01
02	0503010765	3/8" X 3" BOLT		01
03	0521064540	TELESCOPIC LOCK		01
04	0503013357	3/8" SELF-ADJUSTING NUT		01
05	0521011132	FLAT WASHER		01
06	0503010131	3/16" X 1-1/2" COTTERPIN		01
07	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
08	0511054270	TENSIONER SPRING		01
08A	0511069520	TELESC LOCK SPRING TENSIONER		01
08B	0503010013	5/8" NUT		02



Item	Code	Description	See page	QT
01	0521068930	SACADOR AXLE		01
02	0521068931	SLEEVE SACADOR		01

LEFT WHEEL WITH TRANSMISSION

0521055327




Item	Code	Description	See page	QT
01	0521064543	WHEEL SUPPORT		01
02	0561019929	FLAT WASHER		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		02
04	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
05	0551014508	FLAT WASHER		01
06	0503010523	1/4" X 2" COTTERPIN		03
07	0521069575	FLANGE CYLINDER HYDRAULIC FIXER		02
08	0521054953	HYDRAULIC CYLINDER 50,80 X 127,00 X 205	8	01
09	0503010920	1/2" X 1.1/2" BOLT		04
10	0503010019	1/2" SPRING WASHER		04
11	0503010060	1/2" NUT		04
12	0502012731	WHEEL HOLDER		02
13	0581017245	AXLE BODY		01
14	0503011075	3/4" UNC NUT		04
15	0503012334	3/4" UNC X 3.1/2" BOLT		04
16	0503010002	1800 GREASE FITTING		04
17	0521064550	CARRYING-WHEELS FORK		01
18	0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	9	01
19	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
20	0511054491	WHEEL WITHOUT TIRE WITH 27Z GEAR	10	01
21	0531012874	FLAT WASHER		02
22	0511068422	WHEEL GEAR DOBLE		01
23	0551018571	FLAT WASHER		02
24	0511054463	WHEEL TENSIONER SUPORT CENTRAL	12	01
25	0511054464	WHEEL FORK TENSIONER	13	02
26	0561019941	RIGHT PROTECTIVE CAP WHEELS		01
27	0503010849	3/8" X 1-1/2" BOLT		02
28	0501013518	FLAT WASHER		02
29	0503010025	3/8" SPRING WASHER		02
30	0503010209	3/8" UNC BUTTERFLY NUT		02
31	0503016419	50-1 CHAIN X 128 LINK + REDUCION		01


LEFT WHEEL WITH TRANSMISSION

0521055327


Item	Code	Description	See page	QT
32	0501010630	1.1/2" CASTLE NUT		01
33	0501017779	32 X 60 X 4.75 FLAT WASHER		02
34	0503011052	1.1/4" X 0.77" CASTLE NUT		02
35	0511054501	TRANSMISSION CAMBIO LEFT	152	01
36	0503014857	50-1 X CHAIN X 122 LINK + REDUCION		01
37	0503033335	CURRENT 6 X 21 ELOS		01
38	0503010882	BOLT		01
39	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
40	0503010337	5/16" NUT		01



Item	Code	Description	See page	QT
01	0521064556	SUPPORT ASSY TRANSMISSION WHEEL SIDE		01
02	0503010025	3/8" SPRING WASHER		13
03	0503010026	3/8" NUT		11
04	0503010019	1/2" SPRING WASHER		03
05	0503010060	1/2" NUT		03
06	0503010741	1/2" X 2-3/4" BOLT		03
07	0503062231	CLUTCH		01
08	0571015139	FIXER PLATE		01
09	0571015138	SIDE CLUTCH CHOCK		01
10	0511054461	STRETCHER TOP TRANSMISSION SWIRLED	15	02
11	0503011268	3/8" X 2-1/2" BOLT		01
12	0503013542	M10 SPRING WASHER		04
13	0503010188	M10 X 1,5 X 30 BOLT		01
14	0511069511	27Z GEAR		02
15	0571015152	FIXER TRANSMISSION SIDE LEFT		04
16	0571015154	PROTECTION TRANSMISSION LEFT		04




Item	Code	Description	See page	QT
01	0551011625	PROTECTION COVER		01
02	0503010386	CABLE		01
03	0551015037	5/8" UNC X 210 X 198 FASTENER		02
04	0551018630	CARDAN SHAFT GUIDES SLEEVE		01
05	0551018629	GEAR BOX COVER FIXER ROD		01
06	0503010257	1/8" X 1" COTTERPIN		02
07	0503010179	5/16" ZN SPRING WASHER		01
08	0503010337	5/16" NUT		01
09	0501013518	FLAT WASHER		02
10	0521056867	SEMI-ASSEMBLED LEFT EXCHANGE	154	01
11	0503012412	5/8 UNC SELF LOCKING NUT		04
12	0501012140	FLAT WASHER		04
13	0503011268	3/8" X 2-1/2" BOLT		01
14	0503013357	3/8" SELF-ADJUSTING NUT		01
15	0503034417	LETTER ADHESIVE LABEL		01
16	0503032986	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0531060362	LEFT SIDE EXCHANGE FERTILIZER SUPPORT		01
02	0501056444	BEARING WITH ROLLING	19	02
03	0502011758	REAR TENSIONER LEVER		01
04	0551018627	SIDE GEAR BOX DRIVER AXLE		01
05	0503030303	SUPPORT WASHER		05
06	0501056271	BEARING CLOSED	20	02
07	0503010292	0.2" X 1.6" SPRING PIN		05
08	0503010002	1800 GREASE FITTING		01
09	0503010395	1/2" X 1-1/4" BOLT		02
10	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		02
11	0503012389	1/2 BALL		02
12	0503010060	1/2" NUT		02
13	0503011953	5/16" X 1" BOLT		08
14	0501010694	8.5 X 18 X 1.5 FLAT WASHER		08
15	0503010179	5/16" ZN SPRING WASHER		08
16	0503010337	5/16" NUT		08
17	0501052778	CHAIN TENSIONER ASSY	101	01
18	0501048790	AXLE WITH LINK ASSY	22	01
19	0503012204	40-1 CHAIN X 82 LINK + RED		01
20	0511060396	DRIVE/DRIVEN AXLE CONE		02
21	0591011683	MOVED AXIS		01
22	0511067501	26Z GEAR		01
23	0501010984	FLAT WASHER		01
24	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		01
25	0503010025	3/8" SPRING WASHER		01
26	0503019312	40-1 X 51 CHAIN LINK + MENDING		01

FILTER SUPPORT


0521054349




Item	Code	Description	See page	QT
001	0581018644	FILTER SUPPORT		01
002	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
003	0503010179	5/16" ZN SPRING WASHER		04
004	0503015114	BOLT		04
005	0511017302	FLAT WASHER		02
006	0503010019	1/2" SPRING WASHER		02
007	0503010060	1/2" NUT		02
008	0503011082	C1/2" X 1.3/4" SCREW		02



Item	Code	Description	See page	QT
01	0521059121	SUPPORT SILO SIDE FERTILIZER 6 MOUTH LEFT 2433	157	01
02	0521059122	LEFT SUPPORT SILO FERTILIZER 5 MOUTH 2033	158	01
03	0503062391	SILO FERTILIZER 05 MOUTHS		01
04	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		01
05	0503010010	1/4" X 2.1/2" COTTERPIN		01
06	0502012007	SQUARE SLEEVE		01
07	0521051407	FIXER SILO FERTILIZER	34	18




Item	Code	Description	See page	QT
01	0531061328	SIDE SUPPORT WITH 6 MOUTH BACKGROUND		01
02	0501010942	3/8" X 1-1/4" BOLT		24
03	0503010025	3/8" SPRING WASHER		24
04	0503010026	3/8" NUT		24
05	0503030275	AGRICULTURAL BEARING		06
06	1902010685	18Z CONICAL GEAR		06
07	0521054313	CLOSED BEARING	159	01
08	0521054282	BEARING	36	01
09	0503030303	SUPPORT WASHER		03
10	0501053788	Q3/4" FASTENER AXLE ASSY	37	02
11	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	160	06
12	0571018899	SQUARE SHAFT 3/4 X 2565		01
13	0503034396	FERTILIZER SIDE COVER		06
14	0503010362	1/8" X 1.1/4" COTTERPIN		06




Item	Code	Description	See page	QT
01	0531061331	LEFT SUPPORT WITH 5 MOUTH BACKGROUND		01
02	0503030275	AGRICULTURAL BEARING		05
03	1902010685	18Z CONICAL GEAR		05
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0521054282	BEARING	36	02
08	0501053788	Q3/4" FASTENER AXLE ASSY	37	04
09	0503030303	SUPPORT WASHER		04
10	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	160	05
11	0511061759	22Z P12,70 FQ 3/4" GEAR		01
12	0571018896	SQUARE SHAFT		01
13	0503034396	FERTILIZER SIDE COVER		05
14	0503010362	1/8" X 1.1/4" COTTERPIN		05

CLOSED BEARING


0521054313



Item	Code	Description	See page	QT
01	0501056271	BEARING CLOSED	20	01
01A	0502012310	GEAR BOX CLOSE BEARING		01
01B	0503013462	BEARING WITH BALL BEARING		01
01C	0503011105	SEAL RING		01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01



Item	Code	Description	See page	QT
01	0531061330	SIDE SUPPORT 5 MOUTH 1602 LEFT		01
02	0503062962	SILO SEED 05 ASSY MOUTH		01
03	0521055365	SEED CONDUCTOR	33	05
04	0521050525	FIXER FERTILIZER CONDUCTOR	32	05
05	0521051407	FIXER SILO FERTILIZER	34	08

SIDE DUCT ASSEMBLY


0521059310



Item	Code	Description	See page	QT
01	0511059943	SUPPORT FASTENER ASSY		03
01A	0581011417	DUTO HOLDER SUPPORT		01
01B	0503010237	3/8" X 1" BOLT		02
01C	0503010025	3/8" SPRING WASHER		02
01D	0503010026	3/8" NUT		02
02	0511059928	SIDE DUTY SUPPORT	47	01
03	0581018407	BODY FASTENER 2 DUCTS		02
04	0581018409	FASTENER BODY		06
05	0531061333	OIL DUCT 3 OUTPUTS		02
06	0521069280	OIL DUCT 16 X 22 X 2180		04
07	0503011268	3/8" X 2-1/2" BOLT		07
08	0503010025	3/8" SPRING WASHER		07
09	0503010026	3/8" NUT		07
10	0501082190	HOSE 3/8 X 160 TR-TR		02

SEMI-ASSEMBLED LEFT MARKER

0521059256




Item	Code	Description	See page	QT
01	0521062493	LEFT SUPPORT		01
02	0531061364	FOREARM		01
03	0541012195	ARM BEFORE ARTICULICION AXLE		01
04	0503011052	1.1/4" X 0.77" CASTLE NUT		03
05	0503010038	3/16 X 2 COTTERPIN		07
06	0541012194	INTERMEDIATE ARM ARTIC ALXE		01
07	0511065481	LEFT INTERMEDIATE ARM		01
08	0531061365	HIGHER LEVER		01
09	0501011445	FLAT WASHER		05
10	0501014063	25 X 55 COUPLING SHAFT		05
11	0503010523	1/4" X 2" COTTERPIN		05
12	0521064440	MARKER ARM LINE 1000		01
13	0541012193	MARK ARM ARTICULACCION ALXE		01
14	0531061366	EXTENSOR 1390		01
15	0541015917	MARK ARM GUIDE		01
16	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
17	0541012196	SMALLER LEVER		01
18	0511065487	REGULATOR SPINDLE		01
19	0511065475	ADJUSTMENT ROD		01
20	0511058227	HYDRAULIC CYLINDER 38,10 X 63,50 X 608 X 290	89	01
21	0541015714	CYLINDER ARTICULACCION ALXE		01
22	0501019435	32 X 50 X 1.5 FLAT WASHER		04
23	0551016251	PIVOT SHAFT		01
24	0511017592	11.8" X 1.6" TRANSPORT LOCK		01
25	0501068994	0.3" X 3.1" LOCK PIN		01
26	0503030168	HAIR PIN		01
27	0503010027	5/8" SPRING WASHER		05
28	0503010013	5/8" NUT		04
29	0503010233	5/8" X 2-1/2" BOLT		04
30	0511042494	ROW MARKER DISC ASSY	90	01
31	0503010002	1800 GREASE FITTING		03


Item	Code	Description	See page	QT
32	0501081900	HOSE 3/8 X 1800 TR-TC		01
33	0501082092	HOSE 3/8 X 1250 TR-TR		01
34	0503011070	BEATER		01
35	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
36	0551019213	FLAT WASHER		01

PANTOGRAPHY HEADER


0521057792




Item	Code	Description	See page	QT
01	0531060744	UPPER ARM PANTOGRAPHIC HEADER		01
02	0531060743	LOWER ARM PANTOGRAPHIC HEADER		01
03	0531060745	PANTOGRAPHIC ARM EAR		02
04	0502040864	GEAR BOX WITH REGULATOR		01
05	0521068007	TRACTOR HITCH		01
06	1902040327	LOCK SLEEVE		01
07	0503010523	1/4" X 2" COTTERPIN		01
08	0503010002	1800 GREASE FITTING		04
09	0521063432	LOCK AXLE		02
10	0503031035	HAIR PIN		02
11	0531060746	AXIS 278 TELESCOPIC HEADER		02
12	0531060792	AXIS 200 TELESCOPIC HEADER		01
13	0531060776	HYDRAULIC HOSE SUPPORT FIXER		01
14	0503011052	1.1/4" X 0.77" CASTLE NUT		02
15	0503010038	3/16 X 2 COTTERPIN		03
16	0521010578	COUPLING SHAFT		01
17	0521057786	HYDRAULIC CYLINDER HEAD PANTOGRAPH	165	01
18	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		02




Item	Code	Description	See page	QT
01	0531060769	PANTOGRAPHIC HEAD CYLINDER CASE		01
02	0531060770	PANTOGRAPHIC HEAD CYLINDER ROD		01
03	0503010817	1.1/4" SELF LOCKING NUT		01
04	0503010345	2-218 N 3006-9B O'RING		01
05	0502010382	5" END CAP		01
06	0581010353	RING SUPPORT		01
07	0503018026	1870-2000-375 B GASKET		01
08	0503011453	O'RING		02
09	0503018152	O'RING		02
10	0503018024	RING BS		01
11	0503018025	RING GUIDE		01
12	0581010354	PISTON		01
13	0503018150	RING GUIDE		01
14	0503018151	RING BS		02
15	0503010039	D-2000 SCRAPER RING		01
16	0503030385	CYLINDER PLUG N-002		02




Item	Code	Description	See page	QT
01	0503015764	BOLT 7/8		01
02	0501010076	FLAT WASHER		01
03	0503010408	7/8" SPRING WASHER		01
04	0503010417	7/8" NUT		01
05	0501012140	FLAT WASHER		08
06	0503010233	5/8" X 2-1/2" BOLT		04
07	0503010027	5/8" SPRING WASHER		04
08	0503010013	5/8" NUT		04
09	0521051433	FRENCH HAND FRONT AXLE ASSY		02
09A	0511069442	FRENCH HAND FRONT AXLE		01
09B	0501017779	32 X 60 X 4.75 FLAT WASHER		01
09C	0503011052	1.1/4" X 0.77" CASTLE NUT		01
09D	0503010038	3/16 X 2 COTTERPIN		01
09E	0581014420	SLEVE GUIDE		02
10	0531061292	TELESCOPIC HEADER 2000/3225		01
11	0531060746	AXIS 278 TELESCOPIC HEADER		03
12	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		01
13	0521069860	INTERNAL CANUDE HEADER TELESCOPE 4986		01
14	0503011052	1.1/4" X 0.77" CASTLE NUT		03
15	0503010038	3/16 X 2 COTTERPIN		03
16	0503010002	1800 GREASE FITTING		03
17	0531060747	TELESCOPIC HOSE GUIDE		01
18	0531060748	REST SUPPORT		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	169	01
03	0521058088	ROTULA WITH EXTENSOR AXIS 2	170	01
04	0531061168	FRENCH HAND 1725 X 1800 X 4737		01
05	0521069640	OIL TUBE		02
06	1902010477	UPPER CLAMP BODY		09
07	0502012907	FRENCH HAND DUCTS SUPPORT		06
08	0503010964	BOLT		06
09	0503010589	1/2" UNC SELF ADJUSTING NUT		06
10	0501010984	FLAT WASHER		09
11	0503010025	3/8" SPRING WASHER		09
12	0503011404	BOLT		09
13	0591010238	FRENCH HAND TRACK 20 X 38 X 1745		02
14	0521053050	ASSY RAIL GUIDE		01
14A	0571011891	GUIDE RAIL		01
14B	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
14C	0503010179	5/16" ZN SPRING WASHER		02
14D	0503010337	5/16" NUT		02
14E	0503011952	5/16" X 3/4" BOLT		02
15	0521069639	OIL TUBE		01
16	0581018419	SUPPORT		03
17	0521069638	OIL TUBE		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	169	01
03	0521058088	ROTULA WITH EXTENSOR AXIS 2	170	01
04	0531061168	FRENCH HAND 1725 X 1800 X 4737		01
05	0521069638	OIL TUBE		02
06	1902010477	UPPER CLAMP BODY		06
07	0502012907	FRENCH HAND DUCTS SUPPORT		06
08	0501010984	FLAT WASHER		06
09	0503010025	3/8" SPRING WASHER		06
10	0503010964	BOLT		06
11	0503010589	1/2" UNC SELF ADJUSTING NUT		06
12	0503011404	BOLT		06
13	0591010238	FRENCH HAND TRACK 20 X 38 X 1745		02
14	0521053050	ASSY RAIL GUIDE		01
14A	0571011891	GUIDE RAIL		01
14B	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
14C	0503010179	5/16" ZN SPRING WASHER		02
14D	0503010337	5/16" NUT		02
14E	0503011952	5/16" X 3/4" BOLT		02
15	0521069639	OIL TUBE		01
16	0581018419	SUPPORT		03




Item	Code	Description	See page	QT
01	0521062244	PIVOT SHAFT		01
02	0551019529	FLAT WASHER		01
03	0503010027	5/8" SPRING WASHER		01
04	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		01




Item	Code	Description	See page	QT
01	0531061046	ROTULA WITH R2 LEFT NUT		01
02	0503010002	1800 GREASE FITTING		02
03	0501078990	TURNBUCLE AXLE		01
04	0561019879	LOCK ATTACHMENT BAR		01




Item	Code	Description	See page	QT
01	0521063662	BOX OF TOOLS		01
02	0551018356	BOX OF TOOLS COVER ASSY		01
03	0521010528	0.3" X 1.6" COUPLING SHAFT		02
04	0503010140	1/8" X 3/4" COTTERPIN		02
05	0503011907	PMC 594-S NYLON LUG		01
06	0503010358	5/16" X 5/8" BOLT		02
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503010337	5/16" NUT		02
09	0511017302	FLAT WASHER		04
10	0503010964	BOLT		02
11	0503010589	1/2" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521063339	HIGHER		06
02	0571011070	5/8" UNC FASTENER		06
03	0503010027	5/8" SPRING WASHER		12
04	0503010013	5/8" NUT		12




Item	Code	Description	See page	QT
01	0531060794	HYDRAULIC HOSE SUPPORT		01
02	0503015490	SELF-LOCKING NUT 7/16		02
03	0503011173	7/16" X 2" BOLT		02
04	0501010937	13.5 X 28 X 3 FLAT WASHER		02



Item	Code	Description	See page	QT
01	0503014820	COROTE BLACK WATER		01
02	0503019262	SOAP DISH VACUUM		01



Item	Code	Description	See page	QT
01	0531060668	REST SUPPORT		01
02	0503010571	1/4" X 1.1/2 COTTERPIN		02
03	0521010784	COUPLING SHAFT		01
04	0531060758	AXLE JUNCTION 25.4 X 150 WITH HANDLE		01
05	0503030085	LOCK PIN		02
06	0531060667	REST		01
07	0591013219	INTERNAL TUBE REST		01
08	0521010580	COUPLING SHAFT		01
09	0521012533	COUPLING SHAFT		01



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

