

ROW CROP PLANTERS

**PST TRIO FLEX TITANIUM - FRAME
6850/7860/8460/8960/10460 - CSU**

Code: 0501091893
Series: S-0116
Revision: 00
Date Revision: JULHO/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111260127	PST TRIO FLEX 10460/21E500 DC20 CSU TIT S-0116
0111260122	PST TRIO FLEX 10460/21E500 ESPECIAL S-0116
0111260089	PST TRIO FLEX 10460/21E500 MH DC20 CSU TIT S-0116
0111260099	PST TRIO FLEX 6850/15E450 ESPECIAL S-0116
0111260129	PST TRIO FLEX 6850/15E450 ESPECIAL S-0116
0111260070	PST TRIO FLEX 6850/15E450 MH CSU TIT S-0116
0111260130	PST TRIO FLEX 7860/17E450 CSU TIT CAB HIDR S-0116
0111260064	PST TRIO FLEX 7860/17E450 ESPECIAL S-0116
0111260116	PST TRIO FLEX 8460/18E450 MH CSU TIT S-0116
0111260096	PST TRIO FLEX 8960/18E500 DC20 CSU TIT S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.

INDEX

0909092566	ASSY FRAME	1
0511059420	FRAME WITH ARTICULATION 6850	2
0511059983	7860 ARTICULATION FRAME WITH	3
0511056311	ARTICULATION FRAME 8460	4
0511056249	FRAME WITH ARTICULATION 8960	5
0511055264	FRAME WITH ARTICULATION 10460	6
0511053046	RIGHT FRAME WITH AXLE WHEELED 6850	7
0511059288	CENTRAL FRAME WITH WHEELED AXLE 5750/6850/7860/8160	8
0511053047	LEFT FRAME WITH WHEELED AXLE 6850	9
0511053135	RIGHT FRAME WITH WHEELED AXLE 7860	10
0511053136	LEFT FRAME WITH WHEELED AXLE 7860	11
0511056312	RIGHT FRAME WITH WHEELED AXLE 8460	12
0511056313	LEFT FRAME WITH WHEELED AXLE 8460	13
0511053190	CENTRAL FRAME WITH WHEELED AXLE 6450/7285/7450/8460	14
0511056156	RIGHT FRAME WITH WHEEL AXLE	15
0511056157	LEFT FRAME WITH WHEEL AXLE	16
0511056064	CENTRAL FRAME WITH WHEEL AXLE	17
0511053768	CENTRAL FRAME WITH WHEELED AXLE 5850/7960	18
0511055268	RIGHT FRAME WITH WHEEL AXLE	19
0511055270	CENTRAL FRAME WITH WHEEL AXLE	20
0511055269	LEFT FRAME WITH WHEEL AXLE	21
0511058233	PLATFORM SET 6850	22
0511058281	PLATFORM SET 8460	23
0511058888	PLATFORM SET 8960	24
0511058899	PLATFORM SET 10460	25
0511058234	HANDLE ASSEMBLY 6850	26
0511058276	HANDLE ASSEMBLY 7860	27
0511058282	HANDLE ASSEMBLY 8460	28
0511058889	HANDLE ASSEMBLY 8960	29
0511058898	HANDLE ASSEMBLY 10460	30
0511058232	SET FERTILIZER SILO 6850	31
0511058274	SET FERTILIZER SILO 7860	32
0521050250	SET FERTILIZER SILO 8460	33
0511058887	SET FERTILIZER SILO 8960	34
0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS	35
0503062169	ASSEMBLED FERTILIZER HOPPER	36
0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS	37
0511059275	ASSY MANUAL DOOR	38
0511058263	TRANSMISSION ASSEMBLY 6850	39
0511059740	ASSEMBLY TRANSMISSION 7860	40
0511058836	ASSEMBLY TRANSMISSION 7960/8160/8460	41
0511058885	TRANSMISSION ASSEMBLY 8960	42
0511058850	TRANSMISSION ASSEMBLY 9960/10460	43
0501052560	MOTOR AXLE SIGNAL	44
0511051434	TRANSMISSION ACTUATOR	45
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	46
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	47
0521043316	RIGHT GEAR BOX ASSY	48
0521043317	LEFT GEAR BOX ASSY	49
0501058212	SEMI MOUNTED RIGHT CHANGE	50
0501058213	LH GEAR BOX	51
0511059266	CLOSED BEARING	52
0501056271	GEARBOX CLOSED BEARING	53
0501056443	GEAR HOUSING BEARING	54
0501056444	BEARING WITH ROLLER	55



MARCHESAN

INDEX

0501048790	AXLE WITH RING	56
0501054655	CHAIN TENSIONER ASSY	57
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	58
0511054363	CHAIN TENSIONER	59
0501058234	LOWER CHAIN TENSIONER	60
0521055207	TOP CURRENT STRETCHER	61
0501058236	BEARING WITH 21Z GEAR	62
0501058237	16Z GEAR BEARING	63
0501055112	MICRO GRANULATED CHAIN TENSIONER	64
0511059261	CHAIN TENSIONER	65
0521055217	LOWER CURRENT STRETCH	66
0501058254	UPPER SEED CHAIN TENSIONER	67
0521055216	BEARING WITH GEAR	68
0521055218	BEARING GEAR WITH DOUBLE	69
0521055214	BEARING GEAR WITH	70
0521055215	DOUBLE TRANSMISSION BEARING	71
0511059265	WHEELED WITH SPRING TRACTION WITH TRANSMISSION	72
0521043313	WHEELED WITH SPRING TRACTION WITHOUT TRANSMISSION	73
0511059262	WHEEL SUPPORT ASSY	74
0501058241	WHEEL SUPPORT CHAIN TENSIONER	75
0511052770	WHEEL WITH TIRE	76
0503062159	WHEEL WITH TIRE	77
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	78
0501058240	WHEEL FASTENER WITH TENSIONER	79
0501058244	WHEEL FIXED CHAIN TENSIONER	80
0501058239	WHEEL CHAIN TENSIONER BEARING	81
0501058242	WHEEL MOBILE CHAIN TENSIONER	82
0511054336	SUPPORT WHEELED WITHOUT TRANSMISSION	83
0521051801	WHEEL WITH TIRE 7.00X16 WHEELED BOX WITHOUT TRANSMISSION	84
0521051800	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	85
0503062206	CARDAN TERMINAL	86
0511057287	TRANSMISSION	87
0511056536	LADDER ASSEMBLY	88
0511056736	HOSE SUPPORT	89
0511059232	ASSEMBLY SPRING TRACTION	90
0511054971	JACK ASSEMBLY	91
0501050633	ROW MARKER DISC ASSEMBLY	92
0511053904	ROW MARKER DISC	93
0511053056	MARKER CYLINDER	94
0511057889	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE 8460	95
0511055786	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE 10460	96
0511058449	HYDRAULIC CYLINDER	97
0511058431	HYDRAULIC CYLINDER	98
0501054649	HBM SEQUENTIAL VALVE	99
0501053834	MALE QUICK COUPLER	100
0511059419	HYDRAULIC SYSTEM ASSEMBLY 6850/7285/7450/7860/7960	101
0511058284	HYDRAULIC SYSTEM ASSEMBLY	102
0511058901	HYDRAULIC SYSTEM ASSEMBLY	103
0511059290	VALVE ASSEMBLY	104
0501053835	FEMALE QUICK COUPLER	105
0511053065	TRIPLE VALVE	106
0511059273	CENTER CYLINDER ASSEMBLY	107
0511058406	HYDRAULIC CYLINDER	108



MARCHESAN

INDEX


0511059274	SIDE CYLINDER ASSEMBLY		109
0511054601	HITCH ARTICULATED TRACTOR		110
0511055096	TRACTOR HITCH		111
0511053179	TRACTOR COUPLING SHAFT		112
0511058229	CYLINDER ASSEMBLY		113
0511059237	3 POINT TURNBUCKLE		114
0511053075	3 POINT TURNBUCKLE		115
0511053076	TURNBUCKLE SIDE UPPER		116
0511055277	TURNBUCKLE SIDE UPPER		117
0521050133	TURNBUCKLE SIDE 755/480		118
0511059980	COMPLETE SIDE EXTENDER (1.1/4 X 1)		119
0511055275	COMPLETE SIDE EXTENDER		120
0909092552	FERTILIZER/SEED ROW ASSY	(OPTIONAL)	121
0501059834	LEFT SHORT SEED ROW FRONT		122
0501059833	RIGHT SHORT SEED ROW FRONT		123
0501059835	RIGHT LONG SEED ROW FRONT		124
0501059836	LEFT LONG SEED ROW FRONT		125
0511054635	BEARING AXLE BODY		126
0511057159	TRANSMISSION HOPPER SEED ROW		127
0511050609	BEARING WITH 17Z GEAR ASSY		128
0511050617	FRONT SEED ROW BEARING		129
0501052769	BEARING WITH 17Z GEAR		130
0511055260	SEED ROW CHAIN TENSIONER		131
0511059264	BEARING WITH AXLE		132
0501059326	UNIVERSAL JOINT AXLE		133
0511056621	RIGHT REAR SEED ROW		134
0511056622	LEFT REAR SEED ROW		135
0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8		136
0511056585	RIGHT 15" X 15" DOUBLE DISC SEED		137
0511056586	15 X 15 SEED DDD LEFT		138
0511052301	SUPPORT DDD 15 RIGHT		139
0511052302	LH SUPPORT DDD GUIDE		140
0521050096	SEED HOPPER SYSTEM (CSU)		141
0511052058	SEED SYSTEM TITANIUM		142
0521046122	DEPTH SYSTEM / COMPACTOR ASSY		143
0521044269	PRESS WHEELS/DEPTH ASSY		144
0521044460	SYSTEM DEPTH / COMPACTOR		145
0521046501	DEPTH CONTROL AND PRESS WHEEL WITH FAST ADJUSTING		146
0511058650	SEMI-MOUNTED DEPTH CONTROL		147
0511058652	LEFT DEPTH WHEEL ARM WITH HUB		148
0511058651	RIGHT DEPTH WHEEL ARM WITH HUB		149
0501052627	ASSY DEPTH WHEEL HUB		150
0501052297	DEPTH WHEELS REGULATOR ASSY		151
0501052538	DEPTH BAND WITH ARMS		152
0511054333	COMPACT WHEEL RIGHT WITH BEARING		153
0511054334	COMPACT WHEEL LEFT WITH BEARING		154
0511055326	DEPTH CONTROL PRESS WHEEL ASSY		155
0501059228	ADJUSTMENT LEVER		156
0511055328	DEPTH WHEEL SYSTEM		157
0511055329	LEFT DEPTH WHEEL		158
0511055627	WHEEL ASSY RAYED		159
0511055327	COMPACTING WHEEL V ASSY RUBBER		160
0511055690	WHEEL SYSTEM		161
0511055628	DEPTH WHEEL SYSTEM		162



MARCHESAN

INDEX

0511055629	DEPTH WHEEL SYSTEM	163
0511059462	DEPTH CONTROL WITH FAST ADJUSTMENT	164
0501056769	DEPTH WHEELS REGULATOR ASSY	165
0511059463	COMFORT WHEEL WITH FAST ADJUSTMENT	166
0511050077	WHEEL STRIPED	167
0511052287	DEPTH WHEEL HUB ASSY	168
0501052908	COMPACTOR WHEEL WITH BEARING	169
0511059350	FERTILIZER ROW SUPPORT ASSEMBLY	170
0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	171
0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	172
0501058423	FERTILIZER ROD SPRING ROW	173
0511058619	20" SHORT ROW DISC BLADE	174
0511058617	DISC CUT 18 SHORT LINE	175
0511058620	20" LONG ROW DISC BLADE	176
0511058618	DISC CUT 18 LONG LINE	177
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	178
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	179
0511053172	LEFT LOW HUB WITH 15 DISC	180
0511053173	RIGHT LOW HUB WITH 15 DISC	181
0511058648	HUB WITH 20" DISC BLADE	182
0511056910	HUB WITH 18" DISC BLADE	183
0511056909	DISC BLADE HUB WITHOUT DISC	184
0501110231	SCARIFIER ROD WITH TIP	185
0511057542	HDA	186
0511057533	ROD WITH POINT FLANGE WASHER SPRING	187
0511052024	FAST CLOSING SET	188
0501050120	LARGER WALKING BEAM ASSY	189
0503062066	DISC SET WITH CORN RING	190
0503062067	DISC SET / RING SOY 90F TITANIUM	191



Item	Code	Description	See page	6850	7860	8460	8960	10460
01	0511059420	FRAME WITH ARTICULATION 6850	2	01	00	00	00	00
01.	0511059983	7860 ARTICULATION FRAME WITH	3	00	01	00	00	00
01..	0511056311	ARTICULATION FRAME 8460	4	00	00	01	00	00
01...	0511056249	FRAME WITH ARTICULATION 8960	5	00	00	00	01	00
01....	0511055264	FRAME WITH ARTICULATION 10460	6	00	00	00	00	01
02	0511058233	PLATFORM SET 6850	22	01	00	00	00	00
02.	0511058275	PLATFORM SET 7860		00	01	00	00	00
02..	0511058281	PLATFORM SET 8460	23	00	00	01	00	00
02...	0511058888	PLATFORM SET 8960	24	00	00	00	01	00
02....	0511058899	PLATFORM SET 10460	25	00	00	00	00	01
03	0511058234	HANDLE ASSEMBLY 6850	26	01	00	00	00	00
03.	0511058276	HANDLE ASSEMBLY 7860	27	00	01	00	00	00
03..	0511058282	HANDLE ASSEMBLY 8460	28	00	00	01	00	00
03...	0511058889	HANDLE ASSEMBLY 8960	29	00	00	00	01	00
03....	0511058898	HANDLE ASSEMBLY 10460	30	00	00	00	00	01
04	0531058094	SINGLE SEED HOPPER SET C3 X 175 3CX 18B - 6850		01	00	00	00	00
04.	0531058041	ASSY CSU C3 X 175 3CX 21B C/17C - 7860		00	01	00	00	00
04..	0531058031	ASSY CSU C3 X 175 3CX 21B C/18C - 8460		00	00	01	00	00
04...	0531058025	ASSY CSU C3 X 175 4CX 24B C/18C - 8960		00	00	00	01	00
04....	0531057996	ASSY CSU C3 X 175 6CX 30B C/21C - 10460		00	00	00	00	01
05	0511058232	SET FERTILIZER SILO 6850	31	01	00	00	00	00
05.	0511058274	SET FERTILIZER SILO 7860	32	00	01	00	00	00
05..	0521050250	SET FERTILIZER SILO 8460	33	00	00	01	00	00
05...	0511058887	SET FERTILIZER SILO 8960	34	00	00	00	01	00
05....	0521050514	FERTILIZER SILO SET 10460		00	00	00	00	01
06	0511059275	ASSY MANUAL DOOR	38	01	01	01	01	01
07	0511058263	TRANSMISSION ASSEMBLY 6850	39	01	00	00	00	00
07.	0511059740	ASSEMBLY TRANSMISSION 7860	40	00	01	00	00	00
07..	0511058836	ASSEMBLY TRANSMISSION 7960/8160/8460	41	00	00	01	00	00
07...	0511058885	TRANSMISSION ASSEMBLY 8960	42	00	00	00	01	00
07....	0511058850	TRANSMISSION ASSEMBLY 9960/10460	43	00	00	00	00	01

ASSY FRAME

0909092566


Item	Code	Description	See page	6850	7860	8460	8960	10460
08	0503010002	1800 GREASE FITTING		02	02	02	02	02
09	0503010003	1845 GREASE FITTING		08	08	08	08	08
10	0503010004	1890 GREASE FITTING		02	02	02	02	02
11	0521064285	LOCK LOWER FRAME		02	02	02	02	02
12	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		02	02	02	02	02
13	0511059265	WHEELED WITH SPRING TRACTION WITH 72 TRANSMISSION		04	04	04	04	04
14	0521043313	WHEELED WITH SPRING TRACTION WITHOUT 73 TRANSMISSION		02	02	02	02	02
15	0503062206	CARDAN TERMINAL	86	00	02	00	02	02
16	0571013724	5/8 X 1250 HEX AXLE		00	00	00	02	00
16.	0571014914	SHAFT AXLE 5/8 X 2720		00	00	00	02	00
16..	0581013362	5/8 X 2652 HEX AXLE		00	00	02	00	00
16...	0571015983	5/8 X 1500 HEX AXLE		00	00	00	00	01
16....	0581013848	HEX AXIS 5/8 X 3220		00	00	00	00	02
17	0571019949	JUNCTION SHAFT		04	04	04	04	04
18	0511057287	TRANSMISSION	87	02	00	02	00	00
19	0571013470	5/8 X 1100 HEX AXLE		01	02	02	00	00
19.	0571013469	5/8 X 700 HEX AXLE		01	02	00	00	00
19..	0571013468	5/8 X 2040 HEX AXLE		02	00	00	00	00
19...	0581013887	5/8 X 2560 HEX AXLE		00	02	00	00	00
19....	0571015984	5/8 HEX AXLE		00	00	00	00	01
20	0561014215	BEARING COVER LOWER ROW FRAME		02	02	02	02	02
21	0502040534	SPRING GUIDE BUSHING LOCK		08	08	08	08	08
22	0501018535	1/2 X 1 BOLT		08	08	08	08	08
23	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02	02	02	02	02
24	0501010694	FLAT WASHER		04	04	04	04	04
25	0503010179	LOCK WASHER 5/16 ZN 1K01528		02	02	02	02	02
26	0503010337	5/16" NUT		02	02	02	02	02
27	0511056536	LADDER ASSEMBLY	88	02	02	02	02	02
28	0501047895	25 ROD STOP		03	03	03	03	03
28.	0501047885	30 ROD STOP		03	03	03	03	03
28..	0501047886	35 ROD STOP		03	03	03	03	03
28...	0501047887	40 ROD STOP		03	03	03	03	03
29	0511056736	HOSE SUPPORT	89	01	01	01	01	01
30	0521066304	HOSE GUIDE		01	01	01	01	01
31	0521066800	BODY REGULATORY KEY		01	01	01	01	01
32	0541015451	FIXED KEY 2.3/8 X 2.3/4		01	01	01	01	01
33	0501065677	STRUT		02	02	02	02	02
34	0511059232	ASSEMBLY SPRING TRACTION	90	02	02	02	02	02
35	0511054971	JACK ASSEMBLY	91	02	02	02	02	02
36	0501050633	ROW MARKER DISC ASSEMBLY	92	02	02	02	02	02
37	0511053056	MARKER CYLINDER	94	02	00	00	00	00
37.	0511057879	DOUBLE ARTICULATED HYDRAULIC MARKER		00	02	00	00	00
37..	0511057889	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE 8460	95	00	00	02	00	00
37...	0511055786	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE 10460	96	00	00	00	00	02
38	0511059419	HYDRAULIC SYSTEM ASSEMBLY 6850/7285/7450/7860/7960	101	01	01	00	00	00
38.	0511058284	HYDRAULIC SYSTEM ASSEMBLY	102	00	00	01	00	00
38..	0511058901	HYDRAULIC SYSTEM ASSEMBLY	103	00	00	00	00	01
39	0511059273	CENTER CYLINDER ASSEMBLY	107	01	01	01	01	01
40	0511059274	SIDE CYLINDER ASSEMBLY	109	02	02	02	02	02
41	0521013022	TRANSPORT LOCK		03	03	03	03	03
42	0501068994	8,30 X 78 LOCK PIN		03	03	03	03	03
43	0503030168	HITCH PIN CLIP		03	03	03	03	03
44	0521066289	5750/6350/6850 FRONT DRAWBAR		01	01	00	00	00
44.	0521065284	HYDRAULIC HEADER		00	00	01	00	00
44..	0521065202	HEADER		00	00	00	01	00




ASSY FRAME

0909092566


Item	Code	Description	See page	6850	7860	8460	8960	10460
44...	0521064835	HEADER		00	00	00	00	01
45	0521066290	INTERMEDIATE HEAD 5750/6850/7860/8160		01	01	00	00	00
45.	0521065283	INTERMEDIATE HEADER		00	00	01	00	00
45..	0521065203	INTERMEDIATE HEADING		00	00	00	01	00
45...	0521067839	INTERMEDIATE HEAD 9460/10460/10985		00	00	00	00	01
46	0511054601	HITCH ARTICULATED TRACTOR	110	01	01	01	01	00
46.	0511055096	TRACTOR HITCH	111	00	00	00	00	01
47	0511053179	TRACTOR COUPLING SHAFT	112	01	01	01	01	01
48	0511058229	CYLINDER ASSEMBLY	113	01	01	01	01	01
49	0521010582	COUPLING SHAFT		01	01	01	01	01
50	0521010580	COUPLING SHAFT		01	01	01	01	01
51	0531016049	FLAT WASHER		02	02	02	02	02
52	0503030085	LOCK PIN		02	02	02	02	02
53	0511061021	SUPPORT FASTENER		04	04	04	04	04
54	0502010175	HITCH CLAMP		06	06	06	06	06
55	0501010163	5/8" X 4-1/2" BOLT		16	16	16	16	16
56	0501012140	FLAT WASHER		16	16	16	16	16
57	0503010027	5/8 SPRING WASHER		16	16	16	16	16
58	0503010013	5/8 NUT		16	16	16	16	16
59	0511059237	3 POINT TURNBUCKLE	114	01	01	00	00	00
59.	0511053075	3 POINT TURNBUCKLE	115	00	00	01	01	01
60	0571019951	JUNCTION SHAFT		01	01	01	01	01
61	0571019950	COUPLING SHAFT		01	01	01	01	01
62	0503030119	LOCK PIN		06	06	06	06	06
63	0503010523	1/4" X 2" SPLIT PIN		04	04	04	04	04
64	0511053076	TURNBUCKLE SIDE UPPER	116	02	02	02	00	00
64.	0511055277	TURNBUCKLE SIDE UPPER	117	00	00	00	02	02
65	0521050133	TURNBUCKLE SIDE 755/480	118	02	00	00	00	00
66	0511059980	COMPLETE SIDE EXTENDER (1.1/4 X 1)	119	00	02	00	00	00
66.	0511055275	COMPLETE SIDE EXTENDER	120	00	00	02	02	02
67	0521010571	COUPLING SHAFT		04	04	04	04	04
68	0521010780	1.2" X 4.5" COUPLING SHAFT		04	00	00	00	00
68.	0571019949	JUNCTION SHAFT		00	04	04	04	04
69	0521010588	0.9" X 7.0" COUPLING SHAFT		02	00	00	00	00
69.	0571019951	JUNCTION SHAFT		00	02	02	00	00
70	0503010523	1/4" X 2" SPLIT PIN		04	04	04	04	04
71	0909092552	FERTILIZER/SEED ROW ASSY	121	15	17	18	18	21




Item	Code	Description	See page	QT
01	0511053046	RIGHT FRAME WITH AXLE WHEELED 6850	7	01
02	0511059288	CENTRAL FRAME WITH WHEELED AXLE 5750/6850/7860/8160	8	01
03	0511053047	LEFT FRAME WITH WHEELED AXLE 6850	9	01
04	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		04
05	0503011442	3/4" SPRING WASHER		18
06	0501010098	3/4" UNC BOLT		18
07	0571010094	SLEEVE FLANGE		06
08	0571013510	LOCK AXLE		02
09	0503030085	LOCK PIN		02
10	0571010095	FLAT WASHER		02
11	0521063003	LOCK PIN		02
12	0571010969	LOCK SLEEVE FRAME		02
13	0503013627	1.1/2 SPRING WASHER		02
14	0501010110	1.1/2" NUT		02
15	0502012698	CLAMP		04
16	0503011444	SPRING WASHER		04
17	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
18	0521063912	PIVOT SHAFT		02
19	0581015857	GUTTER 24 X 50 X 1080		01
20	0581018001	GUTTER 24 X 50 X 980		02
21	0581017747	GUTTER 25 X 50 X 1200		02
22	0503010026	3/8" NUT		12
23	0503010025	3/8 SPRING WASHER		12
24	0501011643	3/8 X 1" BOLT		12




Item	Code	Description	See page	QT
01	0511053135	RIGHT FRAME WITH WHEELED AXLE 7860	10	01
02	0511053136	LEFT FRAME WITH WHEELED AXLE 7860	11	01
03	0511059288	CENTRAL FRAME WITH WHEELED AXLE 8 5750/6850/7860/8160	8	01
04	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		04
05	0503011442	3/4" SPRING WASHER		18
06	0501010098	3/4" UNC BOLT		18
07	0571010094	SLEEVE FLANGE		06
08	0521063912	PIVOT SHAFT		02
09	0571013510	LOCK AXLE		02
10	0503030085	LOCK PIN		02
11	0571010095	FLAT WASHER		02
12	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
13	0503011444	SPRING WASHER		04
14	0502012698	CLAMP		04
15	0501011643	3/8 X 1" BOLT		14
16	0503010025	3/8 SPRING WASHER		14
17	0503010026	3/8" NUT		14
18	0521063003	LOCK PIN		02
19	0571010969	LOCK SLEEVE FRAME		02
20	0503013627	1.1/2 SPRING WASHER		02
21	0501010110	1.1/2" NUT		02
22	0581016293	TROUGH 24 X 50 X 1420		02
23	0581017747	GUTTER 25 X 50 X 1200		02
24	0581015857	GUTTER 24 X 50 X 1080		02




Item	Code	Description	See page	QT
01	0511056312	RIGHT FRAME WITH WHEELED AXLE 8460	12	01
02	0511056313	LEFT FRAME WITH WHEELED AXLE 8460	13	01
03	0511053190	CENTRAL FRAME WITH WHEELED AXLE 6450/7285/7450/8460	14	01
04	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		04
05	0503011442	3/4" SPRING WASHER		16
06	0501010098	3/4" UNC BOLT		16
07	0571010094	SLEEVE FLANGE		06
08	0521063912	PIVOT SHAFT		02
09	0571013510	LOCK AXLE		02
10	0503030085	LOCK PIN		02
11	0571010095	FLAT WASHER		02
12	0503011442	3/4" SPRING WASHER		02
13	0501010098	3/4" UNC BOLT		02
14	0521063003	LOCK PIN		02
15	0571010969	LOCK SLEEVE FRAME		02
16	0503013627	1.1/2 SPRING WASHER		02
17	0502012698	CLAMP		04
18	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
19	0503011444	SPRING WASHER		04
20	0501010110	1.1/2" NUT		02
21	0581017979	GUTTER		02
22	0581017935	GUTTER		02
23	0581018018	TROUGH 24 X 50 X 1255		02
24	0501011643	3/8 X 1" BOLT		12
25	0503010025	3/8 SPRING WASHER		12
26	0503010026	3/8" NUT		12




Item	Code	Description	See page	QT
001	0511056156	RIGHT FRAME WITH WHEEL AXLE	15	01
002	0511056157	LEFT FRAME WITH WHEEL AXLE	16	01
003	0511056064	CENTRAL FRAME WITH WHEEL AXLE	17	01
004	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		04
005	0503011442	3/4" SPRING WASHER		16
006	0501010098	3/4" UNC BOLT		16
007	0571010094	SLEEVE FLANGE		06
008	0521064842	PIVOT SHAFT		02
009	0571013510	LOCK AXLE		02
010	0503030085	LOCK PIN		02
011	0571010095	FLAT WASHER		02
012	0503011442	3/4" SPRING WASHER		02
013	0501010098	3/4" UNC BOLT		02
014	0521063003	LOCK PIN		02
015	0571010969	LOCK SLEEVE FRAME		02
016	0503013627	1.1/2 SPRING WASHER		02
017	0502012698	CLAMP		04
018	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
019	0503011444	SPRING WASHER		04
020	0501010110	1.1/2" NUT		02




Item	Code	Description	See page	QT
001	0511055268	RIGHT FRAME WITH WHEEL AXLE	19	01
002	0511055269	LEFT FRAME WITH WHEEL AXLE	21	01
003	0511055270	CENTRAL FRAME WITH WHEEL AXLE	20	01
004	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		04
005	0503011442	3/4" SPRING WASHER		16
006	0501010098	3/4" UNC BOLT		16
007	0571010094	SLEEVE FLANGE		06
008	0521064842	PIVOT SHAFT		02
009	0571013510	LOCK AXLE		02
010	0503030085	LOCK PIN		02
011	0571010095	FLAT WASHER		02
012	0503011442	3/4" SPRING WASHER		02
013	0501010098	3/4" UNC BOLT		02
014	0521063003	LOCK PIN		02
015	0571010969	LOCK SLEEVE FRAME		02
016	0503013627	1.1/2 SPRING WASHER		02
017	0502012698	CLAMP		04
018	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
019	0503011444	SPRING WASHER		04
020	0501010110	1.1/2" NUT		02




Item	Code	Description	See page	QT
01	0521063886	RIGHT FRAME		01
02	0521063872	ARTICLES AXLE RIGHT ROLLED		01
03	0521013199	LOWER BEARING SEMI		02
04	0503010899	5/8 UNC X 2.1/4 BOLT		04
05	0501012140	FLAT WASHER		08
06	0531013922	0.6" X 0.8" X 1" SLEEVE		04
07	0503011445	SPRING WASHER		04
08	0503010013	5/8 NUT		04




Item	Code	Description	See page	QT
01	0521066916	CENTRAL FRAME		01
02	0521013199	LOWER BEARING SEMI		04
03	0503010899	5/8 UNC X 2.1/4 BOLT		08
04	0501012140	FLAT WASHER		16
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503010013	5/8 NUT		08
08	0521063878	ARTICLE AXLE ROLLED		01




Item	Code	Description	See page	QT
01	0521063885	LEFT FRAME		01
02	0521063873	ARTICLES AXLE LEFT ROLLED		01
03	0521013199	LOWER BEARING SEMI		02
04	0503010899	5/8 UNC X 2.1/4 BOLT		04
05	0501012140	FLAT WASHER		08
06	0531013922	0.6" X 0.8" X 1" SLEEVE		04
07	0503011445	SPRING WASHER		04
08	0503010013	5/8 NUT		04




Item	Code	Description	See page	QT
01	0521063971	FRAME BRACKET		01
02	0521063975	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
01	0521063972	FRAME BRACKET		01
02	0521063981	SIDE CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
01	0521065394	RIGHT FRAME		01
02	0521065222	SIDE ROD JOINT AXLE		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06





Item	Code	Description	See page	QT
01	0521065395	LEFT FRAME		01
02	0521065223	SHAFT SHAFT SHAFT SIDE SHAFT		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
01	0521064011	CENTRAL FRAME		01
02	0521064022	CENTRAL ARTICLES AXLE ROLLED		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8 UNC X 2.1/4 BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8 NUT		08




Item	Code	Description	See page	QT
001	0521065220	RIGHT FRAME		01
002	0521065222	SIDE ROD JOINT AXLE		01
003	0521013199	LOWER BEARING SEMI		03
004	0503010899	5/8 UNC X 2.1/4 BOLT		06
005	0501012140	FLAT WASHER		12
006	0531013922	0.6" X 0.8" X 1" SLEEVE		06
007	0503011445	SPRING WASHER		06
008	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
001	0521065221	LEFT FRAME		01
002	0521065223	SHAFT SHAFT SHAFT SIDE SHAFT		01
003	0521013199	LOWER BEARING SEMI		03
004	0503010899	5/8 UNC X 2.1/4 BOLT		06
005	0501012140	FLAT WASHER		12
006	0531013922	0.6" X 0.8" X 1" SLEEVE		06
007	0503011445	SPRING WASHER		06
008	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
001	0521065207	CENTRAL FRAME		01
002	0521065208	ARTICLE AXLE ROLLED		01
003	0521013199	LOWER BEARING SEMI		04
004	0503010899	5/8 UNC X 2.1/4 BOLT		08
005	0501012140	FLAT WASHER		16
006	0531013922	0.6" X 0.8" X 1" SLEEVE		08
007	0503011445	SPRING WASHER		08
008	0503010013	5/8 NUT		08




Item	Code	Description	See page	QT
01	0521064281	CENTRAL FRAME		01
02	0521013199	LOWER BEARING SEMI		04
03	0503010899	5/8 UNC X 2.1/4 BOLT		08
04	0501012140	FLAT WASHER		16
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503010013	5/8 NUT		08
08	0521064282	CARRYING-WHEELS PIVOT SHAFT		01




Item	Code	Description	See page	QT
001	0521064840	RIGHT FRAME		01
002	0521064838	ARTICLES AXLE RIGHT ROLLED		01
003	0521013199	LOWER BEARING SEMI		03
004	0503010899	5/8 UNC X 2.1/4 BOLT		06
005	0501012140	FLAT WASHER		12
006	0531013922	0.6" X 0.8" X 1" SLEEVE		06
007	0503011445	SPRING WASHER		06
008	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
001	0521064839	CENTRAL FRAME		01
002	0521064836	CENTRAL RODE JOINT SHAFT		01
003	0521013199	LOWER BEARING SEMI		04
004	0503010899	5/8 UNC X 2.1/4 BOLT		08
005	0501012140	FLAT WASHER		16
006	0531013922	0.6" X 0.8" X 1" SLEEVE		08
007	0503011445	SPRING WASHER		08
008	0503010013	5/8 NUT		08




Item	Code	Description	See page	QT
001	0521064841	LEFT FRAME		01
002	0521064837	ARTICLES AXLE LEFT ROLLED		01
003	0521013199	LOWER BEARING SEMI		03
004	0503010899	5/8 UNC X 2.1/4 BOLT		06
005	0501012140	FLAT WASHER		12
006	0531013922	0.6" X 0.8" X 1" SLEEVE		06
007	0503011445	SPRING WASHER		06
008	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
001	0511069661	PLATFORM SUPPORT PIVOT		06
002	0503010849	3/8" X 1-1/2" BOLT		10
003	0501010984	10,50 X 27 X 3,00 FLAT WASHER		20
004	0503010025	3/8 SPRING WASHER		10
005	0503010026	3/8" NUT		10
006	0521063869	RIGHT PLATFORM		01
007	0521063868	SIDE PLATFORM		01
008	0521063870	PLATFORM CENTER		01
009	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		06
010	0503011336	1/2" HEX SELF ADJUSTING NUT		06
011	0503011333	COVER FIXER		03
012	0503010274	5/32"X 2" COTTERPIN		03
013	0502012740	PLATFORM RIGHT FIXER SUPPORT		02
014	0502012739	PLATFORM LEFT FIXER SUPPORT		01
015	0571017990	PLATFORM ENHANCEMENT PROTECTION		02
016	0501010942	3/8" X 1-1/4" BOLT		04
017	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
018	0503010025	3/8 SPRING WASHER		04
019	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
001	0511069661	PLATFORM SUPPORT PIVOT		06
002	0503010849	3/8" X 1-1/2" BOLT		10
003	0501010984	10,50 X 27 X 3,00 FLAT WASHER		20
004	0503010025	3/8 SPRING WASHER		10
005	0503010026	3/8" NUT		10
006	0521064290	RIGHT PLATFORM		01
007	0521064288	LEFT PLATFORM		01
008	0521064017	PLATFORM CENTER		01
009	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		06
010	0503011336	1/2" HEX SELF ADJUSTING NUT		06
011	0503011333	COVER FIXER		03
012	0503010274	5/32"X 2" COTTERPIN		03
013	0502012740	PLATFORM RIGHT FIXER SUPPORT		02
014	0502012739	PLATFORM LEFT FIXER SUPPORT		01
015	0571017990	PLATFORM ENHANCEMENT PROTECTION		02
016	0501010942	3/8" X 1-1/4" BOLT		04
017	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
018	0503010025	3/8 SPRING WASHER		04
019	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
001	0511069661	PLATFORM SUPPORT PIVOT	06	
002	0503010849	3/8" X 1-1/2" BOLT	10	
003	0501010984	10,50 X 27 X 3,00 FLAT WASHER	20	
004	0503010025	3/8 SPRING WASHER	10	
005	0503010026	3/8" NUT	10	
006	0521064290	RIGHT PLATFORM	01	
007	0521064288	LEFT PLATFORM	01	
008	0521065206	PLATFORM CENTER	01	
009	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	06	
010	0503011336	1/2" HEX SELF ADJUSTING NUT	06	
011	0503011333	COVER FIXER	03	
012	0503010274	5/32"X 2" COTTERPIN	03	
013	0502012740	PLATFORM RIGHT FIXER SUPPORT	02	
014	0502012739	PLATFORM LEFT FIXER SUPPORT	01	
015	0571017990	PLATFORM ENHANCEMENT PROTECTION	02	
016	0501010942	3/8" X 1-1/4" BOLT	04	
017	0501010984	10,50 X 27 X 3,00 FLAT WASHER	04	
018	0503010025	3/8 SPRING WASHER	04	
019	0503010026	3/8" NUT	04	




Item	Code	Description	See page	QT
001	0511069661	PLATFORM SUPPORT PIVOT	06	
002	0503010849	3/8" X 1-1/2" BOLT	10	
003	0501010984	10,50 X 27 X 3,00 FLAT WASHER	20	
004	0503010025	3/8 SPRING WASHER	10	
005	0503010026	3/8" NUT	10	
006	0521064829	RIGHT PLATAFORM	01	
007	0521064828	SIDE PLATFORM	01	
008	0521064827	CENTRAL PLATFORM	01	
009	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	06	
010	0503011336	1/2" HEX SELF ADJUSTING NUT	06	
011	0503011333	COVER FIXER	03	
012	0503010274	5/32"X 2" COTTERPIN	03	
013	0502012740	PLATFORM RIGHT FIXER SUPPORT	02	
014	0502012739	PLATFORM LEFT FIXER SUPPORT	01	
015	0571017990	PLATFORM ENHANCEMENT PROTECTION	02	
016	0501010942	3/8" X 1-1/4" BOLT	04	
017	0501010984	10,50 X 27 X 3,00 FLAT WASHER	04	
018	0503010025	3/8 SPRING WASHER	04	
019	0503010026	3/8" NUT	04	




Item	Code	Description	See page	QT
01	0521063871	SIDE HANDRAIL		02
02	0521063875	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2 UNC G.5 ZN HEX NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8 SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
01	0521063976	SIDE HANDRAIL		02
02	0521063875	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2 UNC G.5 ZN HEX NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8 SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
01	0521064280	SIDE HANDRAIL		02
02	0521064018	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2 UNC G.5 ZN HEX NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8 SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04



Item	Code	Description	See page	QT
01	0521064280	SIDE HANDRAIL		02
02	0521065205	HANDRAIL CENTRAL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2 UNC G.5 ZN HEX NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8 SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
01	0521064844	SIDE HANDRAIL	02	
02	0521064843	CENTRAL HANDRAIL	01	
03	0503010395	1/2" X 1-1/4" BOLT	04	
04	0503010019	1/2" SPRING WASHER	12	
05	0503010060	1/2 UNC G.5 ZN HEX NUT	12	
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	06	
07	0503011082	C1/2" X 1.3/4" SCREW	02	
08	0551019884	45 X 50 X 3/8 FASTENER	08	
09	0571017991	CHAIN FIXER HANDRAIL	08	
10	0503013357	3/8 SELF-ADJUSTING NUT	16	
11	0503034094	22 TWISTED CHAIN	04	




Item	Code	Description	See page	QT
001	0511053051	RIGHT BEAM SUPPORT WITH DISTRIBUTOR		01
002	0511053052	LEFT BEAM SUPPORT WITH DISTRIBUTOR		01
003	0511053053	SUPPORT CENTER BEAM WITH DISTRIBUTOR		01
004	0503010849	3/8" X 1-1/2" BOLT		16
005	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
006	0503010025	3/8 SPRING WASHER		16
007	0503010026	3/8" NUT		16
008	0503034396	FERTILIZER SIDE COVER		15
009	0503010362	1/8 X 1.1/4 COTTERPIN		15
010	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS	35	02
011	0503062169	ASSEMBLED FERTILIZER HOPPER	36	01
012	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		06
013	0503010849	3/8" X 1-1/2" BOLT		12
014	0501010984	10,50 X 27 X 3,00 FLAT WASHER		24
015	0503010025	3/8 SPRING WASHER		12
016	0503010026	3/8" NUT		12
017	0503062562	CARDAN TERMINAL		02
018	0503011855	0.2" X 1.8" SPRING PIN		04
019	0503030331	1.2" X 1.2" X 12.2" HOSE		02
020	0503010243	CLAMP		04
021	0551019156	GEAR BOX LEVER LOCK		02
022	0503011953	5/16" X 1" BOLT		04
023	0501010694	FLAT WASHER		04
024	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
025	0503010337	5/16" NUT		04
026	0503010847	1/2" X 3.1/4" BOLT		02
027	0551019168	SLEEVE		02
028	0551019160	LEVER		02
029	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
030	0503010019	1/2" SPRING WASHER		02
031	0503010060	1/2 UNC G.5 ZN HEX NUT		02

Item	Code	Description	See page	QT
032	0551019167	SLEEVE UNION		02
033	0511069676	INNER LEVER		02
034	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
035	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
036	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
037	0503010019	1/2" SPRING WASHER		02
038	0503010060	1/2 UNC G.5 ZN HEX NUT		02
039	0501013518	FLAT WASHER		02
040	0503010140	1/8" X 3/4" COTTERPIN		02
041	0511069678	LH LOWER LEVER		02
042	0501013518	FLAT WASHER		02
043	0503010140	1/8" X 3/4" COTTERPIN		04
044	0551019159	LEVER FIXER BODY		02
045	0561016468	FASTENER		02
046	0503011336	1/2" HEX SELF ADJUSTING NUT		04
047	0571013471	PLATFORM FIXER LOCK		03
048	0501010096	3/8" X 2" BOLT		03
049	0501010984	10,50 X 27 X 3,00 FLAT WASHER		03
050	0503013357	3/8 SELF-ADJUSTING NUT		03




Item	Code	Description	See page	QT
001	0511053137	RIGHT BEAM SUPPORT WITH DISTRIBUTOR		01
002	0511053138	LEFT BEAM SUPPORT WITH DISTRIBUTOR		01
003	0511053053	SUPPORT CENTER BEAM WITH DISTRIBUTOR		01
004	0503010849	3/8" X 1-1/2" BOLT		20
005	0501010984	10,50 X 27 X 3,00 FLAT WASHER		40
006	0503010025	3/8 SPRING WASHER		20
007	0503010026	3/8" NUT		20
008	0503034396	FERTILIZER SIDE COVER		17
009	0503010362	1/8 X 1.1/4 COTTERPIN		17
010	0503062169	ASSEMBLED FERTILIZER HOPPER	36	03
011	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		06
012	0503010849	3/8" X 1-1/2" BOLT		12
013	0501010984	10,50 X 27 X 3,00 FLAT WASHER		24
014	0503010025	3/8 SPRING WASHER		12
015	0503010026	3/8" NUT		12
016	0503011957	NYLON HANDLE		02
017	0503010371	5/16" X 1" BOLT		04
018	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
019	0503010337	5/16" NUT		04
020	0503062562	CARDAN TERMINAL		02
021	0503011855	0.2" X 1.8" SPRING PIN		04
022	0503030331	1.2" X 1.2" X 12.2" HOSE		02
023	0503010243	CLAMP		04
024	0551018055	22,65 X 60 SLEEVE		02
025	0521014167	CONE LOCK		02
026	0551019156	GEAR BOX LEVER LOCK		02
027	0503011953	5/16" X 1" BOLT		04
028	0501010694	FLAT WASHER		04
029	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
030	0503010337	5/16" NUT		04
031	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02

Item	Code	Description	See page	QT
032	0581011541	ARTICULAT SLEEVE		02
033	0561016800	ARM/DISARMMENT LEVER		02
034	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
035	0503010019	1/2" SPRING WASHER		02
036	0503010060	1/2 UNC G.5 ZN HEX NUT		02
037	0561016797	SLEEVE UNION LEVER		02
038	0511069676	INNER LEVER		02
039	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
040	0503011082	C1/2" X 1.3/4" SCREW		02
041	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
042	0503010019	1/2" SPRING WASHER		02
043	0503010060	1/2 UNC G.5 ZN HEX NUT		02
044	0501013518	FLAT WASHER		02
045	0503010140	1/8" X 3/4" COTTERPIN		02
046	0511069678	LH LOWER LEVER		02
047	0501013518	FLAT WASHER		02
048	0503010140	1/8" X 3/4" COTTERPIN		04
049	0551019159	LEVER FIXER BODY		02
050	0561016468	FASTENER		02
051	0503011336	1/2" HEX SELF ADJUSTING NUT		04
052	0571015891	PLATFORM FIXER LOCK		03
053	0501010096	3/8" X 2" BOLT		03
054	0501010984	10,50 X 27 X 3,00 FLAT WASHER		03
055	0503013357	3/8 SELF-ADJUSTING NUT		03




Item	Code	Description	See page	QT
001	0511056159	RH BEAM SUPPORT & METERING		01
002	0511056160	LH BEAM SUPPORT & METERING		01
003	0521050249	SUPPORT CENTER BEAM WITH DISTRIBUTOR		01
004	0503010849	3/8" X 1-1/2" BOLT		20
005	0501010984	10,50 X 27 X 3,00 FLAT WASHER		40
006	0503010025	3/8 SPRING WASHER		20
007	0503010026	3/8" NUT		20
008	0503034396	FERTILIZER SIDE COVER		18
009	0503010362	1/8 X 1.1/4 COTTERPIN		18
010	0503062169	ASSEMBLED FERTILIZER HOPPER	36	03
011	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		06
012	0503010849	3/8" X 1-1/2" BOLT		12
013	0501010984	10,50 X 27 X 3,00 FLAT WASHER		24
014	0503010025	3/8 SPRING WASHER		12
015	0503010026	3/8" NUT		12
016	0503011957	NYLON HANDLE		02
017	0503010371	5/16" X 1" BOLT		04
018	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
019	0503010337	5/16" NUT		04
020	0503062208	CARDAN TERMINAL		02
021	0503011855	0.2" X 1.8" SPRING PIN		04
022	0503030331	1.2" X 1.2" X 12.2" HOSE		02
023	0503010243	CLAMP		04
024	0551018055	22,65 X 60 SLEEVE		02
025	0521014167	CONE LOCK		02
026	0551019156	GEAR BOX LEVER LOCK		02
027	0503011953	5/16" X 1" BOLT		04
028	0501010694	FLAT WASHER		04
029	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
030	0503010337	5/16" NUT		04
031	0503010847	1/2" X 3.1/4" BOLT		02

Item	Code	Description	See page	QT
032	0551019168	SLEEVE		02
033	0551019160	LEVER		02
034	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
035	0503010019	1/2" SPRING WASHER		02
036	0503010060	1/2 UNC G.5 ZN HEX NUT		02
037	0551019167	SLEEVE UNION		02
038	0511069676	INNER LEVER		02
039	0503013357	3/8 SELF-ADJUSTING NUT		03
040	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
041	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
042	0503010019	1/2" SPRING WASHER		02
043	0503010060	1/2 UNC G.5 ZN HEX NUT		02
044	0501013518	FLAT WASHER		02
045	0503010140	1/8" X 3/4" COTTERPIN		02
046	0511069678	LH LOWER LEVER		02
047	0501013518	FLAT WASHER		02
048	0503010140	1/8" X 3/4" COTTERPIN		04
049	0551019159	LEVER FIXER BODY		02
050	0561016468	FASTENER		02
051	0503011336	1/2" HEX SELF ADJUSTING NUT		04
052	0571013471	PLATFORM FIXER LOCK		03
053	0501010096	3/8" X 2" BOLT		03
054	0501010984	10,50 X 27 X 3,00 FLAT WASHER		03




Item	Code	Description	See page	QT
001	0511056159	RH BEAM SUPPORT & METERING		01
002	0511056160	LH BEAM SUPPORT & METERING		01
003	0511056066	BEAM SUPPORT & METERING		01
004	0503010849	3/8" X 1-1/2" BOLT		20
005	0501010984	10,50 X 27 X 3,00 FLAT WASHER		40
006	0503010025	3/8 SPRING WASHER		20
007	0503010026	3/8" NUT		20
008	0503034396	FERTILIZER SIDE COVER		18
009	0503010362	1/8 X 1.1/4 COTTERPIN		18
010	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS	37	02
011	0503062169	ASSEMBLED FERTILIZER HOPPER	36	02
012	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		06
013	0571015546	FERTILIZER HOPPER FIXER		01
014	0503010849	3/8" X 1-1/2" BOLT		14
015	0501010984	10,50 X 27 X 3,00 FLAT WASHER		28
016	0503010025	3/8 SPRING WASHER		14
017	0503010026	3/8" NUT		14
018	0503062208	CARDAN TERMINAL		02
019	0503011855	0.2" X 1.8" SPRING PIN		04
020	0503030331	1.2" X 1.2" X 12.2" HOSE		02
021	0503010243	CLAMP		04
022	0551018055	22,65 X 60 SLEEVE		02
023	0521014167	CONE LOCK		02
024	0551019156	GEAR BOX LEVER LOCK		02
025	0503011953	5/16" X 1" BOLT		04
026	0501010694	FLAT WASHER		04
027	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
028	0503010337	5/16" NUT		04
029	0503010847	1/2" X 3.1/4" BOLT		02
030	0551019168	SLEEVE		02
031	0551019160	LEVER		02


Item	Code	Description	See page	QT
032	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
033	0503010019	1/2" SPRING WASHER		02
034	0503010060	1/2 UNC G.5 ZN HEX NUT		02
035	0551019167	SLEEVE UNION		02
036	0511069676	INNER LEVER		02
037	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
038	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
039	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
040	0503010019	1/2" SPRING WASHER		02
041	0503010060	1/2 UNC G.5 ZN HEX NUT		02
042	0501013518	FLAT WASHER		02
043	0503010140	1/8" X 3/4" COTTERPIN		02
044	0511069678	LH LOWER LEVER		02
045	0501013518	FLAT WASHER		02
046	0503010140	1/8" X 3/4" COTTERPIN		04
047	0551019159	LEVER FIXER BODY		02
048	0561016468	FASTENER		02
049	0503011336	1/2" HEX SELF ADJUSTING NUT		04
050	0571013471	PLATFORM FIXER LOCK		03
051	0501010096	3/8" X 2" BOLT		03
052	0501010984	10,50 X 27 X 3,00 FLAT WASHER		03
053	0503013357	3/8 SELF-ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0503033577	BEAN FERTILIZ 5 MOUTHS		01
02	0503033578	FERTILIZER BEAM LOCK		01
03	0503032136	FERTILIZER BEAM COVER		02
04	0503032052	LID ARTICULATING SHAFT		04
05	0503032051	LID SHAFT FIXER		08
06	0503032054	FLAT WASHER (INOX)		02
07	0503032053	BOLT C.A.S.I		02
08	0503032055	BOLT LID		02




Item	Code	Description	See page	QT
01	0503033801	BEAM FERTILIZER		01
02	0503033578	FERTILIZER BEAM LOCK		02
03	0503032134	FERTILIZER HOPPER LID		03
04	0503032052	LID ARTICULATING SHAFT		06
05	0503032051	LID SHAFT FIXER		12
06	0503032054	FLAT WASHER (INOX)		04
07	0503032053	BOLT C.A.S.I		04
08	0503032055	BOLT LID		04



Item	Code	Description	See page	QT
01	0503033576	FERTILIZER HOPPER		01
02	0503033578	FERTILIZER BEAM LOCK		01
03	0503032134	FERTILIZER HOPPER LID		02
04	0503032052	LID ARTICULATING SHAFT		04
05	0503032051	LID SHAFT FIXER		08
06	0503032054	FLAT WASHER (INOX)		02
07	0503032053	BOLT C.A.S.I		02
08	0503032055	BOLT LID		02




Item	Code	Description	See page	QT
001	0503060100	INSTRUCTIONS MANUAL CANISTER		01
002	0503010267	NYLON CLAMP		01
003	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
004	0501010694	FLAT WASHER		01
005	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
006	0503010337	5/16" NUT		01
007	0511031948	PLASTIC COVER WITH INSTRUCTIONS MANUAL		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2 UNC G.5 ZN HEX NUT		08
09	0571014441	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0501052560	MOTOR AXLE SIGNAL	44	02
15	0511051434	TRANSMISSION ACTUATOR	45	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	46	01
16.	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	47	01
17	0521043316	RIGHT GEAR BOX ASSY	48	01
17.	0521043317	LEFT GEAR BOX ASSY	49	01
18	0501010243	1/2" X 1-1/2" BOLT		06
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
20	0503010019	1/2" SPRING WASHER		10
21	0503012682	1/2" BSW NUT		06
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
23	0503010060	1/2 UNC G.5 ZN HEX NUT		04
24	0521062072	33Z GEAR		02
25	0511054363	CHAIN TENSIONER	59	02
26	0501058234	LOWER CHAIN TENSIONER	60	02
27	0521055207	TOP CURRENT STRETCHER	61	02
28	0501058236	BEARING WITH 21Z GEAR	62	02
29	0501058237	16Z GEAR BEARING	63	02

Item	Code	Description	See page	QT
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	64	02
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		02
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		04
34	0503010256	3/8" X 3/4" BOLT		02
35	0503010025	3/8 SPRING WASHER		02
36	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
37	0501010637	FLAT WASHER		02
38	0503030303	SUPPORT WASHER		06




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2 UNC G.5 ZN HEX NUT		08
09	0571014440	ENGINE SHAFT 2475		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0501052560	MOTOR AXLE SIGNAL	44	02
15	0511051434	TRANSMISSION ACTUATOR	45	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	46	01
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	47	01
18	0521043316	RIGHT GEAR BOX ASSY	48	01
19	0521043317	LEFT GEAR BOX ASSY	49	01
20	0503014734	BOLT		06
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
22	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2 UNC G.5 ZN HEX NUT		10
25	0521064448	GEAR		02
26	0511059261	CHAIN TENSIONER	65	04
27	0521055217	LOWER CURRENT STRETCH	66	02
28	0501058254	UPPER SEED CHAIN TENSIONER	67	02
29	0521055216	BEARING WITH GEAR	68	02
30	0521055218	BEARING GEAR WITH DOUBLE	69	02
31	0521055214	BEARING GEAR WITH	70	02

Item	Code	Description	See page	QT
32	0503012204	40-1 CHAIN X 82 LINK + RED		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2 UNC G.5 ZN HEX NUT		08
09	0571014442	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0501052560	MOTOR AXLE SIGNAL	44	02
15	0511051434	TRANSMISSION ACTUATOR	45	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	46	01
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	47	01
18	0521043316	RIGHT GEAR BOX ASSY	48	01
19	0521043317	LEFT GEAR BOX ASSY	49	01
20	0501011600	1/2" X 1-1/4" BOLT		06
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
22	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2 UNC G.5 ZN HEX NUT		10
25	0521064448	GEAR		02
26	0511059261	CHAIN TENSIONER	65	04
27	0521055217	LOWER CURRENT STRETCH	66	02
28	0501058254	UPPER SEED CHAIN TENSIONER	67	02
29	0521055216	BEARING WITH GEAR	68	02
30	0521055218	BEARING GEAR WITH DOUBLE	69	02
31	0521055214	BEARING GEAR WITH	70	02

Item	Code	Description	See page	QT
32	0503012204	40-1 CHAIN X 82 LINK + RED		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2 UNC G.5 ZN HEX NUT		08
09	0571014442	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0501052560	MOTOR AXLE SIGNAL	44	02
15	0511051434	TRANSMISSION ACTUATOR	45	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	46	01
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	47	01
18	0521043316	RIGHT GEAR BOX ASSY	48	01
19	0521043317	LEFT GEAR BOX ASSY	49	01
20	0501011600	1/2" X 1-1/4" BOLT		06
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
22	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2 UNC G.5 ZN HEX NUT		10
25	0521064448	GEAR		02
26	0511059261	CHAIN TENSIONER	65	04
27	0521055217	LOWER CURRENT STRETCH	66	02
28	0501058254	UPPER SEED CHAIN TENSIONER	67	02
29	0521055216	BEARING WITH GEAR	68	02
30	0521055218	BEARING GEAR WITH DOUBLE	69	02
31	0521055214	BEARING GEAR WITH	70	02

Item	Code	Description	See page	QT
32	0503012204	40-1 CHAIN X 82 LINK + RED		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2 UNC G.5 ZN HEX NUT		08
09	0571017078	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0501052560	MOTOR AXLE SIGNAL	44	02
15	0511051434	TRANSMISSION ACTUATOR	45	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	46	01
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	47	01
18	0521043316	RIGHT GEAR BOX ASSY	48	01
19	0521043317	LEFT GEAR BOX ASSY	49	01
20	0501010243	1/2" X 1-1/2" BOLT		06
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
22	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2 UNC G.5 ZN HEX NUT		10
25	0521064448	GEAR		02
26	0511059261	CHAIN TENSIONER	65	04
27	0521055217	LOWER CURRENT STRETCH	66	02
28	0501058254	UPPER SEED CHAIN TENSIONER	67	02
29	0521055216	BEARING WITH GEAR	68	02
30	0521055218	BEARING GEAR WITH DOUBLE	69	02
31	0521055214	BEARING GEAR WITH	70	02


Item	Code	Description	See page	QT
32	0503012204	40-1 CHAIN X 82 LINK + RED		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	50	01
02	0511059266	CLOSED BEARING	52	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	54	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	56	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	57	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	58	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	51	01
02	0511059266	CLOSED BEARING	52	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	54	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	56	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	57	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	58	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	53	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	55	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	GEARBOX BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8 SPRING WASHER		01
09	0503010013	5/8 NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503019355	BEARING 6202 2RS1		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0551019173	CHAIN SLEEVE TENSIONER		01
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01
08	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOUBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019174	DOUBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
06	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	1 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503031805	11Z 1/2" GEAR		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8 SPRING WASHER		01
09	0503010013	5/8 NUT		01




Item	Code	Description	See page	QT
01	0521018933	CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0501011234	5/8" X 3" BOLT		01
02	0531017086	50 AXLETIGHTENER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0503019356	BEARING 6005 2RS1		01
05	0503011105	SEAL RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0503016460	5/8" X 4.1/2" BOLT		01
02	0551019175	DOUBLE GEAR AXLE		01
03	0503019356	BEARING 6005 2RS1		02
04	0511069680	20Z X 28Z DOUBLE GEAR		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511063106	20Z AXLE BEARING DOUBLE		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0521055215	DOUBLE TRANSMISSION BEARING	71	01
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503019356	BEARING 6005 2RS1		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0511059262	WHEEL SUPPORT ASSY	74	01
02	0501058240	WHEEL FASTENER WITH TENSIONER	79	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0511054336	SUPPORT WHEELED WITHOUT TRANSMISSION	83	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8 SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0531062422	WHEEL ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0501058241	WHEEL SUPPORT CHAIN TENSIONER	75	01
07	0511052770	WHEEL WITH TIRE	76	01
08	0503018981	BOLT		02
09	0503010027	5/8 SPRING WASHER		04
10	0591010589	BODY LOCK WHEEL		01
11	0521069983	WHEEL COVER		01
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
13	0551017715	FLAT WASHER		02
14	0503013030	5/8" X 3.1/4" BOLT		01
15	0511050681	TRACTION SPRING		01
15A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
15B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	77	01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	78	01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8 NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER		01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	80	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	82	01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	81	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	81	01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521061566	CARRYING WHEEL ARM TRACTION		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0503018981	BOLT		02
07	0503010027	5/8 SPRING WASHER		02
08	0521012190	AXLE LOCK		02
09	0521051801	WHEEL WITH TIRE 7.00X16 WHEELED BOX 84 WITHOUT TRANSMISSION		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	77	01
02	0521051800	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	85	01




Item	Code	Description	See page	QT
01	0503010328	25590/25523 ROLLER BEARING		02
02	0503010804	00547-B SEAL		02
03	0521012185	TRANSMISSION WHEEL AXLE		01
04	0503010330	KM 9 LOCKNUT		01
05	0511015949	LOCK NUT		01
06	0503010329	LOCK WASHER		01
07	0503010002	1800 GREASE FITTING		01
08	0501110721	WHEEL HUB WITH SCREW / NUTS		01
08A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
08B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
08C	0503016516	5/8 UNF CONIC NUT		06




Item	Code	Description	See page	QT
01	0503062206	CARDAN TERMINAL	86	01




Item	Code	Description	See page	QT
01	0503062392	DRIVE SHAFT		01
02	0503030331	1.2" X 1.2" X 12.2" HOSE		01
03	0503010243	CLAMP		02
04	0503011855	0.2" X 1.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8 SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
08	0503013357	3/8 SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		05
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		10
03	0501012140	FLAT WASHER		10




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01



Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	93	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01



Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
001	0511069622	ROW MARKER ARM SUPPORT		02
002	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
003	0503012412	5/8" UNC SELF LOCKING NUT		08
004	0503011070	BEATER		02
005	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		02
006	0511061811	ROW MARKER ARM		02
007	0521061655	BOLT 5/8 UNC X 320 MM		02
008	0521010479	SLEEVE ARTICULATION		04
009	0501012140	FLAT WASHER		04
010	0503012412	5/8" UNC SELF LOCKING NUT		02
011	0511058449	HYDRAULIC CYLINDER	97	02
012	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
013	0503010523	1/4" X 2" SPLIT PIN		02
014	0511015779	1" X 4.2" AXLE		02
015	0503010523	1/4" X 2" SPLIT PIN		02
016	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
017	0501068994	8,30 X 78 LOCK PIN		02
018	0503030168	HITCH PIN CLIP		02
019	0501066949	1235 TURNBUCKLE		02
020	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
021	0501054649	HBM SEQUENTIAL VALVE	99	01
022	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
023	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
024	0503010025	3/8 SPRING WASHER		02
025	0511057093	HYDRAULIC MARKER HYGIENE SET		01
025A	0501080388	3/8 X 4300 TR-TC HOSE ASSY		02
025B	0501081791	HOSE ASSY		02
025C	0501080878	3/8 X 4200 TC-TM HOSE ASSY		02
026	0501053834	MALE QUICK COUPLER	100	02
026A	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
026B	0503011882	MALE QUICK COUPLER CAP		01




PST TRIO FLEX TITANIUM - FRAME
MARKER CYLINDER

Page 94
0511053056


Item	Code	Description	See page	QT
027	0502012702	BODY SUPPORT CLAMP		02
028	0531011180	UPPER BODY CLIP		08
029	0503010180	7/16" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0501054649	HBM SEQUENTIAL VALVE	99	01
02	0511058431	HYDRAULIC CYLINDER	98	01
03	0511058431	HYDRAULIC CYLINDER	98	01
04	0511015573	2.07" X 1.6" TRANSPORT LOCK		02
05	0501068994	8,30 X 78 LOCK PIN		02
06	0503030168	HITCH PIN CLIP		02
07	0511057890	17 E 500 HYDRAULIC MARKER HOSE ASSEMBLY		01
07A	0501080383	3/8" X 197" TC-TM HOSE		02
07B	0501081748	HOSE		02
07C	0501081981	HOSES		02
08	0501053834	MALE QUICK COUPLER	100	02
08A	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
08B	0503011882	MALE QUICK COUPLER CAP		01
09	0511018012	HIDRAULIC ADAPTER		04




Item	Code	Description	See page	QT
001	0501054649	HBM SEQUENTIAL VALVE	99	01
002	0511058431	HYDRAULIC CYLINDER	98	01
003	0511058431	HYDRAULIC CYLINDER	98	01
004	0511015573	2.07" X 1.6" TRANSPORT LOCK		02
005	0501068994	8,30 X 78 LOCK PIN		02
006	0503030168	HITCH PIN CLIP		02
007	0511057526	HYDRAULIC MARKER HAND SET		01
007A	0501081980	HOSE 3/8 X 5200 TC-TM		02
007B	0501082034	HOSE		02
007C	0501082035	HOSE		02
008	0501053834	MALE QUICK COUPLER	100	02
008A	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
008B	0503011882	MALE QUICK COUPLER CAP		01
009	0511018012	HIDRAULIC ADAPTER		04




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0501067700	2.5" X 25" CYLINDER CASE		01
02	0521066632	EXTENDER		01
03	0503030384	CON PLUG N-001		02
04	0502012837	PISTON		01
05	0503018005	RING		01
06	0503011109	2-119 N 3006-9B O'RING		01
07	0503010163	D-1500 SCRAPER RING		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503018004	RING		01
11	0503018003	GASKET		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0503010002	1800 GREASE FITTING		02
15	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01



Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0591019605	FLUXO DIVIDER VALVE SUPPORT		01
01.	0591019604	VALVE SUPPORT		01
02	0511059290	VALVE ASSEMBLY	104	01
03	0501053835	FEMALE QUICK COUPLER	105	02
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0531011180	UPPER BODY CLIP		04
06	0521066564	DUCT SEAL OIL		01
07	0531013922	0.6" X 0.8" X 1" SLEEVE		02
08	0503011179	3/8" X 2-1/4" BOLT		02
09	0503010025	3/8 SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0502012702	BODY SUPPORT CLAMP		12
12	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
13	0501053834	MALE QUICK COUPLER	100	04
14	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		04
15	0503010244	7/16" NUT		04
16	0503010180	7/16" SPRING WASHER		08
17	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
18	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2 UNC G.5 ZN HEX NUT		02
21	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
22	0571017774	SPRING PROTECTION QUICK HOSE		01
23	0511059418	HYDRAULIC SYSTEM HOSE ASSEMBLY		01
23A	0501080406	3/8" X 23" TR-TC HOSE		01
23B	0501080150	3/8 X 800 TR-TC HOSE		01
23C	0501081930	HOSE		01
23D	0501081646	TC-TC HOSE ASSY		03
24	0521052484	HOSE 1/2 X 4122 TM-TM BLACK / RED		01
24A	0501080881	HOSE		01
24B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02


Item	Code	Description	See page	QT
24C	0503034495	HYDRAULIC HOSE GRIP (RED)		02
24D	0503018952	PLASTIC BOLT		12
25	0521052485	HOSE 1/2 X 4122 TM-TM BLACK / BLUE		01
25A	0501080881	HOSE		01
25B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
25C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		02
25D	0503018952	PLASTIC BOLT		12




Item	Code	Description	See page	QT
001	0571013472	FIXER BODY VALVE		01
002	0511053065	TRIPLE VALVE	106	01
003	0503010371	5/16" X 1" BOLT		02
004	0503010421	5/16" X 1-1/2" BOLT		02
005	0501010694	FLAT WASHER		04
006	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
007	0503010337	5/16" NUT		04
008	0502012701	LOWER BODY CLIP		02
009	0521063909	DUCT SEAL OIL		01
010	0531013922	0.6" X 0.8" X 1" SLEEVE		02
011	0531011180	UPPER BODY CLIP		02
012	0511057676	HOSE KIT SYSTEM HYDRAULIC		01
012A	0501080406	3/8" X 23" TR-TC HOSE		01
012B	0501080150	3/8 X 800 TR-TC HOSE		01
012C	0501080392	3/8 X 3300 TR-TC HOSE		01
012D	0501080442	3/8" X 130" TC-TC HOSE ASSY		03
012E	0501081073	HOSE 1/2 X 4200 TC-TM		02
013	0501053834	MALE QUICK COUPLER	100	02
013A	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
013B	0503011882	MALE QUICK COUPLER CAP		01
014	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
015	0571017774	SPRING PROTECTION QUICK HOSE		01
016	0502012702	BODY SUPPORT CLAMP		12
017	0503010244	7/16" NUT		04
018	0503010180	7/16" SPRING WASHER		08
019	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
020	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		04
021	0503013100	NYLON CLAMP		02




Item	Code	Description	See page	QT
001	0571013472	FIXER BODY VALVE		01
002	0511053065	TRIPLE VALVE	106	01
003	0503010237	3/8" X 1" BOLT		02
004	0503011179	3/8" X 2-1/4" BOLT		02
005	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
006	0503010025	3/8 SPRING WASHER		02
007	0503010026	3/8" NUT		02
008	0531011180	UPPER BODY CLIP		02
009	0521063909	DUCT SEAL OIL		01
010	0531013922	0.6" X 0.8" X 1" SLEEVE		02
011	0531011180	UPPER BODY CLIP		02
012	0511057083	HOSE KIT SYSTEM HYDRAULIC		01
012A	0501080406	3/8" X 23" TR-TC HOSE		01
012B	0501080150	3/8 X 800 TR-TC HOSE		01
012C	0501080388	3/8 X 4300 TR-TC HOSE ASSY		01
012D	0501080757	HOSE 3/8 X 4300 TC-TC		03
012E	0501081922	HOSE		02
013	0501053834	MALE QUICK COUPLER	100	02
013A	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
013B	0503011882	MALE QUICK COUPLER CAP		01
014	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
015	0571017774	SPRING PROTECTION QUICK HOSE		01
016	0502012702	BODY SUPPORT CLAMP		12
017	0503010244	7/16" NUT		04
018	0503010180	7/16" SPRING WASHER		08
019	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
020	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		04
021	0503013100	NYLON CLAMP		02




Item	Code	Description	See page	QT
01	0503016524	DIVIDER VALVE		01
02	0581011593	NIPPLE R.1.1/16 UN		01
03	0511010111	7/8" NIPPLE		03
04	0503011109	2-119 N 3006-9B O'RING		01
05	0503010045	O'RING		03




Item	Code	Description	See page	QT
01	0503011883	QUICK CONNECTION COVER		01
02	0503011628	FEMALE QUICK COUPLER		01




Item	Code	Description	See page	QT
01	0503016524	DIVIDER VALVE		01
02	0551012400	7/8" UNF NIPPLE		01
03	0501011460	7/8 NF REDUCTION NIPPLE		03
04	0503010190	2-114 N 3006-9B O'RING		04




Item	Code	Description	See page	QT
001	0511058406	HYDRAULIC CYLINDER	108	01
002	0521012536	COUPLING SHAFT		01
003	0503010523	1/4" X 2" SPLIT PIN		02
004	0531012565	SLEEVE 16,3X 30 X 88		01
005	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
006	0503010027	5/8 SPRING WASHER		01
007	0503010013	5/8 NUT		01
008	0531019171	1.25" X 7" COUPLING SHAFT		01




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCKLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
001	0511058406	HYDRAULIC CYLINDER	108	01
002	0521012538	1.2" X 3.5" COUPLING SHAFT		01
003	0521012536	COUPLING SHAFT		01
004	0503010523	1/4" X 2" SPLIT PIN		02
005	0531012565	SLEEVE 16,3X 30 X 88		01
006	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
007	0503010027	5/8 SPRING WASHER		01
008	0503010013	5/8 NUT		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	LEFT COMPRESSION SPRING		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	LEFT COMPRESSION SPRING		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	108	03
02	0521012538	1.2" X 3.5" COUPLING SHAFT		03
03	0521012536	COUPLING SHAFT		03
04	0503010523	1/4" X 2" SPLIT PIN		06
05	0531012565	SLEEVE 16,3X 30 X 88		03
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		03
07	0503010027	5/8 SPRING WASHER		03
08	0503010013	5/8 NUT		03




Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0511061880	SIDE RIGHT RATCHET		01
03	0511061881	RATCHET FOLLOWER		01
04	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
05	0503011179	3/8" X 2-1/4" BOLT		05
06	0503010025	3/8 SPRING WASHER		05
07	0503010026	3/8" NUT		05
08	0503010002	1800 GREASE FITTING		02
09	0531010264	SIDE RATCHET		01
10	0521066919	3-POINT EXTENSOR RIGHT FUSE		01
11	0521066337	LEFT EXTENSOR 3 SPIKE		01




Item	Code	Description	See page	QT
01	0502011237	ESTABILIZER BODY		01
02	0521063913	JACKET LEFT		01
03	0521063914	JACKET RIGHT		01
04	0511061880	SIDE RIGHT RATCHET		01
05	0531010264	SIDE RATCHET		01
06	0511061881	RATCHET FOLLOWER		01
07	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
08	0503011179	3/8" X 2-1/4" BOLT		05
09	0503011443	3/8" SPRING WASHER		05
10	0503010026	3/8" NUT		05
11	0503010002	1800 GREASE FITTING		05
12	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0502011195	ADJUSTMENT NUT BODY		02
02	0521063884	LEFT TURNBUCKLE		02
03	0521063883	RIGHT TURNBUCKLE		02
04	0541018673	COUNTERNUT		02
05	0541018672	COUNTERNUT		02
06	0503010002	1800 GREASE FITTING		04




Item	Code	Description	See page	QT
001	0502011197	170 ADJUSTMENT NUT BODY		01
002	0521064845	EXTENSOR		01
003	0521064846	EXTENSOR		01
004	0541018673	COUNTERNUT		01
005	0541018672	COUNTERNUT		01
006	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521065193	TURNBUCKLE AXLE		01
02	0521067392	FIXED BRACKET		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0521067393	EXTERNAL SIDE EAR		01
06	0571019949	JUNCTION SHAFT		01
07	0503030119	LOCK PIN		01
08	0503010002	1800 GREASE FITTING		03



Item	Code	Description	See page	QT
001	0501078990	TURNBUCKLE AXLE		01
002	0561019879	LOCK ATTACHMENT BAR		01
003	0521063917	POINT REVOLVING EXTENDING		01
004	0521066340	SIDE EXTENDER		01




Item	Code	Description	See page	QT
001	0521064834	LATERAL EXTENSOR		01
002	0501078990	TURNBUCKLE AXLE		01
003	0561019879	LOCK ATTACHMENT BAR		01
004	0521063917	POINT REVOLVING EXTENDING		01
005	0511017907	1/8" BSPT X 6 PLUG		02
006	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0501059834	LEFT SHORT SEED ROW FRONT	122	01
02	0501059833	RIGHT SHORT SEED ROW FRONT	123	01
03	0501059835	RIGHT LONG SEED ROW FRONT	124	01
04	0501059836	LEFT LONG SEED ROW FRONT	125	01
05	0511056621	RIGHT REAR SEED ROW	134	01
06	0511056622	LEFT REAR SEED ROW	135	01
07	0521050096	SEED HOPPER SYSTEM (CSU)	141	01
08	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	143	01
09	0521044269	PRESS WHEELS/DEPTH ASSY	144	01
10	0521044460	SYSTEM DEPTH / COMPACTOR	145	01
11	0521046501	DEPTH CONTROL AND PRESS WHEEL WITH FAST ADJUSTING	146	01
12	0511059350	FERTILIZER ROW SUPPORT ASSEMBLY	170	01
13	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	171	01
14	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	172	01
15	0501058423	FERTILIZER ROD SPRING ROW	173	01
16	0511058619	20" SHORT ROW DISC BLADE	174	01
17	0511058617	DISC CUT 18 SHORT LINE	175	01
18	0511058620	20" LONG ROW DISC BLADE	176	01
19	0511058618	DISC CUT 18 LONG LINE	177	01
20	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	178	01
21	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	179	01
22	0503030408	2X2X390 HOSE		01
23	0503010243	CLAMP		02
24	0501010066	3/4" X 9" BOLT		01
25	0521017831	SUPPORT SLEEVE SPACER		01
26	0511017232	FLAT WASHER		01
27	0503011255	3/4" LOCK NUT		01
28	0503030391	RIGHT FERTILIZER NOZZLE		01
29	0503030392	LEFT FERTILIZER NOZZLE		01

Item	Code	Description	See page	QT
30	0503031050	CURVED CONDUCTOR		01
30.	0581011691	CURVED CONDUCTOR		01
30..	0503031826	CURVED CONDUCTOR		01
31	0503010246	CLAMP		01
32	0503031145	2" X 2" X 20" HOSE		01
32.	0503030331	1.2" X 1.2" X 12.2" HOSE		01
33	0503031076	2" HOSE CLAMP		01
34	0503010905	1/2" X 2-1/4" BOLT		02
35	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
36	0503010019	1/2" SPRING WASHER		04
37	0503010060	1/2 UNC G.5 ZN HEX NUT		04
38	0531013600	PRESS ADJUSTMENT LEVER		01
39	0511057542	HDA	186	01
40	0503030520	SEED SOCKET		01
41	0581010083	FERTILIZER SOCKET LEFT		01
42	0521013164	EXTENDER		01
43	0501110231	SCARIFIER ROD WITH TIP	185	01
44	0511017969	0.1" SPACING PLATE		02
45	0511061852	ADJUSTAMENT CONDUCTOR FERTILIZER		01
46	0521018501	TURNBUCKLE LEVER		01
47	0503033672	NOZZLE WITHOUT TITANIUM		01
48	0511052024	FAST CLOSING SET	188	01
49	0501050120	LARGER WALKING BEAM ASSY	189	01
50	0503062066	DISC SET WITH CORN RING	190	01
51	0503062067	DISC SET / RING SOY 90F TITANIUM	191	01




Item	Code	Description	See page	QT
01	0521064651	LEFT SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	126	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION HOPPER SEED ROW	127	01
12	0561014904	TRANSMISSION AXLE FRAME ROW		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	128	01
14	0511055260	SEED ROW CHAIN TENSIONER	131	01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521061427	SHORT SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" COTTERPIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" COTTERPIN		01
31	0503034580	TRACTION SPRING		02



PST TRIO FLEX TITANIUM - FRAME
LEFT SHORT SEED ROW FRONT

Page 122
0501059834

Item	Code	Description	See page	QT
32	0511059264	BEARING WITH AXLE	132	01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064653	RIGH SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	126	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION HOPPER SEED ROW	127	01
12	0561014904	TRANSMISSION AXLE FRAME ROW		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	128	01
14	0511055260	SEED ROW CHAIN TENSIONER	131	01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521061427	SHORT SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" COTTERPIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" COTTERPIN		01
31	0503034580	TRACTION SPRING		02



PST TRIO FLEX TITANIUM - FRAME
RIGHT SHORT SEED ROW FRONT

Page 123
0501059833

Item	Code	Description	See page	QT
32	0511059264	BEARING WITH AXLE	132	01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064652	RH SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	126	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION HOPPER SEED ROW	127	01
12	0561014904	TRANSMISSION AXLE FRAME ROW		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	128	01
14	0511055260	SEED ROW CHAIN TENSIONER	131	01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521061427	SHORT SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" COTTERPIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" COTTERPIN		01
31	0503034580	TRACTION SPRING		02



PST TRIO FLEX TITANIUM - FRAME
RIGHT LONG SEED ROW FRONT

Page 124
0501059835

Item	Code	Description	See page	QT
32	0511059264	BEARING WITH AXLE	132	01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064650	LEFT SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	126	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION HOPPER SEED ROW	127	01
12	0561014904	TRANSMISSION AXLE FRAME ROW		01
13	0501052769	BEARING WITH 17Z GEAR	130	01
14	0511055260	SEED ROW CHAIN TENSIONER	131	01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521061427	SHORT SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" COTTERPIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" COTTERPIN		01
31	0503034580	TRACTION SPRING		02




PST TRIO FLEX TITANIUM - FRAME
LEFT LONG SEED ROW FRONT

Page 125
0501059836


Item	Code	Description	See page	QT
32	0511059264	BEARING WITH AXLE	132	01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0502012718	ROW BEARING		01
02	0503012882	BEARING		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01
17	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0511050617	FRONT SEED ROW BEARING	129	01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0502012819	17Z GEAR WITH HEX HOLE		01




Item	Code	Description	See page	QT
01	0502011697	GEARBOX BEARING		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0503010406	501025 CLAMPING RING (FOR AXLE)		01
02	0502011697	GEARBOX BEARING		01
03	0503011410	ROLLER BEARING		01
04	0503011105	SEAL RING		01
05	0503011953	5/16" X 1" BOLT		02
06	0501010694	FLAT WASHER		02
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
08	0503010337	5/16" NUT		02
09	0502012819	17Z GEAR WITH HEX HOLE		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0501059326	UNIVERSAL JOINT AXLE	133	01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0511050611	5/8" HEX AXLE BEARING		01




Item	Code	Description	See page	QT
01	0561016322	5/8" HEX AXLE		01
02	0501056296	UNIVERSAL JOINT		01
03	0503011855	0.2" X 1.8" SPRING PIN		02
04	0561014794	350 AXLE HEX		01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8	136	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503011443	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	137	01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8	136	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503011443	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511056586	15 X 15 SEED DDD LEFT	138	01




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502012639	12Z LOWER CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	139	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	181	01
03	0511053172	LEFT LOW HUB WITH 15 DISC	180	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	140	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	181	01
03	0511053172	LEFT LOW HUB WITH 15 DISC	180	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0521050118	3" NOZZLE SEED HOPPER		01
02	0581014295	FIXING SLEEVE		01
03	0511052058	SEED SYSTEM TITANIUM	142	01
04	0503010358	5/16" X 5/8" BOLT		05
05	0501010694	FLAT WASHER		05
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
07	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0503062031	BASE SET		01
02	0503062032	NECK TITANIUM ASSY		01
03	0503062033	OPPOSITE BASE SET		01
04	0503062034	CENTRAL ADAPTER SET		01
05	0503062035	SET FALSE ADAPT CENTER		01
06	0503062036	SUBSET ASSY LOCK BASE		01
07	0503062037	SUBSET ESCOVAFLEX ASSY		01
08	0503062038	ASSY ANTI-LEAP		01
09	0503062039	POLIFLOW TITANIUM ASSY		01
09.	0503016279	POLIFLOW TITANIUM ASSY		01
10	0503062040	DISPLAY ASSY TITANIUM 1050010		01
11	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
12	0503062042	SET BOLT ARTICULADOR		01
13	0503062043	ASSY LIMIT WEIGHT		01
14	0503062044	ASSEMBLY SEED HOPPER SET		01
14A	0503016285	BOLT		05
14B	0503016286	HEX NUT		05
14C	0503016287	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	147	01
02	0501052538	DEPTH BAND WITH ARMS	152	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	153	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	154	01
07	0503033942	COMPACTOR WHEEL REGULATOR LID		01




Item	Code	Description	See page	QT
01	0511055326	DEPTH CONTROL PRESS WHEEL ASSY	155	01
02	0551019650	SLEEVE 13,20 X 25 X 74		01
03	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0511055327	COMPACTING WHEEL V ASSY RUBBER	160	01




Item	Code	Description	See page	QT
01	0511055690	WHEEL SYSTEM	161	01
02	0551019650	SLEEVE 13,20 X 25 X 74		01
03	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0511055327	COMPACTING WHEEL V ASSY RUBBER	160	01




Item	Code	Description	See page	QT
01	0511059462	DEPTH CONTROL WITH FAST ADJUSTMENT	164	01
02	0511050077	WHEEL STRIPED	167	02
03	0503016453	1/2" X 2.1/2 BOLT		02
04	0503010019	1/2" SPRING WASHER		04
05	0503010028	1/2" NUT		02
06	0501052908	COMPACTOR WHEEL WITH BEARING	169	02
07	0503010752	1/2" X 3.1/2" BOLT		01
08	0503013739	1/2" X 1" BOLT		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT DEPTH WHEEL ARM WITH HUB	148	01
07	0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	149	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	151	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	3/8 UNC X 3/4 BOLT		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL HUB	150	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL HUB	150	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	PROTECTION LID		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	169	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	169	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502012758	DEPTH CONTROL SUPPORT		01
02	0503010585	0,24" X 1.18" SPRING PIN		02
03	0503010002	1800 GREASE FITTING		01
04	0501059228	ADJUSTMENT LEVER	156	01
05	0502012611	DEPTH CONTROL AXLE		01
06	0571015326	ARTICULATION SLEEVE HANDLE		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
08	0503011443	3/8" SPRING WASHER		01
09	0503010237	3/8" X 1" BOLT		01
10	0571016132	PIVOT SHAFT		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0561014336	PIVOT SHAFT		01
13	0503010071	3/16" X 1" COTTERPIN		02
14	0511055328	DEPTH WHEEL SYSTEM	157	01
15	0511055329	LEFT DEPTH WHEEL	158	01




Item	Code	Description	See page	QT
01	0502012603	ADJUSTMENT LEVER		01
02	0502011689	1/8" DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0511015976	FLAT WASHER		01
05	0503010140	1/8" X 3/4" COTTERPIN		01




Item	Code	Description	See page	QT
01	0561014385	CARRYING-WHEELS PIVOT SHAFT		01
02	0501110777	RIGHT WHEEL ARM		01
03	0503010019	1/2" SPRING WASHER		01
04	0511055627	WHEEL ASSY RAYED	159	01
05	0503016453	1/2" X 2.1/2 BOLT		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	0503010002	1800 GREASE FITTING		01
08	0503030012	HITCH PIN CLIP		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
11	0501011445	FLAT WASHER		03
12	0571015974	WASHER		01
13	0503012412	5/8" UNC SELF LOCKING NUT		01
14	0503011440	SPRING WASHER		01




Item	Code	Description	See page	QT
01	0571015973	CARRYING-WHEELS PIVOT SHAFT		01
02	0503010019	1/2" SPRING WASHER		01
03	0511055627	WHEEL ASSY RAYED	159	01
04	0503016453	1/2" X 2.1/2 BOLT		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01
07	0503030012	HITCH PIN CLIP		01
08	0501110776	ARM,LEFT		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
11	0501011445	FLAT WASHER		03
12	0571015974	WASHER		01
13	0503012412	5/8" UNC SELF LOCKING NUT		01
14	0503011440	SPRING WASHER		01




Item	Code	Description	See page	QT
01	0511055626	SPREADED DEPTH WHEEL HUB		01
02	0551019904	PRESS WHEEL RIM		02
03	0503030891	RUBBER BAND		01
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0571015324	COMPACT WHEEL RIGHT ARM		01
02	0571015325	LH ARM PRESS WHEELS		01
03	0541012145	13,5 X 25 X 18 SLEEVE		02
04	0501058362	LARGER HANDLE ASSY		01
04A	0502011689	1/8" DEPTH CONTROL LEVER		01
04B	0521064892	REGULACION SPRING COMPACTOR		01
04C	0541012146	0.53" X 0.74" X 0.33" SLEEVE		01
04D	0503030174	COMPRESSION SPRING		01
04E	0541012143	FLAT WASHER		01
04F	0503010257	1/8" X 1" COTTERPIN		01
05	0503010479	BOLT		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01
08	0503031393	1.57" X 5.98" X 0.2" TRACTION SPRING		01
09	0501055289	HANDLE SMALLER ASSY		01
09A	0511065451	PRESS WHEEL ADJUSTER		01
09B	0511065496	PRESS WHEEL FIXER		01
09C	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
09D	0541012143	FLAT WASHER		01
09E	0503010257	1/8" X 1" COTTERPIN		01
10	0503010397	5/16" X 1-3/4" BOLT		02
11	0541012144	8,50 X 16 X 21 SLEEVE		02
12	0503011444	SPRING WASHER		02
13	0503010337	5/16" NUT		02
14	0501052908	COMPACTOR WHEEL WITH BEARING	169	02
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503013739	1/2" X 1" BOLT		01
17	0503011440	SPRING WASHER		02




Item	Code	Description	See page	QT
01	0502012758	DEPTH CONTROL SUPPORT		01
02	0503010585	0,24" X 1.18" SPRING PIN		02
03	0503010002	1800 GREASE FITTING		01
04	0501059228	ADJUSTMENT LEVER	156	01
05	0502012611	DEPTH CONTROL AXLE		01
06	0571015326	ARTICULATION SLEEVE HANDLE		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
08	0503011443	3/8" SPRING WASHER		01
09	0503010237	3/8" X 1" BOLT		01
10	0571016132	PIVOT SHAFT		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0561014336	PIVOT SHAFT		01
13	0503010071	3/16" X 1" COTTERPIN		02
14	0511055628	DEPTH WHEEL SYSTEM	162	01
15	0511055629	DEPTH WHEEL SYSTEM	163	01




Item	Code	Description	See page	QT
01	0561014385	CARRYING-WHEELS PIVOT SHAFT		01
02	0503010019	1/2" SPRING WASHER		01
03	0511055627	WHEEL ASSY RAYED	159	01
04	0503016453	1/2" X 2.1/2 BOLT		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01
07	0503030012	HITCH PIN CLIP		01
08	0501110777	RIGHT WHEEL ARM		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
11	0501011445	FLAT WASHER		03
12	0503012412	5/8" UNC SELF LOCKING NUT		01
13	0503011440	SPRING WASHER		01




Item	Code	Description	See page	QT
01	0571015973	CARRYING-WHEELS PIVOT SHAFT		01
02	0503010019	1/2" SPRING WASHER		01
03	0511055627	WHEEL ASSY RAYED	159	01
04	0503016453	1/2" X 2.1/2 BOLT		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01
07	0503030012	HITCH PIN CLIP		01
08	0501110776	ARM,LEFT		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
11	0501011445	FLAT WASHER		03
12	0503012412	5/8" UNC SELF LOCKING NUT		01
13	0503011440	SPRING WASHER		01




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0503010257	1/8" X 1" COTTERPIN		01
04	0571013054	DEPTH CONTROL WHEEL AXLE		01
05	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
06	0511015346	FLAT WASHER		04
07	0501110720	ARM LEFT		01
07A	0502012726	LEFT DEPTH WHEEL ARM		01
07B	0503034375	WHEEL ARM SLEEVE		02
08	0501110719	DEPTH CONTROL RIGHT ARM		01
08A	0501110720	ARM LEFT		01
08B	0503034375	WHEEL ARM SLEEVE		02
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
10	0503011440	SPRING WASHER		04
11	0502012663	EXTENSION		01
12	0503010002	1800 GREASE FITTING		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
15	0503031393	1.57" X 5.98" X 0.2"TRACTION SPRING		01
16	0501056769	DEPTH WHEELS REGULATOR ASSY	165	01
17	0503010311	1/2" X 1-1/4" BOLT		02
18	0503010256	3/8" X 3/4" BOLT		01
19	0511059463	COMFORT WHEEL WITH FAST ADJUSTMENT	166	01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0521067072	COMPACT WHEEL RIGHT ARM		01
02	0521067071	COMPACT RUEDA LEFT ARM		01
03	0541012144	8,50 X 16 X 21 SLEEVE		02
04	0501055289	HANDLE SMALLER ASSY		01
04A	0511065451	PRESS WHEEL ADJUSTER		01
04B	0511065496	PRESS WHEEL FIXER		01
04C	0503031719	0.7" X 1" X 1,1" COMPRESSION SPRING		01
04D	0541012143	FLAT WASHER		01
04E	0503010257	1/8" X 1" COTTERPIN		01
05	0511059461	COMPLETE REGULATOR		01
05A	0503030174	COMPRESSION SPRING		01
05B	0502011689	1/8" DEPTH CONTROL LEVER		01
05C	0503010257	1/8" X 1" COTTERPIN		01
05D	0521067070	PRESS WHEEL ADJUSTER		01
05E	0511015976	FLAT WASHER		01
05F	0541012146	0.53" X 0.74" X 0.33" SLEEVE		01
06	0541012145	13,5 X 25 X 18 SLEEVE		02
07	0503010479	BOLT		01
08	0503010060	1/2 UNC G.5 ZN HEX NUT		01
09	0503011440	SPRING WASHER		01
10	0503010397	5/16" X 1-3/4" BOLT		02
11	0503011444	SPRING WASHER		02
12	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	168	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEEL HUB		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0502012823	DISC BLADE SUPPORT		01
02	0503034318	5/8 UNC X 2 BOLT		02
03	0503010013	5/8 NUT		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	178	01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061153	FERTILIZER ROW LONG ARM		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	179	01




Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD		01
02	0502040534	SPRING GUIDE BUSHING LOCK		02
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502012510	SPRING ROD SUPPORT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0501018535	1/2 X 1 BOLT		02
08	0503030678	BOLT 1/2 UNC X 1.1/2 C50P G.5 ZN		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02
10	1902010891	SPRING CHOCK SUPPORT VARON		01
11	0503010014	3/4" HEX NUT		01
12	0561014471	COUPLING SHAFT		01
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012825	DISC BLADE FIXED AXLE		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	THRUST WASHER		01
17	0503034319	LOCK PIN		01
18	0511058648	HUB WITH 20" DISC BLADE	182	01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0503010003	1845 GREASE FITTING		01
03	0571019976	LEFT BRACELET CUTTING DISC		01
04	0503011411	1/2" X 5-1/2" BOLT		01
05	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
06	0503011440	SPRING WASHER		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01
08	0502020394	SPRING SUPPORT		01
09	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
10	0502020393	SPRING UPPER SUPPORT		01
11	0521010452	SLEEVE		01
12	0503013185	3/4" X 5-1/2" BOLT		01
13	0501067323	SPRING REGULATOR		01
14	0511056910	HUB WITH 18" DISC BLADE	183	01
15	0502012825	DISC BLADE FIXED AXLE		01
16	0503011255	3/4" LOCK NUT		02
17	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
18	0581011111	THRUST WASHER		01
19	0503034319	LOCK PIN		01
20	0511056909	DISC BLADE HUB WITHOUT DISC	184	01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012824	DISC BLADE FIXED AXLE		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	THRUST WASHER		01
17	0503034319	LOCK PIN		01
18	0511058648	HUB WITH 20" DISC BLADE	182	01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0503010003	1845 GREASE FITTING		01
03	0571019976	LEFT BRACELET CUTTING DISC		01
04	0503011411	1/2" X 5-1/2" BOLT		01
05	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
06	0503011440	SPRING WASHER		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01
08	0502020394	SPRING SUPPORT		01
09	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
10	0502020393	SPRING UPPER SUPPORT		01
11	0521010452	SLEEVE		01
12	0503013185	3/4" X 5-1/2" BOLT		01
13	0501067323	SPRING REGULATOR		01
14	0511056910	HUB WITH 18" DISC BLADE	183	01
15	0502012824	DISC BLADE FIXED AXLE		01
16	0503011255	3/4" LOCK NUT		02
17	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
18	0581011111	THRUST WASHER		01
19	0503034319	LOCK PIN		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	180	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	181	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8 SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511053173	RIGHT LOW HUB WITH 15 DISC	181	01
02	0511053172	LEFT LOW HUB WITH 15 DISC	180	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010025	3/8 SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUBLE DISC AXLE		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0511056909	DISC BLADE HUB WITHOUT DISC	184	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01




Item	Code	Description	See page	QT
01	0511056909	DISC BLADE HUB WITHOUT DISC	184	01
02	0603026013	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0502012793	DISC HUB		01
02	0571018047	DISC BLADE HUB AXLE		01
03	0503017755	NUT		01
04	0502020641	BLADE DISC FLANGE		01
05	0503013816	5/16" LOCKNUT		06
06	0571018048	BACKREST WASHER		02
07	0521065882	NILOS SEALING RING		02
08	0571018049	DUST CLOAK		02
09	0581010575	7/8" X 145 BOLT		01
10	0503018825	5/16 UNC UNC BOLT		06
11	0501010694	FLAT WASHER		06
12	0503016061	BEARING		02
13	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER ROD		01
02	1902070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01




Item	Code	Description	See page	QT
01	0521066202	SUPPORT FIXER ROD		01
02	0511057533	ROD WITH POINT FLANGE WASHER SPRING	187	01
03	0571015538	SLEEVE 37 X 28,3 X 16,70		01
04	0503012795	5/8" HEX SELF ADJUSTING NUT		01
05	0571015552	BOLT FIXER		01
06	0503010417	7/8" NUT		01
07	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
08	0503034106	80 X 230 X 16,50 COMPRESSSION SPRING		01
09	0503010691	1/4" GREASE FITTING		01
10	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
11	0571019531	BODY SOCKET FERTILIZER		01
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
13	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
14	0503010026	3/8" NUT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010384	1/2" X 5" BOLT		02
17	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
18	0503010547	1/2" X 4" BOLT		02
19	0503011336	1/2" HEX SELF ADJUSTING NUT		04
20	0571019462	SUPPORT GUIDE PRING		01




Item	Code	Description	See page	QT
01	0501110810	ROD WITH POINT ARM/DISARMENT		01
02	0521066123	FLANGE WASHER SPRING		01
03	0571015521	PIN LOCK STEM		01
04	0571017723	FLAT WASHER		01
05	0503012104	501015 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0503030379	LARGER ROCKER ARM		01
02	0502060001	PLASTIC PULLEY FOR MAIZE		01
03	0503010669	FLAT WASHER		01
04	0503010667	3/16" NUT		02
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		01



Item	Code	Description	See page	QT
01	0503016204	CORN DISC 12 ORANGE		01
02	0503016398	TITANIUM RING CORN / SOY (YELLOW FLAT)		01
03	0503016399	TITANIUM RING CORN (GREEN)		01
04	0503016400	TITANIUM RING CORN (GREY)		01
05	0503016401	TITANIUM RING CORN (BLUE)		01



Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016218	DISC OF SOYBEAN		01
03	0503016403	TITANIUM RING FOR SOYBEAN (LILAC)		01
04	0503016404	TITANIUM RING FOR SOYBEAN (PURPLE)		01
05	0503016406	TITANIUM RING FOR SOYBEAN (ORANGE)		01
06	0503016407	TITANIUM RING FOR SOYBEAN		01



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

