

ROW CROP PLANTERS

PST PLUS FLEX SUPREMA P.P - FRAME 4045 - CSU

Code: 0501091916
Series: S-0116
Revision: 00
Date Revision: JUNHO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111390012	PST PLUS FLEX SUP PP 4045/8E500 ESPECIAL S-0116
0111390017	PST PLUS FLEX SUP PP 4045/8E500 ESPECIAL S-0116
0111390021	PST PLUS FLEX SUP PP 4045/8E500 ESPECIAL S-0116
0111390066	PST PLUS FLEX SUP PP 4045/8E500 ESPECIAL S-0116
0111390068	PST PLUS FLEX SUP PP 4045/8E500 ESPECIAL S-0116
0111390070	PST PLUS FLEX SUP PP 4045/9E450 ESPECIAL S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909092631	ASSY FRAME	1
0511057303	FRAME WITH WHEEL AXLE - 4045	2
0511057266	HYDRAULIC SYSTEM ASSEMBLY - 3245/3495/4045/4395	3
0511058655	CYLINDER SET - 3245/3495/4045/4395	4
0511058607	HYDRAULIC CYLINDER	5
0511057499	ASSY HANDRAIL	6
0511057307	PLATFORM ASSEMBLY - 4045	7
0511056536	LADDER ASSEMBLY	8
0511054971	JACK ASSEMBLY	9
0511057333	DRAWBAR ASSEMBLY - 3495/4045/4395/4845/5345/5745	10
0511054601	HITCH ARTICULATED TRACTOR	11
0511053179	TRACTOR COUPLING SHAFT	12
0511057270	DRAWBAR EXTENDER	13
0511057817	SUPPORT HOSE	14
0521050143	SET TURBINE 4045/8	15
0511059887	TURBINE PRECISION PLANTING	16
0521050154	TURBINE P.P WITH HOLE	17
0521052028	MTH TURBINE ASSEMBLY P.P CSU	18
0511057348	DISTRIBUTOR VACUUM	19
0511057846	ASSY HOSE KIT	20
0501053834	MALE QUICK COUPLER	21
0501050633	ROW MARKER DISK ASSEMBLY	22
0511053904	ROW MARKER DISC	23
0909095964	HEXAGONAL SHAFT ASSEMBLY - 4045	24
0521055338	ROW SEED BEARING	25
0511056392	PLANTING MONITORING ASSY 09L SEED AND FERTILIZER	26
0521053445	MONITORING ASSEMBLY PLANTING SEEDS 09L PM400	27
0511058653	WHEELS WITH TRACTION SPRING	28
0511058654	WHEEL SUPPORT	29
0501058241	WHEEL SUPPORT CHAIN TENSIONER	30
0511052770	WHEEL WITH TIRE	31
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	32
0501058240	WHEEL FASTENER WITH TENSIONER	33
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	34
0501058244	WHEEL FIXED CHAIN TENSIONER	35
0501058242	WHEEL MOBILE CHAIN TENSIONER	36
0521053444	PLANTING MONITORING ASSY 8L SEED PM400	37
0521050152	LABEL ASSY	38
0511059323	PLATFORM TRANSPORT SUPPORT	39
0511058769	SINGLE SEED BOX - 4045/8 E500	40
0511058770	2 BOXES WITH 8 CONDUCTORS ASSEMBLY	41
0511058827	SINGLE SEED BOX - 4045/9 E450	42
0511058828	2 BOXES WITH 9 CONDUCTORS ASSEMBLY	43
0511057690	3" ARTICULATED SEED CONDUCTOR	44
0511057311	SEMI-ASSEMBLED HYDRAULIC MARKER - 4045	45
0511058449	HYDRAULIC CYLINDER	46
0501054649	HBM SEQUENTIAL VALVE	47
0511058119	VALVE SUPPORT ASSEMBLY	48
0511057305	FERTILIZER BOX ASSEMBLY - 4045	49
0511057309	BOX SUPPORT WITH DISTRIBUTOR - 4045	50
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	51
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	52
0501053788	3/4 SQUARE AXLE FASTENER	53
0501056271	GEARBOX CLOSED BEARING	54
0909092619	SEED FERTILIZER ROW	55




MARCHESAN

INDEX

0511057505	SEED ROW FRONT PNEUM PP SHORT WITH RIGHT REAR	56
0511057506	SEED ROW FRONT PNEUM PP LONG WITH RIGHT REAR	57
0511057276	TRANSMISSION SUPPORT RIGHT ASSY	58
0521050149	SEED ROW RIGHT REAR	59
0511057108	RIGHT REAR SEED ROW PRECISION PLANTING CSU 3	60
0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA CSU 3	61
0511057155	PRECISION PLANTING LEFT TRANSMISSION BOX	62
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	63
0511057154	RIGHT DDD	64
0511053173	CUBE LOW RIGHT WITH DISC 15	65
0511053172	LEFT LOW CUBE WITH DISC 15	66
0521050150	LEFT REAR SEED ROW	67
0511057115	REAR LEFT SEED ROW PRECISION PLANTING CSU 3	68
0511057153	DDD LEFT SUPREMA PRECISION PLANTING	69
0501058972	ASSEMBLY SENSOR ELECTRONIC	70
0511058639	SHORT FERTILIZER ROW WITH DDD/DC20	71
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	72
0511058630	20" DISC CUT	73
0511058648	BOX WITH DISC BLADE 20	74
0511056909	DISC BOX CUT WITHOUT DISC	75
0511058640	LONG FERTILIZER ROW WITH DDD/DC20	76
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	77
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	78
0511058650	SEMI-MOUNTED DEPTH CONTROL	79
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	80
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	81
0501052627	ASSY DEPTH WHEEL BOX	82
0501052297	DEPTH WHEELS REGULATOR ASSY	83
0501052538	DEPTH BAND WITH ARMS	84
0511054333	COMPACT WHEEL RIGHT WITH BEARING	85
0511054334	COMPACT WHEEL LEFT WITH BEARING	86
0501052908	COMPACTOR WHEEL WITH BEARING	87
0521050525	FIXER FERTILIZER CONDUCTOR	88
0521057957	FIXED ROD EXTENSION WITH FIXATION	89
0521051424	WHEEL SYSTEM DEPTH/COMPACTOR QUICK ADJUSTMENT	90
0501056769	DEPTH WHEELS REGULATOR ASSY	91
0521051423	COMPACTOR SUPPORT	92
0511050077	WHEEL STRIPED	93
0511052287	DEPTH WHEEL HUB ASSY	94
0511058338	CBR ASSY	95
0511058337	CBR ASSY	96
0501052957	IRON V PRESS WHEELS	97

ASSY FRAME

0909092631




Item	Code	Description	See page	4045
01	0511057303	FRAME WITH WHEEL AXLE - 4045	2	01
02	0511057266	HYDRAULIC SYSTEM ASSEMBLY	- 3	01
		3245/3495/4045/4395		
03	0503010003	1845 GREASE FITTING		04
04	0511058655	CYLINDER SET - 3245/3495/4045/4395	4	01
05	0511057499	ASSY HANDRAIL	6	01
06	0511057307	PLATFORM ASSEMBLY - 4045	7	01
07	0511056536	LADDER ASSEMBLY	8	02
08	0511054971	JACK ASSEMBLY	9	02
09	0511057333	DRAWBAR ASSEMBLY	- 10	01
		3495/4045/4395/4845/5345/5745		
10	0511054601	HITCH ARTICULATED TRACTOR	11	01
11	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
12	0511053179	TRACTOR COUPLING SHAFT	12	01
13	0511057270	DRAWBAR EXTENDER	13	01
14	0501065677	STRUT		02
15	0521013022	TRANSPORT LOCK		01
16	0501068994	8,30 X 78 LOCK PIN		01
17	0503030168	HITCH PIN CLIP		01
18	0511057817	SUPPORT HOSE	14	01
19	0503010045	O'RING		01
20	0503014120	CHAIN		01
21	0503014321	CABLE STEEL SHACKLE		01
22	0501047895	ROD STOP		01
23	0501047885	ROD STOP		01
24	0501047886	ROD STOP		01
25	0501047887	ROD STOP		01
26	0502012702	BODY SUPPORT CLAMP		08
27	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		08
28	0503010180	7/16" SPRING WASHER		08
29	0503032624	FERTILIZER BOX GUTTER		05
30	0541010080	TERMINAL R.1 / 2 NPT		01


ASSY FRAME

0909092631


Item	Code	Description	See page	4045
31	0503031436	AIR DITRIBUTOR PUMP		05
32	0521050143	SET TURBINE 4045/8	15	01
32.	0521052028	MTH TURBINE ASSEMBLY P.P CSU	18	01
33	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01
34	0581013729	NIPLE 1/2 NPT		01
35	0501053834	MALE QUICK COUPLER	21	01
36	0501050633	ROW MARKER DISK ASSEMBLY	22	01
37	0503010246	CLAMP		11
38	0909095964	HEXAGONAL SHAFT ASSEMBLY - 4045	24	01
39	0511058653	WHEELS WITH TRACTION SPRING	28	04
40	0511056392	PLANTING MONITORING ASSY 09L SEED AND FERTILIZER	26	01
40.	0521053444	PLANTING MONITORING ASSY 8L SEED PM400	37	01
40..	0521053445	MONITORING ASSEMBLY PLANTING SEEDS 09L PM400	27	01
41	0511058694	TRANSMISSION ASSY		01
42	0521050152	LABEL ASSY	38	01
43	0511059322	LIFTING SUPPORT ASSEMBLY		01
44	0511059323	PLATFORM TRANSPORT SUPPORT	39	01
45	0511058769	SINGLE SEED BOX - 4045/8 E500	40	01
45.	0511058827	SINGLE SEED BOX - 4045/9 E450	42	01
46	0571013990	GUTTER		02
47	0571017368	SUPPORT GUTTER		06
48	0501011643	3/8 X 1"BOLT		06
49	0501010984	FLAT WASHER		06
50	0503010025	3/8" SPRING WASHER		06
51	0503010026	3/8" NUT		06
52	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		02
53	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
54	0511017302	FLAT WASHER		04
55	0503010019	1/2" SPRING WASHER		04
56	0503010060	1/2" NUT		04
57	0511057311	SEMI-ASSEMBLED HYDRAULIC MARKER - 4045	45	01
58	0511057305	FERTILIZER BOX ASSEMBLY - 4045	49	01
59	0909092619	SEED FERTILIZER ROW	55	01




Item	Code	Description	See page	QT
01	0521065919	FRAME - 4045		01
02	0521065928	CARRYING-WHEELS PIVOT SHAFT - 4045		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	SCREW		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0511057267	HOSE KIT HYDRAULIC		01
01A	0501080722	3/8 X 3300 TC-TM HOSE ASSY		01
01B	0501082023	HOSE 3/8 X 3600 TC-TM		01
02	0501053834	MALE QUICK COUPLER	21	02
03	0503013100	NYLON CLAMP		02
04	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0521045510	HYDRAULIC CYLINDER		01
02	0551014099	COUPLING SHAFT 31,75 X 185		01
03	0521010547	1.2" X 6.5" COUPLING SHAFT		01
04	0503010523	1/4" X 2" COTTERPIN		02
05	0501047888	ROD STOP		01




Item	Code	Description	See page	QT
01	0521066740	CYLINDER CASE		01
02	0581013698	PISTON		01
03	0521067586	TURNBUCKLE		01
04	0503010817	1.1/4" SELF LOCKING NUT		01
05	0503010003	1845 GREASE FITTING		01
06	0503030385	CYLINDER PLUG N-002		02
07	0503018439	WIPER SEAL		01
08	0503018150	RING GUIDE		01
09	0502010382	5" END CAP		01
10	0581010353	RING SUPPORT		01
11	0503018026	1870-2000-375 B GASKET		01
12	0503011453	O'RING		02
13	0503018152	O'RING		02
14	0503018024	RING BS		01
15	0503018025	RING GUIDE		01
16	0503010039	D-2000 SCRAPER RING		01
17	0503010173	2-220 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0521065950	HANDRAIL		02
02	0503010752	1/2" X 3.1/2" BOLT		08
03	0511017302	FLAT WASHER		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0571018866	SET PLATFORM 4045		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	FLAT WASHER		16
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012806	SUPPORT REAR FIXER DRAWBAR		04
02	0502012789	FIXER SUPPORT FERTILIZER ROW		04
03	0503017960	5/8" X 3-12" BOLT		16
04	0503010811	5/8" UNF SELF ADJUSTING NUT		16
05	0501010191	1" X 6" BOLT		04
06	0503010012	1" SPRING WASHER		04
07	0501010059	1.5/8 NUT		04
08	0502012805	SUPPORT FRONT FIXER DRAWBAR		04
09	0502012789	FIXER SUPPORT FERTILIZER ROW		04
10	0503017960	5/8" X 3-12" BOLT		16
11	0503010811	5/8" UNF SELF ADJUSTING NUT		16
12	0521065958	DRAWBAR		01
13	0561019087	DRAWBAR TRANSPORT LOCK		01
14	0551014099	COUPLING SHAFT 31,75 X 185		01
15	0521010544	1.2" X 4.9" COUPLING SHAFT		01
16	0503030085	LOCK PIN		02
17	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0521065959	JACK R.1.1/2 UNC RIGHT X 240		01
03	0521065960	JACK R.1.1/2 UNC LEFT X 240		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521066302	HOSE HOLDER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0581012111	RIGHT SUPPORT		01
02	0581012112	LEFT SUPPORT		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2" NUT		04
06	0581012166	HOSE		02
07	0503011372	102 TO 121 CLAMP		04
08	0511057348	DISTRIBUTOR VACUUM	19	02
09	0503031436	AIR DITRIBUTOR PUMP		01
10	0503010246	CLAMP		01
11	0571019403	STAPLE FIXER		04
12	0501010984	FLAT WASHER		08
13	0503010025	3/8" SPRING WASHER		08
14	0503010026	3/8" NUT		08
15	0571013731	VACUUM GAUGE SUPPORT		01
16	0503013584	VACUUM GAUGE		01
17	0511057846	ASSY HOSE KIT	20	01
17A	0501080850	3/8" X 6100 TC-TM HOSE		01
17B	0501081810	HOSE 1/2 X 6200 TC-TM		02
17C	0501053834	MALE QUICK COUPLER	21	02
17D	0581012991	SPRING PROTECTION PLASTIC HOSE		01
17E	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN		01
18	0511059887	TURBINE PRECISION PLANTING	16	01
19	0503031576	ELBOW		02
20	0571019716	ADAPTER		08
21	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		08




Item	Code	Description	See page	QT
01	0521050154	TURBINE P.P WITH HOLE	17	01
02	0503015420	VALVE ANTI-CAVITACAO CV10208TN5		01
03	0501011460	7/8 NF REDUCTION NIPPLE		04
04	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
05	0503010392	2-046 N 3006 9B O'RING		01
06	0503010190	2-114 N 3006-9B O'RING		04
07	0501080218	1/2 X 750 HOSE		01
08	0581012096	ROUND SLEEVE		02
09	0503031087	ADHESIVE LABEL		01
10	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01




Item	Code	Description	See page	QT
01	0581012111	RIGHT SUPPORT		01
02	0581012112	LEFT SUPPORT		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2" NUT		04
06	0581012166	HOSE		02
07	0503011372	102 TO 121 CLAMP		02
08	0503031576	ELBOW		02
09	0511057348	DISTRIBUTOR VACUUM	19	02
10	0503031436	AIR DITRIBUTOR PUMP		01
11	0503010246	CLAMP		01
12	0571019403	STAPLE FIXER		04
13	0501010984	FLAT WASHER		08
14	0503010025	3/8" SPRING WASHER		08
15	0503010026	3/8" NUT		08
16	0571013731	VACUUM GAUGE SUPPORT		01
17	0503013584	VACUUM GAUGE		01
18	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		09
19	0571019716	ADAPTER		09
20	0511057846	ASSY HOSE KIT	20	01
21	0511059887	TURBINE PRECISION PLANTING	16	01
22	0521052549	CLAMP		18




Item	Code	Description	See page	QT
01	0571017215	SOCKET DISTRIBUTOR AR		01
02	0503012566	COVER KAP 110 YELLOW		01
03	0503031943	SOCKET		05
04	0503012856	POP RIVET		10
05	0571019405	BODY DISTRIBUTOR VACUUM 4845/5345		01



Item	Code	Description	See page	QT
001	0511057847	ASSY HOSE TURBINE		01
001A	0503033158	PLASTIC BAG		01
001B	0521052531	3/8 X 6108 TC-TM HOSE YELLOW / GREEN		01
001C	0521052528	1/2 X 6200 TC-TM HOSE YELLOW / RED		01
001D	0521052529	1/2 X 6200 TC-TM HOSE YELLOW / BLUE		01
002	0501053834	MALE QUICK COUPLER	21	02
003	0581012991	SPRING PROTECTION PLASTIC HOSE		01
004	0503033981	ADHESIVE LABEL		01
005	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	23	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01

ROW MARKER DISC


0511053904




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0521055338	ROW SEED BEARING	25	04
02	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		22
02A	0502012699	TRANSMISSION BOX LOCK SLEEVE		01
02B	0503010256	3/8" X 3/4" BOLT		01
03	0571018915	3/4 X 2090 AXLE HEX		01
04	0571018914	3/4 X 1905 AXLE HEX		01




Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	ROW SEED BEARING		01
03A	0502012030	HOUSING BEARING		01
03B	0503012861	6006 2RS BALL BEARING		01
03C	0503012858	502075 CLAMPING RING (FOR HOLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02
07	0501013518	FLAT WASHER		02
08	0501010694	FLAT WASHER		02



Item	Code	Description	See page	09 L
01	0503016555	9 ROW SIMPLE MONITOR CABLE		01
02	0503017602	MONITOR PLANT PM400		01
03	0503016234	TRIMBLE FIXING WINDOW		01
04	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
05	0571012196	MOUNTING BRACKET PM 400		01
06	0503017443	ANTENNA GPS PM 400		01
07	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		135
08	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
09	0503010669	FLAT WASHER		02
10	0503010668	3/16" SPRING WASHER		02
11	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0503062794	SEED MONITORING KIT 9L 45/50 PM400		01
01A	0503016555	9 ROW SIMPLE MONITOR CABLE		01
01B	0503019100	SENSOR		09
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503013100	NYLON CLAMP		45
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		**
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
08	0503010669	FLAT WASHER		02
09	0503010668	3/16" SPRING WASHER		02
10	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0511058654	WHEEL SUPPORT	29	01
02	0501058240	WHEEL FASTENER WITH TENSIONER	33	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01

WHEEL SUPPORT


0511058654




Item	Code	Description	See page	QT
01	0521066716	WHEEL ARM ASSY		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511050681	TRACTION SPRING		01
06A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
06B	0561016062	SPRING HITCH		02
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
08	0503010027	5/8" SPRING WASHER		01
09	0501058241	WHEEL SUPPORT CHAIN TENSIONER	30	01
10	0503013030	5/8" X 3.1/4" BOLT		01
11	0551017715	FLAT WASHER		02
12	0511052770	WHEEL WITH TIRE	31	01
13	0591010589	BODY LOCK WHEEL		01
14	0503010027	5/8" SPRING WASHER		02
15	0503011167	M16 X 2 X 30 BOLT		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE		01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	32	01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	34	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	35	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	36	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01



Item	Code	Description	See page	QT
01	0551018252	CHAIN TIGHTENER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN UPPER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503062793	SEED MONITORING KIT		01
01A	0503016554	8 ROW SIMPLE MONITOR CABLE		01
01B	0503019100	SENSOR		08
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503013100	NYLON CLAMP		40
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		120
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
08	0503010669	FLAT WASHER		02
09	0503010668	3/16" SPRING WASHER		02
10	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0503033892	ADHESIVE LABEL LOGO TATU BOX 190 X 720	01	01
02	0503034226	LABEL ADHESIVE		02
03	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		02
04	0503034257	ADHESIVE LABEL		01
05	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
07	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
08	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
09	0503031428	READ MANUAL DECAL		01
10	0503031942	ADHESIVE LABEL		01
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
12	0503031565	ADHESIVE LABEL CARE		02
13	0503031566	ADHESIVE LABEL		02
14	0503034249	ADHESIVE LABEL TABLE PLANTS		02
15	0503031425	ADHESIVE LABEL ATTENTION		02
16	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
17	0503031669	ADHESIVE LABEL		01
18	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
19	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
20	0503032930	ADHESIVE LABEL DANGER		05
21	0503031087	ADHESIVE LABEL		01
22	0503034003	SERIAL NUMBER TAG 61 X 118		01
23	0503010001	3.2 X 5.5 RIVET		04
24	0503032979	ADHESIVE LABEL LETTERS A B C D		02
25	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0581011989	SIDE BODY FIXER PLATFORM		01
02	0551019884	45 X 50 X 3/8 FASTENER		01
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0501010984	FLAT WASHER		02
07	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0511058770	2 BOXES WITH 8 CONDUCTORS ASSEMBLY	41	01
02	0521066102	TOWER SUPPORT HOPPER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8 UNC SELF LOCKING NUT		08
10	0571019393	PROTECTOR		02
11	0551019884	45 X 50 X 3/8 FASTENER		08
12	0501010453	FLAT WASHER		16
13	0503010025	3/8" SPRING WASHER		16
14	0503010026	3/8" NUT		16
15	0521066211	PROTECTOR CENTRAL		01
16	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
17	0501013519	FLAT WASHER		04
18	0503010019	1/2" SPRING WASHER		04
19	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521064748	05 NOZZLES SINGLE SEED BOX SUPPORT		02
02	0503061987	05 NOZZLES FERTILIZER BOX		02
03	0521063401	SEED BOX ONLY FIXING LOCK		04
04	0501010984	FLAT WASHER		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	44	08
08	0501010942	3/8" X 1-1/4" BOLT		32
09	0503010025	3/8" SPRING WASHER		32
10	0503010026	3/8" NUT		32
11	0571015773	SUPPORT SEED		02
12	0501011643	3/8 X 1"BOLT		08
13	0503010025	3/8" SPRING WASHER		08
14	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0511058828	2 BOXES WITH 9 CONDUCTORS ASSEMBLY	43	01
02	0521066102	TOWER SUPPORT HOPPER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8 UNC SELF LOCKING NUT		08
10	0571019393	PROTECTOR		02
11	0551019884	45 X 50 X 3/8 FASTENER		08
12	0501010453	FLAT WASHER		16
13	0503010025	3/8" SPRING WASHER		16
14	0503010026	3/8" NUT		16
15	0521066211	PROTECTOR CENTRAL		01
16	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
17	0501013519	FLAT WASHER		04
18	0503010019	1/2" SPRING WASHER		04
19	0503010060	1/2" NUT		04



Item	Code	Description	See page	QT
01	0521064748	05 NOZZLES SINGLE SEED BOX SUPPORT		02
02	0503061987	05 NOZZLES FERTILIZER BOX		02
03	0521063401	SEED BOX ONLY FIXING LOCK		04
04	0501010984	FLAT WASHER		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	44	09
08	0501010942	3/8" X 1-1/4" BOLT		36
09	0503010025	3/8" SPRING WASHER		36
10	0503010026	3/8" NUT		36
11	0571015773	SUPPORT SEED		01
12	0501011643	3/8 X 1"BOLT		04
13	0503010025	3/8" SPRING WASHER		04
14	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER		02
09	0503010179	LOCK WASHER		02
10	0503010337	5/16" NUT		02
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT		01




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
03	0503012412	5/8 UNC SELF LOCKING NUT		04
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0511058449	HYDRAULIC CYLINDER	46	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" COTTERPIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501069643	890 TURNBUCKLE		02
21	0503011854	5/8" X 1-1/4" BOLT		04
22	0501054649	HBM SEQUENTIAL VALVE	47	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	FLAT WASHER		02
25	0503010025	3/8" SPRING WASHER		02
26	0511058119	VALVE SUPPORT ASSEMBLY	48	01
27	0501053834	MALE QUICK COUPLER	21	02
28	0502012702	BODY SUPPORT CLAMP		08
29	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		08
30	0503010180	7/16" SPRING WASHER		08
31	0503010244	7/16" NUT		02


Item	Code	Description	See page	QT
32	0571014419	PLASTIC PROTECTION SPRING HOSE 3/4 X 700MM		04
33	0511057312	HOSE KIT MARKER HYDRAULIC		
33A	0501081727	TR-TR HOSE ASSY		02
33B	0501080408	HOSE 3/8 X 3200 TR-TC		02
34	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
34A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
34B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
34C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
34D	0503018952	PLASTIC BOLT		06
35	0521052850	3/8 X 4200 TC-TM PURPLE/BUE HOSE		01
35A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
35B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
35C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
35D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0581010011	VALVE FIXING SUPPORT		01
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
03	0501010984	FLAT WASHER		04
04	0503010025	3/8" SPRING WASHER		02
05	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0511057309	BOX SUPPORT WITH DISTRIBUTOR - 4045	50	01
02	0503062391	FERTILIZER BOX		02
03	0503013751	3/8 UNC X 1.1/4 BOLT		16
04	0571019051	FIXER BOX WASHER		16
05	0503012535	3/8" SPRING WASHER		16
06	0503012531	3/8" INOX NUT		16
07	0503011957	NYLON LUG		02
08	0503010371	5/16" X 1" BOLT		04
09	0503010179	LOCK WASHER		04
10	0503010337	5/16" NUT		04
11	0503034396	FERTILIZER SIDE COVER		10
12	0503010362	1/8 X 1.1/4 COTTERPIN		10
13	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		10
14	0501010984	FLAT WASHER		20
15	0503010025	3/8" SPRING WASHER		10
16	0503010026	3/8" NUT		10




Item	Code	Description	See page	QT
01	0521065934	FERTILIZER BEAM SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	51	05
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	52	05
04	0501010942	3/8" X 1-1/4" BOLT		40
05	0503011443	3/8" SPRING WASHER		40
06	0503010026	3/8" NUT		40
07	0571018896	SQUARE SHAFT		02
08	0503030275	AGRICULTURAL BEARING		10
09	1902010685	18Z CONICAL GEAR		10
10	0551018055	22,65 X 60 SLEEVE		02
11	0501053788	3/4 SQUARE AXLE FASTENER	53	04
12	0511061759	22Z P12,70 FQ 3/4" GEAR		02
13	0503030303	SUPPORT WASHER		04
14	0501056271	GEARBOX CLOSED BEARING	54	02
15	0503011953	5/16" X 1" BOLT		04
16	0501010694	FLAT WASHER		04
17	0521011039	FLAT WASHER		04
18	0503011444	SPRING WASHER		04
19	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01



Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01



Item	Code	Description	See page	QT
01	0511057505	SEED ROW FRONT PNEUM PP SHORT WITH RIGHT REAR	56	01
02	0511057506	SEED ROW FRONT PNEUM PP LONG WITH RIGHT REAR	57	01
03	0521050149	SEED ROW RIGHT REAR	59	01
03.	0511057108	RIGHT REAR SEED ROW PRECISION PLANTING CSU 3	60	01
04	0521050150	LEFT REAR SEED ROW	67	01
04.	0511057115	REAR LEFT SEED ROW PRECISION PLANTING CSU 3	68	01
05	0511058639	SHORT FERTILIZER ROW WITH DDD/DC20	71	01
06	0511058640	LONG FERTILIZER ROW WITH DDD/DC20	76	01
07	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	78	01
07.	0521051424	WHEEL SYSTEM DEPTH/COMPACTOR QUICK ADJUSTMENT	90	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503030392	LEFT FERTILIZER NOZZLE		01
10	0503031145	2" X 2" X 20" HOSE		01
11	0503031076	2" HOSE CLAMP		02
12	0571011730	SEED CONDUCTOR 3" X 1500		01
13	0521050525	FIXER FERTILIZER CONDUCTOR	88	01
14	0531013600	PRESS ADJUSTMENT LEVER		01
15	0501110804	SCARIFIER ROD WITH POINT		01
16	0521069127	BOTTOM NOZZLE FERTILIZER		01
17	0503031050	CURVED CONDUCTOR		01
18	0511017969	0.1" SPACING PLATE		01
19	0511018662	SPACING PLATE		01
20	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
21	0503030520	SEED SOCKET		01
22	0521057957	FIXED ROD EXTENSION WITH FIXATION	89	01
23	0503010026	3/8" NUT		
24	0503062608	MONITOR VISUM		01

Item	Code	Description	See page	QT
25	0511058338	CBR ASSY	95	01
26	0511058337	CBR ASSY	96	01
27	0503010920	1/2" X 1.1/2" BOLT		01
28	0511017302	FLAT WASHER		01
29	0503010019	1/2" SPRING WASHER		01
30	0503010060	1/2" NUT		01
31	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
32	0503010019	1/2" SPRING WASHER		01
33	0503010060	1/2" NUT		01
34	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
35	0501010984	FLAT WASHER		01
36	0503010025	3/8" SPRING WASHER		01




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		02
03	0503017857	BOLT 5/8 UNF 4		04
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8 UNC SELF LOCKING NUT		04
08	0502012804	PIVOT ARM SEED ROW		02
09	0571018882	SEED ROW ARM SLEEVE		08
10	0503010002	1800 GREASE FITTING		04
11	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
12	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
13	0571018883	PIN FIXER SPRING		03
14	0571018884	LOCK PIN ROW ARTICULAT		01
15	0503030168	HITCH PIN CLIP		04
16	0511057276	TRANSMISSION SUPPORT RIGHT ASSY	58	01
17	0521065943	REAR FRAME LONG ROW SEED		01
18	0511057269	CHAIN TENSIONER		01
19	0511057507	TRANSMISSION LOWER FRONT		01
19A	0511059190	BEARING DOBLE		01
19B	0581010976	5/8" HEX AXLE		01
19C	0503010300	5/32" X 1" COTTERPIN		01
19D	0501056296	UNIVERSAL JOINT		01
19E	0503011855	0.2" X 1.8" SPRING PIN		02
19F	0561014794	350 AXLE HEX		01
20	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
21	0581011694	PROTECTION REAR COVER SEED ROW		01
22	0503010765	3/8" X 3" BOLT		01
23	0503010025	3/8" SPRING WASHER		01
24	0503010026	3/8" NUT		01
25	0511058512	PROTECTION COVER		01
26	0581011430	DRAWBAR ASSY		01



PST PLUS FLEX SUPREMA P.P - FRAME 4045 - CSU
SEED ROW FRONT PNEUM PP SHORT WITH RIGHT REAR

Page 56
0511057505

Item	Code	Description	See page	QT
27	0521064369	HOSE HOLDER		01
28	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		02
03	0503017960	5/8" X 3-12" BOLT		04
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8 UNC SELF LOCKING NUT		04
08	0502012804	PIVOT ARM SEED ROW		02
09	0571018882	SEED ROW ARM SLEEVE		08
10	0503010002	1800 GREASE FITTING		04
11	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
12	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
13	0571018883	PIN FIXER SPRING		03
14	0571018884	LOCK PIN ROW ARTICULAT		01
15	0503030168	HITCH PIN CLIP		04
16	0511057276	TRANSMISSION SUPPORT RIGHT ASSY	58	01
17	0521066158	FRAME REAR LONG ROW SEED		01
18	0511057269	CHAIN TENSIONER		01
19	0511057508	TRANSMISSION LOWER FRONT		01
19A	0511059190	BEARING DOBLE		01
19B	0581010976	5/8" HEX AXLE		01
19C	0503010300	5/32" X 1" COTTERPIN		02
19D	0501056296	UNIVERSAL JOINT		01
19E	0503011855	0.2" X 1.8" SPRING PIN		02
19F	0561014794	350 AXLE HEX		01
20	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
21	0581011694	PROTECTION REAR COVER SEED ROW		01
22	0503010765	3/8" X 3" BOLT		01
23	0503010025	3/8" SPRING WASHER		01
24	0503010026	3/8" NUT		01
25	0511058512	PROTECTION COVER		01
26	0581011430	DRAWBAR ASSY		01




PST PLUS FLEX SUPREMA P.P - FRAME 4045 - CSU
SEED ROW FRONT PNEUM PP LONG WITH RIGHT REAR

Page 57
0511057506


Item	Code	Description	See page	QT
27	0521064369	HOSE HOLDER		01
28	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511058766	BEARING		01
02	0511057273	ASSEMBLY TRANSMISSION		01
03	0503010300	5/32" X 1" COTTERPIN		01



Item	Code	Description	See page	QT
01	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA 61 CSU 3	61	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	RIGHT DDD	64	01
07	0501058972	ASSEMBLY SENSOR ELECTRONIC	70	01




Item	Code	Description	See page	QT
01	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA 61 CSU 3	61	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	RIGHT DDD	64	01




Item	Code	Description	See page	QT
01	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
02	0571017899	PIN LOCK PP		01
03	0503030190	0.5" X 1.6" X 0.05" SPRING		01
04	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
05	0511057155	PRECISION PLANTING LEFT TRANSMISSION BOX	62	01
06	0571017894	PIN DRAG PRECISION PLANTING		01
07	0503013357	3/8" SELF-ADJUSTING NUT		01
08	0501013518	FLAT WASHER		02
09	0503015356	SPRING PIN		01
10	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
11	0571017895	PIN FIXER CONDUCTOR P.P		01
12	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
13	0503010293	BAQUELITE MANIPULACION		02
14	0503010140	1/8" X 3/4" COTTERPIN		02
15	0503010131	3/16" X 1-1/2" COTTERPIN		01
16	0503010025	3/8" SPRING WASHER		02
17	0571019491	SLUICE PNEUMATIC PRECISION PLANTING		01
18	0501011643	3/8 X 1" BOLT		01
19	0503010209	3/8" UNC BUTTERFLY NUT		01
20	0502012807	SUPPORT BOX PRECISION PLANTING		01
21	0571019489	CLAMP PRECISION PLANTING		01
22	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
23	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	63	01
24	0561014778	HEX UNIVERSAL JOINT		01
25	0503013958	1/4" X 1" BOLT		02
26	0503011855	0.2" X 1.8" SPRING PIN		01
27	0503012721	1/4" X 4" BOLT		01
28	0503012880	1/4" UNC SELF ADJUSTING NUT		04
29	0571014024	FAST BOLT GUIDE AXLE		01
30	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02


Item	Code	Description	See page	QT
31	0503015110	M06 SPRING WASHER		02
32	0503818139	BOLT		03
33	0503037390	PACKING FOR PLANTING		01
34	0503015752	3/8" X 2" BOLT		01
35	0503034824	FIXATIVE		01
36	0581011226	FIXER CLOSING P PLANTING CONTR CPRA		01
37	0503010337	5/16" NUT		04
38	0503010179	LOCK WASHER		04
39	0503011953	5/16" X 1" BOLT		03
40	0503012163	5/16" X 1-1/2" BOLT		01
41	0521066707	FEEDER		01




Item	Code	Description	See page	QT
01	0502050052	LEFT SIDE TRANSMISSION BOX PP		01
02	0502050053	RIGHT SIDE TRANSMISSION BOX PP		01
03	0503011410	ROLLER BEARING		02
04	0503011182	6203 ROLLER BEARING		02
05	0503011184	502040 CLAMPING RING (FOR AXLE)		01
06	0571017655	SLEEVE FIXER HITCH PNEUMATIC		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
08	0503010144	1/4" NUT		03
09	0511057504	JOIN GEAR		01
09A	0571017898	BODY GEAR TRANSMISSION		01
09B	0503011769	M8 X 0.5" BOLT		01
10	0581011222	PINION AXLE 6Z PNEUMATIC		01
11	0503034340	PINION AXLE 6Z PNEUMATIC		01




Item	Code	Description	See page	QT
01	0571019613	STRAW PRECISION PLANTING SHIELD		01
02	0521052131	DISTRIBUTOR VSET2 WITH CORN DISK WITHOUT PROTECTION		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	66	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15	65	01
04	0503810026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501810984	FLAT WASHER		02
07	0503810751	3/8 UNC X 1.1/4 C S G.5 - SCREW		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012780	SUPPORT DDD RIGHT		01
11	0511815098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA 61 CSU 3	61	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	69	01
07	0501058972	ASSEMBLY SENSOR ELECTRONIC	70	01




Item	Code	Description	See page	QT
01	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA 61 CSU 3	61	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	69	01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	66	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15	65	01
04	0503810026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501810984	FLAT WASHER		02
07	0503810751	3/8 UNC X 1.1/4 C S G.5 - SCREW		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012781	SUPPORT DDD LEFT		01
11	0511815098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503015218	SENSOR FOTOELE PM 400		01
02	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		03




Item	Code	Description	See page	QT
01	0511058633	FIXED SHORT SUPPORT FERTILIZER ROW		01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057272	LH SHORT ARM ROW FERTILIZER		01
06	0511058630	20" DISC CUT	73	01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	66	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	65	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15\"X15\" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8\" X 1.1/4\" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010026	3/8\" NUT		01
14	0503010025	3/8\" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2\" X 0.8\" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0571018989	LH BLADE DISC ARM		01
02	0502012790	LOCK NUT		01
03	0511058648	BOX WITH DISC BLADE 20	74	01
04	0521065978	RIGHT ARM WITH WASHER LOCK		01
05	0571019035	SLEEVE SUPPORT ARM		01
06	0521010452	SLEEVE		01
07	0521066743	REGULACION SPRING		01
08	0503010417	7/8" NUT		04
09	0571019033	FIXATION AXLE		01
10	0503034319	LOCK PIN		01
11	0502012813	FLANGE WASHER SPRING		01
12	0503034320	COMPRESSSION SPRING		01
13	0571019032	SUPPORT WASHER		01
14	0571019034	FLANGE WASHER AXLE		02
15	0503010002	1800 GREASE FITTING		01
16	0503013185	3/4" X 5-1/2" BOLT		01
17	0503011255	3/4" LOCK NUT		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503011440	SPRING WASHER		01
20	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511056909	DISC BOX CUT WITHOUT DISC	75	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01




Item	Code	Description	See page	QT
01	0502012793	DC PST		01
02	0571018047	CUTTING DISC BOX SHAFT		01
03	0503017755	NUT		01
04	0502020641	BLADE DISC FLANGE		01
05	0503013816	5/16" LOCKNUT		06
06	0571018048	BACKREST WASHER		02
07	0521065882	NILOS SEALING RING		02
08	0571018049	DOOR DUST		02
09	0581010575	7/8" X 145 BOLT		01
10	0503018825	5/16 UNC UNC BOLT		06
11	0501010694	FLAT WASHER		06
12	0503016061	BEARING		02
13	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG		01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057271	RH LONG ARM ROW FERTILIZER		01
06	0511058630	20" DISC CUT	73	01




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	65	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	66	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	79	01
02	0501052538	DEPTH BAND WITH ARMS	84	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	85	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	86	01
07	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	80	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	81	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	83	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	SCREWEW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL BOX	82	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL BOX	82	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	COVER DEPTH		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	87	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	87	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	NUT		02




Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0581014858	DEPTH WHEEL AXLE		01
04	0501110720	ARM LEFT		01
05	0501110719	DEPTH CONTROL RIGHT ARM		01
06	0502012663	EXTENSION		01
07	0503010002	1800 GREASE FITTING		02
08	0501056769	DEPTH WHEELS REGULATOR ASSY	91	01
09	0503034793	ARTICULATION SLEEVE		02
10	0521051423	COMPACTOR SUPPORT	92	01
11	0571017749	FLAT WASHER		02
12	0503010311	1/2" X 1-1/4" BOLT		02
13	0503016453	1/2" X 2.1/2 BOLT		02
14	0503034817	SPRING		01
15	0503010581	RING		01
16	0503034377	SCREWEW 3/8 UNC X 3/4		01
17	0503010019	1/2" SPRING WASHER		08
18	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
19	0503010060	1/2" NUT		04
20	0501052908	COMPACTOR WHEEL WITH BEARING	87	02
21	0503013739	1/2" X 1" BOLT		01
22	0511050077	WHEEL STRIPED	93	02
23	0503010752	1/2" X 3.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0521068003	RIGHT SIDE		01
02	0521068002	LEFT SIDE		01
03	0581014847	PLATE UPPER		01
04	0581015855	SLEEVE		02
05	0521068004	HANDLE BODY		01
06	0581014969	SLEEVE GUIDE		01
07	0581014968	SLEEVE FLANGE		01
08	0503010937	5/16" X 3" BOLT		02
09	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
10	0521068005	LEVER		01
11	0503010179	LOCK WASHER		04
12	0503010337	5/16" NUT		04
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2" NUT		01
15	0503010847	1/2" X 3.1/4" BOLT		01
16	0503010882	BOLT		02
17	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
18	0503030878	LEVER CRANK		01
19	0581015854	RIGHT PROTECTION COVER		01
20	0581015853	LEFT PROTECTION COVER		01
21	0581015903	SPACER WASHER		01




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	94	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	LOCK WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEELS BOX		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0521066457	WHEEL SUPPORT		01
02	0531013272	0.5" X 1" X 2.2" SLEEVE		01
03	0511064128	PRESS SUPPORT LOWWER WHEEL		01
04	0502011757	PRESS REGULATOR		01
05	0501013491	5/8" TENSIONER SPRING		01
06	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
07	0503010752	1/2" X 3.1/2" BOLT		01
08	0503010019	1/2" SPRING WASHER		01
09	0503010060	1/2" NUT		01
10	0503010013	5/8" NUT		02
11	0503010849	3/8" X 1-1/2" BOLT		02
12	0503010026	3/8" NUT		02
13	0521014508	FLAT WASHER		07
14	0501052957	IRON V PRESS WHEELS	97	02
15	0503010025	3/8" SPRING WASHER		02
16	0503010003	1845 GREASE FITTING		01
17	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
18	0503016864	LH 1/2" LOCK NUT		01
19	0503012136	NUT 1/2 NF		01
20	0503016449	1/2 X 4 BOLT		01



Item	Code	Description	See page	QT
01	0521066456	WHEEL SUPPORT		01
02	0531013272	0.5" X 1" X 2.2" SLEEVE		01
03	0511064128	PRESS SUPPORT LOWWER WHEEL		01
04	0502011757	PRESS REGULATOR		01
05	0501013491	5/8" TENSIONER SPRING		01
06	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
07	0503010752	1/2" X 3.1/2" BOLT		01
08	0503010019	1/2" SPRING WASHER		01
09	0503010060	1/2" NUT		01
10	0503010013	5/8" NUT		02
11	0503010849	3/8" X 1-1/2" BOLT		02
12	0503010026	3/8" NUT		02
13	0521014508	FLAT WASHER		07
14	0501052957	IRON V PRESS WHEELS	97	02
15	0503010025	3/8" SPRING WASHER		02
16	0503010003	1845 GREASE FITTING		01
17	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
18	0503016864	LH 1/2" LOCK NUT		01
19	0503012136	NUT 1/2 NF		01
20	0503016449	1/2 X 4 BOLT		01



Item	Code	Description	See page	QT
01	0502011932	IRON PRESS WHEELS		01
02	0503010269	6204 BALL BEARING		02
03	0503011105	SEAL RING		01
04	0503013848	5072-BR SEAL		02
05	0521019147	V COMPACT WHEELS AXLE		02
06	0511011927	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01



MARCHESAN

Technical Publications | Elaboration and Revision

MARINA PEREZ NIZA

www.marchesan.com.br

