

ROW CROP PLANTERS

PST DUO FLEX TITANIUM - FRAME 4880/5950

Code: 0501091928
Series: S-0116
Revision: 00
Date Revision: JUNHO/2017

PARTS CATALOGUE



MARCHESAN

PRODUCTS

Code	Description
0111240280	PST DUO FLEX 4880/10E500 CI DC20 CBR CSU TIT S0116
0111240281	PST DUO FLEX 4880/10E500 ESPECIAL S-0116
0111240282	PST DUO FLEX 4880/10E500 ESPECIAL S-0116
0111240300	PST DUO FLEX 4880/10E500 ESPECIAL S-0116
0111240231	PST DUO FLEX 4880/10E500 ESPECIAL S-0116
0111240202	PST DUO FLEX 4880/10E500 ESPECIAL S-0116
0111240232	PST DUO FLEX 4880/10E500 ESPECIAL S-0116
0111240271	PST DUO FLEX 4880/10E500 ESPECIAL S-0116
0111240283	PST DUO FLEX 4880/10E500 ESPECIAL S-0116
0111240240	PST DUO FLEX 4880/10E500 HDA MH CSU TIT S-0116
0111240212	PST DUO FLEX 4880/10E500 MH DC20 PM400 TIT S-0116
0111240214	PST DUO FLEX 4880/10E500 MH DC20 TIT S-0116
0111240264	PST DUO FLEX 4880/11E450 CI DC20 TIT S-0116
0111240170	PST DUO FLEX 4880/11E450 CPRA D/HDA MH TIT S-0116
0111240218	PST DUO FLEX 4880/11E450 CPRA H TIT S-0116
0111240146	PST DUO FLEX 4880/11E450 CPRA MH CSU TIT S-0116
0111240221	PST DUO FLEX 4880/11E450 CPRA TIT S-0116
0111240223	PST DUO FLEX 4880/11E450 D DC20 CSU TIT S-0116
0111240174	PST DUO FLEX 4880/11E450 ESPECIAL S-0116
0111240242	PST DUO FLEX 4880/11E450 ESPECIAL S-0116
0111240217	PST DUO FLEX 4880/11E450 ESPECIAL S-0116
0111240224	PST DUO FLEX 4880/11E450 ESPECIAL S-0116
0111240197	PST DUO FLEX 4880/11E450 ESPECIAL S-0116
0111240206	PST DUO FLEX 4880/11E450 ESPECIAL S-0116
0111240248	PST DUO FLEX 4880/11E450 ESPECIAL S-0116
0111240279	PST DUO FLEX 4880/11E450 ESPECIAL S-0116
0111240292	PST DUO FLEX 4880/11E450 ESPECIAL S-0116
0111240303	PST DUO FLEX 4880/11E450 ESPECIAL S-0116
0111240220	PST DUO FLEX 4880/11E450 HDA MH TIT S-0116
0111240199	PST DUO FLEX 4880/11E450 IAPAR MH TIT S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.

PRODUCTS

0111240178	PST DUO FLEX 4880/11E450 MH CSU TIT CEAC S-0116
0111240229	PST DUO FLEX 4880/11E450 MH CSU TIT S-0116
0111240181	PST DUO FLEX 4880/11E450 MH TIT S-0116
0111240211	PST DUO FLEX 5340/11E500 ESPECIAL S-0116
0111240285	PST DUO FLEX 5340/11E500 ESPECIAL S-0116
0111240291	PST DUO FLEX 5340/11E500 ESPECIAL S-0116
0111240250	PST DUO FLEX 5340/11E500 ESPECIAL S-0116
0111240257	PST DUO FLEX 5340/11E500 ESPECIAL S-0116
0111240210	PST DUO FLEX 5340/11E500 ESPECIAL S-0116
0111240215	PST DUO FLEX 5340/11E500 ESPECIAL S-0116
0111240246	PST DUO FLEX 5340/11E500 ESPECIAL S-0116
0111240247	PST DUO FLEX 5340/11E500 H DC20 TIT S-0116
0111240216	PST DUO FLEX 5340/11E500 H TIT S-0116
0111240177	PST DUO FLEX 5340/11E500 MH CSU TIT S-0116
0111240237	PST DUO FLEX 5950/12E500 D/HDA MH TIT S-0116
0111240195	PST DUO FLEX 5950/12E500 DC20 PM100 TIT S-0116
0111240193	PST DUO FLEX 5950/12E500 ESPECIAL S-0116
0111240238	PST DUO FLEX 5950/12E500 ESPECIAL S-0116
0111240208	PST DUO FLEX 5950/12E500 ESPECIAL S-0116
0111240258	PST DUO FLEX 5950/12E500 ESPECIAL S-0116
0111240297	PST DUO FLEX 5950/12E500 ESPECIAL S-0116
0111240301	PST DUO FLEX 5950/12E500 ESPECIAL S-0116
0111240239	PST DUO FLEX 5950/12E500 H MH CSU TIT S-0116
0111240167	PST DUO FLEX 5950/12E500 MH CSU TIT S-0116
0111240191	PST DUO FLEX 5950/12E500 MH DC20 CSU TIT S-0116
0111240194	PST DUO FLEX 5950/12E500 MH DC20 PM100 TIT S-0116
0111240290	PST DUO FLEX 5950/13E450 CI MH DC20 CSU TIT S-0116
0111240213	PST DUO FLEX 5950/13E450 D/IAPAR MH CSU TIT S-0116
0111240168	PST DUO FLEX 5950/13E450 ESPECIAL S-0116
0111240263	PST DUO FLEX 5950/13E450 ESPECIAL S-0116
0111240249	PST DUO FLEX 5950/13E450 ESPECIAL S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.

PRODUCTS

0111240225	PST DUO FLEX 5950/13E450 ESPECIAL S-0116
0111240276	PST DUO FLEX 5950/13E450 ESPECIAL S-0116
0111240277	PST DUO FLEX 5950/13E450 ESPECIAL S-0116
0111240284	PST DUO FLEX 5950/13E450 ESPECIAL S-0116
0111240288	PST DUO FLEX 5950/13E450 ESPECIAL S-0116
0111240298	PST DUO FLEX 5950/13E450 ESPECIAL S-0116
0111240305	PST DUO FLEX 5950/13E450 ESPECIAL S-0116
0111240169	PST DUO FLEX 5950/13E450 MH CSU TIT S-0116
0111240192	PST DUO FLEX 5950/13E450 RPA H MH TIT S-0116
0111240172	PST DUO FLEX 6350/13E500 ESPECIAL S-0116
0111240289	PST DUO FLEX 6350/13E500 ESPECIAL S-0116
0111240227	PST DUO FLEX 6350/13E500 MH DC20 CSU TIT S-0116
0111240241	PST DUO FLEX 6350/13E500 MH PM100 CSU TIT S-0116
0111240184	PST DUO FLEX 6850/14E500 ESPECIAL S-0116
0111240185	PST DUO FLEX 6850/14E500 ESPECIAL S-0116
0111240294	PST DUO FLEX 6850/14E500 ESPECIAL S-0116
0111240253	PST DUO FLEX 6850/14E500 ESPECIAL S-0116
0111240203	PST DUO FLEX 6850/14E500 MH DC20 CSU TIT S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909092649	ASSY FRAME - 08A13 L	1
0511056545	CHASSI COM ARTICULATION	2
0511056546	RIGHT FRAME WITH WHEEL AXLE - FRAME 4880	3
0511056738	LEFT FRAME WITH WHEEL AXLE - FRAME 4880	4
0511056787	FRAME WHIT ARTICULATION	5
0511056786	RIGHT FRAME WITH WHEEL AXLE - FRAME 5950	6
0511056785	LEFT FRAME WITH WHEEL AXLE - FRAME 5950	7
0511058667	SPRING FLOW ENSEMBLY	8
0511056529	CYLINDER ASSY	9
0511058406	HYDRAULIC CYLINDER	10
0511059265	WHEELED WITH SPRING TRACTION WITH TRANSMISSION	11
0511059262	WHEEL SUPPORT ASSY	12
0511052770	WHEEL WITH TIRE	13
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	14
0503062159	WHEEL WITH TIRE	15
0501058240	WHEEL FASTENER WITH TENSIONER	16
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	17
0501058244	WHEEL FIXED CHAIN TENSIONER	18
0501058242	WHEEL MOBILE CHAIN TENSIONER	19
0521043312	HUB SPINDLE ASSY	20
0501058241	WHEEL SUPPORT CHAIN TENSIONER	21
0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	22
0521043313	WHEELED WITH SPRING TRACTION WITHOUT TRANSMISSION	23
0521050294	RIGHT TRANSMISSION ASSY - 4880	24
0511051434	TRANSMISSION ACTUATOR	25
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	26
0521050183	RIGHT GEAR BOX ASSY	27
0501058212	SEMI MOUNTED RIGHT CHANGE	28
0501048790	AXLE WITH RING	29
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	30
0501056443	GEAR HOUSING BEARING	31
0511059266	CLOSED BEARING	32
0501056271	GEARBOX CLOSED BEARING	33
0501054655	CHAIN TENSIONER ASSY	34
0521050851	RIGHT TRANSMISSION ASSY SUPREME PP 5340	35
0521051266	RIGHT TRANSMISSION 5950	36
0521050185	5950 RIGHT TRANSMISSION ASSEMBLY	37
0501052560	MOTOR AXLE SIGNAL	38
0511054363	CHAIN TENSIONER	39
0501058265	STRETCHER LOWER CURRENT 21Z SEED	40
0501058254	UPPER SEED CHAIN TENSIONER	41
0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42
0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43
0521050295	LEFT TRANSMISSION ASSY - 4880	44
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	45
0521050184	EXCHANGE LEFT ASSY	46
0501058213	LH GEAR BOX	47
0521050852	LEFT TRANSMISSION ASSY SUPREME PP 5340	48
0521051267	LEFT TRANSMISSION	49
0521050186	5950 LEFT TRANSMISSION ASSEMBLY	50
0511056744	SET FERTILIZER SILO	51
0511056747	RH BEAM SUPPORT	52
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	53
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	54



MARCHESAN

INDEX


0511056748	LH BEAM SUPPORT	55
0511056792	SET FERTILIZER SILO	56
0511051932	RH BEAM SUPPORT	57
0511051933	LH BEAM SUPPORT	58
0511056533	SET FERTILIZER SILO	59
0511056350	RH BEAM SUPPORT PST DUO/F 11E500	60
0511051741	RH BEAM SUPPORT	61
0511056351	LH BEAM SUPPORT PST DUO/F 11E500	62
0511051742	LH BEAM SUPPORT	63
0511056745	LATFORM SET	64
0511056793	PLATFORM SET	65
0511056534	PLATFORM ASSY	66
0521050259	SET HANDRAIL	67
0521050853	HANDRAIL ASSY	68
0511058734	HANDRAIL SET PST DUO/F 5950 MTH	69
0511056536	LADDER ASSEMBLY	70
0909094295	HEADER ASSY	71
0511054601	HITCH ARTICULATED TRACTOR	72
0511054327	RIGHT TURNBUCKLE	73
0511054328	LEFT TURNBUCKLE	74
0511052311	3 POINT TURNBUCKLE	75
0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	76
0511056532	ASSY SYSTEM HYDRAULIC 5340	77
0511056743	SEMI MOUNTED HYDRAULIC MARKER 4880	78
0511058449	HYDRAULIC CYLINDER	79
0501054649	HBM SEQUENTIAL VALVE	80
0511056735	SEMI MOUNTED HYDRAULIC MARKER 5340	81
0511056789	SEMI MOUNTED HYDRAULIC MARKER 5720/5950	82
0511054971	JACK ASSEMBLY	83
0511057518	ASSY PORT MANUAL INSTRUCCION	84
0511059792	CSU C3 SEMI-ASSEMBLED ASSY 4045/4495 8	85
0511059585	ASSEMBLY CSU C3 SEMI MOUNTED 4880	86
0511059072	ASSEMBLY CSU C3 SEMI MOUNTED 5340	87
0511058723	ASSEMBLY CSU C3 SEMI MOUNTED 5950	88
0521050006	ASSEMBLY CSU PST DUO/F SUP 5950/13	89
0909093584	FERTILIZER SEED ROW ASSY	90
0501059834	LEFT SHORT SEED ROW FRONT	91
0501059833	RIGHT SHORT SEED ROW FRONT	92
0501059835	RIGHT LONG SEED ROW FRONT	93
0501059836	LEFT LONG SEED ROW FRONT	94
0511054884	TRANSMISSION BOX	95
0511059264	BEARING WITH AXLE	96
0511050609	BEARING WITH 17Z GEAR ASSY	97
0511056621	RIGHT REAR SEED ROW	98
0511056622	LEFT REAR SEED ROW	99
0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	100
0511056586	15 X 15 SEED DDD LEFT	101
0511052301	SUPPORT DDD 15 RIGHT	102
0511053172	LEFT LOW HUB WITH 15 DISC	103
0511053173	RIGHT LOW HUB WITH 15 DISC	104
0511056608	TITANIUM SEED SYSTEM	105
0521050096	SEED HOPPER SYSTEM (CSU)	106
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	107
0511058650	SEMI-MOUNTED DEPTH CONTROL	108
0511058652	LEFT DEPTH WHEEL ARM WITH HUB	109



MARCHESAN


INDEX

0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	110
0501052297	DEPTH WHEELS REGULATOR ASSY	111
0501052627	ASSY DEPTH WHEEL HUB	112
0501052538	DEPTH BAND WITH ARMS	113
0501054333	RIGHT CONVEX PRESS WHEELS	114
0501056269	SUPPORT WHEEL ASSY CONCAVE RIGHT	115
0501052501	CONVEX PRESS WHEEL	116
0511053341	MOTOR SHAFT ASSEMBLY	117
0521044269	PRESS WHEELS/DEPTH ASSY	118
0511055326	DEPTH CONTROL PRESS WHEEL ASSY	119
0501059228	ADJUSTMENT LEVER	120
0511055328	DEPTH WHEEL SYSTEM	121
0511055329	LEFT DEPTH WHEEL	122
0511055627	WHEEL ASSY RAYED	123
0511055626	SPREADED DEPTH WHEEL HUB	124
0511055327	COMPACTING WHEEL V ASSY RUBBER	125
0521044460	SYSTEM DEPTH / COMPACTOR	126
0511055690	WHEEL SYSTEM	127
0511055628	DEPTH WHEEL SYSTEM	128
0511055629	DEPTH WHEEL SYSTEM	129
0521046501	DEPTH CONTROL AND PRESS WHEEL WITH FAST ADJUSTING	130
0511059462	DEPTH CONTROL WITH FAST ADJUSTMENT	131
0511050077	WHEEL STRIPED	132
0501052908	COMPACTOR WHEEL WITH BEARING	133
0501056769	DEPTH WHEELS REGULATOR ASSY	134
0511059463	COMFORT WHEEL WITH FAST ADJUSTMENT	135
0511059350	FERTILIZER ROW SUPPORT ASSEMBLY	136
0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	137
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	138
0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	139
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	140
0501058423	FERTILIZER ROD SPRING ROW	141
0511058619	20" SHORT ROW DISC BLADE	142
0511058617	DISC CUT 18 SHORT LINE	143
0511056909	DISC BLADE HUB WITHOUT DISC	144
0511058620	20" LONG ROW DISC BLADE	145
0511058618	DISC CUT 18 LONG LINE	146
0501050633	ROW MARKER DISC ASSEMBLY	147
0909094321	HEX AXLE ASSEMBLY	148
0511054682	HEX AXLE ASSEMBLY - 4845	149
0909094322	HEX AXLE ASSEMBLY	150
0511059410	HDA BC	151
0511059396	SCARIFIER SPINDLE WITH POINT	152
0511052341	CEAC ASSY 11L	153
0511052339	CEAC ASSY 13L	154
0909093700	PM100 SEED MONITORING ASSEMBLY	155
0909092664	PM 400 SEED END FERTILIZER MONITORING ASSEMBLY	156
0521052617	WHEEL SYSTEM DEPTH / COMPACTOR	157




Item	Code	Description	See page	08	10	11	12	13	L
01	0511056545	CHASSI COM ARTICULATION	2	01	01	00	00	00	
02	0511056787	FRAME WHIT ARTICULATION	5	00	00	01	01	01	
03	0521064285	LOCK LOWER FRAME		01	01	01	01	01	
04	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		01	01	01	01	01	
05	0511058667	SPRING FLOW ENSEMBLY	8	01	01	01	01	01	
06	0503010002	1800 GREASE FITTING		01	01	01	01	01	
07	0503010003	1845 GREASE FITTING		05	05	02	02	02	
08	0503010004	1890 GREASE FITTING		02	02	02	02	02	
09	0511056529	CYLINDER ASSY	9	01	01	01	01	01	
10	0511059265	WHEELED WITH SPRING TRACTION WITH TRANSMISSION	11	04	04	00	04	04	
11	0521043312	HUB SPINDLE ASSY	20	00	00	04	00	00	
12	0521043313	WHEELED WITH SPRING TRACTION WITHOUT TRANSMISSION	23	00	00	00	02	02	
13	0521050294	RIGHT TRANSMISSION ASSY - 4880	24	01	01	00	00	00	
13.	0521050851	RIGHT TRANSMISSION ASSY SUPREME PP 5340	35	00	00	01	00	00	
13..	0521051266	RIGHT TRANSMISSION 5950	36	00	00	00	01	00	
13...	0521050185	5950 RIGHT TRANSMISSION ASSEMBLY	37	00	00	00	00	01	
14	0521050295	LEFT TRANSMISSION ASSY - 4880	44	01	01	00	00	00	
14.	0521050852	LEFT TRANSMISSION ASSY SUPREME PP 5340	48	00	00	01	00	00	
14..	0521051267	LEFT TRANSMISSION	49	00	00	00	01	00	
14...	0521050186	5950 LEFT TRANSMISSION ASSEMBLY	50	00	00	00	00	01	
15	0511056744	SET FERTILIZER SILO	51	01	01	00	00	00	
15.	0511056792	SET FERTILIZER SILO	56	00	00	00	01	01	
15..	0511056533	SET FERTILIZER SILO	59	00	00	01	00	00	
16	0511056745	LATFORM SET	64	01	01	00	00	00	
16.	0511056793	PLATFORM SET	65	00	00	00	01	01	
16..	0511056534	PLATFORM ASSY	66	00	00	01	00	00	
17	0521050259	SET HANDRAIL	67	01	01	00	00	00	
17.	0521050853	HANDRAIL ASSY	68	00	00	01	00	00	
17..	0511058734	HANDRAIL SET PST DUO/F 5950 MTH	69	00	00	00	01	01	
18	0511056536	LADDER ASSEMBLY	70	02	02	02	02	02	


Item	Code	Description	See page	08	10	11	12	13	L
19	0909094295	HEADER ASSY	71	01	01	01	01	01	
20	0501047895	25 ROD STOP		02	02	02	02	02	
21	0501047885	30 ROD STOP		02	02	02	02	02	
22	0501047886	35 ROD STOP		02	02	02	02	02	
23	0501047887	40 ROD STOP		02	02	02	02	02	
24	0521013022	TRANSPORT LOCK		02	02	02	02	02	
25	0501068994	8,30 X 78 LOCK PIN		02	02	02	02	02	
26	0503030168	HITCH PIN CLIP		02	02	02	02	02	
27	0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	76	01	01	00	01	01	
27.	0511056532	ASSY SYSTEM HYDRAULIC 5340	77	00	00	01	00	00	
28	0511056743	SEMI MOUNTED HYDRAULIC MARKER 4880	78	01	01	00	00	00	
28.	0511056735	SEMI MOUNTED HYDRAULIC MARKER 5340	81	00	00	01	00	00	
28..	0511056789	SEMI MOUNTED HYDRAULIC MARKER 5720/5950	82	00	00	00	01	01	
29	0511054971	JACK ASSEMBLY	83	04	04	04	04	04	
30	0511057518	ASSY PORT MANUAL INSTRUCCION	84	01	01	01	01	01	
31	0511059792	CSU C3 SEMI-ASSEMBLED ASSY 4045/4495 8	85	01	00	00	00	00	
32	0511059585	ASSEMBLY CSU C3 SEMI MOUNTED 4880	86	00	01	00	00	00	
33	0511059072	ASSEMBLY CSU C3 SEMI MOUNTED 5340	87	00	00	01	00	00	
34	0511058723	ASSEMBLY CSU C3 SEMI MOUNTED 5950	88	00	00	00	01	00	
35	0521050006	ASSEMBLY CSU PST DUO/F SUP 5950/13	89	00	00	00	00	01	
36	0909093584	FERTILIZER SEED ROW ASSY	90	08	10	11	12	13	
37	0501065677	STRUT		02	02	02	02	02	
38	0503032624	FERTILIZER HOPPER GUTTER		06	06	06	06	06	
39	0501050633	ROW MARKER DISC ASSEMBLY	147	02	02	02	02	02	
40	0541015451	FIXED KEY 2.3/8 X 2.3/4		01	01	01	01	01	
41	0909094321	HEX AXLE ASSEMBLY	148	01	00	00	00	00	
42	0511054682	HEX AXLE ASSEMBLY - 4845	149	00	01	01	00	01	
43	0909094322	HEX AXLE ASSEMBLY	150	00	00	00	01	00	
44	0511052341	CEAC ASSY 11L	153	01	01	01	01	01	
45	0511052339	CEAC ASSY 13L	154	01	01	01	01	01	
46	0909093700	PM100 SEED MONITORING ASSEMBLY	155	01	01	01	01	01	
47	0909092664	PM 400 SEED END FERTILIZER MONITORING ASSEMBLY	156	01	01	01	01	01	




Item	Code	Description	See page	QT
001	0511056546	RIGHT FRAME WITH WHEEL AXLE - FRAME 4880	3	01
002	0511056738	LEFT FRAME WITH WHEEL AXLE - FRAME 4880	4	01
003	0501110791	FRONT ARTICULATOR HUB WITH SLEEVES		01
004	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		01
005	0503011442	3/4" SPRING WASHER		09
006	0501010098	3/4" UNC BOLT		09
007	0571010094	SLEEVE FLANGE		02
008	0521065616	ARTICULATION		01
009	0502012698	CLAMP		02
010	0503011444	SPRING WASHER		02
011	0571013510	LOCK AXLE		01
012	0503030085	LOCK PIN		01
013	0571010095	FLAT WASHER		01
014	0521063003	LOCK PIN		01
015	0571010969	LOCK SLEEVE FRAME		01
016	0503013627	1.1/2 SPRING WASHER		01
017	0501010110	1.1/2" NUT		01
018	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
019	0501018059	3/4" X 2-1/4" BOLT		03
020	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
001	0521065512	CH RIGHT		01
002	0521063930	PIVOT SHAFT		01
003	0521013199	LOWER BEARING SEMI		03
004	0503010899	5/8 UNC X 2.1/4 BOLT		06
005	0531013922	0.6" X 0.8" X 1" SLEEVE		06
006	0503010013	5/8 NUT		06
007	0503011445	SPRING WASHER		06
008	0501012140	FLAT WASHER		12




Item	Code	Description	See page	QT
001	0521065632	CH LEFT		01
002	0521063929	CARRYING-WHEELS PIVOT SHAFT		01
003	0521013199	LOWER BEARING SEMI		03
004	0503010899	5/8 UNC X 2.1/4 BOLT		06
005	0531013922	0.6" X 0.8" X 1" SLEEVE		06
006	0503010013	5/8 NUT		06
007	0503011445	SPRING WASHER		06
008	0501012140	FLAT WASHER		12




Item	Code	Description	See page	QT
001	0511056786	RIGHT FRAME WITH WHEEL AXLE - FRAME 5950	6	01
002	0511056785	LEFT FRAME WITH WHEEL AXLE - FRAME 5950	7	01
003	0501110791	FRONT ARTICULATOR HUB WITH SLEEVES		01
004	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		01
005	0503011442	3/4" SPRING WASHER		09
006	0501010098	3/4" UNC BOLT		09
007	0571010094	SLEEVE FLANGE		02
008	0521065616	ARTICULATION		01
009	0502012698	CLAMP		02
010	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
011	0503011444	SPRING WASHER		02
012	0571013510	LOCK AXLE		01
013	0503030085	LOCK PIN		01
014	0571010095	FLAT WASHER		01
015	0521063003	LOCK PIN		01
016	0571010969	LOCK SLEEVE FRAME		01
017	0503013627	1.1/2 SPRING WASHER		01
018	0501010110	1.1/2" NUT		01




Item	Code	Description	See page	QT
001	0521065639	CH RIGHT		01
002	0521063938	CARRYING-WHEELS PIVOT SHAFT		01
003	0521013199	LOWER BEARING SEMI		03
004	0503010899	5/8 UNC X 2.1/4 BOLT		06
005	0531013922	0.6" X 0.8" X 1" SLEEVE		06
006	0503010013	5/8 NUT		06
007	0503011445	SPRING WASHER		06
008	0501012140	FLAT WASHER		12




Item	Code	Description	See page	QT
001	0521065634	CH LEFT		01
002	0521063937	PIVOT SHAFT		01
003	0521013199	LOWER BEARING SEMI		03
004	0503010899	5/8 UNC X 2.1/4 BOLT		06
005	0531013922	0.6" X 0.8" X 1" SLEEVE		06
006	0503010013	5/8 NUT		06
007	0503011445	SPRING WASHER		06
008	0501012140	FLAT WASHER		12




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		06
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		12
03	0501012140	FLAT WASHER		24




Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	10	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521012536	COUPLING SHAFT		02
04	0503010523	1/4" X 2" SPLIT PIN		04
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010013	5/8 NUT		02




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCKLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O'RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O'RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0511059262	WHEEL SUPPORT ASSY	12	01
02	0501058240	WHEEL FASTENER WITH TENSIONER	16	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0531062422	WHEEL ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0501058241	WHEEL SUPPORT CHAIN TENSIONER	21	01
07	0511052770	WHEEL WITH TIRE	13	01
08	0503018981	BOLT		02
09	0503010027	5/8 SPRING WASHER		04
10	0591010589	BODY LOCK WHEEL		01
11	0521069983	WHEEL COVER		01
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
13	0551017715	FLAT WASHER		02
14	0503013030	5/8" X 3.1/4" BOLT		01
15	0511050681	TRACTION SPRING		01
15A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
15B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	15	01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	14	01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8 NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	17	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	18	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	19	01



Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01

HUB SPINDLE ASSY


0521043312




Item	Code	Description	See page	QT
01	0511054335	WHEEL SUPPORT ASSY		01
01A	0521061566	CARRYING WHEEL ARM TRACTION		01
01B	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
01C	0531016887	CARRYING WHEEL AXLE ARM		01
01D	0503010523	1/4" X 2" SPLIT PIN		01
01E	0503010003	1845 GREASE FITTING		01
01F	0511050681	TRACTION SPRING		01
01FA	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01FB	0561016062	SPRING HITCH		02
01G	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
01H	0503010027	5/8 SPRING WASHER		01
01I	0503013030	5/8" X 3.1/4" BOLT		01
01J	0551017715	FLAT WASHER		02
01K	0511052770	WHEEL WITH TIRE	13	01
01KA	0503062159	WHEEL WITH TIRE	15	01
01KB	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	14	01
01L	0521012190	AXLE LOCK		02
01M	0503010027	5/8 SPRING WASHER		02
01N	0503011167	M16 X 2 X 30 BOLT		02
01O	0501058241	WHEEL SUPPORT CHAIN TENSIONER	21	01
01P	0501012140	FLAT WASHER		01
02	0501058240	WHEEL FASTENER WITH TENSIONER	16	01
03	0502011308	WHELL FASTENER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0521066557	CYLINDER CASE 101,60 X 352		01
02	0581010680	TURNBUCKLE 50,80 X 386		01
03	0571015629	CILINDER SPINDLE FORK		01
04	0503010817	1.1/4" SELF LOCKING NUT		01
05	0503010345	2-218 N 3006-9B O'RING		01
06	0503011094	3/8" X 2" BOLT		01
07	0503010026	3/8" NUT		01
08	0503010025	3/8 SPRING WASHER		01
09	0503030385	CYLINDER PLUG N-002		02
10	0503015633	SELEMASTER SEALING		01
11	0581010678	50,80 X 101 RING SUPPORT		01
12	0503015636	SCRAPER SEAL		01
13	0503018025	RING GUIDE		01
14	0503018026	1870-2000-375 B GASKET		01
15	0503010338	2-342 N 3006-9B O'RING		02
16	0503011061	8-342 BACK-UP RING		02
17	0502012822	101.60 END CAP		01
18	0502012820	50,80 X 101,60 PISTON		01
19	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0511054336	SUPPORT WHEELED WITHOUT TRANSMISSION	01	
02	0502010584	CARRYING-WHEELS SUPPORT FIXER	02	
03	0503011119	7/8" X 6" BOLT	04	
04	0501014251	FLAT WASHER	04	
05	0503011254	7/8" HEX SELF ADJUSTING NUT	04	
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN	01	
07	0503010027	5/8 SPRING WASHER	02	
08	0551017715	FLAT WASHER	02	
09	0503013030	5/8" X 3.1/4" BOLT	01	
10	0511050681	TRACTION SPRING	01	
10A	0503031681	2.1" X 7.78" EXTENSION SPRING	01	
10B	0561016062	SPRING HITCH	02	




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	38	01
14A	0503031825	AXLE MOTOR SLOW-MOVING		02
14B	0503010240	BOLT		02
14C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
14D	0503010337	5/16" NUT		02
15	0511051434	TRANSMISSION ACTUATOR	25	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	26	01
17	0521050183	RIGHT GEAR BOX ASSY	27	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01

Item	Code	Description	See page	QT
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	39	01
30A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
30B	0503031805	11Z 1/2" GEAR		01
30C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
30D	0503010019	1/2" SPRING WASHER		01
30E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01
31A	0511062169	21Z P 1/2" GEAR		01
31B	0503011410	ROLLER BEARING		01
31C	0503011105	SEAL RING		01
31D	0531017086	50 AXLETIGHTENER		01
31E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
31F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
31G	0501012140	FLAT WASHER		01
31H	0503010027	5/8 SPRING WASHER		01
31I	0503010013	5/8 NUT		01
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
32A	0503031805	11Z 1/2" GEAR		01
32B	0503010302	501019 SEAL RING		01
32C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
32D	0503010019	1/2" SPRING WASHER		01
32E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
32F	0521018933	CHAIN TENSIONER AXLE		01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
33A	0511062169	21Z P 1/2" GEAR		01
33B	0503011410	ROLLER BEARING		01
33C	0503011105	SEAL RING		01
33D	0531017086	50 AXLETIGHTENER		01
33E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
33F	0501011234	5/8" X 3" BOLT		01
33G	0503012412	5/8" UNC SELF LOCKING NUT		01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
34A	0511069680	20Z X 28Z DOUBLE GEAR		01
34B	0503011410	ROLLER BEARING		02
34C	0551019175	DOUBLE GEAR AXLE		01
34D	0503010406	501025 CLAMPING RING (FOR AXLE)		01
34E	0503016460	5/8" X 4.1/2" BOLT		01
34F	0503012412	5/8" UNC SELF LOCKING NUT		01
35	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0521017590	GUIDE AXLE		01
03	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
04	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
05	0501019734	FLAT WASHER		02
06	0502010710	RIGHT CAM, SMALLER		02
07	0503010003	1845 GREASE FITTING		02
08	0502012539	26Z P12,7 GEAR		01
09	0501019735	FLAT WASHER		01
10	0521017593	FLAT WASHER		01
11	0503010542	501045 CLAMPING RING (FOR AXLE)		01
12	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01

RIGHT GEAR BOX ASSY


0521050183




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	28	01
02	0511059266	CLOSED BEARING	32	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	31	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	29	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	34	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	30	01
23	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01
30	0511065209	20Z GEAR		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0502011978	CENTRAL BEARING GEARBOX		01
02	0503013462	6005 2RS1 ROLLER BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056444	SUPPORT WITH ROLLER BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	33	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
001	0501110639	BEARING		04
002	0503011099	GREASE FITTING		04
003	0503010300	5/32" X 1" SPLIT PIN		04
004	0551019114	MOTOR BEARING AXLE SUPPORT		02
005	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
006	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
007	0503010019	1/2" SPRING WASHER		04
008	0503010060	1/2 UNC G.5 ZN HEX NUT		04
009	0571017428	MOTOR SHAFT		01
010	0501018466	FLAT WASHER		02
011	0511015961	LOCK BUSHING		02
012	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
013	0503010060	1/2 UNC G.5 ZN HEX NUT		02
014	0501052560	MOTOR AXLE SIGNAL	38	01
014A	0503031825	AXLE MOTOR SLOW-MOVING		02
014B	0503010240	BOLT		02
014C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
014D	0503010337	5/16" NUT		02
015	0511051434	TRANSMISSION ACTUATOR	25	02
016	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	26	01
017	0521050183	RIGHT GEAR BOX ASSY	27	01
018	0501010243	1/2" X 1-1/2" BOLT		03
019	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
020	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
021	0503010019	1/2" SPRING WASHER		05
022	0503012682	1/2" BSW NUT		03
023	0503010060	1/2 UNC G.5 ZN HEX NUT		02
024	0521064449	36Z P1/2 SH 3/4 GEAR		01
025	0503030275	AGRICULTURAL BEARING		01
026	0501010637	FLAT WASHER		02
027	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01

Item	Code	Description	See page	QT
028	0503010025	3/8 SPRING WASHER		01
029	0503010256	3/8" X 3/4" BOLT		01
030	0511054363	CHAIN TENSIONER	39	01
030A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
030B	0503031805	11Z 1/2" GEAR		01
030C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
030D	0503010019	1/2" SPRING WASHER		01
030E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
031	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01
031A	0511062169	21Z P 1/2" GEAR		01
031B	0503011410	ROLLER BEARING		01
031C	0503011105	SEAL RING		01
031D	0531017086	50 AXLETIGHTENER		01
031E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
031F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
031G	0501012140	FLAT WASHER		01
031H	0503010027	5/8 SPRING WASHER		01
031I	0503010013	5/8 NUT		01
032	0501058254	UPPER SEED CHAIN TENSIONER	41	01
032A	0503031805	11Z 1/2" GEAR		01
032B	0503010302	501019 SEAL RING		01
032C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
032D	0503010019	1/2" SPRING WASHER		01
032E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
032F	0521018933	CHAIN TENSIONER AXLE		01
033	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
033A	0511062169	21Z P 1/2" GEAR		01
033B	0503011410	ROLLER BEARING		01
033C	0503011105	SEAL RING		01
033D	0531017086	50 AXLETIGHTENER		01
033E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
033F	0501011234	5/8" X 3" BOLT		01
033G	0503012412	5/8" UNC SELF LOCKING NUT		01
034	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
034A	0511069680	20Z X 28Z DOUBLE GEAR		01
034B	0503011410	ROLLER BEARING		02
034C	0551019175	DOUBLE GEAR AXLE		01
034D	0503010406	501025 CLAMPING RING (FOR AXLE)		01
034E	0503016460	5/8" X 4.1/2" BOLT		01
034F	0503012412	5/8" UNC SELF LOCKING NUT		01
035	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
036	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
037	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
038	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
001	0501110639	BEARING		04
002	0503011099	GREASE FITTING		04
003	0503010300	5/32" X 1" SPLIT PIN		04
004	0551019114	MOTOR BEARING AXLE SUPPORT		02
005	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
006	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
007	0503010019	1/2" SPRING WASHER		04
008	0503010060	1/2 UNC G.5 ZN HEX NUT		04
009	0571011442	MOTOR SHAFT		01
010	0501018466	FLAT WASHER		02
011	0511015961	LOCK BUSHING		02
012	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
013	0503010060	1/2 UNC G.5 ZN HEX NUT		02
014	0501052560	MOTOR AXLE SIGNAL	38	01
014A	0503031825	AXLE MOTOR SLOW-MOVING		02
014B	0503010240	BOLT		02
014C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
014D	0503010337	5/16" NUT		02
015	0511051434	TRANSMISSION ACTUATOR	25	02
016	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	26	01
017	0521050183	RIGHT GEAR BOX ASSY	27	01
018	0501010243	1/2" X 1-1/2" BOLT		03
019	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
020	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
021	0503010019	1/2" SPRING WASHER		05
022	0503012682	1/2" BSW NUT		03
023	0503010060	1/2 UNC G.5 ZN HEX NUT		02
024	0521064449	36Z P1/2 SH 3/4 GEAR		01
025	0503030275	AGRICULTURAL BEARING		01
026	0501010637	FLAT WASHER		02
027	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01

Item	Code	Description	See page	QT
028	0503010025	3/8 SPRING WASHER		01
029	0503010256	3/8" X 3/4" BOLT		01
030	0511054363	CHAIN TENSIONER	39	01
030A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
030B	0503031805	11Z 1/2" GEAR		01
030C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
030D	0503010019	1/2" SPRING WASHER		01
030E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
031	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01
031A	0511062169	21Z P 1/2" GEAR		01
031B	0503011410	ROLLER BEARING		01
031C	0503011105	SEAL RING		01
031D	0531017086	50 AXLETIGHTENER		01
031E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
031F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
031G	0501012140	FLAT WASHER		01
031H	0503010027	5/8 SPRING WASHER		01
031I	0503010013	5/8 NUT		01
032	0501058254	UPPER SEED CHAIN TENSIONER	41	01
032A	0503031805	11Z 1/2" GEAR		01
032B	0503010302	501019 SEAL RING		01
032C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
032D	0503010019	1/2" SPRING WASHER		01
032E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
032F	0521018933	CHAIN TENSIONER AXLE		01
033	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
033A	0511062169	21Z P 1/2" GEAR		01
033B	0503011410	ROLLER BEARING		01
033C	0503011105	SEAL RING		01
033D	0531017086	50 AXLETIGHTENER		01
033E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
033F	0501011234	5/8" X 3" BOLT		01
033G	0503012412	5/8" UNC SELF LOCKING NUT		01
034	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
034A	0511069680	20Z X 28Z DOUBLE GEAR		01
034B	0503011410	ROLLER BEARING		02
034C	0551019175	DOUBLE GEAR AXLE		01
034D	0503010406	501025 CLAMPING RING (FOR AXLE)		01
034E	0503016460	5/8" X 4.1/2" BOLT		01
034F	0503012412	5/8" UNC SELF LOCKING NUT		01
035	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
036	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0571011442	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	38	01
15	0511051434	TRANSMISSION ACTUATOR	25	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	26	01
17	0521050183	RIGHT GEAR BOX ASSY	27	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	39	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01


Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
35	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8 SPRING WASHER		01
09	0503010013	5/8 NUT		01




Item	Code	Description	See page	QT
01	0521018933	CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501011234	5/8" X 3" BOLT		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOUBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019175	DOUBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503016460	5/8" X 4.1/2" BOLT		01
06	0503012412	5/8" UNC SELF LOCKING NUT		01



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	38	01
14A	0503031825	AXLE MOTOR SLOW-MOVING		02
14B	0503010240	BOLT		02
14C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
14D	0503010337	5/16" NUT		02
15	0511051434	TRANSMISSION ACTUATOR	25	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	45	01
17	0521050184	EXCHANGE LEFT ASSY	46	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01


Item	Code	Description	See page	QT
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	39	01
30A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
30B	0503031805	11Z 1/2" GEAR		01
30C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
30D	0503010019	1/2" SPRING WASHER		01
30E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01
31A	0511062169	21Z P 1/2" GEAR		01
31B	0503011410	ROLLER BEARING		01
31C	0503011105	SEAL RING		01
31D	0531017086	50 AXLETIGHTENER		01
31E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
31F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
31G	0501012140	FLAT WASHER		01
31H	0503010027	5/8 SPRING WASHER		01
31I	0503010013	5/8 NUT		01
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
32A	0503031805	11Z 1/2" GEAR		01
32B	0503010302	501019 SEAL RING		01
32C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
32D	0503010019	1/2" SPRING WASHER		01
32E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
32F	0521018933	CHAIN TENSIONER AXLE		01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
33A	0511062169	21Z P 1/2" GEAR		01
33B	0503011410	ROLLER BEARING		01
33C	0503011105	SEAL RING		01
33D	0531017086	50 AXLETIGHTENER		01
33E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
33F	0501011234	5/8" X 3" BOLT		01
33G	0503012412	5/8" UNC SELF LOCKING NUT		01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
34A	0511069680	20Z X 28Z DOUBLE GEAR		01
34B	0503011410	ROLLER BEARING		02
34C	0551019175	DOUBLE GEAR AXLE		01
34D	0503010406	501025 CLAMPING RING (FOR AXLE)		01
34E	0503016460	5/8" X 4.1/2" BOLT		01
34F	0503012412	5/8" UNC SELF LOCKING NUT		01
35	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

EXCHANGE LEFT ASSY


0521050184



Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	47	01
02	0511059266	CLOSED BEARING	32	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	31	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	29	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	34	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	30	01
23	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01
30	0511065209	20Z GEAR		01



Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
001	0501110639	BEARING		04
002	0503011099	GREASE FITTING		04
003	0503010300	5/32" X 1" SPLIT PIN		04
004	0551019114	MOTOR BEARING AXLE SUPPORT		02
005	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
006	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
007	0503010019	1/2" SPRING WASHER		04
008	0503010060	1/2 UNC G.5 ZN HEX NUT		04
009	0571017428	MOTOR SHAFT		01
010	0501018466	FLAT WASHER		02
011	0511015961	LOCK BUSHING		02
012	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
013	0503010060	1/2 UNC G.5 ZN HEX NUT		02
014	0501052560	MOTOR AXLE SIGNAL	38	01
014A	0503031825	AXLE MOTOR SLOW-MOVING		02
014B	0503010240	BOLT		02
014C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
014D	0503010337	5/16" NUT		02
015	0511051434	TRANSMISSION ACTUATOR	25	02
016	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	45	01
017	0521050184	EXCHANGE LEFT ASSY	46	01
018	0501010243	1/2" X 1-1/2" BOLT		03
019	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
020	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
021	0503010019	1/2" SPRING WASHER		05
022	0503012682	1/2" BSW NUT		03
023	0503010060	1/2 UNC G.5 ZN HEX NUT		02
024	0521064449	36Z P1/2 SH 3/4 GEAR		01
025	0503030275	AGRICULTURAL BEARING		01
026	0501010637	FLAT WASHER		02
027	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01

Item	Code	Description	See page	QT
028	0503010025	3/8 SPRING WASHER		01
029	0503010256	3/8" X 3/4" BOLT		01
030	0511054363	CHAIN TENSIONER	39	01
031	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01
031A	0511062169	21Z P 1/2" GEAR		01
031B	0503011410	ROLLER BEARING		01
031C	0503011105	SEAL RING		01
031D	0531017086	50 AXLETIGHTENER		01
031E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
031F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
031G	0501012140	FLAT WASHER		01
031H	0503010027	5/8 SPRING WASHER		01
031I	0503010013	5/8 NUT		01
032	0501058254	UPPER SEED CHAIN TENSIONER	41	01
032A	0503031805	11Z 1/2" GEAR		01
032B	0503010302	501019 SEAL RING		01
032C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
032D	0503010019	1/2" SPRING WASHER		01
032E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
032F	0521018933	CHAIN TENSIONER AXLE		01
033	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
033A	0511062169	21Z P 1/2" GEAR		01
033B	0503011410	ROLLER BEARING		01
033C	0503011105	SEAL RING		01
033D	0531017086	50 AXLETIGHTENER		01
033E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
033F	0501011234	5/8" X 3" BOLT		01
033G	0503012412	5/8" UNC SELF LOCKING NUT		01
034	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
034A	0511069680	20Z X 28Z DOUBLE GEAR		01
034B	0503011410	ROLLER BEARING		02
034C	0551019175	DOUBLE GEAR AXLE		01
034D	0503010406	501025 CLAMPING RING (FOR AXLE)		01
034E	0503016460	5/8" X 4.1/2" BOLT		01
034F	0503012412	5/8" UNC SELF LOCKING NUT		01
035	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
036	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
037	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
038	0503014907	40-1 X 151 CHAIN LINK + MENDING		01

LEFT TRANSMISSION

0521051267




Item	Code	Description	See page	QT
001	0501110639	BEARING		04
002	0503011099	GREASE FITTING		04
003	0503010300	5/32" X 1" SPLIT PIN		04
004	0551019114	MOTOR BEARING AXLE SUPPORT		02
005	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
006	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
007	0503010019	1/2" SPRING WASHER		04
008	0503010060	1/2 UNC G.5 ZN HEX NUT		04
009	0571011442	MOTOR SHAFT		01
010	0501018466	FLAT WASHER		02
011	0511015961	LOCK BUSHING		02
012	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
013	0503010060	1/2 UNC G.5 ZN HEX NUT		02
014	0501052560	MOTOR AXLE SIGNAL	38	01
014A	0503031825	AXLE MOTOR SLOW-MOVING		02
014B	0503010240	BOLT		02
014C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
014D	0503010337	5/16" NUT		02
015	0511051434	TRANSMISSION ACTUATOR	25	02
016	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	45	01
017	0521050184	EXCHANGE LEFT ASSY	46	01
018	0501010243	1/2" X 1-1/2" BOLT		03
019	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
020	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
021	0503010019	1/2" SPRING WASHER		05
022	0503012682	1/2" BSW NUT		03
023	0503010060	1/2 UNC G.5 ZN HEX NUT		02
024	0521064449	36Z P1/2 SH 3/4 GEAR		01
025	0503030275	AGRICULTURAL BEARING		01
026	0501010637	FLAT WASHER		02
027	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01

LEFT TRANSMISSION


0521051267

Item	Code	Description	See page	QT
028	0503010025	3/8 SPRING WASHER		01
029	0503010256	3/8" X 3/4" BOLT		01
030	0511054363	CHAIN TENSIONER	39	01
030A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
030B	0503031805	11Z 1/2" GEAR		01
030C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
030D	0503010019	1/2" SPRING WASHER		01
030E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
031	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01
031A	0511062169	21Z P 1/2" GEAR		01
031B	0503011410	ROLLER BEARING		01
031C	0503011105	SEAL RING		01
031D	0531017086	50 AXLETIGHTENER		01
031E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
031F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
031G	0501012140	FLAT WASHER		01
031H	0503010027	5/8 SPRING WASHER		01
031I	0503010013	5/8 NUT		01
032	0501058254	UPPER SEED CHAIN TENSIONER	41	01
032A	0503031805	11Z 1/2" GEAR		01
032B	0503010302	501019 SEAL RING		01
032C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
032D	0503010019	1/2" SPRING WASHER		01
032E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
032F	0521018933	CHAIN TENSIONER AXLE		01
033	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
033A	0511062169	21Z P 1/2" GEAR		01
033B	0503011410	ROLLER BEARING		01
033C	0503011105	SEAL RING		01
033D	0531017086	50 AXLETIGHTENER		01
033E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
033F	0501011234	5/8" X 3" BOLT		01
033G	0503012412	5/8" UNC SELF LOCKING NUT		01
034	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
034A	0511069680	20Z X 28Z DOUBLE GEAR		01
034B	0503011410	ROLLER BEARING		02
034C	0551019175	DOUBLE GEAR AXLE		01
034D	0503010406	501025 CLAMPING RING (FOR AXLE)		01
034E	0503016460	5/8" X 4.1/2" BOLT		01
034F	0503012412	5/8" UNC SELF LOCKING NUT		01
035	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
036	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0571011442	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CS PC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	38	01
15	0511051434	TRANSMISSION ACTUATOR	25	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	45	01
17	0521050184	EXCHANGE LEFT ASSY	46	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	39	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
35	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
001	0511056747	RH BEAM SUPPORT	52	01
002	0511056748	LH BEAM SUPPORT	55	01
003	0503010849	3/8" X 1-1/2" BOLT		12
004	0501010984	10,50 X 27 X 3,00 FLAT WASHER		24
005	0503010025	3/8 SPRING WASHER		12
006	0503010026	3/8" NUT		12
007	0503034396	FERTILIZER SIDE COVER		12
008	0503010362	1/8" X 1.1/4" SPLIT PIN		12
009	0503062169	ASSEMBLED FERTILIZER HOPPER		02
010	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
011	0503010849	3/8" X 1-1/2" BOLT		08
012	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
013	0503010025	3/8 SPRING WASHER		08
014	0503010026	3/8" NUT		08
015	0551019156	GEAR BOX LEVER LOCK		02
016	0503011953	5/16" X 1" BOLT		04
017	0501010694	FLAT WASHER		04
018	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
019	0503010337	5/16" NUT		04
020	0503010847	1/2" X 3.1/4" BOLT		02
021	0551019168	SLEEVE		02
022	0551019160	LEVER		02
023	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
024	0503010019	1/2" SPRING WASHER		02
025	0503010060	1/2 UNC G.5 ZN HEX NUT		02
026	0551019167	SLEEVE UNION		02
027	0511069676	INNER LEVER		02
028	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
029	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
030	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
031	0503010019	1/2" SPRING WASHER		02


Item	Code	Description	See page	QT
032	0503010060	1/2 UNC G.5 ZN HEX NUT		02
033	0501013518	FLAT WASHER		02
034	0503010140	1/8" X 3/4" SPLIT PIN		02
035	0511069678	LH LOWER LEVER		02
036	0503013357	3/8 SELF-ADJUSTING NUT		02
037	0503010140	1/8" X 3/4" SPLIT PIN		04
038	0551019159	LEVER FIXER BODY		02
039	0561016468	FASTENER		02
040	0503011336	1/2" HEX SELF ADJUSTING NUT		04
041	0551019115	LOCKING PLATFORM FIXATION		02
042	0501010096	3/8" X 2" BOLT		02
043	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02




Item	Code	Description	See page	QT
001	0521065561	FERTILIZER BEAN RIGHT SUPPORT		01
002	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	53	04
003	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	54	02
004	0511061759	22Z P12,70 FQ 3/4" GEAR		01
005	0521014167	CONE LOCK		01
006	0503030275	AGRICULTURAL BEARING		06
007	1902010685	18Z CONICAL GEAR		06
008	0521010691	AXLE FASTENER		02
009	0501010694	FLAT WASHER		04
010	0503011441	SPRING WASHER		02
011	0503010144	1/4" NUT		02
012	0501110392	HOPPER SUPPORT BEARING		01
013	0551018055	22,65 X 60 SLEEVE		01
014	0571012299	SQUARE SHAFT		01
015	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
016	0521012485	GEAR BOX BEARING AGRICUTURAL		01
017	0503011953	5/16" X 1" BOLT		02
018	0521011039	FLAT WASHER		02
019	0503011444	SPRING WASHER		02
020	0503010337	5/16" NUT		02
021	0503010003	1845 GREASE FITTING		01
022	0501010942	3/8" X 1-1/4" BOLT		24
023	0503011443	3/8" SPRING WASHER		24
024	0503010026	3/8" NUT		24




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" SPLIT PIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01



Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" SPLIT PIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01



Item	Code	Description	See page	QT
001	0521065562	LH FERTILIZER BOX SUPPORT		01
002	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	54	04
003	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	53	02
004	0571012299	SQUARE SHAFT		01
005	0501010942	3/8" X 1-1/4" BOLT		24
006	0503011443	3/8" SPRING WASHER		24
007	0503010026	3/8" NUT		24
008	0511061759	22Z P12,70 FQ 3/4" GEAR		01
009	0521014167	CONE LOCK		01
010	0503030275	AGRICULTURAL BEARING		06
011	1902010685	18Z CONICAL GEAR		06
012	0521010691	AXLE FASTENER		02
013	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
014	0501010694	FLAT WASHER		04
015	0503011441	SPRING WASHER		02
016	0503010144	1/4" NUT		02
017	0501110392	HOPPER SUPPORT BEARING		01
018	0521012485	GEAR BOX BEARING AGRICUTURAL		01
019	0503011953	5/16" X 1" BOLT		02
020	0521011039	FLAT WASHER		02
021	0503011444	SPRING WASHER		02
022	0503010337	5/16" NUT		02
023	0551018055	22,65 X 60 SLEEVE		01
024	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
001	0511051932	RH BEAM SUPPORT	57	01
002	0511051933	LH BEAM SUPPORT	58	01
003	0503010849	3/8" X 1-1/2" BOLT		28
004	0501010984	10,50 X 27 X 3,00 FLAT WASHER		60
005	0503010025	3/8 SPRING WASHER		28
006	0503010026	3/8" NUT		28
007	0503062018	ASSEMBLED FERTILIZER HOPPER		02
008	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		02
009	0503010362	1/8" X 1.1/4" SPLIT PIN		14
010	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		08
011	0551019156	GEAR BOX LEVER LOCK		02
012	0503011953	5/16" X 1" BOLT		04
013	0501010694	FLAT WASHER		04
014	0503010847	1/2" X 3.1/4" BOLT		02
015	0551019168	SLEEVE		02
016	0551019160	LEVER		02
017	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
018	0503010060	1/2 UNC G.5 ZN HEX NUT		04
019	0551019167	SLEEVE UNION		02
020	0511069676	INNER LEVER		02
021	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
022	0501013518	FLAT WASHER		02
023	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
024	0503010337	5/16" NUT		04
025	0503010019	1/2" SPRING WASHER		04
026	0503013357	3/8 SELF-ADJUSTING NUT		02
027	0501010096	3/8" X 2" BOLT		02
028	0551019115	LOCKING PLATFORM FIXATION		02
029	0503011336	1/2" HEX SELF ADJUSTING NUT		04
030	0511069679	RH UPPER LEVER		02
031	0503010140	1/8" X 3/4" SPLIT PIN		06




SET FERTILIZER SILO

0511056792


Item	Code	Description	See page	QT
032	0511069678	LH LOWER LEVER		01
033	0511069677	RH LOWER LEVER		01
034	0561016468	FASTENER		02
035	0503034396	FERTILIZER SIDE COVER		14



Item	Code	Description	See page	QT
01	0521063171	RH FERTILIZER BOX SUPPORT		01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	53	04
03	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	54	03
04	0501010942	3/8" X 1-1/4" BOLT		28
05	0503011443	3/8" SPRING WASHER		28
06	0503010026	3/8" NUT		28
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571011428	SQUARE SHAFT		01
09	0501053788	3/4" SQUARE AXLE FASTENER		02
09.	0503010144	1/4" NUT		01
09A	0521010691	AXLE FASTENER		01
09B	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
09C	0511017303	FLAT WASHER		02
09D	0503010143	1/4" SPRING WASHER		01
10	0501110392	HOPPER SUPPORT BEARING		01
11	0521012485	GEAR BOX BEARING AGRICUTURAL		01
12	0503011953	5/16" X 1" BOLT		02
13	0501010694	FLAT WASHER		02
14	0503011444	SPRING WASHER		02
15	0503010337	5/16" NUT		02
16	0551018055	22,65 X 60 SLEEVE		01
17	0503010003	1845 GREASE FITTING		01
18	0521014167	CONE LOCK		01
19	0503030275	AGRICULTURAL BEARING		07
20	0503030303	SUPPORT WASHER		01
21	1902010685	18Z CONICAL GEAR		07




Item	Code	Description	See page	QT
001	0521063172	LH FERTILIZER BOX SUPPORT		01
002	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	53	03
003	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	54	04
004	0501010942	3/8" X 1-1/4" BOLT		28
005	0503011443	3/8" SPRING WASHER		28
006	0503010026	3/8" NUT		28
007	0511061759	22Z P12,70 FQ 3/4" GEAR		01
008	0571011428	SQUARE SHAFT		01
009	0501053788	3/4" SQUARE AXLE FASTENER		02
009A	0521010691	AXLE FASTENER		01
009B	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
009C	0511017303	FLAT WASHER		02
009D	0503010143	1/4" SPRING WASHER		01
009E	0503010144	1/4" NUT		01
010	0501110392	HOPPER SUPPORT BEARING		01
011	0521012485	GEAR BOX BEARING AGRICUTURAL		01
012	0503011953	5/16" X 1" BOLT		02
013	0501010694	FLAT WASHER		02
014	0503011444	SPRING WASHER		02
015	0503010337	5/16" NUT		02
016	0551018055	22,65 X 60 SLEEVE		01
017	0503010003	1845 GREASE FITTING		01
018	0521014167	CONE LOCK		01
019	0503030275	AGRICULTURAL BEARING		07
020	0503030303	SUPPORT WASHER		01
021	1902010685	18Z CONICAL GEAR		07




Item	Code	Description	See page	QT
001	0511056350	RH BEAM SUPPORT PST DUO/F 11E500	60	01
002	0511056351	LH BEAM SUPPORT PST DUO/F 11E500	62	01
003	0503010849	3/8" X 1-1/2" BOLT		12
004	0501010984	10,50 X 27 X 3,00 FLAT WASHER		24
005	0503010025	3/8 SPRING WASHER		12
006	0503010026	3/8" NUT		12
007	0503034396	FERTILIZER SIDE COVER		12
008	0503010362	1/8" X 1.1/4" SPLIT PIN		12
009	0503060642	COVER BOX RIGHT FERTILIZER		02
009.	0503060643	COVER BOX LEFT FERTILIZER		02
010	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
011	0503010849	3/8" X 1-1/2" BOLT		08
012	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
013	0503010025	3/8 SPRING WASHER		08
014	0503010026	3/8" NUT		08
015	0551019156	GEAR BOX LEVER LOCK		02
016	0503011953	5/16" X 1" BOLT		04
017	0501010694	FLAT WASHER		04
018	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
019	0503010337	5/16" NUT		04
020	0503010847	1/2" X 3.1/4" BOLT		02
021	0551019168	SLEEVE		02
022	0551019160	LEVER		02
023	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
024	0503010019	1/2" SPRING WASHER		02
025	0503010060	1/2 UNC G.5 ZN HEX NUT		02
026	0551019167	SLEEVE UNION		02
027	0511069676	INNER LEVER		02
028	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
029	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
030	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02


Item	Code	Description	See page	QT
031	0503010019	1/2" SPRING WASHER		02
032	0503010060	1/2 UNC G.5 ZN HEX NUT		02
033	0501013518	FLAT WASHER		02
034	0503010140	1/8" X 3/4" SPLIT PIN		02
035	0511069678	LH LOWER LEVER		02
036	0503013357	3/8 SELF-ADJUSTING NUT		02
037	0503010140	1/8" X 3/4" SPLIT PIN		04
038	0551019159	LEVER FIXER BODY		02
039	0561016468	FASTENER		02
040	0503011336	1/2" HEX SELF ADJUSTING NUT		04
041	0551019115	LOCKING PLATFORM FIXATION		02
042	0501010096	3/8" X 2" BOLT		02
043	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02




Item	Code	Description	See page	QT
001	0521065374	RH FERTILIZER BEAN SUPPORT PST DUO/F 11E500		01
002	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	53	04
003	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	54	02
004	0511061759	22Z P12,70 FQ 3/4" GEAR		01
005	0521014167	CONE LOCK		01
006	0503030275	AGRICULTURAL BEARING		06
007	1902010685	18Z CONICAL GEAR		06
008	0521010691	AXLE FASTENER		02
009	0501010694	FLAT WASHER		04
010	0503011441	SPRING WASHER		02
011	0503010144	1/4" NUT		02
012	0501110392	HOPPER SUPPORT BEARING		01
013	0551018055	22,65 X 60 SLEEVE		01
014	0571017429	SQUARE SHAFT		01
015	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
016	0521012485	GEAR BOX BEARING AGRICUTURAL		01
017	0503011953	5/16" X 1" BOLT		02
018	0521011039	FLAT WASHER		02
019	0503011444	SPRING WASHER		02
020	0503010337	5/16" NUT		02
021	0503010003	1845 GREASE FITTING		01
022	0501010942	3/8" X 1-1/4" BOLT		24
023	0503011443	3/8" SPRING WASHER		24
024	0503010026	3/8" NUT		24




Item	Code	Description	See page	QT
001	0521063405	RH BEAM SUPPORT		01
002	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	53	04
003	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	54	02
004	0501010942	3/8" X 1-1/4" BOLT		24
005	0503011443	3/8" SPRING WASHER		24
006	0503010026	3/8" NUT		24
007	0511061759	22Z P12,70 FQ 3/4" GEAR		01
008	0521014167	CONE LOCK		01
009	0503030275	AGRICULTURAL BEARING		06
010	1902010685	18Z CONICAL GEAR		06
011	0571012299	SQUARE SHAFT		01
012	0521010691	AXLE FASTENER		02
013	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
014	0501010694	FLAT WASHER		02
015	0503011441	SPRING WASHER		02
016	0503010144	1/4" NUT		02
017	0501110392	HOPPER SUPPORT BEARING		01
018	0521012485	GEAR BOX BEARING AGRICUTURAL		01
019	0503011953	5/16" X 1" BOLT		02
020	0501010694	FLAT WASHER		02
021	0521011039	FLAT WASHER		02
022	0503011444	SPRING WASHER		02
023	0503010337	5/16" NUT		02
024	0551018055	22,65 X 60 SLEEVE		01
025	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
001	0521065375	LH FERTILIZER BEAM SUPPORT		01
002	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	53	04
003	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	54	02
004	0571017426	HEX AXLE		01
005	0501010942	3/8" X 1-1/4" BOLT		24
006	0503011443	3/8" SPRING WASHER		24
007	0503010026	3/8" NUT		24
008	0511061759	22Z P12,70 FQ 3/4" GEAR		01
009	0521014167	CONE LOCK		01
010	0503030275	AGRICULTURAL BEARING		06
011	1902010685	18Z CONICAL GEAR		06
012	0521010691	AXLE FASTENER		02
013	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
014	0501010694	FLAT WASHER		04
015	0503011441	SPRING WASHER		02
016	0503010144	1/4" NUT		02
017	0501110392	HOPPER SUPPORT BEARING		01
018	0521012485	GEAR BOX BEARING AGRICUTURAL		01
019	0503011953	5/16" X 1" BOLT		02
020	0521011039	FLAT WASHER		02
021	0503011444	SPRING WASHER		02
022	0503010337	5/16" NUT		02
023	0551018055	22,65 X 60 SLEEVE		01
024	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
001	0521063406	LH BEAM SUPPORT		01
002	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	53	02
003	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	54	04
004	0501010942	3/8" X 1-1/4" BOLT		24
005	0503011443	3/8" SPRING WASHER		24
006	0503010026	3/8" NUT		24
007	0511061759	22Z P12,70 FQ 3/4" GEAR		01
008	0521014167	CONE LOCK		01
009	0503030275	AGRICULTURAL BEARING		06
010	1902010685	18Z CONICAL GEAR		06
011	0571012299	SQUARE SHAFT		01
012	0521010691	AXLE FASTENER		02
013	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
014	0501010694	FLAT WASHER		02
015	0503011441	SPRING WASHER		02
016	0503010144	1/4" NUT		02
017	0501110392	HOPPER SUPPORT BEARING		01
018	0521012485	GEAR BOX BEARING AGRICUTURAL		01
019	0503011953	5/16" X 1" BOLT		02
020	0501010694	FLAT WASHER		02
021	0521011039	FLAT WASHER		02
022	0503011444	SPRING WASHER		02
023	0503010337	5/16" NUT		02
024	0551018055	22,65 X 60 SLEEVE		01
025	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
001	0511069661	PLATFORM SUPPORT PIVOT	04	
002	0503010849	3/8" X 1-1/2" BOLT	08	
003	0501010984	10,50 X 27 X 3,00 FLAT WASHER	16	
004	0503010025	3/8 SPRING WASHER	08	
005	0503010026	3/8" NUT	08	
006	0521062991	RIGHT PLATFORM	01	
007	0521062992	LEFT PLATFORM PST DUO 11/F	01	
008	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
009	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
010	0503011333	COVER FIXER	02	
011	0503010274	5/32" X 2" SPLIT PIN	02	
012	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
013	0502012739	PLATFORM LEFT FIXER SUPPORT	01	
014	0571017990	PLATFORM ENHANCEMENT PROTECTION	01	
015	0501010942	3/8" X 1-1/4" BOLT	02	
016	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
017	0503010025	3/8 SPRING WASHER	02	
018	0503010026	3/8" NUT	02	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT		04
02	0503010849	3/8" X 1-1/2" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		18
04	0503010025	3/8 SPRING WASHER		10
05	0503010026	3/8" NUT		10
06	0521063178	RIGHT PLATFORM		01
07	0521063179	LEFT PLATFORM PST DUO 13/F		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		04
09	0503011333	COVER FIXER		02
10	0503010274	5/32" X 2" SPLIT PIN		02
11	0571017990	PLATFORM ENHANCEMENT PROTECTION		01
12	0501010942	3/8" X 1-1/4" BOLT		02
13	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
14	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
15	0502012739	PLATFORM LEFT FIXER SUPPORT		01




Item	Code	Description	See page	QT
001	0511069661	PLATFORM SUPPORT PIVOT		04
002	0503010849	3/8" X 1-1/2" BOLT		08
003	0501010984	10,50 X 27 X 3,00 FLAT WASHER		18
004	0503010025	3/8 SPRING WASHER		10
005	0503010026	3/8" NUT		10
006	0521065381	RIGHT PLATFORM PST DUO/F 11 E500 S-0614		01
007	0521065382	LEFT PLATFORM PST DUO/F 11 E500 S-0614		01
008	0503011336	1/2" HEX SELF ADJUSTING NUT		04
009	0503011333	COVER FIXER		02
010	0503010274	5/32" X 2" SPLIT PIN		02
011	0571017990	PLATFORM ENHANCEMENT PROTECTION		01
012	0501010942	3/8" X 1-1/4" BOLT		02
013	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
014	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
015	0502012739	PLATFORM LEFT FIXER SUPPORT		01




Item	Code	Description	See page	QT
001	0521062988	HANDRAIL		02
002	0503014007	1/2" X 1-1/4" BOLT		04
003	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
004	0503010905	1/2" X 2-1/4" BOLT		02
005	0503010019	1/2" SPRING WASHER		08
006	0503010060	1/2 UNC G.5 ZN HEX NUT		08
007	0503034094	22 TWISTED CHAIN		02
008	0571017991	CHAIN FIXER HANDRAIL		04
009	0551019884	45 X 50 X 3/8 FASTENER		04
010	0503013357	3/8 SELF-ADJUSTING NUT		08



Item	Code	Description	See page	QT
001	0521065384	HANDRAIL		02
002	0503014007	1/2" X 1-1/4" BOLT		04
003	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
004	0503010905	1/2" X 2-1/4" BOLT		02
005	0503010019	1/2" SPRING WASHER		08
006	0503010060	1/2 UNC G.5 ZN HEX NUT		08
007	0503034094	22 TWISTED CHAIN		02
008	0571017991	CHAIN FIXER HANDRAIL		04
009	0551019884	45 X 50 X 3/8 FASTENER		04
010	0503013357	3/8 SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
001	0521063175	HANDRAIL		02
002	0503014007	1/2" X 1-1/4" BOLT		04
003	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
004	0503010905	1/2" X 2-1/4" BOLT		02
005	0503010019	1/2" SPRING WASHER		08
006	0503010060	1/2 UNC G.5 ZN HEX NUT		08
007	0503034094	22 TWISTED CHAIN		02
008	0571017991	CHAIN FIXER HANDRAIL		04
009	0551019884	45 X 50 X 3/8 FASTENER		04
010	0503013357	3/8 SELF-ADJUSTING NUT		08



Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8 SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
08	0503013357	3/8 SELF-ADJUSTING NUT	02	

HEADER ASSY

0909094295




Item	Code	Description	See page	4880	5340	5950	6850
01	0521065557	CABEÇALHO		001	001	001	001
02	0511054601	HITCH ARTICULATED TRACTOR	72	001	001	001	001
03	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		001	001	001	001
04	0511053179	TRACTOR COUPLING SHAFT		001	001	001	001
04A	0521064036	TRACTOR HITCH AXLE		001	001	001	001
04B	0503030012	HITCH PIN CLIP		001	001	001	001
05	0521063529	LOCK AXLE		001	001	001	001
06	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		001	001	001	001
07	0503010010	1/4" X 2.1/2" SPLIT PIN		001	001	001	001
08	0521063528	EXTENDING FIXER		001	001	001	001
09	0521062916	LEFT FRENCH HAND		001	001	001	001
10	0501010171	BOLT 1 UNC X 3.1/2 C S G.5		002	002	002	002
11	0503010012	1" SPRING WASHER		002	002	002	002
12	0501010059	1.5/8 NUT		002	002	002	002
13	0521010585	0.9" X 5.9" COUPLING SHAFT		001	001	001	001
14	0503030085	LOCK PIN		001	001	001	001
15	0521064203	EAR PIVOT DRAWBAR		001	001	001	001
16	0571010661	PIVOT SHAFT		001	001	001	001
17	0503010010	1/4" X 2.1/2" SPLIT PIN		001	001	001	001
18	0521053311	RIGHT EXTENSOR DRAWBAR 36,00 - 4880/5720/5950	-	001	000	001	000
18.	0521053312	RIGHT EXTENSOR DRAWBAR 36,00 - 5340		000	001	000	000
18..	0521053319	RIGHT EXTENSOR DRAWBAR 36,00 - 6850		000	000	000	001
19	0521053310	LEFT EXTENSION DRAWBAR 36.00 - 4880/5720/5950	-	001	000	001	000
19.	0521053313	LEFT EXTENSION DRAWBAR 36.00 - 5340		000	001	000	000
19..	0521053318	LEFT EXTENSION DRAWBAR 36.00 - 6850		000	000	000	001
20	0501010500	3/4" X 3" BOLT		002	002	002	002
21	0503010023	3/4" SPRING WASHER		002	002	002	002
22	0503010014	3/4" HEX NUT		002	002	002	002
23	0571019949	JUNCTION SHAFT		002	002	002	002
24	0503030119	LOCK PIN		002	002	002	002




HEADER ASSY

0909094295

Item	Code	Description	See page	4880	5340	5950	6850
25	0521010572	0.9" X 2.9" COUPLING SHAFT		001	001	001	001
26	0503030085	LOCK PIN		003	003	003	003
27	0511052311	3 POINT TURNBUCKLE	75	001	001	001	001
28	0521012532	0.9" X 3.9" COUPLING SHAFT		001	001	001	001
29	0521010582	COUPLING SHAFT		001	001	001	001
30	0511056736	HOSE SUPPORT		001	001	001	001




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2" SPLIT PIN		01
10	0503033731	LEFT COMPRESSION SPRING		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521064425	POINT FIXER EXTENDING RIGHT		01
02	0501078990	TURNBUCKLE AXLE		01
03	0561019879	LOCK ATTACHMENT BAR		01
04	0521063917	POINT REVOLVING EXTENDING		01
05	0503010002	1800 GREASE FITTING		02

LEFT TURNBUCKLE


0511054328



Item	Code	Description	See page	QT
01	0521064426	POINT FIXER EXTENDING LEFT		01
02	0501078990	TURNBUCKLE AXLE		01
03	0561019879	LOCK ATTACHMENT BAR		01
04	0521063917	POINT REVOLVING EXTENDING		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0571012279	JACK RIGHT		01
03	0571012280	JACK LEFT		01
04	0531010264	SIDE RATCHET		02
05	0521018500	SHAFT LEVER EXTENSOR		01
06	0511061881	RATCHET FOLLOWER		01
07	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
08	0503011179	3/8" X 2-1/4" BOLT		05
09	0503010025	3/8 SPRING WASHER		05
10	0503010026	3/8" NUT		05
11	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0571017027	VALVE SUPPORT	01	
02	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT	02	
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN	02	
04	0503010019	1/2" SPRING WASHER	02	
05	0503010060	1/2 UNC G.5 ZN HEX NUT	02	
06	0501054452	FLOW DIVIDING VALVE	01	
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN	02	
08	0503010143	1/4" SPRING WASHER	02	
09	0503010144	1/4" NUT	02	
10	0541012166	NIPPLE 3/4" UNF X 7/8"	01	
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT	01	
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT	01	
13	0501053834	MALE QUICK COUPLER	02	
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM	02	
15	0571017774	SPRING PROTECTION QUICK HOSE	02	
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN	03	
17	0503010180	7/16" SPRING WASHER	03	
18	0502012702	BODY SUPPORT CLAMP	03	
19	0511057089	HOSE KIT SYSTEM HYDRAULIC	01	
19A	0501080045	3/8" X 850 TR-TR HOSE	01	
19B	0501080999	3/8" X 39" TC-TC HOSE	01	
19C	0501081987	HOSE 3/8 X 1550 TR-TC	01	
19D	0501081986	HOSE 3/8 X 1550 TC-TC	01	
19E	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED	01	
19EA	0501080185	HOSE 1/2 X 4000 TR-TM	01	
19EB	0503034492	HYDRAULIC HOSE GRIP (BLACK)	01	
19EC	0503034495	HYDRAULIC HOSE GRIP (RED)	01	
19ED	0503018952	PLASTIC BOLT	06	
19F	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE	01	
19FA	0501080185	HOSE 1/2 X 4000 TR-TM	01	
19FB	0503034492	HYDRAULIC HOSE GRIP (BLACK)	01	




Item	Code	Description	See page	QT
19FC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
19FD	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0571017027	VALVE SUPPORT	01	
02	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT	02	
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN	02	
04	0503010019	1/2" SPRING WASHER	02	
05	0503010060	1/2 UNC G.5 ZN HEX NUT	02	
06	0501054694	COMPLETE FLOW DIVIDER VALVE	01	
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN	02	
08	0503010143	1/4" SPRING WASHER	02	
09	0503010144	1/4" NUT	02	
10	0541012166	NIPPLE 3/4" UNF X 7/8"	01	
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT	01	
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT	01	
13	0501053834	MALE QUICK COUPLER	02	
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM	02	
15	0571017774	SPRING PROTECTION QUICK HOSE	01	
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN	03	
17	0503010180	7/16" SPRING WASHER	03	
18	0502012702	BODY SUPPORT CLAMP	03	
19	0511057104	HOSE KIT SYSTEM HYDRAULIC	01	
19A	0501080104	3/8 X 900 TR-TR HOSE	01	
19B	0501080963	3/8 X 1050 TC-TC 90G LEFT OSE	01	
19C	0501080714	3/8 X 1600 TR-TC HOSE	01	
19D	0501081994	3/8 X 1600 TC-TC 180G HOSE	01	
20	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED	01	
20A	0501080185	HOSE 1/2 X 4000 TR-TM	01	
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)	01	
20C	0503034495	HYDRAULIC HOSE GRIP (RED)	01	
20D	0503018952	PLASTIC BOLT	06	
21	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE	01	
21A	0501080185	HOSE 1/2 X 4000 TR-TM	01	
21B	0503034492	HYDRAULIC HOSE GRIP (BLACK)	01	

Item	Code	Description	See page	QT
21C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21D	0503018952	PLASTIC BOLT		06
22	0503013100	NYLON CLAMP		02




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	79	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" SPLIT PIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	80	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
23	0503010025	3/8 SPRING WASHER		02
24	0511057090	HYDRAULIC MARKER HAND SET		01
24A	0501081728	HOSE 3/8 X 3100 TR-TR		01
24B	0501080392	3/8 X 3300 TR-TC HOSE		01
24C	0501081988	3/8" X 145.6" TR-TC HOSE		01
24D	0501081682	TC-TC HOSE ASSY		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01


Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER		02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8" UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04



Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	79	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" SPLIT PIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	80	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
23	0503010025	3/8 SPRING WASHER		02
24	0511057101	HYDRAULIC MARKER HANDLE SET		01
24A	0501081330	HOSE		01
24B	0501081718	HOSE		01
24C	0501081799	HOSE		01
24D	0501081995	HOSE		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER		02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8" UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	79	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" SPLIT PIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	80	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
23	0503010025	3/8 SPRING WASHER		02
24	0511057091	HYDRAULIC MARKER HANDLE SET		01
24A	0501081793	HOSE		01
24B	0501081967	3/8" X 151" TR-TC HOSE		01
24C	0501081996	HOSE		01
24D	0501081997	HOSE		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01


Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER		02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8" UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
001	0503060100	INSTRUCTIONS MANUAL CANISTER		01
002	0511031808	BAG WITH MANUAL		01
003	0503010267	NYLON CLAMP		01
004	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
005	0501010694	FLAT WASHER		01
006	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
007	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0511059790	CSU C3 SET - 02 HOPPERS 06 NOZZLES - 08 CONDUCTORS		01
02	0521066208	HOPPER SUPPORT TOWER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
05	0503010025	3/8 SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0501010453	FLAT WASHER		08
10	0503012412	5/8" UNC SELF LOCKING NUT		08




Item	Code	Description	See page	QT
01	0511059584	2 HOPPERS WITH 10 CONDUCTORS SET		01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RIGHT SUPPORT TOWER WITH BOLT		01
07	0521051931	LEFT SUPPORT TOWER WITH BOLT		01
08	0521051927	TOWER SUPPORT HOPPER		02




Item	Code	Description	See page	QT
01	0511057919	2 HOPPERS WITH 11 CONDUCTORS SET		01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RIGHT SUPPORT TOWER WITH BOLT		01
07	0521051931	LEFT SUPPORT TOWER WITH BOLT		01
08	0521051927	TOWER SUPPORT HOPPER		02



Item	Code	Description	See page	QT
01	0511058724	2 HOPPERS WITH 12 CONDUCTORS ASSEMBLY	01	
02	0501010942	3/8" X 1-1/4" BOLT	08	
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER	08	
04	0503010025	3/8 SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0521051931	LEFT SUPPORT TOWER WITH BOLT	02	
07	0521051927	TOWER SUPPORT HOPPER	02	




Item	Code	Description	See page	QT
001	0511058802	2 HOPPERS WITH 13 CONDUCTORS ASSEMBLY		01
002	0521066208	HOPPER SUPPORT TOWER		04
003	0501010942	3/8" X 1-1/4" BOLT		08
004	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
005	0503010025	3/8 SPRING WASHER		08
006	0503010026	3/8" NUT		08
007	0502010175	HITCH CLAMP		04
008	0501011543	5/8" X 4" BOLT		08
009	0501010453	FLAT WASHER		08
010	0503012412	5/8" UNC SELF LOCKING NUT		08



Item	Code	Description	See page	QT
01	0501059834	LEFT SHORT SEED ROW FRONT	91	01
02	0501059833	RIGHT SHORT SEED ROW FRONT	92	01
03	0501059835	RIGHT LONG SEED ROW FRONT	93	01
04	0501059836	LEFT LONG SEED ROW FRONT	94	01
05	0511056621	RIGHT REAR SEED ROW	98	01
06	0511056622	LEFT REAR SEED ROW	99	01
07	0511056608	TITANIUM SEED SYSTEM	105	01
07.	0521050096	SEED HOPPER SYSTEM (CSU)	106	01
08	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	107	01
09	0521044269	PRESS WHEELS/DEPTH ASSY	118	01
10	0521044460	SYSTEM DEPTH / COMPACTOR	126	01
11	0521046501	DEPTH CONTROL AND PRESS WHEEL WITH FAST ADJUSTING	130	01
12	0511059350	FERTILIZER ROW SUPPORT ASSEMBLY	136	01
13	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	137	01
14	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	139	01
15	0501058423	FERTILIZER ROD SPRING ROW	141	01
16	0511058619	20" SHORT ROW DISC BLADE	142	01
17	0511058617	DISC CUT 18 SHORT LINE	143	01
18	0511058620	20" LONG ROW DISC BLADE	145	01
19	0511058618	DISC CUT 18 LONG LINE	146	01
20	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	138	01
21	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	140	01
22	0503031145	2" X 2" X 20" HOSE		01
23	0503010246	CLAMP		02
24	0501010066	3/4" X 9" BOLT		01
25	0521017831	SUPPORT SLEEVE SPACER		01
26	0511017232	FLAT WASHER		01
27	0503011255	3/4" LOCK NUT		01
28	0503030391	RIGHT FERTILIZER NOZZLE		01


Item	Code	Description	See page	QT
29	0503030392	LEFT FERTILIZER NOZZLE		01
30	0503031050	CURVED CONDUCTOR		01
31	0503010246	CLAMP		01
32	0503031145	2" X 2" X 20" HOSE		01
33	0503031076	2" HOSE CLAMP		01
34	0503010905	1/2" X 2-1/4" BOLT		02
35	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
36	0503010019	1/2" SPRING WASHER		04
37	0503010060	1/2 UNC G.5 ZN HEX NUT		04
38	0531013600	PRESS ADJUSTMENT LEVER		01
39	0511059410	HDA BC	151	01
40	0581010082	FERTILIZER SOCKET RIGHT		01
41	0581010083	FERTILIZER SOCKET LEFT		01
42	0521018501	TURNBUCKLE LEVER		01
43	0501110723	SCARIFIER ROD		01
44	0501110714	INNER SOCKET FASTENER		01



Item	Code	Description	See page	QT
01	0521064651	LEFT SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY		02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION HOPPER SEED ROW		01
12	0561014904	TRANSMISSION AXLE FRAME ROW		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	97	01
14	0511055260	SEED ROW CHAIN TENSIONER		01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521061427	SHORT SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" SPLIT PIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" SPLIT PIN		01
31	0503034580	TRACTION SPRING		02




Item	Code	Description	See page	QT
32	0511059264	BEARING WITH AXLE	96	01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04



Item	Code	Description	See page	QT
01	0521064653	RIGH SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY		02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION HOPPER SEED ROW		01
12	0561014904	TRANSMISSION AXLE FRAME ROW		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	97	01
14	0511055260	SEED ROW CHAIN TENSIONER		01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521061427	SHORT SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" SPLIT PIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" SPLIT PIN		01
31	0503034580	TRACTION SPRING		02




Item	Code	Description	See page	QT
32	0511059264	BEARING WITH AXLE	96	01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04



Item	Code	Description	See page	QT
01	0521064652	RH SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY		02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION HOPPER SEED ROW		01
12	0561014904	TRANSMISSION AXLE FRAME ROW		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	97	01
14	0511055260	SEED ROW CHAIN TENSIONER		01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521061427	SHORT SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" SPLIT PIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" SPLIT PIN		01
31	0503034580	TRACTION SPRING		02




Item	Code	Description	See page	QT
32	0511059264	BEARING WITH AXLE	96	01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064650	LEFT SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8" UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	FLAT WASHER	04	
08	0503010179	LOCK WASHER 5/16 ZN 1K01528	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION HOPPER SEED ROW	01	
12	0561014904	TRANSMISSION AXLE FRAME ROW	01	
13	0501052769	BEARING WITH 17Z GEAR	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEED ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521061427	SHORT SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" SPLIT PIN	01	
27	0503030168	HITCH PIN CLIP	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" SPLIT PIN	01	
31	0503034580	TRACTION SPRING	02	




Item	Code	Description	See page	QT
32	0511059264	BEARING WITH AXLE	96	01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0502040857	CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503010003	1845 GREASE FITTING		01
13	0503011409	6005 Z BALL BEARING		01
14	0503017008	SEAL RING		01
15	0503017007	SEAL RING		02
16	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0501059326	UNIVERSAL JOINT AXLE		01
02	0503010071	3/16" X 1" SPLIT PIN		01
03	0511050611	5/8" HEX AXLE BEARING		01




Item	Code	Description	See page	QT
01	0511050617	FRONT SEED ROW BEARING		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0502012819	17Z GEAR WITH HEX HOLE		01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503011443	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	100	01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503011443	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511056586	15 X 15 SEED DDD LEFT	101	01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	102	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	104	01
03	0511053172	LEFT LOW HUB WITH 15 DISC	103	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE		01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	104	01
03	0511053172	LEFT LOW HUB WITH 15 DISC	103	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUBLE DISC AXLE		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0511052058	SEED SYSTEM TITANIUM		01
01A	0503062031	BASE SET		01
01B	0503062032	NECK TITANIUM ASSY		01
01C	0503062033	OPPOSITE BASE SET		01
01D	0503062034	CENTRAL ADAPTER SET		01
01E	0503062035	SET FALSE ADAPT CENTER		01
01F	0503062036	SUBSET ASSY LOCK BASE		01
01G	0503062037	SUBSET ESCOVAFLEX ASSY		01
01H	0503062038	ASSY ANTI-LEAP		01
01I	0503062039	POLIFLOW TITANIUM ASSY		01
01J	0503062040	DISPLAY ASSY TITANIUM 1050010		01
01K	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
01L	0503062042	SET BOLT ARTICULADOR		01
01M	0503062043	ASSY LIMIT WEIGHT		01
02	0503062276	ASSY SEED DEPOSIT		01
03	0503010371	5/16" X 1" BOLT		05
04	0501010694	FLAT WASHER		05
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
06	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0521050118	3" NOZZLE SEED HOPPER		01
02	0581014295	FIXING SLEEVE		01
03	0511052058	SEED SYSTEM TITANIUM		01
04	0503010358	5/16" X 5/8" BOLT		05
05	0501010694	FLAT WASHER		05
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
07	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	108	01
02	0501052538	DEPTH BAND WITH ARMS	113	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING		01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING		01
07	0503033942	COMPACTOR WHEEL REGULATOR LID		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT DEPTH WHEEL ARM WITH HUB	109	01
07	0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	110	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	111	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" SPLIT PIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	3/8 UNC X 3/4 BOLT		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL HUB	112	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL HUB	112	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" SPLIT PIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	PROTECTION LID		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05



Item	Code	Description	See page	QT
01	0501056269	SUPPORT WHEEL ASSY CONCAVE RIGHT	115	01
02	0531017413	LEFT FORK CONVEX PRESS VHEEL		01
03	0531017412	RIGHT FORK CONVEX PRESS VHEEL		01
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0501052501	CONVEX PRESS VHEEL	116	01
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
09	0503010019	1/2" SPRING WASHER		02
10	0503011336	1/2" HEX SELF ADJUSTING NUT		02
11	0503010479	BOLT		02
12	0503010019	1/2" SPRING WASHER		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0502012121	RIGHT ARM CONVEX PRESS WHEELS		01
02	0503030883	RIGHT TORSION SPRING		01
03	0502011066	PRESS WHEELS ARM SUPPORT		01
04	0531017415	1" X 4.72" AXLE JOINT		01
05	0503010839	03"X 0.6" SPRING PIN		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502020600	MARKER ARM DISC HUB	02	
02	0503010272	SEAL 00715-BA	02	
03	0503010690	6204 BALL BEARING	02	
04	0501015883	COMPACT WHEEL AXLE	01	
05	0503030143	3.3" X 1.9" X 0.1" JOINT	02	
06	0503010691	1/4" GREASE FITTING	02	
07	0501014071	RIM SEMI	02	
08	0503010743	1/4" X 1-1/4" BOLT	05	
09	0503010143	1/4" SPRING WASHER	05	
10	0503010144	1/4" NUT	05	
11	0503030240	DEPTH CONTROL WHEEL RUBBER BAND	01	
12	0503013758	1/4" X 1-1/2" BOLT	05	
13	0503010143	1/4" SPRING WASHER	05	
14	0503010144	1/4" NUT	05	

MOTOR SHAFT ASSEMBLY


0511053341



Item	Code	Description	See page	QT
01	0561017269	MOTOR AXLE BEARING SUPPORT		04
02	0503011082	C1/2" X 1.3/4" SCREW		08
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0501110639	BEARING		08
07	0503010300	5/32" X 1" SPLIT PIN		08
08	0503011099	GREASE FITTING		08
09	0561016795	2775 MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	26	01
15	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	45	01
16	0511051434	TRANSMISSION ACTUATOR	25	04
17	0503012958	2050 CHAIN X 42 LINK + REDUCTION		04




Item	Code	Description	See page	QT
01	0511055326	DEPTH CONTROL PRESS WHEEL ASSY	119	01
02	0551019650	SLEEVE 13,20 X 25 X 74		01
03	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0511055327	COMPACTING WHEEL V ASSY RUBBER	125	01




Item	Code	Description	See page	QT
01	0502012758	DEPTH CONTROL SUPPORT		01
02	0503010585	0,24" X 1.18" SPRING PIN		02
03	0503010002	1800 GREASE FITTING		01
04	0501059228	ADJUSTMENT LEVER	120	01
05	0502012611	DEPTH CONTROL AXLE		01
06	0571015326	ARTICULATION SLEEVE HANDLE		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
08	0503011443	3/8" SPRING WASHER		01
09	0503010237	3/8" X 1" BOLT		01
10	0571016132	PIVOT SHAFT		01
11	0503010071	3/16" X 1" SPLIT PIN		01
12	0561014336	PIVOT SHAFT		01
13	0503010071	3/16" X 1" SPLIT PIN		02
14	0511055328	DEPTH WHEEL SYSTEM	121	01
15	0511055329	LEFT DEPTH WHEEL	122	01

ADJUSTMENT LEVER

0501059228




Item	Code	Description	See page	QT
01	0502012603	ADJUSTMENT LEVER		01
02	0502011689	1/8" DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0511015976	FLAT WASHER		01
05	0503010140	1/8" X 3/4" SPLIT PIN		01




Item	Code	Description	See page	QT
01	0561014385	CARRYING-WHEELS PIVOT SHAFT		01
02	0501110777	RIGHT WHEEL ARM		01
03	0503010019	1/2" SPRING WASHER		01
04	0511055627	WHEEL ASSY RAYED	123	01
05	0503016453	1/2" X 2.1/2 BOLT		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	0503010002	1800 GREASE FITTING		01
08	0503030012	HITCH PIN CLIP		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
11	0501011445	FLAT WASHER		03
12	0571015974	WASHER		01
13	0503012412	5/8" UNC SELF LOCKING NUT		01
14	0503011440	SPRING WASHER		01

LEFT DEPTH WHEEL


0511055329




Item	Code	Description	See page	QT
01	0571015973	CARRYING-WHEELS PIVOT SHAFT		01
02	0503010019	1/2" SPRING WASHER		01
03	0511055627	WHEEL ASSY RAYED	123	01
04	0503016453	1/2" X 2.1/2 BOLT		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01
07	0503030012	HITCH PIN CLIP		01
08	0501110776	ARM,LEFT		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
11	0501011445	FLAT WASHER		03
12	0571015974	WASHER		01
13	0503012412	5/8" UNC SELF LOCKING NUT		01
14	0503011440	SPRING WASHER		01




Item	Code	Description	See page	QT
01	0511055626	SPREADED DEPTH WHEEL HUB	124	01
02	0551019904	PRESS WHEEL RIM		02
03	0503030891	RUBBER BAND		01
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
06	0503010337	5/16" NUT		06



Item	Code	Description	See page	QT
01	0503010269	6204 BALL BEARING		02
02	0502012607	DEPTH SPREADED WHEEL HUB		01
03	0503010689	SEAL 00763-BR		01
04	0501013636	SPACING SLEEVE		01
05	0503011105	SEAL RING		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0521019178	PROTECTION LID		01
08	0503013758	1/4" X 1-1/2" BOLT		03
09	0503011441	SPRING WASHER		03
10	0521063443	DEPTH CONTROL AXLE		01
11	0503010811	5/8" UNF SELF ADJUSTING NUT		01
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0571015324	COMPACT WHEEL RIGHT ARM		01
02	0571015325	LH ARM PRESS WHEELS		01
03	0541012145	13,5 X 25 X 18 SLEEVE		02
04	0501058362	LARGER HANDLE ASSY		01
04A	0502011689	1/8" DEPTH CONTROL LEVER		01
04B	0521064892	REGULACION SPRING COMPACTOR		01
04C	0541012146	0.53" X 0.74" X 0.33" SLEEVE		01
04D	0503030174	COMPRESSION SPRING		01
04E	0541012143	FLAT WASHER		01
04F	0503010257	1/8" X 1" SPLIT PIN		01
05	0503010479	BOLT		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01
08	0503031393	1.57" X 5.98" X 0.2" TRACTION SPRING		01
09	0501055289	HANDLE SMALLER ASSY		01
09A	0511065451	PRESS WHEEL ADJUSTER		01
09B	0511065496	PRESS WHEEL FIXER		01
09C	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
09D	0541012143	FLAT WASHER		01
09E	0503010257	1/8" X 1" SPLIT PIN		01
10	0503010397	5/16" X 1-3/4" BOLT		02
11	0541012144	8,50 X 16 X 21 SLEEVE		02
12	0503011444	SPRING WASHER		02
13	0503010337	5/16" NUT		02
14	0501052908	COMPACTOR WHEEL WITH BEARING	133	02
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503013739	1/2" X 1" BOLT		01
17	0503011440	SPRING WASHER		02




Item	Code	Description	See page	QT
01	0511055690	WHEEL SYSTEM	127	01
02	0551019650	SLEEVE 13,20 X 25 X 74		01
03	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0511055327	COMPACTING WHEEL V ASSY RUBBER	125	01

WHEEL SYSTEM


0511055690




Item	Code	Description	See page	QT
01	0502012758	DEPTH CONTROL SUPPORT		01
02	0503010585	0,24" X 1.18" SPRING PIN		02
03	0503010002	1800 GREASE FITTING		01
04	0501059228	ADJUSTMENT LEVER	120	01
05	0502012611	DEPTH CONTROL AXLE		01
06	0571015326	ARTICULATION SLEEVE HANDLE		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
08	0503011443	3/8" SPRING WASHER		01
09	0503010237	3/8" X 1" BOLT		01
10	0571016132	PIVOT SHAFT		01
11	0503010071	3/16" X 1" SPLIT PIN		01
12	0561014336	PIVOT SHAFT		01
13	0503010071	3/16" X 1" SPLIT PIN		02
14	0511055628	DEPTH WHEEL SYSTEM	128	01
15	0511055629	DEPTH WHEEL SYSTEM	129	01




Item	Code	Description	See page	QT
01	0561014385	CARRYING-WHEELS PIVOT SHAFT		01
02	0503010019	1/2" SPRING WASHER		01
03	0511055627	WHEEL ASSY RAYED	123	01
04	0503016453	1/2" X 2.1/2 BOLT		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01
07	0503030012	HITCH PIN CLIP		01
08	0501110777	RIGHT WHEEL ARM		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
11	0501011445	FLAT WASHER		03
12	0503012412	5/8" UNC SELF LOCKING NUT		01
13	0503011440	SPRING WASHER		01




Item	Code	Description	See page	QT
01	0571015973	CARRYING-WHEELS PIVOT SHAFT		01
02	0503010019	1/2" SPRING WASHER		01
03	0511055627	WHEEL ASSY RAYED	123	01
04	0503016453	1/2" X 2.1/2 BOLT		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01
07	0503030012	HITCH PIN CLIP		01
08	0501110776	ARM,LEFT		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
11	0501011445	FLAT WASHER		03
12	0503012412	5/8" UNC SELF LOCKING NUT		01
13	0503011440	SPRING WASHER		01




Item	Code	Description	See page	QT
01	0511059462	DEPTH CONTROL WITH FAST ADJUSTMENT	131	01
02	0511050077	WHEEL STRIPED	132	02
03	0503016453	1/2" X 2.1/2 BOLT		02
04	0503010019	1/2" SPRING WASHER		04
05	0503010028	1/2" NUT		02
06	0501052908	COMPACTOR WHEEL WITH BEARING	133	02
07	0503010752	1/2" X 3.1/2" BOLT		01
08	0503013739	1/2" X 1" BOLT		01




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0503010257	1/8" X 1" SPLIT PIN		01
04	0571013054	DEPTH CONTROL WHEEL AXLE		01
05	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
06	0511015346	FLAT WASHER		04
07	0501110720	ARM LEFT		01
07A	0502012726	LEFT DEPTH WHEEL ARM		01
07B	0503034375	WHEEL ARM SLEEVE		02
08	0501110719	DEPTH CONTROL RIGHT ARM		01
08A	0501110720	ARM LEFT		01
08B	0503034375	WHEEL ARM SLEEVE		02
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
10	0503011440	SPRING WASHER		04
11	0502012663	EXTENSION		01
12	0503010002	1800 GREASE FITTING		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
15	0503031393	1.57" X 5.98" X 0.2" TRACTION SPRING		01
16	0501056769	DEPTH WHEELS REGULATOR ASSY	134	01
17	0503010311	1/2" X 1-1/4" BOLT		02
18	0503010256	3/8" X 3/4" BOLT		01
19	0511059463	COMFORT WHEEL WITH FAST ADJUSTMENT	135	01




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY		01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" SPLIT PIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0521067072	COMPACT WHEEL RIGHT ARM		01
02	0521067071	COMPACT RUEDA LEFT ARM		01
03	0541012144	8,50 X 16 X 21 SLEEVE		02
04	0501055289	HANDLE SMALLER ASSY		01
04A	0511065451	PRESS WHEEL ADJUSTER		01
04B	0511065496	PRESS WHEEL FIXER		01
04C	0503031719	0.7" X 1" X 1,1" COMPRESSION SPRING		01
04D	0541012143	FLAT WASHER		01
04E	0503010257	1/8" X 1" SPLIT PIN		01
05	0511059461	COMPLETE REGULATOR		01
05A	0503030174	COMPRESSION SPRING		01
05B	0502011689	1/8" DEPTH CONTROL LEVER		01
05C	0503010257	1/8" X 1" SPLIT PIN		01
05D	0521067070	PRESS WHEEL ADJUSTER		01
05E	0511015976	FLAT WASHER		01
05F	0541012146	0.53" X 0.74" X 0.33" SLEEVE		01
06	0541012145	13,5 X 25 X 18 SLEEVE		02
07	0503010479	BOLT		01
08	0503010060	1/2 UNC G.5 ZN HEX NUT		01
09	0503011440	SPRING WASHER		01
10	0503010397	5/16" X 1-3/4" BOLT		02
11	0503011444	SPRING WASHER		02
12	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012823	DISC BLADE SUPPORT		01
02	0503034318	5/8 UNC X 2 BOLT		02
03	0503010013	5/8 NUT		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	138	01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	103	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	104	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8 SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061153	FERTILIZER ROW LONG ARM		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	140	01




Item	Code	Description	See page	QT
01	0511053173	RIGHT LOW HUB WITH 15 DISC	104	01
02	0511053172	LEFT LOW HUB WITH 15 DISC	103	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010025	3/8 SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD		01
02	0502040534	SPRING GUIDE BUSHING LOCK		02
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502012510	SPRING ROD SUPPORT		01
06	0503010257	1/8" X 1" SPLIT PIN		01
07	0501018535	1/2 X 1 BOLT		02
08	0503030678	BOLT 1/2 UNC X 1.1/2 C50P G.5 ZN		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02
10	1902010891	SPRING CHOCK SUPPORT VARON		01
11	0503010014	3/4" HEX NUT		01
12	0561014471	COUPLING SHAFT		01
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012825	DISC BLADE FIXED AXLE		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	THRUST WASHER		01
17	0503034319	LOCK PIN		01
18	0511058648	HUB WITH 20" DISC BLADE		01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0503010003	1845 GREASE FITTING		01
03	0571019976	LEFT BRACELET CUTTING DISC		01
04	0503011411	1/2" X 5-1/2" BOLT		01
05	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
06	0503011440	SPRING WASHER		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01
08	0502020394	SPRING SUPPORT		01
09	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
10	0502020393	SPRING UPPER SUPPORT		01
11	0521010452	SLEEVE		01
12	0503013185	3/4" X 5-1/2" BOLT		01
13	0501067323	SPRING REGULATOR		01
14	0511056910	HUB WITH 18" DISC BLADE		01
15	0502012825	DISC BLADE FIXED AXLE		01
16	0503011255	3/4" LOCK NUT		02
17	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
18	0581011111	THRUST WASHER		01
19	0503034319	LOCK PIN		01
20	0511056909	DISC BLADE HUB WITHOUT DISC	144	01




Item	Code	Description	See page	QT
01	0502012793	DISC HUB		01
02	0571018047	DISC BLADE HUB AXLE		01
03	0503017755	NUT		01
04	0502020641	BLADE DISC FLANGE		01
05	0503013816	5/16" LOCKNUT		06
06	0571018048	BACKREST WASHER		02
07	0521065882	NILOS SEALING RING		02
08	0571018049	DUST CLOAK		02
09	0581010575	7/8" X 145 BOLT		01
10	0503018825	5/16 UNC UNC BOLT		06
11	0501010694	FLAT WASHER		06
12	0503016061	BEARING		02
13	0511017907	1/8" BSPT X 6 PLUG		01



Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012824	DISC BLADE FIXED AXLE		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	THRUST WASHER		01
17	0503034319	LOCK PIN		01
18	0511058648	HUB WITH 20" DISC BLADE		01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0503010003	1845 GREASE FITTING		01
03	0571019976	LEFT BRACELET CUTTING DISC		01
04	0503011411	1/2" X 5-1/2" BOLT		01
05	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
06	0503011440	SPRING WASHER		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01
08	0502020394	SPRING SUPPORT		01
09	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
10	0502020393	SPRING UPPER SUPPORT		01
11	0521010452	SLEEVE		01
12	0503013185	3/4" X 5-1/2" BOLT		01
13	0501067323	SPRING REGULATOR		01
14	0511056910	HUB WITH 18" DISC BLADE		01
15	0502012824	DISC BLADE FIXED AXLE		01
16	0503011255	3/4" LOCK NUT		02
17	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
18	0581011111	THRUST WASHER		01
19	0503034319	LOCK PIN		01




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01

HEX AXLE ASSEMBLY

0909094321




Item	Code	Description	See page	QT
001	0571017425	5/8 X 2530 HEX AXLE		01
002	0571017427	5/8 X 2700 HEX AXLE		01
003	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE		02
003A	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8		01
003AA	0502011987	DOUBLE HOUSING BEARING		01
003AB	0503011410	ROLLER BEARING		02
003AC	0503011105	SEAL RING		01
003B	0511063106	20Z AXLE BEARING DOUBLE		01
003C	0503010406	501025 CLAMPING RING (FOR AXLE)		02
003D	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
003E	0501010694	FLAT WASHER		04
003F	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
003G	0503010337	5/16" NUT		02
004	0561014215	BEARING COVER LOWER ROW FRAME		02
005	0502040534	SPRING GUIDE BUSHING LOCK		04
006	0503010237	3/8" X 1" BOLT		04




Item	Code	Description	See page	QT
001	0521013430	HEX AXLE 5/8 X 2580		01
002	0521013434	HEX AXLE 5/8 X 2300		01
003	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE		02
003A	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8		01
003AA	0502011987	DOUBLE HOUSING BEARING		01
003AB	0503011410	ROLLER BEARING		02
003AC	0503011105	SEAL RING		01
003B	0511063106	20Z AXLE BEARING DOUBLE		01
003C	0503010406	501025 CLAMPING RING (FOR AXLE)		02
003D	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
003E	0501010694	FLAT WASHER		04
003F	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
003G	0503010337	5/16" NUT		02
004	0561014215	BEARING COVER LOWER ROW FRAME		02
005	0502040534	SPRING GUIDE BUSHING LOCK		04
006	0503010237	3/8" X 1" BOLT		04

HEX AXLE ASSEMBLY


0909094322




Item	Code	Description	See page	QT
001	0561018502	SHAFT AXIS 5/8 X 3000	01	
002	0571011980	5/8 X 2810 HEX AXLE	01	
003	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	02	
003A	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8	01	
003AA	0502011987	DOUBLE HOUSING BEARING	01	
003AB	0503011410	ROLLER BEARING	02	
003AC	0503011105	SEAL RING	01	
003B	0511063106	20Z AXLE BEARING DOUBLE	01	
003C	0503010406	501025 CLAMPING RING (FOR AXLE)	02	
003D	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN	02	
003E	0501010694	FLAT WASHER	04	
003F	0503010179	LOCK WASHER 5/16 ZN 1K01528	02	
003G	0503010337	5/16" NUT	02	
004	0561014215	BEARING COVER LOWER ROW FRAME	02	
005	0502040534	SPRING GUIDE BUSHING LOCK	04	
006	0503010237	3/8" X 1" BOLT	04	



Item	Code	Description	See page	QT
01	0521067063	SPRING HUB		01
02	0511059396	SCARIFIER SPINDLE WITH POINT	152	01
03	0581812084	LARGE BUSHING		01
04	0503012795	5/8" HEX SELF ADJUSTING NUT		01
05	0581812082	BOLT FIXER		01
06	0503810417	NUT		01
07	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
08	0503034106	80 X 230 X 16,50 COMPRESSSION SPRING		01
09	0503010691	1/4" GREASE FITTING		01
10	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
11	0571018541	BODY SOCKET FERTILIZER		01
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
13	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
14	0503010026	3/8" NUT		02
15	0503010025	3/8 SPRING WASHER		02
16	0503010384	1/2" X 5" BOLT		02
17	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
18	0503010547	1/2" X 4" BOLT		02
19	0503011336	1/2" HEX SELF ADJUSTING NUT		04
20	0571019462	SUPPORT GUIDE PRING		01
21	0581812081	SMALLER BUSHING		01
22	0581012094	SUPPORT WASHER		01




Item	Code	Description	See page	QT
01	0501110849	STEM WITH BEAK		01
01A	0521067064	ROD WITHOUT BEAK AUTO DISARM		01
01B	0521066870	POINT SUBSOILER		01
01C	0503016853	SPRING PIN		02
01D	0503011402	0.2" X 0.8" SPRING PIN		02
02	0581012092	AXLE FIXER		01
03	0581012093	WASHER		02
04	0503010406	501025 CLAMPING RING (FOR AXLE)		02
05	0521067065	FLANGE WASHER SPRING		01




Item	Code	Description	See page	QT
01	0521063492	SUPPORT RIGHT ACTUATOR	01	
02	0521063493	SUPPORT LEFT ACTUATOR	01	
03	0503016360	LINEAR ACTUATOR	02	
04	0503010420	BOLT	02	
05	0503012880	1/4" UNC SELF ADJUSTING NUT	04	
06	0521063491	PIVOT ARM	02	
07	0503010733	1/4" X 1-3/4" BOLT	02	
08	0571012352	AXLE FIXER	02	
09	0501010984	10,50 X 27 X 3,00 FLAT WASHER	04	
10	0503010025	3/8 SPRING WASHER	02	
11	0503010026	3/8" NUT	02	
12	0503010257	1/8" X 1" SPLIT PIN	02	
13	0511052438	COUNTERWEIGHT BOX	01	
14	0503014045	CABLE CORD PLASTIC	6 MT	
15	0503014591	RING CONNECTOR	02	
16	3505151602	TUBE	0.100 MT	
17	0571012359	RH CHAIN PROTECTION	01	
18	0571012360	LH CHAIN PROTECTION CAP	01	
19	0503013527	CLAMP ZIPER	20	
20	0503011953	5/16" X 1" BOLT	02	
21	0503010179	LOCK WASHER 5/16 ZN 1K01528	02	
22	0503010499	5/16 UNC BUTTERFLY NUT	02	
23	3505151603	TUBE	0.500 MT	
24	0503015905	TWO-WAY FEMALE MALE CONNECTOR	03	
25	0503015906	TWO-WAY MALE CONNECTOR	03	
26	0503016371	CONNECTOR FEMALE 4 VIAS	01	
27	0503016372	CONNECTOR FEMALE 5 VIAS	01	
28	0503014043	TERMINAL	04	
29	0503014044	TPP-22-L TERMINAL	02	
30	0503015497	CABLE PP	5.500 MT	
31	0503014745	2 X 2,5 MM ELECTRIC CABLE	5.000 MT	

Item	Code	Description	See page	QT
32	0503016454	10 AMPERES FUSE		01
33	0503016455	SUPPORT FUSE		01
34	0503015907	MALE TERMINAL		10
35	0503015908	FEMALE TERMINAL		10
36	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		04
37	0501012140	FLAT WASHER		04
38	0503012412	5/8" UNC SELF LOCKING NUT		04
39	0503015911	CABLE SEAL		16




Item	Code	Description	See page	QT
01	0521063492	SUPPORT RIGHT ACTUATOR	01	
02	0521063493	SUPPORT LEFT ACTUATOR	01	
03	0503016360	LINEAR ACTUATOR	02	
04	0503010420	BOLT	02	
05	0503012880	1/4" UNC SELF ADJUSTING NUT	04	
06	0521063491	PIVOT ARM	02	
07	0503010733	1/4" X 1-3/4" BOLT	02	
08	0571012352	AXLE FIXER	02	
09	0501010984	10,50 X 27 X 3,00 FLAT WASHER	04	
10	0503010025	3/8 SPRING WASHER	02	
11	0503010026	3/8" NUT	02	
12	0503010257	1/8" X 1" SPLIT PIN	02	
13	0511052438	COUNTERWEIGHT BOX	01	
14	0503014045	CABLE CORD PLASTIC	7 MT	
15	0503014591	RING CONNECTOR	02	
16	3505151602	TUBE	0.100 MT	
17	0571012359	RH CHAIN PROTECTION	01	
18	0571012360	LH CHAIN PROTECTION CAP	01	
19	0503013527	CLAMP ZIPER	20	
20	0503011953	5/16" X 1" BOLT	02	
21	0503010179	LOCK WASHER 5/16 ZN 1K01528	02	
22	0503010499	5/16 UNC BUTTERFLY NUT	02	
23	3505151603	TUBE	0.500 MT	
24	0503015905	TWO-WAY FEMALE MALE CONNECTOR	03	
25	0503015906	TWO-WAY MALE CONNECTOR	03	
26	0503016371	CONNECTOR FEMALE 4 VIAS	01	
27	0503016372	CONNECTOR FEMALE 5 VIAS	01	
28	0503014043	TERMINAL	04	
29	0503014044	TPP-22-L TERMINAL	02	
30	0503015497	CABLE PP	5.500 MT	
31	0503014745	2 X 2,5 MM ELECTRIC CABLE	5.000 MT	


Item	Code	Description	See page	QT
32	0503016454	10 AMPERES FUSE		01
33	0503016455	SUPPORT FUSE		01
34	0503015907	MALE TERMINAL		10
35	0503015908	FEMALE TERMINAL		10
36	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		04
37	0501012140	FLAT WASHER		04
38	0503012412	5/8" UNC SELF LOCKING NUT		04
39	0503015911	CABLE SEAL		16




Item	Code	Description	See page	QT
01	0511052681	MONITORING ASSEMBLY PLANTING SEEDS 13L PM100		01
01A	0503016491	MONITOR PLANT PM100		01
02	0503017031	CLEANING BRUSH		01
03	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		01
04	0503016554	8 ROW SIMPLE MONITOR CABLE		01
05	0501011643	3/8 X 1" BOLT		04
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
07	0503010025	3/8 SPRING WASHER		04
08	0503010026	3/8" NUT		04
09	0571013990	GUTTER		02
10	0571017368	SUPPORT GUTTER		02
11	0511053118	ASSEMBLY SENSOR ELECTRONIC		05
11A	0503016492	ELECTRIC PHOTO SENSOR PM 100		05
11B	0503013100	NYLON CLAMP		05



Item	Code	Description	See page	11 13
01	0511056395	SEDD ROW MONITOR ASSY		01 00
01.	0511056396	13L SEED OR FERTILIZER PLANT MONITORING ASSEMBLY PM400		00 01
01A	0503017602	MONITOR PLANT PM400		01 01
01B	0503016559	13 ROW SIMPLE CABLE MONITORING		01 01
01C	0503016234	TRIMBLE FIXING WINDOW		01 01
01D	0503016452	FIXING SUPPORT AG500 TRIMBLE		01 01
01E	0571012196	MOUNTING BRACKET PM 400		01 01
01F	0503017443	ANTENNA GPS PM 400		01 01
01G	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		180 195
01H	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02 02
01I	0503010669	FLAT WASHER		02 02
01J	0503010668	3/16" SPRING WASHER		02 02
01K	0503010667	3/16" NUT		02 02
02	0501058972	ASSEMBLY SENSOR ELECTRONIC		01 01
02A	0503015218	SENSOR FOTOELE PM 400		01 01
02B	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		03 03
03	0571017236	GUTTER		08 00
03.	0571013314	GUTTER 25 X 58 X 1500		00 08
04	0501011643	3/8 X 1" BOLT		08 08
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08 08
06	0503010025	3/8 SPRING WASHER		08 08
07	0503010026	3/8" NUT		08 08
08	0571017368	SUPPORT GUTTER		08 00
08.	0571018663	SUPPORT GUTTER		00 08



Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0503010257	1/8" X 1" SPLIT PIN		01
04	0581014858	DEPTH WHEEL AXLE		01
05	0501110720	ARM LEFT		01
06	0501110719	DEPTH CONTROL RIGHT ARM		01
07	0502012663	EXTENSION		01
08	0503010002	1800 GREASE FITTING		02
09	0501056769	DEPTH WHEELS REGULATOR ASSY	134	01
10	0503810256	SCREW		01
11	0521051423	COMPACTOR SUPPORT		01
12	0503034793	ARTICULATION SLEEVE		02
13	0571017749	FLAT WASHER		02
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		08
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2 UNC G.5 ZN HEX NUT		04
18	0501052908	COMPACTOR WHEEL WITH BEARING	133	02
19	0503013739	1/2" X 1" BOLT		01
20	0503016453	1/2" X 2.1/2 BOLT		02
21	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
22	0503010752	1/2" X 3.1/2" BOLT		01
23	0511059489	CENTRAL RAIL WHEEL		02



MARCHESAN

Technical Publications | Elaboration and Revision

MARINA PEREZ NIZA

www.marchesan.com.br

