

PARTS CATALOG

ROW CROP PLANTERS

PHT4 SUPREMA PP

Code: 0501091957



Series: S-0216

Rev.: 00

Date Rev.: AGOSTO/2017

**ORIGINAL PARTS
TATU**



PRODUCTS

Code

0111330023

Description

PHT4 SUP PP 3185/4E900 MH ANGOLA S-0216


ATTENTION: *IMPORTANT*

MARCHESAN S/A RESERVES THE RIGHT AT ANY TIME TO MAKE IMPROVEMENTS IN THE DESIGN, MATERIAL OR SPECIFICATIONS OF MACHINERY, EQUIPMENT OR PARTS WITHOUT THEREBY BECOMING LIABLE TO MAKE SIMILAR CHANGES IN MACHINERY, EQUIPMENT OR PARTS PREVIOUSLY SOLD.

INDEX


0909092691	FRAME		1
0511057582	CARDAN TURBINE		2
0501053886	PULLEY ASSY WITH FREE ROT		3
0501054649	SEQUENTIAL VALVE ASSY		4
0511041364	DRIVE SHAFT		5
0521040155	HYDRAULIC CYLINDER 31,75X50,8X365X595 PHT4 SUP		6
0501052586	ESTABILIZER DRAWBAR ASSY		7
0501050633	DISC ASSY FOR ROW MARKER		8
0521050859	RIGHT CARRYING-WHEELS		9
0511052484	WHEELS RIGHT		10
0511052486	WHEEL ARM RIGTH		11
0511052487	TURNBUCKLE		12
0501056444	BEARING WITH BALL BEARING		13
0521050860	LEFT CARRYING-WHEELS		14
0511052483	LEFT CARRYING-WHEELS		15
0511052485	LH WHELLS ARM		16
0521040712	FERTILIZER RIGHT BOX ASSY		17
0511051712	RH BEAM SUPPORT		18
0521040718	LH FERTILIZER BOX COVER ASSY		19
0501052977	15 X 15 LEF FERT UNAL DOUB-DISC ASSY		20
0511051717	LH BEAM SUPPORT		20
0909092693	SEED GEAR BOX		21
0909092696	FERTILIZER GEAR BOX		22
0511058968	RH ROW ASSY PP		23
0511058980	LH ROW ASSY PP		24
0511058967	RH SEED ROW ARM		25
0511052324	CARDAN TRANSMISSION BEARING		26
0511058979	LH SEED ROW ARM PP		27
0511057154	RITGH UNAL DOUB-DISC		28
0511057153	RITGH UNAL DOUB-DISC		29
0511058966	DISTRIBUTOR PP		30
0511057502	SET PRECISION PLANTING		31
0511057155	TRANSMISSION BOX PRECISION PLANTING		32
0511057491	ASSY PP SOYBEANS WHIT SEED DISTRIBUTOR		33
0521040159	DEPTH WHEEL SYSTEM		34
0511056937	DEPTH CONTROL SEMI MOUNTED		35
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE		36
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE		37
0501052627	DEPHT WHEELS BOX		38
0501052297	DEPTH WHEELS REGULATOR ASSY		39
0501052538	DEPTH CONTROL WHEEL RUBBER BAND		40
0511054333	COMPACT WHEEL RIGHT C/ BEARING		41
0511054334	COMPACT WHEEL LEFT C/ BEARING		42
0501059135	BOX SEED		43
0501056428	ROW 16 BLADE DISC ASSY		44
0501054379	RIGHT FERTILIZER ROW		45
0501054380	LEFT FERTILIZER ROW		46
0501053348	RH FERTILIZER ROW ARM		47
0501052976	15 X 15 RIGHT FERT UNAL DOUB-DISC ASSY		48
0501053349	LH FERTILIZER ROW ARM		49
0909090853	HYDRAULIC CIRCUIT (MH)		51

(OPTIONAL)




Item	Code	Description	QT
01	0521062567	FRAME 3° SCORE	01
02	0503010834	1/2 X 1 BOLT	12
03	0503010025	3/8 SPRING WASHER	10
04	0501010984	FLAT WASHER	10
05	0521062818	BRACO LEFT MARKER LINE PHT4	01
06	0521062819	BRACO RIGHT MARKER LINE PHT4	01
07	0531012400	COUPLING SHAFT	02
08	0503010577	3/16" X 1-1/4" COTTERPIN	04
09	0501069307	ROW MARKER ARM	02
10	0503011070	BEATER	02
11	0551019213	FLAT WASHER	02
12	0503011336	1/2" HEX SELF ADJUSTING NUT	02
13	0521040155	HYDRAULIC CYLINDER 31,75X50,8X365X595 PHT4	02
14	0521010571	COUPLING SHAFT	02
15	0503030168	HAIR PIN	02
16	0501068994	0.3" X 3.1" LOCK PIN	02
17	0503030168	HAIR PIN	04
18	0501080412	3/8" X 90.55" TR-TC HOSE	02
19	0501080469	3/8" X 98.42" TR-TR HOSE ASSY	02
20	0501080852	3/8" X 1500 TR-TM HOSE	02
21	0501053834	MALE QUICK COUPLING AGRICULTURAL WITH	02
22	0502012702	BODY SUPPORT CLAMP	06
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	08
24	0571010413	VALVE SUPPORT	01
25	0503010371	5/16" X 1" BOLT	02
26	0501010694	FLAT WASHER	02
27	0503010179	SPRING WASHER	02
28	0503010337	5/16" NUT	02
29	0501054649	SEQUENTIAL VALVE ASSY	01
30	0501065337	PLOUGH SUPPORT	02
31	0521010530	COUPLING SHAFT	02
32	0503010140	1/8" X 3/4" COTTERPIN	02
33	0501050633	DISC ASSY FOR ROW MARKER	02

Item	Code	Description	QT
34	0501052586	ESTABILIZER DRAWBAR ASSY	01
35	0521050312	LOWER HITCH ASSY	01
36	0521050521	UPPER HITCH	01
37	0511064353	FASTENER	02
38	0501013233	5/8" X 2-3/4" BOLT	08
39	0503010027	SPRING WASHER	20
40	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	20
41	0521010580	COUPLING SHAFT	01
42	0521010809	11,11 X 64 COUPLING SHAFT	02
43	0561019695	PHT4 SUPREME MARKET TRANSMITTER	02
44	0511057582	CARDAN TURBINE	01
45	0503010834	1/2 X 1 BOLT	01
46	0503010019	1/2" SPRING WASHER	01
47	0503010060	1/2" NUT	01
48	0571012801	COVER PROTECTION TURBINE	01
49	0503010256	3/8" X 3/4" BOLT	01
50	0501010984	FLAT WASHER	01
51	0503010025	3/8 SPRING WASHER	01
52	0503010026	3/8" NUT	01
53	0571011434	HOSE ASSY FIXER SUPPORT OUTPUT AR	01
54	0571011448	AIR CONDUCTOR	01
55	0503010246	CLAMP	12
56	0521018571	HOSE	04
57	0521010647	HOSE	02
58	0511069907	HOSE HOLDER	06
59	0511017302	FLAT WASHER	05
60	0511041364	DRIVE SHAFT	01
61	0501011445	FLAT WASHER	01
62	0503030085	LOCK PIN	04




Item	Code	Description	QT
001	0531017265	TURBINE SUPPORT	01
002	0501053716	BEARING ASSY OF THE LARGER FAN	01
002A	0502012016	CHAIN TENSIONER SUPPOT	01
002B	0503012778	MIDDLE LARGER AXLE	01
002C	0531010881	INTERMEDIARY UPPER SLEEVE	01
002D	0503012689	6306 DDU BEARING	02
002E	0503010325	VCA-118 VALVE	01
003	0503010395	1/2" X 1-1/4" BOLT	04
004	0503011336	1/2" HEX SELF ADJUSTING NUT	04
005	0501053886	PULLEY ASSY WITH FREE ROT	01
006	0501011194	1/2" X 1-3/4" BOLT	04
007	0521018517	FLAT WASHER	04
008	0503010019	1/2" SPRING WASHER	04
009	0503010020	1/2"NUT	04
010	0503013030	5/8" X 3.1/4" BOLT	01
011	0501012140	FLAT WASHER	01
012	0503010013	5/8" NUT	01
013	0503012780	LARGER TURBINE BELT	01
014	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04
015	0503010025	3/8 SPRING WASHER	04
016	0503010026	3/8" NUT	04
017	0521044612	FAN	01
018	0503011775	6 X 6 X 35 KEYWAY	01
019	0503011774	PULLEY	01
020	0503010179	SPRING WASHER	03
021	0503011257	M 8 X 1,25 X 30 BOLT	01
022	0571011731	CONECTOR CENTER	01
023	0503012722	0.16" X 0.4" BLIND RIVET	20
024	0511051733	AIR DISTRIBUTOR	01
025	0511051994	LH AIR DISTRIBUTOR	01
026	0503012856	REBITE POP	08
027	0521066238	SNAIL MECHANICAL	01
028	0571018577	COVER SNAIL TURBINE	01


Item	Code	Description	QT
029	0503010337	5/16" NUT	02
030	0503010363	5/16" X 1" BOLT	02
031	0531012678	4.5" X 0.9" X 0.2" SLEEVE	02




Item	Code	Description	QT
001	0502012020	PULLEY HOUSING BEARING	01
002	0501053888	TURBINE PULLEY ASSY	01
002A	0502012055	TURBINE PULLEY ASSY	01
002B	0503031732	RATCHET TURBINE PULLEY AXLE	01
002C	0503011081	6207 2RS BEARING	02
002D	0531014520	WASHER RATCHET	01
002E	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING	06
002F	0501010649	RATCHET CLICK	03
002G	0503031731	RATCHET PULLEY TURBINE	01
002H	0503012950	5/16" X 2-1/2" BOLT	03
003	0503011081	6207 2RS BEARING	02
004	0531014518	INTERMEDIARY LOWER BUSHING BEARING	01
005	0531014519	FLAT WASHER	01
006	0531014527	FLAT WASHER	01
007	0503010301	0.3" X 1.8" SPRING PIN	01
008	0503011855	0.2" X 1.8" SPRING PIN	01
009	0503010325	VCA-118 VALVE	01




Item	Code	Description	QT
01	0503060132	VDFS-002 T SEQUENCIAL VALVE	01
02	0501010617	3/4" NIPPLE	02
03	0503010190	2-114 N 3006-9B O'RING	02
04	0501012109	3/4" X 9/16" NIPPLE	04
05	0503011036	2-111 N 3006-9B O'RING	06
06	0531019339	9/16" UNF X 12 PUMP	02




Item	Code	Description	QT
01	0501055638	HOMO JOINT WITH FEMALE BUSHING	01
01A	0503012607	TRACTOR HOMOCINETIC TERMINAL	01
01Aa	0521010638	0.5" X 3.3" QUIC HITCH COUPL SHAFT	01
01Ab	0503030518	0.5"X1.0"X 0.1" COMPRESSION SPRING	01
01Ac	0503010140	1/8" X 3/4" COTTERPIN	01
01B	0503012605	CROSSPIECE	02
01C	0503012606	CENTER BODY	01
01D	0503012604	HOMO TERMINAL W/ FEMALE BUSHING	01
01E	0503012618	2.1" X 2.0" X 31" TRIAN FEMALE TUB	01
01F	0503010843	0.4" X 3.3" SPRING PIN	01
01G	0503011878	0.2" X 3.3" SPRING PIN	01
02	0501055639	UNIVERSAL JOINT	01
02A	0503013132	CC292 TERMINAL	01
02B	0503012096	CROSSPIECE	01
02C	0503013187	TERMINAL	01
02D	0503012619	1.8" X 1.7" X 31" TRIAN MALE TUB	01
02E	0503011069	0.4" X 2.8" SPRING PIN	01
02F	0503011805	0.2" X 2.8" SPRING PIN	01
03	0503013189	PROTECTION ASSY	01
04	0503012023	CHAIN FOR UNIV JOINT PROTECTION	01




Item	Code	Description	QT
01	0521062810	CYLINDER CASE	01
02	0571010344	31,75 X 456 ROD	01
03	0551019990	31,75 X 50,80 X 39,40 PISTON	01
04	0503010812	7/8" SELF-ADJUSTING NUT	01
05	0503010949	W2-2000-500 PK RING G.E	01
06	0503013920	GASKET 1870-1625	02
07	0503014677	2-118 O'RING	01
08	0503013917	O'RING 2-224	01
09	0503013914	1870-1250-312B GASKET	01
10	0503013915	D-1250 SCRAPER RING	01
11	0503013918	8-224 BACK-UP RING	01
12	0503014683	W1-1400-500 RING GUIDE	01
13	0501012140	FLAT WASHER	01
14	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	01
15	0571010576	SUPPORT WASHER	01
16	0571011410	SUPPORT RING CYLINDER LINE PHT4	01
17	0571011411	MOBILE COVER	01
18	0503033686	SLEEVE 22 X 38 X 12,50 RUBBER	02



Item	Code	Description	QT
01	0501110096	165 ADJUSTMENT NUT	01
02	0511061503	8.86" RIGTH TURNBUCKLE	01
03	0511061504	8.86" LH TURNBUCKLE	01
04	0501064974	LOCKNUT WITH HANDLER	01
05	0503010002	1800 GREASE FITTING	02




Item	Code	Description	QT
01	0511053904	ROW MARKER DISC	01
02	0503010023	SPRING WASHER	01
03	0503010014	3/4" NUT	01




Item	Code	Description	QT
01	0521063583	WHEEL SUPPORT	02
02	0502010175	HITCH CLAMP	02
03	0501011543	5/8" X 4" BOLT	04
04	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	08
05	0511052484	WHEELS RIGHT	01
06	0521062809	BEARING	04
07	0571010967	CHAIN TENSIONER	02
08	0561016501	GLOVE 30,50	02
09	0511067501	26Z GEAR	02
10	0503012718	40-1 CHAIN X 111 LINK + MENDING	02
11	0571010830	RIGHT CHAIN COVER	01
12	0561016503	PRISONER 3/8 UNC	06
13	0501010984	FLAT WASHER	08
14	0503010025	3/8 SPRING WASHER	08
15	0503010209	3/8" UNC BUTTERFLY NUT	06
16	0571010341	SQUARE SHAFT	02
17	0581014148	AXLE	02
18	0521060880	GEAR 22 TEETH	02
19	0511061757	18Z GEAR	02
20	0503018182	40-1 X 39 CHAIN LINK + MENDING	02
21	0561019679	CHAIN CAP	01
22	0501056444	BEARING WITH BALL BEARING	04
23	0521018630	1.4" X SQUARE 0.8" WASHER	08
24	0503030303	SUPPORT WASHER	08
25	0503010577	3/16" X 1-1/4" COTTERPIN	12
26	0511057192	EXTENSION SPRING	02
26A	0503031681	2.1" X 7.78" EXTENSION SPRING	04
26B	0502011031	SPRING UPPER HITCH	02
27	0503013618	BOLT	04
28	0501011299	FLAT WASHER	04
29	0571010541	BEATER SLEEVE	02
30	0571010964	TENSIONER CHAIN	02
31	0503031805	11Z 1/2" GEAR	02


Item	Code	Description	QT
32	0503010302	501019 SEAL RING	04
33	0511052487	TURNBUCKLE	02
34	0521010784	COUPLING SHAFT	02
35	0501011445	FLAT WASHER	04
36	0503010571	1/4" X 1.1/2 COTTERPIN	02
37	0521017623	0.5" X 1.5" COUPLING SHAFT	02
38	0503010257	1/8" X 1" COTTERPIN	02
39	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"	01
40	0503010302	501019 SEAL RING	02
41	0503010002	1800 GREASE FITTING	02
42	0521012529	CHAIN TIGHTENER AXLE	01
43	0503010019	1/2" SPRING WASHER	01
44	0503030402	PULLEY	01
45	0511017302	FLAT WASHER	03
46	0503010060	1/2" NUT	01
47	0503013462	BEARING WITH BALL BEARING	02
48	0503011105	SEAL RING	02
49	0503011953	5/16" X 1" BOLT	08
50	0501010694	FLAT WASHER	08
51	0503010179	SPRING WASHER	08
52	0503010337	5/16" NUT	08




Item	Code	Description	QT
01	0511052484	WHEELS RIGHT	01
02	0511052486	WHEEL ARM RIGTH	01
03	0503060105	WELL AND TIRE ASSY	01
04	0501010127	9/16" X 1-7/8" LUG BOLT	04
05	0503010035	9/16" CONIC NUT	04




Item	Code	Description	QT
01	0511052486	WHEEL ARM RIGTH	01
02	0521063588	RH WHEEL ARM	01
03	0571010311	SLEEVE INTERMEDIARY	02
04	0503010002	1800 GREASE FITTING	02
05	0503013170	ROLLER BEARING	02
06	0561016502	GUARD POWDER	02
07	0503010707	501030 CLAMPING RING (FOR AXLE)	01
08	0521061662	WHEELED AXLE	01



Item	Code	Description	QT
01	0511052487	TURNBUCKLE	01
02	0521063584	BODY RIGHT TURNBUCLE	01
03	0521063585	LEFT EXTENSOR BODY	01
04	0541010618	STABILIZER BODY	01
05	0541010087	LOOK NUT	01
06	0503010691	1/4" GREASE FITTING	02




Item	Code	Description	QT
01	0502011697	BEARING OF THE GEAR BOX	01
02	0503013462	BEARING WITH BALL BEARING	01
03	0503011105	SEAL RING	01




Item	Code	Description	QT
01	0521063583	WHEEL SUPPORT	02
02	0502010175	HITCH CLAMP	02
03	0501011543	5/8" X 4" BOLT	04
04	0503012412	HEX SELF ADJUSTING NUT 5/8 UNC S	08
05	0511052483	LEFT CARRYING-WHEELS	01
06	0521062809	BEARING	04
07	0571010967	CHAIN TENSIONER	02
08	0561016501	GLOVE 30,50	02
09	0511067501	26Z GEAR	02
10	0503012718	40-1 CHAIN X 111 LINK + MENDING	02
11	0561019680	LEFT CHAIN COVER	01
12	0561016503	PRISONER 3/8 UNC	06
13	0501010984	FLAT WASHER	08
14	0503010025	3/8 SPRING WASHER	08
15	0503010209	3/8" UNC BUTTERFLY NUT	06
16	0571010341	SQUARE SHAFT	02
17	0581014148	AXLE	02
18	0521060880	GEAR 22 TEETH	02
19	0511061757	18Z GEAR	02
20	0503018182	40-1 X 39 CHAIN LINK + MENDING	02
21	0561019679	CHAIN CAP	01
22	0501056444	BEARING WITH BALL BEARING	04
23	0521018630	1.4" X SQUARE 0.8" WASHER	08
24	0503030303	SUPPORT WASHER	08
25	0503010577	3/16" X 1-1/4" COTTERPIN	12
26	0511057192	EXTENSION SPRING	02
26A	0503031681	2.1" X 7.78" EXTENSION SPRING	04
26B	0502011031	SPRING UPPER HITCH	02
27	0503013618	BOLT	04
28	0501011299	FLAT WASHER	04
29	0571010541	BEATER SLEEVE	02
30	0571010964	TENSIONER CHAIN	02
31	0503031805	11Z 1/2" GEAR	02


Item	Code	Description	QT
32	0503010302	501019 SEAL RING	04
33	0511052487	TURNBUCKLE	02
34	0521010784	COUPLING SHAFT	02
35	0501011445	FLAT WASHER	04
36	0503010571	1/4" X 1.1/2 COTTERPIN	02
37	0521017623	0.5" X 1.5" COUPLING SHAFT	02
38	0503010257	1/8" X 1" COTTERPIN	02
39	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"	01
40	0503010302	501019 SEAL RING	02
41	0503010002	1800 GREASE FITTING	02
42	0521012529	CHAIN TIGHTENER AXLE	01
43	0503010019	1/2" SPRING WASHER	01
44	0503030402	PULLEY	01
45	0511017302	FLAT WASHER	03
46	0503010060	1/2" NUT	01
47	0503013462	BEARING WITH BALL BEARING	02
48	0503011105	SEAL RING	02
49	0503011953	5/16" X 1" BOLT	08
50	0501010694	FLAT WASHER	08
51	0503010179	SPRING WASHER	08
52	0503010337	5/16" NUT	08




Item	Code	Description	QT
01	0511052483	LEFT CARRYING-WHEELS	01
02	0511052485	LH WHELLS ARM	01
03	0503060105	WELL AND TIRE ASSY	01
04	0501010127	9/16" X 1-7/8" LUG BOLT	04
05	0503010035	9/16" CONIC NUT	04




Item	Code	Description	QT
01	0511052485	LH WHELLS ARM	01
02	0521063587	LH WHEEL ARM	01
03	0571010311	SLEEVE INTERMEDIARY	02
04	0503010002	1800 GREASE FITTING	02
05	0503013170	ROLLER BEARING	02
06	0561016502	GUARD POWDER	02
07	0503010707	501030 CLAMPING RING (FOR AXLE)	01
08	0521061662	WHEELED AXLE	01



Item	Code	Description	QT
001	0511051712	RH BEAM SUPPORT	01
002	0503060693	BOX FERTILIZER ASSY	01
003	0511065804	FERTILIZER BOX CLAMP	02
004	0501010984	FLAT WASHER	10
005	0503010025	3/8 SPRING WASHER	06
006	0503010026	3/8" NUT	06
007	0503034396	FERTILIZER SIDE COVER	02
008	0503010362	1/8" X 1.1/4" COTTERPIN	02
009	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04




Item	Code	Description	QT
001	0521062960	SUPPORT BIN FERTILIZER BOX PLASTIC	01
002	0511051714	SIDE FERTILIZER DISTRIBUTOR	01
003	0511051715	SIDE FERTILIZER DISTRIBUTOR	02
004	0501011643	3/8 X 1" BOLT	12
005	0503011443	SPRING WASHER	16
006	0503010026	3/8" NUT	16
007	0501056451	BEARING	01
007A	0502011971	HOUSING WITH DOUBLE BEARING	01
007B	0503013462	BEARING WITH BALL BEARING	02
007C	0503011105	SEAL RING	01
008	0501056444	BEARING WITH BALL BEARING	01
009	0503010237	3/8" X 1" BOLT	04
010	0561018362	SQUARE SHAFT	01
011	0501053788	Q3/4" FASTENER AXLE ASSY	04
011A	0521010691	AXLE FASTENER	01
011B	0503010373	1/4" X 2" BOLT	01
011C	0511017303	FLAT WASHER	02
011D	0503010143	SPRING WASHER	01
011E	0503010144	1/4" NUT	01
012	0511066098	23Z GEAR	01




Item	Code	Description	QT
001	0511051717	LH BEAM SUPPORT	01
002	0503060693	BOX FERTILIZER ASSY	01
003	0511065804	FERTILIZER BOX CLAMP	02
004	0501010984	FLAT WASHER	10
005	0503010025	3/8 SPRING WASHER	06
006	0503010026	3/8" NUT	06
007	0503034396	FERTILIZER SIDE COVER	02
008	0503010362	1/8" X 1.1/4" COTTERPIN	02
009	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04

15 X 15 LEF FERT UNAL DOUB-DISC ASSY


0501052977



Item	Code	Description	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT	01
02	0502011930	DOUBLE DISC COULTER BOX	02
03	0503010598	30204 BALL BEARING	04
04	0503011112	SEAL 02376-BRG	02
05	0521019148	LEFT DOUBLE DISC HUB	01
06	0503030282	3/4" CASTLE NUT	02
07	0503010257	1/8" X 1" COTTERPIN	02
08	0603022042	13" X 0.12" PLAIN COULTER BLADE	02
09	0503010546	5/16" X 7/8" BOLT	12
10	0503010337	5/16" NUT	12
11	0511015098	FLAT WASHER	06
12	0511011927	DUST CLOAK	02
13	0503030757	2.9" X 2" X 0.02" JOINT	02
14	0521019178	COVER DEPTH	02
15	0503014729	1/4" UNF X 1/2" BOLT	06
16	0503011441	SPRING WASHER	06
17	0501017542	LH DOUBLE DISC SCRAPER	01
18	0501017541	RH DOUBLE DISC SCRAPER	01
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01
20	0501010984	FLAT WASHER	02
21	0503011443	SPRING WASHER	01
22	0503010026	3/8" NUT	01
23	0502070062	SCRAPER	01
24	0503011402	0.2" X 0.8" SPRING PIN	01
25	0521019154	RIGHT DOUB DISC HUB	01




Item	Code	Description	QT
001	0521062960	SUPPORT BIN FERTILIZER BOX PLASTIC	01
002	0511051714	SIDE FERTILIZER DISTRIBUTOR	02
003	0511051715	SIDE FERTILIZER DISTRIBUTOR	01
004	0501011643	3/8 X 1" BOLT	12
005	0503011443	SPRING WASHER	16
006	0503010026	3/8" NUT	16
007	0501056451	BEARING	01
007A	0502011971	HOUSING WITH DOUBLE BEARING	01
007B	0503013462	BEARING WITH BALL BEARING	02
007C	0503011105	SEAL RING	01
008	0501056444	BEARING WITH BALL BEARING	01
009	0503010237	3/8" X 1" BOLT	04
010	0561018362	SQUARE SHAFT	01
011	0501053788	Q3/4" FASTENER AXLE ASSY	04
011A	0521010691	AXLE FASTENER	01
011B	0503010373	1/4" X 2" BOLT	01
011C	0511017303	FLAT WASHER	02
011D	0503010143	SPRING WASHER	01
011E	0503010144	1/4" NUT	01
012	0511066098	23Z GEAR	01
013	0503030275	AGRICULTURAL BEARING	01
014	0502010685	18Z CONICAL GEAR	01
015	0551018055	22,65 X 60 SLEEVE	01




Item	Code	Description	QT
01	0502011758	REAR TENSIONER LEVER	01
02	0503010292	0.2" X 1.6" SPRING PIN	03
03	0501048790	AXLE WITH LINK ASSY	01
04	0521062568	SIDE	01
05	0561019671	BODY	01
06	0581014147	MOTOR SHAFT	01
07	0561017353	MOTOR SHAFT	01
08	0511060396	DRIVE/DRIVEN AXLE CONE	02
09	0511059266	CLOSED BEARING	03
09A	0501056447	CENTRAL BEARING GEAR BOX	01
09B	0503011953	5/16" X 1" BOLT	09
09C	0501010694	FLAT WASHER	09
09D	0503010179	SPRING WASHER	09
09E	0503010337	5/16" NUT	09
10	0503030303	SUPPORT WASHER	04
11	0571010425	JACK	04
12	0571010426	SLEEVE SUPPORT	04
13	0503011336	1/2" HEX SELF ADJUSTING NUT	08
14	0511067501	26Z GEAR	01
15	0503014528	40-1 CHAIN X 72 LINK + REDECTION	01
16	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	02
17	0503010060	1/2" NUT	03
18	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING	02
19	0503012389	1/2 BALL	02
20	0511069978	CHAIN TENSIONER	01
21	0503012204	40-1 CHAIN X 82 LINK + RED	01
22	0571011451	HEX AXLE	01
23	0511051511	BEARING	01
24	0503010002	1800 GREASE FITTING	01
25	0503031805	11Z 1/2" GEAR	03
26	0503010302	501019 SEAL RING	03
27	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01
28	0501010984	FLAT WASHER	02

Item	Code	Description	QT
29	0503010025	3/8 SPRING WASHER	01
30	0503010026	3/8" NUT	01
31	0511060392	CHAIN TENSIONER	01
32	0503031366	RH TORSION SPRING	01




Item	Code	Description	QT
01	0502011758	REAR TENSIONER LEVER	01
02	0503010292	0.2" X 1.6" SPRING PIN	03
03	0501048790	AXLE WITH LINK ASSY	01
04	0521062568	SIDE	01
05	0561019671	BODY	01
06	0581014147	MOTOR SHAFT	01
07	0561017353	MOTOR SHAFT	01
08	0511060396	DRIVE/DRIVEN AXLE CONE	02
09	0511059266	CLOSED BEARING	03
09A	0501056447	CENTRAL BEARING GEAR BOX	01
09B	0503011953	5/16" X 1" BOLT	09
09C	0501010694	FLAT WASHER	09
09D	0503010179	SPRING WASHER	09
09E	0503010337	5/16" NUT	09
10	0503030303	SUPPORT WASHER	04
11	0571010425	JACK	04
12	0571010426	SLEEVE SUPPORT	04
13	0503011336	1/2" HEX SELF ADJUSTING NUT	08
14	0511061830	17Z P 0.5" GEAR SQUARE HOL	01
15	0503014528	40-1 CHAIN X 72 LINK + REDECTION	01
16	0503010834	1/2 X 1 BOLT	02
17	0503010060	1/2" NUT	03
18	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING	02
19	0503012389	1/2 BALL	02
20	0511069978	CHAIN TENSIONER	01
21	0503012204	40-1 CHAIN X 82 LINK + RED	01
22	0571011451	HEX AXLE	01
23	0511051511	BEARING	01
24	0503010002	1800 GREASE FITTING	01
25	0503031805	11Z 1/2" GEAR	03
26	0503010302	501019 SEAL RING	03
27	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01
28	0501010984	FLAT WASHER	02


Item	Code	Description	QT
29	0503010025	3/8 SPRING WASHER	01
30	0503010026	3/8" NUT	01
31	0511060392	CHAIN TENSIONER	01
32	0503031366	RH TORSION SPRING	01




Item	Code	Description	QT
001	0511058967	RH SEED ROW ARM	01
002	0503062390	SEED CONDUCTOR	01
003	0503010026	3/8" NUT	04
004	0503015920	3/8" UNC X 1.3/4" BOLT	02
005	0571019424	SUPPORT	01
006	0501018526	3/8" X 2" BOLT	02
007	0503010025	3/8 SPRING WASHER	04
008	0561014778	HEX UNIVERSAL JOINT	01
009	0503013958	1/4" X 1" BOLT	02
010	0561016630	AXLE	01
011	0503010371	5/16" X 1" BOLT	04
012	0531010631	SEED BEAM CLAMP	04
013	0503010179	SPRING WASHER	04
014	0503010337	5/16" NUT	04
015	0511058966	DISTRIBUTOR PP	01
016	0581012239	FERTILIZER BEAM ASSY	01




Item	Code	Description	QT
001	0511058979	LH SEED ROW ARM PP	01
002	0503062390	SEED CONDUCTOR	01
003	0503010026	3/8" NUT	04
004	0503015920	3/8" UNC X 1.3/4" BOLT	02
005	0571019424	SUPPORT	01
006	0501018526	3/8" X 2" BOLT	02
007	0503010025	3/8 SPRING WASHER	04
008	0561014778	HEX UNIVERSAL JOINT	01
009	0503013958	1/4" X 1" BOLT	02
010	0561016630	AXLE	01
011	0503010371	5/16" X 1" BOLT	04
012	0531010631	SEED BEAM CLAMP	04
013	0503010179	SPRING WASHER	04
014	0503010337	5/16" NUT	04
015	0511058966	DISTRIBUTOR PP	01
016	0581012239	FERTILIZER BEAM ASSY	01




Item	Code	Description	QT
001	0521066077	SEED ROW ARM	01
002	0502011561	BEARING SEMI	01
003	0502011830	ARTICULACION SUPPORT	01
004	0521018079	SEEP ROW DRAWBAR COVER	01
005	0503014729	1/4" UNF X 1/2" BOLT	02
006	0503011441	SPRING WASHER	02
007	0502010426	UPPER BEARING SEMI	02
008	0503010479	1/2" X 3" BOLT	04
009	0503011440	SPRING WASHER	04
010	0503010060	1/2" NUT	04
011	0503010752	1/2" X 3.1/2" BOLT	02
012	0502011400	18Z CONICAL GEAR	01
013	0502011296	1/2 HEX AXLE BEARING SLEEVE	01
014	0501013354	FLAT WASHER	02
015	0502011505	18Z CONICAL GEAR	01
016	0561019673	1/2" X 540 HEX AXLE	01
017	0501013352	FLAT WASHER	01
018	0511052324	CARDAN TRANSMISSION BEARING	01
019	0511057154	RITGH UNAL DOUB-DISC	01
020	0503010706	1/2" X 4.1/2" BOLT	02
021	0503011440	SPRING WASHER	02
022	0503010060	1/2" NUT	02




Item	Code	Description	QT
001	0571012290	BEARIN BODY	01
002	0571012289	SLLEVE FIXER AXLE	01
003	0503011410	ROLLER BEARING	01
004	0503011105	SEAL RING	01
005	0503010406	501025 CLAMPING RING (FOR AXLE)	01
006	0503010371	5/16" X 1" BOLT	02
007	0501010694	FLAT WASHER	04
008	0503010337	5/16" NUT	02
009	0503010179	SPRING WASHER	02
010	0571012288	HEX AXLE	01
011	0503015356	SPRING PIN	01




Item	Code	Description	QT
001	0521066077	SEED ROW ARM	01
002	0502011561	BEARING SEMI	01
003	0502011830	ARTICULACION SUPPORT	01
004	0521018079	SEEP ROW DRAWBAR COVER	01
005	0503014729	1/4" UNF X 1/2" BOLT	02
006	0503011441	SPRING WASHER	02
007	0502010426	UPPER BEARING SEMI	02
008	0503010479	1/2" X 3" BOLT	04
009	0503011440	SPRING WASHER	04
010	0503010060	1/2" NUT	04
011	0503010752	1/2" X 3.1/2" BOLT	02
012	0502011400	18Z CONICAL GEAR	01
013	0502011296	1/2 HEX AXLE BEARING SLEEVE	01
014	0501013354	FLAT WASHER	02
015	0502011505	18Z CONICAL GEAR	01
016	0561019673	1/2" X 540 HEX AXLE	01
017	0501013352	FLAT WASHER	01
018	0511052324	CARDAN TRANSMISSION BEARING	01
019	0511057153	RITGH UNAL DOUB-DISC	01
020	0503010706	1/2" X 4.1/2" BOLT	02
021	0503011440	SPRING WASHER	02
022	0503010060	1/2" NUT	02




Item	Code	Description	QT
01	0511053172	RIGHT HUB LOWR Y/DISC	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC	01
03	0511053173	LH HUB LOWR Y/DISC	01
04	0503010026	3/8" NUT	01
05	0503011443	SPRING WASHER	01
06	0501010984	FLAT WASHER	02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01
08	0571017964	LEFT DOUBLE DISC SCRAPER	01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18	01
09	0571017963	RIGHT DOUBLE DISC SCRAPER	01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18	01
10	0502012780	SUPPORT DDD RIGHT	01
11	0511015098	FLAT WASHER	04
12	0503011402	0.2" X 0.8" SPRING PIN	01
13	0503013129	ELASTIC PIN	01
14	0503015081	502052 CLAMPING RING (FOR AXLE)	02
15	0511011927	DUST CLOAK	02
16	0571011152	DOUBLE DISC CAP	02
17	0503014679	2-134 O'RING	02



Item	Code	Description	QT
01	0511053172	RIGHT HUB LOWR Y/DISC	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC	01
03	0511053173	LH HUB LOWR Y/DISC	01
04	0503010026	3/8" NUT	01
05	0503011443	SPRING WASHER	01
06	0501010984	FLAT WASHER	02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01
08	0571017964	LEFT DOUBLE DISC SCRAPER	01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18	01
09	0571017963	RIGHT DOUBLE DISC SCRAPER	01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18	01
10	0502012781	SUPPORT DDD LEFT	01
11	0511015098	FLAT WASHER	04
12	0503011402	0.2" X 0.8" SPRING PIN	01
13	0503013129	ELASTIC PIN	01
14	0503015081	502052 CLAMPING RING (FOR AXLE)	02
15	0511011927	DUST CLOAK	02
16	0571011152	DOUBLE DISC CAP	02
17	0503014679	2-134 O'RING	02




Item	Code	Description	QT
001	0503010026	3/8" NUT	04
002	0511057502	SET PRECISION PLANTING	01
003	0503010025	3/8 SPRING WASHER	04
004	0502012798	SUPPORT BOX SEED	01
005	0503010849	3/8" X 1-1/2" BOLT	03
006	0501010096	3/8" X 2" BOLT	01
007	0581012694	COMPACT PROTECTION	01



Item	Code	Description	QT
01	0502012807	SUPPORT BOX PRECISION PLANTING	01
01A	1902012807	SEED BOX SUPPORT	01
02	0502012776	SUPPORT ARTICULATION PNEUMATIC PP	01
03	0571017899	PIN LOCK PP	01
04	0503030190	0.5" X 1.6" X 0.05" SPRING	01
05	0571014024	FAST BOLT GUIDE AXLE	02
06	0571017897	AXLE ARTICULATION PRECISION PLANTING	01
07	0581011225	FIXER P PLANTING CONTR CPRA	01
08	0511057155	TRANSMISSION BOX PRECISION PLANTING	01
09	0571017894	PIN DRAG PRECISION PLANTING	01
10	0503013357	3/8" SELF-ADJUSTING NUT	01
11	0503015752	3/8" X 2" BOLT	01
12	0501013518	FLAT WASHER	02
13	0503015356	SPRING PIN	01
14	0571017896	SLEEVE ARTICULATION PRECISION PLANTING	01
15	0571017895	PIN FIXER CONDUCTOR PRECISION PLANTING	01
16	0503011776	M6 SELF ADJUSTINGNUT	03
17	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING	02
18	0503010293	BAQUELITE MANIPULACION	01
19	0503010140	1/8" X 3/4" COTTERPIN	03
20	0503010131	3/16" X 1-1/2" COTTERPIN	01
21	0503010025	3/8 SPRING WASHER	01
22	0503037390	PACKING FOR PLANTING	01
23	0571019491	SLUICE PNEUMATIC PRECISION PLANTING	01
24	0501011643	3/8 X 1"BOLT	01
25	0503010209	3/8" UNC BUTTERFLY NUT	01
26	0503012721	1/4" X 4" BOLT	01
27	0503012880	1/4" UNC SELF ADJUSTING NUT	01
28	0581011226	FIXER CLOSING P PLANTING CONTR CPRA	01
29	0571019489	CLAMP PRECISION PLANTING	01
30	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION	01
31	0511057491	ASSY PP SOYBEANS WHIT SEED DISTRIBUTOR	01
31A	0503062405	SEED DISTRIBUTOR	01


Item	Code	Description	QT
31B	0503062407	SET SOYBEAN DISTRIBUTION	01
31B-01	0503062417	KIT CORN DISTRIBUTION	01
31B-02	0503062471	DISTRIBUTION ASSY (SORGHUM / MILLET)	01
31B-03	0503062577	DISTRIBUTION ASSY (LARGE CORN / SUNFLOWER	01
31B-04	0503062578	DISTRIBUTION ASSY (LARGE CORN)	01
31B-05	0503062579	DISTRIBUTION ASSY (CORN / SUNFLOWER)	01
31B-06	0503062580	DISTRIBUTION ASSY (POPCORN / COTTON)	01
31B-07	0503062581	DISTRIBUTION ASSY (SMALL CORN / POP CORN)	01
31B-08	0503062573	CONVERSATION SET FOR DISTRIBUTION (LARGE	01
31B-09	0503062574	CONVERSATION SET FOR DISTRIBUTION (SMALL	01
31B-10	0503062564	CONVERSATION SET FOR DISTRIBUTION (	01
32	0561014778	HEX UNIVERSAL JOINT	01
33	0503013958	1/4" X 1" BOLT	02
34	0503818139	M6 BOLT	03
35	0503011812	M6 X 1" BOLT	02
36	0503015110	M06 SPRING WASHER	02



Item	Code	Description	QT
001	0502050052	LEFT SIDE TRANSMISSION BOX PP	01
002	0502050053	RIGHT SIDE TRANSMISSION BOX PP	01
003	0503011410	ROLLER BEARING	02
004	0503011182	6203 ROLLER BEARING	02
005	0503011184	502040 CLAMPING RING (FOR AXLE)	01
006	0571017655	SLEVE FIXER HITCH PNEUMATIC	01
007	0503010373	1/4" X 2" BOLT	03
008	0503010144	1/4" NUT	03
009	0511057504	JOIN GEAR	01
009A	0571017898	BODY GEAR TRANSMISSION	01
009B	0503011769	M8 X 0.5" BOLT	01
010	0581011222	PINION AXLE 6Z PNEUMATIC	01
011	0503034340	PINION AXLE 6Z PNEUMATIC	01


ASSY PP SOYBEANS WHIT SEED DISTRIBUTOR

0511057491




Item	Code	Description	QT
01	0511057491	ASSY PP SOYBEANS WHIT SEED DISTRIBUTOR	01
01A	0503062567	FIXED BASE SEEDS DISTRIBUTOR	01
01AA	0503018908	BODY FIXED BASE DISTRIBUTOR SEED	01
01AB	0503018909	COVER CONDUCTOR DISTRIBUTOR SEED	01
01AC	0503062652	SEED INPUT DEFLECTOR	01
01AD	0503062653	FULL COVER	01
01AE	0503018910	RIVETS LARGEST	01
01AF	0503018911	SPACING BUSHING	01
01AG	0503018912	BOLT	03
01AH	0503018476	SPRING	01
01AI	0503018474	LOWER BRUSH	01
01AJ	0503018475	TOP BRUSH	01
01AK	0503018157	RUBBER	01
01AL	0503018477	LOCK SPRING	01
01B	0503062568	FIXER MOBILE	01
01BA	0503018919	BASE	01
01BB	0503018913	RIVET	01
01BC	0503018914	WASHER	01
01BD	0503018915	BEARING	02
01BE	0503062654	BEARING	01
01BF	0503018916	ADJUSTMENT CHOCK	03
01BG	0503018917	RING	01
01BH	0503018918	CHOCK	02
01BI	0503018417	RUBBER	01
01BJ	0503018478	SPRING	01
01BK	0503018920	SEALING	01
01BL	0503018479	TUBE	01
01BM	0503018735	PROTECTIVE COVER	01
01BN	0503018921	BOLT	06
01BO	0503018922	BOLT	02
01BP	0503018480	REGULATOR PIN	01
01BQ	0503018923	ADAPTER	01
01BR	0503018924	SPRING PIN	01


Item	Code	Description	QT
02	0503062407	SET SOYBEAN DISTRIBUTION	01
02A	0503018483	PLASTIC DISC	01
02B	0503062569	SELECTOR SEED	01
02C	0503062566	ASSY	01
03	0571019613	STRAW PRECISION PLANTING SHIELD	01




Item	Code	Description	QT
01	0511056937	DEPTH CONTROL SEMI MOUNTED	01
02	0501052538	DEPTH CONTROL WHEEL RUBBER BAND	02
03	0503010358	5/16" X 5/8" BOLT	08
04	0503010179	SPRING WASHER	08
05	0503013816	5/16" LOCKNUT	08
06	0511054334	COMPACT WHEEL LEFT C/ BEARING	01
07	0511054333	COMPACT WHEEL RIGHT C/ BEARING	01
08	0503033942	COVER REGULATORY WHEEL	01




Item	Code	Description	QT
01	0502012282	DEPTH CONTROL SUPPORT	01
02	0581011100	DEPTH WHEEL AXLE	01
03	0503010256	3/8" X 3/4" BOLT	01
04	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE	02
05	0511015346	FLAT WASHER	02
06	0521064073	REGULACION WHEEL COMPACTOR	01
07	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	01
08	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	01
09	0571017749	FLAT WASHER	02
10	0503011440	SPRING WASHER	02
11	0501052297	DEPTH WHEELS REGULATOR ASSY	01
12	1902012116	PRESS WHEEL ADJUSTER	01
13	0503010849	3/8" X 1-1/2" BOLT	02
14	0503011443	SPRING WASHER	02
15	0503010026	3/8" NUT	02
16	0541016906	PRESS WHEELS REGULATOR BODY	01
17	0521010539	0.3" X 1.2" COUPLING SHAFT	01
18	0503010140	1/8" X 3/4" COTTERPIN	01
19	0503030805	1.6" X 6" X 0.2" TRACTION SPRING	01
20	0503010311	1/2" X 1-1/4" BOLT	02
21	0503010762	5/8" X 3-12" BOLT	01
22	0521062527	SUPPORT STABILIZER BAR	01
23	0503011445	SPRING WASHER	01
24	0503010013	5/8" NUT	01




Item	Code	Description	QT
001	0501052627	DEPHT WHEELS BOX	01
002	0503010740	1/2" X 2" BOLT	01
003	0503011440	SPRING WASHER	01
004	0503010060	1/2" NUT	01
005	0503010002	1800 GREASE FITTING	01
006	0501110833	DEPTH CONTROL RIGHT ARM	01




Item	Code	Description	QT
001	0501110834	LH ARM	01
002	0501052627	DEPHT WHEELS BOX	01
003	0503010740	1/2" X 2" BOLT	01
004	0503011440	SPRING WASHER	01
005	0503010060	1/2" NUT	01
006	0503010002	1800 GREASE FITTING	01




Item	Code	Description	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK	01
02	0502011907	DEPTH CONTROL WHEEL HUB	01
03	0503010269	6204 BALL BEARING	02
04	0501013636	SPACING SLEEVE	01
05	0503010689	SEAL 00763-BR	01
06	0503011105	SEAL RING	01
07	0503010878	5/8" SELF ALIGNING NUT	01
08	0521019178	COVER DEPTH	01
09	0503030757	2.9" X 2" X 0.02" JOINT	01
10	0503014729	1/4" UNF X 1/2" BOLT	03
11	0503011441	SPRING WASHER	03
12	0503010691	1/4" GREASE FITTING	01




Item	Code	Description	QT
01	0502011689	1/8" DEPTH CONTROL LEVER	01
02	0503030975	0.9" X 1.5" X 0.1" SPRING	01
03	0502011688	SEED SIST CONTROL DEPTH LEVER	01
04	0511015976	FLAT WASHER	01
05	0503010257	1/8" X 1" COTTERPIN	01
06	0511060699	DEPTH WHEEL STOP	01
07	0503010071	3/16" X 1" COTTERPIN	01




Item	Code	Description	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND	01
02	0521010832	RIM FLANGE	02
03	0503010298	1/4" X 1/2" BOLT	05
04	0503010143	SPRING WASHER	05
05	0503010144	1/4" NUT	05




Item	Code	Description	QT
01	0501052908	PRESS WHEELS ASSY	01
02	0503016449	1/2 X 4 BOLT	01
03	0521014508	FLAT WASHER	03
04	0503012136	1 X 9 BOLT	01




Item	Code	Description	QT
001	0501052908	PRESS WHEELS ASSY	01
002	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT	01
003	0521014508	FLAT WASHER	03
004	0503016864	LH 1/2" LOCK NUT	01




Item	Code	Description	QT
01	0501059135	BOX SEED	01
01A	0503060516	SEED BOX WITH SMALLER CAP	01
02	0503010371	5/16" X 1" BOLT	04
03	0503010179	SPRING WASHER	04
04	0503010337	5/16" NUT	04
05	0531018349	SEED FLOW SWITCH PNEUMATIC SYSTEM	01
06	0521060631	FIXING BASE BOX	01
07	0502011760	SEED SILO SUPPORT	01
08	0501011643	3/8 X 1" BOLT	01
09	0501010984	FLAT WASHER	05
10	0503010209	3/8" UNC BUTTERFLY NUT	01
11	0503010025	3/8 SPRING WASHER	05
12	0503010026	3/8" NUT	04
13	0531010631	SEED BEAM CLAMP	04
14	0503010849	3/8" X 1-1/2" BOLT	04




Item	Code	Description	QT
001	0511063081	DISC BLADE SUPPORT	01
002	0502011279	DISC HUB	01
003	0503010215	30205 BEARING	02
004	0503010213	SEAL 30205	02
005	0511061647	BLADE DISC AXLE ASSY	01
006	0501068582	7/8" UNF WITH DUST CLOAK NUT	01
007	0603023009	16" X 0.2" FLAT PLAIN DISC	01
008	0501013839	WASHER	01
009	0503010365	NUT	06
010	0503011444	SPRING WASHER	06
011	0503010337	5/16" NUT	06
012	0503010691	1/4" GREASE FITTING	01
013	0503011438	SPRING WASHER	02
014	0521013510	3/4" NUT	02
015	0511063073	DISC BLADE FIXER	01
016	0531012999	DISC BLADE FIXER AXLE	01
017	0503010361	SPRING PIN	01
018	0503010756	0.2" X 2.4" SPRING PIN	01
019	0503013185	3/4" X 5-1/2" BOLT	01
020	0521014321	ARTICULATION ARM REEL	01
021	0503010046	2-216 N 3006-9B O'RING	02
022	0511015346	FLAT WASHER	02
023	0503011255	3/4" LOCK NUT	01
024	0501010322	FLAT WASHER	01







Item	Code	Description	QT
001	0501053349	LH FERTILIZER ROW ARM	01
002	0521066715	VARAO SPRING ADB PHT4	01
003	0503011411	1/2" X 5-1/2" BOLT	01
004	0511017302	FLAT WASHER	02
005	0521010445	0.53" X 0.75" X 0.45" SLEEVE	02
006	0503011336	1/2" HEX SELF ADJUSTING NUT	01
007	0501013753	FLAT WASHER	01
008	0502040534	SPRING GUIDE BUSHING LOCK	01
009	0501018535	1/2 X 1 BOLT	01
010	0503030609	1"X11.81"X 0.16" COMPRESSION SPRING	01
011	0503030917	1.6"X11.8"X 0.2" COMPRESSION SPRING	01
012	0502011538	SPRING GUIDE	01
013	0503010013	5/8" NUT	01
014	0501010066	3/4" X 9" BOLT	01
015	0521017831	SUPPORT SLEEVE SPACER	02
016	0511017232	FLAT WASHER	02
017	0503010014	3/4" NUT	01
018	0503030392	LEFT FERTILIZER SOCKET	01
019	0503030408	10 X 2 X 390 HOSE	01
020	0503031076	2" HOSE CLAMP	02
021	0503010023	SPRING WASHER	01




Item	Code	Description	QT
001	0521063737	FERTILIZER ROW ARM	01
002	0501052976	15 X 15 RIGHT FERT UNAL DOUB-DISC ASSY	01
003	0511018662	SPACING PLATE	06
004	0503010706	1/2" X 4.1/2" BOLT	01
005	0503011440	SPRING WASHER	01
006	0503010060	1/2" NUT	01



Item	Code	Description	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT	01
02	0502011930	DOUBLE DISC COULTER BOX	02
03	0503010598	30204 BALL BEARING	04
04	0503011112	SEAL 02376-BRG	02
05	0521019148	LEFT DOUBLE DISC HUB	01
06	0503030282	3/4" CASTLE NUT	02
07	0503010257	1/8" X 1" COTTERPIN	02
08	0603022042	13" X 0.12" PLAIN COULTER BLADE	02
09	0503010546	5/16" X 7/8" BOLT	12
10	0503010337	5/16" NUT	12
11	0511015098	FLAT WASHER	06
12	0511011927	DUST CLOAK	02
13	0503030757	2.9" X 2" X 0.02" JOINT	02
14	0521019178	COVER DEPTH	02
15	0503014729	1/4" UNF X 1/2" BOLT	06
16	0503011441	SPRING WASHER	06
17	0501017542	LH DOUBLE DISC SCRAPER	01
18	0501017541	RH DOUBLE DISC SCRAPER	01
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01
20	0501010984	FLAT WASHER	02
21	0503011443	SPRING WASHER	01
22	0503010026	3/8" NUT	01
23	0502070062	SCRAPER	01
24	0503011402	0.2" X 0.8" SPRING PIN	01
25	0521019154	RIGHT DOUB DISC HUB	01



Item	Code	Description	QT
001	0521063737	FERTILIZER ROW ARM	01
002	0501052977	15 X 15 LEF FERT UNAL DOUB-DISC ASSY	01
003	0511018662	SPACING PLATE	06
004	0503010706	1/2" X 4.1/2" BOLT	01
005	0503011440	SPRING WASHER	01
006	0503010060	1/2" NUT	01



Item	Code	Description	QT
001	0521062818	BRACO LEFT MARKER LINE PHT4	01
002	0521062819	BRACO RIGHT MARKER LINE PHT4	01
003	0501069307	ROW MARKER ARM	02
004	0503011070	BEATER	02
005	0503010740	1/2" X 2" BOLT	02
006	0503010019	1/2" SPRING WASHER	02
007	0503010834	1/2 X 1 BOLT	04
008	0503010577	3/16" X 1-1/4" COTTERPIN	02
009	0531012400	COUPLING SHAFT	02
010	0521040155	HYDRAULIC CYLINDER 31,75X50,8X365X595 PHT4	02
011	0521010571	COUPLING SHAFT	02
012	0561019695	PHT4 SUPREME MARKET TRANSMITTER	02
013	0501068994	0.3" X 3.1" LOCK PIN	02
014	0503030168	HAIR PIN	02
015	0501050633	DISC ASSY FOR ROW MARKER	01
016	0502012702	BODY SUPPORT CLAMP	06
017	0503010180	7/16" SPRING WASHER	06
018	0503012555	7/16" X 2" BOLT	06
019	0501054649	SEQUENTIAL VALVE ASSY	01
020	0503010237	3/8" X 1" BOLT	02
021	0503010025	3/8 SPRING WASHER	02
022	0571010413	VALVE SUPPORT	01
023	0503010371	5/16" X 1" BOLT	02
024	0501010694	FLAT WASHER	02
025	0503010179	SPRING WASHER	02
026	0503010337	5/16" NUT	02
027	0501053834	MALE QUICK COUPLING AGRICULTURAL WITH	02
028	0503010571	1/4" X 1.1/2 COTTERPIN	02
029	0501080852	3/8" X 1500 TR-TM HOSE	02
030	0501080469	3/8" X 98.42" TR-TR HOSE ASSY	02
031	0501080412	3/8" X 90.55" TR-TC HOSE	02

This image shows a single page from a notebook or ledger. The page is white with rounded corners and features horizontal ruling lines spaced evenly down its length. There are no margins, text, or other markings on the page.





MARCHESAN IMPLEMENTOS E MÁQUINAS AGRÍCOLAS TATU S.A.

AV. Marchesan, 1979 - Post office box, 131 - CEP 15994-900 - Matão - SP - Brazil

Phone +55 16.3382-8282

(FAX Parts) + 55 16.3382. 8297 - (Export) + 55 16.3382.1003

e.mail: tatu@marchesan.com.br www.marchesan.com.br

Technical Publications: Elaboration

MARINA PEREZ NIZA

Technical Publications: Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

Contact Catálogo:

E-mail = jgaspari@marchesan.com.br

**ORIGINAL PARTS
TATU**

