

SEEDERS

SDA3E - FRAME 4060/5010 - MH/TL

Code: 0501091991
Series: S-0116
Revision: 00
Date Revision: FEVEREIRO/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0112020851	SDA3E 4060/21E175 CD VT CPV F310 CF S-0116
0112020813	SDA3E 4060/23E158 CD VT CPF F310 S-0116
0112020818	SDA3E 4060/23E158 CD VT F260 TL S-0116
0112020821	SDA3E 4060/23E158 CD VT F310 S-0116
0112020831	SDA3E 5010/19E250 CD VT CPV F310 CXF TL S-0116
0112020826	SDA3E 5010/27E175 CD VT CPV F310 CXF S-0116
0112020830	SDA3E 5010/27E175 CD VT CPV F310 CXF TL S-0116
0112020846	SDA3E 5010/27E175 CD VT CPV TL S-0116
0112020805	SDA3E 5010/27E175 MH CD VT CPF CXF TL CH S-0116
0112020837	SDA3E 5010/27E175 MH CD VT DC CPF CXF TL CH S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX


0909091514	FRAME ASSY 19/21/23	1
0909091515	FRAME ASSY 27	2
0511058929	FERTILIZER BOX SEED 15	3
0511058928	CONJUGATED BOX	4
0511059099	RH CONJUGATED BOX ASSY 19	5
0511059101	BOX FERTILIZER SEED	6
0511059100	LH CONJUGATED BOX ASSY 19	7
0511059102	LH BOX FERTILIZER SEED	8
0511059097	RH CONJUGATED BOX ASSY 21	9
0511058663	RIGHT CONJUGATED BOX	10
0511059098	LH CONJUGATED BOX ASSY 21	11
0511058664	LH BOX FERTILIZER SEED	12
0511058666	RH CONJUGATED BOX ASSY	13
0511058665	LH CONJUGATED BOX ASSY 23	14
0511059227	RIGHT SEED FINE BOX ASSY	15
0511059225	RH BOX FERTILIZER SEED FINE	16
0511059228	LH SEED FINE BOX ASSY	17
0511059226	LH BOX FERTILIZER SEED FINE	18
0909092711	HYDRAULIC MARKER	19
0511055774	HYDRAULIC MARKER ASSY	20
0501054886	ROW MARKER DISC	21
0909092853	HYDRAULIC CIRCUIT 19	22
0909092851	HYDRAULIC CIRCUIT 21/23	23
0909092854	HYDRAULIC CIRCUIT 27/29	24
0909092852	HYDRAULIC CIRCUIT 27/29	25
0511047998	HYDRAULIC CYLINDER 44.5 X 85.7 X 525 X 195	26
0501047216	1.7" X 15.9" X 19" X 2.4" HYDRAULIC CYLINDER	27
0501043777	1.7" X 15.9" X 19" X 2.4" HYDRAULIC CYLINDER	28
0501041997	VALVE ASSY	29
0501053195	TRANSMISSION RIGHT DRIVING	30
0501053196	TRANSMISSION LEFT DRIVING	31
0501051598	RIGHT TRANSMISSION DRIVING ASSY	32
0501051599	LEFT TRANSMISSION DRIVING ASSY	33
0501055968	RECALL STUB SHAFT & HUB ASSY	34
0501053140	CARRYING WHEELS WHTOUT TIRE	35
0909091511	FINE SEED BOX	36
0501051381	FINE SEED CHAIN TENSIONER ASSY	37
0511043739	RIGHT FINE SEED BOX ASSY	38
0501053441	RIGHT FINE SEED BOX SDA3E 27	39
0511043740	LH FINE SEED BOX ASSY	40
0501053442	LH FINE SEED BOX SDA3E 27	41
0511058488	OUTPUT SIDE FERTILIZER DISTRIBUTOR	42
0501049704	DRAWBAR ASSY	43
0511055818	DRAWBAR	44
0511040010	DRAWBAR ASSY	45
0511055773	DRAWBAR	46
0501052972	RIGHT RATCHET CHAIN TENSIONER	47
0501052968	AGRICULTURAL BEARING ASSY	48
0501053168	ESTABILIZER DRAWBAR ASSY	49
0501040236	SEED LIMETER	50
0501052081	RH BEARING SEED BOX	51
0501052082	LH BEARING SEED BOX	52
0501043282	RIGHT CHAIN TENSIONER ASSY	53
0501043283	ASSY LEFT CHAIN STRETCHER	54
0501051927	COVER PIVOT SHAFT ASSY	55



MARCHESAN

INDEX

0909093464	DISLOCATED DOUBLE DISK ROW SET (RIGTH/LEFTH) CPV E158	56
0909093465	DISLOCATED DOUBLE DISK ROW SET (RIGTH/LEFTH) CPV E158	57
0909098987	DISLOCATED DOUBLE DISK ROW SET (RIGTH/LEFTH)	58
0909093466	DISLOCATED DOUBLE DISK ROW SET (RIGTH/LEFTH) CPV E250	59
0909092856	DISLOCATED DOUBLE DISK ROW SET (RIGTH/LEFTH)	60
0501056211	RH DDD ROW SMALLER SUPPORT	61
0501056212	LH DDD ROW SMALLER SUPPORT	62
0501056214	LH ROW DDD LARGER SUPPORT	63
0501056217	RH DDD ROW SMALLER SUPPORT	64
0521056218	LOWER SUPPORT LINE DDD LINE	65
0501056219	RH ROW DDD LARGER SUPPORT	66
0501056220	RH ROW DDD LARGER SUPPORT	67
0501056221	RH SIDE ROW LARGER SUPPORT	68
0501056222	LH SIDE ROW DDD LARGER SUPPORT	69
0501056215	RH ROW LARGER SIDE SUPPORT	70
0501056216	LH ROW LARGER SIDE SUPPORT	71
0501057476	RH DDD ROW SMALLER SUPPORT	72
0501057477	RH DDD ROW SMALLER SUPPORT	73
0501057478	RH DDD LARGER SUPPORT	74
0501057479	ROW LARGER SUPPORT	75
0501053303	KIT DISTRIBUTOR	76
0501052990	AGRICULTURAL BEARING	77
0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	78
0501054151	RIGHT DOUBLE DISC COULTER BOX	79
0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	80
0501054168	15" LEFT DOUBLE DISC HUB	81
0521053331	BLADE DISC ASSY 14 SDA3/E	82
0501044399	PLAIN DISC BLADE DISC ASSY	83
0501055213	RIGHT V PRESS SISTEM ASSY	84
0501055214	LEFT V PRESS SISTEM ASSY	85
0501056267	RH V PRESS SISTEM COMPL.	86
0501052908	COMPACTOR WHEEL WITH BEARING	87
0501056268	LF PRESS SISTEM ASSY	88
0501046839	RIGHT IRON PRESS WHEEL	89
0501046844	LEFT IRON PRESS WHEEL ASSY	90
0501053187	LEFT IRON PRESS WHEEL ASSY	91
0501053186	RIGHT IRON PRESS WHEEL ASSY	92
0501055481	HECTARE ELECTRONIC SET	93
0909093484	LONGT TRANSP ASSY	94
0511055597	LONGITUDINAL TRANSPORT	95
0511056480	FRONT FORK WITH TIRE	96
0511056481	FORK WITH REAR TIRE	97
0511056479	LONGITUDINAL TRANSPORT WITHOUT TIRE	98




Item	Code	Description	See page	19 21 23
001	0511062134	LONG TRANS FRAME SDA3E 19		01 00 00
001A	0511062804	LONGIT TRANS FRAME		00 01 01
002	0511062122	RIGHT ROCKER ARM		01 01 01
003	0511062121	LEFT ROCKER ARM		01 01 01
004	0531014044	ROCKER ARM AXLE		02 02 02
005	0521010750	CONICAL SLEEVE		02 02 02
006	0511015383	FLAT WASHER		02 02 02
007	0501010098	3/4" UNC BOLT		02 02 02
008	0503010023	3/4" SPRING WASHER		06 06 06
009	0521010578	COUPLING SHAFT		02 02 02
010	0503030085	LOCK PIN		02 02 02
011	0501051692	14Z GEAR ASSY		02 02 02
012	0503010542	501045 CLAMPING RING (FOR AXLE)		02 02 02
013	0503010004	1890 GREASE FITTING		04 04 04
014	0501050680	CHAIN TENSIONER AXLE ASSY		02 02 02
015	0511015182	3/4" X 1-1/2"C/ BOLT		02 02 02
016	0501055968	RECALL STUB SHAFT & HUB ASSY	34	02 02 02
017	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04 04 04
018	0503010013	5/8 NUT		04 04 04
019	0501055774	0.5"X0.4"X1.1" WHEEL AND TIRE ASSSY		02 02 02
020	0501047216	1.7" X 15.9" X 19" X 2.4" HYDRAULIC CYLINDER	27	01 01 01
021	0501043777	1.7" X 15.9" X 19" X 2.4" HYDRAULIC CYLINDER	28	01 01 01
022	0511062387	CYLINDER ROCKER ARM LOCK PIN		02 02 02
023	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02 02 02
024	0503010019	1/2" SPRING WASHER		02 02 02
025	0503010834	1/2 X 1 BOLT		02 02 02
026	0511062130	MIDDLEMAN BEARING RIGHT SUPPORT		01 01 01
027	0511062131	MIDDLEMAN BEARING LEFT SUPPORT		01 01 01
028	0531012149	CHOCK BEARING		02 02 02
029	0503010233	5/8" X 2-1/2" BOLT		08 08 08
030	0501012140	FLAT WASHER		08 08 08

Item	Code	Description	See page	19 21 23
031	0503010027	5/8 SPRING WASHER		08 08 08
032	0503010013	5/8 NUT		08 08 08
033	0501052968	AGRICULTURAL BEARING ASSY	48	04 04 04
034	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		17 17 17
035	0503010019	1/2" SPRING WASHER		17 17 17
036	0503010060	1/2 UNC G.5 ZN HEX NUT		19 19 19
037	0503010002	1800 GREASE FITTING		08 08 08
038	0521019226	CENTRAL BEARING SUPPORT		01 01 01
039	0503011082	C1/2" X 1.3/4" SCREW		05 05 05
040	0521019239	AXLE AGRICULTURAL BEARING		01 01 01
041	0503012623	3/8" X 1-1/2" BOLT		03 03 03
042	0503012622	3/8" UNF HEX NUT		03 03 03
043	0531010504	RIGHT LIFT ROW AXLE		01 00 00
044	0531010499	LH LIFT ROW AXLE		01 00 00
045	0531010495	RIGHT LIFT ROW AXLE		00 01 01
046	0531010496	LH LIFT ROW AXLE		00 01 01
047	0502011925	AXLE FIXER LOCK		02 02 02
048	0503010395	1/2" X 1-1/4" BOLT		06 06 06
049	0502012524	CYLINDER ARTICULATED SUPPORT		02 02 02
050	0501011787	3/8" X 1-1/2" BOLT		02 02 02
051	0503010014	3/4" HEX NUT		04 04 04
052	0511047998	HYDRAULIC CYLINDER 44.5 X 85.7 X 525 X 195	26	02 02 02
053	0521019210	1.25" X 10.15" AXLE		02 02 02
054	0503010523	1/4" X 2" COTTERPIN		08 08 08
055	0521019604	0.9" X 3.7" COUPLING SHAFT		02 02 02
056	0503010003	1845 GREASE FITTING		02 02 02
057	0521019208	TRANSPORT LOCK		02 02 02
058	0501068994	8,30 X 78 LOCK PIN		02 02 02
059	0503030168	HITCH PIN CLIP		02 02 02
060	0502011922	RATCHET DRIVING		02 02 02
061	0521019222	RATCHET DISMANTLE SUPPORT		02 02 02
062	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		24 24 24
063	0503010025	3/8 SPRING WASHER		26 26 26
064	0503010026	3/8" NUT		26 26 26
065	0521010773	0.37" X 1.18" COUPLING SHAFT		06 06 06
066	0501010984	10,50 X 27 X 3,00 FLAT WASHER		18 18 18
067	0503010257	1/8" X 1" COTTERPIN		10 10 10
068	0501067130	ADJUSTMENT BAR ASSY		02 02 02
069	0521010772	3/4" 19.5" REGULACION		02 02 02
070	0501052972	RIGHT RATCHET CHAIN TENSIONER	47	02 02 02
071	0501052973	LEFT RATCHET CHAIN TENSIONER		02 02 02
072	0501051598	RIGHT TRANSMISSION DRIVING ASSY	32	01 01 01
073	0501051599	LEFT TRANSMISSION DRIVING ASSY	33	01 01 01
074	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02 02 02
075	0531012733	REAR PLATAFORM		01 00 00
076	0531012734	LEFT REAR PLATAFORM		01 00 00
077	0531012735	RH REAR PLATAFORM		00 01 01
078	0531012736	LEFT REAR PLATAFORM		00 01 01
079	0511062120	LOWER PLATAFORM SUPPORT		02 02 02
080	0521019344	0.44" X 3.7" COUPLING SHAFT		02 02 02
081	0521019383	59" LOWER PLATAFORM		01 01 01
082	0511062112	25.6" PLOUGH SUPPORT		02 02 02
083	0501011075	PIN		02 02 02
084	0503030012	HITCH PIN CLIP		02 02 02
085	0501068707	SIMPLE CONNECTION		01 01 01
086	0501068706	DOUBLE CONNECTION		01 01 01
087	0511062113	VALVE FIXATION SUPPORT		01 01 01
088	0531012297	RH CHAIN PROTECTION CAP		01 01 01
089	0531012298	LH CHAIN PROTECTION CAP		01 01 01

Item	Code	Description	See page	19	21	23
090	0521019381	RIGHT SMALLER CHAIN CAP		01	01	01
091	0521019382	LOWER LEFT CHAIN COVER		01	01	01
092	0503010386	CABLE		08	08	08
093	0501049704	DRAWBAR ASSY	43	01	01	01
094	0511014394	1.25" X 4.13" COUPLING SHAFT		02	02	02
095	0501053168	ESTABILIZER DRAWBAR ASSY	49	01	01	01
096	0531010490	AXLE 1.12" X 8"		01	01	01
097	0521010577	0.9" X 4.1" COUPLING SHAFT		01	01	01
098	0502020514	BLOCK 3.7" X 3.4" X 8.7"		15	15	15
099	0531010488	COUNTERBALANCE LATERAL COVER		02	02	02
100	0501047881	AXIS JOINT ASSY		01	01	01
100A	0501068989	COUPLING SHAFT		01	01	01
100B	0503031035	HITCH PIN CLIP		01	01	01
101	0501047884	0.98" ROD STOP		02	02	02
102	0501047885	30 ROD STOP		02	02	02
103	0501047886	35 ROD STOP		02	02	02
104	0501047887	40 ROD STOP		02	02	02
105	0501047888	45 ROD STOP		02	02	02
106	0501047889	1.96" ROD STOP		02	02	02
107	0503010876	2050 CHAIN X 45 LINK + MENDING		02	02	02
108	0503010681	2050 CHAIN X 59 LINK + MENDING		02	02	02
109	0503060100	INSTRUCTIONS MANUAL CANISTER		01	01	01
110	0503010358	5/16" X 5/8" BOLT		01	01	01
111	0503010179	LOCK WASHER 5/16 ZN 1K01528		01	01	01
112	0503010337	5/16" NUT		01	01	01
113	0503010267	NYLON CLAMP		01	01	01
114	0502012525	PIVOT SUPPORT FIXER		02	02	02
115	0521061492	CYLINDER CYLINDER SHAFT		02	02	02
116	0503014950	7/8" UNC X 3" BOLT		04	04	04
117	0503010408	7/8" SPRING WASHER		04	04	04
118	0503010417	7/8" NUT		04	04	04
119	0503010025	3/8 SPRING WASHER		26	26	26
120	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		24	24	24
121	0503010571	1/4" X 1.1/2 COTTERPIN		08	08	08

FRAME ASSY 27


0909091515



Item	Code	Description	See page	QT
001	0511062398	FRAME FOR LONGITUDINAL TRANSPORT		01
002	0511062396	RIGHT ROCKER ARM		01
003	0511062397	LEFT ROCKER ARM		01
004	0531014044	ROCKER ARM AXLE		02
005	0521010750	CONICAL SLEEVE		02
006	0511015383	FLAT WASHER		02
007	0501010098	3/4" UNC BOLT		02
008	0503010023	3/4" SPRING WASHER		05
009	0521010578	COUPLING SHAFT		02
010	0503030085	LOCK PIN		02
011	0501051692	14Z GEAR ASSY		02
012	0503010542	501045 CLAMPING RING (FOR AXLE)		02
013	0503010004	1890 GREASE FITTING		04
014	0501050680	CHAIN TENSIONER AXLE ASSY		02
015	0511015182	3/4" X 1-1/2"C/ BOLT		02
016	0501053140	CARRYING WHEELS WHTOUT TIRE	35	02
017	0511016156	BOLT 5/8 UNC X1.1/2 CS CP G.5 ZN		04
018	0503010013	5/8 NUT		24
019	0503060238	TIRE WHEEL ASSY		02
020	0511059146	HYDRAULIC CYLINDER		02
021	0503010571	1/4" X 1.1/2 COTTERPIN		08
022	0511062387	CYLINDER ROCKER ARM LOCK PIN		02
023	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
024	0503010019	1/2" SPRING WASHER		02
025	0503010834	1/2 X 1 BOLT		02
026	0511062130	MIDDLEMAN BEARING RIGHT SUPPORT		02
027	0511062131	MIDDLEMAN BEARING LEFT SUPPORT		02
028	0531012149	CHOCK BEARING		04
029	0503010233	5/8" X 2-1/2" BOLT		16
030	0501012140	FLAT WASHER		16
031	0503010027	5/8 SPRING WASHER		16

Item	Code	Description	See page	QT
032	0501052968	AGRICULTURAL BEARING ASSY	48	06
033	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		12
034	0503010019	1/2" SPRING WASHER		21
035	0503010060	1/2 UNC G.5 ZN HEX NUT		23
036	0503010002	1800 GREASE FITTING		10
037	0521019226	CENTRAL BEARING SUPPORT		01
038	0503011082	C1/2" X 1.3/4" SCREW		05
039	0521019239	AXLE AGRICULTURAL BEARING		01
040	0503012623	3/8" X 1-1/2" BOLT		03
041	0503012622	3/8" UNF HEX NUT		03
042	0531010236	RIGHT LIFT ROW AXLE		01
043	0531010237	LH LIFT ROW AXLE		01
044	0503060100	INSTRUCTIONS MANUAL CANISTER		01
045	0503010358	5/16" X 5/8" BOLT		01
046	0502011925	AXLE FIXER LOCK		02
047	0503010395	1/2" X 1-1/4" BOLT		06
048	0502012524	CYLINDER ARTICULATED SUPPORT		02
049	0501011787	3/8" X 1-1/2" BOLT		02
050	0503010014	3/4" HEX NUT		04
051	0511047998	HYDRAULIC CYLINDER 44.5 X 85.7 X 525 X 195	26	02
052	0521019210	1.25" X 10.15" AXLE		02
053	0503010523	1/4" X 2" COTTERPIN		08
054	0521061492	CYLINDER CYLINDER SHAFT		02
055	0503010003	1845 GREASE FITTING		02
056	0511010420	8.5" X 1.8" TRANSPORT LOCK		02
057	0501068994	8,30 X 78 LOCK PIN		02
058	0503030168	HITCH PIN CLIP		02
059	0501051598	RIGHT TRANSMISSION DRIVING ASSY	32	01
060	0501051599	LEFT TRANSMISSION DRIVING ASSY	33	01
061	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
062	0502011922	RATCHET DRIVING		02
063	0521019222	RATCHET DISMANTLE SUPPORT		02
064	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		24
065	0503010025	3/8 SPRING WASHER		27
066	0503010026	3/8" NUT		26
067	0521010773	0.37" X 1.18" COUPLING SHAFT		06
068	0501010984	10,50 X 27 X 3,00 FLAT WASHER		18
069	0503010257	1/8" X 1" COTTERPIN		10
070	0501067130	ADJUSTMENT BAR ASSY		02
071	0521010772	3/4" 19.5" REGULACION		02
072	0501052972	RIGHT RATCHET CHAIN TENSIONER	47	02
073	0501052973	LEFT RATCHET CHAIN TENSIONER		02
074	0503010876	2050 CHAIN X 45 LINK + MENDING		02
075	0503010681	2050 CHAIN X 59 LINK + MENDING		02
076	0531012737	RIGHT REAR PLATAFORM		01
077	0531012738	LEFT RAER PLATAFORM		01
078	0511062120	LOWER PLATAFORM SUPPORT		02
079	0521019344	0.44" X 3.7" COUPLING SHAFT		02
080	0521019383	59" LOWER PLATAFORM		01
081	0511062112	25.6" PLOUGH SUPPORT		02
082	0501011075	PIN		02
083	0503030012	HITCH PIN CLIP		02
084	0501068707	SIMPLE CONNECTION		01
085	0501068706	DOUBLE CONNECTION		01
086	0511062113	VALVE FIXATION SUPPORT		01
087	0503034218	CHAIN COVER		01
088	0503034219	LEFT CHAIN COVER		01
089	0521019381	RIGHT SMALLER CHAIN CAP		01
090	0521019382	LOWER LEFT CHAIN COVER		01


Item	Code	Description	See page	QT
091	0503010386	CABLE		08
092	0511040010	DRAWBAR ASSY	45	01
093	0511014394	1.25" X 4.13" COUPLING SHAFT		02
094	0501053168	ESTABILIZER DRAWBAR ASSY	49	01
095	0531010490	AXLE 1.12" X 8"		01
096	0521010577	0.9" X 4.1" COUPLING SHAFT		01
097	0502020514	BLOCK 3.7" X 3.4" X 8.7"		22
098	0531010488	COUNTERBALANCE LATERAL COVER		02
099	0501047881	AXIS JOINT ASSY		01
099A	0501068989	COUPLING SHAFT		01
099B	0503031035	HITCH PIN CLIP		01
100	0501047895	25 ROD STOP		06
101	0501047885	30 ROD STOP		02
102	0501047886	35 ROD STOP		02
103	0501047887	40 ROD STOP		02
104	0501047888	45 ROD STOP		02
105	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
106	0503010337	5/16" NUT		01
107	0502012525	PIVOT SUPPORT FIXER		02
108	0521061492	CYLINDER CYLINDER SHAFT		02
109	0503014950	7/8" UNC X 3" BOLT		04
110	0503010408	7/8" SPRING WASHER		04
111	0503010417	7/8" NUT		04



Item	Code	Description	See page	QT
001	0511058928	CONJUGATED BOX	4	01
002	0511062294	SEED BOX COVER		01
003	0511062295	FERTILIZER BOX COVER		01
004	0521011116	COVER PIVOT BUSHING		04
005	0503010421	5/16" X 1-1/2" BOLT		04
006	0501010694	FLAT WASHER		04
007	0503010179	LOCK WASHER 5/16 ZN 1K01528		15
008	0503010337	5/16" NUT		16
009	0501051927	COVER PIVOT SHAFT ASSY	55	04
010	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
011	0503010025	3/8 SPRING WASHER		08
012	0503010026	3/8" NUT		08
013	0511062272	94.5" HANDRAIL		01
014	0503010358	5/16" X 5/8" BOLT		04
015	0503011907	NYLON HANDLE		02
016	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
017	0511062136	GEAR SUPPORT		02
018	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
019	0503030573	1-1/2" X 2" X 400 HOSE		15
020	0503031145	2" X 2" X 20" HOSE		15
021	0503031076	2" HOSE CLAMP		45
022	0503030887	1-1/2" HOSE CLAMP		15
023	0541012961	FIXER COUNTER HECTARE		01
024	0503060718	ELECTRONIC BLADE HECTARE		01
025	0541013031	HETARE MAGNET FASTENER		01
026	0503060718	ELECTRONIC BLADE HECTARE		01
027	0501010694	FLAT WASHER		04
028	0541015265	RECEIVER MAGNETIC SUPPORT		01
029	0551011948	FIXER BLADE HECTARE		01
030	0503011952	5/16" X 3/4" BOLT		02

CONJUGATED BOX

0511058928




Item	Code	Description	See page	QT
001	0511062285	BOX FERTILIZER SEED		01
002	0501052081	RH BEARING SEED BOX	51	01
003	0501052082	LH BEARING SEED BOX	52	01
004	0503011441	SPRING WASHER		34
005	0503010144	1/4" NUT		36
006	0501053303	KIT DISTRIBUTOR	76	15
007	0511015485	48.6" RIGHT AXLE		01
008	0511015486	54.7" LH AXLE		01
009	0503010257	1/8" X 1" COTTERPIN		30
010	0501052990	AGRICULTURAL BEARING	77	02
011	0511058488	OUTPUT SIDE FERTILIZER DISTRIBUTOR	42	15
012	0503030275	AGRICULTURAL BEARING		15
013	1902010685	18Z CONICAL GEAR		15
014	0503011443	3/8" SPRING WASHER		68
015	0503032078	SPACING SLEEVE		02
016	0502011300	SPROCKET BUSHING		02
017	0502011314	8Z P 1.1/4" RH1.4" GEAR		02
018	0501012370	SEED EXIT COVER		08
019	0503010282	1/4" X 3/4" BOLT		32
020	0511015527	SCALE SUPPORT		02
021	0503030886	SCALE DOSER		02
022	0503032077	LARGE DOSER		02
023	0503010292	701164 6 X 40 SPRING PIN		02
024	0503010001	3.2 X 5.5 RIVET		04
025	0501011768	SPRING FIXER		02
026	0521010691	AXLE FASTENER		02
027	0503010010	1/4" X 2.1/2" COTTERPIN		04
028	0502011345	18Z P 1.25" RH1.3/8" GEAR		02
029	0503030242	0.8" X 4.7" X 0.08" TRACTION SPRING		02
030	0501043283	ASSY LEFT CHAIN STRETCHER	54	01
031	0501043282	RIGHT CHAIN TENSIONER ASSY	53	01


CONJUGATED BOX

0511058928

Item	Code	Description	See page	QT
032	0503034396	FERTILIZER SIDE COVER		15
033	0503010362	1/8 X 1.1/4 COTTERPIN		15
034	0501011643	3/8 X 1"BOLT		60
035	0503010026	3/8" NUT		68
036	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
037	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		08
038	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
039	0503010144	1/4" NUT		02
040	0501010694	FLAT WASHER		32
041	0501011098	RIGHT AXLE		01
042	0501011099	LH AXLE		01




Item	Code	Description	See page	QT
001	0511059101	BOX FERTILIZER SEED	6	01
002	0501069926	54.1" HANDRAIL		01
003	0503010179	LOCK WASHER 5/16 ZN 1K01528		15
004	0503010337	5/16" NUT		16
005	0503010358	5/16" X 5/8" BOLT		04
006	0511062136	GEAR SUPPORT		01
007	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
008	0503010025	3/8 SPRING WASHER		06
009	0503010026	3/8" NUT		06
010	0511062490	RH FERTILIZER BOX COVER		01
011	0511062488	RH SEED BOX COVER		01
012	0521011116	COVER PIVOT BUSHING		04
013	0501051927	COVER PIVOT SHAFT ASSY	55	04
014	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
015	0503010421	5/16" X 1-1/2" BOLT		04
016	0501010694	FLAT WASHER		08
017	0503011907	NYLON HANDLE		02
018	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
019	0503030887	1-1/2" HOSE CLAMP		09
020	0503030573	1-1/2" X 2" X 400 HOSE		09
021	0503031076	2" HOSE CLAMP		27
022	0503031145	2" X 2" X 20" HOSE		09
023	0541012961	FIXER COUNTER HECTARE		01
024	0503060718	ELECTRONIC BLADE HECTARE		01
025	0541015265	RECEIVER MAGNETIC SUPPORT		01
026	0551011948	FIXER BLADE HECTARE		01
027	0503011952	5/16" X 3/4" BOLT		02
028	0541013031	HETARE MAGNET FASTENER		01




Item	Code	Description	See page	QT
001	0511062475	RIGHT BOX FERTILIZER SEED		01
002	0511015467	60.2" RIGHT AXLE		01
003	0501053303	KIT DISTRIBUTOR	76	09
004	0501052081	RH BEARING SEED BOX	51	01
005	0503010778	1/8" X 1.1/2" COTTERPIN		18
006	0511015527	SCALE SUPPORT		01
007	0503032077	LARGE DOSER		01
008	0503030886	SCALE DOSER		01
009	0503010001	3.2 X 5.5 RIVET		02
010	0503010292	701164 6 X 40 SPRING PIN		01
011	0501052990	AGRICULTURAL BEARING	77	01
012	0501011768	SPRING FIXER		01
013	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
014	0511058488	OUTPUT SIDE FERTILIZER DISTRIBUTOR	42	09
015	0501011345	RIGHT AXLE		01
016	0503030275	AGRICULTURAL BEARING		09
017	1902010685	18Z CONICAL GEAR		09
018	0521010691	AXLE FASTENER		01
019	0503010144	1/4" NUT		21
020	0503010143	1/4" SPRING WASHER		20
021	0503034396	FERTILIZER SIDE COVER		09
022	0503010362	1/8 X 1.1/4 COTTERPIN		09
023	0502011300	SPROCKET BUSHING		01
024	0503032078	SPACING SLEEVE		01
025	0502011314	8Z P 1.1/4" RH1.4" GEAR		01
026	0502011345	18Z P 1.25" RH1.3/8" GEAR		01
027	0501043282	RIGHT CHAIN TENSIONER ASSY	53	01
028	0503010010	1/4" X 2.1/2" COTTERPIN		02
029	0503030242	0.8" X 4.7" X 0.08" TRACTION SPRING		01
030	0501012370	SEED EXIT COVER		05
031	0503010282	1/4" X 3/4" BOLT		20

Item	Code	Description	See page	QT
032	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
033	0503011443	3/8" SPRING WASHER		40
034	0503010026	3/8" NUT		40
035	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
036	0503011441	SPRING WASHER		01
037	0501011643	3/8 X 1"BOLT		36
038	0501010694	FLAT WASHER		20




Item	Code	Description	See page	QT
001	0511059102	LH BOX FERTILIZER SEED	8	01
002	0501069925	61" HANDRAIL		01
003	0503010179	LOCK WASHER 5/16 ZN 1K01528		12
004	0503010337	5/16" NUT		12
005	0503010358	5/16" X 5/8" BOLT		04
006	0511062136	GEAR SUPPORT		01
007	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
008	0503010025	3/8 SPRING WASHER		06
009	0503010026	3/8" NUT		06
010	0511062491	LH FERTILIZER BOX COVER		01
011	0511062489	LH SEED BOX COVER		01
012	0521011116	COVER PIVOT BUSHING		04
013	0503010421	5/16" X 1-1/2" BOLT		04
014	0501010694	FLAT WASHER		04
015	0501051927	COVER PIVOT SHAFT ASSY	55	04
016	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
017	0503011907	NYLON HANDLE		02
018	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
019	0503030887	1-1/2" HOSE CLAMP		10
020	0503030573	1-1/2" X 2" X 400 HOSE		10
021	0503031076	2" HOSE CLAMP		30
022	0503031145	2" X 2" X 20" HOSE		10
023	0541015265	RECEIVER MAGNETIC SUPPORT		01
024	0551011948	FIXER BLADE HECTARE		01
025	0503011952	5/16" X 3/4" BOLT		02
026	0541013031	HETARE MAGNET FASTENER		01



Item	Code	Description	See page	QT
001	0511062476	LEFT BOX FERTILIZER SEED		01
002	0511015468	66.7" LH AXLE		01
003	0501011344	LH AXLE		01
004	0501052082	LH BEARING SEED BOX	52	01
005	0501052990	AGRICULTURAL BEARING	77	01
006	0501011768	SPRING FIXER		01
007	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
008	0521010691	AXLE FASTENER		01
009	0503010144	1/4" NUT		21
010	0503010143	1/4" SPRING WASHER		20
011	0502011300	SPROCKET BUSHING		01
012	0503032078	SPACING SLEEVE		01
013	0502011314	8Z P 1.1/4" RH1.4" GEAR		01
014	0503010010	1/4" X 2.1/2" COTTERPIN		02
015	0503030242	0.8" X 4.7" X 0.08" TRACTION SPRING		01
016	0502011345	18Z P 1.25" RH1.3/8" GEAR		01
017	0501043283	ASSY LEFT CHAIN STRETCHER	54	01
018	0511058488	OUTPUT SIDE FERTILIZER DISTRIBUTOR	42	10
019	0503030275	AGRICULTURAL BEARING		10
020	1902010685	18Z CONICAL GEAR		10
021	0503034396	FERTILIZER SIDE COVER		10
022	0503010362	1/8 X 1.1/4 COTTERPIN		10
023	0501053303	KIT DISTRIBUTOR	76	10
024	0503010778	1/8" X 1.1/2" COTTERPIN		20
025	0511015527	SCALE SUPPORT		01
026	0503032077	LARGE DOSER		01
027	0503030886	SCALE DOSER		01
028	0503010001	3.2 X 5.5 RIVET		02
029	0503010292	701164 6 X 40 SPRING PIN		01
030	0501012370	SEED EXIT COVER		05
031	0501010694	FLAT WASHER		20


Item	Code	Description	See page	QT
032	0503010282	1/4" X 3/4" BOLT		20
033	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
034	0503011443	3/8" SPRING WASHER		44
035	0503010026	3/8" NUT		44
036	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
037	0503011441	SPRING WASHER		01
038	0501011643	3/8 X 1"BOLT		40



Item	Code	Description	See page	QT
001	0511058663	RIGHT CONJUGATED BOX	10	01
002	0503030886	SCALE DOSER		01
003	0503010001	3.2 X 5.5 RIVET		02
004	0501012370	SEED EXIT COVER		06
005	0503010282	1/4" X 3/4" BOLT		24
006	0501010694	FLAT WASHER		24
007	0503010143	1/4" SPRING WASHER		24
008	0503010144	1/4" NUT		24
009	0503050060	SEED DISTRIBUTOR BOX SWITCH		11
010	0511062525	RH FERTILIZER BOX COVER		01
011	0511062526	RH SEED BOX COVER		01
012	0503010421	5/16" X 1-1/2" BOLT		04
013	0521011116	COVER PIVOT BUSHING		04
014	0501010694	FLAT WASHER		04
015	0503010179	LOCK WASHER 5/16 ZN 1K01528		12
016	0503010337	5/16" NUT		12
017	0501051927	COVER PIVOT SHAFT ASSY	55	04
018	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
019	0503010025	3/8 SPRING WASHER		06
020	0503010026	3/8" NUT		04
021	0503010140	1/8" X 3/4" COTTERPIN		04
022	0503011907	NYLON HANDLE		02
023	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
024	0501069930	67.9" HANDRAIL		01
025	0503010358	5/16" X 5/8" BOLT		04
026	0511062136	GEAR SUPPORT		01
027	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
028	0502011345	18Z P 1.25 RH 1.3/8" GEAR		02
029	0503010010	1/4" X 2.1/2" COTTERPIN		01
030	0503030573	1-1/2" X 2" X 400 HOSE		11
031	0503031145	2" X 2" X 20" HOSE		11




Item	Code	Description	See page	QT
032	0503030756	SOCKET FASTENER		11
033	0503010369	SEED SOCKET		11
034	0503030887	1-1/2" HOSE CLAMP		11
035	0503031076	2" HOSE CLAMP		33



Item	Code	Description	See page	QT
01	0511062524	RIGHT BOX FERTILIZER SEED		01
02	0511015483	72.6" RIGHT AXLE		01
03	0501053303	KIT DISTRIBUTOR	76	11
04	0501052081	RH BEARING SEED BOX	51	01
05	0503010257	1/8" X 1" COTTERPIN		22
06	0511015527	SCALE SUPPORT		01
07	0503032077	LARGE DOSER		01
08	0503030886	SCALE DOSER		01
09	0503010001	3.2 X 5.5 RIVET		02
10	0503010292	701164 6 X 40 SPRING PIN		01
11	0501052990	AGRICULTURAL BEARING	77	01
12	0501011768	SPRING FIXER		01
13	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
14	0511058488	OUTPUT SIDE FERTILIZER DISTRIBUTOR	42	11
15	0511010866	RIGHT AXLE		01
16	0503030275	AGRICULTURAL BEARING		11
17	0502011412	18Z CONICAL GEAR		11
18	0521010691	AXLE FASTENER		01
19	0503010144	1/4" NUT		21
20	0503010143	1/4" SPRING WASHER		21
21	0503034396	FERTILIZER SIDE COVER		11
22	0503010362	1/8 X 1.1/4 COTTERPIN		11
23	0502011300	SPROCKET BUSHING		01
24	0503032078	SPACING SLEEVE		01
25	0502011314	8Z P 1.1/4" RH1.4" GEAR		01
26	0502011345	18Z P 1.25" RH1.3/8" GEAR		01
27	0501043282	RIGHT CHAIN TENSIONER ASSY	53	01
28	0503010010	1/4" X 2.1/2" COTTERPIN		02
29	0503030242	0.8" X 4.7" X 0.08" TRACTION SPRING		01
30	0501012370	SEED EXIT COVER		06
31	0503010282	1/4" X 3/4" BOLT		24


Item	Code	Description	See page	QT
32	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
33	0503011443	3/8" SPRING WASHER		48
34	0503010026	3/8" NUT		48
35	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
36	0503011441	SPRING WASHER		01
37	0501011643	3/8 X 1"BOLT		44
38	0501010694	FLAT WASHER		24



Item	Code	Description	See page	QT
001	0511058664	LH BOX FERTILIZER SEED	12	01
002	0503030886	SCALE DOSER		01
003	0503010001	3.2 X 5.5 RIVET		02
004	0501012370	SEED EXIT COVER		06
005	0503010282	1/4" X 3/4" BOLT		24
006	0501010694	FLAT WASHER		24
007	0503010143	1/4" SPRING WASHER		24
008	0503010144	1/4" NUT		24
009	0503050060	SEED DISTRIBUTOR BOX SWITCH		11
010	0511062297	LH FERTILIZER BOX COVER		01
011	0511062296	LH SEED BOX COVER		01
012	0503010421	5/16" X 1-1/2" BOLT		04
013	0521011116	COVER PIVOT BUSHING		04
014	0501010694	FLAT WASHER		04
015	0503010179	LOCK WASHER 5/16 ZN 1K01528		12
016	0503010337	5/16" NUT		12
017	0501051927	COVER PIVOT SHAFT ASSY	55	04
018	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
019	0503010025	3/8 SPRING WASHER		06
020	0503010026	3/8" NUT		04
021	0503010140	1/8" X 3/4" COTTERPIN		04
022	0503011907	NYLON HANDLE		02
023	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
024	0501069930	67.9" HANDRAIL		01
025	0503010358	5/16" X 5/8" BOLT		04
026	0511062136	GEAR SUPPORT		01
027	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
028	0502011345	18Z P 1.25" RH1.3/8" GEAR		02
029	0503010010	1/4" X 2.1/2" COTTERPIN		01
030	0503030573	1-1/2" X 2" X 400 HOSE		11
031	0503031145	2" X 2" X 20" HOSE		11




Item	Code	Description	See page	QT
032	0503030756	SOCKET FASTENER		11
033	0503010369	SEED SOCKET		11
034	0503030887	1-1/2" HOSE CLAMP		11
035	0503031076	2" HOSE CLAMP		33




Item	Code	Description	See page	QT
01	0511062288	LH FERTILIZER SEED BOX		01
02	0511015484	78.7" LH AXLE		01
03	0511010865	LH AXLE		01
04	0501052082	LH BEARING SEED BOX	52	01
05	0501052990	AGRICULTURAL BEARING	77	01
06	0501011768	SPRING FIXER		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
08	0521010691	AXLE FASTENER		01
09	0503010144	1/4" NUT		25
10	0503010143	1/4" SPRING WASHER		24
11	0502011300	SPROCKET BUSHING		01
12	0503032078	SPACING SLEEVE		01
13	0502011314	8Z P 1.1/4" RH1.4" GEAR		01
14	0503010010	1/4" X 2.1/2" COTTERPIN		02
15	0503030242	0.8" X 4.7" X 0.08" TRACTION SPRING		01
16	0502011345	18Z P 1.25" RH1.3/8" GEAR		01
17	0501043283	ASSY LEFT CHAIN STRETCHER	54	01
18	0511058488	OUTPUT SIDE FERTILIZER DISTRIBUTOR	42	12
19	0503030275	AGRICULTURAL BEARING		12
20	0502011412	18Z CONICAL GEAR		12
21	0503034396	FERTILIZER SIDE COVER		12
22	0503010362	1/8 X 1.1/4 COTTERPIN		12
23	0501053303	KIT DISTRIBUTOR	76	12
24	0503010257	1/8" X 1" COTTERPIN		24
25	0511015527	SCALE SUPPORT		01
26	0503032077	LARGE DOSER		01
27	0503030886	SCALE DOSER		01
28	0503010001	3.2 X 5.5 RIVET		02
29	0503010292	701164 6 X 40 SPRING PIN		01
30	0501012370	SEED EXIT COVER		06
31	0501010694	FLAT WASHER		24


Item	Code	Description	See page	QT
32	0503010282	1/4" X 3/4" BOLT		24
33	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
34	0503011443	3/8" SPRING WASHER		52
35	0503010026	3/8" NUT		52
36	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
37	0503011441	SPRING WASHER		01
38	0501011643	3/8 X 1"BOLT		48



Item	Code	Description	See page	QT
001	0511058663	RIGHT CONJUGATED BOX	10	01
002	0501069930	67.9" HANDRAIL		01
003	0503010179	LOCK WASHER 5/16 ZN 1K01528		15
004	0503010337	5/16" NUT		16
005	0503010358	5/16" X 5/8" BOLT		04
006	0511062136	GEAR SUPPORT		01
007	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
008	0503010025	3/8 SPRING WASHER		06
009	0503010026	3/8" NUT		06
010	0511062525	RH FERTILIZER BOX COVER		01
011	0511062526	RH SEED BOX COVER		01
012	0521011116	COVER PIVOT BUSHING		04
013	0501051927	COVER PIVOT SHAFT ASSY	55	04
014	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
015	0503010421	5/16" X 1-1/2" BOLT		04
016	0501010694	FLAT WASHER		08
017	0503011907	NYLON HANDLE		02
018	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
019	0503030887	1-1/2" HOSE CLAMP		09
020	0503030573	1-1/2" X 2" X 400 HOSE		09
021	0503031076	2" HOSE CLAMP		27
022	0503031145	2" X 2" X 20" HOSE		09
023	0541012961	FIXER COUNTER HECTARE		01
024	0503060718	ELECTRONIC BLADE HECTARE		01
025	0541015265	RECEIVER MAGNETIC SUPPORT		01
026	0551011948	FIXER BLADE HECTARE		01
027	0503011952	5/16" X 3/4" BOLT		02
028	0541013031	HETARE MAGNET FASTENER		01




Item	Code	Description	See page	QT
001	0511058664	LH BOX FERTILIZER SEED	12	01
002	0501069930	67.9" HANDRAIL		01
003	0503010179	LOCK WASHER 5/16 ZN 1K01528		12
004	0503010337	5/16" NUT		12
005	0503010358	5/16" X 5/8" BOLT		04
006	0511062136	GEAR SUPPORT		01
007	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
008	0503010025	3/8 SPRING WASHER		06
009	0503010026	3/8" NUT		06
010	0511062297	LH FERTILIZER BOX COVER		01
011	0511062296	LH SEED BOX COVER		01
012	0521011116	COVER PIVOT BUSHING		04
013	0503010421	5/16" X 1-1/2" BOLT		04
014	0501010694	FLAT WASHER		04
015	0501051927	COVER PIVOT SHAFT ASSY	55	04
016	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
017	0503011907	NYLON HANDLE		02
018	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
019	0503030887	1-1/2" HOSE CLAMP		10
020	0503030573	1-1/2" X 2" X 400 HOSE		10
021	0503031076	2" HOSE CLAMP		30
022	0503031145	2" X 2" X 20" HOSE		10
023	0541015265	RECEIVER MAGNETIC SUPPORT		01
024	0551011948	FIXER BLADE HECTARE		01
025	0503011952	5/16" X 3/4" BOLT		02
026	0541013031	HETARE MAGNET FASTENER		01



Item	Code	Description	See page	QT
001	0511059225	RH BOX FERTILIZER SEED FINE	16	01
002	0503030886	SCALE DOSER		01
003	0503010001	3.2 X 5.5 RIVET		02
004	0501012370	SEED EXIT COVER		07
005	0503010282	1/4" X 3/4" BOLT		28
006	0501010694	FLAT WASHER		28
007	0503010143	1/4" SPRING WASHER		28
008	0503010144	1/4" NUT		28
009	0511062525	RH FERTILIZER BOX COVER		01
010	0511062526	RH SEED BOX COVER		01
011	0503010421	5/16" X 1-1/2" BOLT		04
012	0521011116	COVER PIVOT BUSHING		04
013	0501010694	FLAT WASHER		04
014	0503010179	LOCK WASHER 5/16 ZN 1K01528		12
015	0503010337	5/16" NUT		12
016	0501051927	COVER PIVOT SHAFT ASSY	55	04
017	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
018	0503010025	3/8 SPRING WASHER		06
019	0503010026	3/8" NUT		04
021	0503011907	NYLON HANDLE		02
022	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
023	0501069930	67.9" HANDRAIL		01
024	0503010358	5/16" X 5/8" BOLT		04
025	0511062136	GEAR SUPPORT		01
026	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
027	0502011345	18Z P 1.25" RH1.3/8" GEAR		02
028	0503010010	1/4" X 2.1/2" COTTERPIN		01
029	0503030573	1-1/2" X 2" X 400 HOSE		13
030	0503031145	2" X 2" X 20" HOSE		13
031	0503030756	SOCKET FASTENER		13
032	0503010369	SEED SOCKET		13




Item	Code	Description	See page	QT
033	0503030887	1-1/2" HOSE CLAMP		13
034	0503031076	2" HOSE CLAMP		39



Item	Code	Description	See page	QT
01	0511062401	RIGHT CONJUGATED BOX		01
02	0531010254	RIGHT SEED BOX AXLE		01
03	0503030180	SEED DISTRIBUTOR BOX		14
04	0501040236	SEED LIMETER	50	14
05	0503010366	ROTOR GUIDE		14
06	0502010950	ROTOR		14
07	0501011064	ROTOR WHASHER		14
08	0503010370	502072 CLAMPING RING (FOR AXLE)		14
09	0501010637	FLAT WASHER		28
10	0503010778	1/8" X 1.1/2" COTTERPIN		28
11	0503010292	701164 6 X 40 SPRING PIN		02
12	0511015527	SCALE SUPPORT		01
13	0503032077	LARGE DOSER		01
14	0503013813	1/4" UNC X 7/8" BOLT		56
15	0511017303	FLAT WASHER		58
16	0503011441	SPRING WASHER		56
17	0503010144	1/4" NUT		56
18	0501053461	RH BEARING BOX FINE SEED		01
19	0511058488	OUTPUT SIDE FERTILIZER DISTRIBUTOR	42	14
20	0501011643	3/8 X 1" BOLT		56
21	0503011443	3/8" SPRING WASHER		56
22	0503010026	3/8" NUT		56
23	0501052990	AGRICULTURAL BEARING	77	01
24	0501011768	SPRING FIXER		01
25	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
26	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
27	0503011443	3/8" SPRING WASHER		02
28	0521010691	AXLE FASTENER		01
29	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
30	0531010256	RIGHT FERTILIZER BOX AXLE		01
31	0503030275	AGRICULTURAL BEARING		14


Item	Code	Description	See page	QT
32	1902010685	18Z CONICAL GEAR		14
33	0503032078	SPACING SLEEVE		01
34	0502011300	SPROCKET BUSHING		01
35	0502011314	8Z P 1.1/4" RH1.4" GEAR		01
36	0503010010	1/4" X 2.1/2" COTTERPIN		01
37	0503030189	COMPRES SPRING		14



Item	Code	Description	See page	QT
001	0511059226	LH BOX FERTILIZER SEED FINE	18	01
002	0503030886	SCALE DOSER		01
003	0503010001	3.2 X 5.5 RIVET		02
004	0501012370	SEED EXIT COVER		07
005	0503010282	1/4" X 3/4" BOLT		28
006	0501010694	FLAT WASHER		28
007	0503010143	1/4" SPRING WASHER		28
008	0503010144	1/4" NUT		28
009	0511062485	LEFT FERTILIZER BOX CAP		01
010	0511062487	LEFT SEED BOX CAP		01
011	0503010421	5/16" X 1-1/2" BOLT		04
012	0521011116	COVER PIVOT BUSHING		04
013	0501010694	FLAT WASHER		04
014	0503010179	LOCK WASHER 5/16 ZN 1K01528		12
015	0503010337	5/16" NUT		12
016	0501051927	COVER PIVOT SHAFT ASSY	55	04
017	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
018	0503010025	3/8 SPRING WASHER		06
019	0503010026	3/8" NUT		04
020	0503011907	NYLON HANDLE		02
021	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
022	0501069930	67.9" HANDRAIL		01
023	0503010358	5/16" X 5/8" BOLT		04
024	0511062136	GEAR SUPPORT		01
025	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
026	0502011345	18Z P 1.25" RH1.3/8" GEAR		02
027	0503010010	1/4" X 2.1/2" COTTERPIN		01
028	0503030573	1-1/2" X 2" X 400 HOSE		14
029	0503031145	2" X 2" X 20" HOSE		14
030	0503030756	SOCKET FASTENER		14
031	0503010369	SEED SOCKET		14




Item	Code	Description	See page	QT
032	0503030887	1-1/2" HOSE CLAMP		14
033	0503031076	2" HOSE CLAMP		42




Item	Code	Description	See page	QT
001	0511062402	LEFT CONJUGATED BOX		01
002	0531010255	LEFT SEED BOX AXLE		01
003	0503030180	SEED DISTRIBUTOR BOX		14
004	0501040236	SEED LIMETER	50	14
005	0503010366	ROTOR GUIDE		14
006	0502010950	ROTOR		14
007	0501011064	ROTOR WHASHER		14
008	0503010370	502072 CLAMPING RING (FOR AXLE)		14
009	0501010637	FLAT WASHER		28
010	0503010778	1/8" X 1.1/2" COTTERPIN		28
011	0503010292	701164 6 X 40 SPRING PIN		02
012	0511015527	SCALE SUPPORT		01
013	0503032077	LARGE DOSER		01
014	0503013813	1/4" UNC X 7/8" BOLT		56
015	0511017303	FLAT WASHER		**
016	0503011441	SPRING WASHER		56
017	0503010144	1/4" NUT		56
018	0501053462	LEFT BEARING BOX FOR FINE SEED		01
019	0511058488	OUTPUT SIDE FERTILIZER DISTRIBUTOR	42	14
020	0501011643	3/8 X 1" BOLT		56
021	0503011443	3/8" SPRING WASHER		56
022	0503010026	3/8" NUT		56
023	0501052990	AGRICULTURAL BEARING	77	01
024	0501011768	SPRING FIXER		01
025	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
026	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
027	0503011443	3/8" SPRING WASHER		02
028	0521010691	AXLE FASTENER		01
029	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
030	0531010257	LEFT FERTILIZER BOX AXLE		01
031	0503030275	AGRICULTURAL BEARING		14

Item	Code	Description	See page	QT
032	1902010685	18Z CONICAL GEAR		14
033	0503032078	SPACING SLEEVE		01
034	0502011300	SPROCKET BUSHING		01
035	0502011314	8Z P 1.1/4" RH1.4" GEAR		01
036	0503010010	1/4" X 2.1/2" COTTERPIN		01
037	0503030189	COMPRES SPRING		14



Item	Code	Description	See page	QT
01	0501066472	ROW MARKER ARM RIGHT SUPPORT		01
02	0501067717	ROW MARKER ARM LEFT SUPPORT		01
03	0502011170	FIXER		04
04	0503011084	3/4" X 5" BOLT		08
05	0503010023	3/4" SPRING WASHER		11
06	0503010014	3/4" HEX NUT		11
07	0501069470	ROW MARKER ARM		02
08	0503010769	5/8" X 2-1/4" BOLT		04
09	0521010479	SLEEVE ARTICULATION		04
10	0501012140	FLAT WASHER		04
11	0503010013	5/8 NUT		04
12	0511058449	HYDRAULIC CYLINDER		02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010571	1/4" X 1.1/2 COTTERPIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" COTTERPIN		02
17	0503011070	BEATER		02
18	0503010019	1/2" SPRING WASHER		02
19	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
20	0501066949	1235 TURNBUCKLE		02
21	0501054886	ROW MARKER DISC	21	02
22	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
23	0501068994	8,30 X 78 LOCK PIN		02
24	0503030168	HITCH PIN CLIP		02
25	0503011267	5/8 UNC X 1.1/2 C S G.5 ZN BOLT		04



Item	Code	Description	See page	QT
01	0501066472	ROW MARKER ARM RIGHT SUPPORT		01
02	0501067717	ROW MARKER ARM LEFT SUPPORT		01
03	1902011170	FIXER		04
04	0503011084	3/4" X 5" BOLT		04
05	0503010023	3/4" SPRING WASHER		04
06	0503010014	3/4" HEX NUT		04
07	0511061811	ROW MARKER ARM		02
08	0503010769	5/8" X 2-1/4" BOLT		04
09	0521010479	SLEEVE ARTICULATION		04
10	0503010013	5/8 NUT		04
11	0511058449	HYDRAULIC CYLINDER		02
12	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
13	0503010571	1/4" X 1.1/2 COTTERPIN		02
14	0511015779	1" X 4.2" AXLE		02
15	0503010523	1/4" X 2" COTTERPIN		02
16	0503011070	BEATER		02
17	0503010019	1/2" SPRING WASHER		02
18	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
19	0501066949	1235 TURNBUCKLE		02
20	0503011267	5/8 UNC X 1.1/2 C S G.5 ZN BOLT		04
21	0501054886	ROW MARKER DISC	21	02
22	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
23	0501068994	8,30 X 78 LOCK PIN		02
24	0503030168	HITCH PIN CLIP		02
25	0501044565	SEQUENCE VALVE		01
26	0503010256	3/8" X 3/4" BOLT		02
27	0503010025	3/8 SPRING WASHER		02
28	0521050451	HOSE HYDRAULIC MARKER GAME		01
28A	0501080442	3/8" X 130" TC-TC HOSE ASSY		01
28B	0501080390	3/8" X 150" TR-TC HOSE ASSY		02
28C	0501080418	3/8" X 165" TR-TC HOSE ASSY		02


**HYDRAULIC MARKER ASSY**

0511055774

Item	Code	Description	See page	QT
29	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		02
30	0501012140	FLAT WASHER		04

ROW MARKER DISC

0501054886




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY	01	
02	0502011907	DEPTH CONTROL WHEEL HUB	01	
03	0602023094	DR16X3 C36AFPAFR73+4FR+4FR D474 10R	01	
04	0503010269	6204 BALL BEARING	02	
05	0501013636	SPACING SLEEVE	01	
06	0503010689	SEAL 00763-BR	01	
07	0503011105	SEAL RING	01	
08	0503030757	2.9" X 2" X 0.02" JOINT	01	
09	0521019178	PROTECTION LID	01	
10	0503011441	SPRING WASHER	03	
11	0503014729	1/4" UNF X 1/2" BOLT	03	
12	0503010878	5/8" SELF ALIGNING NUT	01	
13	0503010691	1/4" GREASE FITTING	01	
14	0503010358	5/16" X 5/8" BOLT	04	
15	0503011444	SPRING WASHER	04	
16	0503010337	5/16" NUT	04	
17	0503810023	PRESSURE WASHER	01	
18	0503010014	3/4" HEX NUT	01	
19	0501069226	ROW MARKER ROD STOP	01	
20	0501011778	3/8" X 2-1/2" BOLT	04	
21	0503011443	3/8" SPRING WASHER	04	
22	0503010026	3/8" NUT	04	

CIRCUITO HIDRÁULICO SDA3E 19


Comando Duplo

Válvula Tripla




Item	Code	Description	See page	QT
01	0501080221	3/8" X 25.6 TR-TR HOSE ASSY		01
02	0501080427	3/8" X 60" TR-TR HOSE ASSY		01
03	0501080550	3/8" X 55.12" TC-TM HOSE		01
04	0501080379	TR-TR HOSE ASSY		02
05	0501080452	3/8" X 98" TR-TR HOSE		02
06	0501080435	3/8" X 3600 TR-TC HOSE		02
07	0501080365	HOSE 3/8 X 3500 TC-TM		03
08	0501041997	VALVE ASSY	29	01
09	0501053834	MALE QUICK COUPLER		04
09A	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		04
09B	0503011882	MALE QUICK COUPLER CAP		04

CIRCUITO HIDRÁULICO SDA3E 21 e 23
Comando Duplo
Válvula Tripla




Item	Code	Description	See page	QT
01	0501080221	3/8" X 25.6 TR-TR HOSE ASSY		01
02	0501080427	3/8" X 60" TR-TR HOSE ASSY		01
03	0501080550	3/8" X 55.12" TC-TM HOSE		01
04	0501080804	3/8" X 125" TR-TR HOSE ASSY		02
05	0501080297	3/8 X 2800 TR-TR HOSE		02
06	0501080435	3/8" X 3600 TR-TC HOSE		02
07	0501080365	HOSE 3/8 X 3500 TC-TM		03
08	0501041997	VALVE ASSY	29	01
09	0501053834	MALE QUICK COUPLER		04
09A	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		04
09B	0503011882	MALE QUICK COUPLER CAP		04

Circuito Hidráulico SDA3E 27/29.
Comando Duplo
Válvula Tripla
Marcador hidráulico




Item	Code	Description	See page	QT
01	0501080048	3/8" X 78" TR-TR HOSE ASSY		01
02	0501080423	3/8" X 14" TR-TR HOSE ASSY		02
03	0501080298	3/8" X 124" TR-TR HOSE ASSY		02
04	0501080342	TR-TR HOSE ASSY		01
05	0501080715	3/8" X 177" TR-TC HOSE ASSY		02
06	0501080365	HOSE 3/8 X 3500 TC-TM		04
07	0501080468	3/8" X 12" TR-TR HOSE ASSY		01
08	0501080442	3/8" X 130" TC-TC HOSE ASSY		01
09	0501080390	3/8" X 150" TR-TC HOSE ASSY		02
10	0501080418	3/8" X 165" TR-TC HOSE ASSY		02
11	0501041997	VALVE ASSY	29	01
12	0501044565	SEQUENCE VALVE		01
13	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		04


CIRCUITO HIDRÁULICO SDA3E 27/29
Comando Duplo
Válvula Tripla




Item	Code	Description	See page	QT
01	0501080048	3/8" X 78" TR-TR HOSE ASSY		01
02	0501080550	3/8" X 55.12" TC-TM HOSE		01
03	0501080423	3/8" X 14" TR-TR HOSE ASSY		02
04	0501080298	3/8" X 124" TR-TR HOSE ASSY		02
05	0501080427	3/8" X 60" TR-TR HOSE ASSY		01
06	0501080715	3/8" X 177" TR-TC HOSE ASSY		02
07	0501080365	HOSE 3/8 X 3500 TC-TM		03
08	0501041997	VALVE ASSY	29	01
09	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		04




Item	Code	Description	See page	QT
01	0521060812	STEM		01
02	0521060813	EXTENSOR		01
03	0502010993	DETACHABLE COVER		01
04	0503010948	W4-3346-590 PK RING G.E		01
05	0503010949	W2-2000-500 PK RING G.E		01
06	0503010976	2-336 N 3006-9B O'RING		01
07	0503010042	2-214 N 3006-9B O'RING		01
08	0503010170	PACKING 3120 2750		02
09	0503010761	D-1750 SCRAPER RING		01
10	0503010990	GASKET		01
11	0503011060	8-336 BACK-UP RING		01
12	0502010843	1.8" X 3.4" PISTON		01
13	0502010781	RING SUPPORT		01
14	0503010063	1" SELF-ALIGNING NUT		01
15	0503010002	1800 GREASE FITTING		02
16	0503030385	CYLINDER PLUG N-002		02




Item	Code	Description	See page	QT
01	0501068010	RIGHT 3.4" X 2.4" CYLINDER CASE		01
02	0501065484	HYDRAULIC CYLINDER TURNBUCKLE		01
03	0502010993	DETACHABLE COVER		01
04	0502010781	RING SUPPORT		01
05	0503010761	D-1750 SCRAPER RING		01
06	0503010990	GASKET		01
07	0503010949	W2-2000-500 PK RING G.E		01
08	0503011060	8-336 BACK-UP RING		01
09	0503010976	2-336 N 3006-9B O'RING		01
10	0503010042	2-214 N 3006-9B O'RING		01
11	0502010843	1.8" X 3.4" PISTON		01
12	0503010170	PACKING 3120 2750		02
13	0503010948	W4-3346-590 PK RING G.E		01
14	0503010063	1" SELF-ALIGNING NUT		01
15	0503030385	CYLINDER PLUG N-002		02
16	0501031796	HYDRAULIC CYLINDER REPAIR KIT		01




Item	Code	Description	See page	QT
001	0501065480	LEFT 3.4" X 2.4" CYLINDER CASE		01
002	0501065484	HYDRAULIC CYLINDER TURNBUCKLE		01
003	0502010993	DETACHABLE COVER		01
004	0502010781	RING SUPPORT		01
005	0502010843	1.8" X 3.4" PISTON		01
006	0503010063	1" SELF-ALIGNING NUT		01
007	0503010761	D-1750 SCRAPER RING		01
008	0503010990	GASKET		01
009	0503010949	W2-2000-500 PK RING G.E		01
010	0503011060	8-336 BACK-UP RING		01
011	0503010976	2-336 N 3006-9B O'RING		01
012	0503010042	2-214 N 3006-9B O'RING		01
013	0503010170	PACKING 3120 2750		02
014	0503010948	W4-3346-590 PK RING G.E		01
015	0503030385	CYLINDER PLUG N-002		02




Item	Code	Description	See page	QT
01	0503060069	VALVE ASSY		01
02	0501219897	NIPPLE 3/4 BSP 14FPP X 3/4 UNF 16FPP X 45		03
03	0503010045	O'RING		03
04	0503030385	CYLINDER PLUG N-002		03




Item	Code	Description	See page	QT
01	0521014682	AXLE RATCHET		01
02	0531011040	RATCHET AXLE COMPLEMENT		01
03	0501110237	RH RATCHET FOLLOWER		01
04	0581018423	GEAR 14Z STEP 31.75 X 61		01
05	0501110268	14Z GEAR WITH RIGHT DRAGGER		01
06	0502010721	LEFT CAM,LARGER		01
07	0502010720	RIGHT CAM, SMALLER		01
08	0501019735	FLAT WASHER		03
09	0501019734	FLAT WASHER		02
10	0503030553	2.3\"X 2.5\"X 0.2\"COMPRESSION SPRING		01
11	0503011440	SPRING WASHER		01
12	0503010395	1/2\" X 1-1/4\" BOLT		01
13	0503010003	1845 GREASE FITTING		02
14	0503010240	BOLT		06
15	0503010179	LOCK WASHER 5/16 ZN 1K01528		06




Item	Code	Description	See page	QT
01	0521014682	AXLE RATCHET		01
02	0531011040	RATCHET AXLE COMPLEMENT		01
03	0581018423	GEAR 14Z STEP 31.75 X 61		01
04	0501019735	FLAT WASHER		03
05	0501019734	FLAT WASHER		02
06	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010395	1/2" X 1-1/4" BOLT		01
09	0503010003	1845 GREASE FITTING		02
10	0501110236	LH RATCHET FOLLOWER		01
11	0501110270	14Z GEAR WITH IZQ DRAGGER		01
12	0502010711	RIGHT CAM,LARGER		01
13	0502010710	RIGHT CAM, SMALLER		01
14	0503010240	BOLT		06
15	0503010179	LOCK WASHER 5/16 ZN 1K01528		06




Item	Code	Description	See page	QT
01	0511014096	RATCHET AXLE	01	
02	0501019735	FLAT WASHER	03	
03	0502011931	14Z GEAR	01	
04	0501110237	RH RATCHET FOLLOWER	01	
05	0501019734	FLAT WASHER	02	
06	0502010710	RIGHT CAM, SMALLER	01	
07	0502010711	RIGHT CAM,LARGER	01	
08	0501110268	14Z GEAR WITH RIGHT DRAGGER	01	
09	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING	01	
10	0503010240	BOLT	06	
11	0503010179	LOCK WASHER 5/16 ZN 1K01528	06	
12	0503010004	1890 GREASE FITTING	01	
13	0503010003	1845 GREASE FITTING	02	



Item	Code	Description	See page	QT
01	0511014096	RATCHET AXLE	01	
02	0501019735	FLAT WASHER	03	
03	0502011931	14Z GEAR	01	
04	0501110236	LH RATCHET FOLLOWER	01	
05	0501019734	FLAT WASHER	02	
06	0502010720	RIGHT CAM, SMALLER	01	
07	0502010721	LEFT CAM,LARGER	01	
08	0501110270	14Z GEAR WITH IZQ DRAGGER	01	
09	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING	01	
10	0503010240	BOLT	06	
11	0503010179	LOCK WASHER 5/16 ZN 1K01528	06	
12	0503010004	1890 GREASE FITTING	01	
13	0503010003	1845 GREASE FITTING	02	




Item	Code	Description	See page	QT
01	0501110734	CARRYING WHEEL HUB		01
02	0503013454	SKF 33109 ROLLER BEARING		01
03	0503013453	SKF 33011 ROLLER BEARING		01
04	0503010086	SEAL 0009B-B		01
05	0541015586	WHEEL AXLE		01
06	0501010630	1.1/2" CASTLE NUT		01
07	0503010523	1/4" X 2" COTTERPIN		01
08	0502020592	COVER		01
09	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
10	0503011444	SPRING WASHER		12
11	0503010002	1800 GREASE FITTING		01
12	0502011070	14Z GEAR		01
13	0503010397	5/16" X 1-3/4" BOLT		08



Item	Code	Description	See page	QT
01	0501110775	ROLLED BOX WITH SCREW		01
01A	0502040464	CARRYING WHEEL HUB		01
01B	0503014048	22 X 1.5 HEX NUT		08
01C	0503810007	WHEEL BOLT		08
02	0531010284	WHEEL AXLE		01
03	0503010007	3982/3920 ROLLER BEARING		01
04	0503010059	33287/33462 ROLLER BEARING		01
05	0502040080	FLANGE NUT R.2.1/2 UN		01
06	0503012231	1/4" X 3" COTTERPIN		01
07	0541013225	WHEEL BOX COVER		01
08	0502011403	14Z GEAR		01
09	0511015317	GEAR WHEEL FLANGE		01
10	0503010086	SEAL 0009B-B		01
11	0503011444	SPRING WASHER		22
12	0503010240	BOLT		14
13	0503010421	5/16" X 1-1/2" BOLT		08
14	0503010002	1800 GREASE FITTING		01

FINE SEED BOX

0909091511




Item	Code	Description	See page	15	19	21	23
00	0511043798	FINE SEED BOX ASSY		01	00	00	00
00A	0511043654	RIGHT FINE SEED BOX ASSY		00	01	00	00
00B	0511043655	LH FINE SEED BOX ASSY		00	01	00	00
00C	0511043701	RIGHT FINE SEED BOX ASSY		00	00	01	01
00D	0511043702	LH FINE SEED BOX ASSY		00	00	01	01
01	0511062286	FINE SEED BOX		01	00	00	00
01A	0511062545	RIGHT FINE SEED BOX		00	01	00	00
01B	0511062546	LEFT FINE SEED BOX		00	01	00	00
01C	0511062289	RIGHT FINE SEED BOX ASSY		00	00	01	01
01D	0511062563	LEFT FINE SEED BOX		00	00	01	01
02	0531010780	RIGHT FINE SEED BOX AXLE		01	00	00	00
02A	0531010781	LEFT FINE SEED BOX AXLE		01	00	00	00
02B	0531010683	RIGHT FINE SEED BOX AXLE		00	01	00	00
02C	0531010682	LEFT FINE SEED BOX AXLE		00	01	00	00
02D	0531010700	RIGHTFINE SEED BOX AXLE		00	00	01	01
02E	0531010699	LEFT FINE SEED BOX AXLE		00	00	01	01
03	0503060150	FINE SEED DISTRIBUTOR		15	19	23	23
03A	0503030706	PASTURE SEED DISTRIBUTOR BOX		15	19	23	23
03B	0503030705	ROTOR GUIDES		15	19	23	23
03C	0503030701	ROTOR		15	19	23	23
03D	0503030702	DISTRIBUTOR BOX SEAL		15	19	23	23
03E	0503030704	MOBILE WASHER SUPPORT SLEEVE		15	19	23	23
03F	0503030703	ROTOR WHASHER		15	19	23	23
04	0503013815	1/4" X 5/8" BOLT		60	72	92	92
05	0503011441	SPRING WASHER		49	58	73	73
06	0503010144	1/4" NUT		64	76	96	96
07	0503010140	1/8" X 3/4" COTTERPIN		30	36	46	46
08	0503050042	FINE SEED DISTR BOX INTER		15	19	23	23
08A	0511015729	PNEUMATIC SWITCH		15	19	23	23
09	0502010901	FINE SEED BOX AGRICULTURAL BEARING		02	02	02	02
10	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04	04	04	04


FINE SEED BOX

0909091511


Item	Code	Description	See page	15	19	21	23
11	0503010025	3/8 SPRING WASHER		04	04	04	04
12	0503010026	3/8" NUT		04	04	04	04
13	0503010002	1800 GREASE FITTING		02	02	02	02
14	0501066928	RIGHT GEAR WITH TEETH REEL		01	01	01	01
15	0501067311	LEFT GEAR WITH TEETH REEL		01	01	01	01
16	0511013557	30Z P 0.5" RH1.2.9" GEAR		02	02	02	02
17	0503811766	BOLT		06	06	06	06
18	0521010743	0.3" X 0.6" X 0.8" SLEEVE		06	06	06	06
19	0503010406	501025 CLAMPING RING (FOR AXLE)		02	02	02	02
20	0521010769	RIGHT REGULACION FINE SEED		01	01	01	01
21	0521013012	LEFT REGULACION FINE SEED		01	01	01	01
22	0511015161	RD FINE SEED REGULATOR		01	01	01	01
23	0511016567	RE FINE SEED REGULATOR		01	01	01	01
24	0502011081	3/8" Q AXLE PULLER SLEEVE		02	02	02	02
25	0503011335	502024 CLAMPING RING (FOR AXLE)		02	02	02	02
26	0503032076	SMALLER DOSADOR		02	02	02	02
27	0503010838	0.1" X 0.8" SPRING PIN		04	04	04	04
28	0503010691	1/4" GREASE FITTING		02	02	02	02
29	0503011321	40-1 CHAIN X 94 LINK + REDUCTION		02	02	02	02
30	0503010371	5/16" X 1" BOLT		04	08	08	08
31	0503010179	LOCK WASHER 5/16 ZN 1K01528		08	16	16	16
32	0501010694	FLAT WASHER		06	12	12	12
33	0503010337	5/16" NUT		08	16	16	16
34	0531017257	FINE SEED RIGHT CHAIN COVER		01	01	01	01
35	0531017258	FINE SEED LEFT CHAIN COVER		01	01	01	01
36	0503010386	CABLE		04	04	04	04
37	0511064167	ROW RH FINE SEED SOCKET		04	05	05	06
38	0511064168	ROW LH FINE SEED SOCKET		03	04	05	05
39	0511064169	ROW RH FINE SEED SOCKET		04	05	06	06
40	0511064170	ROW LH FINE SEED SOCKET		04	05	05	06
41	0531018938	SEED FINE SCALE SUPPORT		02	02	02	02
42	0503010282	1/4" X 3/4" BOLT		04	04	04	04
43	0511062298	FINE SEED BOX CAP		01	00	00	00
44	0511062547	RIGHT FINE SEED BOX CAP		00	01	00	00
45	0511062548	LEFT FINE SEED BOX CAP		00	01	00	00
46	0511062299	RIGHT FINE SEED BOX CAP		00	00	01	01
47	0511062562	LEFT FINE SEED BOX CAP		00	00	01	01
48	0503010421	5/16" X 1-1/2" BOLT		02	04	04	04
49	0521011116	COVER PIVOT BUSHING		02	04	04	04
50	0503011907	NYLON HANDLE		01	02	02	02
51	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		02	04	04	04
52	0503030885	SEED DOSADOR SCALE		01	02	02	02
53	0503010001	3.2 X 5.5 RIVET		02	04	04	04
54	0503031808	0.8" X 0.8" X 23" HOSE		15	19	23	23
55	0503011342	3/4" TO 1 CLAMP		15	19	23	23
56	0503010296	CLAMP		15	19	23	23
57	0501045114	CHAIN TENSIONER		02	00	00	00
57A	0511010919	CHAIN TIGHTENER AXLE		02	02	02	02
57B	0503031805	11Z 1/2" GEAR		02	02	02	02
57C	0503010302	501019 SEAL RING		02	02	02	02
57D	0503010004	1890 GREASE FITTING		02	02	02	02
57E	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02	02	02	02
58	0501051381	FINE SEED CHAIN TENSIONER ASSY	37	00	02	02	02
59	0511015511	WRENCH		02	02	02	02




Item	Code	Description	See page	QT
01	0511010919	CHAIN TIGHTENER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
05	0503010025	3/8 SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0503010004	1890 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501053441	RIGHT FINE SEED BOX SDA3E 27	39	01
02	0511062567	RIGHT FINE SEED BOX CAP		01
03	0503010421	5/16" X 1-1/2" BOLT		02
04	0521011116	COVER PIVOT BUSHING		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	5/16" NUT		04
08	0503011907	NYLON HANDLE		01
09	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		02
10	0503030885	SEED DOSADOR SCALE		01
11	0503010001	3.2 X 5.5 RIVET		02
12	0501045114	CHAIN TENSIONER		01
12A	0511010919	CHAIN TIGHTENER AXLE		01
12B	0503031805	11Z 1/2" GEAR		01
12C	0503010302	501019 SEAL RING		01
12D	0503010004	1890 GREASE FITTING		01
12E	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
12F	0503010025	3/8 SPRING WASHER		01
12G	0503010026	3/8" NUT		01
13	0503010386	CABLE		02
14	0503031808	0.8" X 0.8" X 23" HOSE		14
15	0503010296	CLAMP		14
16	0503011342	3/4" TO 1 CLAMP		14
17	0503050042	FINE SEED DISTR BOX INTER		14




Item	Code	Description	See page	QT
01	0511062569	RIGHT FINE SEED BOX	01	
02	0531010732	RIGHT FINE SEED BOX AXLE	01	
03	0503060150	FINE SEED DISTRIBUTOR	13	
04	0503013815	1/4" X 5/8" BOLT	52	
05	0503011441	SPRING WASHER	39	
06	0503010144	1/4" NUT	52	
07	0503010140	1/8" X 3/4" COTTERPIN	26	
08	0502010901	FINE SEED BOX AGRICULTURAL BEARING	01	
09	0503010002	1800 GREASE FITTING	01	
10	0501066928	RIGHT GEAR WITH TEETH REEL	01	
11	0511013557	30Z P 0.5" RH1.2.9" GEAR	01	
12	0503011766	5/16" X 2-1/2" BOLT	03	
13	0503011444	SPRING WASHER	03	
14	0503010337	5/16" NUT	03	
15	0521010743	0.3" X 0.6" X 0.8" SLEEVE	03	
16	0503010406	501025 CLAMPING RING (FOR AXLE)	01	
17	0521010769	RIGHT REGULACION FINE SEED	01	
18	0511015161	RD FINE SEED REGULATOR	01	
19	0502011081	3/8" Q AXLE PULLER SLEEVE	01	
20	0503011335	502024 CLAMPING RING (FOR AXLE)	01	
21	0531018938	SEED FINE SCALE SUPPORT	01	
22	0503010282	1/4" X 3/4" BOLT	02	
23	0503032076	SMALLER DOSADOR	01	
24	0503010838	0.1" X 0.8" SPRING PIN	02	
25	0503010691	1/4" GREASE FITTING	01	
26	0503010240	BOLT	02	
27	0503011444	SPRING WASHER	02	
28	0503010337	5/16" NUT	02	



Item	Code	Description	See page	QT
01	0501053442	LH FINE SEED BOX SDA3E 27	41	01
02	0511062568	LEFT FINE SEED BOX CAP		01
03	0503010421	5/16" X 1-1/2" BOLT		02
04	0521011116	COVER PIVOT BUSHING		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	5/16" NUT		04
08	0503011907	NYLON HANDLE		01
09	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		02
10	0503030885	SEED DOSADOR SCALE		01
11	0503010001	3.2 X 5.5 RIVET		02
12	0501045114	CHAIN TENSIONER		01
12A	0511010919	CHAIN TIGHTENER AXLE		01
12B	0503031805	11Z 1/2" GEAR		01
12C	0503010302	501019 SEAL RING		01
12D	0503010004	1890 GREASE FITTING		01
12E	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
12F	0503010025	3/8 SPRING WASHER		01
12G	0503010026	3/8" NUT		01
13	0503010386	CABLE		02
14	0503031808	0.8" X 0.8" X 23" HOSE		14
15	0503010296	CLAMP		14
16	0503011342	3/4" TO 1 CLAMP		14
17	0503050042	FINE SEED DISTR BOX INTER		14
17A	0511015729	PNEUMATIC SWITCH		01




Item	Code	Description	See page	QT
01	0511062570	LEFT FINE SEED BOX	01	
02	0531010733	LEFT FINE SEED BOX AXLE	01	
03	0503060150	FINE SEED DISTRIBUTOR	13	
04	0503013815	1/4" X 5/8" BOLT	52	
05	0503011441	SPRING WASHER	39	
06	0503010144	1/4" NUT	52	
07	0503010140	1/8" X 3/4" COTTERPIN	26	
08	0502010901	FINE SEED BOX AGRICULTURAL BEARING	01	
09	0503010002	1800 GREASE FITTING	01	
10	0501067311	LEFT GEAR WITH TEETH REEL	01	
11	0511013557	30Z P 0.5" RH1.2.9" GEAR	01	
12	0503011766	5/16" X 2-1/2" BOLT	03	
13	0503011444	SPRING WASHER	03	
14	0503010337	5/16" NUT	03	
15	0521010743	0.3" X 0.6" X 0.8" SLEEVE	03	
16	0503010406	501025 CLAMPING RING (FOR AXLE)	01	
17	0521013012	LEFT REGULACION FINE SEED	01	
18	0511016567	RE FINE SEED REGULATOR	01	
19	0502011081	3/8" Q AXLE PULLER SLEEVE	01	
20	0503011335	502024 CLAMPING RING (FOR AXLE)	01	
21	0531018938	SEED FINE SCALE SUPPORT	01	
22	0503010282	1/4" X 3/4" BOLT	02	
23	0503032076	SMALLER DOSADOR	01	
24	0503010838	0.1" X 0.8" SPRING PIN	02	
25	0503010691	1/4" GREASE FITTING	01	
26	0503010240	BOLT	02	
27	0503011444	SPRING WASHER	02	
28	0503010337	5/16" NUT	02	



Item	Code	Description	See page	QT
01	0501110831	FERTILIZER DISTRIBUTOR BODY WITH HOSE		01
01A	1902012845	DISTRIBUTOR OF FERTILIZER OUT RIGHT SIDE		01
01B	0581010951	TUBE DISTRIBUTOR FERTILIZER		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0501013774	GREASE SEAL		01
06	0503030303	SUPPORT WASHER		01
07	0591017505	GEAR		01
08	0503010523	1/4" X 2" COTTERPIN		01
09	0503011962	GREASE FITTING		02
10	0503010003	1845 GREASE FITTING		01
11	0501010637	FLAT WASHER		01
12	0503031166	LEFT CONDUTOR		01

DRAWBAR ASSY


0501049704



Item	Code	Description	See page	QT
01	0511055818	DRAWBAR	44	01
02	0511014394	1.25" X 4.13" COUPLING SHAFT		02
03	0503010523	1/4" X 2" COTTERPIN		02
04	0501053168	ESTABILIZER DRAWBAR ASSY	49	01
05	0531010490	AXLE 1.12" X 8"		01
06	0503010523	1/4" X 2" COTTERPIN		02
07	0521010577	0.9" X 4.1" COUPLING SHAFT		01
08	0503010571	1/4" X 1.1/2 COTTERPIN		01

DRAWBAR


0511055818



Item	Code	Description	See page	QT
01	0511062123	DRAWBAR		01
02	0511062245	TRACTOR HITCH ASSY		01
03	0521010681	BUSHING COUPLING BODY		01
04	0521010639	COUPLING SHAFT		01
05	0503010571	1/4" X 1.1/2 COTTERPIN		01
06	0503010002	1800 GREASE FITTING		01

DRAWBAR ASSY


0511040010




Item	Code	Description	See page	QT
01	0511055773	DRAWBAR	46	01
02	0501053168	ESTABILIZER DRAWBAR ASSY	49	01
03	0511014394	1.25" X 4.13" COUPLING SHAFT		02
04	0521010577	0.9" X 4.1" COUPLING SHAFT		01
05	0531010490	AXLE 1.12" X 8"		01
06	0503010523	1/4" X 2" COTTERPIN		04
07	0503010571	1/4" X 1.1/2 COTTERPIN		01

DRAWBAR


0511055773




Item	Code	Description	See page	QT
01	0511068276	DRAWBAR		01
02	0511062245	TRACTOR HITCH ASSY		01
03	0521010681	BUSHING COUPLING BODY		01
04	0521010639	COUPLING SHAFT		01
05	0503010571	1/4" X 1.1/2 COTTERPIN		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511062128	CHAIN TENSIONER		01
02	0503031804	5Z GEAR P31,75		01
03	0503010302	501019 SEAL RING		01
04	0521019253	3.6" PIVOT SHAFT		01
05	0503010292	701164 6 X 40 SPRING PIN		01
06	0503030417	1.7"X 1.4"X 0.14" RH TORSION SPRING		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011923	AGRICULTURAL BEARING ASSY		01
02	0502011924	GUIDE AXLE		01
03	0503011789	501075 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0501110262	245 ADJUSTMENT NUT		01
02	0501063936	LH TURNBUCKLE		01
03	0541818672	LOCKNUT		01
04	0503010002	1800 GREASE FITTING		02
05	0511062478	RIGHT TURNBUCKLE		01




Item	Code	Description	See page	QT
01	0501040236	SEED LIMETER	50	01
01A	0501011271	SUPPORT SPRING		01
01B	0503030185	HOOK SPRING		01
01C	0511014973	LIMITER AXLE		01




Item	Code	Description	See page	QT
01	0502040526	SEED BOX FINE BEARING REEL	01	
02	0561011361	WHEEL TOOTH	01	
03	0511011139	GEAR FLANGE	01	
04	0501110250	BEARING BOX	01	
05	0502012037	RIGHT SEED REGULATOR	01	
06	0502012038	RIGHT SEED REGULATOR	01	
07	0502012197	0.76" X 1.81" X 0.06" SLEEVE	01	
08	0541010247	FLAT WASHER	02	
09	0503012918	2-327 N 3006-9B O-RING	01	
10	0503011105	SEAL RING	01	
11	0503010372	501050 CLAMPING RING (FOR AXLE)	01	
12	0503010003	1845 GREASE FITTING	01	
13	0503010561	SPRING PIN	01	
14	0503011444	SPRING WASHER	06	
15	0503010691	1/4" GREASE FITTING	02	
16	0503010421	5/16" X 1-1/2" BOLT	06	
17	0503010337	5/16" NUT	06	




Item	Code	Description	See page	QT
01	0502040526	SEED BOX FINE BEARING REEL		01
02	0561011361	WHEEL TOOTH		01
03	0511011139	GEAR FLANGE		01
04	0501110250	BEARING BOX		01
05	0502012197	0.76" X 1.81" X 0.06" SLEEVE		01
06	0541010247	FLAT WASHER		02
07	0503012918	2-327 N 3006-9B O-RING		01
08	0503011105	SEAL RING		01
09	0503010372	501050 CLAMPING RING (FOR AXLE)		01
10	0503010003	1845 GREASE FITTING		01
11	0503010561	SPRING PIN		01
12	0503011444	SPRING WASHER		06
13	0503010691	1/4" GREASE FITTING		02
14	0502012130	LH SEED REGULATOR		01
15	0502012131	LEFT SEED REGULATOR		01
16	0503010421	5/16" X 1-1/2" BOLT		06
17	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0501064950	RIGHT CHAIN TENSIONER		01
02	0502012317	WHEEL TOOTH		02
03	0503010302	501019 SEAL RING		02
04	0503010004	1890 GREASE FITTING		02
05	0511014513	1" X 0.6" X 0.4" ARTICULAT SLEEVE		01
06	0503010027	5/8 SPRING WASHER		01
07	0503010013	5/8 NUT		01
08	0501012140	FLAT WASHER		01



Item	Code	Description	See page	QT
01	0501064951	LEFT CHAIN TENSIONER		01
02	0502012317	WHEEL TOOTH		02
03	0503010302	501019 SEAL RING		02
04	0503010004	1890 GREASE FITTING		02
05	0511014513	1" X 0.6" X 0.4" ARTICULAT SLEEVE		01
06	0503010027	5/8 SPRING WASHER		01
07	0503010013	5/8 NUT		01
08	0501012140	FLAT WASHER		01



Item	Code	Description	See page	QT
01	0521011120	COVER PIVOT SHAFT		01
02	0501010694	FLAT WASHER		01
03	0503010140	1/8" X 3/4" COTTERPIN		02
04	0503031329	COMPRES SPRING		01
05	0521011117	PIVOT SPRING AXLE		01




Item	Code	Description	See page	19 23
00	0521050622	RIGHT ROW LOWER / CPV / F310 ESP158 SDA3/E		04 05
00A	0521050623	LEFT ROW LOWER / CPV / F310 ESP158 SDA3/E		05 06
00B	0521050624	RIGHT ROW LARGER		04 05
00C	0521050625	LEFT ROW LARGER / CPV / F310 ESP158 SDA3/E		04 05
00D	0521050626	RH ROW LARGER SIDE		01 01
00E	0521050627	LH ROW LARGER SIDE		01 01
01	0501056211	RH DDD ROW SMALLER SUPPORT	61	04 05
02	0501056212	LH DDD ROW SMALLER SUPPORT	62	05 06
03	0501056213	RH ROW DDD LARGER SUPPORT		04 05
04	0501056214	LH ROW DDD LARGER SUPPORT	63	04 05
05	0501056215	RH ROW LARGER SIDE SUPPORT	70	01 01
06	0501056216	LH ROW LARGER SIDE SUPPORT	71	01 01
07	0511064373	SMALLER TRIPLE DISC SUPPORT		01 01
08	0511064374	LARGER TRIPLE DISC SUPPORT		01 01
09	0502010978	SUPPORT FIXER		01 01
10	0501017315	5/8" X 124 BOLT		01 01
11	0501012140	FLAT WASHER		01 01
12	0503010811	5/8" UNF SELF ADJUSTING NUT		01 01
13	0503010691	1/4" GREASE FITTING		01 01
14	0502040376	ROW FASTENER		01 01
15	0501011543	5/8" X 4" BOLT		01 01
16	0503010027	5/8 SPRING WASHER		02 02
17	0503010013	5/8 NUT		02 02
18	0541014450	158 SPACER ROW		02 02
19	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER		04 04
20	0501010937	13,50 X 28 X 3,00 FLAT WASHER		10 10
21	0503010019	1/2" SPRING WASHER		16 16
22	0503010060	1/2 UNC G.5 ZN HEX NUT		15 15
23	0511066111	RIGHT SIDE ROW SPACER		01 01
24	0511066112	LEFT SIDE ROW SPACER		01 01
25	0502040190	SPRING FIXER SUPPORT		01 01

DISLOCATED DOUBLE DISK ROW SET (RIGTH/LEFTH) CPV

0909093464

Item	Code	Description	See page	19 23
26	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01 01
27	0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	78	01 01
28	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	80	01 01
29	0511065789	FRONT PROTECTOR		01 01
30	0503010547	1/2" X 4" BOLT		02 02
31	0503030520	SEED SOCKET		01 01
32	0503030483	FERTILIZER SOCKET		01 01
33	0503031145	2" X 2" X 20" HOSE		01 01
34	0503031076	2" HOSE CLAMP		03 03
35	0501010452	5/8" X 5" BOLT		02 02
36	0501055213	RIGHT V PRESS SISTEM ASSY	84	01 01
37	0501055214	LEFT V PRESS SISTEM ASSY	85	01 01
38	0503010752	1/2" X 3.1/2" BOLT		02 02
39	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02 02
40	0501056095	SPRING ROD		01 01
41	0521010542	COUPLING SHAFT		01 01
42	0503010300	5/32" X 1" COTTERPIN		01 01
43	0502012523	SPRING GUIDE FIXER		01 01
44	0502012522	SPRING GUIDE FIXER LOCK		01 01
45	0503030168	HITCH PIN CLIP		01 01
46	0541014789	ROW SPACING SIDE SUPPORT		01 01
47	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02 02
48	0503030756	SOCKET FASTENER		01 01
49	0503010369	SEED SOCKET		01 01
50	0503030573	1-1/2" X 2" X 400 HOSE		02 02
51	0503030887	1-1/2" HOSE CLAMP		01 01
52	0561011813	SOCKET LOCK		02 02
53	0503012412	5/8 UNC SELF LOCKING NUT		01 01
54	0501010301	FLAT WASHER		01 01
55	0502020662	ROD STOP		01 01




Item	Code	Description	See page	23
00	0521051148	RIGHT ROW LOWER / CPV / F260 / ESP158 SDA3/E		05
00A	0521051151	LEFT ROW LOWER / CPV / F260 / ESP158 SDA3/E		06
00B	0521051191	RIGHT ROW LARGER / CPV / F260 / ESP158 SDA3/E		05
00C	0521051153	LEFT ROW LARGER / CPV / F260 / ESP158 SDA3/E		05
00D	0521051154	RH ROW LARGER SIDE		01
00E	0521051155	LEFTH ROW LARGER SIDE		01
01	0501056211	RH DDD ROW SMALLER SUPPORT	61	05
02	0501056212	LH DDD ROW SMALLER SUPPORT	62	06
03	0501056213	RH ROW DDD LARGER SUPPORT		05
04	0501056214	LH ROW DDD LARGER SUPPORT	63	05
05	0501056215	RH ROW LARGER SIDE SUPPORT	70	01
06	0501056216	LH ROW LARGER SIDE SUPPORT	71	01
07	0511064373	SMALLER TRIPLE DISC SUPPORT		01
08	0511064374	LARGER TRIPLE DISC SUPPORT		01
09	0502010978	SUPPORT FIXER		01
10	0501017315	5/8" X 124 BOLT		01
11	0501012140	FLAT WASHER		01
12	0503010811	5/8" UNF SELF ADJUSTING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0502040376	ROW FASTENER		01
15	0501011543	5/8" X 4" BOLT		01
16	0503010027	5/8 SPRING WASHER		02
17	0503010013	5/8 NUT		02
18	0541014450	158 SPACER ROW		02
19	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER		04
20	0501010937	13,50 X 28 X 3,00 FLAT WASHER		10
21	0503010019	1/2" SPRING WASHER		16
22	0503010060	1/2 UNC G.5 ZN HEX NUT		15
23	0511066111	RIGHT SIDE ROW SPACER		01
24	0511066112	LEFT SIDE ROW SPACER		01

Item	Code	Description	See page	23
25	0502040190	SPRING FIXER SUPPORT		01
26	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
27	0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	78	01
28	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	80	01
29	0511065789	FRONT PROTECTOR		01
30	0503010547	1/2" X 4" BOLT		02
31	0503030520	SEED SOCKET		01
32	0503030483	FERTILIZER SOCKET		01
33	0503031145	2" X 2" X 20" HOSE		01
34	0503031076	2" HOSE CLAMP		03
35	0501010452	5/8" X 5" BOLT		02
36	0501055213	RIGHT V PRESS SISTEM ASSY	84	01
37	0501055214	LEFT V PRESS SISTEM ASSY	85	01
38	0503010752	1/2" X 3.1/2" BOLT		02
39	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
40	0501056095	SPRING ROD		01
41	0521010542	COUPLING SHAFT		01
42	0503010300	5/32" X 1" COTTERPIN		01
43	0502012523	SPRING GUIDE FIXER		01
44	0502012522	SPRING GUIDE FIXER LOCK		01
45	0503030168	HITCH PIN CLIP		01
46	0541014789	ROW SPACING SIDE SUPPORT		01
47	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
48	0503030756	SOCKET FASTENER		01
49	0503010369	SEED SOCKET		01
50	0503030573	1-1/2" X 2" X 400 HOSE		02
51	0503030887	1-1/2" HOSE CLAMP		01
52	0561011813	SOCKET LOCK		02
53	0503012412	5/8 UNC SELF LOCKING NUT		01
54	0501010301	FLAT WASHER		01
55	0502020574	ROD STOP		23

DISLOCATED DOUBLE DISK ROW SET (RIGTH/LEFTH)

0909098987




Item	Code	Description	See page	21
00	0521051750	RIGHT ROW LOWER		05
00A	0521051751	LEFT ROW LOWER		05
00B	0521051752	RIGHT ROW LARGER		04
00C	0521051753	LEFT ROW LARGER		05
00D	0521051754	RH ROW LARGER SIDE		01
00E	0521051755	LEFT ROW LARGER SIDE		01
01	0521050608	RIGHT ROW LOWER		05
01A	0501056217	RH DDD ROW SMALLER SUPPORT	64	05
02	0521050607	LEFT ROW LOWER		04
02A	0521056218	LOWER SUPPORT LINE DDD LINE	65	04
03	0521050606	RH ROW LARGER		05
03A	0501056219	RH ROW DDD LARGER SUPPORT	66	05
04	0521050605	LEFT ROW LARGER SIDE		01
04A	0501056220	RH ROW DDD LARGER SUPPORT	67	01
05	0521050609	RH ROW LARGER SIDE		01
05A	0501056221	RH SIDE ROW LARGER SUPPORT	68	01
06	0521050610	LEFT ROW LARGER SIDE		01
06A	0501056222	LH SIDE ROW DDD LARGER SUPPORT	69	01
07	0511064373	SMALLER TRIPLE DISC SUPPORT		01
08	0511064374	LARGER TRIPLE DISC SUPPORT		01
09	0502010978	SUPPORT FIXER		01
10	0501010452	5/8" X 5" BOLT		01
11	0501010301	FLAT WASHER		01
12	0503010811	5/8" UNF SELF ADJUSTING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0502040376	ROW FASTENER		01
15	0501011543	5/8" X 4" BOLT		01
16	0503010027	5/8 SPRING WASHER		02
17	0503010013	5/8 NUT		02
18	0541014451	175 ROW SPACER		02
19	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER		04

DISLOCATED DOUBLE DISK ROW SET (RIGTH/LEFTH)

0909098987

Item	Code	Description	See page	21
20	0501010937	13,50 X 28 X 3,00 FLAT WASHER		10
21	0503010019	1/2" SPRING WASHER		16
22	0503010060	1/2 UNC G.5 ZN HEX NUT		15
23	0511066111	RIGHT SIDE ROW SPACER		01
24	0511066112	LEFT SIDE ROW SPACER		01
25	0502040190	SPRING FIXER SUPPORT		01
26	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
27	0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	78	01
28	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	80	01
29	0511065789	FRONT PROTECTOR		01
30	0503010547	1/2" X 4" BOLT		02
31	0503030520	SEED SOCKET		01
32	0503030483	FERTILIZER SOCKET		01
33	0503031145	2" X 2" X 20" HOSE		01
34	0503031076	2" HOSE CLAMP		03
35	0501010452	5/8" X 5" BOLT		02
36	0501055213	RIGHT V PRESS SISTEM ASSY	84	01
37	0501055214	LEFT V PRESS SISTEM ASSY	85	01
38	0503010752	1/2" X 3.1/2" BOLT		02
39	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
40	0501056095	SPRING ROD		01
41	0521010542	COUPLING SHAFT		01
42	0503010300	5/32" X 1" COTTERPIN		01
43	0502012523	SPRING GUIDE FIXER		01
44	0502012522	SPRING GUIDE FIXER LOCK		01
45	0503030168	HITCH PIN CLIP		01
46	0541014789	ROW SPACING SIDE SUPPORT		01
47	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
48	0503030756	SOCKET FASTENER		01
49	0503010369	SEED SOCKET		01
50	0503030575	RING LEVER		02
51	0503030887	1-1/2" HOSE CLAMP		01
52	0561011813	SOCKET LOCK		02
53	0503010013	5/8 NUT		02
54	0501010301	FLAT WASHER		02
55	0502020662	ROD STOP		01



Item	Code	Description	See page	QT
00	0521051142	RIGHT ROW LOWER / CPV / F280 / ESP250 SDA3/E		04
00A	0521051143	LEFT ROW LOWER / CPV / F280 / ESP250 SDA3/E		05
00B	0521051144	RIGHT ROW LARGER / CPV / F280 / ESP250 SDA3/E		04
00C	0521051145	LEFT ROW LARGER / CPV / F280 / ESP250 SDA3/E		04
01	0501057476	RH DDD ROW SMALLER SUPPORT	72	04
02	0501057477	RH DDD ROW SMALLER SUPPORT	73	05
03	0501057478	RH DDD LARGER SUPPORT	74	04
04	0501057479	ROW LARGER SUPPORT	75	04
05	0511064373	SMALLER TRIPLE DISC SUPPORT		01
06	0511064374	LARGER TRIPLE DISC SUPPORT		01
07	0502010978	SUPPORT FIXER		01
08	0501017315	5/8" X 124 BOLT		01
09	0501012140	FLAT WASHER		01
10	0503010811	5/8" UNF SELF ADJUSTING NUT		01
11	0503010691	1/4" GREASE FITTING		01
12	0502040376	ROW FASTENER		01
13	0501011543	5/8" X 4" BOLT		01
14	0503010027	5/8 SPRING WASHER		02
15	0503010013	5/8 NUT		02
16	0501010937	13,50 X 28 X 3,00 FLAT WASHER		10
17	0503010019	1/2" SPRING WASHER		16
18	0503010060	1/2 UNC G.5 ZN HEX NUT		15
19	0511065104	ROW SPACING SPRING FIXER		01
20	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
21	0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	78	01
22	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	80	01
23	0511065789	FRONT PROTECTOR		01
24	0503010547	1/2" X 4" BOLT		02
25	0503030520	SEED SOCKET		01
26	0503030483	FERTILIZER SOCKET		01


DISLOCATED DOUBLE DISK ROW SET (RIGTH/LEFTH) CPV

0909093466

Item	Code	Description	See page	QT
27	0503031145	2" X 2" X 20" HOSE		01
28	0503031076	2" HOSE CLAMP		03
29	0501010452	5/8" X 5" BOLT		02
30	0501055213	RIGHT V PRESS SISTEM ASSY	84	01
31	0501055214	LEFT V PRESS SISTEM ASSY	85	01
32	0503010752	1/2" X 3.1/2" BOLT		02
33	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
34	0501056095	SPRING ROD		01
35	0521010542	COUPLING SHAFT		01
36	0503010300	5/32" X 1" COTTERPIN		01
37	0502012523	SPRING GUIDE FIXER		01
38	0502012522	SPRING GUIDE FIXER LOCK		01
39	0503030168	HITCH PIN CLIP		01
40	0541014789	ROW SPACING SIDE SUPPORT		01
41	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
42	0503030756	SOCKET FASTENER		01
43	0503010369	SEED SOCKET		01
44	0503030573	1-1/2" X 2" X 400 HOSE		02
45	0503030887	1-1/2" HOSE CLAMP		01
46	0561011813	SOCKET LOCK		02
47	0503012412	5/8 UNC SELF LOCKING NUT		01
48	0501010301	FLAT WASHER		01
49	0502020575	ROD STOP		01

DISLOCATED DOUBLE DISK ROW SET (RIGTH/LEFTH)

0909092856




Item	Code	Description	See page	23L
00	0521050611	RIGHT ROW LOWER		05
00A	0521050612	LEFT ROW LOWER CPF / F310		06
00B	0521050633	RIGHT ROW LARGER		05
00C	0521050619	LEFT ROW LARGER / CPF / F310		05
00D	0521050614	RH ROW LARGER SIDE		01
00E	0521050615	LEFT ROW LARGER SIDE - CPF/ F310		01
01	0501056211	RH DDD ROW SMALLER SUPPORT	61	05
02	0501056212	LH DDD ROW SMALLER SUPPORT	62	06
03	0501056213	RH ROW DDD LARGER SUPPORT		05
04	0501056214	LH ROW DDD LARGER SUPPORT	63	05
05	0501056215	RH ROW LARGER SIDE SUPPORT	70	01
06	0501056216	LH ROW LARGER SIDE SUPPORT	71	01
07	0511064373	SMALLER TRIPLE DISC SUPPORT		01
08	0511064374	LARGER TRIPLE DISC SUPPORT		01
09	0502010978	SUPPORT FIXER		01
10	0501017315	5/8" X 124 BOLT		01
11	0501012140	FLAT WASHER		01
12	0503010811	5/8" UNF SELF ADJUSTING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0502040376	ROW FASTENER		01
15	0501011543	5/8" X 4" BOLT		01
16	0503010027	5/8 SPRING WASHER		02
17	0503010013	5/8 NUT		02
18	0541014450	158 SPACER ROW		02
19	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER		04
20	0501010937	13,50 X 28 X 3,00 FLAT WASHER		10
21	0503010019	1/2" SPRING WASHER		16
22	0503010060	1/2 UNC G.5 ZN HEX NUT		15
23	0511066111	RIGHT SIDE ROW SPACER		01
24	0511066112	LEFT SIDE ROW SPACER		01
25	0502040190	SPRING FIXER SUPPORT		01


DISLOCATED DOUBLE DISK ROW SET (RIGTH/LEFTH)

0909092856


Item	Code	Description	See page	23L
26	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
27	0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	78	01
28	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	80	01
29	0511065789	FRONT PROTECTOR		01
30	0503010547	1/2" X 4" BOLT		02
31	0503030520	SEED SOCKET		01
32	0503030483	FERTILIZER SOCKET		01
33	0503031145	2" X 2" X 20" HOSE		01
34	0503031076	2" HOSE CLAMP		03
35	0501010452	5/8" X 5" BOLT		02
36	0501046839	RIGHT IRON PRESS WHEEL	89	01
37	0501046844	LEFT IRON PRESS WHEEL ASSY	90	01
38	0503010752	1/2" X 3.1/2" BOLT		02
39	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
40	0501056095	SPRING ROD		01
41	0521010542	COUPLING SHAFT		01
42	0503010300	5/32" X 1" COTTERPIN		01
43	0502012523	SPRING GUIDE FIXER		01
44	0502012522	SPRING GUIDE FIXER LOCK		01
45	0503030168	HITCH PIN CLIP		01
46	0541014789	ROW SPACING SIDE SUPPORT		01
47	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
48	0503030756	SOCKET FASTENER		01
49	0503010369	SEED SOCKET		01
50	0503030573	1-1/2" X 2" X 400 HOSE		02
51	0503030887	1-1/2" HOSE CLAMP		01
52	0561011813	SOCKET LOCK		02
53	0503012412	5/8 UNC SELF LOCKING NUT		01
54	0501010301	FLAT WASHER		01
55	0502020662	ROD STOP		01




Item	Code	Description	See page	QT
01	0502010978	SUPPORT FIXER		01
02	0501017315	5/8" X 124 BOLT		01
03	0501012140	FLAT WASHER		01
04	0503010811	5/8" UNF SELF ADJUSTING NUT		01
05	0511065789	FRONT PROTECTOR		01
06	0503010547	1/2" X 4" BOLT		02
07	0503011440	SPRING WASHER		06
08	0503010060	1/2 UNC G.5 ZN HEX NUT		06
09	0541014450	158 SPACER ROW		02
10	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER		02
11	0502040190	SPRING FIXER SUPPORT		01
12	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
13	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
14	0503010013	5/8 NUT		02
15	0503011445	SPRING WASHER		02
16	0503010691	1/4" GREASE FITTING		01
17	0511064373	SMALLER TRIPLE DISC SUPPORT		01
18	0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	78	01




Item	Code	Description	See page	QT
01	0502010978	SUPPORT FIXER		01
02	0501017315	5/8" X 124 BOLT		01
03	0501012140	FLAT WASHER		01
04	0503010811	5/8" UNF SELF ADJUSTING NUT		01
05	0511065789	FRONT PROTECTOR		01
06	0503010547	1/2" X 4" BOLT		02
07	0503011440	SPRING WASHER		06
08	0503010060	1/2 UNC G.5 ZN HEX NUT		06
09	0541014450	158 SPACER ROW		02
10	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER		02
11	0502040190	SPRING FIXER SUPPORT		01
12	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
13	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
14	0503010013	5/8 NUT		02
15	0503011445	SPRING WASHER		02
16	0503010691	1/4" GREASE FITTING		01
17	0511064373	SMALLER TRIPLE DISC SUPPORT		01
18	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	80	01




Item	Code	Description	See page	QT
01	0502010978	SUPPORT FIXER		01
02	0501017315	5/8" X 124 BOLT		01
03	0501012140	FLAT WASHER		01
04	0503010811	5/8" UNF SELF ADJUSTING NUT		01
05	0511065789	FRONT PROTECTOR		01
06	0503010547	1/2" X 4" BOLT		02
07	0503011440	SPRING WASHER		06
08	0503010060	1/2 UNC G.5 ZN HEX NUT		06
09	0541014451	175 ROW SPACER		02
10	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER		02
11	0502040190	SPRING FIXER SUPPORT		01
12	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
13	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
14	0503010013	5/8 NUT		02
15	0503011445	SPRING WASHER		02
16	0503010691	1/4" GREASE FITTING		01
17	0511064374	LARGER TRIPLE DISC SUPPORT		01
18	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	80	01




Item	Code	Description	See page	QT
01	0502010978	SUPPORT FIXER		01
02	0501017315	5/8" X 124 BOLT		01
03	0501012140	FLAT WASHER		01
04	0503010811	5/8" UNF SELF ADJUSTING NUT		01
05	0511065789	FRONT PROTECTOR		01
06	0503010547	1/2" X 4" BOLT		02
07	0503011440	SPRING WASHER		06
08	0503010060	1/2 UNC G.5 ZN HEX NUT		06
09	0541014451	175 ROW SPACER		02
10	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER		02
11	0502040190	SPRING FIXER SUPPORT		01
12	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
13	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
14	0503010013	5/8 NUT		02
15	0503011445	SPRING WASHER		02
16	0503010691	1/4" GREASE FITTING		01
17	0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	78	01
18	0511064373	SMALLER TRIPLE DISC SUPPORT		01




Item	Code	Description	See page	QT
01	0502010978	SUPPORT FIXER		01
02	0501017315	5/8" X 124 BOLT		01
03	0501012140	FLAT WASHER		01
04	0503010811	5/8" UNF SELF ADJUSTING NUT		01
05	0511065789	FRONT PROTECTOR		01
06	0503010547	1/2" X 4" BOLT		02
07	0503011440	SPRING WASHER		06
08	0503010060	1/2 UNC G.5 ZN HEX NUT		06
09	0541014451	175 ROW SPACER		02
10	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER		02
11	0502040190	SPRING FIXER SUPPORT		01
12	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
13	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
14	0503010013	5/8 NUT		02
15	0503011445	SPRING WASHER		02
16	0503010691	1/4" GREASE FITTING		01
17	0511064373	SMALLER TRIPLE DISC SUPPORT		01
18	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	80	01




Item	Code	Description	See page	QT
01	0502010978	SUPPORT FIXER		01
02	0501017315	5/8" X 124 BOLT		01
03	0501012140	FLAT WASHER		01
04	0503010811	5/8" UNF SELF ADJUSTING NUT		01
05	0511065789	FRONT PROTECTOR		01
06	0503010547	1/2" X 4" BOLT		02
07	0503011440	SPRING WASHER		06
08	0503010060	1/2 UNC G.5 ZN HEX NUT		06
09	0541014451	175 ROW SPACER		02
10	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER		02
11	0502040190	SPRING FIXER SUPPORT		01
12	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
13	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
14	0503010013	5/8 NUT		02
15	0503011445	SPRING WASHER		02
16	0503010691	1/4" GREASE FITTING		01
17	0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	78	01
18	0511064374	LARGER TRIPLE DISC SUPPORT		01




Item	Code	Description	See page	QT
01	0502010978	SUPPORT FIXER		01
02	0501017315	5/8" X 124 BOLT		01
03	0501012140	FLAT WASHER		01
04	0503010811	5/8" UNF SELF ADJUSTING NUT		01
05	0511065789	FRONT PROTECTOR		01
06	0503010547	1/2" X 4" BOLT		02
07	0503011440	SPRING WASHER		06
08	0503010060	1/2 UNC G.5 ZN HEX NUT		06
09	0541014451	175 ROW SPACER		02
10	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER		02
11	0502040190	SPRING FIXER SUPPORT		01
12	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
13	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
14	0503010013	5/8 NUT		02
15	0503011445	SPRING WASHER		02
16	0503010691	1/4" GREASE FITTING		01
17	0511064374	LARGER TRIPLE DISC SUPPORT		01
18	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	80	01




Item	Code	Description	See page	QT
01	0502010978	SUPPORT FIXER		01
02	0501017315	5/8" X 124 BOLT		01
03	0501012140	FLAT WASHER		01
04	0503010811	5/8" UNF SELF ADJUSTING NUT		01
05	0511065789	FRONT PROTECTOR		01
06	0503010547	1/2" X 4" BOLT		02
07	0503011440	SPRING WASHER		08
08	0503010060	1/2 UNC G.5 ZN HEX NUT		08
09	0541014451	175 ROW SPACER		01
10	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER		02
11	0502040190	SPRING FIXER SUPPORT		01
12	0501010937	13,50 X 28 X 3,00 FLAT WASHER		06
13	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
14	0503010013	5/8 NUT		02
15	0503011445	SPRING WASHER		02
16	0503010691	1/4" GREASE FITTING		01
17	0511064374	LARGER TRIPLE DISC SUPPORT		01
18	0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	78	01
19	0511066111	RIGHT SIDE ROW SPACER		01
20	0541014789	ROW SPACING SIDE SUPPORT		01
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02




Item	Code	Description	See page	QT
01	0502010978	SUPPORT FIXER		01
02	0501017315	5/8" X 124 BOLT		01
03	0501012140	FLAT WASHER		01
04	0503010811	5/8" UNF SELF ADJUSTING NUT		01
05	0511065789	FRONT PROTECTOR		01
06	0503010547	1/2" X 4" BOLT		02
07	0503011440	SPRING WASHER		08
08	0503010060	1/2 UNC G.5 ZN HEX NUT		08
09	0541014451	175 ROW SPACER		01
10	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER		02
11	0502040190	SPRING FIXER SUPPORT		01
12	0501010937	13,50 X 28 X 3,00 FLAT WASHER		06
13	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
14	0503010013	5/8 NUT		02
15	0503011445	SPRING WASHER		02
16	0503010691	1/4" GREASE FITTING		01
17	0511064374	LARGER TRIPLE DISC SUPPORT		01
18	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	80	01
19	0511066112	LEFT SIDE ROW SPACER		01
20	0541014789	ROW SPACING SIDE SUPPORT		01
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02




Item	Code	Description	See page	QT
01	0502010978	SUPPORT FIXER		01
02	0501017315	5/8" X 124 BOLT		01
03	0501012140	FLAT WASHER		01
04	0503010811	5/8" UNF SELF ADJUSTING NUT		01
05	0511065789	FRONT PROTECTOR		01
06	0503010547	1/2" X 4" BOLT		02
07	0503011440	SPRING WASHER		08
08	0503010060	1/2 UNC G.5 ZN HEX NUT		08
09	0541014450	158 SPACER ROW		01
10	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER		02
11	0502040190	SPRING FIXER SUPPORT		01
12	0501010937	13,50 X 28 X 3,00 FLAT WASHER		06
13	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
14	0503010013	5/8 NUT		02
15	0503011445	SPRING WASHER		02
16	0503010691	1/4" GREASE FITTING		01
17	0511064374	LARGER TRIPLE DISC SUPPORT		01
18	0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	78	01
19	0511066111	RIGHT SIDE ROW SPACER		01
20	0541014789	ROW SPACING SIDE SUPPORT		01
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02




Item	Code	Description	See page	QT
01	0502010978	SUPPORT FIXER		01
02	0501017315	5/8" X 124 BOLT		01
03	0501012140	FLAT WASHER		01
04	0503010811	5/8" UNF SELF ADJUSTING NUT		01
05	0511065789	FRONT PROTECTOR		01
06	0503010547	1/2" X 4" BOLT		02
07	0503011440	SPRING WASHER		08
08	0503010060	1/2 UNC G.5 ZN HEX NUT		08
09	0541014450	158 SPACER ROW		01
10	0541014458	R 1/2" UNC X 3" X 3.5" FASTENER		02
11	0502040190	SPRING FIXER SUPPORT		01
12	0501010937	13,50 X 28 X 3,00 FLAT WASHER		06
13	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
14	0503010013	5/8 NUT		02
15	0503011445	SPRING WASHER		02
16	0503010691	1/4" GREASE FITTING		01
17	0511064374	LARGER TRIPLE DISC SUPPORT		01
18	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	80	01
19	0511066112	LEFT SIDE ROW SPACER		01
20	0541014789	ROW SPACING SIDE SUPPORT		01
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02




Item	Code	Description	See page	QT
001	0502010978	SUPPORT FIXER		01
002	0501017315	5/8" X 124 BOLT		01
003	0501012140	FLAT WASHER		01
004	0503010811	5/8" UNF SELF ADJUSTING NUT		01
005	0511065789	FRONT PROTECTOR		01
006	0503010547	1/2" X 4" BOLT		02
007	0503011440	SPRING WASHER		06
008	0503010060	1/2 UNC G.5 ZN HEX NUT		06
009	0511065104	ROW SPACING SPRING FIXER		01
010	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
011	0503010013	5/8 NUT		02
012	0503011445	SPRING WASHER		02
013	0511064373	SMALLER TRIPLE DISC SUPPORT		01
014	0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	78	01




Item	Code	Description	See page	QT
001	0502010978	SUPPORT FIXER		01
002	0501017315	5/8" X 124 BOLT		01
003	0501012140	FLAT WASHER		01
004	0503010811	5/8" UNF SELF ADJUSTING NUT		01
005	0511065789	FRONT PROTECTOR		01
006	0503010547	1/2" X 4" BOLT		02
007	0503011440	SPRING WASHER		06
008	0503010060	1/2 UNC G.5 ZN HEX NUT		06
009	0511065104	ROW SPACING SPRING FIXER		01
010	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
011	0503010013	5/8 NUT		02
012	0503011445	SPRING WASHER		02
013	0511064373	SMALLER TRIPLE DISC SUPPORT		01
014	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	80	01




Item	Code	Description	See page	QT
001	0502010978	SUPPORT FIXER		01
002	0501017315	5/8" X 124 BOLT		01
003	0501012140	FLAT WASHER		01
004	0503010811	5/8" UNF SELF ADJUSTING NUT		01
005	0511065789	FRONT PROTECTOR		01
006	0503010547	1/2" X 4" BOLT		02
007	0503011440	SPRING WASHER		06
008	0503010060	1/2 UNC G.5 ZN HEX NUT		06
009	0511065104	ROW SPACING SPRING FIXER		01
010	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
011	0503010013	5/8 NUT		02
012	0503011445	SPRING WASHER		02
013	0511064374	LARGER TRIPLE DISC SUPPORT		01
014	0501055808	RIGHT 15 X 15 UNAL DOUBLE-DISC	78	01




Item	Code	Description	See page	QT
001	0502010978	SUPPORT FIXER		01
002	0501017315	5/8" X 124 BOLT		01
003	0501012140	FLAT WASHER		01
004	0503010811	5/8" UNF SELF ADJUSTING NUT		01
005	0511065789	FRONT PROTECTOR		01
006	0503010547	1/2" X 4" BOLT		02
007	0503011440	SPRING WASHER		06
008	0503010060	1/2 UNC G.5 ZN HEX NUT		06
009	0511065104	ROW SPACING SPRING FIXER		01
010	0521010666	5/8" UNC X 3.7" X 3" FASTENER		01
011	0503010013	5/8 NUT		02
012	0503011445	SPRING WASHER		02
013	0511064374	LARGER TRIPLE DISC SUPPORT		01
014	0501055809	LEFT 15 X 15 UNAL DOUBLE-DISC	80	01




Item	Code	Description	See page	QT
01	0503030180	SEED DISTRIBUTOR BOX		01
02	0502010950	ROTOR		01
03	0503010366	ROTOR GUIDE		01
04	0501040236	SEED LIMETER	50	01
05	0503010370	502072 CLAMPING RING (FOR AXLE)		01
06	0501011064	ROTOR WHASHER		01
07	0503030189	COMPRES SPRING		01
08	0503050060	SEED DISTRIBUTOR BOX SWITCH		01
09	0503030756	SOCKET FASTENER		01
10	0503010369	SEED SOCKET		01
11	0501010637	FLAT WASHER		02
12	0503013813	1/4" UNC X 7/8" BOLT		04
13	0511017303	FLAT WASHER		08
14	0503011441	SPRING WASHER		04
15	0503010144	1/4" NUT		04




Item	Code	Description	See page	QT
01	0501110250	BEARING BOX		01
02	0502040154	BEARING REEL		01
03	0503010372	501050 CLAMPING RING (FOR AXLE)		01
04	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012114	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0501054151	RIGHT DOUBLE DISC COULTER BOX	79	01
03	0501054168	15" LEFT DOUBLE DISC HUB	81	01
04	0511011927	DUST CLOAK		02
05	0511015098	FLAT WASHER		04
06	0521019178	PROTECTION LID		02
07	0503030757	2.9" X 2" X 0.02" JOINT		02
08	0503014729	1/4" UNF X 1/2" BOLT		06
09	0503011441	SPRING WASHER		06
10	0531013568	RIGHT DOUBLE DISC SCRAPER		01
11	0531013569	LEFT DOUBLE-DISC SCRAPER		01
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
14	0503011443	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0502011933	DOUBLE DISC COULTER BOX		01
02	0503010598	30204 BALL BEARING		02
03	0521019154	RIGHT DOUB DISC HUB		01
04	0603022024	15" X 0.2" C1,2 PLAIN COULTER BLADE		01
05	0503011112	SEAL 02376-BRG		01
06	0503030282	3/4" CASTLE NUT		01
07	0503010257	1/8" X 1" COTTERPIN		01
08	0503010256	3/8" X 3/4" BOLT		03
09	0503011443	3/8" SPRING WASHER		03
10	0503010546	5/16" X 7/8" BOLT		09
11	0503010337	5/16" NUT		09




Item	Code	Description	See page	QT
01	0502012115	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0501054151	RIGHT DOUBLE DISC COULTER BOX	79	01
03	0501054168	15" LEFT DOUBLE DISC HUB	81	01
04	0511011927	DUST CLOAK		02
05	0511015098	FLAT WASHER		04
06	0521019178	PROTECTION LID		02
07	0503030757	2.9" X 2" X 0.02" JOINT		02
08	0503014729	1/4" UNF X 1/2" BOLT		06
09	0503011441	SPRING WASHER		06
10	0531013568	RIGHT DOUBLE DISC SCRAPER		01
11	0531013569	LEFT DOUBLE-DISC SCRAPER		01
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
14	0503011443	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0502011930	OPENING DISCS HUB		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019148	LEFT DOUBLE DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
001	0501061482	REGULATOR GUIDES		02
002	0521010495	0.5" X 0.6" X 2.9" SLEEVE		01
003	0521010653	BLADE DISC REG LOCK AXLE		01
004	0503030168	HITCH PIN CLIP		01
005	0503011123	BOLT		01
006	0503010481	BOLT		04
007	0503010025	3/8 SPRING WASHER		05
008	0503010026	3/8" NUT		05
009	0501044399	PLAIN DISC BLADE DISC ASSY	83	01




Item	Code	Description	See page	QT
001	0501061483	CUTTING DISC REGULATOR	01	
002	0501065138	CUTTING DISC ARM	01	
003	0502011278	BALDE DISC HUB	01	
004	0503010215	30205 BEARING	02	
005	0503010213	SEAL 30205	01	
006	0501010941	FLAT WASHER	01	
007	0503030282	3/4\" CASTLE NUT	01	
008	0503010362	1/8 X 1.1/4 COTTERPIN	01	
009	0503030272	3,1\" X 2,1\" X 0,01\" JOINT	01	
010	0521010383	BALDE DISC PROTECTION CAP	01	
011	0503011441	SPRING WASHER	03	
012	0503013758	1/4\" X 1-1/2\" BOLT	03	
013	0503010002	1800 GREASE FITTING	01	
014	0503010361	SPRING PIN	01	
015	0501011307	BLADE DISC SCRAPER	01	
016	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN	02	
017	0503011444	SPRING WASHER	02	
018	0503010337	5/16\" NUT	02	
019	0603021056	14\" X 0.1\" PLAIN COULTER BLADE	01	
020	0501013839	WASHER	01	
021	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN	06	
022	0503011444	SPRING WASHER	06	
023	0503010337	5/16\" NUT	06	
024	0503010002	1800 GREASE FITTING	01	




Item	Code	Description	See page	QT
01	0501056267	RH V PRESS SISTEM COMPL.	86	01
02	0502012353	PRESS WHEELS FIXER ASSY		01
03	0501052908	COMPACTOR WHEEL WITH BEARING	87	02
04	0521014508	FLAT WASHER		04
05	0503013739	1/2" X 1" BOLT		01
06	0503010752	1/2" X 3.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0501056268	LF PRESS SISTEM ASSY	88	01
02	0502012353	PRESS WHEELS FIXER ASSY		01
03	0501052908	COMPACTOR WHEEL WITH BEARING	87	02
04	0521014508	FLAT WASHER		04
05	0503013739	1/2" X 1" BOLT		01
06	0503010752	1/2" X 3.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502012021	WHELL RIGHT ARM ASSY		01
02	0503030883	RIGHT TORSION SPRING		01
03	0503010839	03"X 0.6" SPRING PIN		01
04	0503010002	1800 GREASE FITTING		01
05	0502011066	PRESS WHEELS ARM SUPPORT		01
06	0531017415	1" X 4.72" AXLE JOINT		01
07	0503010849	3/8" X 1-1/2" BOLT		02
08	0503011443	3/8" SPRING WASHER		02
09	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0502012022	WHELL LEFT ARM ASSY		01
02	0502011067	LEFT PRESS WHEELS ARM SUPPORT		01
03	0503010839	03"X 0.6" SPRING PIN		01
04	0503010002	1800 GREASE FITTING		01
05	0531017415	1" X 4.72" AXLE JOINT		01
06	0503030882	LEFT TORSION SPRING		01
07	0503010849	3/8" X 1-1/2" BOLT		02
08	0503011443	3/8" SPRING WASHER		02
09	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0502011068	RIGHT ARM		01
02	0501053187	LEFT IRON PRESS WHEEL ASSY	91	01
03	0502011155	RIGHT FIXER WHEEL		01
04	0501066592	IRON PRESS WHEEL LEFT SCRAPER		01
05	0502011066	PRESS WHEELS ARM SUPPORT		01
06	0503030883	RIGHT TORSION SPRING		01
07	0521010543	1" X 5" COUPLING SHAFT		01
08	0503010839	03"X 0.6" SPRING PIN		02
09	0503011082	C1/2" X 1.3/4" SCREW		02
10	0503011440	SPRING WASHER		02
11	0501010937	13,50 X 28 X 3,00 FLAT WASHER		02
12	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011069	ARM LEFT		01
02	0501053186	RIGHT IRON PRESS WHEEL ASSY	92	01
03	0502011156	LEFT FIXER WHEEL		01
04	0501066591	IRON PRESS WHEEL RIGHT SCRAPER		01
05	0502011067	LEFT PRESS WHEELS ARM SUPPORT		01
06	0503030882	LEFT TORSION SPRING		01
07	0521010543	1" X 5" COUPLING SHAFT		01
08	0503010839	03"X 0.6" SPRING PIN		02
09	0503011082	C1/2" X 1.3/4" SCREW		02
10	0503011440	SPRING WASHER		02
11	0501010937	13,50 X 28 X 3,00 FLAT WASHER		02
12	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011970	IRON PRESS WHEEL		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019148	LEFT DOUBLE DISC HUB		01
05	0511015098	FLAT WASHER		01
06	0503030282	3/4" CASTLE NUT		01
07	0503010257	1/8" X 1" COTTERPIN		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503013758	1/4" X 1-1/2" BOLT		03
12	0511016896	DUST CLOAK		01




Item	Code	Description	See page	QT
01	0502011970	IRON PRESS WHEEL		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019154	RIGHT DOUB DISC HUB		01
05	0511015098	FLAT WASHER		01
06	0503030282	3/4" CASTLE NUT		01
07	0503010257	1/8" X 1" COTTERPIN		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503013758	1/4" X 1-1/2" BOLT		03
12	0511016896	DUST CLOAK		01




Item	Code	Description	See page	QT
01	0503060718	ELECTRONIC BLADE HECTARE		01
02	0541013032	FIXER BLADE HECTARE		01
03	0541015265	RECEIVER MAGNETIC SUPPORT		01
04	0503011952	5/16" X 3/4" BOLT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0501010694	FLAT WASHER		02
07	0503010337	5/16" NUT		02
08	0541012961	FIXER COUNTER HECTARE		01
09	0541013031	HETARE MAGNET FASTENER		01




Item	Code	Description	See page	QT
01	0521065474	FRONT FORK		01
02	0521065475	REAR FORK		01
03	0511056479	LONGITUDINAL TRANSPORT WITHOUT TIRE	98	01
04	0503060091	L29.5"X0.63"-10L WHEEL AND		01
05	0503811052	1.1/4 UNF X 19,5 SA CASTLE NUT		02
06	0501810086	FLAT WASHER		01
07	0531015109	WHEEL AXLE LOCK		02
08	0503010002	1800 GREASE FITTING		01
09	0501068348	LONGIT TRANSP DRAWBAR		01
10	0521014542	1-1/2" X 5.8" COUPLING SHAFT		01
11	0501811301	CASTLE NUT		02
12	0511018782	2.4" X 1.6" X 3" BUSHING		01
13	0521010596	COUPLING SHAFT		02
14	0503031035	HITCH PIN CLIP		03
15	0521810580	COUPLING SHAFT		01
16	0521012545	COUPLING SHAFT		01
17	0502040733	TRACTOR HITCH		01
18	0503010010	1/4" X 2.1/2" COTTERPIN		02
19	0511060274	TRANSP WHEEL COUPLING SHAFT		02
20	0503030119	LOCK PIN		02
21	0521013850	1.1/2" UNC X 2200 COUPLING SHAFT		02
22	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		02
23	0503010010	1/4" X 2.1/2" COTTERPIN		02
24	0502040223	DRAWBOLT		01
25	0502040327	HITCH LOCK RING		01
26	0521810578	COUPLING SHAFT		01
27	0503010571	1/4" X 1.1/2 COTTERPIN		02
28	0503010002	1800 GREASE FITTING		01
29	0511068281	W10 X 28 WHEEL		01




Item	Code	Description	See page	QT
01	0511056480	FRONT FORK WITH TIRE	96	01
02	0511056481	FORK WITH REAR TIRE	97	01
03	0511060274	TRANSP WHEEL COUPLING SHAFT		02
04	0503030119	LOCK PIN		02
05	0521013850	1.1/2" UNC X 2200 COUPLING SHAFT		02
06	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		02
07	0503010010	1/4" X 2.1/2" COTTERPIN		02




Item	Code	Description	See page	QT
01	0521065474	FRONT FORK		01
02	0511056479	LONGITUDINAL TRANSPORT WITHOUT TIRE	98	01
03	0503060091	L29.5"X0.63"-10L WHEEL AND		01
04	0503011052	1.1/4" X 0.77" CASTLE NUT		02
05	0501010086	FLAT WASHER		01
06	0531015109	WHEEL AXLE LOCK		02
07	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0521065475	REAR FORK		01
02	0511056479	LONGITUDINAL TRANSPORT WITHOUT TIRE	98	01
03	0503060091	L29.5"X0.63"-10L WHEEL AND		01
04	0503011052	1.1/4" X 0.77" CASTLE NUT		02
05	0501010086	FLAT WASHER		01
06	0531015109	WHEEL AXLE LOCK		02
07	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0501110733	WHEEL HUB		01
01A	0502011120	TRANSP WHEEL HUB		01
01B	0501010127	9/16" X 1-7/8" LUG BOLT		06
01C	0503010035	9/16" CONIC NUT		06
02	0571017530	WHEELED AXLE		01
03	0503010328	25590/25523 ROLLER BEARING		02
04	0503010804	00547-B SEAL		02
05	0511015949	LOCK NUT		01
06	0503010329	LOCK WASHER		01
07	0503010330	KM 9 LOCKNUT		01
08	0503010002	1800 GREASE FITTING		01



MARCHESAN

Technical Publications | Elaboration and Revision

MARINA PEREZ NIZA

www.marchesan.com.br

