

ROW CROP PLANTERS

COP TRIO SUPREME P.P - 13/15/17 LINES - CSU

Code: 0501092132
Series: S-0117
Revision: 00
Date Revision: MARÇO/2018

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111420011	COP TRIO SUP PP 5750/13E450 ESPECIAL S-0117
0111420017	COP TRIO SUP PP 5750/13E450 ESPECIAL S-0117
0111420019	COP TRIO SUP PP 5750/13E450 ESPECIAL S-0117
0111420013	COP TRIO SUP PP 6350/13E500 MH MTH PP CSU S-0117
0111420014	COP TRIO SUP PP 6850/15E450 ESPECIAL S-0117
0111420018	COP TRIO SUP PP 6850/15E450 ESPECIAL S-0117
0111420015	COP TRIO SUP PP 6850/15E450 MH MTH PP CSU S-0117
0111420012	COP TRIO SUP PP 7350/15E500 ESPECIAL S-0117
0111420010	COP TRIO SUP PP 7350/15E500 MH2T MTH PP CSU S-0117
0111420016	COP TRIO SUP PP 8450/17E500 ESPECIAL S-0117
0111420009	COP TRIO SUP PP 8450/17E500 MH MTH PP CSU S-0117

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.

INDEX

0909093788	FRAME COP TRIO SUPR 13-15-17 L	1
0521050238	FRAME WITH ARTICULATION 7350	2
0521050978	CH C/ARTICULATION	3
0511059560	CH C/ARTICULATION	4
0511058136	FRAME WITH ARTICULATION 5750	5
0521050085	CH C/ARTICULATION	6
0511059494	TRACTION SPRING ASSY	7
0909093711	ASSY DRAWBAR	8
0909093712	ASSY DRAWBAR	9
0909093789	ASSY DRAWBAR	10
0521045756	HYDRAULIC CYLINDER	11
0511059237	3 POINT TURNBUCKLE	12
0521050133	TURNBUCKLE SIDE 755/480	13
0511055096	TRACTOR HITCH	14
0511058123	RIGHT WHEEL ASSY	15
0511058124	WHEELED ASSEMBLY LEFT	16
0511050439	RIGHT WHEEL ASSY	17
0511050440	WHITH LEFT WHEEL ASSY	18
0511050443	WHITH RIGHT WHEEL ASSY WITHOUT TRANSMISSION	19
0511050444	WHITH LEFT WHEEL ASSY WITHOUT TRANSMISSION	20
0521050234	PLATFORM ASSY 7350	21
0511057799	PLATFORM SET	22
0511059561	PLATFORM SET	23
0511058133	PLATFORM ASSEMBLY 5750	24
0521050076	PLATFORM ASSY	25
0521050229	ASSY SILO FERTILIZER RIGHT/LEFT/CENTRAL - 7350	26
0511057811	SET FERTILIZER SILO	27
0521050903	SET FERTILIZER SILO	28
0511058129	ASSY SILO FERTILIZER RIGHT/LEFT/CENTRAL - 5750	29
0521050077	SET FERTILIZER SILO	30
0521050220	LEFT FERTILIZER BEAM SUPPORT 7350	31
0511057812	LEFT FERTILIZER BOX SUPPORT 7655	32
0521050891	FERTILIZER BEAM SUPPORT	33
0511058130	LEFT FERTILIZER BOX SUPPORT 5750	34
0521050219	RIGHT FERTILIZER SILO SUPPORT 7350	35
0511057813	RIGHT FERTILIZER BOX SUPPORT 7655	36
0521050890	FERTILIZER BEAM SUPPORT	37
0511058131	RIGHT FERTILIZER BOX SUPPORT 5750	38
0521050218	CENTER FERTILIZER SILO SUPPORT 7350	39
0511057814	CENTER FERTILIZER SILO SUPPORT	40
0511058132	CENTRAL FERTILIZER BOX SUPPORT 5750	41
0521050069	LFT FERTILIZER BEAM SUPPORT	42
0521050070	FERTILIZER BEAM SUPPORT	43
0521050071	CENTER FERTILIZER SILO SUPPORT 7655	44
0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	45
0521050195	SILO FERTILIZER LEFT SQUARE AXLE	46
0521050235	HANDRAIL ASSEMBLY 7350	47
0511057800	JOINT HANDRAILSET	48
0511059562	JOINT HANDRAILSET	49
0511058134	HANDRAIL ASSEMBLY 5750	50
0521050075	JOINT HANDRAILSET	51
0521050847	HIDRAULIC ROW MARKER ASSY	52
0521050848	SEMI MOUNTED HYDRAULIC MARKER 5750	53
0909090391	ROW MARKER	54
0511058449	HYDRAULIC CYLINDER	55



MARCHESAN

INDEX

0501050633	MARKER DISC ASSY LINE	56
0511053904	DISC LINE MARKER	57
0521050689	HYDRAULIC ASSEMBLY 7350	58
0521050973	SET HIDRAULICO	59
0521050897	SET HIDRAULICO	60
0521050765	HYDRAULIC ASSEMBLY 5750	61
0521050849	SET HIDRAULICO	62
0521050584	ASSY VALVE	63
0511057843	OIL CONDUCTOR ASSY	64
0511058127	OIL 5750 CONDUCTOR ASSY	65
0521050231	OIL 7350 CONDUCTOR ASSY	66
0511059567	OIL CONDUCTOR ASSY	67
0511053368	HYDRAULIC CYLINDER ASSEMBLY	68
0521050695	HOSE KIT SYSTEM HYDRAULIC	69
0521050570	HYDRAULIC HOSE RIGHT PROTECTION	70
0521050572	PROTECTION LEFT HYDRAULIC HOSE	71
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	72
0501054649	SEQUENTIAL VALVE ASSY	73
0511058431	HYDRAULIC CYLINDER	74
0511048939	ASSY RIGHT EXCHANGE	75
0511050639	RIGHT GEAR BOX ASSY	76
0511048940	LEFT ASSY EXCHANGE	77
0511050640	LEFT GEAR BOX ASSY	78
0501058213	LH GEAR BOX	79
0501058212	SEMI MOUNTED RIGHT CHANGE	80
0501048790	AXLE WITH LINK ASSY	81
0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	82
0501056443	BEARING ASSY GEAR BOX	83
0501056271	BEARING CLOSED	84
0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	85
0511052333	ASSY SUPPORT LEFT FIXER CHANGE	86
0511054971	RESTING ASSEMBLY	87
0521050225	MOTOR SHAFT ASSEMBLY 7350	88
0511057797	MOTOR SHAFT ASSEMBLY	89
0511059566	MOTOR SHAFT ASSEMBLY	90
0511058125	MOTOR SHAFT ASSEMBLY 5750	91
0521050080	MOTOR SHAFT ASSEMBLY	92
0511047069	SIDE TRANSMISSION DRIVING	93
0511047070	LH SIDE TRANSMISSION DRIVING	94
0511051434	TRANSMISSION DRIVING ASSY	95
0501052560	AXLE MOTOR SLOW-MOVING ASSY	96
0511058146	MECHANICAL TRANSMISSION ASSEMBLY	97
0511059162	RIGHT TRANSMISSION ASSY	98
0511057815	RIGHT TRANSMISSION ASSY	99
0521050228	ASSEMBLY CSU C3 SEMI MOUNTED 7350	100
0521050979	ASSEMBLY CSU	101
0521050909	ASSEMBLY CSU	102
0511058579	ASSEMBLY CSU C3 SEMI MOUNTED 5750	103
0521050073	ASSEMBLY CSU	104
0511058564	ASSEMBLY CSU	105
0511058580	ASSEMBLY CSU	106
0511057755	ASSEMBLY CSU 6850	107
0511057951	ASSEMBLY CSU C3 2 BOXES 6B + 1 BOX 7B - 7350	108
0511057803	ASSY PORT MANUAL INSTRUCCION	109
0511053342	SQUARE AXLE ASSEMBLY (730)	110




MARCHESAN

INDEX

0521050763	HEX AXLE ASSEMBLY 5750	111
0521050898	HEX AXLE ASSEMBLY	112
0521050972	HEX AXLE ASSEMBLY	113
0521050688	HEX AXLE ASSEMBLY 7350	114
0521050079	HEX AXLE ASSEMBLY	115
0521050761	CONJ TURB PP COP	116
0521050686	CONJ TURB PP COP	117
0521050922	TURB PP COP	118
0511059508	TURB PP COP	119
0521050579	TURB PP COP	120
0521050564	TURB PP COP	121
0521050571	HYDRAULIC TURBINE ASSEMBLY	122
0521050566	VALVE ANTI-CAVITACAO	123
0521050565	FLOW DIVIDING VALVE ASSY	124
0521050729	DISTRIBUTOR SUPPORT AIR	125
0521050569	DISTRIBUTOR AIR CENTER	126
0511057348	DISTRIBUTOR VACUUM	127
0521050580	HOSE GUIDE	128
0521050582	SET HOSE KIT	129
0511059503	6 MOUTH AIR CONDUCTOR X 2150 - 6850	130
0521050531	4 MOUTHS RIGHT AIR CONDUCTOR - 13	131
0521050532	LEFT AIR CONDUCTOR 4 MOUTHS - 13	132
0521050690	SET HOSE KIT	133
0511059406	TURBINE P.P MOUNTED	134
0511059504	RIGHT AIR CONDUCTOR - 6850	135
0511059505	LEFT AIR CONDUCTOR - 6850	136
0511059318	CSU C3 SEMI-ASSEMBLED ASSY 5950/12	137
0511057906	HOSE ASSY	138
0909093773	SEED/ FERTILIZER ROW SUPREMA ASSY	139
0511057729	FRONT SEED SHORT	140
0511057730	FRONT SEED LONG	141
0521050577	FRONT LINE SEED ELONGATED	142
0511054884	TRANSMISSION BOX	143
0521050578	CH L SEM SM COP TRIO SUP PP S-0117	144
0511053024	FERTILIZER SHORT LINE	145
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	146
0511053023	LONG FERTILIZER LINE	147
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	148
0511053172	LEFT LOW CUBE WITH DISC 15	149
0511053173	CUBE LOW RIGHT WITH DISC 15	150
0511057108	RIGHT REAR SEED ROW PRECISION PLANTING CSU 3	151
0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA CSU 3	152
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	153
0511057154	DDD RITGH SUPREMA PRECISION PLANTING	154
0511057115	REAR LEFT SEED LINE PRECISION PLANTING CSU 3	155
0511057153	DDD LEFT SUPREMA PRECISION PLANTING	156
0521050012	RIGHT REAR ROW SEED P.P PM400/CSU	157
0501058972	ASSEMBLY SENSOR ELECTRONIC	158
0521050013	LEFT REAR ROW SEED P.P PM400/CSU	159
0501054481	RIGHT ARM DEPTH CONTROL WITH WHEEL	160
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	160
0501052297	DEPTH WHEELS REGULATOR ASSY	161
0501054482	DEPTH CONTROL LEFT ARM WITH TIRE	161
0501052627	ASSY DEPTH WHEEL BOX	162
0511051818	DISC CUT 18 SEMI MOUNTED	162


INDEX

0501052139	ASSY CUTTING DISK DPL18		163
0501052538	DEPTH BAND WITH ARMS		163
0511051819	DC 20 SEMI MOUNTED		164
0511054333	COMPACT WHEEL RIGHT WITH BEARING		164
0501052908	COMPACTOR WHEEL WITH BEARING		165
0501054887	20 BLADE DISC WITH FLAT PLAN DISC		165
0511054334	COMPACT WHEEL LEFT WITH BEARING		166
0521050525	FIXER FERTILIZER CONDUCTOR		166
0521046122	DEPTH SYSTEM / COMPACTOR ASSY		167
0521051424	WHEEL SYSTEM DEPTH/COMPACTOR QUICK ADJUSTMENT		167
0501056769	DEPTH WHEELS REGULATOR ASSY		168
0511058650	SEMI-MOUNTED DEPTH CONTROL		168
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE		169
0521051423	COMPACTOR SUPPORT		169
0511050077	WHEEL STRIPED		170
0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL		171
0511052971	CONTROL DEPTH WITH SEMI MOUNTED THREAD		172
0511059325	LEFT ARM WHEELS		173
0511059324	RIGHT ARM COATING WHEEL MOUNTED		174
0511051546	CUBE RIGHT CONTROL DEPTH		175
0511051547	LEFT CUBE CONTROL DEPTH		176
0511051583	DEPTH WHEEL HUB SEMIFINISHED		177
0511055819	DEPTH WHIT AROS BAND		178
0521044269	PRESS WHEELS/DEPTH ASSY		179
0511055326	DEPTH CONTROL PRESS WHEEL ASSY		180
0511055328	DEPTH WHEEL SYSTEM		181
0511055627	WHEEL ASSY RAYED		182
0511055329	LEFT DEPTH WHEEL		183
0501059228	ADJUSTMENT LEVER		184
0511055327	COMPACTING WHEEL V ASSY RUBBER		185
0521044460	SYSTEM DEPTH / COMPACTOR		186
0511055690	WHEEL SISTEM		187
0511055626	BOX ROUND DEPTH ROYAL WITH SPA		188
0511055629	DEPTH WHEEL SYSTEM		189




Item	Code	Description	See page	13 15 17 L
01	0511059560	CH C/ARTICULATION	4	01 00 00
02	0511058136	FRAME WITH ARTICULATION 5750	5	01 00 00
03	0521050978	CH C/ARTICULATION	3	00 01 00
04	0521050238	FRAME WITH ARTICULATION 7350	2	00 01 00
05	0521050085	CH C/ARTICULATION	6	00 00 01
06	0909093711	ASSY DRAWBAR	8	01 01 00
07	0909093712	ASSY DRAWBAR	9	01 01 00
08	0909093789	ASSY DRAWBAR	10	00 00 01
09	0511058123	RIGHT WHEEL ASSY	15	01 01 01
10	0511058124	WHEELED ASSEMBLY LEFT	16	01 01 01
11	0511050439	RIGHT WHEEL ASSY	17	01 01 01
12	0511050440	WHITH LEFT WHEEL ASSY	18	01 01 01
13	0511050443	WHITH RIGHT WHEEL ASSY WITHOUT TRANSMISSION	19	01 01 01
14	0511050444	WHITH LEFT WHEEL ASSY WITHOUT TRANSMISSION	20	01 01 01
15	0521050234	PLATFORM ASSY 7350	21	01 01 00
16	0511057799	PLATFORM SET	22	01 01 00
17	0511059561	PLATFORM SET	23	01 01 00
18	0511058133	PLATFORM ASSEMBLY 5750	24	01 01 00
19	0521050076	PLATFORM ASSY	25	00 00 01
20	0521050229	ASSY SILO FERTILIZER RIGHT/LEFT/CENTRAL - 7350	26	01 01 00
21	0511057811	SET FERTILIZER SILO	27	01 01 00
22	0521050903	SET FERTILIZER SILO	28	01 01 00
23	0511058129	ASSY SILO FERTILIZER RIGHT/LEFT/CENTRAL - 5750	29	01 01 00
24	0521050077	SET FERTILIZER SILO	30	00 00 01
25	0521050235	HANDRAIL ASSEMBLY 7350	47	01 01 00
26	0511057800	JOINT HANDRAILSET	48	01 01 00
27	0511059562	JOINT HANDRAILSET	49	01 01 00
28	0511058134	HANDRAIL ASSEMBLY 5750	50	01 01 00


Item	Code	Description	See page	13 15 17 L
29	0521050075	JOINT HANDRAILSET	51	00 00 01
30	0521050847	HIDRAULIC ROW MARKER ASSY	52	01 01 00
31	0521050848	SEMI MOUNTED HYDRAULIC MARKER 5750	53	01 01 00
32	0909090391	ROW MARKER	54	01 01 01
33	0521050689	HYDRAULIC ASSEMBLY 7350	58	01 01 00
34	0521050973	SET HIDRAULICO	59	01 01 00
35	0521050897	SET HIDRAULICO	60	01 01 00
36	0521050765	HYDRAULIC ASSEMBLY 5750	61	01 01 00
37	0503032624	SILO FERTILIZER GUTTER		01 01 01
38	0521050849	SET HIDRAULICO	62	00 00 01
39	0511048939	ASSY RIGHT EXCHANGE	75	01 01 00
40	0511050639	RIGHT GEAR BOX ASSY	76	00 00 01
41	0511048940	LEFT ASSY EXCHANGE	77	01 01 00
42	0511050640	LEFT GEAR BOX ASSY	78	00 00 01
43	0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	85	01 01 01
44	0511052333	ASSY SUPPORT LEFT FIXER CHANGE	86	01 01 01
45	0511053356	ASSY LADDER		01 01 01
46	0511054971	RESTING ASSEMBLY	87	02 02 02
47	0521050225	MOTOR SHAFT ASSEMBLY 7350	88	01 01 00
48	0511057797	MOTOR SHAFT ASSEMBLY	89	01 01 00
49	0511059566	MOTOR SHAFT ASSEMBLY	90	01 01 00
50	0511058125	MOTOR SHAFT ASSEMBLY 5750	91	01 01 00
51	0521050080	MOTOR SHAFT ASSEMBLY	92	00 00 01
52	0511058146	MECHANICAL TRANSMISSION ASSEMBLY	97	01 01 00
53	0511057815	RIGHT TRANSMISSION ASSY	99	00 00 01
54	0511059162	RIGHT TRANSMISSION ASSY	98	01 01 00
55	0521050228	ASSEMBLY CSU C3 SEMI MOUNTED 7350	100	01 01 00
56	0521050979	ASSEMBLY CSU	101	01 01 00
57	0521050909	ASSEMBLY CSU	102	01 01 00
58	0511058579	ASSEMBLY CSU C3 SEMI MOUNTED 5750	103	01 01 00
59	0521050073	ASSEMBLY CSU	104	00 00 01
60	0511057803	ASSY PORT MANUAL INSTRUCCION	109	01 01 01
61	0511053342	SQUARE AXLE ASSEMBLY (730)	110	02 02 02
62	0521050763	HEX AXLE ASSEMBLY 5750	111	01 01 00
63	0521050898	HEX AXLE ASSEMBLY	112	01 01 00
64	0521050972	HEX AXLE ASSEMBLY	113	01 01 00
65	0521050688	HEX AXLE ASSEMBLY 7350	114	01 01 00
66	0521050079	HEX AXLE ASSEMBLY	115	00 00 01
67	0521050761	CONJ TURB PP COP	116	01 01 00
68	0521050686	CONJ TURB PP COP	117	01 01 00
69	0521050922	TURB PP COP	118	01 01 00
70	0511059508	TURB PP COP	119	01 01 00
71	0521050579	TURB PP COP	120	00 00 01
72	0909093773	SEED/ FERTILIZER ROW SUPREMA ASSY	139	13 15 17




Item	Code	Description	See page	QT
01	0521067445	CH LAT DIR COP TRIO 7350 S-0415		01
02	0521067076	CENTRAL CHASSIS		01
03	0521067446	CH LAT ESQ COP TRIO 7350 S-0415		01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0503011442	3/4" SPRING WASHER		16
06	0501010098	3/4" UNC BOLT		16
07	0571010094	SLEEVE FLANGE		12
08	0521066298	ARTICULATOR		04
09	0571013510	LOCK AXLE		04
10	0503030085	LOCK PIN		04
11	0571010095	FLAT WASHER		04
12	0503011442	3/4" SPRING WASHER		04
13	0501010098	3/4" UNC BOLT		04
14	0521063003	LOCK PIN		02
15	0571010969	LOCK SLEEVE FRAME		02
16	0503013627	1.1/2 SPRING WASHER		02
17	0501010110	1.1/2" NUT		02




Item	Code	Description	See page	QT
001	0521067797	CH LAT DIR COP TRIO 6850 S-0117		01
002	0521066293	CENTRAL CHASSIS		01
003	0521067798	CH LAT ESQ COP TRIO 6850 S-0117		01
004	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
005	0503011442	3/4" SPRING WASHER		16
006	0501010098	3/4" UNC BOLT		16
007	0571010094	SLEEVE FLANGE		12
008	0521066298	ARTICULATOR		04
009	0571013510	LOCK AXLE		04
010	0503030085	LOCK PIN		04
011	0571010095	FLAT WASHER		04
012	0503011442	3/4" SPRING WASHER		04
013	0501010098	3/4" UNC BOLT		04
014	0521063003	LOCK PIN		02
015	0571010969	LOCK SLEEVE FRAME		02
016	0503013627	1.1/2 SPRING WASHER		02
017	0501010110	1.1/2" NUT		02
018	0511059494	TRACTION SPRING ASSY	7	10
019	0521064285	LOCK LOWER FRAME		04
020	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		04



Item	Code	Description	See page	QT
001	0521067077	RIGHT SIDE FRAME ASSY		01
002	0521067076	CENTRAL CHASSIS		01
003	0521067078	RIGHT SIDE FRAME ASSY		01
004	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
005	0503011442	3/4" SPRING WASHER		16
006	0501010098	3/4" UNC BOLT		16
007	0571010094	SLEEVE FLANGE		12
008	0521066298	ARTICULATOR		04
009	0571013510	LOCK AXLE		04
010	0503030085	LOCK PIN		04
011	0571010095	FLAT WASHER		04
012	0503011442	3/4" SPRING WASHER		04
013	0501010098	3/4" UNC BOLT		04
014	0521063003	LOCK PIN		02
015	0571010969	LOCK SLEEVE FRAME		02
016	0503013627	1.1/2 SPRING WASHER		02
017	0501010110	1.1/2" NUT		02
018	0511059494	TRACTION SPRING ASSY	7	10
019	0521064285	LOCK LOWER FRAME		04
020	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		04




Item	Code	Description	See page	QT
01	0521066475	RIGHT SIDE FRAME ASSY	01	
02	0521066293	CENTRAL CHASSIS	01	
03	0521066476	RIGHT SIDE FRAME ASSY	01	
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES	04	
05	0503011442	3/4" SPRING WASHER	16	
06	0501010098	3/4" UNC BOLT	16	
07	0571010094	SLEEVE FLANGE	12	
08	0521066298	ARTICULATOR	04	
09	0571013510	LOCK AXLE	04	
10	0503030085	LOCK PIN	04	
11	0571010095	FLAT WASHER	04	
12	0503011442	3/4" SPRING WASHER	04	
13	0501010098	3/4" UNC BOLT	04	
14	0521063003	LOCK PIN	02	
15	0571010969	LOCK SLEEVE FRAME	02	
16	0503013627	1.1/2 SPRING WASHER	02	
17	0501010110	1.1/2" NUT	02	



Item	Code	Description	See page	QT
001	0521067408	RIGHT SIDE FRAME ASSY		01
002	0521067410	CENTRAL FRAME		01
003	0521067409	LEFT SIDE FRAME ASSY		01
004	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
005	0503011442	3/4" SPRING WASHER		16
006	0501010098	3/4" UNC BOLT		16
007	0571010094	SLEEVE FLANGE		12
008	0521066298	ARTICULATOR		04
009	0571013510	LOCK AXLE		04
010	0503030085	LOCK PIN		04
011	0571010095	FLAT WASHER		04
012	0503011442	3/4" SPRING WASHER		04
013	0501010098	3/4" UNC BOLT		04
014	0521063003	LOCK PIN		02
015	0571010969	LOCK SLEEVE FRAME		02
016	0503013627	1.1/2 SPRING WASHER		02
017	0501010110	1.1/2" NUT		02
018	0521050085	CH C/ARTICULATION	6	10
019	0521064285	LOCK LOWER FRAME		04
020	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		04

TRACTION SPRING ASSY


0511059494



Item	Code	Description	See page	QT
01	0503013030	5/8" X 3.1/4" BOLT		02
02	0511050681	TRACTION SPRING		01
02A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
02B	0561016062	SPRING HITCH		02
03	0501012140	FLAT WASHER		04

ASSY DRAWBAR

0909093711



Item	Code	Description	See page	QT
01	0521066290	INTERMEDIATE HEAD 5750/6850/7860/8160		01
02	0521066289	FRONT HEADER 5750/6350/6850		01
03	0571019949	JUNCTION SHAFT		05
04	0503030119	LOCK PIN		05
05	0521045756	HYDRAULIC CYLINDER	11	02
06	0521010581	0.9" X 4.9" COUPLING SHAFT		01
07	0521010779	31.75 X 95 COUPLING SHAFT		01
08	0531016049	FLAT WASHER		02
09	0503030085	LOCK PIN		02
10	0511059237	3 POINT TURNBUCKLE	12	01
11	0571019950	COUPLING SHAFT		01
12	0571019951	JUNCTION SHAFT		01
13	0503010523	1/4" X 2" COTTERPIN		02
14	0503030119	LOCK PIN		02
15	0521051614	TURNBUCKLE SIDE UPPER		02
16	0521010571	COUPLING SHAFT		04
17	0503030085	LOCK PIN		04
18	0521050133	TURNBUCKLE SIDE 755/480	13	02
19	0571019951	JUNCTION SHAFT		02
20	0503010523	1/4" X 2" COTTERPIN		02
21	0503030119	LOCK PIN		02
22	0521067716	FIXER TUBE		04
23	1902010175	HITCH CLAMP		04
24	0503016485	BOLT 3/4		08
25	0501010322	FLAT WASHER		16
26	0503010152	3/4" SELF LOCKING NUT		08
27	0511055096	TRACTOR HITCH	14	01
28	0511053179	TRACTOR HITCH AXLE		01
28A	0521064036	TRACTOR HITCH AXLE		01
28B	0503030012	HAIR PIN		01
29	0511056736	HOSE SUPPORT		01


**ASSY DRAWBAR**

0909093711

Item	Code	Description	See page	QT
29A	0521065611	HOSE SUPPORT		01
29B	0503010023	3/4" SPRING WASHER		01
29C	0503010014	3/4" NUT		01
30	0503014120	CHAIN		01
31	0503014321	CABLE STEEL SHACKLE		02

ASSY DRAWBAR

0909093712



Item	Code	Description	See page	QT
01	0521067075	INTERMEDIATE HEAD 6450/7285/7350/7450/8460		01
02	0521066289	FRONT HEADER 5750/6350/6850		01
03	0571019949	JUNCTION SHAFT		05
04	0503030119	LOCK PIN		05
05	0521045756	HYDRAULIC CYLINDER	11	02
06	0521010581	0.9" X 4.9" COUPLING SHAFT		01
07	0521010779	31.75 X 95 COUPLING SHAFT		01
08	0531016049	FLAT WASHER		02
09	0503030085	LOCK PIN		02
10	0511059237	3 POINT TURNBUCKLE	12	01
11	0571019950	COUPLING SHAFT		01
12	0571019951	JUNCTION SHAFT		01
13	0503010523	1/4" X 2" COTTERPIN		02
14	0503030119	LOCK PIN		02
15	0521051614	TURNBUCKLE SIDE UPPER		02
16	0521010571	COUPLING SHAFT		04
17	0503030085	LOCK PIN		04
18	0521050133	TURNBUCKLE SIDE 755/480	13	02
19	0571019951	JUNCTION SHAFT		02
20	0503010523	1/4" X 2" COTTERPIN		02
21	0503030119	LOCK PIN		02
22	0521067716	FIXER TUBE		04
23	1902010175	HITCH CLAMP		04
24	0503016485	BOLT 3/4		08
25	0501010322	FLAT WASHER		16
26	0503010152	3/4" SELF LOCKING NUT		08
27	0511055096	TRACTOR HITCH	14	01
28	0511053179	TRACTOR HITCH AXLE		01
28A	0521064036	TRACTOR HITCH AXLE		01
28B	0503030012	HAIR PIN		01
29	0511056736	HOSE SUPPORT		01


**ASSY DRAWBAR**

0909093712

Item	Code	Description	See page	QT
29A	0521065611	HOSE SUPPORT		01
29B	0503010023	3/4" SPRING WASHER		01
29C	0503010014	3/4" NUT		01
30	0503014120	CHAIN		01
31	0503014321	CABLE STEEL SHACKLE		02

ASSY DRAWBAR

0909093789




Item	Code	Description	See page	QT
01	0521067407	INTERMEDIATE HEAD 7655		01
02	0521067406	DRAWBAR ASSY 7655		01
03	0571019949	JUNCTION SHAFT		05
04	0503030119	LOCK PIN		05
05	0521045756	HYDRAULIC CYLINDER	11	02
06	0521010581	0.9" X 4.9" COUPLING SHAFT		01
07	0521010779	31.75 X 95 COUPLING SHAFT		01
08	0531016049	FLAT WASHER		02
09	0503030085	LOCK PIN		02
10	0511059237	3 POINT TURNBUCKLE	12	01
11	0571019950	COUPLING SHAFT		01
12	0571019951	JUNCTION SHAFT		01
13	0503010523	1/4" X 2" COTTERPIN		02
14	0503030119	LOCK PIN		02
15	0521051614	TURNBUCKLE SIDE UPPER		02
16	0521010571	COUPLING SHAFT		04
17	0503030085	LOCK PIN		04
18	0521050133	TURNBUCKLE SIDE 755/480	13	02
19	0571019951	JUNCTION SHAFT		02
20	0503010523	1/4" X 2" COTTERPIN		02
21	0503030119	LOCK PIN		02
22	0521067716	FIXER TUBE		04
23	1902010175	HITCH CLAMP		04
24	0503016485	BOLT 3/4		08
25	0501010322	FLAT WASHER		16
26	0503010152	3/4" SELF LOCKING NUT		08
27	0511055096	TRACTOR HITCH	14	01
28	0511053179	TRACTOR HITCH AXLE		01
28A	0521064036	TRACTOR HITCH AXLE		01
28B	0503030012	HAIR PIN		01
29	0511056736	HOSE SUPPORT		01

**ASSY DRAWBAR**

0909093789


Item	Code	Description	See page	QT
29A	0521065611	HOSE SUPPORT		01
29B	0503010023	3/4" SPRING WASHER		01
29C	0503010014	3/4" NUT		01
30	0503014120	CHAIN		01
31	0503014321	CABLE STEEL SHACKLE		02




Item	Code	Description	See page	QT
01	0511057653	HYDRAULIC CYLINDER		01
02	0501053835	FEMALE QUICK COUPLER		02

3 POINT TURNBUCKLE

0511059237




Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0511061880	SIDE RIGHT RATCHET		01
03	0511061881	RATCHET FOLLOWER		01
04	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
05	0503011179	3/8" X 2-1/4" BOLT		05
06	0503010025	3/8" SPRING WASHER		05
07	0503010026	3/8" NUT		05
08	0503010002	1800 GREASE FITTING		02
09	0531010264	SIDE RATCHET		01
10	0521066919	3-POINT EXTENSOR RIGHT FUSE		01
11	0521066337	LEFT EXTENSOR 3 SPIKE		01



Item	Code	Description	See page	QT
01	0521065193	TURNBUCKLE AXLE		01
02	0521067392	FIXED BRACKET		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0521067393	EXTERNAL SIDE EAR		01
06	0571019949	JUNCTION SHAFT		01
07	0503030119	LOCK PIN		01
08	0503010002	1800 GREASE FITTING		03

TRACTOR HITCH


0511055096



Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	COMPRESSION SPRING LEFT		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01

RIGHT WHEEL ASSY

0511058123




Item	Code	Description	See page	QT
01	0521066480	RH WHEELS SUPPORT	01	
02	0501054284	STRETCHER CURRENT TRANSMISSION SIDE	01	
03	0511064744	WHEEL FORK	01	
04	0501110625	BEARING ARTICULATION WHEEL	02	
05	0503013232	1/2" BOLT	08	
06	0503010019	1/2" SPRING WASHER	08	
07	0561013021	BEARING INNER LOK	02	
08	0561013022	BEARING EXTERNAL LOCK	02	
09	0503010398	501082 CLAMPING RING (FOR AXLE)	02	
10	0561013020	KM 12 NUT	02	
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX	01	
12	0521012190	AXLE LOCK	02	
13	0503010027	5/8" SPRING WASHER	02	
14	0503011167	M16 X 2 X 30 BOLT	02	
15	0511061808	15Z GEAR WITH AXLE,	01	
16	0501018466	FLAT WASHER	01	
17	0511061809	15Z GEAR WITH COUPLING	01	
18	0503011103	7/16" X 2-1/2" BOLT	01	
19	0503010180	7/16" SPRING WASHER	01	
20	0503010244	7/16" NUT	01	
21	0503010004	1890 GREASE FITTING	02	
22	0541012098	LEFT CHAIN TIGHTENER LARGER SUPPORT	01	
23	0531018653	CHAIN TIGHTENER MINOR SUPPORT	01	
24	0531016916	SLEEVE BEARING SUPPORT	02	
25	0503010899	5/8" X 2-1/4" BOLT	01	
26	0503010027	5/8" SPRING WASHER	01	
27	0503010013	5/8" NUT	01	
28	0501013491	5/8" TENSIONER SPRING	01	
29	0503010013	5/8" NUT	02	
30	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING	01	
31	0501053522	WHEEL CHAIN TENSIONER	01	

RIGHT WHEEL ASSY

0511058123

Item	Code	Description	See page	QT
32	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
33	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
34	0511053375	CURRENT DEVIATION ASSY WHEEL		01
35	0531016051	CARRY-WHEEL CHAIN PROTECTION CAP		01
36	0503010834	1/2 X 1 BOLT		02
37	0511017302	FLAT WASHER		02
38	0503010019	1/2" SPRING WASHER		02
39	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
40	0511010736	5/8" X 5-1/4" BOLT		04
41	0501013753	FLAT WASHER		04
42	0503010811	5/8" UNF SELF ADJUSTING NUT		04
43	0502012720	WHEEL SUPPORT FIXER		01
44	0503017857	BOLT 5/8 UNF 4		04
45	0503010811	5/8" UNF SELF ADJUSTING NUT		04
46	0501012140	FLAT WASHER		04



Item	Code	Description	See page	QT
01	0521066479	RH WHEELS SUPPORT	01	
02	0501054284	STRETCHER CURRENT TRANSMISSION SIDE	01	
03	0511065842	LEFT WHEEL FORK	01	
04	0501110625	BEARING ARTICULATION WHEEL	02	
05	0503013232	1/2" BOLT	08	
06	0503010019	1/2" SPRING WASHER	08	
07	0561013021	BEARING INNER LOK	02	
08	0561013022	BEARING EXTERNAL LOCK	02	
09	0503010398	501082 CLAMPING RING (FOR AXLE)	02	
10	0561013020	KM 12 NUT	02	
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX	01	
12	0521012190	AXLE LOCK	02	
13	0503010027	5/8" SPRING WASHER	02	
14	0503011167	M16 X 2 X 30 BOLT	02	
15	0511061808	15Z GEAR WITH AXLE,	01	
16	0501018466	FLAT WASHER	01	
17	0511061809	15Z GEAR WITH COUPLING	01	
18	0503011103	7/16" X 2-1/2" BOLT	01	
19	0503010180	7/16" SPRING WASHER	01	
20	0503010244	7/16" NUT	01	
21	0503010004	1890 GREASE FITTING	02	
22	0531018654	CHAIN TIGHTENER SUPPORT	01	
23	0531018653	CHAIN TIGHTENER MINOR SUPPORT	01	
24	0531016916	SLEEVE BEARING SUPPORT	02	
25	0503010899	5/8" X 2-1/4" BOLT	01	
26	0503010027	5/8" SPRING WASHER	01	
27	0503010013	5/8" NUT	01	
28	0501013491	5/8" TENSIONER SPRING	01	
29	0503010013	5/8" NUT	02	
30	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING	01	
31	0501053522	WHEEL CHAIN TENSIONER	01	


WHEELED ASSEMBLY LEFT

0511058124

Item	Code	Description	See page	QT
32	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
33	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
34	0511053375	CURRENT DEVIATION ASSY WHEEL		01
35	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		01
36	0503010834	1/2 X 1 BOLT		02
37	0511017302	FLAT WASHER		02
38	0503010019	1/2" SPRING WASHER		02
39	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
40	0511010736	5/8" X 5-1/4" BOLT		04
41	0501013753	FLAT WASHER		04
42	0503010811	5/8" UNF SELF ADJUSTING NUT		04
43	0502012720	WHEEL SUPPORT FIXER		01
44	0503017857	BOLT 5/8 UNF 4		04
45	0503010811	5/8" UNF SELF ADJUSTING NUT		04
46	0501012140	FLAT WASHER		04

RIGHT WHEEL ASSY

0511050439




Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT	01	
02	0501054284	STRETCHER CURRENT TRANSMISSION SIDE	01	
03	0511064744	WHEEL FORK	01	
04	0501110625	BEARING ARTICULATION WHEEL	02	
05	0503013232	1/2" BOLT	08	
06	0503010019	1/2" SPRING WASHER	08	
07	0561013021	BEARING INNER LOK	02	
08	0561013022	BEARING EXTERNAL LOCK	02	
09	0503010398	501082 CLAMPING RING (FOR AXLE)	02	
10	0561013020	KM 12 NUT	02	
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX	01	
12	0591010589	BODY LOCK WHEEL	02	
13	0503010027	5/8" SPRING WASHER	02	
14	0503011167	M16 X 2 X 30 BOLT	02	
15	0511061808	15Z GEAR WITH AXLE,	01	
16	0501018466	FLAT WASHER	01	
17	0511061809	15Z GEAR WITH COUPLING	01	
18	0503011103	7/16" X 2-1/2" BOLT	01	
19	0503010180	7/16" SPRING WASHER	01	
20	0503010244	7/16" NUT	01	
21	0503010004	1890 GREASE FITTING	02	
22	0541012098	LEFT CHAIN TIGHTENER LARGER SUPPORT	01	
23	0531018653	CHAIN TIGHTENER MINOR SUPPORT	01	
24	0531016916	SLEEVE BEARING SUPPORT	02	
25	0503010899	5/8" X 2-1/4" BOLT	01	
26	0503010027	5/8" SPRING WASHER	01	
27	0503010013	5/8" NUT	01	
28	0501013491	5/8" TENSIONER SPRING	01	
29	0503010013	5/8" NUT	02	
30	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING	01	
31	0501053522	WHEEL CHAIN TENSIONER	01	

RIGHT WHEEL ASSY

0511050439

Item	Code	Description	See page	QT
32	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
33	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
34	0511053375	CURRENT DEVIATION ASSY WHEEL		01
35	0531016051	CARRY-WHEEL CHAIN PROTECTION CAP		01
36	0503010834	1/2 X 1 BOLT		02
37	0511017302	FLAT WASHER		02
38	0503010019	1/2" SPRING WASHER		02
39	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
40	0503016485	BOLT 3/4		04
41	0501010322	FLAT WASHER		04
42	0503010152	3/4" SELF LOCKING NUT		04
43	0502012720	WHEEL SUPPORT FIXER		01
44	0503017857	BOLT 5/8 UNF 4		04
45	0503010811	5/8" UNF SELF ADJUSTING NUT		04
46	0501012140	FLAT WASHER		04
47	0501047888	ROD STOP		01




Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT	01	
02	0501054284	STRETCHER CURRENT TRANSMISSION SIDE	01	
03	0511065842	LEFT WHEEL FORK	01	
04	0501110625	BEARING ARTICULATION WHEEL	02	
05	0503013232	1/2" BOLT	08	
06	0503010019	1/2" SPRING WASHER	08	
07	0561013021	BEARING INNER LOK	02	
08	0561013022	BEARING EXTERNAL LOCK	02	
09	0503010398	501082 CLAMPING RING (FOR AXLE)	02	
10	0561013020	KM 12 NUT	02	
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX	01	
12	0591010589	BODY LOCK WHEEL	02	
13	0503010027	5/8" SPRING WASHER	02	
14	0503011167	M16 X 2 X 30 BOLT	02	
15	0511061808	15Z GEAR WITH AXLE,	01	
16	0501018466	FLAT WASHER	01	
17	0511061809	15Z GEAR WITH COUPLING	01	
18	0503011103	7/16" X 2-1/2" BOLT	01	
19	0503010180	7/16" SPRING WASHER	01	
20	0503010244	7/16" NUT	01	
21	0503010004	1890 GREASE FITTING	02	
22	0531018654	CHAIN TIGHTENER SUPPORT	01	
23	0531018653	CHAIN TIGHTENER MINOR SUPPORT	01	
24	0531016916	SLEEVE BEARING SUPPORT	02	
25	0503010899	5/8" X 2-1/4" BOLT	01	
26	0503010027	5/8" SPRING WASHER	01	
27	0503010013	5/8" NUT	01	
28	0501013491	5/8" TENSIONER SPRING	01	
29	0503010013	5/8" NUT	02	
30	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING	01	
31	0501053522	WHEEL CHAIN TENSIONER	01	


WHITH LEFT WHEEL ASSY

0511050440


Item	Code	Description	See page	QT
32	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
33	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
34	0511053375	CURRENT DEVIATION ASSY WHEEL		01
35	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		01
36	0503010834	1/2 X 1 BOLT		02
37	0511017302	FLAT WASHER		02
38	0503010019	1/2" SPRING WASHER		02
39	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
40	0503016485	BOLT 3/4		04
41	0501010322	FLAT WASHER		04
42	0503010152	3/4" SELF LOCKING NUT		04
43	0502012720	WHEEL SUPPORT FIXER		01
44	0503017857	BOLT 5/8 UNF 4		04
45	0503010811	5/8" UNF SELF ADJUSTING NUT		04
46	0501012140	FLAT WASHER		04
47	0501047888	ROD STOP		01



Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0503011167	M16 X 2 X 30 BOLT		02
03	0511064744	WHEEL FORK		01
04	0501110625	BEARING ARTICULATION WHEEL		02
05	0503013232	1/2' BOLT		08
06	0503010019	1/2" SPRING WASHER		08
07	0561013021	BEARING INNER LOK		02
08	0561013022	BEARING EXTERNAL LOCK		02
09	0503010398	501082 CLAMPING RING (FOR AXLE)		02
10	0561013020	KM 12 NUT		02
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX		01
12	0521012190	AXLE LOCK		02
13	0503010027	5/8" SPRING WASHER		02
14	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
15	0511010736	5/8" X 5-1/4" BOLT		04
16	0501013753	FLAT WASHER		04
17	0503010811	5/8" UNF SELF ADJUSTING NUT		04
18	0502012720	WHEEL SUPPORT FIXER		01
19	0503017857	BOLT 5/8 UNF 4		04
20	0503010811	5/8" UNF SELF ADJUSTING NUT		04
21	0501012140	FLAT WASHER		04
22	0501047888	ROD STOP		01




Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT	01	
02	0503011167	M16 X 2 X 30 BOLT	02	
03	0511065842	LEFT WHEEL FORK	01	
04	0501110625	BEARING ARTICULATION WHEEL	02	
05	0503013232	1/2" BOLT	08	
06	0503010019	1/2" SPRING WASHER	08	
07	0561013021	BEARING INNER LOK	02	
08	0561013022	BEARING EXTERNAL LOCK	02	
09	0503010398	501082 CLAMPING RING (FOR AXLE)	02	
10	0561013020	KM 12 NUT	02	
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX	01	
12	0521012190	AXLE LOCK	02	
13	0503010027	5/8" SPRING WASHER	02	
14	0502010584	CARRYING-WHEELS SUPPORT FIXER	02	
15	0511010736	5/8" X 5-1/4" BOLT	04	
16	0501013753	FLAT WASHER	04	
17	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
18	0503017857	BOLT 5/8 UNF 4	04	
19	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
20	0501012140	FLAT WASHER	04	
21	0502012720	WHEEL SUPPORT FIXER	01	
22	0501047888	ROD STOP	01	



Item	Code	Description	See page	QT
01	0521061861	PLATFORM FIXER	02	
02	0511069661	PLATFORM SUPPORT PIVOT	04	
03	0503010849	3/8" X 1-1/2" BOLT	12	
04	0501010984	FLAT WASHER	24	
05	0503010025	3/8" SPRING WASHER	12	
06	0503010026	3/8" NUT	12	
07	0521067448	SIDE PLATFORM	01	
08	0521067447	RIGHT PLATAFORM	01	
09	0521067086	PLATFORM CENTER	01	
10	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	06	
11	0503011336	1/2" HEX SELF ADJUSTING NUT	06	
12	0503011333	COVER FIXER	03	
13	0503010274	5/32"X 2" COTTERPIN	03	
14	0551019115	LOCKING PLATFORM FIXATION	03	
15	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	
16	0501010096	3/8" X 2" BOLT	02	
17	0571019831	X 0.2" SLEEVE	02	
18	0501010984	FLAT WASHER	03	
19	0503013357	3/8" SELF-ADJUSTING NUT	03	
20	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
21	0502012739	PLATFORM LEFT FIXER SUPPORT	02	
22	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	02	
23	0503010019	1/2" SPRING WASHER	02	
24	0503010060	1/2" NUT	02	
25	0571017990	PLATFORM ENHANCEMENT PROTECTION	02	
26	0501010942	3/8" X 1-1/4" BOLT	04	
27	0501010984	FLAT WASHER	04	
28	0503010025	3/8" SPRING WASHER	04	
29	0503010026	3/8" NUT	04	

PLATFORM SET


0511057799




Item	Code	Description	See page	QT
001	0521061861	PLATFORM FIXER	02	
002	0511069661	PLATFORM SUPPORT PIVOT	04	
003	0503010849	3/8" X 1-1/2" BOLT	12	
004	0501010984	FLAT WASHER	24	
005	0503010025	3/8" SPRING WASHER	12	
006	0503010026	3/8" NUT	12	
007	0521063868	SIDE PLATFORM	01	
008	0521063869	RIGHT PLATFORM	01	
009	0521063870	PLATFORM CENTER	01	
010	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	06	
011	0503011336	1/2" HEX SELF ADJUSTING NUT	06	
012	0503011333	COVER FIXER	03	
013	0503010274	5/32"X 2" COTTERPIN	03	
014	0551019115	LOCKING PLATFORM FIXATION	03	
015	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	
016	0501010096	3/8" X 2" BOLT	02	
017	0571019831	X 0.2" SLEEVE	02	
018	0501010984	FLAT WASHER	03	
019	0503013357	3/8" SELF-ADJUSTING NUT	03	
020	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
021	0502012739	PLATFORM LEFT FIXER SUPPORT	02	
022	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	06	
023	0503010019	1/2" SPRING WASHER	06	
024	0503010060	1/2" NUT	06	
025	0571017990	PLATFORM ENHANCEMENT PROTECTION	02	
026	0501010942	3/8" X 1-1/4" BOLT	04	
027	0501010984	FLAT WASHER	04	
028	0503010025	3/8" SPRING WASHER	04	
029	0503010026	3/8" NUT	04	

PLATFORM SET

0511059561




Item	Code	Description	See page	QT
001	0521061861	PLATFORM FIXER	02	
002	0511069661	PLATFORM SUPPORT PIVOT	04	
003	0503010849	3/8" X 1-1/2" BOLT	12	
004	0501010984	FLAT WASHER	24	
005	0503010025	3/8" SPRING WASHER	12	
006	0503010026	3/8" NUT	12	
007	0521067085	SIDE PLATFORM	01	
008	0521067084	RIGHT PLATAFORM	01	
009	0521067086	PLATFORM CENTER	01	
010	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	06	
011	0503011336	1/2" HEX SELF ADJUSTING NUT	06	
012	0503011333	COVER FIXER	03	
013	0503010274	5/32"X 2" COTTERPIN	03	
014	0551019115	LOCKING PLATFORM FIXATION	03	
015	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	
016	0501010096	3/8" X 2" BOLT	02	
017	0571019831	X 0.2" SLEEVE	02	
018	0501010984	FLAT WASHER	03	
019	0503013357	3/8" SELF-ADJUSTING NUT	03	
020	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
021	0502012739	PLATFORM LEFT FIXER SUPPORT	02	
022	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	02	
023	0503010019	1/2" SPRING WASHER	02	
024	0503010060	1/2" NUT	02	
025	0571017990	PLATFORM ENHANCEMENT PROTECTION	02	
026	0501010942	3/8" X 1-1/4" BOLT	04	
027	0501010984	FLAT WASHER	04	
028	0503010025	3/8" SPRING WASHER	04	
029	0503010026	3/8" NUT	04	




Item	Code	Description	See page	QT
01	0521061861	PLATFORM FIXER	02	
02	0511069661	PLATFORM SUPPORT PIVOT	04	
03	0503010849	3/8" X 1-1/2" BOLT	12	
04	0501010984	FLAT WASHER	24	
05	0503010025	3/8" SPRING WASHER	12	
06	0503010026	3/8" NUT	12	
07	0521066487	SIDE PLATFORM	01	
08	0521066486	RIGHT PLATAFORM	01	
09	0521063870	PLATFORM CENTER	01	
10	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	06	
11	0503011336	1/2" HEX SELF ADJUSTING NUT	06	
12	0503011333	COVER FIXER	03	
13	0503010274	5/32"X 2" COTTERPIN	03	
14	0551019115	LOCKING PLATFORM FIXATION	03	
15	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	
16	0501010096	3/8" X 2" BOLT	02	
17	0571019831	X 0.2" SLEEVE	02	
18	0501010984	FLAT WASHER	03	
19	0503013357	3/8" SELF-ADJUSTING NUT	03	
20	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
21	0502012739	PLATFORM LEFT FIXER SUPPORT	02	
22	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	02	
23	0503010019	1/2" SPRING WASHER	02	
24	0503010060	1/2" NUT	02	
25	0571017990	PLATFORM ENHANCEMENT PROTECTION	02	
26	0501010942	3/8" X 1-1/4" BOLT	04	
27	0501010984	FLAT WASHER	04	
28	0503010025	3/8" SPRING WASHER	04	
29	0503010026	3/8" NUT	04	

PLATFORM ASSY

0521050076




Item	Code	Description	See page	QT
001	0521061861	PLATFORM FIXER	02	
002	0511069661	PLATFORM SUPPORT PIVOT	04	
003	0503010849	3/8" X 1-1/2" BOLT	12	
004	0501010984	FLAT WASHER	24	
005	0503010025	3/8" SPRING WASHER	12	
006	0503010026	3/8" NUT	12	
007	0521067401	SIDE PLATFORM	01	
008	0521067400	RIGHT PLATAFORM	01	
009	0521067405	PLATFORM CENTER	01	
010	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	06	
011	0503011336	1/2" HEX SELF ADJUSTING NUT	06	
012	0503011333	COVER FIXER	03	
013	0503010274	5/32"X 2" COTTERPIN	03	
014	0551019115	LOCKING PLATFORM FIXATION	03	
015	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	
016	0501010096	3/8" X 2" BOLT	02	
017	0571019831	X 0.2" SLEEVE	02	
018	0501010984	FLAT WASHER	03	
019	0503013357	3/8" SELF-ADJUSTING NUT	03	
020	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
021	0502012739	PLATFORM LEFT FIXER SUPPORT	02	
022	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	02	
023	0503010019	1/2" SPRING WASHER	02	
024	0503010060	1/2" NUT	02	
025	0571017990	PLATFORM ENHANCEMENT PROTECTION	02	
026	0501010942	3/8" X 1-1/4" BOLT	04	
027	0501010984	FLAT WASHER	04	
028	0503010025	3/8" SPRING WASHER	04	
029	0503010026	3/8" NUT	04	



Item	Code	Description	See page	QT
01	0521050219	RIGHT FERTILIZER SILO SUPPORT 7350	35	01
02	0521050218	CENTER FERTILIZER SILO SUPPORT 7350	39	01
03	0521050220	LEFT FERTILIZER BEAM SUPPORT 7350	31	01
04	0503034396	FERTILIZER SIDE COVER		15
05	0503010362	1/8" X 1.1/4" COTTERPIN		15
06	0503010849	3/8" X 1-1/2" BOLT		16
07	0501010984	FLAT WASHER		32
08	0503010025	3/8" SPRING WASHER		16
09	0503010026	3/8" NUT		16
10	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		01
11	0503062391	SILO FERTILIZER 05 MOUTHS		02
12	0571019051	FIXER BOX WASHER		26
13	0503013751	3/8 UNC X 1.1/4 BOLT		26
14	0503012535	3/8" SPRING WASHER		26
15	0503012531	3/8" INOX NUT		26
16	0503011957	NYLON LUG		02
17	0503010371	5/16" X 1" BOLT		04
18	0503010179	5/16" ZN SPRING WASHER		04
19	0503010337	5/16" NUT		04
20	0503062476	CARDAN TERMINAL		02
21	0503011855	0.2" X 1.8" SPRING PIN		04
22	0503030331	1.2" X 1.2" X 12.2" HOSE		02
23	0503010243	CLAMP		04
24	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	45	02
25	0521050195	SILO FERTILIZER LEFT SQUARE AXLE	46	02

SET FERTILIZER SILO


0511057811




Item	Code	Description	See page	QT
001	0511057813	RIGHT FERTILIZER BOX SUPPORT 7655	36	01
002	0511057812	LEFT FERTILIZER BOX SUPPORT 7655	32	01
003	0511057814	CENTER FERTILIZER SILO SUPPORT	40	01
004	0571010590	FERTILIZER SIDE COVER		15
005	0503010362	1/8" X 1.1/4" COTTERPIN		15
006	0503010849	3/8" X 1-1/2" BOLT		12
007	0501010984	FLAT WASHER		24
008	0503010025	3/8" SPRING WASHER		12
009	0503010026	3/8" NUT		12
010	0503062391	SILO FERTILIZER 05 MOUTHS		03
011	0571019051	FIXER BOX WASHER		24
012	0503013751	3/8 UNC X 1.1/4 BOLT		24
013	0503012535	3/8" SPRING WASHER		24
014	0503012531	3/8" INOX NUT		24
015	0503011957	NYLON LUG		02
016	0503010371	5/16" X 1" BOLT		04
017	0503010179	5/16" ZN SPRING WASHER		04
018	0503010337	5/16" NUT		04
019	0503011855	0.2" X 1.8" SPRING PIN		04
020	0503030331	1.2" X 1.2" X 12.2" HOSE		02
021	0503010243	CLAMP		04
022	0503062208	CARDAN TERMINAL		02

SET FERTILIZER SILO

0521050903




Item	Code	Description	See page	QT
001	0521050890	FERTILIZER BEAM SUPPORT	37	01
002	0521050891	FERTILIZER BEAM SUPPORT	33	01
003	0521050218	CENTER FERTILIZER SILO SUPPORT 7350	39	01
004	0503034396	FERTILIZER SIDE COVER		14
005	0503010362	1/8" X 1.1/4" COTTERPIN		14
006	0503010849	3/8" X 1-1/2" BOLT		16
007	0501010984	FLAT WASHER		32
008	0503010025	3/8" SPRING WASHER		16
009	0503010026	3/8" NUT		16
010	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		01
011	0503062362	SILO FERTILIZER 04 MOUTH		02
012	0571019051	FIXER BOX WASHER		22
013	0503013751	3/8 UNC X 1.1/4 BOLT		22
014	0503012535	3/8" SPRING WASHER		22
015	0503012531	3/8" INOX NUT		22
016	0503011957	NYLON LUG		02
017	0503010371	5/16" X 1" BOLT		04
018	0503010179	5/16" ZN SPRING WASHER		04
019	0503010337	5/16" NUT		04
020	0503062476	CARDAN TERMINAL		02
021	0503011855	0.2" X 1.8" SPRING PIN		04
022	0503030331	1.2" X 1.2" X 12.2" HOSE		02
023	0503010243	CLAMP		04
024	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	45	01
025	0521050195	SILO FERTILIZER LEFT SQUARE AXLE	46	01



Item	Code	Description	See page	QT
01	0511058131	RIGHT FERTILIZER BOX SUPPORT 5750	38	01
02	0511058132	CENTRAL FERTILIZER BOX SUPPORT 5750	41	01
03	0511058130	LEFT FERTILIZER BOX SUPPORT 5750	34	01
04	0503034396	FERTILIZER SIDE COVER		13
05	0503010362	1/8" X 1.1/4" COTTERPIN		13
06	0503010849	3/8" X 1-1/2" BOLT		16
07	0501010984	FLAT WASHER		32
08	0503010025	3/8" SPRING WASHER		16
09	0503010026	3/8" NUT		16
10	0503062391	SILO FERTILIZER 05 MOUTHS		01
11	0503062362	SILO FERTILIZER 04 MOUTH		02
12	0571019051	FIXER BOX WASHER		20
13	0503013751	3/8 UNC X 1.1/4 BOLT		20
14	0503012535	3/8" SPRING WASHER		20
15	0503012531	3/8" INOX NUT		20
16	0503011957	NYLON LUG		02
17	0503010371	5/16" X 1" BOLT		04
18	0503010179	5/16" ZN SPRING WASHER		04
19	0503010337	5/16" NUT		04
20	0503062476	CARDAN TERMINAL		02
21	0503011855	0.2" X 1.8" SPRING PIN		04
22	0503030331	1.2" X 1.2" X 12.2" HOSE		02
23	0503010243	CLAMP		04

SET FERTILIZER SILO


0521050077




Item	Code	Description	See page	QT
001	0521050069	LFT FERTILIZER BEAM SUPPORT	42	01
002	0521050070	FERTILIZER BEAM SUPPORT	43	01
003	0521050071	CENTER FERTILIZER SILO SUPPORT 7655	44	01
004	0503034396	FERTILIZER SIDE COVER		17
005	0503010362	1/8" X 1.1/4" COTTERPIN		17
006	0503010849	3/8" X 1-1/2" BOLT		16
007	0501010984	FLAT WASHER		32
008	0503010025	3/8" SPRING WASHER		16
009	0503010026	3/8" NUT		16
010	0503062362	SILO FERTILIZER 04 MOUTH		02
011	0571019051	FIXER BOX WASHER		32
012	0503013751	3/8 UNC X 1.1/4 BOLT		32
013	0503012535	3/8" SPRING WASHER		32
014	0503012531	3/8" INOX NUT		32
015	0503011957	NYLON LUG		02
016	0503010371	5/16" X 1" BOLT		04
017	0503010179	5/16" ZN SPRING WASHER		04
018	0503010337	5/16" NUT		04
019	0503062562	CARDAN TERMINAL		02
020	0503011855	0.2" X 1.8" SPRING PIN		04
021	0503030331	1.2" X 1.2" X 12.2" HOSE		02
022	0503010243	CLAMP		04
023	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		02

LEFT FERTILIZER BEAM SUPPORT 7350

0521050220




Item	Code	Description	See page	QT
01	0521067456	LH FERTILIZER BOX SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2		04
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2		01
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0501056271	BEARING CLOSED	84	01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	5/16" ZN SPRING WASHER		02
11	0503010337	5/16" NUT		02
12	0581013342	SQUARE SHAFT		01
13	0571019828	LOCK AXLE		01
14	0503010365	NUT		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521014167	CONE LOCK		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	Q3/4" FASTENER AXLE ASSY		01
20	0503030275	AGRICULTURAL BEARING		05
21	1902010685	18Z CONICAL GEAR		05




Item	Code	Description	See page	QT
01	0521066297	FERTILIZER SUPPORT LEFT BEAM		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2		03
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2		02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0501056271	BEARING CLOSED	84	01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	5/16" ZN SPRING WASHER		02
11	0503010337	5/16" NUT		02
12	0571019827	SQUARE SHAFT		01
13	0571019828	LOCK AXLE		01
14	0503010365	NUT		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521014167	CONE LOCK		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	Q3/4" FASTENER AXLE ASSY		01
20	0503030275	AGRICULTURAL BEARING		05
21	1902010685	18Z CONICAL GEAR		05

FERTILIZER BEAM SUPPORT


0521050891




Item	Code	Description	See page	QT
001	0521067081	LH FERTILIZER BOX SUPPORT		01
002	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2		02
003	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2		02
004	0501010942	3/8" X 1-1/4" BOLT		16
005	0503011443	3/8" SPRING WASHER		16
006	0503010026	3/8" NUT		16
007	0501056271	BEARING CLOSED	84	01
008	0521011039	FLAT WASHER		02
009	0503011953	5/16" X 1" BOLT		02
010	0503011444	SPRING WASHER		02
011	0503010337	5/16" NUT		02
012	0581014216	SQUARE SHAFT		01
013	1902010685	18Z CONICAL GEAR		04
014	0503030275	AGRICULTURAL BEARING		04
015	0571019828	LOCK AXLE		01
016	0503010365	NUT		02
017	0503013816	5/16" LOCKNUT		02
018	0511061759	22Z P12,70 FQ 3/4" GEAR		01
019	0521014167	CONE LOCK		03
020	0503030303	SUPPORT WASHER		01
021	0511059491	AXLE HOLDER		01
021A	0521010691	AXLE FASTENER		01
021B	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
021C	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
021D	0503011441	SPRING WASHER		01
021E	0503010144	1/4" NUT		01
22	0571010590	FERTILIZER SIDE COVER		05
23	0503010362	1/8" X 1.1/4" COTTERPIN		05



Item	Code	Description	See page	QT
01	0521066471	FERTILIZER SUPPORT LEFT BEAM		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2		01
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2		03
04	0501010942	3/8" X 1-1/4" BOLT		18
05	0503010025	3/8" SPRING WASHER		18
06	0503010026	3/8" NUT		18
07	0501056271	BEARING CLOSED	84	01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	5/16" ZN SPRING WASHER		02
11	0503010337	5/16" NUT		02
12	0581010469	SQUARE SHAFT		01
13	0571019828	LOCK AXLE		01
14	0503010365	NUT		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521014167	CONE LOCK		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	Q3/4" FASTENER AXLE ASSY		01
20	0503030275	AGRICULTURAL BEARING		04
21	1902010685	18Z CONICAL GEAR		04




Item	Code	Description	See page	QT
01	0521067455	FERTILIZER BEAN RIGHT SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2		01
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2		04
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0501056271	BEARING CLOSED	84	01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	5/16" ZN SPRING WASHER		02
11	0503010337	5/16" NUT		02
12	0581013342	SQUARE SHAFT		01
13	0571019828	LOCK AXLE		01
14	0503010365	NUT		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521014167	CONE LOCK		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	Q3/4" FASTENER AXLE ASSY		01
20	0503030275	AGRICULTURAL BEARING		05
21	1902010685	18Z CONICAL GEAR		05




Item	Code	Description	See page	QT
01	0521066295	FERTILIZER BEAM RIGHT SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2		02
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2		03
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0501056271	BEARING CLOSED	84	01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	5/16" ZN SPRING WASHER		02
11	0503010337	5/16" NUT		02
12	0571019827	SQUARE SHAFT		01
13	0571019828	LOCK AXLE		01
14	0503010365	NUT		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521014167	CONE LOCK		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	Q3/4" FASTENER AXLE ASSY		01
20	0503030275	AGRICULTURAL BEARING		05
21	1902010685	18Z CONICAL GEAR		05

FERTILIZER BEAM SUPPORT


0521050890




Item	Code	Description	See page	QT
001	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2		02
002	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2		02
003	0501010942	3/8" X 1-1/4" BOLT		16
004	0503011443	3/8" SPRING WASHER		16
005	0503010026	3/8" NUT		16
006	0501056271	BEARING CLOSED	84	01
007	0521011039	FLAT WASHER		02
008	0503011953	5/16" X 1" BOLT		02
009	0503011444	SPRING WASHER		02
010	0503010337	5/16" NUT		02
011	0581014216	SQUARE SHAFT		01
012	1902010685	18Z CONICAL GEAR		04
013	0503030275	AGRICULTURAL BEARING		04
014	0571019828	LOCK AXLE		01
015	0503010365	NUT		02
016	0503013816	5/16" LOCKNUT		02
017	0511061759	22Z P12,70 FQ 3/4" GEAR		01
018	0521014167	CONE LOCK		03
019	0503030303	SUPPORT WASHER		01
020	0511059491	AXLE HOLDER		01
020A	0521010691	AXLE FASTENER		01
020B	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
020C	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
020D	0503011441	SPRING WASHER		01
020E	0503010144	1/4" NUT		01
021	0521067079	FERTILIZER BEAN RIGHT SUPPORT		01
022	0571010590	FERTILIZER SIDE COVER		05
023	0503010362	1/8" X 1.1/4" COTTERPIN		05




Item	Code	Description	See page	QT
01	0521066472	FERTILIZER BEAN RIGHT SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2		01
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2		03
04	0501010942	3/8" X 1-1/4" BOLT		16
05	0503010025	3/8" SPRING WASHER		16
06	0503010026	3/8" NUT		16
07	0501056271	BEARING CLOSED	84	01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	5/16" ZN SPRING WASHER		02
11	0503010337	5/16" NUT		02
12	0581010469	SQUARE SHAFT		01
13	0571019828	LOCK AXLE		01
14	0503010365	NUT		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521014167	CONE LOCK		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	Q3/4" FASTENER AXLE ASSY		01
20	0503030275	AGRICULTURAL BEARING		04
21	1902010685	18Z CONICAL GEAR		04




Item	Code	Description	See page	QT
01	0521067454	CENTER FERTILIZER SILO SUPPORT	01	
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	03	
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	03	
04	0501010942	3/8" X 1-1/4" BOLT	24	
05	0503011443	3/8" SPRING WASHER	24	
06	0503010026	3/8" NUT	24	
07	0571019828	LOCK AXLE	02	
08	0503010365	NUT	04	
09	0503013816	5/16" LOCKNUT	04	
10	0581010471	SQUARE SHAFT	01	
11	1902010685	18Z CONICAL GEAR	06	
12	0503030275	AGRICULTURAL BEARING	06	



Item	Code	Description	See page	QT
001	0521066296	SEED SILO CENTRAL SUPPORT		01
002	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2		02
003	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2		03
004	0501010942	3/8" X 1-1/4" BOLT		20
005	0503011443	3/8" SPRING WASHER		20
006	0503010026	3/8" NUT		20
007	0571019828	LOCK AXLE		02
008	0503010365	NUT		04
009	0503013816	5/16" LOCKNUT		04
010	0571019826	SQUARE SHAFT		01
011	0571019825	SQUARE SHAFT		01
012	1902010685	18Z CONICAL GEAR		01
013	0503030275	AGRICULTURAL BEARING		01




Item	Code	Description	See page	QT
01	0521066296	SEED SILO CENTRAL SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2		03
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2		02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0571019828	LOCK AXLE		02
08	0503010365	NUT		04
09	0503013816	5/16" LOCKNUT		04
10	0581010471	SQUARE SHAFT		01
11	0581010470	SQUARE SHAFT		01
12	1902010685	18Z CONICAL GEAR		05
13	0503030275	AGRICULTURAL BEARING		05




Item	Code	Description	See page	QT
001	0521067402	LH FERTILIZER BOX SUPPORT		01
002	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2		03
003	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2		02
004	0501010942	3/8" X 1-1/4" BOLT		20
005	0503011443	3/8" SPRING WASHER		24
006	0503010026	3/8" NUT		24
007	0501056271	BEARING CLOSED	84	01
008	0521011039	FLAT WASHER		02
009	0503011953	5/16" X 1" BOLT		02
010	0503011444	SPRING WASHER		02
011	0503010337	5/16" NUT		02
012	0581013169	SQUARE SHAFT		01
013	1902010685	18Z CONICAL GEAR		05
014	0503030275	AGRICULTURAL BEARING		05
015	0571019828	LOCK AXLE		01
016	0503010365	NUT		02
017	0503013816	5/16" LOCKNUT		02
018	0511061759	22Z P12,70 FQ 3/4" GEAR		01
019	0521014167	CONE LOCK		03
020	0503030303	SUPPORT WASHER		01
021	0511059491	AXLE HOLDER		01
021A	0521010691	AXLE FASTENER		01
021B	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
021C	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
021D	0503011441	SPRING WASHER		01
021E	0503010144	1/4" NUT		01
022	0511062163	FERTILIZER BEAM LOWER COVER		01
023	0501011643	3/8 X 1"BOLT		04

FERTILIZER BEAM SUPPORT


0521050070




Item	Code	Description	See page	QT
001	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2		02
002	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2		03
003	0501010942	3/8" X 1-1/4" BOLT		20
004	0503011443	3/8" SPRING WASHER		24
005	0503010026	3/8" NUT		24
006	0501056271	BEARING CLOSED	84	01
007	0521011039	FLAT WASHER		02
008	0503011953	5/16" X 1" BOLT		02
009	0503011444	SPRING WASHER		02
010	0503010337	5/16" NUT		02
011	0581013169	SQUARE SHAFT		01
012	1902010685	18Z CONICAL GEAR		05
013	0503030275	AGRICULTURAL BEARING		05
014	0571019828	LOCK AXLE		01
015	0503010365	NUT		02
016	0503013816	5/16" LOCKNUT		02
017	0511061759	22Z P12,70 FQ 3/4" GEAR		01
018	0521014167	CONE LOCK		03
019	0503030303	SUPPORT WASHER		01
020	0511059491	AXLE HOLDER		01
020A	0521010691	AXLE FASTENER		01
020B	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
020C	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
020D	0503011441	SPRING WASHER		01
020E	0503010144	1/4" NUT		01
021	0521067403	RIGHT SUPPORT SILO FERTILIZER 8450		01
022	0571010590	FERTILIZER SIDE COVER		05
023	0503010362	1/8" X 1.1/4" COTTERPIN		05




Item	Code	Description	See page	QT
01	0521067404	CENTER FERTILIZER SILO SUPPORT	01	
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	03	
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	04	
04	0501010942	3/8" X 1-1/4" BOLT	28	
05	0503011443	3/8" SPRING WASHER	32	
06	0503010026	3/8" NUT	32	
07	0571019828	LOCK AXLE	02	
08	0503010365	NUT	04	
09	0503013816	5/16" LOCKNUT	04	
10	0581010470	SQUARE SHAFT	01	
11	0581013175	SQUARE SHAFT	01	
12	1902010685	18Z CONICAL GEAR	07	
13	0503030275	AGRICULTURAL BEARING	07	
14	0511062163	FERTILIZER BEAM LOWER COVER	01	
15	0501011643	3/8 X 1"BOLT	04	
16	0501010984	FLAT WASHER	04	




Item	Code	Description	See page	QT
01	0581013322	BEARING RIGHT SUPPORT		01
02	0503011953	5/16" X 1" BOLT		04
03	0501010984	FLAT WASHER		02
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
05	0503013816	5/16" LOCKNUT		04
06	0501056444	BEARING WITH ROLLING		01




Item	Code	Description	See page	QT
01	0581013324	BEARING LEFT SUPPORT		01
02	0503011953	5/16" X 1" BOLT		04
03	0501010984	FLAT WASHER		02
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
05	0503013816	5/16" LOCKNUT		04
06	0501056444	BEARING WITH ROLLING		01




Item	Code	Description	See page	QT
01	0521067449	FRONT SIDE CORRIMAO		02
02	0521064018	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2" NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
07	0503011082	C1/2" X 1.3/4" SCREW		04
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8" SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
001	0521063871	SIDE HANDRAIL	02	
002	0521063875	CENTRAL HANDRAIL	01	
003	0503010395	1/2" X 1-1/4" BOLT	04	
004	0503011082	C1/2" X 1.3/4" SCREW	04	
005	0503010019	1/2" SPRING WASHER	08	
006	0503010060	1/2" NUT	08	
007	0503034094	22 TWISTED CHAIN	04	
008	0571017991	CHAIN FIXER HANDRAIL	08	
009	0551019884	45 X 50 X 3/8 FASTENER	08	
010	0503013357	3/8" SELF-ADJUSTING NUT	16	




Item	Code	Description	See page	QT
001	0521067082	SIDE HANDRAIL	02	
002	0521064018	CENTRAL HANDRAIL	01	
003	0503010395	1/2" X 1-1/4" BOLT	04	
004	0503011082	C1/2" X 1.3/4" SCREW	04	
005	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	04	
006	0503010019	1/2" SPRING WASHER	12	
007	0503010060	1/2" NUT	12	
008	0503034094	22 TWISTED CHAIN	04	
009	0571017991	CHAIN FIXER HANDRAIL	08	
010	0551019884	45 X 50 X 3/8 FASTENER	08	
011	0503013357	3/8" SELF-ADJUSTING NUT	16	



Item	Code	Description	See page	QT
01	0521066485	FRONT SIDE CORRÍMAO		02
02	0521063875	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2" NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
07	0503011082	C1/2" X 1.3/4" SCREW		04
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8" SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
001	0521067398	RIGHT SIDE CORRIMAO	02	
002	0521067399	CENTRAL HANDRAIL	01	
003	0503010395	1/2" X 1-1/4" BOLT	04	
004	0503011082	C1/2" X 1.3/4" SCREW	04	
005	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	04	
006	0503010019	1/2" SPRING WASHER	12	
007	0503010060	1/2" NUT	12	
008	0503034094	22 TWISTED CHAIN	04	
009	0571017991	CHAIN FIXER HANDRAIL	08	
010	0551019884	45 X 50 X 3/8 FASTENER	08	
011	0503013357	3/8" SELF-ADJUSTING NUT	16	



Item	Code	Description	See page	QT
001	0511065449	ROW MARKER ARM SUPPORT		02
002	0501010098	3/4" UNC BOLT		08
003	0503011255	3/4" LOCK NUT		08
004	0511061811	ROW MARKER ARM		02
005	0503011067	5/8" X 2-1/2" BOLT		04
006	0521010479	SLEEVE ARTICULATION		04
007	0501012140	FLAT WASHER		04
008	0503012795	5/8" HEX SELF ADJUSTING NUT		04
009	0511058449	HYDRAULIC CYLINDER	55	02
010	0503010571	1/4" X 1.1/2 COTTERPIN		02
011	0511015779	1" X 4.2" AXLE		02
012	0503010523	1/4" X 2" COTTERPIN		02
013	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
014	0501068994	0.3" X 3.1" LOCK PIN		02
015	0503030168	HAIR PIN		02
016	0501066949	1235 TURNBUCKLE		02
017	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
018	0501054649	SEQUENTIAL VALVE ASSY	73	01
019	0541012165	3/4" NIPPLE		04
020	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		04
021	0521050694	HOSE ASSY		01
021A	0501080635	3/8" X 19" TR-TR HOSE		02
021B	0501080413	3/8" X 27" TR-TC HOSE		02
021C	0501080150	HOSE ASSY		04
021D	0501080460	3/8" X 23" TR-TR HOSE		04
021E	0501080675	HOSE 3/8 X 1000 TC-TC 180G		04
021F	0501082121	3/8 X 4450 TR-TM HOSE		02
022	0581010090	SPRING PROTECTION PLASTIC HOSE		02
023	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	72	02
024	0502012702	BODY SUPPORT CLAMP		02
025	0503010677	7/16" X 2-3/4" BOLT		02

Item	Code	Description	See page	QT
026	0503010180	7/16" SPRING WASHER		02
027	0503010244	7/16" NUT		02
028	0503011070	BEATER		02
029	0503010019	1/2" SPRING WASHER		02
030	0503011082	C1/2" X 1.3/4" SCREW		02
031	0503010256	3/8" X 3/4" BOLT		02
032	0501010984	FLAT WASHER		02
033	0503010025	3/8" SPRING WASHER		02
034	0501050633	MARKER DISC ASSY LINE	56	02
035	0521010575	C0.9" X 3.3" COUPLING SHAFT		02




Item	Code	Description	See page	QT
01	0511065449	ROW MARKER ARM SUPPORT		02
02	0501010098	3/4" UNC BOLT		08
03	0503011255	3/4" LOCK NUT		08
04	0511061811	ROW MARKER ARM		02
05	0503011067	5/8" X 2-1/2" BOLT		04
06	0521010479	SLEEVE ARTICULATION		04
07	0501012140	FLAT WASHER		04
08	0503012795	5/8" HEX SELF ADJUSTING NUT		04
09	0511058449	HYDRAULIC CYLINDER	55	02
10	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
11	0503010523	1/4" X 2" COTTERPIN		02
12	0511015779	1" X 4.2" AXLE		02
13	0503010571	1/4" X 1.1/2 COTTERPIN		02
14	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
15	0501068994	0.3" X 3.1" LOCK PIN		02
16	0503030168	HAIR PIN		02
17	0501066949	1235 TURNBUCKLE		02
18	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
19	0501054649	SEQUENTIAL VALVE ASSY	73	01
20	0541012165	3/4" NIPPLE		04
21	0511018387	3/4" X 0.3 ADJUSTMENT VALVE NUT		04
22	0581010090	SPRING PROTECTION PLASTIC HOSE		02
23	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	72	02
24	0502012702	BODY SUPPORT CLAMP		02
25	0503010677	7/16" X 2-3/4" BOLT		02
26	0511017302	FLAT WASHER		04
27	0503010180	7/16" SPRING WASHER		02
28	0503010244	7/16" NUT		02
29	0503011070	BEATER		02
30	0503011082	C1/2" X 1.3/4" SCREW		02
31	0503010019	1/2" SPRING WASHER		02

Item	Code	Description	See page	QT
32	0521050766	SET HOSE KIT		01
32A	0501080635	3/8" X 19" TR-TR HOSE		02
32B	0501080413	3/8" X 27" TR-TC HOSE		02
32C	0501080150	HOSE ASSY		04
32D	0501080460	3/8" X 23" TR-TR HOSE		04
32E	0501080301	HOSE 3/8 X 1300 TC-TC		04
33	0521052307	HOSE 3/8 X 4450 TC-TM PURPLE / BLUE		01
33A	0501082121	3/8 X 4450 TR-TM HOSE		01
33B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
33C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
33D	0503018952	PLASTIC BOLT		06
34	0521052306	HOSE 3/8 X 4450 TC-TM PURPLE / RED		01
34A	0501082121	3/8 X 4450 TR-TM HOSE		01
34B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
34C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
34D	0503018952	PLASTIC BOLT		06

ROW MARKER


0909090391




Item	Code	Description	See page	QT
01	0511061022	ROW MARKER SUPPORT		02
02	0511066119	MARKER SUPP FIXER FASTENER		04
03	0502010175	HITCH CLAMP		08
04	0501010216	3/4" X 4-1/2" BOLT		16
05	0503010023	3/4" SPRING WASHER		16
06	0503010014	3/4" NUT		16
07	0511060013	ROW MARKER ARM		02
08	0521013347	1.1/4" X 8.4" AXLE		02
09	0501019435	32 X 50 X 1.5 FLAT WASHER		16
10	0503010523	1/4" X 2" COTTERPIN		16
11	0511060014	ROW MARKER ARM		02
12	0511058431	HYDRAULIC CYLINDER	74	02
13	0521011142	1.1/4" X 7.5" AXLE		04
14	0521011141	1.1/4" X 6.5" AXLE		02
15	0511060010	1400 TURNBUCKLE		02
16	0521012324	1/2" X 3.2"X 2.54" FASTENER		04
17	0511017302	FLAT WASHER		08
18	0503010019	1/2" SPRING WASHER		08
19	0503010060	1/2" NUT		08
20	0511015573	2.07" X 1.6" TRANSPORT LOCK		02
21	0501068994	0.3" X 3.1"LOCK PIN		02
22	0503030168	HAIR PIN		02
23	0501050633	MARKER DISC ASSY LINE	56	02
24	0503010002	1800 GREASE FITTING		04
25	0503010004	1890 GREASE FITTING		02
26	0501010617	3/4" NIPPLE		04
27	0503010190	2-114 N 3006-9B O'RING		04

HYDRAULIC CYLINDER

0511058449




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02




Item	Code	Description	See page	QT
01	0511053904	DISC LINE MARKER	57	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01

DISC LINE MARKER

0511053904




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0521050584	ASSY VALVE	63	01
02	0521050231	OIL 7350 CONDUCTOR ASSY	66	01
03	0511053368	HYDRAULIC CYLINDER ASSEMBLY	68	01
04	0581010324	HOSE PROTECTOR		01
05	0503010358	5/16" X 5/8" BOLT		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0503010025	3/8" SPRING WASHER		02
09	0521050570	HYDRAULIC HOSE RIGHT PROTECTION	70	02
10	0521050572	PROTECTION LEFT HYDRAULIC HOSE	71	02
11	0581010729	SPRING PROTECTION PLASTIC HOSE 3/4" X 3800MM		01
12	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	72	02
13	0581013560	VALV. SUPPORT		01
14	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
15	0501010984	FLAT WASHER		02
16	0521050695	HOSE KIT SYSTEM HYDRAULIC	69	01
16A	0501080760	3/8" X 500 TC-TC HOSE		08
16B	0501080599	3/8 X 650 TC-TR HOSE		02
16C	0501080328	3/8" X 29" TR-TC HOSE		02
16D	0501080105	TR-TR HOSE ASSY		04
16E	0501080150	HOSE ASSY		01
16F	0501080055	3/8" X 1000 TR-TC HOSE		03
17	0521052302	HOSE 1/2 X 4700 TC-TM BLACK / RED		01
17A	0501082119	1/2" X 185" TR-TM HOSE ASSY		01
17B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
17C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
17D	0503018952	PLASTIC BOLT		06
18	0521052301	HOSE 1/2 X 4600 TC-TM BLACK / BLUE		01
18A	0501082120	1/2" X 177" TR-TM HOSE ASSY		01
18B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
18C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01




Item	Code	Description	See page	QT
18D	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
001	0521050584	ASSY VALVE	63	01
002	0511057843	OIL CONDUCTOR ASSY	64	01
003	0511053368	HYDRAULIC CYLINDER ASSEMBLY	68	01
004	0581010324	HOSE PROTECTOR		01
005	0503010358	5/16" X 5/8" BOLT		04
006	0503010179	5/16" ZN SPRING WASHER		04
007	0503010337	5/16" NUT		04
008	0521050695	HOSE KIT SYSTEM HYDRAULIC	69	01
009	0521050570	HYDRAULIC HOSE RIGHT PROTECTION	70	02
010	0521050572	PROTECTION LEFT HYDRAULIC HOSE	71	02
011	0581010091	SPRING PROTECTION PLASTIC HOSE		01
012	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	72	02
013	0581010090	SPRING PROTECTION PLASTIC HOSE		02
014	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		01
015	0581013560	VALV. SUPPORT		01
016	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
017	0501010984	FLAT WASHER		02
018	0503010025	3/8" SPRING WASHER		02




Item	Code	Description	See page	QT
001	0521050584	ASSY VALVE	63	01
002	0511059567	OIL CONDUCTOR ASSY	67	01
003	0511053368	HYDRAULIC CYLINDER ASSEMBLY	68	01
004	0581010324	HOSE PROTECTOR		01
005	0503010358	5/16" X 5/8" BOLT		04
006	0503010179	5/16" ZN SPRING WASHER		04
007	0503010337	5/16" NUT		04
008	0521050695	HOSE KIT SYSTEM HYDRAULIC	69	01
009	0521050570	HYDRAULIC HOSE RIGHT PROTECTION	70	02
010	0521050572	PROTECTION LEFT HYDRAULIC HOSE	71	02
011	0581010091	SPRING PROTECTION PLASTIC HOSE		01
012	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	72	02
013	0581010090	SPRING PROTECTION PLASTIC HOSE		02
014	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		01
015	0581013560	VALV. SUPPORT		01
016	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
017	0501010984	FLAT WASHER		02
018	0503010025	3/8" SPRING WASHER		02



Item	Code	Description	See page	QT
01	0521050584	ASSY VALVE	63	01
02	0511058127	OIL 5750 CONDUCTOR ASSY	65	01
03	0511053368	HYDRAULIC CYLINDER ASSEMBLY	68	01
04	0581010324	HOSE PROTECTOR		01
05	0503010358	5/16" X 5/8" BOLT		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0503010025	3/8" SPRING WASHER		02
09	0521050570	HYDRAULIC HOSE RIGHT PROTECTION	70	02
10	0521050572	PROTECTION LEFT HYDRAULIC HOSE	71	02
11	0581010091	SPRING PROTECTION PLASTIC HOSE		01
12	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	72	02
13	0581010090	SPRING PROTECTION PLASTIC HOSE		02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		01
15	0581013560	VALV. SUPPORT		01
16	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
17	0501010984	FLAT WASHER		02
18	0521050695	HOSE KIT SYSTEM HYDRAULIC	69	01
18A	0501080760	3/8" X 500 TC-TC HOSE		08
18B	0501080599	3/8 X 650 TC-TR HOSE		02
18C	0501080328	3/8" X 29" TR-TC HOSE		02
18D	0501080105	TR-TR HOSE ASSY		04
18E	0501080150	HOSE ASSY		01
18F	0501080055	3/8" X 1000 TR-TC HOSE		03
19	0521052302	HOSE 1/2 X 4700 TC-TM BLACK / RED		01
19A	0501082119	1/2" X 185" TR-TM HOSE ASSY		01
19B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
19C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
19D	0503018952	PLASTIC BOLT		06
20	0521052301	HOSE 1/2 X 4600 TC-TM BLACK / BLUE		01
20A	0501082120	1/2" X 177" TR-TM HOSE ASSY		01


Item	Code	Description	See page	QT
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
20C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
20D	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
001	0501054649	SEQUENTIAL VALVE ASSY	73	01
002	0541012165	3/4" NIPPLE		04
003	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		04
004	0511058431	HYDRAULIC CYLINDER	74	01
005	0511058431	HYDRAULIC CYLINDER	74	01
006	0503010002	1800 GREASE FITTING		04
007	0501010617	3/4" NIPPLE		04
008	0551016274	HYDRAULIC CYLINDER ADAPTER		02
009	0501068994	0.3" X 3.1" LOCK PIN		02
010	0511015573	2.07" X 1.6" TRANSPORT LOCK		02
011	0503030168	HAIR PIN		02
012	0581011173	SPRING PROTECTION PLASTIC HOSE		02
013	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	72	02
014	0502012702	BODY SUPPORT CLAMP		02
015	0503010677	7/16" X 2-3/4" BOLT		02
016	0503010180	7/16" SPRING WASHER		02
017	0503010244	7/16" NUT		02
018	0521050850	HOSE ASSY		01
018A	0501080714	HOSE 3/8 X 1600 TR-TC		04
018B	0501080150	HOSE ASSY		04
018C	0501080460	3/8" X 23" TR-TR HOSE		04
018D	0501080675	HOSE 3/8 X 1000 TC-TC 180G		04
018E	0501082121	3/8 X 4450 TR-TM HOSE		02

ASSY VALVE


0521050584




Item	Code	Description	See page	QT
01	0571010596	SUPPORT VALVE 50/50		01
02	0503010365	NUT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02
06	0503013791	DOUBLE MOTOR		01
07	0541018940	7/8 NF X R 1 BSPT X 55 NIPPLE		01
08	0551012463	1/2" BSPT X 3/4" UNF X 51 NIPPLE		02
09	0503015075	M10 SPRING WASHER		04
10	0501010984	FLAT WASHER		04
11	0503011051	M10 X 0.6" NUT		04
12	0541012166	NIPPLE 3/4" UNF X 7/8"		01
13	0503062180	T ADAPTER WITH ROTATING NUT		01
14	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01

OIL CONDUCTOR ASSY


0511057843



Item	Code	Description	See page	QT
001	0561017277	OIL CONDUCTOR FIXER PLATE	08	
002	0521010718	5/8" U BOLT	08	
003	0503010027	5/8" SPRING WASHER	16	
004	0503010013	5/8" NUT	16	
005	0502012702	BODY SUPPORT CLAMP	16	
006	0521066305	OIL CONDUCTOR	04	
007	0521066421	CONDUCTOR OIL DRUM 1072 WHEELED 6850	04	
008	0521065258	HYDRAULIC MARKER 9/450 OIL CONDUCTOR	04	
009	0521066306	OIL CONDUCTOR	04	
010	0503011268	3/8" X 2-1/2" BOLT	12	
011	0503010025	3/8" SPRING WASHER	12	
012	0503010026	3/8" NUT	12	
013	0501012140	FLAT WASHER	12	




Item	Code	Description	See page	QT
01	0561017277	OIL CONDUCTOR FIXER PLATE	06	
02	0521010718	5/8" U BOLT	06	
03	0503010027	5/8" SPRING WASHER	12	
04	0503010013	5/8" NUT	12	
05	0502012702	BODY SUPPORT CLAMP	12	
06	0521066483	OIL CONDUCTOR	04	
07	0521066484	OIL CONDUCTOR	04	
08	0521066306	OIL CONDUCTOR	04	
09	0521066305	OIL CONDUCTOR	04	
10	0503011268	3/8" X 2-1/2" BOLT	12	
11	0503010025	3/8" SPRING WASHER	12	
12	0503010026	3/8" NUT	12	
13	0501012140	FLAT WASHER	12	




Item	Code	Description	See page	QT
01	0561017277	OIL CONDUCTOR FIXER PLATE		08
02	0521010718	5/8" U BOLT		08
03	0503010027	5/8" SPRING WASHER		16
04	0503010013	5/8" NUT		16
05	0502012702	BODY SUPPORT CLAMP		16
06	0521067088	OIL CONDUCTOR		04
07	0521066484	OIL CONDUCTOR		04
08	0521067453	OIL CONDUCTOR		04
09	0521067452	OIL CONDUCTOR		04
10	0503011268	3/8" X 2-1/2" BOLT		16
11	0503010025	3/8" SPRING WASHER		16
12	0503010026	3/8" NUT		16
13	0501012140	FLAT WASHER		16

OIL CONDUCTOR ASSY


0511059567




Item	Code	Description	See page	QT
001	0561017277	OIL CONDUCTOR FIXER PLATE		08
002	0521010718	5/8" U BOLT		08
003	0503010027	5/8" SPRING WASHER		16
004	0503010013	5/8" NUT		16
005	0502012702	BODY SUPPORT CLAMP		16
006	0521066484	OIL CONDUCTOR		04
007	0521067089	OIL CONDUCTOR		04
008	0521067088	OIL CONDUCTOR		08
009	0503011268	3/8" X 2-1/2" BOLT		16
010	0503010025	3/8" SPRING WASHER		16
011	0503010026	3/8" NUT		16
012	0501012140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0511066351	FLANGE CYLINDER HYDRAULIC FIXER		12
02	0503010834	1/2 X 1 BOLT		24
03	0503010019	1/2" SPRING WASHER		24
04	0511058411	HYDRAULIC CYLINDER		06
05	0521010546	1.2" X 5.7" COUPLING SHAFT		06
06	0501017779	32 X 60 X 4.75 FLAT WASHER		12
07	0503010523	1/4" X 2" COTTERPIN		06




Item	Code	Description	See page	QT
001	0501080760	3/8" X 500 TC-TC HOSE		08
002	0501080599	3/8 X 650 TC-TR HOSE		02
003	0501080328	3/8" X 29" TR-TC HOSE		02
004	0501080105	TR-TR HOSE ASSY		04
005	0501080150	HOSE ASSY		01
006	0501080055	3/8" X 1000 TR-TC HOSE		03
007	0501082120	1/2" X 177" TR-TM HOSE ASSY		01
008	0501082119	1/2" X 185" TR-TM HOSE ASSY		01




Item	Code	Description	See page	QT
01	0581013808	RIGHT SUPPORT		01
02	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		02
03	0501012140	FLAT WASHER		02
04	0503010027	5/8" SPRING WASHER		02
05	0503010013	5/8" NUT		02
06	0581013806	SUPPORT AXLE HOSE PROTECTOR		01
07	0503010071	3/16" X 1" COTTERPIN		02
08	0581013805	0.6" X 1.2" SLEEVE		01




Item	Code	Description	See page	QT
01	0581013807	LEFT SUPPORT HOSE PROTECTION		01
02	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		02
03	0501012140	FLAT WASHER		02
04	0503010027	5/8" SPRING WASHER		02
05	0503010013	5/8" NUT		02
06	0581013806	SUPPORT AXLE HOSE PROTECTOR		01
07	0503010071	3/16" X 1" COTTERPIN		02
08	0581013805	0.6" X 1.2" SLEEVE		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01



Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02



Item	Code	Description	See page	QT
01	0501067700	2.5" X 25" CYLINDER CASE		01
02	0521066632	EXTENDER		01
03	0503030384	CON PLUG N-001		02
04	0502012837	PISTON		01
05	0503018005	RING		01
06	0503011109	2-119 N 3006-9B O'RING		01
07	0503010163	D-1500 SCRAPER RING		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503018004	RING		01
11	0503018003	GASKET		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	80	01
02	0503031805	11Z 1/2" GEAR		04
03	0503010302	501019 SEAL RING		04
04	0501048790	AXLE WITH LINK ASSY	81	02
05	0503010002	1800 GREASE FITTING		02
06	0551018209	DRIVING AXLE		01
07	0521018259	DRIVEN AXLE		01
08	0551018210	DRIVEN AXLE		01
09	0551018211	INTERM SHAFT		01
10	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	82	01
11	0503030303	SUPPORT WASHER		05
12	0501056443	BEARING ASSY GEAR BOX	83	02
13	0501056271	BEARING CLOSED	84	05
14	0503011953	5/16" X 1" BOLT		10
15	0501010694	8.5 X 18 X 1.5 FLAT WASHER		10
16	0503010179	5/16" ZN SPRING WASHER		10
17	0503010337	5/16" NUT		10
18	0511060396	DRIVE/DRIVEN AXLE CONE		04
19	0503012389	1/2 BALL		04
20	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
21	0503010060	1/2" NUT		04
22	0503010395	1/2" X 1-1/4" BOLT		04
23	0511061759	22Z P12,70 FQ 3/4" GEAR		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0511067501	26Z GEAR		01
26	0503010292	0.2" X 1.6" SPRING PIN		07
27	0503012204	40-1 CHAIN X 82 LINK + RED		02
28	0503012713	40-1 CHAIN X 45 LINK + MEN		01
29	0501054655	CHAIN TENSIONER ASSY		02
30	0501010984	FLAT WASHER		01
31	0503010025	3/8" SPRING WASHER		01


**ASSY RIGHT EXCHANGE**

0511048939

Item	Code	Description	See page	QT
32	0503010256	3/8" X 3/4" BOLT		01
33	0503030303	SUPPORT WASHER		03
34	0521018630	1.4" X SQUARE 0.8" WASHER		06
35	0511061822	25Z P0.5" GEAR SQUARE HOL		01

RIGHT GEAR BOX ASSY

0511050639



Item	Code	Description	See page	QT
01	0511050639	RIGHT GEAR BOX ASSY	76	01
01A	0501058212	SEMI MOUNTED RIGHT CHANGE	80	01
02	0503031805	11Z 1/2" GEAR		04
03	0503010302	501019 SEAL RING		04
04	0501048790	AXLE WITH LINK ASSY	81	02
05	0503010002	1800 GREASE FITTING		02
06	0551018209	DRIVING AXLE		01
07	0521018259	DRIVEN AXLE		01
08	0551018210	DRIVEN AXLE		01
09	0551018211	INTERM SHAFT		01
10	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	82	01
11	0503030303	SUPPORT WASHER		05
12	0501056443	BEARING ASSY GEAR BOX	83	02
13	0501056271	BEARING CLOSED	84	05
14	0503010256	3/8" X 3/4" BOLT		01
15	0503030275	AGRICULTURAL BEARING		01
16	0521018630	1.4" X SQUARE 0.8" WASHER		03
17	0511061822	25Z P0.5" GEAR SQUARE HOL		01
18	0502040868	GEAR CONE REPLACEMENT		04
19	0503012389	1/2 BALL		04
20	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
21	0503010060	1/2" NUT		04
22	0503010395	1/2" X 1-1/4" BOLT		04
23	0521062072	33Z GEAR		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0511067501	26Z GEAR		01
26	0503010292	0.2" X 1.6" SPRING PIN		07
27	0503012204	40-1 CHAIN X 82 LINK + RED		02
28	0503012713	40-1 CHAIN X 45 LINK + MEN		01
29	0501054655	CHAIN TENSIONER ASSY		02
30	0501010984	FLAT WASHER		01




RIGHT GEAR BOX ASSY

0511050639

Item	Code	Description	See page	QT
31	0503010025	3/8" SPRING WASHER		01

LEFT ASSY EXCHANGE

0511048940



Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	79	01
02	0503031805	11Z 1/2" GEAR		04
03	0503010302	501019 SEAL RING		04
04	0501048790	AXLE WITH LINK ASSY	81	02
05	0503010002	1800 GREASE FITTING		02
06	0551018209	DRIVING AXLE		01
07	0521018259	DRIVEN AXLE		01
08	0551018210	DRIVEN AXLE		01
09	0551018211	INTERM SHAFT		01
10	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	82	01
11	0503030303	SUPPORT WASHER		05
12	0501056443	BEARING ASSY GEAR BOX	83	02
13	0501056271	BEARING CLOSED	84	05
14	0503011953	5/16" X 1" BOLT		10
15	0501010694	8.5 X 18 X 1.5 FLAT WASHER		10
16	0503010179	5/16" ZN SPRING WASHER		10
17	0503010337	5/16" NUT		10
18	0511060396	DRIVE/DRIVEN AXLE CONE		04
19	0503012389	1/2 BALL		04
20	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
21	0503010060	1/2" NUT		04
22	0503010395	1/2" X 1-1/4" BOLT		04
23	0511061759	22Z P12,70 FQ 3/4" GEAR		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0511067501	26Z GEAR		01
26	0503010292	0.2" X 1.6" SPRING PIN		07
27	0503012204	40-1 CHAIN X 82 LINK + RED		02
28	0503012713	40-1 CHAIN X 45 LINK + MEN		01
29	0501054655	CHAIN TENSIONER ASSY		02
30	0501010984	FLAT WASHER		01
31	0503010025	3/8" SPRING WASHER		01


**LEFT ASSY EXCHANGE**

0511048940

Item	Code	Description	See page	QT
32	0503010256	3/8" X 3/4" BOLT		01
33	0503030303	SUPPORT WASHER		03
34	0521018630	1.4" X SQUARE 0.8" WASHER		06
35	0511061822	25Z P0.5" GEAR SQUARE HOL		01

LEFT GEAR BOX ASSY

0511050640




Item	Code	Description	See page	QT
01	0511050640	LEFT GEAR BOX ASSY	78	01
01A	0501058213	LH GEAR BOX	79	01
02	0503031805	11Z 1/2" GEAR		04
03	0503010302	501019 SEAL RING		04
04	0501048790	AXLE WITH LINK ASSY	81	02
05	0503010002	1800 GREASE FITTING		02
06	0551018209	DRIVING AXLE		01
07	0521018259	DRIVEN AXLE		01
08	0551018210	DRIVEN AXLE		01
09	0551018211	INTERM SHAFT		01
10	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	82	01
11	0503030303	SUPPORT WASHER		05
12	0501056443	BEARING ASSY GEAR BOX	83	02
13	0501056271	BEARING CLOSED	84	05
14	0503010256	3/8" X 3/4" BOLT		01
15	0503030275	AGRICULTURAL BEARING		01
16	0521018630	1.4" X SQUARE 0.8" WASHER		03
17	0511061822	25Z P0.5" GEAR SQUARE HOL		01
18	0502040868	GEAR CONE REPLACEMENT		04
19	0503012389	1/2 BALL		04
20	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
21	0503010060	1/2" NUT		04
22	0503010395	1/2" X 1-1/4" BOLT		04
23	0521062072	33Z GEAR		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0511067501	26Z GEAR		01
26	0503010292	0.2" X 1.6" SPRING PIN		07
27	0503012204	40-1 CHAIN X 82 LINK + RED		02
28	0503012713	40-1 CHAIN X 45 LINK + MEN		01
29	0501054655	CHAIN TENSIONER ASSY		02
30	0501010984	FLAT WASHER		01




LEFT GEAR BOX ASSY

0511050640


Item	Code	Description	See page	QT
31	0503010025	3/8" SPRING WASHER		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
05	0503010179	5/16" ZN SPRING WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING		01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0561019899	RIGHT SUPPORT FIXER RECAMBIO		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0503011082	C1/2" X 1.3/4" SCREW		02
05	0511017302	FLAT WASHER		04
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0561019898	LEFT SUPPORT FIXER RECAMBIO		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0503011082	C1/2" X 1.3/4" SCREW		02
05	0511017302	FLAT WASHER		04
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02

RESTING ASSEMBLY

0511054971




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01



Item	Code	Description	See page	QT
01	0561017269	MOTOR AXLE BEARING SUPPORT		04
02	0503011082	C1/2" X 1.3/4" SCREW		08
03	0511017302	FLAT WASHER		16
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0501110639	BEARING		08
07	0503010300	5/32" X 1" COTTERPIN		08
08	0503011099	GREASE FITTING		08
09	0581013330	MOTOR SHAFT ASSEMBLY		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 C508 G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0511047069	SIDE TRANSMISSION DRIVING	93	01
15	0511047070	LH SIDE TRANSMISSION DRIVING	94	01
16	0511051434	TRANSMISSION DRIVING ASSY	95	04
17	0501052560	AXLE MOTOR SLOW-MOVING ASSY	96	02

MOTOR SHAFT ASSEMBLY


0511057797




Item	Code	Description	See page	QT
01	0561017269	MOTOR AXLE BEARING SUPPORT		04
02	0503011082	C1/2" X 1.3/4" SCREW		08
03	0511017302	FLAT WASHER		16
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0501110639	BEARING		08
07	0503010300	5/32" X 1" COTTERPIN		08
08	0503011099	GREASE FITTING		08
09	0571014441	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0511047069	SIDE TRANSMISSION DRIVING	93	01
15	0511047070	LH SIDE TRANSMISSION DRIVING	94	01
16	0511051434	TRANSMISSION DRIVING ASSY	95	04
17	0501052560	AXLE MOTOR SLOW-MOVING ASSY	96	02

MOTOR SHAFT ASSEMBLY

0511059566




Item	Code	Description	See page	QT
001	0561017269	MOTOR AXLE BEARING SUPPORT		04
002	0503011082	C1/2" X 1.3/4" SCREW		08
003	0511017302	FLAT WASHER		16
004	0503010019	1/2" SPRING WASHER		08
005	0503010060	1/2" NUT		08
006	0501110639	BEARING		08
007	0503010300	5/32" X 1" COTTERPIN		08
008	0503011099	GREASE FITTING		08
009	0581012156	MOTOR SHAFT ASSEMBLY		02
010	0501018466	FLAT WASHER		04
011	0511015961	LOCK BUSHING		04
012	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
013	0503010060	1/2" NUT		04
014	0511047069	SIDE TRANSMISSION DRIVING	93	01
015	0511047070	LH SIDE TRANSMISSION DRIVING	94	01
016	0511051434	TRANSMISSION DRIVING ASSY	95	04
017	0501052560	AXLE MOTOR SLOW-MOVING ASSY	96	02




Item	Code	Description	See page	QT
01	0561017269	MOTOR AXLE BEARING SUPPORT		04
02	0503011082	C1/2" X 1.3/4" SCREW		08
03	0511017302	FLAT WASHER		16
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0501110639	BEARING		08
07	0503010300	5/32" X 1" COTTERPIN		08
08	0503011099	GREASE FITTING		08
09	0581010468	MOTOR SHAFT ASSEMBLY		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0511047069	SIDE TRANSMISSION DRIVING	93	01
15	0511047070	LH SIDE TRANSMISSION DRIVING	94	01
16	0511051434	TRANSMISSION DRIVING ASSY	95	04
17	0501052560	AXLE MOTOR SLOW-MOVING ASSY	96	02

MOTOR SHAFT ASSEMBLY


0521050080




Item	Code	Description	See page	QT
001	0561017269	MOTOR AXLE BEARING SUPPORT		04
002	0503011082	C1/2" X 1.3/4" SCREW		08
003	0511017302	FLAT WASHER		16
004	0503010019	1/2" SPRING WASHER		08
005	0503010060	1/2" NUT		08
006	0501110639	BEARING		08
007	0503010300	5/32" X 1" COTTERPIN		08
008	0503011099	GREASE FITTING		08
009	0581013152	MOTOR SHAFT		02
010	0501018466	FLAT WASHER		04
011	0511015961	LOCK BUSHING		04
012	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
013	0503010060	1/2" NUT		04
014	0511047069	SIDE TRANSMISSION DRIVING	93	01
015	0511047070	LH SIDE TRANSMISSION DRIVING	94	01
016	0511051434	TRANSMISSION DRIVING ASSY	95	04
017	0501052560	AXLE MOTOR SLOW-MOVING ASSY	96	02




Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02



Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	5/16" X 3/4" BOLT		02
03	0503010179	5/16" ZN SPRING WASHER		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ETIQUETA ADHESIVA		01




Item	Code	Description	See page	QT
01	0561018212	ARTICULAT SLEEVE	02	
02	0503010547	1/2" X 4" BOLT	02	
03	0511017302	FLAT WASHER	02	
04	0503010019	1/2" SPRING WASHER	02	
05	0503010060	1/2" NUT	02	
06	0561017281	ARTICULACION ARM	02	
07	0511053366	CHAIN TENSIONER EXCHANGE	02	
08	0511050385	BEARING DOUBLE GEAR	02	
09	0501058265	STRETCHER LOWER CURRENT 21Z SEED	02	
10	0511056387	INTERMEDIATE BEARING SEED WITH GEAR 21Z	02	
11	0511057852	SILO SUPPORT CHAIN DEVIATION	02	
12	0501053126	FERTILIZER CHAIN TENSIONER ASSY	02	
13	0571019829	LEVER FIXER	02	
14	0503010237	3/8" X 1" BOLT	02	
15	0503010025	3/8" SPRING WASHER	02	
16	0503010026	3/8" NUT	02	
17	0571019830	LEVER FIXER	02	
18	0503011312	ROTATIVE CABLE	02	
19	0503030093	TRACTION SPRING	02	
20	0561017273	FIXER SPRING	02	
21	0503010237	3/8" X 1" BOLT	02	
22	0503010025	3/8" SPRING WASHER	02	
23	0503010026	3/8" NUT	02	
24	0561017282	LOWER LEVER	02	
25	0561016797	SLEEVE UNION LEVER	02	
26	0503011082	C1/2" X 1.3/4" SCREW	02	
27	0511017302	FLAT WASHER	04	
28	0503010019	1/2" SPRING WASHER	02	
29	0503010060	1/2" NUT	02	
30	0521010773	0.37" X 1.18" COUPLING SHAFT	04	
31	0501010984	FLAT WASHER	02	

MECHANICAL TRANSMISSION ASSEMBLY

0511058146

Item	Code	Description	See page	QT
32	0503010140	1/8" X 3/4" COTTERPIN		04
33	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		02
34	0503012717	40-1 CHAIN X 101 LINK + MENDING		02
35	0503012719	40-1 CHAIN X 113 LINK + MENDING		02
36	0503011721	40-1 CHAIN X 122 LINK + REDUCTION		02




Item	Code	Description	See page	QT
001	0511053366	CHAIN TENSIONER EXCHANGE		02
001A	0531019479	AXLE CHAIN GEAR		01
001B	0503031805	11Z 1/2" GEAR		01
001C	0503010302	501019 SEAL RING		01
001D	0511017302	FLAT WASHER		02
001E	0503010019	1/2" SPRING WASHER		01
001F	0503010060	1/2" NUT		01
002	0511050385	BEARING DOUBLE GEAR		02
002A	0521061843	20Z DOBLE GEAR		01
002B	0503011410	ROLLER BEARING		02
002C	0551019175	DOUBLE GEAR AXLE		01
002D	0503010406	501025 CLAMPING RING (FOR AXLE)		01
002E	0501010163	5/8" X 4-1/2" BOLT		01
002F	0503012412	5/8 UNC SELF LOCKING NUT		01
003	0501058265	STRETCHER LOWER CURRENT 21Z SEED		02
003A	0511062169	21Z P 1/2" GEAR		01
003B	0503011410	ROLLER BEARING		01
003C	0503011105	SEAL RING		01
003D	0531017086	50 AXLETIGHTENER		01
003E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
003F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
003G	0501012140	FLAT WASHER		01
003H	0503010027	5/8" SPRING WASHER		01
003I	0503010013	5/8" NUT		01
004	0511056387	INTERMEDIATE BEARING SEED WITH GEAR 21Z		02
004A	0511062169	21Z P 1/2" GEAR		01
004B	0503011410	ROLLER BEARING		01
004C	0503011105	SEAL RING		01
004D	0531017086	50 AXLETIGHTENER		01
004E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
004F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01

RIGHT TRANSMISSION ASSY

0511059162

Item	Code	Description	See page	QT
004G	0503012412	5/8 UNC SELF LOCKING NUT		01
005	0501053126	FERTILIZER CHAIN TENSIONER ASSY		02
005A	0501011541	5/8" X 3" BOLT		01
005B	0511062169	21Z P 1/2" GEAR		01
005C	0503011410	ROLLER BEARING		01
005D	0503011105	SEAL RING		01
005E	0521018415	TIGHTENER AXLE		01
005F	0503010406	501025 CLAMPING RING (FOR AXLE)		01
005G	0503012412	5/8 UNC SELF LOCKING NUT		01
006	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		02
007	0503012717	40-1 CHAIN X 101 LINK + MENDING		02
008	0503015124	40-1 X 5" CHAIN LINK + MENDING		02
009	0503011721	40-1 CHAIN X 122 LINK + REDUCTION		02




Item	Code	Description	See page	5750/6850
001	0561018212	ARTICULAT SLEEVE		02
002	0503010547	1/2" X 4" BOLT		02
003	0511017302	FLAT WASHER		02
004	0503010019	1/2" SPRING WASHER		02
005	0503010060	1/2" NUT		02
006	0561017281	ARTICULACION ARM		02
007	0511053366	CHAIN TENSIONER EXCHANGE		02
007A	0531019479	AXLE CHAIN GEAR		02
007B	0503031805	11Z 1/2" GEAR		02
007C	0503010302	501019 SEAL RING		02
007D	0511017302	FLAT WASHER		04
008	0511050385	BEARING DOUBLE GEAR		02
008A	0521061843	20Z DOBLE GEAR		02
008B	0551019175	DOUBLE GEAR AXLE		02
008C	0501010163	5/8" X 4-1/2" BOLT		02
008D	0503012412	5/8 UNC SELF LOCKING NUT		06
009	0501058265	STRETCHER LOWER CURRENT 21Z SEED		02
009A	0511062169	21Z P 1/2" GEAR		01
009B	0503011410	ROLLER BEARING		01
009C	0503011105	SEAL RING		01
009D	0531017086	50 AXLETIGHTENER		01
009E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
009F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
009G	0501012140	FLAT WASHER		01
009H	0503010027	5/8" SPRING WASHER		01
009I	0503010013	5/8" NUT		01
010	0511056387	INTERMEDIATE BEARING SEED WITH GEAR 21Z		02
010A	0511062169	21Z P 1/2" GEAR		01
010B	0503011410	ROLLER BEARING		01
010C	0503011105	SEAL RING		01
010D	0531017086	50 AXLETIGHTENER		01


RIGHT TRANSMISSION ASSY

0511057815

Item	Code	Description	See page	5750/6850
010E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
010F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
010G	0503012412	5/8 UNC SELF LOCKING NUT		01
011	0511057852	SILO SUPPORT CHAIN DEVIATION		02
011A	0571019832	SLEEVE CHAIN DEVIATION		02
011B	0502012367	17Z X P 1/2" GEAR INTERM		02
011C	0503012882	BEARING		02
011D	0503011945	503050 CLAMPING RING (FOR AXLE)		02
011E	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
011F	0503010019	1/2" SPRING WASHER		02
011G	0503010060	1/2" NUT		02
012	0501053126	FERTILIZER CHAIN TENSIONER ASSY		02
012A	0501011541	5/8" X 3" BOLT		01
012B	0511062169	21Z P 1/2" GEAR		01
012C	0503011410	ROLLER BEARING		01
012D	0503011105	SEAL RING		01
012E	0521018415	TIGHTENER AXLE		01
012F	0503010406	501025 CLAMPING RING (FOR AXLE)		01
012G	0503012412	5/8 UNC SELF LOCKING NUT		01
013	0571019829	LEVER FIXER		02
014	0503010237	3/8" X 1" BOLT		02
015	0503010025	3/8" SPRING WASHER		02
016	0503010026	3/8" NUT		02
017	0571019830	LEVER FIXER		02
018	0503011312	ROTATIVE CABLE		02
019	0503030093	TRACTION SPRING		02
020	0561017273	FIXER SPRING		02
021	0503010237	3/8" X 1" BOLT		02
022	0503010025	3/8" SPRING WASHER		02
023	0503010026	3/8" NUT		02
024	0561017282	LOWER LEVER		02
025	0561016797	SLEEVE UNION LEVER		02
026	0503011082	C1/2" X 1.3/4" SCREW		02
027	0511017302	FLAT WASHER		04
028	0503010019	1/2" SPRING WASHER		02
029	0503010060	1/2" NUT		02
030	0521010773	0.37" X 1.18" COUPLING SHAFT		04
031	0501010984	FLAT WASHER		02
032	0503010140	1/8" X 3/4" COTTERPIN		04
033	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		02
034	0503012717	40-1 CHAIN X 101 LINK + MENDING		02
035	0503015124	40-1 X 5" CHAIN LINK + MENDING		02
036	0503011721	40-1 CHAIN X 122 LINK + REDUCTION		02




Item	Code	Description	See page	QT
01	0511057951	ASSEMBLY CSU C3 2 BOXES 6B + 1 BOX 7B - 7350	108	01
02	0521063064	SUPPORT TOWER SILO SEED CSU		06
03	0501010942	3/8" X 1-1/4" BOLT		12
04	0501010984	FLAT WASHER		12
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12
07	0502010175	HITCH CLAMP		06
08	0501011543	5/8" X 4" BOLT		12
09	0501010453	FLAT WASHER		12
10	0503012412	5/8 UNC SELF LOCKING NUT		12




Item	Code	Description	See page	QT
001	0511057755	ASSEMBLY CSU 6850	107	01
002	0501010942	3/8" X 1-1/4" BOLT		12
003	0501010984	FLAT WASHER		12
004	0503010025	3/8" SPRING WASHER		12
005	0503010026	3/8" NUT		12
006	0502010175	HITCH CLAMP		06
007	0501011543	5/8" X 4" BOLT		12
008	0503012412	5/8 UNC SELF LOCKING NUT		12
009	0501010453	FLAT WASHER		12
010	0521063064	SUPPORT TOWER SILO SEED CSU		06

ASSEMBLY CSU


0521050909




Item	Code	Description	See page	QT
001	0511058564	ASSEMBLY CSU	105	01
002	0521063064	SUPPORT TOWER SILO SEED CSU		06
003	0501010942	3/8" X 1-1/4" BOLT		12
004	0501010984	FLAT WASHER		12
005	0503010025	3/8" SPRING WASHER		12
006	0503010026	3/8" NUT		12
007	0502010175	HITCH CLAMP		06
008	0501011543	5/8" X 4" BOLT		12
009	0501010453	FLAT WASHER		12
010	0503012412	5/8 UNC SELF LOCKING NUT		12




Item	Code	Description	See page	QT
01	0511058580	ASSEMBLY CSU	106	01
02	0521063064	SUPPORT TOWER SILO SEED CSU		06
03	0501010942	3/8" X 1-1/4" BOLT		12
04	0501010984	FLAT WASHER		12
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12
07	0502010175	HITCH CLAMP		06
08	0501011543	5/8" X 4" BOLT		12
09	0501012140	FLAT WASHER		12
10	0503012412	5/8 UNC SELF LOCKING NUT		12




Item	Code	Description	See page	QT
001	0521050074	ASSEMBLY CSU		01
002	0521063064	SUPPORT TOWER SILO SEED CSU		08
003	0501010942	3/8" X 1-1/4" BOLT		16
004	0501010984	FLAT WASHER		16
005	0503010025	3/8" SPRING WASHER		16
006	0503010026	3/8" NUT		16
007	0502010175	HITCH CLAMP		08
008	0501011543	5/8" X 4" BOLT		16
009	0501010453	FLAT WASHER		16
010	0503012412	5/8 UNC SELF LOCKING NUT		16




Item	Code	Description	See page	QT
01	0521064748	05 MOUTHS CSU SUPPORT	02	
02	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS	01	
03	0503061987	SILO FERTILIZER 05 MOUTHS FRONT MOUNTED	02	
04	0503061899	REAR BEAN FERTILIZER ASSY	01	
05	0521063401	SEED BOX ONLY FIXING LOCK	06	
06	0501010984	FLAT WASHER	06	
07	0503010025	3/8" SPRING WASHER	06	
08	0503010026	3/8" NUT	06	
09	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	13	
10	0501010942	3/8" X 1-1/4" BOLT	52	
11	0503010025	3/8" SPRING WASHER	52	
12	0503010026	3/8" NUT	52	
13	0571015773	SUPPORT SEED CSU	03	
14	0501011643	3/8 X 1"BOLT	12	
15	0503010025	3/8" SPRING WASHER	12	
16	0503010026	3/8" NUT	12	




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		06
02	0501010984	FLAT WASHER		06
03	0503010025	3/8" SPRING WASHER		66
04	0503010026	3/8" NUT		66
05	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU		13
06	0501010942	3/8" X 1-1/4" BOLT		52
07	0571015773	SUPPORT SEED CSU		02
08	0501011643	3/8 X 1"BOLT		08
09	0521064748	05 MOUTHS CSU SUPPORT		03
10	0503061987	SILO FERTILIZER 05 MOUTHS FRONT MOUNTED		03



Item	Code	Description	See page	QT
01	0503061899	REAR BEAN FERTILIZER ASSY		03
02	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS		03
03	0521063401	SEED BOX ONLY FIXING LOCK		06
04	0501010984	FLAT WASHER		06
05	0503010025	3/8" SPRING WASHER		78
06	0503010026	3/8" NUT		78
07	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU		15
08	0501010942	3/8" X 1-1/4" BOLT		60
09	0501011643	3/8 X 1" BOLT		12
10	0571015773	SUPPORT SEED CSU		03




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		06
02	0501010984	FLAT WASHER		06
03	0503010025	3/8" SPRING WASHER		66
04	0503010026	3/8" NUT		66
05	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU		15
06	0501010942	3/8" X 1-1/4" BOLT		60
07	0571015773	SUPPORT SEED CSU		04
08	0501011643	3/8 X 1"BOLT		16
09	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS		02
10	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		01
11	0503061899	REAR BEAN FERTILIZER ASSY		02
12	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		01




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
05	0503010179	5/16" ZN SPRING WASHER		01
06	0503010337	5/16" NUT		01

SQUARE AXLE ASSEMBLY (730)

0511053342




Item	Code	Description	See page	QT
01	0501056271	BEARING CLOSED	84	02
02	0501056444	BEARING WITH ROLLING		02
03	0503011953	5/16" X 1" BOLT		08
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		08
05	0503010179	5/16" ZN SPRING WASHER		08
06	0503010337	5/16" NUT		08
07	0511014218	3/4" X 28.7" SQUARE SHAFT		02
08	0521010691	AXLE FASTENER		04
09	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		04
10	0511017303	FLAT WASHER		04
11	0503010143	1/4" SPRING WASHER		04
12	0503010144	1/4" NUT		04
13	0503030303	SUPPORT WASHER		04
14	0521061852	LEVER RATCHET		02
15	0521061847	AXLE ADRIVING ASSY		02
16	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
17	0521061849	DISASSEMBLE LEVER		02
18	0503010140	1/8" X 3/4" COTTERPIN		04
19	0571012792	LOWER LEVER		02
20	0503011082	C1/2" X 1.3/4" SCREW		02
21	0511017302	FLAT WASHER		04
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2" NUT		02
24	0561016797	SLEEVE UNION LEVER		02
25	0501010096	3/8" X 2" BOLT		02
26	0501010984	FLAT WASHER		04
27	0503010026	3/8" NUT		04



Item	Code	Description	See page	QT
01	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE		02
02	0581014057	5/8" X 95.8" HEX AXLE		01
03	0581013561	5/8" X 95.8" HEX AXLE		01
04	0581014059	5/8" X HEX AXLE		01
05	0581014058	5/8" X HEX AXLE		01
06	0502040534	SPRING GUIDE BUSHING LOCK		08
07	0503010834	1/2 X 1 BOLT		08
08	0561014215	BEARING COVER LOWER ROW FRAME		02
09	0503062392	DRIVE SHAFT		02
10	0503011855	0.2" X 1.8" SPRING PIN		04
11	0503030331	1.2" X 1.2" X 12.2" HOSE		02
12	0503010243	CLAMP		04

HEX AXLE ASSEMBLY


0521050898




Item	Code	Description	See page	QT
001	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE		02
002	0581010593	HEX AXLE 5/8 X 600		01
003	0571013470	5/8 X 1100 HEX AXLE		01
004	0581012155	5/8" X HEX AXLE		01
005	0581014215	5/8" X HEX AXLE		01
006	0502040534	SPRING GUIDE BUSHING LOCK		08
007	0503010834	1/2 X 1 BOLT		08
008	0561014215	BEARING COVER LOWER ROW FRAME		02
009	0503062206	CARDAN TERMINAL		02
010	0503011855	0.2" X 1.8" SPRING PIN		04
011	0503030331	1.2" X 1.2" X 12.2" HOSE		02
012	0503010243	CLAMP		04

HEX AXLE ASSEMBLY

0521050972




Item	Code	Description	See page	QT
001	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	02	
002	0581014057	5/8" X 95.8" HEX AXLE	01	
003	0581013561	5/8" X 95.8" HEX AXLE	01	
004	0581014319	5/8" X 95.8" HEX AXLE	01	
005	0581014318	5/8" X HEX AXLE	01	
006	0502040534	SPRING GUIDE BUSHING LOCK	08	
007	0503010834	1/2 X 1 BOLT	08	
008	0561014215	BEARING COVER LOWER ROW FRAME	02	
009	0503062392	DRIVE SHAFT	02	
010	0503011855	0.2" X 1.8" SPRING PIN	04	
011	0503030331	1.2" X 1.2" X 12.2" HOSE	02	
012	0503010243	CLAMP	04	




Item	Code	Description	See page	QT
01	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	02	
02	0581010593	HEX AXLE 5/8 X 600	01	
03	0571013470	5/8 X 1100 HEX AXLE	01	
04	0581013331	5/8" X HEX AXLE	01	
05	0581013978	5/8" X HEX AXLE	01	
06	0502040534	SPRING GUIDE BUSHING LOCK	08	
07	0503010834	1/2 X 1 BOLT	08	
08	0561014215	BEARING COVER LOWER ROW FRAME	02	
09	0503062206	CARDAN TERMINAL	02	
10	0503011855	0.2" X 1.8" SPRING PIN	04	
11	0503030331	1.2" X 1.2" X 12.2" HOSE	02	
12	0503010243	CLAMP	04	

HEX AXLE ASSEMBLY


0521050079




Item	Code	Description	See page	QT
001	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE		02
002	0571013470	5/8 X 1100 HEX AXLE		01
003	0581013812	5/8" X 60.4" HEX AXLE		01
004	0581013151	5/8" X HEX AXLE		01
005	0581013813	5/8" X HEX AXLE		01
006	0502040534	SPRING GUIDE BUSHING LOCK		08
007	0503010834	1/2 X 1 BOLT		08
008	0561014215	BEARING COVER LOWER ROW FRAME		02
009	0503062206	CARDAN TERMINAL		02
010	0503011855	0.2" X 1.8" SPRING PIN		04
011	0503030331	1.2" X 1.2" X 12.2" HOSE		02
012	0503010243	CLAMP		04




Item	Code	Description	See page	QT
001	0581011413	SOPORTE IZQUIERDO CUERPO DE LA TURBINA		01
002	0581011414	BODY RIGHT SUPPORT TURBINE		01
003	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
004	0503010920	1/2" X 1.1/2" BOLT		01
005	0503010019	1/2" SPRING WASHER		05
006	0503010060	1/2" NUT		05
007	0571017282	FIXER SUPPORT TURBINE		02
008	0581011415	SUPPORTER FIXING BAR		01
009	0503011082	C1/2" X 1.3/4" SCREW		04
010	0511017302	FLAT WASHER		08
011	0503010019	1/2" SPRING WASHER		04
012	0503010060	1/2" NUT		04
013	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02
014	0501012140	FLAT WASHER		02
015	0503012412	5/8 UNC SELF LOCKING NUT		02
016	0521050729	DISTRIBUTOR SUPPORT AIR	125	06
017	0511059503	6 MOUTH AIR CONDUCTOR X 2150 - 6850	130	01
018	0521050531	4 MOUTHS RIGHT AIR CONDUCTOR - 13	131	01
019	0521050532	LEFT AIR CONDUCTOR 4 MOUTHS - 13	132	01
020	0581012166	HOSE		02
021	0511015569	HOSE		02
022	0521050580	HOSE GUIDE	128	02
023	0503011372	102 TO 121 CLAMP		08
024	0503013584	VACUUM GAUGE		01
025	0503015062	TUBE		01
026	0521050690	SET HOSE KIT	133	01
027	0571013731	VACUUM GAUGE SUPPORT		01
028	0511059406	TURBINE P.P MOUNTED	134	01
029	0503031436	AIR DITRIBUTOR PUMP		01
030	0503010246	CLAMP		01




Item	Code	Description	See page	QT
001	0581011413	SOPORTE IZQUIERDO CUERPO DE LA TURBINA		01
002	0581011414	BODY RIGHT SUPPORT TURBINE		01
003	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
004	0503010920	1/2" X 1.1/2" BOLT		01
005	0503010019	1/2" SPRING WASHER		05
006	0503010060	1/2" NUT		05
007	0571017282	FIXER SUPPORT TURBINE		02
008	0581011415	SUPPORTER FIXING BAR		01
009	0503011082	C1/2" X 1.3/4" SCREW		04
010	0511017302	FLAT WASHER		08
011	0503010019	1/2" SPRING WASHER		04
012	0503010060	1/2" NUT		04
013	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02
014	0501012140	FLAT WASHER		02
015	0503012412	5/8 UNC SELF LOCKING NUT		02
016	0521050729	DISTRIBUTOR SUPPORT AIR	125	06
017	0511059503	6 MOUTH AIR CONDUCTOR X 2150 - 6850	130	01
018	0511059504	RIGHT AIR CONDUCTOR - 6850	135	01
019	0511059505	LEFT AIR CONDUCTOR - 6850	136	01
020	0581012166	HOSE		02
021	0511015569	HOSE		02
022	0521050580	HOSE GUIDE	128	02
023	0503011372	102 TO 121 CLAMP		08
024	0503013584	VACUUM GAUGE		01
025	0503015062	TUBE		01
026	0521050690	SET HOSE KIT	133	01
027	0571013731	VACUUM GAUGE SUPPORT		01
028	0511059406	TURBINE P.P MOUNTED	134	01
029	0503031436	AIR DITRIBUTOR PUMP		01
030	0503010246	CLAMP		01




Item	Code	Description	See page	QT
001	0581011413	SOPORTE IZQUIERDO CUERPO DE LA TURBINA		01
002	0581011414	BODY RIGHT SUPPORT TURBINE		01
003	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
004	0503010920	1/2" X 1.1/2" BOLT		01
005	0503010019	1/2" SPRING WASHER		05
006	0503010060	1/2" NUT		05
007	0571017282	FIXER SUPPORT TURBINE		02
008	0581011415	SUPPORTER FIXING BAR		01
009	0503011082	C1/2" X 1.3/4" SCREW		04
010	0511017302	FLAT WASHER		08
011	0503010019	1/2" SPRING WASHER		04
012	0503010060	1/2" NUT		04
013	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02
014	0501012140	FLAT WASHER		02
015	0503012412	5/8 UNC SELF LOCKING NUT		02
016	0521050729	DISTRIBUTOR SUPPORT AIR	125	06
017	0511059503	6 MOUTH AIR CONDUCTOR X 2150 - 6850	130	01
018	0521050531	4 MOUTHS RIGHT AIR CONDUCTOR - 13	131	01
019	0521050532	LEFT AIR CONDUCTOR 4 MOUTHS - 13	132	01
020	0581012166	HOSE		02
021	0511015569	HOSE		02
022	0521050580	HOSE GUIDE	128	02
023	0503011372	102 TO 121 CLAMP		08
024	0503013584	VACUUM GAUGE		01
025	0503015062	TUBE		01
026	0521050690	SET HOSE KIT	133	01
027	0571013731	VACUUM GAUGE SUPPORT		01
028	0511059406	TURBINE P.P MOUNTED	134	01
029	0503031436	AIR DITRIBUTOR PUMP		01
030	0503010246	CLAMP		01




Item	Code	Description	See page	QT
001	0581011413	SOPORTE IZQUIERDO CUERPO DE LA TURBINA		01
002	0581011414	BODY RIGHT SUPPORT TURBINE		01
003	0503011239	1/2" X 2" BOLT		04
004	0503010060	1/2" NUT		04
005	0581011415	SUPPORTER FIXING BAR		01
006	0503011082	C1/2" X 1.3/4" SCREW		04
007	0511017302	FLAT WASHER		08
008	0503010019	1/2" SPRING WASHER		04
009	0503010060	1/2" NUT		04
010	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02
011	0501012140	FLAT WASHER		02
012	0503012412	5/8 UNC SELF LOCKING NUT		02
013	0511059319	AIR FIXING SUPPORT		06
014	0511059503	6 MOUTH AIR CONDUCTOR X 2150 - 6850	130	01
015	0511059504	RIGHT AIR CONDUCTOR - 6850	135	01
016	0511059505	LEFT AIR CONDUCTOR - 6850	136	01
017	0581012166	HOSE		04
018	0503011372	102 TO 121 CLAMP		06
019	0503013584	VACUUM GAUGE		01
020	0503015062	TUBE		01
021	0511057906	HOSE ASSY	138	01
022	0571013731	VACUUM GAUGE SUPPORT		01
023	0511059406	TURBINE P.P MOUNTED	134	01




Item	Code	Description	See page	QT
001	0521050564	TURB PP COP	121	02
002	0521050571	HYDRAULIC TURBINE ASSEMBLY	122	02
003	0571017282	FIXER SUPPORT TURBINE		01
004	0503011082	C1/2" X 1.3/4" SCREW		02
005	0503014007	1/2" X 1-1/4" BOLT		02
006	0503010019	1/2" SPRING WASHER		04
007	0503010060	1/2" NUT		04
008	0581013802	VALV. SUPPORT		01
009	0503010237	3/8" X 1" BOLT		02
010	0503010025	3/8" SPRING WASHER		02
011	0503010026	3/8" NUT		02
012	0521050566	VALVE ANTI-CAVITACAO	123	01
013	0521050565	FLOW DIVIDING VALVE ASSY	124	01
014	0521060118	"T" TERMINAL		01
015	0503033787	NUT 3/4 UNF		01
016	0521050729	DISTRIBUTOR SUPPORT AIR	125	07
017	0521050569	DISTRIBUTOR AIR CENTER	126	01
018	0511057348	DISTRIBUTOR VACUUM	127	02
019	0503031576	ELBOW		02
020	0521050580	HOSE GUIDE	128	02
021	0531016191	4" X 55" AIR CONDUCTOR		02
022	0511015569	HOSE		02
023	0503031436	AIR DITRIBUTOR PUMP		01
024	0503010246	CLAMP		01
025	0503011372	102 TO 121 CLAMP		06
026	0571013731	VACUUM GAUGE SUPPORT		01
027	0503013584	VACUUM GAUGE		01
028	0521050582	SET HOSE KIT	129	01
029	0503016022	T-120 L CRAMP NYLON		14




Item	Code	Description	See page	QT
001	0502010175	HITCH CLAMP		01
002	0501011543	5/8" X 4" BOLT		02
003	0501012140	FLAT WASHER		02
004	0503012412	5/8 UNC SELF LOCKING NUT		02
005	0521067621			01




Item	Code	Description	See page	QT
001	0503062558	VACUUM TURBINE		01
002	0501011460	7/8 NF REDUCTION NIPPLE		02
003	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
004	0503010392	2-046 N 3006 9B O'RING		01
005	0503010190	2-114 N 3006-9B O'RING		02
006	0503031087	ADHESIVE LABEL		01
007	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01




Item	Code	Description	See page	QT
001	0503015420	VALVE ANTI-CAVITACAO CV10208TN5		01
002	0503010190	2-114 N 3006-9B O'RING		02
003	0501011460	7/8 NF REDUCTION NIPPLE		02
004	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
005	0503010143	1/4" SPRING WASHER		02
006	0503010144	1/4" NUT		02
007	0503010305	FLAT WASHER		04
008	0503013055	"T" ADAPTOR WITH GIRAT NUT		01




Item	Code	Description	See page	QT
001	0503013791	DOUBLE MOTOR		01
002	0503010025	3/8" SPRING WASHER		04
003	0541018940	7/8 NF X R 1 BSPT X 55 NIPPLE		01
004	0501010984	FLAT WASHER		04
005	0503011051	M10 X 0.6" NUT		04
006	0581013814	1/2" NIPPLE		02




Item	Code	Description	See page	QT
001	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
002	0503010019	1/2" SPRING WASHER		02
003	0503010060	1/2" NUT		02
004	0503010371	5/16" X 1" BOLT		02
005	0503010179	5/16" ZN SPRING WASHER		02
006	0503010337	5/16" NUT		02
007	0581014038	DISTRIBUTOR SUPPORT AIR		01
008	0521018402	AIR CONDUCTOR CLAMP		01



Item	Code	Description	See page	QT
001	0521050261	DISTRIBUTOR AIR CENTER 08 MOUTHS - 19 A 21		01
001A	0503031943	SOCKET		08
001B	0503012856	REBITE POP		16
001C	0503012566	COVER KAP 110 YELLOW		02
001D	0571019406	BODY DISTRIBUTOR VACUUM		01
001E	0561017670	BODY DISTRIBUTOR AR		02
001F	0511057036	AIR DISTRIBUTOR BOARD		02
002	0503062560	TUBE FOR METER CLOCK 730142		01




Item	Code	Description	See page	QT
01	0571017215	SOCKET DISTRIBUTOR AR		01
02	0503012566	COVER KAP 110 YELLOW		01
03	0503031943	SOCKET		05
04	0503012856	REBITE POP		10
05	0571019405	BODY DISTRIBUTOR VACUUM 4845/5345		01




Item	Code	Description	See page	QT
001	0521066304	HOSE GUIDE		01
002	0511017302	FLAT WASHER		01
003	0503010019	1/2" SPRING WASHER		01
004	0503010060	1/2" NUT		01
005	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01

SET HOSE KIT


0521050582




Item	Code	Description	See page	QT
001	0521050583	SET TURBINE HOSE REAR COP TRIO		01
001A	0501082026	HOSE 1/2 X 7500 TC-TM		02
001B	0501080683	3/8 X 7700 TC-TM HOSE		01
001C	0501081118	3/8 X 1350 TR-TC HOSE		02
001D	0501080941	1/2 X 1800 TC-TR HOSE		02
001E	0501080627	HOSE 1/2 X 1800 TC-TC		02
002	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	72	02
003	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN		01
004	0581012991	SPRING PROTECTION PLASTIC HOSE		01
005	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
006	0581011173	SPRING PROTECTION PLASTIC HOSE		02
007	0503033981	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0503017845	PVC KNEE 90 SOLD AVEL		02
02	0571018559	WHITE PVC TUBE		04
03	0503031943	SOCKET		06
04	0503012856	REBITE POP		12
05	0503012567	T-JOIN FOR TUBE 110		02
06	0581012167	AR 600 CONDUCTOR BODY		03




Item	Code	Description	See page	QT
01	0571019406	BODY DISTRIBUTOR VACUUM		01
02	0503012566	COVER KAP 110 YELLOW		01
03	0503031943	SOCKET		04
04	0503012856	REBITE POP		08
05	0521050393	ASSY KNEE		01




Item	Code	Description	See page	QT
01	0571019406	BODY DISTRIBUTOR VACUUM		01
02	0503012566	COVER KAP 110 YELLOW		01
03	0503031943	SOCKET		04
04	0503012856	REBITE POP		08
05	0521050393	ASSY KNEE		01

SET HOSE KIT


0521050690




Item	Code	Description	See page	QT
001	0521050691	SET TURBINE HOSE REAR COP TRIO		01
001A	0501082124	1/2" X 6700 TR-TR HOSE		02
001B	0501080640	3/8 X 7200 TC-TM HOSE		01
002	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	72	02
003	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN		01
004	0581012991	SPRING PROTECTION PLASTIC HOSE		01
005	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
006	0503033981	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE	01	
02	0501011460	7/8 NF REDUCTION NIPPLE	04	
03	0503034385	NIPPLE 7/16 UNF X UNF JIC	01	
04	0503010392	2-046 N 3006 9B O'RING	01	
05	0581012096	ROUND SLEEVE	02	
06	0503015420	VALVE ANTI-CAVITACAO CV10208TN5	01	
07	0521050154	TURBINE P.P WITH HOLE	01	
08	0503031087	ADHESIVE LABEL	01	
09	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN	02	
10	0501010694	8.5 X 18 X 1.5 FLAT WASHER	02	
11	0503010143	1/4" SPRING WASHER	02	
12	0503010144	1/4" NUT	02	
13	0503010190	2-114 N 3006-9B O'RING	04	
14	0501081235	1/2 X 650 TR- TC HOSE	01	
15	0503031426	ADHESIVE LABEL ATTENTION TURBINE	01	



Item	Code	Description	See page	QT
01	0503017845	PVC KNEE 90 SOLD AVEL		01
02	0571019405	BODY DISTRIBUTOR VACUUM 4845/5345		01
03	0503012566	COVER KAP 110 YELLOW		01
04	0503031943	SOCKET		05
05	0503012856	REBITE POP		10
06	0571018559	WHITE PVC TUBE		01




Item	Code	Description	See page	QT
01	0503017845	PVC KNEE 90 SOLD AVEL		01
02	0571019405	BODY DISTRIBUTOR VACUUM 4845/5345		01
03	0503012566	COVER KAP 110 YELLOW		01
04	0503031943	SOCKET		05
05	0503012856	REBITE POP		10
06	0571018559	WHITE PVC TUBE		01




Item	Code	Description	See page	QT
01	0501010942	3/8" X 1-1/4" BOLT		08
02	0501010984	FLAT WASHER		08
03	0503010025	3/8" SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0521051927	TOWER SUPPORT HOPPER		04
06	0511058724	ASSEMBLY CSU C3 2BOXES 7/6 12E500		01

HOSE ASSY

0511057906




Item	Code	Description	See page	QT
01	0511057840	ASSY TURBINE HOSE REAR		01
01A	0521052534	HOSE 1/2 X 7012 TC-TM YELLOW / RED		01
01AA	0501081247	HOSE 1/2 X 7012 TC-TM		01
01AB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01AD	0503018952	PLASTIC BOLT		06
01B	0521052535	HOSE 1/2 X 7012 TC-TM YELLOW / BLUE		01
01BA	0501081247	HOSE 1/2 X 7012 TC-TM		01
01BB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01BD	0503018952	PLASTIC BOLT		06
01C	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
01CA	0501080477	HOSE 3/8 X 7012 TC-TM		01
01CB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01CC	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
01CD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	72	02
03	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
04	0503033981	ADHESIVE LABEL		01
05	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN		01



Item	Code	Description	See page	QT
01	0511057729	FRONT SEED SHORT	140	01
02	0511057730	FRONT SEED LONG	141	01
03	0521050577	FRONT LINE SEED ELONGATED	142	01
04	0521050578	CH L SEM SM COP TRIO SUP PP S-0117	144	01
05	0511053024	FERTILIZER SHORT LINE	145	01
06	0511053023	LONG FERTILIZER LINE	147	01
07	0511057108	RIGHT REAR SEED ROW PRECISION PLANTING CSU 3	151	01
08	0511057115	REAR LEFT SEED LINE PRECISION PLANTING CSU 3	155	01
09	0521050012	RIGHT REAR ROW SEED P.P PM400/CSU	157	01
10	0521050013	LEFT REAR ROW SEED P.P PM400/CSU	159	01
11	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA CSU 3	152	01
12	0503010905	1/2" X 2-1/4" BOLT		03
13	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		03
14	0503010019	1/2" SPRING WASHER		06
15	0503010060	1/2" NUT		06
16	0501054481	RIGHT ARM DEPTH CONTROL WITH WHEEL	160	01
17	0501054482	DEPTH CONTROL LEFT ARM WITH TIRE	161	01
18	0503010547	1/2" X 4" BOLT		02
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2" NUT		02
21	0511065909	DEPTH FIXER BASE		01
22	0511051818	DISC CUT 18 SEMI MOUNTED	162	01
23	0511051819	DC 20 SEMI MOUNTED	164	01
24	0571011730	SEED CONDUCTOR 3X1500		01
25	0503010246	CLAMP		01
26	0503031050	CURVED CONDUCTOR		01
27	0531013600	PRESS ADJUSTMENT LEVER		01
28	0503062417	KIT CORN DISTRIBUTION		01
29	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01

Item	Code	Description	See page	QT
30	0511063823	FERT CONDUCTOR WITH REGULATOR		01
31	0511065843	FERT CONDUCTOR WITH REGULATOR		01
32	0521050525	FIXER FERTILIZER CONDUCTOR	166	02
33	0571018663	SUPPORT GUTTER		01
34	0571017368	SUPPORT GUTTER		01
35	0571018391	GUTTER 25 X 58 X 1200		02
36	0571013313	GUTTER 25 X 58 X 2150		02
37	0571019693	GUN 25 X 58 X 800		02
38	0571013314	GUTTER 25 X 58 X 1500		02
39	0501011643	3/8 X 1"BOLT		02
40	0501010984	FLAT WASHER		02
41	0503010025	3/8" SPRING WASHER		02
42	0503010026	3/8" NUT		02
43	0503062403	TUBE SEED P.P		02
44	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	167	01
45	0521051424	WHEEL SYSTEM DEPTH/COMPACTOR QUICK ADJUSTMENT	167	01
46	0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	171	01
47	0521044269	PRESS WHEELS/DEPTH ASSY	179	01
48	0521044460	SYSTEM DEPTH / COMPACTOR	186	01
49	0571019716	ADAPTER		01
50	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		01




Item	Code	Description	See page	QT
001	0502012784	DRIVER PIVOT		02
002	0503010002	1800 GREASE FITTING		04
003	0531015151	0.6" X 1" X 2.4" SLEEVE		08
004	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
005	0531015184	FLAT WASHER		08
006	0503012412	5/8 UNC SELF LOCKING NUT		04
007	0571012449	CONTROL AXLE		01
008	0503030024	1.7" X10.2" X 0.2" EXTENSION SPRING		02
009	0503030168	HAIR PIN		02
010	0571012448	LOCK SLEEVE AXLE REGULATION		01
011	0503010131	3/16" X 1-1/2" COTTERPIN		01
012	0521065914	FRAME ASSY		01
013	0521065677	LIMITER		01
014	0571012443	COUPLING SHAFT		01
015	0571012442	COUPLING SHAFT		03
016	0503010131	3/16" X 1-1/2" COTTERPIN		02
017	0502012785	SEED ROW ADJUSTMENT LEVER ASSY		01
018	0502012814	BOX LEVER LOCK		01
019	0511054635	BEARING AXLE BODY		02
019A	0502012718	BEARIN BODY		01
019B	0503012882	BEARING		01
019C	0503017011	SEAL RING		01
019D	0503011945	503050 CLAMPING RING (FOR AXLE)		01
020	0503011953	5/16" X 1" BOLT		04
021	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
022	0503010179	5/16" ZN SPRING WASHER		04
023	0503010337	5/16" NUT		04
024	0571012441	TRANSMISSION AXLE		01
025	0511054884	TRANSMISSION BOX	143	01
026	0503011378	M6X1X16 C S 8.8 ZN BOLT		02
027	0503015110	M06 SPRING WASHER		02

FRONT SEED SHORT

0511057729

Item	Code	Description	See page	QT
028	0503011855	0.2" X 1.8" SPRING PIN		01
029	0511052393	BEARING FOLLOWER ROW ASSY		01
029A	0521063532	BEARING FOLLOWER ROW ASSY		01
029B	0503011410	ROLLER BEARING		01
029C	0503011105	SEAL RING		01
029D	0571012450	COP FLEX AXLE		01
029E	0571012459	COP FLEX AXLE		01
029F	0503010406	501025 CLAMPING RING (FOR AXLE)		02
029G	0503015356	SPRING PIN		01
029H	0503010691	1/4" GREASE FITTING		01
030	0503032984	HOOD HEX AXLE ROW		01
031	0503013100	NYLON CLAMP		01
032	0511057625	ROW SEED BEARING		01
032A	0511057156	BEARING LINE SEMI MOUNTED		01
032AA	0521065913	ROW SEED BEARING		01
032AB	0503011410	ROLLER BEARING		02
032AC	0503011105	SEAL RING		01
032AD	0503010406	501025 CLAMPING RING (FOR AXLE)		02
032AE	0571017815	BEARING AXLE BODY		01
032AF	0503017008	SEAL RING		01
032B	0571018731	HEX AXLE		01
032C	0571017900	5/8" X 77" HEX AXLE		01
032D	0561014778	HEX UNIVERSAL JOINT		01
032E	0501056296	UNIVERSAL JOINT		01
032F	0503011855	0.2" X 1.8" SPRING PIN		03
032G	0503013958	1/4" X 1" BOLT		02
033	0503011953	5/16" X 1" BOLT		04
034	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
035	0503010179	5/16" ZN SPRING WASHER		04
036	0503010337	5/16" NUT		04
037	0521063525	SHORT SEED ROW FRONT		01
038	0511050609	BEARING WITH 17Z GEAR ASSY		01
038A	0511050617	FRONT SEED ROW BEARING		01
038AA	0502011697	BEARING OF THE GEAR BOX		01
038AB	0503011410	ROLLER BEARING		01
038AC	0503011105	SEAL RING		01
038AD	0503011953	5/16" X 1" BOLT		02
038AE	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
038AF	0503010179	5/16" ZN SPRING WASHER		02
038AG	0503010337	5/16" NUT		02
038B	0503010406	501025 CLAMPING RING (FOR AXLE)		01
038C	0502012819	17Z GEAR WITH HEX HOLE		01
039	0503011953	5/16" X 1" BOLT		02
040	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
041	0503010179	5/16" ZN SPRING WASHER		02
042	0503010337	5/16" NUT		02
043	1902010175	HITCH CLAMP		01
044	0503010811	5/8" UNF SELF ADJUSTING NUT		02
045	0531019479	AXLE CHAIN GEAR		01
046	0541016454	PULLEY		01
047	0503011828	FLAT WASHER		01
048	0503010019	1/2" SPRING WASHER		01
049	0503010060	1/2" NUT		01
050	0503016501	40-1 X 49 CHAIN LINK + MENDING		01
051	0501012140	FLAT WASHER		02
052	0502012782	17Z GEAR WITH HEX HOLE		01
053	0571019706	HEX AXLE		01
054	0503016460	5/8" X 4.1/2" BOLT		02




Item	Code	Description	See page	QT
001	0502012784	DRIVER PIVOT		02
002	0503010002	1800 GREASE FITTING		04
003	0531015151	0.6" X 1" X 2.4" SLEEVE		08
004	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
005	0531015184	FLAT WASHER		08
006	0503012412	5/8 UNC SELF LOCKING NUT		04
007	0571012449	CONTROL AXLE		01
008	0503030024	1.7" X10.2" X 0.2" EXTENSION SPRING		02
009	0503030168	HAIR PIN		02
010	0571012448	LOCK SLEEVE AXLE REGULATION		01
011	0503010131	3/16" X 1-1/2" COTTERPIN		01
012	0521065677	LIMITER		01
013	0571012443	COUPLING SHAFT		01
014	0571012442	COUPLING SHAFT		03
015	0503010131	3/16" X 1-1/2" COTTERPIN		02
016	0502012785	SEED ROW ADJUSTMENT LEVER ASSY		01
017	0502012814	BOX LEVER LOCK		01
018	0511054635	BEARING AXLE BODY		02
018A	0502012718	BEARIN BODY		01
018B	0503012882	BEARING		01
018C	0503017011	SEAL RING		01
018D	0503011945	503050 CLAMPING RING (FOR AXLE)		01
019	0503011953	5/16" X 1" BOLT		04
020	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
021	0503010179	5/16" ZN SPRING WASHER		04
022	0503010337	5/16" NUT		04
023	0571012441	TRANSMISSION AXLE		01
024	0511054884	TRANSMISSION BOX	143	01
025	0503011378	M6X1X16 C S 8.8 ZN BOLT		02
026	0503015110	M06 SPRING WASHER		02
027	0503011855	0.2" X 1.8" SPRING PIN		01

Item	Code	Description	See page	QT
028	0511052393	BEARING FOLLOWER ROW ASSY		01
028A	0521063532	BEARING FOLLOWER ROW ASSY		01
028B	0503011410	ROLLER BEARING		01
028C	0503011105	SEAL RING		01
028D	0571012450	COP FLEX AXLE		01
028E	0571012459	COP FLEX AXLE		01
028F	0503010406	501025 CLAMPING RING (FOR AXLE)		02
028G	0503015356	SPRING PIN		01
028H	0503010691	1/4" GREASE FITTING		01
029	0503032984	HOOD HEX AXLE ROW		01
030	0503013100	NYLON CLAMP		01
031	0511057625	ROW SEED BEARING		01
031A	0511057156	BEARING LINE SEMI MOUNTED		01
031AA	0521065913	ROW SEED BEARING		01
031AB	0503011410	ROLLER BEARING		02
031AC	0503011105	SEAL RING		01
031AD	0503010406	501025 CLAMPING RING (FOR AXLE)		02
031AE	0571017815	BEARING AXLE BODY		01
031AF	0503017008	SEAL RING		01
031B	0571018731	HEX AXLE		01
031C	0571017900	5/8" X 77" HEX AXLE		01
031D	0561014778	HEX UNIVERSAL JOINT		01
031E	0501056296	UNIVERSAL JOINT		01
031F	0503011855	0.2" X 1.8" SPRING PIN		03
031G	0503013958	1/4" X 1" BOLT		02
032	0503011953	5/16" X 1" BOLT		04
033	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
034	0503010179	5/16" ZN SPRING WASHER		04
035	0503010337	5/16" NUT		04
036	0571019706	HEX AXLE		01
037	0521063524	FRAME FRONT LINE SEED		01
038	0511050609	BEARING WITH 17Z GEAR ASSY		01
038A	0511050617	FRONT SEED ROW BEARING		01
038AA	0502011697	BEARING OF THE GEAR BOX		01
038AB	0503011410	ROLLER BEARING		01
038AC	0503011105	SEAL RING		01
038AD	0503011953	5/16" X 1" BOLT		02
038AE	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
038AF	0503010179	5/16" ZN SPRING WASHER		02
038AG	0503010337	5/16" NUT		02
038B	0503010406	501025 CLAMPING RING (FOR AXLE)		01
038C	0502012819	17Z GEAR WITH HEX HOLE		01
039	0503011953	5/16" X 1" BOLT		02
040	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
041	0503010179	5/16" ZN SPRING WASHER		02
042	0503010337	5/16" NUT		02
043	1902010175	HITCH CLAMP		01
044	0503010811	5/8" UNF SELF ADJUSTING NUT		02
045	0531019479	AXLE CHAIN GEAR		01
046	0541016454	PULLEY		01
047	0503011828	FLAT WASHER		01
048	0503010019	1/2" SPRING WASHER		01
049	0503010060	1/2" NUT		01
050	0503012142	40-1 CHAIN X 61 LINK + MENDING		01
051	0501012140	FLAT WASHER		02
052	0502012782	17Z GEAR WITH HEX HOLE		01
053	0521065914	FRAME ASSY		01
054	0503817859	5/8" X 4.3/4" BOLT		02

FRONT LINE SEED ELONGATED

0521050577




Item	Code	Description	See page	QT
01	0502012784	DRIVER PIVOT	02	
02	0503010002	1800 GREASE FITTING	04	
03	0581014435	SLEEVE ARM LINE SEED	08	
04	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
05	0531015184	FLAT WASHER	08	
06	0503012412	5/8 UNC SELF LOCKING NUT	04	
07	0571012449	CONTROL AXLE	01	
08	0503030024	1.7" X10.2" X 0.2" EXTENSION SPRING	02	
09	0503030168	HAIR PIN	02	
10	0571012448	LOCK SLEEVE AXLE REGULATION	01	
11	0503010131	3/16" X 1-1/2" COTTERPIN	01	
12	0521065677	LIMITER	01	
13	0571012443	COUPLING SHAFT	01	
14	0571012442	COUPLING SHAFT	03	
15	0503010131	3/16" X 1-1/2" COTTERPIN	02	
16	0502012785	SEED ROW ADJUSTMENT LEVER ASSY	01	
17	0502012814	BOX LEVER LOCK	01	
18	0511054635	BEARING AXLE BODY	02	
19	0503011953	5/16" X 1" BOLT	04	
20	0501010694	8.5 X 18 X 1.5 FLAT WASHER	04	
21	0503010179	5/16" ZN SPRING WASHER	04	
22	0503010337	5/16" NUT	04	
23	0571012441	TRANSMISSION AXLE	01	
24	0511057159	TRANSMISSION BOX SEED LINE	01	
25	0503011378	M6X1X16 C S 8.8 ZN BOLT	02	
26	0503015110	M06 SPRING WASHER	02	
27	0511052393	BEARING FOLLOWER ROW ASSY	01	
28	0503032984	HOOD HEX AXLE ROW	01	
29	0503013100	NYLON CLAMP	01	
30	0521068102	LONG SEED LINE FRONT SUPPORT	01	
31	0511050609	BEARING WITH 17Z GEAR ASSY	01	


Item	Code	Description	See page	QT
32	1902010175	HITCH CLAMP		01
33	0503817859	5/8" X 4.3/4" BOLT		02
34	0503010811	5/8" UNF SELF ADJUSTING NUT		02
35	0531019479	AXLE CHAIN GEAR		01
36	0541016454	PULLEY		01
37	0503011828	FLAT WASHER		01
38	0503010019	1/2" SPRING WASHER		01
39	0503010060	1/2" NUT		01
40	0503012142	40-1 CHAIN X 61 LINK + MENDING		01
41	0501012140	FLAT WASHER		02
42	0502012782	17Z GEAR WITH HEX HOLE		01

TRANSMISSION BOX


0511054884



Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	BOX TRANSMISSION COVER		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0502040857	CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503010003	1845 GREASE FITTING		01
13	0503011409	6005 Z BALL BEARING		01
14	0503017008	SEAL RING		01
15	0503017007	SEAL RING		02
16	0511017907	1/8" BSPT X 6 PLUG		01



Item	Code	Description	See page	QT
001	0521067620	SEED LINE REAR FRAME	01	
002	0511057156	BEARING LINE SEMI MOUNTED	01	
002A	0521065913	ROW SEED BEARING	01	
002B	0503011410	ROLLER BEARING	02	
002C	0503011105	SEAL RING	01	
002D	0503010406	501025 CLAMPING RING (FOR AXLE)	02	
002E	0571017815	BEARING AXLE BODY	01	
002F	0503017008	SEAL RING	01	
003	0503011953	5/16" X 1" BOLT	04	
004	0501010984	FLAT WASHER	04	
005	0503010179	5/16" ZN SPRING WASHER	04	
006	0503010337	5/16" NUT	04	
007	0571017900	5/8" X 77" HEX AXLE	01	
008	0571019706	HEX AXLE	01	
009	0581013794	5/8" X HEX AXLE	01	
010	0561014778	HEX UNIVERSAL JOINT	01	
011	0501056296	UNIVERSAL JOINT	01	
012	0503011855	0.2" X 1.8" SPRING PIN	03	
013	0503013958	1/4" X 1" BOLT	02	




Item	Code	Description	See page	QT
01	0511053223	FERTILIZER ROW SUPPORT WITH SCREW		01
02	0502012728	ROW FERTILIZER SUPPORT		01
03	0503017856	BOLT 3/4		02
04	0503010152	3/4" SELF LOCKING NUT		02
05	0521063504	FERTILIZER ROW LOWER SUPPORT		01
06	0561017928	FERTILIZER ROW ARTICULAT SLEEVE		02
07	0511015098	FLAT WASHER		06
08	0503010233	5/8" X 2-1/2" BOLT		02
09	0503012412	5/8 UNC SELF LOCKING NUT		02
10	0511063862	FERTILIZER ROW UPPER SUPPORT		01
11	0501010452	5/8" X 5" BOLT		01
12	0531016207	0.6" X 1" X 2.8" SLEEVE		01
13	0503012412	5/8 UNC SELF LOCKING NUT		01
14	0521061855	FERTILIZER ROW REAR SUPPORT		01
15	0501010452	5/8" X 5" BOLT		02
16	0531016031	1/2" SPRING WASHER		04
17	0531016207	0.6" X 1" X 2.8" SLEEVE		02
18	0503012412	5/8 UNC SELF LOCKING NUT		02
19	0521062073	SPRING GUIDE		01
20	0521016057	COUP SHA OF THE CARRY-W SPRING GUI		01
21	0503030168	HAIR PIN		01
22	1902020393	SPRING UPPER SUPPORT		01
23	0503031450	2.7" X 9.2" X 0.03" SPRING		01
24	1902020393	SPRING UPPER SUPPORT		01
25	0521011158	SPRING LOCKNUT		01
26	0521018575	REGULATOR SPINDLE 100		01
27	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	146	01
28	0502012352	DOUBLE-DISC SPACING PLATE		01
29	0541013035	5.55" X 4.0" X 0.38" PLATE		01
30	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
31	0503010019	1/2" SPRING WASHER		02




FERTILIZER SHORT LINE

0511053024

Item	Code	Description	See page	QT
32	0503010060	1/2" NUT		02
33	0503010752	1/2" X 3.1/2" BOLT		02
34	0503010019	1/2" SPRING WASHER		02
35	0503010060	1/2" NUT		02
36	0503030520	SEED SOCKET		01
37	0503031145	2" X 2" X 20" HOSE		01
38	0503031076	2" HOSE CLAMP		02
39	0503010003	1845 GREASE FITTING		03



Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	149	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	150	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0521063759	ROW FERTILIZER SUPPORT	01	
02	0511053223	FERTILIZER ROW SUPPORT WITH SCREW	01	
03	0503017855	3/4" BOLT	02	
04	0503010152	3/4" SELF LOCKING NUT	02	
05	0521063504	FERTILIZER ROW LOWER SUPPORT	01	
06	0503010233	5/8" X 2-1/2" BOLT	02	
07	0511015098	FLAT WASHER	06	
08	0561017928	FERTILIZER ROW ARTICULAT SLEEVE	02	
09	0503012412	5/8 UNC SELF LOCKING NUT	02	
10	0511063862	FERTILIZER ROW UPPER SUPPORT	01	
11	0501010163	5/8" X 4-1/2" BOLT	01	
12	0531015184	FLAT WASHER	01	
13	0531016031	1/2" SPRING WASHER	01	
14	0503012412	5/8 UNC SELF LOCKING NUT	01	
15	0531016207	0.6" X 1" X 2.8" SLEEVE	01	
16	0521061855	FERTILIZER ROW REAR SUPPORT	01	
17	0501010452	5/8" X 5" BOLT	02	
18	0531016031	1/2" SPRING WASHER	04	
19	0531016207	0.6" X 1" X 2.8" SLEEVE	02	
20	0503012412	5/8 UNC SELF LOCKING NUT	02	
21	0521062073	SPRING GUIDE	01	
22	0521016057	COUP SHA OF THE CARRY-W SPRING GUI	01	
23	0503030168	HAIR PIN	01	
24	1902020393	SPRING UPPER SUPPORT	01	
25	0503031450	2.7" X 9.2" X 0.03" SPRING	01	
26	1902020393	SPRING UPPER SUPPORT	01	
27	0521011158	SPRING LOCKNUT	01	
28	0521018575	REGULATOR SPINDLE 100	01	
29	0502012724	FERTILIZER ROW FIXER	01	
30	0503017960	5/8" X 3-12" BOLT	04	
31	0503010811	5/8" UNF SELF ADJUSTING NUT	04	


LONG FERTILIZER LINE

0511053023


Item	Code	Description	See page	QT
32	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	148	01
33	0502012352	DOUBLE-DISC SPACING PLATE		01
34	0541013035	5.55" X 4.0" X 0.38" PLATE		01
35	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
36	0503010019	1/2" SPRING WASHER		02
37	0503010060	1/2" NUT		02
38	0503010752	1/2" X 3.1/2" BOLT		02
39	0503010019	1/2" SPRING WASHER		02
40	0503010060	1/2" NUT		02
41	0503030520	SEED SOCKET		01
42	0503031145	2" X 2" X 20" HOSE		01
43	0503031076	2" HOSE CLAMP		02
44	0503010003	1845 GREASE FITTING		02
45	0503010004	1890 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	150	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	149	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01



Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA CSU 3	152	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	DDD RITGH SUPREMA PRECISION PLANTING	154	01




Item	Code	Description	See page	QT
01	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
02	0571017899	PIN LOCK PP		01
03	0503030190	0.5" X 1.6" X 0.05" SPRING		01
04	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
05	0511057155	PRECISION PLANTING LEFT TRANSMISSION BOX		01
06	0571017894	PIN DRAG PRECISION PLANTING		01
07	0503013357	3/8" SELF-ADJUSTING NUT		01
08	0501013518	FLAT WASHER		02
09	0503015356	SPRING PIN		01
10	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
11	0571017895	PIN FIXER CONDUCTOR P.P		01
12	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
13	0503010293	BAQUELITE MANIPULACION		02
14	0503010140	1/8" X 3/4" COTTERPIN		02
15	0503010131	3/16" X 1-1/2" COTTERPIN		01
16	0503010025	3/8" SPRING WASHER		02
17	0571019491	SLUICE PNEUMATIC PRECISION PLANTING		01
18	0501011643	3/8 X 1"BOLT		01
19	0503010209	3/8" UNC BUTTERFLY NUT		01
20	0502012807	SUPPORT BOX PRECISION PLANTING		01
21	0571019489	CLAMP PRECISION PLANTING		01
22	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
23	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN 153 DISC	153	01
24	0561014778	HEX UNIVERSAL JOINT		01
25	0503013958	1/4" X 1" BOLT		02
26	0503011855	0.2" X 1.8" SPRING PIN		01
27	0503012721	1/4" X 4" BOLT		01
28	0503012880	1/4" UNC SELF ADJUSTING NUT		04
29	0571014024	FAST BOLT GUIDE AXLE		01
30	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02


Item	Code	Description	See page	QT
31	0503015110	M06 SPRING WASHER		02
32	0503818139	BOLT		03
33	0503037390	PACKING FOR PLANTING		01
34	0503015752	3/8" X 2" BOLT		01
35	0503034824	FIXATIVE		01
36	0581011226	FIXER CLOSING P PLANTING CONTR CPRA		01
37	0503010337	5/16" NUT		04
38	0503010179	5/16" ZN SPRING WASHER		04
39	0503011953	5/16" X 1" BOLT		03
40	0503012163	5/16" X 1-1/2" BOLT		01
41	0521066707	FEEDER		01




Item	Code	Description	See page	QT
01	0571019613	STRAW PRECISION PLANTING SHIELD		01
02	0521052131	DISTRIBUTOR VSET2 WITH CORN DISK WITHOUT PROTECTION		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	149	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15	150	01
04	0503010026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501010984	FLAT WASHER		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012780	SUPPORT DDD RIGHT		01
11	0511015098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02




Item	Code	Description	See page	QT
01	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA CSU 3	152	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	156	01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	149	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15	150	01
04	0503010026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501010984	FLAT WASHER		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012781	SUPPORT DDD LEFT		01
11	0511015098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02




Item	Code	Description	See page	QT
001	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA CSU 3	152	01
002	0503015920	3/8" UNC X 1.3/4" BOLT		04
003	0503010025	3/8" SPRING WASHER		04
004	0503010026	3/8" NUT		04
005	0503062403	TUBE SEED P.P		01
006	0511057154	DDD RITGH SUPREMA PRECISION PLANTING	154	01
007	0501058972	ASSEMBLY SENSOR ELECTRONIC	158	01




Item	Code	Description	See page	QT
01	0503015218	SENSOR FOTOELE PM 400		01
02	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		03




Item	Code	Description	See page	QT
001	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA CSU 3	152	01
002	0503015920	3/8" UNC X 1.3/4" BOLT		04
003	0503010025	3/8" SPRING WASHER		04
004	0503010026	3/8" NUT		04
005	0503062403	TUBE SEED P.P		01
006	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	156	01
007	0501058972	ASSEMBLY SENSOR ELECTRONIC	158	01




Item	Code	Description	See page	QT
01	0501056430	ARM RIGHT CONTROL DEPTH WITHOUT WHEEL		01
02	0501052538	DEPTH BAND WITH ARMS	163	01
03	0503010358	5/16" X 5/8" BOLT		04
04	0503013816	5/16" LOCKNUT		04




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL BOX	162	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0501056435	LEFT CONTROL ARM DEPTH WITHOUT WHEEL		01
02	0501052538	DEPTH BAND WITH ARMS	163	01
03	0503010358	5/16" X 5/8" BOLT		04
04	0503013816	5/16" LOCKNUT		04




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	COVER DEPTH		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012369	BLADE DISC SUPPORT		01
02	0501067323	SPRING REGULATOR		01
03	0521010452	SLEEVE		01
04	0521015376	DUST CLOAK		02
05	0521013510	3/4" NUT		02
06	0503011438	SPRING WASHER		02
07	0503034498	SPRING		01
08	0521067844	RIGHT ARM		01
09	0521067843	LEFT ARM		01
10	0503011255	3/4" LOCK NUT		02
11	0581014407	FLAT WASHER 36.5 X 65.00 X 3.00		01
12	0503030430	7/16 X 2" PIN LOCK		01
13	0503010003	1845 GREASE FITTING		01
14	0501052139	ASSY CUTTING DISK DPL18	163	01
15	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
16	0521062962	BLADE DISC AXLE		01
17	0581014524	SPRING SUPPORT WASHER		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503010060	1/2" NUT		01
20	0503011440	SPRING WASHER		01
21	0503013185	3/4" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502011562	DC BOX		01
02	0503010276	6206 BALL BEARING		02
03	0521013610	BLADE DISC HUB AXLE		01
04	0503030832	FLAT WASHER		02
05	0503012417	SEAL		02
06	0503011800	SEAL RING		02
07	0503010691	1/4" GREASE FITTING		01
08	0603026013	PLAIN COULTER BLADE		01
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0503011444	SPRING WASHER		06
12	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0521062962	BLADE DISC AXLE		01
02	0502012369	BLADE DISC SUPPORT		01
03	0541018684	FLAT WASHER		01
04	0503010361	SPRING PIN		01
05	0503010756	0.2" X 2.4" SPRING PIN		01
06	0503010003	1845 GREASE FITTING		01
07	0521018935	RIGHT ARM OF THE BLADE DISC		01
08	0521018936	LEFT ARM OF THE BLADE DISC		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503016525	3/4" X 6" BOLT		01
12	0503011442	3/4" SPRING WASHER		01
13	0503010014	3/4" NUT		01
14	0502020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0502020394	SPRING SUPPORT		01
17	0503010014	3/4" NUT		02
18	0501054887	20 BLADE DISC WITH FLAT PLAN DISC	165	01
19	0521015376	DUST CLOAK		02
20	0511015346	FLAT WASHER		02
21	0503011438	SPRING WASHER		02
22	0521013510	3/4" NUT		02
23	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
24	0503011411	1/2" X 5-1/2" BOLT		01
25	0503011440	SPRING WASHER		01
26	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	165	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0502011562	DC BOX		01
02	0503010276	6206 BALL BEARING		02
03	0521013610	BLADE DISC HUB AXLE		01
04	0503030832	FLAT WASHER		02
05	0503012417	SEAL		02
06	0503011800	SEAL RING		02
07	0503010691	1/4" GREASE FITTING		01
08	0603027851	20" X 0.2" FLAT PLAIN DISC		01
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0503011444	SPRING WASHER		06
12	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	165	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010365	NUT		02




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	168	01
02	0501052538	DEPTH BAND WITH ARMS	163	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	164	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	166	01
07	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0581014858	DEPTH WHEEL AXLE		01
04	0501110720	ARM LEFT		01
05	0501110719	DEPTH CONTROL RIGHT ARM		01
06	0502012663	EXTENSION		01
07	0503010002	1800 GREASE FITTING		02
08	0501056769	DEPTH WHEELS REGULATOR ASSY	168	01
09	0503034793	ARTICULATION SLEEVE		02
10	0521051423	COMPACTOR SUPPORT	169	01
11	0571017749	FLAT WASHER		02
12	0503010311	1/2" X 1-1/4" BOLT		02
13	0503016453	1/2" X 2.1/2 BOLT		02
14	0503034817	SPRING		01
15	0503010581	RING		01
16	0503034377	SCREWEW 3/8 UNC X 3/4		01
17	0503010019	1/2" SPRING WASHER		08
18	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
19	0503010060	1/2" NUT		04
20	0501052908	COMPACTOR WHEEL WITH BEARING	165	02
21	0503013739	1/2" X 1" BOLT		01
22	0511050077	WHEEL STRIPED	170	02
23	0503010752	1/2" X 3.1/2" BOLT		01



Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	SEED SIST CONTROL DEPTH LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	169	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	160	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	161	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	SCREWEW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL BOX	162	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01

COMPACTOR SUPPORT


0521051423




Item	Code	Description	See page	QT
01	0521068003	RIGHT SIDE		01
02	0521068002	LEFT SIDE		01
03	0581014847	PLATE UPPER		01
04	0581015855	SLEEVE		02
05	0521068004	HANDLE BODY		01
06	0581014969	SLEEVE GUIDE		01
07	0581014968	SLEEVE FLANGE		01
08	0503010937	5/16" X 3" BOLT		02
09	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
10	0521068005	LEVER		01
11	0503010179	5/16" ZN SPRING WASHER		04
12	0503010337	5/16" NUT		04
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2" NUT		01
15	0503010847	1/2" X 3.1/4" BOLT		01
16	0503010882	BOLT		02
17	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
18	0503030878	LEVER CRANK		01
19	0581015854	RIGHT PROTECTION COVER		01
20	0581015853	LEFT PROTECTION COVER		01
21	0581015903	SPACER WASHER		01



Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY		01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	5/16" ZN SPRING WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0511052971	CONTROL DEPTH WITH SEMI MOUNTED THREAD	172	01
02	0511052970	SYSTEM COMPACTOR V SEMI MOUNTED		01
03	0501052908	COMPACTOR WHEEL WITH BEARING	165	02
04	0503010019	1/2" SPRING WASHER		06
05	0503010752	1/2" X 3.1/2" BOLT		01
06	0503013739	1/2" X 1" BOLT		01
07	0503010479	BOLT		02
08	0503010060	1/2" NUT		04
09	0503030012	HAIR PIN		01
10	0571013222	FIXING CHOCK		01
11	0503010741	1/2" X 2-3/4" BOLT		02
12	0511055819	DEPTH WHIT AROS BAND	178	02
13	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
14	0503013816	5/16" LOCKNUT		08




Item	Code	Description	See page	QT
01	0521063808	DEPTH CONTROL INNER COLUMN CONTROL WITH SCREW		01
02	0521063809	DEPTH CONTROL EXTERNAL COLUMN CONTROL WITH SCREW		01
03	0571013194	REGULATOR SPINDLE		01
04	0551010616	ROD HEX		01
05	0503010683	0,2" X 1,2" SPRING PIN		01
06	0571013202	REGULATOR AXLE WHEELS COBRIDORA		01
07	0521063812	REGULATOR LEVER ALXE		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		01
09	0511065308	LOCK REGULATOR		01
10	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
11	0541011627	FLAT WASHER		01
12	0503010140	1/8" X 3/4" COTTERPIN		01
13	0511059325	LEFT ARM WHEELS	173	01
14	0511059324	RIGHT ARM COATING WHEEL MOUNTED	174	01
15	0571014709	SLEEVE LOCK CONTROL ARM		02
16	0503011440	SPRING WASHER		03
17	0503819099	BOLT		02
18	0511051546	CUBE RIGHT CONTROL DEPTH	175	01
19	0511051547	LEFT CUBE CONTROL DEPTH	176	01
20	0503011442	3/4" SPRING WASHER		02
21	0571013189	SLEEVE SUPPORT BEATER		01
22	0521063813	WHEEL PRESS BEATER		01
23	0501010937	13.5 X 28 X 3 FLAT WASHER		01
24	0503010920	1/2" X 1.1/2" BOLT		01

LEFT ARM WHEELS


0511059325




Item	Code	Description	See page	QT
01	0502012844	LEFT ARM WHEELS		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	GLOVE SUPPORT ARM WHEEL COBRIDORA		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012843	RIGHT WHEEL ARM		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	GLOVE SUPPORT ARM WHEEL COBRIDORA		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511051583	DEPTH WHEEL HUB SEMIFINISHED	177	01
02	0511066638	AXLE WHEEL RIGHT DEPTH WITH DOOR DUST		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	COVER DEPTH		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0511051583	DEPTH WHEEL HUB SEMIFINISHED	177	01
02	0511066637	AXLE WHEEL LEFT DEPTH WITH DOOR DUST		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	COVER DEPTH		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03



Item	Code	Description	See page	QT
01	0502011907	DEPTH CONTROL WHEEL HUB		01
02	0503010269	6204 BALL BEARING		02
03	0501013636	SPACING SLEEVE		01
04	0503010689	SEAL 00763-BR		01
05	0503011105	SEAL RING		01
06	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503013758	1/4" X 1-1/2" BOLT		05
04	0503013814	1/4" NC LOCKNUT		05



Item	Code	Description	See page	QT
01	0511055326	DEPTH CONTROL PRESS WHEEL ASSY	180	01
02	0551019650	SLEEVE 13,20 X 25 X 74		01
03	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0511055327	COMPACTING WHEEL V ASSY RUBBER	185	01

DEPTH CONTROL PRESS WHEEL ASSY


0511055326




Item	Code	Description	See page	QT
01	0502012758	DEPTH CONTROL SUPPORT		01
02	0503010585	0,24" X 1.18" SPRING PIN		02
03	0503010002	1800 GREASE FITTING		01
04	0501059228	ADJUSTMENT LEVER	184	01
05	0502012611	DEPTH CONTROL AXLE		01
06	0571015326	ARTICULATION SLEEVE HANDLE		01
07	0501010984	FLAT WASHER		01
08	0503011443	3/8" SPRING WASHER		01
09	0503010237	3/8" X 1" BOLT		01
10	0571016132	PIVOT SHAFT		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0561014336	PIVOT SHAFT		01
13	0503010071	3/16" X 1" COTTERPIN		02
14	0511055328	DEPTH WHEEL SYSTEM	181	01
15	0511055329	LEFT DEPTH WHEEL	183	01

DEPTH WHEEL SYSTEM

0511055328




Item	Code	Description	See page	QT
01	0561014385	CARRYING-WHEELS PIVOT SHAFT		01
02	0501110777	RIGHT WHEEL ARM		01
03	0503010019	1/2" SPRING WASHER		01
04	0511055627	WHEEL ASSY RAYED	182	01
05	0503016453	1/2" X 2.1/2 BOLT		01
06	0503010060	1/2" NUT		01
07	0503010002	1800 GREASE FITTING		01
08	0503030012	HAIR PIN		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER		01
11	0501011445	FLAT WASHER		03
12	0571015974	WASHER		01
13	0503012412	5/8 UNC SELF LOCKING NUT		01
14	0503011440	SPRING WASHER		01



Item	Code	Description	See page	QT
01	0511055626	BOX ROUND DEPTH ROYAL WITH SPA	188	01
02	0551019904	PRESS WHEEL RIM		02
03	0503030891	RUBBER BAND		01
04	0503010365	NUT		06
05	0503010179	5/16" ZN SPRING WASHER		06
06	0503010337	5/16" NUT		06

LEFT DEPTH WHEEL


0511055329



Item	Code	Description	See page	QT
01	0571015973	CARRYING-WHEELS PIVOT SHAFT		01
02	0503010019	1/2" SPRING WASHER		01
03	0511055627	WHEEL ASSY RAYED	182	01
04	0503016453	1/2" X 2.1/2 BOLT		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01
07	0503030012	HAIR PIN		01
08	0501110776	ARM,LEFT		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER		01
11	0501011445	FLAT WASHER		03
12	0571015974	WASHER		01
13	0503012412	5/8 UNC SELF LOCKING NUT		01
14	0503011440	SPRING WASHER		01

ADJUSTMENT LEVER


0501059228




Item	Code	Description	See page	QT
01	0502012603	ADJUSTMENT LEVER		01
02	0502011689	1/8" DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0511015976	FLAT WASHER		01
05	0503010140	1/8" X 3/4" COTTERPIN		01

COMPACTING WHEEL V ASSY RUBBER

0511055327




Item	Code	Description	See page	QT
01	0571015324	COMPACT WHEEL RIGHT ARM		01
02	0571015325	LH ARM PRESS WHEELS		01
03	0541012145	SLEEV 13,5 X 25 X 18		02
04	0501058362	LARGER HANDLE ASSY		01
04A	0502011689	1/8" DEPTH CONTROL LEVER		01
04B	0521064892	REGULACION SPRING COMPACTOR		01
04C	0541012146	0.53" X 0.74" X 0.33" SLEEVE		01
04D	0503030174	COMPRESSION SPRING		01
04E	0541012143	FLAT WASHER		01
04F	0503010257	1/8" X 1" COTTERPIN		01
05	0503010479	BOLT		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0503031393	1.57" X 5.98" X 0.2"TRACTION SPRING		01
09	0501055289	HANDLE SMALLER ASSY		01
09A	0511065451	PRESS WHEEL ADJUSTER		01
09B	0511065496	PRESS WHEEL FIXER		01
09C	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
09D	0541012143	FLAT WASHER		01
09E	0503010257	1/8" X 1" COTTERPIN		01
10	0503010397	5/16" X 1-3/4" BOLT		02
11	0541012144	8,50 X 16 X 21 SLEEVE		02
12	0503011444	SPRING WASHER		02
13	0503010337	5/16" NUT		02
14	0501052908	COMPACTOR WHEEL WITH BEARING	165	02
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503013739	1/2" X 1" BOLT		01
17	0503011440	SPRING WASHER		02




Item	Code	Description	See page	QT
01	0511055690	WHEEL SISTEM	187	01
02	0551019650	SLEEVE 13,20 X 25 X 74		01
03	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0511055327	COMPACTING WHEEL V ASSY RUBBER	185	01

WHEEL SISTEM

0511055690




Item	Code	Description	See page	QT
01	0502012758	DEPTH CONTROL SUPPORT		01
02	0503010585	0,24" X 1.18" SPRING PIN		02
03	0503010002	1800 GREASE FITTING		01
04	0501059228	ADJUSTMENT LEVER	184	01
05	0502012611	DEPTH CONTROL AXLE		01
06	0571015326	ARTICULATION SLEEVE HANDLE		01
07	0501010984	FLAT WASHER		01
08	0503011443	3/8" SPRING WASHER		01
09	0503010237	3/8" X 1" BOLT		01
10	0571016132	PIVOT SHAFT		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0561014336	PIVOT SHAFT		01
13	0503010071	3/16" X 1" COTTERPIN		02
14	0511055628	DEPTH WHEEL SYSTEM		01
15	0511055629	DEPTH WHEEL SYSTEM	189	01




Item	Code	Description	See page	QT
01	0503010269	6204 BALL BEARING		02
02	0502012607	STRIPED BOX WHEEL DEPTH		01
03	0503010689	SEAL 00763-BR		01
04	0501013636	SPACING SLEEVE		01
05	0503011105	SEAL RING		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0521019178	COVER DEPTH		01
08	0503013758	1/4" X 1-1/2" BOLT		03
09	0503011441	SPRING WASHER		03
10	0521063443	DEPTH CONTROL AXLE		01
11	0503010811	5/8" UNF SELF ADJUSTING NUT		01
12	0503010691	1/4" GREASE FITTING		01

DEPTH WHEEL SYSTEM

0511055629



Item	Code	Description	See page	QT
01	0571015973	CARRYING-WHEELS PIVOT SHAFT		01
02	0503010019	1/2" SPRING WASHER		01
03	0511055627	WHEEL ASSY RAYED	182	01
04	0503016453	1/2" X 2.1/2 BOLT		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01
07	0503030012	HAIR PIN		01
08	0501110776	ARM,LEFT		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER		01
11	0501011445	FLAT WASHER		03
12	0503012412	5/8 UNC SELF LOCKING NUT		01
13	0503011440	SPRING WASHER		01



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

