

ROW CROP PLANTERS

PST4 FLEX - FRAME 4045/4495/4845/5345 - CSU (UP TO 03/2022)

Code: 0501092230
Series: S-0116
Revision: 00
Date Revision: NOVEMBRO/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS

Code	Description
0111280360	PST4 FLEX 4045/8E500 H CI DC20 CSU S-0116
0111280442	PST4 FLEX 4045/9E450 CI DC20 CSU S-0116
0111280411	PST4 FLEX 4045/9E450 CI MH DC20 CSU S-0116
0111280463	PST4 FLEX 4045/9E450 CPERA D DC20 CSU S-0116
0111280271	PST4 FLEX 4045/9E450 CSU S-0116
0111280394	PST4 FLEX 4045/9E450 D/HDA BC DC20 CSU S-0116
0111280323	PST4 FLEX 4045/9E450 D/HDA P.1 MH CSU S-0116
0111280347	PST4 FLEX 4045/9E450 MH CSU S-0116
0111280466	PST4 FLEX 4495/10E450 CI MH CSU S-0116
0111280448	PST4 FLEX 4495/9E500 CI MH DC20 CSU S-0116
0111280330	PST4 FLEX 4495/9E500 D/HDA MH CSU S-0116
0111280435	PST4 FLEX 4495/9E500 SPACRRA CI DC20 CSU S-0116
0111280496	PST4 FLEX 4845/10E500 ESPECIAL S-0116
0111280458	PST4 FLEX 4845/10E500 H CI MH DC20 CSU S-0116
0111280367	PST4 FLEX 4845/11E450 CI MH DC20 CSU S-0116
0111280481	PST4 FLEX 4845/11E450 DAOC MH DC20 CSU S-0116
0111280328	PST4 FLEX 4845/11E450 MH CSU S-0116
0111280450	PST4 FLEX 5345/11E500 H CI MH DC20 CSU S-0116
0111280482	PST4 FLEX 5345/11E500 SPCRR D/HF MH DC20 CSU S0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909099179	4045/4495 - ASSY FRAME	1
0909091891	FRAME ASSY - 4845/5345	2
0501058195	FRAME WITH AXLE WHEEL - 4045	3
0511050836	WHEEL AXLE FRAME - 4495	4
0501058196	WHEEL AXLE FRAME - 4845	5
0511051118	WHEEL AXLE FRAME - 5345	6
0511059265	WHEELED WITH SPRING TRACTION WITH TRANSMISSION	7
0511059262	WHEEL SUPPORT ASSY	8
0501058241	WHEEL SUPPORT CHAIN TENSIONER	9
0501058240	WHEEL FASTENER WITH TENSIONER	10
0511052770	WHEEL WITH TIRE	11
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	12
0511058599	RIGHT TRANSMISSION ASSY - 4045	13
0511058592	RIGHT TRANSMISSION ASSY - 4495	14
0511056751	RIGHT TRANSMISSION ASSY - 4880	15
0511058310	RIGHT TRANSMISSION ASSY - 5345	16
0501052560	MOTOR AXLE SIGNAL	17
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	18
0521043316	RIGHT GEAR BOX ASSY	19
0501058212	SEMI MOUNTED RIGHT CHANGE	20
0511054363	CHAIN TENSIONER	21
0501058265	STRETCHER LOWER CURRENT 21Z SEED	22
0501058254	UPPER SEED CHAIN TENSIONER	23
0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	24
0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	25
0501055112	MICRO GRANULATED CHAIN TENSIONER	26
0511058600	LEFT TRANSMISSION ASSY - 4045	27
0511058593	LEFT TRANSMISSION ASSY - 4495	28
0511056752	LEFT TRANSMISSION ASSY - 4880	29
0511058309	LEFT TRANSMISSION ASSY - 5345	30
0521043317	LEFT GEAR BOX ASSY	31
0501058213	LH GEAR BOX	32
0511059266	CLOSED BEARING	33
0501056271	GEARBOX CLOSED BEARING	34
0501056443	GEAR HOUSING BEARING	35
0501056444	BEARING WITH ROLLING	36
0501054655	CHAIN TENSIONER ASSY	37
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	38
0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	39
0511050838	SEMI-ASSEMBLED HYDRAULIC MARKER 4495	40
0501058172	SEMI-ASSEMBLED HYDRAULIC MARKER 4845/11	41
0511051119	SEMI-ASSEMBLED HYDRAULIC MARKER 5345	42
0511058449	HYDRAULIC CYLINDER	43
0501050633	ROW MARKER DISK ASSEMBLY	44
0511053904	ROW MARKER DISC	45
0511057129	PLATFORM ASSY - 4045	46
0511057565	PLATFORM ASSY - 4495	47
0511057650	PLATFORM ASSY - 4845	48
0511058312	PLATFORM ASSY - 5345	49
0511057130	HANDRAIL ASSY - 4045	50
0511057566	HANDRAIL ASSY - 4495	51
0511057651	HANDRAIL ASSY - 4845	52
0511058308	HANDRAIL ASSY - 5345	53
0511057142	ASSY HEADER - 3245/3695/4045/4495	54
0511057150	HEADER ASSEMBLY - 4845/5345	55



MARCHESAN

INDEX

0511057151	ASSY DOOR HAND BOOK	56
0511057401	LABEL ASSY FOR HYDRAULIC MARKER 4045	57
0511059211	LABEL ASSY 4045	58
0511058302	LABEL ASSY FOR HYDRAULIC MARKER 4495	59
0511057149	HYDRAULIC MARKER LABEL ASSY 4845	60
0511058313	HYDRAULIC MARKER LABEL ASSY 5345	61
0511056529	CYLINDER ASSY	62
0511057124	CYLINDER ASSY	63
0511053179	TRACTOR COUPLING SHAFT	64
0511058406	HYDRAULIC CYLINDER	65
0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	66
0511056536	LADDER ASSEMBLY	67
0511054971	JACK ASSEMBLY	68
0501054258	DRAWBAR ESTABILIZER ASSY	69
0511054601	HITCH ARTICULATED TRACTOR	70
0511057146	HYDRAULIC SYSTEM ASSY - 4845/5345	71
0501053834	MALE QUICK COUPLER	72
0511057235	SET SUPPORT RIGHT LEFT	73
0511057128	SET SUPPORT RIGHT LEFT	74
0511057564	SET SUPPORT RIGHT LEFT	75
0511057147	ASSEMBLY SUPPORT RIGHT/LEFT BOX FERTILIZER	76
0511058311	RIGHT / LEFT SUPPORT BOX ASSEMBLY ASSY 12	77
0511051120	RIGHT BEAM SUPPORT WITH DISTRIBUTOR 12	78
0511051121	LEFT BEAM SUPPORT WITH DISTRIBUTOR 12	79
0501058206	RIGHT SILO SUPPORT WITH DISTRIBUTOR 11	80
0501058207	LEFT SILO SUPPORT WITH DISTRIBUTOR 11	81
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	82
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	83
0501053788	3/4 SQUARE AXLE FASTENER	84
0511056338	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 1"	85
0511056339	DISTRIBUTOR FERTILIZER SIDE RIGHT STEP 1"	86
0511056392	PLANTING MONITORING ASSY 09L SEED AND FERTILIZER	87
0521053446	MONITORING ASSEMBLY PLANTING SEEDS 10L PM400	88
0909094140	COMPLETE SEED LINE	89
0501059834	FRONT LINE SEED SHORT LEFT CARDAN	90
0501059833	FRONT LINE SEED SHORT RIGHT CARDAN	91
0501059835	FRONT LINE SEED LONG RIGHT CARDAN	92
0501059836	FRONT LINE SEED LONG LEFT CARDAN	93
0511054884	TRANSMISSION BOX	94
0511059264	BEARING WITH AXLE	95
0511056621	REAR RIGHT SEED LINE	96
0511056622	LEFT REAR LINE SEED	97
0511056628	REAR RIGHT	98
0511056629	LEFT REAR	99
0511056625	RIGHT REAR LINE SEED PM 100	100
0511056626	LEFT REAR LINE SEED PM100	101
0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	102
0511056586	15 X 15 SEED DDD LEFT	103
0511053173	CUBE LOW RIGHT WITH DISC 15	104
0511053172	LEFT LOW CUBE WITH DISC 15	105
0511057017	SEED SYSTEM ASSY	106
0511059023	SEED SYSTEM ASSY	107
0501051094	ASSY SEED DISTRIBUTOR	108
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	109
0511058650	SEMI-MOUNTED DEPTH CONTROL	110



MARCHESAN

INDEX


0501052297	DEPTH WHEELS REGULATOR ASSY	111
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	112
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	113
0501052627	ASSY DEPTH WHEEL BOX	114
0521042327	DEPTH CONTROL & PRESS WHEEL ASSY	115
0511053550	DEPTH CONTROL ASSY	116
0511050077	WHEEL STRIPED	117
0511052287	DEPTH WHEEL HUB ASSY	118
0521045198	PRESS WHEELS	119
0521044460	SYSTEM DEPTH / COMPACTOR	120
0511055690	WHEEL SYSTEM	121
0501059228	ADJUSTMENT LEVER	122
0511055628	DEPTH WHEEL SYSTEM	123
0511055629	DEPTH WHEEL SYSTEM	124
0511055327	COMPACTING WHEEL V ASSY RUBBER	125
0501052908	COMPACTOR WHEEL WITH BEARING	126
0521044269	PRESS WHEELS/DEPTH ASSY	127
0511055326	DEPTH CONTROL PRESS WHEEL ASSY	128
0511055328	DEPTH WHEEL SYSTEM	129
0511055329	LEFT DEPTH WHEEL	130
0511059462	DEPTH CONTROL WITH FAST ADJUSTMENT	131
0521046501	DEPTH CONTROL AND PRESS WHEEL WITH FAST ADJUSTING	132
0521044538	DEPTH WHIT REGULACION ANGLE COMPACT CONTROL	133
0511052971	SEMI-ASSEMBLED DEPTH CONTROL WITH THREAD	134
0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	135
0511055819	DEPTH WHIT AROS BAND	136
0511059325	LEFT ARM COVERED WHEEL ASSEMBLED	137
0511059324	RIGHT ARM COVERED WHEEL ASSEMBLED	138
0511051546	CUBE RIGHT CONTROL DEPTH	139
0511051547	LEFT CUBE CONTROL DEPTH	140
0511054835	HDA	141
0511058935	ROD WITH POINT FLANGE WASHER SPRING HDA	142
0511052024	FAST CLOSING SET	143
0521041006	COVERING WHEEL ASSY FERTILIZER RIGHT IRON	144
0521041007	COVERING WHEEL ASSY FERTILIZER LEFT IRON	145
0501054292	V RIGHT WHEEL PRESS FERTILIZER ASSY	146
0501054293	V LEFT WHEEL PRESS FERTILIZER ASSY	147
0521052836	WHEEL SYSTEM DEPTH/COMPACTOR	148
0521052831	DEPTH WHEEL SYSTEM	149
0521052825	SUPPORT WHEELS COMPACTORS	150
0501050120	LARGER WALKING BEAM ASSY	151
0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	152
0511044585	20" COULTER BLADE ASSY FOR LONG ROW	153
0501054887	20 BLADE DISC WITH FLAT PLAN DISC	154
0511045593	DC 20 ASSY SHORT	155
0511045594	ASSY LONG DC 20	156
0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	157
0511044573	18" COULTER BLADE ASSY FOR LONG ROW	158
0511047378	FULL DC DPLO 18 CT	159
0511047379	FULL DC DPLO 18 LG	160
0501055267	"V" RIGHT WHEEL PRESS FERTILIZER ASSY	161
0501055268	"V" LEFT WHEEL PRESS FERTILIZER ASSY	162
0501058423	FERTILIZER ROD SPRING ROW	163
0521050525	FIXER FERTILIZER CONDUCTOR	164



MARCHESAN


INDEX

0909091900	FERTILIZER LINE WITH DDD ROD		165
0909092327	FERTILIZER LINE WITH STEM		166
0909092330	FERTILIZER LINE WITH STEM		167
0909091899	FERTILIZER ROW WITH DDD & 18"/20" COULTER BLADE		168
0511058101	ASSEMBLY CSU C3 SEMI MOUNTED 4045/4495		169
0511057918	CSU C3 SEMI-ASSEMBLED ASSY 4845/5345		170
0511057736	CSU C3 SEMI-ASSEMBLED ASSY 4845/10		171
0521050490	2 BOXES WITH 7 CONDUCTORS ASSEMBLY		172
0511058100	2 BOXES WITH 9 CONDUCTORS ASSEMBLY		173
0511057919	2 BOXES WITH 11 CONDUCTORS ASSEMBLY		174
0511057737	2 BOXES WITH 10 CONDUCTORS ASSEMBLY		175
0511055088	SEED TUBE ASSY WITH 2 ADJUSTING POSITION		176
0511057690	3" ARTICULATED SEED CONDUCTOR		177
0521051927	TOWER SUPPORT HOPPER		178
0521052687	RH SUPPORT TOWER SILO		179
0521051931	LH SUPPORT TOWER SILO		180
0501054649	HBM SEQUENTIAL VALVE		181
0511059221	DAOC 18 LEFT WITH NOZZLE		182
0511059220	DAOC 18 RIGHT WITH NOZZLE		183
0511059219	LEFT SUPPORT		184
0511059218	RIGHT SUPPORT		185
0511059230	BOX WITH DOC 18 TURBO LEFT		186
0511059229	BOX WITH DOC 18 TURBO RIGHT		187
0521050168	MOUNTED FERTILIZER CONDUCTOR		188
0909094592	HEX AXLE ASSEMBLY		189
0909096062	HEX AXLE ASSEMBLY		190




Item	Code	Description	See page	4045	4495
01	0501058195	FRAME WITH AXLE WHEEL - 4045	3	01	00
01.	0511050836	WHEEL AXLE FRAME - 4495	4	00	01
02	0503010003	1845 GREASE FITTING		04	04
03	0511057124	CYLINDER ASSY	63	01	01
04	0511059265	WHEELED WITH SPRING TRACTION WITH 7 TRANSMISSION		02	02
05	0511058599	RIGHT TRANSMISSION ASSY - 4045	13	01	00
05.	0511058592	RIGHT TRANSMISSION ASSY - 4495	14	00	01
06	0511058600	LEFT TRANSMISSION ASSY - 4045	27	01	00
06.	0511058593	LEFT TRANSMISSION ASSY - 4495	28	00	01
07	0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	39	01	01
08	0511050838	SEMI-ASSEMBLED HYDRAULIC MARKER 4495	40	00	01
09	0501050633	ROW MARKER DISK ASSEMBLY	44	02	02
10	0511057128	SET SUPPORT RIGHT LEFT	74	01	00
10.	0511057564	SET SUPPORT RIGHT LEFT	75	00	01
11	0511057129	PLATFORM ASSY - 4045	46	01	00
11.	0511057565	PLATFORM ASSY - 4495	47	00	01
12	0511057130	HANDRAIL ASSY - 4045	50	01	00
12.	0511057566	HANDRAIL ASSY - 4495	51	00	01
13	0511056536	LADDER ASSEMBLY	67	02	02
14	0511054971	JACK ASSEMBLY	68	02	02
15	0511057142	ASSY HEADER - 3245/3695/4045/4495	54	01	01
16	0511057151	ASSY DOOR HAND BOOK	56	01	01
17	0511057401	LABEL ASSY FOR HYDRAULIC MARKER 4045	57	01	00
17.	0511059211	LABEL ASSY 4045	58	01	01
17..	0511058302	LABEL ASSY FOR HYDRAULIC MARKER 4495	59	00	01
18	0909099112	HEX AXLE ASSEMBLY		01	01
19	0501065677	STRUT		02	02
20	0501054258	DRAWBAR ESTABILIZER ASSY	69	01	01
21	0511054601	HITCH ARTICULATED TRACTOR	70	01	01
22	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01	01
23	0511053179	TRACTOR COUPLING SHAFT	64	02	02

Item	Code	Description	See page	4045	4495
24	0521013022	TRANSPORT LOCK		01	01
25	0501068994	0.3" X 3.1" LOCK PIN		01	01
26	0503030168	CUPILLA		01	01
27	0503014120	CHAIN		01	01
28	0503014321	CABLE STEEL SHACKLE		01	01
29	0511056736	HOSE SUPPORT		01	01
30	0501047895	ROD STOP		01	01
31	0501047885	ROD STOP		01	01
32	0501047886	ROD STOP		01	01
33	0501047887	ROD STOP		01	01
34	0503032624	SILO FERTILIZER GUTTER		05	06
35	0503010780	N-2050 AMENDMENT		02	02
36	0503011750	AMENDMENT WITH LOCK		06	06
37	0503010951	REDUCTION		04	04
38	0503011751	REDUCTION		06	06
39	0503010246	CLAMP		09	09
40	0511058368	EAR MOVABLE		02	02
41	0511056392	PLANTING MONITORING ASSY 09L SEED AND 87 FERTILIZER		01	01
42	0511066652	400 TURNBUCKLE		02	02
43	0571013314	GUTTER 25 X 58 X 1500		02	02
44	0571017368	SUPPORT GUTTER		04	04
45	0501011643	3/8 X 1" BOLT		04	04
46	0501010984	FLAT WASHER		04	04
47	0503010025	3/8" SPRING WASHER		04	04
48	0503010026	3/8" NUT		04	04
49	0511059792	CSU C3 SEMI-ASSEMBLED ASSY 4045/4495 8		01	01
50	0511058101	ASSEMBLY CSU C3 SEMI MOUNTED 4045/4495	169	01	01
51	0909094140	COMPLETE SEED LINE	89	01	01




Item	Code	Description	See page	4845	5345
01	0501058196	WHEEL AXLE FRAME - 4845	5	01	00
01.	0511051118	WHEEL AXLE FRAME - 5345	6	00	01
02	0503010003	1845 GREASE FITTING		04	04
03	0511056529	CYLINDER ASSY	62	01	01
04	0511059265	WHEELED WITH SPRING TRACTION WITH 7 TRANSMISSION		02	02
05	0511056751	RIGHT TRANSMISSION ASSY - 4880	15	01	00
05.	0511058310	RIGHT TRANSMISSION ASSY - 5345	16	00	01
06	0511056752	LEFT TRANSMISSION ASSY - 4880	29	01	00
06.	0511058309	LEFT TRANSMISSION ASSY - 5345	30	00	01
07	0511057146	HYDRAULIC SYSTEM ASSY - 4845/5345	71	01	01
08	0501058172	SEMI-ASSEMBLED HYDRAULIC MARKER 4845/11	41	01	00
08.	0511051119	SEMI-ASSEMBLED HYDRAULIC MARKER 5345	42	00	01
09	0501050633	ROW MARKER DISK ASSEMBLY	44	02	02
10	0511057147	ASSEMBLY SUPPORT RIGHT/LEFT BOX FERTILIZER	76	01	00
10.	0511058311	RIGHT / LEFT SUPPORT BOX ASSEMBLY ASSY 12	77	00	01
11	0511057650	PLATFORM ASSY - 4845	48	01	00
11.	0511058312	PLATFORM ASSY - 5345	49	00	01
12	0511057651	HANDRAIL ASSY - 4845	52	01	00
12.	0511058308	HANDRAIL ASSY - 5345	53	00	01
13	0511056536	LADDER ASSEMBLY	67	02	02
14	0511054971	JACK ASSEMBLY	68	02	02
15	0511057150	HEADER ASSEMBLY - 4845/5345	55	01	01
16	0511057151	ASSY DOOR HAND BOOK	56	01	01
17	0511057149	HYDRAULIC MARKER LABEL ASSY 4845	60	01	00
17.	0511058313	HYDRAULIC MARKER LABEL ASSY 5345	61	00	01
18	0909099112	HEX AXLE ASSEMBLY		01	01
19	0501065677	STRUT		02	02
20	0501054258	DRAWBAR ESTABILIZER ASSY	69	01	01
21	0511054601	HITCH ARTICULATED TRACTOR	70	01	01
22	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01	01


Item	Code	Description	See page	4845	5345
23	0511053179	TRACTOR COUPLING SHAFT	64	02	02
24	0521013022	TRANSPORT LOCK		01	01
25	0501068994	0.3" X 3.1" LOCK PIN		01	01
26	0503030168	CUPILLA		01	01
27	0503014120	CHAIN		01	01
28	0503014321	CABLE STEEL SHACKLE		01	01
29	0511056736	HOSE SUPPORT		01	01
30	0501047895	ROD STOP		01	01
31	0501047885	ROD STOP		01	01
32	0501047886	ROD STOP		01	01
33	0501047887	ROD STOP		01	01
34	0503032624	SILO FERTILIZER GUTTER		04	04
35	0503010780	N-2050 AMENDMENT		02	02
36	0503011750	AMENDMENT WITH LOCK		06	06
37	0503010951	REDUCTION		04	04
38	0503011751	REDUCTION		06	06
39	0503010246	CLAMP		09	09
40	0511058368	EAR MOVABLE		02	02
41	0511056392	PLANTING MONITORING ASSY 09L SEED AND 87 FERTILIZER		01	01
41.	0521053446	MONITORING ASSEMBLY PLANTING SEEDS 10L 88 PM400		01	00
42	0511066652	400 TURNBUCKLE		02	02
43	0571013314	GUTTER 25 X 58 X 1500		02	02
43.	0591019959	GUTTER		01	00
43..	0591019960	GUTTER		01	00
44	0571017368	SUPPORT GUTTER		04	04
45	0501011643	3/8 X 1" BOLT		04	04
46	0501010984	FLAT WASHER		04	04
47	0503010025	3/8" SPRING WASHER		04	04
48	0503010026	3/8" NUT		04	04
49	0503010060	1/2" NUT		08	08
50	0511057918	CSU C3 SEMI-ASSEMBLED ASSY 4845/5345	170	01	01
50.	0511057736	CSU C3 SEMI-ASSEMBLED ASSY 4845/10	171	01	00
51	0521013164	EXTENSOR		02	02
52	0501011310	FIXER LOCK		08	08
53	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		08	08
54	0503010019	1/2" SPRING WASHER		08	08
55	0909099117	ASSY FERTILIZER/SEED LINE		01	01




Item	Code	Description	See page	QT
01	0511069529	FRAME		01
02	0511069682	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0521062243	FRAME		01
02	0521062242	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0511069616	FRAME		01
02	0511069717	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8" X 2-1/4" BOLT		12
05	0501012140	FLAT WASHER		24
06	0531013922	0.6" X 0.8" X 1" SLEEVE		12
07	0503011445	SPRING WASHER		12
08	0503010013	5/8" NUT		12




Item	Code	Description	See page	QT
01	0521062442	FRAME		01
02	0521062447	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8" X 2-1/4" BOLT		12
05	0501012140	FLAT WASHER		24
06	0531013922	0.6" X 0.8" X 1" SLEEVE		12
07	0503011445	SPRING WASHER		12
08	0503010013	5/8" NUT		12




Item	Code	Description	See page	QT
01	0511059262	WHEEL SUPPORT ASSY	8	01
02	0501058240	WHEEL FASTENER WITH TENSIONER	10	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0531062422	WHEEL ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0501058241	WHEEL SUPPORT CHAIN TENSIONER	9	01
07	0511052770	WHEEL WITH TIRE	11	01
08	0503018981	BOLT		02
09	0503010027	5/8" SPRING WASHER		04
10	0591010589	BODY LOCK WHEEL		01
11	0521069983	WHEEL COVER		01
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
13	0551017715	FLAT WASHER		02
14	0503013030	5/8" X 3.1/4" BOLT		01
15	0511050681	TRACTION SPRING		01
15A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
15B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER		01
07	0501058244	WHEEL FIXED CHAIN TENSIONER		01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER		01



Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE		01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	12	01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSM AXLE CARRYING-WHEEL		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016881	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	17	01
15	0511051434	TRANSMISSION ACTUATOR		02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	18	01
17	0521043316	RIGHT GEAR BOX ASSY	19	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521064448	GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	FLAT WASHER		01
28	0503010025	3/8" SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	21	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	22	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	23	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	24	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	25	01
35	0501055112	MICRO GRANULATED CHAIN TENSIONER	26	01
36	0503012204	40-1 CHAIN X 82 LINK + RED		01
37	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
38	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
39	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561018351	2155 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	17	01
15	0511051434	TRANSMISSION ACTUATOR		02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	18	01
17	0521043316	RIGHT GEAR BOX ASSY	19	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2" X 1.1/2" BOLT		02
20	0511017302	FLAT WASHER		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2" NUT		02
24	0521064448	GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	FLAT WASHER		01
28	0503010025	3/8" SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	21	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	22	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	23	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	24	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	25	01
35	0501055112	MICRO GRANULATED CHAIN TENSIONER	26	01
36	0503012204	40-1 CHAIN X 82 LINK + RED		01
37	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
38	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
39	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	17	01
15	0511051434	TRANSMISSION ACTUATOR		02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	18	01
17	0521043316	RIGHT GEAR BOX ASSY	19	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2" X 1.1/2" BOLT		02
20	0511017302	FLAT WASHER		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2" NUT		02
24	0521064448	GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	FLAT WASHER		01
28	0503010025	3/8" SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	21	01
31	0521055217	LOWER CURRENT STRETCH		01


Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	23	01
33	0521055216	BEARING WITH GEAR		01
34	0521055218	BEARING GEAR WITH DOUBLE		01
35	0501055112	MICRO GRANULATED CHAIN TENSIONER	26	01
36	0503012204	40-1 CHAIN X 82 LINK + RED		01
37	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
38	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
39	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0511051434	TRANSMISSION ACTUATOR		02
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0503010300	5/32" X 1" COTTERPIN		04
06	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
07	0511017302	FLAT WASHER		08
08	0503010019	1/2" SPRING WASHER		09
09	0503010060	1/2" NUT		11
10	0501018466	FLAT WASHER		03
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0501052560	MOTOR AXLE SIGNAL	17	01
14	0511059261	CHAIN TENSIONER		01
15	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
16	0503014734	BOLT		03
17	0521064448	GEAR		01
18	0501058265	STRETCHER LOWER CURRENT 21Z SEED	22	01
19	0501058254	UPPER SEED CHAIN TENSIONER	23	01
20	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	24	01
21	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	25	01
22	0501055112	MICRO GRANULATED CHAIN TENSIONER	26	01
23	0503014907	40-1 X 151 CHAIN LINK + MENDING		01
24	0561019204	MOTOR SHAFT		01
25	0503012204	40-1 CHAIN X 82 LINK + RED		01
26	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
27	0521043316	RIGHT GEAR BOX ASSY	19	01
28	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	18	01
29	0503010920	1/2" X 1.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER	01	
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
03	0503010060	1/2" NUT	01	
04	0521017590	GUIDE AXLE	01	
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING	01	
06	0502012009	DRIVING AXLE RIGHT FOLLOWER	01	
07	0501019734	FLAT WASHER	02	
08	0502010710	RIGHT CAM, SMALLER	02	
09	0503010003	1845 GREASE FITTING	02	
10	0502012539	26Z P12,7 GEAR	01	
11	0501019735	FLAT WASHER	01	
12	0521017593	FLAT WASHER	01	
13	0503010542	501045 CLAMPING RING (FOR AXLE)	01	




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	20	01
02	0511059266	CLOSED BEARING	33	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	35	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING		02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	37	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	38	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX	01	
02	0502011758	REAR TENSIONER LEVER	02	
03	0503010292	0.2" X 1.6" SPRING PIN	02	
04	0511061794	CHAIN TENSIONER	01	
05	0503031367	SPRING	01	
06	0511060392	CHAIN TENSIONER	01	
07	0503031366	RIGHT TWISTED SPRING RECAMBIO	01	




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0521018933	FERT CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501011234	5/8" X 3" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01



Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019175	DOUBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503016460	5/8" X 4.1/2" BOLT		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016881	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	17	01
15	0511051434	TRANSMISSION ACTUATOR		02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR		01
17	0521043317	LEFT GEAR BOX ASSY	31	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521064448	GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	FLAT WASHER		01
28	0503010025	3/8" SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	21	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	22	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	23	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	24	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	25	01
35	0501055112	MICRO GRANULATED CHAIN TENSIONER	26	01
36	0503012204	40-1 CHAIN X 82 LINK + RED		01
37	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
38	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
39	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561018351	2155 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	17	01
15	0511051434	TRANSMISSION ACTUATOR		02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR		01
17	0521043317	LEFT GEAR BOX ASSY	31	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2" X 1.1/2" BOLT		02
20	0511017302	FLAT WASHER		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2" NUT		02
24	0521064448	GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	FLAT WASHER		01
28	0503010025	3/8" SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	21	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	22	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	23	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	24	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	25	01
35	0501055112	MICRO GRANULATED CHAIN TENSIONER	26	01
36	0503012204	40-1 CHAIN X 82 LINK + RED		01
37	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
38	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
39	0503014907	40-1 X 151 CHAIN LINK + MENDING		01



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	17	01
15	0511051434	TRANSMISSION ACTUATOR		02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR		01
17	0521043317	LEFT GEAR BOX ASSY	31	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2" X 1.1/2" BOLT		02
20	0511017302	FLAT WASHER		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2" NUT		02
24	0521064448	GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	FLAT WASHER		01
28	0503010025	3/8" SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	21	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	22	01


Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	23	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	24	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	25	01
35	0501055112	MICRO GRANULATED CHAIN TENSIONER	26	01
36	0503012204	40-1 CHAIN X 82 LINK + RED		01
37	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
38	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
39	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0511051434	TRANSMISSION ACTUATOR		02
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0503010300	5/32" X 1" COTTERPIN		04
06	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
07	0511017302	FLAT WASHER		08
08	0503010019	1/2" SPRING WASHER		09
09	0503010060	1/2" NUT		11
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0501052560	MOTOR AXLE SIGNAL	17	01
14	0511047070	LEFT SIDE TRANSMISSION ACTUATOR		01
15	0521043317	LEFT GEAR BOX ASSY	31	01
16	0503010920	1/2" X 1.1/2" BOLT		02
17	0511059261	CHAIN TENSIONER		01
18	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
19	0503014734	BOLT		03
20	0521064448	GEAR		01
21	0501058265	STRETCHER LOWER CURRENT 21Z SEED	22	01
22	0501058254	UPPER SEED CHAIN TENSIONER	23	01
23	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	24	01
24	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	25	01
25	0501055112	MICRO GRANULATED CHAIN TENSIONER	26	01
26	0503014907	40-1 X 151 CHAIN LINK + MENDING		01
27	0561019204	MOTOR SHAFT		01
28	0503012204	40-1 CHAIN X 82 LINK + RED		01
29	0503012718	40-1 CHAIN X 111 LINK + MENDING		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	32	01
02	0511059266	CLOSED BEARING	33	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	35	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING		02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	37	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	38	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	34	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	36	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0511057070	HOSE KIT HYDRAULIC		01
01A	0521052285	TC-TM HOSE ASSY		01
01AA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01AB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01AD	0503018952	PLASTIC BOLT		06
01B	0521052287	TC-TM HOSE ASSY		01
01BA	0501080446	3/8 X" 169" TC-TM HOSE ASSY		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01BD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	72	02
03	0503013100	NYLON CLAMP		02
04	0581010091	SPRING PROTECTION PLASTIC HOSE		01




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0501069470	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	43	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	CUPILLA		02
18	0501069643	890 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	181	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0501053834	MALE QUICK COUPLER	72	02
25	0502012702	BODY SUPPORT CLAMP		06
26	0503011103	7/16" X 2-1/2" BOLT		06
27	0501012803	FLAT WASHER		02
28	0503010180	7/16" SPRING WASHER		06
29	0503010244	7/16" NUT		06
30	0501012140	FLAT WASHER		04
31	0503012412	5/8 UNC SELF LOCKING NUT		02

Item	Code	Description	See page	QT
32	0511011311	VALVE SUPPORT		01
33	0503010232	5/8" X 1.3/4" BOLT		02
34	0503010027	5/8" SPRING WASHER		02
35	0503010013	5/8" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		08
37	0511057071	HYDRAULIC HOSE MARKER ASSY 10L		01
37A	0501081729	HOSE 3/8 X 3125 TR-TR		02
37B	0501081633	HOSE 3/8 X 3325 TR-TC		02
38	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
38A	0501080422	HOSE 3/8 X 4000 TC-TM		01
38B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
38C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
38D	0503018952	PLASTIC BOLT		06
39	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
39A	0501080422	HOSE 3/8 X 4000 TC-TM		01
39B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
39C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
39D	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8 UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503011082	C1/2" X 1.3/4" SCREW		02
07	0501069470	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0501012140	FLAT WASHER		04
11	0503012412	5/8 UNC SELF LOCKING NUT		02
12	0511058449	HYDRAULIC CYLINDER	43	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" COTTERPIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	0.3" X 3.1" LOCK PIN		02
19	0503030168	CUPILLA		02
20	0501066949	1235 TURNBUCKLE		02
21	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
22	0511011311	VALVE SUPPORT		01
23	0503010232	5/8" X 1.3/4" BOLT		02
24	0503010027	5/8" SPRING WASHER		02
25	0503010013	5/8" NUT		02
26	0501054649	HBM SEQUENTIAL VALVE	181	01
27	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
28	0501010984	FLAT WASHER		02
29	0503010025	3/8" SPRING WASHER		02
30	0502012702	BODY SUPPORT CLAMP		06
31	0503011103	7/16" X 2-1/2" BOLT		06

Item	Code	Description	See page	QT
32	0501012803	FLAT WASHER		02
33	0503010180	7/16" SPRING WASHER		06
34	0503010244	7/16" NUT		06
35	0501053834	MALE QUICK COUPLER	72	02
36	0511057069	HYDRAULIC HOSE MARKER ASSY		01
36A	0501080343	TR-TR HOSE ASSY		02
36B	0501080720	HOSE 3/8 X 3500 TR-TC		02
37	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
37A	0501080422	HOSE 3/8 X 4000 TC-TM		01
37B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
37C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
37D	0503018952	PLASTIC BOLT		06
38	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
38A	0501080422	HOSE 3/8 X 4000 TC-TM		01
38B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
38C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
38D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0501012140	FLAT WASHER		12
04	0503012412	5/8 UNC SELF LOCKING NUT		10
05	0503011070	BEATER		02
06	0503010920	1/2" X 1.1/2" BOLT		02
07	0503010019	1/2" SPRING WASHER		02
08	0511061811	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0511058449	HYDRAULIC CYLINDER	43	02
12	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
13	0503010523	1/4" X 2" COTTERPIN		04
14	0511015779	1" X 4.2" AXLE		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	CUPILLA		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	181	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0501053834	MALE QUICK COUPLER	72	02
25	0531011180	UPPER BODY CLIP		08
26	0503010180	7/16" SPRING WASHER		08
27	0511011311	VALVE SUPPORT		01
28	0511059271	HYDRAULIC MARKER HAND SET		01
28A	0501081731	3/8 X 3550 TR-TR HOSE		02
28B	0501081732	3/8" X 3750 TR-TR HOSE		02
28C	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01




**PST4 FLEX - FRAME 4045/4495/4845/5345 - CSU (UP TO
SEMI-ASSEMBLED HYDRAULIC MARKER 5345**

Page 42
0511051119


Item	Code	Description	See page	QT
28D	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
29	0503011103	7/16" X 2-1/2" BOLT		08
30	0502012702	BODY SUPPORT CLAMP		08
31	0503010244	7/16" NUT		08
32	0503010232	5/8" X 1.3/4" BOLT		02
33	0503010027	5/8" SPRING WASHER		02
34	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	45	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	FLAT WASHER	16	
04	0503010025	3/8" SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0511069665	PLATFORM RIGHT	01	
07	0521062323	PLATFORM LEFT	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	FLAT WASHER	16	
04	0503010025	3/8" SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0521062237	RIGHT PLATAFORM	01	
07	0521062238	LEFT PLATAFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT		04
02	0503010849	3/8" X 1-1/2" BOLT		08
03	0501010984	FLAT WASHER		16
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0511069718	PLATFORM RIGHT		01
07	0521062324	PLATFORM LEFT		01
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
09	0503011336	1/2" HEX SELF ADJUSTING NUT		04
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
13	0502012739	PLATFORM LEFT FIXER SUPPORT		01




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT		04
02	0503010849	3/8" X 1-1/2" BOLT		08
03	0501010984	FLAT WASHER		16
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521062450	RIGHT PLATFORM		01
07	0521062451	LEFT PLATFORM		01
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
09	0503011336	1/2" HEX SELF ADJUSTING NUT		04
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
13	0502012739	PLATFORM LEFT FIXER SUPPORT		01




Item	Code	Description	See page	QT
01	0511069656	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0521062239	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0511069660	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0521062449	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0502012329	DRAWBAR FIXATION REAR SUPPORT		02
02	0502012330	SUPPORT FIXER PIVOT		04
03	0503011084	3/4" X 5" BOLT		08
04	0501010322	FLAT WASHER		08
05	0503010023	3/4" SPRING WASHER		08
06	0503010014	3/4" NUT		08
07	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02
08	0561014393	COUPLING SHAFT		02
09	0503030119	LOCK PIN		04
10	0531063130	HEADER		01
11	0561019087	DRAWBAR TRANSPORT LOCK		01
12	0521010578	COUPLING SHAFT		01
13	0521010588	0.9" X 7.0" COUPLING SHAFT		01
14	0503030085	LOCK PIN		02
15	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	1902012329	REAR SUPPORT FIXING HEADER	04	
02	1902012330	FIXER SUPPORT ARTICULATED	08	
03	0503011084	3/4" X 5" BOLT	16	
04	0503010023	3/4" SPRING WASHER	16	
05	0503010014	3/4" NUT	16	
06	1902012328	FIXED FRONT SUPPORT HEADER	04	
07	0561014393	COUPLING SHAFT	04	
08	0503030119	LOCK PIN	08	
09	0511064808	DRAWBAR	01	
10	0561019087	DRAWBAR TRANSPORT LOCK	01	
11	0521010588	0.9" X 7.0" COUPLING SHAFT	01	
12	0521010578	COUPLING SHAFT	01	
13	0503030085	LOCK PIN	02	
14	0503010002	1800 GREASE FITTING	01	
15	0501010322	FLAT WASHER	16	




Item	Code	Description	See page	QT
001	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
002	0503010267	NYLON CLAMP		01
003	0503010363	5/16" X 1" BOLT		01
004	0501010694	FLAT WASHER		01
005	0503010179	LOCK WASHER		01
006	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0503033867	ADHESIVE LABEL		02
02	0503033854	ADHESIVE LABEL		02
03	0503033853	ADHESIVE LABEL		02
04	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
07	0503032979	ADHESIVE LABEL LETTERS A B C D		02
08	0503033008	ADHESIVE LABEL		02
09	0503031428	READ MANUAL DECAL		01
10	0503031942	ADHESIVE LABEL		01
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
12	0503031565	ADHESIVE LABEL CARE		02
13	0503031566	ADHESIVE LABEL		02
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
15	0503031425	ADHESIVE LABEL ATTENTION		02
16	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
17	0503034500	ADHESIVE LABEL		01
18	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
19	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
20	0503032930	ADHESIVE LABEL DANGER		05
21	0503031087	ADHESIVE LABEL		01
22	0503034003	SERIAL NUMBER TAG 61 X 118		01
23	0503010001	3.2 X 5.5 RIVET		04
24	0503034078	LIFTING POINTS DECAL		03




Item	Code	Description	See page	QT
01	0503033867	ADHESIVE LABEL		02
02	0503033854	ADHESIVE LABEL		02
03	0503033853	ADHESIVE LABEL		02
04	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
07	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
08	0503033008	ADHESIVE LABEL		02
09	0503031428	READ MANUAL DECAL		01
10	0503031942	ADHESIVE LABEL		01
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
12	0503031565	ADHESIVE LABEL CARE		02
13	0503031566	ADHESIVE LABEL		02
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
15	0503031425	ADHESIVE LABEL ATTENTION		02
16	0503031669	ADHESIVE LABEL		01
17	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
18	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
19	0503032930	ADHESIVE LABEL DANGER		05
20	0503031087	ADHESIVE LABEL		01
21	0503034078	LIFTING POINTS DECAL		03
22	0503034003	SERIAL NUMBER TAG 61 X 118		01
23	0503010001	3.2 X 5.5 RIVET		04
24	0503032979	ADHESIVE LABEL LETTERS A B C D		02
25	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
001	0503033867	ADHESIVE LABEL		02
002	0503033854	ADHESIVE LABEL		02
003	0503033853	ADHESIVE LABEL		02
004	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
005	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
006	0503033423	LABEL ADHESIVE NUMBER 9		02
007	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
008	0503033008	ADHESIVE LABEL		02
009	0503031428	READ MANUAL DECAL		01
010	0503031942	ADHESIVE LABEL		01
011	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
012	0503031565	ADHESIVE LABEL CARE		02
013	0503031566	ADHESIVE LABEL		02
014	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
015	0503031425	ADHESIVE LABEL ATTENTION		02
016	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
017	0503031669	ADHESIVE LABEL		01
018	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
019	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
020	0503032930	ADHESIVE LABEL DANGER		05
021	0503031087	ADHESIVE LABEL		01
022	0503034003	SERIAL NUMBER TAG 61 X 118		01
023	0503010001	3.2 X 5.5 RIVET		04
024	0503034078	LIFTING POINTS DECAL		03
025	0503032979	ADHESIVE LABEL LETTERS A B C D		02
026	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
001	0503033867	ADHESIVE LABEL		02
002	0503033854	ADHESIVE LABEL		02
003	0503033853	ADHESIVE LABEL		02
004	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
005	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
006	0503033422	ADHESIVE LABEL		02
007	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
008	0503033008	ADHESIVE LABEL		02
009	0503031428	READ MANUAL DECAL		01
010	0503031942	ADHESIVE LABEL		01
011	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
012	0503031565	ADHESIVE LABEL CARE		02
013	0503031566	ADHESIVE LABEL		02
014	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
015	0503031425	ADHESIVE LABEL ATTENTION		02
016	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
017	0503031669	ADHESIVE LABEL		01
018	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
019	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
020	0503032930	ADHESIVE LABEL DANGER		06
021	0503031087	ADHESIVE LABEL		01
022	0503034078	LIFTING POINTS DECAL		03
023	0503034003	SERIAL NUMBER TAG 61 X 118		01
024	0503010001	3.2 X 5.5 RIVET		04
025	0503032979	ADHESIVE LABEL LETTERS A B C D		02
026	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
001	0503033867	ADHESIVE LABEL		02
002	0503033854	ADHESIVE LABEL		02
003	0503033853	ADHESIVE LABEL		02
004	0503033417	ADHESIVE LABEL		02
005	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
006	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		04
007	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
008	0503033008	ADHESIVE LABEL		02
009	0503031428	READ MANUAL DECAL		01
010	0503031942	ADHESIVE LABEL		01
011	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
012	0503031565	ADHESIVE LABEL CARE		02
013	0503031566	ADHESIVE LABEL		02
014	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
015	0503031425	ADHESIVE LABEL ATTENTION		02
016	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
017	0503031669	ADHESIVE LABEL		01
018	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
019	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
020	0503032930	ADHESIVE LABEL DANGER		06
021	0503031087	ADHESIVE LABEL		01
022	0503034078	LIFTING POINTS DECAL		03
023	0503034003	SERIAL NUMBER TAG 61 X 118		01
024	0503010001	3.2 X 5.5 RIVET		04
025	0503032979	ADHESIVE LABEL LETTERS A B C D		02
026	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	65	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521012536	COUPLING SHAFT		02
04	0503010523	1/4" X 2" COTTERPIN		04
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	66	01
02	0531019171	1.25" X 7" COUPLING SHAFT		01
03	0521012536	COUPLING SHAFT		01
04	0503010523	1/4" X 2" COTTERPIN		02
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HAIR PIN		01




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O'RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O'RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0511064055	5" X 15" CYLINDER CASE		01
02	0511064056	BUSHING 2" X 14" TURNBUCLE		01
03	0502010382	5" END CAP		01
04	0502012227	50.80 X 127 RING SUPPORT		01
05	0503010039	D-2000 SCRAPER RING		01
06	0503010991	1870-2000-375-B GASKET		01
07	0503010952	W2-2250-500 RING		01
08	0503010351	2-425 N 3006-9B O'RING		01
09	0503011062	8-425 BACK-UP RING		01
10	0502010963	2.0" X 5.0" PISTON		01
11	0503010552	PACKING 3750-4250-625-B		02
12	0503010345	2-218 N 3006-9B O'RING		01
13	0503010974	W2-5000-500 RING		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503010003	1845 GREASE FITTING		01
16	0503030385	CYLINDER PLUG N-002		02




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0511062887	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01



Item	Code	Description	See page	QT
01	0511063404	"T" OIL CONDUCTOR		02
02	0581010091	SPRING PROTECTION PLASTIC HOSE		01
03	0503013100	NYLON CLAMP		02
04	0502012702	BODY SUPPORT CLAMP		02
05	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		02
06	0503010180	7/16" SPRING WASHER		02
07	0501053834	MALE QUICK COUPLER	72	02
08	0511057068	HOSE KIT SYSTEM HYDRAULIC		01
08A	0501080449	3/8" X 1500 TC-TC HOSE		04
09	0521052334	3/8 X 4000 TR-TM HOSE BLACK / BLUE		01
09A	0501080361	3/8" X 157" TR-TM HOSE		01
09B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
09C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
09D	0503018952	PLASTIC BOLT		06
10	0521052333	3/8 X 4000 TR-TM HOSE BLACK / RED		01
10A	0501080361	3/8" X 157" TR-TM HOSE		01
10B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
10C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
10D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	DIR	ESQ
01	0511052419	RH BEAM SUPPORT		01	00
01A	0521063542	FERTILIZER BEAN RIGHT SUPPORT		01	00
02	0511052420	LH BEAM SUPPORT & METERING		00	01
02A	0521063543	FERTILIZER BEAN LEFT SUPPORT		00	01
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	83	00	04
04	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	82	04	00
05	0501010942	3/8" X 1-1/4" BOLT		16	16
06	0503011443	3/8" SPRING WASHER		16	16
07	0503010026	3/8" NUT		16	16
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01	01
09	0521014167	CONE LOCK		01	01
10	0503030275	AGRICULTURAL BEARING		04	04
11	0502010685	18Z CONICAL GEAR		04	04
12	0561018362	SQUARE SHAFT		01	01
13	0501053788	3/4 SQUARE AXLE FASTENER	84	02	02
14	0501110392	SILO SUPPORT BEARING		01	01
15	0521012485	GEAR BOX BEARING AGRICUTURAL		01	01
16	0503011953	5/16" X 1" BOLT		02	02
17	0501010694	FLAT WASHER		02	02
18	0521011039	FLAT WASHER		02	02
19	0503011444	SPRING WASHER		02	02
20	0503010337	5/16" NUT		02	02
21	0551018055	22,65 X 60 SLEEVE		02	02
22	0503010003	1845 GREASE FITTING		01	01
23	0503010849	3/8" X 1-1/2" BOLT		08	08
24	0501010984	FLAT WASHER		17	17
25	0503010025	3/8" SPRING WASHER		08	08
26	0503010026	3/8" NUT		08	08
27	0571010590	FERTILIZER SIDE COVER		04	04
28	0503010362	1/8" X 1.1/4" COTTERPIN		04	04
29	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		01	01

Item	Code	Description	See page	DIR	ESQ
30	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02	02
31	0551019156	GEAR BOX LEVER LOCK		01	01
32	0503011953	5/16" X 1" BOLT		02	02
33	0501010694	FLAT WASHER		02	02
34	0503010179	LOCK WASHER		02	02
35	0503010337	5/16" NUT		02	02
36	0503010847	1/2" X 3.1/4" BOLT		01	01
37	0551019168	SLEEVE		01	01
38	0551019160	LEVER		01	01
39	0511017302	FLAT WASHER		03	03
40	0503010019	1/2" SPRING WASHER		02	02
41	0503010060	1/2" NUT		01	01
42	0551019167	SLEEVE UNION		01	01
43	0511069676	INNER LEVER		01	01
44	0501013518	FLAT WASHER		02	02
45	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01	01
46	0503010140	1/8" X 3/4" COTTERPIN		03	03
47	0511069678	LH LOWER LEVER		02	02
48	0503011336	1/2" HEX SELF ADJUSTING NUT		02	02
49	0551019115	LOCKING PLATFORM FIXATION		01	01
50	0501010096	3/8" X 2" BOLT		01	01
51	0503013357	3/8" SELF-ADJUSTING NUT		01	01
52	0551019159	LEVER FIXER BODY		01	01
53	0561016468	FASTENER		01	01



Item	Code	Description	See page	DIR	ESQ
01	0511052253	RH BEAM SUPPORT & METERING		01	00
01A	0521063436	FERTILIZER BEAN RIGHT SUPPORT		01	00
02	0511052254	LH BEAM SUPPORT & METERING		00	01
02A	0521063437	FERTILIZER BEAN LEFT SUPPORT		00	01
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	83	00	05
04	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	82	05	00
05	0501010942	3/8" X 1-1/4" BOLT		20	20
06	0503011443	3/8" SPRING WASHER		20	20
07	0503010026	3/8" NUT		20	20
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01	01
09	0521014167	CONE LOCK		01	01
10	0503030275	AGRICULTURAL BEARING		05	05
11	0502010685	18Z CONICAL GEAR		05	05
12	0551018213	3/4" X 1830 SQUARE SHAFT		01	01
13	0521010691	AXLE FASTENER		02	02
14	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02	02
15	0501010694	FLAT WASHER		02	02
16	0503011441	SPRING WASHER		02	02
17	0503010144	1/4" NUT		02	02
18	0501110392	SILO SUPPORT BEARING		01	01
19	0521012485	GEAR BOX BEARING AGRICUTURAL		01	01
20	0503011953	5/16" X 1" BOLT		02	02
21	0501010694	FLAT WASHER		02	02
22	0521011039	FLAT WASHER		02	02
23	0503011444	SPRING WASHER		02	02
24	0503010337	5/16" NUT		02	02
25	0551018055	22,65 X 60 SLEEVE		01	01
26	0503010003	1845 GREASE FITTING		01	01
27	0503010849	3/8" X 1-1/2" BOLT		08	08
28	0501010984	FLAT WASHER		17	17
29	0503010025	3/8" SPRING WASHER		08	08

Item	Code	Description	See page	DIR	ESQ
30	0503010026	3/8" NUT		08	08
31	0503034396	FERTILIZER SIDE COVER		05	05
32	0503010362	1/8" X 1.1/4" COTTERPIN		05	05
33	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		01	01
34	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02	02
35	0551019156	GEAR BOX LEVER LOCK		01	01
36	0503011953	5/16" X 1" BOLT		02	02
37	0501010694	FLAT WASHER		02	02
38	0503010179	LOCK WASHER		02	02
39	0503010337	5/16" NUT		02	02
40	0503010847	1/2" X 3.1/4" BOLT		01	01
41	0551019168	SLEEVE		01	01
42	0511069678	LH LOWER LEVER		01	01
43	0511017302	FLAT WASHER		03	03
44	0503010019	1/2" SPRING WASHER		02	02
45	0503010060	1/2" NUT		02	02
46	0551019167	SLEEVE UNION		01	01
47	0511069678	LH LOWER LEVER		01	01
48	0501013518	FLAT WASHER		02	02
49	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01	01
50	0503010140	1/8" X 3/4" COTTERPIN		03	03
51	0511069678	LH LOWER LEVER		02	02
52	0503011336	1/2" HEX SELF ADJUSTING NUT		02	02
53	0551019115	LOCKING PLATFORM FIXATION		01	01
54	0501010096	3/8" X 2" BOLT		01	01
55	0503013357	3/8" SELF-ADJUSTING NUT		01	01
56	0551019159	LEVER FIXER BODY		01	01
57	0561016468	FASTENER		01	01




Item	Code	Description	See page	DIR	ESQ
01	0511053240	RIGHT SILO SUPPORT WITH DISTRIBUTOR 10	01	00	
02	0511053241	LEFT SILO SUPPORT WITH DISTRIBUTOR 10	00	01	
03	0503010849	3/8" X 1-1/2" BOLT	08	08	
04	0501010984	FLAT WASHER	17	17	
05	0503010025	3/8" SPRING WASHER	08	08	
06	0503010026	3/8" NUT	08	08	
07	0571010590	FERTILIZER SIDE COVER	05	05	
08	0503010362	1/8" X 1.1/4" COTTERPIN	05	05	
09	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS	01	01	
10	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE	02	02	
11	0551019156	GEAR BOX LEVER LOCK	01	01	
12	0503011953	5/16" X 1" BOLT	02	02	
13	0501010694	FLAT WASHER	02	02	
14	0503010179	LOCK WASHER	02	02	
15	0503010337	5/16" NUT	02	02	
16	0503010847	1/2" X 3.1/4" BOLT	01	01	
17	0551019168	SLEEVE	01	01	
18	0551019160	LEVER	01	01	
19	0511017302	FLAT WASHER	03	03	
20	0503010019	1/2" SPRING WASHER	02	02	
21	0503010060	1/2" NUT	02	02	
22	0551019167	SLEEVE UNION	01	01	
23	0511069676	INNER LEVER	01	01	
24	0501013518	FLAT WASHER	02	02	
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	01	01	
26	0503010140	1/8" X 3/4" COTTERPIN	03	03	
27	0511069678	LH LOWER LEVER	02	02	
28	0503011336	1/2" HEX SELF ADJUSTING NUT	02	02	
29	0551019115	LOCKING PLATFORM FIXATION	01	01	
30	0501010096	3/8" X 2" BOLT	01	01	
31	0503013357	3/8" SELF-ADJUSTING NUT	01	01	




**PST4 FLEX - FRAME 4045/4495/4845/5345 - CSU (UP TO
SET SUPPORT RIGHT LEFT**

Page 75
0511057564

Item	Code	Description	See page	DIR	ESQ
32	0551019159	LEVER FIXER BODY		01	01
33	0561016468	FASTENER		01	01



Item	Code	Description	See page	QT
32	0503010019	1/2" SPRING WASHER		02
33	0503010060	1/2" NUT		02
34	0511069678	LH LOWER LEVER		02
35	0501013518	FLAT WASHER		02
36	0503010140	1/8" X 3/4" COTTERPIN		04
37	0551019159	LEVER FIXER BODY		02
38	0561016468	FASTENER		02
39	0503011336	1/2" HEX SELF ADJUSTING NUT		04
40	0551019115	LOCKING PLATFORM FIXATION		02
41	0501010096	3/8" X 2" BOLT		02
42	0501010984	FLAT WASHER		02
43	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0511051120	RIGHT BEAM SUPPORT WITH DISTRIBUTOR 12	78	01
02	0511051121	LEFT BEAM SUPPORT WITH DISTRIBUTOR 12	79	01
03	0503062169	SILO FERTILIZER 6 MOUTHS MOUNTED		02
04	0503010849	3/8" X 1-1/2" BOLT		20
05	0501010984	FLAT WASHER		42
06	0503010025	3/8" SPRING WASHER		20
07	0503010026	3/8" NUT		20
08	0503034396	FERTILIZER SIDE COVER		12
09	0503010362	1/8" X 1.1/4" COTTERPIN		12
10	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
11	0551019156	GEAR BOX LEVER LOCK		02
12	0503011953	5/16" X 1" BOLT		04
13	0501010694	FLAT WASHER		04
14	0503010179	LOCK WASHER		04
15	0503010337	5/16" NUT		04
16	0551019160	LEVER		02
17	0551019168	SLEEVE		02
18	0503010847	1/2" X 3.1/4" BOLT		02
19	0511017302	FLAT WASHER		06
20	0503010019	1/2" SPRING WASHER		04
21	0503010060	1/2" NUT		04
22	0511069676	INNER LEVER		02
23	0551019167	SLEEVE UNION		02
24	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
25	0511069678	LH LOWER LEVER		02
26	0501013518	FLAT WASHER		06
27	0503010140	1/8" X 3/4" COTTERPIN		06
28	0551019159	LEVER FIXER BODY		02
29	0561016468	FASTENER		02
30	0503011336	1/2" HEX SELF ADJUSTING NUT		04
31	0551019115	LOCKING PLATFORM FIXATION		02




**PST4 FLEX - FRAME 4045/4495/4845/5345 - CSU (UP TO
RIGHT / LEFT SUPPORT BOX ASSEMBLY ASSY 12**

Page 77
0511058311


Item	Code	Description	See page	QT
32	0501010096	3/8" X 2" BOLT		02
33	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	83	01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	82	05
03	0511061759	22Z P12,70 FQ 3/4" GEAR		01
04	0521014167	CONE LOCK		01
05	0503030275	AGRICULTURAL BEARING		06
06	0502010685	18Z CONICAL GEAR		06
07	0551018198	SQUARE SHAFT		01
08	0501053788	3/4 SQUARE AXLE FASTENER	84	02
09	0501110392	SILO SUPPORT BEARING		01
10	0521012485	GEAR BOX BEARING AGRICUTURAL		01
11	0503010003	1845 GREASE FITTING		01
12	0551018055	22,65 X 60 SLEEVE		01
13	0521066239	RIGHT SUPPORT SILO FERTILIZER 12		01
14	0501010694	FLAT WASHER		02
15	0521011039	FLAT WASHER		02
16	0503010337	5/16" NUT		02
17	0503010179	LOCK WASHER		02
18	0503011953	5/16" X 1" BOLT		02
19	0501010942	3/8" X 1-1/4" BOLT		24
20	0503010025	3/8" SPRING WASHER		24
21	0503010026	3/8" NUT		24




Item	Code	Description	See page	QT
01	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	83	03
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	82	03
03	0521014167	CONE LOCK		01
04	0503030275	AGRICULTURAL BEARING		06
05	0502010685	18Z CONICAL GEAR		06
06	0551018198	SQUARE SHAFT		01
07	0501053788	3/4 SQUARE AXLE FASTENER	84	02
08	0501110392	SILO SUPPORT BEARING		01
09	0521012485	GEAR BOX BEARING AGRICUTURAL		01
10	0503010003	1845 GREASE FITTING		01
11	0551018055	22,65 X 60 SLEEVE		01
12	0521066240	LEFT SUPPORT SILO FERTILIZER 12		01
13	0511061759	22Z P12,70 FQ 3/4 GEAR		01
14	0501010942	3/8" X 1-1/4" BOLT		24
15	0503010025	3/8" SPRING WASHER		24
16	0503010026	3/8" NUT		24
17	0503011953	5/16" X 1" BOLT		02
18	0501010694	FLAT WASHER		02
19	0521011039	FLAT WASHER		02
20	0503010337	5/16" NUT		02
21	0503010179	LOCK WASHER		02




Item	Code	Description	See page	QT
01	0521066242	FERTILIZER BEAN RIGHT SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	82	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	83	03
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503011443	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		06
10	1902010685	18Z CONICAL GEAR		06
11	0511014265	3/4" X 86" SQUARE SHAFT		01
12	0501053788	3/4 SQUARE AXLE FASTENER	84	02
13	0501110392	SILO SUPPORT BEARING		01
14	0521012485	GEAR BOX BEARING AGRICUTURAL		01
15	0503011953	5/16" X 1" BOLT		02
16	0521011039	FLAT WASHER		02
17	0503011444	SPRING WASHER		02
18	0503010337	5/16" NUT		02
19	0551018055	22,65 X 60 SLEEVE		01
20	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521066241	FERTILIZER BEAN LEFT SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	82	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	83	03
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503011443	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		06
10	1902010685	18Z CONICAL GEAR		06
11	0511014265	3/4" X 86" SQUARE SHAFT		01
12	0501053788	3/4 SQUARE AXLE FASTENER	84	02
13	0501110392	SILO SUPPORT BEARING		01
14	0521012485	GEAR BOX BEARING AGRICUTURAL		01
15	0503011953	5/16" X 1" BOLT		02
16	0521011039	FLAT WASHER		02
17	0503011444	SPRING WASHER		02
18	0503010337	5/16" NUT		02
19	0551018055	22,65 X 60 SLEEVE		01
20	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031159	RIGHT HELICAL CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031166	LEFT CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01



Item	Code	Description	See page	09 L
01	0503016555	9 ROW SIMPLE MONITOR CABLE		01
02	0503017602	MONITOR PLANT PM400		01
03	0503016234	TRIMBLE FIXING WINDOW		01
04	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
05	0571012196	MOUNTING BRACKET PM 400		01
06	0503017443	ANTENNA GPS PM 400		01
07	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		135
08	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
09	0503010669	FLAT WASHER		02
10	0503010668	3/16" SPRING WASHER		02
11	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0503062795	KIT MONITORING SEED 10L 45/50 PM400 PM410SSM		01
01A	0503016556	10 ROW SIMPLE MONITOR CABLE		01
01B	0503019100	SENSOR		10
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503013100	NYLON CLAMP		50
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		150
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
08	0503010669	FLAT WASHER		02
09	0503010668	3/16" SPRING WASHER		02
10	0503010667	3/16" NUT		02



Item	Code	Description	See page	QT
01	0501059834	FRONT LINE SEED SHORT LEFT CARDAN	90	01
02	0501059833	FRONT LINE SEED SHORT RIGHT CARDAN	91	01
03	0501059835	FRONT LINE SEED LONG RIGHT CARDAN	92	01
04	0501059836	FRONT LINE SEED LONG LEFT CARDAN	93	01
05	0511056621	REAR RIGHT SEED LINE	96	01
06	0511056622	LEFT REAR LINE SEED	97	01
07	0511056628	REAR RIGHT	98	01
08	0511056629	LEFT REAR	99	01
09	0511056625	RIGHT REAR LINE SEED PM 100	100	01
10	0511056626	LEFT REAR LINE SEED PM100	101	01
11	0511057017	SEED SYSTEM ASSY	106	01
12	0511059023	SEED SYSTEM ASSY	107	01
13	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	109	01
14	0521042327	DEPTH CONTROL & PRESS WHEEL ASSY	115	01
15	0521045198	PRESS WHEELS	119	01
16	0521044460	SYSTEM DEPTH / COMPACTOR	120	01
17	0521044269	PRESS WHEELS/DEPTH ASSY	127	01
18	0521046501	DEPTH CONTROL AND PRESS WHEEL WITH FAST ADJUSTING	132	01
19	0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	133	01
20	0501110714	INNER SOCKET FASTENER		01
20.	0521069127	BOTTOM NOZZLE FERTILIZER		01
21	0503030483	FERTILIZER SOCKET		01
22	0503031050	CURVED CONDUCTOR		01
23	0503031145	2" X 2" X 20" HOSE		01
24	0571011730	SEED CONDUCTOR 3" X 1500		01
25	0521050525	FIXER FERTILIZER CONDUCTOR	164	01
26	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
27	0503016204	CORN DISK 12 ORANGE		01
28	0503016214	RING CORN (APOLLO740)		01
29	0503016218	DISC OF SOYBEAN		01

Item	Code	Description	See page	QT
30	0503016220	RING TO SOYBEANS (APOLLO 745)		01
31	0503016221	RING TO SOYBEANS (APOLLO 571)		01
32	0503030558	PULLEY 4Z CORN PLASTIC		01
33	0503033672	NOZZLE WITHOUT TITANIUM		01
34	0501050120	LARGER WALKING BEAM ASSY	151	01
35	0511052024	FAST CLOSING SET	143	02
36	0531013600	PRESS ADJUSTMENT LEVER		01
37	0503010246	CLAMP		01
38	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
39	0501010984	FLAT WASHER		01
40	0503010025	3/8" SPRING WASHER		01
41	0503010026	3/8" NUT		01
42	0511054835	HDA	141	01
43	0511017969	0.1" SPACING PLATE		01
44	0511018662	SPACING PLATE		01
45	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	152	01
46	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	153	01
47	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	157	01
48	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	158	01
49	0511047378	FULL DC DPLO 18 CT	159	01
50	0511047379	FULL DC DPLO 18 LG	160	01
51	0503010905	1/2" X 2-1/4" BOLT		01
52	0503010019	1/2" SPRING WASHER		01
53	0503010060	1/2" NUT		01
54	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
55	0501058423	FERTILIZER ROD SPRING ROW	163	01
56	0521061121	SHORT FERTILIZER ROW ARM		01
56.	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC		01
57	0521061153	LONG ARM FERTILIZER LINE		01
57.	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC		01
58	0511059221	DAOC 18 LEFT WITH NOZZLE	182	01
59	0511059220	DAOC 18 RIGHT WITH NOZZLE	183	01
60	0511058212	ASSY LINE SUPPORT FERTILIZER		01
61	0502010175	HITCH CLAMP		01
62	0501011543	5/8" X 4" BOLT		02
63	0503012412	5/8 UNC SELF LOCKING NUT		02




Item	Code	Description	See page	QT
01	0521064651	LEFT SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8 UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	FLAT WASHER	04	
08	0503010179	LOCK WASHER	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION BOX SEED LINE	01	
12	0561014904	TRANSMISSION AXLE FRAME LINE	01	
13	0511050609	BEARING WITH 17Z GEAR ASSY	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEED ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521061427	SHORT SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" COTTERPIN	01	
27	0503030168	CUPILLA	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" COTTERPIN	01	
31	0503034580	TRACTION SPRING	02	



**PST4 FLEX - FRAME 4045/4495/4845/5345 - CSU (UP TO
FRONT LINE SEED SHORT LEFT CARDAN**

Page 90
0501059834

Item	Code	Description	See page	QT
32	0511059264	BEARING WITH AXLE	95	01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064653	RIGH SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8 UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	FLAT WASHER	04	
08	0503010179	LOCK WASHER	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION BOX SEED LINE	01	
12	0561014904	TRANSMISSION AXLE FRAME LINE	01	
13	0511050609	BEARING WITH 17Z GEAR ASSY	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEED ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521061427	SHORT SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" COTTERPIN	01	
27	0503030168	CUPILLA	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" COTTERPIN	01	
31	0503034580	TRACTION SPRING	02	



**PST4 FLEX - FRAME 4045/4495/4845/5345 - CSU (UP TO
FRONT LINE SEED SHORT RIGHT CARDAN**

Page 91
0501059833

Item	Code	Description	See page	QT
32	0511059264	BEARING WITH AXLE	95	01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064652	RH SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8 UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	FLAT WASHER	04	
08	0503010179	LOCK WASHER	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION BOX SEED LINE	01	
12	0561014904	TRANSMISSION AXLE FRAME LINE	01	
13	0511050609	BEARING WITH 17Z GEAR ASSY	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEED ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521061427	SHORT SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" COTTERPIN	01	
27	0503030168	CUPILLA	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" COTTERPIN	01	
31	0503034580	TRACTION SPRING	02	



**PST4 FLEX - FRAME 4045/4495/4845/5345 - CSU (UP TO
FRONT LINE SEED LONG RIGHT CARDAN**

Page 92
0501059835

Item	Code	Description	See page	QT
32	0511059264	BEARING WITH AXLE	95	01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064650	LEFT SEED ROW SUPPORT FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503017857	BOLT 5/8 UNF 4	04	
04	0503012412	5/8 UNC SELF LOCKING NUT	04	
05	0511054635	BEARING AXLE BODY	02	
06	0503011953	5/16" X 1" BOLT	04	
07	0501010694	FLAT WASHER	04	
08	0503010179	LOCK WASHER	04	
09	0503010337	5/16" NUT	04	
10	0502012782	17Z GEAR WITH HEX HOLE	01	
11	0511057159	TRANSMISSION BOX SEED LINE	01	
12	0561014904	TRANSMISSION AXLE FRAME LINE	01	
13	0501052769	BEARING WITH 17Z GEAR	01	
14	0511055260	SEED ROW CHAIN TENSIONER	01	
15	0502012666	SEED ROW LOWER ARM	01	
16	0503010003	1845 GREASE FITTING	04	
17	0561015858	SPACER LOWER SLEEVE	01	
18	0531015151	0.6" X 1" X 2.4" SLEEVE	07	
19	0531015184	FLAT WASHER	08	
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
21	0502012350	SEED ROW UPPER ARM	01	
22	0521061427	SHORT SEED ROW FRAME	01	
23	0502012568	UPPER ROCKER ARM	01	
24	0561019032	SEED FERTIL ROW LOCK	01	
25	0501011388	COUPLING SHAFT	02	
26	0503010071	3/16" X 1" COTTERPIN	01	
27	0503030168	CUPILLA	01	
28	0581018487	FIXER UPPER SPRING	01	
29	0521010773	0.37" X 1.18" COUPLING SHAFT	01	
30	0503010140	1/8" X 3/4" COTTERPIN	01	
31	0503034580	TRACTION SPRING	02	




**PST4 FLEX - FRAME 4045/4495/4845/5345 - CSU (UP TO
FRONT LINE SEED LONG LEFT CARDAN**

Page 93
0501059836


Item	Code	Description	See page	QT
32	0511059264	BEARING WITH AXLE	95	01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	BOX TRANSMISSION COVER		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0502040857	CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503010003	1845 GREASE FITTING		01
13	0503011409	6005 Z BALL BEARING		01
14	0503017008	SEAL RING		01
15	0503017007	SEAL RING		02
16	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0501059326	UNIVERSAL JOINT AXLE		01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0511050611	5/8" HEX AXLE BEARING		01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503011443	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	102	01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503011443	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511056586	15 X 15 SEED DDD LEFT	103	01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8		01
02	0503033672	NOZZLE WITHOUT TITANIUM		01
03	0501058972	ASSEMBLY SENSOR ELECTRONIC		01
04	0503015920	3/8" UNC X 1.3/4" BOLT		04
05	0503011443	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	102	01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8		01
02	0503033672	NOZZLE WITHOUT TITANIUM		01
03	0501058972	ASSEMBLY SENSOR ELECTRONIC		01
04	0503015920	3/8" UNC X 1.3/4" BOLT		04
05	0503011443	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511056586	15 X 15 SEED DDD LEFT	103	01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8		01
01A	0502012704	BASE FIXING SYSTEM		01
01B	0501013354	FLAT WASHER		01
01C	0502012639	12Z LOWER CONICAL GEAR		01
01D	0502011418	40Z CONICAL GEAR		01
01E	0511018700	AXLE		01
01F	0503010002	1800 GREASE FITTING		02
02	0503033672	NOZZLE WITHOUT TITANIUM		01
03	0511053118	ASSEMBLY SENSOR ELECTRONIC		01
03A	0503016492	ELECTRIC PHOTO SENSOR PM 100		01
03B	0503013100	NYLON CLAMP		03
04	0503015920	3/8" UNC X 1.3/4" BOLT		04
05	0503011443	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	102	01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8		01
01A	0502012704	BASE FIXING SYSTEM		01
01B	0501013354	FLAT WASHER		01
01C	0502012639	12Z LOWER CONICAL GEAR		01
01D	0502011418	40Z CONICAL GEAR		01
01E	0511018700	AXLE		01
01F	0503010002	1800 GREASE FITTING		02
02	0503033672	NOZZLE WITHOUT TITANIUM		01
03	0511053118	ASSEMBLY SENSOR ELECTRONIC		01
03A	0503016492	ELECTRIC PHOTO SENSOR PM 100		01
03B	0503013100	NYLON CLAMP		03
04	0503015920	3/8" UNC X 1.3/4" BOLT		04
05	0503011443	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511056586	15 X 15 SEED DDD LEFT	103	01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT		01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	104	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	105	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511015098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE		01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	104	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	105	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511015098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016219	RING TO SOYBEANS		01
03	0503010025	3/8" SPRING WASHER		04
04	0503010209	3/8" UNC BUTTERFLY NUT		03
05	0503016283	M8 NUT HEX		01
06	0502020693	SUPPORT SEED BOX		01
07	0502012721	SEED DISC LOWER TRAIL		01
08	0503030083	3/8" X 3/8" X 1.6" STUD		02
09	0503016282	ALLEN BOLT		01
10	0503010675	5/16" X 2.1/4" BOLT		01
11	0503010179	LOCK WASHER		05
12	0503010337	5/16" NUT		01
13	0501010694	FLAT WASHER		04
14	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
15	0501051094	ASSY SEED DISTRIBUTOR	108	01
16	0503031508	COVER GREEN BEAM SEED YELLOW		01
17	0571018536	HEX PRISONER		01
18	0501013518	FLAT WASHER		02
19	0503034131	DEFLECTOR		01




Item	Code	Description	See page	QT
01	0502020693	SUPPORT SEED BOX		01
02	0502012721	SEED DISC LOWER TRAIL		01
03	0503034131	DEFLECTOR		01
04	0503010025	3/8" SPRING WASHER		03
05	0503010209	3/8" UNC BUTTERFLY NUT		03
06	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
07	0571018536	HEX PRISONER		01
08	0501010984	FLAT WASHER		01
09	0503010337	5/16" NUT		01
10	0503010179	LOCK WASHER		05
11	0503062582	DEPOSIT SEED		01
12	0581011346	ADAPTER DEPOSIT		01
13	0501010694	FLAT WASHER		04
14	0503016282	ALLEN BOLT		01
15	0503016283	M8 NUT HEX		01
16	0501051094	ASSY SEED DISTRIBUTOR	108	01
17	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
18	0503016219	RING TO SOYBEANS		01
19	0503010675	5/16" X 2.1/4" BOLT		01
20	0503030083	3/8" X 3/8" X 1.6" STUD		02




Item	Code	Description	See page	QT
01	0503030381	SEED DISTRIBUTOR BOX		01
02	0502010447	TRIGGER		02
03	0501013467	KEY AXLE		01
04	0503030378	0.4" X 1.1" X 0.03" SPRING		03
05	0501013466	KEY LIMITER AXLE		01
06	0501051119	DOUBLE PULLEY ROCKER'S		01
07	0501013468	ROCKER ARM AXLE, OF THE PULLEY		01
08	0503030377	SCRAPER		01




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	110	01
02	0501052538	DEPTH BAND WITH ARMS		02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING		01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING		01
07	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	113	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	112	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	111	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	SCREWEW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL BOX	114	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL BOX	114	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	COVER DEPTH		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511053550	DEPTH CONTROL ASSY	116	01
02	0511050077	WHEEL STRIPED	117	02
03	0511054333	COMPACT WHEEL RIGHT WITH BEARING		01
04	0511054334	COMPACT WHEEL LEFT WITH BEARING		01
05	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT	01	
02	0521064073	REGULACION WHEEL COMPACTOR	01	
03	0521019093	0.6" X 2.7" PIVOT SHAFT	01	
04	0503010581	RING	01	
05	0571013054	DEPTH CONTROL WHEEL AXLE	01	
06	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE	02	
07	0511015346	FLAT WASHER	04	
08	0501110720	ARM LEFT	01	
08A	0502012726	LEFT DEPTH WHEEL ARM	01	
08B	0503034375	SLEEVE ARM WHEEL DEPTH CONTROL	02	
09	0501110719	DEPTH CONTROL RIGHT ARM	01	
09A	0502012725	DEPTH WHEEL RIGHT ARM	01	
09B	0503034375	SLEEVE ARM WHEEL DEPTH CONTROL	02	
10	0511017302	FLAT WASHER	02	
11	0503011440	SPRING WASHER	04	
12	1902012116	PRESS WHEEL ADJUSTER	01	
13	0503010849	3/8" X 1-1/2" BOLT	02	
14	0503011443	3/8" SPRING WASHER	02	
15	0503010026	3/8" NUT	02	
16	0521010539	0.3" X 1.2" COUPLING SHAFT	01	
17	0503010140	1/8" X 3/4" COTTERPIN	01	
18	0502012663	EXTENSION	01	
19	0503010002	1800 GREASE FITTING	02	
20	0503010060	1/2" NUT	02	
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	02	
22	0503030805	1.6" X 6" X 0.2 TRACTION SPRING	01	
23	0541016906	PRESS WHEELS REGULATOR BODY	01	
24	0501056769	DEPTH WHEELS REGULATOR ASSY	01	
25	0503010311	1/2" X 1-1/4" BOLT	02	
26	0503010256	3/8" X 3/4" BOLT	01	



Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	118	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	LOCK WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEELS BOX		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0511056691	CONTROL DEPTH SUPPORT		01
01A	0502012282	DEPTH CONTROL SUPPORT		01
02	0571016886	DEPTH WHEEL AXLE		01
03	0503810256	SCREW		01
04	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
05	0503033942	COVER REGULATORY WHEEL		01
06	0521064073	REGULACION WHEEL COMPACTOR		01
07	0511056692	DEPTH WHEEL RIGHT ARM		01
07A	0501110796	DEPTH CONTROL RIGHT ARM		01
07Aa	0502012769	BRACO DIR RODA PROF		01
07Ab	0571016883	GLOVE NYLON		01
07B	0501052627	ASSY DEPTH WHEEL BOX	114	02
07Ba	0502011907	DEPTH CONTROL WHEEL HUB		02
07Bb	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		02
07Bc	0503010269	6204 BALL BEARING		04
07Bd	0501013636	SPACING SLEEVE		02
07Be	0503010689	SEAL 00763-BR		02
07Bf	0503011105	SEAL RING		02
07Bg	0503010878	5/8" SELF ALIGNING NUT		02
07Bh	0521019178	COVER DEPTH		02
07bi	0503030757	2.9" X 2" X 0.02" JOINT		02
07Bj	0503014729	1/4" UNF X 1/2" BOLT		06
07Bk	0503011441	SPRING WASHER		06
07Bl	0503010691	1/4" GREASE FITTING		02
07C	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07D	0503011440	SPRING WASHER		02
07E	0503010060	1/2" NUT		02
07F	0503010002	1800 GREASE FITTING		02
08	0511056693	LH ARM DEPTH CONTROL WHEEL		01
08A	0501110797	ARM LEFT GLOVE WITH DEPTH CONTROL		01
08Aa	0502012770	LEFT ARM WHEEL DEPTH		01


Item	Code	Description	See page	QT
08Ab	0571016883	GLOVE NYLON		01
09	0571017749	FLAT WASHER		02
10	0503011440	SPRING WASHER		02
11	0503010311	1/2" X 1-1/4" BOLT		02
12	0501052297	DEPTH WHEELS REGULATOR ASSY	111	01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010257	1/8" X 1" COTTERPIN		01
15	0502012116	PRESS WHEEL ADJUSTER		01
16	0503010849	3/8" X 1-1/2" BOLT		02
17	0503011443	3/8" SPRING WASHER		02
18	0503010026	3/8" NUT		02
19	0541016906	PRESS WHEELS REGULATOR BODY		01
20	0521010539	0.3" X 1.2" COUPLING SHAFT		01
21	0503010140	1/8" X 3/4" COTTERPIN		01
22	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
23	0501052538	DEPTH BAND WITH ARMS		02
24	0503010358	5/16" X 5/8" BOLT		08
25	0503010179	LOCK WASHER		08
26	0503013816	5/16" LOCKNUT		08
27	0511054333	COMPACT WHEEL RIGHT WITH BEARING		01
28	0511054334	COMPACT WHEEL LEFT WITH BEARING		01




Item	Code	Description	See page	QT
01	0511055690	WHEEL SISTEM	121	01
02	0551019650	SLEEVE 13,20 X 25 X 74		01
03	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0511055327	COMPACTING WHEEL V ASSY RUBBER	125	01




Item	Code	Description	See page	QT
01	0502012758	DEPTH CONTROL SUPPORT		01
02	0503010585	0,24" X 1.18" SPRING PIN		02
03	0503010002	1800 GREASE FITTING		01
04	0501059228	ADJUSTMENT LEVER	122	01
05	0502012611	DEPTH CONTROL AXLE		01
06	0571015326	ARTICULATION SLEEVE HANDLE		01
07	0501010984	FLAT WASHER		01
08	0503011443	3/8" SPRING WASHER		01
09	0503010237	3/8" X 1" BOLT		01
10	0571016132	PIVOT SHAFT		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0561014336	PIVOT SHAFT		01
13	0503010071	3/16" X 1" COTTERPIN		02
14	0511055628	DEPTH WHEEL SYSTEM	123	01
15	0511055629	DEPTH WHEEL SYSTEM	124	01




Item	Code	Description	See page	QT
01	0502012603	ADJUSTMENT LEVER		01
02	0502011689	1/8" DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0511015976	FLAT WASHER		01
05	0503010140	1/8" X 3/4" COTTERPIN		01




Item	Code	Description	See page	QT
01	0561014385	CARRYING-WHEELS PIVOT SHAFT		01
02	0503010019	1/2" SPRING WASHER		01
03	0511055627	WHEEL ASSY RAYED		01
04	0503016453	1/2" X 2.1/2 BOLT		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01
07	0503030012	HAIR PIN		01
08	0501110777	RIGHT WHEEL ARM		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER		01
11	0501011445	FLAT WASHER		03
12	0503012412	5/8 UNC SELF LOCKING NUT		01
13	0503011440	SPRING WASHER		01




Item	Code	Description	See page	QT
01	0571015973	CARRYING-WHEELS PIVOT SHAFT		01
02	0503010019	1/2" SPRING WASHER		01
03	0511055627	WHEEL ASSY RAYED		01
04	0503016453	1/2" X 2.1/2 BOLT		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01
07	0503030012	HAIR PIN		01
08	0501110776	ARM,LEFT		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER		01
11	0501011445	FLAT WASHER		03
12	0503012412	5/8 UNC SELF LOCKING NUT		01
13	0503011440	SPRING WASHER		01




Item	Code	Description	See page	QT
01	0571015324	COMPACT WHEEL RIGHT ARM		01
02	0571015325	LH ARM PRESS WHEELS		01
03	0541012145	SLEEV 13,5 X 25 X 18		02
04	0501058362	LARGER HANDLE ASSY		01
04A	0502011689	1/8" DEPTH CONTROL LEVER		01
04B	0521064892	REGULACION SPRING COMPACTOR		01
04C	0541012146	0.53" X 0.74" X 0.33" SLEEVE		01
04D	0503030174	COMPRESSION SPRING		01
04E	0541012143	FLAT WASHER		01
04F	0503010257	1/8" X 1" COTTERPIN		01
05	0503010479	BOLT		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0503031393	1.57" X 5.98" X 0.2" TRACTION SPRING		01
09	0501055289	HANDLE SMALLER ASSY		01
09A	0511065451	PRESS WHEEL ADJUSTER		01
09B	0511065496	PRESS WHEEL FIXER		01
09C	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
09D	0541012143	FLAT WASHER		01
09E	0503010257	1/8" X 1" COTTERPIN		01
10	0503010397	5/16" X 1-3/4" BOLT		02
11	0541012144	8,50 X 16 X 21 SLEEVE		02
12	0503011444	SPRING WASHER		02
13	0503010337	5/16" NUT		02
14	0501052908	COMPACTOR WHEEL WITH BEARING	126	02
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503013739	1/2" X 1" BOLT		01
17	0503011440	SPRING WASHER		02




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0511055326	DEPTH CONTROL PRESS WHEEL ASSY	128	01
02	0551019650	SLEEVE 13,20 X 25 X 74		01
03	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0511055327	COMPACTING WHEEL V ASSY RUBBER	125	01




Item	Code	Description	See page	QT
01	0502012758	DEPTH CONTROL SUPPORT		01
02	0503010585	0,24" X 1.18" SPRING PIN		02
03	0503010002	1800 GREASE FITTING		01
04	0501059228	ADJUSTMENT LEVER	122	01
05	0502012611	DEPTH CONTROL AXLE		01
06	0571015326	ARTICULATION SLEEVE HANDLE		01
07	0501010984	FLAT WASHER		01
08	0503011443	3/8" SPRING WASHER		01
09	0503010237	3/8" X 1" BOLT		01
10	0571016132	PIVOT SHAFT		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0561014336	PIVOT SHAFT		01
13	0503010071	3/16" X 1" COTTERPIN		02
14	0511055328	DEPTH WHEEL SYSTEM	129	01
15	0511055329	LEFT DEPTH WHEEL	130	01




Item	Code	Description	See page	QT
01	0561014385	CARRYING-WHEELS PIVOT SHAFT		01
02	0501110777	RIGHT WHEEL ARM		01
03	0503010019	1/2" SPRING WASHER		01
04	0511055627	WHEEL ASSY RAYED		01
05	0503016453	1/2" X 2.1/2 BOLT		01
06	0503010060	1/2" NUT		01
07	0503010002	1800 GREASE FITTING		01
08	0503030012	HAIR PIN		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER		01
11	0501011445	FLAT WASHER		03
12	0571015974	WASHER		01
13	0503012412	5/8 UNC SELF LOCKING NUT		01
14	0503011440	SPRING WASHER		01




Item	Code	Description	See page	QT
01	0571015973	CARRYING-WHEELS PIVOT SHAFT		01
02	0503010019	1/2" SPRING WASHER		01
03	0511055627	WHEEL ASSY RAYED		01
04	0503016453	1/2" X 2.1/2 BOLT		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01
07	0503030012	HAIR PIN		01
08	0501110776	ARM,LEFT		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER		01
11	0501011445	FLAT WASHER		03
12	0571015974	WASHER		01
13	0503012412	5/8 UNC SELF LOCKING NUT		01
14	0503011440	SPRING WASHER		01




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT	01	
02	0521019093	0.6" X 2.7" PIVOT SHAFT	01	
03	0503010257	1/8" X 1" COTTERPIN	01	
04	0571013054	DEPTH CONTROL WHEEL AXLE	01	
05	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE	02	
06	0511015346	FLAT WASHER	04	
07	0501110720	ARM LEFT	01	
07A	0502012726	LEFT DEPTH WHEEL ARM	01	
07B	0503034375	SLEEVE ARM WHEEL DEPTH CONTROL	02	
08	0501110719	DEPTH CONTROL RIGHT ARM	01	
08A	0501110720	ARM LEFT	01	
08B	0503034375	SLEEVE ARM WHEEL DEPTH CONTROL	02	
09	0511017302	FLAT WASHER	02	
10	0503011440	SPRING WASHER	04	
11	0502012663	EXTENSION	01	
12	0503010002	1800 GREASE FITTING	02	
13	0503010060	1/2" NUT	02	
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	02	
15	0503031393	1.57" X 5.98" X 0.2"TRACTION SPRING	01	
16	0501056769	DEPTH WHEELS REGULATOR ASSY	01	
17	0503010311	1/2" X 1-1/4" BOLT	02	
18	0503010256	3/8" X 3/4" BOLT	01	
19	0511059463	COMFORT WHEEL WITH FAST ADJUSTMENT	01	




Item	Code	Description	See page	QT
01	0511059462	DEPTH CONTROL WITH FAST ADJUSTMENT	131	01
02	0511050077	WHEEL STRIPED	117	02
03	0503016453	1/2" X 2.1/2" BOLT		02
04	0503010019	1/2" SPRING WASHER		04
05	0503010028	1/2" NUT		02
06	0501052908	COMPACTOR WHEEL WITH BEARING	126	02
07	0503010752	1/2" X 3.1/2" BOLT		01
08	0503013739	1/2" X 1" BOLT		01




Item	Code	Description	See page	QT
01	0511052971	SEMI-ASSEMBLED DEPTH CONTROL WITH THREAD	134	01
02	0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	135	01
03	0501052908	COMPACTOR WHEEL WITH BEARING	126	02
04	0503010019	1/2" SPRING WASHER		06
05	0503010752	1/2" X 3.1/2" BOLT		01
06	0503013739	1/2" X 1" BOLT		01
07	0503010479	BOLT		02
08	0503010060	1/2" NUT		04
09	0503030012	HAIR PIN		01
10	0571013222	FIXING CHOCK		01
11	0503010741	1/2" X 2-3/4" BOLT		02
12	0511055819	DEPTH WHIT AROS BAND	136	02
13	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
14	0503013816	5/16" LOCKNUT		08




Item	Code	Description	See page	QT
01	0521063808	DEPTH CONTROL INNER COLUMN CONTROL WITH SCREW		01
02	0521063809	DEPTH CONTROL EXTERNAL COLUMN CONTROL WITH SCREW		01
03	0571013194	REGULATOR SPINDLE		01
04	0551010616	ROD HEX		01
05	0503010683	0,2" X 1,2" SPRING PIN		01
06	0571013202	REGULATOR AXLE WHEELS COBRIDORA		01
07	0521063812	REGULATOR LEVER ALXE		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		01
09	0511065308	LOCK REGULATOR		01
10	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
11	0541011627	FLAT WASHER		01
12	0503010140	1/8" X 3/4" COTTERPIN		01
13	0511059325	LEFT ARM COVERED WHEEL ASSEMBLED	137	01
14	0511059324	RIGHT ARM COVERED WHEEL ASSEMBLED	138	01
15	0571014709	SLEEVE LOCK CONTROL ARM		02
16	0503011440	SPRING WASHER		03
17	0503819099	BOLT		02
18	0511051546	CUBE RIGHT CONTROL DEPTH	139	01
19	0511051547	LEFT CUBE CONTROL DEPTH	140	01
20	0503011442	3/4" SPRING WASHER		02
21	0571013189	SLEEVE SUPPORT BEATER		01
22	0521063813	WHEEL PRESS BEATER		01
23	0501010937	13.5 X 28 X 3 FLAT WASHER		01
24	0503010920	1/2" X 1.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502012850	PRESS WHEELS ARM	01	01
02	0503030883	RIGHT TORSION SPRING	01	01
03	0502011066	PRESS WHEELS ARM SUPPORT	01	01
04	0531017415	1" X 4.72" AXLE JOINT	01	01
05	0503010839	03"X 0.6" SPRING PIN	01	01
06	0521063841	REGULATOR RIGHT COMPACTOR	01	01
07	0521063842	REGULATOR LEFT COMPACTOR	01	01
08	0503811404	BOLT	02	02
09	0503011443	3/8" SPRING WASHER	02	02
10	0503010026	3/8" NUT	02	02
11	0571013295	ALXE REGULATOR COMPACTOR	01	01
12	0521063812	REGULATOR LEVER ALXE	01	01
13	0503011336	1/2" HEX SELF ADJUSTING NUT	02	02
14	0511065308	LOCK REGULATOR	01	01
15	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING	01	01
16	0541011627	FLAT WASHER	01	01
17	0503010140	1/8" X 3/4" COTTERPIN	01	01
18	0571013293	SLEEVE LOCK COMPACTOR V CONTROL WITH SCREW	01	01
19	0503811172	BOLT	01	01
20	0503010002	1800 GREASE FITTING	01	01
21	0581013744	PROTECTION COVER - CPRA	01	01
22	0503813096	BOLT	01	01
23	0503013816	5/16" LOCKNUT	0	0




Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503013758	1/4" X 1-1/2" BOLT		05
04	0503013814	1/4" NC LOCKNUT		05




Item	Code	Description	See page	QT
01	0502012844	LEFT ARM WHEELS		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	GLOVE SUPPORT ARM WHEEL COBRIDORA		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012843	RIGHT WHEEL ARM		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	GLOVE SUPPORT ARM WHEEL COBRIDORA		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB		01
02	0511066638	AXLE WHEEL RIGHT DEPTH WITH DOOR DUST		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	COVER DEPTH		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB		01
02	0511066637	AXLE WHEEL LEFT DEPTH WITH DOOR DUST		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	COVER DEPTH		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0571015538	SLEEVE 37 X 28,3 X 16,70		01
02	0503012412	5/8 UNC SELF LOCKING NUT		01
03	0503010691	1/4" GREASE FITTING		01
04	0503011336	1/2" HEX SELF ADJUSTING NUT		04
05	0511017302	FLAT WASHER		04
06	0503010384	1/2" X 5" BOLT		02
07	0503010547	1/2" X 4" BOLT		02
08	0503010417	7/8" NUT		01
09	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
10	0521064736	FERTILIZER SOCKET		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
12	0501010984	FLAT WASHER		04
13	0503010025	3/8" SPRING WASHER		02
14	0503010026	3/8" NUT		02
15	0521064739	ROD SUPPORT		01
16	0571015616	GUIDE SPRING SUPPORT		01
17	0571015552	BOLT FIXER		01
18	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
19	0503034106	80 X 230 X 16,50 HDA COMPRESSSION SPRING		01
20	0511058935	ROD WITH POINT FLANGE WASHER SPRING HDA	142	01




Item	Code	Description	See page	QT
01	0511070103	FLANGE WASHER		01
02	0571017723	FLAT WASHER		01
03	0503012104	501015 CLAMPING RING (FOR AXLE)		01
04	0571015521	PIN LOCK STEM		01
05	0501110780	ROD WITH ARM		01
05A	0521064728	SCARIFIER SPINDLE ASSY		01
05B	0503016853	SPRING PIN		02
05C	0503011402	0.2" X 0.8" SPRING PIN		02
05D	0521066870	POINT SUBSOILER		01




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0521063363	RIGHT SUPPORT COVERING WHEEL FERTILIZER IRON		01
02	0503010795	5/8" X 7" BOLT		01
03	0503012412	5/8 UNC SELF LOCKING NUT		01
04	0531016207	0.6" X 1" X 2.8" SLEEVE		01
05	0521063362	SUPPORT ARTICULATION COVERING WHEEL FERTILIZER IRON		01
06	0501010452	5/8" X 5" BOLT		01
07	0501012140	FLAT WASHER		02
08	0503012412	5/8 UNC SELF LOCKING NUT		01
09	0503010002	1800 GREASE FITTING		01
10	0511052086	LEFT WHEEL COVERING IRON FERTILIZER		01




Item	Code	Description	See page	QT
01	0521063364	LEFT SUPPORT COVERING WHEEL FERTILIZER IRON		01
02	0503010795	5/8" X 7" BOLT		01
03	0503012412	5/8 UNC SELF LOCKING NUT		01
04	0531016207	0.6" X 1" X 2.8" SLEEVE		01
05	0521063362	SUPPORT ARTICULATION COVERING WHEEL FERTILIZER IRON		01
06	0501010452	5/8" X 5" BOLT		01
07	0501012140	FLAT WASHER		02
08	0503012412	5/8 UNC SELF LOCKING NUT		01
09	0503010002	1800 GREASE FITTING		01
10	0511052086	LEFT WHEEL COVERING IRON FERTILIZER		01




Item	Code	Description	See page	QT
01	0521062253	RIGHT PRESS WHEEL FERT UP SUPPORT	01	
02	0511064128	PRESS SUPPORT LOWWER WHEEL	01	
03	0503010752	1/2" X 3.1/2" BOLT	01	
04	0531013272	0.5" X 1" X 2.2" SLEEVE	01	
05	0503010019	1/2" SPRING WASHER	01	
06	0503010060	1/2" NUT	01	
07	0501013491	5/8" TENSIONER SPRING	01	
08	0503010013	5/8" NUT	02	
09	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING	01	
10	0503010002	1800 GREASE FITTING	01	
11	0503010849	3/8" X 1-1/2" BOLT	02	
12	0503010025	3/8" SPRING WASHER	02	
13	0503010026	3/8" NUT	02	
14	0503010795	5/8" X 7" BOLT	01	
15	0503012412	5/8 UNC SELF LOCKING NUT	01	
16	0502011757	PRESS REGULATOR	01	
17	0511054333	COMPACT WHEEL RIGHT WITH BEARING	01	
18	0511054334	COMPACT WHEEL LEFT WITH BEARING	01	




Item	Code	Description	See page	QT
01	0521062254	LEFT PRESS WHEEL FERT UPPER SUPPORT	01	
02	0511064128	PRESS SUPPORT LOWWER WHEEL	01	
03	0503010752	1/2" X 3.1/2" BOLT	01	
04	0531013272	0.5" X 1" X 2.2" SLEEVE	01	
05	0503010019	1/2" SPRING WASHER	01	
06	0503010060	1/2" NUT	01	
07	0501013491	5/8" TENSIONER SPRING	01	
08	0503010013	5/8" NUT	02	
09	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING	01	
10	0503010002	1800 GREASE FITTING	01	
11	0503010849	3/8" X 1-1/2" BOLT	02	
12	0503010025	3/8" SPRING WASHER	02	
13	0503010026	3/8" NUT	02	
14	0503010795	5/8" X 7" BOLT	01	
15	0503012412	5/8 UNC SELF LOCKING NUT	01	
16	0502011757	PRESS REGULATOR	01	
17	0511054333	COMPACT WHEEL RIGHT WITH BEARING	01	
18	0511054334	COMPACT WHEEL LEFT WITH BEARING	01	




Item	Code	Description	See page	QT
01	0521052831	DEPTH WHEEL SYSTEM	149	01
02	0521052825	SUPPORT WHEELS COMPACTORS	150	01
03	0551019650	SLEEVE 13,20 X 25 X 74		01
04	0503031393	1.57" X 5.98" X 0.2" TRACTION SPRING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0503010547	1/2" X 4" BOLT		01
08	0501052908	COMPACTOR WHEEL WITH BEARING	126	02
09	0503010019	1/2" SPRING WASHER		02
10	0503013739	1/2" X 1" BOLT		01
11	0503010752	1/2" X 3.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502012758	DEPTH CONTROL SUPPORT		01
02	0501059228	ADJUSTMENT LEVER	122	01
03	0571016132	PIVOT SHAFT		01
04	0503010071	3/16" X 1" COTTERPIN		01
05	0502012611	DEPTH CONTROL AXLE		01
06	0503010002	1800 GREASE FITTING		01
07	0571015326	ARTICULATION SLEEVE HANDLE		01
08	0521052835	RIGHT DEPTH WHEEL		01
09	0501010984	FLAT WASHER		01
10	0503011443	3/8" SPRING WASHER		01
11	0503010237	3/8" X 1" BOLT		01
12	0521052834	LEFT DEPTH WHEEL		01
13	0581017075	LARGER AXLE		01
14	0581017076	SMALLER AXLE		01
15	0581017077	CARRYING-WHEELS PIVOT SHAFT		02
16	0501011445	FLAT WASHER		04
17	0511017302	FLAT WASHER		02
18	0503011336	1/2" HEX SELF ADJUSTING NUT		02
19	0503030012	HAIR PIN		04
20	0503011402	0.2" X 0.8" SPRING PIN		02
21	0503012795	5/8" HEX SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521068514	LEFT SIDE BASE		01
02	0521068660	RIGHT SIDE BASE		01
03	0581014969	SLEEVE GUIDE		01
04	0581014968	SLEEVE FLANGE		01
05	0581014847	PLATE UPPER		01
06	0521068661	LEVER		01
07	0503030878	LEVER CRANK		01
08	0521068004	HANDLE BODY		01
09	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
10	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
11	0581015855	SLEEVE		02
12	0503010882	BOLT		02
13	0503010179	LOCK WASHER		04
14	0503010337	5/16" NUT		04
15	0503010847	1/2" X 3.1/4" BOLT		01
16	0503010019	1/2" SPRING WASHER		01
17	0503010060	1/2" NUT		01
18	0503010937	5/16" X 3" BOLT		02
19	0581015853	LEFT PROTECTION COVER		02
20	0581015854	RIGHT PROTECTION COVER		02
21	0581015903	SPACER WASHER		01




Item	Code	Description	See page	QT
01	0503030379	LARGER ROCKER ARM		01
02	0502060001	PLASTIC PULLEY FOR MAIZE		01
03	0503010669	FLAT WASHER		01
04	0503010667	3/16" NUT		02
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		01




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	
02	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01	
03	0541018684	FLAT WASHER	01	
04	0503010756	0.2" X 2.4" SPRING PIN	01	
05	0503010361	SPRING PIN	01	
06	0503010003	1845 GREASE FITTING	01	
07	0521014137	RIGHT ARM OF THE BLADE DISC	01	
08	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503013185	3/4" X 5-1/2" BOLT	01	
12	0503011255	3/4" LOCK NUT	01	
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
14	0503011411	1/2" X 5-1/2" BOLT	01	
15	0503010019	1/2" SPRING WASHER	01	
16	0503010060	1/2" NUT	01	
17	0502020393	SPRING UPPER SUPPORT	01	
18	0502020394	SPRING SUPPORT	01	
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
20	0503010014	3/4" NUT	02	
21	0521054680	CUTTING DISC BOX 20	01	



Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	
02	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE	01	
03	0541018684	FLAT WASHER	01	
04	0503010756	0.2" X 2.4" SPRING PIN	01	
05	0503010361	SPRING PIN	01	
06	0503010003	1845 GREASE FITTING	01	
07	0521014137	RIGHT ARM OF THE BLADE DISC	01	
08	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503013185	3/4" X 5-1/2" BOLT	01	
12	0503011255	3/4" LOCK NUT	01	
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
14	0503011411	1/2" X 5-1/2" BOLT	01	
15	0503010019	1/2" SPRING WASHER	01	
16	0503010060	1/2" NUT	01	
17	0502020393	SPRING UPPER SUPPORT	02	
18	0502020394	SPRING SUPPORT	01	
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
20	0503010014	3/4" NUT	02	
21	0521054680	CUTTING DISC BOX 20	01	



Item	Code	Description	See page	QT
01	0502011562	DC BOX		01
02	0503010276	6206 BALL BEARING		02
03	0521013610	BLADE DISC HUB AXLE		01
04	0503030832	FLAT WASHER		02
05	0503012417	SEAL		02
06	0503011800	SEAL RING		02
07	0503010691	1/4" GREASE FITTING		01
08	0603027851	20" X 0.2" FLAT PLAIN DISC		01
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0503011444	SPRING WASHER		06
12	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
001	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01	
002	0502012368	BLADE DISC SUPPORT AXLE	01	
003	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN	02	
004	0503010361	SPRING PIN	01	
005	0541018684	FLAT WASHER	01	
006	0521014137	RIGHT ARM OF THE BLADE DISC	01	
007	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
008	0501067323	SPRING REGULATOR	01	
009	0521010452	SLEEVE	01	
010	0503013185	3/4" X 5-1/2" BOLT	01	
011	0503011255	3/4" LOCK NUT	01	
012	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
013	0503011411	1/2" X 5-1/2" BOLT	01	
014	0503011440	SPRING WASHER	01	
015	0503010060	1/2" NUT	01	
016	1902020393	SPRING UPPER SUPPORT	01	
017	1902020394	SPRING SUPPORT	01	
018	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
019	0503010014	3/4" NUT	02	
020	0521015376	DUST CLOAK	02	
021	0502011562	DC BOX	01	
022	0503010276	6206 BALL BEARING	02	
023	0521013610	BLADE DISC HUB AXLE	01	
024	0503030832	FLAT WASHER	02	
025	0503012417	SEAL	02	
026	0503011800	SEAL RING	02	
027	0503010691	1/4" GREASE FITTING	01	
028	0607026008	20" PLAIN COULTER BLADE	01	
029	0502020641	BLADE DISC FLANGE	01	
030	0503010371	5/16" X 1" BOLT	06	
031	0503011444	SPRING WASHER	06	



**PST4 FLEX - FRAME 4045/4495/4845/5345 - CSU (UP TO
DC 20 ASSY SHORT**

Page 155
0511045593

Item	Code	Description	See page	QT
032	0503010337	5/16" NUT		06
033	0511015346	FLAT WASHER		02
034	0503011442	3/4" SPRING WASHER		02
035	0521013510	3/4" NUT		02
036	0503010003	1845 GREASE FITTING		01
037	1882970002	GREASE SOAP		00




Item	Code	Description	See page	QT
001	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE	01	
002	0502012368	BLADE DISC SUPPORT AXLE	01	
003	0541018684	FLAT WASHER	01	
004	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN	02	
005	0503010361	SPRING PIN	01	
006	0521014137	RIGHT ARM OF THE BLADE DISC	01	
007	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
008	0501067323	SPRING REGULATOR	01	
009	0521010452	SLEEVE	01	
010	0503013185	3/4" X 5-1/2" BOLT	01	
011	0503011255	3/4" LOCK NUT	01	
012	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
013	0503011411	1/2" X 5-1/2" BOLT	01	
014	0503011440	SPRING WASHER	01	
015	0503010060	1/2" NUT	01	
016	1902020393	SPRING UPPER SUPPORT	01	
017	1902020394	SPRING SUPPORT	01	
018	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
019	0503010014	3/4" NUT	02	
020	0502011562	DC BOX	01	
021	0503010276	6206 BALL BEARING	02	
022	0521013610	BLADE DISC HUB AXLE	01	
023	0503030832	FLAT WASHER	02	
024	0503012417	SEAL	02	
025	0503011800	SEAL RING	02	
026	0503010691	1/4" GREASE FITTING	01	
027	0607026008	20" PLAIN COULTER BLADE	01	
028	0502020641	BLADE DISC FLANGE	01	
029	0503010371	5/16" X 1" BOLT	06	
030	0503011444	SPRING WASHER	06	
031	0503010337	5/16" NUT	06	




**PST4 FLEX - FRAME 4045/4495/4845/5345 - CSU (UP TO
ASSY LONG DC 20**

Page 156
0511045594


Item	Code	Description	See page	QT
032	0521015376	DUST CLOAK		02
033	0511015346	FLAT WASHER		02
034	0503011438	SPRING WASHER		02
035	0521013510	3/4" NUT		02
036	0503010003	1845 GREASE FITTING		01
037	1882970002	GREASE SOAP		00



Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	
02	0503010003	1845 GREASE FITTING	01	
03	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01	
04	0521014137	RIGHT ARM OF THE BLADE DISC	01	
05	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
06	0521054686	CUTTING DISC BOX 18	01	
07	0503010756	0.2" X 2.4" SPRING PIN	01	
08	0503010361	SPRING PIN	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503011255	3/4" LOCK NUT	01	
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
13	1902020394	SPRING SUPPORT	01	
14	1902020393	SPRING UPPER SUPPORT	01	
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
16	0503010014	3/4" NUT	02	
17	0541018684	FLAT WASHER	01	
18	0503013185	3/4" X 5-1/2" BOLT	01	
19	0503010019	1/2" SPRING WASHER	01	
20	0503010060	1/2" NUT	01	
21	0503011411	1/2" X 5-1/2" BOLT	01	



Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	
02	0503010003	1845 GREASE FITTING	01	
03	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE	01	
04	0521014137	RIGHT ARM OF THE BLADE DISC	01	
05	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
06	0521054686	CUTTING DISC BOX 18	01	
07	0503010756	0.2" X 2.4" SPRING PIN	01	
08	0503010361	SPRING PIN	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503011255	3/4" LOCK NUT	01	
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
13	1902020394	SPRING SUPPORT	01	
14	1902020393	SPRING UPPER SUPPORT	01	
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
16	0503010014	3/4" NUT	02	
17	0541018684	FLAT WASHER	01	
18	0503013185	3/4" X 5-1/2" BOLT	01	
19	0503010019	1/2" SPRING WASHER	01	
20	0503010060	1/2" NUT	01	
21	0503011411	1/2" X 5-1/2" BOLT	01	




Item	Code	Description	See page	QT
01	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01	
02	0502012368	BLADE DISC SUPPORT AXLE	01	
03	0503010756	0.2" X 2.4" SPRING PIN	01	
04	0503010361	SPRING PIN	01	
05	0541018684	FLAT WASHER	01	
06	0521014137	RIGHT ARM OF THE BLADE DISC	01	
07	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
08	0501067323	SPRING REGULATOR	01	
09	0521010452	SLEEVE	01	
10	0503013185	3/4" X 5-1/2" BOLT	01	
11	0503011255	3/4" LOCK NUT	01	
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
13	0503011411	1/2" X 5-1/2" BOLT	01	
14	0503011440	SPRING WASHER	01	
15	0503010060	1/2" NUT	01	
16	1902020393	SPRING UPPER SUPPORT	01	
17	0502020394	SPRING SUPPORT	01	
18	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
19	0503010014	3/4" NUT	02	
20	0521015376	DUST CLOAK	02	
21	0502011562	DC BOX	01	
22	0503010276	6206 BALL BEARING	02	
23	0521013610	BLADE DISC HUB AXLE	01	
24	0503030832	FLAT WASHER	02	
25	0503012417	SEAL	02	
26	0503011800	SEAL RING	02	
27	0503010691	1/4" GREASE FITTING	01	
28	0607025008	PLAIN COULTER BLADE	01	
29	0502020641	BLADE DISC FLANGE	01	
30	0503010371	5/16" X 1" BOLT	06	
31	0503011444	SPRING WASHER	06	



**PST4 FLEX - FRAME 4045/4495/4845/5345 - CSU (UP TO
FULL DC DPLO 18 CT**

Page 159
0511047378

Item	Code	Description	See page	QT
32	0503010337	5/16" NUT		06
33	0511815346	FLAT WASHER		02
34	0503011442	3/4" SPRING WASHER		02
35	0521813510	R3/4UNC NUT		02
36	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE		01
02	0502012368	BLADE DISC SUPPORT AXLE		01
03	0503010756	0.2" X 2.4" SPRING PIN		01
04	0503010361	SPRING PIN		01
05	0541018684	FLAT WASHER		01
06	0521014137	RIGHT ARM OF THE BLADE DISC		01
07	0521014138	SUPPORT ARM LEFT BALDE DISC		01
08	0501067323	SPRING REGULATOR		01
09	0521010452	SLEEVE		01
10	0503013185	3/4" X 5-1/2" BOLT		01
11	0503011255	3/4" LOCK NUT		01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
13	0503011411	1/2" X 5-1/2" BOLT		01
14	0503011440	SPRING WASHER		01
15	0503010060	1/2" NUT		01
16	1902020393	SPRING UPPER SUPPORT		01
17	0502020394	SPRING SUPPORT		01
18	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
19	0503010014	3/4" NUT		02
20	0521015376	DUST CLOAK		02
21	0502011562	DC BOX		01
22	0503010276	6206 BALL BEARING		02
23	0521013610	BLADE DISC HUB AXLE		01
24	0503030832	FLAT WASHER		02
25	0503012417	SEAL		02
26	0503011800	SEAL RING		02
27	0503010691	1/4" GREASE FITTING		01
28	0607025008	PLAIN COULTER BLADE		01
29	0502020641	BLADE DISC FLANGE		01
30	0503010371	5/16" X 1" BOLT		06
31	0503011444	SPRING WASHER		06




**PST4 FLEX - FRAME 4045/4495/4845/5345 - CSU (UP TO
FULL DC DPLO 18 LG**

Page 160
0511047379


Item	Code	Description	See page	QT
32	0503010337	5/16" NUT		06
33	0511815346	FLAT WASHER		02
34	0503011442	3/4" SPRING WASHER		02
35	0521813510	R3/4UNC NUT		02
36	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521062253	RIGHT PRESS WHEEL FERT UP SUPPORT	01	
02	0511064128	PRESS SUPPORT LOWWER WHEEL	01	
03	0503010752	1/2" X 3.1/2" BOLT	01	
04	0531013272	0.5" X 1" X 2.2" SLEEVE	01	
05	0503010019	1/2" SPRING WASHER	01	
06	0503010060	1/2" NUT	01	
07	0501013491	5/8" TENSIONER SPRING	01	
08	0503010013	5/8" NUT	02	
09	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING	01	
10	0503010002	1800 GREASE FITTING	01	
11	0503010849	3/8" X 1-1/2" BOLT	02	
12	0503010025	3/8" SPRING WASHER	02	
13	0503010026	3/8" NUT	02	
14	0503010795	5/8" X 7" BOLT	01	
15	0503012412	5/8 UNC SELF LOCKING NUT	01	
16	0502011757	PRESS REGULATOR	01	
17	0511054837	RH IRON PRESS WHEEL	01	
18	0511054838	LH IRON PRESS WHEEL	01	




Item	Code	Description	See page	QT
01	0521062254	LEFT PRESS WHEEL FERT UPPER SUPPORT	01	
02	0511064128	PRESS SUPPORT LOWWER WHEEL	01	
03	0503010752	1/2" X 3.1/2" BOLT	01	
04	0531013272	0.5" X 1" X 2.2" SLEEVE	01	
05	0503010019	1/2" SPRING WASHER	01	
06	0503010060	1/2" NUT	01	
07	0501013491	5/8" TENSIONER SPRING	01	
08	0503010013	5/8" NUT	02	
09	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING	01	
10	0503010002	1800 GREASE FITTING	01	
11	0503010849	3/8" X 1-1/2" BOLT	02	
12	0503010025	3/8" SPRING WASHER	02	
13	0503010026	3/8" NUT	02	
14	0503010795	5/8" X 7" BOLT	01	
15	0503012412	5/8 UNC SELF LOCKING NUT	01	
16	0502011757	PRESS REGULATOR	01	
17	0511054837	RH IRON PRESS WHEEL	01	
18	0511054838	LH IRON PRESS WHEEL	01	




Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD	01	
02	0502040534	SPRING GUIDE BUSHING LOCK	02	
03	0502012184	FERTILIZER SPRING GUIDE	02	
04	0503031910	1.7" X 22.8" X 0.3" SPRING	01	
05	0502012510	SPRING ROD SUPPORT	01	
06	0503010257	1/8" X 1" COTTERPIN	01	
07	0501018535	1/2 X 1 BOLT	02	
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	02	
09	0503010060	1/2" NUT	02	
10	1902010891	SPRING CHOCK SUPPORT VARON	01	
11	0503010014	3/4" NUT	01	
12	0561014471	COUPLING SHAFT	01	
13	0511017302	FLAT WASHER	01	



Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	NUT		02



Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0502010175	HITCH CLAMP		01
03	0501011543	5/8" X 4" BOLT		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC		01
06	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC		00
07	0501010066	3/4" X 9" BOLT		01
08	0521017831	SUPPORT SLEEVE SPACER		02
09	0511017232	FLAT WASHER		02
10	0503011255	3/4" LOCK NUT		01
11	0501058423	FERTILIZER ROD SPRING ROW	163	01
12	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	152	01
12.	0511045593	DC 20 ASSY SHORT	155	01
13	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	153	00
13.	0511045594	ASSY LONG DC 20	156	01
14	0503030391	RIGHT FERTILIZER NOZZLE		01
15	0503030392	LEFT FERTILIZER NOZZLE		00
16	0503031050	CURVED CONDUCTOR		01
17	0503010246	CLAMP		01
18	0503031145	2" X 2" X 20" HOSE		01
19	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0502010175	HITCH CLAMP		01
03	0501011543	5/8" X 4" BOLT		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0521061153	LONG ARM FERTILIZER LINE		00
07	0501010066	3/4" X 9" BOLT		01
08	0521017831	SUPPORT SLEEVE SPACER		02
09	0511017232	FLAT WASHER		02
10	0503011255	3/4" LOCK NUT		01
11	0501058423	FERTILIZER ROD SPRING ROW	163	01
12	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	152	01
13	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	153	00
14	0503031050	CURVED CONDUCTOR		01
15	0503010246	CLAMP		01
16	0503031145	2" X 2" X 20" HOSE		01
17	0503031076	2" HOSE CLAMP		02
18	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
18A	0511061768	FERTILIZER SCARIFIER ROD		01
18B	0501056132	POINT SUBSOILER		01
18BA	0502070061	POINT SUBSOILER		01
18BB	0503010585	0.24" X 1.18" SPRING PIN		01
18BC	0503011373	0.4" X 1.1" SPRING PIN		01
19	0511017969	0.1" SPACING PLATE		01
20	0511061852	ADJUSTMENT CONDUCTOR FERTILIZER		01
20.	0521069127	BOTTOM NOZZLE FERTILIZER		01
21	0503010547	1/2" X 4" BOLT		02
22	0503011440	SPRING WASHER		02
23	0503010060	1/2" NUT		02
24	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
25	0501010984	FLAT WASHER		01




**PST4 FLEX - FRAME 4045/4495/4845/5345 - CSU (UP TO
FERTILIZER LINE WITH STEM**

Page 166
0909092327


Item	Code	Description	See page	QT
26	0503010025	3/8" SPRING WASHER		01
27	0503010026	3/8" NUT		01
28	0521044545	20" SHORT CURVED CORRIGATED DISC		04
29	0521044546	20" LONG CURVED CORRUGATED DISC		03




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0502010175	HITCH CLAMP		01
03	0501011543	5/8" X 4" BOLT		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0521061153	LONG ARM FERTILIZER LINE		00
07	0501010066	3/4" X 9" BOLT		01
08	0521017831	SUPPORT SLEEVE SPACER		02
09	0511017232	FLAT WASHER		02
10	0503011255	3/4" LOCK NUT		01
11	0501058423	FERTILIZER ROD SPRING ROW	163	01
12	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	152	01
13	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	153	00
14	0503031050	CURVED CONDUCTOR		01
15	0503010246	CLAMP		01
16	0503031145	2" X 2" X 20" HOSE		01
17	0503031076	2" HOSE CLAMP		02
18	0501110723	SCARIFIER ROD		01
18A	0521063867	SCARIFIER ROD		01
18B	0502070082	POINT SUBSOILER		01
18C	0503010585	0,24" X 1.18" SPRING PIN		03
19	0511017969	0.1" SPACING PLATE		01
20	0511061852	ADJUSTMENT CONDUCTOR FERTILIZER		01
20.	0521069127	BOTTOM NOZZLE FERTILIZER		01
21	0503010547	1/2" X 4" BOLT		02
22	0503011440	SPRING WASHER		02
23	0503010060	1/2" NUT		02
24	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
25	0501010984	FLAT WASHER		01
26	0503010025	3/8" SPRING WASHER		01
27	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0502010175	HITCH CLAMP		01
03	0501011543	5/8" X 4" BOLT		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC		01
06	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC		00
07	0501010066	3/4" X 9" BOLT		01
08	0521017831	SUPPORT SLEEVE SPACER		02
09	0511017232	FLAT WASHER		02
10	0503011255	3/4" LOCK NUT		01
11	0501058423	FERTILIZER ROD SPRING ROW	163	01
12	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	157	01
13	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	158	00
14	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	152	01
15	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	153	01
16	0503030391	RIGHT FERTILIZER NOZZLE		01
17	0503030392	LEFT FERTILIZER NOZZLE		00
18	0503031050	CURVED CONDUCTOR		01
19	0503010246	CLAMP		01
20	0503031145	2" X 2" X 20" HOSE		01
21	0503031076	2" HOSE CLAMP		02
22	0521044545	20" SHORT CURVED CORRIGATED DISC		04
23	0521044546	20" LONG CURVED CORRUGATED DISC		03
24	0909092327	FERTILIZER LINE WITH STEM	166	




Item	Code	Description	See page	QT
01	0511058100	2 BOXES WITH 9 CONDUCTORS ASSEMBLY	173	01
02	0521051927	TOWER SUPPORT HOPPER	178	04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0511057919	2 BOXES WITH 11 CONDUCTORS ASSEMBLY	174	01
02	0521051927	TOWER SUPPORT HOPPER	178	04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0511057737	2 BOXES WITH 10 CONDUCTORS ASSEMBLY	175	01
02	0521051927	TOWER SUPPORT HOPPER	178	04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0521064748	05 MOUTHS CSU SUPPORT		02
02	0503061987	SILO FERTILIZER 05 MOUTHS FRONT MOUNTED		02
03	0521063401	SEED BOX ONLY FIXING LOCK		04
04	0501010984	FLAT WASHER		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	177	07
08	0501010942	3/8" X 1-1/4" BOLT		28
09	0503010025	3/8" SPRING WASHER		28
10	0503010026	3/8" NUT		28
11	0571015773	SUPPORT SEED		03
12	0501011643	3/8 X 1"BOLT		12
13	0503010025	3/8" SPRING WASHER		12
14	0503010026	3/8" NUT		12




Item	Code	Description	See page	QT
01	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS		02
02	0503061899	REAR BEAN FERTILIZER ASSY		02
03	0521063401	SEED BOX ONLY FIXING LOCK		04
04	0501010984	FLAT WASHER		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	177	09
08	0501010942	3/8" X 1-1/4" BOLT		36
09	0503010025	3/8" SPRING WASHER		36
10	0503010026	3/8" NUT		36
11	0571015773	SUPPORT SEED		03
12	0501011643	3/8 X 1"BOLT		12
13	0503010025	3/8" SPRING WASHER		12
14	0503010026	3/8" NUT		12




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		04
02	0501010984	FLAT WASHER		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	3" ARTICULATED SEED CONDUCTOR	177	11
06	0571015773	SUPPORT SEED		03
07	0501011643	3/8 X 1"BOLT		12
08	0501010942	3/8" X 1-1/4" BOLT		44
09	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		02
02	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02
03	0521063401	SEED BOX ONLY FIXING LOCK		04
04	0501010984	FLAT WASHER		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	177	10
08	0501010942	3/8" X 1-1/4" BOLT		40
09	0503010025	3/8" SPRING WASHER		40
10	0503010026	3/8" NUT		40
11	0571015773	SUPPORT SEED		04
12	0501011643	3/8 X 1"BOLT		16
13	0503010025	3/8" SPRING WASHER		16
14	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION	01	
02	0501010942	3/8" X 1-1/4" BOLT	01	
03	0503010025	3/8" SPRING WASHER	03	
04	0501010984	FLAT WASHER	03	
05	0503010026	3/8" NUT	02	
06	0503010209	3/8" UNC BUTTERFLY NUT	01	
07	0501011898	3/8" X 1-1/4" BOLT	02	
08	0501010984	FLAT WASHER	03	
09	0503010025	3/8" SPRING WASHER	03	
10	0521064045	CONDUCTOR WITH FLANGED	01	
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT	01	




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER		02
09	0503010179	LOCK WASHER		02
10	0503010337	5/16" NUT		02
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT		01




Item	Code	Description	See page	QT
01	0521066208	SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066206	RH SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066207	LH SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0511059219	LEFT SUPPORT	184	01
02	0571019645	CONDUCTOR SUPPORT		01
03	0503030483	FERTILIZER SOCKET		01
04	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
05	0521018517	FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511059218	RIGHT SUPPORT	185	01
02	0571019645	CONDUCTOR SUPPORT		01
03	0503030483	FERTILIZER SOCKET		01
04	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
05	0521018517	FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521066977	ARM BLADE DISC		01
02	0581011838	SLEVE GUIDES		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0521015376	DUST CLOAK		01
05	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02
08	0503012417	SEAL		01
09	0503011800	SEAL RING		01
10	0503010276	6206 BALL BEARING		01
11	0503030832	FLAT WASHER		01
12	0511059230	BOX WITH DOC 18 TURBO LEFT	186	01




Item	Code	Description	See page	QT
01	0521066977	ARM BLADE DISC		01
02	0581011838	SLEVE GUIDES		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0521015376	DUST CLOAK		01
05	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02
08	0503012417	SEAL		01
09	0503011800	SEAL RING		01
10	0503010276	6206 BALL BEARING		01
11	0503030832	FLAT WASHER		01
12	0511059229	BOX WITH DOC 18 TURBO RIGHT	187	01




Item	Code	Description	See page	QT
01	0502011562	DC BOX		01
02	0503011800	SEAL RING		01
03	0503012417	SEAL		01
04	0503010276	6206 BALL BEARING		01
05	0503030832	FLAT WASHER		01
06	0503011444	SPRING WASHER		06
07	0503010691	1/4" GREASE FITTING		01
08	0503010337	5/16" NUT		06
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0607025032	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0502011562	DC BOX		01
02	0503011800	SEAL RING		01
03	0503012417	SEAL		01
04	0503010276	6206 BALL BEARING		01
05	0503030832	FLAT WASHER		01
06	0503011444	SPRING WASHER		06
07	0503010691	1/4" GREASE FITTING		01
08	0503010337	5/16" NUT		06
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0607025032	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0581013298	SUPPORT		01
02	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
03	0521018517	FLAT WASHER		01
04	0503010060	1/2" NUT		01
05	0503010019	1/2" SPRING WASHER		01
06	0503030483	FERTILIZER SOCKET		01
07	0503031050	CURVED CONDUCTOR		01
08	0503010246	CLAMP		01



Item	Code	Description	See page	07	09	11 L.
01	0521013432	5/8" X 59" AXLE HEX		01	00	00
02	0521013428	HEX AXLE		01	00	00
03	0521013433	5/8" X 75" AXLE HEX		00	01	00
04	0521013429	AXLE HEX 5/8 X 2180		00	01	00
05	0521013434	HEX AXLE 5/8 X 2300		00	00	01
06	0521013430	HEX AXLE 5/8 X 2580		00	00	01
07	0511015098	FLAT WASHER		02	02	02
08	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8		00	02	02
09	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"		02	00	02
10	0503010003	1845 GREASE FITTING		02	02	02
11	0503010365	NUT		04	04	04
12	0501010984	FLAT WASHER		04	04	04
13	0501010694	FLAT WASHER		08	08	08
14	0503010179	LOCK WASHER		04	04	04
15	0503010337	5/16" NUT		04	04	04
16	0511017305	FLAT WASHER		04	04	04
17	0511065562	20Z GEAR		02	02	02
18	0502011299	BUSHING GEAR		02	02	02
19	0503010010	1/4" X 2.1/2" COTTERPIN		02	02	02



Item	Code	Description	See page	10L
01	0531016944	RIGHT 5/8" X 96" HEX AXLE	01	
02	0531016945	LEFT 5/8" X 90" HEX AXLE	01	
03	0511015098	FLAT WASHER	02	
04	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8	02	
05	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	02	
06	0503010003	1845 GREASE FITTING	02	
07	0503010365	NUT	04	
08	0501010984	FLAT WASHER	04	
09	0501010694	FLAT WASHER	08	
10	0503010179	LOCK WASHER	04	
11	0503010337	5/16" NUT	04	
12	0511017305	FLAT WASHER	04	
13	0511065562	20Z GEAR	02	
14	0502011299	BUSHING GEAR	02	
15	0503010010	1/4" X 2.1/2" COTTERPIN	02	
16	0561014215	BEARING COVER LOWER ROW FRAME	02	



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

