

ROW CROP PLANTERS

**PHP - TRAILLED PLANTER - 04/05/06/07 ROWS
(UP TO 03/2022)**

PHP - ARRASTO - 04/05/06/07 LINHAS (ATÉ 03/2022)

Code: 0501092321

Series: S-0816

Revision: 00

Revision Date: MAY/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Working Width	Description
0111170040		PHP 1980/5E450 DC ARRASTO S-0816
0111170043		PHP 1980/5E450 MH DC ARRASTO S-0816
0111170029		PHP 2880/4E900 MH DC ARRASTO S-0816
0111170059		PHP 2880/5E550 CI MH DC ARRASTO S-0816
0111170039		PHP 2880/5E600 DC ARRASTO S-0816
0111170056		PHP 2880/6E500 CI DC ARRASTO S-0816
0111170041		PHP 2880/6E500 CI MH DC ARRASTO S-0816
0111170060		PHP 2880/7E450 CI DOC ARRASTO S-0816
0111170045		PHP 2880/7E450 CI MH DC ARRASTO S-0816
0111170038		PHP 2880/7E450 DC ARRASTO S-0816

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.




MARCHESAN

INDEX

0909094664	FRAME ASSY - 04/05/06/07 LINES	1
0909094730	SEMI MOUNTED FRAME - 05/05	2
0909094716	SEMI MOUNTED FRAME - 07/04 - 07/05 - 07/06 - 07/07	3
0521053751	FRAME WITH DISTRIBUTOR - 1980	4
0511057983	FRAMES WITH DISTRIBUTOR PHP 7	5
0501055357	FERTILIZER DISTRIBUTOR LEFT ASSY	6
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	7
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	8
0501056450	5/8 DOUBLE BEARING SEED TRANSMISSION	9
0501053788	3/4" SQUARE AXLE FASTENER	10
0521053745	FERTILIZER BOX SET - 1980	11
0511059897	ASSY BEAM FERTILIZER TRUDGE PHP 2880	12
0511059900	DRAWBAR FIXER ASSEMBLY - 2880	13
0511059902	JACK ASSEMBLY - 2880	14
0909094665	ASSY HEADER	15
0501051160	TRACTOR HITCH PIN	16
0511053179	TRACTOR COUPLING SHAFT	17
0511056736	HOSE SUPPORT	18
0521050037	STABILIZER HEADER	19
0531052890	ASSEMBLY LEFT SEED ROW	20
0531052889	ASSEMBLY RIGHT SEED ROW	21
0501053347	SEED SYSTEM ASSEMBLY	22
0501051094	SEED DISTRIBUTOR ASSY	23
0501051119	DOUBLE PULLEY ROCKER'S	24
0501054915	SEED ROW ARM WITH LEFT DOUBLE DISC	25
0501054914	SEED ROW ARM WITH RIGHT DOUBLE DISC	26
0501055675	LEFT SEED DOUBLE DISC	27
0501055674	RIGHT SEED DOUBLE DISC	28
0501054992	DEPTH WHEEL V CONTROL ASSEMBLY	29
0501043613	DEPTH WHEEL	30
0501050421	HUB DEPTH REGULATOR ASSY	31
0501059329	WHEELS ASSY	32
0511054333	COMPACT WHEEL RIGHT WITH BEARING	33
0511054334	COMPACT WHEEL LEFT WITH BEARING	34
0501052908	COMPACTOR WHEEL WITH BEARING	35
0511053857	FAST CLOSING SET	36
0511050331	LH FERTILIZER ROW ASSY	37
0511050330	RH FERTILIZER ROW ASSY	38
0501053349	LH FERTILIZER ROW ARM	39
0501053348	RH FERTILIZER ROW ARM	40
0501052977	LEFT FERTILIZER DOUBLE DISC	41
0501052976	RIGHT FERTILIZER DOUBLE DISC	42
0511058164	16" COULTER BLADE ASSY	43
0531050258	CUTTING DISC 16 ASSY DOC	44
0501056428	16" CUTTING DISC SEMI-ASSEMBLED	45
0531050257	CUTTING DISC 16 SEMI-ASSEMBLED DOC	46
0511057192	EXTENSION SPRING	47
0511057767	ASSY LEFT WHEELED	48
0511057914	WHEEL ASSY RIGHT	49
0511050666	ASSY LEFT WHEELED ARM	50
0511050265	ASSY RIGHT WHEELED ARM	51
0909094798	WHEELED LEFT SUPPORT ASSY	52
0909094791	WHEELED RIGHT SUPPORT ASSY	53
0503060141	WHEEL AND TIRE ASSY	54
0511051531	ASSY TENSIONER LEFT	55
0511051517	ASSY TENSIONER RIGHT	56
0511051371	ASSY CURRENT TENSIONER	57
0909094799	COVER ASSY DRIVE LEFT	58
0909094792	COVER ASSY DRIVE RIGHT	59


INDEX

0909094800	RATCHET LEFT ASSY	60
0909094793	RATCHET RIGHT ASSY	61
0909094794	CYLINDER ASSY	62
0521040065	HYDRAULIC CYLINDER 38,10 X 63,50 X 385 X 150	63
0909094795	SPRING SCREW ASSY	64
0909094796	STARTER ASSY TRANSMISSION LEFT SIDE	65
0909094801	STARTER ASSY TRANSMISSION RIGHT SIDE	66
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	67
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	68
0511051532	GEAR ASSY 26Z	69
0511059901	HYDRAULIC MARKER ASSY - 2880	70
0521052326	HYDRAULIC MARKER ASSY - PHP 1980	71
0521040155	HYDRAULIC CYLINDER 31,75 X 50,8 X 365 X 595	72
0501054649	HBM SEQUENTIAL VALVE	73
0501053834	MALE QUICK COUPLER	74
0501050633	ROW MARKER DISC ASSEMBLY	75
0511053904	ROW MARKER DISC	76
0511059903	ASSY PORT MANUAL INSTRUCCION	77
0511059905	WHEELED HYDRAULIC ASSY	78
0521050798	DIVIDER VALVE ASSEMBLY	79
0521053752	WHEEL HYDRAULIC ASSEMBLY - 1980	80
0521053754	DIVIDER VALVE ASSEMBLY	81
0501050120	LARGER WALKING BEAM ASSY	82
0521053369	LABEL ASSY - 2880	83
0521055490	LABEL ASSY PHP 1980 MH	84
0511059899	LABEL ASSY - 2880 MH	85
0521053735	HEAD STABILIZER	86




Item	Code	Description	See page	05/05	07/04	07/05	07/06	07/07
01		SEMI MOUNTED FRAME - 05/05	2					
01.		SEMI MOUNTED FRAME - 07/04 - 07/05 - 07/06 - 07/07	3					
02		ASSY HEADER	15					
03	0531052890	ASSEMBLY LEFT SEED ROW	20	003	002	003	003	004
04	0531052889	ASSEMBLY RIGHT SEED ROW	21	002	002	002	003	003
05	0511050331	LH FERTILIZER ROW ASSY	37	002	002	002	003	003
06	0511050330	RH FERTILIZER ROW ASSY	38	003	002	003	003	004
07	0511058164	16" COULTER BLADE ASSY	43	005	004	005	006	007
07.	0531050258	CUTTING DISC 16 ASSY DOC	44	000	000	000	000	007
08	0501018652	CORN STABILIZER BAR		003	003	003	008	003
09	0501013714	STABILIZER BAR		004	000	004	000	006
10	0511057914	WHEEL ASSY RIGHT	49	001	001	001	001	001
11	0511057767	ASSY LEFT WHEELED	48	001	001	001	001	001
12	0511059901	HYDRAULIC MARKER ASSY - 2880	70	000	001	001	000	001
12.	0521052326	HYDRAULIC MARKER ASSY - PHP 1980	71	001	000	000	000	000
13	0501050633	ROW MARKER DISC ASSEMBLY	75	002	002	002	000	002
14	0511059903	ASSY PORT MANUAL INSTRUCCION	77	001	001	001	001	001
15	0503012555	7/16" UNC X 2" CS RT G.7 ZN SCREW		001	001	001	001	001
16	0503010180	7/16" SPRING WASHER		001	001	001	001	001
17	0531011180	SUPPORT		001	001	001	001	001
18	0502012702	BODY SUPPORT CLAMP		001	001	001	001	001
19	0511059905	WHEELED HYDRAULIC ASSY	78	000	001	001	001	001
19.	0521053752	WHEEL HYDRAULIC ASSEMBLY - 1980	80	001	000	000	000	000
20	0511059898	TRANSMISSION ASSY PHP 2880		000	001	001	001	001
20.	0521053749	TRANSMISSION ASSY PHP 1980		001	000	000	000	000
20.A	0581018040	5/8 X 2170 HEX AXLE		001	000	000	000	000
20.B	0581010407	SLEEVE 25.4 X 88		001	000	000	000	000
20.C	0503010131	3/16" X 1.1/2" SPLIT PIN		002	000	000	000	000
20.D	0503018182	40-1 X 39 CHAIN LINK + MENDING		001	000	000	000	000
20A	0561018502	SHAFT AXIS 5/8 X 3000		000	001	001	001	001
20B	0581010407	SLEEVE 25.4 X 88		000	001	001	001	001


Item	Code	Description	See page	05/05	07/04	07/05	07/06	07/07
20C	0503010131	3/16" X 1.1/2" SPLIT PIN		000	002	002	002	002
20D	0503018182	40-1 X 39 CHAIN LINK + MENDING		000	001	001	001	001
21	0503016214	RING CORN (APOLLO740)		005	004	005	006	007
22	0503016220	RING TO SOYBEANS (APOLLO 745)		005	004	005	006	007
23	0503016221	RING TO SOYBEANS (APOLLO 571)		005	004	005	006	007
24	0503016218	DISC OF SOYBEAN		005	004	005	006	007
25	0503016204	CORN DISC 12 ORANGE		005	004	005	006	007
26	0511017969	0.1" SPACING PLATE		010	008	010	012	014
27	0501110231	SCARIFIER ROD WITH TIP		005	004	005	006	007
28	0503032624	FERTILIZER HOPPER GUTTER		003	004	004	004	004
29	0521061654	TRANSPORT LATCH 153 X 40 X 8.00		002	002	002	002	002
30	0501068994	8,30 X 78 LOCK PIN		002	002	002	002	002
31	0503030168	HITCH PIN CLIP		002	002	002	002	002
32	0521063905	EXTENDER		002	002	000	000	000
33	0521060879	38Z GEAR		002	002	002	002	002
34	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		002	002	002	002	002
35	0511065366	GEAR 30Z P 12.7		002	002	002	002	002
36	0521060880	GEAR 22 TEETH		002	002	002	002	002
37	0511061757	18Z GEAR		002	002	002	002	002
38	0521060881	GEAR 14Z		002	002	002	002	002
39	0501050120	LARGER WALKING BEAM ASSY	82	005	004	005	006	007
40	0503030558	PULLEY 4Z CORN PLASTIC		005	004	005	006	007
41	0503031050	CURVED CONDUCTOR		005	004	005	006	007
42	0503031145	2" X 2" X 20" HOSE		005	004	005	006	007
43	0503010246	CLAMP		004	004	004	004	004
44	0511061769	RIGHT FERTILIZER CONDUCTOR WITH REGULATOR		003	002	003	000	004
45	0511061770	LEFT CONDUCTOR FERTILIZER WITH REGULATOR		002	002	002	000	003
46	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		010	008	010	012	014
47	0501010984	10,50 X 27 X 3,00 FLAT WASHER		020	016	020	024	028
48	0503010025	3/8" SPRING WASHER		010	008	010	012	014
49	0503010026	3/8" NUT		010	008	010	012	014
50	0503011198	BOLT 3/4" UNC X 6" CS G.5		000	002	002	000	000
51	0501010322	20,50 X 46 X 4,00 ZN FLAT WASHER		000	002	002	000	000
52	0503010023	3/4" SPRING WASHER		000	002	002	000	000
53	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		000	002	002	000	000
54	0571016118	FERTILIZER NOZZLE		000	000	005	006	000
55	0503030391	RIGHT FERTILIZER NOZZLE		000	000	003	003	000
56	0503030392	LEFT FERTILIZER NOZZLE		000	000	002	003	000
57	0503010002	1800 GREASE FITTING		000	000	001	001	000
58	0521053369	LABEL ASSY - 2880	83	000	000	000	001	001
58.	0521055490	LABEL ASSY PHP 1980 MH	84	001	000	000	000	000
58..	0511059899	LABEL ASSY - 2880 MH	85	000	000	001	001	000
59	0503034003	61 X 118 SERIAL NUMBER TAG		001	001	001	001	001
60	0503010001	RIVET 3,2 X 5,5		004	004	004	004	004
61	0521053735	HEAD STABILIZER	86	001	000	000	000	000




Item	Code	Description	See page	QT
01	0521053751	FRAME WITH DISTRIBUTOR - 1980	4	01
02	0521053745	FERTILIZER BOX SET - 1980	11	01
03	0511059900	DRAWBAR FIXER ASSEMBLY - 2880	13	01
04	0511059902	JACK ASSEMBLY - 2880	14	01




Item	Code	Description	See page	QT
01	0511057983	FRAMES WITH DISTRIBUTOR PHP 7	5	01
02	0511059897	ASSY BEAM FERTILIZER TRUDGE PHP 2880	12	01
03	0511059900	DRAWBAR FIXER ASSEMBLY - 2880	13	01
04	0511059902	JACK ASSEMBLY - 2880	14	01




Item	Code	Description	See page	QT
01	0521069049	FRAME - 1980		01
02	0501055357	FERTILIZER DISTRIBUTOR LEFT ASSY	6	06
03	0501011643	3/8 X 1" BOLT		24
04	0501013518	FLAT WASHER 10,50 X 24 X 1,50 ZN		24
05	0503011443	SPRING WASHER 3/8"		26
06	0503010026	3/8" NUT		26
07	0503030275	AGRICULTURAL BEARING		06
08	1902010685	18Z CONICAL GEAR		06
09	0561015942	19,05 X 2150 SQUARE AXLE		01
10	0501056450	5/8 DOUBLE BEARING SEED TRANSMISSION	9	01
11	0511065209	20Z GEAR		01
12	0521014167	CONE LOCK		04
13	0503010571	1/4" X 1.1/2" SPLIT PIN		01
14	0501053788	3/4" SQUARE AXLE FASTENER	10	02
15	0581018042	BEARING SUPPORT		01
16	0503010849	3/8" X 1-1/2" BOLT		02
17	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
18	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		02
19	0501010694	FLAT WASHER 8,50 X 18 X 1,50 ZN		02
20	0503011444	SPRING WASHER 5/16"		02
21	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0521060762	FRAME 7		01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	7	04
03	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	8	04
04	0501010942	3/8" X 1-1/4" BOLT		32
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		36
06	0503011443	SPRING WASHER 3/8"		34
07	0503010026	3/8" NUT		34
08	0503030275	AGRICULTURAL BEARING		10
09	1902010685	18Z CONICAL GEAR		08
10	0561018501	AXIS Q 19.05 X 3050		01
11	0511065209	20Z GEAR		01
12	0521014167	CONE LOCK		02
13	0503010571	1/4" X 1.1/2" SPLIT PIN		01
14	0581010574	BEARING SUPPORT		01
15	0503010849	3/8" X 1-1/2" BOLT		02
16	0501053788	3/4" SQUARE AXLE FASTENER	10	01
17	0502011697	GEARBOX SUPPORT		01
18	0503011105	SEAL RING		01
19	0503013462	6005 2RS1 ROLLER BEARING		01
20	0503011953	5/16" X 1" BOLT		02
21	0501010694	FLAT WASHER 8,50 X 18 X 1,50 ZN		02
22	0503011444	SPRING WASHER 5/16"		02
23	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0501110143	TUBE FERTILIZER METERING BODY		01
02	0503030275	AGRICULTURAL BEARING		02
03	0503031165	LEFT HELICOID CONDUCTOR		01
04	0511017137	FLAT WASHER		01
05	0503030303	SUPPORT WASHER		01
06	0501013774	GREASE SEAL		01
07	0502011412	18Z CONICAL GEAR		01
08	0503010523	1/4 X 2 SPLIT PIN		01
09	0503011962	GREASE FITTING		01
10	0503012826	CREASE FITTING		02
11	0571011152	DOUBLE DISC CAP		01
12	0571019534	DISTRIBUTION GLOVE		01
13	0503015081	502052 CLAMPING RING (FOR AXLE)		01
14	0571019536	DISTRIBUTOR AXIS FERTILIZER		01




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4 X 2 SPLIT PIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4 X 2 SPLIT PIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503013462	6005 2RS1 ROLLER BEARING		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0503062831	FERTILIZER HOPPER ASSY		02
02	0511065804	SIMPLE FERTILIZER BOX CLAMP		02
03	0511065805	DOUBLE FERTILIZER BOX CLAMP		01
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		03
05	0503010025	3/8" SPRING WASHER		03
06	0503010026	3/8" NUT		03
07	0551019117	FERTILIZER DISTRIBUTOR COVER		06
08	0503010362	1/8" X 1.1/4" SPLIT PIN		06




Item	Code	Description	See page	QT
001	0503062648	RIGHT FERTILIZER WITH COVER		01
002	0503062649	LEFT BOX FERTILIZER WITH COVER		01
003	0511061884	FERTILIZER HOPPER FIXER		02
004	0511061885	FERTILIZER HOPPER DOUBLE FIXER		01
005	0501010937	13,50 X 28 X 3,00 FLAT WASHER		03
006	0503010019	1/2" SPRING WASHER		03
007	0503010060	1/2 UNC G.5 ZN HEX NUT		03
008	0571010590	FERTILIZER SIDE COVER		08
009	0503010257	1/8" X 1" SPLIT PIN		08




Item	Code	Description	See page	QT
001	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02
002	0502012329	DRAWBAR FIXATION REAR SUPPORT		02
003	0502012330	SUPPORT FIXER PIVOT		04
004	0503011084	3/4" X 5" BOLT		08
005	0501010322	20,50 X 46 X 4,00 ZN FLAT WASHER		08
006	0503010023	3/4" SPRING WASHER		08
007	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		08
008	0561014393	COUPLING SHAFT		02
009	0503030119	LOCK PIN		04




Item	Code	Description	See page	QT
001	0502011530	SUPPORT		02
002	0502010175	HITCH CLAMP		02
003	0501011543	5/8" X 4" BOLT		04
004	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
005	0503012412	5/8" UNC SELF LOCKING NUT		04
006	0511062112	25.6" PLOUGH SUPPORT		02
007	0501011075	PIN		02
008	0503030012	HITCH PIN CLIP		02




Item	Code	Description	See page	QT
01	0521066895	HEADER		01
02	0501051160	TRACTOR HITCH PIN	16	01
03	0511053179	TRACTOR COUPLING SHAFT	17	01
04	0511056736	HOSE SUPPORT	18	01
05	0503012555	7/16" UNC X 2" CS RT G.7 ZN SCREW		01
06	0503010180	7/16" SPRING WASHER		01
07	0531011180	SUPPORT		01
08	0502012702	BODY SUPPORT CLAMP		01
09	0521010577	0.9" X 4.1" COUPLING SHAFT		01
10	0521010579	COUPLING SHAFT		01
11	0503030085	LOCK PIN		02
12	0521050037	STABILIZER HEADER	19	01




Item	Code	Description	See page	QT
01	0521010681	BUSHING COUPLING BODY		01
02	0502040556	HITCH TURNER		01
03	0521010639	COUPLING SHAFT		01
04	0503010571	1/4" X 1.1/2" SPLIT PIN		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		01




Item	Code	Description	See page	QT
01	0521066420	R.1.1/2" UNC X 290 LEFT EXTENDER		01
02	0501110262	245 ADJUSTMENT NUT		01
03	0521066700	EXTENSOR R.1./2 UNC RIGHT X 290		01
04	0501061056	1.1/2" RIGHT LOCK-NUT		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	1902010891	SPRING CHOCK SUPPORT VARON		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		05
04	0503010395	1/2" X 1-1/4" BOLT		01
05	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		01
06	0511060376	SEED SPRING GUIDE		01
07	0521010542	COUPLING SHAFT		01
08	0503010257	1/8" X 1" SPLIT PIN		01
09	0502040534	SPRING GUIDE BUSHING LOCK		02
10	0501013753	FLAT WASHER		01
11	0501018535	1/2 X 1 BOLT		02
12	0503031359	1"X15.75"X0.15" COMPRESSION SPRING		01
13	0503031360	1.68"X17.75"X0.3" COMPRESS SPRING		01
14	0503010479	BOLT		02
15	0503010019	1/2" SPRING WASHER		03
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
17	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
18	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
19	0503011099	GREASE FITTING		02
20	0503012412	5/8" UNC SELF LOCKING NUT		03
21	0503030482	SEED SOCKET		01
22	0501053347	SEED SYSTEM ASSEMBLY	22	01
23	0502012129	SPRING GUIDE SUPPORT		01
24	0501054915	SEED ROW ARM WITH LEFT DOUBLE DISC	25	01
25	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
26	0501010163	5/8" X 4-1/2" BOLT		01
27	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		02
28	0501054992	DEPTH WHEEL V CONTROL ASSEMBLY	29	01
29	0511053857	FAST CLOSING SET	36	01




Item	Code	Description	See page	QT
001	0502011567	FERTILIZER ROW SUPPORT		01
002	1902010891	SPRING CHOCK SUPPORT VARON		01
003	0503010060	1/2 UNC G.5 ZN HEX NUT		05
004	0503010395	1/2" X 1-1/4" BOLT		01
005	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		01
006	0511060376	SEED SPRING GUIDE		01
007	0521010542	COUPLING SHAFT		01
008	0503010257	1/8" X 1" SPLIT PIN		01
009	0502040534	SPRING GUIDE BUSHING LOCK		02
010	0501013753	FLAT WASHER		01
011	0501018535	1/2 X 1 BOLT		02
012	0503031359	1"X15.75"X0.15" COMPRESSION SPRING		01
013	0503031360	1.68"X17.75"X0.3" COMPRESS SPRING		01
014	0503010479	BOLT		02
015	0503010019	1/2" SPRING WASHER		03
016	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
017	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
018	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
019	0503011099	GREASE FITTING		02
020	0503012412	5/8" UNC SELF LOCKING NUT		03
021	0503030482	SEED SOCKET		01
022	0501053347	SEED SYSTEM ASSEMBLY	22	01
023	0502012129	SPRING GUIDE SUPPORT		01
024	0501054914	SEED ROW ARM WITH RIGHT DOUBLE DISC	26	01
025	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
026	0501010163	5/8" X 4-1/2" BOLT		01
027	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		02
028	0501054992	DEPTH WHEEL V CONTROL ASSEMBLY	29	01
029	0511053857	FAST CLOSING SET	36	01




Item	Code	Description	See page	QT
01	0502020324	SEED HOPPER SUPPORT		01
02	0503031508	COVER GREEN BEAM SEED YELLOW		01
03	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
04	0501010694	FLAT WASHER 8,50 X 18 X 1,50 ZN		04
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
06	0501051094	SEED DISTRIBUTOR ASSY	23	01
07	0503010675	5/16" X 2.1/4" BOLT		01
08	0503010026	3/8" NUT		01
09	0503010337	NUT 5/16 UNC G.5 ZN		01
10	0502010408	SEED DISC LOWER TRAIL		01
11	0521010536	0.3" X 3.8" COUPLING SHAFT		01
12	0503010140	1/8" X 3/4" SPLIT PIN		01
13	0503030083	3/8" X 3/8" X 1.6" STUD		01
14	0503010025	3/8" SPRING WASHER		03
15	0503010209	3/8" UNC BUTTERFLY NUT		02
16	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
17	0503016219	RING TO SOYBEANS		01
18	0571018536	HEX PRISONER		01
19	0503034131	DEFLECTOR		01
20	0531018622	BOLT FAST SUPPORT UPPER		01
21	0501013518	FLAT WASHER 10,50 X 24 X 1,50 ZN		01
22	0501010096	3/8" X 2" BOLT		01
23	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01




Item	Code	Description	See page	QT
01	0503030381	SEED DISTRIBUTOR HUB		01
02	0502010447	TRIGGER		02
03	0501013467	KEY AXLE		01
04	0503030378	0.4" X 1.1" X 0.03" SPRING		03
05	0501013466	KEY LIMITER AXLE		01
06	0501051119	DOUBLE PULLEY ROCKER'S	24	01
07	0501013468	ROCKER ARM AXLE, OF THE PULLEY		01
08	0503030377	SCRAPER		01




Item	Code	Description	See page	QT
01	0503031129	DOUBLE PULLEY ROCKER ARM		01
02	0503031128	5Z PLASTIC DOUBLE PULLEY FOR SOYBEAN		02
03	0521010649	TOOTH PULLEY COUPLING SHAFT		01
04	0503011853	503050 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0511065045	SEED ROW ARM		01
02	0502011830	ARTICULATION SUPPORT		01
03	0521018079	SEED ROW DRAWBAR LID		01
04	0502011400	18Z CONICAL GEAR		01
05	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
06	0502011505	18Z CONICAL GEAR		01
07	0521018588	1/2 X 32.28 HEX AXLE		01
08	0503010257	1/8" X 1" SPLIT PIN		01
09	0501055675	LEFT SEED DOUBLE DISC	27	01
10	0503010752	1/2" X 3.1/2" BOLT		04
11	0503010479	BOLT		04
12	0503010060	1/2 UNC G.5 ZN HEX NUT		08
13	0503010019	1/2" SPRING WASHER		08
14	0503014729	1/4" UNF X 1/2" BOLT		02
15	0503010143	1/4" SPRING WASHER		02
16	0501013352	FLAT WASHER		03
17	0501013354	FLAT WASHER		02
18	0502010426	UPPER BEARING SEMI		02
19	0502011561	BEARING SEMI		01




Item	Code	Description	See page	QT
01	0511065045	SEED ROW ARM		01
02	0502011830	ARTICULATION SUPPORT		01
03	0521018079	SEED ROW DRAWBAR LID		01
04	0502011400	18Z CONICAL GEAR		01
05	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
06	0502011505	18Z CONICAL GEAR		01
07	0521018588	1/2 X 32.28 HEX AXLE		01
08	0503010257	1/8" X 1" SPLIT PIN		01
09	0501055674	RIGHT SEED DOUBLE DISC	28	01
10	0503010752	1/2" X 3.1/2" BOLT		04
11	0503010479	BOLT		04
12	0503010060	1/2 UNC G.5 ZN HEX NUT		08
13	0503010019	1/2" SPRING WASHER		08
14	0503014729	1/4" UNF X 1/2" BOLT		02
15	0503010143	1/4" SPRING WASHER		02
16	0501013352	FLAT WASHER		03
17	0501013354	FLAT WASHER		02
18	0502010426	UPPER BEARING SEMI		02
19	0502011561	BEARING SEMI		01




Item	Code	Description	See page	QT
01	0502012072	15 X 15 DOUBLE LEFT DISC SUPPORT		01
02	0503011410	ROLLER BEARING		01
03	0502012225	10Z CONICAL GEAR		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0501813354	FLAT WASHER		01
06	0501110383	40Z CONICAL GEAR		01
07	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01
08	0503011440	SPRING WASHER		01
09	0502011930	OPENING DISCS HUB		02
10	0503010598	30204 BALL BEARING		04
11	0503011112	SEAL 02376-BRG		02
12	0521019154	RIGHT SHAFT DOUBLE DISC HUB		01
13	0521019148	LEFT DOUBLE DISC HUB		01
14	0503030282	3/4" CASTLE NUT		02
15	0503010257	1/8" X 1" SPLIT PIN		02
16	0603022042	13" X 0.12" PLAIN COULTER BLADE		02
17	0503010546	5/16" X 7/8" BOLT		12
18	0503010337	NUT 5/16 UNC G.5 ZN		12
19	0511815098	FLAT WASHER		06
20	0511011927	DUST CLOAK		02
21	0503030757	2.9" X 2" X 0.02" JOINT		02
22	0521019178	PROTECTION LID		02
23	0503014729	1/4" UNF X 1/2" BOLT		06
24	0503010143	1/4" SPRING WASHER		06
25	0501017542	LH DOUBLE DISC SCRAPER		01
26	0501017541	RIGHT DOUBLE DISC SCRAPER		01
27	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
28	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
29	0503010025	3/8" SPRING WASHER		01
30	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0502012071	15 X 15 DOUBLE RIGHT DISC SUPPORT		01
02	0503011410	ROLLER BEARING		01
03	0502012225	10Z CONICAL GEAR		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0501813354	FLAT WASHER		01
06	0501110383	40Z CONICAL GEAR		01
07	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01
08	0503011440	SPRING WASHER		01
09	0502011930	OPENING DISCS HUB		02
10	0503010598	30204 BALL BEARING		04
11	0503011112	SEAL 02376-BRG		02
12	0521019154	RIGHT SHAFT DOUBLE DISC HUB		01
13	0521019148	LEFT DOUBLE DISC HUB		01
14	0503030282	3/4" CASTLE NUT		02
15	0503010257	1/8" X 1" SPLIT PIN		02
16	0603022042	13" X 0.12" PLAIN COULTER BLADE		02
17	0503010546	5/16" X 7/8" BOLT		12
18	0503010337	NUT 5/16 UNC G.5 ZN		12
19	0511815098	FLAT WASHER		06
20	0511011927	DUST CLOAK		02
21	0503030757	2.9" X 2" X 0.02" JOINT		02
22	0521019178	PROTECTION LID		02
23	0503014729	1/4" UNF X 1/2" BOLT		06
24	0503010143	1/4" SPRING WASHER		06
25	0501017542	LH DOUBLE DISC SCRAPER		01
26	0501017541	RIGHT DOUBLE DISC SCRAPER		01
27	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
28	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
29	0503010025	3/8" SPRING WASHER		01
30	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0502012236	DEPTH WHEEL SUPPORT		01
02	0501043613	DEPTH WHEEL	30	01
03	0501018535	1/2 X 1 BOLT		02
04	0501059329	WHEELS ASSY	32	01




Item	Code	Description	See page	QT
01	0501050421	HUB DEPTH REGULATOR ASSY	31	01
02	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		02
03	0521010832	RIM FLANGE		04
04	0503010358	5/16" X 5/8" BOLT		08
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
06	0503010337	NUT 5/16 UNC G.5 ZN		08
07	0503010298	1/4" X 1/2" BOLT		10
08	0503010143	1/4" SPRING WASHER		10
09	0503010144	1/4" NUT		10




Item	Code	Description	See page	QT
01	0501064772	DEPTH REGULATOR ARM		01
02	0503010689	SEAL 00763-BR		02
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		02
05	0503011105	SEAL RING		01
06	0502011907	DEPTH CONTROL WHEEL HUB		02
07	0503010878	5/8" SELF ALIGNING NUT		02
08	0503030757	2.9" X 2" X 0.02" JOINT		02
09	0521019178	PROTECTION LID		02
10	0503014729	1/4" UNF X 1/2" BOLT		06
11	0503010143	1/4" SPRING WASHER		06
12	0503010691	1/4" GREASE FITTING		02




Item	Code	Description	See page	QT
01	0502011757	PRESS REGULATOR		01
02	0511054333	COMPACT WHEEL RIGHT WITH BEARING	33	01
03	0511054334	COMPACT WHEEL LEFT WITH BEARING	34	01
04	0501013798	LEFT ARM		01
05	0501013799	RIGHT ARM		01
06	0503010849	3/8" X 1-1/2" BOLT		02
07	0503010025	3/8" SPRING WASHER		02
08	0503010026	3/8" NUT		02
09	0501069979	SPRING REGULATOR		01
10	0521013310	0.5" X 3" COUPLING SHAFT		01
11	0503010300	5/32" X 1" SPLIT PIN		01
12	0503010479	BOLT		01
13	0541016309	13,2 X 22,18 SLEEVE		01
14	0503010019	1/2" SPRING WASHER		01
15	0503010060	1/2 UNC G.5 ZN HEX NUT		01
16	0502040534	SPRING GUIDE BUSHING LOCK		02
17	0503030399	1" X 5.1" X 0.2" COMPRESSION SPRING		01
18	0501018535	1/2 X 1 BOLT		02




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	35	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	35	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0502012744	SPEED LOCK LEVER ASSY		01
02	0502012743	FAST BOLT ASSY		01
03	0571014534	FAST BOLT ADJUSTMENT		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010257	1/8" X 1" SPLIT PIN		02




Item	Code	Description	See page	QT
01	0501053349	LH FERTILIZER ROW ARM	39	01
02	0521066715	SPRING GUIDE ROD		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
05	0503011336	1/2" HEX SELF ADJUSTING NUT		01
06	0501013753	FLAT WASHER		02
07	0502040534	SPRING GUIDE BUSHING LOCK		02
08	0501018535	1/2 X 1 BOLT		02
09	0503030609	1"X11.81"X 0.16" COMPRESSION SPRING		01
10	0503030917	1.6"X11.8"X 0.2" COMPRESSION SPRING		01
11	0511016281	3/4" X 8" BOLT		01
12	0511017232	FLAT WASHER		02
13	0503011255	3/4" LOCK NUT		01
14	0503030645	2 X 2 X 225 HOSE		01
15	0521018797	0.7" X 1" X .55" SLEEVE		02
16	0511017304	FLAT WASHER		02
17	0521010445	0.53" X 0.75" X 0.45" SLEEVE		02
18	0503031076	2" HOSE CLAMP		02
19	0503030392	LEFT FERTILIZER NOZZLE		01
20	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0501053348	RH FERTILIZER ROW ARM	40	01
02	0521066715	SPRING GUIDE ROD		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
05	0503011336	1/2" HEX SELF ADJUSTING NUT		01
06	0501013753	FLAT WASHER		02
07	0502040534	SPRING GUIDE BUSHING LOCK		02
08	0501018535	1/2 X 1 BOLT		02
09	0503030609	1"X11.81"X 0.16" COMPRESSION SPRING		01
10	0503030917	1.6"X11.8"X 0.2" COMPRESSION SPRING		01
11	0511016281	3/4" X 8" BOLT		01
12	0511017232	FLAT WASHER		02
13	0503011255	3/4" LOCK NUT		01
14	0503030391	RIGHT FERTILIZER NOZZLE		01
15	0503030645	2 X 2 X 225 HOSE		01
16	0521018797	0.7" X 1" X .55" SLEEVE		02
17	0511017304	FLAT WASHER		02
18	0521010445	0.53" X 0.75" X 0.45" SLEEVE		02
19	0503031076	2" HOSE CLAMP		02
20	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0521063737	FERTILIZER ROW ARM	41	01
02	0501052977	LEFT FERTILIZER DOUBLE DISC		01
03	0511018662	SPACING PLATE		06
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521063737	FERTILIZER ROW ARM		01
02	0501052976	RIGHT FERTILIZER DOUBLE DISC	42	01
03	0511018662	SPACING PLATE		06
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011161	SUPPORT DDD 15 X 15 LEFT	01	
02	0502011930	OPENING DISCS HUB	02	
03	0503010598	30204 BALL BEARING	04	
04	0503011112	SEAL 02376-BRG	02	
05	0521019148	LEFT DOUBLE DISC HUB	01	
06	0503030282	3/4" CASTLE NUT	02	
07	0503010257	1/8" X 1" SPLIT PIN	02	
08	0603022042	13" X 0.12" PLAIN COULTER BLADE	02	
09	0503010546	5/16" X 7/8" BOLT	12	
10	0503010337	NUT 5/16 UNC G.5 ZN	12	
11	0511015098	FLAT WASHER	06	
12	0511011927	DUST CLOAK	02	
13	0503030757	2.9" X 2" X 0.02" JOINT	02	
14	0521019178	PROTECTION LID	02	
15	0503014729	1/4" UNF X 1/2" BOLT	06	
16	0503011441	SPRING WASHER	06	
17	0501017542	LH DOUBLE DISC SCRAPER	01	
18	0501017541	RIGHT DOUBLE DISC SCRAPER	01	
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	
20	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
21	0503011443	SPRING WASHER 3/8"	01	
22	0503010026	3/8" NUT	01	
23	0502070062	SCRAPER	01	
24	0503011402	0.2" X 0.8" SPRING PIN	01	
25	0521019154	RIGHT SHAFT DOUBLE DISC HUB	01	




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT	01	
02	0502011930	OPENING DISCS HUB	02	
03	0503010598	30204 BALL BEARING	04	
04	0503011112	SEAL 02376-BRG	02	
05	0521019148	LEFT DOUBLE DISC HUB	01	
06	0503030282	3/4" CASTLE NUT	02	
07	0503010257	1/8" X 1" SPLIT PIN	02	
08	0603022042	13" X 0.12" PLAIN COULTER BLADE	02	
09	0503010546	5/16" X 7/8" BOLT	12	
10	0503010337	NUT 5/16 UNC G.5 ZN	12	
11	0511015098	FLAT WASHER	06	
12	0511011927	DUST CLOAK	02	
13	0503030757	2.9" X 2" X 0.02" JOINT	02	
14	0521019178	PROTECTION LID	02	
15	0503014729	1/4" UNF X 1/2" BOLT	06	
16	0503011441	SPRING WASHER	06	
17	0501017542	LH DOUBLE DISC SCRAPER	01	
18	0501017541	RIGHT DOUBLE DISC SCRAPER	01	
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	
20	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
21	0503011443	SPRING WASHER 3/8"	01	
22	0503010026	3/8" NUT	01	
23	0502070062	SCRAPER	01	
24	0503011402	0.2" X 0.8" SPRING PIN	01	
25	0521019154	RIGHT SHAFT DOUBLE DISC HUB	01	




Item	Code	Description	See page	QT
01	0501056428	16" CUTTING DISC SEMI-ASSEMBLED	45	01
02	0503013329	1/2 UNC X 4.3/4 C S G.8 RT ZN BOLT		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0511057192	EXTENSION SPRING	47	01
06	0531012869	SUPPORT SPRING		01
07	0503011264	1/2" X 2-1/2" BOLT		01
08	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02




Item	Code	Description	See page	QT
01	0531050257	CUTTING DISC 16 SEMI-ASSEMBLED DOC	46	01
02	0503013329	1/2 UNC X 4.3/4 C S G.8 RT ZN BOLT		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0511057192	EXTENSION SPRING	47	01
06	0531012869	SUPPORT SPRING		01
07	0503011264	1/2" X 2-1/2" BOLT		01
08	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02




Item	Code	Description	See page	QT
01	0511063081	DISC BLADE SUPPORT		01
02	0502011279	DISC HUB		01
03	0503010215	30205 BEARING		02
04	0503010213	SEAL 30205		02
05	0511061647	BLADE DISC AXLE ASSY		01
06	0501068582	7/8" UNF WITH DUST CLOAK NUT		01
07	0603023013	DPL16X4,5 AFD80+6FR D224 TATU		01
08	0501013839	WASHER		01
09	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
11	0503010337	NUT 5/16 UNC G.5 ZN		06
12	0503010691	1/4" GREASE FITTING		01
13	0503010012	1" SPRING WASHER		02
14	0521013510	3/4" NUT		02
15	0511063073	DISC BLADE FIXER		01
16	0531012999	DISC BLADE FIXER AXLE		01
17	0503010361	SPRING PIN		01
18	0503010756	0.2" X 2.4" SPRING PIN		01
19	0503013185	BOLT 3/4" UNC X 5.1/2 C S G.7 ZN		01
20	0521014321	ARTICULATION ARM REEL		01
21	0503010046	2-216 N 3006-9B O'RING		02
22	0511015346	FLAT WASHER		02
23	0503011255	3/4" LOCK NUT		01
24	0501010322	20,50 X 46 X 4,00 ZN FLAT WASHER		01




Item	Code	Description	See page	QT
01	0511063081	DISC BLADE SUPPORT		01
02	0502011279	DISC HUB		01
03	0503010215	30205 BEARING		02
04	0503010213	SEAL 30205		02
05	0511061647	BLADE DISC AXLE ASSY		01
06	0501068582	7/8" UNF WITH DUST CLOAK NUT		01
07	0501013839	WASHER		01
08	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
10	0503010337	NUT 5/16 UNC G.5 ZN		06
11	0503010691	1/4" GREASE FITTING		01
12	0521013510	3/4" NUT		02
13	0511063073	DISC BLADE FIXER		01
14	0531012999	DISC BLADE FIXER AXLE		01
15	0503010361	SPRING PIN		01
16	0503010756	0.2" X 2.4" SPRING PIN		01
17	0521014321	ARTICULATION ARM REEL		01
18	0503010046	2-216 N 3006-9B O'RING		02
19	0503011255	3/4" LOCK NUT		01
20	0503010002	1800 GREASE FITTING		01
21	0503013185	BOLT 3/4" UNC X 5.1/2 C S G.7 ZN		01
22	0501010322	20,50 X 46 X 4,00 ZN FLAT WASHER		01
23	0511015346	FLAT WASHER		02
24	0503010012	1" SPRING WASHER		02
25	0607023039	DPLO16X4,5 AFD80+6FR D244 25/DOC		01




Item	Code	Description	See page	QT
01	0503031681	2.1" X 7.78" EXTENSION SPRING		01
02	0502011031	SPRING UPPER HITCH		02




Item	Code	Description	See page	QT
01		WHEELED RIGHT SUPPORT ASSY	53	
02	0511050265	ASSY RIGHT WHEELED ARM	51	01
03	0503060141	WHEEL AND TIRE ASSY	54	01
04	0511051531	ASSY TENSIONER LEFT	55	01
05	0511051371	ASSY CURRENT TENSIONER	57	02
06	0581012762	RIGHT CHAIN COVER		01
07	0561016503	PRISONER 3/8 UNC		03
08	0501013518	FLAT WASHER 10,50 X 24 X 1,50 ZN		06
09	0503010025	3/8" SPRING WASHER		03
10	0503010209	3/8" UNC BUTTERFLY NUT		03
11	0503013357	3/8 SELF-ADJUSTING NUT		03
12	0581010654	CHAIN INTERNAL PROTECTION		01
13		COVER ASSY DRIVE RIGHT	59	
14		RATCHET RIGHT ASSY	61	
15		CYLINDER ASSY	62	
16		SPRING SCREW ASSY	64	
17		STARTER ASSY TRANSMISSION LEFT SIDE	65	




Item	Code	Description	See page	QT
01		WHEELED RIGHT SUPPORT ASSY	53	
02	0511050265	ASSY RIGHT WHEELED ARM	51	01
03	0503060141	WHEEL AND TIRE ASSY	54	01
04	0511051517	ASSY TENSIONER RIGHT	56	01
05	0511051371	ASSY CURRENT TENSIONER	57	02
06	0581012762	RIGHT CHAIN COVER		01
07	0561016503	PRISONER 3/8 UNC		03
08	0501013518	FLAT WASHER 10,50 X 24 X 1,50 ZN		06
09	0503010025	3/8" SPRING WASHER		03
10	0503010209	3/8" UNC BUTTERFLY NUT		03
11	0503013357	3/8 SELF-ADJUSTING NUT		03
12	0581010654	CHAIN INTERNAL PROTECTION		01
13	0581014313	CHAIN TENSIONER PROTECTION WASHER		01
14		COVER ASSY DRIVE RIGHT	59	
15		RATCHET RIGHT ASSY	61	
16		CYLINDER ASSY	62	
17		SPRING SCREW ASSY	64	
18		STARTER ASSY TRANSMISSION LEFT SIDE	65	




Item	Code	Description	See page	QT
01	0521061627	WHEELED LEFT ARM		01
02	0501110807	WHEELED AXLE ASSY		01
02A	0521066379	WHEELED AXLE		01
02B	0501010127	9/16" X 1-7/8" LUG BOLT		06
02C	0503013001	9/16" CONICAL NUT		06
03	0503010804	00547-B SEAL		02
04	0503010328	25590/25523 ROLLER BEARING		02
05	0511015949	LOCK NUT		01
06	0503010329	LOCK WASHER		01
07	0503010330	KM 9 LOCKNUT		01
08	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521061549	RIGHT WHEEL ARM		01
02	0501110807	WHEELED AXLE ASSY		01
02A	0521066379	WHEELED AXLE		01
02B	0501010127	9/16" X 1-7/8" LUG BOLT		06
02C	0503013001	9/16" CONICAL NUT		06
03	0503010804	00547-B SEAL		02
04	0503010328	25590/25523 ROLLER BEARING		02
05	0511015949	LOCK NUT		01
06	0503010329	LOCK WASHER		01
07	0503010330	KM 9 LOCKNUT		01
08	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521067285	WHEEL SUPPORT		01
02	1902010175	HITCH CLAMP		04
03	0501011543	5/8" X 4" BOLT		08
04	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		08
05	0503012412	5/8" UNC SELF LOCKING NUT		08




Item	Code	Description	See page	QT
01	0521066317	RIGHT WHEEL SUPPORT		01
02	1902010175	HITCH CLAMP		04
03	0501011543	5/8" X 4" BOLT		08
04	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		08
05	0503012412	5/8" UNC SELF LOCKING NUT		08




Item	Code	Description	See page	QT
01	0503011101	CANVAS TIRE		01
02	0503010694	INNER TIRE		01
03	0503010894	0.2"X0.6"X4.6"X6F0.6"X6" WHEEL		01




Item	Code	Description	See page	QT
01	0521061630	LEFT STRETCH SUPPORT		01
02	0511061795	CHAIN TENSIONER		01
03	0503031367	SPRING		01
04	0502012669	LEVER TENSIONER REAR		01
05	0501048790	AXLE WITH RING		01
06	0503010292	701164 6 X 40 SPRING PIN		01
07	0503031805	11Z 1/2" GEAR		02
08	0503010302	501019 SEAL RING		02
09	0503010002	1800 GREASE FITTING		01
10	0501011643	3/8 X 1" BOLT		02
11	0501013518	FLAT WASHER 10,50 X 24 X 1,50 ZN		02
12	0503013357	3/8 SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521061629	RIGHT STRETCH SUPPORT		01
02	0511061795	CHAIN TENSIONER		01
03	0503031366	RIGHT TWISTED SPRING		01
04	0502012669	LEVER TENSIONER REAR		01
05	0501048790	AXLE WITH RING		01
06	0503010292	701164 6 X 40 SPRING PIN		01
07	0503031805	11Z 1/2" GEAR		02
08	0503010302	501019 SEAL RING		02
09	0503010002	1800 GREASE FITTING		01
10	0501011643	3/8 X 1" BOLT		02
11	0501013518	FLAT WASHER 10,50 X 24 X 1,50 ZN		02
12	0503013357	3/8 SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0561013049	CHAIN TIGHTENER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0501013519	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0581012765	LEFT DRIVE COVER		01
02	0581010775	MOTOR SHAFT BEARING SUPPORT		01
03	0561016503	PRISONER 3/8 UNC		04
04	0501013518	FLAT WASHER 10,50 X 24 X 1,50 ZN		08
05	0503013357	3/8 SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0581012764	RIGHT DRIVE COVER		01
02	0581010775	MOTOR SHAFT BEARING SUPPORT		01
03	0561016503	PRISONER 3/8 UNC		04
04	0501013518	FLAT WASHER 10,50 X 24 X 1,50 ZN		08
05	0503013357	3/8 SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0581014097	RATCHET HUB		01
02	0521067699	DRAG LEFT RATCHET		01
03	0581014094	RATCHET BODY		01
04	0521067697	RATCHET COVER		01
05	0503010421	5/16" X 1-1/2" BOLT		03
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		03
07	0503010337	NUT 5/16 UNC G.5 ZN		03
08	0511067501	26Z GEAR		01
09	0521018630	1.4" X SQUARE 0.8" WASHER		02
10	0503030085	LOCK PIN		01
11	0503013253	40-1 X CHAIN X 116 LINK+REDECTION		01
12	0551019100	LOCK RATCHET		02
13	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
14	0503010174	501028 CLAMPING RING (FOR AXLE)		01
15	0503031030	5/16" X 1.98" KEYWAY		01
16	0503011771	6008 2RS BALL BEARING		01
17	0503017398	HOLE RETAINER RING		01
18	0503010217	501040 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0581014097	RATCHET HUB	01	
02	0521067698	DRAG RATCHET RIGHT	01	
03	0581014094	RATCHET BODY	01	
04	0521067697	RATCHET COVER	01	
05	0503010421	5/16" X 1-1/2" BOLT	03	
06	0503010179	LOCK WASHER 5/16 ZN 1K01528	03	
07	0503010337	NUT 5/16 UNC G.5 ZN	03	
08	0511067501	26Z GEAR	01	
09	0521018630	1.4" X SQUARE 0.8" WASHER	02	
10	0503030085	LOCK PIN	01	
11	0503013253	40-1 X CHAIN X 116 LINK+REDECTION	01	
12	0551019100	LOCK RATCHET	02	
13	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING	02	
14	0503010174	501028 CLAMPING RING (FOR AXLE)	01	
15	0503031030	5/16" X 1.98" KEYWAY	01	
16	0503011771	6008 2RS BALL BEARING	01	
17	0503017398	HOLE RETAINER RING	01	
18	0503010217	501040 CLAMPING RING (FOR AXLE)	01	




Item	Code	Description	See page	QT
01	0521040065	HYDRAULIC CYLINDER 38,10 X 63,50 X 385 X 150	63	01
02	0581010814	JUNCTION AXLE 25,40 X 230		01
03	0503010571	1/4" X 1.1/2" SPLIT PIN		03
04	0521810577	COUPLING SHAFT		01
05	0511015994	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521066042	63,50 X 303 BARREL		01
02	0521066286	38,10 X 325 CYLINDER EXTENDER		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502010471	63,50 MOBILE CAP		01
05	0503010163	D-1500 SCRAPER RING		01
06	0503018003	GASKET		01
07	0503018163	BACK-UP RING		02
08	0503018162	O'RING		02
09	0503018004	RING		01
10	0581010668	RING SUPPORT		01
11	0503011109	O'RING 2-119 N 3006 9B		01
12	0503018005	RING		01
13	0502012837	PISTON		01




Item	Code	Description	See page	QT
01	0521067700	FUSE SPRING WHEELED		01
02	0511057192	EXTENSION SPRING	47	01
02A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
02B	0502011031	SPRING UPPER HITCH		02
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0581014099	WHEELED SPRING COPIER		01
06	0503013329	1/2 UNC X 4.3/4 C S G.8 RT ZN BOLT		01
07	0581013724	19,05 X 190 JUNCTION AXLE		01
08	0501010941	FLAT WASHER		02
09	0503010577	3/16" X 1.1/4" SPLIT PIN		02




Item	Code	Description	See page	QT
01	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	67	01
02	0521061628	RIGHT LEVER		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	0503010140	1/8" X 3/4" SPLIT PIN		04
05	0501011532	3/8" X 1-3/4" BOLT		01
06	0581010688	ACTUATOR LOCK SLEEVE		01
07	0501013518	FLAT WASHER 10,50 X 24 X 1,50 ZN		01
08	0503013357	3/8 SELF-ADJUSTING NUT		01
09	0503018827	CHAIN 40-1 X 57		02
10	0521066403	26Z F.R. 32,20/32,30 P.12,70 GEAR		01
11	0503010937	5/16" X 3" BOLT		01
12	0503010337	NUT 5/16 UNC G.5 ZN		02
13	0501018466	FLAT WASHER		04
14	0501110639	BEARING		02
15	0503010691	1/4" GREASE FITTING		02
16	0581010798	360 MOTOR AXLE		01
17	0503010010	1/4" X 2.1/2" SPLIT PIN		01
18	0503013849	1/4" UNC X 3/4" BOLT		12
19	0503010143	1/4" SPRING WASHER		12
20	0521065426	GEAR DRAWER		01
21	0511051532	GEAR ASSY 26Z	69	02
22	0503010707	501030 CLAMPING RING (FOR AXLE)		02
23	0503010391	501038 CLAMPING RING (FOR AXLE)		02
24	0581010793	WHEELED ARTICULATED AXLE		01
25	0521065403	GEAR DRAWER		01
26	0503030303	SUPPORT WASHER		01
27	0521018630	1.4" X SQUARE 0.8" WASHER		01
28	0511067501	26Z GEAR		01
29	0503030085	LOCK PIN		01
30	0503010756	0.2" X 2.4" SPRING PIN		01




Item	Code	Description	See page	QT
01	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	68	01
02	0521060763	AUTOMATIC ARM/DISARM LEFT LEVER		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	0503010140	1/8" X 3/4" SPLIT PIN		04
05	0501011532	3/8" X 1-3/4" BOLT		01
06	0581010688	ACTUATOR LOCK SLEEVE		01
07	0501013518	FLAT WASHER 10,50 X 24 X 1,50 ZN		01
08	0503013357	3/8 SELF-ADJUSTING NUT		01
09	0503018827	CHAIN 40-1 X 57		01
10	0521066769	20Z P12,70 GEAR 35,20/35,30 SLEEVE		01
11	0503010937	5/16" X 3" BOLT		01
12	0503010337	NUT 5/16 UNC G.5 ZN		02
13	0501018466	FLAT WASHER		04
14	0501110639	BEARING		02
15	0503010691	1/4" GREASE FITTING		02
16	0581010798	360 MOTOR AXLE		01
17	0503010010	1/4" X 2.1/2" SPLIT PIN		01
18	0503013849	1/4" UNC X 3/4" BOLT		06
19	0503010143	1/4" SPRING WASHER		06
20	0521065403	GEAR DRAWER		01
21	0511051532	GEAR ASSY 26Z	69	02
22	0503010707	501030 CLAMPING RING (FOR AXLE)		01
23	0503010391	501038 CLAMPING RING (FOR AXLE)		02
24	0581010793	WHEELED ARTICULATED AXLE		01
25	0503010756	0.2" X 2.4" SPRING PIN		01
26	0503030303	SUPPORT WASHER		01
27	0521018630	1.4" X SQUARE 0.8" WASHER		01
28	0511067501	26Z GEAR		01
29	0503030085	LOCK PIN		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 C50P G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0521017590	GUIDE AXLE		01
03	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
04	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
05	0501019734	FLAT WASHER		02
06	0502010710	RIGHT CAM, SMALLER		02
07	0503010003	1845 GREASE FITTING		02
08	0502012539	26Z P12,7 GEAR		01
09	0501019735	FLAT WASHER		01
10	0521017593	FLAT WASHER		01
11	0503010542	501045 CLAMPING RING (FOR AXLE)		01
12	0503030678	BOLT 1/2 UNC X 1.1/2 C50 G.5 ZN		01
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0521065852	26Z P12,70 GEAR		01
02	0503011800	SEAL RING		01
03	0503013170	ROLLER BEARING		01




Item	Code	Description	See page	QT
01	0521063904	HYDRAULIC MARKER HANDLE HOLDER		02
02	0502010175	HITCH CLAMP		02
03	0501011543	5/8" X 4" BOLT		04
04	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
05	0503012412	5/8" UNC SELF LOCKING NUT		04
06	0521062818	LEFT ARM		01
07	0521062819	RIGHT ARM		01
08	0501018535	1/2 X 1 BOLT		04
09	0571013458	19,05 X 230 AXIS		02
10	0501017065	FLAT WASHER		04
11	0503010577	3/16" X 1.1/4" SPLIT PIN		04
12	0501069307	ROW MARKER ARM		02
13	0521040155	HYDRAULIC CYLINDER 31,75 X 50,8 X 365 X 595	72	02
14	0521010571	COUPLING SHAFT		02
15	0503010523	1/4 X 2 SPLIT PIN		02
16	0561019695	TRANSPORT LOCK		02
17	0501068994	8,30 X 78 LOCK PIN		02
18	0503030168	HITCH PIN CLIP		02
19	0511059904	PLAY HOSE		01
19A	0501080469	3/8" X 98" TR-TC HOSE		02
19B	0501081875	HOSE 3/8 X 2850 TR-TC		02
19C	0501080365	3/8" X 137.80" TC-TM HOSE		02
20	0501054649	HBM SEQUENTIAL VALVE	73	01
21	0503011087	3/8" X 1" BOLT		02
22	0503010025	3/8" SPRING WASHER		02
23	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
24	0503011087	3/8" X 1" BOLT		02
25	0503010025	3/8" SPRING WASHER		02
26	0503010026	3/8" NUT		02
27	0571013459	SEQUENTIAL VALVE SUPPORT		01
28	0503012555	7/16" UNC X 2" CS RT G.7 ZN SCREW		06
29	0503010180	7/16" SPRING WASHER		10



PHP - TRAILED PLANTER - 04/05/06/07 ROWS (UP TO
HYDRAULIC MARKER ASSY - 2880

Page 70
0511059901

Item	Code	Description	See page	QT
30	0531011180	SUPPORT		04
31	0502012702	BODY SUPPORT CLAMP		06
32	0503011102	BOLT 7/16 UNC X 1.1/4 C S G.5 ZN		04
33	0501053834	MALE QUICK COUPLER	74	02




Item	Code	Description	See page	QT
01	0521063904	HYDRAULIC MARKER HANDLE HOLDER		02
02	0502010175	HITCH CLAMP		02
03	0501011543	5/8" X 4" BOLT		04
04	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
05	0503012412	5/8" UNC SELF LOCKING NUT		04
06	0521062818	LEFT ARM		01
07	0521062819	RIGHT ARM		01
08	0501018535	1/2 X 1 BOLT		04
09	0571013458	19,05 X 230 AXIS		02
10	0501017065	FLAT WASHER		04
11	0503010577	3/16" X 1.1/4" SPLIT PIN		04
12	0501069307	ROW MARKER ARM		02
13	0521040155	HYDRAULIC CYLINDER 31,75 X 50,8 X 365 X 595	72	02
14	0521010571	COUPLING SHAFT		02
15	0503010523	1/4 X 2 SPLIT PIN		02
16	0561019695	TRANSPORT LOCK		02
17	0501068994	8,30 X 78 LOCK PIN		02
18	0503030168	HITCH PIN CLIP		02
19	0521055492	HOSE MARKER HYDRAULIC GAME		01
19A	0501081780	3/8" X 80" TR-TC HOSE		02
19B	0501080451	3/8" X 94.50" TR-TC HOSE		02
19C	0501080365	3/8" X 137.80" TC-TM HOSE		02
20	0501054649	HBM SEQUENTIAL VALVE	73	01
21	0503011087	3/8" X 1" BOLT		02
22	0503010025	3/8" SPRING WASHER		02
23	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
24	0503011087	3/8" X 1" BOLT		02
25	0503010025	3/8" SPRING WASHER		02
26	0503010026	3/8" NUT		02
27	0571013459	SEQUENTIAL VALVE SUPPORT		01
28	0503012555	7/16" UNC X 2" CS RT G.7 ZN SCREW		06
29	0503010180	7/16" SPRING WASHER		10




PHP - TRAILLED PLANTER - 04/05/06/07 ROWS (UP TO
HYDRAULIC MARKER ASSY - PHP 1980

Page 71
0521052326


Item	Code	Description	See page	QT
30	0531011180	SUPPORT		04
31	0502012702	BODY SUPPORT CLAMP		06
32	0503011102	BOLT 7/16 UNC X 1.1/4 C S G.5 ZN		04
33	0501053834	MALE QUICK COUPLER	74	02




Item	Code	Description	See page	QT
01	0521062810	2X 350 CYLINDER BARREL		01
02	0571010344	31,75 X 456 ROD		01
03	0551019990	31,75 X 50,80 X 39,40 PISTON		01
04	0503010812	7/8" UNF SELF LOCKING NUT		01
05	0503010949	W2-2000-500 PK RING G.E		01
06	0503013920	GASKET 1870-1625		02
07	0503014677	2-118 O'RING		01
08	0503013917	O'RING 2-224		01
09	0503013914	1870-1250-312B GASKET		01
10	0503013915	D-1250 SCRAPER RING		01
11	0503013918	8-224 BACK-UP RING		01
12	0503014683	W1-1400-500 RING GUIDE		01
13	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		01
14	0503012412	5/8" UNC SELF LOCKING NUT		01
15	0571010576	MARKER SUPPORT WASHER		01
16	0571011410	RING SUPPORT		01
17	0571011411	MOBILE CYLINDER LID		01
18	0503033686	SLEEVE 22 X 38 X 12,50 RUBBER		02
19	0501038643	CYLINDER REPAIR KIT (0503032411)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	NIPLE 3/4" NF X 3/4" NF HEX. 7/8" X 44		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	76	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		01




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER 5/16"		04
16	0503010337	NUT 5/16 UNC G.5 ZN		04




Item	Code	Description	See page	QT
01	0503060100	SUPPORT INSTRUCTION MANUAL		01
02	0503010267	NYLON CLAMP 3,60 X 1,3 X 155 MM		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER 8,50 X 18 X 1,50 ZN		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	NUT 5/16 UNC G.5 ZN		01
07	0511032389	MANUAL PACKING		01




Item	Code	Description	See page	QT
01	0521050798	DIVIDER VALVE ASSEMBLY	79	01
02	0503011102	BOLT 7/16 UNC X 1.1/4 C S G.5 ZN		02
03	0503010025	3/8" SPRING WASHER		02
04	0531011180	SUPPORT		08
05	0511059906	PLAY HOSE		01
05A	0501080412	3/8" X 90.55" TR-TC HOSE		02
05B	0501080452	3/8" X 98" TR-TR HOSE		02
05C	0521053757	3/8" X 118" TR-TM BLACK/RED HOSE		01
05D	0521053758	3/8" X 118" TR-TM BLACK/BLEU HOSE		01
06	0501053834	MALE QUICK COUPLER	74	02




Item	Code	Description	See page	QT
01	0581014101	VALVE SUPPORT		01
02	0521050797	FLOW DIVIDER VALVE		01
02A	0503012481	FLOW DIVIDING VALVE		01
02B	0501010617	NIPPLE 3/4" NF X 3/4" NF HEX. 7/8" X 44		03
02C	0503010190	2-114 N 3006-9B O'RING		03
03	0503037376	3/4" T ADAPTER WITH SWIVEL NUT		01
04	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		02
05	0541012165	3/4" NIPPLE		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
07	0501013518	FLAT WASHER 10,50 X 24 X 1,50 ZN		02
08	0503010025	3/8" SPRING WASHER		02
09	0503010026	3/8" NUT		02
10	0503010882	BOLT		02
11	0501010694	FLAT WASHER 8,50 X 18 X 1,50 ZN		02
12	0503013759	NUT		02





Item	Code	Description	See page	QT
01	0581018041	VALVE SUPPORT		01
02	0521050797	FLOW DIVIDER VALVE		01
02A	0503012481	FLOW DIVIDING VALVE		01
02B	0501010617	NIPPLE 3/4" NF X 3/4" NF HEX. 7/8" X 44		03
02C	0503010190	2-114 N 3006-9B O'RING		03
03	0503037376	3/4" T ADAPTER WITH SWIVEL NUT		01
04	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		02
05	0541012165	3/4" NIPPLE		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
07	0501013518	FLAT WASHER 10,50 X 24 X 1,50 ZN		02
08	0503010025	3/8" SPRING WASHER		02
09	0503010026	3/8" NUT		02
10	0503010882	BOLT		02
11	0501010694	FLAT WASHER 8,50 X 18 X 1,50 ZN		02
12	0503013759	NUT		02



Item	Code	Description	See page	QT
01	0503030379	LARGER ROCKER ARM		01
02	0502060001	PLASTIC PULLEY FOR MAIZE		01
03	0503010669	FLAT WASHER 5 X 11 X 1,00 ZN		01
04	0503010667	3/16" NUT		02
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		01



0503033854



0503033853



0503031428



0503034078



0503032930



0503033424



0503030360



0503030362




0503033416



0503033422



0503033414



0503034500



0503033897

Item	Code	Description	See page	QT
01	0503033854	TATU LOGO DECAL		04
02	0503033853	SIDE TATU LOGO DECAL		02
03	0503031428	ATTENTION READ MANUAL DECAL		01
04	0503034078	LIFTING POINTS DECAL		02
05	0503032930	DANGER DECAL		08
06	0503033424	DIRECT PLANTING DECAL		02
07	0503030360	MOTOR ADHESIVE LABEL 25 X 85		02
08	0503030362	ADHESIVE LABEL MOVED 25 X 85		02
09	0503033416	NUMBER 2 DECAL		02
10	0503033422	NUMBER 8 DECAL		04
11	0503033414	NUMBER 0 DECAL		02
12	0503034500	GRIP COLORS (PLANTERS) DECAL		01
13	0503033897	BIGGEST ADHESIVE LABEL		02




0503033853



0503031424



0503031428



0503034078



0503032930



0503033424



0503030360



0503030362




0503033415




0503033422



0503033423



0503033414



0503034500


Item	Code	Description	See page	QT
01	0503033853	SIDE TATU LOGO DECAL		02
02	0503031424	ATTENTION HYDRAULIC MARKER DECAL		02
03	0503031428	ATTENTION READ MANUAL DECAL		01
04	0503034078	LIFTING POINTS DECAL		02
05	0503032930	DANGER DECAL		08
06	0503033424	DIRECT PLANTING DECAL		02
07	0503030360	MOTOR ADHESIVE LABEL 25 X 85		02
08	0503030362	ADHESIVE LABEL MOVED 25 X 85		02
09	0503033415	ADHESIVE LABEL		02
10	0503033422	NUMBER 8 DECAL		02
11	0503033423	NUMBER 9 DECAL		02
12	0503033414	NUMBER 0 DECAL		02
13	0503034500	GRIP COLORS (PLANTERS) DECAL		01




0503033853



0503031424



0503031428



0503034078



0503032930



0503033424




0503030360




0503030362




0503033416



0503033422



0503033414



0503034500




0503033865




0503033874

Item	Code	Description	See page	QT
01	0503033853	SIDE TATU LOGO DECAL		02
02	0503031424	ATTENTION HYDRAULIC MARKER DECAL		02
03	0503031428	ATTENTION READ MANUAL DECAL		01
04	0503034078	LIFTING POINTS DECAL		02
05	0503032930	DANGER DECAL		08
06	0503033424	DIRECT PLANTING DECAL		02
07	0503030360	MOTOR ADHESIVE LABEL 25 X 85		02
08	0503030362	ADHESIVE LABEL MOVED 25 X 85		02
09	0503033416	NUMBER 2 DECAL		02
10	0503033422	NUMBER 8 DECAL		04
11	0503033414	NUMBER 0 DECAL		02
12	0503034500	GRIP COLORS (PLANTERS) DECAL		01
13	0503033865	SMALL ADHESIVE LABEL		02
14	0503033874	ADHESIVE LABEL LOGO TATU BOX 180X545		02



Item	Code	Description	See page	QT
01	0501110262	245 ADJUSTMENT NUT		01
02	0511060558	RIGHT TURNBUCKLE		01
03	0511060559	LEFT TURNBUCKLE		01
04	0501061056	1.1/2" RIGHT LOCK-NUT		01
05	0503010002	1800 GREASE FITTING		02



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

