


PARTS CATALOG

ROW CROP PLANTERS

PHT SUPREMA-CONVENTIONAL-41/DIRECT-41

Code: 0501092363



Series: S-0595

Rev.: 00

Date Rev.: FEVEREIRO/2019

ORIGINAL PARTS
TATU



PRODUCTS

Code	Description	
0111030023	PHT 8/4 C41 PNEUMATIC	S-0595
0111030027	PHT 8/4 D41 PNEUMATIC	S-0595
0111030021	PHT 8/5 C41 PNEUMATIC	S-0595
0111030028	PHT 8/5 D41 PNEUMATIC	S-0595
0111030024	PHT 8/6 C41 PNEUMATIC	S-0595
0111030029	PHT 8/6 D41 PNEUMATIC	S-0595
0111030025	PHT 8/7 C41 PNEUMATIC	S-0595
0111030030	PHT 8/7 D41 PNEUMATIC	S-0595
0111030026	PHT 8/8 C41 PNEUMATIC	S-0595
0111030031	PHT 8/8 D41 PNEUMATIC	S-0595


ATTENTION: **IMPORTANT**

MARCHESAN S/A RESERVES THE RIGHT AT ANY TIME TO MAKE IMPROVEMENTS IN THE DESIGN, MATERIAL OR SPECIFICATIONS OF MACHINERY, EQUIPMENT OR PARTS WITHOUT THEREBY BECOMING LIABLE TO MAKE SIMILAR CHANGES IN MACHINERY, EQUIPMENT OR PARTS PREVIOUSLY SOLD.

INDEX

0909095066	FRAME ASSY	1
0501050889	SEMIFINISHED FRAME	2
0909095046	ROW MARKER	3
0909095047	CARRYNG-WHEELS ASSY	4
0909095048	ENGINE AXLE ASSY	5
0909095073	FERTILIZER BOX ASSY	6
0909095065	HEXAGONAL SHAFT ASSEMBLY	7
0501042500	CHAIN TENSIONER ASSY	8
0501041671	RIGHT TRANSM CHAIN TENSIONER	9
0909095285	SEED/FERTILIZER ROW ASSY	10
0501047062	SEED ROW	11
0501047060	DDD SEED LINEA ASSY	12
0501047061	DDD SEED LINEA ASSY	13
0909091405	DDD FERTILIZER ROW ASSY	14
0909091403	FERTILIZER ROW ASSY	15
0511041090	PNEUMATIC SEED DISTRIBUTOR	16
0501050728	PRESS WHEELS/DEPTH ASSY	17
0501050717	SEED ROW DEPTH WHEEL REGULATOR	18
0501050916	LEFT DEPTH CONTROL WHEEL ASSY	19
0501050915	RIGHT DEPTH CONTROL WHEEL ASSY	20
0501052627	ASSY DEPTH WHEEL BOX	21
0501052564	RIGHT ARM DEPTH CONTROL WHEEL	22
0501052565	LEFT ARM DEPTH CONTROL WHEEL	23
0501052538	DEPTH CONTROL WHEEL RUBBER BAND	24
0501047701	LH SEED UNAL DOUB-DISC ASSY	25
0501047702	SEED UNAL DOUB-DISC ASSY	26
0511040018	CARDAN TURBINE	27
0909095304	ADHESIVE	28

FRAME ASSY




Item	Code	Description	See page	QT
01	0501050889	SEMIFINISHED FRAME	2	01
02	0909095046	ROW MARKER	3	01
03	0909095047	CARRYNG-WHEELS ASSY	4	02
04	0909095048	ENGINE AXLE ASSY	5	01
05	0909095073	FERTILIZER BOX ASSY	6	01
06	0909095065	HEXAGONAL SHAFT ASSEMBLY	7	01
07	0501042500	CHAIN TENSIONER ASSY	8	02
08	0501041671	RIGHT TRANSM CHAIN TENSIONER	9	02
09	0501047060	DDD SEED LINEA ASSY	12	02
10	0501047056	RH DDD FERTILIZER ROW ASSY		02
11	0501047061	DDD SEED LINEA ASSY	13	02
12	0501047057	LH DDD FERTILIZER ROW ASSY		02
13	0503010306	2050 CHAIN X 47 LINK + MENDING		02
14	0503010450	2050 CHAIN X 30 LINK + REDUCTION		02
15	0503010679	2050 CHAIN X 36 LINK + REDUCTION		02
16	0511010806	RIGHT CHAIN COVER		01
17	0511010807	RIGHTCHAIN COVER		01
18	0501013702	HEX STUD 3/8" X 3/8" X 142MM		04
19	0503010025	3/8 SPRING WASHER		04
20	0503010026	3/8" NUT		04
21	0501011020	FLAT WASHER		04
22	0503010209	3/8" UNC BUTTERFLY NUT		04
23	0511040018	CARDAN TURBINE	27	01
24	0503010849	3/8" X 1-1/2" BOLT		04
25	0503010025	3/8 SPRING WASHER		04
26	0503010026	3/8" NUT		04
27	0501047551	DRIVE SHAFT		01
28	0501067849	AIR DITRIBUTOR		01
29	0531017072	AIR DISTRIBUTOR FIXER		01
30	0531017071	DISTRIBUTOR SUPPORT AIR		01
31	0503010363	5/16" X 1" BOLT		02



FRAME ASSY


0909095066

Item	Code	Description	See page	QT
32	0503010179	SPRING WASHER		02
33	0503010337	5/16" NUT		02
34	0511010360	CLAMP		02
35	0511017302	FLAT WASHER		04
36	0503010019	1/2" SPRING WASHER		04
37	0503010060	1/2" NUT		04



Item	Code	Description	See page	QT
001	0501068303	FRAME		01
002	0502010817	TRACTOR HITCH		02
003	0502010819	TRACTOR HITCH FIXER		02
004	0503010901	3/4UNC 3.1/2 BOLT		04
005	0503010023	SPRING WASHER		04
006	0503010014	3/4" NUT		04
007	0521010595	1.1" X 4.3" COUPLING SHAFT		02
008	0521011132	FLAT WASHER		04
009	0503031035	HAIR PIN		02
010	0521010579	COUPLING SHAFT		01
011	0503030085	LOCK PIN		01

ROW MARKER




Item	Code	Description	See page	QT
01	0501065331	RH ROW MARKER SUPPORT	01	01
02	0501066555	LH ROW MARKER SUPPORT	01	01
03	0502011170	FIXER	02	02
04	0503011084	3/4" X 5" BOLT	04	04
05	0503010023	SPRING WASHER	04	04
06	0503010014	3/4" NUT	04	04
07	0501065332	RH ROW MARKER ARM	01	01
08	0501066554	LH ROW MARKER ARM	01	01
09	0511010800	ROW MARKER AXLE	02	02
10	0503010577	3/16" X 1-1/4" COTTERPIN	04	04
11	0501065337	PLOUGH SUPPORT	02	02
12	0501013671	0.3" X 2.4" X 0.3" X 2.6" PIN	02	02
13	0501013159	11,11 MM X 47 MM PIN	02	02
14	0503030168	HAIR PIN	02	02
15	0503010140	1/8" X 3/4" COTTERPIN	02	02
16	0501018500	ROW MARK TURNBUCKLE	02	02
17	0503010834	1/2 X 1 BOLT	02	02
18	0501065617	DISC FIXER ROW MARKER	02	02
19	0503010232	5/8" X 1.3/4" BOLT	02	02
20	0503010013	5/8" NUT	02	02
21	0501050293	MARKER DISC HUB	02	02
22	0503010765	3/8" X 3" BOLT	02	02
23	0502010421	SIDE PULLEY	02	02
24	0511019373	0.39" X 0.63" X 1.50" BUSHING	02	02
25	0501010984	FLAT WASHER	02	02
26	0503010025	3/8 SPRING WASHER	02	02
27	0503010026	3/8" NUT	02	02
28	0501065334	REAR LEVER FASTENER	01	01
29	0511010610	PULLEY SUPPORT	01	01
30	0501065335	LEVER	01	01
31	0503030190	0.5" X 1.6" X 0.05" SPRING	01	01




ROW MARKER

0909095046

Item	Code	Description	See page	QT
32	0501010984	FLAT WASHER		01
33	0511010804	SPRING ROD		01
34	0503010140	1/8" X 3/4" COTTERPIN		01
35	0502010420	CENTRAL PULLEY		02
36	0503010240	5/16" X 3/4" BOLT		02
37	0503010179	SPRING WASHER		02
38	0503010337	5/16" NUT		02
39	0501011048	3/8" X 2-1/2" BOLT		02
40	0511014569	0.39" X 0.75" 1.42" BUSHING		02
41	0501010276	1" X 3" BOLT		01
42	0503010012	1" SPRING WASHER		01
43	0501010059	1.5/8 NUT		01
44	0501046986	CHAIN ROW MARKER COUPLING		02
44A	0511017454	CHAIN WHIT LINK		01
44B	0501013783	HOOK WITH CHAIN		02
45	0511010805	3/8" X 216.54" ROPE		01
46	0511017450	ANGLE BAR		01
47	0501010276	1" X 3" BOLT		01
48	0503010012	1" SPRING WASHER		01
49	0501010059	1.5/8 NUT		01
50	0503010296	CLAMP		02




Item	Code	Description	See page	QT
01	0501065326	RH WHEEL ARM	02	
02	0501065327	LH WHEEL ARM	02	
03	0501043676	CARRY-WEEL SYS WIT TIRE	02	
04	0501017066	FLAT WASHER	04	
05	0503010023	SPRING WASHER	04	
06	0503010014	3/4" NUT	04	
07	0502010818	CARRYNG-WHEELS FIXER SUPPORT	02	
08	0511010809	PIVOT SHAFT	02	
09	0501010322	FLAT WASHER	04	
10	0503010023	SPRING WASHER	04	
11	0503010014	3/4" NUT	04	
12	0502011170	FIXER	02	
13	0501011543	5/8" X 4" BOLT	04	
14	0501012140	FLAT WASHER	04	
15	0503010027	SPRING WASHER	04	
16	0503010013	5/8" NUT	04	
17	0511044310	CHAIN TENSIONER ASSY	02	
17A	0511066810	WHEEL CHAIN TENSIONER	01	
17B	0503030402	PULLEY	02	
17C	0503010302	501019 SEAL RING	02	
18	0503030093	TRACTION SPRING	02	
19	0503010025	3/8 SPRING WASHER	02	
20	0503010026	3/8" NUT	02	



Item	Code	Description	See page	QT
01	0501051614	TRANSMISSION RIGHT DRIVING		02
01.	0501051615	TRANSMISSION LEFT DRIVING		01
02	0511010799	1.3/8" X 1200MM MOTOR SHAFT		02
03	0501110025	AGRICULTURAL BEARING		04
04	0502010410	8Z GEAR		02
05	0502011345	18Z P 1.25" RH 1.3/8" GEAR		02
06	0503010010	1/4" X 2.1/2" COTTERPIN		04
07	0501067355	RH RATCHET HANDLE LEVER		01
08	0501067356	LH RATCHET HANDLE LEVER		01
09	0511017302	FLAT WASHER		02
10	0503010300	5/32" X 1" COTTERPIN		04
11	0503010238	1/2" X 1-3/4" BOLT		02
12	0501010937	FLAT WASHER		02
13	0503010019	1/2" SPRING WASHER		02
14	0503010060	1/2" NUT		02
15	0503010002	1800 GREASE FITTING		02
16	0501013671	0.3" X 2.4" X 0.3" X 2.6" PIN		02

FERTILIZER BOX ASSY



Item	Code	Description	See page	QT
00	0501046983	RIGHT FERTILIZER BOX	01	
00.	0501046984	LEFT BOX FERTILIZER	01	
01	0501068308	RIGHT FERTILIZER BOX	01	
01.	0501068309	LEFT BOX FERTILIZER	01	
02	0501050273	LH FERTILIZER METERING	04	
02.	0501050272	DISTRIBUTOR OF RIGHT FERTILIZER	04	
02A	0501110120	FERTILIZER DISTRIBUTOR BODY	08	
02Aa	0502010596	FERTILIZER DISTRIBUTOR BODY	08	
02Ab	0511013789	FERTILIZER TUBE	08	
02B	0503013155	1/4" X 1.1/4" COTTERPIN	16	
02C	0501017391	3/4" X 14.3" SQUARE SHAFT	08	
02D	0503030275	AGRICULTURAL BEARING	16	
02E	0501013774	GREASE SEAL	08	
02F	0503030303	SUPPORT WASHER	08	
02G	0501010637	FLAT WASHER	16	
02H	0503031164	RIGHT HELICAL CONDUTOR	04	
02I	0503031165	LEFT HELICAL CONDUTOR	04	
02J	0502011304	1.5" X 2.0" X 1.2" SLEEVE INTER	08	
02K	0503011962	GREASE FITTING	08	
02L	0503010004	1890 GREASE FITTING	08	
03	0501010942	3/8" X 1-1/4" BOLT	32	
04	0501011020	FLAT WASHER	32	
05	0503011443	SPRING WASHER	32	
06	0503010026	3/8" NUT	32	
07	0501050274	BOX BEARING ASSY	02	
07A	0501110001	BOX BEARING ASSY	02	
07B	0502040379	FERTILIZER BOX BEARINGREEL	02	
07C	0503010372	501050 CLAMPING RING (FOR AXLE)	02	
07D	0503010002	1800 GREASE FITTING	02	
08	0501010063	1/2" X 1-1/2" BOLT	06	
09	0503011440	SPRING WASHER	06	




FERTILIZER BOX ASSY


0909095073

Item	Code	Description	See page	QT
10	0503010060	1/2" NUT		06
11	0502011300	BUSHING GEAR		02
12	0502011314	8Z P 1.1/4" RH1.4" GEAR		02
13	0503010010	1/4" X 2.1/2" COTTERPIN		02
14	0501017476	DRAGING		06
15	0503010397	5/16" X 1-3/4" BOLT		06
16	0503010337	5/16" NUT		12
17	0501010080	3/8" BOLT		08
18	0501011020	FLAT WASHER		08
19	0501065345	SEED BOX COVER		02
20	0501011742	MOBILE HINGE		04
21	0503010295	5/16" X 5/8" BOLT		04
22	0501010694	FLAT WASHER		04
23	0503010179	SPRING WASHER		04
24	0511011015	FIXED HINGE		04
25	0503010358	5/16" X 5/8" BOLT		08
26	0511010238	6,8MM X 40MM PIN		04
27	0503010140	1/8" X 3/4" COTTERPIN		04
28	0503010293	BAQUELITE MANIPULACION		02
29	0511013417	1/8" X 29 LINK CHAIN		02
30	0503010025	3/8 SPRING WASHER		08
31	0503010298	1/4" X 1/2" BOLT		02
32	0503010305	FLAT WASHER		02
33	0503010144	1/4" NUT		02


HEXAGONAL SHAFT ASSEMBLY




Item	Code	Description	See page	QT
01	0501017440	5/8" X 60.4" HEX AXLE		01
02	0501017441	5/8" X 69.3" HEX AXLE		01
03	0502040723	5/8 HEX AXLE BEARING SLEEVE		02
04	0502011299	BUSHING GEAR		02
05	0502011314	8Z P 1.1/4" RH1.4" GEAR		02
06	0501110036	HEX AXLE RIGHT BEARING ASSY		02
07	0501017558	5/8" HEX AXLE BEARING SUPPORT		02
08	0501010063	1/2" X 1-1/2" BOLT		04
09	0501010937	FLAT WASHER		04
10	0503010019	1/2" SPRING WASHER		04
11	0503012682	1/2" BSW NUT		04
12	0503010363	5/16" X 1" BOLT		04
13	0503010179	SPRING WASHER		04
14	0503010337	5/16" NUT		04
15	0501013671	0.3" X 2.4" X 0.3" X 2.6" PIN		02
16	0503010140	1/8" X 3/4" COTTERPIN		02



Item	Code	Description	See page	QT
001	0501067694	CHAIN TENSIONER		01
002	0503030402	PULLEY		02
003	0503010302	501019 SEAL RING		02
004	0503010002	1800 GREASE FITTING		02
005	0503010300	5/32" X 1" COTTERPIN		02
006	0503030418	TRACTION SPRING		02




Item	Code	Description	See page	QT
001	0501062729	CHAIN TENSIONER SUPPORT		01
002	0511018661	3/4" X 3.3" PIVOT SHAFT		01
003	0503010023	SPRING WASHER		01
004	0503011260	3/4" HEX NUT		01
005	0503030417	1.7"X 1.4"X 0.14" RH TORSION SPRING		01
006	0503010292	0.2" X 1.6" SPRING PIN		01
007	0503010002	1800 GREASE FITTING		03
008	0503030402	PULLEY		02
009	0503010302	501019 SEAL RING		02
010	1882970002	GREASE SOAP		00
011	0501010322	FLAT WASHER		01



Item	Code	Description	See page	QT
01	0501047062	SEED ROW	11	01
02	0501047060	DDD SEED LINEA ASSY	12	01
03	0501047061	DDD SEED LINEA ASSY	13	01
04	0909091403	FERTILIZER ROW ASSY	15	01
05	0909091405	DDD FERTILIZER ROW ASSY	14	01

SEED ROW




Item	Code	Description	See page	QT
01	0502010573	LOWER BEARING SEMI	01	01
02	0521010672	5/8" X 4.9" X 4.4" FASTENER	01	01
03	0503010027	SPRING WASHER	02	02
04	0503010013	5/8" NUT	02	02
05	0502011261	LOCK SUPORT	01	01
06	0502010426	UPPER BEARING SEMI	02	02
07	0503010479	1/2" X 3" BOLT	04	04
08	0503010019	1/2" SPRING WASHER	04	04
09	0503010060	1/2" NUT	04	04
10	0511017313	SEED ROW ARM	01	01
11	0502011413	18Z CONICAL GEAR	01	01
12	0511010813	1/2" X 580MM HEX AXLE	01	01
13	0501013352	FLAT WASHER	02	02
14	0501013354	FLAT WASHER	01	01
15	0502011296	1/2 HEX AXLE BEARING SLEEVE	01	01
16	0502011505	18Z CONICAL GEAR	01	01
17	0501013354	FLAT WASHER	01	01
18	0502011413	18Z CONICAL GEAR	01	01
19	0502011505	18Z CONICAL GEAR	01	01
20	0511011971	1/2" X 46" HEX AXLE	01	01
21	0501069018	12Z GEAR	01	01
22	0503011371	CHAIN TR-081 X 1.8" LINK + MENDING	01	01
23	0501068425	PROTECTION	01	01
24	0502011296	1/2 HEX AXLE BEARING SLEEVE	02	02
25	0503010257	1/8" X 1" COTTERPIN	02	02
26	0503010337	5/16" NUT	04	04
27	0503010752	1/2" X 3.1/2" BOLT	02	02
28	0503010019	1/2" SPRING WASHER	02	02
29	0503010060	1/2" NUT	02	02
30	0503030150	BEND SOCKET	01	01
31	0521011744	0.3" X 3.1" COUPLING SHAFT	01	01



SEED ROW

0501047062


Item	Code	Description	See page	QT
32	0503010257	1/8" X 1" COTTERPIN		01
33	0503010002	1800 GREASE FITTING		03
34	0503010691	1/4" GREASE FITTING		02
35	0501062628	SPINDLE GUIDE		01
36	0511015610	SPRING GUIDE FIXER PIN		01
37	0503010257	1/8" X 1" COTTERPIN		01
38	0501011090	FLAT WASHER		02
39	0503030187	1" X 19" X 4" COMPRESSION SPRING		01
40	0502040534	SPRING GUIDE BUSHING LOCK		02
41	0503010834	1/2 X 1 BOLT		02
42	0503030168	HAIR PIN		01
43	0511041090	PNEUMATIC SEED DISTRIBUTOR	16	01
44	0503010428	M12 X 1,75 X30 BOLT		03
45	0503010019	1/2" SPRING WASHER		03
46	0501046289	DEPTH CONTROL PRESS WHEELS		08
47	0503011053	5/16" X 3" C S 6.5 ZN BOLT		02
48	0503010179	SPRING WASHER		02
49	0503010337	5/16" NUT		02
50	0503010674	7/16" X 3-1/4" BOLT		01
51	0503010180	7/16" SPRING WASHER		01
52	0503010244	7/16" NUT		01
53	0521010189	ARTIC SUPPORT COVER		01
54	0503013758	1/4" X 1-1/2" BOLT		02
55	0511017303	FLAT WASHER		02
56	0503010143	SPRING WASHER		02
57	0501067067	TUBE		01
58	0503030961	4.6" X 3.3" X 0.03" JOINT		01
59	0503011378	M6 X 1" BOLT		03
60	0503010143	SPRING WASHER		03
61	0511015570	AIR CONDUCTOR 1.1/4 X 1500		01
62	0503010184	CLAMP		02
63	0501067828	HOSE HOLDER		01
64	0502010820	ROD GUIDE ROW		01
65	0502011210	ROW FASTENER		01
66	0501011543	5/8" X 4" BOLT		01
67	0503010027	SPRING WASHER		01
68	0503010013	5/8" NUT		01
69	0503060172	SEED DRAINER		01
70	0503013815	1/4" X 5/8" BOLT		02
71	0503010326	1/4" UNC BUTTERFLY NUT		02
72	0503031083	SEED RESERVOIR ASSY		01
73	0503010240	5/16" X 3/4" BOLT		04
74	0503010179	SPRING WASHER		04
75	0501067064	SUPPORT DISTRIBUTOR SEED		01
76	0511060732	HEX AXLE BEARING SUPPORT		01



Item	Code	Description	See page	QT
01	0502010573	LOWER BEARING SEMI		01
02	0521010672	5/8" X 4.9" X 4.4" FASTENER		01
03	0503010027	SPRING WASHER		02
04	0503010013	5/8" NUT		02
05	0502011261	LOCK SUPORT		01
06	0502010426	UPPER BEARING SEMI		02
07	0503010479	1/2" X 3" BOLT		04
08	0503010019	1/2" SPRING WASHER		04
09	0503010060	1/2" NUT		04
10	0511017313	SEED ROW ARM		01
11	0502011413	18Z CONICAL GEAR		01
12	0511010813	1/2" X 580MM HEX AXLE		01
13	0501013352	FLAT WASHER		02
14	0501013354	FLAT WASHER		01
15	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
16	0502011505	18Z CONICAL GEAR		01
17	0501013354	FLAT WASHER		01
18	0502011413	18Z CONICAL GEAR		01
19	0502011505	18Z CONICAL GEAR		01
20	0511011971	1/2" X 46" HEX AXLE		01
21	0501069018	12Z GEAR		01
22	0503011371	CHAIN TR-081 X 1.8" LINK + MENDING		01
23	0501068425	PROTECTION		01
24	0502011296	1/2 HEX AXLE BEARING SLEEVE		02
25	0503010257	1/8" X 1" COTTERPIN		02
26	0501047701	LH SEED UNAL DOUB-DISC ASSY	25	01
27	0503010752	1/2" X 3.1/2" BOLT		02
28	0503010019	1/2" SPRING WASHER		02
29	0503010060	1/2" NUT		02
30	0521011744	0.3" X 3.1" COUPLING SHAFT		01
31	0503010257	1/8" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
32	0503010002	1800 GREASE FITTING		03
33	0503010691	1/4" GREASE FITTING		02
34	0501062628	SPINDLE GUIDE		01
35	0511015610	SPRING GUIDE FIXER PIN		01
36	0503010257	1/8" X 1" COTTERPIN		01
37	0501011090	FLAT WASHER		02
38	0503030184	1.6" X 19" X 6" COMPRESSION SPRING		01
39	0503030187	1" X 19" X 4" COMPRESSION SPRING		01
40	0503030188	2" X 19" X 8" COMPRESSION SPRING		01
41	0502040534	SPRING GUIDE BUSHING LOCK		02
42	0503010834	1/2 X 1 BOLT		02
43	0503030168	HAIR PIN		01
44	0511041090	PNEUMATIC SEED DISTRIBUTOR	16	01
45	0503010428	M12 X 1,75 X30 BOLT		03
46	0503010019	1/2" SPRING WASHER		03
47	0501046291	DEPTH CONTROL PRESS WHEEL ASSY		01
48	0503011053	5/16" X 3" C S 6.5 ZN BOLT		02
49	0503010179	SPRING WASHER		02
50	0503010337	5/16" NUT		02
51	0503010674	7/16" X 3-1/4" BOLT		01
52	0503010180	7/16" SPRING WASHER		01
53	0503010244	7/16" NUT		01
54	0521010189	ARTIC SUPPORT COVER		01
55	0503013758	1/4" X 1-1/2" BOLT		02
56	0511017303	FLAT WASHER		02
57	0503010143	SPRING WASHER		02
58	0501067067	TUBE		01
59	0503030961	4.6" X 3.3" X 0.03" JOINT		01
60	0503011378	M6 X 1" BOLT		03
61	0503010143	SPRING WASHER		03
62	0511015570	AIR CONDUCTOR 1.1/4 X 1500		01
63	0503010184	CLAMP		02
64	0501067828	HOSE HOLDER		01
65	0502011053	SPRING ROD GUIDE SUPPORT		01
66	0503010547	1/2" X 4" BOLT		01
67	0503010019	1/2" SPRING WASHER		01
68	0503012682	1/2" BSW NUT		01
69	0502011210	ROW FASTENER		01
70	0501011543	5/8" X 4" BOLT		01
71	0503010027	SPRING WASHER		01
72	0503010013	5/8" NUT		01
73	0503060172	SEED DRAINER		01
74	0503013815	1/4" X 5/8" BOLT		02
75	0503010326	1/4" UNC BUTTERFLY NUT		02
76	0503031083	SEED RESERVOIR ASSY		01
77	0503010240	5/16" X 3/4" BOLT		04
78	0503010179	SPRING WASHER		04
79	0503010337	5/16" NUT		04
80	0501067064	SUPPORT DISTRIBUTOR SEED		01
81	0511060732	HEX AXLE BEARING SUPPORT		01



Item	Code	Description	See page	QT
001	0502010573	LOWER BEARING SEMI		01
002	0521010672	5/8" X 4.9" X 4.4" FASTENER		01
003	0503010027	SPRING WASHER		02
004	0503010013	5/8" NUT		02
005	0502011261	LOCK SUPORT		01
006	0502010426	UPPER BEARING SEMI		02
007	0503010479	1/2" X 3" BOLT		04
008	0503010019	1/2" SPRING WASHER		04
009	0503010060	1/2" NUT		04
010	0511017313	SEED ROW ARM		01
011	0502011413	18Z CONICAL GEAR		01
012	0511010813	1/2" X 580MM HEX AXLE		01
013	0501013352	FLAT WASHER		02
014	0501013354	FLAT WASHER		01
015	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
016	0502011505	18Z CONICAL GEAR		01
017	0501013354	FLAT WASHER		01
018	0502011413	18Z CONICAL GEAR		01
019	0502011505	18Z CONICAL GEAR		01
020	0511011971	1/2" X 46" HEX AXLE		01
021	0501069018	12Z GEAR		01
022	0503011371	CHAIN TR-081 X 1.8" LINK + MENDING		01
023	0501068425	PROTECTION		01
024	0502011296	1/2 HEX AXLE BEARING SLEEVE		02
025	0503010257	1/8" X 1" COTTERPIN		02
026	0501047702	SEED UNAL DOUB-DISC ASSY	26	01
027	0503010752	1/2" X 3.1/2" BOLT		02
028	0503010019	1/2" SPRING WASHER		02
029	0503010060	1/2" NUT		02
030	0521011744	0.3" X 3.1" COUPLING SHAFT		01
031	0503010257	1/8" X 1" COTTERPIN		01



Item	Code	Description	See page	QT
032	0503010002	1800 GREASE FITTING		03
033	0503010691	1/4" GREASE FITTING		02
034	0501062628	SPINDLE GUIDE		01
035	0511015610	SPRING GUIDE FIXER PIN		01
036	0503010257	1/8" X 1" COTTERPIN		01
037	0501011090	FLAT WASHER		02
038	0503030184	1.6" X 19" X 6" COMPRESSION SPRING		01
039	0503030187	1" X 19" X 4" COMPRESSION SPRING		01
040	0503030188	2" X 19" X 8" COMPRESSION SPRING		01
041	0502040534	SPRING GUIDE BUSHING LOCK		02
042	0503010834	1/2 X 1 BOLT		02
043	0503030168	HAIR PIN		01
044	0511041090	PNEUMATIC SEED DISTRIBUTOR	16	01
045	0503010428	M12 X 1,75 X30 BOLT		03
046	0503010019	1/2" SPRING WASHER		03
047	0501046291	DEPTH CONTROL PRESS WHEEL ASSY		01
048	0503011053	5/16" X 3" C S 6.5 ZN BOLT		02
049	0503010179	SPRING WASHER		02
050	0503010337	5/16" NUT		02
051	0503010674	7/16" X 3-1/4" BOLT		01
052	0503010180	7/16" SPRING WASHER		01
053	0503010244	7/16" NUT		01
054	0521010189	ARTIC SUPPORT COVER		01
055	0503013758	1/4" X 1-1/2" BOLT		02
056	0511017303	FLAT WASHER		02
057	0503010143	SPRING WASHER		02
058	0501067067	TUBE		01
059	0503030961	4.6" X 3.3" X 0.03" JOINT		01
060	0503011378	M6 X 1" BOLT		03
061	0503010143	SPRING WASHER		03
062	0511015570	AIR CONDUCTOR 1.1/4 X 1500		01
063	0503010184	CLAMP		02
064	0501067828	HOSE HOLDER		01
065	0502010820	ROD GUIDE ROW		01
066	0502011210	ROW FASTENER		01
067	0501011543	5/8" X 4" BOLT		01
068	0503010027	SPRING WASHER		01
069	0503010013	5/8" NUT		01
070	0503060172	SEED DRAINER		01
071	0503013815	1/4" X 5/8" BOLT		02
072	0503010326	1/4" UNC BUTTERFLY NUT		02
073	0503031083	SEED RESERVOIR ASSY		01
074	0503010240	5/16" X 3/4" BOLT		04
075	0503010179	SPRING WASHER		04
076	0503010337	5/16" NUT		04
077	0501067064	SUPPORT DISTRIBUTOR SEED		01
078	0511060732	HEX AXLE BEARING SUPPORT		01



Item	Code	Description	See page	QT
00	0501047056	RH DDD FERTILIZER ROW ASSY		01
00.	0501047057	LH DDD FERTILIZER ROW ASSY		01
01	0502010892	FERTILIZER ROW SUPPORT		01
02	0521010669	5/8" X 4.33" X 3.46" HOLDER		01
03	0503010027	SPRING WASHER		01
04	0503010013	5/8" NUT		01
05	0502011052	FERTILIZER ARM ROW		01
06	0511010736	5/8" X 5-1/4" BOLT		01
07	0503010811	5/8" UNF SELF ADJUSTING NUT		01
08	0503010002	1800 GREASE FITTING		01
09	0502010470	WEDGE ROW FERTILIZER		01
10	0501011536	1/2" X 2-3/4" BOLT		03
11	0503010019	1/2" SPRING WASHER		03
12	0503010020	1/2"NUT		02
13	0501044082	LH 30204 UNAL DOUBLE-DISC ASSY		01
13A	0502010927	RH SEED UNAL DOUB-DISC SUPP FERT		01
13B	0502011930	DOUBLE DISC COULTER BOX		02
13C	0503010598	30204 BALL BEARING		04
13D	0503011112	SEAL 02376-BRG		02
13E	0521019154	RIGHT DOUB DISC HUB		01
13F	0503030282	3/4" CASTLE NUT		01
13G	0503010257	1/8" X 1" COTTERPIN		02
13H	0603022042	13" X 0.12" PLAIN COULTER BLADE		02
13I	0503010546	5/16" X 7/8" BOLT		12
13J	0503010337	5/16" NUT		12
13K	0511015098	FLAT WASHER		02
13L	0511011927	DUST CLOAK		02
13M	0503030757	2.9" X 2" X 0.02" JOINT		02
13N	0521019178	COVER DEPTH		02
13O	0503010298	1/4" X 1/2" BOLT		06
13P	0503011441	SPRING WASHER		06




DDD FERTILIZER ROW ASSY

0909091405

Item	Code	Description	See page	QT
13Q	0501017541	RH DOUBLE DISC SCRAPER		01
13R	0501017542	LH DOUBLE DISC SCRAPER		01
13S	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13T	0501010984	FLAT WASHER		02
13U	0503011443	SPRING WASHER		01
13V	0503010026	3/8" NUT		01
14	0501044083	LH 30204 UNAL DOUBLE-DISC ASSY		01
14A	0502010928	LH SEED UNAL DOUB-DISC SUPP FERT		01
14B	0521019148	LEFT DOUBLE DISC HUB		01
15	0501065339	FERTILIZER SPRING GUIDE		01
16	0521010542	COUPLING SHAFT		01
17	0503010257	1/8" X 1" COTTERPIN		01
18	0502040534	SPRING GUIDE BUSHING LOCK		02
19	0503010834	1/2 X 1 BOLT		02
20	0503030609	1"X11.81"X 0.16" COMPRESSION SPRING		01
21	0503030917	1.6"X11.8"X 0.2" COMPRESSION SPRING		01
22	0503030918	58,5MM/300MM/8MM COMPRESSION SPRING		01
23	0502011053	SPRING ROD GUIDE SUPPORT		01
24	0502010358	ROW FIXER CLAMP		01
25	0503010547	1/2" X 4" BOLT		01
26	0503030168	HAIR PIN		01
27	0503030408	10 X 2 X 390 HOSE		01
28	0503031076	2" HOSE CLAMP		01
29	0503030483	FERTILIZER SOCKET		01
30	0502011170	FIXER		01

FERTILIZER ROW ASSY




Item	Code	Description	See page	QT
00	0501047027	RIGHT ROW FERTILIZER DOUBLE DISC		01
00.	0501047028	LH DOUB-DISC FERTILIZER ROW ASSY		01
01	0502010892	FERTILIZER ROW SUPPORT		01
02	0521010669	5/8" X 4.33" X 3.46" HOLDER		01
03	0503010027	SPRING WASHER		02
04	0503010013	5/8" NUT		02
05	0502011052	FERTILIZER ARM ROW		01
06	0511010736	5/8" X 5-1/4" BOLT		01
07	0503010811	5/8" UNF SELF ADJUSTING NUT		01
08	0503010002	1800 GREASE FITTING		03
09	0502010470	WEDGE ROW FERTILIZER		01
10	0501011536	1/2" X 2-3/4" BOLT		02
11	0503010019	1/2" SPRING WASHER		03
12	0503010020	1/2"NUT		03
13	0501050440	FERTILIZER DOUBLE DISC		01
13A	0502010733	HUB DISC DOUBLE		02
13B	0503010276	6206 BALL BEARING		02
13C	0511010044	DISC DOUBLE HUB AXLE		02
13D	0503010526	3011 SEAL RING		02
13E	0503010525	00797-BA SEAL		02
13F	0603022008	D272 TATU PLAIN COULTER BLADE		02
13G	0503010814	5/16" X 3/4" BOLT		12
13H	0503010337	5/16" NUT		12
13I	0503010179	SPRING WASHER		12
13J	0502010434	DOUBLE BLADE DISC SUPPORT		01
13K	0511017958	5/8" X 1.9" RIGHT BOLT		01
13L	0511017959	5/8" X 1.9" LEFT BOLT		01
13M	0503030593	FENCE JOINT		02
13N	0502020599	COVER		02
13O	0503010282	1/4" X 3/4" BOLT		06
13P	0503010143	SPRING WASHER		06



FERTILIZER ROW ASSY

0909091403

Item	Code	Description	See page	QT
13Q	0501017541	RH DOUBLE DISC SCRAPER		01
13R	0501017542	LH DOUBLE DISC SCRAPER		01
13S	0503010256	3/8" X 3/4" BOLT		01
13T	0501010984	FLAT WASHER		02
13U	0503010025	3/8 SPRING WASHER		01
13V	0503010026	3/8" NUT		01
13X	0503030432	FERTILIZER SOCKET		01
14	0501065339	FERTILIZER SPRING GUIDE		01
15	0521010542	COUPLING SHAFT		01
16	0503010257	1/8" X 1" COTTERPIN		01
17	0502040534	SPRING GUIDE BUSHING LOCK		02
18	0501018535	1/2 X 1 BOLT		02
19	0503030609	1"X11.81"X 0.16" COMPRESSION SPRING		01
20	0502011053	SPRING ROD GUIDE SUPPORT		01
21	0502010358	ROW FIXER CLAMP		01
22	0503010547	1/2" X 4" BOLT		01
23	0503030168	HAIR PIN		01
24	0503030408	10 X 2 X 390 HOSE		01
25	0503031076	2" HOSE CLAMP		01
26	0502011170	FIXER		01




Item	Code	Description	See page	QT
00	0511041090	PNEUMATIC SEED DISTRIBUTOR	16	01
01	0502050029	MINOR SIDE		01
02	0503010427	METRIC M8 X P.0.5" NUT		01
03	0503011295	M 8 X 1,25 X 25 BOLT		01
04	0503011770	SEAL # V-75 A		01
05	0501067722	26Z GEAR WITH BUSHING		01
06	0503011771	6008 2RS BALL BEARING		01
07	0503011772	DIN 471 O'RING		01
08	0502050028	DISC SUPPORT		01
09	0503010143	SPRING WASHER		06
10	0503011378	M6 X 1" BOLT		09
11	0503011809	M12 KNOB		01
12	0503011769	M8 X 0.5" BOLT		01
13	0511017229	1.6" X 2.5" X 0.7" BUSHING		01
14	0511017210	PNEUMATIC SWITCH SUPPORT		01
15	0503031060	PNEUMATIC SWITCH		01
16	0501110311	LOWER SELECTOR ASSY		01
17	0503011813	M6 X 1.2" BOLT		01
18	0503011820	CRINKLE WASHER		02
19	0503011823	0.1" X 0.6" SPRING PIN		02
20	0502020559	UPPER SELECTOR ACTUATOR		01
21	0531014481	0.2" X 0.6" AXLE		01
22	0503011817	UPPER SELECTOR		01
23	0503011821	CRINKLE WASHER		04
24	0503011776	M6 SELF ADJUSTINGNUT		01
25	0511017303	FLAT WASHER		04
26	0503011812	M6 X 1" BOLT		01
27	0511017186	SEED LEVEL REGULATOR		01
28	0503011808	LARGER SIDE		01
29	0511016220	LOWER SELECTOR INDICATOR		01
30	0503011815	TOOTHED WASHER		01




PNEUMATIC SEED DISTRIBUTOR

0511041090


Item	Code	Description	See page	QT
31	0503012445	M6 C/ABA 1.20" BUTTERFLY NUT		04
32	0501067818	SCALE INDICATOR WITH PIN		01
33	0511017219	SCALE INDICATOR GUIDE		01
34	0503011810	M6 X 1" BUTTERFLY BOLT		01
35	0503031058	UPPER SELECTOR SCALE		01
36	0503011840	FLAT WASHER		02
37	0503011825	M4 X 8" BOLT		02
38	0503011828	FLAT WASHER		01
39	0503011827	504.100 CLAMPING RING (FOR HOLE)		01
40	0503012970	PNEUMATIC SEED DISTRIBUTOR VISOR		01
41	0503013020	SEED DRAINER COVER		01
42	0503031660	SEED DISTRIBUTOR RUBBER BACKING		01
43	0511015627	SEED DISC LEVER		01
44	0503011511	DISC 3245 OF THE SMALL CORN		01
44A	0503011512	DISC 3255 LARGE CORN		01
44B	0503011454	DISC 6445 LARGE SOYBEAN		01
44C	0503011455	DISC 6450 LARGE SOYBEAN		01
44D	0503011513	DISC 6430 SMALL SOYBEAN/COTTON		01
44E	0503011437	DISC 6420 SORGHUM		01
44F	0503011456	DISC 4820 SORGHUM		01
44G	0503011391	DISC 3230 SUNFLOWER		01
44H	0503011436	DISC 4845 MIDDLE BEAN		01
44I	0503011392	DISC 4855 GREAT BEAN		01
44J	0503011717	DISC 4835 DELINTED COTTON / BEAN		01
44K	0503012574	DISC 6460 PEANUT P18 A 26		01
44L	0503011889	DISC 7512 TOMATO		01
44M	0503012576	DISC 3660 CORN		01
44N	0503012577	DISC 3650 MIDDLE CORN		01
44O	0503012578	DISC 3645 CORN		01
44P	0503012579	DISC 3630 SUNFLOWER		01
44Q	0503012580	DISC 8440 MIDDLE SOYBEAN		01
44R	0503012581	DISC 8045 LARGE SOYBEAN		01
44S	0503012582	DISC 18016 RICE		01
44T	0503012860	DISC 3240 POPCORN		01
44U	0503012728	DISC WITHOUT HOLE		01




Item	Code	Description	See page	QT
001	0501067171	LH SEED BOX SIDE SUPPORT ASSY		01
002	0531010765	DEPTH WHEEL AXLE		01
003	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
004	0521015818	FLAT WASHER		06
005	0501050915	RIGHT DEPTH CONTROL WHEEL ASSY	20	01
006	0501050916	LEFT DEPTH CONTROL WHEEL ASSY	19	01
007	0511017302	FLAT WASHER		02
008	0503010019	1/2" SPRING WASHER		02
009	0503010311	1/2" X 1-1/4" BOLT		02
010	0503010002	1800 GREASE FITTING		02
011	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
012	0501050717	SEED ROW DEPTH WHEEL REGULATOR	18	01
013	0521010775	0.3" X 1.6" COUPLING SHAFT		01
014	0503010140	1/8" X 3/4" COTTERPIN		01
015	0511014702	REGULATOR PLATE		01
016	0501010984	FLAT WASHER		01
017	0503010256	3/8" X 3/4" BOLT		02




Item	Code	Description	See page	QT
001	0501066920	CONCAVE PRESS WHEEL REGULACION		01
002	0501067709	DEPTH WHEEL SMALLER BEATER		01
003	0511015976	FLAT WASHER		01
004	0503010257	1/8" X 1" COTTERPIN		01
005	0511015926	PIN FIXER		01
006	0503010257	1/8" X 1" COTTERPIN		01
007	0511014894	HANDLE AXLE		01
008	0503030975	0.9" X 1.5" X 0.1" SPRING		01
009	0511015976	FLAT WASHER		01
010	0503010584	1/4" X 1" COTTERPIN		01
011	0502020558	DEPTH CONTROL HANDLE		01
012	0511014702	REGULATOR PLATE		01




Item	Code	Description	See page	
00	0501050916	LEFT DEPTH CONTROL WHEEL ASSY	19	01
01	0501052538	DEPTH CONTROL WHEEL RUBBER BAND	24	01
02	0501052565	LEFT ARM DEPTH CONTROL WHEEL	23	01
03	0503010178	5/16" X 7/8" BOLT		04
04	0503010179	SPRING WASHER		04
05	0503010337	5/16" NUT		04



Item	Code	Description	See page	
00	0501050915	RIGHT DEPTH CONTROL WHEEL ASSY	20	01
01	0501052538	DEPTH CONTROL WHEEL RUBBER BAND	24	01
02	0501052564	RIGHT ARM DEPTH CONTROL WHEEL	22	01
03	0503010178	5/16" X 7/8" BOLT		04
04	0503010179	SPRING WASHER		04
05	0503010337	5/16" NUT		04
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	COVER DEPTH		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
00	0501052564	RIGHT ARM DEPTH CONTROL WHEEL	22	01
01	0502011699	RIGHT DEPTH WHEEL ARM		01
02	0501052627	ASSY DEPTH WHEEL BOX	21	01
03	0503010740	1/2" X 2" BOLT		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01


LEFT ARM DEPTH CONTROL WHEEL




Item	Code	Description	See page
00	0501052565	LEFT ARM DEPTH CONTROL WHEEL	23 01
01	0502011698	LEFT DEPTH WHEEL ARM	01
02	0501052627	ASSY DEPTH WHEEL BOX	21 01
03	0503010740	1/2" X 2" BOLT	01
04	0503011440	SPRING WASHER	01
05	0503010060	1/2" NUT	01
06	0503010002	1800 GREASE FITTING	01



Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0502011275	DOBLE DISC BOX		02
02	0503010598	30204 BALL BEARING		04
03	0521017655	LEFT DDD HUB AXLE		01
04	0521017654	RIGHT DDD HUB AXLE		01
05	0503011112	SEAL 02376-BRG		02
06	0511015098	FLAT WASHER		04
07	0511011927	DUST CLOAK		02
08	0503030282	3/4" CASTLE NUT		02
09	0503010257	1/8" X 1" COTTERPIN		02
10	0521019178	COVER DEPTH		02
11	0503013815	1/4" X 5/8" BOLT		06
12	0503010143	SPRING WASHER		06
13	0603020019	D272 PLAIN COULTER BLADE		01
14	0603022008	D272 TATU PLAIN COULTER BLADE		01
15	0501067991	RIGHT DOUBLE DISC SUPPORT		01
16	0503010546	5/16" X 7/8" BOLT		12
17	0503010179	SPRING WASHER		12
18	0503010337	5/16" NUT		12
19	0503010002	1800 GREASE FITTING		01
20	0501017541	RH DOUBLE DISC SCRAPER		01
21	0501017542	LH DOUBLE DISC SCRAPER		01
22	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
23	0501010984	FLAT WASHER		02
24	0503010025	3/8 SPRING WASHER		01
25	0503010026	3/8" NUT		01
26	0503030150	BEND SOCKET		01



Item	Code	Description	See page	QT
001	0502011275	DOBLE DISC BOX		02
002	0503010598	30204 BALL BEARING		04
003	0521017655	LEFT DDD HUB AXLE		01
004	0521017654	RIGHT DDD HUB AXLE		01
005	0503011112	SEAL 02376-BRG		02
006	0511015098	FLAT WASHER		02
007	0511011927	DUST CLOAK		02
008	0503030282	3/4" CASTLE NUT		02
009	0503010257	1/8" X 1" COTTERPIN		02
010	0521019178	COVER DEPTH		02
011	0503013815	1/4" X 5/8" BOLT		06
012	0503010143	SPRING WASHER		06
013	0603020019	D272 PLAIN COULTER BLADE		01
014	0603022008	D272 TATU PLAIN COULTER BLADE		01
015	0501067992	SUPT DDD 15 X 15 ESQ		01
016	0503010546	5/16" X 7/8" BOLT		12
017	0503010179	SPRING WASHER		12
018	0503010337	5/16" NUT		12
019	0503010002	1800 GREASE FITTING		01
020	0501017542	LH DOUBLE DISC SCRAPER		01
021	0501017541	RH DOUBLE DISC SCRAPER		01
022	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
023	0501010984	FLAT WASHER		02
024	0503010025	3/8 SPRING WASHER		01
025	0503010026	3/8" NUT		01
026	0503030150	BEND SOCKET		01

CARDAN TURBINE





Item	Code	Description	See page	QT
00	0511040705	TURBINE ASSY FOR CARDAN		
00A	0511042082	TURBINE ASSY FOR CARDAN		
01	0511061094	TURBINE SUPPORT		01
02	0501053716	BEARING ASSY OF THE LARGER FAN		01
02A	0502012016	CHAIN TENSIONER SUPPOT		01
02B	0503012778	MIDDLE LARGER AXLE		01
02C	0531010881	INTERMEDIARY UPPER SLEEVE		01
02D	0503012689	6306 DDU BEARING		02
02E	0503010325	VCA-118 VALVE		01
02F	3402510052	GRAXA SHELL STAMINA/RL-2		00
02G	3914303202	COLA		00
03	0503010920	1/2" X 1.1/2" BOLT		02
04	0511017302	FLAT WASHER		02
05	0503010395	1/2" X 1-1/4" BOLT		02
06	0503011336	1/2" HEX SELF ADJUSTING NUT		04
07	0501054759	PULLEY ASSY		01
07A	0502012020	PULLEY HOUSING BEARING		01
07B	0501053888	TURBINE PULLEY ASSY		01
07C	0503011081	6207 2RS BEARING		02
07D	0531014518	INTERMEDIARY LOWER BUSHING BEARING		01
07E	0531014519	FLAT WASHER		01
07F	0531015571	CARDAN SLEEVE HITCH		01
07G	0503010301	0.3" X 1.8" SPRING PIN		01
07H	0503011855	0.2" X 1.8" SPRING PIN		01
07I	0503010325	VCA-118 VALVE		01
07J	3402510052	GRAXA SHELL STAMINA/RL-2		00
07K	3914303202	COLA		00
08	0501010711	1/2" X 1-5/8" BOLT		04
09	0521018517	FLAT WASHER		04
10	0503010019	1/2" SPRING WASHER		04
11	0503010020	1/2"NUT		04



CARDAN TURBINE

0511040018

Item	Code	Description	See page	QT
12	0503013030	5/8" X 3.1/4" BOLT		01
13	0501012140	FLAT WASHER		01
14	0503010013	5/8" NUT		01
15	0503012780	LARGER TURBINE BELT		01
16	0531017194	FRONT COVER		01
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
18	0503010025	3/8 SPRING WASHER		04
19	0503010026	3/8" NUT		04
20	0511040440	17.3" MIDDLE FAN		01
21	0503011775	6 X 6 X 35 KEYWAY		01
22	0503011774	PULLEY		01
23	0503010179	SPRING WASHER		01
24	0503011257	M 8 X 1,25 X 30 BOLT		01
25	0503011807	M 8 X 1,25 X 10 BOLT		01
26	0501054272	RIBBON FOR COVER CLOSING ASSY		01
27	0503031776	TURBINE RIBBON SEAL		02
28	0531017195	REAR COVER		01
29	0521018267	LARGER TURBINE FRONTAL COVER CENTER		01
30	0503013031	1/4" X 3.1/4" BOLT		15
31	0521011316	0.4" X 0.5" X 0.6" SLEEVE		02
32	0503012721	1/4" X 4" BOLT		02
33	0511017303	FLAT WASHER		34
34	0503012880	1/4" UNC SELF ADJUSTING NUT		17
35	0531010771	WASHER GUIDE		01
36	0531010757	TURBINE FAN		01
37	0531010770	FLAT WASHER		01
38	0503010179	SPRING WASHER		03
39	0503011429	M 8 X 1,25 X 40 BOLT		01
40	0531012760	TURBINE REAR COVER		01
41	0503010298	1/4" X 1/2" BOLT		04
42	0511017303	FLAT WASHER		04
43	0503031812	TURBINE OUTPUT SOCKET		01
44	0503013096	5/16" X 4" BOLT		02
45	0501010694	FLAT WASHER		04
46	0503010499	5/16" UNC BUTTERFLY NUT		02



Item	Code	Description	See page	QT
01	0503030360			04
02	0503030362			02
03	0503030411			02
04	0503030310	ADHESIVE		01



MARCHESAN IMPLEMENTOS E MÁQUINAS AGRÍCOLAS TATU S.A.

AV. Marchesan, 1979 - Post office box, 131 - CEP 15994-900 - Matão - SP - Brazil

Phone +55 16.3382-8282

(FAX Parts) + 55 16.3382. 8297 - (Export) + 55 16.3382.1003

e.mail: tatu@marchesan.com.br www.marchesan.com.br

Technical Publications: Elaboration

LUIZ CANDIDO

Contact Catálogo:

E-mail = jgaspari@marchesan.com.br

Technical Publications: Revision

LUIZ CANDIDO

**ORIGINAL PARTS
TATU**

