

PARTS CATALOG

SEEDERS

TATU INTEGRAL DRILL

Code: 0501092402



Series: S-1218

Rev.: 00

Date Rev.: JANEIRO/2019

ORIGINAL PARTS
TATU



PRODUCTS


Code	Description
0112030036	1275 TATU INTEGRAL DRILL 17 LINHAS S-1218

ATTENTION: **IMPORTANT**


MARCHESAN S/A RESERVES THE RIGHT AT ANY TIME TO MAKE IMPROVEMENTS IN THE DESIGN, MATERIAL OR SPECIFICATIONS OF MACHINERY, EQUIPMENT OR PARTS WITHOUT THEREBY BECOMING LIABLE TO MAKE SIMILAR CHANGES IN MACHINERY, EQUIPMENT OR PARTS PREVIOUSLY SOLD.

INDEX


0909095050	FRAME ASSY	1
0909095051	ASSY FRAME	2
0909095049	DRAWBAR ASSY	3
0521054909	DRAWBAR	4
0521054936	TURNBUCKLE	5
0909095052	WHEELS LEFT TRANSMISSION	6
0521054918	LH CARRYING-WHEELS ASSY	7
0521054934	TENSIONER ASSY	8
0521054935	BEARING DOUBLE	9
0521054933	TENSIONER	10
0501051381	FINE SEED CHAIN TENSIONER ASSY	11
0511050684	LH TRANSMISSION DRIVING	12
0521054929	LEFT WHEEL	13
0521054921	CARRYING WHEEL HUB	14
0501110832	HUB CARRYING WHEELS WITH BOLT	15
0521054919	HIDRAULIC CYLINDER	16
0521054917	WHEELS RIGHT	17
0521054920	WHEELS RIGHT	18
0501051142	CARRYING WHEEL HUB	19
0521054945	SEED BOX	20
0521054916	FINE SEED BOX ASSY	21
0503032990	SEED DISTRIBUTOR BOX	22
0501051927	COVER PIVOT SHAFT ASSY	23
0521054908	SEED BOX BEARING ASSY	24
0503060150	FINE SEED DISTRIBUTOR	25
0909095056	LONG ROW	26
0909095057	ROW SHORT FRAME	27
0521054943	LONG ROW	28
0521054944	SHORT ROW	29
0521054939	SEED UNALIGNED DOUBLE-DISC	30
0521054938	LH HUB LOWR Y/DISC	31
0521054940	RIGHT HUB LOWR Y/DISC	32
0521054941	PRESS WHEELS	33
0501054326	COMPACTOR CONCAVA WEEL	34
0521054942	SPRING ROD	35
0909095061	REGULATOR ASSY	36
0909095062	ENSEMBLE BRAS	37
0909095063	ENSEMBLE BRAS	38
0909095058	ELECTRONIC BLADE HECTARE	39
0503060718	ELECTRONIC BLADE HECTARE	40
0909095059	HYDRAULIC ASSEMBLY	41
0501053834	MALE QUICK COUPLING AGRICULTURAL WITH COVER - 1/2 NPT	42




Item	Code	Description	QT
01	0909095051	ASSY FRAME	01
02	0909095049	DRAWBAR ASSY	01
03	0909095052	WHEELS LEFT TRANSMISSION	01
04	0909095055	WHEEL ASSY RIGHT	01
05	0521054945	SEED BOX	01
06	0521054916	FINE SEED BOX ASSY	01
07	0909095056	LONG ROW	09
08	0909095057	ROW SHORT FRAME	08
09	0521069543	CHAIN PROTECTION CAP	01
10	0909095058	ELECTRONIC BLADE HECTARE	01
11	0581010158	COVER FIXER L	03
12	0503010386	CABLE	03
13	0503010025	3/8 SPRING WASHER	03
14	0503010026	3/8" NUT	03
15	0909095059	HYDRAULIC ASSEMBLY	01
16	0501069315	FINE SEED RIGHT CHAIN COVER	01
17	0503010179	SPRING WASHER	02
18	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT	02




Item	Code	Description	QT
01	0521069503	FRAME	01
02	0521069539	LEFT REAR PLATFORM	01
03	0521069540	RIGHT REAR PLATFORM	01
04	0501010942	3/8" X 1-1/4" BOLT	08
05	0503017813	3/8" X 2" BOLT	03
06	0503010920	1/2" X 1.1/2" BOLT	04
07	0503010025	3/8 SPRING WASHER	11
08	0503010026	3/8" NUT	11
09	0503010019	1/2" SPRING WASHER	04
10	0503010060	1/2" NUT	04
11	0521069555	SIDE LADDER	02
12	0909095060	SUPPORT BOX	02
13	0501010942	3/8" X 1-1/4" BOLT	04
14	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	02
15	0501010984	FLAT WASHER	12
16	0503010025	3/8 SPRING WASHER	08
17	0503010026	3/8" NUT	08
18	0521069542	PLOUGH SUPPORT	02
19	0521010549	COUPLING SHAFT	02
20	0503030168	HAIR PIN	02
21	0541015542	1.1/8" HITCH AXLE	02
22	0541018684	FLAT WASHER	02
23	0511017480	FLAT WASHER	02
24	0503030430	7/16 X 2" PIN LOCK	04
25	0502010477	UPPER CLIP	03
26	0503010180	7/16" SPRING WASHER	03
27	0503011102	PARAFUSO 7/16 UNC X 1.1/4 C S G.5	03




Item	Code	Description	QT
01	0521054909	DRAWBAR	01
02	0501013658	HOSE HOLDER	01
03	0503010014	3/4" NUT	02
04	0501068989	COUPLING SHAFT	01
05	0503031035	HAIR PIN	01
06	0503013150	1300 X 3/8 CHAIN	01
07	0521054936	TURNBUCKLE	01
08	0511014394	1.25" X 4.13" COUPLING SHAFT	01
09	0503010023	SPRING WASHER	01
10	0503030085	LOCK PIN	01




Item	Code	Description	QT
001	0521069546	DRAWBAR	01
002	0501064967	TRACTOR HITCH	01
003	0521016397	1.55" X 2.16" X 1.10" SLEEVE	01
004	0521016396	0.55" X 2.36" COUPLING SHAFT	01
005	0503010071	3/16" X 1" COTTERPIN	01
006	0503010002	1800 GREASE FITTING	01
007	0521012532	0.9" X 3.9" COUPLING SHAFT	01
008	0503030085	LOCK PIN	01



Item	Code	Description	QT
001	0521064756	ADJUSTING NUT	01
002	0501064974	LOCKNUT WITH HANDLER	01
003	0521069548	LH TURNBUCKLE	01
004	0521069547	LH TURNBUCKLE	01
005	0503010002	1800 GREASE FITTING	02



Item	Code	Description	QT
01	0521054918	LH CARRYING-WHEELS ASSY	01
02	0581019440	LOCKS TRANSPORT	01
03	0521010175	SPACER	01
04	0503017857	BOLT 5/8 UNF 4	04
05	0501012140	FLAT WASHER	04
06	0503012795	5/8" HEX SELF ADJUSTING NUT	04
07	0503014087	50-1 X CHAIN	01
08	0521054934	TENSIONER ASSY	01
09	0521054935	BEARING DOUBLE	01
10	0521054933	TENSIONER	01
11	0503012463	50-1 X CHAIN	01
12	0501068515	30Z GEAR	01
13	0501051381	FINE SEED CHAIN TENSIONER ASSY	01
14	0503013215	40-1 CHAIN X 89 LINK + MENDING	01
15	0581019328	WHEEL TOOTH 30 Z	01
16	0501017574	0.3" X 2.7" AXLE	01
17	0521069531	LH CARRYING-WHEELS SUPPORT	01
18	0581019329	30Z P1/2" GEAR	01
19	0521069506	28Z GEAR REEL	01




Item	Code	Description	QT
001	0521069534	FORK LEFT WHEEL	01
002	0511050684	LH TRANSMISSION DRIVING	01
003	0521054929	LEFT WHEEL	01
004	0521054919	HIDRAULIC CYLINDER	01
005	0521069538	FIXER FLANGE	02
006	0501110932	WHEEL PIVOT BEARING	02
007	0561013022	BEARING EXTERNAL LOCK	02
008	0561013021	BEARING INNER LOK	02
009	0561013020	KM 12 NUT	02
010	0503010398	501082 CLAMPING RING (FOR AXLE)	02
011	0581019363	REGULATOR LEVER	01
012	0503010969	2050 CHAIN X 50 LINK + REDUCTION	01
013	0511011887	COUPLING SHAFT	01
014	0503010019	1/2" SPRING WASHER	12
015	0503010003	1845 GREASE FITTING	04
016	0501019435	FLAT WASHER	01
017	0503010523	1/4" X 2" COTTERPIN	01
018	0581019343	DRIVER AXLE	01
019	0521069580	WHEEL TOOTH	01
020	0503010237	3/8" X 1" BOLT	01
021	0503010026	3/8" NUT	02
022	0503010060	1/2" NUT	02
023	0503030678	1/2"X1-1/2"BOLT	02
024	0503010834	1/2 X 1 BOLT	04
025	0503060094	WHEEL AND TIRE ASSY	01
026	0503010311	1/2" X 1-1/4" BOLT	08
027	0501013518	FLAT WASHER	04
028	0521010773	0.37" X 1.18" COUPLING SHAFT	01
029	0503010140	1/8" X 3/4" COTTERPIN	01
030	0503010025	3/8 SPRING WASHER	01
031	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01




TATU INTEGRAL DRILL
LH CARRYING-WHEELS ASSY

Page 7
0521054918


Item	Code	Description	QT
032	0521054932	CHAIN TENSIONER	01




Item	Code	Description	QT
001	0581019372	TIGHTENER AXLE	01
002	0503031806	9Z X P 5/8" GEAR	01
003	0503010302	501019 SEAL RING	01
004	0503010060	1/2" NUT	01
005	0503011828	FLAT WASHER	01




Item	Code	Description	QT
001	0502011300	BUSHING GEAR	02
002	0521055050	BEARING DOBLE	02
003	0581019373	SQUARE SHAFT	01
004	0521069541	WHEEL TOOTH	02
005	0503012231	1/4" X 3" COTTERPIN	02
006	0501010984	FLAT WASHER	02
007	0503010025	3/8 SPRING WASHER	02
008	0503010026	3/8" NUT	02
009	0503017813	3/8" X 2" BOLT	02
010	0581019370	BUSHING	01




Item	Code	Description	QT
001	0581019371	TIGHTENER AXLE	01
002	0503031806	9Z X P 5/8" GEAR	01
003	0503010302	501019 SEAL RING	01
004	0503011828	FLAT WASHER	01
005	0503010060	1/2" NUT	01
006	0503010019	1/2" SPRING WASHER	01




Item	Code	Description	QT
001	0511010919	CHAIN TIGHTENER AXLE	01
002	0503031805	11Z 1/2" GEAR	01
003	0503010302	501019 SEAL RING	01
004	0501010984	FLAT WASHER	01
005	0503010025	3/8 SPRING WASHER	01
006	0503010026	3/8" NUT	01
007	0503010004	1890 GREASE FITTING	01




Item	Code	Description	QT
01	0502011995	LH DRIVING AXLE FOLLOWER	01
02	0502011996	SLLEVE FIXER	01
03	0503010395	1/2" X 1-1/4" BOLT	01
04	0503010060	1/2" NUT	01
05	0521017590	GUIDE AXLE	01
06	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING	01
07	0501019734	FLAT WASHER	02
08	0502010710	RIGHT CAM, SMALLER	01
09	0502010711	RIGHT CAM,LARGER	01
10	0502011331	LH 14Z P 1.25" GEAR WITH DRAGGER	01
11	0501019735	FLAT WASHER	01
12	0521017593	FLAT WASHER	01
13	0503010542	501045 CLAMPING RING (FOR AXLE)	01
14	0503010003	1845 GREASE FITTING	02




Item	Code	Description	QT
001	0502020591	PROTECCION COVER	01
002	0501016545	FLAT WASHER	01
003	0503030009	1" CASTLE NUT	01
004	0503010018	5/32 X 1-1/2 COTTERPIN	01
005	0503010002	1800 GREASE FITTING	01
006	0503011444	SPRING WASHER	04
007	0503010358	5/16" X 5/8" BOLT	04
008	0581019339	SPINDLE	01
009	0521054921	CARRYING WHEEL HUB	01




Item	Code	Description	QT
001	0501110832	HUB CARRYING WHEELS WITH BOLT	01
002	0503010006	32210 ROLLER BEARING	01
003	0503010037	30207 ROLLER BEARING	01
004	0503012928	SEAL	01
005	0503010371	5/16" X 1" BOLT	06
006	0503011444	SPRING WASHER	06
007	0521069536	FLANGE 14Z	01




Item	Code	Description	QT
001	0502011065	HUB	01
002	0501010127	9/16" X 1-7/8" LUG BOLT	06
003	0503013001	9/16" CONICAL NUT	06




Item	Code	Description	QT
001	0581010668	RING SUPPORT	01
002	0502010471	MOBILE COVER	01
003	0502012837	PISTON	01
004	0521069535	63,50 X 227 CASE	01
005	0521069537	1.5" TURNBUCLE	01
006	0503018005	RING	01
007	0503011109	2-119 N 3006-9B O'RING	01
008	0503018163	BACK-UP RING	02
009	0503018162	O'RING	02
010	0503010163	D-1500 SCRAPER RING	01
011	0503018004	RING	01
012	0503018003	GASKET	01
013	0503010002	1800 GREASE FITTING	01
014	0503030385	CYLINDER PLUG N-002	02




Item	Code	Description	QT
001	0521069533	FORK RIGHT WHEEL	01
002	0521054920	WHEELS RIGHT	01
003	0521054919	HIDRAULIC CYLINDER	01
004	0521069538	FIXER FLANGE	02
005	0501110932	WHEEL PIVOT BEARING	02
006	0561013022	BEARING EXTERNAL LOCK	02
007	0561013021	BEARING INNER LOK	02
008	0561013020	KM 12 NUT	02
009	0503010398	501082 CLAMPING RING (FOR AXLE)	02
010	0503060094	WHEEL AND TIRE ASSY	01
011	0503010019	1/2" SPRING WASHER	12
012	0503010003	1845 GREASE FITTING	02
013	0501019435	FLAT WASHER	01
014	0511011887	COUPLING SHAFT	01
015	0503010523	1/4" X 2" COTTERPIN	01
016	0503010060	1/2" NUT	02
017	0503030678	1/2"X1-1/2"BOLT	02
018	0503010834	1/2 X 1 BOLT	04
019	0503010311	1/2" X 1-1/4" BOLT	08



Item	Code	Description	QT
001	0502020591	PROTECCION COVER	01
002	0501051142	CARRYING WHEEL HUB	01
003	0501016545	FLAT WASHER	01
004	0503030009	1" CASTLE NUT	01
005	0503010018	5/32 X 1-1/2 COTTERPIN	01
006	0503010002	1800 GREASE FITTING	01
007	0503011444	SPRING WASHER	04
008	0503010358	5/16" X 5/8" BOLT	04
009	0581019339	SPINDLE	01




Item	Code	Description	QT
01	0501110728	WHEEL HUB	01
01A	0502011121	CARRYING WHEEL HUB	01
01B	0501010127	9/16" X 1-7/8" LUG BOLT	06
01C	0503010035	9/16" CONIC NUT	06
02	0503010037	30207 ROLLER BEARING	01
03	0503010006	32210 ROLLER BEARING	01
04	0503012928	SEAL	01



Item	Code	Description	QT
001	0503032990	SEED DISTRIBUTOR BOX	17
002	0503011953	5/16" X 1" BOLT	68
003	0503010337	5/16" NUT	82
004	0501010694	FLAT WASHER	78
005	0571017642	LATCH GLOVE BOX	34
006	0503017021	M8 X 0.5" BOLT	35
007	0503010179	SPRING WASHER	82
008	0551019597	SEED REGULACION HANDLE	01
009	0541015305	HANDLE SPINDLE	01
010	0503012882	BALL BEARING	02
011	0502012325	SEED REG BEARING	01
012	0503011945	503050 CLAMPING RING (FOR AXLE)	01
013	0503012104	501015 CLAMPING RING (FOR AXLE)	01
014	0503011907	PMC 594-S NYLON LUG	02
015	0503010363	5/16" X 1" BOLT	04
016	0521011116	COVER PIVOT BUSHING	04
017	0501051927	COVER PIVOT SHAFT ASSY	04
018	0503010421	5/16" X 1-1/2" BOLT	04
019	0501010984	FLAT WASHER	16
020	0503010025	3/8 SPRING WASHER	13
021	0503010026	3/8" NUT	13
022	0571017641	LARGER DOSER	01
023	0503030886	SCALE DOSER	01
024	0503010001	RIVET POP	02
025	0521069544	SEED BOX	01
026	0521069545	SEED BOX COVER	02
027	0521054908	SEED BOX BEARING ASSY	01
028	0581019325	SQUARE AXLE	01
029	0521069529	MIXER ASSY	01
030	0521069526	FIXATEUR COP CL	01
031	0501068515	30Z GEAR	01



Item	Code	Description	QT
032	0501068514	SIDE MIXER BEARING	02
033	0503030408	10 X 2 X 390 HOSE	17
034	0503010246	CLAMP	34
035	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	06
036	0581019326	SEMILLA SCALE SUPPORT	01
037	0503010571	1/4" X 1.1/2 COTTERPIN	02
038	0503010002	1800 GREASE FITTING	02
039	0503010358	5/16" X 5/8" BOLT	06
040	0501013518	FLAT WASHER	03
041	0503010237	3/8" X 1" BOLT	03
042	0503031035	HAIR PIN	01
043	0503012215	5/16" X 2-1/2" COTTERPIN	01
044	0511015346	FLAT WASHER	01
045	0503010691	1/4" GREASE FITTING	01




Item	Code	Description	QT
001	0503060150	FINE SEED DISTRIBUTOR	17
002	0571018305		34
003	0503015779	ALLEN BOLT	34
004	0503010519	1/4" X 5/8" BOLT	68
005	0503010143	SPRING WASHER	68
006	0503010144	1/4" NUT	70
007	0511017303	FLAT WASHER	68
008	0502010901	FINE SEED BOX AGRICULTURAL BEARING	01
009	0502011081	3/8" Q AXLE PULLER SLEEVE	01
010	0503011335	502024 CLAMPING RING (FOR AXLE)	01
011	0503010838	0.1" X 0.8" SPRING PIN	02
012	0503010002	1800 GREASE FITTING	01
013	0503010406	501025 CLAMPING RING (FOR AXLE)	01
014	0503010237	3/8" X 1" BOLT	02
015	0503010025	3/8 SPRING WASHER	06
016	0503010026	3/8" NUT	06
017	0521010223	BOX COVER BUSHING	04
018	0503010365	NUT	04
019	0503010179	SPRING WASHER	16
020	0503010337	5/16" NUT	16
021	0501010694	FLAT WASHER	04
022	0503011907	PMC 594-S NYLON LUG	02
023	0503010240	5/16" X 3/4" BOLT	04
024	0521069527		01
025	0521069530		01
026	0521069528		02
027	0581019333		01
028	0503032076	SMALLER DOSADOR	01
029	0503030885	SEED DOSADOR SCALE	01
030	0503010001	RIVET POP	02
031	0531018938	SEED FINE SCALE SUPPORT	01
032	0503010298	1/4" X 1/2" BOLT	02




TATU INTEGRAL DRILL
FINE SEED BOX ASSY


Item	Code	Description	QT
033	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT	08
034	0503011342	3/4" TO 1 CLAMP	34
035	0501069926	54.1" HANDRAIL	02
036	0531015345	LEFT SEED FINE ADJUSTMENT	01
037	0531015347	RIGHT SEED FINE REGULACION	01
038	0501013518	FLAT WASHER	04
039	0501011643	3/8 X 1"BOLT	04
040	0503030616	17" X 17" X 15.7"HOSE	17
041	0503050042	FINE SEED DISTR BOX INTER	17
042	0909095058	ELECTRONIC BLADE HECTARE	01




Item	Code	Description	QT
01	0503015222	BUSHING	01
02	0503014540	M6 NUT	01
03	0503015223	LARGER COVER	01
04	0503015224	DISTRIBUTOR	01
05	0503015225	SMALLER COVER	01
06	0503011397	M5 X 0.3" NUT	01
07	0503015226	REGULATOR FLOW	01
08	0503015227	GRAPHITIZED RING	01
09	0503015228	TOOTHED WASHER	01
10	0503015229	TOOTH LOCKWASHER COVER	01
11	0503015230	M5 BOLT	01
12	0503015231	ROTOR	01
13	0503015232	M 6 X 12 BOLT	01
14	0503015233	COVER	01




Item	Code	Description	QT
01	0521011120	COVER PIVOT SHAFT	01
02	0501010694	FLAT WASHER	01
03	0503010140	1/8" X 3/4" COTTERPIN	02
04	0503031329	COMPRES SPRING	01
05	0521011117	PIVOT SPRING AXLE	01




Item	Code	Description	QT
001	0501110250	BEARING BOX	01
002	0503010372	501050 CLAMPING RING (FOR AXLE)	01
003	0503030832	FLAT WASHER	01
004	0503010397	5/16" X 1-3/4" BOLT	03
005	0503010337	5/16" NUT	03
006	0503010237	3/8" X 1" BOLT	02
007	0503010025	3/8" SPRING WASHER	02
008	0503010026	3/8" NUT	02
009	0503010003	1845 GREASE FITTING	01
010	0581019329	30Z P1/2" GEAR	01
011	0521069506	28Z GEAR REEL	01
012	0581019327	0.3" X 0.6" X 0.8" SLEEVE	03




Item	Code	Description	QT
01	0503030706	PASTURE SEED DISTRIBUTOR BOX	01
02	0503030705	ROTOR GUIDES	01
03	0503030701	ROTOR	01
04	0503030702	DISTRIBUTOR BOX SEAL	01
05	0503030704	MOBILE WASHER SUPPORT SLEEVE	01
06	0503030703	ROTOR WHASHER	01




Item	Code	Description	QT
01	0521054943	LONG ROW	01
02	0521054939	SEED UNALIGNED DOUBLE-DISC	01
03	0521054941	PRESS WHEELS	01
04	0521054942	SPRING ROD	02
05	0909095061	REGULATOR ASSY	01
06	0909095062	ENSEMBLE BRAS	01




Item	Code	Description	QT
01	0521054944	SHORT ROW	01
02	0521054939	SEED UNALIGNED DOUBLE-DISC	01
03	0521054941	PRESS WHEELS	01
04	0521054942	SPRING ROD	02
05	0909095061	REGULATOR ASSY	01
06	0909095063	ENSEMBLE BRAS	01




Item	Code	Description	QT
001	0502010358	ROW FIXER CLAMP	01
002	0503010752	1/2" X 3.1/2" BOLT	01
003	0503010706	1/2" X 4.1/2" BOLT	01
004	0521054939	SEED UNALIGNED DOUBLE-DISC	01
005	0521069550	LARGER ARM ROW	01
006	0503030338	SEED FERTILIZER SOCKET	02
007	0521069551	FINE SEED SOCKET	01
008	0502010693	ROW SUPPORT ARTICULACION	01
009	0502011682	PRESS WHEEL FIXER	01
010	0521054941	PRESS WHEELS	01
011	0503013082	M10 X 1,5 X 70 BOLT	01
012	0503011051	M10 X 0.6" NUT	01
013	0503010589	1/2" UNC SELF ADJUSTING NUT	02
014	0501013518	FLAT WASHER	05
015	0503012444	3/8" X 1-1/4" BOLT	04
016	0503010208	3/8" NUT	04
017	0503010025	3/8" SPRING WASHER	07
018	0521014193	WELL LOCK COMPACTOR	01
019	0503030168	HAIR PIN	01
020	0521054942	SPRING ROD	02
021	0581019414	EAR FIXATION	02
022	0503010026	3/8" NUT	03
023	0503010765	3/8" X 3" BOLT	03
024	0581019413	FINE SPEED SOCKET BODY	01




Item	Code	Description	QT
001	0502010358	ROW FIXER CLAMP	01
002	0503010752	1/2" X 3.1/2" BOLT	01
003	0503010706	1/2" X 4.1/2" BOLT	01
004	0521069554	SMALLER ARM ROW	01
005	0503030338	SEED FERTILIZER SOCKET	02
006	0521069551	FINE SEED SOCKET	01
007	0521054939	SEED UNALIGNED DOUBLE-DISC	01
008	0502010693	ROW SUPPORT ARTICULACION	01
009	0502011682	PRESS WHEEL FIXER	01
010	0521054941	PRESS WHEELS	01
011	0503011051	M10 X 0.6" NUT	01
012	0503013082	M10 X 1,5 X 70 BOLT	01
013	0503010589	1/2" UNC SELF ADJUSTING NUT	02
014	0501013518	FLAT WASHER	05
015	0503012444	3/8" X 1-1/4" BOLT	04
016	0503010208	3/8" NUT	04
017	0503010025	3/8" SPRING WASHER	07
018	0521014193	WELL LOCK COMPACTOR	01
019	0503030168	HAIR PIN	01
020	0521054942	SPRING ROD	02
021	0503010026	3/8" NUT	03
022	0503010765	3/8" X 3" BOLT	03
023	0581019403	EAR FIXATION	02
024	0581019413	FINE SPEED SOCKET BODY	01




Item	Code	Description	QT
001	0501017541	RH DOUBLE DISC SCRAPER	01
002	0501017542	LH DOUBLE DISC SCRAPER	01
003	0581019420	DOUBLE BLADE DISC SUPPORT	01
004	0521054938	LH HUB LOWR Y/DISC	01
005	0521054940	RIGHT HUB LOWR Y/DISC	01
006	0503010849	3/8" X 1-1/2" BOLT	01
007	0501010984	FLAT WASHER	02
008	0503010026	3/8" NUT	01
009	0503010025	3/8 SPRING WASHER	01
010	0503014679	2-134 O'RING	02
011	0503015081	502052 CLAMPING RING (FOR AXLE)	02
012	0571011152	DOUBLE DISC CAP	02
013	0503034055	CLAMPING RING	02
014	0581019215	DUST CLOAK	02
015	0521012763	FLAT WASHER	01




Item	Code	Description	QT
001	0503034829	RIGHT HUB AXLE	01
002	0603011024	D 12" X 0.12" PLAIN COULTER BLADE	01
003	0503010337	5/16" NUT	06
004	0503010546	5/16" X 7/8" BOLT	06
005	0581019410	HUB LOWR DDD	01
006	0503019342	ROLLER BEARING	01




Item	Code	Description	QT
001	0503034828	LEFT HUB AXLE	01
002	0603020019	D272 PLAIN COULTER BLADE	01
003	0503010337	5/16" NUT	06
004	0503010546	5/16" X 7/8" BOLT	06
005	0581019410	HUB LOWR DDD	01
006	0503019342	ROLLER BEARING	01




Item	Code	Description	QT
001	0541011724	PRESS WHEEL LOCK	02
002	0503010019	1/2" SPRING WASHER	02
003	0503010060	1/2" NUT	02
004	0521069552	WHEEL FORK	01
005	0501054326	COMPACTOR CONCAVA WEEL	01




Item	Code	Description	QT
001	0531017070	PRESS WHEEL AXLE	01
002	0501014071	RIM SEMI	02
003	0502020600	MARKER ARM DISC HUB	02
004	0503010690	6204 BALL BEARING	02
005	0503010272	SEAL 00715-BA	02
006	0503010691	1/4" GREASE FITTING	02
007	0503030143	3.3" X 1.9" X 0.1" JOINT	02
008	0503013814	1/4" NC LOCKNUT	05
009	0503010743	1/4" X 1-1/4" BOLT	05
010	0511017303	FLAT WASHER	05
011	0503010143	SPRING WASHER	05
012	0503010144	1/4" NUT	05
013	0503013758	1/4" X 1-1/2" BOLT	05
014	0503030239	DEPTH CONTROL WHEEL RUBBER BAND	01




Item	Code	Description	QT
001	0503010060	1/2" NUT	01
002	0501010301	FLAT WASHER	02
003	0521069553	SPRING REGULACION	01
004	0503031516	0.98" X 14.17" X 0.16" SPRING	01
005	0503030285	HAIR PIN	01




Item	Code	Description	QT
01	0521069549	SPRING REGULACION	01
02	0581019406	TRUNNION	01
03	0581019407	REGULATOR FIXER	01
04	0503010706	1/2" X 4.1/2" BOLT	02
05	0501010937	FLAT WASHER	02
06	0503011336	1/2" HEX SELF ADJUSTING NUT	02




Item	Code	Description	QT
01	0521069550	LARGER ARM ROW	01
02	0502010693	ROW SUPPORT ARTICULACION	01
03	0502010358	ROW FIXER CLAMP	01
04	0503010706	1/2" X 4.1/2" BOLT	01
05	0503010752	1/2" X 3.1/2" BOLT	01
06	0503013082	M10 X 1,5 X 70 BOLT	01
07	0503011051	M10 X 0.6" NUT	01
08	0503010589	1/2" UNC SELF ADJUSTING NUT	02
09	0501013518	FLAT WASHER	02




Item	Code	Description	QT
01	0521069554	SMALLER ARM ROW	01
02	0502010693	ROW SUPPORT ARTICULACION	01
03	0502010358	ROW FIXER CLAMP	01
04	0503010706	1/2" X 4.1/2" BOLT	01
05	0503010752	1/2" X 3.1/2" BOLT	01
06	0503013082	M10 X 1,5 X 70 BOLT	01
07	0503011051	M10 X 0.6" NUT	01
08	0503010589	1/2" UNC SELF ADJUSTING NUT	02
09	0501013518	FLAT WASHER	02




Item	Code	Description	QT
01	0503060718	ELECTRONIC BLADE HECTARE	01
02	0581019375	FIXER COUNTER HECTARE	01
03	0503013815	1/4" X 5/8" BOLT	02
04	0503010143	SPRING WASHER	02
05	0503010144	1/4" NUT	02
06	0581019377	MAGNET FIXER BLADE HECTARE	01
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT	02
08	0501010694	FLAT WASHER	04
09	0503010179	SPRING WASHER	04
10	0503010337	5/16" NUT	04
11	0541015265	RECEIVER MAGNETIC SUPPORT	01
12	0503011952	5/16" X 3/4" BOLT	02
13	0521069556	MAGNET FIXER	01
14	0503015779	ALLEN BOLT	01



Item	Code	Description	QT
001	0503032650	ELECTRONIC BLADE HECTARE	01
002	0503032651	MAGNET FIXER	01



Item	Code	Description	QT
01	0501068706	DOUBLE CONNECTION	01
02	0581019378	DISTRIBUTOR DOUBLE SUPPORT	01
03	0503010371	5/16" X 1" BOLT	02
04	0501010694	FLAT WASHER	02
05	0503010179	SPRING WASHER	02
06	0503010337	5/16" NUT	02
07	0501011643	3/8 X 1" BOLT	02
08	0503010025	3/8 SPRING WASHER	02
09	0503010026	3/8" NUT	02
10	0521055061	HOSE KIT	01
10A	0501080473	3/8" X 120" TC-TM HOSE	02
10B	0501080412	3/8" X 90.55" TR-TC HOSE	02
10C	0501080998	3/8" X 2100 TR-TC HOSE ASSY	02
10D	0501053834	MALE QUICK COUPLING AGRICULTURAL WITH COVER - 1/2 NPT	02
11	0501013658	HOSE HOLDER	01
12	0521054919	HIDRAULIC CYLINDER	02



Item	Code	Description	QT
01	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT	01
02	0503011882	QUICK CONNECTION COVER	01



MARCHESAN IMPLEMENTOS E MÁQUINAS AGRÍCOLAS TATU S.A.

AV. Marchesan, 1979 - Post office box, 131 - CEP 15994-900 - Matão - SP - Brazil

Phone +55 16.3382-8282

(FAX Parts) + 55 16.3382. 8297 - (Export) + 55 16.3382.1003

e.mail: tatu@marchesan.com.br www.marchesan.com.br

Technical Publications: Elaboration

MARINA PEREZ NIZA

Technical Publications: Revision

LUIZ CANDIDO

Contact Catálogo:

E-mail = jgaspari@marchesan.com.br

**ORIGINAL PARTS
TATU**

