

ROW CROP PLANTERS

PST TRIO FLEX - FRAME

6850/7450/7860/7960/8160/8460

/8960/9460/9960/10460/10985 (UP TO 03/2022)

Code: 0501092419

Series: S-0119

Revision: 00

Date Revision: JULHO/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS

Code	Description
0111260407	PST TRIO FLEX 10460/21E500 CI MH DC20 S-0119
0111260411	PST TRIO FLEX 10460/22E450 CI MH DC20 S-0119
0111260415	PST TRIO FLEX 10985/22E500 CI MH DC20 S-0119
0111260419	PST TRIO FLEX 10985/24E450 CI MH DC20 S-0119
0111260351	PST TRIO FLEX 6850/15E450 CI MH DC20 S-0119
0111260435	PST TRIO FLEX 6850/15E450 CPF CI MH DC20 S-0119
0111260436	PST TRIO FLEX 6850/15E450 CPRA CI MH DC20 S-0119
0111260446	PST TRIO FLEX 7450/15E500 CI MH DC20 CEAC S-0119
0111260355	PST TRIO FLEX 7450/15E500 CI MH DC20 S-0119
0111260448	PST TRIO FLEX 7450/15E500 SPCRR CI MH DC20 S-0119
0111260447	PST TRIO FLEX 7450/15E500CPRA D/HDA MH DC20 S-0119
0111260359	PST TRIO FLEX 7450/16E450 CI MH DC20 S-0119
0111260363	PST TRIO FLEX 7860/17E450 CI MH DC20 S-0119
0111260367	PST TRIO FLEX 7960/16E500 CI MH DC20 S-0119
0111260371	PST TRIO FLEX 8160/15E550 CI MH DC20 S-0119
0111260375	PST TRIO FLEX 8460/17E500 CI MH DC20 S-0119
0111260379	PST TRIO FLEX 8460/18E450 CI MH DC20 S-0119
0111260383	PST TRIO FLEX 8960/18E500 CI MH DC20 S-0119
0111260387	PST TRIO FLEX 8960/19E450 CI MH DC20 S-0119
0111260391	PST TRIO FLEX 9460/19E500 CI MH DC20 S-0119
0111260395	PST TRIO FLEX 9460/20E450 CI MH DC20 S-0119
0111260399	PST TRIO FLEX 9960/20E500 CI MH DC20 S-0119
0111260403	PST TRIO FLEX 9960/21E450 CI MH DC20 S-0119

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909095197	FRAME ASSY 6850/7450/7860/7960/8160/8460	1
0909095198	FRAME ASSY 8960/9460/9960/10460/10985	2
0511059420	FRAME WITH ARTICULATION 6850	3
0511053046	RIGHT FRAME WITH AXLE WHEELED 6850	4
0511059288	CENTRAL FRAME WITH WHEELED AXLE 5750/6850/7860/8160	5
0511053047	LEFT FRAME WITH WHEELED AXLE 6850	6
0511053196	PST JOINT FRAME	7
0511053188	RIGHT FRAME WITH WHEELED AXLE 7450	8
0511053189	LEFT FRAME WITH WHEELED AXLE 7450	9
0511053190	CENTRAL FRAME WITH WHEELED AXLE 6450/7285/7450/8460	10
0511059983	7860 ARTICULATION FRAME WITH	11
0511053135	RIGHT FRAME WITH WHEELED AXLE 7860	12
0511053136	LEFT FRAME WITH WHEELED AXLE 7860	13
0511053769	FRAME WITH ARTICULATION 7960	14
0511053766	RIGHT FRAME WITH WHEELED AXLE 7960/8160	15
0511053767	LEFT FRAME WITH WHEELED AXLE 7960/8160	16
0511053768	CENTRAL FRAME WITH WHEELED AXLE 5850/7960	17
0511059576	FRAME WITH SHAFT	18
0511056311	ARTICULATION FRAME 8460	19
0511056312	RIGHT FRAME WITH WHEELED AXLE 8460	20
0511056313	LEFT FRAME WITH WHEELED AXLE 8460	21
0511059232	ASSEMBLY SPRING TRACTION	22
0521055229	WHEELED WITH 655 DRIFT SPRING WITH TRANSMISSION	23
0521055241	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	24
0521055231	655 WHEELED SUPPORT WITH TRANSMISSION	25
0521055243	655 WHEELED BRACKET WITHOUT TRANSMISSION	26
0501058241	WHEEL SUPPORT CHAIN TENSIONER	27
0521055232	WHEEL WITH PNEU	28
0521055239	WHEEL WITH TIRE WITHOUT TRANSMISSION	29
0503062159	WHEEL WITH TIRE	30
0521055233	WHEELED TRANSMISSION WITHOUT TIRE	31
0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	32
0521055234	WHEELED FASTENER	33
0521055236	INTERMEDIARY CURRENT STRETCHER	34
0521055237	WHEEL FIXED CURRENT STRETCHER	35
0521055235	WHEEL MOBILE CURRENT STRETCHER	36
0909095199	HEADER FULL ASSEMBLY	37
0909095202	HEADER FULL ASSEMBLY - FRAME 8960/9460/9960/10460/10985	38
0511055096	TRACTOR HITCH	39
0521051614	TURNBUCKLE SIDE UPPER	40
0521050574	EXTENSOR	41
0521050133	TURNBUCKLE SIDE 755/480	42
0521050681	LATERAL EXTENSOR 1250/480	43
0511059237	3 POINT TURNBUCKLE	44
0521045756	HYDRAULIC CYLINDER	45
0511057653	HYDRAULIC CYLINDER	46
0511059419	HYDRAULIC SYSTEM ASSEMBLY 6850/7285/7450/7860/7960	47
0521052860	HYDRAULIC SYSTEM ASSEMBLY 8160/8460	48
0521052895	HYDRAULIC SYSTEM ASSEMBLY 8960/9960	49
0521052913	HYDRAULIC SYSTEM ASSEMBLY 9460/10460	50
0521052953	HYDRAULIC SYSTEM ASSEMBLY 10985	51
0511059290	VALVE ASSEMBLY	52
0501053835	FEMALE QUICK COUPLER	53



MARCHESAN

INDEX

0501053834	MALE QUICK COUPLER	54
0521052737	SILO FERTILIZER ASSEMBLY 6850	55
0521052712	SILO FERTILIZER RIGHT SUPPORT 6850	56
0521052721	SILO FERTILIZER LEFT SUPPORT 6850	57
0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	58
0521050195	SILO FERTILIZER LEFT SQUARE AXLE	59
0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	60
0521052622	ASSY SILO FERTILIZER 7450	61
0521052620	SUPPORT SILO RIGHT FERTILIZER WITH DISTRIBUTOR 7450	62
0521052621	SILO SUPPORT LEFT FERTILIZER WITH DISTRIBUTOR 7450	63
0521051607	SUPPORT SILO CENTRAL FERTILIZER 6450/7285/7450/8460	64
0521052745	ASSY SILO FERTILIZER 7860	65
0521052710	SUPPORT SILO RIGHT FERTILIZER WITH DISTRIBUTOR 7860	66
0521052719	SILO SUPPORT LEFT FERTILIZER WITH DISTRIBUTOR 7860	67
0521052734	SUPPORT SILO CENTRAL FERTILIZER 6850/7860	68
0521052738	ASSY SILO FERTILIZER 7960	69
0521052711	SUPPORT SILO RIGHT FERTILIZER WITH DISTRIBUTOR 7860/7960	70
0521052720	SILO SUPPORT LEFT FERTILIZER WITH DISTRIBUTOR 7820/7960	71
0521052732	SUPPORT SILO CENTRAL FERTILIZER WITH DISTRIBUTOR 7960	72
0521052751	ASSY SILO FERTILIZER 8160	73
0521052704	SUPPORT SILO RIGHT FERTILIZER WITH DISTRIBUTOR 8160	74
0521052713	SILO SUPPORT LEFT FERTILIZER WITH DISTRIBUTOR 8160	75
0521052735	SUPPORT SILO CENTRAL FERTILIZER WITH DISTRIBUTOR 8160	76
0521052744	ASSY SILO FERTILIZER 8460	77
0521052709	SUPPORT SILO RIGHT FERTILIZER WITH DISTRIBUTOR 8460/8960/9460	78
0521052718	SILO SUPPORT LEFT FERTILIZER WITH DISTRIBUTOR 8460/8960/9460	79
0521052740	SILO FERTILIZER ASSEMBLY 8960	80
0521052731	SUPPORT SILO CENTRAL FERTILIZER WITH DISTRIBUTOR 8960	81
0521052741	SILO FERTILIZER ASSEMBLY 9460	82
0521052728	SUPPORT SILO CENTRAL FERTILIZER WITH DISTRIBUTOR 9460	83
0521052747	SILO FERTILIZER ASSEMBLY 9960	84
0521052708	SUPPORT SILO RIGHT FERTILIZER WITH DISTRIBUTOR 9960/10460	85
0521052717	SILO SUPPORT LEFT FERTILIZER WITH DISTRIBUTOR 9960/10460	86
0521052727	SUPPORT SILO CENTRAL FERTILIZER WITH DISTRIBUTOR 9960	87
0521052752	SILO FERTILIZER ASSEMBLY 10460	88
0521052725	SUPPORT SILO CENTRAL FERTILIZER WITH DISTRIBUTOR 10460	89
0521052749	SILO FERTILIZER ASSEMBLY 10985	90
0521052706	SUPPORT SILO RIGHT FERTILIZER WITH DISTRIBUTOR 10985	91
0521052715	SILO SUPPORT LEFT FERTILIZER WITH DISTRIBUTOR 10985	92
0521052723	SUPPORT SILO CENTRAL FERTILIZER WITH DISTRIBUTOR 10985	93
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95
0501053788	3/4 SQUARE AXLE FASTENER	96
0511058230	TRANSMISSION ASSEMBLY 6850	97
0511058249	ASSEMBLY TRANSMISSION 7450	98



MARCHESAN

INDEX

0511059740	ASSEMBLY TRANSMISSION 7860	99
0511058836	ASSEMBLY TRANSMISSION 7960/8160/8460	100
0511058885	TRANSMISSION ASSEMBLY 8960	101
0521050216	TRANSMISSION ASSEMBLY 9460	102
0511058850	TRANSMISSION ASSEMBLY 9960/10460	103
0521051048	TRANSMISSION ASSEMBLY 10985	104
0501052560	MOTOR AXLE SIGNAL	105
0511051434	TRANSMISSION ACTUATOR	106
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	107
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	108
0521043316	RIGHT GEAR BOX ASSY	109
0521043317	LEFT GEAR BOX ASSY	110
0501058212	SEMI MOUNTED RIGHT CHANGE	111
0501058213	LH GEAR BOX	112
0511059266	CLOSED BEARING	113
0501056271	GEARBOX CLOSED BEARING	114
0501056443	GEAR HOUSING BEARING	115
0501056444	BEARING WITH ROLLING	116
0501048790	AXLE WITH RING	117
0501054655	CHAIN TENSIONER ASSY	118
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	119
0511059261	CHAIN TENSIONER	120
0521055217	LOWER CURRENT STRETCH	121
0501058254	UPPER SEED CHAIN TENSIONER	122
0521055216	BEARING WITH GEAR	123
0521055218	BEARING GEAR WITH DOUBLE	124
0521055214	BEARING GEAR WITH	125
0521055215	DOUBLE TRANSMISSION BEARING	126
0521052671	PLATFORM ASSEMBLY 6850	127
0521052672	PLATFORM ASSEMBLY 7450	128
0521052675	PLATFORM ASSEMBLY 7860	129
0521052674	PLATFORM ASSEMBLY 7960	130
0521052673	PLATFORM ASSEMBLY 8160	131
0521052676	PLATFORM ASSEMBLY 8460	132
0521052677	PLATFORM ASSEMBLY 8960	133
0521052678	PLATFORM ASSEMBLY 9460	134
0521052679	PLATFORM ASSEMBLY 9960	135
0521052103	PLATFORM ASSEMBLY 10460	136
0521052681	PLATFORM ASSEMBLY 10985	137
0511058234	HANDLE ASSEMBLY 6850	138
0511058252	HANDLE ASSEMBLY 7450	139
0511058276	HANDLE ASSEMBLY 7860	140
0511058955	HANDLE ASSEMBLY 7960	141
0511059571	HANDLE ASSEMBLY 8160	142
0511058282	HANDLE ASSEMBLY 8460	143
0511058889	HANDLE ASSEMBLY 8960	144
0521050213	HANDLE ASSEMBLY 9460	145
0511058845	HANDLE ASSEMBLY 9960	146
0511058898	HANDLE ASSEMBLY 10460	147
0521051058	HANDLE ASSEMBLY 10985	148
0511054971	JACK ASSEMBLY	149
0511056536	LADDER ASSEMBLY	150
0909095200	DOUBLE HYDRAULIC MARKER ASSEMBLY 6850/7450/7860/ 7960/8160/8460	151



MARCHESAN

INDEX


0909095203	DOUBLE HYDRAULIC MARKER ASSEMBLY 8960/9460/9960 /10460/10985	152
0521055204	LIGNE DE DISQUE MARKER	153
0501054649	HBM SEQUENTIAL VALVE	154
0511058431	HYDRAULIC CYLINDER	155
0521052826	TRANSMISSION AXLE ASSEMBLY 6850	156
0521052827	AXIS TRANSMISSION SEED ASSY 7450	157
0521052858	AXIS TRANSMISSION SEED ASSY 7860	158
0521052855	AXIS TRANSMISSION SEED ASSY 7960	159
0521052887	AXIS TRANSMISSION SEED ASSY 8160	160
0521052863	AXIS TRANSMISSION SEED ASSY 8460	161
0521052898	AXIS TRANSMISSION SEED ASSY 8960	162
0521052909	AXIS TRANSMISSION SEED ASSY 9460	163
0521052921	AXIS TRANSMISSION SEED ASSY 9960	164
0521052928	AXIS TRANSMISSION SEED ASSY 10460	165
0521052958	AXIS TRANSMISSION SEED ASSY 10985	166
0511059233	INTERMEDIATE TRANSMISSION	167
0503062206	CARDAN TERMINAL	168
0521052803	REAR LIGHT ASSEMBLY	169
0521052844	REAR LIGHT ASSEMBLY 7860/7960/8160/8460	170
0521052899	REAR LIGHT ASSEMBLY 8960/9460	171
0521052923	REAR LIGHT ASSEMBLY 9960	172
0521052930	REAR LIGHT ASSEMBLY 10460	173
0521052960	REAR LIGHT ASSEMBLY 10985	174
0521052792	MOUNTED REAR LIGHT	175
0521052796	CYLINDER ASSEMBLY 5750/6850/7860/7960/8460	176
0521052810	ASSY MANUAL DOOR	177
0909095201	SEED LINE/FERTILIZER ASSEMBLY	178
0521053227	FRONT LEFT SHORT SEED ROW	179
0521053230	FRONT RIGHT SHORT SEED ROW	180
0521053228	FRONT LEFT LONG SEED ROW	181
0521053229	FRONT RIGHT LONG SEED ROW	182
0521054737	FRONT SEMI-ASSEMBLED LONG LEFT SEED ROW	183
0521054736	FRONT SEMI-ASSEMBLED OF LONG RIGHT SEED LINE	184
0521055213	LINE BEARING SEED	185
0521055223	SEED LINE TRANSMISSION BOX	186
0511055260	SEED ROW CHAIN TENSIONER	187
0521055226	BEARING WITH AXLE JOINT	188
0501059326	UNIVERSAL JOINT AXLE	189
0521055227	BEARING SHAFT HEX	190
0501059363	5/8" HEX AXLE BEARING	191
0521055219	BEARING WITH GEAR 17Z HEX 5/8	192
0521055220	BEARING FRONT LINE SEED	193
0511059333	SEMI-ASSEMBLED MECHANICAL FRAME	194
0511059334	BEARING WITH LONG FRONT AXLE	195
0511058143	UNIVERSAL JOINT AXLE	196
0521054771	LEFT REAR SEED ROW	197
0521054770	RIGHT REAR SEED ROW	198
0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	199
0521054763	DDD LEFT SEED	200
0521054762	RIGHT DDD SEED	201
0511052302	LH SUPPORT DDD GUIDE	202
0511052301	SUPPORT DDD 15 RIGHT	203
0521054761	LEFT LOW CUBE	204
0521054760	DOWN LOW CUBE	205



MARCHESAN

INDEX


0521054758	CONTROL DEPTH WITH REGULATOR	206
0521054751	DEPTH CONTROL WITH THREAD	207
0521053245	LEFT ARM WHEELS	208
0521053244	ARM RIGHT WHEEL COBRIDORA	209
0521054744	CUBE RIGHT CONTROL DEPTH	210
0521054745	HUB LEFT CONTROL DEPTH	211
0511055819	DEPTH WHIT AROS BAND	212
0521054752	V COMPACTING SYSTEM	213
0521054753	DRIVE WHEEL V RUBBER RIGHT	214
0521054754	DRIVE WHEEL V LEFT RUBBER	215
0521054984	DEPTH/COMPACTOR SYSTEM - SPT	216
0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	217
0501052297	DEPTH WHEELS REGULATOR ASSY	218
0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	219
0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	220
0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	221
0521055033	SEMI-ASSEMBLED COMPACTOR BODY	222
0501052538	DEPTH BAND WITH ARMS	223
0521054990	LEFT COMPACTOR WHEEL	224
0521055017	RIGHT COMPACTOR WHEEL	225
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	226
0521055032	DEPTH SYSTEM WHEELS ASSY IRON WITHOUT LUBRICATION	227
0521055019	IRON IN RIGHT WHEEL COMPACTOR V	228
0521055018	WHEEL DRIVE WHEEL LEFT IN V	229
0521054991	WHEEL DRIVE WHEEL RIGHT	230
0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	231
0521055065	ASSY DEPTH / COMPACTOR	232
0521055054	LEFT ARM WITH SLEEVE	233
0521055066	RIGHT ARM WITH GLOVE	234
0521055068	RAYED WHEEL CENTER CLOSED	235
0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	236
0521054811	FERTILIZER SHORT LINE	237
0521054812	LONG FERTILIZER LINE	238
0521053231	DPL 20 SHORT LINE WITHOUT LUBRICATION CONICAL BEARING	239
0521053232	DPL 20 LONG LINE WITHOUT LUBRICATION CONICAL BEARING	240
0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	241
0521053697	CUTTING DISK BOX	242
0521054906	SPRING ASSY FERTILIZER	243
0521054769	LEFT FERTILIZER WITH SUPPORT	244
0521054765	DDD LEFT FERTILIZER	245
0521054768	DDD RIGHT FERTILIZER WITH SUPPORT	246
0521054764	DDD RIGHT FERTILIZER	247
0511057017	SEED SYSTEM ASSY	248
0501051094	ASSY SEED DISTRIBUTOR	249
0501051119	DOUBLE PULLEY ROCKER'S	250
0511052024	FAST CLOSING SET	251
0521053946	SCARING ROD	252
0521053947	AUTOMATIC DISARMING ROD	253
0521053951	STEM	254
0521053932	ROD WITH BEAK 0869	255
0501050120	LARGER WALKING BEAM ASSY	256
0511056736	HOSE SUPPORT	257



Item	Code	Description	See page	6850	7450	7860	7960	8160	8460
01	0511059420	FRAME WITH ARTICULATION 6850	3	001	000	000	000	000	000
01.	0511053196	PST JOINT FRAME	7	000	001	000	000	000	000
01..	0511059983	7860 ARTICULATION FRAME WITH	11	000	000	001	000	000	000
01...	0511053769	FRAME WITH ARTICULATION 7960	14	000	000	000	001	000	000
01....	0511059576	FRAME WITH SHAFT	18	000	000	000	000	001	000
01.....	0511056311	ARTICULATION FRAME 8460	19	000	000	000	000	000	001
02	0521064285	LOCK LOWER FRAME		002	002	002	002	002	002
03	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		002	002	002	002	002	002
04	0503010002	1800 GREASE FITTING		002	002	002	002	002	002
05	0503010003	1845 GREASE FITTING		008	008	008	008	008	008
06	0503010004	1890 GREASE FITTING		002	002	002	002	002	002
07	0511059232	ASSEMBLY SPRING TRACTION	22	002	002	002	002	002	002
08	0521055229	WHEELED WITH 655 DRIFT SPRING WITH 23	23	004	004	004	004	004	004
09	0521055241	WHEELED WITH 655 DRIFT SPRING WITHOUT 24	24	002	002	004	004	004	004
10	0909095199	HEADER FULL ASSEMBLY	37	001	001	001	001	001	001
11	0511059419	HYDRAULIC SYSTEM ASSEMBLY 6850/7285/7450/7860/7960	47	001	001	001	001	000	000
11.	0521052860	HYDRAULIC SYSTEM ASSEMBLY 8160/8460	48	000	000	000	000	001	001
12	0521052737	SILO FERTILIZER ASSEMBLY 6850	55	001	000	000	000	000	000
12.	0521052622	ASSY SILO FERTILIZER 7450	61	000	001	000	000	000	000
12..	0521052745	ASSY SILO FERTILIZER 7860	65	000	000	001	000	000	000
12...	0521052738	ASSY SILO FERTILIZER 7960	69	000	000	000	001	000	000
12....	0521052751	ASSY SILO FERTILIZER 8160	73	000	000	000	000	001	000
12.....	0521052744	ASSY SILO FERTILIZER 8460	77	000	000	000	000	000	001
13	0511058230	TRANSMISSION ASSEMBLY 6850	97	001	000	000	000	000	000
13.	0511058249	ASSEMBLY TRANSMISSION 7450	98	000	001	000	000	000	000
13..	0511059740	ASSEMBLY TRANSMISSION 7860	99	000	000	001	000	000	000
13...	0511058836	ASSEMBLY TRANSMISSION 7960/8160/8460	100	000	000	000	001	001	001
14	0521052671	PLATFORM ASSEMBLY 6850	127	001	000	000	000	000	000
14.	0521052672	PLATFORM ASSEMBLY 7450	128	000	001	000	000	000	000




Item	Code	Description	See page	6850	7450	7860	7960	8160	8460
14..	0521052675	PLATFORM ASSEMBLY 7860	129	000	000	001	000	000	000
14...	0521052674	PLATFORM ASSEMBLY 7960	130	000	000	000	001	000	000
14....	0521052673	PLATFORM ASSEMBLY 8160	131	000	000	000	000	001	000
14.....	0521052676	PLATFORM ASSEMBLY 8460	132	000	000	000	000	000	001
15	0511058234	HANDLE ASSEMBLY 6850	138	001	000	000	000	000	000
15.	0511058252	HANDLE ASSEMBLY 7450	139	000	001	000	000	000	000
15..	0511058276	HANDLE ASSEMBLY 7860	140	000	000	001	000	000	000
15...	0511058955	HANDLE ASSEMBLY 7960	141	000	000	000	001	000	000
15....	0511059571	HANDLE ASSEMBLY 8160	142	000	000	000	000	001	000
15.....	0511058282	HANDLE ASSEMBLY 8460	143	000	000	000	000	000	001
16	0511054971	JACK ASSEMBLY	149	002	002	002	002	002	002
17	0511056536	LADDER ASSEMBLY	150	002	002	002	002	002	002
18	0909095200	DOUBLE HYDRAULIC MARKER ASSEMBLY 6850/7450/7860/ 7960/8160/8460	151	001	001	001	001	001	001
19	0521052826	TRANSMISSION AXLE ASSEMBLY 6850	156	001	000	000	000	000	000
19.	0521052827	AXIS TRANSMISSION SEED ASSY 7450	157	000	001	000	000	000	000
19..	0521052858	AXIS TRANSMISSION SEED ASSY 7860	158	000	000	001	000	000	000
19...	0521052855	AXIS TRANSMISSION SEED ASSY 7960	159	000	000	000	001	000	000
19....	0521052887	AXIS TRANSMISSION SEED ASSY 8160	160	000	000	000	000	001	000
19.....	0521052863	AXIS TRANSMISSION SEED ASSY 8460	161	000	000	000	000	000	001
20	0521052803	REAR LIGHT ASSEMBLY	169	001	001	000	000	000	000
20.	0521052844	REAR LIGHT ASSEMBLY 7860/7960/8160/8460	170	000	000	001	001	001	001
21	0521052796	CYLINDER ASSEMBLY 5750/6850/7860/7960/8460	176	001	001	001	001	001	001
22	0521052810	ASSY MANUAL DOOR	177	001	001	001	001	001	001
23	0909095201	SEED LINE/FERTILIZER ASSEMBLY	178	001	001	001	001	001	001
24	0541015451	FIXED KEY 2.3/8 X 2.3/4		001	001	001	001	001	001
25	0501065677	STRUT		002	002	002	002	002	002
26	0501047895	ROD STOP		003	003	003	003	003	003
27	0501047885	ROD STOP		003	003	003	003	003	003
28	0501047886	ROD STOP		003	003	003	003	003	003
29	0501047887	ROD STOP		003	003	003	003	003	003
30	0511056736	HOSE SUPPORT	257	001	001	001	001	001	001
31	0521013022	TRANSPORT LOCK		003	003	003	003	003	003
32	0503030168	CUPILLA		003	003	003	003	003	003
33	0501068994	0.3" X 3.1"LOCK PIN		003	003	003	003	003	003
34	0521066304	HOSE GUIDE		001	001	001	001	001	001
35	0503019262	SOAP DISH VACUUM		001	001	001	001	001	001
36	0503010780	N-2050 AMENDMENT		002	002	002	002	002	002
37	0503011750	AMENDMENT WITH LOCK		006	006	006	006	006	006
38	0503011751	REDUCTION		006	006	006	006	006	006
39	0503010951	REDUCTION		004	004	004	004	004	004
40	0503010246	CLAMP		015	015	017	016	015	017
41	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		002	002	002	002	002	002
42	0503013816	5/16" LOCKNUT		002	002	002	002	002	002




Item	Code	Description	See page	8960	9460	9960	10460	10985
01	0521052760	ARTICULATED FRAME 8960		001	000	000	000	000
01.	0521052763	ARTICULATED FRAME 9460		000	001	000	000	000
01..	0521052765	ARTICULATED FRAME 9960		000	000	001	000	000
01...	0521052798	ARTICULATED FRAME 10460		000	000	000	001	000
01....	0521052769	ARTICULATED FRAME 10985		000	000	000	000	001
02	0521064285	LOCK LOWER FRAME		002	002	002	002	002
03	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		002	002	002	002	002
04	0503010002	1800 GREASE FITTING		002	002	002	002	002
05	0503010003	1845 GREASE FITTING		008	008	008	008	008
06	0503010004	1890 GREASE FITTING		002	002	002	002	002
07	0511059232	ASSEMBLY SPRING TRACTION	22	002	002	002	002	002
08	0521055229	WHEELED WITH 655 DRIFT SPRING WITH 23 TRANSMISSION	23	004	004	004	004	004
09	0521055241	WHEELED WITH 655 DRIFT SPRING WITHOUT 24 TRANSMISSION	24	006	006	006	006	008
10	0909095202	HEADER FULL ASSEMBLY - FRAME 8960/9460/9960 38 /10460/10985	38	001	001	001	001	001
11	0521052895	HYDRAULIC SYSTEM ASSEMBLY 8960/9960	49	001	000	001	000	000
11.	0521052913	HYDRAULIC SYSTEM ASSEMBLY 9460/10460	50	000	001	000	001	000
11..	0521052953	HYDRAULIC SYSTEM ASSEMBLY 10985	51	000	000	000	000	001
12	0521052740	SILO FERTILIZER ASSEMBLY 8960	80	001	000	000	000	000
12.	0521052741	SILO FERTILIZER ASSEMBLY 9460	82	000	001	000	000	000
12..	0521052747	SILO FERTILIZER ASSEMBLY 9960	84	000	000	001	000	000
12...	0521052752	SILO FERTILIZER ASSEMBLY 10460	88	000	000	000	001	000
12....	0521052749	SILO FERTILIZER ASSEMBLY 10985	90	000	000	000	000	001
13	0511058885	TRANSMISSION ASSEMBLY 8960	101	001	000	000	000	000
13.	0521050216	TRANSMISSION ASSEMBLY 9460	102	000	001	000	000	000
13..	0511058850	TRANSMISSION ASSEMBLY 9960/10460	103	000	000	001	001	000
13...	0521051048	TRANSMISSION ASSEMBLY 10985	104	000	000	000	000	001
14	0521052677	PLATFORM ASSEMBLY 8960	133	001	000	000	000	000
14.	0521052678	PLATFORM ASSEMBLY 9460	134	000	001	000	000	000
14..	0521052679	PLATFORM ASSEMBLY 9960	135	000	000	001	000	000


Item	Code	Description	See page	8960	9460	9960	10460	10985
14...	0521052103	PLATFORM ASSEMBLY 10460	136	000	000	000	001	000
14....	0521052681	PLATFORM ASSEMBLY 10985	137	000	000	000	000	001
15	0511058889	HANDLE ASSEMBLY 8960	144	001	000	000	000	000
15.	0521050213	HANDLE ASSEMBLY 9460	145	000	001	000	000	000
15..	0511058845	HANDLE ASSEMBLY 9960	146	000	000	001	000	000
15...	0511058898	HANDLE ASSEMBLY 10460	147	000	000	000	001	000
15....	0521051058	HANDLE ASSEMBLY 10985	148	000	000	000	000	001
16	0511054971	JACK ASSEMBLY	149	002	002	002	002	002
17	0511056536	LADDER ASSEMBLY	150	002	002	002	002	002
18	0909095203	DOUBLE HYDRAULIC MARKER ASSEMBLY 8960/9460/9960 /10460/10985	152	001	001	001	001	001
19	0521052898	AXIS TRANSMISSION SEED ASSY 8960	162	001	000	000	000	000
19.	0521052909	AXIS TRANSMISSION SEED ASSY 9460	163	000	001	000	000	000
19..	0521052921	AXIS TRANSMISSION SEED ASSY 9960	164	000	000	001	000	000
19...	0521052928	AXIS TRANSMISSION SEED ASSY 10460	165	000	000	000	001	000
19....	0521052958	AXIS TRANSMISSION SEED ASSY 10985	166	000	000	000	000	001
20	0521052899	REAR LIGHT ASSEMBLY 8960/9460	171	001	001	000	000	000
20.	0521052923	REAR LIGHT ASSEMBLY 9960	172	000	000	001	000	000
20..	0521052930	REAR LIGHT ASSEMBLY 10460	173	000	000	000	001	000
20...	0521052960	REAR LIGHT ASSEMBLY 10985	174	000	000	000	000	001
21	0521052796	CYLINDER ASSEMBLY 5750/6850/7860/7960/8460	176	001	001	001	001	001
22	0521052810	ASSY MANUAL DOOR	177	001	001	001	001	001
23	0909095201	SEED LINE/FERTILIZER ASSEMBLY	178	001	001	001	001	001
24	0541015451	FIXED KEY 2.3/8 X 2.3/4		001	001	001	001	001
25	0501065677	STRUT		002	002	002	002	002
26	0501047895	ROD STOP		006	006	006	006	006
27	0501047885	ROD STOP		006	006	006	006	006
28	0501047886	ROD STOP		006	006	006	006	006
29	0501047887	ROD STOP		006	006	006	006	006
30	0511056736	HOSE SUPPORT	257	001	001	001	001	001
31	0521013022	TRANSPORT LOCK		006	006	006	006	006
32	0503030168	CUPILLA		006	006	006	006	006
33	0501068994	0.3" X 3.1" LOCK PIN		006	006	006	006	006
34	0521066304	HOSE GUIDE		001	001	001	001	001
35	0503019262	SOAP DISH VACUUM		001	001	001	001	001
36	0503010780	N-2050 AMENDMENT		002	002	002	002	002
37	0503011750	AMENDMENT WITH LOCK		006	006	006	006	006
38	0503011751	REDUCTION		006	006	006	006	006
39	0503010951	REDUCTION		004	004	004	004	004
40	0503010246	CLAMP		018	019	020	021	022
41	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		002	002	002	002	002
42	0503013816	5/16" LOCKNUT		002	002	002	002	002




Item	Code	Description	See page	QT
01	0511053046	RIGHT FRAME WITH AXLE WHEELED 6850	4	01
02	0511059288	CENTRAL FRAME WITH WHEELED AXLE 5750/6850/7860/8160	5	01
03	0511053047	LEFT FRAME WITH WHEELED AXLE 6850	6	01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0503011442	3/4" SPRING WASHER		18
06	0501010098	3/4" UNC BOLT		18
07	0571010094	SLEEVE FLANGE		06
08	0571013510	LOCK AXLE		02
09	0503030085	LOCK PIN		02
10	0571010095	FLAT WASHER		02
11	0521063003	LOCK PIN		02
12	0571010969	LOCK SLEEVE FRAME		02
13	0503013627	1.1/2 SPRING WASHER		02
14	0501010110	1.1/2" NUT		02
15	0502012698	CLAMP		04
16	0503011444	SPRING WASHER		04
17	0503010365	NUT		04
18	0521063912	PIVOT SHAFT		02
19	0581015857	GUTTER 24 X 50 X 1080		01
20	0581018001	GUTTER 24 X 50 X 980		02
21	0581017747	GUTTER 25 X 50 X 1200		02
22	0503010026	3/8" NUT		12
23	0503010025	3/8" SPRING WASHER		12
24	0501011643	3/8 X 1" BOLT		12



Item	Code	Description	See page	QT
01	0521063886	RIGHT FRAME		01
02	0521063872	ARTICLES AXLE RIGHT ROLLED		01
03	0521013199	LOWER BEARING SEMI		02
04	0503010899	5/8" X 2-1/4" BOLT		04
05	0501012140	FLAT WASHER		08
06	0531013922	0.6" X 0.8" X 1" SLEEVE		04
07	0503011445	SPRING WASHER		04
08	0503010013	5/8" NUT		04




Item	Code	Description	See page	QT
01	0521066916	CENTRAL CHASSIS		01
02	0521013199	LOWER BEARING SEMI		04
03	0503010899	5/8" X 2-1/4" BOLT		08
04	0501012140	FLAT WASHER		16
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503010013	5/8" NUT		08
08	0521063878	ARTICLE AXLE ROLLED		01




Item	Code	Description	See page	QT
01	0521063885	LEFT FRAME		01
02	0521063873	ARTICLES AXLE LEFT ROLLED		01
03	0521013199	LOWER BEARING SEMI		02
04	0503010899	5/8" X 2-1/4" BOLT		04
05	0501012140	FLAT WASHER		08
06	0531013922	0.6" X 0.8" X 1" SLEEVE		04
07	0503011445	SPRING WASHER		04
08	0503010013	5/8" NUT		04

PST JOINT FRAME


0511053196




Item	Code	Description	See page	QT
01	0511053188	RIGHT FRAME WITH WHEELED AXLE 7450	8	01
02	0511053189	LEFT FRAME WITH WHEELED AXLE 7450	9	01
03	0511053190	CENTRAL FRAME WITH WHEELED AXLE 10	10	01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0503011442	3/4" SPRING WASHER		18
06	0501010098	3/4" UNC BOLT		18
07	0571010094	SLEEVE FLANGE		06
08	0521063912	PIVOT SHAFT		02
09	0571013510	LOCK AXLE		02
10	0503030085	LOCK PIN		02
11	0571010095	FLAT WASHER		02
12	0503010365	NUT		04
13	0503011444	SPRING WASHER		04
14	0502012698	CLAMP		04
15	0501011643	3/8 X 1" BOLT		14
16	0503010025	3/8" SPRING WASHER		14
17	0503010026	3/8" NUT		14
18	0521063003	LOCK PIN		02
19	0571010969	LOCK SLEEVE FRAME		02
20	0503013627	1.1/2 SPRING WASHER		02
21	0501010110	1.1/2" NUT		02
22	0581018018	TROUGH 24 X 50 X 1255		02
23	0581018019	TROUGH 24 X 50 X 1070		02
24	0581015857	GUTTER 24 X 50 X 1080		02




Item	Code	Description	See page	QT
01	0521064009	RIGHT FRAME PST TRIO 15		01
02	0521064023	ARTICLES AXLE RIGHT ROLLED		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521064010	LEFT FRAME PST TRIO 15		01
02	0521064021	ARTICLES AXLE LEFT ROLLED		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521064011	CENTRAL FRAME PST TRIO 15		01
02	0521064022	CENTRAL ARTICLES AXLE ROLLED		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0511053135	RIGHT FRAME WITH WHEELED AXLE 7860	12	01
02	0511053136	LEFT FRAME WITH WHEELED AXLE 7860	13	01
03	0511059288	CENTRAL FRAME WITH WHEELED AXLE 5 5750/6850/7860/8160		01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0503011442	3/4" SPRING WASHER		18
06	0501010098	3/4" UNC BOLT		18
07	0571010094	SLEEVE FLANGE		06
08	0521063912	PIVOT SHAFT		02
09	0571013510	LOCK AXLE		02
10	0503030085	LOCK PIN		02
11	0571010095	FLAT WASHER		02
12	0503010365	NUT		04
13	0503011444	SPRING WASHER		04
14	0502012698	CLAMP		04
15	0501011643	3/8 X 1" BOLT		14
16	0503010025	3/8" SPRING WASHER		14
17	0503010026	3/8" NUT		14
18	0521063003	LOCK PIN		02
19	0571010969	LOCK SLEEVE FRAME		02
20	0503013627	1.1/2 SPRING WASHER		02
21	0501010110	1.1/2" NUT		02
22	0581016293	TROUGH 24 X 50 X 1420		02
23	0581017747	GUTTER 25 X 50 X 1200		02
24	0581015857	GUTTER 24 X 50 X 1080		02




Item	Code	Description	See page	QT
01	0521063971	FRAME BRACKET		01
02	0521063975	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521063972	FRAME BRACKET		01
02	0521063981	SIDE CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0511053766	RIGHT FRAME WITH WHEELED AXLE 7960/8160	15	01
02	0511053767	LEFT FRAME WITH WHEELED AXLE 7960/8160	16	01
03	0511053768	CENTRAL FRAME WITH WHEELED AXLE 5850/7960	17	01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0503011442	3/4" SPRING WASHER		18
06	0501010098	3/4" UNC BOLT		18
07	0571010094	SLEEVE FLANGE		06
08	0521063912	PIVOT SHAFT		02
09	0571013510	LOCK AXLE		02
10	0503030085	LOCK PIN		02
11	0571010095	FLAT WASHER		02
12	0503010365	NUT		04
13	0503011444	SPRING WASHER		04
14	0502012698	CLAMP		04
15	0521063003	LOCK PIN		02
16	0571010969	LOCK SLEEVE FRAME		02
17	0503013627	1.1/2 SPRING WASHER		02
18	0501010110	1.1/2" NUT		02
19	0591011141	CHANNEL 24 X 50 X 1050		02
20	0591011142	CHANNEL 24 X 50 X 1570		02
21	0591011140	24 X 50 X 1010 GUTTER		02
22	0503010026	3/8" NUT		14
23	0503010025	3/8" SPRING WASHER		14
24	0501011643	3/8 X 1" BOLT		14



Item	Code	Description	See page	QT
01	0521064287	FRAME BRACKET		01
02	0521064284	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521064286	FRAME BRACKET		01
02	0521064283	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06



Item	Code	Description	See page	QT
01	0521064281	CENTRAL FRONT FRAME		01
02	0521013199	LOWER BEARING SEMI		04
03	0503010899	5/8" X 2-1/4" BOLT		08
04	0501012140	FLAT WASHER		16
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503010013	5/8" NUT		08
08	0521064282	CARRYING-WHEELS PIVOT SHAFT		01

FRAME WITH SHAFT


0511059576




Item	Code	Description	See page	QT
01	0511053766	RIGHT FRAME WITH WHEELED AXLE 7960/8160	15	01
02	0511053767	LEFT FRAME WITH WHEELED AXLE 7960/8160	16	01
03	0511059288	CENTRAL FRAME WITH WHEELED AXLE 5750/6850/7860/8160		01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0503011442	3/4" SPRING WASHER	18	
06	0501010098	3/4" UNC BOLT	18	
07	0571010094	SLEEVE FLANGE	06	
08	0521063912	PIVOT SHAFT	02	
09	0571013510	LOCK AXLE	02	
10	0503030085	LOCK PIN	02	
11	0571010095	FLAT WASHER	02	
12	0521063003	LOCK PIN	02	
13	0571010969	LOCK SLEEVE FRAME	02	
14	0503013627	1.1/2 SPRING WASHER	02	
15	0501010110	1.1/2" NUT	02	
16	0502012698	CLAMP	04	
17	0503011444	SPRING WASHER	04	
18	0503010365	NUT	04	
19	0581018026	CENTRAL GUTTER	02	
20	0581015857	GUTTER 24 X 50 X 1080	02	
21	0581018027	1570 CENTRAL GUTTER	02	
22	0503010026	3/8" NUT	14	
23	0503010025	3/8" SPRING WASHER	14	
24	0501011643	3/8 X 1" BOLT	14	

ARTICULATION FRAME 8460


0511056311




Item	Code	Description	See page	QT
01	0511056312	RIGHT FRAME WITH WHEELED AXLE 8460	20	01
02	0511056313	LEFT FRAME WITH WHEELED AXLE 8460	21	01
03	0511053190	CENTRAL FRAME WITH WHEELED AXLE 6450/7285/7450/8460	10	01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0503011442	3/4" SPRING WASHER		16
06	0501010098	3/4" UNC BOLT		16
07	0571010094	SLEEVE FLANGE		06
08	0521063912	PIVOT SHAFT		02
09	0571013510	LOCK AXLE		02
10	0503030085	LOCK PIN		02
11	0571010095	FLAT WASHER		02
12	0503011442	3/4" SPRING WASHER		02
13	0501010098	3/4" UNC BOLT		02
14	0521063003	LOCK PIN		02
15	0571010969	LOCK SLEEVE FRAME		02
16	0503013627	1.1/2 SPRING WASHER		02
17	0502012698	CLAMP		04
18	0503010365	NUT		04
19	0503011444	SPRING WASHER		04
20	0501010110	1.1/2" NUT		02
21	0581017979	GUTTER		02
22	0581017935	GUTTER		02
23	0581018018	TROUGH 24 X 50 X 1255		02
24	0501011643	3/8 X 1" BOLT		12
25	0503010025	3/8" SPRING WASHER		12
26	0503010026	3/8" NUT		12




Item	Code	Description	See page	QT
01	0521065394	RIGHT CHASSIS		01
02	0521065222	SIDE ROD JOINT AXLE		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521065395	LEFT CHASSIS		01
02	0521065223	SHAFT SHAFT SHAFT SIDE SHAFT		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		05
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		10
03	0501012140	FLAT WASHER		10




Item	Code	Description	See page	QT
01	0521055231	655 WHEELED SUPPORT WITH TRANSMISSION	25	01
02	0521055234	WHEELED FASTENER	33	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0521055243	655 WHEELED BRACKET WITHOUT TRANSMISSION	26	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0521061566	CARRYING WHEEL ARM TRACTION		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0501058241	WHEEL SUPPORT CHAIN TENSIONER	27	01
07	0521055232	WHEEL WITH PNEU	28	01
08	0503018981	BOLT		02
09	0503010027	5/8" SPRING WASHER		04
10	0521012190	AXLE LOCK		01
11	0581011124	WHEELED COVER		01
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
13	0551017715	FLAT WASHER		02
14	0503013030	5/8" X 3.1/4" BOLT		01
15	0511050681	TRACTION SPRING		01
15A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
15B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0521061566	CARRYING WHEEL ARM TRACTION		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0503018981	BOLT		02
07	0503010027	5/8" SPRING WASHER		02
08	0521012190	AXLE LOCK		02
09	0521055239	WHEEL WITH TIRE WITHOUT TRANSMISSION	29	01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	30	01
02	0521055233	WHEELED TRANSMISSION WITHOUT TIRE	31	01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	30	01
02	0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	32	01



Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0521012185	TRANSM AXLE CARRYING-WHEEL		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0502011339	15Z GEAR P 1.25"		01
09	0503012550	5/16" X 3/4" BOLT		06
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521012185	TRANSM AXLE CARRYING-WHEEL		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01

WHEELED FASTENER


0521055234




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0521055236	INTERMEDIARY CURRENT STRETCHER	34	01
07	0521055237	WHEEL FIXED CURRENT STRETCHER	35	01
08	0521055235	WHEEL MOBILE CURRENT STRETCHER	36	01



Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
02	0551018245	CHAIN TENSIONER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0551018239	SLEEVE 19 X 13,50 X 45		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
02	0551018252	CHAIN TIGHTENER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
02	0551018244	CHAIN UPPER AXLE		01
03	0591017923	GLOVE 15.30 X 30 X 32		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01


HEADER FULL ASSEMBLY

0909095199




Item	Code	Description	See page	6850	7450	7860	7960	8160	8460
01	0521066289	FRONT HEADER 5750/6350/6850		001	001	001	001	001	001
02	0521066290	INTERMEDIATE HEAD 5750/6850/7860/8160		001	000	001	000	001	000
02..	0521067075	INTERMEDIATE HEAD 6450/7285/7350/7450/8460		000	001	000	000	000	001
02..	0521067151	INTERMEDIATE HEAD 5850/7960		000	000	000	001	000	000
03	0571019949	JUNCTION SHAFT		006	006	006	006	006	006
04	0503030119	LOCK PIN		010	010	010	010	010	010
05	0511055096	TRACTOR HITCH	39	001	001	001	001	001	001
06	0511053179	TRACTOR COUPLING SHAFT		001	001	001	001	001	001
06A	0521064036	TRACTOR HITCH AXLE		001	001	001	001	001	001
06B	0503030012	HAIR PIN		001	001	001	001	001	001
07	0503014120	CHAIN		001	001	001	001	001	001
08	0521051614	TURNBUCKLE SIDE UPPER	40	002	002	002	002	002	002
09	0521010571	COUPLING SHAFT		004	004	004	004	004	004
10	0503030085	LOCK PIN		006	006	006	006	006	006
11	0521050133	TURNBUCKLE SIDE 755/480	42	002	002	002	002	002	002
12	0571019951	JUNCTION SHAFT		003	003	003	003	003	003
13	0503010523	1/4" X 2" COTTERPIN		004	004	004	004	004	004
14	0503034772	BOX		001	001	001	001	001	001
15	0521068652	TOOLS BOX SUPPORT		001	001	001	001	001	001
16	0501011643	3/8 X 1" BOLT		004	004	004	004	004	004
17	0503010025	3/8" SPRING WASHER		004	004	004	004	004	004
18	0503010026	3/8" NUT		004	004	004	004	004	004
19	0581017000	PLATE INTERMEDIARY		002	002	002	002	002	002
20	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		004	004	004	004	004	004
21	0503010025	3/8" SPRING WASHER		004	004	004	004	004	004
22	0501010984	FLAT WASHER		004	004	004	004	004	004
23	0503014321	CABLE STEEL SHACKLE		002	002	002	002	002	002
24	0502010584	CARRYING-WHEELS SUPPORT FIXER		008	008	008	008	008	008
25	0503016485	BOLT 3/4		016	016	016	016	016	016
26	0501010322	FLAT WASHER		032	032	032	032	032	032
27	0503010152	3/4" SELF LOCKING NUT		016	016	016	016	016	016

Item	Code	Description	See page	6850	7450	7860	7960	8160	8460
28	0521067716	FIXER TUBE		004	004	004	004	004	004
29	0511059237	3 POINT TURNBUCKLE	44	001	001	001	001	001	001
30	0571019950	COUPLING SHAFT		001	001	001	001	001	001
31	0521045756	HYDRAULIC CYLINDER	45	001	001	001	001	001	001
32	0521010779	31.75 X 95 COUPLING SHAFT		001	001	001	001	001	001
33	0521010581	0.9" X 4.9" COUPLING SHAFT		001	001	001	001	001	001
34	0531016049	FLAT WASHER		002	002	002	002	002	002
35	0503014820	BLACK WATER RESERVOIR		001	001	001	001	001	001
36	0521068651	SUPPORT BOX		001	001	001	001	001	001




Item	Code	Description	See page	8960	9460	9960	10460	10985
01	0521067838	FRONT HEADER 9460/10460/10985		000	001	000	001	001
01.	0521068119	FRONT HEADER 8960/9960		001	000	001	000	000
02	0521067839	INTERMEDIATE HEAD 9460/10460/10985		000	001	000	001	001
02.	0521068118	INTERMEDIATE HEAD 8960/9960		001	000	001	000	000
03	0571019949	JUNCTION SHAFT		006	006	006	006	006
04	0503030119	LOCK PIN		010	010	010	010	010
05	0511055096	TRACTOR HITCH	39	001	001	001	001	001
06	0511053179	TRACTOR COUPLING SHAFT		001	001	001	001	001
06A	0521064036	TRACTOR HITCH AXLE		001	001	001	001	001
06B	0503030012	HAIR PIN		001	001	001	001	001
07	0503014120	CHAIN		001	001	001	001	001
08	0521050574	EXTENSOR	41	002	002	002	002	002
09	0521010571	COUPLING SHAFT		004	004	004	004	004
10	0503030085	LOCK PIN		006	006	006	006	006
11	0521050681	LATERAL EXTENSOR 1250/480	43	002	002	002	002	002
12	0571019951	JUNCTION SHAFT		003	003	003	003	003
13	0503010523	1/4" X 2" COTTERPIN		004	004	004	004	004
14	0503034772	BOX		001	001	001	001	001
15	0521068652	TOOLS BOX SUPPORT		001	001	001	001	001
16	0501011643	3/8 X 1" BOLT		004	004	004	004	004
17	0503010025	3/8" SPRING WASHER		004	004	004	004	004
18	0503010026	3/8" NUT		004	004	004	004	004
19	0581017000	PLATE INTERMEDIARY		002	002	002	002	002
20	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		004	004	004	004	004
21	0503010025	3/8" SPRING WASHER		004	004	004	004	004
22	0501010984	FLAT WASHER		004	004	004	004	004
23	0503014321	CABLE STEEL SHACKLE		002	002	002	002	002
24	0502010584	CARRYING-WHEELS SUPPORT FIXER		008	008	008	008	008
25	0503016485	BOLT 3/4		016	016	016	016	016
26	0501010322	FLAT WASHER		032	032	032	032	032
27	0503010152	3/4" SELF LOCKING NUT		016	016	016	016	016


Item	Code	Description	See page	8960	9460	9960	10460	10985
28	0521067716	FIXER TUBE		002	004	002	004	004
28.	0521068136	FIXER INTERMEDIATE HEAD		002	000	002	000	000
29	0511059237	3 POINT TURNBUCKLE	44	001	001	001	001	001
30	0571019950	COUPLING SHAFT		001	001	001	001	001
31	0521045756	HYDRAULIC CYLINDER	45	001	001	001	001	001
32	0521010779	31.75 X 95 COUPLING SHAFT		001	001	001	001	001
33	0521010581	0.9" X 4.9" COUPLING SHAFT		001	001	001	001	001
34	0531016049	FLAT WASHER		002	002	002	002	002
35	0503014820	BLACK WATER RESERVOIR		001	001	001	001	001
36	0521068651	SUPPORT BOX		001	001	001	001	001




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	COMPRESSION SPRING LEFT		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0502011195	ADJUSTMENT NUT BODY		01
02	0521068096	EXTENSOR R.1.1 / 2 UNC RIGHT		01
03	0521068095	EXTENSOR R.1.1/2 UNC LEFT		01
04	0541018672	COUNTERNUT		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521066300	RIGHT TURNBUCKLE		01
02	0503010002	1800 GREASE FITTING		02
03	0521066301	LEFT TURNBUCKLE		01
04	0541018672	COUNTERNUT		01
05	0502011195	ADJUSTMENT NUT BODY		01




Item	Code	Description	See page	QT
01	0521065193	TURNBUCKLE AXLE		01
02	0521067392	FIXED BRACKET		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0521067393	EXTERNAL SIDE EAR		01
06	0571019949	JUNCTION SHAFT		01
07	0503030119	LOCK PIN		01
08	0503010002	1800 GREASE FITTING		03




Item	Code	Description	See page	QT
01	0521065193	TURNBUCLE AXLE		01
02	0521067661	1250 SIDE EXTENSION FIXED TIP		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0521067393	EXTERNAL SIDE EAR		01
06	0571019949	JUNCTION SHAFT		01
07	0503030119	LOCK PIN		01
08	0503010002	1800 GREASE FITTING		03




Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0511061880	SIDE RIGHT RATCHET		01
03	0511061881	RATCHET FOLLOWER		01
04	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
05	0503011179	3/8" X 2-1/4" BOLT		05
06	0503010025	3/8" SPRING WASHER		05
07	0503010026	3/8" NUT		05
08	0503010002	1800 GREASE FITTING		02
09	0531010264	SIDE RATCHET		01
10	0521066919	3-POINT EXTENSOR RIGHT FUSE		01
11	0521066337	LEFT EXTENSOR 3 SPIKE		01



Item	Code	Description	See page	QT
01	0511057653	HYDRAULIC CYLINDER	46	01
02	0501053835	FEMALE QUICK COUPLER	53	02




Item	Code	Description	See page	QT
01	0521066550	CASE		01
02	0521066551	EXTENSION DRAWBAR		01
03	0503010002	1800 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010669	EMBOLUS 63.50 X 40 USAP		01
06	0503018005	RING		01
07	0503010558	7/8" NUT		01
08	0502010471	MOBILE COVER		01
09	0503011058	8-330 BACK-UP RING		01
10	0571019866	RING SUPPORT		01
11	0503010163	D-1500 SCRAPER RING		01
12	0503018004	RING		01
13	0503010161	2-330 N 3006 9B O'RING		01
14	0503018003	GASKET		01
15	0503010605	O'RING		01
16	0581010652	JIC ADAPTER		01




Item	Code	Description	See page	QT
01	0591019605	FLUXO DIVIDER VALVE SUPPORT		01
01.	0591019604	VALVE SUPPORT		01
02	0511059290	VALVE ASSEMBLY	52	01
03	0501053835	FEMALE QUICK COUPLER	53	02
04	0501010984	FLAT WASHER		04
05	0531011180	UPPER BODY CLIP		04
06	0521066564	DUCT SEAL OIL		01
07	0531013922	0.6" X 0.8" X 1" SLEEVE		02
08	0503011179	3/8" X 2-1/4" BOLT		02
09	0503010025	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0502012702	BODY SUPPORT CLAMP		12
12	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
13	0501053834	MALE QUICK COUPLER	54	04
14	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		04
15	0503010244	7/16" NUT		04
16	0503010180	7/16" SPRING WASHER		08
17	0503010920	1/2" X 1.1/2" BOLT		02
18	0511017302	FLAT WASHER		02
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2" NUT		02
21	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
22	0571017774	SPRING PROTECTION QUICK HOSE		01
23	0511059418	HYDRAULIC SYSTEM HOSE ASSEMBLY		01
23A	0501080406	3/8" X 23" TR-TC HOSE		01
23B	0501080150	3/8 X 800 TR-TC HOSE		01
23C	0501081930	HOSE		01
23D	0501081646	TC-TC HOSE ASSY		03
24	0521052484	HOSE 1/2 X 4122 TM-TM BLACK / RED		01
24A	0501080881	HOSE		01
24B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02

Item	Code	Description	See page	QT
24C	0503034495	HYDRAULIC HOSE GRIP (RED)		02
24D	0503018952	PLASTIC BOLT		12
25	0521052485	HOSE 1/2 X 4122 TM-TM BLACK / BLUE		01
25A	0501080881	HOSE		01
25B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
25C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		02
25D	0503018952	PLASTIC BOLT		12




Item	Code	Description	See page	QT
01	0571013472	FIXER BODY VALVE		01
02	0511059290	VALVE ASSEMBLY	52	01
03	0501053835	FEMALE QUICK COUPLER	53	02
04	0501010984	FLAT WASHER		04
05	0531011180	UPPER BODY CLIP		04
06	0521066564	DUCT SEAL OIL		01
07	0531013922	0.6" X 0.8" X 1" SLEEVE		02
08	0503011179	3/8" X 2-1/4" BOLT		02
09	0503010025	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0502012702	BODY SUPPORT CLAMP		12
12	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
13	0501053834	MALE QUICK COUPLER	54	04
14	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		04
15	0503010244	7/16" NUT		04
16	0503010180	7/16" SPRING WASHER		08
17	0503010920	1/2" X 1.1/2" BOLT		02
18	0511017302	FLAT WASHER		02
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2" NUT		02
21	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
22	0571017774	SPRING PROTECTION QUICK HOSE		01
23	0511059418	HYDRAULIC SYSTEM HOSE ASSEMBLY		01
23A	0501080406	3/8" X 23" TR-TC HOSE		01
23B	0501080150	3/8 X 800 TR-TC HOSE		01
23C	0501080392	3/8 X 3300 TR-TC HOSE		01
23D	0501080442	3/8" X 130" TC-TC HOSE ASSY		03
24	0521052484	HOSE 1/2 X 4122 TM-TM BLACK / RED		01
24A	0501080881	HOSE		01
24B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
24C	0503034495	HYDRAULIC HOSE GRIP (RED)		02

Item	Code	Description	See page	QT
24D	0503018952	PLASTIC BOLT		12
25	0521052485	HOSE 1/2 X 4122 TM-TM BLACK / BLUE		01
25A	0501080881	HOSE		01
25B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
25C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		02
25D	0503018952	PLASTIC BOLT		12




Item	Code	Description	See page	QT
01	0571013472	FIXER BODY VALVE		01
02	0511059290	VALVE ASSEMBLY	52	01
03	0501053835	FEMALE QUICK COUPLER	53	02
04	0501010984	FLAT WASHER		04
05	0531011180	UPPER BODY CLIP		08
06	0521066564	DUCT SEAL OIL		01
07	0531013922	0.6" X 0.8" X 1" SLEEVE		02
08	0503011179	3/8" X 2-1/4" BOLT		02
09	0503010025	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0502012702	BODY SUPPORT CLAMP		14
12	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		02
13	0503011271	3/4" UNF "T" CONNECTION T 3 SIDES		06
14	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		04
15	0503010244	7/16" NUT		04
16	0503010180	7/16" SPRING WASHER		08
17	0503010920	1/2" X 1.1/2" BOLT		02
18	0511017302	FLAT WASHER		02
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2" NUT		02
21	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
22	0571017774	SPRING PROTECTION QUICK HOSE		01
23	0503010851	7/16" X 3.1/2" BOLT		02
24	0501053834	MALE QUICK COUPLER	54	04
25	0521052894	HYDRAULIC SYSTEM HOSE ASSEMBLY		01
25A	0501082077	TR-TM HOSE ASSY		01
25B	0501080445	TR-TM HOSE ASSY		03
25C	0501080199	3/8" X 13.4" TC-TC HOSE ASSY		02
25D	0501080373	TR-TR HOSE ASSY		02
25E	0501080302	TR-TC HOSE ASSY		02
25F	0501080025	3/8 X 1400 TR-TC HOSE		02

Item	Code	Description	See page	QT
25G	0501080056	3/8" X 1700 TR-TC HOSE ASSY		02
25H	0501081607	HOSE 3/8 X 2450 TC-TR		03
25I	0501080452	3/8" X 98" TR-TR HOSE		01
26	0521052663	HOSE 1/2 X 5500 TM-TM BLACK / RED		01
26A	0501081359	1/2 X 5500 TM-TM HOSE ASSY		01
26B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
26C	0503034495	HYDRAULIC HOSE GRIP (RED)		02
26D	0503018952	PLASTIC BOLT		12
27	0521052664	HOSE 1/2 X 5500 TM-TM BLACK / BLUE		01
27A	0501081359	1/2 X 5500 TM-TM HOSE ASSY		01
27B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
27C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		02
27D	0503018952	PLASTIC BOLT		12




Item	Code	Description	See page	QT
01	0571013472	FIXER BODY VALVE		01
02	0511059290	VALVE ASSEMBLY	52	01
03	0501053835	FEMALE QUICK COUPLER	53	02
04	0501010984	FLAT WASHER		04
05	0531011180	UPPER BODY CLIP		08
06	0521066564	DUCT SEAL OIL		01
07	0531013922	0.6" X 0.8" X 1" SLEEVE		02
08	0503011179	3/8" X 2-1/4" BOLT		02
09	0503010025	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0502012702	BODY SUPPORT CLAMP		14
12	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		02
13	0503011271	3/4" UNF "T" CONNECTION T 3 SIDES		06
14	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		04
15	0503010244	7/16" NUT		04
16	0503010180	7/16" SPRING WASHER		08
17	0503010920	1/2" X 1.1/2" BOLT		02
18	0511017302	FLAT WASHER		02
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2" NUT		02
21	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
22	0571017774	SPRING PROTECTION QUICK HOSE		01
23	0503010851	7/16" X 3.1/2" BOLT		02
24	0501053834	MALE QUICK COUPLER	54	04
25	0521052878	HOSE KIT SYSTEM HYDRAULIC		01
25A	0501082077	TR-TM HOSE ASSY		01
25B	0501080445	TR-TM HOSE ASSY		03
25C	0501080199	3/8" X 13.4" TC-TC HOSE ASSY		02
25D	0501080373	TR-TR HOSE ASSY		02
25E	0501080302	TR-TC HOSE ASSY		02
25F	0501081796	3/8" X 1650 TR-TC HOSE		02

Item	Code	Description	See page	QT
25G	0501080212	3/8 X 1930 TR-TC HOSE ASSY		02
25H	0501080401	3/8" X 106" TR-TC HOSE		03
25I	0501080296	3/8" X 106" TR-TR HOSE		01
26	0521052663	HOSE 1/2 X 5500 TM-TM BLACK / RED		01
26A	0501081359	1/2 X 5500 TM-TM HOSE ASSY		01
26B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
26C	0503034495	HYDRAULIC HOSE GRIP (RED)		02
26D	0503018952	PLASTIC BOLT		12
27	0521052664	HOSE 1/2 X 5500 TM-TM BLACK / BLUE		01
27A	0501081359	1/2 X 5500 TM-TM HOSE ASSY		01
27B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
27C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		02
27D	0503018952	PLASTIC BOLT		12




Item	Code	Description	See page	QT
01	0571013472	FIXER BODY VALVE		01
02	0511059290	VALVE ASSEMBLY	52	01
03	0501053835	FEMALE QUICK COUPLER	53	02
04	0501010984	FLAT WASHER		04
05	0531011180	UPPER BODY CLIP		08
06	0521066564	DUCT SEAL OIL		01
07	0531013922	0.6" X 0.8" X 1" SLEEVE		02
08	0503011179	3/8" X 2-1/4" BOLT		02
09	0503010025	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0502012702	BODY SUPPORT CLAMP		14
12	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		02
13	0503011271	3/4" UNF "T" CONNECTION T 3 SIDES		06
14	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		04
15	0503010244	7/16" NUT		04
16	0503010180	7/16" SPRING WASHER		08
17	0503010920	1/2" X 1.1/2" BOLT		02
18	0511017302	FLAT WASHER		02
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2" NUT		02
21	0571017774	SPRING PROTECTION QUICK HOSE		01
22	0503010851	7/16" X 3.1/2" BOLT		02
23	0501053834	MALE QUICK COUPLER	54	04
24	0521052951	HYDRAULIC CIRCUIT ASSEMBLY		01
24A	0501082077	TR-TM HOSE ASSY		01
24B	0501080445	TR-TM HOSE ASSY		03
24C	0501080199	3/8" X 13.4" TC-TC HOSE ASSY		02
24D	0501080221	3/8" X 25.6 TR-TR HOSE ASSY		02
24E	0501080328	3/8" X 29" TR-TC HOSE		02
24F	0501080150	3/8 X 800 TR-TC HOSE		02
24G	0501080485	3/8 X 1100 TR-TC HOSE		02


Item	Code	Description	See page	QT
24H	0501081718	HOSE		03
24I	0501081731	3/8 X 3550 TR-TR HOSE		01
25	0521052663	HOSE 1/2 X 5500 TM-TM BLACK / RED		01
25A	0501081359	1/2 X 5500 TM-TM HOSE ASSY		01
25B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		02
25D	0503018952	PLASTIC BOLT		12
26	0521052664	HOSE 1/2 X 5500 TM-TM BLACK / BLUE		01
26A	0501081359	1/2 X 5500 TM-TM HOSE ASSY		01
26B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		02
26D	0503018952	PLASTIC BOLT		12




Item	Code	Description	See page	QT
01	0503016524	DIVIDER VALVE		01
02	0581011593	NIPPLE R.1.1/16 UN		01
03	0511010111	7/8" NIPPLE		03
04	0503011109	2-119 N 3006-9B O'RING		01
05	0503010045	O'RING		03



Item	Code	Description	See page	QT
01	0503011883	QUICK CONNECTION COVER		01
02	0503011628	FEMALE QUICK COUPLER		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521052712	SILO FERTILIZER RIGHT SUPPORT 6850	56	01
02	0521052721	SILO FERTILIZER LEFT SUPPORT 6850	57	01
03	0521052734	SUPPORT SILO CENTRAL FERTILIZER 6850/7860	68	01
04	0501010984	FLAT WASHER		40
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0503062391	FERTILIZER BOX		03
09	0571019051	FIXER BOX WASHER		24
10	0503013751	3/8 UNC X 1.1/4 BOLT		24
11	0503012535	3/8" SPRING WASHER		24
12	0503012531	3/8" INOX NUT		24
13	0503011957	NYLON LUG		02
14	0503010371	5/16" X 1" BOLT		04
15	0503010179	LOCK WASHER		08
16	0503010337	5/16" NUT		08
17	0501010694	FLAT WASHER		04
18	0503011953	5/16" X 1" BOLT		04
19	0551019168	SLEEVE		02
20	0551019160	LEVER		02
21	0551019167	SLEEVE UNION		02
22	0511017302	FLAT WASHER		06
23	0503010479	BOLT		02
24	0503011336	1/2" HEX SELF ADJUSTING NUT		06
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
26	0503010019	1/2" SPRING WASHER		02
27	0503010060	1/2" NUT		02
28	0501013518	FLAT WASHER		06
29	0503010140	1/8" X 3/4" COTTERPIN		06
30	0511069678	LH LOWER LEVER		02
31	0561016468	FASTENER		02


Item	Code	Description	See page	QT
32	0581012605	GEAR BOX LEVER LOCK		02
33	0521061741	INNER LEVER		02
34	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	58	01
35	0551019159	LEVER FIXER BODY		02
36	0503034396	FERTILIZER SIDE COVER		15
37	0503010362	1/8" X 1.1/4" COTTERPIN		15
38	0521050195	SILO FERTILIZER LEFT SQUARE AXLE	59	01
39	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	60	02




Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	02
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	03
03	0501010942	3/8" X 1-1/4" BOLT		20
04	0503011443	3/8" SPRING WASHER		20
05	0503010026	3/8" NUT		20
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0501053788	3/4 SQUARE AXLE FASTENER	96	01
11	0501110392	SILO SUPPORT BEARING		01
12	0521012485	GEAR BOX BEARING AGRICUTURAL		01
13	0503011953	5/16" X 1" BOLT		02
14	0521011039	FLAT WASHER		02
15	0503011444	SPRING WASHER		02
16	0503010337	5/16" NUT		02
17	0503010003	1845 GREASE FITTING		01
18	1902010685	18Z CONICAL GEAR		05
19	0503030275	AGRICULTURAL BEARING		05
20	0581016972	AXIS Q 3/4 X 1953		01
21	0521068605	SUPPORT RIGHT SILO FERTILIZER		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521068615	LEFT SILO FERTILIZER SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0501053788	3/4 SQUARE AXLE FASTENER	96	01
12	0501110392	SILO SUPPORT BEARING		01
13	0521012485	GEAR BOX BEARING AGRICUTURAL		01
14	0503011953	5/16" X 1" BOLT		02
15	0521011039	FLAT WASHER		02
16	0503011444	SPRING WASHER		02
17	0503010337	5/16" NUT		02
18	0503010003	1845 GREASE FITTING		01
19	1902010685	18Z CONICAL GEAR		05
20	0503030275	AGRICULTURAL BEARING		05
21	0581016972	AXIS Q 3/4 X 1953		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0581013322	BEARING RIGHT SUPPORT		01
02	0503011953	5/16" X 1" BOLT		04
03	0501010984	FLAT WASHER		02
04	0501010694	FLAT WASHER		04
05	0503013816	5/16" LOCKNUT		04
06	0501056444	BEARING WITH ROLLING	116	01



Item	Code	Description	See page	QT
01	0581013324	BEARING LEFT SUPPORT		01
02	0503011953	5/16" X 1" BOLT		04
03	0501010984	FLAT WASHER		02
04	0501010694	FLAT WASHER		04
05	0503013816	5/16" LOCKNUT		04
06	0501056444	BEARING WITH ROLLING	116	01




Item	Code	Description	See page	QT
01	0503030331	1.2" X 1.2" X 12.2" HOSE		01
02	0503010243	CLAMP		02
03	0503062755	TRANSMISSION AXLE		01
04	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
05	0503012880	1/4" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521052620	SUPPORT SILO RIGHT FERTILIZER WITH DISTRIBUTOR 7450	62	01
02	0521052621	SILO SUPPORT LEFT FERTILIZER WITH DISTRIBUTOR 7450	63	01
03	0521051607	SUPPORT SILO CENTRAL FERTILIZER 6450/7285/7450/8460	64	01
04	0501010984	FLAT WASHER		40
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0503062391	FERTILIZER BOX		02
09	0571019051	FIXER BOX WASHER		26
10	0503013751	3/8 UNC X 1.1/4 BOLT		26
11	0503012535	3/8" SPRING WASHER		26
12	0503012531	3/8" INOX NUT		26
13	0503011957	NYLON LUG		02
14	0503010371	5/16" X 1" BOLT		04
15	0503010179	LOCK WASHER		08
16	0503010337	5/16" NUT		08
17	0501010694	FLAT WASHER		04
18	0503011953	5/16" X 1" BOLT		04
19	0551019168	SLEEVE		02
20	0551019160	LEVER		02
21	0551019167	SLEEVE UNION		02
22	0511017302	FLAT WASHER		06
23	0503010479	BOLT		02
24	0503011336	1/2" HEX SELF ADJUSTING NUT		06
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
26	0503010019	1/2" SPRING WASHER		02
27	0503010060	1/2" NUT		02
28	0501013518	FLAT WASHER		06
29	0503010140	1/8" X 3/4" COTTERPIN		06


Item	Code	Description	See page	QT
30	0511069678	LH LOWER LEVER		02
31	0561016468	FASTENER		02
32	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	60	02
33	0581012605	GEAR BOX LEVER LOCK		02
34	0521061741	INNTER LEVER		02
35	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	58	01
36	0551019159	LEVER FIXER BODY		02
37	0503034396	FERTILIZER SIDE COVER		15
38	0503010362	1/8" X 1.1/4" COTTERPIN		15
39	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		01
40	0521050195	SILO FERTILIZER LEFT SQUARE AXLE	59	01




Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	02
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	03
03	0501010942	3/8" X 1-1/4" BOLT		20
04	0503011443	3/8" SPRING WASHER		20
05	0503010026	3/8" NUT		20
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0501053788	3/4 SQUARE AXLE FASTENER	96	01
11	0501110392	SILO SUPPORT BEARING		01
12	0503030275	AGRICULTURAL BEARING		05
13	0503011953	5/16" X 1" BOLT		02
14	0521011039	FLAT WASHER		02
15	0503011444	SPRING WASHER		02
16	0503010337	5/16" NUT		02
17	0503010003	1845 GREASE FITTING		01
18	1902010685	18Z CONICAL GEAR		05
19	0521012485	GEAR BOX BEARING AGRICUTURAL		01
20	0581018078	SQUARE AXLE 3/4 X 1944.5		01
21	0521069062	SILO FERTILIZER RIGHT SUPPORT		01
22	0503013816	5/16" LOCKNUT		02



Item	Code	Description	See page	QT
01	0521068563	LEFT SILO FERTILIZER SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0501053788	3/4 SQUARE AXLE FASTENER	96	01
12	0501110392	SILO SUPPORT BEARING		01
13	0521012485	GEAR BOX BEARING AGRICUTURAL		01
14	0503011953	5/16" X 1" BOLT		02
15	0521011039	FLAT WASHER		02
16	0503011444	SPRING WASHER		02
17	0503010337	5/16" NUT		02
18	0503010003	1845 GREASE FITTING		01
19	1902010685	18Z CONICAL GEAR		05
20	0503030275	AGRICULTURAL BEARING		05
21	0581016776	SQUARE AXLE 3/4 X 2028		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521068089	SUPPORT CENTRAL SILO FERTILIZER		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0581016973	SQUARE AXLE 3/4 X 790		01
08	0571019828	LOCK AXLE		02
09	0503010365	NUT		04
10	1902010685	18Z CONICAL GEAR		05
11	0503030275	AGRICULTURAL BEARING		05
12	0503013816	5/16" LOCKNUT		04
13	0511062163	FERTILIZER BEAM LOWER COVER		01
14	0501010984	FLAT WASHER		04
15	0501011643	3/8 X 1" BOLT		04
16	0581016950	SQUARE AXLE 3/4 X 1115		01




Item	Code	Description	See page	QT
01	0521052710	SUPPORT SILO RIGHT FERTILIZER WITH DISTRIBUTOR 7860	66	01
02	0521052719	SILO SUPPORT LEFT FERTILIZER WITH DISTRIBUTOR 7860	67	01
03	0521052734	SUPPORT SILO CENTRAL FERTILIZER 6850/7860	68	01
04	0501010984	FLAT WASHER		40
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0503062391	FERTILIZER BOX		01
09	0571019051	FIXER BOX WASHER		28
10	0503013751	3/8 UNC X 1.1/4 BOLT		28
11	0503012535	3/8" SPRING WASHER		28
12	0503012531	3/8" INOX NUT		28
13	0503011957	NYLON LUG		02
14	0503010371	5/16" X 1" BOLT		04
15	0503010179	LOCK WASHER		08
16	0503010337	5/16" NUT		08
17	0501010694	FLAT WASHER		04
18	0503011953	5/16" X 1" BOLT		04
19	0551019168	SLEEVE		02
20	0551019160	LEVER		02
21	0551019167	SLEEVE UNION		02
22	0511017302	FLAT WASHER		06
23	0503010479	BOLT		02
24	0503011336	1/2" HEX SELF ADJUSTING NUT		06
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
26	0503010019	1/2" SPRING WASHER		02
27	0503010060	1/2" NUT		02
28	0501013518	FLAT WASHER		06
29	0503010140	1/8" X 3/4" COTTERPIN		06
30	0511069678	LH LOWER LEVER		02


Item	Code	Description	See page	QT
31	0561016468	FASTENER		02
32	0581012605	GEAR BOX LEVER LOCK		02
33	0521061741	INNTER LEVER		02
34	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	58	01
35	0551019159	LEVER FIXER BODY		02
36	0503034396	FERTILIZER SIDE COVER		17
37	0503010362	1/8" X 1.1/4" COTTERPIN		17
38	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		02
39	0521050195	SILO FERTILIZER LEFT SQUARE AXLE	59	01
40	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	60	02




Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	05
03	0501010942	3/8" X 1-1/4" BOLT		24
04	0503011443	3/8" SPRING WASHER		24
05	0503010026	3/8" NUT		24
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0501053788	3/4 SQUARE AXLE FASTENER	96	01
11	0501110392	SILO SUPPORT BEARING		01
12	0521012485	GEAR BOX BEARING AGRICUTURAL		01
13	0503011953	5/16" X 1" BOLT		02
14	0521011039	FLAT WASHER		02
15	0503011444	SPRING WASHER		02
16	0503010337	5/16" NUT		02
17	0503010003	1845 GREASE FITTING		01
18	1902010685	18Z CONICAL GEAR		06
19	0503030275	AGRICULTURAL BEARING		06
20	0581016968	SQUARE AXLE 3/4 X 2462		01
21	0521068603	SUPPORT RIGHT SILO FERTILIZER		01
22	0503013816	5/16" LOCKNUT		02



Item	Code	Description	See page	QT
01	0521068613	LEFT SILO FERTILIZER SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	05
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	01
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503011443	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0501053788	3/4 SQUARE AXLE FASTENER	96	01
12	0501110392	SILO SUPPORT BEARING		01
13	0521012485	GEAR BOX BEARING AGRICUTURAL		01
14	0503011953	5/16" X 1" BOLT		02
15	0521011039	FLAT WASHER		02
16	0503011444	SPRING WASHER		02
17	0503010337	5/16" NUT		02
18	0503010003	1845 GREASE FITTING		01
19	1902010685	18Z CONICAL GEAR		06
20	0503030275	AGRICULTURAL BEARING		06
21	0581016968	SQUARE AXLE 3/4 X 2462		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521066913	CENTER FERTILIZER SILO SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	02
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	03
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0581016971	AXIS Q 3/4 X 1063		01
08	0571019828	LOCK AXLE		02
09	0503010365	NUT		04
10	1902010685	18Z CONICAL GEAR		05
11	0503030275	AGRICULTURAL BEARING		05
12	0503013816	5/16" LOCKNUT		04
13	0581016970	AXIS Q 3/4 X 763		01




Item	Code	Description	See page	QT
01	0521052711	SUPPORT SILO RIGHT FERTILIZER WITH 70 DISTRIBUTOR 7860/7960	01	01
02	0521052720	SILO SUPPORT LEFT FERTILIZER WITH 71 DISTRIBUTOR 7820/7960	01	01
03	0521052732	SUPPORT SILO CENTRAL FERTILIZER WITH 72 DISTRIBUTOR 7960	01	01
04	0501010984	FLAT WASHER		40
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0503062391	FERTILIZER BOX		01
09	0571019051	FIXER BOX WASHER		28
10	0503013751	3/8 UNC X 1.1/4 BOLT		28
11	0503012535	3/8" SPRING WASHER		28
12	0503012531	3/8" INOX NUT		28
13	0503011957	NYLON LUG		02
14	0503010371	5/16" X 1" BOLT		04
15	0503010179	LOCK WASHER		08
16	0503010337	5/16" NUT		08
17	0501010694	FLAT WASHER		04
18	0503011953	5/16" X 1" BOLT		04
19	0551019168	SLEEVE		02
20	0551019160	LEVER		02
21	0551019167	SLEEVE UNION		02
22	0511017302	FLAT WASHER		06
23	0503010479	BOLT		02
24	0503011336	1/2" HEX SELF ADJUSTING NUT		06
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
26	0503010019	1/2" SPRING WASHER		02
27	0503010060	1/2" NUT		02
28	0501013518	FLAT WASHER		06
29	0503010140	1/8" X 3/4" COTTERPIN		06


Item	Code	Description	See page	QT
30	0511069678	LH LOWER LEVER		02
31	0561016468	FASTENER		02
32	0581012605	GEAR BOX LEVER LOCK		02
33	0521061741	INNTER LEVER		02
34	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	58	01
35	0551019159	LEVER FIXER BODY		02
36	0503034396	FERTILIZER SIDE COVER		16
37	0503010362	1/8" X 1.1/4" COTTERPIN		16
38	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		02
39	0521050195	SILO FERTILIZER LEFT SQUARE AXLE	59	01
40	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	60	02




Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	05
03	0501010942	3/8" X 1-1/4" BOLT		24
04	0503011443	3/8" SPRING WASHER		24
05	0503010026	3/8" NUT		24
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0501053788	3/4 SQUARE AXLE FASTENER	96	01
11	0501110392	SILO SUPPORT BEARING		01
12	0521012485	GEAR BOX BEARING AGRICUTURAL		01
13	0503011953	5/16" X 1" BOLT		02
14	0521011039	FLAT WASHER		02
15	0503011444	SPRING WASHER		02
16	0503010337	5/16" NUT		02
17	0503010003	1845 GREASE FITTING		01
18	1902010685	18Z CONICAL GEAR		06
19	0503030275	AGRICULTURAL BEARING		06
20	0581016969	SQUARE AXLE 3/4 X 2485		01
21	0521068604	SUPPORT RIGHT SILO FERTILIZER		01
22	0503013816	5/16" LOCKNUT		02



Item	Code	Description	See page	QT
01	0521068614	LEFT SILO FERTILIZER SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	05
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	01
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503011443	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0501053788	3/4 SQUARE AXLE FASTENER	96	01
12	0501110392	SILO SUPPORT BEARING		01
13	0521012485	GEAR BOX BEARING AGRICUTURAL		01
14	0503011953	5/16" X 1" BOLT		02
15	0521011039	FLAT WASHER		02
16	0503011444	SPRING WASHER		02
17	0503010337	5/16" NUT		02
18	0503010003	1845 GREASE FITTING		01
19	1902010685	18Z CONICAL GEAR		06
20	0503030275	AGRICULTURAL BEARING		06
21	0581016969	SQUARE AXLE 3/4 X 2485		01
22	0503013816	5/16" LOCKNUT		02



Item	Code	Description	See page	QT
01	0521066981	SUPPORT CENTRAL SILO FERTILIZER		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	02
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	02
04	0501010942	3/8" X 1-1/4" BOLT		16
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0571019828	LOCK AXLE		02
08	0503010365	NUT		04
09	1902010685	18Z CONICAL GEAR		04
10	0503030275	AGRICULTURAL BEARING		04
11	0503013816	5/16" LOCKNUT		04
12	0511062163	FERTILIZER BEAM LOWER COVER		01
13	0501010984	FLAT WASHER		04
14	0501011643	3/8 X 1"BOLT		04
15	0581016973	SQUARE AXLE 3/4 X 790		02




Item	Code	Description	See page	QT
01	0521052704	SUPPORT SILO RIGHT FERTILIZER WITH 74 DISTRIBUTOR 8160	01	01
02	0521052713	SILO SUPPORT LEFT FERTILIZER WITH 75 DISTRIBUTOR 8160	01	01
03	0521052735	SUPPORT SILO CENTRAL FERTILIZER WITH 76 DISTRIBUTOR 8160	01	01
04	0501010984	FLAT WASHER		40
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0571019051	FIXER BOX WASHER		30
09	0503013751	3/8 UNC X 1.1/4 BOLT		30
10	0503012535	3/8" SPRING WASHER		30
11	0503012531	3/8" INOX NUT		30
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	LOCK WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0551019168	SLEEVE		02
19	0551019160	LEVER		02
20	0551019167	SLEEVE UNION		02
21	0511017302	FLAT WASHER		06
22	0503010479	BOLT		02
23	0503011336	1/2" HEX SELF ADJUSTING NUT		06
24	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
25	0503010019	1/2" SPRING WASHER		02
26	0503010060	1/2" NUT		02
27	0501013518	FLAT WASHER		06
28	0503010140	1/8" X 3/4" COTTERPIN		06
29	0511069678	LH LOWER LEVER		02


**ASSY SILO FERTILIZER 8160**

0521052751


Item	Code	Description	See page	QT
30	0561016468	FASTENER		02
31	0581012605	GEAR BOX LEVER LOCK		02
32	0521061741	INNTER LEVER		02
33	0551019159	LEVER FIXER BODY		02
34	0503034396	FERTILIZER SIDE COVER		15
35	0503010362	1/8" X 1.1/4" COTTERPIN		15
36	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		03
37	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	60	02




Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	03
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	02
03	0501010942	3/8" X 1-1/4" BOLT		24
04	0503010025	3/8" SPRING WASHER		24
05	0503010026	3/8" NUT		24
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0501053788	3/4 SQUARE AXLE FASTENER	96	01
11	0501110392	SILO SUPPORT BEARING		01
12	0521012485	GEAR BOX BEARING AGRICUTURAL		01
13	0503011953	5/16" X 1" BOLT		02
14	0521011039	FLAT WASHER		02
15	0503010179	LOCK WASHER		02
16	0503010337	5/16" NUT		02
17	0503010003	1845 GREASE FITTING		01
18	1902010685	18Z CONICAL GEAR		05
19	0503030275	AGRICULTURAL BEARING		05
20	0581016969	SQUARE AXLE 3/4 X 2485		01
21	0521068604	SUPPORT RIGHT SILO FERTILIZER		01
22	0503013816	5/16" LOCKNUT		02
23	0511062163	FERTILIZER BEAM LOWER COVER		01
24	0501810984	FLAT WASHER		04



Item	Code	Description	See page	QT
01	0521068614	LEFT SILO FERTILIZER SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	02
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	03
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503010025	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0501053788	3/4 SQUARE AXLE FASTENER	96	01
12	0501110392	SILO SUPPORT BEARING		01
13	0521012485	GEAR BOX BEARING AGRICUTURAL		01
14	0503011953	5/16" X 1" BOLT		02
15	0521011039	FLAT WASHER		02
16	0503010179	LOCK WASHER		02
17	0503010337	5/16" NUT		02
18	0503010003	1845 GREASE FITTING		01
19	1902010685	18Z CONICAL GEAR		05
20	0503030275	AGRICULTURAL BEARING		05
21	0581016969	SQUARE AXLE 3/4 X 2485		01
22	0503013816	5/16" LOCKNUT		02
23	0511062163	FERTILIZER BEAM LOWER COVER		01
24	0501810984	FLAT WASHER		04






Item	Code	Description	See page	QT
01	0521052709	SUPPORT SILO RIGHT FERTILIZER WITH 78 DISTRIBUTOR 8460/8960/9460	01	01
02	0521052718	SILO SUPPORT LEFT FERTILIZER WITH 79 DISTRIBUTOR 8460/8960/9460	01	01
03	0521051607	SUPPORT SILO CENTRAL FERTILIZER 64 6450/7285/7450/8460	01	01
04	0501010984	FLAT WASHER		40
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0571019051	FIXER BOX WASHER		28
09	0503013751	3/8 UNC X 1.1/4 BOLT		28
10	0503012535	3/8" SPRING WASHER		28
11	0503012531	3/8" INOX NUT		28
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	LOCK WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0551019168	SLEEVE		02
19	0551019160	LEVER		02
20	0551019167	SLEEVE UNION		02
21	0511017302	FLAT WASHER		06
22	0503010479	BOLT		02
23	0503011336	1/2" HEX SELF ADJUSTING NUT		06
24	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
25	0503010019	1/2" SPRING WASHER		02
26	0503010060	1/2" NUT		02
27	0501013518	FLAT WASHER		06
28	0503010140	1/8" X 3/4" COTTERPIN		06
29	0511069678	LH LOWER LEVER		02


**ASSY SILO FERTILIZER 8460**

0521052744


Item	Code	Description	See page	QT
30	0561016468	FASTENER		02
31	0581012605	GEAR BOX LEVER LOCK		02
32	0521061741	INNTER LEVER		02
33	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	58	01
34	0551019159	LEVER FIXER BODY		02
35	0503034396	FERTILIZER SIDE COVER		17
36	0503010362	1/8" X 1.1/4" COTTERPIN		17
37	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		03
38	0521050195	SILO FERTILIZER LEFT SQUARE AXLE	59	01
39	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	60	02



Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	05
03	0501010942	3/8" X 1-1/4" BOLT		24
04	0503010025	3/8" SPRING WASHER		24
05	0503010026	3/8" NUT		24
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0503013816	5/16" LOCKNUT		02
11	0581016967	SQUARE SHAFT		01
12	1902010685	18Z CONICAL GEAR		06
13	0503030275	AGRICULTURAL BEARING		06
14	0501053788	3/4 SQUARE AXLE FASTENER	96	01
15	0501110392	SILO SUPPORT BEARING		01
16	0503010003	1845 GREASE FITTING		01
17	0521068602	SUPPORT RIGHT SILO FERTILIZER WITH DISTRIBUTOR		01
18	0503011953	5/16" X 1" BOLT		02
19	0521011039	FLAT WASHER		02
20	0503010179	LOCK WASHER		02
21	0503010337	5/16" NUT		02
22	0521012485	GEAR BOX BEARING AGRICUTURAL		01




Item	Code	Description	See page	QT
01	0521068612	SILO FERTILIZER SUPPORT WITH DISTRIBUTOR		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	05
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	01
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503010025	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0503010337	5/16" NUT		02
12	0581016967	SQUARE SHAFT		01
13	0503030275	AGRICULTURAL BEARING		06
14	1902010685	18Z CONICAL GEAR		06
15	0503010003	1845 GREASE FITTING		01
16	0501053788	3/4 SQUARE AXLE FASTENER	96	01
17	0521012485	GEAR BOX BEARING AGRICUTURAL		01
18	0501110392	SILO SUPPORT BEARING		01
19	0503011953	5/16" X 1" BOLT		02
20	0521011039	FLAT WASHER		02
21	0503010179	LOCK WASHER		02
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521052709	SUPPORT SILO RIGHT FERTILIZER WITH 78 DISTRIBUTOR 8460/8960/9460	01	01
02	0521052731	SUPPORT SILO CENTRAL FERTILIZER WITH 81 DISTRIBUTOR 8960	01	01
03	0521052718	SILO SUPPORT LEFT FERTILIZER WITH 79 DISTRIBUTOR 8460/8960/9460	01	01
04	0501010984	FLAT WASHER		40
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0503013751	3/8 UNC X 1.1/4 BOLT		32
09	0571019051	FIXER BOX WASHER		32
10	0503012535	3/8" SPRING WASHER		32
11	0503012531	3/8" INOX NUT		32
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	LOCK WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0581012605	GEAR BOX LEVER LOCK		02
19	0551019160	LEVER		02
20	0521061741	INNTER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0511017302	FLAT WASHER		06
23	0551019167	SLEEVE UNION		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501013518	FLAT WASHER		06
27	0503010140	1/8" X 3/4" COTTERPIN		06
28	0503010479	BOLT		02
29	0551019168	SLEEVE		02

Item	Code	Description	See page	QT
30	0503011336	1/2" HEX SELF ADJUSTING NUT		06
31	0511069678	LH LOWER LEVER		02
32	0561016468	FASTENER		02
33	0551019159	LEVER FIXER BODY		02
34	0503034396	FERTILIZER SIDE COVER		18
35	0503010362	1/8" X 1.1/4" COTTERPIN		18
36	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		02
37	0503062362	FERTILIZER BOX		02
38	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	60	02




Item	Code	Description	See page	QT
01	0521068620	SUPPORT CENTRAL SILO FERTILIZER		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	03
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503011443	3/8" SPRING WASHER		32
06	0503010026	3/8" NUT		32
07	0571019828	LOCK AXLE		02
08	0503010365	NUT		04
09	0503013816	5/16" LOCKNUT		04
10	1902010685	18Z CONICAL GEAR		06
11	0503030275	AGRICULTURAL BEARING		06
12	0581016966	AXIS Q 3/4 X 1371		02
13	0511062163	FERTILIZER BEAM LOWER COVER		02
14	0501011643	3/8 X 1"BOLT		08
15	0501010984	FLAT WASHER		08




Item	Code	Description	See page	QT
01	0521052718	SILO SUPPORT LEFT FERTILIZER WITH 79 DISTRIBUTOR 8460/8960/9460	79	01
02	0521052709	SUPPORT SILO RIGHT FERTILIZER WITH 78 DISTRIBUTOR 8460/8960/9460	78	01
03	0521052728	SUPPORT SILO CENTRAL FERTILIZER WITH 83 DISTRIBUTOR 9460	83	01
04	0501010984	FLAT WASHER		40
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0571019051	FIXER BOX WASHER		32
09	0503013751	3/8 UNC X 1.1/4 BOLT		32
10	0503012535	3/8" SPRING WASHER		32
11	0503012531	3/8" INOX NUT		32
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	LOCK WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0551019168	SLEEVE		02
19	0551019160	LEVER		02
20	0551019167	SLEEVE UNION		02
21	0511017302	FLAT WASHER		06
22	0503010479	BOLT		02
23	0503011336	1/2" HEX SELF ADJUSTING NUT		06
24	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
25	0503010019	1/2" SPRING WASHER		02
26	0503010060	1/2" NUT		02
27	0501013518	FLAT WASHER		06
28	0503010140	1/8" X 3/4" COTTERPIN		06
29	0511069678	LH LOWER LEVER		02

Item	Code	Description	See page	QT
30	0561016468	FASTENER		02
31	0581012605	GEAR BOX LEVER LOCK		02
32	0521061741	INNTER LEVER		02
33	0551019159	LEVER FIXER BODY		02
34	0503034396	FERTILIZER SIDE COVER		19
35	0503010362	1/8" X 1.1/4" COTTERPIN		19
36	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		02
37	0503062362	FERTILIZER BOX		02
38	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	58	01
39	0521050195	SILO FERTILIZER LEFT SQUARE AXLE	59	01
40	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	60	02




Item	Code	Description	See page	QT
01	0521068619	LR SEED SILO CENTRAL SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	04
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	03
04	0501010942	3/8" X 1-1/4" BOLT		28
05	0503011443	3/8" SPRING WASHER		32
06	0503010026	3/8" NUT		32
07	0571019828	LOCK AXLE		02
08	0503010365	NUT		04
09	1902010685	18Z CONICAL GEAR		07
10	0503030275	AGRICULTURAL BEARING		07
11	0503013816	5/16" LOCKNUT		04
12	0511062163	FERTILIZER BEAM LOWER COVER		01
13	0501010984	FLAT WASHER		04
14	0501011643	3/8 X 1" BOLT		04
15	0581016963	SQUARE SHAFT		01
16	0581016964	3/4" X 1320 SQUARE SHAFT 19 E 500		01




Item	Code	Description	See page	QT
01	0521052708	SUPPORT SILO RIGHT FERTILIZER WITH 85 DISTRIBUTOR 9960/10460	01	01
02	0521052717	SILO SUPPORT LEFT FERTILIZER WITH 86 DISTRIBUTOR 9960/10460	01	01
03	0521052727	SUPPORT SILO CENTRAL FERTILIZER WITH 87 DISTRIBUTOR 9960	01	01
04	0501010984	FLAT WASHER		40
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0571019051	FIXER BOX WASHER		36
09	0503013751	3/8 UNC X 1.1/4 BOLT		36
10	0503012535	3/8" SPRING WASHER		36
11	0503012531	3/8" INOX NUT		36
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	LOCK WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0551019168	SLEEVE		02
19	0551019160	LEVER		02
20	0551019167	SLEEVE UNION		02
21	0511017302	FLAT WASHER		06
22	0503010479	BOLT		02
23	0503011336	1/2" HEX SELF ADJUSTING NUT		06
24	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
25	0503010019	1/2" SPRING WASHER		02
26	0503010060	1/2" NUT		02
27	0501013518	FLAT WASHER		06
28	0503010140	1/8" X 3/4" COTTERPIN		06
29	0511069678	LH LOWER LEVER		02


Item	Code	Description	See page	QT
30	0561016468	FASTENER		02
31	0581012605	GEAR BOX LEVER LOCK		02
32	0521061741	INNTER LEVER		02
33	0551019159	LEVER FIXER BODY		02
34	0503034396	FERTILIZER SIDE COVER		20
35	0503010362	1/8" X 1.1/4" COTTERPIN		20
36	0503062362	FERTILIZER BOX		06
37	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	60	02




Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	03
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	04
03	0501010942	3/8" X 1-1/4" BOLT		32
04	0503010025	3/8" SPRING WASHER		32
05	0503010026	3/8" NUT		32
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0503013816	5/16" LOCKNUT		02
11	0581016961	SQUARE SHAFT		01
12	1902010685	18Z CONICAL GEAR		07
13	0503030275	AGRICULTURAL BEARING		07
14	0501053788	3/4 SQUARE AXLE FASTENER	96	01
15	0501110392	SILO SUPPORT BEARING		01
16	0503010003	1845 GREASE FITTING		01
17	0521068601	20 E 500 RH FERTILIZER BEAM SUPPORT		01
18	0503011953	5/16" X 1" BOLT		02
19	0521011039	FLAT WASHER		02
20	0503010179	LOCK WASHER		02
21	0503010337	5/16" NUT		02
22	0521012485	GEAR BOX BEARING AGRICUTURAL		01
23	0511062163	FERTILIZER BEAM LOWER COVER		01
24	0501810984	FLAT WASHER		04



Item	Code	Description	See page	QT
01	0521068611	LEFT SILO FERTILIZER SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	04
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	03
04	0501010942	3/8" X 1-1/4" BOLT		32
05	0503010025	3/8" SPRING WASHER		32
06	0503010026	3/8" NUT		32
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0501053788	3/4 SQUARE AXLE FASTENER	96	01
12	0501110392	SILO SUPPORT BEARING		01
13	0521012485	GEAR BOX BEARING AGRICUTURAL		01
14	0503011953	5/16" X 1" BOLT		02
15	0521011039	FLAT WASHER		02
16	0503010179	LOCK WASHER		02
17	0503010337	5/16" NUT		02
18	0503010003	1845 GREASE FITTING		01
19	1902010685	18Z CONICAL GEAR		07
20	0503030275	AGRICULTURAL BEARING		07
21	0581016961	SQUARE SHAFT		01
22	0503013816	5/16" LOCKNUT		02
23	0511062163	FERTILIZER BEAM LOWER COVER		01
24	0501010984	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521068618	CENTRAL FERTILIZER BOX SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	03
04	0501010942	3/8" X 1-1/4" BOLT		32
05	0503010025	3/8" SPRING WASHER		32
06	0503010026	3/8" NUT		32
07	0571019828	LOCK AXLE		02
08	0503010365	NUT		04
09	1902010685	18Z CONICAL GEAR		06
10	0503030275	AGRICULTURAL BEARING		06
11	0503013816	5/16" LOCKNUT		04
12	0511062163	FERTILIZER BEAM LOWER COVER		02
13	0501010984	FLAT WASHER		08
14	0581016962	3/4" X 1392 SQUARE SHAFT 20 E 500		02




Item	Code	Description	See page	QT
01	0521052708	SUPPORT SILO RIGHT FERTILIZER WITH 85 DISTRIBUTOR 9960/10460	85	01
02	0521052717	SILO SUPPORT LEFT FERTILIZER WITH 86 DISTRIBUTOR 9960/10460	86	01
03	0521052725	SUPPORT SILO CENTRAL FERTILIZER WITH 89 DISTRIBUTOR 10460	89	01
04	0501010984	FLAT WASHER		40
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0571019051	FIXER BOX WASHER		36
09	0503013751	3/8 UNC X 1.1/4 BOLT		36
10	0503012535	3/8" SPRING WASHER		36
11	0503012531	3/8" INOX NUT		36
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	LOCK WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0551019168	SLEEVE		02
19	0551019160	LEVER		02
20	0551019167	SLEEVE UNION		02
21	0511017302	FLAT WASHER		06
22	0503010479	BOLT		02
23	0503011336	1/2" HEX SELF ADJUSTING NUT		06
24	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
25	0503010019	1/2" SPRING WASHER		02
26	0503010060	1/2" NUT		02
27	0501013518	FLAT WASHER		06
28	0503010140	1/8" X 3/4" COTTERPIN		06
29	0511069678	LH LOWER LEVER		02

Item	Code	Description	See page	QT
30	0561016468	FASTENER		02
31	0581012605	GEAR BOX LEVER LOCK		02
32	0521061741	INNTER LEVER		02
33	0551019159	LEVER FIXER BODY		02
34	0503034396	FERTILIZER SIDE COVER		21
35	0503010362	1/8" X 1.1/4" COTTERPIN		21
36	0503062362	FERTILIZER BOX		06
37	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	58	01
38	0521050195	SILO FERTILIZER LEFT SQUARE AXLE	59	01
39	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	60	02




Item	Code	Description	See page	QT
01	0521068619	LR SEED SILO CENTRAL SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	04
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	03
04	0501010942	3/8" X 1-1/4" BOLT		32
05	0503010025	3/8" SPRING WASHER		32
06	0503010026	3/8" NUT		32
07	0571019828	LOCK AXLE		02
08	0503010365	NUT		04
09	1902010685	18Z CONICAL GEAR		07
10	0503030275	AGRICULTURAL BEARING		07
11	0503013816	5/16" LOCKNUT		04
12	0511062163	FERTILIZER BEAM LOWER COVER		01
13	0501010984	FLAT WASHER		04
14	0581016956	3/4" X 1565 SQUARE SHAFT		01
15	0581016957	3/4" X 1265 SQUARE SHAFT		01




Item	Code	Description	See page	QT
01	0521052706	SUPPORT SILO RIGHT FERTILIZER WITH 91 DISTRIBUTOR 10985	01	01
02	0521052715	SILO SUPPORT LEFT FERTILIZER WITH 92 DISTRIBUTOR 10985	02	01
03	0521052723	SUPPORT SILO CENTRAL FERTILIZER WITH 93 DISTRIBUTOR 10985	03	01
04	0501010984	FLAT WASHER		40
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0571019051	FIXER BOX WASHER		36
09	0503013751	3/8 UNC X 1.1/4 BOLT		36
10	0503012535	3/8" SPRING WASHER		36
11	0503012531	3/8" INOX NUT		36
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	LOCK WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0551019168	SLEEVE		02
19	0551019160	LEVER		02
20	0551019167	SLEEVE UNION		02
21	0511017302	FLAT WASHER		06
22	0503010479	BOLT		02
23	0503011336	1/2" HEX SELF ADJUSTING NUT		06
24	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
25	0503010019	1/2" SPRING WASHER		02
26	0503010060	1/2" NUT		02
27	0501013518	FLAT WASHER		06
28	0503010140	1/8" X 3/4" COTTERPIN		06
29	0511069678	LH LOWER LEVER		02


Item	Code	Description	See page	QT
30	0561016468	FASTENER		02
31	0581012605	GEAR BOX LEVER LOCK		02
32	0521061741	INNTER LEVER		02
33	0551019159	LEVER FIXER BODY		02
34	0503034396	FERTILIZER SIDE COVER		22
35	0503010362	1/8" X 1.1/4" COTTERPIN		22
36	0503062362	FERTILIZER BOX		06
37	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	60	02




Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	03
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	04
03	0501010942	3/8" X 1-1/4" BOLT		32
04	0503010025	3/8" SPRING WASHER		32
05	0503010026	3/8" NUT		32
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0503013816	5/16" LOCKNUT		02
11	0581016954	3/4 X 3293 SQUARE SHAFT		01
12	1902010685	18Z CONICAL GEAR		07
13	0503030275	AGRICULTURAL BEARING		07
14	0501053788	3/4 SQUARE AXLE FASTENER	96	01
15	0501110392	SILO SUPPORT BEARING		01
16	0503010003	1845 GREASE FITTING		01
17	0521068599	22 E 500 RH FERTILIZER BEAM SUPPORT PST TRIO/FLEX		01
18	0503011953	5/16" X 1" BOLT		02
19	0521011039	FLAT WASHER		02
20	0503010179	LOCK WASHER		02
21	0503010337	5/16" NUT		02
22	0521012485	GEAR BOX BEARING AGRICUTURAL		01
23	0511062163	FERTILIZER BEAM LOWER COVER		01
24	0501810984	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521068609	LH SILO FERTILIZER SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	04
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	03
04	0501010942	3/8" X 1-1/4" BOLT		32
05	0503010025	3/8" SPRING WASHER		32
06	0503010026	3/8" NUT		32
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0501053788	3/4 SQUARE AXLE FASTENER	96	01
12	0501110392	SILO SUPPORT BEARING		01
13	0521012485	GEAR BOX BEARING AGRICUTURAL		01
14	0503011953	5/16" X 1" BOLT		02
15	0521011039	FLAT WASHER		02
16	0503010179	LOCK WASHER		02
17	0503010337	5/16" NUT		02
18	0503010003	1845 GREASE FITTING		01
19	1902010685	18Z CONICAL GEAR		07
20	0503030275	AGRICULTURAL BEARING		07
21	0581016954	3/4 X 3293 SQUARE SHAFT		01
22	0503013816	5/16" LOCKNUT		02
23	0511062163	FERTILIZER BEAM LOWER COVER		01
24	0501010984	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521068617	CENTRAL FERTILIZER BOX SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	94	04
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	95	04
04	0501010942	3/8" X 1-1/4" BOLT		32
05	0503011443	3/8" SPRING WASHER		32
06	0503010026	3/8" NUT		32
07	0571019828	LOCK AXLE		02
08	0503010365	NUT		04
09	1902010685	18Z CONICAL GEAR		08
10	0503030275	AGRICULTURAL BEARING		08
11	0503013816	5/16" LOCKNUT		04
12	0581016955	3/4" X 1506 SQUARE SHAFT		02




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01



Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0571014441	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0501052560	MOTOR AXLE SIGNAL	105	02
15	0511051434	TRANSMISSION ACTUATOR	106	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	107	01
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	108	01
18	0521043316	RIGHT GEAR BOX ASSY	109	01
19	0521043317	LEFT GEAR BOX ASSY	110	01
20	0501011600	1/2" X 1-1/4" BOLT		06
21	0503010920	1/2" X 1.1/2" BOLT		04
22	0511017302	FLAT WASHER		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2" NUT		10
25	0521064448	GEAR		02
26	0511059261	CHAIN TENSIONER	120	04
27	0521055217	LOWER CURRENT STRETCH	121	02
28	0501058254	UPPER SEED CHAIN TENSIONER	122	02
29	0521055216	BEARING WITH GEAR	123	02
30	0521055218	BEARING GEAR WITH DOUBLE	124	02
31	0521055214	BEARING GEAR WITH	125	02

Item	Code	Description	See page	QT
32	0503012204	40-1 CHAIN X 82 LINK + RED		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0571014439	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0501052560	MOTOR AXLE SIGNAL	105	02
15	0511051434	TRANSMISSION ACTUATOR	106	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	107	01
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	108	01
18	0521043316	RIGHT GEAR BOX ASSY	109	01
19	0521043317	LEFT GEAR BOX ASSY	110	01
20	0503014734	BOLT		06
21	0503010920	1/2" X 1.1/2" BOLT		04
22	0511017302	FLAT WASHER		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2" NUT		10
25	0521064448	GEAR		02
26	0511059261	CHAIN TENSIONER	120	04
27	0521055217	LOWER CURRENT STRETCH	121	02
28	0501058254	UPPER SEED CHAIN TENSIONER	122	02
29	0521055216	BEARING WITH GEAR	123	02
30	0521055218	BEARING GEAR WITH DOUBLE	124	02
31	0521055214	BEARING GEAR WITH	125	02

Item	Code	Description	See page	QT
32	0503012204	40-1 CHAIN X 82 LINK + RED		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0571014440	ENGINE SHAFT 2475		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0501052560	MOTOR AXLE SIGNAL	105	02
15	0511051434	TRANSMISSION ACTUATOR	106	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	107	01
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	108	01
18	0521043316	RIGHT GEAR BOX ASSY	109	01
19	0521043317	LEFT GEAR BOX ASSY	110	01
20	0503014734	BOLT		06
21	0503010920	1/2" X 1.1/2" BOLT		04
22	0511017302	FLAT WASHER		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2" NUT		10
25	0521064448	GEAR		02
26	0511059261	CHAIN TENSIONER	120	04
27	0521055217	LOWER CURRENT STRETCH	121	02
28	0501058254	UPPER SEED CHAIN TENSIONER	122	02
29	0521055216	BEARING WITH GEAR	123	02
30	0521055218	BEARING GEAR WITH DOUBLE	124	02
31	0521055214	BEARING GEAR WITH	125	02

Item	Code	Description	See page	QT
32	0503012204	40-1 CHAIN X 82 LINK + RED		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0571014442	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0501052560	MOTOR AXLE SIGNAL	105	02
15	0511051434	TRANSMISSION ACTUATOR	106	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	107	01
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	108	01
18	0521043316	RIGHT GEAR BOX ASSY	109	01
19	0521043317	LEFT GEAR BOX ASSY	110	01
20	0501011600	1/2" X 1-1/4" BOLT		06
21	0503010920	1/2" X 1.1/2" BOLT		04
22	0511017302	FLAT WASHER		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2" NUT		10
25	0521064448	GEAR		02
26	0511059261	CHAIN TENSIONER	120	04
27	0521055217	LOWER CURRENT STRETCH	121	02
28	0501058254	UPPER SEED CHAIN TENSIONER	122	02
29	0521055216	BEARING WITH GEAR	123	02
30	0521055218	BEARING GEAR WITH DOUBLE	124	02
31	0521055214	BEARING GEAR WITH	125	02

Item	Code	Description	See page	QT
32	0503012204	40-1 CHAIN X 82 LINK + RED		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0571014442	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0501052560	MOTOR AXLE SIGNAL	105	02
15	0511051434	TRANSMISSION ACTUATOR	106	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	107	01
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	108	01
18	0521043316	RIGHT GEAR BOX ASSY	109	01
19	0521043317	LEFT GEAR BOX ASSY	110	01
20	0501011600	1/2" X 1-1/4" BOLT		06
21	0503010920	1/2" X 1.1/2" BOLT		04
22	0511017302	FLAT WASHER		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2" NUT		10
25	0521064448	GEAR		02
26	0511059261	CHAIN TENSIONER	120	04
27	0521055217	LOWER CURRENT STRETCH	121	02
28	0501058254	UPPER SEED CHAIN TENSIONER	122	02
29	0521055216	BEARING WITH GEAR	123	02
30	0521055218	BEARING GEAR WITH DOUBLE	124	02
31	0521055214	BEARING GEAR WITH	125	02

Item	Code	Description	See page	QT
32	0503012204	40-1 CHAIN X 82 LINK + RED		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0571014442	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0501052560	MOTOR AXLE SIGNAL	105	02
15	0511051434	TRANSMISSION ACTUATOR	106	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	107	01
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	108	01
18	0521043316	RIGHT GEAR BOX ASSY	109	01
19	0521043317	LEFT GEAR BOX ASSY	110	01
20	0501010243	1/2" X 1-1/2" BOLT		06
21	0503010920	1/2" X 1.1/2" BOLT		04
22	0511017302	FLAT WASHER		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2" NUT		10
25	0521064448	GEAR		02
26	0511059261	CHAIN TENSIONER	120	04
27	0521055217	LOWER CURRENT STRETCH	121	02
28	0501058254	UPPER SEED CHAIN TENSIONER	122	02
29	0521055216	BEARING WITH GEAR	123	02
30	0521055218	BEARING GEAR WITH DOUBLE	124	02
31	0521055214	BEARING GEAR WITH	125	02

Item	Code	Description	See page	QT
32	0503012204	40-1 CHAIN X 82 LINK + RED		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0571017078	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0501052560	MOTOR AXLE SIGNAL	105	02
15	0511051434	TRANSMISSION ACTUATOR	106	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	107	01
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	108	01
18	0521043316	RIGHT GEAR BOX ASSY	109	01
19	0521043317	LEFT GEAR BOX ASSY	110	01
20	0501010243	1/2" X 1-1/2" BOLT		06
21	0503010920	1/2" X 1.1/2" BOLT		04
22	0511017302	FLAT WASHER		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2" NUT		10
25	0521064448	GEAR		02
26	0511059261	CHAIN TENSIONER	120	04
27	0521055217	LOWER CURRENT STRETCH	121	02
28	0501058254	UPPER SEED CHAIN TENSIONER	122	02
29	0521055216	BEARING WITH GEAR	123	02
30	0521055218	BEARING GEAR WITH DOUBLE	124	02
31	0521055214	BEARING GEAR WITH	125	02

Item	Code	Description	See page	QT
32	0503012204	40-1 CHAIN X 82 LINK + RED		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		10
02	0503011099	GREASE FITTING		10
03	0503010300	5/32" X 1" COTTERPIN		10
04	0551019114	MOTOR BEARING AXLE SUPPORT		06
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		06
06	0511017302	FLAT WASHER		12
07	0503010019	1/2" SPRING WASHER		12
08	0503010060	1/2" NUT		12
09	0581014383	3387 MOTOR SHAFT PST TRIO/F 22 E 450/15 E 760		02
10	0501018466	FLAT WASHER		06
11	0511015961	LOCK BUSHING		06
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		06
13	0503010060	1/2" NUT		06
14	0501052560	MOTOR AXLE SIGNAL	105	02
15	0511051434	TRANSMISSION ACTUATOR	106	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	107	01
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	108	01
18	0521043316	RIGHT GEAR BOX ASSY	109	01
19	0521043317	LEFT GEAR BOX ASSY	110	01
20	0501010243	1/2" X 1-1/2" BOLT		06
21	0503010920	1/2" X 1.1/2" BOLT		04
22	0511017302	FLAT WASHER		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2" NUT		10
25	0521064448	GEAR		02
26	0511059261	CHAIN TENSIONER	120	04
27	0521055217	LOWER CURRENT STRETCH	121	02
28	0501058254	UPPER SEED CHAIN TENSIONER	122	02
29	0521055216	BEARING WITH GEAR	123	02
30	0521055218	BEARING GEAR WITH DOUBLE	124	02
31	0521055214	BEARING GEAR WITH	125	02


Item	Code	Description	See page	QT
32	0503012204	40-1 CHAIN X 82 LINK + RED		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02



Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

LEFT SIDE TRANSMISSION ACTUATOR


0511047070



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY


0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	111	01
02	0511059266	CLOSED BEARING	113	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	115	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	117	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	118	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	119	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	112	01
02	0511059266	CLOSED BEARING	113	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	115	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	117	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	118	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	119	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	114	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	116	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0503031805	1 1/2" GEAR		01
02	0511017302	FLAT WASHER		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0521018933	FERT CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501011234	5/8" X 3" BOLT		01
02	0531017086	50 AXLETIGHTENER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0503019356	BEARING 6005 2RS1		01
05	0503011105	SEAL RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0503016460	5/8" X 4.1/2" BOLT		01
02	0551019175	DOUBLE GEAR AXLE		01
03	0503019356	BEARING 6005 2RS1		02
04	0511069680	20Z X 28Z DOBLE GEAR		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511063106	20Z AXLE BEARING DOBLE		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0521055215	DOUBLE TRANSMISSION BEARING	126	01
04	0503010365	NUT		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503019356	BEARING 6005 2RS1		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521068581	RIGHT PLATFORM		01
02	0521068597	CENTRAL PLATFORM		01
03	0521068589	LEFT PLATFORM		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		28
07	0503010025	3/8" SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	CUPILLA		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32"X 2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0521068580	RIGHT PLATFORM		01
02	0521068596	CENTRAL PLATFORM		01
03	0521068588	LEFT PLATFORM		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		28
07	0503010025	3/8" SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	CUPILLA		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32"X 2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0521068504	RIGHT PLATFORM		01
02	0521068597	CENTRAL PLATFORM		01
03	0521068586	LEFT PLATFORM		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		28
07	0503010025	3/8" SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	CUPILLA		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32"X 2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0521068579	RIGHT PLATFORM		01
02	0521068595	CENTRAL PLATFORM		01
03	0521068587	LEFT PLATFORM		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		28
07	0503010025	3/8" SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	CUPILLA		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32"X 2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0521068579	RIGHT PLATFORM		01
02	0521068597	CENTRAL PLATFORM		01
03	0521068587	LEFT PLATFORM		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		28
07	0503010025	3/8" SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	CUPILLA		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32"X 2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0521068579	RIGHT PLATFORM		01
02	0521068596	CENTRAL PLATFORM		01
03	0521068587	LEFT PLATFORM		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		28
07	0503010025	3/8" SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	CUPILLA		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32"X 2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0521068579	RIGHT PLATFORM		01
02	0521068594	CENTRAL PLATFORM		01
03	0521068587	LEFT PLATFORM		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		28
07	0503010025	3/8" SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	CUPILLA		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32"X 2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0521068579	RIGHT PLATFORM		01
02	0521068313	PLATFORM CENTER		01
03	0521068587	LEFT PLATFORM		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		28
07	0503010025	3/8" SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	CUPILLA		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32"X 2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0521068315	RIGHT PLATFORM		01
02	0521068594	CENTRAL PLATFORM		01
03	0521068314	LEFT PLATFORM		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		28
07	0503010025	3/8" SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	CUPILLA		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32"X 2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0521068315	RIGHT PLATFORM		01
02	0521068313	PLATFORM CENTER		01
03	0521068314	LEFT PLATFORM		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		28
07	0503010025	3/8" SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	CUPILLA		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32"X 2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0521068582	22 E 500 RH PLATFORM ASSY PST TRIO/FLEX		01
02	0521068313	PLATFORM CENTER		01
03	0521068590	LEFT PLATFORM 22 E 500		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		28
07	0503010025	3/8" SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	CUPILLA		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32"X 2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0521063871	SIDE HANDRAIL		02
02	0521063875	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2" NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8" SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
01	0521064019	SIDE HANDRAIL	02	
02	0521064018	CENTRAL HANDRAIL	01	
03	0503010395	1/2" X 1-1/4" BOLT	04	
04	0503010019	1/2" SPRING WASHER	12	
05	0503010060	1/2" NUT	12	
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	06	
07	0503011082	C1/2" X 1.3/4" SCREW	02	
08	0551019884	45 X 50 X 3/8 FASTENER	08	
09	0571017991	CHAIN FIXER HANDRAIL	08	
10	0503013357	3/8" SELF-ADJUSTING NUT	16	
11	0503034094	22 TWISTED CHAIN	04	




Item	Code	Description	See page	QT
01	0521063976	SIDE HANDRAIL		02
02	0521063875	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2" NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8" SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
01	0521064280	SIDE HANDRAIL		02
02	0521064279	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2" NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8" SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
01	0521064280	SIDE HANDRAIL		02
02	0521063875	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2" NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8" SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
01	0521064280	SIDE HANDRAIL		02
02	0521064018	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2" NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8" SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
01	0521064280	SIDE HANDRAIL		02
02	0521065205	HANDRAIL CENTRAL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2" NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8" SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
01	0521064280	SIDE HANDRAIL	02	
02	0521064843	CENTRAL HANDRAIL	01	
03	0503010395	1/2" X 1-1/4" BOLT	04	
04	0503010019	1/2" SPRING WASHER	12	
05	0503010060	1/2" NUT	12	
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	06	
07	0503011082	C1/2" X 1.3/4" SCREW	02	
08	0551019884	45 X 50 X 3/8 FASTENER	08	
09	0571017991	CHAIN FIXER HANDRAIL	08	
10	0503013357	3/8" SELF-ADJUSTING NUT	16	
11	0503034094	22 TWISTED CHAIN	04	




Item	Code	Description	See page	QT
01	0521064844	SIDE HANDRAIL	02	
02	0521065205	HANDRAIL CENTRAL	01	
03	0503010395	1/2" X 1-1/4" BOLT	04	
04	0503010019	1/2" SPRING WASHER	12	
05	0503010060	1/2" NUT	12	
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	06	
07	0503011082	C1/2" X 1.3/4" SCREW	02	
08	0551019884	45 X 50 X 3/8 FASTENER	08	
09	0571017991	CHAIN FIXER HANDRAIL	08	
10	0503013357	3/8" SELF-ADJUSTING NUT	16	
11	0503034094	22 TWISTED CHAIN	04	




Item	Code	Description	See page	QT
01	0521064844	SIDE HANDRAIL	02	
02	0521064843	CENTRAL HANDRAIL	01	
03	0503010395	1/2" X 1-1/4" BOLT	04	
04	0503010019	1/2" SPRING WASHER	12	
05	0503010060	1/2" NUT	12	
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	06	
07	0503011082	C1/2" X 1.3/4" SCREW	02	
08	0551019884	45 X 50 X 3/8 FASTENER	08	
09	0571017991	CHAIN FIXER HANDRAIL	08	
10	0503013357	3/8" SELF-ADJUSTING NUT	16	
11	0503034094	22 TWISTED CHAIN	04	




Item	Code	Description	See page	QT
01	0521067842	22 E 450 /15 E 760 SIDE HARDWARE	02	
02	0521064843	CENTRAL HANDRAIL	01	
03	0503010395	1/2" X 1-1/4" BOLT	04	
04	0503010019	1/2" SPRING WASHER	12	
05	0503010060	1/2" NUT	12	
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	06	
07	0503011082	C1/2" X 1.3/4" SCREW	02	
08	0551019884	45 X 50 X 3/8 FASTENER	08	
09	0571017991	CHAIN FIXER HANDRAIL	08	
10	0503013357	3/8" SELF-ADJUSTING NUT	16	
11	0503034094	22 TWISTED CHAIN	04	



Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	6850	7450	7860	7960	8160	8460
01	0521055204	LIGNE DE DISQUE MARKER	153	002	002	002	002	002	002
02	0521061790	1750 TURNBUCKLE		002	002	002	002	002	002
03	0511060014	ROW MARKER ARM		002	002	002	002	002	002
04	0521012324	1/2" X 3.2" X 2.54" FASTENER		004	004	004	004	004	004
05	0511017302	FLAT WASHER		008	008	008	008	008	008
06	0503010019	1/2" SPRING WASHER		008	008	008	008	008	008
07	0503010060	1/2" NUT		008	008	008	008	008	008
08	0503010003	1845 GREASE FITTING		002	002	002	002	002	002
09	0511060013	ROW MARKER ARM		002	002	002	002	002	002
10	0503010004	1890 GREASE FITTING		002	002	002	002	002	002
11	0521011142	1.1/4" X 7.5" AXLE		004	004	004	004	004	004
12	0501019435	32 X 50 X 1.5 FLAT WASHER		016	016	016	016	016	016
13	0511061022	ROW MARKER SUPPORT		002	002	002	002	002	002
14	0511066119	MARKER SUPP FIXER FASTENER		004	004	004	004	004	004
15	0502010175	HITCH CLAMP		008	008	008	008	008	008
16	0501010216	3/4" X 4-1/2" BOLT		016	016	016	016	016	016
17	0503010023	3/4" SPRING WASHER		016	016	016	016	016	016
18	0503010014	3/4" NUT		016	016	016	016	016	016
19	0503010523	1/4" X 2" COTTERPIN		016	016	016	016	016	016
20	0521013347	1.1/4" X 8.4" AXLE		002	002	002	002	002	002
21	0521011141	1.1/4" X 6.5" AXLE		002	002	002	002	002	002
22	0501054649	HBM SEQUENTIAL VALVE	154	001	001	001	001	001	001
23	0511058431	HYDRAULIC CYLINDER	155	002	002	002	002	002	002
24	0511015573	2.07" X 1.6" TRANSPORT LOCK		002	002	002	002	002	002
25	0501068994	0.3" X 3.1" LOCK PIN		002	002	002	002	002	002
26	0503030168	CUPILLA		002	002	002	002	002	002
27	0511018012	HIDRAULIC ADAPTER		004	004	004	004	004	004
28	0501053834	MALE QUICK COUPLER	54	002	002	002	002	002	002
29	0511057093	HYDRAULIC MARKER HYGIENE SET		001	000	000	000	000	000
29A	0501081791	HOSE ASSY		002	000	000	000	000	000
29B	0501080388	3/8 X 4300 TR-TC HOSE ASSY		002	000	000	000	000	000

Item	Code	Description	See page	6850	7450	7860	7960	8160	8460
30	0511057880	HYDRAULIC MARKER HAND ASSY		000	000	001	000	000	000
30A	0501082038	HOSE 3/8 X 5350 TR-TC		000	000	002	000	000	000
30B	0501082037	HOSE 3/8 X 5150 TR-TC		000	000	002	000	000	000
31	0521052851	HYDRAULIC MARKER HAND ASSY		000	000	000	001	000	000
31A	0501081225	HOSE 3/8 X 5000 TR-TC		000	000	000	002	000	000
31B	0501081465	HOSE 3/8 X 4890 TR-TC		000	000	000	002	000	000
32	0521052278	HOSE 3/8 X 4212 TC-TM PURPLE / BLUE		001	001	000	000	000	000
32A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		001	001	000	000	000	000
32B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		001	001	000	000	000	000
32C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		001	001	000	000	000	000
32D	0503018952	PLASTIC BOLT		006	006	000	000	000	000
33	0521052277	HOSE 3/8 X 4212 TC-TM PURPLE / RED		001	001	000	000	000	000
33A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		001	001	000	000	000	000
33B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		001	001	000	000	000	000
33C	0503034495	HYDRAULIC HOSE GRIP (RED)		001	001	000	000	000	000
33D	0503018952	PLASTIC BOLT		006	006	000	000	000	000
34	0521052509	HOSE 3/8 X 4650 TC-TM PURPLE / BLUE		000	000	001	000	000	000
34A	0501081774	HOSE 3/8 X 4650 TC-TM		000	000	001	000	000	000
34B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		000	000	001	000	000	000
34C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		000	000	001	000	000	000
34D	0503018952	PLASTIC BOLT		000	000	006	000	000	000
35	0521052508	HOSE 3/8 X 4650 TC-TM PURPLE / RED		000	000	001	000	000	000
35A	0501081774	HOSE 3/8 X 4650 TC-TM		000	000	001	000	000	000
35B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		000	000	001	000	000	000
35C	0503034495	HYDRAULIC HOSE GRIP (RED)		000	000	001	000	000	000
35D	0503018952	PLASTIC BOLT		000	000	006	000	000	000
36	0521052850	HOSE 3/8 X 4200 TC-TM PURPLE / BLUE		000	000	000	001	001	000
36A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		000	000	000	001	001	000
36B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		000	000	000	001	001	000
36C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		000	000	000	001	001	000
36D	0503018952	PLASTIC BOLT		000	000	000	006	006	000
37	0521052849	HOSE 3/8 X 4200 TC-TM PURPLE / RED		000	000	000	001	001	000
37A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		000	000	000	001	001	000
37B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		000	000	000	001	001	000
37C	0503034495	HYDRAULIC HOSE GRIP (RED)		000	000	000	001	001	000
37D	0503018952	PLASTIC BOLT		000	000	000	001	006	000
38	0511057094	HYDRAULIC HOSE MARKER ASSY 6450		000	001	000	000	000	000
38A	0501081093	3/8" X 188.9" TR-TC HOSE ASSY		000	002	000	000	000	000
38B	0501081804	HOSE ASSY		000	002	000	000	000	000
39	0521052885	15/55 DOUBLE ARTICULATED HYDRAULIC MARKER		000	000	000	000	001	000
39A	0501082037	HOSE 3/8 X 5150 TR-TC		000	000	000	000	002	000
39B	0501081953	3/8 X 4940 TR-TC HOSE		000	000	000	000	002	000
40	0511057890	17 E 500 HYDRAULIC MARKER HOSE ASSEMBLY		000	000	000	000	000	001
40A	0501081981	HOSES		000	000	000	000	000	002
40B	0501081748	HOSE		000	000	000	000	000	002
41	0521052511	3/8 X 5000 TC-TM ROXO/AZUL HOSE		000	000	000	000	000	001
41A	0501080383	3/8" X 197" TC-TM HOSE		000	000	000	000	000	001
41B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		000	000	000	000	000	001
41C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		000	000	000	000	000	001
41D	0503018952	PLASTIC BOLT		000	000	000	000	000	006
42	0521052510	3/8 X 5000 TC-TM ROXO/VERM HOSE		000	000	000	000	000	001
42A	0501080383	3/8" X 197" TC-TM HOSE		000	000	000	000	000	001
42B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		000	000	000	000	000	001
42C	0503034495	HYDRAULIC HOSE GRIP (RED)		000	000	000	000	000	001
42D	0503018952	PLASTIC BOLT		000	000	000	000	000	006
43	0501010617	3/4" NIPPLE		004	004	004	004	004	004




Item	Code	Description	See page	8960	9460	9960	10460	10985
01	0521055204	LIGNE DE DISQUE MARKER	153	002	002	002	002	002
02	0521061790	1750 TURNBUCKLE		002	000	000	000	000
02.	0521064307	EXTENSOR 2400 DOUBLE HEAD		000	002	002	002	002
03	0511060014	ROW MARKER ARM		002	002	002	002	002
04	0521012324	1/2" X 3.2" X 2.54" FASTENER		004	004	004	004	004
05	0511017302	FLAT WASHER		008	008	008	008	008
06	0503010019	1/2" SPRING WASHER		008	008	008	008	008
07	0503010060	1/2" NUT		008	008	008	008	008
08	0503010003	1845 GREASE FITTING		002	002	002	002	002
09	0511060013	ROW MARKER ARM		002	002	002	002	002
10	0503010004	1890 GREASE FITTING		002	002	002	002	002
11	0521011142	1.1/4" X 7.5" AXLE		004	004	004	004	004
12	0501019435	32 X 50 X 1.5 FLAT WASHER		016	016	016	016	016
13	0511061022	ROW MARKER SUPPORT		002	002	002	002	002
14	0511066119	MARKER SUPP FIXER FASTENER		004	004	004	004	004
15	0502010175	HITCH CLAMP		008	008	008	008	008
16	0501010216	3/4" X 4-1/2" BOLT		016	016	016	016	016
17	0503010023	3/4" SPRING WASHER		016	016	016	016	016
18	0503010014	3/4" NUT		016	016	016	016	016
19	0503010523	1/4" X 2" COTTERPIN		016	016	016	016	016
20	0521013347	1.1/4" X 8.4" AXLE		002	002	002	002	002
21	0521011141	1.1/4" X 6.5" AXLE		002	002	002	002	002
22	0501054649	HBM SEQUENTIAL VALVE	154	001	001	001	001	001
23	0511058431	HYDRAULIC CYLINDER	155	002	002	002	002	002
24	0511015573	2.07" X 1.6" TRANSPORT LOCK		002	002	002	002	002
25	0501068994	0.3" X 3.1" LOCK PIN		002	002	002	002	002
26	0503030168	CUPILLA		002	002	002	002	002
27	0511018012	HIDRAULIC ADAPTER		004	004	004	004	004
28	0501053834	MALE QUICK COUPLER	54	002	002	002	002	002
29	0511057739	HYDRAULIC MARKER HAND SET		001	000	000	000	000
29A	0501081982	HOSE		002	000	000	000	000


Item	Code	Description	See page	8960	9460	9960	10460	10985
29B	0501081981	HOSES		002	000	000	000	000
30	0521050879	HYDRAULIC MARKER HOSE ASSY		000	000	001	000	000
30A	0501081447	3/8 X 6600 TC-TR HOSE		000	000	002	000	000
30B	0501080744	3/8" X 248" TR-TC HOSE ASSY		000	000	002	000	000
31	0511057526	HYDRAULIC MARKER HAND SET		000	000	000	002	000
31A	0501082035	HOSE		000	000	000	002	000
31B	0501082034	HOSE		000	000	000	002	000
32	0521051377	15 / 450 DOUBLE ARTICULATED HYDRAULIC MARKER		000	000	000	000	001
32A	0501082136	3/8 X 8100 TR-TC HOSE		000	000	000	000	002
32B	0501082135	3/8 X 7900 TR-TC HOSE		000	000	000	000	002
33	0521052513	HOSE 3/8 X 5200 TC-TM PURPLE / BLUE		001	000	001	001	001
33A	0501081980	HOSE 3/8 X 5200 TC-TM		001	001	001	001	001
33B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		001	001	001	001	001
33C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		001	001	001	001	001
33D	0503018952	PLASTIC BOLT		006	006	006	006	006
34	0521052512	HOSE 3/8 X 5200 TC-TM PURPLE / RED		001	000	001	001	001
34A	0501081980	HOSE 3/8 X 5200 TC-TM		001	001	001	001	001
34B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		001	001	001	001	001
34C	0503034495	HYDRAULIC HOSE GRIP (RED)		001	001	001	001	001
34D	0503018952	PLASTIC BOLT		006	006	006	006	006
35	0501080744	3/8" X 248" TR-TC HOSE ASSY		000	002	000	000	000
36	0501081255	TR-TC HOSE ASSY		000	002	000	000	000
37	0501010617	3/4" NIPPLE		004	004	004	004	004




Item	Code	Description	See page	QT
01	0521069643	DISC AXLE MARKER LINE		01
02	0602023094	DR16X3 C36AFPAFR73+4FR+4FR D474 10R		01
03	0581019513	DEPTH WHEEL BOX		01
04	0503019342	ROLLER BEARING		01
05	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503013758	1/4" X 1-1/2" BOLT		03
11	0503010143	1/4" SPRING WASHER		03
12	0503010358	5/16" X 5/8" BOLT		04
13	0503010179	LOCK WASHER		04
14	0503010337	5/16" NUT		04
15	0503034055	CLAMPING RING		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0501067700	2.5" X 25" CYLINDER CASE		01
02	0521066632	EXTENDER		01
03	0503030384	CON PLUG N-001		02
04	0502012837	PISTON		01
05	0503018005	RING		01
06	0503011109	2-119 N 3006-9B O'RING		01
07	0503010163	D-1500 SCRAPER RING		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503018004	RING		01
11	0503018003	GASKET		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0503010002	1800 GREASE FITTING		02
15	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0561014215	BEARING COVER LOWER ROW FRAME		02
02	0502040534	SPRING GUIDE BUSHING LOCK		08
03	0501018535	1/2 X 1 BOLT		08
04	0581013561	5/8" X 95.8" HEX AXLE		01
05	0511057287	TRANSMISSION		02
06	0571013469	5/8 X 700 HEX AXLE		01
07	0571013468	5/8 X 2040 HEX AXLE		02




Item	Code	Description	See page	QT
01	0571013726	5/8 X 800 HEX AXLE		01
02	0571013724	5/8 X 1250 HEX AXLE		01
03	0571013725	5/8 X 2190 HEX AXLE		02
04	0503062206	CARDAN TERMINAL	168	02
05	0561014215	BEARING COVER LOWER ROW FRAME		02
06	0502040534	SPRING GUIDE BUSHING LOCK		08
07	0501018535	1/2 X 1 BOLT		08




Item	Code	Description	See page	QT
01	0571013469	5/8 X 700 HEX AXLE		01
02	0571013470	5/8 X 1100 HEX AXLE		01
03	0581013887	5/8 X 2560 HEX AXLE		02
04	0511057287	TRANSMISSION		02
05	0561014215	BEARING COVER LOWER ROW FRAME		02
06	0502040534	SPRING GUIDE BUSHING LOCK		08
07	0501018535	1/2 X 1 BOLT		08




Item	Code	Description	See page	QT
01	0581018862	HEX AXLE 5/8 X 850		02
02	0571014914	SHAFT AXLE		02
03	0511059233	INTERMEDIATE TRANSMISSION	167	02
04	0561014215	BEARING COVER LOWER ROW FRAME		02
05	0502040534	SPRING GUIDE BUSHING LOCK		08
06	0501018535	1/2 X 1 BOLT		08




Item	Code	Description	See page	QT
01	0571013724	5/8 X 1250 HEX AXLE		01
02	0581015231	2475 - 15 E500 5/8" X 60.4" HEX AXLE		02
03	0571013726	5/8 X 800 HEX AXLE		01
04	0561014215	BEARING COVER LOWER ROW FRAME		02
05	0502040534	SPRING GUIDE BUSHING LOCK		08
06	0501018535	1/2 X 1 BOLT		08
07	0511059233	INTERMEDIATE TRANSMISSION	167	02




Item	Code	Description	See page	QT
01	0571013470	5/8 X 1100 HEX AXLE		01
02	0581015232	2735 - 17 E 500 5/8" X 60.4" HEX AXLE		02
03	0581012154	HEX 5/8 X AXIS 755		01
04	0561014215	BEARING COVER LOWER ROW FRAME		02
05	0502040534	SPRING GUIDE BUSHING LOCK		08
06	0501018535	1/2 X 1 BOLT		08
07	0511059233	INTERMEDIATE TRANSMISSION	167	02




Item	Code	Description	See page	QT
01	0561014215	BEARING COVER LOWER ROW FRAME		02
02	0502040534	SPRING GUIDE BUSHING LOCK		08
03	0501018535	1/2 X 1 BOLT		08
04	0571014914	SHAFT AXLE		02
05	0511059233	INTERMEDIATE TRANSMISSION	167	02
06	0571013724	5/8 X 1250 HEX AXLE		02




Item	Code	Description	See page	QT
01	0571015984	5/8 HEX AXLE		01
02	0571014914	SHAFT AXLE		02
03	0571013724	5/8 X 1250 HEX AXLE		01
04	0561014215	BEARING COVER LOWER ROW FRAME		02
05	0502040534	SPRING GUIDE BUSHING LOCK		08
06	0501018535	1/2 X 1 BOLT		08
07	0511059233	INTERMEDIATE TRANSMISSION	167	02




Item	Code	Description	See page	QT
01	0561014215	BEARING COVER LOWER ROW FRAME		02
02	0502040534	SPRING GUIDE BUSHING LOCK		08
03	0501018535	1/2 X 1 BOLT		08
04	0581013848	HEX AXIS 5/8 X 3220		02
05	0571013724	5/8 X 1250 HEX AXLE		02
06	0511059233	INTERMEDIATE TRANSMISSION	167	02




Item	Code	Description	See page	QT
01	0561014215	BEARING COVER LOWER ROW FRAME		02
02	0502040534	SPRING GUIDE BUSHING LOCK		08
03	0501018535	1/2 X 1 BOLT		08
04	0581013848	HEX AXIS 5/8 X 3220		02
05	0581014408	5/8" X 69.3" HEX AXLE		01
06	0571013724	5/8 X 1250 HEX AXLE		01
07	0511059233	INTERMEDIATE TRANSMISSION	167	02




Item	Code	Description	See page	QT
01	0561014215	BEARING COVER LOWER ROW FRAME		02
02	0502040534	SPRING GUIDE BUSHING LOCK		08
03	0501018535	1/2 X 1 BOLT		08
04	0581014744	HEX AXIS 5/8 X 3235		02
05	0581014215	5/8" X HEX AXLE		02
06	0511059233	INTERMEDIATE TRANSMISSION	167	02




Item	Code	Description	See page	QT
01	0503062206	CARDAN TERMINAL	168	01
02	0503030331	1.2" X 1.2" X 12.2" HOSE		01
03	0503010243	CLAMP		02
04	0503011855	0.2" X 1.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503062206	CARDAN TERMINAL	168	01




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		16
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		03
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	175	03
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		15




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		17
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		03
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	175	03
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		15




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		21
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		04
04	0503012903	T-80M CRAMP NYLON		60
05	0521052792	MOUNTED REAR LIGHT	175	04
06	3505151602	TUBE		0,4mt
07	0503017702	FIXER		20



Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		22
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		05
04	0503012903	T-80M CRAMP NYLON		70
05	0521052792	MOUNTED REAR LIGHT	175	05
06	3505151602	TUBE		0,5mt
07	0503017702	FIXER		25




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		24
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		06
04	0503012903	T-80M CRAMP NYLON		80
05	0521052792	MOUNTED REAR LIGHT	175	06
06	3505151602	TUBE		0,6mt
07	0503017702	FIXER		30




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		26
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		06
04	0503012903	T-80M CRAMP NYLON		80
05	0521052792	MOUNTED REAR LIGHT	175	06
06	3505151602	TUBE		0,6mt
07	0503017702	FIXER		30

MOUNTED REAR LIGHT


0521052792




Item	Code	Description	See page	QT
01	0503018738	LIGHTHOUSE		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	LOCK WASHER		04
08	0503010337	5/16" NUT		04



Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER		03
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521015501	COUPLING SHAFT		03
04	0503010523	1/4" X 2" COTTERPIN		06
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		03
06	0531012565	SLEEVE 16,3X 30 X 88		03
07	0503010027	5/8" SPRING WASHER		03
08	0503010013	5/8" NUT		03
09	0551014099	COUPLING SHAFT 31,75 X 185		01




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER		01
06	0503010337	5/16" NUT		01



Item	Code	Description	See page	QT
01	0521053227	FRONT LEFT SHORT SEED ROW	179	01
02	0521053230	FRONT RIGHT SHORT SEED ROW	180	01
03	0521053228	FRONT LEFT LONG SEED ROW	181	01
04	0521053229	FRONT RIGHT LONG SEED ROW	182	01
05	0521054737	FRONT SEMI-ASSEMBLED LONG LEFT SEED ROW	183	01
06	0521054736	FRONT SEMI-ASSEMBLED OF LONG RIGHT SEED LINE	184	01
07	0511059333	SEMI-ASSEMBLED MECHANICAL FRAME	194	01
08	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
09	0503010019	1/2" SPRING WASHER		01
10	0503010060	1/2" NUT		01
11	0521054771	LEFT REAR SEED ROW	197	01
12	0521054770	RIGHT REAR SEED ROW	198	01
13	0521054758	CONTROL DEPTH WITH REGULATOR	206	01
13.	0521054984	DEPTH/COMPACTOR SYSTEM - SPT	216	01
13..	0521055032	DEPTH SYSTEM WHEELS ASSY IRON WITHOUT LUBRICATION	227	01
13...	0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	231	01
14	0521054811	FERTILIZER SHORT LINE	237	01
15	0521054812	LONG FERTILIZER LINE	238	01
16	0521054769	LEFT FERTILIZER WITH SUPPORT	244	01
17	0521054768	DDD RIGHT FERTILIZER WITH SUPPORT	246	01
18	0511057017	SEED SYSTEM ASSY	248	01
19	0511052024	FAST CLOSING SET	251	01
20	0503010905	1/2" X 2-1/4" BOLT		01
21	0503030391	RIGHT FERTILIZER NOZZLE		01
22	0503030392	LEFT FERTILIZER NOZZLE		01
23	0503031050	CURVED CONDUCTOR		01
24	0503010246	CLAMP		01
25	0503031076	2" HOSE CLAMP		01
26	0503031145	2" X 2" X 20" HOSE		01
27	0503010019	1/2" SPRING WASHER		01

Item	Code	Description	See page	QT
28	0503010060	1/2" NUT		01
29	0531013600	PRESS ADJUSTMENT LEVER		01
30	0521053946	SCARING ROD	252	01
31	0511017969	0.1" SPACING PLATE		01
32	0521069127	BOTTOM NOZZLE FERTILIZER		01
33	0503030483	FERTILIZER SOCKET		01
34	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
35	0501010984	FLAT WASHER		01
36	0503010025	3/8" SPRING WASHER		01
37	0503010026	3/8" NUT		01
38	0503016204	CORN DISK 12 ORANGE		01
38.	0503016218	DISC OF SOYBEAN		01
39	0503016214	RING CORN (APOLLO740)		01
39.	0503016220	RING TO SOYBEANS (APOLLO 745)		01
39..	0503016221	RING TO SOYBEANS (APOLLO 571)		01
40	0503033672	NOZZLE WITHOUT TITANIUM		01
41	0521018501	TURNBUCKLE LEVER		01
42	0521053947	AUTOMATIC DISARMING ROD	253	01
43	0581010082	FERTILIZER SOCKET RIGHT		01
44	0581010083	FERTILIZER SOCKET LEFT		01
45	0503030520	SEED SOCKET		01
46	0501050120	LARGER WALKING BEAM ASSY	256	01
47	0503030558	PULLEY 4Z CORN PLASTIC		01
48	0511018662	SPACING PLATE		01
49	0521068982	KEY CASH DISC CUTTING		01




Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	185	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	186	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	CUPILLA		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	187	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	188	01
20	0521064651	LEFT SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	192	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06



FRONT LEFT SHORT SEED ROW

0521053227


Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08



Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
03	0521055213	LINE BEARING SEED	185	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	186	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	CUPILLA		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	187	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	188	01
20	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	192	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06



Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	185	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	186	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	CUPILLA		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	187	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	188	01
20	0521064650	LEFT SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	192	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06



FRONT LEFT LONG SEED ROW

0521053228

Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	185	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	186	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	CUPILLA		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	187	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	188	01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	192	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06

**FRONT RIGHT LONG SEED ROW**

0521053229


Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08



Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0503010045	O'RING		08
03	0521055213	LINE BEARING SEED	185	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	186	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	CUPILLA		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	187	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
20	0521064650	LEFT SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	192	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06



Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01




Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0503010045	O'RING		08
03	0521055213	LINE BEARING SEED	185	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	186	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	CUPILLA		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	187	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	192	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06




PST TRIO FLEX - FRAME 6850/7450/7860/7960/8160/8460
FRONT SEMI-ASSEMBLED OF LONG RIGHT SEED LINE

Page 184
0521054736


Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01




Item	Code	Description	See page	QT
01	0502012718	BEARIN BODY		01
02	0503019355	BEARING 6202 2RS1		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	BOX TRANSMISSION COVER		01
03	0503019361	BEARING 6006 RS1		02
04	0503019363	BEARING 6005		01
05	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503019362	BEARING 6005 RS1		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501059326	UNIVERSAL JOINT AXLE	189	01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0521055227	BEARING SHAFT HEX	190	01




Item	Code	Description	See page	QT
01	0561016322	5/8" HEX AXLE		01
02	0501056296	UNIVERSAL JOINT		01
03	0503011855	0.2" X 1.8" SPRING PIN		02
04	0561014794	350 AXLE HEX		01




Item	Code	Description	See page	QT
01	0501059363	5/8" HEX AXLE BEARING	191	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0561014911	AXLE SLEEVE GUIDES HEX		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		02




Item	Code	Description	See page	QT
01	0502012819	17Z GEAR WITH HEX HOLE		01
02	0521055220	BEARING FRONT LINE SEED	193	01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503019356	BEARING 6005 2RS1		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521066496	FRAME MECHANICAL CENTRAL SEED LINE		01
02	0511059334	BEARING WITH LONG FRONT AXLE	195	01




Item	Code	Description	See page	QT
01	0511058143	UNIVERSAL JOINT AXLE	196	01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0521055227	BEARING SHAFT HEX	190	01




Item	Code	Description	See page	QT
01	0561014794	350 AXLE HEX		01
02	0501056296	UNIVERSAL JOINT		01
03	0503011855	0.2" X 1.8" SPRING PIN		02
04	0581010483	HEX AXLE		01




Item	Code	Description	See page	QT
01	0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	199	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0521055871	LEFT DOUBLE DISC SEED 15 X 15		01




Item	Code	Description	See page	QT
01	0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	199	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0521055870	RIGHT DOUBLE DISC SEED 15 X 15		01




Item	Code	Description	See page	QT
01	0581019201	CROWN SHAFT		01
02	0503019340	LUBRICANT GLOVE		02
03	0503011030	2-014 N 3006-9B O'RING		02
04	0581019200	CONICA 40Z GEAR		01
05	0581019199	FIXED BASE		01
06	0581019202	PINHAO CONICO 10Z X 5/8		01
07	0501013354	FLAT WASHER		01
08	0503010410	RING		02
09	0503019341	LUBRICANT GLOVE		01




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	202	01
02	0521054761	LEFT LOW CUBE	204	01
03	0521054760	DOWN LOW CUBE	205	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0511015098	FLAT WASHER		04
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	203	01
02	0521054761	LEFT LOW CUBE	204	01
03	0521054760	DOWN LOW CUBE	205	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0511015098	FLAT WASHER		04
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502012736	HUB LOWR DDD		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06



Item	Code	Description	See page	QT
01	0502012736	HUB LOWR DDD		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06



Item	Code	Description	See page	QT
01	0521054751	DEPTH CONTROL WITH THREAD	207	01
02	0511055819	DEPTH WHIT AROS BAND	212	02
03	0521054752	V COMPACTING SYSTEM	213	01
04	0503010479	BOLT		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2" NUT		02
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
08	0503013816	5/16" LOCKNUT		08
09	0521054753	DRIVE WHEEL V RUBBER RIGHT	214	01
10	0521054754	DRIVE WHEEL V LEFT RUBBER	215	01




Item	Code	Description	See page	QT
01	0581017621	CONTROL AXLE		01
02	0521063812	REGULATOR LEVER ALXE		01
03	0503011336	1/2" HEX SELF ADJUSTING NUT		01
04	0511065308	LOCK REGULATOR		01
05	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
06	0541011627	FLAT WASHER		01
07	0503010140	1/8" X 3/4" COTTERPIN		01
08	0521053245	LEFT ARM WHEELS	208	01
09	0521053244	ARM RIGHT WHEEL COBRIDORA	209	01
10	0581017646	SLEEVE LOCK CONTROL ARM		02
11	0571013189	SLEEVE SUPPORT BEATER		01
12	0521063813	WHEEL PRESS BEATER		01
13	0501010937	13.5 X 28 X 3 FLAT WASHER		01
14	0503010045	O'RING		04
15	0503017375	1/2" X 1-1/4" BOLT		01
16	0503014007	1/2" X 1-1/4" BOLT		01
17	0503010019	1/2" SPRING WASHER		03
18	0503010920	1/2" X 1.1/2" BOLT		01
19	0503010023	3/4" SPRING WASHER		04
20	0521053483	CPRA RIGHT DEPTH CONTROL CUBE WITHOUT LUBRICATION		01
21	0521053484	CPRA LEFT DEPTH CONTROL CUBE WITHOUT LUBRICATION		01
22	0581019171	REGULATOR		01
23	0521069476	EXTERNAL COLUMN CONTROL DEPTH		01
24	0521069475	INTERNAL COLUMN CHECK DEPTH		01
25	0503010683	0,2" X 1,2" SPRING PIN		01
26	0503034830	REGULATION LATCHE		01
27	0521054750	CRANK ASSEMBLY		01
27A	0521069477	HAND CRANK		01
27B	0503030878	LEVER CRANK		01
28	0503030751	REGULATOR PLATE		01




Item	Code	Description	See page	QT
29	0503010001	3.2 X 5.5 RIVET		04

LEFT ARM WHEELS


0521053245




Item	Code	Description	See page	QT
01	0581017620	LEFT ARM WHEELS		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503019275	SLEEVE LUBRICATION SYSTEM		01




Item	Code	Description	See page	QT
01	0581011340	ARM COVER		01
02	0503011402	0.2" X 0.8" SPRING PIN		02
03	0581017645	WHEEL RIGHT ARM		01
04	0503019275	SLEEVE LUBRICATION SYSTEM		01




Item	Code	Description	See page	QT
01	0581019165	CASE WHEEL DEPTH WITHOUT GREASE FITTING		01
02	0503015081	502052 CLAMPING RING (FOR AXLE)		01
03	0503014679	2-134 O'RING		01
04	0581019170	CUBE COVER		01
05	0501010984	FLAT WASHER		01
06	0503010025	3/8" SPRING WASHER		01
07	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
08	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
09	0581019166	RIGHT AXIS		01
10	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		01




Item	Code	Description	See page	QT
01	0581019165	CASE WHEEL DEPTH WITHOUT GREASE FITTING		01
02	0503015081	502052 CLAMPING RING (FOR AXLE)		01
03	0503014679	2-134 O'RING		01
04	0581019170	CUBE COVER		01
05	0581019167	LEFT AXLE		01
06	0501010984	FLAT WASHER		01
07	0503010025	3/8" SPRING WASHER		01
08	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
09	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
10	0503019348	SCREW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503013758	1/4" X 1-1/2" BOLT		05
04	0503013814	1/4" NC LOCKNUT		05




Item	Code	Description	See page	QT
01	0581017647	PRESS WHEELS ARM		01
02	0503030883	RIGHT TORSION SPRING		01
03	0581017622	SEAT SUPPORT		01
04	0581017648	PIVOT SHAFT		01
05	0503010839	03"X 0.6" SPRING PIN		01
06	0521069490	RIGHT REGULATOR		01
07	0521069491	LEFT REGULATOR		01
08	0581017817	ADJUSTMENT SHAFT COMPACTOR 1/2 THREAD WITHOUT LUBRICATION		01
09	0521063812	REGULATOR LEVER ALXE		01
10	0503011336	1/2" HEX SELF ADJUSTING NUT		02
11	0511065308	LOCK REGULATOR		01
12	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
13	0541011627	FLAT WASHER		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0571013293	SLEEVE LOCK COMPACTOR V CONTROL WITH SCREW		01
16	0581013744	PROTECTION COVER - CPRA		01
17	0503013096	5/16" X 4" BOLT		01
18	0503013816	5/16" LOCKNUT		01
19	0503019273	SLEEVE		02
20	0503010045	O'RING		02
21	0503010025	3/8" SPRING WASHER		02
22	0503010026	3/8" NUT		02
23	0503011404	BOLT		02
24	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01




Item	Code	Description	See page	QT
01	0581019097	BOX LOWER WHEEL		01
02	0581012949	BEARING COVER		01
03	0503018045	2-130 (AGEL) O'RING		01
04	0503011105	SEAL RING		01
05	0502012893	WHEEL BOX		01
06	0521018928	PRESS WHEEL RIM		02
07	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
08	0503013816	5/16" LOCKNUT		09
09	0503010011	5/16" X 1/2" BOLT		06
10	0503010358	5/16" X 5/8" BOLT		03
11	0581019166	RIGHT AXIS		01
12	0501010984	FLAT WASHER		01
13	0503010025	3/8" SPRING WASHER		01
14	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
15	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		01
16	0503033787	NUT 3/4 UNF		01
17	0581019215	DUST CLOAK		01




Item	Code	Description	See page	QT
01	0581019097	BOX LOWER WHEEL		01
02	0581012949	BEARING COVER		01
03	0503018045	2-130 (AGEL) O'RING		01
04	0503011105	SEAL RING		01
05	0502012893	WHEEL BOX		01
06	0521018928	PRESS WHEEL RIM		02
07	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
08	0503013816	5/16" LOCKNUT		09
09	0503010011	5/16" X 1/2" BOLT		06
10	0503010358	5/16" X 5/8" BOLT		03
11	0581019167	LEFT AXLE		01
12	0501010984	FLAT WASHER		01
13	0503010025	3/8" SPRING WASHER		01
14	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
15	0503033788	NUT 3/4		01
16	0503019348	SCREW 3/8 UNC X 3/4		01
17	0581019215	DUST CLOAK		01




Item	Code	Description	See page	QT
01	0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	217	01
02	0501052538	DEPTH BAND WITH ARMS	223	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0521054990	LEFT COMPACTOR WHEEL	224	01
06	0521055017	RIGHT COMPACTOR WHEEL	225	01




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	218	01
02	0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	219	01
03	0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	220	01
04	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	222	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	SCREW 3/8 UNC X 3/4		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED GLOVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	221	01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	221	01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL BOX		01
02	0581019515	AXIS		01
03	0503034055	CLAMPING RING		01
04	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
05	0503013758	1/4" X 1-1/2" BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0503010878	5/8" SELF ALIGNING NUT		01
10	0503030757	2.9" X 2" X 0.02" JOINT		01
11	0521019178	COVER DEPTH		01




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT GLOVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	226	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	226	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	217	01
02	0501052538	DEPTH BAND WITH ARMS	223	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0521055019	IRON IN RIGHT WHEEL COMPACTOR V	228	01
06	0521055018	WHEEL DRIVE WHEEL LEFT IN V	229	01




Item	Code	Description	See page	QT
01	0503010752	1/2" X 3.1/2" BOLT		01
02	0521014508	FLAT WASHER		04
03	0521054991	WHEEL DRIVE WHEEL RIGHT	230	01




Item	Code	Description	See page	QT
01	0503013739	1/2" X 1" BOLT		01
02	0521014508	FLAT WASHER		04
03	0521054991	WHEEL DRIVE WHEEL RIGHT	230	01




Item	Code	Description	See page	QT
01	0581019509	IRON WHEEL COMPACTOR		01
02	0503011105	SEAL RING		01
03	0503013848	5072-BR SEAL		02
04	0511011927	DUST CLOAK		02
05	0503019342	ROLLER BEARING		01
06	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521055065	ASSY DEPTH / COMPACTOR	232	01
02	0521055068	RAYED WHEEL CENTER CLOSED	235	02
03	0521054990	LEFT COMPACTOR WHEEL	224	01
04	0521055017	RIGHT COMPACTOR WHEEL	225	01
05	0503016453	1/2" X 2.1/2 BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010028	1/2" NUT		02




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0571013054	DEPTH CONTROL WHEEL AXLE		01
04	0502012663	EXTENSION		01
05	0501056769	DEPTH WHEELS REGULATOR ASSY		01
06	0503019398	AXLE RETAINER RING		01
07	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	222	01
08	0521055054	LEFT ARM WITH SLEEVE	233	01
09	0521055066	RIGHT ARM WITH GLOVE	234	01
10	0511015346	FLAT WASHER		04
11	0571015974	WASHER		02
12	0511017302	FLAT WASHER		02
13	0503010256	3/8" X 3/4" BOLT		01
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		04
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2" NUT		02
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0581019473	ARTICULATED GLOVE		02
20	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0581019523	LEFT ARM WHEEL DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019524	RIGHT ARM DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	236	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	LOCK WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0581019522	CASE WHEEL DEPTH WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0503010143	1/4" SPRING WASHER		03
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019529	DEPTH REGULATOR SHAFT		01
11	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01




Item	Code	Description	See page	QT
01	0501010066	3/4" X 9" BOLT		01
02	0511017232	FLAT WASHER		02
03	0503011255	3/4" LOCK NUT		01
04	0502012873	SUPPORT DC LINE FERTILIZER		01
05	0503019278	LUBRICANT GLOVE		02
06	0581019195	SIDE GUIDE GLOVE		02
07	0581019196	CENTRAL GUIDE GLOVE		01
08	0503010410	RING		02
09	0502012876	CLAMP		01
10	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
11	0503010013	5/8" NUT		02
12	0521054906	SPRING ASSY FERTILIZER	243	01
13	0521053231	DPL 20 SHORT LINE WITHOUT LUBRICATION CONICAL BEARING	239	01
14	0521066231	SHORT FERTILIZER LINE ARM		01
15	0503017857	BOLT 5/8 UNF 4		03
16	0503010811	5/8" UNF SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0501010066	3/4" X 9" BOLT		01
02	0511017232	FLAT WASHER		02
03	0503011255	3/4" LOCK NUT		01
04	0502012873	SUPPORT DC LINE FERTILIZER		01
05	0503019278	LUBRICANT GLOVE		02
06	0581019195	SIDE GUIDE GLOVE		02
07	0581019196	CENTRAL GUIDE GLOVE		01
08	0503010410	RING		02
09	0502012876	CLAMP		01
10	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
11	0503010013	5/8" NUT		02
12	0521054906	SPRING ASSY FERTILIZER	243	01
13	0521053232	DPL 20 LONG LINE WITHOUT LUBRICATION CONICAL BEARING	240	01
14	0521066230	LONG FERTILIZER LINE ARM		01
15	0503017857	BOLT 5/8 UNF 4		03
16	0503010811	5/8" UNF SELF ADJUSTING NUT		03



Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	241	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	241	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012824	FIXING SHAFT DISC CUT LINE		01



Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	CUTTING DISK BOX	242	01

CUTTING DISK BOX


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4	01	
02	0502040872	REGULATORY NUT	01	
03	0503010370	502072 CLAMPING RING (FOR AXLE)	02	
04	0503010590	00674-B SEAL	02	
05	0503019285	RING	02	
06	0503012170	30207 ROLLER BEARING	02	
07	0502020641	BLADE DISC FLANGE	01	
08	0502012862	CUTTING DISK BOX	01	
09	0502040873	CUTTING DISC AXLE	01	
10	0503017755	NUT	01	
11	0503018825	5/16 UNC UNC BOLT	06	
12	0501010694	FLAT WASHER	06	
13	0503013816	5/16" LOCKNUT	06	
14	0511017907	1/8" BSPT X 6 PLUG	02	

SPRING ASSY FERTILIZER


0521054906




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK		02
02	0502012184	FERTILIZER SPRING GUIDE		02
03	0503031910	1.7" X 22.8" X 0.3" SPRING		01
04	0502012510	SPRING ROD SUPPORT		01
05	0591018219	JUNCTION SHAFT 12.70 X 109 ZN		01
06	0501018535	1/2 X 1 BOLT		02
07	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		02
08	0503010060	1/2" NUT		02
09	0502010891	SPRING CHOCK SUPPORT VARON		01
10	0503010014	3/4" NUT		01
11	0521067619	TUBE LINE FERTILIZER		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0501010937	13.5 X 28 X 3 FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	204	01
03	0521054760	DOWN LOW CUBE	205	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511015098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	204	01
03	0521054760	DOWN LOW CUBE	205	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511015098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016219	RING TO SOYBEANS		01
03	0503010025	3/8" SPRING WASHER		04
04	0503010209	3/8" UNC BUTTERFLY NUT		03
05	0503016283	M8 NUT HEX		01
06	0502020693	SUPPORT SEED BOX		01
07	0502012721	SEED DISC LOWER TRAIL		01
08	0503030083	3/8" X 3/8" X 1.6" STUD		02
09	0503016282	ALLEN BOLT		01
10	0503010675	5/16" X 2.1/4" BOLT		01
11	0503010179	LOCK WASHER		05
12	0503010337	5/16" NUT		01
13	0501010694	FLAT WASHER		04
14	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
15	0501051094	ASSY SEED DISTRIBUTOR	249	01
16	0503031508	COVER GREEN BEAM SEED YELLOW		01
17	0571018536	HEX PRISONER		01
18	0501013518	FLAT WASHER		02
19	0503034131	DEFLECTOR		01



Item	Code	Description	See page	QT
01	0503030381	SEED DISTRIBUTOR BOX		01
02	0502010447	TRIGGER		02
03	0501013467	KEY AXLE		01
04	0503030378	0.4" X 1.1" X 0.03" SPRING		03
05	0501013466	KEY LIMITER AXLE		01
06	0501051119	DOUBLE PULLEY ROCKER'S	250	01
07	0501013468	ROCKER ARM AXLE, OF THE PULLEY		01
08	0503030377	SCRAPER		01




Item	Code	Description	See page	QT
01	0503031129	DOUBLE PULLEY ROCKER ARM		01
02	0503031128	5Z PLASTIC DOUB PULLEY FOR SOYBEAN		02
03	0521010649	TOOTH PULLEY COUPLING SHAFT		01
04	0503011853	503050 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02

SCARING ROD


0521053946




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070085	FIXED ROD BEARING		01
03	0513010288	ELASTIC PIN 701211 10 X 24		02
04	0513010289	ELASTIC PIN 701211 10 X 24		02




Item	Code	Description	See page	QT
01	0521068567	BOX SPRING		01
02	0521053951	STEM	254	01
03	0503034106	80 X 230 X 16,50 HDA COMPRESSION SPRING		01
04	0581012094	SUPPORT WASHER		01
05	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
06	0571019462	SUPPORT GUIDE PRING		01
07	0503012795	5/8" HEX SELF ADJUSTING NUT		01
08	0503010691	1/4" GREASE FITTING		01
09	0503010384	1/2" X 5" BOLT		02
10	0511017302	FLAT WASHER		04
11	0503011336	1/2" HEX SELF ADJUSTING NUT		04
12	0503017874	BOLT 1/2 UNC		02
13	0571018541	BODY SOCKET FERTILIZER		01
14	0503010026	3/8" NUT		02
15	0503010025	3/8" SPRING WASHER		02
16	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
17	0501010984	FLAT WASHER		04
18	0503010417	7/8" NUT		01
19	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
20	0581012084	ARTICULATED GLOVE		01
21	0581012082	SCREW		01
22	0581012081	GLOVE		01




Item	Code	Description	See page	QT
01	0521053932	ROD WITH BEAK 0869	255	01
02	0521067065	FLANGE WASHER SPRING		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0581012092	AXLE FIXER		01
05	0521015818	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521067523	STEM WITHOUT BEAK DISARM		01
02	0502040901	FIXED ROD NOZZLE		01
03	0503016853	SPRING PIN		02
04	0503011402	0.2" X 0.8" SPRING PIN		02



Item	Code	Description	See page	QT
01	0503030379	LARGER ROCKER ARM		01
02	0502060001	PLASTIC PULLEY FOR MAIZE		01
03	0503010669	FLAT WASHER		01
04	0503010667	3/16" NUT		02
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		01



Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

