

ROW CROP PLANTERS

PST DUO FLEX - FRAME
4880/5340/5950/6350/6850 - CSU
(UP TO 03/2022)

Code: 0501092426
Series: S-0119
Revision: 00
Date Revision: MARÇO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS

Code	Description
0111240314	PST DUO FLEX 4880/10E500 CI MH DC20 CSU S-0119
0111240469	PST DUO FLEX 4880/10E500 CPERA D DC20 CSU S-0119
0111240404	PST DUO FLEX 4880/10E500 ESPECIAL S-0119
0111240477	PST DUO FLEX 4880/10E500 ESPECIAL S-0119
0111240346	PST DUO FLEX 4880/10E500 ESPECIAL S-0119
0111240318	PST DUO FLEX 4880/11E450 CI MH DC20 CSU S-0119
0111240478	PST DUO FLEX 4880/11E450 CPERRA D DC20 CSU S-0119
0111240417	PST DUO FLEX 4880/11E450 CPRA CI DC20 CSU S-0119
0111240458	PST DUO FLEX 4880/11E450 D/HDA BC DC20 CSU S-0119
0111240447	PST DUO FLEX 4880/11E450 ESPECIAL S-0119
0111240457	PST DUO FLEX 4880/11E450 ESPECIAL S-0119
0111240487	PST DUO FLEX 4880/11E450 ESPECIAL S-0119
0111240516	PST DUO FLEX 4880/11E450 ESPECIAL S-0119
0111240345	PST DUO FLEX 4880/11E450 ESPECIAL S-0119
0111240342	PST DUO FLEX 4880/11E450CPRA CI MH DC20 CSU S-0119
0111240358	PST DUO FLEX 5340/10E550 CI MH DC20 CSU S-0119
0111240322	PST DUO FLEX 5340/11E500 CI MH DC20 CSU S-0119
0111240354	PST DUO FLEX 5340/11E500 ESPECIAL S-0119
0111240416	PST DUO FLEX 5340/11E500 ESPECIAL S-0119
0111240326	PST DUO FLEX 5950/12E500 CI MH DC20 CSU S-0119
0111240476	PST DUO FLEX 5950/12E500 CPERRA D DC20 CSU S-0119
0111240501	PST DUO FLEX 5950/12E500 ESP S-0119
0111240472	PST DUO FLEX 5950/12E500 ESPECIAL S-0119
0111240492	PST DUO FLEX 5950/12E500 ESPECIAL S-0119
0111240460	PST DUO FLEX 5950/12E500 H CI MH DC20 CSU S-0119
0111240367	PST DUO FLEX 5950/12E500CPRA CI MH DC20 CSU S-0119
0111240330	PST DUO FLEX 5950/13E450 CI MH DC20 CSU S-0119
0111240359	PST DUO FLEX 5950/13E450 ESPECIAL S-0119
0111240364	PST DUO FLEX 5950/13E450 ESPECIAL S-0119
0111240365	PST DUO FLEX 5950/13E450 ESPECIAL S-0119

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.

PRODUCTS

0111240334	PST DUO FLEX 6350/13E500 CI MH DC20 CSU S-0119
0111240455	PST DUO FLEX 6350/13E500 ESPECIAL S-0119
0111240519	PST DUO FLEX 6350/13E500 ESPECIAL S-0119
0111240338	PST DUO FLEX 6850/14E500 CI MH DC20 CSU S-0119
0111240412	PST DUO FLEX 6850/14E500 ESPECIAL S-0119
0111240495	PST DUO FLEX 6850/14E500 ESPECIAL S-0119

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909095194	FRAME ASSY	1
0521054576	FRAME WITH ARTICULATION 4880	2
0521054567	RIGHT FRAME WITH WHEELED AXLE 4880	3
0521054569	FRAME LEFT WITH SHAFT WHEELED 4880	4
0521054577	FRAME WITH ARTICULATION 5340	5
0521054570	RIGHT FRAME WITH WHEELED AXLE 5340	6
0521054571	FRAME LEFT WITH SHAFT WHEELED 5340	7
0521054578	FRAME WITH ARTICULATION 5950	8
0521054572	RIGHT FRAME WITH WHEELED AXLE 5950	9
0521054573	FRAME LEFT WITH SHAFT WHEELED 5950	10
0521054579	FRAME WITH ARTICULATION 6350	11
0521054574	RIGHT FRAME WITH WHEELED AXLE 6350	12
0521054575	FRAME LEFT WITH SHAFT WHEELED 6350	13
0521053418	FRAME WITH ARTICULATION 6850	14
0521053420	RIGHT FRAME WITH WHEELED AXLE 6850	15
0521053419	FRAME LEFT WITH SHAFT WHEELED 6850	16
0511058667	SPRING FLOW ENSEMBLY	17
0521055229	WHEELED WITH 655 DRIFT SPRING WITH TRANSMISSION	18
0521055231	655 WHEELED SUPPORT WITH TRANSMISSION	19
0501058241	WHEEL SUPPORT CHAIN TENSIONER	20
0521055232	WHEEL WITH PNEU	21
0521055233	WHEELED TRANSMISSION WITHOUT TIRE	22
0521055234	WHEELED FASTENER	23
0521055236	INTERMEDIARY CURRENT STRETCHER	24
0521055237	WHEEL FIXED CURRENT STRETCHER	25
0521055235	WHEEL MOBILE CURRENT STRETCHER	26
0521058402	WHEELED WITH 655 DRIFT SPRING WITH TRANSMISSION	27
0521058401	655 WHEELED SUPPORT WITH TRANSMISSION	28
0521058393	WHEEL WITH PNEU 7.00X16 14L PR TT WITH TRANSMISSION	29
0521054561	CYLINDER ASSEMBLY	30
0511058406	HYDRAULIC CYLINDER	31
0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	32
0511056532	ASSY SYSTEM HYDRAULIC 5340	33
0511056808	ASSY SYSTEM HYDRAULIC 6350	34
0511056832	ASSY SYSTEM HYDRAULIC 6850	35
0501054694	FLOW DIVIDING VALVE ASSY	36
0501053834	MALE QUICK COUPLER	37
0909095186	HEADER ASSY	38
0511055096	TRACTOR HITCH	39
0521053310	LEFT EXTENSION HEADER 36.00 - 4880/5720/5950	40
0521053313	LEFT EXTENSION HEADER 36.00 - 5340	41
0521053320	LEFT EXTENSION HEADER 36.00 - 6350	42
0531052540	HEADER ASSY	43
0521053318	LEFT EXTENSION HEADER 36.00 - 6850	44
0521053311	RIGHT EXTENSOR HEAD 36,00 - 4880/5720/5950	45
0521053312	RIGHT EXTENSOR HEAD 36,00 - 5340	46
0521053321	RIGHT EXTENSOR HEAD 36,00 - 6350	47
0521053319	RIGHT EXTENSOR HEAD 36,00 - 6850	48
0531052545	LEFT EXTENSION HEADER 36.00 - 4880/5950	49
0511052311	3 POINT TURNBUCKLE	50
0511056736	HOSE SUPPORT	51
0521054526	SILO FERTILIZER ASSY 4880	52
0521054528	SILO FERTILIZER RIGHT SUPPORT 4880	53
0521054527	LEFT FERTILIZER BEAM SUPPORT 4880	54
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	55



MARCHESAN

INDEX

0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	56
0501053788	3/4 SQUARE AXLE FASTENER	57
0521054534	SILO FERTILIZER ASSY 5340	58
0521054535	SILO FERTILIZER RIGHT SUPPORT 5340	59
0521054536	LEFT FERTILIZER BEAM SUPPORT 5340	60
0521054537	SILO FERTILIZER ASSY 5950	61
0521054539	SILO FERTILIZER RIGHT SUPPORT 5950	62
0521054538	LEFT FERTILIZER BEAM SUPPORT 5950	63
0521054540	SILO FERTILIZER ASSY 6350	64
0521054541	SILO FERTILIZER RIGHT SUPPORT 6350	65
0521054542	LEFT FERTILIZER BEAM SUPPORT 6350	66
0521054543	SILO FERTILIZER ASSY 6850	67
0521054544	SILO FERTILIZER RIGHT SUPPORT 6850	68
0521054545	LEFT FERTILIZER BEAM SUPPORT 6850	69
0909095187	ASSEMBLY TRANSMISSION 4880/5340/5950/6350/6850	70
0501052560	MOTOR AXLE SIGNAL	71
0511051434	TRANSMISSION ACTUATOR	72
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	73
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	74
0521043316	RIGHT GEAR BOX ASSY	75
0521043317	LEFT GEAR BOX ASSY	76
0501058212	SEMI MOUNTED RIGHT CHANGE	77
0501058213	LH GEAR BOX	78
0511059266	CLOSED BEARING	79
0501056271	GEARBOX CLOSED BEARING	80
0501056443	GEAR HOUSING BEARING	81
0501056444	BEARING WITH ROLLING	82
0501048790	AXLE WITH RING	83
0501054655	CHAIN TENSIONER ASSY	84
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	85
0501055112	MICRO GRANULATED CHAIN TENSIONER	86
0521055217	LOWER CURRENT STRETCH	87
0501058254	UPPER SEED CHAIN TENSIONER	88
0521055216	BEARING WITH GEAR	89
0521055218	BEARING GEAR WITH DOUBLE	90
0521055214	BEARING GEAR WITH	91
0521055215	DOUBLE TRANSMISSION BEARING	92
0511054363	CHAIN TENSIONER	93
0521055241	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	94
0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	95
0521055243	655 WHEELED BRACKET WITHOUT TRANSMISSION	96
0521058403	655 WHEELED BRACKET WITHOUT TRANSMISSION	97
0521058394	WHEEL WITH PNEUME	98
0521055239	WHEEL WITH TIRE WITHOUT TRANSMISSION	99
0503062159	WHEEL WITH TIRE	100
0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	101
0521054562	PLATFORM ASSEMBLY 4880	102
0521054563	PLATFORM ASSEMBLY 5340	103
0521054564	PLATFORM ASSEMBLY 5950	104
0521054565	PLATFORM ASSEMBLY 6350	105
0521054566	PLATFORM ASSEMBLY 6850	106
0511056746	HANDRAIL ASSY 4880	107
0511056535	HANDRAIL ASSY 5340	108



MARCHESAN

INDEX

0521054568	HANDRAIL ASSY 5950	109
0511056812	HANDRAIL ASSY 6350	110
0511056836	HANDRAIL ASSY 6850	111
0511054971	JACK ASSEMBLY	112
0511056536	LADDER ASSEMBLY	113
0511056743	SEMI MOUNTED HYDRAULIC MARKER 4880	114
0511056735	SEMI MOUNTED HYDRAULIC MARKER 5340	115
0511056789	SEMI MOUNTED HYDRAULIC MARKER 5720/5950	116
0511056809	SEMI MOUNTED HYDRAULIC MARKER 6350	117
0511056833	SEMI MOUNTED HYDRAULIC MARKER 6850	118
0521056983	SEMI MOUNTED HYDRAULIC MARKER 4880	119
0511058449	HYDRAULIC CYLINDER	120
0501054649	HBM SEQUENTIAL VALVE	121
0521055204	ROW MARKER DISC	122
0511059585	ASSEMBLY CSU C3 SEMI MOUNTED 4880	123
0511059584	2 BOXES WITH 10 CONDUCTORS ASSEMBLY	124
0511057690	3" ARTICULATED SEED CONDUCTOR	125
0521052687	RH SUPPORT TOWER SILO	126
0521051931	LH SUPPORT TOWER SILO	127
0521051927	TOWER SUPPORT HOPPER	128
0521051928	FIXED TOWER SIDE RIGHT SILO SUPPORT WITH SCREW	129
0521051929	SIDE FIXED TOWER LEFT SILO SUPPORT WITH SCREW	130
0511059072	ASSEMBLY CSU C3 SEMI MOUNTED 5340	131
0511057919	2 BOXES WITH 11 CONDUCTORS ASSEMBLY	132
0511058628	ASSEMBLY CSU C3 SEMI MOUNTED 5720/5950	133
0511058802	2 BOXES WITH 13 CONDUCTORS ASSEMBLY	134
0511058924	ASSEMBLY CSU C3 SEMI MOUNTED 6350	135
0511058723	ASSEMBLY CSU C3 SEMI MOUNTED 5950	136
0511058724	2 BOXES WITH 12 CONDUCTORS ASSEMBLY	137
0521054558	ASSEMBLY CSU C3 SEMI MOUNTED 6850	138
0521054560	ASSEMBLY CSU C3 2 BOXES 5/4 2 BOXES 5/3 6850	139
0511058997	ASSEMBLY CSU	140
0511058996	ASSEMBLY CSU	141
0521054580	REAR LIGHTING ASSEMBLY 4880	142
0521054581	REAR LIGHTING ASSEMBLY 5340	143
0521054582	REAR LIGHTING ASSEMBLY 5720/5950	144
0521054583	REAR LIGHTING ASSEMBLY	145
0521054584	REAR LIGHTING ASSEMBLY 6850	146
0521052792	MOUNTED REAR LIGHT	147
0521054585	ASSY MANUAL DOOR	148
0909095195	ASSY SEED / FERTILIZER LINE	149
0521053227	FRONT LEFT SHORT SEED ROW	150
0521053230	FRONT RIGHT SHORT SEED ROW	151
0521053228	FRONT LEFT LONG SEED ROW	152
0521053229	FRONT RIGHT LONG SEED ROW	153
0521054737	FRONT SEMI-ASSEMBLED LONG LEFT SEED ROW	154
0521054736	FRONT SEMI-ASSEMBLED OF LONG RIGHT SEED LINE	155
0521055213	LINE BEARING SEED	156
0521055223	SEED LINE TRANSMISSION BOX	157
0511055260	SEED ROW CHAIN TENSIONER	158
0521055226	BEARING WITH AXLE JOINT	159
0501059326	UNIVERSAL JOINT AXLE	160
0521055227	BEARING SHAFT HEX	161
0501059363	5/8" HEX AXLE BEARING	162
0521055219	BEARING WITH GEAR 17Z HEX 5/8	163



MARCHESAN

INDEX

0521055220	BEARING FRONT LINE SEED	164
0511059333	SEMI-ASSEMBLED MECHANICAL FRAME	165
0521052266	SEMI-ASSEMBLED MECHANICAL FRAME SPA	166
0511059334	BEARING WITH LONG FRONT AXLE	167
0521052268	LONG SHAFT BEARING AND JOINT SPA	168
0521054771	LEFT REAR SEED ROW	169
0521054770	RIGHT REAR SEED ROW	170
0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	171
0521054763	DDD LEFT SEED	172
0521054762	RIGHT DDD SEED	173
0511052302	LH SUPPORT DDD GUIDE	174
0511052301	SUPPORT DDD 15 RIGHT	175
0521054761	LEFT LOW CUBE	176
0521054760	DOWN LOW CUBE	177
0521054984	DEPTH/COMPACTOR SYSTEM - SPT	178
0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	179
0501052538	DEPTH BAND WITH ARMS	180
0501052297	DEPTH WHEELS REGULATOR ASSY	181
0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	182
0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	183
0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	184
0521055033	SEMI-ASSEMBLED COMPACTOR BODY	185
0521054758	CONTROL DEPTH WITH REGULATOR	186
0521054751	DEPTH CONTROL WITH THREAD	187
0521053245	LEFT ARM WHEELS	188
0521053244	ARM RIGHT WHEEL COBRIDORA	189
0521054744	CUBE RIGHT CONTROL DEPTH	190
0521054745	HUB LEFT CONTROL DEPTH	191
0511055819	DEPTH WHIT AROS BAND	192
0521054752	V COMPACTING SYSTEM	193
0521054753	DRIVE WHEEL V RUBBER RIGHT	194
0521054754	DRIVE WHEEL V LEFT RUBBER	195
0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	196
0521055065	ASSY DEPTH / COMPACTOR	197
0521055054	LEFT ARM WITH SLEEVE	198
0521055066	RIGHT ARM WITH GLOVE	199
0521055068	RAYED WHEEL CENTER CLOSED	200
0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	201
0521054990	LEFT COMPACTOR WHEEL	202
0521055017	RIGHT COMPACTOR WHEEL	203
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	204
0521055397	DEEP WHEEL / COMPACTOR SYSTEM	205
0521055398	DEPTH WHEEL	206
0501059228	ADJUSTMENT LEVER	207
0521055399	LEFT ARM WITH WHEEL	208
0521055058	LEFT ARM	209
0521055401	ASSY WHEEL	210
0521055073	ASSEMBLY DEPTH WHEEL BOX	211
0521055400	RIGHT ARM WITH WHEEL	212
0521055074	RIGHT ARM WITH O-RING	213
0521055093	BODY COMPACTOR	214
0521056317	DEPTH CONTROL WITH LEVER ANGLE REGULATOR AXIS CPERA	215
0531050978	DEPTH CONTROL WITH FAST ANGLE REGULATING AXIS	216
0531050980	SEM SEMI-ASSEMBLED CONTROL WITHOUT LUBRICATION	217




MARCHESAN

INDEX

0531050975	LEFT ARM WHEELS DEPTH WITH CUBE WITHOUT LUBRICATION	218
0531050973	RIGHT ARM DEPTH WHEEL WITH HUB WITHOUT LUBRICATION	219
0521056314	LEFT ARM WHEEL DEPTH WITH CUBE CPERA	220
0521056313	RIGHT ARM WHEEL DEPTH WITH CUBE CPERA	221
0521056316	DEPTH WHEEL BOX WITH COMPLETE ANGLE ADJUSTING AXLE	222
0521054811	FERTILIZER SHORT LINE	223
0521054812	LONG FERTILIZER LINE	224
0521053231	DPL 20 SHORT LINE WITHOUT LUBRICATION CONICAL BEARING	225
0521053232	DPL 20 LONG LINE WITHOUT LUBRICATION CONICAL BEARING	226
0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	227
0521053697	CUTTING DISK BOX	228
0521054906	SPRING ASSY FERTILIZER	229
0521054769	LEFT DDD FERTILIZER WITH SUPPORT	230
0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	231
0521054765	DDD LEFT FERTILIZER	232
0521054764	DDD RIGHT FERTILIZER	233
0521052273	ASSY SEED PIPE SYSTEM WITH GLOVE	234
0511059023	SEED SYSTEM ASSY	235
0501051094	ASSY SEED DISTRIBUTOR	236
0501051119	DOUBLE PULLEY ROCKER'S	237
0511052024	FAST CLOSING SET	238
0521053947	AUTOMATIC DISARMING ROD	239
0521053951	STEM	240
0521053932	ROD WITH BEAK 0869	241
0521050525	FIXER FERTILIZER CONDUCTOR	242
0521053946	SCARING ROD	243
0501110723	SCARIFIER ROD	244
0501054292	V RIGHT WHEEL PRESS FERTILIZER ASSY	245
0501054293	V LEFT WHEEL PRESS FERTILIZER ASSY	246
0511054333	COMPACT WHEEL RIGHT WITH BEARING	247
0511054334	COMPACT WHEEL LEFT WITH BEARING	248
0501052908	COMPACTOR WHEEL WITH BEARING	249
0501050120	LARGER WALKING BEAM ASSY	250
0521057911	SHORT FERTILIZER LINE DPLEB 18 ASSY	251
0521057909	DPLEB 18 SHORT LINE WITHOUT LUBRICATION TAPERED BEARING	252
0521057912	FULL FERTILIZER LINE DPLEB 18 ASSY	253
0521057910	DPLEB 18 LONG LINE WITHOUT CONICAL BEARING LUBRICATION	254
0521057908	DPLEB 18 BOX CONICAL BEARING	255
0521057957	FIXED ROD EXTENSION WITH FIXATION	256
0521054181	TOOL BOX ASSEMBLY	257
0521054525	CONTAINER WATER TANK	258
0909095190	ASSY HEX AXLE	259
0521053407	MONITORING ASSEMBLY PLANTING SEEDS 13L PM400	260
0521053448	MONITORING ASSEMBLY PLANTING SEEDS 12L PM400	261
0521053437	MONITORING ASSEMBLY PLANTING SEEDS 14L 50 PM100	262

FRAME ASSY

0909095194




Item	Code	Description	See page	4880	5340	5950	6350	6850
01	0521054576	FRAME WITH ARTICULATION 4880	2	001	000	000	000	000
01.	0521054577	FRAME WITH ARTICULATION 5340	5	000	001	000	000	000
01..	0521054578	FRAME WITH ARTICULATION 5950	8	000	000	001	000	000
01...	0521054579	FRAME WITH ARTICULATION 6350	11	000	000	000	001	000
01....	0521053418	FRAME WITH ARTICULATION 6850	14	000	000	000	000	001
02	0521064285	LOCK LOWER FRAME		001	001	001	001	001
03	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		001	001	001	001	001
04	0503010002	1800 GREASE FITTING		001	001	001	001	001
05	0503010003	1845 GREASE FITTING		005	005	005	005	005
06	0503010004	1890 GREASE FITTING		002	002	002	002	002
07	0511058667	SPRING FLOW ENSEMBLY	17	001	001	001	001	001
08	0521055229	WHEELED WITH 655 DRIFT SPRING WITH TRANSMISSION	18	004	004	004	004	004
08.	0521058402	WHEELED WITH 655 DRIFT SPRING WITH TRANSMISSION	27	004	000	000	000	000
09	0521054561	CYLINDER ASSEMBLY	30	001	001	001	001	001
10	0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	32	001	000	001	000	000
10.	0511056532	ASSY SYSTEM HYDRAULIC 5340	33	000	001	000	000	000
10..	0511056808	ASSY SYSTEM HYDRAULIC 6350	34	000	000	000	001	000
10...	0511056832	ASSY SYSTEM HYDRAULIC 6850	35	000	000	000	000	001
11	0909095186	HEADER ASSY	38	001	001	001	001	001
12	0511056736	HOSE SUPPORT	51	001	001	001	001	001
13	0521054526	SILO FERTILIZER ASSY 4880	52	001	000	000	000	000
13.	0521054534	SILO FERTILIZER ASSY 5340	58	000	001	000	000	000
13..	0521054537	SILO FERTILIZER ASSY 5950	61	000	000	001	000	000
13...	0521054540	SILO FERTILIZER ASSY 6350	64	000	000	000	001	000
13....	0521054543	SILO FERTILIZER ASSY 6850	67	000	000	000	000	001
14	0909095187	ASSEMBLY TRANSMISSION 4880/5340/5950/6350/6850	70	001	001	001	001	001
15	0521055241	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	94	000	000	002	002	002

FRAME ASSY


0909095194

Item	Code	Description	See page	4880	5340	5950	6350	6850
15.	0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	95	000	000	000	002	000
16	0521054562	PLATFORM ASSEMBLY 4880	102	001	000	000	000	000
16.	0521054563	PLATFORM ASSEMBLY 5340	103	000	001	000	000	000
16..	0521054564	PLATFORM ASSEMBLY 5950	104	000	000	001	000	000
16...	0521054565	PLATFORM ASSEMBLY 6350	105	000	000	000	001	000
16....	0521054566	PLATFORM ASSEMBLY 6850	106	000	000	000	000	001
17	0511056746	HANDRAIL ASSY 4880	107	001	000	000	000	000
17.	0511056535	HANDRAIL ASSY 5340	108	000	001	000	000	000
17..	0521054568	HANDRAIL ASSY 5950	109	000	000	001	000	000
17...	0511056812	HANDRAIL ASSY 6350	110	000	000	000	001	000
17....	0511056836	HANDRAIL ASSY 6850	111	000	000	000	000	001
18	0511054971	JACK ASSEMBLY	112	004	004	004	004	004
19	0511056536	LADDER ASSEMBLY	113	002	002	002	002	002
20	0511056743	SEMI MOUNTED HYDRAULIC MARKER 4880	114	001	000	000	000	000
20.	0511056735	SEMI MOUNTED HYDRAULIC MARKER 5340	115	000	001	000	000	000
20..	0511056789	SEMI MOUNTED HYDRAULIC MARKER 5720/5950	116	000	000	001	000	000
20...	0511056809	SEMI MOUNTED HYDRAULIC MARKER 6350	117	000	000	000	001	000
20....	0511056833	SEMI MOUNTED HYDRAULIC MARKER 6850	118	000	000	000	000	001
20.....	0521056983	SEMI MOUNTED HYDRAULIC MARKER 4880	119	001	000	000	000	000
21	0521055204	ROW MARKER DISC	122	002	002	002	002	002
22	0511059585	ASSEMBLY CSU C3 SEMI MOUNTED 4880	123	001	000	000	000	000
22.	0511059072	ASSEMBLY CSU C3 SEMI MOUNTED 5340	131	000	001	000	000	000
22..	0511058628	ASSEMBLY CSU C3 SEMI MOUNTED 5720/5950	133	000	000	001	000	000
22...	0511058924	ASSEMBLY CSU C3 SEMI MOUNTED 6350	135	000	000	000	001	000
22....	0521054558	ASSEMBLY CSU C3 SEMI MOUNTED 6850	138	000	000	000	000	001
22.....	0511058997	ASSEMBLY CSU	140	001	000	000	000	000
22.....	0511058723	ASSEMBLY CSU C3 SEMI MOUNTED 5950	136	000	000	001	000	000
23	0521054580	REAR LIGHTING ASSEMBLY 4880	142	001	000	000	000	000
23.	0521054581	REAR LIGHTING ASSEMBLY 5340	143	000	001	000	000	000
23..	0521054582	REAR LIGHTING ASSEMBLY 5720/5950	144	000	000	001	000	000
23...	0521054583	REAR LIGHTING ASSEMBLY	145	000	000	000	001	000
23....	0521054584	REAR LIGHTING ASSEMBLY 6850	146	000	000	000	000	001
24	0521054585	ASSY MANUAL DOOR	148	001	001	001	001	001
25	0909095195	ASSY SEED / FERTILIZER LINE	149	001	001	001	001	001
26	0501065677	STRUT		002	002	002	002	002
27	0541015451	FIXED KEY 2.3/8 X 2.3/4		001	001	001	001	001
28	0501047895	ROD STOP		002	002	002	002	002
29	0501047885	ROD STOP		002	002	002	002	002
30	0501047886	ROD STOP		002	002	002	002	002
31	0501047887	ROD STOP		002	002	002	002	002
32	0521013022	TRANSPORT LOCK		002	002	002	002	002
33	0503030168	CUPILLA		002	002	002	002	002
34	0501068994	0.3" X 3.1" LOCK PIN		002	002	002	002	002
35	0521054181	TOOL BOX ASSEMBLY	257	001	001	001	001	001
36	0521054525	CONTAINER WATER TANK	258	001	001	001	001	001
37	0503019262	SOAP DISH VACUUM		001	001	001	001	001
38	0503010780	N-2050 AMENDMENT		002	002	002	002	002
39	0503011750	AMENDMENT WITH LOCK		006	006	006	006	006
40	0503011751	REDUCTION		006	006	006	006	006
41	0503010951	REDUCTION		004	004	004	004	004
42	0503010246	CLAMP		010	011	012	013	014
43	0909095190	ASSY HEX AXLE	259	001	001	001	001	001
44	0503010014	3/4" NUT		002	002	002	002	002
45	0503010023	3/4" SPRING WASHER		002	002	002	002	002
46	0503032624	SILO FERTILIZER GUTTER		006	005	007	003	002
47	0521065613	HOSE HOLDER		001	001	001	001	001
48	0503011953	5/16" X 1" BOLT		002	002	002	002	002
49	0503013816	5/16" LOCKNUT		002	002	002	002	002


Item	Code	Description	See page	4880	5340	5950	6350	6850
50	0521053407	MONITORING ASSEMBLY PLANTING SEEDS 13L 260 PM400		000	000	001	000	000
50.	0521053448	MONITORING ASSEMBLY PLANTING SEEDS 12L 261 PM400		000	000	001	000	000
51	0521053437	MONITORING ASSEMBLY PLANTING SEEDS 14L 262 50 PM100		000	000	000	000	001
52	0521013164	EXTENSOR		000	000	002	000	000
53	0501011310	FIXER LOCK		000	000	008	000	000
54	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		000	000	008	000	000
55	0503010019	1/2" SPRING WASHER		000	000	008	000	000
56	0503010060	1/2" NUT		000	000	008	000	000




Item	Code	Description	See page	QT
01	0521054567	RIGHT FRAME WITH WHEELED AXLE 4880	3	01
02	0521054569	FRAME LEFT WITH SHAFT WHEELED 4880	4	01
03	0501110791	FRONT ARTICULATOR HUB WITH GLOVES		01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	NUT		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581018964	TROUGH 24 X 50 X 1320		02
20	0581018965	TROUGH 24 X 50 X 940		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8" SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
01	0521068942	RIGHT FRAME		01
02	0521069426	RIGHT ARTICULATED AXLE		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521068943	LEFT FRAME		01
02	0521069427	LEFT ARTICULATED AXLE		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521054570	RIGHT FRAME WITH WHEELED AXLE 5340	6	01
02	0521054571	FRAME LEFT WITH SHAFT WHEELED 5340	7	01
03	0501110791	FRONT ARTICULATOR HUB WITH GLOVES		01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	NUT		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581018962	TROUGH 24 X 50 X 1490		03
20	0581018963	TROUGH 24 X 50 X 1007		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8" SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
01	0521068944	RIGHT FRAME 5340		01
02	0521069428	ARTICULATED AXLE RIGHT SIDE ROLLER 5340		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521068945	LEFT FRAME 5340		01
02	0521069429	LEFT ARTICULATED AXLE 5340		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521054572	RIGHT FRAME WITH WHEELED AXLE 5950	9	01
02	0521054573	FRAME LEFT WITH SHAFT WHEELED 5950	10	01
03	0501110791	FRONT ARTICULATOR HUB WITH GLOVES		01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	NUT		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581018960	TROUGH 24 X 50 X 1855		02
20	0581018961	TROUGH 24 X 50 X 945		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8" SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
01	0521068946	RIGHT FRAME 5950		01
02	0521069430	RIGHT SIDE RIGHT ARTICULATED AXLE 5950		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521068947	LEFT FRAME 5950		01
02	0521069431	LEFT ARTICULATED AXLE 5950		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521054574	RIGHT FRAME WITH WHEELED AXLE 6350	12	01
02	0521054575	FRAME LEFT WITH SHAFT WHEELED 6350	13	01
03	0501110791	FRONT ARTICULATOR HUB WITH GLOVES		01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	NUT		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581018182	TROUGH 24 X 50 X 1750		02
20	0581018181	TROUGH 24 X 50 X 1250		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8" SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
01	0521068948	RIGHT FRAME 6350		01
02	0521069432	RIGHT SIDE RIGHT ARTICULATED AXLE 6350		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521068949	LEFT FRAME 6350		01
02	0521069433	LEFT ARTICULATED AXLE 6350		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521053420	RIGHT FRAME WITH WHEELED AXLE 6850	15	01
02	0521053419	FRAME LEFT WITH SHAFT WHEELED 6850	16	01
03	0501110791	FRONT ARTICULATOR HUB WITH GLOVES		01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	NUT		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581017758	TROUGH 24 X 50 X 1900 6850		02
20	0581017759	TROUGH 24 X 50 X 1350 6850		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8" SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03
26	0591019177	GLOVE		01




Item	Code	Description	See page	QT
01	0521068950	RIGHT FRAME 6850		01
02	0521069172	RIGHT SIDE RIGHT ARTICULATED AXLE 6850		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521068951	LEFT FRAME 6850		01
02	0521069173	LEFT ARTICULATED AXLE 6850		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		06
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		12
03	0501012140	FLAT WASHER		24




Item	Code	Description	See page	QT
01	0521055231	655 WHEELED SUPPORT WITH TRANSMISSION	19	01
02	0521055234	WHEELED FASTENER	23	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0521061566	CARRYING WHEEL ARM TRACTION		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0501058241	WHEEL SUPPORT CHAIN TENSIONER	20	01
07	0521055232	WHEEL WITH PNEU	21	01
08	0503018981	BOLT		02
09	0503010027	5/8" SPRING WASHER		04
10	0521012190	AXLE LOCK		01
11	0581011124	WHEELED COVER		01
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
13	0551017715	FLAT WASHER		02
14	0503013030	5/8" X 3.1/4" BOLT		01
15	0511050681	TRACTION SPRING		01
15A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
15B	0561016062	SPRING HITCH		02



Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	100	01
02	0521055233	WHEELED TRANSMISSION WITHOUT TIRE	22	01




Item	Code	Description	See page	QT
01	0521012185	TRANSM AXLE CARRYING-WHEEL		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0502011339	15Z GEAR P 1.25"		01
09	0503012550	5/16" X 3/4" BOLT		06
10	0503010002	1800 GREASE FITTING		01

WHEELED FASTENER


0521055234




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0521055236	INTERMEDIARY CURRENT STRETCHER	24	01
07	0521055237	WHEEL FIXED CURRENT STRETCHER	25	01
08	0521055235	WHEEL MOBILE CURRENT STRETCHER	26	01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
02	0551018245	CHAIN TENSIONER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0551018239	SLEEVE 19 X 13,50 X 45		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
02	0551018252	CHAIN TIGHTENER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
02	0551018244	CHAIN UPPER AXLE		01
03	0591017923	GLOVE 15.30 X 30 X 32		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521058401	655 WHEELED SUPPORT WITH TRANSMISSION	28	01
02	0521055234	WHEELED FASTENER	23	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0531062422	WHEEL ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0501058241	WHEEL SUPPORT CHAIN TENSIONER	20	01
07	0521058393	WHEEL WITH PNEU 7.00X16 14L PR TT WITH 29 TRANSMISSION		01
08	0503018981	BOLT		02
09	0503010027	5/8" SPRING WASHER		04
10	0591010589	BODY LOCK WHEEL		01
11	0521069983	WHEEL COVER		01
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
13	0551017715	FLAT WASHER		02
14	0503013030	5/8" X 3.1/4" BOLT		01
15	0511050681	TRACTION SPRING		01
15A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
15B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0503063172	WHEEL		01
02	0521055233	WHEELED TRANSMISSION WITHOUT TIRE	22	01



Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	31	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521015501	COUPLING SHAFT		02
04	0503010523	1/4" X 2" COTTERPIN		04
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
06	0531012565	SLEEVE 16,3X 30 X 88		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01



Item	Code	Description	See page	QT
01	0571017027	VALVE SUPPORT		01
02	0503010920	1/2" X 1.1/2" BOLT		02
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0501054452	FLOW DIVIDING VALVE		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER	37	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		02
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057089	HOSE KIT SYSTEM HYDRAULIC		01
19A	0501080045	3/8" X 850 TR-TR HOSE		01
19B	0501080999	3/8" X 39" TC-TC HOSE		01
19C	0501081987	HOSE 3/8 X 1550 TR-TC		01
19D	0501081986	HOSE 3/8 X 1550 TC-TC		01
19E	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
19EA	0501080185	HOSE 1/2 X 4000 TR-TM		01
19EB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
19EC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
19ED	0503018952	PLASTIC BOLT		06
19F	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
19FA	0501080185	HOSE 1/2 X 4000 TR-TM		01
19FB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01




Item	Code	Description	See page	QT
19FC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
19FD	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0571017027	VALVE SUPPORT		01
02	0503010920	1/2" X 1.1/2" BOLT		02
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0501054694	FLOW DIVIDING VALVE ASSY	36	01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER	37	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		01
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057104	HOSE KIT SYSTEM HYDRAULIC		01
19A	0501080104	3/8 X 900 TR-TR HOSE		01
19B	0501080963	3/8 X 1050 TC-TC 90G LEFT OSE		01
19C	0501080714	3/8 X 1600 TR-TC HOSE		01
19D	0501081994	3/8 X 1600 TC-TC 180G HOSE		01
20	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
20A	0501080185	HOSE 1/2 X 4000 TR-TM		01
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
20C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
20D	0503018952	PLASTIC BOLT		06
21	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
21A	0501080185	HOSE 1/2 X 4000 TR-TM		01
21B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01

Item	Code	Description	See page	QT
21C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21D	0503018952	PLASTIC BOLT		06
22	0503013100	NYLON CLAMP		02




Item	Code	Description	See page	QT
01	0571017027	VALVE SUPPORT		01
02	0503010920	1/2" X 1.1/2" BOLT		02
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0501054694	FLOW DIVIDING VALVE ASSY	36	01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER	37	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		01
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057105	ASSY HYDRAULIC SYSTEM HOSE 6350		01
19A	0501080127	HOSE		01
19B	0501081998	HOSE 3/8 X 1300 TC-TC		01
19C	0501082001	TR-TC HOSE ASSY		01
19D	0501082000	TC-TC HOSE ASSY		01
20	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
20A	0501080185	HOSE 1/2 X 4000 TR-TM		01
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
20C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
20D	0503018952	PLASTIC BOLT		06
21	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
21A	0501080185	HOSE 1/2 X 4000 TR-TM		01
21B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01

Item	Code	Description	See page	QT
21C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21D	0503018952	PLASTIC BOLT		06
22	0503013100	NYLON CLAMP		02




Item	Code	Description	See page	QT
01	0571017027	VALVE SUPPORT		01
02	0503010920	1/2" X 1.1/2" BOLT		02
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0501054694	FLOW DIVIDING VALVE ASSY	36	01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER	37	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		01
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057106	ASSY HYDRAULIC SYSTEM HOSE 6850		01
19A	0501080373	TR-TR HOSE ASSY		01
19B	0501081989	HOSE 3/8 X 1400 TC-TC 90G		01
19C	0501081992	HOSE		01
19D	0501081991	HOSE 3/8 X 1950 TC-TC 180G		01
20	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
20A	0501080185	HOSE 1/2 X 4000 TR-TM		01
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
20C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
20D	0503018952	PLASTIC BOLT		06
21	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
21A	0501080185	HOSE 1/2 X 4000 TR-TM		01
21B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01

Item	Code	Description	See page	QT
21C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21D	0503018952	PLASTIC BOLT		06
22	0503013100	NYLON CLAMP		02




Item	Code	Description	See page	QT
01	0503012481	FLOW DIVIDING VALVE		01
02	0503030923	3/4" UNF X 13/16UN OFS X 40 NIPPLE		03
03	0503010190	2-114 N 3006-9B O'RING		03



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01

HEADER ASSY

0909095186



Item	Code	Description	See page	4880	5340	5950	6350	6850
01	0521068561	LONG COUPLING HEADER		001	001	001	001	001
02	0511055096	TRACTOR HITCH	39	001	001	001	001	001
03	0511053179	TRACTOR COUPLING SHAFT		001	001	001	001	001
03A	0521064036	TRACTOR HITCH AXLE		001	001	001	001	001
03B	0503030012	HAIR PIN		001	001	001	001	001
04	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		001	001	001	001	001
05	0503014120	CHAIN		001	001	001	001	001
06	0503014321	CABLE STEEL SHACKLE		002	002	002	002	002
07	0571010661	PIVOT SHAFT		001	001	001	001	001
08	0503010010	1/4\" X 2.1/2\" COTTERPIN		002	002	002	002	002
09	0521064203	EAR PIVOT DRAWBAR		001	001	001	001	001
10	0521053310	LEFT EXTENSION HEADER 36.00 - 4880/5720/5950	40	001	000	001	000	000
10.	0531052545	LEFT EXTENSION HEADER 36.00 - 4880/5950	49	001	000	000	000	000
10..	0521053313	LEFT EXTENSION HEADER 36.00 - 5340	41	000	001	000	000	000
10...	0531052543	LEFT EXTENSION HEADER 36.00 - 5340		000	001	000	000	000
10....	0521053320	LEFT EXTENSION HEADER 36.00 - 6350	42	000	000	000	001	000
10.....	0531052540	HEADER ASSY	43	000	000	000	001	000
10.....	0521053318	LEFT EXTENSION HEADER 36.00 - 6850	44	000	000	000	000	001
11	0501010500	3/4\"X3\"BOLT		002	002	002	002	002
12	0503010023	3/4\" SPRING WASHER		002	002	002	002	002
13	0503010014	3/4\" NUT		002	002	002	002	002
14	0571019949	JUNCTION SHAFT		002	002	002	002	002
15	0503030119	LOCK PIN		002	002	002	002	002
16	0521053311	RIGHT EXTENSOR HEAD 36,00 - 4880/5720/5950	45	001	000	001	000	000
16.	0521053312	RIGHT EXTENSOR HEAD 36,00 - 5340	46	000	001	000	000	000
16..	0521053321	RIGHT EXTENSOR HEAD 36,00 - 6350	47	000	000	000	001	000
16...	0521053319	RIGHT EXTENSOR HEAD 36,00 - 6850	48	000	000	000	000	001
17	0521010572	0.9\" X 2.9\" COUPLING SHAFT		001	001	001	001	001
18	0503030085	LOCK PIN		004	004	004	004	004
19	0521063528	EXTENDING FIXER		001	001	001	001	001
20	0501010171	BOLT 1 UNC X 3.1/2 C S G.5		003	003	003	003	003




HEADER ASSY

0909095186


Item	Code	Description	See page	4880	5340	5950	6350	6850
21	0503010012	1" SPRING WASHER		003	003	003	003	003
22	0501010059	1.5/8 NUT		003	003	003	003	003
23	0521062916	LEFT FRENCH HAND		001	001	001	001	001
24	0521010585	0.9" X 5.9" COUPLING SHAFT		001	001	001	001	001
25	0511052311	3 POINT TURNBUCKLE	50	001	001	001	001	001
26	0521012532	0.9" X 3.9" COUPLING SHAFT		001	001	001	001	001
27	0521010582	COUPLING SHAFT		001	001	001	001	001
28	0521063529	LOCK AXLE		001	001	001	001	001
29	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		001	001	001	001	001
30	0501212237	HITCH GLOVE ARTICULATED 85 X 35 MM		000	000	000	001	000

TRACTOR HITCH


0511055096




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	COMPRESSION SPRING LEFT		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0521064426	POINT FIXER EXTENDING LEFT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064426	POINT FIXER EXTENDING LEFT		01
02	0521065193	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064238	POINT FIXER EXTENDING LEFT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0531062849	LEFT EXTENDER FIXED CRAMPON		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02
06	0531062854	ARTICULATED ARM BAR		01
07	0503010023	3/4" SPRING WASHER		04
08	0503010014	3/4" NUT		04
09	0503035565	COMPRESSION SPRING		04
10	0503012951	3/4" X 10-1/2" BOLT		04
11	0501017065	FLAT WASHER		08




Item	Code	Description	See page	QT
01	0521064238	POINT FIXER EXTENDING LEFT		01
02	0521065193	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064425	POINT FIXER EXTENDING RIGHT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064425	POINT FIXER EXTENDING RIGHT		01
02	0521065193	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064237	POINT FIXER EXTENDING RIGHT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064237	POINT FIXER EXTENDING RIGHT		01
02	0521065193	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0531062838	LEFT POINT FIXER EXTENDING		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02
06	0531062839	ARTICULATED ARM BAR		01
07	0503010023	3/4" SPRING WASHER		04
08	0503010014	3/4" NUT		04
09	0503035565	COMPRESSION SPRING		04
10	0503012951	3/4" X 10-1/2" BOLT		04
11	0501017065	FLAT WASHER		08



Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0571012279	JACK RIGHT		01
03	0571012280	JACK LEFT		01
04	0531010264	SIDE RATCHET		02
05	0521018500	SHAFT LEVER EXTENSOR		01
06	0511061881	RATCHET FOLLOWER		01
07	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
08	0503011179	3/8" X 2-1/4" BOLT		05
09	0503010025	3/8" SPRING WASHER		05
10	0503010026	3/8" NUT		05
11	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0521054528	SILO FERTILIZER RIGHT SUPPORT 4880	53	01
02	0521054527	LEFT FERTILIZER BEAM SUPPORT 4880	54	01
03	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		02
04	0501010984	FLAT WASHER		24
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12
07	0503010849	3/8" X 1-1/2" BOLT		12
08	0503013751	3/8 UNC X 1.1/4 BOLT		21
09	0571019051	FIXER BOX WASHER		21
10	0503012535	3/8" SPRING WASHER		21
11	0503012531	3/8" INOX NUT		21
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	LOCK WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0581018923	LOWER LEVER LEVER CHANGE		02
19	0581018922	LEVER ARM DISARMING MINOR		02
20	0521061741	INNTER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0511017302	FLAT WASHER		06
23	0551019167	SLEEVE UNION		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501013518	FLAT WASHER		06
27	0503010140	1/8" X 3/4" COTTERPIN		06
28	0503010479	BOLT		02
29	0551019168	SLEEVE		02
30	0503011336	1/2" HEX SELF ADJUSTING NUT		06
31	0511069678	LH LOWER LEVER		02




Item	Code	Description	See page	QT
32	0561016468	FASTENER		02
33	0551019159	LEVER FIXER BODY		02
34	0503034396	FERTILIZER SIDE COVER		12
35	0503010362	1/8" X 1.1/4" COTTERPIN		12




Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	55	01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	56	05
03	0501010942	3/8" X 1-1/4" BOLT		24
04	0503011443	3/8" SPRING WASHER		24
05	0503010026	3/8" NUT		24
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0503013816	5/16" LOCKNUT		02
11	0581018921	SQUARE AXLE 3/4 X 2275		01
12	1902010685	18Z CONICAL GEAR		06
13	0503030275	AGRICULTURAL BEARING		06
14	0501053788	3/4 SQUARE AXLE FASTENER	57	01
15	0501110392	SILO SUPPORT BEARING		01
16	0503010003	1845 GREASE FITTING		01
17	0521069407	SUPPORT RIGHT SILO FERTILIZER		01
18	0503011953	5/16" X 1" BOLT		02
19	0521011039	FLAT WASHER		02
20	0503011444	SPRING WASHER		02
21	0503010337	5/16" NUT		02
22	0521012485	GEAR BOX BEARING AGRICUTURAL		01




Item	Code	Description	See page	QT
01	0521069406	LEFT SUPPORT SILO FERTILIZER		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	55	05
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	56	01
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503011443	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0503010337	5/16" NUT		02
12	0581018921	SQUARE AXLE 3/4 X 2275		01
13	0503030275	AGRICULTURAL BEARING		06
14	1902010685	18Z CONICAL GEAR		06
15	0503010003	1845 GREASE FITTING		01
16	0501053788	3/4 SQUARE AXLE FASTENER	57	01
17	0521012485	GEAR BOX BEARING AGRICUTURAL		01
18	0501110392	SILO SUPPORT BEARING		01
19	0503011953	5/16" X 1" BOLT		02
20	0521011039	FLAT WASHER		02
21	0503011444	SPRING WASHER		02
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01



Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0521054535	SILO FERTILIZER RIGHT SUPPORT 5340	59	01
02	0521054536	LEFT FERTILIZER BEAM SUPPORT 5340	60	01
03	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		02
04	0501010984	FLAT WASHER		24
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12
07	0503010849	3/8" X 1-1/2" BOLT		12
08	0503013751	3/8 UNC X 1.1/4 BOLT		20
09	0571019051	FIXER BOX WASHER		20
10	0503012535	3/8" SPRING WASHER		20
11	0503012531	3/8" INOX NUT		20
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	LOCK WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0581012605	GEAR BOX LEVER LOCK		02
19	0551019160	LEVER		02
20	0521061741	INNTER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0511017302	FLAT WASHER		06
23	0551019167	SLEEVE UNION		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501013518	FLAT WASHER		06
27	0503010140	1/8" X 3/4" COTTERPIN		06
28	0503010479	BOLT		02
29	0551019168	SLEEVE		02
30	0503011336	1/2" HEX SELF ADJUSTING NUT		06
31	0511069678	LH LOWER LEVER		02




Item	Code	Description	See page	QT
32	0561016468	FASTENER		02
33	0551019159	LEVER FIXER BODY		02
34	0503034396	FERTILIZER SIDE COVER		12
35	0503010362	1/8" X 1.1/4" COTTERPIN		12



Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	55	01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	56	05
03	0501010942	3/8" X 1-1/4" BOLT		24
04	0503011443	3/8" SPRING WASHER		24
05	0503010026	3/8" NUT		24
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0503013816	5/16" LOCKNUT		02
11	0581018924	SQUARE AXLE 3/4 X 2388 - 5340		01
12	1902010685	18Z CONICAL GEAR		06
13	0503030275	AGRICULTURAL BEARING		06
14	0501053788	3/4 SQUARE AXLE FASTENER	57	01
15	0501110392	SILO SUPPORT BEARING		01
16	0503010003	1845 GREASE FITTING		01
17	0521069408	SUPPORT RIGHT SILO FERTILIZER 5340		01
18	0503011953	5/16" X 1" BOLT		02
19	0521011039	FLAT WASHER		02
20	0503011444	SPRING WASHER		02
21	0503010337	5/16" NUT		02
22	0521012485	GEAR BOX BEARING AGRICUTURAL		01




Item	Code	Description	See page	QT
01	0521069409	LEFT SILO FERTILIZER 5340 SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	55	05
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	56	01
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503011443	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0503010337	5/16" NUT		02
12	0581018924	SQUARE AXLE 3/4 X 2388 - 5340		01
13	0503030275	AGRICULTURAL BEARING		06
14	1902010685	18Z CONICAL GEAR		06
15	0503010003	1845 GREASE FITTING		01
16	0501053788	3/4 SQUARE AXLE FASTENER	57	01
17	0521012485	GEAR BOX BEARING AGRICUTURAL		01
18	0501110392	SILO SUPPORT BEARING		01
19	0503011953	5/16" X 1" BOLT		02
20	0521011039	FLAT WASHER		02
21	0503011444	SPRING WASHER		02
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521054539	SILO FERTILIZER RIGHT SUPPORT 5950	62	01
02	0521054538	LEFT FERTILIZER BEAM SUPPORT 5950	63	01
03	0503062362	FERTILIZER BOX		02
04	0501010984	FLAT WASHER		24
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12
07	0503010849	3/8" X 1-1/2" BOLT		12
08	0503013751	3/8 UNC X 1.1/4 BOLT		20
09	0571019051	FIXER BOX WASHER		20
10	0503012535	3/8" SPRING WASHER		20
11	0503012531	3/8" INOX NUT		20
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	LOCK WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0581012605	GEAR BOX LEVER LOCK		02
19	0551019160	LEVER		02
20	0521061741	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0511017302	FLAT WASHER		06
23	0551019167	SLEEVE UNION		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501013518	FLAT WASHER		06
27	0503010140	1/8" X 3/4" COTTERPIN		06
28	0503010479	BOLT		02
29	0551019168	SLEEVE		02
30	0503011336	1/2" HEX SELF ADJUSTING NUT		06
31	0511069678	LH LOWER LEVER		02




Item	Code	Description	See page	QT
32	0561016468	FASTENER		02
33	0551019159	LEVER FIXER BODY		02
34	0503034396	FERTILIZER SIDE COVER		12
35	0503010362	1/8" X 1.1/4" COTTERPIN		12
36	0503062927	SILO FERTILIZER 3 MOUTHS		02



Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	55	02
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	56	05
03	0501010942	3/8" X 1-1/4" BOLT		28
04	0503011443	3/8" SPRING WASHER		28
05	0503010026	3/8" NUT		28
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0503013816	5/16" LOCKNUT		02
11	0581018930	SQUARE AXLE 3/4 X 2788 - 5950		01
12	1902010685	18Z CONICAL GEAR		07
13	0503030275	AGRICULTURAL BEARING		07
14	0501053788	3/4 SQUARE AXLE FASTENER	57	01
15	0501110392	SILO SUPPORT BEARING		01
16	0503010003	1845 GREASE FITTING		01
17	0521069410	SUPPORT RIGHT SILO FERTILIZER 5950		01
18	0503011953	5/16" X 1" BOLT		02
19	0521011039	FLAT WASHER		02
20	0503011444	SPRING WASHER		02
21	0503010337	5/16" NUT		02
22	0521012485	GEAR BOX BEARING AGRICUTURAL		01




Item	Code	Description	See page	QT
01	0521069411	LEFT SILO FERTILIZER 5950 SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	55	05
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	56	02
04	0501010942	3/8" X 1-1/4" BOLT		28
05	0503011443	3/8" SPRING WASHER		28
06	0503010026	3/8" NUT		28
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0503010337	5/16" NUT		02
12	0581018930	SQUARE AXLE 3/4 X 2788 - 5950		01
13	0503030275	AGRICULTURAL BEARING		07
14	1902010685	18Z CONICAL GEAR		07
15	0503010003	1845 GREASE FITTING		01
16	0501053788	3/4 SQUARE AXLE FASTENER	57	01
17	0521012485	GEAR BOX BEARING AGRICUTURAL		01
18	0501110392	SILO SUPPORT BEARING		01
19	0503011953	5/16" X 1" BOLT		02
20	0521011039	FLAT WASHER		02
21	0503011444	SPRING WASHER		02
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521054541	SILO FERTILIZER RIGHT SUPPORT 6350	65	01
02	0521054542	LEFT FERTILIZER BEAM SUPPORT 6350	66	01
03	0503062362	FERTILIZER BOX		02
04	0501010984	FLAT WASHER		24
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12
07	0503010849	3/8" X 1-1/2" BOLT		12
08	0503013751	3/8 UNC X 1.1/4 BOLT		20
09	0571019051	FIXER BOX WASHER		20
10	0503012535	3/8" SPRING WASHER		20
11	0503012531	3/8" INOX NUT		20
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	LOCK WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0581012605	GEAR BOX LEVER LOCK		02
19	0551019160	LEVER		02
20	0521061741	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0511017302	FLAT WASHER		06
23	0551019167	SLEEVE UNION		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501013518	FLAT WASHER		06
27	0503010140	1/8" X 3/4" COTTERPIN		06
28	0503010479	BOLT		02
29	0551019168	SLEEVE		02
30	0503011336	1/2" HEX SELF ADJUSTING NUT		06
31	0511069678	LH LOWER LEVER		02




Item	Code	Description	See page	QT
32	0561016468	FASTENER		02
33	0551019159	LEVER FIXER BODY		02
34	0503034396	FERTILIZER SIDE COVER		12
35	0503010362	1/8" X 1.1/4" COTTERPIN		12
36	0503062927	SILO FERTILIZER 3 MOUTHS		02



Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	55	03
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	56	04
03	0501010942	3/8" X 1-1/4" BOLT		28
04	0503011443	3/8" SPRING WASHER		28
05	0503010026	3/8" NUT		28
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0503013816	5/16" LOCKNUT		02
11	0581018936	SQUARE AXLE 3/4 X 2890 6350		01
12	1902010685	18Z CONICAL GEAR		07
13	0503030275	AGRICULTURAL BEARING		07
14	0501053788	3/4 SQUARE AXLE FASTENER	57	01
15	0501110392	SILO SUPPORT BEARING		01
16	0503010003	1845 GREASE FITTING		01
17	0521069412	SUPPORT RIGHT SILO FERTILIZER 6350		01
18	0503011953	5/16" X 1" BOLT		02
19	0521011039	FLAT WASHER		02
20	0503011444	SPRING WASHER		02
21	0503010337	5/16" NUT		02
22	0521012485	GEAR BOX BEARING AGRICUTURAL		01




Item	Code	Description	See page	QT
01	0521069413	SUPPORT LEFT SILO FERTILIZER 6350		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	55	04
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	56	03
04	0501010942	3/8" X 1-1/4" BOLT		28
05	0503011443	3/8" SPRING WASHER		28
06	0503010026	3/8" NUT		28
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0503010337	5/16" NUT		02
12	0581018936	SQUARE AXLE 3/4 X 2890 6350		01
13	0503030275	AGRICULTURAL BEARING		07
14	1902010685	18Z CONICAL GEAR		07
15	0503010003	1845 GREASE FITTING		01
16	0501053788	3/4 SQUARE AXLE FASTENER	57	01
17	0521012485	GEAR BOX BEARING AGRICUTURAL		01
18	0501110392	SILO SUPPORT BEARING		01
19	0503011953	5/16" X 1" BOLT		02
20	0521011039	FLAT WASHER		02
21	0503011444	SPRING WASHER		02
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521054544	SILO FERTILIZER RIGHT SUPPORT 6850	68	01
02	0521054545	LEFT FERTILIZER BEAM SUPPORT 6850	69	01
03	0503062362	FERTILIZER BOX		04
04	0501010984	FLAT WASHER		24
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12
07	0503010849	3/8" X 1-1/2" BOLT		12
08	0503013751	3/8 UNC X 1.1/4 BOLT		24
09	0571019051	FIXER BOX WASHER		24
10	0503012535	3/8" SPRING WASHER		24
11	0503012531	3/8" INOX NUT		24
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	LOCK WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0581012605	GEAR BOX LEVER LOCK		02
19	0551019160	LEVER		02
20	0521061741	INNTER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0511017302	FLAT WASHER		06
23	0551019167	SLEEVE UNION		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501013518	FLAT WASHER		06
27	0503010140	1/8" X 3/4" COTTERPIN		06
28	0503010479	BOLT		02
29	0551019168	SLEEVE		02
30	0503011336	1/2" HEX SELF ADJUSTING NUT		06
31	0511069678	LH LOWER LEVER		02




Item	Code	Description	See page	QT
32	0561016468	FASTENER		02
33	0551019159	LEVER FIXER BODY		02
34	0503034396	FERTILIZER SIDE COVER		12
35	0503010362	1/8" X 1.1/4" COTTERPIN		12



Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	55	04
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	56	04
03	0501010942	3/8" X 1-1/4" BOLT		32
04	0503011443	3/8" SPRING WASHER		32
05	0503010026	3/8" NUT		32
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0503013816	5/16" LOCKNUT		02
11	0581018942	SQUARE AXLE 3/4 X 3185 6850		01
12	1902010685	18Z CONICAL GEAR		08
13	0503030275	AGRICULTURAL BEARING		08
14	0501053788	3/4 SQUARE AXLE FASTENER	57	01
15	0501110392	SILO SUPPORT BEARING		01
16	0503010003	1845 GREASE FITTING		01
17	0521069414	SUPPORT RIGHT SILO FERTILIZER 6850		01
18	0503011953	5/16" X 1" BOLT		02
19	0521011039	FLAT WASHER		02
20	0503011444	SPRING WASHER		02
21	0503010337	5/16" NUT		02
22	0521012485	GEAR BOX BEARING AGRICUTURAL		01




Item	Code	Description	See page	QT
01	0521069415	LEFT SILO FERTILIZER 6850 SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	55	04
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	56	04
04	0501010942	3/8" X 1-1/4" BOLT		32
05	0503011443	3/8" SPRING WASHER		32
06	0503010026	3/8" NUT		32
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0503010337	5/16" NUT		02
12	0581018942	SQUARE AXLE 3/4 X 3185 6850		01
13	0503030275	AGRICULTURAL BEARING		08
14	1902010685	18Z CONICAL GEAR		08
15	0503010003	1845 GREASE FITTING		01
16	0501053788	3/4 SQUARE AXLE FASTENER	57	01
17	0521012485	GEAR BOX BEARING AGRICUTURAL		01
18	0501110392	SILO SUPPORT BEARING		01
19	0503011953	5/16" X 1" BOLT		02
20	0521011039	FLAT WASHER		02
21	0503011444	SPRING WASHER		02
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	4880	5340	5950	6350	6850
00a	0511056751	RIGHT TRANSMISSION ASSY - 4880		001	000	000	000	000
00b	0511056752	LEFT TRANSMISSION ASSY - 4880		001	000	000	000	000
00c	0511056541	RIGHT TRANSMISSION ASSEMBLY 5340		000	001	000	000	000
00d	0511056542	LEFT TRANSMISSION ASSEMBLY 5340		000	001	000	000	000
00e	0511056818	RIGHT TRANSMISSION ASSY 5950		000	000	001	000	000
00f	0511056819	LEFT TRANSMISSION ASSY 5950		000	000	001	000	000
00g	0511056824	RIGHT TRANSMISSION ASSEMBLY 6350		000	000	000	001	000
00h	0511056825	LEFT TRANSMISSION ASSEMBLY 6350		000	000	000	001	000
00i	0511056830	RIGHT TRANSMISSION ASSEMBLY 6850		000	000	000	000	001
00j	0511056831	LEFT TRANSMISSION ASSEMBLY 6850		000	000	000	000	001
01	0501110639	BEARING		008	008	008	008	008
02	0503011099	GREASE FITTING		008	008	008	008	008
03	0503010300	5/32" X 1" COTTERPIN		008	008	008	008	008
04	0551019114	MOTOR BEARING AXLE SUPPORT		004	004	004	004	004
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		004	004	004	004	004
06	0511017302	FLAT WASHER		008	008	008	008	008
07	0503010019	1/2" SPRING WASHER		008	008	008	008	008
08	0503010060	1/2" NUT		008	008	008	008	008
09	0561016876	MOTOR SHAFT		002	000	000	000	000
09.	0571017428	MOTOR SHAFT		000	002	000	000	000
09..	0571011442	MOTOR SHAFT		000	000	002	000	000
09...	0571013750	MOTOR AXLE 3060		000	000	000	002	000
09....	0571017032	MOTOR SHAFT		000	000	000	000	002
10	0501018466	FLAT WASHER		004	004	004	004	004
11	0511015961	LOCK BUSHING		004	004	004	004	004
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		004	004	004	004	004
13	0503010060	1/2" NUT		004	004	004	004	004
14	0501052560	MOTOR AXLE SIGNAL	71	002	002	002	002	002
15	0511051434	TRANSMISSION ACTUATOR	72	004	004	004	004	004
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	73	001	001	001	001	001
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	74	001	001	001	001	001


Item	Code	Description	See page	4880	5340	5950	6350	6850
18	0521043316	RIGHT GEAR BOX ASSY	75	001	001	001	001	001
19	0521043317	LEFT GEAR BOX ASSY	76	001	001	001	001	001
20	0503014734	BOLT		006	006	006	006	006
21	0503010920	1/2" X 1.1/2" BOLT		004	004	004	004	004
22	0511017302	FLAT WASHER		008	008	008	008	008
23	0503010019	1/2" SPRING WASHER		010	010	010	010	010
24	0503010060	1/2" NUT		010	010	010	010	010
25	0521064448	GEAR		002	002	002	002	002
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	86	002	002	002	002	002
27	0521055217	LOWER CURRENT STRETCH	87	002	002	002	002	002
28	0501058254	UPPER SEED CHAIN TENSIONER	88	002	002	002	002	002
29	0521055216	BEARING WITH GEAR	89	002	002	002	002	002
30	0521055218	BEARING GEAR WITH DOUBLE	90	002	002	002	002	002
31	0521055214	BEARING GEAR WITH	91	002	002	002	002	002
32	0503012204	40-1 CHAIN X 82 LINK + RED		002	002	002	002	002
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		002	002	002	002	002
34	0503012718	40-1 CHAIN X 111 LINK + MENDING		002	002	002	002	002
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		002	002	002	002	002
36	0503010256	3/8" X 3/4" BOLT		002	002	002	002	002
37	0503010025	3/8" SPRING WASHER		002	002	002	002	002
38	0501010984	FLAT WASHER		002	002	002	002	002
39	0501010637	FLAT WASHER		004	004	004	004	004
40	0503030275	AGRICULTURAL BEARING		002	002	002	002	002
41	0511054363	CHAIN TENSIONER	93	002	002	002	002	002




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY


0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	77	01
02	0511059266	CLOSED BEARING	79	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	81	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	83	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	84	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	85	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	78	01
02	0511059266	CLOSED BEARING	79	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	81	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	83	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	84	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	85	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	80	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	82	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0521018933	FERT CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501011234	5/8" X 3" BOLT		01
02	0531017086	50 AXLETIGHTENER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0503019356	BEARING 6005 2RS1		01
05	0503011105	SEAL RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0503016460	5/8" X 4.1/2" BOLT		01
02	0551019175	DOUBLE GEAR AXLE		01
03	0503019356	BEARING 6005 2RS1		02
04	0511069680	20Z X 28Z DOBLE GEAR		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511063106	20Z AXLE BEARING DOBLE		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0521055215	DOUBLE TRANSMISSION BEARING	92	01
04	0503010365	NUT		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503019356	BEARING 6005 2RS1		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521055243	655 WHEELED BRACKET WITHOUT TRANSMISSION	96	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0521058403	655 WHEELED BRACKET WITHOUT TRANSMISSION	97	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0521061566	CARRYING WHEEL ARM TRACTION		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0503018981	BOLT		02
07	0503010027	5/8" SPRING WASHER		02
08	0521012190	AXLE LOCK		02
09	0521055239	WHEEL WITH TIRE WITHOUT TRANSMISSION	99	01




Item	Code	Description	See page	QT
01	0531062422	WHEEL ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0503018981	BOLT		02
07	0503010027	5/8" SPRING WASHER		02
08	0591010589	BODY LOCK WHEEL		02
09	0521058394	WHEEL WITH PNEUME	98	01




Item	Code	Description	See page	QT
01	0503063172	WHEEL		01
02	0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	101	01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	100	01
02	0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	101	01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0521012185	TRANSM AXLE CARRYING-WHEEL		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521069416	RIGHT PLATFORM		01
02	0521069421	LEFT PLATFORM		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	FLAT WASHER		18
06	0503010025	3/8" SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	CUPILLA		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521069417	RIGHT PLATFORM 5340		01
02	0521069422	LEFT PLATFORM 5340		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	FLAT WASHER		18
06	0503010025	3/8" SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	CUPILLA		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521069418	RIGHT PLATFORM 5950		01
02	0521069423	LEFT PLATFORM 5950		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	FLAT WASHER		18
06	0503010025	3/8" SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	CUPILLA		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521069419	RIGHT PLATFORM 6350		01
02	0521069424	LEFT PLATFORM 6350		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	FLAT WASHER		18
06	0503010025	3/8" SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	CUPILLA		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521069420	RIGHT PLATFORM 6850		01
02	0521069425	LEFT PLATFORM 6850		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	FLAT WASHER		18
06	0503010025	3/8" SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	CUPILLA		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521062988	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8" SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0521065384	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8" SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0521063175	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8" SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0521064028	HANDRAIL 6350		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8" SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0521065192	HANDRAIL 6850		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8" SELF-ADJUSTING NUT		08



Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	120	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	CUPILLA		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	121	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0511057090	HYDRAULIC MARKER HAND SET		01
24A	0501081728	HOSE 3/8 X 3100 TR-TR		01
24B	0501080392	3/8 X 3300 TR-TC HOSE		01
24C	0501081988	3/8" X 145.6" TR-TC HOSE		01
24D	0501081682	TC-TC HOSE ASSY		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	37	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	120	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	CUPILLA		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	121	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0511057101	HYDRAULIC MARKER HANDLE SET		01
24A	0501081330	HOSE		01
24B	0501081718	HOSE		01
24C	0501081799	HOSE		01
24D	0501081995	HOSE		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	37	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	120	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	CUPILLA		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	121	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0511057091	HYDRAULIC MARKER HANDLE SET		01
24A	0501081793	HOSE		01
24B	0501081967	TR-TC HOSE ASSY		01
24C	0501081996	HOSE		01
24D	0501081997	HOSE		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	37	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	120	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	CUPILLA		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	121	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0511057102	HOSE KIT MARKER HIDRAULICO 6350		01
24A	0501081794	TR-TC HOSE ASSY		01
24B	0501081999	3/8 X 4050 TR-TC HOSE ASSY		01
24C	0501080612	HOSE 3/8 X 4450 TR-TC		01
24D	0501082002	3/8 X 4650 TC-TC HOSE ASSY		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	37	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	120	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	CUPILLA		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	121	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0511057103	HYDRAULIC MARKER HANDLE ASSY 6850		01
24A	0501081990	HOSE 3/8 X 4100 TR-TR		01
24B	0501080388	3/8 X 4300 TR-TC HOSE ASSY		01
24C	0501080724	3/8" X 4700 TR-TC HOSE ASSY		01
24D	0501081993	HOSE 3/8 X 4900 TC-TC 180G		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	37	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0501014177	5/8" X 2-1/2" BOLT		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0531061696	LINE MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	120	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	CUPILLA		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	121	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0511057090	HYDRAULIC MARKER HAND SET		01
24A	0501081728	HOSE 3/8 X 3100 TR-TR		01
24B	0501080392	3/8 X 3300 TR-TC HOSE		01
24C	0501081988	3/8" X 145.6" TR-TC HOSE		01
24D	0501081682	TC-TC HOSE ASSY		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01


Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	37	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04
38	0551018948	BODY MARKER SUPPORT LINE		02




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0521069643	DISC AXLE MARKER LINE		01
02	0602023094	DR16X3 C36AFPAFR73+4FR+4FR D474 10R		01
03	0581019513	DEPTH WHEEL BOX		01
04	0503019342	ROLLER BEARING		01
05	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503013758	1/4" X 1-1/2" BOLT		03
11	0503010143	1/4" SPRING WASHER		03
12	0503010358	5/16" X 5/8" BOLT		04
13	0503010179	LOCK WASHER		04
14	0503010337	5/16" NUT		04
15	0503034055	CLAMPING RING		01




Item	Code	Description	See page	QT
01	0511059584	2 BOXES WITH 10 CONDUCTORS ASSEMBLY	124	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RH SUPPORT TOWER SILO	126	01
07	0521051931	LH SUPPORT TOWER SILO	127	01
08	0521051927	TOWER SUPPORT HOPPER	128	02




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		04
02	0501010984	FLAT WASHER		04
03	0503010025	3/8" SPRING WASHER		52
04	0503010026	3/8" NUT		52
05	0511057690	3" ARTICULATED SEED CONDUCTOR	125	10
06	0571015773	SUPPORT SEED		02
07	0501011643	3/8 X 1"BOLT		08
08	0501010942	3/8" X 1-1/4" BOLT		40
09	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS		02
10	0503061899	REAR BEAN FERTILIZER ASSY		02




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER		02
09	0503010179	LOCK WASHER		02
10	0503010337	5/16" NUT		02
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT		01




Item	Code	Description	See page	QT
01	0521066206	RH SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066207	LH SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066208	SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066204	TOWER SUPPORT LEFT SIDE FIXER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066205	TOWER SUPPORT LEFT SIDE FIXER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0511057919	2 BOXES WITH 11 CONDUCTORS ASSEMBLY	132	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RH SUPPORT TOWER SILO	126	01
07	0521051931	LH SUPPORT TOWER SILO	127	01
08	0521051927	TOWER SUPPORT HOPPER	128	02




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		04
02	0501010984	FLAT WASHER		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	3" ARTICULATED SEED CONDUCTOR	125	11
06	0571015773	SUPPORT SEED		03
07	0501011643	3/8 X 1"BOLT		12
08	0501010942	3/8" X 1-1/4" BOLT		44
09	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0511058802	2 BOXES WITH 13 CONDUCTORS ASSEMBLY	134	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RH SUPPORT TOWER SILO	126	01
07	0521051931	LH SUPPORT TOWER SILO	127	01
08	0531051996	LEFT TOWER SUPPORT SILO SUPPORT WITH SCREW		01
09	0531051994	RIGHT TOWER SUPPORT SILO SUPPORT WITH SCREW		01




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		04
02	0501010984	FLAT WASHER		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	3" ARTICULATED SEED CONDUCTOR	125	13
06	0571015773	SUPPORT SEED		01
07	0501011643	3/8 X 1"BOLT		04
08	0501010942	3/8" X 1-1/4" BOLT		52
09	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0511058802	2 BOXES WITH 13 CONDUCTORS ASSEMBLY	134	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521051927	TOWER SUPPORT HOPPER	128	04




Item	Code	Description	See page	QT
01	0511058724	2 BOXES WITH 12 CONDUCTORS ASSEMBLY	137	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521051931	LH SUPPORT TOWER SILO	127	02
07	0521051927	TOWER SUPPORT HOPPER	128	02




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		04
02	0501010984	FLAT WASHER		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	3" ARTICULATED SEED CONDUCTOR	125	12
06	0571015773	SUPPORT SEED		02
07	0501011643	3/8 X 1"BOLT		08
08	0501010942	3/8" X 1-1/4" BOLT		48
09	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0521054560	ASSEMBLY CSU C3 2 BOXES 5/4 2 BOXES 5/3 6850	139	01
02	0501010942	3/8" X 1-1/4" BOLT		16
03	0501010984	FLAT WASHER		16
04	0503010025	3/8" SPRING WASHER		16
05	0503010026	3/8" NUT		16
06	0521051927	TOWER SUPPORT HOPPER	128	04
07	0521051928	FIXED TOWER SIDE RIGHT SILO SUPPORT WITH SCREW	129	01
08	0521051929	SIDE FIXED TOWER LEFT SILO SUPPORT WITH SCREW	130	01




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		08
02	0501010984	FLAT WASHER		08
03	0503010025	3/8" SPRING WASHER		88
04	0503010026	3/8" NUT		88
05	0511057690	3" ARTICULATED SEED CONDUCTOR	125	14
06	0571015773	SUPPORT SEED		06
07	0501011643	3/8 X 1" BOLT		24
08	0501010942	3/8" X 1-1/4" BOLT		56
09	0503061987	SILO FERTILIZER 05 MOUTHS FRONT MOUNTED		04
10	0521064748	05 MOUTHS CSU SUPPORT		04




Item	Code	Description	See page	QT
01	0511058996	ASSEMBLY CSU	141	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RH SUPPORT TOWER SILO	126	01
07	0521051931	LH SUPPORT TOWER SILO	127	01
08	0531051994	RIGHT TOWER SUPPORT SILO SUPPORT WITH SCREW		01
09	0531051996	LEFT TOWER SUPPORT SILO SUPPORT WITH SCREW		01




Item	Code	Description	See page	QT
01	0503061899	REAR BEAN FERTILIZER ASSY		02
02	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS		02
03	0511057690	3" ARTICULATED SEED CONDUCTOR	125	11
04	0501010942	3/8" X 1-1/4" BOLT		44
05	0503010025	3/8" SPRING WASHER		52
06	0503010026	3/8" NUT		52
07	0501011643	3/8 X 1"BOLT		04
08	0571015773	SUPPORT SEED		01
09	0521063401	SEED BOX ONLY FIXING LOCK		04
10	0501010984	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		15mt
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		02
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	147	02
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		14




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		16mt
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		02
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	147	02
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		14




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		17mt
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		02
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	147	02
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		14




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		18mt
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		02
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	147	02
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		14




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		22mt
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		04
04	0503012903	T-80M CRAMP NYLON		70
05	0521052792	MOUNTED REAR LIGHT	147	04
06	3505151602	TUBE		0,6mt
07	0503017702	FIXER		20



Item	Code	Description	See page	QT
01	0503018738	LIGHTHOUSE		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	LOCK WASHER		04
08	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER		01
06	0503010337	5/16" NUT		01
07	0511033413	PACKAGING WITH MANUAL / CATALOG		01



Item	Code	Description	See page	QT
01	0521053227	FRONT LEFT SHORT SEED ROW	150	01
02	0521053230	FRONT RIGHT SHORT SEED ROW	151	01
03	0521053228	FRONT LEFT LONG SEED ROW	152	01
04	0521053229	FRONT RIGHT LONG SEED ROW	153	01
05	0521054737	FRONT SEMI-ASSEMBLED LONG LEFT SEED ROW	154	01
06	0521054736	FRONT SEMI-ASSEMBLED OF LONG RIGHT SEED LINE	155	01
07	0511059333	SEMI-ASSEMBLED MECHANICAL FRAME	165	01
07.	0521052266	SEMI-ASSEMBLED MECHANICAL FRAME SPA	166	01
08	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
09	0503010019	1/2" SPRING WASHER		01
10	0503010060	1/2" NUT		01
11	0521054771	LEFT REAR SEED ROW	169	01
12	0521054770	RIGHT REAR SEED ROW	170	01
13	0521054984	DEPTH/COMPACTOR SYSTEM - SPT	178	01
13.	0521054758	CONTROL DEPTH WITH REGULATOR	186	01
13..	0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	196	01
13...	0521055397	DEEP WHEEL / COMPACTOR SYSTEM	205	01
13....	0521056317	DEPTH CONTROL WITH LEVER REGULATOR AXIS CPERA	ANGLE 215	01
13.....	0531050978	DEPTH CONTROL WITH FAST REGULATING AXIS	ANGLE 216	01
14	0521054811	FERTILIZER SHORT LINE	223	01
15	0521054812	LONG FERTILIZER LINE	224	01
16	0521054769	LEFT DDD FERTILIZER WITH SUPPORT	230	01
17	0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	231	01
18	0521052273	ASSY SEED PIPE SYSTEM WITH GLOVE	234	01
18.	0511059023	SEED SYSTEM ASSY	235	01
19	0511052024	FAST CLOSING SET	238	01
20	0521053947	AUTOMATIC DISARMING ROD	239	01
21	0503030391	RIGHT FERTILIZER NOZZLE		01
22	0503030392	LEFT FERTILIZER NOZZLE		01

Item	Code	Description	See page	QT
23	0503031050	CURVED CONDUCTOR		01
24	0503010246	CLAMP		01
25	0503031076	2" HOSE CLAMP		01
26	0503031145	2" X 2" X 20" HOSE		01
27	0511018662	SPACING PLATE		01
28	0581010082	FERTILIZER SOCKET RIGHT		01
29	0531013600	PRESS ADJUSTMENT LEVER		01
30	0521053946	SCARING ROD	243	01
31	0511017969	0.1" SPACING PLATE		01
32	0521069127	BOTTOM NOZZLE FERTILIZER		01
33	0503030483	FERTILIZER SOCKET		01
34	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
35	0501010984	FLAT WASHER		01
36	0503010025	3/8" SPRING WASHER		01
37	0503010026	3/8" NUT		01
38	0503016204	CORN DISK 12 ORANGE		01
38.	0503016218	DISC OF SOYBEAN		01
39	0503016214	RING CORN (APOLLO740)		01
39.	0503016220	RING TO SOYBEANS (APOLLO 745)		01
39..	0503016221	RING TO SOYBEANS (APOLLO 571)		01
40	0503033672	NOZZLE WITHOUT TITANIUM		01
41	0503010905	1/2" X 2-1/4" BOLT		01
42	0521068982	KEY CASH DISC CUTTING		01
43	0503010019	1/2" SPRING WASHER		01
44	0503010060	1/2" NUT		01
45	0501054292	V RIGHT WHEEL PRESS FERTILIZER ASSY	245	01
46	0501054293	V LEFT WHEEL PRESS FERTILIZER ASSY	246	01
47	0581010083	FERTILIZER SOCKET LEFT		01
48	0501050120	LARGER WALKING BEAM ASSY	250	01
49	0503030558	PULLEY 4Z CORN PLASTIC		01
50	0521057911	SHORT FERTILIZER LINE DPLEB 18 ASSY	251	01
51	0521057912	FULL FERTILIZER LINE DPLEB 18 ASSY	253	01
52	0571011730	SEED CONDUCTOR 3" X 1500		01
53	0521057957	FIXED ROD EXTENSION WITH FIXATION	256	01




Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	156	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	157	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	CUPILLA		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	158	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	159	01
20	0521064651	LEFT SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	163	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06

**FRONT LEFT SHORT SEED ROW**

0521053227


Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08



Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
03	0521055213	LINE BEARING SEED	156	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	157	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	CUPILLA		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	158	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	159	01
20	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	163	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06




Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08



Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	156	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	157	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	CUPILLA		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	158	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	159	01
20	0521064650	LEFT SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	163	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06




Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08



Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	156	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	157	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	CUPILLA		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	158	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	159	01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	163	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06



Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0503010045	O'RING		08
03	0521055213	LINE BEARING SEED	156	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	157	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	CUPILLA		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	158	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
20	0521064650	LEFT SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	163	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06



PST DUO FLEX - FRAME 4880/5340/5950/6350/6850 - CSU
FRONT SEMI-ASSEMBLED LONG LEFT SEED ROW

Page 154
0521054737

Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01




Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0503010045	O'RING		08
03	0521055213	LINE BEARING SEED	156	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	157	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	CUPILLA		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	158	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	163	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06




PST DUO FLEX - FRAME 4880/5340/5950/6350/6850 - CSU
FRONT SEMI-ASSEMBLED OF LONG RIGHT SEED LINE

Page 155
0521054736


Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01




Item	Code	Description	See page	QT
01	0502012718	BEARIN BODY		01
02	0503019355	BEARING 6202 2RS1		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	BOX TRANSMISSION COVER		01
03	0503019361	BEARING 6006 RS1		02
04	0503019363	BEARING 6005		01
05	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503019362	BEARING 6005 RS1		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501059326	UNIVERSAL JOINT AXLE	160	01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0521055227	BEARING SHAFT HEX	161	01




Item	Code	Description	See page	QT
01	0561016322	5/8" HEX AXLE		01
02	0501056296	UNIVERSAL JOINT		01
03	0503011855	0.2" X 1.8" SPRING PIN		02
04	0561014794	350 AXLE HEX		01




Item	Code	Description	See page	QT
01	0501059363	5/8" HEX AXLE BEARING	162	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0561014911	AXLE SLEEVE GUIDES HEX		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		02




Item	Code	Description	See page	QT
01	0502012819	17Z GEAR WITH HEX HOLE		01
02	0521055220	BEARING FRONT LINE SEED	164	01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503019356	BEARING 6005 2RS1		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521066496	FRAME MECHANICAL CENTRAL SEED LINE		01
02	0511059334	BEARING WITH LONG FRONT AXLE	167	01




Item	Code	Description	See page	QT
01	0521066539	CENTRAL SEED LINE FRAME		01
02	0521052268	LONG SHAFT BEARING AND JOINT SPA	168	01




Item	Code	Description	See page	QT
01	0511058143	UNIVERSAL JOINT AXLE		01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0521055227	BEARING SHAFT HEX	161	01




Item	Code	Description	See page	QT
01	0521052269	UNIVERSAL JOINT AXLE SPA		01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0521055227	BEARING SHAFT HEX	161	01




Item	Code	Description	See page	QT
01	0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	171	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0521055871	LEFT DOUBLE DISC SEED 15 X 15		01




Item	Code	Description	See page	QT
01	0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	171	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0521055870	RIGHT DOUBLE DISC SEED 15 X 15		01




Item	Code	Description	See page	QT
01	0581019201	CROWN SHAFT		01
02	0503019340	LUBRICANT GLOVE		02
03	0503011030	2-014 N 3006-9B O'RING		02
04	0581019200	CONICA 40Z GEAR		01
05	0581019199	FIXED BASE		01
06	0581019202	PINHAO CONICO 10Z X 5/8		01
07	0501013354	FLAT WASHER		01
08	0503010410	RING		02
09	0503019341	LUBRICANT GLOVE		01




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	174	01
02	0521054761	LEFT LOW CUBE	176	01
03	0521054760	DOWN LOW CUBE	177	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0511015098	FLAT WASHER		04
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	175	01
02	0521054761	LEFT LOW CUBE	176	01
03	0521054760	DOWN LOW CUBE	177	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0511015098	FLAT WASHER		04
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O-RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502012736	HUB LOWER		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012736	HUB LOWER		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	179	01
02	0501052538	DEPTH BAND WITH ARMS	180	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0521054990	LEFT COMPACTOR WHEEL	202	01
06	0521055017	RIGHT COMPACTOR WHEEL	203	01




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	181	01
02	0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	182	01
03	0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	183	01
04	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	185	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	SCREW 3/8 UNC X 3/4		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED GLOVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	184	01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	184	01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL BOX		01
02	0581019515	AXIS		01
03	0503034055	CLAMPING RING		01
04	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
05	0503013758	1/4" X 1-1/2" BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0503010878	5/8" SELF ALIGNING NUT		01
10	0503030757	2.9" X 2" X 0.02" JOINT		01
11	0521019178	COVER DEPTH		01



Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT GLOVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02



Item	Code	Description	See page	QT
01	0521054751	DEPTH CONTROL WITH THREAD	187	01
02	0511055819	DEPTH WHIT AROS BAND	192	02
03	0521054752	V COMPACTING SYSTEM	193	01
04	0503010479	BOLT		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2" NUT		02
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
08	0503013816	5/16" LOCKNUT		08
09	0521054753	DRIVE WHEEL V RUBBER RIGHT	194	01
10	0521054754	DRIVE WHEEL V LEFT RUBBER	195	01




Item	Code	Description	See page	QT
01	0581017621	CONTROL AXLE		01
02	0521063812	REGULATOR LEVER ALXE		01
03	0503011336	1/2" HEX SELF ADJUSTING NUT		01
04	0511065308	LOCK REGULATOR		01
05	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
06	0541011627	FLAT WASHER		01
07	0503010140	1/8" X 3/4" COTTERPIN		01
08	0521053245	LEFT ARM WHEELS	188	01
09	0521053244	ARM RIGHT WHEEL COBRIDORA	189	01
10	0581017646	SLEEVE LOCK CONTROL ARM		02
11	0571013189	SLEEVE SUPPORT BEATER		01
12	0521063813	WHEEL PRESS BEATER		01
13	0501010937	13.5 X 28 X 3 FLAT WASHER		01
14	0503010045	O'RING		04
15	0503017375	1/2" X 1-1/4" BOLT		01
16	0503014007	1/2" X 1-1/4" BOLT		01
17	0503010019	1/2" SPRING WASHER		03
18	0503010920	1/2" X 1.1/2" BOLT		01
19	0503010023	3/4" SPRING WASHER		04
20	0521053483	CPRA RIGHT DEPTH CONTROL CUBE WITHOUT LUBRICATION		01
21	0521053484	CPRA LEFT DEPTH CONTROL CUBE WITHOUT LUBRICATION		01
22	0581019171	REGULATOR		01
23	0521069476	EXTERNAL COLUMN CONTROL DEPTH		01
24	0521069475	INTERNAL COLUMN CHECK DEPTH		01
25	0503010683	0,2" X 1,2" SPRING PIN		01
26	0503034830	REGULATION LATCHE		01
27	0521054750	CRANK ASSEMBLY		01
27A	0521069477	HAND CRANK		01
27B	0503030878	LEVER CRANK		01
28	0503030751	REGULATOR PLATE		01




Item	Code	Description	See page	QT
29	0503010001	3.2 X 5.5 RIVET		04

LEFT ARM WHEELS


0521053245




Item	Code	Description	See page	QT
01	0581017620	LEFT ARM WHEELS		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503019275	SLEEVE LUBRICATION SYSTEM		01




Item	Code	Description	See page	QT
01	0581011340	ARM COVER		01
02	0503011402	0.2" X 0.8" SPRING PIN		02
03	0581017645	WHEEL RIGHT ARM		01
04	0503019275	SLEEVE LUBRICATION SYSTEM		01




Item	Code	Description	See page	QT
01	0581019165	CASE WHEEL DEPTH WITHOUT GREASE FITTING		01
02	0503015081	502052 CLAMPING RING (FOR AXLE)		01
03	0503014679	2-134 O'RING		01
04	0581019170	CUBE COVER		01
05	0501010984	FLAT WASHER		01
06	0503010025	3/8" SPRING WASHER		01
07	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
08	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
09	0581019166	RIGHT AXIS		01
10	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		01




Item	Code	Description	See page	QT
01	0581019165	CASE WHEEL DEPTH WITHOUT GREASE FITTING		01
02	0503015081	502052 CLAMPING RING (FOR AXLE)		01
03	0503014679	2-134 O'RING		01
04	0581019170	CUBE COVER		01
05	0581019167	LEFT AXLE		01
06	0501010984	FLAT WASHER		01
07	0503010025	3/8" SPRING WASHER		01
08	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
09	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
10	0503019348	SCREW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503013758	1/4" X 1-1/2" BOLT		05
04	0503013814	1/4" NC LOCKNUT		05




Item	Code	Description	See page	QT
01	0581017647	PRESS WHEELS ARM		01
02	0503030883	RIGHT TORSION SPRING		01
03	0581017622	SEAT SUPPORT		01
04	0581017648	PIVOT SHAFT		01
05	0503010839	03"X 0.6" SPRING PIN		01
06	0521069490	RIGHT REGULATOR		01
07	0521069491	LEFT REGULATOR		01
08	0581017817	ADJUSTMENT SHAFT COMPACTOR 1/2 THREAD WITHOUT LUBRICATION		01
09	0521063812	REGULATOR LEVER ALXE		01
10	0503011336	1/2" HEX SELF ADJUSTING NUT		02
11	0511065308	LOCK REGULATOR		01
12	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
13	0541011627	FLAT WASHER		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0571013293	SLEEVE LOCK COMPACTOR V CONTROL WITH SCREW		01
16	0581013744	PROTECTION COVER - CPRA		01
17	0503013096	5/16" X 4" BOLT		01
18	0503013816	5/16" LOCKNUT		01
19	0503019273	SLEEVE		02
20	0503010045	O'RING		02
21	0503010025	3/8" SPRING WASHER		02
22	0503010026	3/8" NUT		02
23	0503011404	BOLT		02
24	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01




Item	Code	Description	See page	QT
01	0581019097	BOX LOWER WHEEL		01
02	0581012949	BEARING COVER		01
03	0503018045	2-130 (AGEL) O'RING		01
04	0503011105	SEAL RING		01
05	0502012893	WHEEL BOX		01
06	0521018928	PRESS WHEEL RIM		02
07	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
08	0503013816	5/16" LOCKNUT		09
09	0503010011	5/16" X 1/2" BOLT		06
10	0503010358	5/16" X 5/8" BOLT		03
11	0581019166	RIGHT AXIS		01
12	0501010984	FLAT WASHER		01
13	0503010025	3/8" SPRING WASHER		01
14	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
15	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		01
16	0503033787	NUT 3/4 UNF		01
17	0581019215	DUST CLOAK		01




Item	Code	Description	See page	QT
01	0581019097	BOX LOWER WHEEL		01
02	0581012949	BEARING COVER		01
03	0503018045	2-130 (AGEL) O'RING		01
04	0503011105	SEAL RING		01
05	0502012893	WHEEL BOX		01
06	0521018928	PRESS WHEEL RIM		02
07	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
08	0503013816	5/16" LOCKNUT		09
09	0503010011	5/16" X 1/2" BOLT		06
10	0503010358	5/16" X 5/8" BOLT		03
11	0581019167	LEFT AXLE		01
12	0501010984	FLAT WASHER		01
13	0503010025	3/8" SPRING WASHER		01
14	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
15	0503033788	NUT 3/4		01
16	0503019348	SCREW 3/8 UNC X 3/4		01
17	0581019215	DUST CLOAK		01




Item	Code	Description	See page	QT
01	0521055065	ASSY DEPTH / COMPACTOR	197	01
02	0521055068	RAYED WHEEL CENTER CLOSED	200	02
03	0521054990	LEFT COMPACTOR WHEEL	202	01
04	0521055017	RIGHT COMPACTOR WHEEL	203	01
05	0503016453	1/2" X 2.1/2 BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010028	1/2" NUT		02




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0571013054	DEPTH CONTROL WHEEL AXLE		01
04	0502012663	EXTENSION		01
05	0501056769	DEPTH WHEELS REGULATOR ASSY		01
06	0503019398	AXLE RETAINER RING		01
07	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	185	01
08	0521055054	LEFT ARM WITH SLEEVE	198	01
09	0521055066	RIGHT ARM WITH GLOVE	199	01
10	0511015346	FLAT WASHER		04
11	0571015974	WASHER		02
12	0511017302	FLAT WASHER		02
13	0503010256	3/8" X 3/4" BOLT		01
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		04
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2" NUT		02
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0581019473	ARTICULATED GLOVE		02
20	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0581019523	LEFT ARM WHEEL DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019524	RIGHT ARM DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	201	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	LOCK WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0581019522	CASE WHEEL DEPTH WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0503010143	1/4" SPRING WASHER		03
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019529	DEPTH REGULATOR SHAFT		01
11	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	204	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05



Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	204	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02



Item	Code	Description	See page	QT
01	0521055398	DEPTH WHEEL	206	01
02	0521055093	BODY COMPACTOR	214	01
03	0521055017	RIGHT COMPACTOR WHEEL	203	01
04	0521054990	LEFT COMPACTOR WHEEL	202	01

DEPTH WHEEL


0521055398




Item	Code	Description	See page	QT
01	0581019532	DEPTH CONTROL SUPPORT		01
02	0581019531	ARTICULATED AXLE WHEEL DEPTH		02
03	0501059228	ADJUSTMENT LEVER	207	01
04	0502012611	DEPTH CONTROL AXLE		01
05	0571015326	ARTICULATION SLEEVE HANDLE		01
06	0581017075	LARGER AXLE		01
07	0581017076	SMALLER AXLE		01
08	0501011445	FLAT WASHER		04
09	0511017302	FLAT WASHER		02
10	0503011336	1/2" HEX SELF ADJUSTING NUT		02
11	0503030012	HAIR PIN		04
12	0503011402	0.2" X 0.8" SPRING PIN		02
13	0503012795	5/8" HEX SELF ADJUSTING NUT		02
14	0503010237	3/8" X 1" BOLT		01
15	0503010025	3/8" SPRING WASHER		01
16	0501010984	FLAT WASHER		01
17	0581019526	ARTICULATED AXLE LEVER DEPTH		01
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0503010302	501019 SEAL RING		01
20	0581019473	ARTICULATED GLOVE		02
21	0503010045	O'RING		02
22	0521055399	LEFT ARM WITH WHEEL	208	01
23	0521055400	RIGHT ARM WITH WHEEL	212	01

ADJUSTMENT LEVER


0501059228




Item	Code	Description	See page	QT
01	0502012603	ADJUSTMENT LEVER		01
02	0502011689	1/8" DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0511015976	FLAT WASHER		01
05	0503010140	1/8" X 3/4" COTTERPIN		01




Item	Code	Description	See page	QT
01	0521055058	LEFT ARM	209	01
02	0521055401	ASSY WHEEL	210	01
03	0581018815	SET DEVIATION		01
04	0503010741	1/2" X 2-3/4" BOLT		01
05	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0581019525	LEFT ARM WHEEL DEPTH		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT GLOVE		02




Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503030891	RUBBER BAND		01
03	0503010365	NUT		06
04	0503010179	LOCK WASHER		06
05	0503010337	5/16" NUT		06
06	0521055073	ASSEMBLY DEPTH WHEEL BOX	211	01
07	0561016889	STRIPED CAP WHEEL DEPTH		01




Item	Code	Description	See page	QT
01	0581019528	BOX WHEEL DEPTH SPA WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
11	0581019529	DEPTH REGULATOR SHAFT		01




Item	Code	Description	See page	QT
01	0521055074	RIGHT ARM WITH O-RING	213	01
02	0521055401	ASSY WHEEL	210	01
03	0581018815	SET DEVIATION		01
04	0503010741	1/2" X 2-3/4" BOLT		01
05	0503010589	1/2" UNC SELF ADJUSTING NUT		01



Item	Code	Description	See page	QT
01	0581019530	RIGHT ARM ROD DEPTH SPA NO LUBRICATION		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT GLOVE		02



Item	Code	Description	See page	QT
01	0501011753	5/16" X 1-3/4" BOLT	02	
02	0503013816	5/16" LOCKNUT	04	
03	0581015855	SLEEVE	02	
04	0502012877	PRESS WHEEL ADJUSTMENT LEVER	01	
05	0521068661	LEVER	01	
06	0503030878	LEVER CRANK	01	
07	0503031393	1.57" X 5.98" X 0.2" TRACTION SPRING	01	
08	0581019520	AXIS	01	
09	0571812442	COUPLING SHAFT	01	
10	0503010257	1/8" X 1" COTTERPIN	01	
11	0581019511	COVER	01	
12	0503010848	5/16" X 3.1/2" BOLT	02	
13	0503010752	1/2" X 3.1/2" BOLT	01	
14	0503011336	1/2" HEX SELF ADJUSTING NUT	01	
15	0503030190	0.5" X 1.6" X 0.05" SPRING	01	
16	0581019510	AXIS	01	
17	0581019512	PLATE TOP	01	
18	0503019351	LUBRICANT GLOVE	02	
19	0521069591	LEFT SIDE	01	
20	0581019548	RIGHT SIDE BODY	01	




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
03	0521019093	0.6" X 2.7" PIVOT SHAFT		01
04	0503010581	RING		01
05	1902012116	PRESS WHEEL ADJUSTER		01
06	0501052297	DEPTH WHEELS REGULATOR ASSY	181	01
07	0501052908	COMPACTOR WHEEL WITH BEARING	249	02
08	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
09	0521014508	FLAT WASHER		10
10	0503011336	1/2" HEX SELF ADJUSTING NUT		02
11	0581011100	DEPTH WHEEL AXLE		01
12	0571017749	FLAT WASHER		02
13	0521056314	LEFT ARM WHEEL DEPTH WITH CUBE CPERA	220	01
14	0521056313	RIGHT ARM WHEEL DEPTH WITH CUBE CPERA	221	01
15	0503010358	5/16" X 5/8" BOLT		08
16	0503010179	LOCK WASHER		08
17	0503013816	5/16" LOCKNUT		08
18	0501011445	FLAT WASHER		02
19	0503010311	1/2" X 1-1/4" BOLT		02
20	0503010019	1/2" SPRING WASHER		02
21	0503010025	3/8" SPRING WASHER		02
22	0503010026	3/8" NUT		02
23	0503010849	3/8" X 1-1/2" BOLT		02
24	0503010256	3/8" X 3/4" BOLT		01
25	0511055819	DEPTH WHIT AROS BAND	192	02
26	0503010691	1/4" GREASE FITTING		02
27	0503033942	COVER REGULATORY WHEEL		01
28	0521064073	REGULACION WHEEL COMPACTOR		01
29	0541016906	PRESS WHEELS REGULATOR BODY		01
30	0521010539	0.3" X 1.2" COUPLING SHAFT		01
31	0503010140	1/8" X 3/4" COTTERPIN		01




PST DUO FLEX - FRAME 4880/5340/5950/6350/6850 - CSU
DEPTH CONTROL WITH LEVER ANGLE REGULATOR AXIS

Page 215
0521056317


Item	Code	Description	See page	QT
32	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01




Item	Code	Description	See page	QT
01	0531050980	SEM SEMI-ASSEMBLED CONTROL WITHOUT LUBRICATION	217	01
02	0503010358	5/16" X 5/8" BOLT		08
03	0503013816	5/16" LOCKNUT		08
04	0521055017	RIGHT COMPACTOR WHEEL	203	01
05	0521054990	LEFT COMPACTOR WHEEL	202	01
06	0511055819	DEPTH WHIT AROS BAND	192	02




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	181	01
02	0531050975	LEFT ARM WHEELS DEPTH WITH CUBE WITHOUT LUBRICATION	218	01
03	0531050973	RIGHT ARM DEPTH WHEEL WITH HUB WITHOUT LUBRICATION	219	01
04	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	185	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	SCREEW 3/8 UNC X 3/4		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED GLOVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0531050974	CUBE CONTROL DEPTH WITHOUT LUBRICATION		01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0531050974	CUBE CONTROL DEPTH WITHOUT LUBRICATION		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503010060	1/2" NUT		01
05	0503010019	1/2" SPRING WASHER		01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0521056316	DEPTH WHEEL BOX WITH COMPLETE ANGLE 222 ADJUSTING AXLE		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110833	DEPTH CONTROL RIGHT ARM		01
02	0521056316	DEPTH WHEEL BOX WITH COMPLETE ANGLE 222		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501013636	SPACING SLEEVE		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010689	SEAL 00763-BR		01
04	0503011105	SEAL RING		01
05	0503010269	6204 BALL BEARING		02
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0521019178	COVER DEPTH		01
09	0503010143	1/4" SPRING WASHER		03
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0521060071	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0501010066	3/4" X 9" BOLT		01
02	0511017232	FLAT WASHER		02
03	0503011255	3/4" LOCK NUT		01
04	0502012873	SUPPORT DC LINE FERTILIZER		01
05	0503019278	LUBRICANT GLOVE		02
06	0581019195	SIDE GUIDE GLOVE		02
07	0581019196	CENTRAL GUIDE GLOVE		01
08	0503010410	RING		02
09	0502012876	CLAMP		01
10	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
11	0503010013	5/8" NUT		02
12	0521054906	SPRING ASSY FERTILIZER	229	01
13	0521053231	DPL 20 SHORT LINE WITHOUT LUBRICATION CONICAL BEARING	225	01
14	0521066231	SHORT FERTILIZER LINE ARM		01
15	0503017857	BOLT 5/8 UNF 4		03
16	0503010811	5/8" UNF SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0501010066	3/4" X 9" BOLT		01
02	0511017232	FLAT WASHER		02
03	0503011255	3/4" LOCK NUT		01
04	0502012873	SUPPORT DC LINE FERTILIZER		01
05	0503019278	LUBRICANT GLOVE		02
06	0581019195	SIDE GUIDE GLOVE		02
07	0581019196	CENTRAL GUIDE GLOVE		01
08	0503010410	RING		02
09	0502012876	CLAMP		01
10	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
11	0503010013	5/8" NUT		02
12	0521054906	SPRING ASSY FERTILIZER	229	01
13	0521053232	DPL 20 LONG LINE WITHOUT LUBRICATION CONICAL BEARING	226	01
14	0521066230	LONG FERTILIZER LINE ARM		01
15	0503017857	BOLT 5/8 UNF 4		03
16	0503010811	5/8" UNF SELF ADJUSTING NUT		03



Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	227	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	227	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012824	FIXING SHAFT DISC CUT LINE		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	CUTTING DISK BOX	228	01

CUTTING DISK BOX


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	CUTTING DISK BOX		01
09	0502040873	CUTTING DISC AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK		02
02	0502012184	FERTILIZER SPRING GUIDE		02
03	0503031910	1.7" X 22.8" X 0.3" SPRING		01
04	0502012510	SPRING ROD SUPPORT		01
05	0591018219	JUNCTION SHAFT 12.70 X 109 ZN		01
06	0501018535	1/2 X 1 BOLT		02
07	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		02
08	0503010060	1/2" NUT		02
09	0502010891	SPRING CHOCK SUPPORT VARON		01
10	0503010014	3/4" NUT		01
11	0521067619	TUBE LINE FERTILIZER		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0501010937	13.5 X 28 X 3 FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	176	01
03	0521054760	DOWN LOW CUBE	177	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511015098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	176	01
03	0521054760	DOWN LOW CUBE	177	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511015098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0511059023	SEED SYSTEM ASSY	235	01
02	0581014295	FIXING GLOVE		01




Item	Code	Description	See page	QT
01	0502020693	SUPPORT SEED BOX		01
02	0502012721	SEED DISC LOWER TRAIL		01
03	0503034131	DEFLECTOR		01
04	0503010025	3/8" SPRING WASHER		03
05	0503010209	3/8" UNC BUTTERFLY NUT		03
06	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
07	0571018536	HEX PRISONER		01
08	0501010984	FLAT WASHER		01
09	0503010337	5/16" NUT		01
10	0503010179	LOCK WASHER		05
11	0503062582	DEPOSIT SEED		01
12	0581011346	ADAPTER DEPOSIT		01
13	0501010694	FLAT WASHER		04
14	0503016282	ALLEN BOLT		01
15	0503016283	M8 NUT HEX		01
16	0501051094	ASSY SEED DISTRIBUTOR	236	01
17	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
18	0503016219	RING TO SOYBEANS		01
19	0503010675	5/16" X 2.1/4" BOLT		01
20	0503030083	3/8" X 3/8" X 1.6" STUD		02




Item	Code	Description	See page	QT
01	0503030381	SEED DISTRIBUTOR BOX		01
02	0502010447	TRIGGER		02
03	0501013467	KEY AXLE		01
04	0503030378	0.4" X 1.1" X 0.03" SPRING		03
05	0501013466	KEY LIMITER AXLE		01
06	0501051119	DOUBLE PULLEY ROCKER'S	237	01
07	0501013468	ROCKER ARM AXLE, OF THE PULLEY		01
08	0503030377	SCRAPER		01




Item	Code	Description	See page	QT
01	0503031129	DOUBLE PULLEY ROCKER ARM		01
02	0503031128	5Z PLASTIC DOUB PULLEY FOR SOYBEAN		02
03	0521010649	TOOTH PULLEY COUPLING SHAFT		01
04	0503011853	503050 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0521068567	BOX SPRING		01
02	0521053951	STEM	240	01
03	0503034106	80 X 230 X 16,50 HDA COMPRESSION SPRING		01
04	0581012094	SUPPORT WASHER		01
05	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
06	0571019462	SUPPORT GUIDE PRING		01
07	0503012795	5/8" HEX SELF ADJUSTING NUT		01
08	0503010691	1/4" GREASE FITTING		01
09	0503010384	1/2" X 5" BOLT		02
10	0511017302	FLAT WASHER		04
11	0503011336	1/2" HEX SELF ADJUSTING NUT		04
12	0503017874	BOLT 1/2 UNC		02
13	0571018541	BODY SOCKET FERTILIZER		01
14	0503010026	3/8" NUT		02
15	0503010025	3/8" SPRING WASHER		02
16	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
17	0501010984	FLAT WASHER		04
18	0503010417	7/8" NUT		01
19	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
20	0581012084	ARTICULATED GLOVE		01
21	0581012082	SCREW		01
22	0581012081	GLOVE		01



Item	Code	Description	See page	QT
01	0521053932	ROD WITH BEAK 0869	241	01
02	0521067065	FLANGE WASHER SPRING		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0581012092	AXLE FIXER		01
05	0521015818	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521067523	STEM WITHOUT BEAK DISARM		01
02	0502040901	FIXED ROD NOZZLE		01
03	0503016853	SPRING PIN		02
04	0503011402	0.2" X 0.8" SPRING PIN		02



Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	NUT		02

SCARING ROD


0521053946




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070085	FIXED ROD BEARING		01
03	0513010288	ELASTIC PIN 701211 10 X 24		02
04	0513010289	ELASTIC PIN 701211 10 X 24		02

SCARIFIER ROD


0501110723




Item	Code	Description	See page	QT
01	0521063867	SCARIFIER ROD		01
02	0502070082	POINT SUBSOILER		01
03	0503010585	0,24" X 1.18" SPRING PIN		03




Item	Code	Description	See page	QT
01	0521062253	RIGHT PRESS WHEEL FERT UP SUPPORT		01
02	0511064128	PRESS SUPPORT LOWWER WHEEL		01
03	0503010752	1/2" X 3.1/2" BOLT		01
04	0531013272	0.5" X 1" X 2.2" SLEEVE		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0501013491	5/8" TENSIONER SPRING		01
08	0503010013	5/8" NUT		02
09	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
10	0503010002	1800 GREASE FITTING		01
11	0503010849	3/8" X 1-1/2" BOLT		02
12	0503010025	3/8" SPRING WASHER		02
13	0503010026	3/8" NUT		02
14	0503010795	5/8" X 7" BOLT		01
15	0503012412	5/8 UNC SELF LOCKING NUT		01
16	0502011757	PRESS REGULATOR		01
17	0511054333	COMPACT WHEEL RIGHT WITH BEARING	247	01
18	0511054334	COMPACT WHEEL LEFT WITH BEARING	248	01




Item	Code	Description	See page	QT
01	0521062254	LEFT PRESS WHEEL FERT UPPER SUPPORT		01
02	0511064128	PRESS SUPPORT LOWWER WHEEL		01
03	0503010752	1/2" X 3.1/2" BOLT		01
04	0531013272	0.5" X 1" X 2.2" SLEEVE		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0501013491	5/8" TENSIONER SPRING		01
08	0503010013	5/8" NUT		02
09	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
10	0503010002	1800 GREASE FITTING		01
11	0503010849	3/8" X 1-1/2" BOLT		02
12	0503010025	3/8" SPRING WASHER		02
13	0503010026	3/8" NUT		02
14	0503010795	5/8" X 7" BOLT		01
15	0503012412	5/8 UNC SELF LOCKING NUT		01
16	0502011757	PRESS REGULATOR		01
17	0511054333	COMPACT WHEEL RIGHT WITH BEARING	247	01
18	0511054334	COMPACT WHEEL LEFT WITH BEARING	248	01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	249	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	249	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0503030379	LARGER ROCKER ARM		01
02	0502060001	PLASTIC PULLEY FOR MAIZE		01
03	0503010669	FLAT WASHER		01
04	0503010667	3/16" NUT		02
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		01




Item	Code	Description	See page	QT
01	0521066231	SHORT FERTILIZER LINE ARM		01
02	0502012873	SUPPORT DC LINE FERTILIZER		01
03	0502012876	CLAMP		01
04	0503017857	BOLT 5/8 UNF 4		03
05	0503010811	5/8" UNF SELF ADJUSTING NUT		03
06	0503011255	3/4" LOCK NUT		01
07	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
08	0503010013	5/8" NUT		02
09	0521057909	DPLEB 18 SHORT LINE WITHOUT LUBRICATION 252 TAPERED BEARING		01
10	0521054906	SPRING ASSY FERTILIZER	229	01
11	0501010066	3/4" X 9" BOLT		01
12	0511017232	FLAT WASHER		02
13	0581019195	SIDE GUIDE GLOVE		02
14	0503010410	RING		02
15	0503019278	LUBRICANT GLOVE		02
16	0581019196	CENTRAL GUIDE GLOVE		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521057908	DPLEB 18 BOX CONICAL BEARING	255	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01




Item	Code	Description	See page	QT
01	0521066230	LONG FERTILIZER LINE ARM		01
02	0502012873	SUPPORT DC LINE FERTILIZER		01
03	0502012876	CLAMP		01
04	0503017857	BOLT 5/8 UNF 4		03
05	0503010811	5/8" UNF SELF ADJUSTING NUT		03
06	0503011255	3/4" LOCK NUT		01
07	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
08	0503010013	5/8" NUT		02
09	0521057910	DPLEB 18 LONG LINE WITHOUT CONICAL 254 BEARING LUBRICATION		01
10	0521054906	SPRING ASSY FERTILIZER	229	01
11	0501010066	3/4" X 9" BOLT		01
12	0511017232	FLAT WASHER		02
13	0581019195	SIDE GUIDE GLOVE		02
14	0503010410	RING		02
15	0503019278	LUBRICANT GLOVE		02
16	0581019196	CENTRAL GUIDE GLOVE		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521057908	DPLEB 18 BOX CONICAL BEARING	255	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012824	FIXING SHAFT DISC CUT LINE		01




Item	Code	Description	See page	QT
01	0605025015	18" PLAIN COULTER BLADE		01
02	0521053697	CUTTING DISK BOX	228	01



Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
02	0511017302	FLAT WASHER		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0521069295	SUPPORT TOOL CHEST		01
06	0581017000	PLATE INTERMEDIARY		02
07	0503034772	BOX		01
08	0501011643	3/8 X 1" BOLT		04
09	0503010025	3/8" SPRING WASHER		04
10	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
02	0511017302	FLAT WASHER		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0521069405	WATER TANK SUPPORT		01
06	0503014820	BLACK WATER RESERVOIR		01

ASSY HEX AXLE


0909095190




Item	Code	Description	See page	4880	5340	5950	6350	6850
01	0531016944	RIGHT 5/8" X 96" HEX AXLE		001	000	000	000	000
01.	0561019199	5/8" X 2275 AXLE HEX		001	000	000	000	000
02	0571017427	5/8" X 2700 HEX AXLE		000	001	000	000	000
02.	0571017425	5/8" X 2530 HEX AXLE		000	001	000	000	000
03	0561018502	SHAFT AXIS 5/8 X 3000		000	000	001	001	000
03.	0571011980	HEX AXLE		000	000	001	000	000
04	0531016949	LEFT 5/8" X 125" AXLE HEX		000	000	000	001	000
04.	0561018502	SHAFT AXIS 5/8 X 3000		000	000	000	001	000
05	0571017030	SHAFT AXLE 5 / 8X3450 14E500		000	000	000	000	001
05.	0571017029	AXLE HEX		000	000	000	000	001
05..	0571017030	SHAFT AXLE 5 / 8X3450 14E500		000	000	000	000	001
05...	0571017029	AXLE HEX		000	000	000	000	001
06	0561014215	BEARING COVER LOWER ROW FRAME		002	002	002	002	002
07	0521055214	BEARING GEAR WITH	91	002	002	002	002	002
08	0502040534	SPRING GUIDE BUSHING LOCK		004	004	004	004	004
09	0501018535	1/2 X 1 BOLT		004	004	004	004	004




Item	Code	Description	See page	QT
01	0503062798	KIT MONITORING SEED 13L 45/50 PM400 PM413SSM		01
01A	0503016559	13 ROW SIMPLE CABLE MONITORING		01
01B	0503019100	SENSOR		13
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503013100	NYLON CLAMP		65
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		195
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
08	0503010669	FLAT WASHER		02
09	0503010668	3/16" SPRING WASHER		02
10	0503010667	3/16" NUT		02



Item	Code	Description	See page	QT
01	0503062797	KIT MONITORING SEED 12L 45/50 PM400		01
01A	0503016558	12 ROW SIMPLE CABLE MONITORING		01
01B	0503019100	SENSOR		12
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503013100	NYLON CLAMP		60
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		180
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
08	0503010669	FLAT WASHER		02
09	0503010668	3/16" SPRING WASHER		02
10	0503010667	3/16" NUT		02



Item	Code	Description	See page	QT
01	0503062788	SEED MONITORING KIT 14L 50 PM100 PM114SSM		01
01A	0503016491	MONITOR PLANT PM100		01
01B	0503017031	CLEANING BRUSH		01
01C	0503018974	SIMPLE MONITOR CABLE 14L 50 S PM100 020011431		01
01D	0503019100	SENSOR		14
02	0503013100	NYLON CLAMP		70
03	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		210



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

