

ROW CROP PLANTERS

PST TRIO FLEX TITANIUM - FRAME 6450/6850

Code: 0501092441
Series: S-0119
Revision: 00
Date Revision: JULHO/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS

Code	Description
0111260348	PST TRIO FLEX 6450/13E500 CI MH DC20 TIT S-0119
0111260427	PST TRIO FLEX 6450/13E500 ESPECIAL S-0119
0111260428	PST TRIO FLEX 6450/13E500 ESPECIAL S-0119
0111260350	PST TRIO FLEX 6450/13E500CI MH DC20 CSU TIT S-0119
0111260352	PST TRIO FLEX 6850/15E450 CI MH DC20 TIT S-0119
0111260335	PST TRIO FLEX 6850/15E450 ESPECIAL S-0119
0111260430	PST TRIO FLEX 6850/15E450 ESPECIAL S-0119
0111260431	PST TRIO FLEX 6850/15E450 ESPECIAL S-0119
0111260432	PST TRIO FLEX 6850/15E450 ESPECIAL S-0119
0111260433	PST TRIO FLEX 6850/15E450 ESPECIAL S-0119
0111260437	PST TRIO FLEX 6850/15E450 ESPECIAL S-0119
0111260354	PST TRIO FLEX 6850/15E450CI MH DC20 CSU TIT S-0119
0111260434	PST TRIO FLEX 6850/15E450D/HDA DC20 CSU TIT S-0119

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.

INDEX

0909095123	FRAME ASSY	1
0521051604	FRAME WITH ARTICULATION 6450	2
0511059420	FRAME WITH ARTICULATION 6850	3
0521051602	RIGHT FRAME WITH AXLE WHEELED 6450	4
0511053046	RIGHT FRAME WITH AXLE WHEELED 6850	5
0511053190	CENTRAL FRAME WITH WHEELED AXLE 6450/7285/7450/8460	6
0511059288	CENTRAL FRAME WITH WHEELED AXLE 5750/6850/7860/8160	7
0521051603	LEFT FRAME WITH WHEELED AXLE 6450	8
0511053047	LEFT FRAME WITH WHEELED AXLE 6850	9
0511059232	ASSEMBLY SPRING TRACTION	10
0521055229	WHEELED WITH 655 DRIFT SPRING WITH TRANSMISSION	11
0521055241	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	12
0521055231	655 WHEELED SUPPORT WITH TRANSMISSION	13
0521055243	655 WHEELED BRACKET WITHOUT TRANSMISSION	14
0501058241	TENSIONER CHAIN SUPPORT	15
0521055232	WHEEL WITH PNEU	16
0521055239	WHEEL WITH PNEUME WHEELED BOX WITHOUT TRANSMISSION	17
0503062159	WHEEL	18
0521055233	WHEELED TRANSMISSION WITHOUT TIRE	19
0521055244	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	20
0521055234	WHEELED FASTENER	21
0521055236	INTERMEDIARY CURRENT STRETCHER	22
0521055237	WHEEL FIXED CURRENT STRETCHER	23
0521055235	WHEEL MOBILE CURRENT STRETCHER	24
0909095124	HEADER FULL ASSEMBLY	25
0511055096	TRACTOR HITCH	26
0521051614	TURNBUCKLE SIDE UPPER	27
0521051616	TURNBUCKLE SIDE 505/480	28
0521050133	TURNBUCKLE SIDE 755/480	29
0511059237	3 POINT TURNBUCKLE	30
0521045756	HYDRAULIC CYLINDER	31
0521051627	HYDRAULIC SYSTEM ASSEMBLY 6450	32
0511059419	HYDRAULIC SYSTEM ASSEMBLY 6850/7285/7450/7860/7960	33
0511059290	VALVE ASSEMBLY	34
0501053835	FEMALE QUICK COUPLER	35
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	36
0521051608	SILO FERTILIZER ASSEMBLY 6450	37
0521052737	SILO FERTILIZER ASSEMBLY 6850	38
0521053360	SILO FERTILIZER ASSEMBLY STEP 1 6850	39
0521051606	SILO FERTILIZER RIGHT SUPPORT 6450	40
0521052712	SILO FERTILIZER RIGHT SUPPORT 6850	41
0521053357	SUPPORT SILO FERTILIZER RIGHT DISTRIBUTOR STEP 1 6850	42
0521051605	SILO FERTILIZER LEFT SUPPORT 6450	43
0521052721	SILO FERTILIZER LEFT SUPPORT 6850	44
0521053358	SUPPORT SILO FERTILIZER LEFT DISTRIBUTOR STEP 1 6850	45
0521051607	SUPPORT SILO CENTRAL FERTILIZER 6450/7285/7450/8460	46
0521052734	SUPPORT SILO CENTRAL FERTILIZER 6850/7860	47
0521053359	SUPPORT SILO CENTRAL FERTILIZER WITH DISTRIBUTOR STEP 1 6850	48
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	49
0511056339	DISTRIBUTOR FERTILIZER SIDE RIGHT STEP 1"	50
0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	51
0511056338	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 1"	52



MARCHESAN

INDEX

0501053788	Q3/4" FASTENER AXLE ASSY	53
0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	54
0521051628	TRANSMISSION ASSEMBLY 6450	55
0511058230	TRANSMISSION ASSEMBLY 6850	56
0501052560	AXLE MOTOR SLOW-MOVING ASSY	57
0511051434	TRANSMISSION DRIVING ASSY	58
0511047069	SIDE TRANSMISSION DRIVING	59
0511047070	LH SIDE TRANSMISSION DRIVING	60
0521043316	RIGHT GEAR BOX ASSY	61
0521043317	LEFT GEAR BOX ASSY	62
0501058212	SEMI MOUNTED RIGHT CHANGE	63
0501058213	LH GEAR BOX	64
0511059266	CLOSED BEARING	65
0501056271	BEARING CLOSED	66
0501056443	BEARING ASSY GEAR BOX	67
0501056444	BEARING WITH ROLLING	68
0501048790	AXLE WITH LINK ASSY	69
0501054655	CHAIN TENSIONER ASSY	70
0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	71
0511059261	CHAIN TENSIONER	72
0521055217	LOWER CURRENT STRETCH	73
0501058254	UPPER SEED CHAIN TENSIONER	74
0521055216	BEARING WITH GEAR	75
0521055218	BEARING GEAR WITH DOUBLE	76
0521055214	BEARING GEAR WITH	77
0521055215	DOUBLE TRANSMISSION BEARING	78
0521052670	PLATFORM ASSEMBLY 6450	79
0521052671	PLATFORM ASSEMBLY 6850	80
0521051609	HANDLE ASSEMBLY 6450	81
0511058234	HANDLE ASSEMBLY 6850	82
0511054971	RESTING ASSEMBLY	83
0511056536	ASSEMBLY LADDER	84
0521051625	SEMI MOUNTED HYDRAULIC MARKER 6450	85
0909095125	DOUBLE HYDRAULIC MARKER ASSEMBLY 6850	86
0521055204	LIGNE DE DISQUE MARKER	87
0501054649	SEQUENTIAL VALVE ASSY	88
0511058449	HYDRAULIC CYLINDER	89
0511058431	HYDRAULIC CYLINDER	90
0521052821	TRANSMISSION AXLE ASSEMBLY 6450	91
0521052826	TRANSMISSION AXLE ASSEMBLY 6850	92
0511059233	INTERMEDIATE TRANSMISSION	93
0511057287	TRANSMISSION	94
0503062206	CARDAN TERMINAL	95
0503062392	DRIVE SHAFT	96
0521052803	REAR LIGHT ASSEMBLY 5750/5850/6450/6850/7285/7450	97
0521052792	MOUNTED REAR LIGHT	98
0521051617	ASSEMBLY CSU C3 SEMI MOUNTED 6450	99
0511057979	ASSEMBLY CSU 6850	100
0521050210	ASSEMBLY CSU 6450	101
0511057755	ASSEMBLY CSU 6850	102
0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	103
0521051927	TOWER SUPPORT HOPPER	104
0521052810	ASSY MANUAL DOOR	105
0909095140	SEED LINE/FERTILIZER ASSEMBLY	106
0909095126	SEED LINE/FERTILIZER CSU ASSEMBLY	107




MARCHESAN

INDEX

0521053227	LEFT SHORT SEED ROW FRONT	108
0521053230	SHORT SEED ROW FRONT	109
0521053228	LEFT SHORT SEED ROW FRONT	110
0521053229	SHORT SEED ROW FRONT	111
0521054737	FRONT SEMI MOUNTED LINE LONG LEFT SEED WITHOUT LUBRICATION	112
0521054736	FRONT SEMI MOUNTED ROW LONG RIGHT SEED LINE WITHOUT LUBRICATION	113
0521055213	LINE BEARING SEED	114
0521055223	SEED LINE TRANSMISSION BOX	115
0511055260	SEED ROW CHAIN TENSIONER	116
0521055226	BEARING WITH AXLE JOINT	117
0501059326	UNIVERSAL JOINT AXLE	118
0521055227	BEARING SHAFT HEX	119
0501059363	5/8" HEX AXLE BEARING	120
0521055219	BEARING WITH GEAR 17Z HEX 5/8	121
0521055220	BEARING FRONT LINE SEED	122
0511059333	SEMI-ASSEMBLED MECHANICAL FRAME	123
0511059334	BEARING WITH LONG FRONT AXLE	124
0511058143	UNIVERSAL JOINT AXLE	125
0521054771	LEFT REAR SEAL LINE WITHOUT LUBRICATION	126
0521054770	REAR RIGHT SEED LINE WITHOUT LUBRICATION	127
0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	128
0521054763	DDD LEFT SEED	129
0521054762	RIGHT DDD SEED	130
0511052302	LH SUPPORT DDD GUIDE	131
0511052301	SUPPORT DDD 15 RIGHT	132
0521054761	LEFT LOW CUBE	133
0521054760	DOWN LOW CUBE	134
0521054984	DEPTH SYSTEM / COMPACTOR WITHOUT LUBRICATION	135
0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	136
0501052297	DEPTH WHEELS REGULATOR ASSY	137
0521054987	LEFT ARM WHEEL DEPTH WITH NO LUBRICATION CUBE	138
0521054988	RIGHT ARM ROD DEPTH WITH LUBRICANT-FREE HUB	139
0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	140
0521055033	COMPACTADOR BODY	141
0521055054	LEFT ARM WITH SLEEVE	142
0521055066	RIGHT ARM WITH GLOVE	143
0501052538	DEPTH BAND WITH ARMS	144
0521054990	LEFT COMPACTOR WHEEL	145
0521055017	RIGHT COMPACTOR WHEEL	146
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	147
0521054811	FERTILIZER SHORT LINE	148
0521054812	LONG FERTILIZER LINE	149
0521053231	DPL 20 SHORT LINE WITHOUT LUBRICATION CONICAL BEARING	150
0521053232	DPL 20 LONG LINE WITHOUT LUBRICATION CONICAL BEARING	151
0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	152
0521053697	CUTTING DISK BOX	153
0521054906	SPRING ASSY FERTILIZER	154
0521054769	LEFT FERTILIZER WITH SUPPORT	155
0521054768	DDD RIGHT FERTILIZER WITH SUPPORT	156
0521054765	DDD LEFT FERTILIZER	157
0521054764	DDD RIGHT FERTILIZER	158
0511056608	TITANIUM SEED SYSTEM	159

INDEX

0521050096	SEED DEPOSIT SYSTEM (CSU)	160
0511057777	SYSTEM SEED POPCORN MAKER TVS ASSY	161
0511052058	SEED SYSTEM TITANIUM	162
0511052024	FAST CLOSING SET	163
0521053947	HDA	164
0521053951	STEM	165
0521050525	FIXER FERTILIZER CONDUCTOR	166
0521053946	SCARING ROD	167
0521054758	CONTROL DEPTH WITH REGULATOR	168
0521055053	DEEP WHEEL / COMPACTOR SYSTEM	169
0521054751	DEPTH CONTROL WITH THREAD	170
0521055065	ASSY DEPTH / COMPACTOR	171
0511055819	DEPTH WHIT AROS BAND	172
0521054752	V COMPACTING SYSTEM	173
0521055068	RAYED WHEEL CENTER CLOSED	174
0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	175
0521054753	DRIVE WHEEL V RUBBER RIGHT	176
0521054754	DRIVE WHEEL V LEFT RUBBER	177
0511056736	HOSE SUPPORT	178
0521052796	CYLINDER ASSEMBLY 5750/6850/7860/7960/8460	179
0511058406	HYDRAULIC CYLINDER	180
0521053426	MONITORING ASSEMBLY PLANTING SEEDS 15L PM400	181




Item	Code	Description	See page	6450	6850
01	0521051604	FRAME WITH ARTICULATION 6450	2	001	000
01.	0511059420	FRAME WITH ARTICULATION 6850	3	000	001
02	0521064285	LOCK LOWER FRAME		002	002
03	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		002	002
04	0503010002	1800 GREASE FITTING		002	002
05	0503010003	1845 GREASE FITTING		008	008
06	0503010004	1890 GREASE FITTING		002	002
07	0511059232	ASSEMBLY SPRING TRACTION	10	002	002
08	0521055229	WHEELED WITH 655 DRIFT SPRING WITH 11		004	004
09	0521055241	WHEELED WITH 655 DRIFT SPRING WITHOUT 12		002	002
10	0909095124	HEADER FULL ASSEMBLY	25	001	001
11	0521051627	HYDRAULIC SYSTEM ASSEMBLY 6450	32	001	000
11.	0511059419	HYDRAULIC SYSTEM ASSEMBLY 6850/7285/7450/7860/7960	33	000	001
12	0521051608	SILO FERTILIZER ASSEMBLY 6450	37	001	000
12.	0521052737	SILO FERTILIZER ASSEMBLY 6850	38	000	001
13	0521051628	TRANSMISSION ASSEMBLY 6450	55	001	000
13.	0511058230	TRANSMISSION ASSEMBLY 6850	56	000	001
14	0521052670	PLATFORM ASSEMBLY 6450	79	001	000
14.	0521052671	PLATFORM ASSEMBLY 6850	80	000	001
15	0521051609	HANDLE ASSEMBLY 6450	81	001	000
15.	0511058234	HANDLE ASSEMBLY 6850	82	000	001
16	0511054971	RESTING ASSEMBLY	83	002	002
17	0511056536	ASSEMBLY LADDER	84	002	002
18	0521051625	SEMI MOUNTED HYDRAULIC MARKER 6450	85	001	000
18.	0909095125	DOUBLE HYDRAULIC MARKER ASSEMBLY 6850	86	000	001
19	0521052821	TRANSMISSION AXLE ASSEMBLY 6450	91	001	000
19.	0521052826	TRANSMISSION AXLE ASSEMBLY 6850	92	000	001
20	0521052803	REAR LIGHT ASSEMBLY 5750/5850/6450/6850/7285/7450	97	001	001


FRAME ASSY

0909095123


Item	Code	Description	See page	6450	6850
21	0521051617	ASSEMBLY CSU C3 SEMI MOUNTED 6450	99	001	000
21.	0511057979	ASSEMBLY CSU 6850	100	000	001
22	0521052810	ASSY MANUAL DOOR	105	001	001
23	0909095140	SEED LINE/FERTILIZER ASSEMBLY	106	001	001
23.	0909095126	SEED LINE/FERTILIZER CSU ASSEMBLY	107	001	001
24	0541015451	FIXED KEY 2.3/8 X 2.3/4		001	001
25	0501065677	STRUT		002	002
26	0501047895	ROD STOP		003	003
27	0501047885	ROD STOP		003	003
28	0501047886	ROD STOP		003	003
29	0501047887	ROD STOP		003	003
30	0511056736	HOSE SUPPORT	178	001	001
31	0521013022	TRANSPORT LOCK		003	003
32	0503030168	HAIR PIN		003	003
33	0501068994	0.3" X 3.1" LOCK PIN		003	003
34	0521066304	HOSE GUIDE		001	001
35	0503019262	SOAP DISH VACUUM		001	001
36	0503010780	N-2050 AMENDMENT		002	002
37	0503011750	AMENDMENT WITH LOCK		006	006
38	0503011751	REDUCTION		006	006
39	0503010951	REDUCTION		004	004
40	0503010246	CLAMP		013	015
41	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		002	002
42	0503013816	5/16" LOCKNUT		002	002
43	0521052796	CYLINDER ASSEMBLY 5750/6850/7860/7960/8460	179	001	001
44	0521053426	MONITORING ASSEMBLY PLANTING SEEDS 15L PM400	181	000	001
45	0521055204	LIGNE DE DISQUE MARKER	87	002	002




Item	Code	Description	See page	QT
01	0521051602	RIGHT FRAME WITH AXLE WHEELED 6450	4	01
02	0521051603	LEFT FRAME WITH WHEELED AXLE 6450	8	01
03	0511053190	CENTRAL FRAME WITH WHEELED AXLE 6450/7285/7450/8460	6	01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0503011442	3/4" SPRING WASHER		18
06	0501010098	3/4" UNC BOLT		18
07	0571010094	SLEEVE FLANGE		06
08	0521063912	PIVOT SHAFT		02
09	0571013510	LOCK AXLE		02
10	0503030085	LOCK PIN		02
11	0571010095	FLAT WASHER		02
12	0521063003	LOCK PIN		02
13	0571010969	LOCK SLEEVE FRAME		02
14	0503013627	1.1/2 SPRING WASHER		02
15	0501010110	1.1/2" NUT		02
16	0502012698	CLAMP		04
17	0503011444	SPRING WASHER		04
18	0503010365	NUT		04
19	0503010026	3/8" NUT		07
20	0503010025	3/8" SPRING WASHER		07
21	0501011643	3/8 X 1" BOLT		12
22	0581018028	TROUGH 24 X 50 X 1650		02
23	0581018018	TROUGH 24 X 50 X 1255		02




Item	Code	Description	See page	QT
01	0511053046	RIGHT FRAME WITH AXLE WHEELED 6850	5	01
02	0511059288	CENTRAL FRAME WITH WHEELED AXLE 5750/6850/7860/8160	7	01
03	0511053047	LEFT FRAME WITH WHEELED AXLE 6850	9	01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0503011442	3/4" SPRING WASHER		18
06	0501010098	3/4" UNC BOLT		18
07	0571010094	SLEEVE FLANGE		06
08	0571013510	LOCK AXLE		02
09	0503030085	LOCK PIN		02
10	0571010095	FLAT WASHER		02
11	0521063003	LOCK PIN		02
12	0571010969	LOCK SLEEVE FRAME		02
13	0503013627	1.1/2 SPRING WASHER		02
14	0501010110	1.1/2" NUT		02
15	0502012698	CLAMP		04
16	0503011444	SPRING WASHER		04
17	0503010365	NUT		04
18	0521063912	PIVOT SHAFT		02
19	0581015857	GUTTER 24 X 50 X 1080		01
20	0581018001	GUTTER 24 X 50 X 980		02
21	0581017747	GUTTER 25 X 50 X 1200		02
22	0503010026	3/8" NUT		12
23	0503010025	3/8" SPRING WASHER		12
24	0501011643	3/8 X 1" BOLT		12




Item	Code	Description	See page	QT
01	0521068087	FRAME RIGHT 6450		01
02	0521068085	RIGHT ARTICULATED AXLE		01
03	0521013199	LOWER BEARING SEMI		02
04	0503010899	5/8" X 2-1/4" BOLT		04
05	0501012140	FLAT WASHER		08
06	0531013922	0.6" X 0.8" X 1" SLEEVE		04
07	0503011445	SPRING WASHER		04
08	0503010013	5/8" NUT		04




Item	Code	Description	See page	QT
01	0521063886	RIGHT FRAME		01
02	0521063872	ARTICLES AXLE RIGHT ROLLED		01
03	0521013199	LOWER BEARING SEMI		02
04	0503010899	5/8" X 2-1/4" BOLT		04
05	0501012140	FLAT WASHER		08
06	0531013922	0.6" X 0.8" X 1" SLEEVE		04
07	0503011445	SPRING WASHER		04
08	0503010013	5/8" NUT		04




Item	Code	Description	See page	QT
01	0521064011	CENTRAL FRAME PST TRIO 15		01
02	0521064022	CENTRAL ARTICLES AXLE ROLLED		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0521066916	CENTRAL CHASSIS		01
02	0521013199	LOWER BEARING SEMI		04
03	0503010899	5/8" X 2-1/4" BOLT		08
04	0501012140	FLAT WASHER		16
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503010013	5/8" NUT		08
08	0521063878	ARTICLE AXLE ROLLED		01




Item	Code	Description	See page	QT
01	0521068088	FRAME LEFT 6450		01
02	0521068086	LEFT ARTICULATED AXLE		01
03	0521013199	LOWER BEARING SEMI		02
04	0503010899	5/8" X 2-1/4" BOLT		04
05	0501012140	FLAT WASHER		08
06	0531013922	0.6" X 0.8" X 1" SLEEVE		04
07	0503011445	SPRING WASHER		04
08	0503010013	5/8" NUT		04




Item	Code	Description	See page	QT
01	0521063885	LEFT FRAME		01
02	0521063873	ARTICLES AXLE LEFT ROLLED		01
03	0521013199	LOWER BEARING SEMI		02
04	0503010899	5/8" X 2-1/4" BOLT		04
05	0501012140	FLAT WASHER		08
06	0531013922	0.6" X 0.8" X 1" SLEEVE		04
07	0503011445	SPRING WASHER		04
08	0503010013	5/8" NUT		04




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		05
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		10
03	0501012140	FLAT WASHER		10




Item	Code	Description	See page	QT
01	0521055231	655 WHEELED SUPPORT WITH TRANSMISSION	13	01
02	0521055234	WHEELED FASTENER	21	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0521055243	655 WHEELED BRACKET WITHOUT TRANSMISSION	14	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0521061566	CARRYING WHEEL ARM TRACTION		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0501058241	TENSIONER CHAIN SUPPORT	15	01
07	0521055232	WHEEL WITH PNEU	16	01
08	0503018981	BOLT		02
09	0503010027	5/8" SPRING WASHER		04
10	0521012190	AXLE LOCK		01
11	0581011124	WHEELED COVER		01
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
13	0551017715	FLAT WASHER		02
14	0503013030	5/8" X 3.1/4" BOLT		01
15	0511050681	TRACTION SPRING		01
15A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
15B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0521061566	CARRYING WHEEL ARM TRACTION		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0503018981	BOLT		02
07	0503010027	5/8" SPRING WASHER		02
08	0521012190	AXLE LOCK		02
09	0521055239	WHEEL WITH PNEUME WHEELED BOX WITHOUT TRANSMISSION	17	01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL	18	01
02	0521055233	WHEELED TRANSMISSION WITHOUT TIRE	19	01




Item	Code	Description	See page	QT
01	0503062159	WHEEL	18	01
02	0521055244	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	20	01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503012114	7.00 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0521012185	TRANSM AXLE CARRYING-WHEEL	01	
02	0503010330	KM 9 LOCKNUT	01	
03	0503010329	LOCK WASHER	01	
04	0511015949	LOCK NUT	01	
05	0503010804	00547-B SEAL	02	
06	0503019364	BEARING 25590/25523	02	
07	0501110721	WHEEL HUB WITH SCREW / NUTS	01	
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION	01	
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR	06	
07C	0503016516	5/8 UNF CONIC NUT	06	
08	0502011339	15Z GEAR P 1.25"	01	
09	0503012550	5/16" X 3/4" BOLT	06	
10	0503010002	1800 GREASE FITTING	01	




Item	Code	Description	See page	QT
01	0521012185	TRANSM AXLE CARRYING-WHEEL		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0521055236	INTERMEDIARY CURRENT STRETCHER	22	01
07	0521055237	WHEEL FIXED CURRENT STRETCHER	23	01
08	0521055235	WHEEL MOBILE CURRENT STRETCHER	24	01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
01A	0503019355	BEARING 6202 2RS1		01
01B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
01C	0502012853	GEAR		01
02	0551018245	CHAIN TENSIONER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0551018239	SLEEVE 19 X 13,50 X 45		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
01A	0503019355	BEARING 6202 2RS1		01
01B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
01C	0502012853	GEAR		01
02	0551018252	CHAIN TIGHTENER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
01A	0503019355	BEARING 6202 2RS1		01
01B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
01C	0502012853	GEAR		01
02	0551018244	CHAIN UPPER AXLE		01
03	0551018240	SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	6450	6850
01	0521066289	FRONT HEADER 5750/6350/6850		001	001
02	0521067075	INTERMEDIATE HEAD 6450/7285/7350/7450/8460		001	000
02.	0521066290	INTERMEDIATE HEAD 5750/6850/7860/8160		000	001
03	0571019949	JUNCTION SHAFT		006	006
04	0503030119	LOCK PIN		010	010
05	0511055096	TRACTOR HITCH	26	001	001
06	0511053179	TRACTOR HITCH AXLE		001	001
06A	0521064036	TRACTOR HITCH AXLE		001	001
06B	0503030012	HAIR PIN		001	001
07	0503014120	CHAIN		001	001
08	0521051614	TURNBUCKLE SIDE UPPER	27	002	002
09	0521010571	COUPLING SHAFT		004	004
10	0503030085	LOCK PIN		006	006
11	0521051616	TURNBUCKLE SIDE 505/480	28	002	000
11.	0521050133	TURNBUCKLE SIDE 755/480	29	000	002
12	0571019951	JUNCTION SHAFT		003	003
13	0503010523	1/4" X 2" COTTERPIN		004	004
14	0503034772	BOX		001	001
15	0521068652	TOOLS BOX SUPPORT		001	001
16	0501011643	3/8 X 1" BOLT		004	004
17	0503010025	3/8" SPRING WASHER		004	004
18	0503010026	3/8" NUT		004	004
19	0581017000	PLATE INTERMEDIARY		002	002
20	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		004	004
21	0503010025	3/8" SPRING WASHER		004	004
22	0501010984	FLAT WASHER		004	004
23	0503014321	CABLE STEEL SHACKLE		002	002
24	0502010584	CARRYING-WHEELS SUPPORT FIXER		008	008
25	0503016485	BOLT 3/4		016	016
26	0501010322	FLAT WASHER		032	032
27	0503010152	3/4" SELF LOCKING NUT		016	016


Item	Code	Description	See page	6450	6850
28	0521067716	FIXER TUBE		004	004
29	0511059237	3 POINT TURNBUCKLE	30	001	001
30	0571019950	COUPLING SHAFT		001	001
31	0521045756	HYDRAULIC CYLINDER	31	001	001
32	0521010779	31.75 X 95 COUPLING SHAFT		001	001
33	0521010581	0.9" X 4.9" COUPLING SHAFT		001	001
34	0531016049	FLAT WASHER		002	002
35	0503014820	COROTE BLACK WATER		001	001
36	0521068651	SUPPORT BOX		001	001

TRACTOR HITCH


0511055096




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	COMPRESSION SPRING LEFT		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0502011195	ADJUSTMENT NUT BODY		01
02	0521068096	EXTENSOR R.1.1 / 2 UNC RIGHT		01
03	0521068095	EXTENSOR R.1.1/2 UNC LEFT		01
04	0541018672	COUNTERNUT		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521068097	505 SIDE EXTENSOR FIXED POINT		01
02	0521066338	EXTERNAL ROTATING BRIDGE		01
03	0561019879	LOCK ATTACHMENT BAR		01
04	0521067393	EXTERNAL SIDE EAR		01
05	0571019949	JUNCTION SHAFT		01
06	0503030119	LOCK PIN		01
07	0503010002	1800 GREASE FITTING		03
08	0521065193	TURNBUCKLE AXLE		01




Item	Code	Description	See page	QT
01	0521065193	TURNBUCKLE AXLE		01
02	0521067392	FIXED BRACKET		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0521067393	EXTERNAL SIDE EAR		01
06	0571019949	JUNCTION SHAFT		01
07	0503030119	LOCK PIN		01
08	0503010002	1800 GREASE FITTING		03



Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0511061880	SIDE RIGHT RATCHET		01
03	0511061881	RATCHET FOLLOWER		01
04	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
05	0503011179	3/8" X 2-1/4" BOLT		05
06	0503010025	3/8" SPRING WASHER		05
07	0503010026	3/8" NUT		05
08	0503010002	1800 GREASE FITTING		02
09	0531010264	SIDE RATCHET		01
10	0521066919	3-POINT EXTENSOR RIGHT FUSE		01
11	0521066337	LEFT EXTENSOR 3 SPIKE		01




Item	Code	Description	See page	QT
01	0511057653	HYDRAULIC CYLINDER		01
02	0501053835	FEMALE QUICK COUPLER	35	02



Item	Code	Description	See page	QT
01	0571013472	FIXER BODY VALVE		01
02	0511059290	VALVE ASSEMBLY	34	01
03	0501053835	FEMALE QUICK COUPLER	35	02
04	0501010984	FLAT WASHER		04
05	0531011180	UPPER BODY CLIP		04
06	0521066564	DUCT SEAL OIL		01
07	0531013922	0.6" X 0.8" X 1" SLEEVE		02
08	0503011179	3/8" X 2-1/4" BOLT		02
09	0503010025	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	36	04
12	0503010920	1/2" X 1.1/2" BOLT		02
13	0511017302	FLAT WASHER		02
14	0503010019	1/2" SPRING WASHER		02
15	0503010060	1/2" NUT		02
16	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
17	0571017774	SPRING PROTECTION QUICK HOSE		01
18	0521051626	HYDRAULIC SYSTEM HOSE SET		01
18A	0501080406	3/8" X 23" TR-TC HOSE		01
18B	0501080150	HOSE ASSY		01
18C	0501080382	3/8" X 102" TR-TC HOSE ASSY		01
18D	0501080432	3/8" X 2600 TC-TC HOSE ASSY		03
19	0521052484	HOSE 1/2 X 4122 TM-TM BLACK / RED		01
19A	0501080881	HOSE		01
19B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
19C	0503034495	HYDRAULIC HOSE GRIP (RED)		02
19D	0503018952	PLASTIC BOLT		12
20	0521052485	HOSE 1/2 X 4122 TM-TM BLACK / BLUE		01
20A	0501080881	HOSE		01
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
20C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		02




Item	Code	Description	See page	QT
20D	0503018952	PLASTIC BOLT		12




Item	Code	Description	See page	QT
01	0571013472	FIXER BODY VALVE		01
02	0511059290	VALVE ASSEMBLY	34	01
03	0501053835	FEMALE QUICK COUPLER	35	02
04	0501010984	FLAT WASHER		04
05	0531011180	UPPER BODY CLIP		04
06	0521066564	DUCT SEAL OIL		01
07	0531013922	0.6" X 0.8" X 1" SLEEVE		02
08	0503011179	3/8" X 2-1/4" BOLT		02
09	0503010025	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0502012702	BODY SUPPORT CLAMP		12
12	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
13	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	36	04
14	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		04
15	0503010244	7/16" NUT		04
16	0503010180	7/16" SPRING WASHER		08
17	0503010920	1/2" X 1.1/2" BOLT		02
18	0511017302	FLAT WASHER		02
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2" NUT		02
21	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
22	0571017774	SPRING PROTECTION QUICK HOSE		01
23	0511059418	HYDRAULIC SYSTEM HOSE ASSEMBLY		01
23A	0501080406	3/8" X 23" TR-TC HOSE		01
23B	0501080150	HOSE ASSY		01
23C	0501081930	HOSE		01
23D	0501081646	TC-TC HOSE ASSY		03
24	0521052484	HOSE 1/2 X 4122 TM-TM BLACK / RED		01
24A	0501080881	HOSE		01
24B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
24C	0503034495	HYDRAULIC HOSE GRIP (RED)		02


Item	Code	Description	See page	QT
24D	0503018952	PLASTIC BOLT		12
25	0521052485	HOSE 1/2 X 4122 TM-TM BLACK / BLUE		01
25A	0501080881	HOSE		01
25B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
25C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		02
25D	0503018952	PLASTIC BOLT		12




Item	Code	Description	See page	QT
01	0503016524	DIVIDER VALVE		01
02	0581011593	NIPPLE R.1.1/16 UN		01
03	0511010111	7/8" NIPPLE		03
04	0503011109	2-119 N 3006-9B O'RING		01
05	0503010045	O'RING		03



Item	Code	Description	See page	QT
01	0503011883	QUICK CONNECTION COVER		01
02	0503011628	FEMALE QUICK COUPLER		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521051606	SILO FERTILIZER RIGHT SUPPORT 6450	40	01
02	0521051607	SUPPORT SILO CENTRAL FERTILIZER 6450/7285/7450/8460	46	01
03	0521051605	SILO FERTILIZER LEFT SUPPORT 6450	43	01
04	0501010984	FLAT WASHER		32
05	0503010025	3/8" SPRING WASHER		16
06	0503010026	3/8" NUT		16
07	0503010849	3/8" X 1-1/2" BOLT		16
08	0571019051	FIXER BOX WASHER		22
09	0503013751	3/8 UNC X 1.1/4 BOLT		22
10	0503012535	3/8" SPRING WASHER		22
11	0503012531	3/8" INOX NUT		22
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	5/16" ZN SPRING WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0551019168	SLEEVE		02
19	0551019160	LEVER		02
20	0551019167	SLEEVE UNION		02
21	0511017302	FLAT WASHER		06
22	0503010479	BOLT		02
23	0503011336	1/2" HEX SELF ADJUSTING NUT		06
24	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
25	0503010019	1/2" SPRING WASHER		02
26	0503010060	1/2" NUT		02
27	0501013518	FLAT WASHER		06
28	0503010140	1/8" X 3/4" COTTERPIN		06
29	0511069678	LH LOWER LEVER		02
30	0561016468	FASTENER		02
31	0581012605	GEAR BOX LEVER LOCK		02

Item	Code	Description	See page	QT
32	0521061741	INNER LEVER		02
33	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER		01
34	0551019159	LEVER FIXER BODY		02
35	0503034396	FERTILIZER SIDE COVER		13
36	0503010362	1/8" X 1.1/4" COTTERPIN		13
37	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		01
38	0503062362	SILO FERTILIZER 04 MOUTH		02
39	0521050195	SILO FERTILIZER LEFT SQUARE AXLE		01
40	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	54	02




Item	Code	Description	See page	QT
01	0521052712	SILO FERTILIZER RIGHT SUPPORT 6850	41	01
02	0521052721	SILO FERTILIZER LEFT SUPPORT 6850	44	01
03	0521052734	SUPPORT SILO CENTRAL FERTILIZER 6850/7860	47	01
04	0501010984	FLAT WASHER		40
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0503062391	SILO FERTILIZER 05 MOUTHS		03
09	0571019051	FIXER BOX WASHER		24
10	0503013751	3/8 UNC X 1.1/4 BOLT		24
11	0503012535	3/8" SPRING WASHER		24
12	0503012531	3/8" INOX NUT		24
13	0503011957	NYLON LUG		02
14	0503010371	5/16" X 1" BOLT		04
15	0503010179	5/16" ZN SPRING WASHER		08
16	0503010337	5/16" NUT		08
17	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
18	0503011953	5/16" X 1" BOLT		04
19	0551019168	SLEEVE		02
20	0551019160	LEVER		02
21	0551019167	SLEEVE UNION		02
22	0511017302	FLAT WASHER		06
23	0503010479	BOLT		02
24	0503011336	1/2" HEX SELF ADJUSTING NUT		06
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
26	0503010019	1/2" SPRING WASHER		02
27	0503010060	1/2" NUT		02
28	0501013518	FLAT WASHER		06
29	0503010140	1/8" X 3/4" COTTERPIN		06
30	0511069678	LH LOWER LEVER		02
31	0561016468	FASTENER		02

Item	Code	Description	See page	QT
32	0581012605	GEAR BOX LEVER LOCK		02
33	0521061741	INNTER LEVER		02
34	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER		01
35	0551019159	LEVER FIXER BODY		02
36	0503034396	FERTILIZER SIDE COVER		15
37	0503010362	1/8" X 1.1/4" COTTERPIN		15
38	0521050195	SILO FERTILIZER LEFT SQUARE AXLE		01
39	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	54	02




Item	Code	Description	See page	QT
01	0521053357	SUPPORT SILO FERTILIZER RIGHT DISTRIBUTOR STEP 1 6850	42	01
02	0521053358	SUPPORT SILO FERTILIZER LEFT DISTRIBUTOR STEP 1 6850	45	01
03	0521053359	SUPPORT SILO CENTRAL FERTILIZER WITH DISTRIBUTOR STEP 1 6850	48	01
04	0501010984	FLAT WASHER		40
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0503062391	SILO FERTILIZER 05 MOUTHS		03
09	0571019051	FIXER BOX WASHER		24
10	0503013751	3/8 UNC X 1.1/4 BOLT		24
11	0503012535	3/8" SPRING WASHER		24
12	0503012531	3/8" INOX NUT		24
13	0503011957	NYLON LUG		02
14	0503010371	5/16" X 1" BOLT		04
15	0503010179	5/16" ZN SPRING WASHER		08
16	0503010337	5/16" NUT		08
17	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
18	0503011953	5/16" X 1" BOLT		04
19	0551019168	SLEEVE		02
20	0551019160	LEVER		02
21	0551019167	SLEEVE UNION		02
22	0511017302	FLAT WASHER		06
23	0503010479	BOLT		02
24	0503011336	1/2" HEX SELF ADJUSTING NUT		06
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
26	0503010019	1/2" SPRING WASHER		02
27	0503010060	1/2" NUT		02
28	0501013518	FLAT WASHER		06
29	0503010140	1/8" X 3/4" COTTERPIN		06


Item	Code	Description	See page	QT
30	0511069678	LH LOWER LEVER		02
31	0561016468	FASTENER		02
32	0581012605	GEAR BOX LEVER LOCK		02
33	0521061741	INNTER LEVER		02
34	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER		01
35	0551019159	LEVER FIXER BODY		02
36	0503034396	FERTILIZER SIDE COVER		15
37	0503010362	1/8" X 1.1/4" COTTERPIN		15
38	0521050195	SILO FERTILIZER LEFT SQUARE AXLE		01
39	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	54	02




Item	Code	Description	See page	QT
01	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	49	02
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	51	02
03	0501010942	3/8" X 1-1/4" BOLT		16
04	0503011443	3/8" SPRING WASHER		16
05	0503010026	3/8" NUT		16
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0501053788	Q3/4" FASTENER AXLE ASSY	53	01
11	0501110392	SILO SUPPORT BEARING		01
12	0503030275	AGRICULTURAL BEARING		04
13	0503011953	5/16" X 1" BOLT		02
14	0521011039	FLAT WASHER		02
15	0503011444	SPRING WASHER		02
16	0503010337	5/16" NUT		02
17	0503010003	1845 GREASE FITTING		01
18	1902010685	18Z CONICAL GEAR		04
19	0521012485	GEAR BOX BEARING AGRICUTURAL		01
20	0581012758	SQUARE AXLE 3/4 X 1525		01
21	0521068090	SUPPORT RIGHT SILO FERTILIZER		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	49	02
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	51	03
03	0501010942	3/8" X 1-1/4" BOLT		20
04	0503011443	3/8" SPRING WASHER		20
05	0503010026	3/8" NUT		20
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0501053788	Q3/4" FASTENER AXLE ASSY	53	01
11	0501110392	SILO SUPPORT BEARING		01
12	0521012485	GEAR BOX BEARING AGRICUTURAL		01
13	0503011953	5/16" X 1" BOLT		02
14	0521011039	FLAT WASHER		02
15	0503011444	SPRING WASHER		02
16	0503010337	5/16" NUT		02
17	0503010003	1845 GREASE FITTING		01
18	1902010685	18Z CONICAL GEAR		05
19	0503030275	AGRICULTURAL BEARING		05
20	0581016972	AXIS Q 3/4 X 1953		01
21	0521068605	SUPPORT RIGHT SILO FERTILIZER		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0511056339	DISTRIBUTOR FERTILIZER SIDE RIGHT STEP 1"	50	02
02	0511056338	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 1"	52	03
03	0501010942	3/8" X 1-1/4" BOLT		20
04	0503011443	3/8" SPRING WASHER		20
05	0503010026	3/8" NUT		20
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0501053788	Q3/4" FASTENER AXLE ASSY	53	01
11	0501110392	SILO SUPPORT BEARING		01
12	0521012485	GEAR BOX BEARING AGRICUTURAL		01
13	0503011953	5/16" X 1" BOLT		02
14	0521011039	FLAT WASHER		02
15	0503011444	SPRING WASHER		02
16	0503010337	5/16" NUT		02
17	0503010003	1845 GREASE FITTING		01
18	1902010685	18Z CONICAL GEAR		05
19	0503030275	AGRICULTURAL BEARING		05
20	0581016972	AXIS Q 3/4 X 1953		01
21	0521068605	SUPPORT RIGHT SILO FERTILIZER		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521068091	LEFT SILO FERTILIZER SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	49	02
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	51	02
04	0501010942	3/8" X 1-1/4" BOLT		16
05	0503011443	3/8" SPRING WASHER		16
06	0503010026	3/8" NUT		16
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0501053788	Q3/4" FASTENER AXLE ASSY	53	01
12	0501110392	SILO SUPPORT BEARING		01
13	0521012485	GEAR BOX BEARING AGRICUTURAL		01
14	0503011953	5/16" X 1" BOLT		02
15	0521011039	FLAT WASHER		02
16	0503011444	SPRING WASHER		02
17	0503010337	5/16" NUT		02
18	0503010003	1845 GREASE FITTING		01
19	1902010685	18Z CONICAL GEAR		04
20	0503030275	AGRICULTURAL BEARING		04
21	0581012758	SQUARE AXLE 3/4 X 1525		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521068615	LEFT SILO FERTILIZER SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	49	03
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	51	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0501053788	Q3/4" FASTENER AXLE ASSY	53	01
12	0501110392	SILO SUPPORT BEARING		01
13	0521012485	GEAR BOX BEARING AGRICUTURAL		01
14	0503011953	5/16" X 1" BOLT		02
15	0521011039	FLAT WASHER		02
16	0503011444	SPRING WASHER		02
17	0503010337	5/16" NUT		02
18	0503010003	1845 GREASE FITTING		01
19	1902010685	18Z CONICAL GEAR		05
20	0503030275	AGRICULTURAL BEARING		05
21	0581016972	AXIS Q 3/4 X 1953		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521068615	LEFT SILO FERTILIZER SUPPORT		01
02	0511056339	DISTRIBUTOR FERTILIZER SIDE RIGHT STEP 1"	50	03
03	0511056338	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 1"	52	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0501053788	Q3/4" FASTENER AXLE ASSY	53	01
12	0501110392	SILO SUPPORT BEARING		01
13	0521012485	GEAR BOX BEARING AGRICUTURAL		01
14	0503011953	5/16" X 1" BOLT		02
15	0521011039	FLAT WASHER		02
16	0503011444	SPRING WASHER		02
17	0503010337	5/16" NUT		02
18	0503010003	1845 GREASE FITTING		01
19	1902010685	18Z CONICAL GEAR		05
20	0503030275	AGRICULTURAL BEARING		05
21	0581016972	AXIS Q 3/4 X 1953		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521068089	SUPPORT CENTRAL SILO FERTILIZER		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	49	03
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	51	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0581016973	SQUARE AXLE 3/4 X 790		01
08	0571019828	LOCK AXLE		02
09	0503010365	NUT		04
10	1902010685	18Z CONICAL GEAR		05
11	0503030275	AGRICULTURAL BEARING		05
12	0503013816	5/16" LOCKNUT		04
13	0511062163	FERTILIZER BEAM LOWER COVER		01
14	0501010984	FLAT WASHER		04
15	0501011643	3/8 X 1" BOLT		04
16	0581016950	SQUARE AXLE 3/4 X 1115		01




Item	Code	Description	See page	QT
01	0521066913	CENTER FERTILIZER SILO SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	49	02
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	51	03
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0581016971	AXIS Q 3/4 X 1063		01
08	0571019828	LOCK AXLE		02
09	0503010365	NUT		04
10	1902010685	18Z CONICAL GEAR		05
11	0503030275	AGRICULTURAL BEARING		05
12	0503013816	5/16" LOCKNUT		04
13	0581016970	AXIS Q 3/4 X 763		01




Item	Code	Description	See page	QT
01	0521066913	CENTER FERTILIZER SILO SUPPORT		01
02	0511056339	DISTRIBUTOR FERTILIZER SIDE RIGHT STEP 1"	50	02
03	0511056338	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 1"	52	03
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0581016971	AXIS Q 3/4 X 1063		01
08	0571019828	LOCK AXLE		02
09	0503010365	NUT		04
10	1902010685	18Z CONICAL GEAR		05
11	0503030275	AGRICULTURAL BEARING		05
12	0503013816	5/16" LOCKNUT		04
13	0581016970	AXIS Q 3/4 X 763		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031166	LEFT CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031159	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01



Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511817303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0503030331	1.2" X 1.2" X 12.2" HOSE		01
02	0503010243	CLAMP		02
03	0503062755	TRANSMISSION AXLE		01
04	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
05	0503012880	1/4" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0581015103	MOTOR AXLE 1.3 / 8 X 1620		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	57	02
15	0511051434	TRANSMISSION DRIVING ASSY	58	04
16	0511047069	SIDE TRANSMISSION DRIVING	59	01
17	0511047070	LH SIDE TRANSMISSION DRIVING	60	01
18	0521043316	RIGHT GEAR BOX ASSY	61	01
19	0521043317	LEFT GEAR BOX ASSY	62	01
20	0503014734	BOLT		06
21	0503010920	1/2" X 1.1/2" BOLT		04
22	0511017302	FLAT WASHER		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2" NUT		10
25	0521064448	GEAR		02
26	0511059261	CHAIN TENSIONER	72	04
27	0521055217	LOWER CURRENT STRETCH	73	02
28	0501058254	UPPER SEED CHAIN TENSIONER	74	02
29	0521055216	BEARING WITH GEAR	75	02
30	0521055218	BEARING GEAR WITH DOUBLE	76	02
31	0521055214	BEARING GEAR WITH	77	02

Item	Code	Description	See page	QT
32	0503012204	40-1 CHAIN X 82 LINK + RED		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0571014441	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	57	02
15	0511051434	TRANSMISSION DRIVING ASSY	58	04
16	0511047069	SIDE TRANSMISSION DRIVING	59	01
17	0511047070	LH SIDE TRANSMISSION DRIVING	60	01
18	0521043316	RIGHT GEAR BOX ASSY	61	01
19	0521043317	LEFT GEAR BOX ASSY	62	01
20	0501011600	1/2" X 1-1/4" BOLT		06
21	0503010920	1/2" X 1.1/2" BOLT		04
22	0511017302	FLAT WASHER		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2" NUT		10
25	0521064448	GEAR		02
26	0511059261	CHAIN TENSIONER	72	04
27	0521055217	LOWER CURRENT STRETCH	73	02
28	0501058254	UPPER SEED CHAIN TENSIONER	74	02
29	0521055216	BEARING WITH GEAR	75	02
30	0521055218	BEARING GEAR WITH DOUBLE	76	02
31	0521055214	BEARING GEAR WITH	77	02


Item	Code	Description	See page	QT
32	0503012204	40-1 CHAIN X 82 LINK + RED		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	5/16" X 3/4" BOLT		02
03	0503010179	5/16" ZN SPRING WASHER		02
04	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 C5PC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY


0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	63	01
02	0511059266	CLOSED BEARING	65	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	BEARING ASSY GEAR BOX	67	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH LINK ASSY	69	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	70	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	71	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	64	01
02	0511059266	CLOSED BEARING	65	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	BEARING ASSY GEAR BOX	67	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH LINK ASSY	69	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	70	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	71	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0501056271	BEARING CLOSED	66	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	68	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	1 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
05	0503010179	5/16" ZN SPRING WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0503031805	1 1/2" GEAR		01
02	0511017302	FLAT WASHER		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER		01
03	0511062169	21Z P 1/2" GEAR		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0521018933	FERT CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501011234	5/8" X 3" BOLT		01
02	0531017086	50 AXLETIGHTENER		01
03	0511062169	21Z P 1/2" GEAR		01
04	0503019356	BEARING 6005 2RS1		01
05	0503011105	SEAL RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0503016460	5/8" X 4.1/2" BOLT		01
02	0551019175	DOUBLE GEAR AXLE		01
03	0503019356	BEARING 6005 2RS1		02
04	0511069680	20Z X 28Z DOBLE GEAR		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511063106	20Z AXLE BEARING DOBLE		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0521055215	DOUBLE TRANSMISSION BEARING	78	01
04	0503010365	NUT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503019356	BEARING 6005 2RS1		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521068584	RIGHT PLATFORM		01
02	0521068596	CENTRAL PLATFORM		01
03	0521068592	LEFT PLATFORM		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		28
07	0503010025	3/8" SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	HAIR PIN		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32"X 2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0521068581	RIGHT PLATFORM		01
02	0521068597	CENTRAL PLATFORM		01
03	0521068589	LEFT PLATFORM		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		28
07	0503010025	3/8" SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	HAIR PIN		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32"X 2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0521068092	SIDE HANDRAIL		02
02	0521064018	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2" NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8" SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
01	0521063871	SIDE HANDRAIL		02
02	0521063875	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2" NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8" SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04



Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		02
02	0503010237	3/8" X 1" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511069636	LADDER		01
06	0503011179	3/8" X 2-1/4" BOLT		02
07	0501010984	FLAT WASHER		02
08	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0501012140	FLAT WASHER		12
04	0503012412	5/8 UNC SELF LOCKING NUT		10
05	0503011070	BEATER		02
06	0503010920	1/2" X 1.1/2" BOLT		02
07	0503010019	1/2" SPRING WASHER		02
08	0511061811	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0511058449	HYDRAULIC CYLINDER	89	02
12	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
13	0503010523	1/4" X 2" COTTERPIN		04
14	0511015779	1" X 4.2" AXLE		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	HAIR PIN		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	SEQUENTIAL VALVE ASSY	88	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	36	02
25	0531011180	UPPER BODY CLIP		10
26	0503011102	BOLT 7/16 UNC X 1.1/4 C S G.5 ZN		04
27	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		02
28	0503010180	7/16" SPRING WASHER		10
29	0502012702	BODY SUPPORT CLAMP		10
30	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		04
31	0503010244	7/16" NUT		04

Item	Code	Description	See page	QT
32	0521051624	HYDRAULIC MARKER HANDLE SET		01
32A	0501080612	HOSE 3/8 X 4450 TR-TC		02
32B	0501080418	3/8" X 165" TR-TC HOSE ASSY		02
33	0521052277	HOSE 3/8 X 4212 TC-TM PURPLE / RED		01
33A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
33B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
33C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
33D	0503018952	PLASTIC BOLT		06
34	0521052278	HOSE 3/8 X 4212 TC-TM PURPLE / BLUE		01
34A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
34B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
34C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
34D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0521055204	LIGNE DE DISQUE MARKER	87	02
02	0521061790	1750 TURNBUCKLE		02
03	0511060014	ROW MARKER ARM		02
04	0521012324	1/2" X 3.2"X 2.54" FASTENER		04
05	0511017302	FLAT WASHER		08
06	0503010019	1/2" SPRING WASHER		08
07	0503010060	1/2" NUT		08
08	0503010003	1845 GREASE FITTING		02
09	0511060013	ROW MARKER ARM		02
10	0503010004	1890 GREASE FITTING		02
11	0521011142	1.1/4" X 7.5" AXLE		04
12	0501019435	32 X 50 X 1.5 FLAT WASHER		16
13	0511061022	ROW MARKER SUPPORT		02
14	0511066119	MARKER SUPP FIXER FASTENER		04
15	0502010175	HITCH CLAMP		08
16	0501010216	3/4" X 4-1/2" BOLT		16
17	0503010023	3/4" SPRING WASHER		16
18	0503010014	3/4" NUT		16
19	0503010523	1/4" X 2" COTTERPIN		16
20	0521013347	1.1/4" X 8.4" AXLE		02
21	0521011141	1.1/4" X 6.5" AXLE		02
22	0501054649	SEQUENTIAL VALVE ASSY	88	01
23	0511058431	HYDRAULIC CYLINDER	90	02
24	0511015573	2.07" X 1.6" TRANSPORT LOCK		02
25	0501068994	0.3" X 3.1" LOCK PIN		02
26	0503030168	HAIR PIN		02
27	0511018012	HIDRAULIC ADAPTER		04
28	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	36	02
29	0511057093	HYDRAULIC MARKER HYGIENE SET		01
29A	0501081791	HOSE ASSY		02
29B	0501080388	3/8 X 4300 TR-TC HOSE ASSY		02


Item	Code	Description	See page	QT
30	0521052278	HOSE 3/8 X 4212 TC-TM PURPLE / BLUE		01
30A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
30B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
30C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
30D	0503018952	PLASTIC BOLT		06
31	0521052277	HOSE 3/8 X 4212 TC-TM PURPLE / RED		01
31A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
31B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
31C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
31D	0503018952	PLASTIC BOLT		06
32	0501010617	3/4" NIPPLE		04




Item	Code	Description	See page	QT
01	0521069643	DISC AXLE MARKER LINE		01
02	0602023094	DR16X3 C36AFPAFR73+4FR+4FR D474 10R		01
03	0581019513	DEPTH WHEEL BOX		01
04	0503019342	ROLLER BEARING		01
05	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503013758	1/4" X 1-1/2" BOLT		03
11	0503010143	1/4" SPRING WASHER		03
12	0503010358	5/16" X 5/8" BOLT		04
13	0503010179	5/16" ZN SPRING WASHER		04
14	0503010337	5/16" NUT		04
15	0503034055	CLAMPING RING		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENTIAL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02




Item	Code	Description	See page	QT
01	0501067700	2.5" X 25" CYLINDER CASE		01
02	0521066632	EXTENDER		01
03	0503030384	CON PLUG N-001		02
04	0502012837	PISTON		01
05	0503018005	RING		01
06	0503011109	2-119 N 3006-9B O'RING		01
07	0503010163	D-1500 SCRAPER RING		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503018004	RING		01
11	0503018003	GASKET		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0571013470	5/8 X 1100 HEX AXLE		01
02	0581012154	HEX 5/8 X AXIS 755		01
03	0581015104	HEX 5/8 X AXIS 1750		02
04	0511059233	INTERMEDIATE TRANSMISSION	93	02
05	0561014215	BEARING COVER LOWER ROW FRAME		02
06	0502040534	SPRING GUIDE BUSHING LOCK		08
07	0501018535	1/2 X 1 BOLT		08




Item	Code	Description	See page	QT
01	0561014215	BEARING COVER LOWER ROW FRAME		02
02	0502040534	SPRING GUIDE BUSHING LOCK		08
03	0501018535	1/2 X 1 BOLT		08
04	0581013561	5/8" X 95.8" HEX AXLE		01
05	0511057287	TRANSMISSION	94	02
06	0571013469	5/8 X 700 HEX AXLE		01
07	0571013468	5/8 X 2040 HEX AXLE		02




Item	Code	Description	See page	QT
01	0503062206	CARDAN TERMINAL	95	01
02	0503030331	1.2" X 1.2" X 12.2" HOSE		01
03	0503010243	CLAMP		02
04	0503011855	0.2" X 1.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503062392	DRIVE SHAFT	96	01
02	0503030331	1.2" X 1.2" X 12.2" HOSE		01
03	0503010243	CLAMP		02
04	0503011855	0.2" X 1.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503062206	CARDAN TERMINAL	95	01




Item	Code	Description	See page	QT
01	0503062392	DRIVE SHAFT	96	01




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		16
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		03
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	98	03
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		15




Item	Code	Description	See page	QT
01	0503018738	LIGHTHOUSE		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	5/16" ZN SPRING WASHER		04
08	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0521050210	ASSEMBLY CSU 6450	101	01
02	0501010942	3/8" X 1-1/4" BOLT		12
03	0501010984	FLAT WASHER		12
04	0503010025	3/8" SPRING WASHER		12
05	0503010026	3/8" NUT		12
06	0521051927	TOWER SUPPORT HOPPER	104	06




Item	Code	Description	See page	QT
01	0511057755	ASSEMBLY CSU 6850	102	01
02	0521051927	TOWER SUPPORT HOPPER	104	06
03	0501010942	3/8" X 1-1/4" BOLT		12
04	0501010984	FLAT WASHER		12
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		06
02	0501010984	FLAT WASHER		06
03	0503010025	3/8" SPRING WASHER		74
04	0503010026	3/8" NUT		74
05	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	103	13
06	0501010942	3/8" X 1-1/4" BOLT		52
07	0571015773	SUPPORT SEED CSU		04
08	0501011643	3/8 X 1"BOLT		16
09	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		01
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		01
11	0521064748	05 MOUTHS CSU SUPPORT		02
12	0503061987	SILLO FERTILIZER 05 MOUTHS FRONT MOUNTED		02




Item	Code	Description	See page	QT
01	0503061899	REAR BEAN FERTILIZER ASSY		03
02	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS		03
03	0521063401	SEED BOX ONLY FIXING LOCK		06
04	0501010984	FLAT WASHER		06
05	0503010025	3/8" SPRING WASHER		78
06	0503010026	3/8" NUT		78
07	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	103	15
08	0501010942	3/8" X 1-1/4" BOLT		60
09	0501011643	3/8 X 1" BOLT		12
10	0571015773	SUPPORT SEED CSU		03




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
09	0503010179	5/16" ZN SPRING WASHER		02
10	0503010337	5/16" NUT		02
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT		01



Item	Code	Description	See page	QT
01	0521066208	SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
05	0503010179	5/16" ZN SPRING WASHER		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0521053227	LEFT SHORT SEED ROW FRONT	108	01
02	0521053230	SHORT SEED ROW FRONT	109	01
03	0521053228	LEFT SHORT SEED ROW FRONT	110	01
04	0521053229	SHORT SEED ROW FRONT	111	01
05	0521054737	FRONT SEMI MOUNTED LINE LONG LEFT SEED WITHOUT LUBRICATION	112	01
06	0521054736	FRONT SEMI MOUNTED ROW LONG RIGHT SEED LINE WITHOUT LUBRICATION	113	01
07	0511059333	SEMI-ASSEMBLED MECHANICAL FRAME	123	01
08	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		01
09	0503010019	1/2" SPRING WASHER		01
10	0503010060	1/2" NUT		01
11	0521054771	LEFT REAR SEAL LINE WITHOUT LUBRICATION	126	01
12	0521054770	REAR RIGHT SEED LINE WITHOUT LUBRICATION	127	01
13	0521054984	DEPTH SYSTEM / COMPACTOR WITHOUT LUBRICATION	135	01
14	0521054811	FERTILIZER SHORT LINE	148	01
15	0521054812	LONG FERTILIZER LINE	149	01
16	0521054769	LEFT FERTILIZER WITH SUPPORT	155	01
17	0521054768	DDD RIGHT FERTILIZER WITH SUPPORT	156	01
18	0511056608	TITANIUM SEED SYSTEM	159	01
19	0511052024	FAST CLOSING SET	163	01
20	0521053947	HDA	164	01
21	0503030391	RIGHT FERTILIZER NOZZLE		01
22	0503030392	LEFT FERTILIZER NOZZLE		01
23	0503031050	CURVED CONDUCTOR		01
24	0503010246	CLAMP		01
25	0503031076	2" HOSE CLAMP		01
26	0503031145	2" X 2" X 20" HOSE		01
27	0521054758	CONTROL DEPTH WITH REGULATOR	168	01
28	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
29	0531013600	PRESS ADJUSTMENT LEVER		01

Item	Code	Description	See page	QT
30	0521053946	SCARING ROD	167	01
31	0511017969	0.1" SPACING PLATE		01
32	0521069127	BOTTOM NOZZLE FERTILIZER		01
33	0503030483	FERTILIZER SOCKET		01
34	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
35	0501010984	FLAT WASHER		04
36	0503010025	3/8" SPRING WASHER		02
37	0503010026	3/8" NUT		02
38	0503062066	DISC SET WITH CORN RING		01
39	0503062067	DISC SET / RING SOY 90F TITANIUM		01
40	0503033672	NOZZLE WITHOUT TITANIUM		01
41	0521018501	TURNBUCKLE LEVER		01
42	0521068982	KEY CASH DISC CUTTING		01
43	0503010905	1/2" X 2-1/4" BOLT		02
44	0503010019	1/2" SPRING WASHER		04
45	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521053227	LEFT SHORT SEED ROW FRONT	108	01
02	0521053230	SHORT SEED ROW FRONT	109	01
03	0521053228	LEFT SHORT SEED ROW FRONT	110	01
04	0521053229	SHORT SEED ROW FRONT	111	01
05	0521054737	FRONT SEMI MOUNTED LINE LONG LEFT SEED WITHOUT LUBRICATION	112	01
06	0521054736	FRONT SEMI MOUNTED ROW LONG RIGHT SEED LINE WITHOUT LUBRICATION	113	01
07	0511059333	SEMI-ASSEMBLED MECHANICAL FRAME	123	01
08	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		01
09	0503010019	1/2" SPRING WASHER		01
10	0503010060	1/2" NUT		01
11	0521054771	LEFT REAR SEAL LINE WITHOUT LUBRICATION	126	01
12	0521054770	REAR RIGHT SEED LINE WITHOUT LUBRICATION	127	01
13	0521054984	DEPTH SYSTEM / COMPACTOR WITHOUT LUBRICATION	135	01
14	0521054811	FERTILIZER SHORT LINE	148	01
15	0521054812	LONG FERTILIZER LINE	149	01
16	0521054769	LEFT FERTILIZER WITH SUPPORT	155	01
17	0521054768	DDD RIGHT FERTILIZER WITH SUPPORT	156	01
18	0521050096	SEED DEPOSIT SYSTEM (CSU)	160	01
18.	0511057777	SYSTEM SEED POPCORN MAKER TVS ASSY	161	01
19	0511052024	FAST CLOSING SET	163	01
20	0521053947	HDA	164	01
21	0503030391	RIGHT FERTILIZER NOZZLE		01
22	0503030392	LEFT FERTILIZER NOZZLE		01
23	0503031050	CURVED CONDUCTOR		01
24	0503010246	CLAMP		01
25	0503031076	2" HOSE CLAMP		01
26	0503031145	2" X 2" X 20" HOSE		01
27	0571011730	SEED CONDUCTOR 3X1500		01
28	0521050525	FIXER FERTILIZER CONDUCTOR	166	01

Item	Code	Description	See page	QT
29	0531013600	PRESS ADJUSTMENT LEVER		01
30	0521053946	SCARING ROD	167	01
31	0511017969	0.1" SPACING PLATE		01
32	0521069127	BOTTOM NOZZLE FERTILIZER		01
33	0503030483	FERTILIZER SOCKET		01
34	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
35	0501010984	FLAT WASHER		04
36	0503010025	3/8" SPRING WASHER		02
37	0503010026	3/8" NUT		02
38	0503062066	DISC SET WITH CORN RING		01
39	0503062067	DISC SET / RING SOY 90F TITANIUM		01
40	0503033672	NOZZLE WITHOUT TITANIUM		01
41	0521018501	TURNBUCKLE LEVER		01
42	0521068982	KEY CASH DISC CUTTING		01
43	0503010905	1/2" X 2-1/4" BOLT		02
44	0503010019	1/2" SPRING WASHER		04
45	0503010060	1/2" NUT		04
46	0521054758	CONTROL DEPTH WITH REGULATOR	168	01
46.	0521055053	DEEP WHEEL / COMPACTOR SYSTEM	169	01
47	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
48	0511018662	SPACING PLATE		01
49	0503030520	SEED SOCKET		01
50	0503017945	CENTRAL VISUM 1040002		01



Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	114	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	115	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	116	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	117	01
20	0521064651	LEFT SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	121	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01
31	0581017624	SPACING SLEEVE		06


Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08



Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0521061426	LH SEED ROW SUPPORT FRONT		01
03	0521055213	LINE BEARING SEED	114	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	115	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	116	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	117	01
20	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	121	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01
31	0581017624	SPACING SLEEVE		06




Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08



Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	114	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	115	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	116	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	117	01
20	0521064650	LEFT SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	121	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01
31	0581017624	SPACING SLEEVE		06


Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08



Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	114	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	115	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	116	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	117	01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	121	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01
31	0581017624	SPACING SLEEVE		06



Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0503010045	O'RING		08
03	0521055213	LINE BEARING SEED	114	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	115	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	116	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
20	0521064650	LEFT SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	121	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01



PST TRIO FLEX TITANIUM - FRAME 6450/6850
FRONT SEMI MOUNTED LINE LONG LEFT SEED WITHOUT

Page 112
0521054737

Item	Code	Description	See page	QT
31	0581017624	SPACING SLEEVE		06
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01




Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0503010045	O'RING		08
03	0521055213	LINE BEARING SEED	114	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	115	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	116	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	121	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01




PST TRIO FLEX TITANIUM - FRAME 6450/6850
FRONT SEMI MOUNTED ROW LONG RIGHT SEED LINE

Page 113
0521054736


Item	Code	Description	See page	QT
31	0581017624	SPACING SLEEVE		06
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01




Item	Code	Description	See page	QT
01	0502012718	BEARIN BODY		01
02	0503019355	BEARING 6202 2RS1		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	BOX TRANSMISSION COVER		01
03	0503019361	BEARING 6006 RS1		02
04	0503019363	BEARING 6005		01
05	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503019362	BEARING 6005 RS1		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501059326	UNIVERSAL JOINT AXLE	118	01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0521055227	BEARING SHAFT HEX	119	01




Item	Code	Description	See page	QT
01	0561016322	5/8" HEX AXLE		01
02	0501056296	UNIVERSAL JOINT		01
03	0503011855	0.2" X 1.8" SPRING PIN		02
04	0561014794	350 AXLE HEX		01




Item	Code	Description	See page	QT
01	0501059363	5/8" HEX AXLE BEARING	120	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0561014911	AXLE SLEVE GUIDES HEX		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		02




Item	Code	Description	See page	QT
01	0502012819	17Z GEAR WITH HEX HOLE		01
02	0521055220	BEARING FRONT LINE SEED	122	01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503019356	BEARING 6005 2RS1		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521066496	FRAME MECHANICAL CENTRAL SEED LINE		01
02	0511059334	BEARING WITH LONG FRONT AXLE	124	01




Item	Code	Description	See page	QT
01	0511058143	UNIVERSAL JOINT AXLE	125	01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0521055227	BEARING SHAFT HEX	119	01




Item	Code	Description	See page	QT
01	0561014794	350 AXLE HEX		01
02	0501056296	UNIVERSAL JOINT		01
03	0503011855	0.2" X 1.8" SPRING PIN		02
04	0581010483	HEX AXLE		01




Item	Code	Description	See page	QT
01	0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	128	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0521054763	DDD LEFT SEED	129	01




Item	Code	Description	See page	QT
01	0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	128	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0521054762	RIGHT DDD SEED	130	01




Item	Code	Description	See page	QT
01	0581019201	CROWN SHAFT		01
02	0503019340	LUBRICANT GLOVE		02
03	0503011030	2-014 N 3006-9B O'RING		02
04	0581019200	CONICA 40Z GEAR		01
05	0581019199	FIXED BASE		01
06	0581019202	PINHAO CONICO 10Z X 5/8		01
07	0501013354	FLAT WASHER		01
08	0503010410	RING		02
09	0503019341	LUBRICANT GLOVE		01




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	131	01
02	0521054761	LEFT LOW CUBE	133	01
03	0521054760	DOWN LOW CUBE	134	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0511015098	FLAT WASHER		04
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	132	01
02	0521054761	LEFT LOW CUBE	133	01
03	0521054760	DOWN LOW CUBE	134	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0511015098	FLAT WASHER		04
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502012736	HUB LOWR DDD		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012736	HUB LOWR DDD		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	136	01
02	0501052538	DEPTH BAND WITH ARMS	144	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0521054990	LEFT COMPACTOR WHEEL	145	01
06	0521055017	RIGHT COMPACTOR WHEEL	146	01




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	137	01
02	0521054987	LEFT ARM WHEEL DEPTH WITH NO LUBRICATION CUBE	138	01
03	0521054988	RIGHT ARM ROD DEPTH WITH LUBRICANT-FREE HUB	139	01
04	0521055033	COMPACTADOR BODY	141	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	SCREWEW 3/8 UNC X 3/4		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED GLOVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0511015976	FLAT WASHER		01
05	0503010257	1/8" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503010071	3/16" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	140	01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	140	01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL BOX		01
02	0581019515	AXIS		01
03	0503034055	CLAMPING RING		01
04	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
05	0503013758	1/4" X 1-1/2" BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0503010878	5/8" SELF ALIGNING NUT		01
10	0503030757	2.9" X 2" X 0.02" JOINT		01
11	0521019178	COVER DEPTH		01




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT GLOVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0581019523	LEFT ARM WHEEL DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019524	RIGHT ARM DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	147	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	147	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521066231	SHORT FERTILIZER LINE ARM		01
02	0502012873	SUPPORT DC LINE FERTILIZER		01
03	0502012876	CLAMP		01
04	0503016110	BOLT 5/8 UNC X 4 C S G.7 ZN		02
05	0503012412	5/8 UNC SELF LOCKING NUT		03
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0503019116	BOLT		02
08	0503010013	5/8" NUT		02
09	0521053231	DPL 20 SHORT LINE WITHOUT LUBRICATION 150 CONICAL BEARING		01
10	0521054906	SPRING ASSY FERTILIZER	154	01
11	0501010066	3/4" X 9" BOLT		01
12	0511017232	FLAT WASHER		02
13	0581019195	SIDE GUIDE GLOVE		02
14	0503010410	RING		02
15	0503019278	LUBRICANT GLOVE		02
16	0581019196	CENTRAL GUIDE GLOVE		01
17	0503011255	3/4" LOCK NUT		01




Item	Code	Description	See page	QT
01	0521066230	LONG FERTILIZER LINE ARM		01
02	0502012873	SUPPORT DC LINE FERTILIZER		01
03	0502012876	CLAMP		01
04	0503016110	BOLT 5/8 UNC X 4 C S G.7 ZN		02
05	0503012412	5/8 UNC SELF LOCKING NUT		03
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0503019116	BOLT		02
08	0503010013	5/8" NUT		02
09	0521053232	DPL 20 LONG LINE WITHOUT LUBRICATION 151		01
		CONICAL BEARING		
10	0521054906	SPRING ASSY FERTILIZER	154	01
11	0501010066	3/4" X 9" BOLT		01
12	0511017232	FLAT WASHER		02
13	0581019195	SIDE GUIDE GLOVE		02
14	0503010410	RING		02
15	0503019278	LUBRICANT GLOVE		02
16	0581019196	CENTRAL GUIDE GLOVE		01
17	0503011255	3/4" LOCK NUT		01



Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	152	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	152	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012824	FIXING SHAFT DISC CUT LINE		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	CUTTING DISK BOX	153	01

CUTTING DISK BOX


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	CUTTING DISK BOX		01
09	0502040873	CUTTING DISC AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02




Item	Code	Description	See page	QT
01	0521067619	TUBE LINE FERTILIZER		01
02	0502012510	SPRING ROD SUPPORT		01
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502040534	SPRING GUIDE BUSHING LOCK		02
06	0501018535	1/2 X 1 BOLT		02
07	0503010014	3/4" NUT		01
08	0502010891	SPRING CHOCK SUPPORT VARON		01
09	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
10	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		02
12	0581013793	PIN LOCK		01
13	0503010577	3/16" X 1-1/4" COTTERPIN		01




Item	Code	Description	See page	QT
01	0521054765	DDD LEFT FERTILIZER	157	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521054764	DDD RIGHT FERTILIZER	158	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	133	01
03	0521054760	DOWN LOW CUBE	134	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511015098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	133	01
03	0521054760	DOWN LOW CUBE	134	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511015098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0511052058	SEED SYSTEM TITANIUM	162	01
01A	0503062031	BASE SET		01
01B	0503062032	NECK TITANIUM ASSY		01
01C	0503062033	OPPOSITE BASE SET		01
01D	0503062034	CENTRAL ADAPTER SET		01
01E	0503062035	SET FALSE ADAPT CENTER		01
01F	0503062036	SUBSET ASSY LOCK BASE		01
01G	0503062037	SUBSET ESCOVAFLEX ASSY		01
01H	0503062038	ASSY ANTI-LEAP		01
01I	0503062039	POLIFLOW TITANIUM ASSY		01
01J	0503062040	DISPLAY ASSY TITANIUM 1050010		01
01K	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
01L	0503062042	SET BOLT ARTICULADOR		01
01M	0503062043	ASSY LIMIT WEIGHT		01
02	0503062276	ASSY SEED DEPOSIT		01
03	0503010371	5/16" X 1" BOLT		05
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		05
05	0503010179	5/16" ZN SPRING WASHER		05
06	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0521050118	DEPOSIT SEED BOCAL		01
02	0581014295	FIXING GLOVE		01
03	0511052058	SEED SYSTEM TITANIUM	162	01
04	0503010358	5/16" X 5/8" BOLT		05
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		05
06	0503010179	5/16" ZN SPRING WASHER		05
07	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0521050118	DEPOSIT SEED BOCAL		01
02	0581014295	FIXING GLOVE		01
03	0503062420	ASSY TITANIUM VISUM		01
04	0503010358	5/16" X 5/8" BOLT		05
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		05
06	0503010179	5/16" ZN SPRING WASHER		05
07	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0503062031	BASE SET		01
02	0503062032	NECK TITANIUM ASSY		01
03	0503062033	OPPOSITE BASE SET		01
04	0503062034	CENTRAL ADAPTER SET		01
05	0503062035	SET FALSE ADAPT CENTER		01
06	0503062036	SUBSET ASSY LOCK BASE		01
07	0503062037	SUBSET ESCOVAFLEX ASSY		01
08	0503062038	ASSY ANTI-LEAP		01
09	0503062039	POLIFLOW TITANIUM ASSY		01
10	0503062040	DISPLAY ASSY TITANIUM 1050010		01
11	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
12	0503062042	SET BOLT ARTICULADOR		01
13	0503062043	ASSY LIMIT WEIGHT		01




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0521068567	BOX SPRING		01
02	0521053951	STEM	165	01
03	0503034106	80 X 230 X 16,50 HDA COMPRESSION SPRING		01
04	0581012094	SUPPORT WASHER		01
05	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
06	0571019462	SUPPORT GUIDE PRING		01
07	0503012795	5/8" HEX SELF ADJUSTING NUT		01
08	0503010691	1/4" GREASE FITTING		01
09	0503010384	1/2" X 5" BOLT		02
10	0511017302	FLAT WASHER		04
11	0503011336	1/2" HEX SELF ADJUSTING NUT		04
12	0503017874	BOLT 1/2 UNC		02
13	0571018541	BODY SOCKET FERTILIZER		01
14	0503010026	3/8" NUT		02
15	0503010025	3/8" SPRING WASHER		02
16	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
17	0501010984	FLAT WASHER		04
18	0503010417	7/8" NUT		01
19	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
20	0581012084	ARTICULATED GLOVE		01
21	0581012082	SCREW		01
22	0581012081	GLOVE		01




Item	Code	Description	See page	QT
01	0521053932	ROD WITH BEAK		01
02	0521067065	FLANGE WASHER SPRING		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0581012092	AXLE FIXER		01
05	0521015818	FLAT WASHER		02




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010365	NUT		02




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502040869	FIXED ROD BEARING		01
03	0503010546	5/16" X 7/8" BOLT		02
04	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521054751	DEPTH CONTROL WITH THREAD	170	01
02	0511055819	DEPTH WHIT AROS BAND	172	02
03	0521054752	V COMPACTING SYSTEM	173	01
04	0503010479	BOLT		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2" NUT		02
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
08	0503013816	5/16" LOCKNUT		08
09	0521054753	DRIVE WHEEL V RUBBER RIGHT	176	01
10	0521054754	DRIVE WHEEL V LEFT RUBBER	177	01




Item	Code	Description	See page	QT
01	0521055065	ASSY DEPTH / COMPACTOR	171	01
02	0521055068	RAYED WHEEL CENTER CLOSED	174	02
03	0521054990	LEFT COMPACTOR WHEEL	145	01
04	0521055017	RIGHT COMPACTOR WHEEL	146	01
05	0503016453	1/2" X 2.1/2 BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010028	1/2" NUT		02




Item	Code	Description	See page	QT
01	0581017621	CONTROL AXLE		01
02	0521063812	REGULATOR LEVER ALXE		01
03	0503011336	1/2" HEX SELF ADJUSTING NUT		01
04	0511065308	LOCK REGULATOR		01
05	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
06	0541011627	FLAT WASHER		01
07	0503010140	1/8" X 3/4" COTTERPIN		01
08	0521053245	LEFT ARM WHEELS		01
09	0521053244	ARM RIGHT WHEEL COBRIDORA		01
10	0581017646	SLEEVE LOCK CONTROL ARM		02
11	0571013189	SLEEVE SUPPORT BEATER		01
12	0521063813	WHEEL PRESS BEATER		01
13	0501010937	13.5 X 28 X 3 FLAT WASHER		01
14	0503010045	O'RING		04
15	0503017375	1/2" X 1-1/4" BOLT		01
16	0503014007	1/2" X 1-1/4" BOLT		01
17	0503010019	1/2" SPRING WASHER		03
18	0503010920	1/2" X 1.1/2" BOLT		01
19	0503010023	3/4" SPRING WASHER		04
20	0521054744	CUBE RIGHT CONTROL DEPTH		01
21	0521054745	HUB LEFT CONTROL DEPTH		01
22	0581019171	REGULATOR		01
23	0521069476	EXTERNAL COLUMN CONTROL DEPTH		01
24	0521069475	INTERNAL COLUMN CHECK DEPTH		01
25	0503010683	0.2" X 1.2" SPRING PIN		01
26	0503034830	REGULATION LATCHE		01
27	0521054750	CRANK ASSEMBLY		01
27A	0521069477	HAND CRANK		01
27B	0503030878	LEVER CRANK		01
28	0503030751	REGULATOR PLATE		01
29	0503010001	3.2 X 5.5 RIVET		04




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0571013054	DEPTH CONTROL WHEEL AXLE		01
04	0502012663	EXTENSION		01
05	0501056769	DEPTH WHEELS REGULATOR ASSY		01
06	0503010581	RING		01
07	0521055033	COMPACTADOR BODY	141	01
08	0521055054	LEFT ARM WITH SLEEVE	142	01
09	0521055066	RIGHT ARM WITH GLOVE	143	01
10	0511015346	FLAT WASHER		04
11	0571015974	WASHER		02
12	0511017302	FLAT WASHER		02
13	0503010256	3/8" X 3/4" BOLT		01
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		04
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2" NUT		02
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0581019473	ARTICULATED GLOVE		02
20	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0581017647	PRESS WHEELS ARM		01
02	0503030883	RIGHT TORSION SPRING		01
03	0581017622	SEAT SUPPORT		01
04	0581017648	PIVOT SHAFT		01
05	0503010839	03"X 0.6" SPRING PIN		01
06	0521069490	RIGHT REGULATOR		01
07	0521069491	LEFT REGULATOR		01
08	0581019175	REGULATOR AXLE		01
09	0521063812	REGULATOR LEVER ALXE		01
10	0503011336	1/2" HEX SELF ADJUSTING NUT		02
11	0511065308	LOCK REGULATOR		01
12	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
13	0541011627	FLAT WASHER		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0571013293	SLEEVE LOCK COMPACTOR V CONTROL WITH SCREW		01
16	0581013744	PROTECTION COVER - CPRA		01
17	0503013096	5/16" X 4" BOLT		01
18	0503013816	5/16" LOCKNUT		01
19	0503019273	SLEEVE		02
20	0503010045	O'RING		02
21	0503010025	3/8" SPRING WASHER		02
22	0503010026	3/8" NUT		02
23	0503011404	BOLT		02
24	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01




Item	Code	Description	See page	QT
01	0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	175	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	5/16" ZN SPRING WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0581019522	CASE WHEEL DEPTH WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0503010143	1/4" SPRING WASHER		03
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019529	DEPTH REGULATOR SHAFT		01
11	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01




Item	Code	Description	See page	QT
01	0581019097	BOX LOWER WHEEL		01
02	0581012949	BEARING COVER		01
03	0503018045	2-130 (AGEL) O'RING		01
04	0503011105	SEAL RING		01
05	0502012893	WHEEL BOX		01
06	0521018928	PRESS WHEEL RIM		02
07	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
08	0503013816	5/16" LOCKNUT		09
09	0503010011	5/16" X 1/2" BOLT		06
10	0503010358	5/16" X 5/8" BOLT		03
11	0581019166	RIGHT AXIS		01
12	0501010984	FLAT WASHER		01
13	0503010025	3/8" SPRING WASHER		01
14	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
15	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		01
16	0503033787	NUT 3/4 UNF		01
17	0581019215	DUST CLOAK		01




Item	Code	Description	See page	QT
01	0581019097	BOX LOWER WHEEL		01
02	0581012949	BEARING COVER		01
03	0503018045	2-130 (AGEL) O'RING		01
04	0503011105	SEAL RING		01
05	0502012893	WHEEL BOX		01
06	0521018928	PRESS WHEEL RIM		02
07	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
08	0503013816	5/16" LOCKNUT		09
09	0503010011	5/16" X 1/2" BOLT		06
10	0503010358	5/16" X 5/8" BOLT		03
11	0581019167	LEFT AXLE		01
12	0501010984	FLAT WASHER		01
13	0503010025	3/8" SPRING WASHER		01
14	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
15	0503033788	NUT 3/4		01
16	0503019348	SCREW 3/8 UNC X 3/4		01
17	0581019215	DUST CLOAK		01




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	180	03
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521015501	COUPLING SHAFT		03
04	0503010523	1/4" X 2" COTTERPIN		06
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		03
06	0531012565	SLEEVE 16,3X 30 X 88		03
07	0503010027	5/8" SPRING WASHER		03
08	0503010013	5/8" NUT		03
09	0531019171	1.25" X 7" COUPLING SHAFT		01



Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01



Item	Code	Description	See page	QT
01	0503062808	KIT MONITOR SEED 15L 45/50 PM400		01
01A	0503016561	15 ROW SIMPLE MONITOR CABLE		01
01B	0503019100	SENSOR		15
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503013100	NYLON CLAMP		75
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		225
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
08	0503010669	FLAT WASHER		02
09	0503010668	3/16" SPRING WASHER		02
10	0503010667	3/16" NUT		02



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

