

ROW CROP PLANTERS

PHT FLEX - FRAME 2200/2700/3200 (UP TO 03/2022)

Code: 0501092444
Series: S-0118
Revision: 00
Date Revision: FEVEREIRO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111470005	PHT FLEX 2200/2E900 D/H S-0118
0111470002	PHT FLEX 2200/2E900 S-0118
0111470006	PHT FLEX 2200/3E450 D/H S-0118
0111470003	PHT FLEX 2200/3E450 S-0118
0111470007	PHT FLEX 2200/3E500 D/H S-0118
0111470004	PHT FLEX 2200/3E500 S-0118
0111470011	PHT FLEX 2700/3E900 D/H S-0118
0111470008	PHT FLEX 2700/3E900 S-0118
0111470012	PHT FLEX 2700/4E450 D/H S-0118
0111470009	PHT FLEX 2700/4E450 S-0118
0111470013	PHT FLEX 2700/4E500 D/H S-0118
0111470010	PHT FLEX 2700/4E500 S-0118
0111470017	PHT FLEX 3200/4E900 D/H S-0118
0111470014	PHT FLEX 3200/4E900 S-0118
0111470018	PHT FLEX 3200/5E450 D/H S-0118
0111470015	PHT FLEX 3200/5E450 S-0118
0111470019	PHT FLEX 3200/5E500 D/H S-0118
0111470016	PHT FLEX 3200/5E500 S-0118

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.




MARCHESAN

INDEX


0909095157	FRAME ASSY	1
0521052477	LONG SEED LINE/ASSY FERTILIZER	2
0521052476	SHORT LINE SEED/COMPLETE FERTILIZER	3
0501048893	DISTRIBUTOR FERTILIZER	4
0521052367	LEFT SEED LINE	5
0521052366	RIGHT SEED LINE	6
0511053857	FAST CLOSING SET	7
0501052979	LEFT 15" X 15" DOUBLE DISC	8
0501052978	RIGHT 15" X 15" DOUBLE DISC	9
0521051956	SEMI MOUNTED SEED SYSTEM	10
0501051094	ASSY SEED DISTRIBUTOR	11
0501051119	DOUBLE PULLEY ROCKER'S	12
0521052363	DEPTH / COMPACTOR WHEEL SYSTEM V	13
0521055434	DEPTH CONTROL COMPACTOR	14
0501043613	DEPTH WHEEL	15
0501055187	DEPTH WHEEL WITHOUT CUBE	16
0521055436	DEPTH CONTROL	17
0521055435	SEMI MOUNTED DEPTH ASSEMBLY	18
0521055439	CUBE CONTROL RIGHT DEPTH	19
0521055438	CUBE LEFT DEPTH CONTROL	20
0521055433	LONG WHEEL COMPACTOR ASSEMBLY	21
0501050421	HUB DEPTH REGULATOR ASSY	22
0501059329	WHEELS ASSY	23
0511054333	COMPACT WHEEL RIGHT WITH BEARING	24
0511054334	COMPACT WHEEL LEFT WITH BEARING	25
0501052908	COMPACTOR WHEEL WITH BEARING	26
0521055431	LONG COMPACTOR WHEEL	27
0521052362	CONICA GEAR 18Z X 48 WITH BEARING	28
0501052775	ROW SEED BEARING	29
0521052361	CONICA GEAR 18Z X 59 WITH BEARING	30
0511059191	FRONT BEARING DOBLE	31
0521052358	LONG LINE FERTILIZER	32
0521052357	SHORT LINE FERTILIZER	33
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	34
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	35
0511053173	CUBE LOW RIGHT WITH DISC 15	36
0511053172	LEFT LOW CUBE WITH DISC 15	37
0521052356	ASSY CUTTING DISC	38
0521052350	ROD SPRING MOUNTED FERTILIZER	39
0521052365	DOUBLE SEED STRIPPER	40
0521052368	STRETCHER SIMPLE SEED	41
0521052364	BEARING WITH GEAR 17Z HEX 5/8 ASSY	42
0521052795	DISC ASSY SEED	43
0501050120	LARGER WALKING BEAM ASSY	44
0521052755	ROD ASSEMBLY	45
0521052348	WHEEL SEED LAW	46
0521052349	WHEEL LEFT FERTILIZER	47
0503060105	WELL AND TIRE ASSY	48
0501059313	AGRICULTURAL BEARING	49
0501048790	AXLE WITH RING	50
0501059985	RH WHEEL ARM	51
0501059986	LEFT WHEEL ARM	52
0521052375	BEARING SHAFT HEX 5/8 ASSY	53
0501059363	5/8" HEX AXLE BEARING	54
0521052347	BEARING TRANSMISSION ASSY DOUBLE	55

INDEX

0501056450	5/8 DOUB BEARING SEED TRANSMISSION	56
0501052777	CHAIN TENSIONER ASSY	57
0501052779	CHAIN TENSIONER ASSY	58
0511051371	ASSY CURRENT TENSIONER	59
0521052460	FRAME 2200 FERTILIZER/SEED TRANSMISSION	60
0521052464	FRAME 2700 FERTILIZER/SEED TRANSMISSION	61
0521052467	FRAME 3200 FERTILIZER/SEED TRANSMISSION	62
0521052461	PLATFORM 2200 ASSY	63
0521052465	PLATFORM 2700 ASSY	64
0521052468	PLATFORM 3200 ASSY	65
0521052462	HANDRAIL 2200 ASSY	66
0521052466	HANDRAIL 2700 ASSY	67
0521052469	HANDRAIL 3200 ASSY	68
0521052649	HANDRAIL REAR 2200	69
0521052632	HANDRAIL REAR 2700	70
0521052650	HANDRAIL REAR 3200	71
0521052651	HANDRAIL FRONT 2200	72
0521052633	HANDRAIL FRONT 2700	73
0521052652	HANDRAIL FRONT 3200	74
0511059383	HANDRAIL INTERNAL FIXER	75
0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	76
0521052463	ASSY LOWER HITCH	77
0521052764	GEAR ASSEMBLY	78




Item	Code	Description	See page	2200	2700	3200
01	0521068505	FRAME 2200		001	000	000
01.	0521068481	FRAME 2700		000	001	000
01..	0521068480	FRAME 3200		000	000	001
02	0521052477	LONG SEED LINE/ASSY FERTILIZER	2	001	002	002
03	0521052476	SHORT LINE SEED/COMPLETE FERTILIZER	3	001	001	002
04	0521052795	DISC ASSY SEED	43	002	003	004
05	0521052755	ROD ASSEMBLY	45	002	003	004
06	0521052348	WHEEL SEED LAW	46	001	001	001
07	0521052349	WHEEL LEFT FERTILIZER	47	001	001	001
08	0521052460	FRAME 2200 FERTILIZER/SEED TRANSMISSION	60	001	000	000
08.	0521052464	FRAME 2700 FERTILIZER/SEED TRANSMISSION	61	000	001	000
08..	0521052467	FRAME 3200 FERTILIZER/SEED TRANSMISSION	62	000	000	001
09	0521052461	PLATFORM 2200 ASSY	63	001	000	000
09.	0521052465	PLATFORM 2700 ASSY	64	000	001	000
09..	0521052468	PLATFORM 3200 ASSY	65	000	000	001
10	0521052462	HANDRAIL 2200 ASSY	66	001	000	000
10.	0521052466	HANDRAIL 2700 ASSY	67	000	001	000
10..	0521052469	HANDRAIL 3200 ASSY	68	000	000	001
11	0521052463	ASSY LOWER HITCH	77	001	001	001
12	0521010577	0.9" X 4.1" COUPLING SHAFT		001	001	001
13	0503030119	LOCK PIN		001	001	001
14	0521052764	GEAR ASSEMBLY	78	001	001	001




Item	Code	Description	See page	QT
01	0501048893	DISTRIBUTOR FERTILIZER	4	01
02	0503030275	AGRICULTURAL BEARING		01
03	0502012990	CONICA 14Z SQUARE GEAR		01
04	0502012798	SUPPORT BOX SEED		01
05	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		02
06	0502011538	SPRING GUIDE		01
07	0521068476	PANTOGRAPHY ARM SEAL LINE		01
08	0521052367	LEFT SEED LINE	5	01
09	0521068496	FERTILIZER CASH FIXED SUPPORT		01
10	0521068498	LOWER PANTOGRAPH		01
11	0521068497	TOP PANTOGRAPH		01
12	0581016458	SUPPORT SPRING PANTOGRAPH		01
13	0581016456	FIXER COVER CURRENT 88		01
14	0581016457	FIXER COVER CURRENT 105		01
15	0521052358	LONG LINE FERTILIZER	32	01
16	0521052350	ROD SPRING MOUNTED FERTILIZER	39	01
17	0581016455	PIN 15.88 X 110 WITH HOLES		01
18	0521052365	DOUBLE SEED STRIPPER	40	01
19	0521052368	STRETCHER SIMPLE SEED	41	01
20	0581016422	COVER CURRENT SEED		01
21	0503011076	40-1 X 2.87 CHAIN LINK + MENDING		01
22	0531015151	0.6" X 1" X 2.4" SLEEVE		08
23	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
24	0503012412	5/8 UNC SELF LOCKING NUT		04
25	0501011299	FLAT WASHER		04
26	0503010014	3/4" NUT		02
27	0503010023	3/4" SPRING WASHER		02
28	0501010941	FLAT WASHER		02
29	0501010827	3/4" X 2-3/4" BOLT		02
30	0501010984	FLAT WASHER		04
31	0581016478	THREADED ROD		02

Item	Code	Description	See page	QT
32	0503014508	CURRENT 40-1 X 98		01
33	0502010901	FINE SEED BOX AGRICULTURAL BEARING		01
34	0521068502	SPROCKET WITH DOUBLE AXIS 17Z		01
35	0521052364	BEARING WITH GEAR 17Z HEX 5/8 ASSY	42	01
36	0503010071	3/16" X 1" COTTERPIN		02
37	0503010002	1800 GREASE FITTING		04
38	0581016485	FLAT WASHER 25.5 X 2.00 X 37		01
39	0503010406	501025 CLAMPING RING (FOR AXLE)		01
40	0501010694	FLAT WASHER		08
41	0503010179	LOCK WASHER		08
42	0503010337	5/16" NUT		02
43	0503010371	5/16" X 1" BOLT		02
44	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		02
45	0503010765	3/8" X 3" BOLT		01
46	0501013518	FLAT WASHER		01
47	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
48	0503030408	2X2X390 HOSE		01
49	0503010246	CLAMP		02
50	0503010362	1/8" X 1.1/4" COTTERPIN		01
51	0551019117	FERTILIZER DISTRIBUTOR COVER		01
52	0503062749	SILO FERTILIZER WITH BLUE COVER		01
53	0503010003	1845 GREASE FITTING		01
54	0503010025	3/8" SPRING WASHER		07
55	0503010026	3/8" NUT		07




Item	Code	Description	See page	QT
01	0501048893	DISTRIBUTOR FERTILIZER	4	01
02	0503030275	AGRICULTURAL BEARING		01
03	0502012990	CONICA 14Z SQUARE GEAR		01
04	0502012798	SUPPORT BOX SEED		01
05	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		02
06	0502011538	SPRING GUIDE		01
07	0521068476	PANTOGRAPHY ARM SEAL LINE		01
08	0521052366	RIGHT SEED LINE	6	01
09	0521068496	FERTILIZER CASH FIXED SUPPORT		01
10	0521068498	LOWER PANTOGRAPH		01
11	0521068497	TOP PANTOGRAPH		01
12	0581016458	SUPPORT SPRING PANTOGRAPH		01
13	0581016456	FIXER COVER CURRENT 88		01
14	0581016457	FIXER COVER CURRENT 105		01
15	0521052357	SHORT LINE FERTILIZER	33	01
16	0521052350	ROD SPRING MOUNTED FERTILIZER	39	01
17	0581016455	PIN 15.88 X 110 WITH HOLES		01
18	0521052365	DOUBLE SEED STRIPPER	40	01
19	0521052368	STRETCHER SIMPLE SEED	41	01
20	0581016422	COVER CURRENT SEED		01
21	0503011076	40-1 X 2.87 CHAIN LINK + MENDING		01
22	0531015151	0.6" X 1" X 2.4" SLEEVE		08
23	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
24	0503012412	5/8 UNC SELF LOCKING NUT		04
25	0501011299	FLAT WASHER		04
26	0503010014	3/4" NUT		02
27	0503010023	3/4" SPRING WASHER		02
28	0501010941	FLAT WASHER		02
29	0501010827	3/4" X 2-3/4" BOLT		02
30	0501010984	FLAT WASHER		04
31	0581016478	THREADED ROD		02


Item	Code	Description	See page	QT
32	0503014508	CURRENT 40-1 X 98		01
33	0502010901	FINE SEED BOX AGRICULTURAL BEARING		01
34	0521068502	SPROCKET WITH DOUBLE AXIS 17Z		01
35	0521052364	BEARING WITH GEAR 17Z HEX 5/8 ASSY	42	01
36	0503010071	3/16" X 1" COTTERPIN		02
37	0503010002	1800 GREASE FITTING		04
38	0581016485	FLAT WASHER 25.5 X 2.00 X 37		01
39	0503010406	501025 CLAMPING RING (FOR AXLE)		01
40	0501010694	FLAT WASHER		08
41	0503010179	LOCK WASHER		08
42	0503010337	5/16" NUT		02
43	0503010371	5/16" X 1" BOLT		02
44	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		02
45	0503010765	3/8" X 3" BOLT		01
46	0501013518	FLAT WASHER		01
47	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
48	0503030408	2X2X390 HOSE		01
49	0503010246	CLAMP		02
50	0503010362	1/8" X 1.1/4" COTTERPIN		01
51	0551019117	FERTILIZER DISTRIBUTOR COVER		01
52	0503062749	SILO FERTILIZER WITH BLUE COVER		01
53	0503010003	1845 GREASE FITTING		01
54	0503010025	3/8" SPRING WASHER		07
55	0503010026	3/8" NUT		07




Item	Code	Description	See page	QT
01	0501110143	TUBE FERTILIZER METERING BODY		01
01A	1902020469	DISTRIBUTOR FERTILIZER		01
01B	0541016687	268 FERTILIZER TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0511017137	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503012826	CREASE FITTING		02
12	0503011962	GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012314	SEED BOX FIXING BASE		01
02	0502011418	40Z CONICAL GEAR		01
03	0511018700	AXLE		01
04	0502011411	10Z CONICAL GEAR		01
05	0501013352	FLAT WASHER		02
06	0501010694	FLAT WASHER		01
07	0503010179	LOCK WASHER		03
08	0511053857	FAST CLOSING SET	7	01
09	0501052979	LEFT 15" X 15" DOUBLE DISC	8	01
10	0501053347	SEED SYSTEM ASSEMBLY		01
11	0521068499	SEED LINE PANTOGRAPH		01
12	0521052363	DEPTH / COMPACTOR WHEEL SYSTEM V	13	01
13	0521052362	CONICA GEAR 18Z X 48 WITH BEARING	28	01
14	0521052361	CONICA GEAR 18Z X 59 WITH BEARING	30	01
15	0581016413	GEAR 17Z P1 / 2 X 1/2 HEX		01
16	0521068500	AXIS TRANSMISSION LINE SEED		01
17	0581016412	SLEEVE 25,4 X 15 X 32		01
18	0581016421	AXIS TRANSMISSION LINE SEED 198		01
19	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		03
20	0503011446	SPRING WASHER		03
21	0503010244	7/16" NUT		03
22	0503010848	5/16" X 3.1/2" BOLT		02
23	0503010337	5/16" NUT		02
24	0503010479	BOLT		01
25	0503010060	1/2" NUT		01
26	0503011440	SPRING WASHER		01
27	0503010180	7/16" SPRING WASHER		01
28	0503010244	7/16" NUT		01
29	0503011135	BOLT		01
30	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		01




Item	Code	Description	See page	QT
01	0502012314	SEED BOX FIXING BASE		01
02	0502011418	40Z CONICAL GEAR		01
03	0511018700	AXLE		01
04	0502011411	10Z CONICAL GEAR		01
05	0501013352	FLAT WASHER		02
06	0501010694	FLAT WASHER		01
07	0503010179	LOCK WASHER		03
08	0511053857	FAST CLOSING SET	7	01
09	0501052978	RIGHT 15" X 15" DOUBLE DISC	9	01
10	0501053347	SEED SYSTEM ASSEMBLY		01
11	0521068499	SEED LINE PANTOGRAPH		01
12	0521052363	DEPTH / COMPACTOR WHEEL SYSTEM V	13	01
13	0521052362	CONICA GEAR 18Z X 48 WITH BEARING	28	01
14	0521052361	CONICA GEAR 18Z X 59 WITH BEARING	30	01
15	0581016413	GEAR 17Z P1 / 2 X 1/2 HEX		01
16	0521068500	AXIS TRANSMISSION LINE SEED		01
17	0581016412	SLEEVE 25,4 X 15 X 32		01
18	0581016421	AXIS TRANSMISSION LINE SEED 198		01
19	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		03
20	0503011446	SPRING WASHER		03
21	0503010244	7/16" NUT		03
22	0503010848	5/16" X 3.1/2" BOLT		02
23	0503010337	5/16" NUT		02
24	0503010479	BOLT		01
25	0503010060	1/2" NUT		01
26	0503011440	SPRING WASHER		01
27	0503010180	7/16" SPRING WASHER		01
28	0503010244	7/16" NUT		01
29	0503011135	BOLT		01
30	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		01




Item	Code	Description	See page	QT
01	0502012744	SPEED LOCK LEVER ASSY		01
02	0502012743	FAST BOLT ASSY		01
03	0571014534	FAST BOLT ADJUSTMENT		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010257	1/8" X 1" COTTERPIN		02




Item	Code	Description	See page	QT
01	0502011183	15"X15" LW SEED UNAL DOUB-DISC SUPP		01
02	0501054167	BOX DDD ASSY DPL 15 RIGHT		01
03	0511011927	DUST CLOAK		02
04	0503030757	2.9" X 2" X 0.02" JOINT		02
05	0521019178	COVER DEPTH		02
06	0501054168	BOX DDD ASSY DPL 15 LEFT		01
07	0511015098	FLAT WASHER		06
08	0501017542	LH DOUBLE DISC SCRAPER		01
09	0501017541	RIGHT DOUBLE DISC SCRAPER		01
10	0503010143	1/4" SPRING WASHER		06
11	0503014729	1/4" UNF X 1/2" BOLT		06
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0502011184	15" X 15" DOUBLE DISC SUPPORT		01
02	0501054167	BOX DDD ASSY DPL 15 RIGHT		01
03	0511011927	DUST CLOAK		02
04	0503030757	2.9" X 2" X 0.02" JOINT		02
05	0521019178	COVER DEPTH		02
06	0501054168	BOX DDD ASSY DPL 15 LEFT		01
07	0511015098	FLAT WASHER		06
08	0501017542	LH DOUBLE DISC SCRAPER		01
09	0501017541	RIGHT DOUBLE DISC SCRAPER		01
10	0503014729	1/4" UNF X 1/2" BOLT		06
11	0503010143	1/4" SPRING WASHER		06
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0502020324	SEED BOX SUPPORT		01
02	0503031667	BOX YELLOW SEED WITH GREEN COVER		01
03	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
04	0501010694	FLAT WASHER		04
05	0503010179	LOCK WASHER		04
06	0501051094	ASSY SEED DISTRIBUTOR	11	01
07	0503010675	5/16" X 2.1/4" BOLT		01
08	0503010179	LOCK WASHER		01
09	0503010337	5/16" NUT		01
10	0502010408	SEED DISC LOWER TRAIL		01
11	0521010536	0.3" X 3.8" COUPLING SHAFT		01
12	0503010140	1/8" X 3/4" COTTERPIN		01
13	0503030083	3/8" X 3/8" X 1.6" STUD		01
14	0503010025	3/8" SPRING WASHER		01
15	0503010209	3/8" UNC BUTTERFLY NUT		01
16	0503010025	3/8" SPRING WASHER		02
17	0571018536	HEX PRISONER		01
18	0503034131	DEFLECTOR		01
19	0503010209	3/8" UNC BUTTERFLY NUT		01
20	0501013518	FLAT WASHER		01
21	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
22	0503016219	RING TO SOYBEANS		01
23	0531018622	BOLT FAST SUPPORT UPPER		01
24	0501010096	3/8" X 2" BOLT		01
25	0501010984	FLAT WASHER		01
26	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0503030381	SEED DISTRIBUTOR BOX		01
02	0502010447	TRIGGER		02
03	0501013467	KEY AXLE		01
04	0503030378	0.4" X 1.1" X 0.03" SPRING		03
05	0501013466	KEY LIMITER AXLE		01
06	0501051119	DOUBLE PULLEY ROCKER'S	12	01
07	0501013468	ROCKER ARM AXLE, OF THE PULLEY		01
08	0503030377	SCRAPER		01




Item	Code	Description	See page	QT
01	0503031129	DOUBLE PULLEY ROCKER ARM		01
02	0503031128	5Z PLASTIC DOUB PULLEY FOR SOYBEAN		02
03	0521010649	TOOTH PULLEY COUPLING SHAFT		01
04	0503011853	503050 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0502012331	DEPTH WHEEL SUPPORT		01
02	0501043613	DEPTH WHEEL	15	01
03	0501018535	1/2 X 1 BOLT		02
04	0501059329	WHEELS ASSY	23	01




Item	Code	Description	See page	QT
01	0521055436	DEPTH CONTROL	17	01
02	0501055187	DEPTH WHEEL WITHOUT CUBE	16	02
03	0581018117	AXIS 13,50 X 22,15 X 72		01
04	0503010691	1/4" GREASE FITTING		01
05	0503010358	5/16" X 5/8" BOLT		08
06	0503013816	5/16" LOCKNUT		08
07	0521055433	LONG WHEEL COMPACTOR ASSEMBLY	21	01
08	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		01
09	0501010937	13.5 X 28 X 3 FLAT WASHER		01
10	0503011336	1/2" HEX SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0501050421	HUB DEPTH REGULATOR ASSY	22	01
02	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		02
03	0521010832	RIM FLANGE		04
04	0503010358	5/16" X 5/8" BOLT		08
05	0503010179	LOCK WASHER		08
06	0503010337	5/16" NUT		08
07	0503010298	1/4" X 1/2" BOLT		10
08	0503010143	1/4" SPRING WASHER		10
09	0503010144	1/4" NUT		10




Item	Code	Description	See page	QT
01	0503032005	RUBBER BAND		01
02	0541011628	DEPTH WHEEL RIM SEMI		02
03	0503010519	1/4" X 5/8" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0521069079	EXTERNAL COLUMN CONTROL DEPTH		01
02	0521055435	SEMI MOUNTED DEPTH ASSEMBLY	18	01
03	0581018123	ADJUSTING ROD 215		01
04	0581018124	ROD HEX 1.1 / 4 X 40 WITH HOLE		01
05	0511015098	FLAT WASHER		01
06	0503010683	0,2" X 1,2" SPRING PIN		01
07	0503030285	HAIR PIN		01




Item	Code	Description	See page	QT
01	0521069080	INTERNAL COLUMN BODY CONTROL DEPTH		01
02	0521055439	CUBE CONTROL RIGHT DEPTH	19	01
03	0521055438	CUBE LEFT DEPTH CONTROL	20	01




Item	Code	Description	See page	QT
01	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
02	0503019342	ROLLER BEARING		01
03	0503034055	CLAMPING RING		01
04	0581019513	DEPTH WHEEL BOX		01
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0521019178	COVER DEPTH		01
08	0503010143	1/4" SPRING WASHER		03
09	0503011105	SEAL RING		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0581019859	RIGHT AXLE CHECK DEPTH		01




Item	Code	Description	See page	QT
01	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
02	0503019342	ROLLER BEARING		01
03	0503034055	CLAMPING RING		01
04	0581019513	DEPTH WHEEL BOX		01
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0521019178	COVER DEPTH		01
08	0503010143	1/4" SPRING WASHER		03
09	0503011105	SEAL RING		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0581019858	LEFT AXLE CHECK DEPTH		01




Item	Code	Description	See page	QT
01	0503033942	COVER REGULATORY WHEEL		01
02	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
03	0521068997	LONG COMPACTOR WHEEL REGULATOR		01
04	0581018129	LEVER REGULATING WHEEL COMPACTOR WIDE		01
05	0503010140	1/8" X 3/4" COTTERPIN		01
06	0521055431	LONG COMPACTOR WHEEL	27	01
07	0501010937	13.5 X 28 X 3 FLAT WASHER		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		01
09	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0501064772	DEPTH REGULATOR ARM		01
02	0503010689	SEAL 00763-BR		02
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		02
05	0503011105	SEAL RING		01
06	0502011907	DEPTH CONTROL WHEEL HUB		02
07	0503010878	5/8" SELF ALIGNING NUT		02
08	0503030757	2.9" X 2" X 0.02" JOINT		02
09	0521019178	COVER DEPTH		02
10	0503014729	1/4" UNF X 1/2" BOLT		06
11	0503010143	1/4" SPRING WASHER		06
12	0503010691	1/4" GREASE FITTING		02




Item	Code	Description	See page	QT
01	0502011757	PRESS REGULATOR		01
02	0511054333	COMPACT WHEEL RIGHT WITH BEARING	24	01
03	0511054334	COMPACT WHEEL LEFT WITH BEARING	25	01
04	0501013798	LEFT ARM		01
05	0501013799	RIGHT ARM		01
06	0503010849	3/8" X 1-1/2" BOLT		02
07	0503010025	3/8" SPRING WASHER		02
08	0503010026	3/8" NUT		02
09	0501069979	SPRING REGULATOR		01
10	0521013310	0.5" X 3" COUPLING SHAFT		01
11	0503010300	5/32" X 1" COTTERPIN		01
12	0503010479	BOLT		01
13	0541016309	13,2 X 22,18 SLEEVE		01
14	0503010019	1/2" SPRING WASHER		01
15	0503010060	1/2" NUT		01
16	0502040534	SPRING GUIDE BUSHING LOCK		02
17	0503030399	1"X5.1"X 0.2" COMPRESSION SPRING		01
18	0501018535	1/2 X 1 BOLT		02




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	26	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	26	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0581018311	LONG SINGLE COMPACTOR WHEEL	01	
02	0581018337	CUBE COMPACTING WHEEL	02	
03	0503019309	BEARING 6204-2RLD -V2	02	
04	0503010272	SEAL 00715-BA	02	
05	0503030143	3.3" X 1.9" X 0.1" JOINT	02	
06	0503031514	DEPTH CONTROL WHEEL RUBBER BAND	01	
07	0521014107	PRESS WHEEL RIM	02	
08	0503010143	1/4" SPRING WASHER	05	
09	0503010144	1/4" NUT	05	
10	0503013815	1/4" X 5/8" BOLT	05	
11	0503013814	1/4" NC LOCKNUT	05	
12	0503010743	1/4" X 1-1/4" BOLT	05	
13	0511017303	FLAT WASHER	05	




Item	Code	Description	See page	QT
01	0501052775	ROW SEED BEARING	29	01
02	0581016420	CONICA GEAR TEETH 18 HEXAGONAL 1/2 X 48		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503010371	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0511059191	FRONT BEARING DOBLE	31	01
02	0581016418	GEAR CONICA 18Z HEX 1/2 X 59		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0503010365	NUT		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011971	HOUSING WITH DOUBLE BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	34	01
02	0531014527	FLAT WASHER		02
03	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
04	0581011812	SPRING LOWER SUPPORT		01
05	1902020393	SPRING UPPER SUPPORT		01
06	0503030483	FERTILIZER SOCKET		01
07	0511018662	SPACING PLATE		04
08	0521068492	SHORT FERTILIZER LINE ARM		02
09	0521068493	TRUNNION DC		01
10	0581016466	GLOVE TRUNNION DC		01
11	0521068494	ROD DC		01
12	0521052356	ASSY CUTTING DISC	38	01
13	0503011075	3/4" UNC NUT		01
14	0503010002	1800 GREASE FITTING		01
15	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
16	0503010019	1/2" SPRING WASHER		02
17	0503010060	1/2" NUT		02
18	0503016485	BOLT 3/4		01
19	0501017065	FLAT WASHER		02
20	0503010152	3/4" SELF LOCKING NUT		01
21	0503010839	03"X 0.6" SPRING PIN		01
22	0521068490	FIXER LINE SHORT FERTILIZER		01
23	0511017969	0.1" SPACING PLATE		04




Item	Code	Description	See page	QT
01	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	35	01
02	0531014527	FLAT WASHER		02
03	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
04	0581011812	SPRING LOWER SUPPORT		01
05	1902020393	SPRING UPPER SUPPORT		01
06	0503030483	FERTILIZER SOCKET		01
07	0511018662	SPACING PLATE		04
08	0521068492	SHORT FERTILIZER LINE ARM		02
09	0521068493	TRUNNION DC		01
10	0581016466	GLOVE TRUNNION DC		01
11	0521068494	ROD DC		01
12	0521052356	ASSY CUTTING DISC	38	01
13	0503011075	3/4" UNC NUT		01
14	0503010002	1800 GREASE FITTING		01
15	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
16	0503010019	1/2" SPRING WASHER		02
17	0503010060	1/2" NUT		02
18	0503016485	BOLT 3/4		01
19	0501017065	FLAT WASHER		02
20	0503010152	3/4" SELF LOCKING NUT		01
21	0503010839	03"X 0.6" SPRING PIN		01
22	0521068490	FIXER LINE SHORT FERTILIZER		01
23	0511017969	0.1" SPACING PLATE		04




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	36	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	37	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	37	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	36	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0521068495	ARM DC		01
02	0502011281	DISC HUB		01
03	0503010215	30205 BEARING		02
04	0503010213	SEAL 30205		01
05	0503010691	1/4" GREASE FITTING		01
06	0503030282	3/4" CASTLE NUT		01
07	0501010941	FLAT WASHER		01
08	0503010362	1/8" X 1.1/4" COTTERPIN		01
09	0503030272	3,1" X 2,1" X 0,01" JOINT		01
10	0521010383	BALDE DISC PROTECTION CAP		01
11	0503010298	1/4" X 1/2" BOLT		03
12	0503010143	1/4" SPRING WASHER		03
13	0503810365	BOLT 5/16 UNC X 1.1/4 CS G.5		06
14	0503011444	SPRING WASHER		06
15	0503010337	5/16" NUT		06
16	0603023009	16" X 0.2" FLAT PLAIN DISC		01
17	0501013839	WASHER		01




Item	Code	Description	See page	QT
01	0503030917	1.6"X11.8"X 0.2" COMPRESSION SPRING		01
02	0502012184	FERTILIZER SPRING GUIDE		02
03	0502040534	SPRING GUIDE BUSHING LOCK		02
04	0503010834	1/2 X 1 BOLT		02
05	0521068487	ROD SPRING FERTILIZER		01
06	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0503010292	0.2" X 1.6" SPRING PIN		01
02	0503010302	501019 SEAL RING		03
03	0503010002	1800 GREASE FITTING		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0511017302	FLAT WASHER		01
07	0503030394	1.7"X 1.4"X 0.14" LH TORSION SPRING		01
08	0503031805	11Z 1/2" GEAR		02
09	0521068501	DOUBLE SEED STRIPPER		01
10	0581016481	ARTICULATED SHAFT 78		01




Item	Code	Description	See page	QT
01	0581016479	CURRENT STRETCH SHAFT 81		01
02	0503030402	PULLEY		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503010406	501025 CLAMPING RING (FOR AXLE)		01
02	0502012819	17Z GEAR WITH HEX HOLE		01
03	0502011697	BEARING OF THE GEAR BOX		01
04	0503011410	ROLLER BEARING		01
05	0503011105	SEAL RING		01
06	0503010371	5/16" X 1" BOLT		02
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER		02
09	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0503016204	CORN DISK 12 ORANGE		01
02	0503016214	RING CORN (APOLLO740)		01
03	0503016218	DISC OF SOYBEAN		01
04	0503016220	RING TO SOYBEANS (APOLLO 745)		01
05	0503016221	RING TO SOYBEANS (APOLLO 571)		01
06	0503030558	PULLEY 4Z CORN PLASTIC		01
07	0502060001	PLASTIC PULLEY FOR MAIZE		01
08	0501050120	LARGER WALKING BEAM ASSY	44	01



Item	Code	Description	See page	QT
01	0503030379	LARGER ROCKER ARM		01
02	0502060001	PLASTIC PULLEY FOR MAIZE		01
03	0503010669	FLAT WASHER		01
04	0503010667	3/16" NUT		02
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		01



Item	Code	Description	See page	QT
01	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
02	0511018662	SPACING PLATE		02
03	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
04	0503010060	1/2" NUT		02
05	0503011440	SPRING WASHER		02
06	0511017969	0.1" SPACING PLATE		04
07	0503030483	FERTILIZER SOCKET		01
08	0561015595	FERTILIZER SOCKET		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
10	0501010984	FLAT WASHER		04
11	0503010025	3/8" SPRING WASHER		02
12	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0503030303	SUPPORT WASHER		02
02	0511065209	20Z GEAR		01
03	0521018630	1.4" X SQUARE 0.8" WASHER		03
04	0561013761	SQUARE SHAFT		01
05	0502011758	REAR TENSIONER LEVER		01
06	0503010292	0.2" X 1.6" SPRING PIN		01
07	0561016503	PRISONER 3/8 UNC		02
08	0503010209	3/8" UNC BUTTERFLY NUT		02
09	0501010984	FLAT WASHER		02
10	0561016521	RH CHAIN PROTECTION CAP		01
11	0503010027	5/8" SPRING WASHER		02
12	0503010013	5/8" NUT		02
13	1902011530	REST SUPPORT		01
14	0501011075	PIN		01
15	0503030012	HAIR PIN		01
16	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
17	0503013030	5/8" X 3.1/4" BOLT		01
18	0501011299	FLAT WASHER		02
19	0521068484	RODE SEED SUPPORT		01
20	0503060105	WELL AND TIRE ASSY	48	01
21	0501059313	AGRICULTURAL BEARING	49	02
22	0561016501	GLOVE 30,50		01
23	0501048790	AXLE WITH RING	50	01
24	0503010571	1/4" X 1.1/2 COTTERPIN		03
25	0501059985	RH WHEEL ARM	51	01
26	0521052375	BEARING SHAFT HEX 5/8 ASSY	53	01
27	0521068486	REST 726		01
28	0511050681	TRACTION SPRING		01
28A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
28B	0561016062	SPRING HITCH		02
29	0511067501	26Z GEAR		02



WHEEL SEED LAW

0521052348

Item	Code	Description	See page	QT
30	0503013253	40-1 X CHAIN X 116 LINK+REDECTION		01
31	0571015212	COUPLING SHAFT		01
32	0503030085	LOCK PIN		01
33	0501052777	CHAIN TENSIONER ASSY	57	01
34	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
35	0511051371	ASSY CURRENT TENSIONER	59	01




Item	Code	Description	See page	QT
01	0503030303	SUPPORT WASHER		02
02	0511065209	20Z GEAR		01
03	0521018630	1.4" X SQUARE 0.8" WASHER		03
04	0561013761	SQUARE SHAFT		01
05	0502011758	REAR TENSIONER LEVER		01
06	0503010292	0.2" X 1.6" SPRING PIN		01
07	0561016503	PRISONER 3/8 UNC		02
08	0503010209	3/8" UNC BUTTERFLY NUT		02
09	0501010984	FLAT WASHER		02
10	0561016522	LEFT CHAIN PROTECTION CAP		01
11	0503010027	5/8" SPRING WASHER		02
12	0503010013	5/8" NUT		02
13	1902011530	REST SUPPORT		01
14	0501011075	PIN		01
15	0503030012	HAIR PIN		01
16	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
17	0503013030	5/8" X 3.1/4" BOLT		01
18	0501011299	FLAT WASHER		02
19	0521068485	RODE FERTILIZER SUPPORT		01
20	0503060105	WELL AND TIRE ASSY	48	01
21	0501059313	AGRICULTURAL BEARING	49	02
22	0561016501	GLOVE 30,50		01
23	0501048790	AXLE WITH RING	50	01
24	0503010571	1/4" X 1.1/2 COTTERPIN		03
25	0501059986	LEFT WHEEL ARM	52	01
26	0521052347	BEARING TRANSMISSION ASSY DOUBLE	55	01
27	0521068486	REST 726		01
28	0511050681	TRACTION SPRING		01
28A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
28B	0561016062	SPRING HITCH		02
29	0511067501	26Z GEAR		02


**WHEEL LEFT FERTILIZER**

0521052349


Item	Code	Description	See page	QT
30	0503013253	40-1 X CHAIN X 116 LINK+REDECTION		01
31	0571015212	COUPLING SHAFT		01
32	0503030085	LOCK PIN		01
33	0501052779	CHAIN TENSIONER ASSY	58	01
34	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
35	0511051371	ASSY CURRENT TENSIONER	59	01
36	0503010025	3/8" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0503011010	CANVAS TIRE		01
02	0503010791	AR F 15 INNER TIRE		01
03	0503010789	0.2"J X 15H2" X0.2"F X0.6"X6" WHEEL		01



Item	Code	Description	See page	QT
01	0521060912	CARRYING-WHEELS OF THE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01
04	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0521061660	RH WHEEL ARM		01
02	0561013765	SLEEVE WEELS		02
03	0521061662	WHEELED AXLE		01
04	0501010127	9/16" X 1-7/8" LUG BOLT		04
05	0503013170	ROLLER BEARING		02
06	0561016502	GUARD POWDER		02
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0503010003	1845 GREASE FITTING		01
09	0503010002	1800 GREASE FITTING		02

LEFT WHEEL ARM


0501059986




Item	Code	Description	See page	QT
01	0521061661	LH WHEEL ARM		01
02	0561013765	SLEEVE WEELS		02
03	0521061662	WHEELED AXLE		01
04	0501010127	9/16" X 1-7/8" LUG BOLT		04
05	0503013170	ROLLER BEARING		02
06	0561016502	GUARD POWDER		02
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0503010004	1890 GREASE FITTING		01
09	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0501059363	5/8" HEX AXLE BEARING	54	01
02	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0561014911	AXLE SLEEVE GUIDES HEX		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		02




Item	Code	Description	See page	QT
01	0501056450	5/8 DOUB BEARING SEED TRANSMISSION	56	01
02	0501010942	3/8" X 1-1/4" BOLT		02
03	0501013518	FLAT WASHER		02
04	0503010025	3/8" SPRING WASHER		02
05	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0511061795	CHAIN TENSIONER		01
02	0503031366	RIGHT TWISTED SPRING RECAMBIO		01
03	0503031805	11Z 1/2" GEAR		02
04	0503010302	501019 SEAL RING		02




Item	Code	Description	See page	QT
01	0511061795	CHAIN TENSIONER		01
02	0503031367	SPRING		01
03	0503031805	11Z 1/2" GEAR		02
04	0503010302	501019 SEAL RING		02




Item	Code	Description	See page	QT
01	0561013049	CHAIN TIGHTENER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0501013519	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0581016497	SQUARE AXLE 3/4 X 1700 - 2200	01	
02	0531012714	HEX AXLE	01	
03	0521010691	AXLE FASTENER	04	
04	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN	04	
05	0511017303	FLAT WASHER	04	
06	0503010143	1/4" SPRING WASHER	04	
07	0503010144	1/4" NUT	04	
08	0511065209	20Z GEAR	01	
09	0521018630	1.4" X SQUARE 0.8" WASHER	03	
10	0503011076	40-1 X 2.87 CHAIN LINK + MENDING	01	
11	0521065328	20Z GEAR WITH HOLE SHAFT HEX 16.5	01	
12	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN	02	
13	0521011859	FLAT WASHER	01	
14	0502040534	SPRING GUIDE BUSHING LOCK	01	
15	0501018535	1/2 X 1 BOLT	01	
16	0503014911	40-1 X 63 CHAIN LINK + MENDING	01	




Item	Code	Description	See page	QT
01	0581016454	SQUARE AXLE 3/4 X 2200 - 2700	01	
02	0571013540	5/8" X 85" HEX AXLE	01	
03	0521010691	AXLE FASTENER	04	
04	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN	04	
05	0511017303	FLAT WASHER	04	
06	0503010143	1/4" SPRING WASHER	04	
07	0503010144	1/4" NUT	04	
08	0511065209	20Z GEAR	01	
09	0521018630	1.4" X SQUARE 0.8" WASHER	03	
10	0503011076	40-1 X 2.87 CHAIN LINK + MENDING	01	
11	0521065328	20Z GEAR WITH HOLE SHAFT HEX 16.5	01	
12	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN	02	
13	0521011859	FLAT WASHER	01	
14	0502040534	SPRING GUIDE BUSHING LOCK	01	
15	0501018535	1/2 X 1 BOLT	01	
16	0503014911	40-1 X 63 CHAIN LINK + MENDING	01	




Item	Code	Description	See page	QT
01	0581016498	SQUARE AXLE 3/4 X 2700 - 3200	01	
02	0571017427	5/8" X 2700 HEX AXLE	01	
03	0521010691	AXLE FASTENER	04	
04	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN	04	
05	0511017303	FLAT WASHER	04	
06	0503010143	1/4" SPRING WASHER	04	
07	0503010144	1/4" NUT	04	
08	0511065209	20Z GEAR	01	
09	0521018630	1.4" X SQUARE 0.8" WASHER	03	
10	0503011076	40-1 X 2.87 CHAIN LINK + MENDING	01	
11	0521065328	20Z GEAR WITH HOLE SHAFT HEX 16.5	01	
12	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN	02	
13	0521011859	FLAT WASHER	01	
14	0502040534	SPRING GUIDE BUSHING LOCK	01	
15	0501018535	1/2 X 1 BOLT	01	
16	0503014911	40-1 X 63 CHAIN LINK + MENDING	01	




Item	Code	Description	See page	QT
01	0581016434	PLATFORM 2200		01
02	0503010237	3/8" X 1" BOLT		04
03	0501010942	3/8" X 1-1/4" BOLT		04
04	0501010984	FLAT WASHER		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0581016435	PLATFORM 2700		01
02	0503010237	3/8" X 1" BOLT		08
03	0501010942	3/8" X 1-1/4" BOLT		04
04	0501010984	FLAT WASHER		12
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0581016424	PLATFORM 3200		01
02	0503010237	3/8" X 1" BOLT		10
03	0501010942	3/8" X 1-1/4" BOLT		04
04	0501010984	FLAT WASHER		14
05	0503010025	3/8" SPRING WASHER		14
06	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521052649	HANDRAIL REAR 2200	69	01
02	0521052651	HANDRAIL FRONT 2200	72	01
03	0501010942	3/8" X 1-1/4" BOLT		10
04	0501010984	FLAT WASHER		10
05	0503010025	3/8" SPRING WASHER		10
06	0503010026	3/8" NUT		10




Item	Code	Description	See page	QT
01	0521052632	HANDRAIL REAR 2700	70	01
02	0521052633	HANDRAIL FRONT 2700	73	01
03	0501010942	3/8" X 1-1/4" BOLT		10
04	0501010984	FLAT WASHER		10
05	0503010025	3/8" SPRING WASHER		10
06	0503010026	3/8" NUT		10




Item	Code	Description	See page	QT
01	0521052650	HANDRAIL REAR 3200	71	01
02	0521052652	HANDRAIL FRONT 3200	74	01
03	0501010942	3/8" X 1-1/4" BOLT		10
04	0501010984	FLAT WASHER		10
05	0503010025	3/8" SPRING WASHER		10
06	0503010026	3/8" NUT		10




Item	Code	Description	See page	QT
01	0511059383	HANDRAIL INTERNAL FIXER	75	06
02	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	76	02
03	0521068478	REAR HITCH FIXER		02
04	0581016502	TUBE 33,70 X 27,00 X 600		04
05	0581016461	BAR U 20 X 125 X 1030 X 2,00		01
06	0551019884	45 X 50 X 3/8 FASTENER		02
07	0501013518	FLAT WASHER		04
08	0503013357	3/8" SELF-ADJUSTING NUT		04
09	0581012718	HANDRAIL		04
10	0581016492	TUBE 33,70 X 27,00 X 2185 FRAME 2200		02




Item	Code	Description	See page	QT
01	0511059383	HANDRAIL INTERNAL FIXER	75	06
02	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	76	02
03	0521068478	REAR HITCH FIXER		02
04	0581016502	TUBE 33,70 X 27,00 X 600		04
05	0581016461	BAR U 20 X 125 X 1030 X 2,00		01
06	0551019884	45 X 50 X 3/8 FASTENER		02
07	0501013518	FLAT WASHER		04
08	0503013357	3/8" SELF-ADJUSTING NUT		04
09	0581012718	HANDRAIL		04
10	0581016430	TUBE 33,70 X 27,00 X 2685 FRAME 2700		02




Item	Code	Description	See page	QT
01	0511059383	HANDRAIL INTERNAL FIXER	75	06
02	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	76	02
03	0521068478	REAR HITCH FIXER		02
04	0581016502	TUBE 33,70 X 27,00 X 600		04
05	0581016461	BAR U 20 X 125 X 1030 X 2,00		01
06	0551019884	45 X 50 X 3/8 FASTENER		02
07	0501013518	FLAT WASHER		04
08	0503013357	3/8" SELF-ADJUSTING NUT		04
09	0581012718	HANDRAIL		04
10	0581016492	TUBE 33,70 X 27,00 X 2185 FRAME 2200		02




Item	Code	Description	See page	QT
01	0581016492	TUBE 33,70 X 27,00 X 2185 FRAME 2200		01
02	0511059383	HANDRAIL INTERNAL FIXER	75	02
03	0581012718	HANDRAIL		02
04	0521068479	LATERAL CORRIENTE DELANTERO		02




Item	Code	Description	See page	QT
01	0581016430	TUBE 33,70 X 27,00 X 2685 FRAME 2700		01
02	0511059383	HANDRAIL INTERNAL FIXER	75	02
03	0581012718	HANDRAIL		02
04	0521068479	LATERAL CORRIENTE DELANTERO		02



Item	Code	Description	See page	QT
01	0511059383	HANDRAIL INTERNAL FIXER	75	08
02	0581012718	HANDRAIL		02
03	0521068479	LATERAL CORRIENTE DELANTERO		02
04	0581016490	TUBE 33,70 X 27,00 X 3052 FRAME 3200		01
05	0581016447	TUBE 33,70 X 27,00 X 3185 FRAME 3200		01
06	0581016423	TUBE 33,70 X 27,00 X 350 FRAME 3200		02




Item	Code	Description	See page	QT
01	0502012857	EXTERNAL FIXER HANDRAIL		01
02	0502012858	INTERNAL FIXER HANDRAIL		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		01
04	0503015490	SELF-LOCKING NUT 7/16		01




Item	Code	Description	See page	QT
01	0502012855	CENTRAL FIXER		01
02	0502012856	CENTRAL FIXER		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		02
04	0503015490	SELF-LOCKING NUT 7/16		02

ASSY LOWER HITCH


0521052463



Item	Code	Description	See page	QT
01	0521068482	HITCH LOWER		02
02	1902012330	FIXER SUPPORT ARTICULATED		02
03	0503010797	3/4" X 4" BOLT		04
04	0501010941	FLAT WASHER		04
05	0503010023	3/4" SPRING WASHER		04
06	0503010014	3/4" NUT		04
07	0521010594	1.1" X 4.1" COUPLING SHAFT		02
08	0503030119	LOCK PIN		02



Item	Code	Description	See page	QT
01	0521060881	GEAR 14Z		02
02	0511061757	18Z GEAR		02
03	0521060880	GEAR 22 TEETH		02
04	0511065366	GEAR 30Z P 12.7		02
05	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		02
06	0521060879	38Z GEAR		02
07	0503030085	LOCK PIN		02



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

