

PARTS CATALOGUE

ROW CROP PLANTERS

Code:

0501092542

Product:

USAP SUPREMA PRECISION PLANTING - 45 LINES/SPACING 450 -
CSC/APT

**Series:**

S-0118

Revision:

00

Date Revision:

JULHO/2019

PRODUCTS



Code	Description
0111440116	USAP SUP PP 45E450 CSC ESPECIAL S-0118

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.



MARCHESAN

INDEX

0909095369	FRAME ASSY	1
0909095370	FRAME RIGHT SIDE ASSY	2
0909095371	ASSY CENTRAL FRAME	3
0909095372	LEFT SIDE FRAME ASSY	4
0909095373	SEED LINE / ASSY FERTILIZER	5
0521053863	TELESCOPIC HEADER 1210 WITH FIXATIONS	6
0521054520	TELESCOPIC 9000 WITH LATCH	7
0521051435	PANTOGRAPHY HEADER	8
0511058228	HYDRAULIC CYLINDER DRAWBAR HYDRAULIC	9
0511052507	FRONT SUPPORT ASSY HOSES	10
0521053862	FRENCH HAND RIGHT ASSY 7545	11
0521053849	FRENCH HAND LEFT ASSY 7545	12
0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	13
0511051299	ROTATING RIGHT AXIS EXTENSOR	14
0501059876	ROTATING LEFT AXIS EXTENSOR	15
0521051438	HEADER 3 POINTS ASSY	16
0511052052	TRANSPORT SUPPORT ASSY FRAME 20900	17
0521052138	LADDER REAR	18
0511052457	REAR SIDE HANDRAIL LADDER	19
0511052499	HANDRAIL LADDER BACK RIGHT CENTRAL FRAME	20
0511059383	INTERNAL FIXER ASSY HANDLE	21
0521053046	SIDE WHEEL WITHOUT TRANSMISSION LARGER	22
0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	23
0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE	24
0511058240	HYDRAULIC CYLINDER	25
0521054003	SEED BOX 30/17 SIDE RIGHT SIDE	26
0521053871	SIDE SUPPORT GREATER FIXING	27
0521053173	CENTRAL SEED BOX 15 EXITS	28
0503062687	BOX SEED	29
0503062686	FULL COVER	30
0521053175	BASE CSC BOX 15 OUTPUTS	31
0521053991	SIDE PLATFORM CSCP FRAME 7770	32
0521053858	SUPPORT SIDE PLATFORM ASSY	33
0521052175	SUPPORT PLATFORM ASSY	34
0511053320	ASSY SIDE LADDER	35
0521054001	RIGHT SIDE HANDRAIL 7770 CSCP	36
0521053860	FRONT SIDE HANDRAIL 1173	37
0521053870	FRONT SIDE HANDRAIL 2851	38
0521053869	FRONT SIDE HANDRAIL 2302	39
0521053868	FRONT SIDE HANDRAIL 1544	40
0521052136	FRONT SIDE HANDRAIL 2235	41
0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	42
0511059821	FIXER ASSY FRONT SIDE HANDLE CSCP	43
0521053989	HEX AXLE SIDE ASSY 45E450 CSC	44
0521054000	TURBINE HYDRAULIC ASSY GREATEST RIGHT CSCP	45
0521053861	SUPPORT TURBINE ASSY SIDE	46
0521045392	HYDRAULIC TURBINE WITH SCREEN	47
0501054983	NIPPLE HIDRAULIC MOTOR	48
0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE	49
0521053960	HOSE WITH JUNCTION	50
0521053068	MOTOR SUPPORT APT ASSY	51
0511052600	STRETCHER HYDRAULIC MOTOR SUPPORT	52
0521054002	ASSEMBLY DUTY AIR SIDE RIGHT 45E450 CSCP	53
0521053856	17 SIDE AIR CONDUCTOR BOCAS 7453	54
0521052152	REAR CENTRAL AIR CONDUCTOR 1520	55



MARCHESAN

INDEX


0521053867	ASSY AIR CONDUCTOR SUPPORT	56
0511057646	ASSY AIR CONDUCTOR SUPPORT	57
0521052549	CLAMP	58
0521052168	SEED HOSE GUIDE	59
0521053850	ASSY FRONT AIR CONDUCTOR SUPPORT	60
0521053999	ASSEMBLY DUTY AIR SIDE RIGHT 45E450 CSCP APT	61
0521053992	FRAME 7770 SIDE GUTTER ASSEMBLY	62
0511057011	SUPPORT GUTTER ASSY	63
0521053859	TURBINE PRECISION PLANTING SIDE FRAME ASSY LARGER	64
0511059406	TURBINE PRECISION PLANTING MOUNTED	65
0521050154	TURBINE PRECISION PLANTING WITH HOLE	66
0521050332	VACUOMETER WITH ASSY SUPPORT	67
0521053223	CENTRAL FRAME 4686 WITH FIXER	68
0521053207	INTERNAL PLATE WITH FIXATION SCREW 1/2	69
0521052189	38,10X63,50X386X148 HYDRAULIC CYLINDER	70
0521054013	SEED 15/11 OUTPUTS CENTRAL CASH	71
0521052156	ASSY CENTRAL SUPPORT	72
0521053766	REAR PLATFORM BASE ASSY	73
0521052154	ASSY REAR LADDER PLATFORM	74
0521052140	HANDRAIL SIDE FRAME CENTRAL	75
0521052174	LANTERN WITH SUPPORT	76
0521053058	ARM JOINT RIGHT ASSY	77
0521053057	ARM JOINT LEFT ASSY	78
0521053038	CENTRAL WHEEL 385 WITHOUT RIGHT TRANSMISSION	79
0521053036	CENTRAL WHEEL 385 WITHOUT GREATER TRANSMISSION	80
0521053037	TIRE WITH WHEEL 15 X 19,50 14 LONAS	81
0521053040	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION LARGER	82
0521053212	FRAME 22500 ARTICULATED ARM CYLINDER ASSY	83
0511058761	HYDRAULIC CYLINDER	84
0521054015	CENTRAL TROUGH ASSEMBLY 45645 CSC APT FRAME 4686	85
0521054016	ADHESIVE STICKER ASSY 45L CSC APT	86
0521053067	ASSY SENSOR LEVANTE APT WHEELSET MAJOR	87
0511059814	TELESCOPIC LOCK ASSY	88
0511052388	REST GREATER ASSY	89
0511053121	GREATER TOOL BOX ASSY	90
0521055004	ELECTRICAL SYSTEM HEADLIGHT / LANTERN USAP APT 19M BCE	91
0521053944	SUPPORT WITH DIVIDER BLOCK FLOW TO 05 TURBINES	92
0521055356	FLUX DIVIDER BLOCK FOR 03 TURBINES	93
0521054011	CENTRAL ASSY HEX AXLE	94
0521051436	BOX ECU APT TVT WITH CHANGE	95
0521054024	HYDRAULIC ASSEMBLY CSC 45E450 FRAME 20226 APT	96
0521054022	CENTRAL DUCT ASSEMBLY 45E45	97
0521053537	CENTRAL REAR DUCT SUPPORT	98
0521055280	CENTRAL BLOCK SUPPORT WITH FIXATION	99
0521055201	DIVIDER VALVE TRIPLE (17,163,025,002) WITH NIPPLES	100
0521054020	ASSY HOSE ARTICULATED CSC FRAME 20226	101
0521054018	ASSY HEAD HOSE CSC FRAME 20226	102
0521054021	HOSE KIT LEVANTE CSC FRAME 20226	103
0521054510	ASSY HOSE 5 TURBINES PRECISION PLANTING TATU CSC FRAME 22422	104
0521054012	ASSY HOSE APT FRAME 20226	105
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	106
0521054026	ELECTRIC ASSEMBLY ISOBUS 18590/22500 CSC	107
0521053672	LIGHTHOUSE ASSY	108




MARCHESAN

INDEX

0521054014	ASSY AIR DUCT CENTRAL CSC FRAME 4686	109
0521053846	CONDUCTOR AR CENTRAL 11 BOCAS SPACING 450	110
0521051096	REAR CENTRAL AIR CONDUCTOR 1120 CSCP	111
0521053530	REAR CENTRAL AIR CONDUCTOR 1400 CSC	112
0521051092	AIR CONDUCTOR ASSY SUPPORT CSCP	113
0521050785	SUPPORT CONDUCTOR AIR ASSY	114
0521054028	ASSY ISOBUS 45 LINES/45 MONITOR WITH SEED	115
0503062918	KIT INTELLIAG 45 LINES/45 WITH MONITOR E 010080934	116
0521050826	BLOCK LIMITATION ASSY FLOW	117
0511056973	PARKER OMP 80 HYDRAULIC MOTOR WITH VALVE	118
0511056972	FILTER HYDAC	119
0521053296	AXIS ARTICULATOR	120
0521053990	SEED BOX 30/17 SIDE LEFT SIDE	121
0521053993	LEFT SIDE HANDRAIL 7770 CSCP	122
0521052135	LEFT SIDE HANDRAIL 2235	123
0521053995	TURBINE HYDRAULIC ASSY GREATEST LEFT CSCP	124
0521053852	SUPPORT LARGEST TURBINE AIR POSITIVE ASSY	125
0521053988	ASSEMBLY DUTY AIR SIDE LEFT 45E450 CSCP APT	126
0521053851	17 SIDE AIR CONDUCTOR BOCAS 7418	127
0521053994	ASSEMBLY DUTY SIDE LEFT 45E450 CSCP APT	128
0521053025	DUCT SUPPORT OIL	129
0521052902	SHORT / RIGHT LINE	130
0521052901	LONG / LEFT LINE	131
0521052904	SHORT / RIGHT LINE (INTERNAL)	132
0521052262	FRONT SHORT SEED LINE	133
0521052261	FRONT LONG SEED LINE	134
0521052265	INTERNAL FRONT SHORT SEED LINE	135
0511057159	TRANSMISSION BOX SEED LINE	136
0511057223	SHORT TRANSMISSION ASSY AXLE	137
0511057224	LONG TRANSMISSION ASSY AXLE	138
0511057225	BEARING ASSY LINE FRONT	139
0501057684	SIDE BEARING FRONT SUPPORT SEED LINE	140
0501053566	BEARING SEED LINE	141
0521053343	REAR RIGHT PRECISION PLANTING	142
0521053345	LEFT REAR PRECISION PLANTING	143
0521053344	DOUBLE DISC RIGHT HIGH CUBE	144
0521053356	DOUBLE DISC LEFT HIGH CUBE	145
0501054167	BOX DDD ASSY DPL 15 RIGHT	146
0501054168	BOX DDD ASSY DPL 15 LEFT	147
0521051428	CUTTING DISC DPLE 20 TB 60E ASSY	148
0521051426	LOWER SUPPORT WITH DPLE 20 TB 60E	149
0521051425	BOX WITH CUT DISC DPLE20 TB 60E	150
0511056909	DISC BOX CUT WITHOUT THE DISC	151
0511059816	ASSY PRECISION PLANTING V-SET2 CSC	152
0511057491	PRECISION PLANTING SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	153
0511057503	CAJA DE TRANSMISIÓN DERECHA PRECISION PLANTING	154
0511059817	DEPOSIT SEED ASSY AIR POSITIVE	155
0521051424	WHEEL SYSTEM DEPTH / COMPACTOR QUICK ADJUSTMENT	156
0521052157	DEPTH ASSY QUICK REGULATOR	157
0501056769	DEPTH WHEELS REGULATOR ASSY	158
0521051423	COMPACTOR SUPPORT	159
0501052908	COMPACTOR WHEEL WITH BEARING	160
0511050077	WHEEL STRIPED	161
0511052287	DEPTH WHEEL HUB ASSY	162




Item	Code	Description	See page	QT
01	0909095370	FRAME RIGHT SIDE ASSY	2	01
02	0909095371	ASSY CENTRAL FRAME	3	01
03	0909095372	LEFT SIDE FRAME ASSY	4	01
04	0521053863	TELESCOPIC HEADER 1210 WITH FIXATIONS	6	01
05	0521068718	TRANSPORT LOCK 1250		01
06	0521054520	TELESCOPIC 9000 WITH LATCH	7	01
07	0521051435	PANTOGRAPHY HEADER	8	01
08	0521053862	FRENCH HAND RIGHT ASSY 7545	11	01
09	0521053849	FRENCH HAND LEFT ASSY 7545	12	01
10	0521051438	HEADER 3 POINTS ASSY	16	01
11	0511052052	TRANSPORT SUPPORT ASSY FRAME 20900	17	01
12	0521052138	LADDER REAR	18	01
13	0521068717	LOCK AXLE		01
14	0503030085	LOCK PIN		01
15	0501011445	FLAT WASHER		01



Item	Code	Description	See page	QT
00	0521048535	RIGHT SIDE FRAME		01
01	0501110912	FRAME RIGHT WITH GLOVE 7770		01
01A	0521069110	RIGHT SIDE FRAME 7770		01
01B	0581012179	DRIVER ROCKING SLEEVE		02
02	0521053046	SIDE WHEEL WITHOUT TRANSMISSION LARGER	22	02
03	0521054003	SEED BOX 30/17 SIDE RIGHT SIDE	26	01
04	0521053991	SIDE PLATFORM CSCP FRAME 7770	32	01
05	0511053320	ASSY SIDE LADDER	35	01
06	0521054001	RIGHT SIDE HANDRAIL 7770 CSCP	36	01
07	0521053989	HEX AXLE SIDE ASSY 45E450 CSC	44	01
08	0521054000	TURBINE HYDRAULIC ASSY GREATEST RIGHT CSCP	45	01
09	0521053068	MOTOR SUPPORT APT ASSY	51	01
10	0521054002	ASSEMBLY DUTY AIR SIDE RIGHT 45E450 CSCP	53	01
11	0521053999	ASSEMBLY DUTY AIR SIDE RIGHT 45E450 CSCP APT	61	01
12	0521053992	FRAME 7770 SIDE GUTTER ASSEMBLY	62	01
13	0521053859	TURBINE PRECISION PLANTING SIDE FRAME ASSY LARGER	64	01
14	0521050332	VACUOMETER WITH ASSY SUPPORT	67	02
15	0503015062	TUBE		02
16	0909095373	SEED LINE / ASSY FERTILIZER	5	01

ASSY CENTRAL FRAME

0909095371



Item	Code	Description	See page	QT
00	0521048533	CENTRAL FRAME		01
01	0521053223	CENTRAL FRAME 4686 WITH FIXER	68	01
02	0521054013	SEED 15/11 OUTPUTS CENTRAL CASH	71	01
03	0521053766	REAR PLATFORM BASE ASSY	73	01
04	0521053058	ARM JOINT RIGHT ASSY	77	01
05	0521053057	ARM JOINT LEFT ASSY	78	01
06	0521053038	CENTRAL WHEEL 385 WITHOUT RIGHT TRANSMISSION	79	02
07	0521053036	CENTRAL WHEEL 385 WITHOUT GREATER TRANSMISSION	80	02
08	0521053212	FRAME 22500 ARTICULATED ARM CYLINDER ASSY	83	01
09	0521054015	CENTRAL TROUGH ASSEMBLY 45645 CSC APT FRAME 4686	85	01
10	0521053068	MOTOR SUPPORT APT ASSY	51	01
11	0521054016	ADHESIVE STICKER ASSY 45L CSC APT	86	01
12	0511059406	TURBINE PRECISION PLANTING MOUNTED	65	01
13	0503010232	5/8" X 1.3/4" BOLT		02
14	0503010027	5/8" SPRING WASHER		02
15	0503010013	5/8" NUT		02
16	0521053067	ASSY SENSOR LEVANTE APT WHEELSET MAJOR	87	01
17	0511059814	TELESCOPIC LOCK ASSY	88	01
18	0511052388	REST GREATER ASSY	89	01
19	0511053121	GREATER TOOL BOX ASSY	90	01
20	0521055637	ASSY TRANSPORT LOCK		04
20A	0551018312	TRANSPORT LOCK		04
20B	0501068994	0.3" X 3.1" LOCK PIN		04
20C	0503030168	HAIR PIN		04
21	0561016793	FIXED WRENCH		01
22	0501047885	ROD STOP		08
23	0501047886	ROD STOP		08
24	0561017063	HOLDER TUBE		02


ASSY CENTRAL FRAME

0909095371


Item	Code	Description	See page	QT
25	0503014120	CHAIN		01
26	0503014321	CABLE STEEL SHACKLE		02
27	0511054256	COROT WATER		01
28	0521050332	VACUOMETER WITH ASSY SUPPORT	67	01
29	0503015062	TUBE		01
30	0521055004	ELECTRICAL SYSTEM HEADLIGHT / LANTERN USAP APT 19M BCE	91	01
31	0521053944	SUPPORT WITH DIVIDER BLOCK FLOW TO TURBINES	05 92	01
32	0521054011	CENTRAL ASSY HEX AXLE	94	01
33	0521051436	BOX ECU APT TVT WITH CHANGE	95	01
34	0521054024	HYDRAULIC ASSEMBLY CSC 45E450 FRAME APT	20226 96	01
35	0521054026	ELECTRIC ASSEMBLY ISOBUS 18590/22500 CSC	107	01
36	0521054014	ASSY AIR DUCT CENTRAL CSC FRAME 4686	109	01
37	0521054028	ASSY ISOBUS 45 LINES/45 MONITOR WITH SEED	115	01
38	0521053296	AXIS ARTICULATOR	120	01
39	0909095373	SEED LINE / ASSY FERTILIZER	5	01

LEFT SIDE FRAME ASSY

0909095372




Item	Code	Description	See page	QT
00	0521048534	LEFT SIDE FRAME		01
01	0501110911	LEFT FRAME WITH GLOVE 7770		01
01A	0521069109	LEFT SIDE FRAME 7770		01
01B	0581012179	DRIVER ROCKING SLEEVE		02
02	0521053046	SIDE WHEEL WITHOUT TRANSMISSION LARGER	22	02
03	0521053990	SEED BOX 30/17 SIDE LEFT SIDE	121	01
04	0521053991	SIDE PLATFORM CSCP FRAME 7770	32	01
05	0511053320	ASSY SIDE LADDER	35	01
06	0521053993	LEFT SIDE HANDRAIL 7770 CSCP	122	01
07	0521053989	HEX AXLE SIDE ASSY 45E450 CSC	44	01
08	0521053995	TURBINE HYDRAULIC ASSY GREATEST LEFT CSCP	124	01
09	0521053068	MOTOR SUPPORT APT ASSY	51	01
10	0521053988	ASSEMBLY DUTY AIR SIDE LEFT 45E450 CSCP APT	126	01
11	0521053994	ASSEMBLY DUTY SIDE LEFT 45E450 CSCP APT	128	01
12	0521053992	FRAME 7770 SIDE GUTTER ASSEMBLY	62	01
13	0521053859	TURBINE PRECISION PLANTING SIDE FRAME ASSY LARGER	64	01
14	0521050332	VACUOMETER WITH ASSY SUPPORT	67	02
15	0503015062	TUBE		02
16	0521053671	ASSEMBLY SUPPORT HIGHER PRESSURE FILTER		01
17	0909095373	SEED LINE / ASSY FERTILIZER	5	01




Item	Code	Description	See page	QT
01	0521052902	SHORT / RIGHT LINE	130	01
02	0521052901	LONG / LEFT LINE	131	01
03	0521052904	SHORT / RIGHT LINE (INTERNAL)	132	01
04	0521051428	CUTTING DISC DPLE 20 TB 60E ASSY	148	01
05	0511059816	ASSY PRECISION PLANTING V-SET2 CSC	152	01
06	0521051424	WHEEL SYSTEM DEPTH / COMPACTOR QUICK ADJUSTMENT	156	01
07	0521052157	DEPTH ASSY QUICK REGULATOR	157	01
08	0531013600	PRESS ADJUSTMENT LEVER		01
09	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
10	0503010184	CLAMP		01
11	0503010905	1/2" X 2-1/4" BOLT		01
12	0503010019	1/2" SPRING WASHER		01
13	0503010060	1/2" NUT		01

TELESCOPIC HEADER 1210 WITH FIXATIONS

0521053863




Item	Code	Description	See page	QT
01	0503010027	5/8" SPRING WASHER		04
02	0503010013	5/8" NUT		04
03	0503010002	1800 GREASE FITTING		02
04	0521051433	ATTACHMENT BAR REAR AXLE		02
04A	0511069442	ATTACHMENT BAR REAR AXLE		01
04B	0581014420	SLEVE GUIDE		02
04C	0503010038	3/16 X 2 COTTERPIN		01
04D	0501017779	32 X 60 X 4.75 FLAT WASHER		01
04E	0503011052	1.1/4" X 0.77" CASTLE NUT		01
05	0521069118	TELESCOPIC HEADER 1210		01
06	0501012140	FLAT WASHER		08
07	0503010233	5/8" X 2-1/2" BOLT		04
08	0503011052	1.1/4" X 0.77" CASTLE NUT		03
09	0521011688	FLAT WASHER		03
10	0521068715	1210 HEADER AXIS TELESCOPIC		02
11	0503010010	1/4" X 2.1/2" COTTERPIN		03
12	0521068716	AXIS HEADER TELESCOPIC WITHOUT GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521068723	INTERNAL CANUD EARS FIXING		01
02	0503010523	1/4" X 2" COTTERPIN		04
03	0521011132	FLAT WASHER		04
04	0571013059	PIVOT SHAFT LOCK		01
05	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
06	0511054270	TENSIONER SPRING		01
06A	0511069520	TELESC LOCK SPRING TENSIONER		01
06B	0503010013	5/8" NUT		02
07	0521068719	LOCK		01
08	0503010002	1800 GREASE FITTING		01
09	1902010477	UPPER CLAMP BODY		01
10	0503010180	7/16" SPRING WASHER		01
11	0503011135	7/16" X 1-1/2" BOLT		01

PANTOGRAPHY HEADER


0521051435




Item	Code	Description	See page	QT
01	0521062955	SEED ARM SUPPORT ROW		01
02	0501079585	ARM USAP		01
03	0521063433	EAR ARM PANTOGRAPH WITH LOOK		01
04	0521063434	EAR ARM PANTOGRAPH		01
05	0502040864	GEAR BOX		01
06	0521068007	TRACTOR HITCH		01
07	1902040327	LOCK SLEEVE		01
08	0521010578	COUPLING SHAFT		01
09	0503010523	1/4\" X 2\" COTTERPIN		01
10	0521063432	LOCK AXLE		02
11	0521063022	AXLE LOWER		04
12	0571011013	AXLE ARM		01
13	0503012198	3/16\" X 2\" COTTERPIN		07
14	0503010002	1800 GREASE FITTING		04
15	0501019435	32 X 50 X 1.5 FLAT WASHER		12
16	0503031035	HAIR PIN		02
17	0511058228	HYDRAULIC CYLINDER DRAWBAR HYDRAULIC	9	01
18	0511052507	FRONT SUPPORT ASSY HOSES	10	01
19	0501081848	HOSE 3/8 X 3200 TR-TM USAP		02
20	0503011052	1.1/4\" X 0.77\" CASTLE NUT		02
21	0501010307	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521062362	CYLINDER CASE		01
02	0521062361	ROD CILINDER DRAWBAR HYDRAULIC		01
03	0503010002	1800 GREASE FITTING		02
04	0503030384	CON PLUG N-001		02
05	0503010817	1.1/4" SELF LOCKING NUT		01
06	0503010345	2-218 N 3006-9B O'RING		01
07	0502010382	5" END CAP		01
08	0581010353	RING SUPPORT		01
09	0503018026	1870-2000-375 B GASKET		01
10	0503011453	O'RING		02
11	0503018152	O'RING		02
12	0503018024	RING BS		01
13	0503018025	RING GUIDE		01
14	0581010354	PISTON		01
15	0503018150	RING GUIDE		01
16	0503018151	RING BS		02
17	0503010039	D-2000 SCRAPER RING		01
18	0511032524	ASSY CYLINDER REPAIR KIT 50,8X127 USAP (0511058228)		01




Item	Code	Description	See page	QT
01	0521066319	FIXATION FRONT SUPPORT		01
02	0503010019	1/2" SPRING WASHER		01
03	0503014007	1/2" X 1-1/4" BOLT		01




Item	Code	Description	See page	QT
01	0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	13	01
02	0503010180	7/16" SPRING WASHER		20
03	1902010477	UPPER CLAMP BODY		20
04	0503011135	7/16" X 1-1/2" BOLT		20
05	0503010002	1800 GREASE FITTING		01
06	0521068724	FRENCH HAND 7545		01
07	0511051299	ROTATING RIGHT AXIS EXTENSOR	14	01
08	0501082208	HOSE 3/4 X 180 TR-TR		02
09	0501082189	HOSE 1/2 X 160 TR-TR		05
10	0501082190	HOSE 3/8 X 160 TR-TR		01
11	0521069203	OIL DUCT R.1.1 / 16 X 3230		04
12	0521069202	OIL DUCT R.7/8 X 3230		10
13	0521069201	OIL DUCT R.3/4 X 3230		02




Item	Code	Description	See page	QT
01	0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	13	01
02	0503010180	7/16" SPRING WASHER		20
03	1902010477	UPPER CLAMP BODY		30
04	0503011135	7/16" X 1-1/2" BOLT		15
05	0501012803	FLAT WASHER		05
06	0581017304	FRENCH HAND CHUTE 20 X 38 X 2180		03
07	0503010002	1800 GREASE FITTING		01
08	0521068724	FRENCH HAND 7545		01
09	0521053050	ASSY RAIL GUIDE		02
09A	0571011891	GUIDE RAIL		01
09B	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
09C	0503010179	5/16" ZN SPRING WASHER		02
09D	0503010337	5/16" NUT		02
09E	0503011952	5/16" X 3/4" BOLT		02
10	0501059876	ROTATING LEFT AXIS EXTENSOR	15	01
11	0503011103	7/16" X 2-1/2" BOLT		05
12	0521069201	OIL DUCT R.3/4 X 3230		06
13	0521069202	OIL DUCT R.7/8 X 3230		14
14	0501082189	HOSE 1/2 X 160 TR-TR		07
15	0501082190	HOSE 3/8 X 160 TR-TR		03



Item	Code	Description	See page	QT
01	0521062244	PIVOT SHAFT		01
02	0551019529	FLAT WASHER		01
03	0503010027	5/8" SPRING WASHER		01
04	0503011267	5/8" X 1.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0521062617	NUT FIXER		01
02	0503010002	1800 GREASE FITTING		02
03	0501078990	TURNBUCLE AXLE		01
04	0561019879	LOCK ATTACHMENT BAR		01




Item	Code	Description	See page	QT
01	0501078991	NUT FIXER		01
02	0503010002	1800 GREASE FITTING		02
03	0501078990	TURNBUCLE AXLE		01
04	0561019879	LOCK ATTACHMENT BAR		01

HEADER 3 POINTS ASSY

0521051438




Item	Code	Description	See page	QT
01	0561013456	GUIDE DRAWBAR ASSY		02
02	0501010276	1" X 3" BOLT		04
03	0503010012	1" SPRING WASHER		04
04	0501010059	1.5/8 NUT		04
05	0503030119	LOCK PIN		02
06	0511069471	PLOUGH SUPPORT		02
07	0501011075	PIN		02
08	0503030285	HAIR PIN		02
09	0521068020	DRAWBAR ASSY		01
10	0503030085	LOCK PIN		04
11	0521068018	UPPER AXLE		01
12	0521068015	UPPER AXLE		01
13	0521068013	UPPER AXLE		01
14	0521068011	AXLE LOWER		02
15	0521068010	HITCH AXLE		01
16	0521068009	UPPER AXLE		01
17	0503031035	HAIR PIN		01



Item	Code	Description	See page	QT
01	0521063339	HIGHER		06
02	0571011070	5/8" UNC FASTENER		06
03	0503010027	5/8" SPRING WASHER		12
04	0503010013	5/8" NUT		12

LADDER REAR


0521052138




Item	Code	Description	See page	QT
01	0581015998	CSCP REAR SIDE STAIR		02
02	0521064790	DEGRAU 600 USAP CXC		04
03	0503010025	3/8" SPRING WASHER		16
04	0503010026	3/8" NUT		16
05	0503010237	3/8" X 1" BOLT		16
06	0511052457	REAR SIDE HANDRAIL LADDER	19	01
07	0511052499	HANDRAIL LADDER BACK RIGHT CENTRAL FRAME	20	01
08	0503010395	1/2" X 1-1/4" BOLT		04
09	0503010589	1/2" UNC SELF ADJUSTING NUT		04

REAR SIDE HANDRAIL LADDER

0511052457




Item	Code	Description	See page	QT
01	0581012741	SIDE HANDRAIL BODY (1113) CSCP		01
02	0511059383	INTERNAL FIXER ASSY HANDLE	21	06
03	0581012748	BODY LARGER LADDER REAR		02
04	0581012742	SIDE HANDRAIL BODY		01
05	0581012744	REINFORCEMENT REAR SIDE HANDRAIL		01
06	0581012718	HANDRAIL		02
07	0581014429	SHIM HANDRAIL		02
08	0503011179	3/8" X 2-1/4" BOLT		04
09	0503013357	3/8" SELF-ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0581012741	SIDE HANDRAIL BODY (1113) CSCP		01
02	0511059383	INTERNAL FIXER ASSY HANDLE	21	06
03	0581012748	BODY LARGER LADDER REAR		02
04	0581012742	SIDE HANDRAIL BODY		01
05	0581012744	REINFORCEMENT REAR SIDE HANDRAIL		01
06	0581012718	HANDRAIL		02
07	0581014429	SHIM HANDRAIL		02
08	0503010025	3/8" SPRING WASHER		04
09	0503010026	3/8" NUT		04
10	0503011179	3/8" X 2-1/4" BOLT		04

INTERNAL FIXER ASSY HANDLE

0511059383




Item	Code	Description	See page	QT
01	0502012857	OUTER FIXER		01
02	0502012858	INNER FIXER		01
03	0503019083	7/16" X 2.1/4" BOLT		01
04	0503015490	NUT AUTOFREN 7/16 NC		01




Item	Code	Description	See page	QT
01	0521068721	FORK WHEELED HIGHER SIDE		01
02	0521064573	LARGER SUPPORT		01
03	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
04	0561019929	FLAT WASHER		01
05	0503011345	1/4" X 3-1/2" COTTERPIN		01
06	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
07	0551014508	FLAT WASHER		01
08	0503010010	1/4" X 2.1/2" COTTERPIN		02
09	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
10	0503010920	1/2" X 1.1/2" BOLT		04
11	0503010019	1/2" SPRING WASHER		04
12	0503010060	1/2" NUT		04
13	0503010067	3/16" X 2.1/2" COTTER PIN		01
14	0502012731	CATCH RODEIRO		02
15	0501010322	FLAT WASHER		04
16	0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	23	01
17	0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE	24	01
18	0503011052	1.1/4" X 0.77" CASTLE NUT		02
19	0501017779	32 X 60 X 4.75 FLAT WASHER		02
20	0511058240	HYDRAULIC CYLINDER	25	01
21	0501010630	1.1/2" CASTLE NUT		01
22	0503010003	1845 GREASE FITTING		03
23	0503010882	5/16" X 2" BOLT		01
24	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
25	0503033458	CURRENT 6 X 17 ELOS		01
26	0503010337	5/16" NUT		01
27	0521068341	WHEEL LIFT SHAFT		01
28	0501018466	FLAT WASHER		01
29	0503010023	3/4" SPRING WASHER		04
30	0503019245	SCREW 3/4 UNC X 4 C S R P G.8 ZN		02
31	0503019247	NUT 3/4 NC S G.8		04



Item	Code	Description	See page	QT
32	0503019246	BOLT		02




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503010007	3982/3920 ROLLER BEARING		01
04	0503010059	33287/33462 ROLLER BEARING		01
05	0503010009	RETAINER 00573-B		01
06	0503010086	SEAL 0009B-B		01
07	0551014473	SPACING SLEEVE HUB		01
08	0503012702	KM-12 NUT		02
09	0503012703	LOCK WASHER		01
10	0503010002	1800 GREASE FITTING		01
11	0503011444	SPRING WASHER		04
12	0503011339	M22 X 1,5 X 72 BOLT		08
13	0503014048	22 X 1.5 HEX NUT		08
14	0503010363	5/16" X 1" BOLT		04
15	0511068415	PFFP-3770 SEAL GUIDE		01




Item	Code	Description	See page	QT
01	0511065331	11.75 X 17.5 HOOP WHEEL		01
02	0503015355	INNER TIRE		01
03	0503013247	PLY TIRE		01

HYDRAULIC CYLINDER


0511058240




Item	Code	Description	See page	QT
01	0521066557	CYLINDER CASE 101,60 X 352 USAP		01
02	0581010680	TURNBUCKLE 50,80 X 386 USAP		01
03	0571015629	CILINDER SPINDLE FORK		01
04	0503010817	1.1/4" SELF LOCKING NUT		01
05	0503010345	2-218 N 3006-9B O'RING		01
06	0503011094	3/8" X 2" BOLT		01
07	0503010026	3/8" NUT		01
08	0503010025	3/8" SPRING WASHER		01
09	0503030385	CYLINDER PLUG N-002		02
10	0503015633	SELEMASTER SEALING		01
11	0581010678	50,80 X 101 RING SUPPORT		01
12	0503015636	SCRAPER SEAL		01
13	0503018025	RING GUIDE		01
14	0503018026	1870-2000-375 B GASKET		01
15	0503010338	2-342 N 3006-9B O'RING		02
16	0503011061	8-342 BACK-UP RING		02
17	0502012822	101.60 END CAP		01
18	0502012820	50.80 X 101.60 PISTON		01
19	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01



Item	Code	Description	See page	QT
01	0521053871	SIDE SUPPORT GREATER FIXING	27	02
02	0521053173	CENTRAL SEED BOX 15 EXITS	28	02
03	1164920015	BLACK SUCTION HOSE		25mts
04	0503034345	AIR DISPENSER COVER		13
05	0503010184	CLAMP		30




Item	Code	Description	See page	QT
01	0501011643	3/8 X 1"BOLT	16	
02	0501010984	FLAT WASHER	24	
03	0503013357	3/8" SELF-ADJUSTING NUT	16	
04	0581012237	SEAL BOX FIXER	02	
05	0581012245	SEAL BOX SHOULDER	02	
06	0503010025	3/8" SPRING WASHER	04	
07	0503010026	3/8" NUT	04	
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04	
09	0521067113	SEED BOX SIDE SUPPORT	01	
10	0503010027	5/8" SPRING WASHER	08	
11	0501012140	FLAT WASHER	08	
12	0503010013	5/8" NUT	08	
13	0571011070	5/8" UNC FASTENER	04	
14	0581016040	LOWER SUPPORT CASH SEED	04	




Item	Code	Description	See page	QT
01	0521068977	TUBE AR 15 OUTPUTS		01
02	0521053175	BASE CSC BOX 15 OUTPUTS	31	01
03	0501010984	FLAT WASHER		26
04	0503015075	M10 SPRING WASHER		26
05	0503010025	3/8" SPRING WASHER		08
06	0503010172	M10 X 1,5 X 25 BOLT		26
07	0503062687	BOX SEED	29	01
08	0503019284	M8 X BOLT		04
09	0503010849	3/8" X 1-1/2" BOLT		08
10	0581017922	WASHER		04

BOX SEED


0503062687




Item	Code	Description	See page	QT
001	0503034538	BOX SEED		01
002	0503034539	GREASE SEAL		01
003	0503062686	FULL COVER	30	01
004	0503034387	FLAT WASHER		36
005	0503011841	M10 SELF ADJUSTING NUT		18
006	0503034388	M10 X 1,5 X 25 BOLT		18



Item	Code	Description	See page	QT
001	0503034540	RING SLYDRING		01
002	0503034541	PIVOT ARM		01
003	0503034542	COVER		01
004	0503034390	AXLE WASHER BLADE		02
005	0503010302	501019 SEAL RING		02
006	0503034543	ARM ARTICULACCION ALXE		01
007	0503034305	COVER SHAFT		01
008	0503034391	M8 X BOLT		02
009	0503034544	SEAL RING		01
010	0503034562	COVER		01




Item	Code	Description	See page	QT
01	0521068978	CASH FUND COVER		03
02	0503015135	FLAT WASHER 10 X 18 X 2		06
03	0503011823	0.1" X 0.6" SPRING PIN		06
04	0521068851	SYSTEM ASSY		01
05	0503034571	SEALING		01
06	0503034573	SEALING		03
07	0581017529	VARAO 9.53		03
08	0503062759	SEALING		03
09	0503034692	FAST LOCK ASSY		06
10	0503030085	LOCK PIN		06
11	0503019290	BOLT		24




Item	Code	Description	See page	QT
01	0581018239	PLATFORM 1720		01
02	0581017737	PLATFORM 2570		02
03	0521053858	SUPPORT SIDE PLATFORM ASSY	33	03
04	0521052175	SUPPORT PLATFORM ASSY	34	04

SUPPORT SIDE PLATFORM ASSY

0521053858




Item	Code	Description	See page	QT
01	0521067275	SIDE CHASSIS PLATFORM SUPPORT		01
02	0571011070	5/8" UNC FASTENER		02
03	0501012140	FLAT WASHER		04
04	0503010027	5/8" SPRING WASHER		04
05	0503010013	5/8" NUT		04
06	0511017302	FLAT WASHER		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2" NUT		01
09	0503010920	1/2" X 1.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0581016058	PLATFORM SUPPORT		01
02	0511017302	FLAT WASHER		01
03	0503010060	1/2" NUT		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010920	1/2" X 1.1/2" BOLT		01
06	0503010395	1/2" X 1-1/4" BOLT		05
07	0503010589	1/2" UNC SELF ADJUSTING NUT		05

ASSY SIDE LADDER


0511053320




Item	Code	Description	See page	QT
01	0511069819	SIDE LADDER		01
02	0502012742	FIXER SUPPORT LADDER		02
03	0503013357	3/8" SELF-ADJUSTING NUT		02
04	0501010984	FLAT WASHER		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0503010237	3/8" X 1" BOLT		04
07	0503010025	3/8" SPRING WASHER		04
08	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521053860	FRONT SIDE HANDRAIL 1173	37	01
02	0521053870	FRONT SIDE HANDRAIL 2851	38	01
03	0521053869	FRONT SIDE HANDRAIL 2302	39	01
04	0521053868	FRONT SIDE HANDRAIL 1544	40	01
05	0521052136	FRONT SIDE HANDRAIL 2235	41	01
06	0511059821	FIXER ASSY FRONT SIDE HANDLE CSCP	43	02




Item	Code	Description	See page	QT
01	0581018245	TUBE 33,7 X 27,00 X 1091		03
02	0511059383	INTERNAL FIXER ASSY HANDLE	21	08
03	0581012718	HANDRAIL		02
04	0503011179	3/8" X 2-1/4" BOLT		02
05	0581015996	TUBE 33,7 X 27 X 1131		02
06	0581014429	SHIM HANDRAIL		01
07	0503013357	3/8" SELF-ADJUSTING NUT		02
08	0581015992	TUBE		02
09	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	42	01




Item	Code	Description	See page	QT
01	0581018244	TUBE 33,7 X 27,00 X 2769		03
02	0511059383	INTERNAL FIXER ASSY HANDLE	21	12
03	0581012718	HANDRAIL		02
04	0503011179	3/8" X 2-1/4" BOLT		04
05	0581015996	TUBE 33,7 X 27 X 1131		02
06	0581014429	SHIM HANDRAIL		02
07	0503013357	3/8" SELF-ADJUSTING NUT		04
08	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	42	03
09	0581015992	TUBE		06




Item	Code	Description	See page	QT
01	0581018243	TUBE 33,7 X 27,00 X 2220		03
02	0511059383	INTERNAL FIXER ASSY HANDLE	21	10
03	0581012718	HANDRAIL		02
04	0503011179	3/8" X 2-1/4" BOLT		02
05	0581015996	TUBE 33,7 X 27 X 1131		02
06	0581014429	SHIM HANDRAIL		02
07	0503013357	3/8" SELF-ADJUSTING NUT		02
08	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	42	02
09	0581015992	TUBE		04




Item	Code	Description	See page	QT
01	0581018242	TUBE 33,7 X 27,00 X 1462		03
02	0511059383	INTERNAL FIXER ASSY HANDLE	21	08
03	0581012718	HANDRAIL		02
04	0503011179	3/8" X 2-1/4" BOLT		04
05	0581015996	TUBE 33,7 X 27 X 1131		02
06	0581014429	SHIM HANDRAIL		02
07	0503013357	3/8" SELF-ADJUSTING NUT		04
08	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	42	01
09	0581015992	TUBE		02




Item	Code	Description	See page	QT
01	0581015996	TUBE 33,7 X 27 X 1131		01
02	0511059383	INTERNAL FIXER ASSY HANDLE	21	10
03	0581015995	TUBE 33,7 X 27 X 925		01
04	0581012718	HANDRAIL		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0581014429	SHIM HANDRAIL		01
07	0521068338	FIXING HANDRAIL RIGHT		01
08	0581012708	HANDRAIL REAR SIDE BODY		02
09	0581015992	TUBE		04
10	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	42	02
11	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0502012855	CENTRAL FIXER		01
02	0502012856	CENTRAL FIXER		01
03	0503019083	7/16" X 2.1/4" BOLT		02
04	0503015490	NUT AUTOFREN 7/16 NC		02




Item	Code	Description	See page	QT
01	0581012698	FRONT SIDE CORRIMAO FIXER		01
02	0503010237	3/8" X 1" BOLT		02
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503011179	3/8" X 2-1/4" BOLT		02



Item	Code	Description	See page	QT
01	0571013242	HEX AXLE 3/4 X 2240		01
02	0561016764	3/4 X 2645 HEX AXLE		02
03	0511054314	TRANSMISSION AXLE FULL TRANSMISSION GLOVE		43
03A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
03B	0503010256	3/8" X 3/4" BOLT		01
04	0561015837	SLEEVE 31,75 X SEXT 19,80/20 X 90		02
05	0503010523	1/4" X 2" COTTERPIN		02
06	0521063774	GEAR ASSY		01




Item	Code	Description	See page	QT
01	0521053861	SUPPORT TURBINE ASSY SIDE	46	01
02	0521045392	HYDRAULIC TURBINE WITH SCREEN	47	01
03	0521053960	HOSE WITH JUNCTION	50	01
04	0503011372	102 TO 121 CLAMP		02



Item	Code	Description	See page	QT
01	0521069111	SIDE FRAME TURBINE SUPPORT		01
02	0501012140	FLAT WASHER		04
03	0503010027	5/8" SPRING WASHER		06
04	0503010013	5/8" NUT		06
05	0571011070	5/8" UNC FASTENER		02
06	0503010232	5/8" X 1.3/4" BOLT		02

HYDRAULIC TURBINE WITH SCREEN


0521045392




Item	Code	Description	See page	QT
01	0501054983	NIPPLE HIDRAULIC MOTOR	48	01
02	0503010025	3/8" SPRING WASHER		12
03	0503010026	3/8" NUT		10
04	0521044613	FAN 480 X 50 S (HIDRAULIC)		01
05	0503010143	1/4" SPRING WASHER		01
06	0503010849	3/8" X 1-1/2" BOLT		02
07	0531018764	FLAT WASHER		01
08	0503011104	M6 X 1" BOLT		01
09	0503012722	0.16" X 0.4" BLIND RIVET		24
10	0521065857	CARACOL MECHANICAL TURBINE S MEC		01
11	0521065858	TURBIN SUPPORT		01
12	0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC 49 TURBINE		01
13	0561010634	VALVE SUPPORT ASSY		01
14	0503010237	3/8" X 1" BOLT		08
15	0503010206	3/8" X 1/2" BOLT		02
16	0571018577	COVER SNAIL TURBINE		01
17	0571018578	TURBINE PROTECTIVE SCREEN		01
18	0541013274	LISA WASHER 10 X 38 X 4.75		02
19	0521069167	FRONT PROTECTION		01
20	0501080709	3/8" X 21.6" TR-TR HOSE		01
21	0501080091	1/2" X 550 TR-TR HOSE		02

NIPPLE HIDRAULIC MOTOR


0501054983




Item	Code	Description	See page	QT
01	0503012871	HYDRAULIC MOTOR		01
02	0531018770	R 3/4"UNF X R 1/4"BSP ELBOW		01
03	0561016941	3/4" NUT		01
04	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
05	0541011065	3/4"UNF X R1/4BSP19FPP X43.5 NIPPLE		01




Item	Code	Description	See page	QT
01	0503012291	BLOCK COMMAND		01
02	0501010590	7/8" REDUCTION NIPPLE		04
03	0503010045	2-116 N 3006-9B O'RING		04
04	0541011066	3/4" UNF X 43.5 NIPPLE		01
05	0503010190	2-114 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0581018370	HOSE JOINT GLOVE		01
02	0581018371	HOSE 4 X 237,5		02
03	0503011372	102 TO 121 CLAMP		04




Item	Code	Description	See page	QT
01	0521063601	SUPPORT HYDRAULIC MOTOR		01
02	0521062807	17Z GEAR WITH SLEEVE		01
03	0511052600	STRETCHER HYDRAULIC MOTOR SUPPORT	52	01
04	0571012677	WASHER GUIDE		01
05	0501010937	13.5 X 28 X 3 FLAT WASHER		02
06	0503010060	1/2" NUT		02
07	0503010019	1/2" SPRING WASHER		02
08	0503010238	1/2" X 1-3/4" BOLT		02
09	0571012684	FIXING SHAFT		01
10	0571012680	FLAT WASHER		01
11	0503010179	5/16" ZN SPRING WASHER		01
12	0503010025	3/8" SPRING WASHER		01
13	0503010026	3/8" NUT		01
14	0503013758	1/4" X 1-1/2" BOLT		01
15	0503010237	3/8" X 1" BOLT		01
16	0502012768	CLAMP UPPER		01
17	0503019024	5/8" X 3" BOLT		02
18	0503010811	5/8" UNF SELF ADJUSTING NUT		02
19	0503017392	40-1 X 67 CHAIN LINK + MENDING		01
20	0521063774	GEAR ASSY		01
21	0511054314	TRANSMISSION AXLE FULL TRANSMISSION GLOVE		02
21A	0502012699	LATCH GLOVE BOX TRANSMISSION		02
21B	0503010256	3/8" X 3/4" BOLT		02




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503012882	BEARING		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0571012703	SLEEVE FLANGE		01
05	0503010479	1/2" X 3" BOLT		01
06	0511017302	FLAT WASHER		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0521053856	17 SIDE AIR CONDUCTOR BOCAS 7453	54	01
02	0521052152	REAR CENTRAL AIR CONDUCTOR 1520	55	01
03	0521053867	ASSY AIR CONDUCTOR SUPPORT	56	02
04	0511057646	ASSY AIR CONDUCTOR SUPPORT	57	04
05	0581016488	AIR CONDUCTOR		17
06	0521052549	CLAMP	58	17
07	0521052168	SEED HOSE GUIDE	59	08
08	0521053850	ASSY FRONT AIR CONDUCTOR SUPPORT	60	02




Item	Code	Description	See page	QT
01	0503012566	COVER KAP 110 YELLOW		01
02	0503031943	SOCKET		17
03	0503012856	REBITE POP		34
04	0581018221	AIR CONDUCTOR BODY 3 MOUTH 1326		01
05	0511057036	SUPREME AIR DISTRIBUTOR BOARD		02
05A	0503012567	T-JOIN FOR TUBE 110		01
05B	0581013890	SOCKET DISTRIBUTOR AR		01
06	0521050393	COMPLETE KNEE		01
06A	0503017845	PVC KNEE 90 SOLD AVEL		01
06B	0581013890	SOCKET DISTRIBUTOR AR		01
07	0581018220	7 MOUTHS AIR CONDUCTOR SIDE BODY 2860		01
08	0571019716	ADAPTER		17
09	0581018222	7 MOUTH AIR CONDUCTOR SIDE BODY 2980		01



Item	Code	Description	See page	QT
01	0581016018	AIR CONDUCTOR BODY 1400		01
02	0581013633	SOCKET DISTRIBUTOR AR		02

ASSY AIR CONDUCTOR SUPPORT


0521053867



Item	Code	Description	See page	QT
01	0521069122	AIR CONDUCTOR SUPPORT		01
02	0511017302	FLAT WASHER		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0571018437	PRISONER 1/2 X		02
06	0581018240	AIR CONDUCTOR SUPPORT BODY		01

ASSY AIR CONDUCTOR SUPPORT


0511057646




Item	Code	Description	See page	QT
01	0521066281	AIR CONDUCTOR SUPPORT		01
02	0511017302	FLAT WASHER		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521018402	AIR CONDUCTOR CLAMP		01
06	0503010371	5/16" X 1" BOLT		02
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503010337	5/16" NUT		02
09	0571019615	FITTING 1/2 UNC 130 X 198 ZN		01

CLAMP

0521052549




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0521068360	SEED HOSE GUIDE		01
02	0521018402	AIR CONDUCTOR CLAMP		01
03	0503010371	5/16" X 1" BOLT		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02

ASSY FRONT AIR CONDUCTOR SUPPORT


0521053850




Item	Code	Description	See page	QT
01	0521069123	AIR CONDUCTOR SUPPORT		01
02	0511017302	FLAT WASHER		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0521018402	AIR CONDUCTOR CLAMP		01
06	0503010371	5/16" X 1" BOLT		02
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503010337	5/16" NUT		02
09	0571018437	PRISONER 1/2 X		02
10	0581018240	AIR CONDUCTOR SUPPORT BODY		01




Item	Code	Description	See page	QT
01	0521069115	OIL DUCT 3/4 X 2760		01
02	0521069117	OIL DUCT R.7/8 X 1790		02
03	0521069116	OIL DUCT R.7/8 1000		02
04	0521069114	OIL DUCT R.7/8 2750		02
05	0521069113	OIL DUCT 03 EXIT R.3/4 X 1790		01
06	0521069204	OIL DUCT R.1.1/16 X 1770		02
07	0521069205	OIL DUCT R.3/4 X 3470		02
08	0521069112	OIL DUCT 03 EXIT R.3/4 X 2680		02
09	0521069104	OIL DUCT R.7/8 X 1770		01
10	0511059943	SUPPORT FASTENER ASSY		07
10A	0581011417	DUTO HOLDER SUPPORT		01
10B	0503010237	3/8" X 1" BOLT		02
10C	0503010025	3/8" SPRING WASHER		02
10D	0503010026	3/8" NUT		02
11	0581018415	PROTECTION BODY		10
12	0581018409	FASTENER BODY		06
13	0581018408	SUPPORT SCALE		01
14	0581018407	SUPPORT SCALE		04
15	0503010481	BOLT		02
16	0503011268	3/8" X 2-1/2" BOLT		12
17	0503010025	3/8" SPRING WASHER		14
18	0503010026	3/8" NUT		14
19	0501082189	HOSE 1/2 X 160 TR-TR		02
20	0501082190	HOSE 3/8 X 160 TR-TR		03




Item	Code	Description	See page	QT
01	0581018246	GUTTER		01
02	0581017736	TROUGH 30 X 55 X 2540		01
03	0581017745	TROUGH 30 X 55 X 2420		01
04	0511057011	SUPPORT GUTTER ASSY	63	06




Item	Code	Description	See page	QT
01	0571013956	CENTRAL TRACK SUPPORT		01
02	0503010025	3/8" SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0503013029	3/8" X 3/4" BOLT		01
05	0501011643	3/8 X 1" BOLT		01



Item	Code	Description	See page	QT
01	0581014830	FIXER MOVEL TURBINE		01
02	0511059406	TURBINE PRECISION PLANTING MOUNTED	65	01
03	0503010027	5/8" SPRING WASHER		08
04	0503010013	5/8" NUT		08
05	0501012140	FLAT WASHER		04
06	0503010232	5/8" X 1.3/4" BOLT		04
07	0571011070	5/8" UNC FASTENER		02




Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE		01
02	0501011460	7/8 NF REDUCTION NIPPLE		04
03	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
04	0503010392	2-046 N 3006 9B O'RING		01
05	0581012096	ROUND SLEEVE		02
06	0503015420	VALVE ANTI-CAVITACAO CV10208TN5		01
07	0521050154	TURBINE PRECISION PLANTING WITH HOLE	66	01
08	0503011372	102 TO 121 CLAMP		02
09	0503014491	1/4 UNC X 2 C S G.5 ZN BOLT		02
10	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
11	0503010143	1/4\" SPRING WASHER		02
12	0503010144	1/4\" NUT		02
13	0503010190	2-114 N 3006-9B O'RING		04
14	0501081235	1/2 X 650 TR- TC HOSE		01




Item	Code	Description	See page	QT
01	0503034404	TURBINE REAR COVER		01
02	0503034405	MOTOR PP 730425		01
03	0503034406	FAN PP 730115		01
04	0503034407	NUT		01
05	0503062606	COVER		01
06	0503034409	JOINT PP 730134		01
07	0503034410	DISTRIBUTOR TUBE		01
08	0503034411	DISTRIBUTOR TUBE GUIDE		04
09	0503034402	WASHER 3/8		04
10	0503034403	SCREW 3/8 16FPP X 1		04
11	0503034412	NUT 3/8 16 FPP		02
12	0503034413	FLAT WASHER		07
13	0503034414	SCREW 5/16 X 1		07
14	0503011336	1/2" HEX SELF ADJUSTING NUT		02
15	0511817302	FLAT WASHER		02
16	0503810706	SCREW 1/2 UNC X 4.1/2 C S G.5 SA		02
17	0503062560	TUBE FOR METER CLOCK 730142		01

VACUOMETER WITH ASSY SUPPORT


0521050332




Item	Code	Description	See page	QT
01	0571019137	SWITCH FIXER		01
02	0503013584	VACUUM GAUGE		01
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0581014411	BREATHE		01




Item	Code	Description	See page	QT
01	0521068722	CENTRAL FRAME LARGER		01
02	0501010276	1" X 3" BOLT		16
03	0503010012	1" SPRING WASHER		16
04	0503012182	1" NUT		16
05	0571012964	AXLE BODY WHEELS PIVOT		02
06	0501010630	1.1/2" CASTLE NUT		02
07	0503011345	1/4" X 3-1/2" COTTERPIN		02
08	0521053207	INTERNAL PLATE WITH FIXATION SCREW 1/2	69	01
09	0502010477	HOSE CLAMP		01
10	0503010180	7/16" SPRING WASHER		01
11	0503011135	7/16" X 1-1/2" BOLT		01
12	0521052189	38,10X63,50X386X148 HYDRAULIC CYLINDER	70	01



Item	Code	Description	See page	QT
01	0561017061	TUBE ADJUSTMENT PLATE		01
02	0503010019	1/2" SPRING WASHER		08
03	0501010161	1/2" X 1.1/4" BOLT		08




Item	Code	Description	See page	QT
01	0521068383	CYLINDER CASE		01
02	0581010670	CORPO HASTE 38,10 X 345		01
03	0511070058	GUIDE HIDRAULIC		01
04	0503010163	D-1500 SCRAPER RING		01
05	0502010471	MOBILE COVER		01
06	0581010668	RING SUPPORT		01
07	0503018004	RING		01
08	0503018003	GASKET		01
09	0503018163	BACK-UP RING		02
10	0503018162	O'RING		02
11	0503030385	CYLINDER PLUG N-002		02
12	0502012837	PISTON		01
13	0503018005	RING		01
14	0503011109	2-119 N 3006-9B O'RING		01
15	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01



Item	Code	Description	See page	QT
01	0521053173	CENTRAL SEED BOX 15 EXITS	28	01
02	0521052156	ASSY CENTRAL SUPPORT	72	01
03	1164920015	BLACK SUCTION HOSE		22mts
04	0503034345	AIR DISPENSER COVER		04
05	0503010184	CLAMP		15

ASSY CENTRAL SUPPORT


0521052156




Item	Code	Description	See page	QT
01	0521068348	CENTRAL SUPPORT SEED BOX		01
02	0581016040	LOWER SUPPORT CASH SEED		04
03	0501011643	3/8 X 1"BOLT		16
04	0503013357	3/8" SELF-ADJUSTING NUT		16
05	0501010984	FLAT WASHER		24
06	0581012237	SEAL BOX FIXER		02
07	0581012245	SEAL BOX SHOULDER		02
08	0503010025	3/8" SPRING WASHER		04
09	0503010026	3/8" NUT		04
10	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
11	0511017302	FLAT WASHER		06
12	0503010019	1/2" SPRING WASHER		06
13	0503010060	1/2" NUT		06
14	0503010920	1/2" X 1.1/2" BOLT		06

REAR PLATFORM BASE ASSY


0521053766




Item	Code	Description	See page	QT
01	0521068345	REAR PLATFORM BASE		01
02	0521052154	ASSY REAR LADDER PLATFORM	74	02
03	0503010019	1/2" SPRING WASHER		08
04	0503010060	1/2" NUT		08
05	0503014734	1/2" X 1" BOLT		08
06	0521052140	HANDRAIL SIDE FRAME CENTRAL	75	02
07	0521052174	LANTERN WITH SUPPORT	76	02



Item	Code	Description	See page	QT
01	0521068347	PLATFORM 430 X 980		01
02	0501010984	FLAT WASHER		08
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04




Item	Code	Description	See page	QT
01	0581012750	SIDE HANDRAIL BODY (1085)		02
02	0511059383	INTERNAL FIXER ASSY HANDLE	21	06
03	0581016002	REAR HANDRAIL REINFORCEMENT 468		03
04	0581012718	HANDRAIL		02
05	0581014429	SHIM HANDRAIL		03
06	0503011179	3/8" X 2-1/4" BOLT		04
07	0503010025	3/8" SPRING WASHER		04
08	0503013357	3/8" SELF-ADJUSTING NUT		04



Item	Code	Description	See page	QT
01	0571019753	SOPORTE LATERAL USAP-CSC		01
02	0503032811	FLASHLIGHT		01
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0503010395	1/2" X 1-1/4" BOLT		02

ARM JOINT RIGHT ASSY


0521053058




Item	Code	Description	See page	QT
01	0571011825	BUSHING		02
02	0503010408	7/8" SPRING WASHER		01
03	0503015322	BOLT 7/8		01
04	0571017893	HORIZONTAL ARTICULATION SHAFT USAP		01
05	0503011198	C3/4" X 6" SCREW		01
06	0503011255	3/4" LOCK NUT		01
07	0503010002	1800 GREASE FITTING		01
08	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
09	0503032042	SHEET POLYETHYLENE		01
10	0503010814	5/16" X 3/4" BOLT		14
11	0521068749	ARTICULATION ARM RIGHT		01
12	0571011767	LISA WASHER 125 X 88 X 4.76		01
13	0503010004	1890 GREASE FITTING		01

ARM JOINT LEFT ASSY


0521053057




Item	Code	Description	See page	QT
01	0521068748	ARTICULATION ARM LEFT		01
02	0571011825	BUSHING		02
03	0503015322	BOLT 7/8		01
04	0503010408	7/8" SPRING WASHER		01
05	0571017893	HORIZONTAL ARTICULATION SHAFT USAP		01
06	0503011198	C3/4" X 6" SCREW		01
07	0503011255	3/4" LOCK NUT		01
08	0503010002	1800 GREASE FITTING		01
09	0503032042	SHEET POLYETHYLENE		01
10	0503010814	5/16" X 3/4" BOLT		14
11	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
12	0571011767	LISA WASHER 125 X 88 X 4.76		01
13	0503010004	1890 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
02	0551014508	FLAT WASHER		01
03	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
04	0501018466	FLAT WASHER		02
05	0561019929	FLAT WASHER		01
06	0511058240	HYDRAULIC CYLINDER	25	01
07	0503033458	CURRENT 6 X 17 ELOS		01
08	0521068707	LARGER CENTRAL WHEELED FORK		01
09	0521053037	TIRE WITH WHEEL 15 X 19,50 14 LONAS	81	01
10	0521053040	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION LARGER	82	01
11	0581017245	AXLE BODY		01
12	0521068710	JOINT SHAFT WHEELED GREATER CENTRAL		01
13	0521068713	GREATER RIGHT SUPPORT WHEELED CENTRAL		01
14	0501010630	1.1/2" CASTLE NUT		01
15	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
16	0501017779	32 X 60 X 4.75 FLAT WASHER		02
17	0503010002	1800 GREASE FITTING		02
18	0503010003	1845 GREASE FITTING		02
19	0503010010	1/4" X 2.1/2" COTTERPIN		04
20	0503010019	1/2" SPRING WASHER		04
21	0503010023	3/4" SPRING WASHER		06
22	0503010060	1/2" NUT		04
23	0503010337	5/16" NUT		01
24	0503010882	5/16" X 2" BOLT		01
25	0503010920	1/2" X 1.1/2" BOLT		04
26	0503011052	1.1/4" X 0.77" CASTLE NUT		02
27	0503011345	1/4" X 3-1/2" COTTERPIN		01
28	0503013394	3/4" X 3" BOLT		06
29	0503019247	NUT 3/4 NC S G.8		06




Item	Code	Description	See page	QT
01	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
02	0551014508	FLAT WASHER		01
03	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
04	0501018466	FLAT WASHER		02
05	0561019929	FLAT WASHER		01
06	0511058240	HYDRAULIC CYLINDER	25	01
07	0503033458	CURRENT 6 X 17 ELOS		01
08	0521068707	LARGER CENTRAL WHEELED FORK		01
09	0521053037	TIRE WITH WHEEL 15 X 19,50 14 LONAS	81	01
10	0521053040	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION LARGER	82	01
11	0581017245	AXLE BODY		01
12	0521068710	JOINT SHAFT WHEELED GREATER CENTRAL		01
13	0521068712	LARGER SUPPORT LEFT WHEELED CENTRAL		01
14	0501010630	1.1/2" CASTLE NUT		01
15	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
16	0501017779	32 X 60 X 4.75 FLAT WASHER		02
17	0503010002	1800 GREASE FITTING		02
18	0503010003	1845 GREASE FITTING		02
19	0503010010	1/4" X 2.1/2" COTTERPIN		04
20	0503010019	1/2" SPRING WASHER		04
21	0503010023	3/4" SPRING WASHER		06
22	0503010060	1/2" NUT		04
23	0503010337	5/16" NUT		01
24	0503010882	5/16" X 2" BOLT		01
25	0503010920	1/2" X 1.1/2" BOLT		04
26	0503011052	1.1/4" X 0.77" CASTLE NUT		02
27	0503011345	1/4" X 3-1/2" COTTERPIN		01
28	0503013394	3/4" X 3" BOLT		06
29	0503019247	NUT 3/4 NC S G.8		06



Item	Code	Description	See page	QT
01	0503034606	WHEEL		01
02	0503019123	TIRE 385/65 R 22,50 D711 DRC 15-19,50 20L		01
03	0503016098	VALVE		01




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0581017252	LARGER WHEEL AXLE		01
03	0503013633	BEARING 33287/33462		01
04	0503010009	RETAINER 00573-B		01
05	0503010086	SEAL 0009B-B		01
06	0551014473	SPACING SLEEVE HUB		01
07	0503012702	KM-12 NUT		02
08	0503012703	LOCK WASHER		01
09	0503010002	1800 GREASE FITTING		01
10	0503011444	SPRING WASHER		04
11	0503014048	22 X 1.5 HEX NUT		08
12	0503010363	5/16" X 1" BOLT		04
13	0503014050	22 X 1.5 BOLT		08
14	0511068415	PFFP-3770 SEAL GUIDE		01
15	0503013496	3982/3920 ROLLER BEARING		01




Item	Code	Description	See page	QT
01	0511058761	HYDRAULIC CYLINDER	84	02
02	0581017527	CYLINDER FIXED AXLE		04
03	0503030119	LOCK PIN		04
04	0501010617	3/4" NIPPLE		04
05	0503010190	2-114 N 3006-9B O'RING		04

HYDRAULIC CYLINDER

0511058761




Item	Code	Description	See page	QT
01	0521066785	2.5" TURNBUCLE		01
02	0521066784	150 X 843 CYLINDER CASE		01
03	0503010287	D-2500 SCRAPER RING		01
04	0503010971	W2-2750-500 PK RING G.I		02
05	0581011197	PISTON		01
06	0581013481	MOBILE COVER 150		01
07	0503030384	CON PLUG N-001		02
08	0581011195	2.5" X 5" RING SUPPORT		01
09	0503014960	GASKET		01
10	0503018466	O'RING		01
11	0503018465	ANILLO O'RING		01
12	0503010141	2-226 N 3006-9B O'RING		01
13	0503018467	RING		01
14	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0581017678	TROUGH 27 X 58 X 1500		02
02	0581018203	TROUGH 30 X 55 X 1980		01
03	0581017745	TROUGH 30 X 55 X 2420		01
04	0511057011	SUPPORT GUTTER ASSY	63	04




Item	Code	Description	See page	QT
01	0503034334	ADHESIVE LABEL CSC (REAR)	03	
02	0503034335	ADHESIVE LABEL	03	
03	0503034336	ADHESIVE LABEL CSC (FRONT)	03	
04	0503034337	ADHESIVE LABEL	03	
05	0503034338	ADHESIVE LABEL	06	
06	0503034339	ADHESIVE LABEL	06	
07	0503031565	ADHESIVE LABEL CARE	02	
08	0503031827	LUBRICATE AND RETIGHTEN DAILY DECAL	03	
09	0503033621	ADHESIVE LABEL	02	
10	0503034682	ADHESIVE LABEL SEED TABLE	01	
11	0503031425	ADHESIVE LABEL ATTENTION	04	
12	0503033597	ADHESIVE	02	
13	0503031428	READ MANUAL DECAL	01	
14	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	02	
15	0503034534	ADHESIVE LABEL	01	
16	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM	02	
17	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM	02	
18	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER	04	
19	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER	01	
20	0503034003	SERIAL NUMBER TAG 61 X 118	01	
21	0503010001	3.2 X 5.5 RIVET	04	
22	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	




Item	Code	Description	See page	QT
01	0503010019	1/2" SPRING WASHER		02
02	0503010060	1/2" NUT		02
03	0503010025	3/8" SPRING WASHER		02
04	0501010984	FLAT WASHER		02
05	0503010238	1/2" X 1-3/4" BOLT		02
06	0581017386	LIFTING SENSOR SUPPORT		01
07	0581017387	ARM DISARM TRIGGER		01
08	0503010026	3/8" NUT		02
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02

TELESCOPIC LOCK ASSY


0511059814




Item	Code	Description	See page	QT
01	0571015072	LOCK AXLE		01
02	0503010765	3/8" X 3" BOLT		01
03	0521064540	TELESCOPIC LOCK		01
04	0503013357	3/8" SELF-ADJUSTING NUT		01
05	0521011132	FLAT WASHER		01
06	0503010131	3/16" X 1-1/2" COTTERPIN		01
07	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
08	0511054270	TENSIONER SPRING		01
08A	0511069520	TELESC LOCK SPRING TENSIONER		01
08B	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0521063510	PLOUGH SUPPORT		01
02	0521063509	FRAME BRACKET		01
03	0571012421	FIXER ARM		01
04	0501014063	25 X 55 COUPLING SHAFT		01
05	0521010596	COUPLING SHAFT		03
06	0521010585	0.9" X 5.9" COUPLING SHAFT		01
07	0521010574	C0.9" X 3.3" COUPLING SHAFT		01
08	0503030085	LOCK PIN		06
09	0571013317	INNER TUBE		01




Item	Code	Description	See page	QT
01	0521063662	BOX OF TOOLS		01
02	0551018356	BOX OF TOOLS COVER ASSY		01
03	0521010528	0.3" X 1.6" COUPLING SHAFT		02
04	0503010140	1/8" X 3/4" COTTERPIN		02
05	0503011907	PMC 594-S NYLON LUG		01
06	0503010358	5/16" X 5/8" BOLT		02
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0503019303	CONTROL PANEL		01
02	0503019304	WIRES BLOCK COMMAND TRACTOR		01
03	0503019305	WHIP		01
04	0503019306	LIGHT / LANTERN CABLE		01
05	0503019307	CABLE TRACTOR HEADLIGHT		01
06	0503019036	CABLE BLOCK WITH IMPLEMENT		01
07	0503016234	TRIMBLE FIXING WINDOW		01
08	0503016452	FIXING SUPPORT AG500 TRIMBLE		01




Item	Code	Description	See page	QT
01	0561016781	SEQUENTIAL VALVE SUPPORT ASSY		02
02	0571011596	FIXER HOSE		01
03	0521060118	"T" TERMINAL		01
04	0503033787	NUT 3/4 UNF		01
05	0503010395	1/2" X 1-1/4" BOLT		02
06	0503010589	1/2" UNC SELF ADJUSTING NUT		02
07	0503010237	3/8" X 1" BOLT		04
08	0503013357	3/8" SELF-ADJUSTING NUT		04
09	0503010025	3/8" SPRING WASHER		04
10	0501010984	FLAT WASHER		04
11	0503010172	M10 X 1,5 X 25 BOLT		04
12	0503034719	FLOW DIVIDER BLOCK		01
13	0521055356	FLUX DIVIDER BLOCK FOR 03 TURBINES	93	01




Item	Code	Description	See page	QT
01	0503034719	FLOW DIVIDER BLOCK		01
02	0501010590	7/8" REDUCTION NIPPLE		02
03	0503010045	2-116 N 3006-9B O'RING		02

CENTRAL ASSY HEX AXLE


0521054011




Item	Code	Description	See page	QT
01	0561018821	HEX AXLE 3/4 X 2600		01
02	0571013341	HEX AXLE		01
03	0561015837	SLEEVE 31,75 X SEXT 19,80/20 X 90		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0511054314	TRANSMISSION AXLE FULL TRANSMISSION GLOVE		06
05A	0502012699	LATCH GLOVE BOX TRANSMISSION		06
05B	0503010256	3/8" X 3/4" BOLT		06
06	0511053648	GEAR		01
06A	0521063774	GEAR ASSY		01
06B	0503016587	CHAIN LINK + MENDING		01



Item	Code	Description	See page	QT
01	0503010257	1/8" X 1" COTTERPIN		02
02	0503010026	3/8" NUT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010144	1/4" NUT		08
05	0503010143	1/4" SPRING WASHER		08
06	0503010060	1/2" NUT		02
07	0503010019	1/2" SPRING WASHER		02
08	0511017302	FLAT WASHER		02
09	0503010237	3/8" X 1" BOLT		04
10	0521068017	BOX BODY APT TVT USAP S-0117		01
11	0571017090	ROD CX		01
12	0581014891	BOX SUPPORT		01
13	0521068016	BOX COVER		01
14	0503018171	FAST LOCK ASSY		02
15	0501013518	FLAT WASHER		04
16	0501010161	1/2" X 1.1/4" BOLT		02
17	0503010461	1/4" X 1" BOLT		04
18	0503010282	1/4" X 3/4" BOLT		04




Item	Code	Description	See page	QT
01	0521054022	CENTRAL DUCT ASSEMBLY 45E45	97	01
02	0503062957	BLOCK COMMAND		01
03	0521055280	CENTRAL BLOCK SUPPORT WITH FIXATION	99	01
04	0521055201	DIVIDER VALVE TRIPLE (17,163,025,002) WITH NIPPLES	100	01
05	0521054020	ASSY HOSE ARTICULATED CSC FRAME 20226	101	01
06	0521054018	ASSY HEAD HOSE CSC FRAME 20226	102	01
07	0521054021	HOSE KIT LEVANTE CSC FRAME 20226	103	01
08	0521054510	ASSY HOSE 5 TURBINES PRECISION PLANTING TATU CSC FRAME 22422	104	01
09	0521054012	ASSY HOSE APT FRAME 20226	105	01
10	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	106	06
11	0581017815	MALE ADAPTER		01




Item	Code	Description	See page	QT
01	0521069198	OIL DUCT R.7/8 X 1480		06
02	0521069036	OIL DUCT		01
03	0521069199	OIL DUCT R.3/4 X 1480		07
04	0521069200	OIL DUCT R.1.1/16 X 1480		02
05	0521069197	OIL DUCT 3 EXIT R.3/4 X 1650		02
06	0581018409	FASTENER BODY		16
07	0521053537	CENTRAL REAR DUCT SUPPORT	98	04
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		08
09	0503011123	3/8" X 4-1/2" BOLT		08
10	0503010025	3/8" SPRING WASHER		16
11	0503010026	3/8" NUT		16
12	0591010127	SUPPORT LEFT DISTRIBUTOR		02
13	0581014867	SIDE DUTY SUPPORT		02

CENTRAL REAR DUCT SUPPORT


0521053537




Item	Code	Description	See page	QT
01	0571019615	FITTING 1/2 UNC 130 X 198 ZN		01
02	0511017302	FLAT WASHER		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0503010025	3/8" SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581017885	SUPPORT BODY		01
08	0503011141	3/8" X 2-3/4" BOLT		01
09	0581018407	SUPPORT SCALE		01




Item	Code	Description	See page	QT
01	0581019704	CENTRAL BLOCK SUPPORT		01
02	0503010172	M10 X 1,5 X 25 BOLT		03
03	0503010025	3/8" SPRING WASHER		03
04	0511017302	FLAT WASHER		04
05	0503010395	1/2" X 1-1/4" BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0503019365	FLOW DIVISOR VALVE		01
02	0503011109	2-119 N 3006-9B O'RING		03
03	0521014704	HOSE NIPPLE 3/4 UNF		02
04	0581013111	NIPPLE R 1.1/6 UN X 1.5/16 12 WIRES		01
05	0501010589	R. 1.1/16UN SEXT 1.1/4 X 52 NIPPLE		01
06	0503014724	2-215 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0501080479	TC-TC HOSE ASSY		01
02	0501080442	3/8" X 130" TC-TC HOSE ASSY		01
03	0501080516	3/8" X 63" TR-TC HOSE ASSY		01
04	0501080571	HOSE 3/8 X 850 TC-TC		01
05	0501080449	3/8" X 1500 TC-TC HOSE		01
06	0501082184	HOSE 1/2 X 2100 TC-TC		01



Item	Code	Description	See page	QT
01	0501080714	3/8" X 63" TR-TC HOSE ASSY	02	
02	0501080105	TR-TR HOSE ASSY	02	
03	0501080128	3/8" X 71" TR-TR HOSE ASSY	02	
04	0501081046	3/8" X 161.4" TC-TM HOSE ASSY	01	
05	0501080390	3/8" X 150" TR-TC HOSE ASSY	01	




Item	Code	Description	See page	QT
01	0501081837	HOSE 3/8 X 700 TR-TC USAP		04
02	0501080700	3/8 X 650 TC-TC HOSE		02
03	0501080599	3/8 X 650 TC-TR HOSE		02
04	0501081838	HOSE		04
05	0501080065	3/8 X 1200 TC-TC HOSE ASSY		01
06	0501080675	3/8" X 165" TC-TM HOSE ASSY		03
07	0501080105	TR-TR HOSE ASSY		04
08	0501081254	3/8" X 900 TR-TC HOSE		02
09	0501080175	3/4 X 900 TR-TC 2T HOSE		01
10	0501080055	3/8" X 1000 TR-TC HOSE		02
11	0501080302	TR-TC HOSE ASSY		01
12	0501080714	3/8" X 63" TR-TC HOSE ASSY		01
13	0501080028	3/4 X 1200 TR-TC HOSE		02
14	0501080012	HOSE		02
15	0501081288	3/4 X 500 TR-TC HOSE		01
16	0501082222	HOSE		01
17	0501080347	HOSE 3/4 X 1800 TR-TR		02
18	0521053712	HOSE 3/4		01
18A	0501082205	HOSE 1/2 X 5900 TR-TM		01
18B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
18C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
18D	0503018952	PLASTIC BOLT		06
19	0521053707	HOSE 3/4		01
19A	0501082205	HOSE 1/2 X 5900 TR-TM		01
19B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
19C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
19D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0501080621	1/2 X 1200 TC-TC HOSE	02	
02	0501080524	3/8 X 1100 TC-TC HOSE ASSY	01	
03	0501080218	1/2 X 750 HOSE	02	
04	0501080150	TR-TC HOSE ASSY	02	
05	0501081235	1/2 X 650 TR- TC HOSE	02	
06	0501080135	HOSE 1/2 X 1800 TR-TR	10	
07	0501080128	3/8" X 71" TR-TR HOSE ASSY	01	
08	0501082241	HOSE 1/2 X 3400 TR-TC	08	
09	0501082040	HOSE 1/2 X 3400 TR-TR	02	
10	0501080515	TR-TC HOSE ASSY	02	
11	0521053716	3/4 X 3200 TR-TM HOSE YELLOW / RED	02	
11A	0501082206	HOSE 3/8 X 3200 TR-TM	02	
11B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)	02	
11C	0503034495	HYDRAULIC HOSE GRIP (RED)	02	
11D	0503018952	PLASTIC BOLT	12	
12	0521053714	HOSE 3/8 X 3200 TR-TM	02	
12A	0501082206	HOSE 3/8 X 3200 TR-TM	02	
12B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)	02	
12C	0503034494	HYDRAULIC HOSE GRIP (BLUE)	02	
12D	0503018952	PLASTIC BOLT	12	
13	0521053713	HOSE 3/8 X 3200 TR-TM	01	
13A	0501080441	TR-TM HOSE ASSY	01	
13B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)	01	
13C	0503034497	HYDRAULIC HOSE GRIP (GREEN)	01	
13D	0503018952	PLASTIC BOLT	06	
14	0501081510	HOSE 1/2 X 1700 TR-TC	01	
15	0501080056	3/8" X 1700 TR-TC HOSE ASSY	01	
16	0501080300	HOSE 1/2 X 1700 TR-TR	01	
17	0501080024	1/2" X 700 TR-TR HOSE	02	
18	0501080105	TR-TR HOSE ASSY	01	
19	0501080461	TR-TC HOSE ASSY	01	




Item	Code	Description	See page	QT
20	0501082159	HOSE 1/2 X 1000 TC-TC 90G LEFT		01
21	0501080931	3/8" X 39" TC-TC HOSE ASSY		01
22	0501082159	HOSE 1/2 X 1000 TC-TC 90G LEFT		01



Item	Code	Description	See page	QT
01	0501080060	1/2 X 1600 TR-TC HOSE	02	
02	0501080618	1/2" X 2200 TR-TC HOSE	01	
03	0501082025	HOSE 1/2 X 2900 TR-TR	01	
04	0501080058	HOSE 1/2 X 1400 TR-TC	02	
05	0501080040	1/2" X 19" TR-TC HOSE ASSY	01	
06	0501080267	HOSE 1/2 X 2100 TR-TC	01	
07	0501080059	1/2" X 61" TR-TC HOSE ASSY	01	
08	0521052567	HOSE 1/2 X 5900 TR-TM	01	
08A	0501081841	HOSE 1/2 X 5900 TR-TM	01	
08B	0503034489	HYDRAULIC HOSE GRIP (GRAY)	01	
08C	0503034495	HYDRAULIC HOSE GRIP (RED)	01	
08D	0503018952	PLASTIC BOLT	06	
09	0521052566	HOSE 1/2 X 5900 TR-TM	01	
09A	0501081841	HOSE 1/2 X 5900 TR-TM	01	
09B	0503034489	HYDRAULIC HOSE GRIP (GRAY)	01	
09C	0503034494	HYDRAULIC HOSE GRIP (BLUE)	01	
09D	0503018952	PLASTIC BOLT	06	
10	0501081235	1/2 X 650 TR- TC HOSE	02	
11	0501080024	1/2" X 700 TR-TR HOSE	01	
12	0501080218	1/2 X 750 HOSE	01	




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521052174	LANTERN WITH SUPPORT	76	02
02	0503032812	1141 12V LAMP		04
03	0503032813	67 12V 5W LAMP		02
04	0521053672	LIGHTHOUSE ASSY	108	05

LIGHTHOUSE ASSY


0521053672




Item	Code	Description	See page	QT
01	0581015856	REDLIGHT SUPPORT		01
02	0503018738	LIGHTHOUSE		01
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010358	5/16" X 5/8" BOLT		02
05	0551019884	45 X 50 X 3/8 FASTENER		02
06	0503013759	NUT		06




Item	Code	Description	See page	QT
01	0521053846	CONDUCTOR AR CENTRAL 11 BOCAS SPACING 450	110	01
02	0521051096	REAR CENTRAL AIR CONDUCTOR 1120 CSCP	111	02
03	0521053530	REAR CENTRAL AIR CONDUCTOR 1400 CSC	112	02
04	0521051092	AIR CONDUCTOR ASSY SUPPORT CSCP	113	04
05	0521050785	SUPPORT CONDUCTOR AIR ASSY	114	03
06	0521052168	SEED HOSE GUIDE	59	04
07	1164920009	FIXER SUPPORT SUCTION		06
08	0503011372	102 TO 121 CLAMP		14
09	0581016488	AIR CONDUCTOR		11
10	0521052549	CLAMP	58	11




Item	Code	Description	See page	QT
01	0511057036	SUPREME AIR DISTRIBUTOR BOARD		04
01A	0503012567	T-JOIN FOR TUBE 110		01
01B	0581013890	SOCKET DISTRIBUTOR AR		01
02	0581018229	AIR CONDUCTOR BODY 3 MOUTH 1242		01
03	0581018206	AIR 150 DRIVER BODY		02
04	0581018230	AIR CONDUCTOR BODY 4 MOUTH 1257		01
05	0581018207	AIR CONDUCTOR BODY 4 MOUTH 1470		01
06	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		02
06A	0503034763	AIR DITRIBUTOR PUMP		02
06B	0503015341	RIVET POP		02
07	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		11
07A	0503034812	SOCKET DISTRIBUTOR AR		01
07B	0503012856	REBITE POP		04




Item	Code	Description	See page	QT
01	0581015132	BODY DISTRIBUTOR AR		01
02	0581013633	SOCKET DISTRIBUTOR AR		01
03	0521050393	COMPLETE KNEE		01
03A	0503017845	PVC KNEE 90 SOLDAVEL		01
03B	0581013890	SOCKET DISTRIBUTOR AR		01




Item	Code	Description	See page	QT
01	0581015132	BODY DISTRIBUTOR AR		01
02	0581013633	SOCKET DISTRIBUTOR AR		02




Item	Code	Description	See page	QT
01	0581014434	DOUBLE BODY SUPPORT AIR CONDUCTOR		01
02	0521018402	AIR CONDUCTOR CLAMP		02
03	0503010179	5/16" ZN SPRING WASHER		04
04	0503010337	5/16" NUT		04
05	0503010371	5/16" X 1" BOLT		04




Item	Code	Description	See page	QT
01	0521067690	BODY DISTRIBUTEUR AR		01
02	0511017302	FLAT WASHER		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521018402	AIR CONDUCTOR CLAMP		01
06	0503010371	5/16" X 1" BOLT		02
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503010337	5/16" NUT		02
09	0571019615	FITTING 1/2 UNC 130 X 198 ZN		01




Item	Code	Description	See page	QT
01	0503062918	KIT INTELLIAG 45 LINES/45 WITH MONITOR E 010080934	116	01
02	0521050826	BLOCK LIMITATION ASSY FLOW	117	01
03	0511056973	PARKER OMP 80 HYDRAULIC MOTOR WITH VALVE	118	03
04	0511056972	FILTER HYDAC	119	01
05	0503017984	SENSOR LEVANTE BOTAO MONT LINE		02
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		675
07	0521068295	RATCHET DRIVING		01
08	0503010920	1/2" X 1.1/2" BOLT		04
09	0503010019	1/2" SPRING WASHER		04
10	0503010060	1/2" NUT		04
11	0503011828	FLAT WASHER		02



Item	Code	Description	See page	QT
01	0503015065	MAST CTRL MODULE		01
02	0503015066	CABLE CTRL MASTER MODULE		01
03	0503015209	MODULES WSMB 18L ISOBUS 4679811100S1		02
04	0503015210	CABLE MODULO WSMB ISOBUS 467981200		02
05	0503016324	ELECTRIC THREAD		01
06	0503015071	CONCTOR		01
07	0503015220	ENCODER ISOB 4,5M 464360171S1		03
08	0503062514	MONITOR CABLE		01
08A	0503018277	LEFT SIDE CABLE WITH MONITOR		01
08B	0503018278	CENTRAL CABLE WITH MONITOR		01
08C	0503018279	RIGHT SIDE CABLE WITH MONITOR		01
09	0503017443	ANTENNA GPS PM 400		01
10	0503016369	THREE FEMALE CONNECTOR		03
11	0503015908	FEMALE TERMINAL		09
12	0503015911	CABLE SEAL		09
13	0503017031	CLEANING BRUSH		01
14	0503015218	SENSOR FOTOELE PM 400		45




Item	Code	Description	See page	QT
01	0503014953	LIMITING FLOW PACK		01
02	0503010045	2-116 N 3006-9B O'RING		02
03	0503011109	2-119 N 3006-9B O'RING		02
04	0571013917	7/8"NF X 1.1/16 UNF NIPPLE		02
05	0503010337	5/16" NUT		02
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503011766	5/16" X 2-1/2" BOLT		02
08	0511010111	7/8" NIPPLE		02




Item	Code	Description	See page	QT
01	0503016037	VALVE		01
02	0501010590	7/8" REDUCTION NIPPLE		02
03	0503010045	2-116 N 3006-9B O'RING		02
04	0503016055	MOTOR HYDRAULIC PARKER OMP 80 ISOBUS		01

FILTER HYDAC


0511056972




Item	Code	Description	See page	QT
01	0503016376	FILTER SPRING		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8"NF UNF NIPPLE		02
04	0503012341	T 7/8" ADAPOR GIRAT NUT		01
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521068930	SACADOR AXLE		01
02	0521068931	SLEEVE SACADOR		01




Item	Code	Description	See page	QT
01	0521053871	SIDE SUPPORT GREATER FIXING	27	02
02	0521053173	CENTRAL SEED BOX 15 EXITS	28	02
03	0501082104	AIR CONDUCTOR 1.1 / 4 X 1700		02
04	0501082105	AIR CONDUCTOR 1.1 / 4 X 1500		03
05	0501082102	AIR CONDUCTOR 1.1/4 X 1900 USAP SUP CSCP		01
06	0503034345	AIR DISPENSER COVER		13
07	0503010184	CLAMP		30




Item	Code	Description	See page	QT
01	0521052135	LEFT SIDE HANDRAIL 2235	123	01
02	0521053868	FRONT SIDE HANDRAIL 1544	40	01
03	0521053869	FRONT SIDE HANDRAIL 2302	39	01
04	0521053870	FRONT SIDE HANDRAIL 2851	38	01
05	0521053860	FRONT SIDE HANDRAIL 1173	37	01
06	0511059821	FIXER ASSY FRONT SIDE HANDLE CSCP	43	02




Item	Code	Description	See page	QT
01	0581015996	TUBE 33,7 X 27 X 1131		01
02	0511059383	INTERNAL FIXER ASSY HANDLE	21	10
03	0581015995	TUBE 33,7 X 27 X 925		01
04	0581012718	HANDRAIL		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0581014429	SHIM HANDRAIL		01
07	0521068339	LEFT HANDRAIL FIXER		01
08	0581012708	HANDRAIL REAR SIDE BODY		02
09	0581015992	TUBE		04
10	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	42	02
11	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521053852	SUPPORT LARGEST TURBINE AIR POSITIVE ASSY	125	01
02	0521045392	HYDRAULIC TURBINE WITH SCREEN	47	01
03	0581014075	HOSE		01
04	0503011372	102 TO 121 CLAMP		02




Item	Code	Description	See page	QT
01	0521067276	AR POSITIVE TURBINE SUPPORT		01
02	0501012140	FLAT WASHER		04
03	0503010027	5/8" SPRING WASHER		06
04	0503010013	5/8" NUT		06
05	0503010232	5/8" X 1.3/4" BOLT		02
06	0571011070	5/8" UNC FASTENER		02



Item	Code	Description	See page	QT
01	0521053851	17 SIDE AIR CONDUCTOR BOCAS 7418	127	01
02	0521052152	REAR CENTRAL AIR CONDUCTOR 1520	55	01
03	0521053867	ASSY AIR CONDUCTOR SUPPORT	56	02
04	0511057646	ASSY AIR CONDUCTOR SUPPORT	57	04
05	0581016488	AIR CONDUCTOR		17
06	0521052549	CLAMP	58	17
07	0521052168	SEED HOSE GUIDE	59	08
08	0521053850	ASSY FRONT AIR CONDUCTOR SUPPORT	60	02




Item	Code	Description	See page	QT
01	0503012566	COVER KAP 110 YELLOW		01
02	0503031943	SOCKET		17
03	0503012856	REBITE POP		34
04	0581018210	AIR CONDUCTOR BODY 4 MOUTH 1741		01
05	0511057036	SUPREME AIR DISTRIBUTOR BOARD		02
05A	0503012567	T-JOIN FOR TUBE 110		01
05B	0581013890	SOCKET DISTRIBUTOR AR		01
06	0521050393	COMPLETE KNEE		01
06A	0503017845	PVC KNEE 90 SOLD AVEL		01
06B	0581013890	SOCKET DISTRIBUTOR AR		01
07	0581018209	SIDE BODY AIR CONDUCTOR 6 MOUTH 2410		01
08	0571019716	ADAPTER		17
09	0581018222	7 MOUTH AIR CONDUCTOR SIDE BODY 2980		01




Item	Code	Description	See page	QT
01	0521069115	OIL DUCT 3/4 X 2760		01
02	0521069114	OIL DUCT R.7/8 2750		02
03	0521069108	OIL DUCT 4 EXIT R.3/4 X 3570		01
04	0521069105	OIL DUCT R.7/8 1390		02
05	0521069116	OIL DUCT R.7/8 1000		02
06	0521069107	OIL DUCT 03 EXIT R.3/4 X 2040		02
07	0521069104	OIL DUCT R.7/8 X 1770		03
08	0521069106	OIL DUCT R.3/4 X 3570		02
09	0521069206	OIL DUCT R.3/4 X 1770		02
10	0511059943	SUPPORT FASTENER ASSY		04
10A	0581011417	DUTO HOLDER SUPPORT		04
10B	0503010237	3/8" X 1" BOLT		08
10C	0503010025	3/8" SPRING WASHER		08
10D	0503010026	3/8" NUT		08
11	0503010481	BOLT		02
12	0503011268	3/8" X 2-1/2" BOLT		12
13	0503010025	3/8" SPRING WASHER		14
14	0503010026	3/8" NUT		14
15	0581018409	FASTENER BODY		08
16	0581018408	SUPPORT SCALE		02
17	0581018407	SUPPORT SCALE		02
18	0581018415	PROTECTION BODY		08
19	0521053025	DUCT SUPPORT OIL	129	02
20	0501082190	HOSE 3/8 X 160 TR-TR		03
21	0501082189	HOSE 1/2 X 160 TR-TR		02

DUCT SUPPORT OIL


0521053025




Item	Code	Description	See page	QT
01	0571019121	FIXER LOWER		01
02	0581013094	DUTO HOLDER SUPPORT		01
03	0571019139	PRISONER		02
04	0511017302	FLAT WASHER		04
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521052262	FRONT SHORT SEED LINE	133	01
02	0521053343	REAR RIGHT PRECISION PLANTING	142	01



Item	Code	Description	See page	QT
01	0521052261	FRONT LONG SEED LINE	134	01
02	0521053345	LEFT REAR PRECISION PLANTING	143	01



Item	Code	Description	See page	QT
01	0521052265	INTERNAL FRONT SHORT SEED LINE	135	01
02	0521053343	REAR RIGHT PRECISION PLANTING	142	01



Item	Code	Description	See page	QT
01	0521068444	FRONT SHORT SEED LINE SUPPORT		01
02	0503010027	5/8" SPRING WASHER		01
03	0503010003	1845 GREASE FITTING		04
04	0521066168	FRAME SEED LINE		01
05	0571012310	ROW LOCK BODY		01
06	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
07	0501012140	FLAT WASHER		01
08	0503010232	5/8" X 1.3/4" BOLT		01
09	0503010013	5/8" NUT		01
10	0581014929	SEED ARM SUPPORT ROW		01
11	0503030168	HAIR PIN		04
12	0561014215	BEARING COVER LOWER ROW FRAME		01
13	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
14	0503010179	5/16" ZN SPRING WASHER		02
15	0503010337	5/16" NUT		02
16	0503033728	PINO FIXER SPRING		02
17	0571014704	UPPER AXLE		01
18	0503011952	5/16" X 3/4" BOLT		02
19	0502012768	CLAMP UPPER		02
20	0503010019	1/2" SPRING WASHER		01
21	0503010060	1/2" NUT		01
22	0571012014	TRANSPORT LOCK		01
23	0503010811	5/8" UNF SELF ADJUSTING NUT		04
24	0581014932	SLEEVE ARM LINE SEED		08
25	0503010479	1/2" X 3" BOLT		01
26	0503019024	5/8" X 3" BOLT		04
27	1902012568	UPPER ROCKER ARM		01
28	0581014930	LOWER BOW ARM		01
29	0503019025	SCREW 5/8 UNF X 8 C S RP G.5 ZN		04
30	0511057159	TRANSMISSION BOX SEED LINE	136	01
31	0511057223	SHORT TRANSMISSION ASSY AXLE	137	01


**FRONT SHORT SEED LINE**

0521052262

Item	Code	Description	See page	QT
32	0501057684	SIDE BEARING FRONT SUPPORT SEED LINE	140	01
33	0503010878	5/8" SELF ALIGNING NUT		04
34	0521068188	HOSE GUIDE		01
35	0501011643	3/8 X 1"BOLT		01
36	0503010025	3/8" SPRING WASHER		01
37	0503010026	3/8" NUT		01

FRONT LONG SEED LINE

0521052261




Item	Code	Description	See page	QT
01	0521068446	FRONT LONG SEED LINE SUPPORT		01
02	0503010027	5/8" SPRING WASHER		01
03	0503010003	1845 GREASE FITTING		04
04	0521066168	FRAME SEED LINE		01
05	0571012310	ROW LOCK BODY		01
06	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
07	0501012140	FLAT WASHER		01
08	0503010232	5/8" X 1.3/4" BOLT		01
09	0503010013	5/8" NUT		01
10	0581014926	SEED ARM SUPPORT ROW		01
11	0503030168	HAIR PIN		04
12	0561014215	BEARING COVER LOWER ROW FRAME		01
13	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
14	0503010179	5/16" ZN SPRING WASHER		02
15	0503010337	5/16" NUT		02
16	0503033728	PINO FIXER SPRING		02
17	0571014704	UPPER AXLE		01
18	0503011952	5/16" X 3/4" BOLT		02
19	0502012768	CLAMP UPPER		02
20	0503010019	1/2" SPRING WASHER		01
21	0503010060	1/2" NUT		01
22	0571012013	TRANSPORT LOCK		01
23	0503010811	5/8" UNF SELF ADJUSTING NUT		04
24	0581014932	SLEEVE ARM LINE SEED		08
25	0503010479	1/2" X 3" BOLT		01
26	0503019024	5/8" X 3" BOLT		04
27	1902012568	UPPER ROCKER ARM		01
28	0581014927	LOWER BOTTOM ARM (123,7)		01
29	0503019025	SCREW 5/8 UNF X 8 C S R P G.5 ZN		04
30	0511057159	TRANSMISSION BOX SEED LINE	136	01
31	0511057224	LONG TRANSMISSION ASSY AXLE	138	01

**FRONT LONG SEED LINE**

0521052261

Item	Code	Description	See page	QT
32	0501057684	SIDE BEARING FRONT SUPPORT SEED LINE	140	01
33	0503010878	5/8" SELF ALIGNING NUT		04
34	0521068188	HOSE GUIDE		01
35	0501011643	3/8 X 1"BOLT		01
36	0503010025	3/8" SPRING WASHER		01
37	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0521068445	INTERNAL FRONT SHORT SEED LINE SUPPORT		01
02	0503010027	5/8" SPRING WASHER		01
03	0503010003	1845 GREASE FITTING		04
04	0521066168	FRAME SEED LINE		01
05	0571012310	ROW LOCK BODY		01
06	0551015826	SEED ROW LOCK GUIDE SLEEV		01
07	0501012140	FLAT WASHER		01
08	0503010232	5/8" X 1.3/4" BOLT		01
09	0503010013	5/8" NUT		01
10	0581014929	SEED ARM SUPPORT ROW		01
11	0503030168	HAIR PIN		04
12	0561014215	BEARING COVER LOWER ROW FRAME		01
13	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
14	0503010179	5/16" ZN SPRING WASHER		02
15	0503010337	5/16" NUT		02
16	0503033728	PINO FIXER SPRING		02
17	0571014704	UPPER AXLE		01
18	0503011952	5/16" X 3/4" BOLT		02
19	0502012768	CLAMP UPPER		02
20	0503010019	1/2" SPRING WASHER		01
21	0503010060	1/2" NUT		01
22	0571012014	TRANSPORT LOCK		01
23	0503010811	5/8" UNF SELF ADJUSTING NUT		04
24	0581014932	SLEEVE ARM LINE SEED		08
25	0503010479	1/2" X 3" BOLT		01
26	0503019024	5/8" X 3" BOLT		04
27	1902012568	UPPER ROCKER ARM		01
28	0581014930	LOWER BOW ARM		01
29	0503019025	SCREW 5/8 UNF X 8 C S RP G.5 ZN		04
30	0511057159	TRANSMISSION BOX SEED LINE	136	01
31	0511057223	SHORT TRANSMISSION ASSY AXLE	137	01


**INTERNAL FRONT SHORT SEED LINE**

0521052265


Item	Code	Description	See page	QT
32	0501057684	SIDE BEARING FRONT SUPPORT SEED LINE	140	01
33	0503010878	5/8" SELF ALIGNING NUT		04
34	0521068188	HOSE GUIDE		01
35	0501011643	3/8 X 1" BOLT		01
36	0503010025	3/8" SPRING WASHER		01
37	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	BOX TRANSMISSION COVER		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511057225	BEARING ASSY LINE FRONT	139	01
02	0551017559	BEARING AXLE BODY		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0551017540	5/8" X 73 AXLE HEX		01
05	0501056296	UNIVERSAL JOINT		02
06	0503011855	0.2" X 1.8" SPRING PIN		04
07	0571012492	HEX AXLE 5/8" X 330		01
08	0571012411	HEX AXLE		01




Item	Code	Description	See page	QT
01	0511057225	BEARING ASSY LINE FRONT	139	01
02	0551017559	BEARING AXLE BODY		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0551017540	5/8" X 73 AXLE HEX		01
05	0501056296	UNIVERSAL JOINT		02
06	0503011855	0.2" X 1.8" SPRING PIN		04
07	0571012486	HEX AXLE 5/8 X 510		01
08	0571012411	HEX AXLE		01




Item	Code	Description	See page	QT
01	0502011971	HOUSING WITH DOUBLE BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	5/16" ZN SPRING WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501053566	BEARING SEED LINE	141	01
02	0551015804	BEARING AXLE BODY		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0511059312	BEARING TRANSMISSION SEED		01
02	0503011953	5/16" X 1" BOLT		02
03	0503010179	5/16" ZN SPRING WASHER		02
04	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521053344	DOUBLE DISC RIGHT HIGH CUBE	144	01
02	0521065999	FRONT SHIELD		01
03	0503010706	1/2" X 4.1/2" BOLT		03
04	0503010019	1/2" SPRING WASHER		03
05	0503010060	1/2" NUT		03




Item	Code	Description	See page	QT
01	0521053356	DOUBLE DISC LEFT HIGH CUBE	145	01
02	0521065999	FRONT SHIELD		01
03	0503010706	1/2" X 4.1/2" BOLT		03
04	0503010019	1/2" SPRING WASHER		03
05	0503010060	1/2" NUT		03




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	BOX DDD ASSY DPL 15 RIGHT	146	01
04	0501054168	BOX DDD ASSY DPL 15 LEFT	147	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	COVER DEPTH		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0501010984	FLAT WASHER		02
09	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
11	0503010026	3/8" NUT		01
12	0503011443	3/8" SPRING WASHER		01
13	0503011441	SPRING WASHER		06
14	0503014729	1/4" UNF X 1/2" BOLT		06
15	0502012780	SUPPORT DDD RIGHT		01




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	BOX DDD ASSY DPL 15 RIGHT	146	01
04	0501054168	BOX DDD ASSY DPL 15 LEFT	147	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	COVER DEPTH		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0501010984	FLAT WASHER		02
09	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
11	0503010026	3/8" NUT		01
12	0503011443	3/8" SPRING WASHER		01
13	0503011441	SPRING WASHER		06
14	0503014729	1/4" UNF X 1/2" BOLT		06
15	0502012781	SUPPORT DDD LEFT		01




Item	Code	Description	See page	QT
01	0502011930	DOUBLE DISC COULTER BOX		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019154	RIGHT DOUB DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06



Item	Code	Description	See page	QT
01	0502011930	DOUBLE DISC COULTER BOX		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019148	LEFT DOUBLE DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012470	BALDE DISC UPPER SUPPORT		01
02	0511016156	5/8" X 1.1/2" BOLT		02
03	0521051426	LOWER SUPPORT WITH DPLE 20 TB 60E	149	01
04	0503012798	5/8" X 2" BOLT		04
05	0503010878	5/8" SELF ALIGNING NUT		04




Item	Code	Description	See page	QT
01	0503031575	2.5"X 12" X 0.5" COMPRESSION SPRING		02
02	0551015883	SPRING GUIDES SLEVE		02
03	0503010002	1800 GREASE FITTING		02
04	0561014164	SUPPORT DISC AXLE		01
05	0571012370	PROTECTION FRONT		01
06	0502012713	BOTTOM BRACKET		01
07	0571012371	SLEEVE 20 X 34,93 X 130		01
08	0503010361	SPRING PIN		01
09	0521068323	LEFT ARM		01
10	0521068322	RIGHT ARM		01
11	0521051425	BOX WITH CUT DISC DPLE20 TB 60E	150	01
12	0521068189	SPRING REGULACION		02
13	0501012140	FLAT WASHER		02
14	0503010179	5/16" ZN SPRING WASHER		02
15	0503010295	5/16" X 5/8" BOLT		02
16	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT		01
17	0503010152	3/4" SELF LOCKING NUT		01
18	0503010806	5/8" X 3" BOLT		02
19	0503011075	3/4" UNC NUT		02
20	0503010878	5/8" SELF ALIGNING NUT		02

Item	Code	Description	See page	QT
01	0511056909	DISC BOX CUT WITHOUT THE DISC	151	01
02	0605027058	20" X 0.1771" PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0502012793	DC PST		01
02	0571018049	DOOR DUST		02
03	0571018047	AXLE DISC		01
04	0503017755	NUT		01
05	0502020641	BLADE DISC FLANGE		01
06	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
07	0503018441	5/16" X 1-1/4" BOLT		06
08	0503013816	5/16" LOCKNUT		06
09	0503010691	1/4" GREASE FITTING		01
10	0571018048	WASHER		02
11	0521065882	SEAL RING		02
12	0503010816	6207 RS ROLLER BEARING		02
13	0581010575	7/8" X 145 BOLT		01



Item	Code	Description	See page	QT
01	0571017899	PIN LOCK PP		01
02	0503030190	0.5" X 1.6" X 0.05" SPRING		01
03	0571017894	PIN DRAG PRECISION PLANTING		01
04	0503013357	3/8" SELF-ADJUSTING NUT		01
05	0501013518	FLAT WASHER		02
06	0503015356	SPRING PIN		01
07	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
08	0571017895	PIN FIXER CONDUCTOR PRECISION PLANTING		01
09	0503011776	M6 SELF ADJUSTINGNUT		03
10	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
11	0503010293	BAQUELITE MANIPULACION		02
12	0503010140	1/8" X 3/4" COTTERPIN		02
13	0503010025	3/8" SPRING WASHER		05
14	0571019491	SLUICE PNEUMATIC PRECISION PLANTING		01
15	0501011643	3/8 X 1"BOLT		01
16	0503010209	3/8" UNC BUTTERFLY NUT		01
17	0502012807	SUPPORT BOX PRECISION PLANTING		01
18	0571019489	CLAMP PRECISION PLANTING		01
19	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
20	0511057491	PRECISION PLANTING SEED ASSY SEED 153 DISTRIBUTOR WITH CORN DISC		01
21	0561014778	HEX UNIVERSAL JOINT		01
22	0503013958	1/4" X 1" BOLT		02
23	0503011855	0.2" X 1.8" SPRING PIN		01
24	0511057503	CAJA DE TRANSMISIÓN DERECHA PRECISION 154 PLANTING		01
25	0571019614	JOINT PNEUMATICA SUPPORT		01
26	0503011812	M6 X 1" BOLT		03
27	0503015110	M06 SPRING WASHER		03
28	0503012721	1/4" X 4" BOLT		01
29	0503012880	1/4" UNC SELF ADJUSTING NUT		01



Item	Code	Description	See page	QT
30	0503818139	M6 BOLT		03
31	0571014024	FAST BOLT GUIDE AXLE		01
32	0503037390	PACKING FOR PLANTING		01
33	0503015752	3/8" X 2" BOLT		01
34	0571019027	FIXER SHIPPING BOX		01
35	0503010179	5/16" ZN SPRING WASHER		01
36	0581011226	FIXER CLOSING P PLANTING CONTR CPRA		01
37	0503034824	FIXATIVE		01
38	0511059817	DEPOSIT SEED ASSY AIR POSITIVE	155	01
39	0503015920	3/8" UNC X 1.3/4" BOLT		04
40	0503010026	3/8" NUT		04
41	0581012694	COMPACT PROTECTION		01
42	0503010706	1/2" X 4.1/2" BOLT		01
43	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0503062405	SEED DISTRIBUTOR	01	
01A	0503062567	FIXED BASE SEEDS DISTRIBUTOR	01	
01AA	0503018908	BODY FIXED BASE DISTRIBUTOR SEED	01	
01AB	0503018909	COVER CONDUCTOR DISTRIBUTOR SEED	01	
01AC	0503062652	SEED INPUT DEFLECTOR	01	
01AD	0503062653	FULL COVER	01	
01AE	0503018910	RIVETS LARGEST	01	
01AF	0503018911	SPACING BUSHING	01	
01AG	0503018912	BOLT	03	
01AH	0503018476	SPRING	01	
01AI	0503018474	LOWER BRUSH	01	
01AJ	0503018475	TOP BRUSH	01	
01AK	0503018157	RUBBER	01	
01AL	0503018477	LOCK SPRING	01	
01B	0503062568	FIXER MOBILE	01	
01BA	0503018919	BASE	01	
01BB	0503018913	RIVET	01	
01BC	0503018914	WASHER	01	
01BD	0503018915	BEARING	02	
01BE	0503062654	BEARING	01	
01BF	0503018916	ADJUSTMENT CHOCK	03	
01BG	0503018917	RING	01	
01BH	0503018918	CHOCK	02	
01BI	0503019288	RUBBER SEAL PP 730518	01	
01BJ	0503018478	SPRING	01	
01BK	0503018920	SEALING	01	
01BL	0503018479	TUBE	01	
01BM	0503018735	PROTECTIVE COVER	01	
01BN	0503018921	BOLT	06	
01BO	0503018922	BOLT	02	
01BP	0503018480	REGULATOR PIN	01	



USAP SUPREMA PRECISION PLANTING - 45 LINES/SPACING
PRECISION PLANTING SEED ASSY SEED DISTRIBUTOR WITH

Page 153
0511057491


Item	Code	Description	See page	QT
01BQ	0503018923	ADAPTER		01
01BR	0503018924	SPRING PIN		01
02	0503062407	SET SOYBEAN DISTRIBUTION		01
02A	0503018483	PLASTIC DISC		01
02B	0503062569	SELECTOR SEED		01
02C	0503062566	ASSY		01
03	0571019613	STRAW PRECISION PLANTING SHIELD		01
03A	0503017957	PROTECTIVE COVER AIR INPUT		01




Item	Code	Description	See page	QT
01	0502050052	LEFT SIDE TRANSMISSION BOX PP		01
02	0502050053	RIGHT SIDE TRANSMISSION BOX PP		01
03	0503011410	ROLLER BEARING		02
04	0503011182	6203 ROLLER BEARING		02
05	0571016187	PINION AXLE 6Z PNEUMATIC		01
06	0503011184	502040 CLAMPING RING (FOR AXLE)		01
07	0571017655	SLEEVE FIXER HITCH PNEUMATIC		01
08	0503010373	1/4" X 2" BOLT		03
09	0503010144	1/4" NUT		03
10	0511057504	JOIN GEAR		01
11	0503033976	GEAR 6Z PNEUMATIC 2014		01

DEPOSIT SEED ASSY AIR POSITIVE

0511059817




Item	Code	Description	See page	QT
01	0503010026	3/8" NUT		04
02	0503010025	3/8" SPRING WASHER		05
03	0503010179	5/16" ZN SPRING WASHER		04
04	0503010337	5/16" NUT		04
05	0502012798	SUPPORT BOX SEED		01
06	0503010849	3/8" X 1-1/2" BOLT		03
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
08	0503010295	5/16" X 5/8" BOLT		04
09	0503062388	SIL USES COMPLETE COMPRESSED AIR SEED		01
10	0521066409	USAP CSC SEED TANK		01
11	0503010209	3/8" UNC BUTTERFLY NUT		01
12	0501010096	3/8" X 2" BOLT		01



Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0581014858	DEPTH WHEEL AXLE		01
04	0501110720	ARM,LEFT		01
05	0501110719	DEPTH CONTROL RIGHT ARM		01
06	0502012663	EXTENSION		01
07	0503010002	1800 GREASE FITTING		02
08	0501056769	DEPTH WHEELS REGULATOR ASSY	158	01
09	0503034793	ARTICULATION SLEEVE		02
10	0521051423	COMPACTOR SUPPORT	159	01
11	0571017749	FLAT WASHER		02
12	0503010311	1/2" X 1-1/4" BOLT		02
13	0503016453	1/2" X 2.1/2 BOLT		02
14	0503034817	SPRING		01
15	0503010581	RING		01
16	0503034377	SCREWEW 3/8 UNC X 3/4		01
17	0503010019	1/2" SPRING WASHER		08
18	0503010740	1/2" X 2" BOLT		02
19	0503010060	1/2" NUT		04
20	0501052908	COMPACTOR WHEEL WITH BEARING	160	02
21	0503013739	1/2" X 1" BOLT		01
22	0511050077	WHEEL STRIPED	161	02
23	0503010752	1/2" X 3.1/2" BOLT		01

DEPTH ASSY QUICK REGULATOR


0521052157



Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0503010581	RING		01
04	0581014858	DEPTH WHEEL AXLE		01
05	0501110720	ARM,LEFT		01
06	0501110719	DEPTH CONTROL RIGHT ARM		01
07	0503010002	1800 GREASE FITTING		02
08	0501056769	DEPTH WHEELS REGULATOR ASSY	158	01
09	0521051423	COMPACTOR SUPPORT	159	01
10	0503034793	ARTICULATION SLEEVE		02
11	0571017749	FLAT WASHER		02
12	0503010311	1/2" X 1-1/4" BOLT		02
13	0503010019	1/2" SPRING WASHER		08
14	0503010740	1/2" X 2" BOLT		02
15	0503010060	1/2" NUT		02
16	0501052908	COMPACTOR WHEEL WITH BEARING	160	02
17	0503013739	1/2" X 1" BOLT		02
18	0511050077	WHEEL STRIPED	161	02
19	0503016453	1/2" X 2.1/2 BOLT		02
20	0503030805	1.6" X 6" X 0.2"TRACTION SPRING		01
21	0502012884	EXTENSION		01
22	0503010028	1/2" NUT		02
23	0503010256	3/8" X 3/4" BOLT		01

DEPTH WHEELS REGULATOR ASSY


0501056769




Item	Code	Description	See page	QT
01	0503010257	1/8" X 1" COTTERPIN		01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0502011689	1/8" DEPTH CONTROL LEVER		01
04	0502011688	SEED SIST CONTROL DEPTH LEVER		01
05	0511065582	DEPTH WHEEL STOP		01
06	0503030975	0.9" X 1.5" X 0.1" SPRING		01
07	0511015976	FLAT WASHER		01

COMPACTOR SUPPORT


0521051423



Item	Code	Description	See page	QT
01	0521068003	RIGHT SIDE		01
02	0521068002	LEFT SIDE		01
03	0581014847	PLATE UPPER		01
04	0581015855	SLEEVE		02
05	0521068004	HANDLE BODY		01
06	0581014969	SLEEVE GUIDE		01
07	0581014968	SLEEVE FLANGE		01
08	0503010937	5/16" X 3" BOLT		02
09	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
10	0521068005	LEVER		01
11	0503010179	5/16" ZN SPRING WASHER		04
12	0503010337	5/16" NUT		04
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2" NUT		01
15	0503010847	1/2" X 3.1/4" BOLT		01
16	0503010882	5/16" X 2" BOLT		02
17	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
18	0503030878	LEVER CRANK		01
19	0581015854	RIGHT PROTECTION COVER		01
20	0581015853	LEFT PROTECTION COVER		01
21	0581015903	SPACER WASHER		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03



Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	162	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	5/16" ZN SPRING WASHER		06
07	0503010337	5/16" NUT		06

DEPTH WHEEL HUB ASSY

0511052287



Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEELS BOX		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01



www.marchesan.com.br



Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI