

PARTS CATALOG

ROW CROP PLANTERS

USAP 45-50L APT TIT SPCRR

Code: 0501092547



Series: S-0118

Rev.: 00

Date Rev.: JULHO/2019

**ORIGINAL PARTS
TATU**



PRODUCTS

Code	Description
0111140388	USAP 45E500 APT TIT SPCRR S-0118
0111140389	USAP 50E450 APT TIT SPCRR S-0118

ATTENTION: **IMPORTANT**

MARCHESAN S/A RESERVES THE RIGHT AT ANY TIME TO MAKE IMPROVEMENTS IN THE DESIGN, MATERIAL OR SPECIFICATIONS OF MACHINERY, EQUIPMENT OR PARTS WITHOUT THEREBY BECOMING LIABLE TO MAKE SIMILAR CHANGES IN MACHINERY, EQUIPMENT OR PARTS PREVIOUSLY SOLD.

INDEX


0909095355	ASSY FRAME	1
0909095357	CENTRAL FRAME	2
0909095361	RH SIDE FRAME	3
0909095359	LEFT SIDE CHASSIS	4
0909095356	FERTILIZER SEED ROW ASSY	5
0521054519	TELESCOPIC HEADER 2310 WITH FIXATIONS	6
0521054520	TELESCOPIC 9000 WITH LATCH	7
0521051435	PANTOGRAPHY HEADER	8
0511058228	HYDRAULIC CYLINDER DRAWBAR HYDRAULIC	9
0511052507	FRONT SUPPORT ASSY HOSES	10
0521051438	HEADER 3 POINTS ASSY	11
0521053048	FRENCH LEFT HAND	12
0521053049	FRENCH HAND	13
0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	14
0511051299	ROTATING RIGHT AXIS EXTENSOR	15
0501059876	ROTATING LEFT AXIS EXTENSOR	16
0511052052	TRANSPORT SUPPORT ASSY FRAME 20900	17
0521054827	CENTRAL FRAME 4686 WITH FIXER	18
0521053207	INTERNAL PLATE WITH FIXATION SCREW 1/2	19
0521052189	38,10 X 63,50 X 386 X 148 HYDRAULIC CYLINDER	20
0521053211	LEFT LONG ROW ASSY	21
0521053210	RIGHT LONG ROW	22
0521053278	LEFT LONG ROW ASSY	23
0521053590	LEFT LONG ROW ASSY	24
0521053111	LEFT SHORT SEED ROW FRONT	25
0521053113	FRONT LINE SEED SHORT	26
0521053114	SHORT SEED ROW FRONT	27
0521053112	INTERNAL FRONT LONG SEED LINE	28
0521053199	LEFT REAR	29
0521053198	RIGHT REAR	30
0511057159	TRANSMISSION BOX SEED LINE	31
0501052769	BEARING WITH 17Z GEAR	32
0501055112	MICRO GRANULATED CHAIN TENSIONER	33
0501053826	BEARING WITH 17Z GEAR	34
0501057684	SIDE BEARING FRONT SUPPORT SEED LINE	35
0501053566	BEARING SEED LINE	36
0501058108	5/8"AXLE	37
0511051693	BASE FIXING SYSTEM	38
0501059632	DDD SEED 15X15 LEFT	39
0501054167	BOX DDD ASSY DPL 15 RIGHT	40
0501054168	BOX DDD ASSY DPL 15 LEFT	41
0511055383	SEED SYSTEM ASSY	42
0521052157	DEPTH ASSY QUICK REGULATOR	43
0521051424	WHEEL SYSTEM DEPTH / COMPACTOR QUICK ADJUSTMENT	44
0501056769	DEPTH WHEELS REGULATOR ASSY	45
0521051423	COMPACTOR SUPPORT	46
0501052908	COMPACTOR WHEEL WITH BEARING	47
0511050077	WHEEL STRIPED	48
0511052287	DEPTH WHEEL HUB ASSY	49
0521053051	LOWER CONDUTOR ASSY	50
0521053052	LOWER CONDUTOR ASSY	51
0521052142	DISC CUT DPL 20 ASSY	52
0521052141	ASSY LOWER SUPPORT DPL 20	53
0511052024	FAST CLOSING SET	54
0521053592	ASSY HEX AXLE	55
0521053213	CENTRAL SHAFT AXLE	56
0521053036	CENTRAL WHEEL 385 WITHOUT GREATER TRANSMISSION	57
0521053038	CENTRAL WHEEL 385 WITHOUT RIGHT TRANSMISSION	58
0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	59
0521053040	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION LARGER	60
0521051436	BOX ECU APT TVT WITH CHANGE	61

INDEX

0521053055	SEED SILO CENTRAL SUPPORT	62
0521053329	ASSY SILO CENTRAL SUPPORT	63
0521051401	ASSY ARTICULATED CONDUCTOR SUPPORT BASE	64
0521051407	FIXER SILO FERTILIZER	65
0521053221	JOINT HANDRAIL SET	66
0521053064	CENTRAL HANDRAIL	67
0521053065	CENTRAL HANDRAIL LEFT	68
0511059383	INTERNAL FIXER ASSY HANDLE	69
0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	70
0521053222	PLATFORM ASSY CENTER FRAME 4686	71
0521053057	ARM JOINT LEFT ASSY	72
0521053058	ARM JOINT RIGHT ASSY	73
0521053212	FRAME 22500 ARTICULATED ARM CYLINDER ASSY	74
0521053215	SET HIDRAULICO	75
0521055280	CENTRAL BLOCK SUPPORT WITH FIXATION	76
0521055201	DIVIDER VALVE TRIPLE (17,163,025,002) WITH NIPPLES	77
0521053216	CENTRAL DUTY ASSEMBLY	78
0521054021	HOSE KIT LEVANTE CSC FRAME 20226	79
0521054020	ASSY HOSE ARTICULATED CSC FRAME 20226	80
0521054018	ASSY HEAD HOSE CSC FRAME 20226	81
0521054012	ASSY HOSE APT FRAME 20226	82
0501053834	MALE QUICK COUPLING AGRICULTURAL WITH COVER - 1/2 NPT	83
0521052134	SUPPORT BLOCK COMMAND	84
0521053214	CENTRAL TRACK ASSEMBLY	85
0521053591	CENTRAL CHUTE ASSEMBLY	86
0521054066	ISOBUS ELECTRICAL ASSEMBLY	87
0521053068	MOTOR SUPPORT APT ASSY	88
0511052600	STRETCHER HYDRAULIC MOTOR SUPPORT	89
0521053593	ISOBUS 50L45 ASSEMBLY WITH SEED MONITOR	90
0521053317	ASSY ISOBUS 45L/50 MONITOR WITH SEED	91
0503062835	KIT INTELLIAG 50 LINES 45/50 WITH MONITOR 010081011	92
0503062773	KIT INTELLIAG 45L/50 WITH MONITOR E 010080932	93
0521050826	BLOCK LIMITATION ASSY FLOW	94
0511056973	PARKER OMP 80 HYDRAULIC MOTOR WITH VALVE	95
0511056972	FILTER HYDAC	96
0521053249	SET LABEL ADHESIVE	97
0521053067	ASSY SENSOR LEVANTE APT WHEELSET MAJOR	98
0521053583	SIDE SEX SIDE AXLE	99
0521053282	SIDE SEX SIDE AXLE	100
0521053046	SIDE WHEEL WITHOUT TRANSMISSION LARGER	101
0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	102
0521053338	RIGHT MOUTH SUPPORT 10 MOUTH ASSY	103
0521053022	PRESS SUPPORT UPPER RIGHT	104
0521053021	PRESS SUPPORT UPPER RIGHT	105
0521053027	SHOE WITH SIDE SUPPORT SILO FIXING	106
0521053054	ASSY SIDE HANDLE	107
0521053584	ASSY PLATFORM SIDE	108
0521053281	LEFT SIDE PLATFORM	109
0521053586	RIGHT SIDE HANDRAIL	110
0521053286	FRONT SIDE CORRIMAO	111
0521053326	RIGHT SIDE HANDRAIL	112
0521053327	RIGHT SIDE HANDRAIL	113
0521053328	RIGHT SIDE HANDRAIL	114
0521053337	RIGHT SIDE HANDRAIL	115
0521053029	FRONT SIDE CORRIMAO	116
0521053030	FRONT SIDE CORRIMAO	117
0521053032	FRONT SIDE CORRIMAO	118
0511053320	ASSY SIDE LADDER	119
0521053588	SIDE CHUTE ASSEMBLY	120
0521053279	SIDE SHAFT ASSEMBLY	121

INDEX


0521053630	RIGHT SIDE DUTY ASSEMBLY		122
0521053209	RIGHT SIDE DUTY ASSEMBLY		123
0521053589	ASSY LABEL ADHESIVE SIDE FRAME		124
0521053250	SET LABEL ADHESIVE		125
0521053330	SUPPORT LEFT SIDE 10 MOUTHS ASSY		126
0521053023	SIDE SUPPORT		127
0521053020	SIDE SUPPORT		128
0521053587	LEFT SIDE HANDRAIL		129
0521053280	LEFT SIDE CORRIMAO		130
0521053096	ASSY SIDE FRAME HANDRAIL FIXER		131
0521053341	LEFT SIDE HANDRAIL		132
0521053053	LEFT SIDE CORRIMAO		133
0521053342	LEFT SIDE HANDRAIL		134
0521053629	LEFT SIDE CORRIMAO		135
0521053283	LEFT SIDE DUTY ASSEMBLY		136
0521053066	PLATFORM SUPPORT ASSY		137
0511057011	SUPPORT GUTTER ASSY		138
0521050525	FIXER FERTILIZER CONDUCTOR		139
0521054882	FLASHLIGHT WITH SUPPORT		140
0521053672	LIGHTHOUSE ASSY		141




Item	Code	Description	See page	45	E450/50	E500
01	0521048829	CENTRAL CHASSIS		01	00	
02	0521048825	CENTRAL CHASSIS		00	01	
03	0521048830	RH SIDE FRAME		01	00	
04	0521048826	SIDE CHASSIS RIGHT		00	01	
05	0521048831	SIDE CHASSIS LEFT		00	01	
06	0521048828	SIDE CHASSIS LEFT		01	00	
07	0521054519	TELESCOPIC HEADER 2310 WITH FIXATIONS	6	01	01	
08	0521054520	TELESCOPIC 9000 WITH LATCH	7	01	01	
09	0521068718	TRANSPORT LOCK 1250		01	01	
10	0521051435	PANTOGRAPHY HEADER	8	01	01	
11	0521051438	HEADER 3 POINTS ASSY	11	01	01	
12	0521053048	FRENCH LEFT HAND	12	01	01	
13	0521053049	FRENCH HAND	13	01	01	
14	0511052052	TRANSPORT SUPPORT ASSY FRAME 20900	17	01	01	

CENTRAL FRAME

0909095357




Item	Code	Description	See page	45	E450/50	E500
01	0521054827	CENTRAL FRAME 4686 WITH FIXER	18	01	01	
02	0909095356	FERTILIZER SEED ROW ASSY	5	10	09	
03	0521053592	ASSY HEX AXLE	55	01	00	
04	0521053213	CENTRAL SHAFT AXLE	56	00	01	
05	0521053036	CENTRAL WHEEL 385 WITHOUT GREATER TRANSMISSION	57	02	02	
06	0521053038	CENTRAL WHEEL 385 WITHOUT RIGHT TRANSMISSION	58	02	02	
07	0521051436	BOX ECU APT TVT WITH CHANGE	61	01	01	
08	0521053055	SEED SILO CENTRAL SUPPORT	62	01	00	
09	0521053329	ASSY SILO CENTRAL SUPPORT	63	00	01	
10	0521053221	JOINT HANDRAIL SET	66	01	01	
11	0521053222	PLATFORM ASSY CENTER FRAME 4686	71	01	01	
12	0521053057	ARM JOINT LEFT ASSY	72	01	01	
13	0521053058	ARM JOINT RIGHT ASSY	73	01	01	
14	0521053212	FRAME 22500 ARTICULATED ARM CYLINDER ASSY	74	01	01	
15	0521053215	SET HIDRAULICO	75	01	01	
16	0521053214	CENTRAL TRACK ASSEMBLY	85	01	00	
17	0521053591	CENTRAL CHUTE ASSEMBLY	86	00	01	
18	0521054066	ISOBUS ELECTRICAL ASSEMBLY	87	01	01	
19	0521053068	MOTOR SUPPORT APT ASSY	88	01	01	
20	0521053593	ISOBUS 50L45 ASSEMBLY WITH SEED MONITOR	90	01	00	
21	0521053317	ASSY ISOBUS 45L/50 MONITOR WITH SEED	91	00	01	
22	0521053249	SET LABEL ADHESIVE	97	01	01	
23	0521053067	ASSY SENSOR LEVANTE APT WHEELSET MAJOR	98	01	01	




Item	Code	Description	See page	50 E450/45	E500
01	0501110927	FRAME RIGHT WITH GLOVE 8868		01	01
01A	0521069391	RIGHT SIDE FRAME 7770 8868		01	01
01B	0581012179	DRIVER ROCKING SLEEVE		02	02
02	0909095356	FERTILIZER SEED ROW ASSY	5	20	18
03	0521053583	SIDE SEX SIDE AXLE	99	01	00
04	0521053282	SIDE SEX SIDE AXLE	100	00	01
05	0521053046	SIDE WHEEL WITHOUT TRANSMISSION LARGER	101	02	02
06	0501047886	ROD STOP		04	04
07	0521053338	RIGHT MOUTH SUPPORT 10 MOUTH ASSY	103	01	00
08	0521053022	PRESS SUPPORT UPPER RIGHT	104	00	01
09	0521053329	ASSY SILO CENTRAL SUPPORT	63	01	00
10	0521053021	PRESS SUPPORT UPPER RIGHT	105	00	01
11	0521053027	SHOE WITH SIDE SUPPORT SILO FIXING	106	08	06
12	0521053054	ASSY SIDE HANDLE	107	01	01
13	0521053584	ASSY PLATFORM SIDE	108	01	00
14	0521053281	LEFT SIDE PLATFORM	109	00	01
15	0521053586	RIGHT SIDE HANDRAIL	110	01	00
16	0521053286	FRONT SIDE CORRIMAO	111	00	01
17	0511053320	ASSY SIDE LADDER	119	01	01
18	0521053588	SIDE CHUTE ASSEMBLY	120	01	00
19	0521053279	SIDE SHAFT ASSEMBLY	121	00	01
20	0521053630	RIGHT SIDE DUTY ASSEMBLY	122	01	00
21	0521053209	RIGHT SIDE DUTY ASSEMBLY	123	00	01
22	0521053068	MOTOR SUPPORT APT ASSY	88	01	01
23	0521053589	ASSY LABEL ADHESIVE SIDE FRAME	124	01	00
24	0521053250	SET LABEL ADHESIVE	125	00	01

LEFT SIDE CHASSIS


0909095359




Item	Code	Description	See page	45	E450/50	E500
01	0501110928	LEFT FRAME WITH GLOVE 8868		01	01	
01A	0521069392	LEFT SIDE FRAME 8868		01	01	
01B	0581012179	DRIVER ROCKING SLEEVE		02	02	
02	0909095356	FERTILIZER SEED ROW ASSY	5	20	18	
03	0521053583	SIDE SEX SIDE AXLE	99	01	00	
04	0521053282	SIDE SEX SIDE AXLE	100	00	01	
05	0521053046	SIDE WHEEL WITHOUT TRANSMISSION LARGER	101	02	02	
06	0501047886	ROD STOP		04	04	
07	0521053330	SUPPORT LEFT SIDE 10 MOUTHS ASSY	126	01	00	
08	0521053023	SIDE SUPPORT	127	00	01	
09	0521053329	ASSY SILO CENTRAL SUPPORT	63	01	00	
10	0521053020	SIDE SUPPORT	128	00	01	
11	0521053027	SHOE WITH SIDE SUPPORT SILO FIXING	106	08	06	
12	0521053054	ASSY SIDE HANDLE	107	01	01	
13	0521053584	ASSY PLATFORM SIDE	108	01	00	
14	0521053281	LEFT SIDE PLATFORM	109	00	01	
15	0521053587	LEFT SIDE HANDRAIL	129	01	00	
16	0521053280	LEFT SIDE CORRIMAO	130	00	01	
17	0511053320	ASSY SIDE LADDER	119	01	01	
18	0521053588	SIDE CHUTE ASSEMBLY	120	01	00	
19	0521053279	SIDE SHAFT ASSEMBLY	121	00	01	
20	0521053629	LEFT SIDE CORRIMAO	135	01	00	
21	0521053283	LEFT SIDE DUTY ASSEMBLY	136	00	01	
22	0521053068	MOTOR SUPPORT APT ASSY	88	01	01	
23	0521053589	ASSY LABEL ADHESIVE SIDE FRAME	124	01	00	
24	0521053250	SET LABEL ADHESIVE	125	00	01	




Item	Code	Description	See page	QT
01	0521053211	LEFT LONG ROW ASSY	21	01
02	0521053210	RIGHT LONG ROW	22	01
03	0521053278	LEFT LONG ROW ASSY	23	01
04	0521053590	LEFT LONG ROW ASSY	24	01
05	0521053113	FRONT LINE SEED SHORT	26	01
06	0521053111	LEFT SHORT SEED ROW FRONT	25	01
07	0521053114	SHORT SEED ROW FRONT	27	01
08	0521053112	INTERNAL FRONT LONG SEED LINE	28	01
09	0521053198	RIGHT REAR	30	01
10	0521053199	LEFT REAR	29	01
11	0511055383	SEED SYSTEM ASSY	42	01
12	0521052157	DEPTH ASSY QUICK REGULATOR	43	01
13	0521051424	WHEEL SYSTEM DEPTH / COMPACTOR QUICK ADJUSTMENT	44	01
14	0521053051	LOWER CONDUTOR ASSY	50	01
15	0521053052	LOWER CONDUTOR ASSY	51	01
16	0521052142	DISC CUT DPL 20 ASSY	52	01
17	0503062066	DISC SET WITH CORN RING		50
18	0503062067	DISC SET / RING SOY 90F TITANIUM		50
19	0531013600	PRESS ADJUSTMENT LEVER		01
20	0511052024	FAST CLOSING SET	54	50




Item	Code	Description	See page	QT
01	0503010027	SPRING WASHER		04
02	0503010013	5/8" NUT		04
03	0503010002	1800 GREASE FITTING		02
04	0521051433	ATTACHMENT BAR REAR AXLE		02
04A	0511069442	ATTACHMENT BAR REAR AXLE		01
04B	0581014420	SLEEVE GUIDE		02
04C	0503010038	3/16 X 2 COTTERPIN		01
04D	0501017779	FLAT WASHER		01
04E	0503011052	1.1/4" X 0.77" CASTLE NUT		01
05	0521069402	2310 HEADER TELESCOPIC		01
06	0501012140	FLAT WASHER		08
07	0503010233	5/8" X 2-1/2" BOLT		04
08	0503011052	1.1/4" X 0.77" CASTLE NUT		03
09	0521011688	FLAT WASHER		03
10	0521068715	1210 HEADER AXIS TELESCOPIC		02
11	0503010010	1/4" X 2.1/2" COTTERPIN		03
12	0521068716	AXIS HEADER TELESCOPIC WITHOUT GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521068723	INTERNAL CANUD EARS FIXING		01
02	0503010523	1/4" X 2" COTTERPIN		04
03	0521011132	FLAT WASHER		04
04	0571013059	PIVOT SHAFT LOCK		01
05	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
06	0511054270	TENSIONER SPRING		01
06A	0511069520	TELESC LOCK SPRING TENSIONER		01
06B	0503010013	5/8" NUT		02
07	0521068719	LOCK		01
08	0503010002	1800 GREASE FITTING		01
09	1902010477	UPPER CLAMP BODY		01
10	0503010180	7/16" SPRING WASHER		01
11	0503011135	7/16" X 1-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0521062955	SEED ARM SUPPORT ROW		01
02	0501079585	ARM USAP		01
03	0521063433	EAR ARM PANTOGRAPH WITH LOOK		01
04	0521063434	EAR ARM PANTOGRAPH		01
05	0502040864	GEAR BOX		01
06	0521068007	TRACTOR HITCH		01
07	1902040327	LOCK SLEEVE		01
08	0521010578	COUPLING SHAFT		01
09	0503010523	1/4" X 2" COTTERPIN		01
10	0521063432	LOCK AXLE		02
11	0521063022	AXLE LOWER		04
12	0571011013	AXLE ARM		01
13	0503012198	3/16" X 2" COTTERPIN		07
14	0503010002	1800 GREASE FITTING		04
15	0501019435	FLAT WASHER		12
16	0503031035	HAIR PIN		02
17	0511058228	HYDRAULIC CYLINDER DRAWBAR HYDRAULIC	9	01
18	0511052507	FRONT SUPPORT ASSY HOSES	10	01
19	0501081848	HOSE 3/8 X 3200 TR-TM USAP		02
20	0503011052	1.1/4" X 0.77" CASTLE NUT		02
21	0501010307	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521062362	CYLINDER CASE		01
02	0521062361	ROD CILINDER DRAWBAR HYDRAULIC		01
03	0503010002	1800 GREASE FITTING		02
04	0503030384	CON N-001 PLUG		02
05	0503010817	1-1/4" SELF-ADJUSTING NUT		01
06	0503010345	2-218 N 3006-9B O'RING		01
07	0502010382	5" HEAD		01
08	0581010353	RING SUPPORT		01
09	0503018026	1870-2000-375 B GASKET		01
10	0503011453	O'RING		02
11	0503018152	O'RING		02
12	0503018024	RING BS		01
13	0503018025	RING GUIDE		01
14	0581010354	PISTON		01
15	0503018150	RING GUIDE		01
16	0503018151	RING BS		02
17	0503010039	D-2000 SCRAPER RING		01




Item	Code	Description	See page	QT
01	0521066319	FIXATION FRONT SUPPORT		01
02	0503010019	1/2" SPRING WASHER		01
03	0503014007	1/2" X 1-1/4" BOLT		01




Item	Code	Description	See page	QT
01	0561013456	GUIDE DRAWBAR ASSY		02
02	0501010276	1" X 3" BOLT		04
03	0503010012	1" SPRING WASHER		04
04	0501010059	1.5/8 NUT		04
05	0503030119	LOCK PIN		02
06	0511069471	PLOUGH SUPPORT		02
07	0501011075	PIN		02
08	0503030285	HAIR PIN		02
09	0521068020	DRAWBAR ASSY		01
10	0503030085	LOCK PIN		04
11	0521068018	UPPER AXLE		01
12	0521068015	UPPER AXLE		01
13	0521068013	UPPER AXLE		01
14	0521068011	AXLE LOWER		02
15	0521068010	HITCH AXLE		01
16	0521068009	UPPER AXLE		01
17	0503031035	HAIR PIN		01




Item	Code	Description	See page	QT
001	0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	14	01
002	1902010477	UPPER CLAMP BODY		10
003	0503010180	7/16" SPRING WASHER		10
004	0503011135	7/16" X 1-1/2" BOLT		10
005	0501012803	FLAT WASHER		05
006	0581017304	FRENCH HAND CHUTE 20 X 38 X 2180		03
007	0503010002	1800 GREASE FITTING		01
008	0521068724	FRENCH HAND 7545		01
009	0521053050	ASSY RAIL GUIDE		02
009A	0571011891	GUIDE RAIL		01
009B	0501010694	FLAT WASHER		02
009C	0503010179	SPRING WASHER		02
009D	0503010337	5/16" NUT		02
009E	0503011952	5/16" X 3/4" BOLT		02
010	0501059876	ROTATING LEFT AXIS EXTENSOR	16	01
011	0501082189	HOSE 1/2 X 160 TR-TR		02
012	0501082190	HOSE 3/8 X 160 TR-TR		02
013	0521069202	OIL DUCT R.7/8 X 3230		04
014	0521069201	OIL DUCT R.3/4 X 3230		04




Item	Code	Description	See page	QT
001	0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	14	01
002	0503010180	7/16" SPRING WASHER		05
003	1902010477	UPPER CLAMP BODY		05
004	0503011135	7/16" X 1-1/2" BOLT		05
005	0503010002	1800 GREASE FITTING		01
006	0521068724	FRENCH HAND 7545		01
007	0511051299	ROTATING RIGHT AXIS EXTENSOR	15	01
008	0501082208	HOSE 3/4 X 180 TR-TR		02
009	0521069203	OIL DUCT R.1.1 / 16 X 3230		04




Item	Code	Description	See page	QT
01	0521062244	PIVOT SHAFT		01
02	0551019529	FLAT WASHER		01
03	0503010027	SPRING WASHER		01
04	0503011267	5/8" X 1.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0521062617	NUT FIXER		01
02	0503010002	1800 GREASE FITTING		02
03	0501078990	TURNBUCLE AXLE		01
04	0561019879	LOCK ATTACHMENT BAR		01




Item	Code	Description	See page	QT
01	0501078991	NUT FIXER		01
02	0503010002	1800 GREASE FITTING		02
03	0501078990	TURNBUCLE AXLE		01
04	0561019879	LOCK ATTACHMENT BAR		01




Item	Code	Description	See page	QT
01	0521063339	HIGHER		06
02	0571011070	5/8" UNC FASTENER		06
03	0503010027	SPRING WASHER		12
04	0503010013	5/8" NUT		12




Item	Code	Description	See page	QT
01	0521069471	BIGGEST CENTRAL FRAME 4500		01
02	0501010276	1" X 3" BOLT		16
03	0503010012	1" SPRING WASHER		16
04	0503012182	1" NUT		16
05	0571012964	AXLE BODY WHEELS PIVOT		02
06	0501010630	1.1/2" CASTLE NUT		02
07	0503011345	1/4" X 3-1/2" COTTERPIN		02
08	0521053207	INTERNAL PLATE WITH FIXATION SCREW 1/2	19	01
09	0502010477	UPPER CLIP		01
10	0503010180	7/16" SPRING WASHER		01
11	0503011135	7/16" X 1-1/2" BOLT		01
12	0521052189	38,10 X 63,50 X 386 X 148 HYDRAULIC CYLINDER	20	01




Item	Code	Description	See page	QT
01	0561017061	TUBE ADJUSTMENT PLATE		01
02	0503010019	1/2" SPRING WASHER		08
03	0501010161	1/2" X 1.1/4" BOLT		08




Item	Code	Description	See page	QT
01	0521068383	CYLINDER CASE		01
02	0581010670	CORPO HASTE 38,10 X 345		01
03	0511070058	GUIDE HIDRAULIC		01
04	0503010163	D-1500 SCRAPER RING		01
05	0502010471	MOBILE COVER		01
06	0581010668	RING SUPPORT		01
07	0503018004	RING		01
08	0503018003	GASKET		01
09	0503018163	BACK-UP RING		02
10	0503018162	O'RING		02
11	0503030385	CYLINDER PLUG N-002		02
12	0502012837	PISTON		01
13	0503018005	RING		01
14	0503011109	2-119 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
001	0521053111	LEFT SHORT SEED ROW FRONT	25	01
002	0521053199	LEFT REAR	29	01




Item	Code	Description	See page	QT
001	0521053113	FRONT LINE SEED SHORT	26	01
002	0521053198	RIGHT REAR	30	01



Item	Code	Description	See page	QT
001	0521053114	SHORT SEED ROW FRONT	27	01
002	0521053198	RIGHT REAR	30	01




Item	Code	Description	See page	QT
001	0521053112	INTERNAL FRONT LONG SEED LINE	28	01
002	0521053199	LEFT REAR	29	01




Item	Code	Description	See page	QT
001	0503010027	SPRING WASHER		01
002	0503010003	1845 GREASE FITTING		04
003	0521066168	CHASSIS SEED LINE		01
004	0571012310	ROW LOCK BODY		01
005	0551015826	SEED ROW LOCK GUIDE SLEEV		01
006	0501012140	FLAT WASHER		01
007	0503010232	5/8" X 1.3/4" BOLT		01
008	0503010013	5/8" NUT		01
009	1902012568	UPPER ROCKER ARM		01
010	0503030168	HAIR PIN		04
011	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
012	0503033728	PINO FIXER SPRING		02
013	0571014704	UPPER AXLE		01
014	0561014215	BEARING COVER LOWER ROW FRAME		01
015	0502012768	CLAMP UPPER		02
016	0571012013	TRANSPORT LOCK		01
017	0503010019	1/2" SPRING WASHER		01
018	0503010060	1/2" NUT		01
019	0503010479	1/2" X 3" BOLT		01
020	0581014932	SLEEVE ARM LINE SEED		08
021	0503010811	5/8" UNF SELF ADJUSTING NUT		04
022	0503019024	5/8" X 3" BOLT		04
023	0581014926	SEED ARM SUPPORT ROW		01
024	0581014927	LOWER BOTTOM ARM (123,7)		01
025	0503019025	SCREW 5/8 UNF X 8 C S RP G.5 ZN		04
026	0503010025	3/8 SPRING WASHER		02
027	0503010026	3/8" NUT		02
028	0501011643	3/8 X 1" BOLT		02
029	0521068452	UP SUPPORT		01
030	0503010878	5/8" SELF ALIGNING NUT		04
031	0511057159	TRANSMISSION BOX SEED LINE	31	01

Item	Code	Description	See page	QT
032	0501052769	BEARING WITH 17Z GEAR	32	01
033	0501055112	MICRO GRANULATED CHAIN TENSIONER	33	01
034	0501053826	BEARING WITH 17Z GEAR	34	01
035	0503013369	40-1 X 62 CHAIN LINK + REDUCTION		01
036	0561015802	13 X 10 X 14 SLEEVE		01
037	0503010178	5/16" X 7/8" BOLT		01
038	0503010421	5/16" X 1-1/2" BOLT		01
039	0503013759	NUT		02
040	0561015801	COVER PROTECTION FRAME		01
041	0501057684	SIDE BEARING FRONT SUPPORT SEED LINE	35	01
042	0501058108	5/8"AXLE	37	01
043	0503010071	3/16" X 1" COTTERPIN		01
044	0581017316	SUPPORT CONDUCTOR		01




Item	Code	Description	See page	QT
001	0503010027	SPRING WASHER		01
002	0503010003	1845 GREASE FITTING		04
003	0521066168	CHASSIS SEED LINE		01
004	0571012310	ROW LOCK BODY		01
005	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
006	0501012140	FLAT WASHER		01
007	0503010232	5/8" X 1.3/4" BOLT		01
008	0503010013	5/8" NUT		01
009	1902012568	UPPER ROCKER ARM		01
010	0503030168	HAIR PIN		04
011	0561014215	BEARING COVER LOWER ROW FRAME		01
012	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
013	0503033728	PINO FIXER SPRING		02
014	0571014704	UPPER AXLE		01
015	0502012768	CLAMP UPPER		02
016	0503010019	1/2" SPRING WASHER		01
017	0503010060	1/2" NUT		01
018	0571012014	TRANSPORT LOCK		01
019	0503010811	5/8" UNF SELF ADJUSTING NUT		04
020	0581014932	SLEEVE ARM LINE SEED		08
021	0503010479	1/2" X 3" BOLT		01
022	0503019024	5/8" X 3" BOLT		04
023	0581014929	SEED ARM SUPPORT ROW		01
024	0581014930	LOWER BOW ARM		01
025	0503019025	SCREW 5/8 UNF X 8 C S RP G.5 ZN		04
026	0503010025	3/8 SPRING WASHER		02
027	0503010026	3/8" NUT		02
028	0501011643	3/8 X 1" BOLT		02
029	0521068448	SHORT SEED ROW LARGE ASSY		01
030	0511057159	TRANSMISSION BOX SEED LINE	31	01
031	0501052769	BEARING WITH 17Z GEAR	32	01

Item	Code	Description	See page	QT
032	0501055112	MICRO GRANULATED CHAIN TENSIONER	33	01
033	0501053826	BEARING WITH 17Z GEAR	34	01
034	0503013369	40-1 X 62 CHAIN LINK + REDUCTION		01
035	0501058107	5/8" AXLE		01
036	0561015802	13 X 10 X 14 SLEEVE		01
037	0503010178	5/16" X 7/8" BOLT		01
038	0503010421	5/16" X 1-1/2" BOLT		01
039	0561015801	COVER PROTECTION FRAME		01
040	0503013759	NUT		02
041	0503010071	3/16" X 1" COTTERPIN		01
042	0503010878	5/8" SELF ALIGNING NUT		04
043	0501057684	SIDE BEARING FRONT SUPPORT SEED LINE	35	01
044	0581017314	SUPPORT CONDUCTOR AIR		01




Item	Code	Description	See page	QT
001	0503010027	SPRING WASHER		01
002	0503010003	1845 GREASE FITTING		04
003	0521066168	CHASSIS SEED LINE		01
004	0571012310	ROW LOCK BODY		01
005	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
006	0501012140	FLAT WASHER		01
007	0503010232	5/8" X 1.3/4" BOLT		01
008	0503010013	5/8" NUT		01
009	1902012568	UPPER ROCKER ARM		01
010	0503030168	HAIR PIN		04
011	0561014215	BEARING COVER LOWER ROW FRAME		01
012	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
013	0503033728	PINO FIXER SPRING		02
014	0571014704	UPPER AXLE		01
015	0502012768	CLAMP UPPER		02
016	0503010019	1/2" SPRING WASHER		01
017	0503010060	1/2" NUT		01
018	0571012014	TRANSPORT LOCK		01
019	0503010811	5/8" UNF SELF ADJUSTING NUT		04
020	0581014932	SLEEVE ARM LINE SEED		08
021	0503010479	1/2" X 3" BOLT		01
022	0503019024	5/8" X 3" BOLT		04
023	0581014929	SEED ARM SUPPORT ROW		01
024	0581014930	LOWER BOW ARM		01
025	0503019025	SCREW 5/8 UNF X 8 C S RP G.5 ZN		04
026	0503010025	3/8 SPRING WASHER		02
027	0503010026	3/8" NUT		02
028	0501011643	3/8 X 1" BOLT		02
029	0521068449	SHORT SEED ROW FRONT		01
030	0511057159	TRANSMISSION BOX SEED LINE	31	01
031	0501052769	BEARING WITH 17Z GEAR	32	01

Item	Code	Description	See page	QT
032	0501055112	MICRO GRANULATED CHAIN TENSIONER	33	01
033	0501053826	BEARING WITH 17Z GEAR	34	01
034	0503013369	40-1 X 62 CHAIN LINK + REDUCTION		01
035	0501058107	5/8" AXLE		01
036	0561015802	13 X 10 X 14 SLEEVE		01
037	0503010178	5/16" X 7/8" BOLT		01
038	0503010421	5/16" X 1-1/2" BOLT		01
039	0561015801	COVER PROTECTION FRAME		01
040	0503013759	NUT		02
041	0503010071	3/16" X 1" COTTERPIN		01
042	0503010878	5/8" SELF ALIGNING NUT		04
043	0501057684	SIDE BEARING FRONT SUPPORT SEED LINE	35	01
044	0581017314	SUPPORT CONDUCTOR AIR		01




Item	Code	Description	See page	QT
001	0503010027	SPRING WASHER		01
002	0503010003	1845 GREASE FITTING		04
003	0521066168	CHASSIS SEED LINE		01
004	0571012310	ROW LOCK BODY		01
005	0551015826	SEED ROW LOCK GUIDE SLEEV		01
006	0501012140	FLAT WASHER		01
007	0503010232	5/8" X 1.3/4" BOLT		01
008	0503010013	5/8" NUT		01
009	1902012568	UPPER ROCKER ARM		01
010	0503030168	HAIR PIN		04
011	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
012	0503033728	PINO FIXER SPRING		02
013	0571014704	UPPER AXLE		01
014	0561014215	BEARING COVER LOWER ROW FRAME		01
015	0502012768	CLAMP UPPER		02
016	0571012013	TRANSPORT LOCK		01
017	0503010019	1/2" SPRING WASHER		01
018	0503010060	1/2" NUT		01
019	0503010479	1/2" X 3" BOLT		01
020	0581014932	SLEEVE ARM LINE SEED		08
021	0503010811	5/8" UNF SELF ADJUSTING NUT		04
022	0503019024	5/8" X 3" BOLT		04
023	0581014926	SEED ARM SUPPORT ROW		01
024	0581014927	LOWER BOTTOM ARM (123,7)		01
025	0503019025	SCREW 5/8 UNF X 8 C S RP G.5 ZN		04
026	0503010025	3/8 SPRING WASHER		02
027	0503010026	3/8" NUT		02
028	0501011643	3/8 X 1" BOLT		02
029	0521068453	LONG FRONT SEED ROW		01
030	0503010878	5/8" SELF ALIGNING NUT		04
031	0511057159	TRANSMISSION BOX SEED LINE	31	01


Item	Code	Description	See page	QT
032	0501052769	BEARING WITH 17Z GEAR	32	01
033	0501055112	MICRO GRANULATED CHAIN TENSIONER	33	01
034	0501053826	BEARING WITH 17Z GEAR	34	01
035	0503013369	40-1 X 62 CHAIN LINK + REDUCTION		01
036	0561015802	13 X 10 X 14 SLEEVE		01
037	0503010178	5/16" X 7/8" BOLT		01
038	0503010421	5/16" X 1-1/2" BOLT		01
039	0503013759	NUT		02
040	0561015801	COVER PROTECTION FRAME		01
041	0501057684	SIDE BEARING FRONT SUPPORT SEED LINE	35	01
042	0501058108	5/8"AXLE	37	01
043	0503010071	3/16" X 1" COTTERPIN		01
044	0581017316	SUPPORT CONDUCTOR		01




Item	Code	Description	See page	QT
001	0511051693	BASE FIXING SYSTEM	38	01
002	0503015920	3/8" UNC X 1.3/4" BOLT		04
003	0503010025	3/8 SPRING WASHER		04
004	0503010026	3/8" NUT		04
005	0521065999	FRONT SHIELD		01
006	0503010706	1/2" X 4.1/2" BOLT		03
007	0503010019	1/2" SPRING WASHER		03
008	0503010060	1/2" NUT		03
009	0503010002	1800 GREASE FITTING		02
010	0501059632	DDD SEED 15X15 LEFT	39	01
011	0503033672	NOZZLE WITHOUT TITANIUM		01




Item	Code	Description	See page	QT
001	0501059631	DDD SEED 15" X 15" RIGHT		01
002	0511051693	BASE FIXING SYSTEM	38	01
003	0503015920	3/8" UNC X 1.3/4" BOLT		04
004	0503010025	3/8 SPRING WASHER		04
005	0503010026	3/8" NUT		04
006	0521065999	FRONT SHIELD		01
007	0503010706	1/2" X 4.1/2" BOLT		03
008	0503010019	1/2" SPRING WASHER		03
009	0503010060	1/2" NUT		03
010	0503010002	1800 GREASE FITTING		02
011	0503033672	NOZZLE WITHOUT TITANIUM		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB	01	
02	0502012464	BOX TRANSMISSION COVER	01	
03	0503016995	6006 BALL BEARING	02	
04	0503015895	6005 Z BALL BEARING	01	
05	0503010143	SPRING WASHER	03	
06	0503011378	M6 X 1" BOLT	03	
07	0503010406	501025 CLAMPING RING (FOR AXLE)	01	
08	0503010707	501030 CLAMPING RING (FOR AXLE)	02	
09	0502040856	CONICAL GEAR	01	
10	0571018870	14Z CONICAL GEAR	01	
11	0503011105	SEAL RING	01	
12	0503011409	6005 Z BALL BEARING	01	
13	0503017008	SEAL RING	01	
14	0503017007	SEAL RING	02	
15	0511017907	1/8" BSPT X 6 PLUG	01	
16	0503010003	1845 GREASE FITTING	01	




Item	Code	Description	See page	QT
01	0503010406	501025 CLAMPING RING (FOR AXLE)		01
02	0502011697	BEARING OF THE GEAR BOX		01
03	0503011410	ROLLER BEARING		01
04	0503011105	SEAL RING		01
05	0503011953	5/16" X 1" BOLT		02
06	0501010694	FLAT WASHER		02
07	0503010179	SPRING WASHER		02
08	0503010337	5/16" NUT		02
09	0502012819	17Z GEAR WITH HEX HOLE		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	1 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501052775	ROW SEED BEARING		01
01A	0502011697	BEARING OF THE GEAR BOX		01
01B	0503011410	ROLLER BEARING		01
01C	0503011105	SEAL RING		01
01D	0503010371	5/16" X 1" BOLT		02
01E	0501010694	FLAT WASHER		02
01F	0503010179	SPRING WASHER		02
01G	0503010337	5/16" NUT		02
02	0502012028	17Z GEAR WITH HEX HOLE AXLE, 0.5"		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0501053566	BEARING SEED LINE	36	01
02	0551015804	BEARING AXLE BODY		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0511059312	BEARING TRANSMISSION SEED		01
02	0503011953	5/16" X 1" BOLT		02
03	0503010179	SPRING WASHER		02
04	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
001	0551018359	5/8" X 440 AXLE BODY		01
002	0501056296	UNIVERSAL JOINT ASSY		01
003	0503011855	0.2" X 1.8" SPRING PIN		01
004	0551018358	5/8" X 74 AXLE BODY		01
005	0503011855	0.2" X 1.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502011411	10Z CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	BOX DDD ASSY DPL 15 RIGHT	40	01
04	0501054168	BOX DDD ASSY DPL 15 LEFT	41	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	COVER DEPTH		02
07	0503014729	1/4" UNF X 1/2" BOLT		06
08	0503011441	SPRING WASHER		06
09	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503011443	SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0511052302	LH SUPPORT DDD GUIDE		01
15A	0561015592	15" X 15" RIGHT DOUBLE DISC SUPPORT		01
15B	0571012491	SOCKET SEED GUIDE		01
15C	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502011930	DOUBLE DISC COULTER BOX		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019154	RIGHT DOUB DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011930	DOUBLE DISC COULTER BOX		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019148	LEFT DOUBLE DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0511055383	SEED SYSTEM ASSY	42	01
02	0511052058	SEED SYSTEM TITANIUM		01
02A	0503062031	BASE SET		01
02Aa	0503016268	BASE TITANIUM		01
02Ab	0503016269	HEX NUT		09
02B	0503062032	NECK TITANIUM ASSY		01
02Ba	0503016270	NECK TITANIUM ASSY		01
02Bb	0503016271	ALLEN BOLT		05
02C	0503062033	OPPOSITE BASE SET		01
02D	0503062034	CENTRAL ADAPTER SET		01
02E	0503062035	SET FALSE ADAPT CENTER		01
02F	0503062036	SUBSET SET LOCK BASE		01
02G	0503062037	SUBSET ESCOVAFLEX SET		01
02H	0503062038	SET ANTI-LEAP		01
02I	0503062039	POLIFLOW TITANIUM ASSY		01
02J	0503062040	DISPLAY ASSY TITANIUM 1050010		01
02K	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
02L	0503062042	SET BOLT ARTICULADOR		01
02La	0503016282	ALLEN BOLT		01
02Lb	0503016283	M8 NUT HEX		02
02M	0503062043	SET LIMIT WEIGHT		01
03	0503062219	SEED BOX		01
04	0503010358	5/16" X 5/8" BOLT		05
05	0501010694	FLAT WASHER		05
06	0503010179	SPRING WASHER		05
07	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0503010581	RING		01
04	0581014858	DEPTH WHEEL AXLE		01
05	0501110720	ARM,LEFT		01
06	0501110719	DEPTH CONTROL RIGHT ARM		01
07	0503010002	1800 GREASE FITTING		02
08	0501056769	DEPTH WHEELS REGULATOR ASSY	45	01
09	0521051423	COMPACTOR SUPPORT	46	01
10	0503034793	ARTICULATION SLEEVE		02
11	0571017749	FLAT WASHER		02
12	0503010311	1/2" X 1-1/4" BOLT		02
13	0503010019	1/2" SPRING WASHER		08
14	0503010740	1/2" X 2" BOLT		02
15	0503010060	1/2" NUT		02
16	0501052908	COMPACTOR WHEEL WITH BEARING	47	02
17	0503013739	1/2" X 1" BOLT		02
18	0511050077	WHEEL STRIPED	48	02
19	0503016453	1/2" X 2.1/2 BOLT		02
20	0503030805	1.6" X 6" X 0.2"TRACTION SPRING		01
21	0502012884	EXTENSION		01
22	0503010028	1/2" NUT		02
23	0503010256	3/8" X 3/4" BOLT		01




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0581014858	DEPTH WHEEL AXLE		01
04	0501110720	ARM,LEFT		01
05	0501110719	DEPTH CONTROL RIGHT ARM		01
06	0502012663	EXTENSION		01
07	0503010002	1800 GREASE FITTING		02
08	0501056769	DEPTH WHEELS REGULATOR ASSY	45	01
09	0503034793	ARTICULATION SLEEVE		02
10	0521051423	COMPACTOR SUPPORT	46	01
11	0571017749	FLAT WASHER		02
12	0503010311	1/2" X 1-1/4" BOLT		02
13	0503016453	1/2" X 2.1/2 BOLT		02
14	0503034817	SPRING		01
15	0503010581	RING		01
16	0503034377	SCREEW 3/8 UNC X 3/4		01
17	0503010019	1/2" SPRING WASHER		08
18	0503010740	1/2" X 2" BOLT		02
19	0503010060	1/2" NUT		04
20	0501052908	COMPACTOR WHEEL WITH BEARING	47	02
21	0503013739	1/2" X 1" BOLT		01
22	0511050077	WHEEL STRIPED	48	02
23	0503010752	1/2" X 3.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0503010257	1/8" X 1" COTTERPIN		01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0502011689	1/8" DEPTH CONTROL LEVER		01
04	0502011688	SEED SIST CONTROL DEPTH LEVER		01
05	0511065582	DEPTH WHEEL STOP		01
06	0503030975	0.9" X 1.5" X 0.1" SPRING		01
07	0511015976	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521068003	RIGHT SIDE		01
02	0521068002	LEFT SIDE		01
03	0581014847	PLATE UPPER		01
04	0581015855	SLEEVE		02
05	0521068004	HANDLE BODY		01
06	0581014969	SLEEVE GUIDE		01
07	0581014968	SLEEVE FLANGE		01
08	0503010937	5/16" X 3" BOLT		02
09	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
10	0521068005	LEVER		01
11	0503010179	SPRING WASHER		04
12	0503010337	5/16" NUT		04
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2" NUT		01
15	0503010847	1/2" X 3.1/4" BOLT		01
16	0503010882	5/16" X 2" BOLT		02
17	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
18	0503030878	LEVER CRANK		01
19	0581015854	RIGHT PROTECTION COVER		01
20	0581015853	LEFT PROTECTION COVER		01
21	0581015903	SPACER WASHER		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	49	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	SPRING WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEELS BOX		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
001	0503034678	COUPLING SET		01
002	0581017319	TUBE PVC		01
003	0521065815	GUIDE SUPPORT		01
004	0503010071	3/16" X 1" COTTERPIN		01
005	0501011643	3/8 X 1"BOLT		01
006	0503017823	THREAD CLAMP WITHOUT END 14MM WIDTH		02
007	0521068727	FERTILIZER CONDUCTOR FIXER		01
008	0503013759	NUT		01
009	0503010365	NUT		01
010	0581017313	SEED CONDUCTOR		01
011	0521050525	FIXER FERTILIZER CONDUCTOR	139	02
012	0503013357	3/8" SELF-ADJUSTING NUT		01




Item	Code	Description	See page	QT
001	0581017317	TUBE PVC		01
002	0521065815	GUIDE SUPPORT		01
003	0503010071	3/16" X 1" COTTERPIN		01
004	0501011643	3/8 X 1"BOLT		01
005	0581017313	SEED CONDUCTOR		01
006	0521050525	FIXER FERTILIZER CONDUCTOR	139	02
007	0503013759	NUT		01
008	0503034678	COUPLING SET		01
009	0503017823	THREAD CLAMP WITHOUT END 14MM WIDTH		02
010	0521068727	FERTILIZER CONDUCTOR FIXER		01
011	0503010365	NUT		01
012	0503013357	3/8" SELF-ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0502012470	BALDE DISC UPPER SUPPORT		01
02	0511016156	5/8" X 1.1/2" BOLT		02
03	0521052141	ASSY LOWER SUPPORT DPL 20	53	01
04	0503012798	5/8" X 2" BOLT		04
05	0503010878	5/8" SELF ALIGNING NUT		04




Item	Code	Description	See page	QT
01	0503031575	2.5"X 12" X 0.5" COMPRESSION SPRING		02
02	0551015883	SPRING GUIDES SLEVE		02
03	0503010002	1800 GREASE FITTING		02
04	0561014164	SUPPORT DISC AXLE		01
05	0571012370	PROTECTION FRONT		01
06	0502012713	BOTTOM BRACKET		01
07	0571012371	SLEEVE 20 X 34,93 X 130		01
08	0503010361	SPRING PIN		01
09	0521068323	LEFT ARM		01
10	0521068322	RIGHT ARM		01
11	0511058648	BOX WITH DISC BLADE 20"		01
12	0521068189	SPRING REGULACION		02
13	0501012140	FLAT WASHER		02
14	0503010179	SPRING WASHER		02
15	0503010295	5/16" X 5/8" BOLT		02
16	0503010152	3/4" UNF SELF ADJUSTINGNTE NUT		01
17	0503010806	5/8" X 3" BOLT		02
18	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT		01
19	0503011075	NUT		02
20	0503010878	5/8" SELF ALIGNING NUT		02



Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
001	0571013341	HEX AXLE		02
002	0561015837	SLEEVE 31,75 X SEXT 19,80/20 X 90		01
003	0503010523	1/4" X 2" COTTERPIN		01
004	0511054314	TRANSMISSION AXLE FULL TRANSMISSION GLOVE		26
004A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
004B	0503010256	3/8" X 3/4" BOLT		01
005	0521063774	GEAR ASSY		01



Item	Code	Description	See page	QT
001	0561016761	3/4 X 1900 HEX AXLE		01
002	0561016762	3/4 X 2390 HEX AXLE		01
003	0561015837	SLEEVE 31,75 X SEXT 19,80/20 X 90		01
004	0503010523	1/4" X 2" COTTERPIN		01
005	0511054314	TRANSMISSION AXLE FULL TRANSMISSION GLOVE		24
005A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
005B	0503010256	3/8" X 3/4" BOLT		01
006	0521063774	GEAR ASSY		01

CENTRAL WHEEL 385 WITHOUT GREATER TRANSMISSION


0521053036




Item	Code	Description	See page	QT
01	0511061810	HYDRAULIC CYLINDER FRANGE	02	
02	0551014508	FLAT WASHER	01	
03	0551014511	CARRYING WEELS AXLE SLEVE GUIDES	02	
04	0501018466	FLAT WASHER	02	
05	0561019929	FLAT WASHER	01	
06	0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	59	01
07	0503033458	CURRENT 6 X 17 ELOS		01
08	0521068707	LARGER CENTRAL WHEELED FORK		01
09	0521053037	TIRE WITH WHEEL 15 X 19,50 14 LONAS		01
10	0521053040	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION 60 LARGER		01
11	0581017245	AXLE BODY		01
12	0521068710	JOINT SHAFT WHEELED GREATER CENTRAL		01
13	0521068712	LARGER SUPPORT LEFT WHEELED CENTRAL		01
14	0501010630	1.1/2" CASTLE NUT		01
15	0501010694	FLAT WASHER		02
16	0501017779	FLAT WASHER		02
17	0503010002	1800 GREASE FITTING		02
18	0503010003	1845 GREASE FITTING		02
19	0503010010	1/4" X 2.1/2" COTTERPIN		04
20	0503010019	1/2" SPRING WASHER		04
21	0503010023	SPRING WASHER		06
22	0503010060	1/2" NUT		04
23	0503010337	5/16" NUT		01
24	0503010882	5/16" X 2" BOLT		01
25	0503010920	1/2" X 1.1/2" BOLT		04
26	0503011052	1.1/4" X 0.77" CASTLE NUT		02
27	0503011345	1/4" X 3-1/2" COTTERPIN		01
28	0503013394	3/4" X 3" BOLT		06
29	0503019247	NUT 3/4 NC S G.8		06

CENTRAL WHEEL 385 WITHOUT RIGHT TRANSMISSION


0521053038




Item	Code	Description	See page	QT
01	0511061810	HYDRAULIC CYLINDER FRANGE	02	
02	0551014508	FLAT WASHER	01	
03	0551014511	CARRYING WEELS AXLE SLEVE GUIDES	02	
04	0501018466	FLAT WASHER	02	
05	0561019929	FLAT WASHER	01	
06	0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	59	01
07	0503033458	CURRENT 6 X 17 ELOS		01
08	0521068707	LARGER CENTRAL WHEELED FORK		01
09	0521053037	TIRE WITH WHEEL 15 X 19,50 14 LONAS		01
10	0521053040	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION 60 LARGER		01
11	0581017245	AXLE BODY		01
12	0521068710	JOINT SHAFT WHEELED GREATER CENTRAL		01
13	0521068713	GREATER RIGHT SUPPORT WHEELED CENTRAL		01
14	0501010630	1.1/2" CASTLE NUT		01
15	0501010694	FLAT WASHER		02
16	0501017779	FLAT WASHER		02
17	0503010002	1800 GREASE FITTING		02
18	0503010003	1845 GREASE FITTING		02
19	0503010010	1/4" X 2.1/2" COTTERPIN		04
20	0503010019	1/2" SPRING WASHER		04
21	0503010023	SPRING WASHER		06
22	0503010060	1/2" NUT		04
23	0503010337	5/16" NUT		01
24	0503010882	5/16" X 2" BOLT		01
25	0503010920	1/2" X 1.1/2" BOLT		04
26	0503011052	1.1/4" X 0.77" CASTLE NUT		02
27	0503011345	1/4" X 3-1/2" COTTERPIN		01
28	0503013394	3/4" X 3" BOLT		06
29	0503019247	NUT 3/4 NC S G.8		06




Item	Code	Description	See page	QT
01	0521066557	CYLINDER CASE 101,60 X 352 USAP		01
02	0581010680	TURNBUCKLE 50,80 X 386 USAP		01
03	0571015629	CILINDER SPINDLE FORK		01
04	0503010817	1-1/4" SELF-ADJUSTING NUT		01
05	0503010345	2-218 N 3006-9B O'RING		01
06	0503011094	3/8" X 2" BOLT C C S I 12.9		01
07	0503010026	3/8" NUT		01
08	0503010025	3/8 SPRING WASHER		01
09	0503030385	CYLINDER PLUG N-002		02
10	0503015633	SELEMASTER SEALING		01
11	0581010678	50,80 X 101 RING SUPPORT		01
12	0503015636	SCRAPER SEAL		01
13	0503018025	RING GUIDE		01
14	0503018026	1870-2000-375 B GASKET		01
15	0503010338	2-342 N 3006-9B O'RING		02
16	0503011061	8-342 BACK-UP RING		02
17	0502012822	101,60 MOBILE COVER		01
18	0502012820	50,80 X 101,60 PISTON		01




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0581017252	LARGER WHEEL AXLE		01
03	0503013633	BEARING 33287/33462		01
04	0503010009	SEAL 00573-B		01
05	0503010086	SEAL 0009B-B		01
06	0551014473	SPACING SLEEVE HUB		01
07	0503012702	KM-12 NUT		02
08	0503012703	LOCK WASHER		01
09	0503010002	1800 GREASE FITTING		01
10	0503011444	SPRING WASHER		04
11	0503014048	CM22 X 1,5 NUT		08
12	0503010363	5/16" X 1" BOLT		04
13	0503014050	M22 X 1,5 BOLT		08
14	0511068415	PFFP-3770 SEAL GUIDE		01
15	0503013496	3982/3920 ROLLER BEARING		01




Item	Code	Description	See page	QT
01	0503010257	1/8" X 1" COTTERPIN		02
02	0503010026	3/8" NUT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010144	1/4" NUT		08
05	0503010143	SPRING WASHER		08
06	0503010060	1/2" NUT		02
07	0503010019	1/2" SPRING WASHER		02
08	0511017302	FLAT WASHER		02
09	0503010237	3/8" X 1" BOLT		04
10	0521068017	BOX BODY APT TVT USAP S-0117		01
11	0571017090	ROD CX		01
12	0581014891	BOX SUPPORT		01
13	0521068016	BOX COVER		01
14	0503018171	FAST LOCK ASSY		02
15	0501013518	FLAT WASHER		04
16	0501010161	1/2" X 1.1/4" BOLT		02
17	0503010461	1/4" X 1" BOLT		04
18	0503010282	1/4" X 3/4" BOLT		04




Item	Code	Description	See page	QT
001	0503062391	SILO FERTILIZER 5 MOUTHS		02
002	0503062766	SEED CONDUCTOR		04
003	0503062767	SEED CONDUCTOR		05
004	0521051401	ASSY ARTICULATED CONDUCTOR SUPPORT 64 BASE		09
005	0521068745	CENTER FERTILIZER SILO SUPPORT		01
006	0511017302	FLAT WASHER		12
007	0503010589	1/2" UNC SELF ADJUSTING NUT		12
008	0503010920	1/2" X 1.1/2" BOLT		12
009	0521051407	FIXER SILO FERTILIZER	65	16
010	0511056999	CAP SET		01




Item	Code	Description	See page	QT
01	0503062391	SILO FERTILIZER 5 MOUTHS		02
02	0503062766	SEED CONDUCTOR		10
03	0521051401	ASSY ARTICULATED CONDUCTOR SUPPORT BASE	64	10
04	0521068745	CENTER FERTILIZER SILO SUPPORT		01
05	0511017302	FLAT WASHER		12
06	0503010589	1/2" UNC SELF ADJUSTING NUT		12
07	0503010920	1/2" X 1.1/2" BOLT		12
08	0521051407	FIXER SILO FERTILIZER	65	16




Item	Code	Description	See page	QT
01	0571018524	TUBE CAP UPPER		01
02	0501011643	3/8 X 1"BOLT		05
03	0503010025	3/8 SPRING WASHER		05
04	0503010209	3/8" UNC BUTTERFLY NUT		01
05	0501010984	FLAT WASHER		04
06	0503010026	3/8" NUT		04
07	0502012797	DUCT BODY		01
08	0503013816	5/16" LOCKNUT		02
09	0503010365	NUT		02




Item	Code	Description	See page	QT
01	0503012531	3/8" INOX NUT		01
02	0503012535	3/8" SPRING WASHER		01
03	0571019051	FIXER BOX WASHER		01
04	0503013751	3/8 UNC X 1.1/4 BOLT		01




Item	Code	Description	See page	QT
001	0521053064	CENTRAL HANDRAIL	67	01
002	0521053065	CENTRAL HANDRAIL LEFT	68	01




Item	Code	Description	See page	QT
001	0521067991	GEAR HANDRAIL		02
002	0511059383	INTERNAL FIXER ASSY HANDLE	69	08
003	0581012718	HANDRAIL		04
004	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	70	07
005	0581015992	TUBE		02
006	0581017390	TUBE		03
007	0581017391	TUBE		03
008	0581017396	TUBE		03
009	0581014825	FRAME TUBE		02




Item	Code	Description	See page	QT
001	0521067991	GEAR HANDRAIL		02
002	0511059383	INTERNAL FIXER ASSY HANDLE	69	08
003	0581012718	HANDRAIL		04
004	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	70	07
005	0581015992	TUBE		02
006	0581017390	TUBE		03
007	0581017391	TUBE		03
008	0581017396	TUBE		03
009	0581014825	FRAME TUBE		02




Item	Code	Description	See page	QT
01	0502012857	OUTER FIXER		01
02	0502012858	INNER FIXER		01
03	0503019083	7/16" X 2.1/4" BOLT		01
04	0503015490	NUT AUTOFREN 7/16 NC		01




Item	Code	Description	See page	QT
01	0502012855	CENTRAL FIXER		01
02	0502012856	CENTRAL FIXER		01
03	0503019083	7/16" X 2.1/4" BOLT		02
04	0503015490	NUT AUTOFREN 7/16 NC		02




Item	Code	Description	See page	QT
01	0581017397	PLATFORM		02
02	0521053066	PLATFORM SUPPORT ASSY	137	04




Item	Code	Description	See page	QT
01	0521068748	ARTICULATION ARM LEFT	01	
02	0571011825	BUSHING	02	
03	0503015322	BOLT 7/8	01	
04	0503010408	7/8" SPRING WASHER	01	
05	0571017893	HORIZONTAL ARTICULATION SHAFT USAP	01	
06	0503011198	C3/4" X 6" BOLT	01	
07	0503011255	3/4" LOCK NUT	01	
08	0503010002	1800 GREASE FITTING	01	
09	0503032042	SHEET POLYETHYLENE	01	
10	0503010814	5/16" X 3/4" BOLT	14	
11	0521063778	RELATION AVEC AXE VERTICAL LATCH	01	
12	0571011767	LISA WASHER 125 X 88 X 4.76	01	
13	0503010004	1890 GREASE FITTING	01	




Item	Code	Description	See page	QT
01	0571011825	BUSHING		02
02	0503010408	7/8" SPRING WASHER		01
03	0503015322	BOLT 7/8		01
04	0571017893	HORIZONTAL ARTICULATION SHAFT USAP		01
05	0503011198	C3/4" X 6" BOLT		01
06	0503011255	3/4" LOCK NUT		01
07	0503010002	1800 GREASE FITTING		01
08	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
09	0503032042	SHEET POLYETHYLENE		01
10	0503010814	5/16" X 3/4" BOLT		14
11	0521068749	ARTICULATION ARM RIGHT		01
12	0571011767	LISA WASHER 125 X 88 X 4.76		01
13	0503010004	1890 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511058761	HYDRAULIC CYLINDER 63,50 X 150 X 610 X 965		02
02	0581017527	CYLINDER FIXED AXLE		04
03	0503030119	LOCK PIN		04
04	0501010617	3/4" NIPPLE		04
05	0503010190	2-114 N 3006-9B O'RING		04




Item	Code	Description	See page	QT
001	0521053216	CENTRAL DUTY ASSEMBLY	78	01
002	0503062957	BLOCK COMMAND		01
003	0521054021	HOSE KIT LEVANTE CSC FRAME 20226	79	01
004	0521054020	ASSY HOSE ARTICULATED CSC FRAME 20226	80	01
005	0521054018	ASSY HEAD HOSE CSC FRAME 20226	81	01
006	0521054012	ASSY HOSE APT FRAME 20226	82	01
007	0501053834	MALE QUICK COUPLING AGRICULTURAL WITH COVER - 1/2 NPT	83	04
008	0521055280	CENTRAL BLOCK SUPPORT WITH FIXATION	76	01
009	0521055201	DIVIDER VALVE TRIPLE (17,163,025,002) WITH NIPPLES	77	01




Item	Code	Description	See page	QT
01	0581019704	CENTRAL BLOCK SUPPORT		01
02	0503010172	M10 X 1,5 X 25 BOLT		03
03	0503010025	3/8 SPRING WASHER		03
04	0511017302	FLAT WASHER		04
05	0503010395	1/2" X 1-1/4" BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0503019365	FLOW DIVISOR VALVE		01
02	0503011109	2-119 N 3006-9B O'RING		03
03	0521014704	HOSE NIPPLE 3/4 UNF		02
04	0581013111	NIPPLE R 1.1/6 UN X 1.5/16 12 WIRES		01
05	0501010589	R. 1.1/16UN SEXT 1.1/4 X 52 NIPPLE		01
06	0503014724	2-215 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
001	0521061963	OIL TUBE		06
002	0521064875	OIL TUBE		06
003	0581010230	LOWER BODY FASTENER CENTRAL DUTUM		16
004	0521062385	DUTO OLEO 3704		01
005	0521062386	OIL DUCT 1654		02
006	0521051537	SIDE DUTY SUPPORT		04
007	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		08
008	0503011123	3/8" X 4-1/2" BOLT		08
009	0503010025	3/8 SPRING WASHER		16
010	0503010026	3/8" NUT		16
011	0591010127	SUPPORT LEFT DISTRIBUTOR		02
012	0581014867	SIDE DUTY SUPPORT		02




Item	Code	Description	See page	QT
01	0501081837	HOSE 3/8 X 700 TR-TC USAP		04
02	0501080700	3/8 X 650 TC-TC HOSE		02
03	0501080599	3/8 X 650 TC-TR HOSE		02
04	0501081838	HOSE		04
05	0501080065	3/8 X 1200 TC-TC HOSE ASSY		01
06	0501080675	3/8" X 165" TC-TM HOSE ASSY		03
07	0501080105	TR-TR HOSE ASSY		04
08	0501081254	HOSE 1/2 X 900 TR-TC		02
09	0501080175	3/4 X 900 TR-TC 2T HOSE		01
10	0501080055	3/8" X 1000 TR-TC HOSE		02
11	0501080302	TR-TC HOSE ASSY		01
12	0501080714	3/8" X 63" TR-TC HOSE ASSY		01
13	0501080028	3/4 X 1200 TR-TC HOSE		02
14	0501080012	HOSE		02
15	0501081288	3/4 X 500 TR-TC HOSE		01
16	0501082222	HOSE		01
17	0501080347	HOSE 3/4 X 1800 TR-TR		02
18	0521053712	HOSE 3/4		01
18A	0501082205	HOSE 1/2 X 5900 TR-TM		01
18B	0503034492	HYDRAULIC HOSE DEPTH		01
18C	0503034495	HYDRAULIC HOSE DEPTH (RED)		01
18D	0503018952	PLASTIC BOLT		06
19	0521053707	HOSE 3/4		01
19A	0501082205	HOSE 1/2 X 5900 TR-TM		01
19B	0503034492	HYDRAULIC HOSE DEPTH		01
19C	0503034494	HYDRAULIC HOSE DEPTH (BLUE)		01
19D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0501080479	TC-TC HOSE ASSY		01
02	0501080442	3/8" X 130" TC-TC HOSE ASSY		01
03	0501080516	3/8" X 63" TR-TC HOSE ASSY		01
04	0501080571	HOSE 3/8 X 850 TC-TC		01
05	0501080449	3/8" X 1500 TC-TC HOSE		01
06	0501082184	HOSE 1/2 X 2100 TC-TC		01




Item	Code	Description	See page	QT
01	0501080714	3/8" X 63" TR-TC HOSE ASSY		02
02	0501080105	TR-TR HOSE ASSY		02
03	0501080128	3/8" X 71" TR-TR HOSE ASSY		02
04	0501081046	3/8" X 161.4" TC-TM HOSE ASSY		01
05	0501080390	3/8" X 150" TR-TC HOSE ASSY		01




Item	Code	Description	See page	QT
01	0501080060	1/2 X 1600 TR-TC HOSE	02	
02	0501080618	1/2" X 2200 TR-TC HOSE	01	
03	0501082025	HOSE 1/2 X 2900 TR-TR	01	
04	0501080058	HOSE 1/2 X 1400 TR-TC	02	
05	0501080040	1/2" X 19" TR-TC HOSE ASSY	01	
06	0501080267	HOSE 1/2 X 2100 TR-TC	01	
07	0501080059	1/2" X 61" TR-TC HOSE ASSY	01	
08	0521052567	HOSE 1/2 X 5900 TR-TM	01	
08A	0501081841	HOSE 1/2 X 5900 TR-TM	01	
08B	0503034489	HYDRAULIC HOSE HANDLE	01	
08C	0503034495	HYDRAULIC HOSE DEPTH (RED)	01	
08D	0503018952	PLASTIC BOLT	06	
09	0521052566	HOSE 1/2 X 5900 TR-TM	01	
09A	0501081841	HOSE 1/2 X 5900 TR-TM	01	
09B	0503034489	HYDRAULIC HOSE HANDLE	01	
09C	0503034494	HYDRAULIC HOSE DEPTH (BLUE)	01	
09D	0503018952	PLASTIC BOLT	06	
10	0501081235	1/2 X 650 TR- TC HOSE	02	
11	0501080024	1/2" X 700 TR-TR HOSE	01	
12	0501080218	1/2 X 750 HOSE	01	




Item	Code	Description	See page	QT
01	0503011627	QUICK CONNECTION (MALE) AGR 1/2 NPT		01
02	0503011882	QUICK CONNECTION COVER		01




Item	Code	Description	See page	QT
001	0581015993	SUPPORT BLOCK HYDRAULIC		01
002	0511017302	FLAT WASHER		02
003	0503014007	1/2" X 1-1/4" BOLT		02
004	0503010019	1/2" SPRING WASHER		02
005	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
001	0571013313	GUTTER 25 X 58 X 2150 USAP		01
002	0511057011	SUPPORT GUTTER ASSY	138	04
003	0571013990	GUTTER		01
004	0581017678	TROUGH 27 X 58 X 1500		02




Item	Code	Description	See page	QT
01	0581017745	TROUGH 30 X 55 X 2420		01
02	0511057011	SUPPORT GUTTER ASSY	138	04
03	0581017744	GUTTER		01
04	0581018338	GUTTER		02
05	0503011267	5/8" X 1.1/2" BOLT		02
06	0503010027	SPRING WASHER		02
07	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0521054882	FLASHLIGHT WITH SUPPORT	140	02
02	0503032812	1141 12V LAMP		04
03	0503032813	67 12V 5W LAMP		02
04	0521053672	LIGHTHOUSE ASSY	141	05




Item	Code	Description	See page	QT
01	0521063601	SUPPORT HYDRAULIC MOTOR		01
02	0521062807	17Z GEAR WITH SLEEVE		01
03	0511052600	STRETCHER HYDRAULIC MOTOR SUPPORT	89	01
04	0571012677	WASHER GUIDE		01
05	0501010937	FLAT WASHER		02
06	0503010060	1/2" NUT		02
07	0503010019	1/2" SPRING WASHER		02
08	0503010238	1/2" X 1-3/4" BOLT		02
09	0571012684	FIXING SHAFT		01
10	0571012680	FLAT WASHER		01
11	0503010179	SPRING WASHER		01
12	0503010025	3/8 SPRING WASHER		01
13	0503010026	3/8" NUT		01
14	0503013758	1/4" X 1-1/2" BOLT		01
15	0503010237	3/8" X 1" BOLT		01
16	0502012768	CLAMP UPPER		01
17	0503019024	5/8" X 3" BOLT		02
18	0503010811	5/8" UNF SELF ADJUSTING NUT		02
19	0503017392	40-1 X 67 CHAIN LINK + MENDING		01
20	0521063774	GEAR ASSY		01
21	0511054314	TRANSMISSION AXLE FULL TRANSMISSION GLOVE		02
21A	0502012699	LATCH GLOVE BOX TRANSMISSION		02
21B	0503010256	3/8" X 3/4" BOLT		02




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503012882	BALL BEARING		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0571012703	SLEEVE FLANGE		01
05	0503010479	1/2" X 3" BOLT		01
06	0511017302	FLAT WASHER		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503062835	KIT INTELLIAG 50 LINES 45/50 WITH MONITOR 010081011	92	01
02	0521050826	BLOCK LIMITATION ASSY FLOW	94	01
03	0511056973	PARKER OMP 80 HYDRAULIC MOTOR WITH VALVE	95	03
04	0511056972	FILTER HYDAC	96	01
05	0503017984	SENSOR LEVANTE BOTAO MONT LINE		02
06	0503016033	4,8 X 1,3 X 300 MM NYLON CLAMP		750
07	0521068295	RATCHET DRIVING		01
08	0503010920	1/2" X 1.1/2" BOLT		04
09	0503010019	1/2" SPRING WASHER		04
10	0503010060	1/2" NUT		04
11	0503011828	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503062773	KIT INTELLIAG 45L/50 WITH MONITOR E 010080932	93	01
02	0521050826	BLOCK LIMITATION ASSY FLOW	94	01
03	0511056973	PARKER OMP 80 HYDRAULIC MOTOR WITH VALVE	95	03
04	0511056972	FILTER HYDAC	96	01
05	0503017984	SENSOR LEVANTE BOTAO MONT LINE		02
06	0503016033	4,8 X 1,3 X 300 MM NYLON CLAMP		675
07	0521068295	RATCHET DRIVING		01
08	0503010920	1/2" X 1.1/2" BOLT		04
09	0503010019	1/2" SPRING WASHER		04
10	0503010060	1/2" NUT		04
11	0503011828	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503015065	MAST CTRL MODULE		01
02	0503015066	CABLE CTRL MASTER MODULE		01
03	0503015209	MODULES WSMB 18L ISOBUS 4679811100S1		02
04	0503015210	CABLE MODULO WSMB ISOBUS 467981200		02
05	0503016324	ELECTRIC THREAD		01
06	0503015071	CONCTOR		01
07	0503015220	ENCODER ISOB 4,5M 464360171S1		03
08	0503062519	MONITOR CABLE		01
08A	0503018292	LEFT SIDE CABLE		01
08B	0503018293	CENTRAL CABLE		01
08C	0503018294	CABLE RIGHT SIDE		01
09	0503017443	ANTENNA GPS PM 400		01
10	0503016369	THREE FEMALE CONNECTOR		03
11	0503015908	FEMALE TERMINAL		09
12	0503015911	CABLE SEAL		09
13	0503017031	CLEANING BRUSH		01
14	0503015218	SENSOR FOTOELE PM 400		50




Item	Code	Description	See page	QT
01	0503015065	MAST CTRL MODULE		01
02	0503015066	CABLE CTRL MASTER MODULE		01
03	0503015209	MODULES WSMB 18L ISOBUS 4679811100S1		02
04	0503015210	CABLE MODULO WSMB ISOBUS 467981200		02
05	0503016324	ELECTRIC THREAD		01
06	0503015071	CONCTOR		01
07	0503015220	ENCODER ISOB 4,5M 464360171S1		03
08	0503062546	MONITOR CABLE		01
08A	0503018376	LEFT SIDE CABLE WITH MONITOR		01
08B	0503018377	CENTRAL CABLE WITH MONITOR		01
08C	0503018378	RIGHT SIDE CABLE WITH MONITOR		01
09	0503017443	ANTENNA GPS PM 400		01
10	0503016369	THREE FEMALE CONNECTOR		03
11	0503015908	FEMALE TERMINAL		09
12	0503015911	CABLE SEAL		09
13	0503017031	CLEANING BRUSH		01
14	0503015218	SENSOR FOTOELE PM 400		45




Item	Code	Description	See page	QT
01	0503014953	LIMITING FLOW PACK		01
02	0503010045	2-116 N 3006-9B O'RING		02
03	0503011109	2-119 N 3006-9B O'RING		02
04	0571013917	7/8"NF X 1.1/16 UNF NIPPLE		02
05	0503010337	5/16" NUT		02
06	0503010179	SPRING WASHER		02
07	0503011766	5/16" X 2-1/2" BOLT		02
08	0511010111	7/8" NIPPLE		02




Item	Code	Description	See page	QT
01	0503016037	VALVE		01
02	0501010590	7/8" REDUCTION NIPPLE		02
03	0503010045	2-116 N 3006-9B O'RING		02
04	0503016055	MOTOR HYDRAULIC PARKER OMP 80 ISOBUS		01




Item	Code	Description	See page	QT
01	0503016376	FILTER SPRING		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8"NF UNF NIPPLE		02
04	0503012341	T 7/8" ADAPOR GIRAT NUT		01
05	0501010694	FLAT WASHER		04
06	0503010179	SPRING WASHER		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
001	0503034003	ALUMINUM IDENTIFICATION LABEL	01	
002	0503010001	RIVET POP	04	
003	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 MOUTH)	20	
004	0503034563	ADHESIVE LABEL	20	
005	0503033853	ADHESIVE LABEL	02	
006	0503031425	ADHESIVE LABEL ATTENTION	02	
007	0503032988	ADHESIVE LABEL	01	
008	0503033597	ADHESIVE	02	
009	0503031087	ADHESIVE LABEL	01	
010	0503032986	ETIQ ADES REC ENGR SEM CEN / ESQ USAP	01	
011	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM	02	
012	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM	02	
013	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER	04	
014	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER	01	
015	0503034471	ADHESIVE LABEL	01	
016	0503034651	ADHESIVE LABEL	02	
017	0503034683	ADHESIVE LABEL	02	
018	0503034534	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0503010019	1/2" SPRING WASHER		02
02	0503010060	1/2" NUT		02
03	0503010025	3/8 SPRING WASHER		02
04	0501010984	FLAT WASHER		02
05	0503010238	1/2" X 1-3/4" BOLT		02
06	0581017386	LIFTING SENSOR SUPPORT		01
07	0581017387	ARM DISARM TRIGGER		01
08	0503010026	3/8" NUT		02
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02



Item	Code	Description	See page	QT
001	0581013468	HEX AXLE		01
002	0581017515	HEX AXLE		01
003	0561010268	3/4 X 3390 HEX AXLE		01
004	0561015837	SLEEVE 31,75 X SEXT 19,80/20 X 90		02
005	0503010523	1/4" X 2" COTTERPIN		02
006	0511054314	TRANSMISSION AXLE FULL TRANSMISSION GLOVE		44
006A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
006B	0503010256	3/8" X 3/4" BOLT		01
007	0521063774	GEAR ASSY		01



Item	Code	Description	See page	QT
001	0581013468	HEX AXLE		01
002	0581017515	HEX AXLE		01
003	0561010268	3/4 X 3390 HEX AXLE		01
004	0561015837	SLEEVE 31,75 X SEXT 19,80/20 X 90		02
005	0503010523	1/4" X 2" COTTERPIN		02
006	0511054314	TRANSMISSION AXLE FULL TRANSMISSION GLOVE		40
006A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
006B	0503010256	3/8" X 3/4" BOLT		01
007	0521063774	GEAR ASSY		01




Item	Code	Description	See page	QT
01	0521068721	FORK WHEELED HIGHER SIDE		01
02	0521064573	LARGER SUPPORT		01
03	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
04	0561019929	FLAT WASHER		01
05	0503011345	1/4" X 3-1/2" COTTERPIN		01
06	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
07	0551014508	FLAT WASHER		01
08	0503010010	1/4" X 2.1/2" COTTERPIN		02
09	0511061810	HYDRAULIC CYLINDER FRANGE		02
10	0503010920	1/2" X 1.1/2" BOLT		04
11	0503010019	1/2" SPRING WASHER		04
12	0503010060	1/2" NUT		04
13	0503010067	3/16" X 2.1/2" COTTER PIN		01
14	0502012731	CATCH RODEIRO		02
15	0501010322	FLAT WASHER		04
16	0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	102	01
17	0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE		01
18	0503011052	1.1/4" X 0.77" CASTLE NUT		02
19	0501017779	FLAT WASHER		02
20	0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	59	01
21	0501010630	1.1/2" CASTLE NUT		01
22	0503010003	1845 GREASE FITTING		03
23	0503010882	5/16" X 2" BOLT		01
24	0501010694	FLAT WASHER		02
25	0503033458	CURRENT 6 X 17 ELOS		01
26	0503010337	5/16" NUT		01
27	0521068341	WHEEL LIFT SHAFT		01
28	0501018466	FLAT WASHER		01
29	0503010023	SPRING WASHER		04
30	0503019245	SCREW 3/4 UNC X 4 C S R P G.8 ZN		02
31	0503019247	NUT 3/4 NC S G.8		04




USAP 45-50L APT TIT SPCRR
SIDE WHEEL WITHOUT TRANSMISSION LARGER

Page 101
0521053046


Item	Code	Description	See page	QT
32	0503019246	BOLT		02




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503010007	3982/3920 ROLLER BEARING		01
04	0503010059	33287/33462 ROLLER BEARING		01
05	0503010009	SEAL 00573-B		01
06	0503010086	SEAL 0009B-B		01
07	0551014473	SPACING SLEEVE HUB		01
08	0503012702	KM-12 NUT		02
09	0503012703	LOCK WASHER		01
10	0503010002	1800 GREASE FITTING		01
11	0503011444	SPRING WASHER		04
12	0503011339	M22 X 1,5 X 72 BOLT		08
13	0503014048	CM22 X 1,5 NUT		08
14	0503010363	5/16" X 1" BOLT		04
15	0511068415	PFFP-3770 SEAL GUIDE		01




Item	Code	Description	See page	QT
01	0521068960	SUPPORT SIDE		01
02	0503062391	SILO FERTILIZER 5 MOUTHS		02
03	0503062766	SEED CONDUCTOR		10
04	0521051401	ASSY ARTICULATED CONDUCTOR SUPPORT BASE	64	10
05	0521051407	FIXER SILO FERTILIZER	65	16




Item	Code	Description	See page	QT
001	0503062362	BEAN FERTILIZER ASSY		02
002	0521051401	ASSY ARTICULATED CONDUCTOR SUPPORT BASE	64	08
003	0503062766	SEED CONDUCTOR		04
004	0503062767	SEED CONDUCTOR		04
005	0521068704	SUPPORT SIDE		01
006	0521051407	FIXER SILO FERTILIZER	65	12




Item	Code	Description	See page	QT
001	0503062391	SILO FERTILIZER 5 MOUTHS		02
002	0503062766	SEED CONDUCTOR		04
003	0503062767	SEED CONDUCTOR		06
004	0521051401	ASSY ARTICULATED CONDUCTOR SUPPORT 64 BASE		10
005	0521068705	SUPPORT SIDE		01
006	0521051407	FIXER SILO FERTILIZER	65	16




Item	Code	Description	See page	QT
01	0521068706	DEPTH SUPPORT		01
02	0571011070	5/8" UNC FASTENER		02
03	0503010027	SPRING WASHER		04
04	0503010013	5/8" NUT		04
05	0511017302	FLAT WASHER		03
06	0503010019	1/2" SPRING WASHER		03
07	0503010060	1/2" NUT		03
08	0503010920	1/2" X 1.1/2" BOLT		03




Item	Code	Description	See page	QT
01	0521068962	HANDLE		01
02	0503013357	3/8" SELF-ADJUSTING NUT		02
03	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0581017735	PLATFORM ASSY		01
02	0581017737	PLATFORM 2570		01
03	0581017224	PLATLFORM		01
04	0521053066	PLATFORM SUPPORT ASSY	137	10




Item	Code	Description	See page	QT
001	0581017223	PLATLFORM		01
002	0581017327	PLATEFORME		01
003	0581017224	PLATLFORM		01
004	0521053066	PLATFORM SUPPORT ASSY	137	08
004A	0551019056	SIDE PLATFORM SUPPORT		01
004B	0503010019	1/2" SPRING WASHER		07
004C	0503010060	1/2" NUT		07
004D	0503010395	1/2" X 1-1/4" BOLT		07
004E	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521053326	RIGHT SIDE HANDRAIL	112	01
02	0521053327	RIGHT SIDE HANDRAIL	113	01
03	0521053328	RIGHT SIDE HANDRAIL	114	01
04	0521053337	RIGHT SIDE HANDRAIL	115	01
05	0521053096	ASSY SIDE FRAME HANDRAIL FIXER	131	01




Item	Code	Description	See page	QT
001	0521053029	FRONT SIDE CORRIMAO	116	01
002	0521053030	FRONT SIDE CORRIMAO	117	01
003	0521053032	FRONT SIDE CORRIMAO	118	01
004	0521053096	ASSY SIDE FRAME HANDRAIL FIXER	131	01
004A	0581017326	HANDRAIL FIXER		01
004B	0503010395	1/2" X 1-1/4" BOLT		02
004C	0503010019	1/2" SPRING WASHER		04
004D	0503010060	1/2" NUT		04
004E	0503010238	1/2" X 1-3/4" BOLT		02




Item	Code	Description	See page	QT
01	0521067991	GEAR HANDRAIL		02
02	0511059383	INTERNAL FIXER ASSY HANDLE	69	08
03	0581012718	HANDRAIL		04
04	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	70	04
05	0581015992	TUBE		02
06	0581014825	FRAME TUBE		01
07	0581017742	OIL TUBE		03
08	0581017743	OIL TUBE		03




Item	Code	Description	See page	QT
01	0521067991	GEAR HANDRAIL		02
02	0511059383	INTERNAL FIXER ASSY HANDLE	69	10
03	0581012718	HANDRAIL		03
04	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	70	05
05	0581015992	TUBE		04
06	0581014825	FRAME TUBE		01
07	0581017739	TUBE		03
08	0581017738	FRAME TUBE		03




Item	Code	Description	See page	QT
01	0521067991	GEAR HANDRAIL		02
02	0511059383	INTERNAL FIXER ASSY HANDLE	69	10
03	0581012718	HANDRAIL		04
04	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	70	05
05	0581015992	TUBE		04
06	0581014825	FRAME TUBE		01
07	0581017739	TUBE		03
08	0581017738	FRAME TUBE		03




Item	Code	Description	See page	QT
01	0521067991	GEAR HANDRAIL		03
02	0511059383	INTERNAL FIXER ASSY HANDLE	69	10
03	0581012718	HANDRAIL		03
04	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	70	05
05	0581015992	TUBE		04
06	0581017740	OIL TUBE		03
07	0581017741	OIL TUBE		03




Item	Code	Description	See page	QT
001	0521067991	GEAR HANDRAIL		02
002	0511059383	INTERNAL FIXER ASSY HANDLE	69	10
003	0581012718	HANDRAIL		04
004	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	70	08
005	0581015992	TUBE		04
006	0581017331	OIL TUBE		03
007	0581017332	OIL TUBE		03
008	0581017396	TUBE		03
009	0581014825	FRAME TUBE		02




Item	Code	Description	See page	QT
001	0521067991	GEAR HANDRAIL		02
002	0511059383	INTERNAL FIXER ASSY HANDLE	69	10
003	0581012718	HANDRAIL		03
004	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	70	05
005	0581015992	TUBE		04
006	0581017230	TUBE		03
007	0581014825	FRAME TUBE		01
008	0581017332	OIL TUBE		03




Item	Code	Description	See page	QT
001	0521067991	GEAR HANDRAIL		02
002	0511059383	INTERNAL FIXER ASSY HANDLE	69	10
003	0581012718	HANDRAIL		02
004	0581017231	TUBE		03
005	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	70	02
006	0581015992	TUBE		04




Item	Code	Description	See page	QT
01	0511069819	SIDE LADDER		01
02	0502012742	FIXER SUPPORT LADDER		02
03	0503013357	3/8" SELF-ADJUSTING NUT		02
04	0501010984	FLAT WASHER		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0503010237	3/8" X 1" BOLT		04
07	0503010025	3/8 SPRING WASHER		04
08	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0581017736	TROUGH 30 X 55 X 2540		01
02	0581017734	GUTTER		02
03	0511057011	SUPPORT GUTTER ASSY	138	06



Item	Code	Description	See page	QT
001	0581017683	GUTTER		02
002	0581017695	GUTTER		01
003	0511057011	SUPPORT GUTTER ASSY	138	06
003A	0571013956	CENTRAL TRACK SUPPORT		01
003B	0503010025	3/8 SPRING WASHER		02
003C	0503010026	3/8" NUT		02
003D	0503013029	3/8" X 3/4" BOLT		01
003E	0501011643	3/8 X 1" BOLT		01




Item	Code	Description	See page	QT
001	0511059943	SUPPORT FASTENER ASSY		04
001A	0581011417	DUTO HOLDER SUPPORT		01
001B	0503010237	3/8" X 1" BOLT		02
001C	0503010025	3/8 SPRING WASHER		02
001D	0503010026	3/8" NUT		02
002	0521053025	DUCT SUPPORT OIL		02
002A	0571019121	FIXER LOWER		01
002B	0581013094	DUTO HOLDER SUPPORT		01
002C	0571019139	PRISONER		02
002D	0511017302	FLAT WASHER		04
002E	0503010019	1/2" SPRING WASHER		04
002F	0503010060	1/2" NUT		04
003	0581014987	LOWER BODY FASTENER		12
004	0501082190	HOSE 3/8 X 160 TR-TR		02
005	0503011268	3/8" X 2-1/2" BOLT		06
006	0503010025	3/8 SPRING WASHER		06
007	0503010026	3/8" NUT		06
008	0521068730	OIL TUBE		02
009	0511068880	3485 OIL TUBE		02



Item	Code	Description	See page	QT
001	0511059943	SUPPORT FASTENER ASSY		04
001A	0581011417	DUTO HOLDER SUPPORT		01
001B	0503010237	3/8" X 1" BOLT		02
001C	0503010025	3/8 SPRING WASHER		02
001D	0503010026	3/8" NUT		02
002	0521053025	DUCT SUPPORT OIL		01
002A	0571019121	FIXER LOWER		01
002B	0581013094	DUTO HOLDER SUPPORT		01
002C	0571019139	PRISONER		02
002D	0511017302	FLAT WASHER		04
002E	0503010019	1/2" SPRING WASHER		04
002F	0503010060	1/2" NUT		04
003	0581014987	LOWER BODY FASTENER		10
004	0501082190	HOSE 3/8 X 160 TR-TR		02
005	0503011268	3/8" X 2-1/2" BOLT		05
006	0503010025	3/8 SPRING WASHER		05
007	0503010026	3/8" NUT		05
008	0521068730	OIL TUBE		02
009	0511068880	3485 OIL TUBE		02


01




0503034682

04 **PLANTIO DIRETO**

0503033424



0503031565



0503032986



0503033621

05

5

0503033419

06

0

0503033414

07

LUBRIFICAR E REAPERTAR DIARIAMENTE
LUBRICATE AND TIGHTEN DAILY
LUBRICAR Y REAPRETAR DIARIAMENTE

0503031827

Item	Code	Description	See page	QT
01	0503034682	ADHESIVE LABEL SEED TABLE		01
02	0503032986	ETIQ ADES REC ENGR SEM CEN / ESQ USAP		01
03	0503033621	ADHESIVE LABEL		01
04	0503033424	DIRECT PLANTIO ADHESIVE LABEL		01
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		01
06	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		01
07	0503031827	ADHESIVE LABEL		01
08	0503031565	ADHESIVE LABEL CARE		01

01

TABLE DE DISTRIBUTION DE SEMENCES
TABLE FOR DISTRIBUTION OF SEEDS
TABELA DE DISTRIBUIÇÃO DE SEMENTES


Modelo	Velocidade (km/h)	Profundidade (cm)	Quantidade (kg/ha)
USAP 45-50L	10	10	10
USAP 45-50L	12	12	12
USAP 45-50L	14	14	14
USAP 45-50L	16	16	16
USAP 45-50L	18	18	18
USAP 45-50L	20	20	20
USAP 45-50L	22	22	22
USAP 45-50L	24	24	24
USAP 45-50L	26	26	26
USAP 45-50L	28	28	28
USAP 45-50L	30	30	30
USAP 45-50L	32	32	32
USAP 45-50L	34	34	34
USAP 45-50L	36	36	36
USAP 45-50L	38	38	38
USAP 45-50L	40	40	40
USAP 45-50L	42	42	42
USAP 45-50L	44	44	44
USAP 45-50L	46	46	46
USAP 45-50L	48	48	48
USAP 45-50L	50	50	50

0503032988


04

PLANTIO DIRETO

0503033424



0503031565



0503032986



0503033621

06

5

0503033419

05

4


0503033418

07


LUBRIFICAR E REAPERTAR DIARIAMENTE
LUBRICATE AND TIGHTEN DAILY
LUBRICAR Y REAPRETAR DIARIAMENTE

0503031827


Item	Code	Description	See page	QT
001	0503032988	ADHESIVE LABEL		01
002	0503032986	ETIQ ADES REC ENGR SEM CEN / ESQ USAP		01
003	0503033621	ADHESIVE LABEL		01
004	0503033424	DIRECT PLANTIO ADHESIVE LABEL		01
005	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		01
006	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		01
007	0503031827	ADHESIVE LABEL		01
008	0503031565	ADHESIVE LABEL CARE		01




Item	Code	Description	See page	QT
01	0521068959	PRESS SUPPORT UPPER RIGHT		01
02	0503062391	SILO FERTILIZER 5 MOUTHS		02
03	0503062766	SEED CONDUCTOR		10
04	0521051401	ASSY ARTICULATED CONDUCTOR SUPPORT BASE	64	10
05	0521051407	FIXER SILO FERTILIZER	65	16




Item	Code	Description	See page	QT
001	0521068728	SUPPORT SIDE		01
002	0503062362	BEAN FERTILIZER ASSY		02
003	0521051401	ASSY ARTICULATED CONDUCTOR SUPPORT BASE	64	08
004	0503062766	SEED CONDUCTOR		04
005	0503062767	SEED CONDUCTOR		04
006	0521051407	FIXER SILO FERTILIZER	65	12




Item	Code	Description	See page	QT
001	0521068729	SUPPORT SIDE		01
002	0503062391	SILO FERTILIZER 5 MOUTHS		02
003	0503062766	SEED CONDUCTOR		04
004	0503062767	SEED CONDUCTOR		06
005	0521051401	ASSY ARTICULATED CONDUCTOR SUPPORT BASE	64	10
006	0521051407	FIXER SILO FERTILIZER	65	16




Item	Code	Description	See page	QT
01	0521053327	RIGHT SIDE HANDRAIL	113	01
02	0521053328	RIGHT SIDE HANDRAIL	114	01
03	0521053341	LEFT SIDE HANDRAIL	132	01
04	0521053342	LEFT SIDE HANDRAIL	134	01
05	0521053096	ASSY SIDE FRAME HANDRAIL FIXER	131	01




Item	Code	Description	See page	QT
001	0521053031	LEFT SIDE CORRIMAO		01
002	0521053032	FRONT SIDE CORRIMAO	118	01
003	0521053053	LEFT SIDE CORRIMAO	133	01
004	0521053096	ASSY SIDE FRAME HANDRAIL FIXER	131	01
004A	0581017326	HANDRAIL FIXER		01
004B	0503010395	1/2" X 1-1/4" BOLT		02
004C	0503010019	1/2" SPRING WASHER		04
004D	0503010060	1/2" NUT		04
004E	0503010238	1/2" X 1-3/4" BOLT		02




Item	Code	Description	See page	QT
01	0581017326	HANDRAIL FIXER		01
02	0503010395	1/2" X 1-1/4" BOLT		02
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0503010238	1/2" X 1-3/4" BOLT		02




Item	Code	Description	See page	QT
01	0521067991	GEAR HANDRAIL		02
02	0511059383	INTERNAL FIXER ASSY HANDLE	69	08
03	0581012718	HANDRAIL		03
04	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	70	04
05	0581015992	TUBE		02
06	0581014825	FRAME TUBE		01
07	0581017742	OIL TUBE		03
08	0581017743	OIL TUBE		03




Item	Code	Description	See page	QT
001	0521067991	GEAR HANDRAIL		02
002	0511059383	INTERNAL FIXER ASSY HANDLE	69	10
003	0581012718	HANDRAIL		04
004	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	70	08
005	0581015992	TUBE		04
006	0581017331	OIL TUBE		03
007	0581017332	OIL TUBE		03
008	0581017396	TUBE		03
009	0581014825	FRAME TUBE		02




Item	Code	Description	See page	QT
01	0521067991	GEAR HANDRAIL		03
02	0511059383	INTERNAL FIXER ASSY HANDLE	69	10
03	0581012718	HANDRAIL		03
04	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	70	05
05	0581015992	TUBE		04
06	0581017740	OIL TUBE		03
07	0581017741	OIL TUBE		03




Item	Code	Description	See page	QT
001	0511059943	SUPPORT FASTENER ASSY	03	
001A	0581011417	DUTO HOLDER SUPPORT	01	
001B	0503010237	3/8" X 1" BOLT	02	
001C	0503010025	3/8 SPRING WASHER	02	
001D	0503010026	3/8" NUT	02	
002	0521053025	DUCT SUPPORT OIL	02	
002A	0571019121	FIXER LOWER	01	
002B	0581013094	DUTO HOLDER SUPPORT	01	
002C	0571019139	PRISONER	02	
002D	0511017302	FLAT WASHER	04	
002E	0503010019	1/2" SPRING WASHER	04	
002F	0503010060	1/2" NUT	04	
003	0581014987	LOWER BODY FASTENER	10	
004	0501082190	HOSE 3/8 X 160 TR-TR	02	
005	0503011268	3/8" X 2-1/2" BOLT	05	
006	0503010025	3/8 SPRING WASHER	05	
007	0503010026	3/8" NUT	05	
008	0521068731	OIL TUBE	02	
009	0511068880	3485 OIL TUBE	02	




Item	Code	Description	See page	QT
001	0511059943	SUPPORT FASTENER ASSY	03	
001A	0581011417	DUTO HOLDER SUPPORT	01	
001B	0503010237	3/8" X 1" BOLT	02	
001C	0503010025	3/8 SPRING WASHER	02	
001D	0503010026	3/8" NUT	02	
002	0521053025	DUCT SUPPORT OIL	01	
002A	0571019121	FIXER LOWER	01	
002B	0581013094	DUTO HOLDER SUPPORT	01	
002C	0571019139	PRISONER	02	
002D	0511017302	FLAT WASHER	04	
002E	0503010019	1/2" SPRING WASHER	04	
002F	0503010060	1/2" NUT	04	
003	0581014987	LOWER BODY FASTENER	08	
004	0501082190	HOSE 3/8 X 160 TR-TR	02	
005	0503011268	3/8" X 2-1/2" BOLT	04	
006	0503010025	3/8 SPRING WASHER	04	
007	0503010026	3/8" NUT	04	
008	0521068731	OIL TUBE	02	
009	0511068880	3485 OIL TUBE	02	
010	0503062180	ADAPT T C / PORCA GIRAT LAT	01	




Item	Code	Description	See page	QT
01	0551019056	SIDE PLATFORM SUPPORT		01
02	0503010019	1/2" SPRING WASHER		07
03	0503010060	1/2" NUT		07
04	0503014007	1/2" X 1-1/4" BOLT		07
05	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0571013956	CENTRAL TRACK SUPPORT		01
02	0503010025	3/8 SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0503013029	3/8" X 3/4" BOLT		01
05	0501011643	3/8 X 1" BOLT		01



Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	NUT		02



Item	Code	Description	See page	QT
01	0551019557	FLASHLIGHT SUPPORT		01
02	0503032811	FLASHLIGHT		01



Item	Code	Description	See page	QT
01	0581015856	REDLIGHT SUPPORT		01
02	0503018738	LIGHTHOUSE		01
03	0501010694	FLAT WASHER		02
04	0503010358	5/16" X 5/8" BOLT		02
05	0551019884	45 X 50 X 3/8 FASTENER		02
06	0503013759	NUT		06

This image shows a single page from a notebook or ledger. The page is white with rounded corners and features horizontal ruling lines spaced evenly down its length. There are no vertical margin lines, and the page is completely blank except for the lines.





MARCHESAN IMPLEMENTOS E MÁQUINAS AGRÍCOLAS TATU S.A.

AV. Marchesan, 1979 - Post office box, 131 - CEP 15994-900 - Matão - SP - Brazil

Phone +55 16.3382-8282

(FAX Parts) + 55 16.3382. 8297 - (Export) + 55 16.3382.1003

e.mail: tatu@marchesan.com.br www.marchesan.com.br

Technical Publications: Elaboration

LUIZ CANDIDO

Technical Publications: Revision

LUIZ CANDIDO

Contact Catálogo:

E-mail = jgaspari@marchesan.com.br

**ORIGINAL PARTS
TATU**

