

ROW CROP PLANTERS

PHT4 FLEX SUPREMA P.P - FRAME 3190/4E900 - CSU / MH

Code: 0501092612
Series: S-1018
Revision: 00
Date Revision: OUTUBRO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS

Code	Description
0111480009	PHT4 FLEX SUP PP 3190/4E900 CSU S-1018
0111480011	PHT4 FLEX SUP PP 3190/4E900 CSU S/ADB S-1018
0111480010	PHT4 FLEX SUP PP 3190/4E900 MH CSU S-1018
0111480013	PHT4 FLEX SUP PP 3190/4E900 MH CSU S/ADB S-1018

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909095041	FRAME ASSY	1
0521054651	FRAME WITH FRONT AND WHEELSETS	2
0521054615	ASSY LEFT WHEEL	3
0521054616	ASSY RIGHT WHEEL	4
0511052483	LEFT CARRYING-WHEELS	5
0511052484	WHEELS RIGHT	6
0503060105	WELL AND TIRE ASSY	7
0511052485	LH WHEELS ARM	8
0511052486	WHEEL ARM RIGTH	9
0511052487	TURNBUCKLE	10
0501056444	BEARING WITH ROLLER	11
0511057192	EXTENSION SPRING	12
0521054617	LEFT FERTILIZER ROW	13
0521054618	RIGHT FERTILIZER ROW	14
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	15
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	16
0511053172	LEFT LOW CUBE WITH DISC 15	17
0511053173	CUBE LOW RIGHT WITH DISC 15	18
0521053891	FRONT SEED	19
0521053565	SEED ROW SUPPORT	20
0511054635	BEARING AXLE BODY	21
0501052769	BEARING WITH 17Z GEAR	22
0511055260	SEED ROW CHAIN TENSIONER	23
0521053688	SEED ROW FRAME	24
0511057159	TRANSMISSION HOPPER SEED ROW	25
0521054636	ASSY CARDAN TRANSMISSION	26
0511052389	BEARING DOUBLE FRONT ROW SEED	27
0521054639	HITCH TO THE THIRD POINT	28
0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	29
0531055990	CARDAN TURBINE WITH AIR TUBE	30
0531055989	425 AIR DISTRIBUTOR	31
0531055986	CARDAN TURBINE	32
0521057355	FAN BEARING	33
0521057406	TURBINE SUPPORT	34
0521053555	PULLEY ASSY	35
0521053556	PULLEY WITH TURBINE AXLE	36
0531055994	RIGHT AIR DUCT SUPPORT	37
0531055993	LEFT AIR DUCT SUPPORT	38
0521054689	HYDRAULIC MARKER ASSEMBLY	39
0521040155	HYDRAULIC CYLINDER 31,75 X 50,8 X 365 X 595	40
0501054649	HBM SEQUENTIAL VALVE	41
0501050633	ROW MARKER DISC ASSEMBLY	42
0511053904	ROW MARKER DISC	43
0521054696	REST ASSEMBLY	44
0521054691	ASSEMBLY LADDER	45
0531055995	2" AIR DUCT SUPPORT	46
0521053964	VALVE SUPPORT	47
0521054665	FERTILIZER GEARBOX	48
0511059266	CLOSED BEARING	49
0501056271	GEARBOX CLOSED BEARING	50
0501056443	GEAR HOUSING BEARING	51
0501048790	AXLE WITH RING	52
0521054666	CHAIN TENSIONER	53
0521054694	SEED TRANSMISSION	54
0511057698	20Z BEARING GEAR	55




MARCHESAN

INDEX

0501059059	LARGE BEARING ROW SEED ASSY	56
0521054692	ASSEMBLY PLATFORM	57
0521054695	HANDRAIL ASSEMBLY	58
0521053558	HANDRAIL EXTERNAL	59
0521053543	HANDRAIL INTERNAL	60
0511059383	HANDRAIL INTERNAL FIXER	61
0521054635	INSTRUCTION MANUAL CANISTER ASSEMBLY	62
0521054693	SEED ASSEMBLY	63
0521053559	SEED HOPPER ASSEMBLY	64
0521040712	RIGHT FERTILIZER HOPPER ASSY	65
0521040718	LEFT FERTILIZER HOPPER ASSY	66
0511051712	RH BEAM SUPPORT	67
0511051717	LH BEAM SUPPORT	68
0511051714	SIDE FERTILIZER DISTRIBUTOR	69
0511051715	SIDE FERTILIZER DISTRIBUTOR	70
0501056451	BEARING	71
0501053788	3/4 SQUARE AXLE FASTENER	72
0521053562	RIGHT REAR SEED ROW ASSEMBLY	73
0521053560	LEFT REAR SEED ROW ASSEMBLY	74
0521053564	ASSEMBLY PRECISION PLANTING	75
0521053561	PRECISION PLANTING ASSEMBLY V-SET2 LEFT	76
0511057155	PRECISION PLANTING LEFT TRANSMISSION HOPPER	77
0521053548	DISTRIBUTOR SEED COMPLETE WITH DISC PEANUT	78
0511059081	LH 15"X15" SEED UNAL DOUB-DISC ASSY	79
0501054167	15" RIGHT OPENING DISC HUB	80
0501054168	15" LEFT DOUBLE DISC HUB	81
0521052617	WHEEL SYSTEM DEPTH / COMPACTOR	82
0501056769	DEPTH WHEELS REGULATOR ASSY	83
0521051423	COMPACTOR SUPPORT	84
0501052908	COMPACTOR WHEEL WITH BEARING	85
0511059489	CENTRAL RAIL WHEEL	86
0511052287	DEPTH WHEEL HUB ASSY	87
0521050525	FIXER FERTILIZER CONDUCTOR	88
0501047947	DRIVE SHAFT	89
0909095039	ROW MARKER HYDRAULIC CIRCUIT	90
0501053834	MALE QUICK COUPLER	91

FRAME ASSY

0909095041




Item	Code	Description	See page	QT
01	0521054651	FRAME WITH FRONT AND WHEELSETS	2	01
02	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	29	01
03	0531055990	CARDAN TURBINE WITH AIR TUBE	30	01
04	0503010246	CLAMP		08
05	0531055994	RIGHT AIR DUCT SUPPORT	37	01
06	0531055993	LEFT AIR DUCT SUPPORT	38	01
07	0581014411	BREATHE		01
08	0521054689	HYDRAULIC MARKER ASSEMBLY	39	01
09	0501050633	ROW MARKER DISC ASSEMBLY	42	02
10	0521054696	REST ASSEMBLY	44	02
11	0521054691	ASSEMBLY LADDER	45	01
12	0531055995	2" AIR DUCT SUPPORT	46	04
13	0521053964	VALVE SUPPORT	47	01
14	0503013584	VACUUM GAUGE		01
15	0521054665	FERTILIZER GEARBOX	48	01
16	0521054694	SEED TRANSMISSION	54	01
17	0502012007	SQUARE SLEEVE		01
18	0521054692	ASSEMBLY PLATFORM	57	01
19	0521054695	HANDRAIL ASSEMBLY	58	01
20	0561014215	BEARING COVER LOWER ROW FRAME		01
21	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		02
22	0501010694	FLAT WASHER		02
23	0503010179	LOCK WASHER 5/16 ZN 1K01528		03
24	0503010337	5/16" NUT		03
25	0521054635	INSTRUCTION MANUAL CANISTER ASSEMBLY	62	01
26	0581010406	MANUAL CASE FIXER		01
27	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
28	0521011039	FLAT WASHER		01
29	0521054693	SEED ASSEMBLY	63	01
30	0521040712	RIGHT FERTILIZER HOPPER ASSY	65	01
31	0521040718	LEFT FERTILIZER HOPPER ASSY	66	01

FRAME ASSY

0909095041


Item	Code	Description	See page	QT
32	0521053562	RIGHT REAR SEED ROW ASSEMBLY	73	02
33	0521053560	LEFT REAR SEED ROW ASSEMBLY	74	02
34	0521052617	WHEEL SYSTEM DEPTH / COMPACTOR	82	04
35	0521010579	COUPLING SHAFT		01
36	0503031035	HITCH PIN CLIP		01
37	0581017313	SEED CONDUCTOR		04
38	0521050525	FIXER FERTILIZER CONDUCTOR	88	08
39	0501215301	2" X 1.1/2" X 75 REDUCING SLEEVE		04
40	0501215311	2" X 2000 HOSE		04
41	0503030391	RIGHT FERTILIZER NOZZLE		02
42	0503030392	LEFT FERTILIZER NOZZLE		02
43	0503030408	2X2X390 HOSE		04
44	0503031050	CURVED CONDUCTOR		04
45	0503031076	2" HOSE CLAMP		08
46	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
47	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
48	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
49	0503010025	3/8" SPRING WASHER		02
50	0503010026	3/8" NUT		02
51	0503010019	1/2" SPRING WASHER		04
52	0503010060	1/2 UNC G.5 ZN HEX NUT		04
53	0501047947	DRIVE SHAFT	89	01
54	0909095039	ROW MARKER HYDRAULIC CIRCUIT	90	01
55	0503010243	CLAMP		04



Item	Code	Description	See page	QT
01	0521069011	FRAME		01
02	0521054615	ASSY LEFT WHEEL	3	01
03	0521054616	ASSY RIGHT WHEEL	4	01
04	0521054618	RIGHT FERTILIZER ROW	14	02
05	0521054617	LEFT FERTILIZER ROW	13	02
06	0521053891	FRONT SEED	19	04
07	0521054639	HITCH TO THE THIRD POINT	28	02

ASSY LEFT WHEEL

0521054615



Item	Code	Description	See page	QT
01	0521063583	WHEEL SUPPORT		01
02	0502010175	HITCH CLAMP		01
03	0501011543	5/8" X 4" BOLT		02
04	0503012412	5/8 UNC SELF LOCKING NUT		03
05	0511052483	LEFT CARRYING-WHEELS	5	01
06	0571010967	CHAIN TENSIONER		01
07	0511052487	TURNBUCKLE	10	01
08	0521010784	COUPLING SHAFT		01
09	0501011445	FLAT WASHER		02
10	0503010571	1/4" X 1.1/2 COTTERPIN		01
11	0521017623	0.5" X 1.5" COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0571010964	TENSIONER CHAIN		01
14	0561016501	30,50 X 42 X 16 SLEEVE		01
15	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01
16	0571010341	SQUARE SHAFT		01
17	0501056444	BEARING WITH ROLLER	11	02
18	0561016503	PRISONER 3/8 UNC		03
19	0503010025	3/8" SPRING WASHER		07
20	0561019680	LEFT CHAIN COVER		01
21	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06
22	0503010209	3/8" UNC BUTTERFLY NUT		03
23	0503030303	SUPPORT WASHER		04
24	0521018630	1.4" X SQUARE 0.8" WASHER		05
25	0503010577	3/16" X 1-1/4" COTTERPIN		05
26	0521060880	GEAR 22 TEETH		01
27	0501013354	FLAT WASHER		02
28	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
29	0511061757	18Z GEAR		01
30	0501011299	FLAT WASHER		01
31	0503030402	PULLEY		01


ASSY LEFT WHEEL

0521054615

Item	Code	Description	See page	QT
32	0503018182	40-1 X 39 CHAIN LINK + MENDING		01
33	0501010694	FLAT WASHER		08
34	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
35	0503010337	5/16" NUT		08
36	0561019679	CHAIN CAP		01
37	0511057192	EXTENSION SPRING	12	01
38	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
39	0503013618	BOLT		02
40	0581018867	AXIS Q 3/4 "X 245 CARDAN TRANSMISSION		01
41	0521062809	BEARING		02
42	0503013462	BEARING WITH BALL BEARING		02
43	0503011105	SEAL RING		02
44	0503031805	11Z 1/2" GEAR		01
45	0503010302	501019 SEAL RING		02
46	0503010002	1800 GREASE FITTING		01
47	0503010026	3/8" NUT		02
48	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		08
49	0521012311	CHAIN TIGHTENER AXLE		01
50	0502012717	GEAR 22Z P.1/2 FQ 3/4"		01

ASSY RIGHT WHEEL

0521054616




Item	Code	Description	See page	QT
01	0521063583	WHEEL SUPPORT		01
02	0502010175	HITCH CLAMP		01
03	0501011543	5/8" X 4" BOLT		02
04	0503012412	5/8 UNC SELF LOCKING NUT		03
05	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06
06	0571010967	CHAIN TENSIONER		01
07	0511052487	TURNBUCKLE	10	01
08	0521010784	COUPLING SHAFT		01
09	0501011445	FLAT WASHER		02
10	0503010571	1/4" X 1.1/2 COTTERPIN		01
11	0521017623	0.5" X 1.5" COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0571010964	TENSIONER CHAIN		01
14	0561016501	30,50 X 42 X 16 SLEEVE		01
15	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01
16	0571010341	SQUARE SHAFT		01
17	0501056444	BEARING WITH ROLLER	11	02
18	0561016503	PRISONER 3/8 UNC		03
19	0503010025	3/8" SPRING WASHER		07
20	0503030303	SUPPORT WASHER		04
21	0503010209	3/8" UNC BUTTERFLY NUT		03
22	0521018630	1.4" X SQUARE 0.8" WASHER		05
23	0503010577	3/16" X 1-1/4" COTTERPIN		05
24	0521060880	GEAR 22 TEETH		01
25	0501013354	FLAT WASHER		02
26	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
27	0511061757	18Z GEAR		01
28	0501011299	FLAT WASHER		01
29	0503030402	PULLEY		01
30	0503018182	40-1 X 39 CHAIN LINK + MENDING		01
31	0501010694	FLAT WASHER		08


ASSY RIGHT WHEEL

0521054616


Item	Code	Description	See page	QT
32	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
33	0503010337	5/16" NUT		08
34	0561019679	CHAIN CAP		01
35	0511057192	EXTENSION SPRING	12	01
36	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
37	0503013618	BOLT		02
38	0581018867	AXIS Q 3/4 "X 245 CARDAN TRANSMISSION		01
39	0521062809	BEARING		02
40	0503013462	BEARING WITH BALL BEARING		02
41	0503011105	SEAL RING		02
42	0503031805	11Z 1/2" GEAR		01
43	0503010302	501019 SEAL RING		02
44	0503010002	1800 GREASE FITTING		01
45	0503010026	3/8" NUT		02
46	0511052484	WHEELS RIGHT	6	01
47	0571010830	RIGHT CHAIN COVER		01
48	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		08
49	0521012311	CHAIN TIGHTENER AXLE		01
50	0502012717	GEAR 22Z P.1/2 FQ 3/4"		01



Item	Code	Description	See page	QT
01	0503060105	WELL AND TIRE ASSY	7	01
02	0511052485	LH WHELLS ARM	8	01
03	0501010127	9/16" X 1-7/8" LUG BOLT		04
04	0503010035	9/16" CONIC NUT		04




Item	Code	Description	See page	QT
01	0503060105	WELL AND TIRE ASSY	7	01
02	0511052486	WHEEL ARM RIGTH	9	01
03	0501010127	9/16" X 1-7/8" LUG BOLT		04
04	0503010035	9/16" CONIC NUT		04



Item	Code	Description	See page	QT
01	0503011010	CANVAS TIRE		01
02	0503010791	AR F 15 INNER TIRE		01
03	0503010789	0.2"J X 15H2" X0.2"F X0.6"X6" WHEEL		01

LH WHELLS ARM


0511052485



Item	Code	Description	See page	QT
01	0521061662	WHEELED AXLE		01
02	0521063587	LH WHEEL ARM		01
03	0571010311	SLEEVE INTERMEDIARY		02
04	0503010002	1800 GREASE FITTING		02
05	0503013170	ROLLER BEARING		02
06	0561016502	GUARD POWDER		02
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01

WHEEL ARM RIGTH


0511052486




Item	Code	Description	See page	QT
01	0521061662	WHEELED AXLE		01
02	0521063588	RH WHEEL ARM		01
03	0571010311	SLEEVE INTERMEDIARY		02
04	0503010002	1800 GREASE FITTING		02
05	0503013170	ROLLER BEARING		02
06	0561016502	GUARD POWDER		02
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01

TURNBUCKLE

0511052487




Item	Code	Description	See page	QT
01	0521063584	BODY RIGHT TURNBUCLE		01
02	0521063585	LEFT EXTENSOR BODY		01
03	0541010618	STABILIZER BODY		01
04	0541010087	LOOK NUT		01
05	0503010691	1/4" GREASE FITTING		02



Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01

EXTENSION SPRING


0511057192



Item	Code	Description	See page	QT
01	0503031681	2.1" X 7.78" EXTENSION SPRING		01
02	0502011031	SPRING UPPER HITCH		02

LEFT FERTILIZER ROW


0521054617




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0511018662	SPACING PLATE		02
03	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	15	01
04	0502010175	HITCH CLAMP		01
05	0581017926	LOWER SUPPORT SPRING FERTILIZER		01
06	0581017927	SUPPORT SPRING FERTILIZER		01
07	0503034712	LONG SPRING 10,50 X 46,50 X 230		01
08	0521069017	SPRING REGULATOR		01
09	0521069394	LEFT FERTILIZER ROW BODY		01
10	0581018866	63,5 X 42 X 20 SPACER SLEEVE		01
11	0501012140	FLAT WASHER		02
12	0503010847	1/2\" X 3.1/4\" BOLT		02
13	0503011075	3/4\" UNC NUT		01
14	0503011198	C3/4\" X 6\" SCREW		01
15	0503011255	3/4\" LOCK NUT		02
16	0503011336	1/2\" HEX SELF ADJUSTING NUT		02
17	0503012412	5/8 UNC SELF LOCKING NUT		02
18	0503016110	BOLT 5/8 UNC X 4 C S G.7 ZN		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
20	0511016281	3/4\" X 8\" BOLT		01
21	0511017232	FLAT WASHER		04
22	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02

RIGHT FERTILIZER ROW


0521054618




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0511018662	SPACING PLATE		02
03	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	16	01
04	0502010175	HITCH CLAMP		01
05	0581017926	LOWER SUPPORT SPRING FERTILIZER		01
06	0581017927	SUPPORT SPRING FERTILIZER		01
07	0503034712	LONG SPRING 10,50 X 46,50 X 230		01
08	0521069017	SPRING REGULATOR		01
09	0521069393	RIGHT FERTILIZER ROW BODY		01
10	0581018866	63,5 X 42 X 20 SPACER SLEEVE		01
11	0501012140	FLAT WASHER		02
12	0503010847	1/2" X 3.1/4" BOLT		02
13	0503011075	3/4" UNC NUT		01
14	0503011198	C3/4" X 6" SCREW		01
15	0503011255	3/4" LOCK NUT		02
16	0503011336	1/2" HEX SELF ADJUSTING NUT		02
17	0503012412	5/8 UNC SELF LOCKING NUT		02
18	0503016110	BOLT 5/8 UNC X 4 C S G.7 ZN		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
20	0511016281	3/4" X 8" BOLT		01
21	0511017232	FLAT WASHER		04
22	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	17	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	18	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15\"X15\" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8\" X 1.1/4\" HEX BOLT G.5		01
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
13	0503010026	3/8\" NUT		01
14	0503010025	3/8\" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2\" X 0.8\" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	18	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	17	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02



Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0521053565	SEED ROW SUPPORT	20	01
02	0531015184	FLAT WASHER		08
03	0501110906	TOP SEED ROW ARM WITH SLEEVE		01
04	0511017907	1/8" BSPT X 6 PLUG		04
05	0501110905	BOTTOM SEED ROW ARM WITH SLEEVE		01
06	0581017914	PANTOGRAPHO SLEEVE		08
07	0521053688	SEED ROW FRAME	24	01
08	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		02
09	0511057159	TRANSMISSION HOPPER SEED ROW	25	01
10	0503012412	5/8 UNC SELF LOCKING NUT		02
11	0502012568	UPPER ROCKER ARM		01
12	0581019051	JUNCTION 15.88 X 85 SHAFT		02
13	0503010577	3/16" X 1-1/4" COTTERPIN		01
14	0503030168	HITCH PIN CLIP		01
15	0581018487	FIXER UPPER SPRING		01
16	0503034580	TRACTION SPRING		02
17	0521054636	ASSY CARDAN TRANSMISSION	26	01
18	0521010773	0.37" X 1.18" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01

SEED ROW SUPPORT


0521053565




Item	Code	Description	See page	QT
01	0561814904	ROW FRAME TRANSMISSION AXLE		01
02	0511054635	BEARING AXLE BODY	21	02
03	0502012782	17Z GEAR WITH HEX HOLE		01
04	0502012789	FIXER SUPPORT FERTILIZER ROW		01
05	0501052769	BEARING WITH 17Z GEAR	22	01
06	0511055260	SEED ROW CHAIN TENSIONER	23	01
07	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
08	0521069395	FRONT SUPPORT		01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		02
10	0501010694	FLAT WASHER		04
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
12	0503010337	5/16" NUT		04
13	0503010811	5/8" UNF SELF ADJUSTING NUT		04
14	0503011953	5/16" X 1" BOLT		04
15	0503012412	5/8 UNC SELF LOCKING NUT		02
16	0503017857	BOLT 5/8 UNF 4		04



Item	Code	Description	See page	QT
01	0502012718	BEARIN BODY		01
02	0503012882	BEARING		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0503010406	501025 CLAMPING RING (FOR AXLE)		01
02	0502011697	BEARING OF THE GEAR BOX		01
03	0503011410	ROLLER BEARING		01
04	0503011105	SEAL RING		01
05	0503011953	5/16" X 1" BOLT		02
06	0501010694	FLAT WASHER		02
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
08	0503010337	5/16" NUT		02
09	0502012819	17Z GEAR WITH HEX HOLE		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01

SEED ROW FRAME


0521053688




Item	Code	Description	See page	QT
01	0521061427	SHORT SEED ROW FRAME		01
02	0521069012	SEED ROW COMPLEMENT		01
03	0503014378	1/2" X 1-1/2" BOLT		04
04	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
05	0503010589	1/2" UNC SELF ADJUSTING NUT		04



Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01
17	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0551017540	5/8" X 73 AXLE HEX		01
02	0551017559	BEARING AXLE BODY		01
03	0501056296	UNIVERSAL JOINT		01
04	0561014778	HEX UNIVERSAL JOINT		01
05	0511052389	BEARING DOUBLE FRONT ROW SEED	27	01
06	0581018851	HEX AXLE 5/8 "X 195		01
07	0503010406	501025 CLAMPING RING (FOR AXLE)		02
08	0503011855	0.2" X 1.8" SPRING PIN		04




Item	Code	Description	See page	QT
01	0502011971	HOUSING WITH DOUBLE BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02

HITCH TO THE THIRD POINT


0521054639




Item	Code	Description	See page	QT
01	0521069288	HITCH TO THE TRACTOR LOWER		01
02	1902010584	CARRYING-WHEELS SUPPORT FIXER		01
03	0503017856	BOLT 3/4		02
04	0501010322	FLAT WASHER		02
05	0503010152	3/4" SELF LOCKING NUT		02
06	0521010596	COUPLING SHAFT		01
07	0503031035	HITCH PIN CLIP		01



Item	Code	Description	See page	QT
01	0503030331	1.2" X 1.2" X 12.2" HOSE		01
02	0503010243	CLAMP		02
03	0503062755	TRANSMISSION AXLE		01
04	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
05	0503012880	1/4" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0503017845	90 PVC KNEE		02
02	0531055989	425 AIR DISTRIBUTOR	31	02
03	0501215296	AIR DISTRIBUTOR NOZZLE		02
04	0531055986	CARDAN TURBINE	32	01



Item	Code	Description	See page	QT
01	0501215297	425 AIR DISTRIBUTOR BODY		01
02	0503031943	SOCKET		02
03	0503012856	POP RIVET		04
04	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
04A	0503034763	AIR DITRIBUTOR PUMP		01
04B	0503015341	POP RIVET		02

CARDAN TURBINE

0531055986




Item	Code	Description	See page	QT
01	0521057355	FAN BEARING	33	01
02	0581017928	PRISONER HEX 5/8 X 235		02
03	0521053555	PULLEY ASSY	35	01
04	0501011194	1/2" X 1-3/4" BOLT		04
05	0521018517	FLAT WASHER		04
06	0503010019	1/2" SPRING WASHER		08
07	0503012682	1/2" BSW NUT		04
08	0501012140	FLAT WASHER		01
09	0503010013	5/8" NUT		01
10	0503013030	5/8" X 3.1/4" BOLT		01
11	0503012780	LARGER TURBINE BELT		01
12	0581017932	FLANGE COUPLING TURBINE		01
13	0503015348	3/8" BOLT		04
14	0503034404	TURBINE REAR COVER		01
15	0503015046	M10 X 1,50 X 20 BOLT		04
16	0503034406	FAN PP 730115		01
17	0503034407	NUT		01
18	0503034413	FLAT WASHER		07
19	0503034414	SCREW 5/16 X 1		07
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
21	0503010384	1/2" X 5" BOLT		02
22	0501010694	FLAT WASHER		02
23	0503010179	LOCK WASHER 5/16 ZN 1K01528		07
24	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		02
25	0531060565	BACK LID		01
26	0591012381	TOP PROTECTION COVER		01
27	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
28	0503010060	1/2 UNC G.5 ZN HEX NUT		04
29	0503013357	3/8" SELF-ADJUSTING NUT		04
30	0501215298	440 SUCTION DUCT		01
31	0531064418	TURNINE LID WITH SLEEVE		01



CARDAN TURBINE

0531055986


Item	Code	Description	See page	QT
32	0503062560	TUBE FOR METER CLOCK 730142		01
33	0503010421	5/16" X 1-1/2" BOLT		05



Item	Code	Description	See page	QT
01	0521057406	TURBINE SUPPORT	34	01
02	0503012689	6306 DDU BEARING		02
03	0531010881	INTERMEDIARY UPPER SLEEVE		01
04	0503034713	AXIS		01
05	0503010707	501030 CLAMPING RING (FOR AXLE)		01
06	0503010325	VCA-118 VALVE		01

TURBINE SUPPORT


0521057406




Item	Code	Description	See page	QT
01	0521069018	ASSEMBLY TURBINE SUPPORT		01
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503011336	1/2" HEX SELF ADJUSTING NUT		04
04	0502012016	CHAIN TENSIONER SUPPOT		01

PULLEY ASSY

0521053555




Item	Code	Description	See page	QT
01	0521053556	PULLEY WITH TURBINE AXLE	36	01
02	0503010845	501035 CLAMPING RING (FOR AXLE)		02
03	0531014519	FLAT WASHER		03
04	0503010325	VCA-118 VALVE		01
05	0502012020	PULLEY HOUSING BEARING		01
06	0503011081	6207 2RS BEARING		02
07	0531014518	INTERMEDIARY LOWER BUSHING BEARING		01



Item	Code	Description	See page	QT
01	0502012055	TURBINE PULLEY ASSY		01
02	0531014520	WASHER RATCHET		01
03	0503011081	6207 2RS BEARING		02
04	0501010649	RATCHET CLICK		03
05	0503034558	RATCHET		01
06	0503012950	5/16" X 2-1/2" BOLT		06
07	0503034559	AXLE RATCHET PULLEY TURBINE		01
08	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		06

RIGHT AIR DUCT SUPPORT


0531055994



Item	Code	Description	See page	QT
01	0501215307	RIGHT AIR DUCT SUPPORT BODY		01
02	0521018402	AIR CONDUCTOR CLAMP		01
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503010848	5/16" X 3.1/2" BOLT		02

LEFT AIR DUCT SUPPORT


0531055993




Item	Code	Description	See page	QT
01	0501215306	LEFT AIR DUCT SUPPORT BODY		01
02	0521018402	AIR CONDUCTOR CLAMP		01
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503010848	5/16" X 3.1/2" BOLT		02

HYDRAULIC MARKER ASSEMBLY


0521054689



Item	Code	Description	See page	QT
01	0501069307	ROW MARKER ARM		02
02	0531012400	COUPLING SHAFT		02
03	0503030168	HITCH PIN CLIP		02
04	0503011070	BEATER		02
05	0521062818	LEFT ARM		01
06	0521040155	HYDRAULIC CYLINDER 31,75 X 50,8 X 365 X 595	40	02
07	0521062819	RIGHT ARM		01
08	1902012702	UPPER CLAMP BODY		06
09	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
10	0501054649	HBM SEQUENTIAL VALVE	41	01
11	0503010019	1/2" SPRING WASHER		02
12	0503010025	3/8" SPRING WASHER		02
13	0503010180	7/16" SPRING WASHER		06
14	0503010237	3/8" X 1" BOLT		02
15	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		06
16	0503010577	3/16" X 1-1/4" COTTERPIN		04
17	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
18	0503010834	1/2 X 1 BOLT		04
19	0521010571	COUPLING SHAFT		02




Item	Code	Description	See page	QT
01	0521062810	2X 350 CYLINDER BARREL		01
02	0571010344	31,75 X 456 ROD		01
03	0551019990	31,75 X 50,80 X 39,40 PISTON		01
04	0503010812	7/8" UNF SELF LOCKING NUT		01
05	0503010949	W2-2000-500 PK RING G.E		01
06	0503013920	GASKET 1870-1625		02
07	0503014677	2-118 O'RING		01
08	0503013917	O'RING 2-224		01
09	0503013914	1870-1250-312B GASKET		01
10	0503013915	D-1250 SCRAPER RING		01
11	0503013918	8-224 BACK-UP RING		01
12	0503014683	W1-1400-500 RING GUIDE		01
13	0501012140	FLAT WASHER		01
14	0503012412	5/8 UNC SELF LOCKING NUT		01
15	0571010576	MARKER SUPPORT WASHER		01
16	0571011410	RING SUPPORT		01
17	0571011411	MOBILE CYLINDER LID		01
18	0503033686	SLEEVE 22 X 38 X 12,50 RUBBER		02
19	0501038643	ASSEMBLY		01



Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02

ROW MARKER DISC ASSEMBLY


0501050633




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	43	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01

ROW MARKER DISC

0511053904




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0501065337	PLOUGH SUPPORT		01
02	0521010530	JUNCTION AXLE 6,80 X 60		01
03	0503010140	1/8" X 3/4" COTTERPIN		01
04	0521010809	11,11 X 64 COUPLING SHAFT		01
05	0503030168	HITCH PIN CLIP		01

ASSEMBLY LADDER

0521054691




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		04
02	0501013687	FLAT WASHER		08
03	0503010025	3/8" SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0503010237	3/8" X 1" BOLT		08
06	0511069636	LADDER		02
07	0501010096	3/8" X 2" BOLT		04
08	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
09	0503013357	3/8" SELF-ADJUSTING NUT		04



Item	Code	Description	See page	QT
01	0531064421	2" AIR DUCT SUPPORT		01
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		04

VALVE SUPPORT


0521053964



Item	Code	Description	See page	QT
01	0581018366	ROW MARKER VALVE SUPPORT		01
02	0581018364	SUPPORT VACUOMETER		01
03	0581018365	BASE SUPPORT VACUOMETER		01
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
05	0503010025	3/8" SPRING WASHER		02
06	0503010026	3/8" NUT		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0503013849	1/4" UNC X 3/4" BOLT		02

FERTILIZER GEARBOX

0521054665




Item	Code	Description	See page	QT
01	0521062568	SIDE		01
02	0502011758	REAR TIGHTENER LEVER		01
03	0571010425	JACK		04
04	0571010426	SLEEVE SUPPORT		04
05	0503031366	RIGHT TWISTED SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0581019073			01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		08
09	0581014147	MOTOR SHAFT		01
10	0561017353	MOTOR SHAFT		01
11	0511060396	DRIVE/DRIVEN SHAFT		02
12	0511059266	CLOSED BEARING	49	03
13	0503030303	SUPPORT WASHER		01
14	0521018630	1.4" X SQUARE 0.8" WASHER		09
15	0503010292	701164 6 X 40 SPRING PIN		05
16	0503031805	11Z 1/2" GEAR		02
17	0503010302	501019 SEAL RING		02
18	0503010002	1800 GREASE FITTING		01
19	0501056443	GEAR HOUSING BEARING	51	01
20	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
21	0503012204	40-1 CHAIN X 82 LINK + RED		01
22	0581012581	TOP RIGHT COVER		01
23	0521067247	RIGHT PROTECTION COVER		01
24	0581012580	REAR COVER		01
25	0501013518	FLAT WASHER		03
26	0503010025	3/8" SPRING WASHER		01
27	0503013357	3/8" SELF-ADJUSTING NUT		02
28	0503011907	NYLON HANDLE		01
29	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		02
30	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
31	0503010337	5/16" NUT		02


FERTILIZER GEARBOX

0521054665


Item	Code	Description	See page	QT
32	0503010256	3/8" X 3/4" BOLT		03
33	0501048790	AXLE WITH RING	52	01
34	0521054666	CHAIN TENSIONER	53	01
35	0503014528	40-1 CHAIN X 72 LINK + REDECTION		01
36	0503012389	1/2 BALL		02
37	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		02
38	0503010395	1/2" X 1-1/4" BOLT		02
39	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	50	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	11	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01



Item	Code	Description	See page	QT
01	0503031805	11Z 1/2" GEAR		01
02	0561016554	CURRENT STRETCH AXIS WHEELED SUPPORT		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511060396	DRIVE/DRIVEN SHAFT		02
02	0511067501	26Z GEAR		01
03	0511060392	CHAIN TENSIONER		01
04	0521018630	1.4" X SQUARE 0.8" WASHER		04
05	0503031805	11Z 1/2" GEAR		03
06	0501056443	GEAR HOUSING BEARING	51	01
07	0503030303	SUPPORT WASHER		01
08	0503031366	RIGHT TWISTED SPRING		01
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		02
10	0502011758	REAR TIGHTENER LEVER		01
11	0561014215	BEARING COVER LOWER ROW FRAME		01
12	0561016554	CURRENT STRETCH AXIS WHEELED SUPPORT		01
13	0561017353	MOTOR SHAFT		01
14	0561019671	BODY		01
15	0521062568	SIDE		01
16	0571010425	JACK		04
17	0501048790	AXLE WITH RING	52	01
18	0511059266	CLOSED BEARING	49	03
19	0503012204	40-1 CHAIN X 82 LINK + RED		01
20	0581012582	LEFT UPPER COVER		01
21	0581012580	REAR COVER		01
22	0521067248	LEFT PROTECTION COVER		01
23	0581014147	MOTOR SHAFT		01
24	0581017912	AXIS HEX 5/8 X 3195		01
25	0511057698	20Z BEARING GEAR	55	01
26	0503014852	40-1 CHAIN X 90 LINK + REDUCTION		01
27	0501010694	FLAT WASHER		02
28	0501013518	FLAT WASHER		01
29	0503010002	1800 GREASE FITTING		01
30	0503010019	1/2" SPRING WASHER		01
31	0503010025	3/8" SPRING WASHER		01


SEED TRANSMISSION

0521054694


Item	Code	Description	See page	QT
32	0503010060	1/2 UNC G.5 ZN HEX NUT		03
33	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
34	0503010256	3/8" X 3/4" BOLT		03
35	0503010292	701164 6 X 40 SPRING PIN		05
36	0503010302	501019 SEAL RING		03
37	0503010337	5/16" NUT		04
38	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		02
39	0503010834	1/2 X 1 BOLT		02
40	0503011336	1/2" HEX SELF ADJUSTING NUT		08
41	0503011907	NYLON HANDLE		01
42	0503011953	5/16" X 1" BOLT		02
43	0503012389	1/2 BALL		02
44	0503013357	3/8" SELF-ADJUSTING NUT		02
45	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0501059059	LARGE BEARING ROW SEED ASSY	56	01
02	0521066333	GEAR 20Z WITH AXIS F HEX 16,5X69		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01



Item	Code	Description	See page	QT
01	0581017911	PLATFORM		01
02	0503010237	3/8" X 1" BOLT		06
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06
04	0503010025	3/8" SPRING WASHER		06
05	0503010026	3/8" NUT		06




Item	Code	Description	See page	QT
01	0521053558	HANDRAIL EXTERNAL	59	01
02	0521053543	HANDRAIL INTERNAL	60	01
03	0503016453	1/2" X 2.1/2 BOLT		08
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
05	0503010019	1/2" SPRING WASHER		08
06	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0511059383	HANDRAIL INTERNAL FIXER	61	10
02	0581017934	TUBE 33,7 X 27 X 3055		02
03	0581017936	TUBE 33,7 X 27 X 460		02
04	0581017915	TUBE 33,7 X 27 X 942		02
05	0581017996	TUBE COMPLEMENT RAILING		01

HANDRAIL INTERNAL


0521053543



Item	Code	Description	See page	QT
01	0511059383	HANDRAIL INTERNAL FIXER	61	12
02	0581017997	TUBE 33,7 X 27 X 3145		02
03	0581017916	TUBE 33,7 X 27 X 315		03
04	0581017915	TUBE 33,7 X 27 X 942		02
05	0581017996	TUBE COMPLEMENT RAILING		01




Item	Code	Description	See page	QT
01	0502012857	EXTERNAL FIXER HANDRAIL		01
02	0502012858	INTERNAL FIXER HANDRAIL		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		01
04	0503015490	SELF-LOCKING NUT 7/16		01



Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0503010267	NYLON CLAMP		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	5/16" NUT		01

SEED ASSEMBLY


0521054693



Item	Code	Description	See page	QT
01	0511017907	1/8" BSPT X 6 PLUG		06
02	0521053559	SEED HOPPER ASSEMBLY	64	02
03	0581017914	PANTOGRAPHO SLEEVE		12
04	0581017913	SEED HOPPER DEFLECTOR		02
05	0521069038	ROW MOVABLE ARTICULATION		02
06	0503062831	FERTILIZER HOPPER ASSY		02
07	0581018853	SEED HOPPER FIXING		04
08	0581018852	13,5 X 35 X 10 SLEEVE		08
09	0581018864	DEFLECTOR SEED		02
10	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		06
11	0501010937	13,50 X 28 X 3,00 FLAT WASHER		16
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
13	0501019219	1/2" X 1-3/4" BOLT		08
14	0503010019	1/2" SPRING WASHER		08
15	0503010025	3/8" SPRING WASHER		04
16	0503010026	3/8" NUT		04
17	0503010060	1/2 UNC G.5 ZN HEX NUT		08
18	0503012412	5/8 UNC SELF LOCKING NUT		06
19	0531015184	FLAT WASHER		10

SEED HOPPER ASSEMBLY


0521053559



Item	Code	Description	See page	QT
01	0521069020	SEED HOPPER SUPPORT	01	
02	0531064462	LEFT SEED ROW JOINT ASSEMBLY	01	
03	0501010942	3/8" X 1-1/4" BOLT	10	
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN	14	
05	0503010025	3/8" SPRING WASHER	14	
06	0503010209	3/8" UNC BUTTERFLY NUT	02	
07	0581017941	UPPER BASE LEFT JOINT SYSTEM	02	
08	0501010694	FLAT WASHER	04	
09	0503010179	LOCK WASHER 5/16 ZN 1K01528	04	
10	0503010337	5/16" NUT	04	
11	0503010026	3/8" NUT	12	
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04	
13	0503010371	5/16" X 1" BOLT	04	
14	0521069043	TOP CONDUCTOR LEFT SEED	01	
15	0521069044	TOP RIGHT SEED CONDUCTOR	01	
16	0571015779	ARTICULATION NOZZLE SUPPORT LID	02	
17	0501111153	SEED ROW FIXED JOINT	01	

RIGHT FERTILIZER HOPPER ASSY


0521040712




Item	Code	Description	See page	QT
01	0511051712	RH BEAM SUPPORT	67	01
02	0503060693	FERTILIZER HOPPER ASSY		01
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0503034396	FERTILIZER SIDE COVER		02
08	0503010362	1/8 X 1.1/4 COTTERPIN		02
09	0581018852	13,5 X 35 X 10 SLEEVE		04
10	0581018853	SEED HOPPER FIXING		02
11	0501010937	13,50 X 28 X 3,00 FLAT WASHER		08
12	0503010019	1/2" SPRING WASHER		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0501019219	1/2" X 1-3/4" BOLT		04

LEFT FERTILIZER HOPPER ASSY

0521040718




Item	Code	Description	See page	QT
01	0511051717	LH BEAM SUPPORT	68	01
02	0503060693	FERTILIZER HOPPER ASSY		01
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0503034396	FERTILIZER SIDE COVER		02
08	0503010362	1/8 X 1.1/4 COTTERPIN		02
09	0581018852	13,5 X 35 X 10 SLEEVE		04
10	0581018853	SEED HOPPER FIXING		02
11	0501010937	13,50 X 28 X 3,00 FLAT WASHER		08
12	0503010019	1/2" SPRING WASHER		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0501019219	1/2" X 1-3/4" BOLT		04




Item	Code	Description	See page	QT
01	0521062960	FERTILIZER HOPPER SUPPORT (PLASTIC HOPPER)		01
02	0511051714	SIDE FERTILIZER DISTRIBUTOR	69	01
03	0511051715	SIDE FERTILIZER DISTRIBUTOR	70	01
04	0501811643	SCREW 3/8 UNC X 1 CAPQ G.2		08
05	0503011443	3/8" SPRING WASHER		12
06	0503810026	3/8" NUT		12
07	0501056451	BEARING	71	01
08	0501056444	BEARING WITH ROLLER	11	01
09	0503810237	3/8 UNC X 1 C S G.5 SA BOLT		04
10	0501215313	3/4 X 1605 SQUARE AXLE		01
11	0501053788	3/4 SQUARE AXLE FASTENER	72	04
12	0511066098	23Z GEAR		01
13	0503030275	AGRICULTURAL BEARING		02
14	1902010685	18Z CONICAL GEAR		02
15	0551018055	22,65 X 60 SLEEVE		02

LH BEAM SUPPORT


0511051717




Item	Code	Description	See page	QT
01	0521062960	FERTILIZER HOPPER SUPPORT (PLASTIC HOPPER)		01
02	0511051714	SIDE FERTILIZER DISTRIBUTOR	69	01
03	0511051715	SIDE FERTILIZER DISTRIBUTOR	70	01
04	0501811643	SCREW 3/8 UNC X 1 CAPQ G.2		08
05	0503011443	3/8" SPRING WASHER		12
06	0503810026	3/8" NUT		12
07	0501056444	BEARING WITH ROLLER	11	01
08	0501056451	BEARING	71	01
09	0503810237	3/8 UNC X 1 C S G.5 SA BOLT		04
10	0501215313	3/4 X 1605 SQUARE AXLE		01
11	0501053788	3/4 SQUARE AXLE FASTENER	72	02
12	0503030275	AGRICULTURAL BEARING		02
13	1902010685	18Z CONICAL GEAR		02
14	0551018055	22,65 X 60 SLEEVE		02




Item	Code	Description	See page	QT
01	0501110690	DISTRIBUTOR FERTILIZER		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		02
12	0503010003	1845 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0501110691	DISTRIBUTOR FERTILIZER WITH SIDE OUTPUT		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		02
12	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011971	HOUSING WITH DOUBLE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011105	SEAL RING		01



Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01

RIGHT REAR SEED ROW ASSEMBLY


0521053562




Item	Code	Description	See page	QT
01	0521053564	ASSEMBLY PRECISION PLANTING	75	01
02	0581018871	HEX AXLE 5/8" X 255		01
03	0503015920	3/8" UNC X 1.3/4" BOLT		04
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0502012663	EXTENSION		01
07	0503010905	1/2" X 2-1/4" BOLT		04
08	0503010019	1/2" SPRING WASHER		06
09	0503010060	1/2 UNC G.5 ZN HEX NUT		06
10	0511059081	LH 15"X15" SEED UNAL DOUB-DISC ASSY	79	01
11	0503062403	TUBE SEED P.P		01
12	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02

LEFT REAR SEED ROW ASSEMBLY

0521053560




Item	Code	Description	See page	QT
01	0521053561	PRECISION PLANTING ASSEMBLY V-SET2 LEFT	76	01
02	0581018871	HEX AXLE 5/8" X 255		01
03	0503015920	3/8" UNC X 1.3/4" BOLT		04
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0502012663	EXTENSION		01
07	0503010905	1/2" X 2-1/4" BOLT		04
08	0503010019	1/2" SPRING WASHER		06
09	0503010060	1/2 UNC G.5 ZN HEX NUT		06
10	0511059081	LH 15"X15" SEED UNAL DOUB-DISC ASSY	79	01
11	0503062403	TUBE SEED P.P		01
12	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0502012776	SUPPORT ARTICULATION PNEUMATIC PP	01	
02	0571017899	PIN LOCK	01	
03	0503030190	0.5" X 1.6" X 0.05" SPRING	01	
04	0571017897	AXLE ARTICULATION PRECISION PLANTING	01	
05	0511057155	PRECISION PLANTING LEFT TRANSMISSION 77 HOPPER	01	
06	0571017894	PIN DRAG PRECISION PLANTING	01	
07	0503013357	3/8" SELF-ADJUSTING NUT	01	
08	0501013518	FLAT WASHER	02	
09	0503015356	SPRING PIN	01	
10	0571017896	SLEEVE ARTICULATION PRECISION PLANTING	01	
11	0571017895	PIN FIXER CONDUCTOR P.P	01	
12	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING	02	
13	0503010293	CLAMP KNOB	02	
14	0503010140	1/8" X 3/4" COTTERPIN	02	
15	0503010131	3/16" X 1-1/2" COTTERPIN	01	
16	0503010025	3/8" SPRING WASHER	02	
17	0571019491	SLUICE PNEUMATIC PRECISION PLANTING	01	
18	0501011643	3/8 X 1" BOLT	01	
19	0503010209	3/8" UNC BUTTERFLY NUT	01	
20	0502012807	SUPPORT HOPPER PRECISION PLANTING	01	
21	0571019489	CLAMP PRECISION PLANTING	01	
22	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING	01	
23	0521053548	DISTRIBUTOR SEED COMPLETE WITH DISC 78 PEANUT	01	
24	0561014778	HEX UNIVERSAL JOINT	01	
25	0503013958	1/4" X 1" BOLT	02	
26	0503011855	0.2" X 1.8" SPRING PIN	01	
27	0503012721	1/4" X 4" BOLT	01	
28	0503012880	1/4" UNC SELF ADJUSTING NUT	04	
29	0571014024	FAST BOLT GUIDE AXLE	01	

Item	Code	Description	See page	QT
30	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
31	0503015110	M06 SPRING WASHER		02
32	0503818139	BOLT		03
33	0503037390	PACKING FOR PLANTING		01
34	0503015752	3/8" X 2" BOLT		01
35	0581011225	FIXER P PLANTING CONTR CPRA		01
36	0581011226	FIXER CLOSING P. PLANTING CONTROL CPRA		01
37	0521069013	OFFSET RIGHT FEEDER 3		01
38	0503011953	5/16" X 1" BOLT		04
39	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
40	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0502012776	SUPPORT ARTICULATION PNEUMATIC PP	01	01
02	0571017899	PIN LOCK	01	01
03	0503030190	0.5" X 1.6" X 0.05" SPRING	01	01
04	0571017897	AXLE ARTICULATION PRECISION PLANTING	01	01
05	0511057155	PRECISION PLANTING LEFT TRANSMISSION 77 HOPPER	01	01
06	0571017894	PIN DRAG PRECISION PLANTING	01	01
07	0503013357	3/8" SELF-ADJUSTING NUT	01	01
08	0501013518	FLAT WASHER	02	02
09	0503015356	SPRING PIN	01	01
10	0571017896	SLEEVE ARTICULATION PRECISION PLANTING	01	01
11	0571017895	PIN FIXER CONDUCTOR P.P	01	01
12	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING	02	02
13	0503010293	CLAMP KNOB	02	02
14	0503010140	1/8" X 3/4" COTTERPIN	02	02
15	0503010131	3/16" X 1-1/2" COTTERPIN	01	01
16	0503010025	3/8" SPRING WASHER	02	02
17	0571019491	SLUICE PNEUMATIC PRECISION PLANTING	01	01
18	0501011643	3/8 X 1" BOLT	01	01
19	0503010209	3/8" UNC BUTTERFLY NUT	01	01
20	0502012807	SUPPORT HOPPER PRECISION PLANTING	01	01
21	0571019489	CLAMP PRECISION PLANTING	01	01
22	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING	01	01
23	0521053548	DISTRIBUTOR SEED COMPLETE WITH DISC 78 PEANUT	01	01
24	0561014778	HEX UNIVERSAL JOINT	01	01
25	0503013958	1/4" X 1" BOLT	02	02
26	0503011855	0.2" X 1.8" SPRING PIN	01	01
27	0503012721	1/4" X 4" BOLT	01	01
28	0503012880	1/4" UNC SELF ADJUSTING NUT	04	04
29	0571014024	FAST BOLT GUIDE AXLE	01	01


Item	Code	Description	See page	QT
30	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
31	0503015110	M06 SPRING WASHER		02
32	0503818139	BOLT		03
33	0503037390	PACKING FOR PLANTING		01
34	0503015752	3/8" X 2" BOLT		01
35	0581011225	FIXER P PLANTING CONTR CPRA		01
36	0581011226	FIXER CLOSING P. PLANTING CONTROL CPRA		01
37	0521069040	DUTY LOWER 3 SEED CONDUCTOR		01
38	0503011953	5/16" X 1" BOLT		04
39	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
40	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0502050052	LEFT SIDE TRANSMISSION HOPPER PP		01
02	0502050053	RIGHT SIDE TRANSMISSION HOPPER PP		01
03	0503011410	ROLLER BEARING		02
04	0503011182	6203 ROLLER BEARING		02
05	0503011184	502040 CLAMPING RING (FOR AXLE)		01
06	0571017655	SLEEVE FIXER HITCH PNEUMATIC		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
08	0503010144	1/4" NUT		03
09	0511057504	JOIN GEAR		01
09A	0571017898	BODY GEAR TRANSMISSION		01
09B	0503011769	M8 X 0.5" BOLT		01
10	0581011222	PINION AXLE 6Z PNEUMATIC		01
11	0503034340	PINION AXLE 6Z PNEUMATIC		01




Item	Code	Description	See page	QT
01	0503062405	SEED DISTRIBUTOR		01
02	0503062576	GIANT PEANUT DISTRIBUTOR ASSEMBLY		01
03	0503062569	SELECTOR SEED		01
04	0571019613	STRAW PRECISION PLANTING SHIELD		01




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	15" RIGHT OPENING DISC HUB	80	01
04	0501054168	15" LEFT DOUBLE DISC HUB	81	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
08	0502012517	COVER		02
09	0503010026	3/8" NUT		01
10	0503011443	3/8" SPRING WASHER		01
11	0503011441	SPRING WASHER		06
12	0502012781	SUPPORT DDD LEFT		01
13	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
14	0503011402	0.2" X 0.8" SPRING PIN		01
15	0503013129	ELASTIC PIN		01
16	0571017963	RIGHT DOUBLE DISC SCRAPER		01
17	0571017964	LEFT DOUBLE DISC SCRAPER		01
18	0503014891	1/4" X 3/4" BOLT		06




Item	Code	Description	See page	QT
01	0502011930	OPENING DISCS HUB		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019154	RIGHT DOUB DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011930	OPENING DISCS HUB		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019148	LEFT DOUBLE DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0503010257	1/8" X 1" COTTERPIN		01
04	0581014858	DEPTH WHEEL AXLE		01
05	0501110720	ARM LEFT		01
06	0501110719	DEPTH CONTROL RIGHT ARM		01
07	0502012663	EXTENSION		01
08	0503010002	1800 GREASE FITTING		02
09	0501056769	DEPTH WHEELS REGULATOR ASSY	83	01
10	0503810256	SCREW		01
11	0521051423	COMPACTOR SUPPORT	84	01
12	0503034793	ARTICULATION SLEEVE		02
13	0571017749	FLAT WASHER		02
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		08
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2 UNC G.5 ZN HEX NUT		04
18	0501052908	COMPACTOR WHEEL WITH BEARING	85	02
19	0503013739	1/2" X 1" BOLT		01
20	0503016453	1/2" X 2.1/2 BOLT		02
21	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
22	0503010752	1/2" X 3.1/2" BOLT		01
23	0511059489	CENTRAL RAIL WHEEL	86	02



Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0521068003	RIGHT SIDE		01
02	0521068002	LEFT SIDE		01
03	0581014847	PLATE UPPER		01
04	0581015855	SLEEVE		02
05	0521068004	HANDLE BODY		01
06	0581014969	GUIDE SLEEVE		01
07	0581014968	SLEEVE FLANGE		01
08	0503010937	5/16" X 3" BOLT		02
09	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
10	0521068005	LEVER		01
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
12	0503010337	5/16" NUT		04
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2 UNC G.5 ZN HEX NUT		01
15	0503010847	1/2" X 3.1/4" BOLT		01
16	0503010882	BOLT		02
17	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
18	0503030878	LEVER CRANK		01
19	0581015854	RIGHT PROTECTION COVER		01
20	0581015853	LEFT PROTECTION COVER		01
21	0581015903	SPACER WASHER		01



Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03

CENTRAL RAIL WHEEL


0511059489




Item	Code	Description	See page	QT
01	0561016889	STRIPED CAP WHEEL DEPTH		01
02	0511052287	DEPTH WHEEL HUB ASSY	87	04
03	0551019904	PRESS WHEEL RIM		02
04	0503030891	RUBBER BAND		01
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
07	0503010337	5/16" NUT		06

DEPTH WHEEL HUB ASSY

0511052287




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEEL HUB		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02

DRIVE SHAFT


0501047947




Item	Code	Description	See page
01	0501050271	UNIVERSAL JOINT WITH SLEEVE	01
02	0501050265	UNIVERSAL JOINT	01
03	0501050333	1-40 TERMINAL WITH HITCH	01
04	0502010565	2-40 TERMINAL W/ SH 1.5"/1.5"	01
05	0503012069	ADAPTER FOR BUSHING PROTECT	01
06	0501017429	31" X 1.5" SQUARE SLEEVE	01
07	0503010836	CARDAN CROSSPIECE	01
08	0503011069	0.4" X 2.8" SPRING PIN	01
09	0503010510	0.2" X 2.6" SPRING PIN	01
10	0501050866	UNIVERSAL JOINT WITH SHAFT	01
11	0501050449	UNIVERSAL JOINT	01
12	0501052526	T8-40 TERMINAL WITH SCREW	01
13	0502010566	3-40 TERMINAL WITH SH 1.2"/1.2"	01
14	0503012070	ADAPTER FOR AXLE PROTECTION	01
15	0501017425	1.2" X 31.5" SQUARE SHAFT	01
16	0503010361	SPRING PIN	01
17	0503010756	0.2" X 2.4" SPRING PIN	01
18	0501051696	UNIVERSAL JOINT WITH SLEEVE PROTECTION	01
19	0501051697	UNIVERSAL JOINT WITH AXLE PROTECTION	01
20	0503012071	PROTECTION ASSY	01
21	0503012072	PROTECTION FOR UNIV JOINT AND SLEEV	01
22	0503012073	PLASTIC PROTECTION FOR AXLE JOINT	01
23	0503012023	CHAIN FOR PROTECTION	02
24	0502010563	1-40 STRIATED 1.3/8" TERMINAL	01
25	0521010638	0.5" X 3.3" QUIC HITCH COUPL SHAFT	01
26	0503030518	0.5"X1.0"X 0.1" COMPRESSION SPRING	01
27	0503010838	0.1" X 0.8" SPRING PIN	01
28	0502010876	8-40 STRIATED 1.3/8 TERMINAL	01
29	0501047756	1/2" X 3" SET PARTS	01



Item	Code	Description	See page	QT
01	0501054649	HBM SEQUENTIAL VALVE	41	01
02	0521040155	HYDRAULIC CYLINDER 31,75 X 50,8 X 365 X 595	40	02
03	0521052312	HOSE 3/8 X 1500 TR-TM PURPLE / RED		01
03A	0501080852	3/8" X 1500 TR-TM HOSE		01
03B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
03C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
03D	0503018952	PLASTIC BOLT		06
04	0521052313	HOSE 3/8 X 1500 TR-TM PURPLE / BLUE		01
04A	0501080852	3/8" X 1500 TR-TM HOSE		01
04B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
04C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
04D	0503018952	PLASTIC BOLT		06
05	0501080412	3/8" X 90.55" TR-TC HOSE		02
06	0501080469	3/8" X 98.42" TR-TR HOSE ASSY		02
07	0501053834	MALE QUICK COUPLER	91	02



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

