

ROW CROP PLANTERS

PST DUO TITANIUM - FRAME 4880/5950/6850 - CSU

Code: 0501092630
Series: S-0119
Revision: 00
Date Revision: DEZEMBRO/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS

Code	Description
0111230261	PST DUO 4880/10E500 CI DC20 CSU TIT S-0119
0111230219	PST DUO 4880/10E500 ESPECIAL S-0119
0111230224	PST DUO 4880/10E500 ESPECIAL S-0119
0111230240	PST DUO 4880/10E500 ESPECIAL S-0119
0111230242	PST DUO 4880/10E500 ESPECIAL S-0119
0111230229	PST DUO 4880/10E500 HDA MH DC20 CSU TIT S-0119
0111230225	PST DUO 4880/11E450 CI DC20 CSU TIT S-0119
0111230216	PST DUO 4880/11E450 CI MH DC20 CSU TIT S-0119
0111230257	PST DUO 4880/11E450 CPRA CI MH DC20 CSU TIT S-0119
0111230232	PST DUO 4880/11E450 ESPECIAL S-0119
0111230226	PST DUO 4880/11E450 ESPECIAL S-0119
0111230218	PST DUO 4880/11E450 SPCRR CI MH DC20 CSU TIT S-0119
0111230246	PST DUO 5950/12E500 D/HDA DC20 CSU TIT CBR S-0119
0111230227	PST DUO 5950/12E500 ESPECIAL S-0119
0111230217	PST DUO 5950/13E450 CI MH DC20 CSU TIT S-0119
0111230247	PST DUO 5950/13E450 ESPECIAL S-0119
0111230250	PST DUO 5950/13E450 ESPECIAL S-0119
0111230239	PST DUO 5950/13E450 ESPECIAL S-0119
0111230244	PST DUO 5950/13E450 ESPECIAL S-0119
0111230256	PST DUO 5950/13E450 ESPECIAL S-0119
0111230264	PST DUO 5950/13E450 SPCRR CI MH DC20 CSU TIT S-0119
0111230237	PST DUO 6850/14E500 CI MH DC20 CSU TIT S-0119

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.



MARCHESAN

INDEX

0909098656	FRAME ASSY	1
0521054576	FRAME WITH ARTICULATION 4880	2
0521054567	RIGHT FRAME WITH WHEELED AXLE 4880	3
0521054569	FRAME LEFT WITH SHAFT WHEELED 4880	4
0521054578	FRAME WITH ARTICULATION 5950	5
0521054572	RIGHT FRAME WITH WHEELED AXLE 5950	6
0521054573	FRAME LEFT WITH SHAFT WHEELED 5950	7
0521053418	FRAME WITH ARTICULATION 6850	8
0521053420	RIGHT FRAME WITH WHEELED AXLE 6850	9
0521053419	FRAME LEFT WITH SHAFT WHEELED 6850	10
0511058667	SPRING FLOW ENSEMBLY	11
0521055228	WHEEL WITH SPRING ASSY	12
0521058397	WHEELSET WITH SPRING TRACTION	13
0521055230	ASSY WHEELED SUPPORT	14
0521058395	WHEEL SUPPORT ASSY WITH TRANSMISSION	15
0501058241	TENSIONER CHAIN SUPPORT	16
0501058240	WHELL FASTENER WITH STRETCHER	17
0521058393	WHEEL WITH PNEU 7.00X16 14L PR TT WITH TRANSMISSION	18
0521055232	WHEEL WITH PNEU	19
0521055233	WHEELED TRANSMISSION WITHOUT TIRE	20
0521055234	WHEELED FASTENER	21
0521055236	INTERMEDIARY CURRENT STRETCHER	22
0521055237	WHEEL FIXED CURRENT STRETCHER	23
0521055235	WHEEL MOBILE CURRENT STRETCHER	24
0501058243	STRETCHER INTERMEDIATE RODE CURRENT	25
0501058244	STRETCHER FIXED CURRENT	26
0501058242	MOVIL CHAIN TENSIONER	27
0521054561	CYLINDER ASSEMBLY	28
0511058406	HYDRAULIC CYLINDER	29
0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	30
0511056832	ASSY SYSTEM HYDRAULIC 6850	31
0501054694	FLOW DIVIDING VALVE ASSY	32
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	33
0909095172	HEADER ASSY	34
0511055096	TRACTOR HITCH	35
0521053310	LEFT EXTENSION HEADER 36,00 - 4880/5720/5950	36
0521053318	LEFT EXTENSION HEADER 36,00 - 6850	37
0521053311	RIGHT EXTENSOR HEAD 36,00 - 4880/5720/5950	38
0521053319	RIGHT EXTENSOR HEAD 36,00 - 6850	39
0511052311	3 POINT TURNBUCKLE	40
0511056736	HOSE SUPPORT	41
0521054526	SILO FERTILIZER ASSY 4880	42
0521054528	SILO FERTILIZER RIGHT SUPPORT 4880	43
0521054527	LEFT FERTILIZER BEAM SUPPORT 4880	44
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	45
0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	46
0501053788	Q3/4" FASTENER AXLE ASSY	47
0521054537	SILO FERTILIZER ASSY 5950	48
0521054539	SILO FERTILIZER RIGHT SUPPORT 5950	49
0521054538	LEFT FERTILIZER BEAM SUPPORT 5950	50
0521054543	SILO FERTILIZER ASSY 6850	51
0521054544	SILO FERTILIZER RIGHT SUPPORT 6850	52
0521054545	LEFT FERTILIZER BEAM SUPPORT 6850	53
0511056740	RIGHT TRANSMISSION ASSY - 4880	54
0511056790	RIGHT TRANSMISSION ASSY - 5950	55



MARCHESAN

INDEX

0511059306	RIGHT TRANSMISSION ASSY - 6850	56
0501052560	AXLE MOTOR SLOW-MOVING ASSY	57
0511051434	TRANSMISSION DRIVING ASSY	58
0511047069	SIDE TRANSMISSION DRIVING	59
0511047070	LH SIDE TRANSMISSION DRIVING	60
0521043316	RIGHT GEAR BOX ASSY	61
0521043317	LEFT GEAR BOX ASSY	62
0501058212	SEMI MOUNTED RIGHT CHANGE	63
0501058213	LH GEAR BOX	64
0511059266	CLOSED BEARING	65
0501056271	BEARING CLOSED	66
0501056443	BEARING ASSY GEAR BOX	67
0501056444	BEARING WITH ROLLING	68
0501048790	AXLE WITH LINK ASSY	69
0501054655	CHAIN TENSIONER ASSY	70
0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	71
0501055112	MICRO GRANULATED CHAIN TENSIONER	72
0511054363	CHAIN TENSIONER	73
0501058234	LOWER CHAIN TENSIONER	74
0521055207	TOP CURRENT STRETCHER	75
0501058236	BEARING WITH 21Z GEAR	76
0501058237	16Z GEAR BEARING	77
0521055240	WHEEL WITH DRAW SPRING ASSY 585 NO TRANSMISSION	78
0521058400	WHEEL WITH DRAW SPRING 585 WITHOUT TRANSMISSION	79
0521055242	WHEELED SUPPORT ASSY 585 WITHOUT TRANSMISSION	80
0521058398	WHEEL SUPPORT WITHOUT TRANSMISSION	81
0521055239	WHEEL WITH PNEUME WHEELED BOX WITHOUT TRANSMISSION	82
0521058394	WHEEL WITH PNEUME	83
0503062159	WHEEL	84
0521055244	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	85
0521054562	PLATFORM ASSEMBLY 4880	86
0521054564	PLATFORM ASSEMBLY 5950	87
0521054566	PLATFORM ASSEMBLY 6850	88
0511056746	HANDRAIL ASSY 4880	89
0521054568	HANDRAIL ASSY 5950	90
0511056836	HANDRAIL ASSY 6850	91
0511054971	RESTING ASSEMBLY	92
0511056536	ASSEMBLY LADDER	93
0521056983	SEMI MOUNTED HYDRAULIC MARKER 4880	94
0511056789	SEMI MOUNTED HYDRAULIC MARKER 5720/5950	95
0511056833	SEMI MOUNTED HYDRAULIC MARKER 6850	96
0511058449	HYDRAULIC CYLINDER	97
0501054649	SEQUENTIAL VALVE ASSY	98
0521055204	LIGNE DE DISQUE MARKER	99
0511059585	ASSEMBLY CSU C3 SEMI MOUNTED 4880	100
0511059584	ASSEMBLY CSU C3 2 BOXES 6B WITH 10 4880	101
0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	102
0521052687	RH SUPPORT TOWER SILO	103
0521051931	LH SUPPORT TOWER SILO	104
0521051927	TOWER SUPPORT HOPPER	105
0521051928	FIXED TOWER SIDE RIGHT SILO SUPPORT WITH SCREW	106
0521051929	SIDE FIXED TOWER LEFT SILO SUPPORT WITH SCREW	107
0511058723	ASSEMBLY CSU C3 SEMI MOUNTED 5950	108
0511058724	ASSEMBLY CSU C3 2BOXES 7/6 12E500	109



MARCHESAN

INDEX


0511058628	ASSEMBLY CSU C3 SEMI MOUNTED 5720/5950	110
0511058802	ASSEMBLY CSU C3 2 BOXES 7B WITH 13 C 5720/6350	111
0521054558	ASSEMBLY CSU C3 SEMI MOUNTED 6850	112
0521054560	ASSEMBLY CSU C3 2 BOXES 5/4 2 BOXES 5/3 6850	113
0521054580	REAR LIGHTING ASSEMBLY 4880	114
0521054582	REAR LIGHTING ASSEMBLY 5720/5950	115
0521054584	REAR LIGHTING ASSEMBLY 6850	116
0521052792	MOUNTED REAR LIGHT	117
0521055105	ASSY MANUAL DOOR	118
0511056741	LEFT TRANSMISSION ASSEMBLY - 4880	119
0511056791	LEFT TRANSMISSION ASSEMBLY - 5950	120
0511059307	LEFT TRANSMISSION ASSEMBLY - 6850	121
0521054181	TOOL BOX ASSEMBLY	122
0521054525	CONTAINER WATER TANK	123
0909098658	ASSY HEX AXLE	124
0521053446	MONITORING ASSEMBLY PLANTING SEEDS 10L PM400	125
0521053447	MONITORING ASSEMBLY PLANTING SEEDS 11L PM400	126
0521053407	MONITORING ASSEMBLY PLANTING SEEDS 13L PM400	127
0521055772	LABEL ASSY CSU - 4880	128
0521055104	HYDRAULIC MARKER LABEL ASSY - 4880	129
0521055309	HYDRAULIC MARKER LABEL ASSY / CSU - 5950	130
0521057464	HYDRAULIC MARKER LABEL ASSY / CSU - 6850	131
0909098659	ASSY SEED / FERTILIZER LINE	132
0521054803	ASSEMBLY LINE SEED/FERTILIZER SHORT WITHOUT LUBRICATION CSU TITANIUM	133
0521054804	ASSEMBLY LINE SEED/FERTILIZER LONG WITHOUT LUBRICATION CSU TITANIUM	134
0521054813	SHORT PIVOT LIFT LINE	135
0521054814	LONG PIVOT LIFT LINE	136
0511052024	FAST CLOSING SET	137
0511059244	ROD SPRING LINE SEED	138
0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	139
0521054775	LEFT REAR SEAL LINE BASE 1/2	140
0521054774	REAR RIGHT LINE SEED LIFT	141
0521054819	BASE 1/2 FIXED WITHOUT ASSY LUBRICATION	142
0521054763	DDD LEFT SEED	143
0521054762	RIGHT DDD SEED	144
0511052302	LH SUPPORT DDD GUIDE	145
0511052301	SUPPORT DDD 15 RIGHT	146
0521054761	LEFT LOW CUBE	147
0521054760	DOWN LOW CUBE	148
0521054718	SYSTEM SEED POPCORN	149
0511052058	SEED SYSTEM TITANIUM	150
0521053231	DPL 20 SHORT LINE WITHOUT LUBRICATION CONICAL BEARING	151
0521053232	DPL 20 LONG LINE WITHOUT LUBRICATION CONICAL BEARING	152
0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	153
0521053697	CUTTING DISK BOX	154
0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	155
0521054768	DDD RIGHT FERTILIZER WITH SUPPORT	156
0521054769	LEFT FERTILIZER WITH SUPPORT	157
0521054764	DDD RIGHT FERTILIZER	158
0521054765	DDD LEFT FERTILIZER	159
0521054984	DEPTH SYSTEM / COMPACTOR WITHOUT LUBRICATION	160
0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	161



MARCHESAN


INDEX

0501052297	DEPTH WHEELS REGULATOR ASSY	162
0521054987	LEFT ARM WHEEL DEPTH WITH NO LUBRICATION CUBE	163
0521054988	RIGHT ARM ROD DEPTH WITH LUBRICANT-FREE HUB	164
0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	165
0521055033	COMPACTADOR BODY	166
0501052538	DEPTH BAND WITH ARMS	167
0521054990	LEFT COMPACTOR WHEEL	168
0521055017	RIGHT COMPACTOR WHEEL	169
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	170
0521054758	CONTROL DEPTH WITH REGULATOR	171
0521054751	DEPTH CONTROL WITH THREAD	172
0521053483	CPRA RIGHT DEPTH CONTROL CUBE WITHOUT LUBRICATION	173
0521053484	CPRA LEFT DEPTH CONTROL CUBE WITHOUT LUBRICATION	174
0521053245	LEFT ARM WHEELS	175
0521053244	ARM RIGHT WHEEL COBRIDORA	176
0521054744	CUBE RIGHT CONTROL DEPTH	177
0521054745	HUB LEFT CONTROL DEPTH	178
0511055819	DEPTH WHIT AROS BAND	179
0521054752	V COMPACTING SYSTEM	180
0521054753	DRIVE WHEEL V RUBBER RIGHT	181
0521054754	DRIVE WHEEL V LEFT RUBBER	182
0521055053	DEEP WHEEL / COMPACTOR SYSTEM	183
0521055065	ASSY DEPTH / COMPACTOR	184
0521055054	LEFT ARM WITH SLEEVE	185
0521055066	RIGHT ARM WITH GLOVE	186
0521055068	RAYED WHEEL CENTER CLOSED	187
0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	188
0521050525	FIXER FERTILIZER CONDUCTOR	189
0521053946	SCARING ROD	190
0521053947	HDA ELEVATION 0869	191
0521053951	STEM	192
0521053932	ROD WITH BEAK 0869	193
0521054912	RIGHT SUPPORT WITH DOC 18	194
0521054914	BOX WITH DOC 18 RIGHT	195
0521054913	LEFT SUPPORT WITH DOC 18	196
0521054915	BOX WITH DOC 18 LEFT	197
0521050168	MOUNTED FERTILIZER CONDUCTOR	198
0501110814	SCARIFIER ROD WITH IAPAR NOZZLE	199
0521058721	WHEEL CBR FERTILIZER V RIGHT RUBBER ROD HIGH LINE	200
0521058722	WHEEL CBR FERTILIZER V LEFT RUBBER ROD HIGH LINE	201
0511054333	COMPACT WHEEL RIGHT WITH BEARING	202
0511054334	COMPACT WHEEL LEFT WITH BEARING	203
0501052908	COMPACTOR WHEEL WITH BEARING	204




Item	Code	Description	See page	4880	5950	6850
01	0521054576	FRAME WITH ARTICULATION 4880	2	001	000	000
01.	0521054578	FRAME WITH ARTICULATION 5950	5	000	001	000
01..	0521053418	FRAME WITH ARTICULATION 6850	8	000	000	001
02	0521064285	LOCK LOWER FRAME		001	001	001
03	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		001	001	001
04	0503010002	1800 GREASE FITTING		001	001	001
05	0503010003	1845 GREASE FITTING		005	005	005
06	0503010004	1890 GREASE FITTING		002	002	002
07	0511058667	SPRING FLOW ENSEMBLY	11	001	001	001
08	0521055228	WHEEL WITH SPRING ASSY	12	004	004	000
08.	0521058397	WHEELSET WITH SPRING TRACTION	13	000	004	004
09	0521054561	CYLINDER ASSEMBLY	28	001	001	001
10	0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	30	001	001	001
10.	0511056832	ASSY SYSTEM HYDRAULIC 6850	31	000	000	001
11	0909095172	HEADER ASSY	34	001	001	001
12	0511056736	HOSE SUPPORT	41	001	001	001
13	0521054526	SILO FERTILIZER ASSY 4880	42	001	000	000
13.	0521054537	SILO FERTILIZER ASSY 5950	48	000	001	000
13..	0521054543	SILO FERTILIZER ASSY 6850	51	000	000	001
14	0511056740	RIGHT TRANSMISSION ASSY - 4880	54	001	000	000
14.	0511056790	RIGHT TRANSMISSION ASSY - 5950	55	000	001	000
14..	0511059306	RIGHT TRANSMISSION ASSY - 6850	56	000	000	001
15	0521055240	WHEEL WITH DRAW SPRING ASSY 585 NO 78 TRANSMISSION	78	000	002	000
15.	0521058400	WHEEL WITH DRAW SPRING 585 WITHOUT TRANSMISSION	79	000	002	002
16	0521054562	PLATFORM ASSEMBLY 4880	86	001	000	000
16.	0521054564	PLATFORM ASSEMBLY 5950	87	000	001	000
16..	0521054566	PLATFORM ASSEMBLY 6850	88	000	000	001
17	0511056746	HANDRAIL ASSY 4880	89	001	000	000
17.	0521054568	HANDRAIL ASSY 5950	90	000	001	000
17..	0511056836	HANDRAIL ASSY 6850	91	000	000	001


Item	Code	Description	See page	4880	5950	6850
18	0511054971	RESTING ASSEMBLY	92	004	004	004
19	0511056536	ASSEMBLY LADDER	93	002	002	002
20	0521056983	SEMI MOUNTED HYDRAULIC MARKER 4880	94	001	000	000
20.	0511056789	SEMI MOUNTED HYDRAULIC MARKER 5720/5950	95	000	001	000
20..	0511056833	SEMI MOUNTED HYDRAULIC MARKER 6850	96	000	000	001
21	0521055204	LIGNE DE DISQUE MARKER	99	002	002	002
22	0511059585	ASSEMBLY CSU C3 SEMI MOUNTED 4880	100	001	000	000
22.	0511058723	ASSEMBLY CSU C3 SEMI MOUNTED 5950	108	000	001	000
22..	0511058628	ASSEMBLY CSU C3 SEMI MOUNTED 5720/5950	110	000	001	000
22...	0521054558	ASSEMBLY CSU C3 SEMI MOUNTED 6850	112	000	000	001
23	0521054580	REAR LIGHTING ASSEMBLY 4880	114	001	000	000
23.	0521054582	REAR LIGHTING ASSEMBLY 5720/5950	115	000	001	000
23..	0521054584	REAR LIGHTING ASSEMBLY 6850	116	000	000	001
24	0521055105	ASSY MANUAL DOOR	118	001	001	001
25	0511056741	LEFT TRANSMISSION ASSEMBLY - 4880	119	001	000	000
25.	0511056791	LEFT TRANSMISSION ASSEMBLY - 5950	120	000	001	000
25..	0511059307	LEFT TRANSMISSION ASSEMBLY - 6850	121	000	000	001
26	0501065677	STRUT		002	002	002
27	0541015451	FIXED KEY 2.3/8 X 2.3/4		001	001	001
28	0501047895	ROD STOP		002	002	002
29	0501047885	ROD STOP		002	002	002
30	0501047886	ROD STOP		002	002	002
31	0501047887	ROD STOP		002	002	002
32	0521013022	TRANSPORT LOCK		002	002	002
33	0503030168	HAIR PIN		002	002	002
34	0501068994	0.3" X 3.1" LOCK PIN		002	002	002
35	0521054181	TOOL BOX ASSEMBLY	122	001	001	001
36	0521054525	CONTAINER WATER TANK	123	001	001	001
37	0503019262	SOAP DISH VACUUM		001	001	001
38	0503010780	N-2050 AMENDMENT		002	002	002
39	0503011750	AMENDMENT WITH LOCK		006	006	006
40	0503011751	REDUCTION		006	006	006
41	0503010951	REDUCTION		004	004	004
42	0503010246	CLAMP		010	012	014
43	0909098658	ASSY HEX AXLE	124	001	001	001
44	0503010014	3/4" NUT		002	002	002
45	0503010023	3/4" SPRING WASHER		002	002	002
46	0503032624	SILO FERTILIZER GUTTER		006	007	002
47	0521065613	HOSE HOLDER		001	001	001
48	0503011953	5/16" X 1" BOLT		002	002	002
49	0503013816	5/16" LOCKNUT		002	002	002
50	0521053446	MONITORING ASSEMBLY PLANTING SEEDS 10L PM400	125	001	000	000
50.	0521053447	MONITORING ASSEMBLY PLANTING SEEDS 11L PM400	126	000	001	000
50..	0521053407	MONITORING ASSEMBLY PLANTING SEEDS 13L PM400	127	000	001	000
51	0521055309	HYDRAULIC MARKER LABEL ASSY / CSU - 5950	130	001	001	000
51.	0521055104	HYDRAULIC MARKER LABEL ASSY - 4880	129	001	001	000
51..	0521055772	LABEL ASSY CSU - 4880	128	001	001	000
51...	0521057464	HYDRAULIC MARKER LABEL ASSY / CSU - 6850	131	000	000	001
52	0501011310	FIXER LOCK		000	000	008
54	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		000	000	004
55	0503010019	1/2" SPRING WASHER		000	000	004
56	0503010060	1/2" NUT		000	000	004
57	0521013164	EXTENSOR		000	000	002
58	0909098659	ASSY SEED / FERTILIZER LINE	132	001	001	001




Item	Code	Description	See page	QT
01	0521054567	RIGHT FRAME WITH WHEELED AXLE 4880	3	01
02	0521054569	FRAME LEFT WITH SHAFT WHEELED 4880	4	01
03	0501110791	FRONT ARTICULATOR HUB WITH GLOVES		01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	NUT		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581018964	TROUGH 24 X 50 X 1320		02
20	0581018965	TROUGH 24 X 50 X 940		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8" SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
01	0521068942	RIGHT FRAME		01
02	0521069426	RIGHT ARTICULATED AXLE		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521068943	LEFT FRAME		01
02	0521069427	LEFT ARTICULATED AXLE		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521054572	RIGHT FRAME WITH WHEELED AXLE 5950	6	01
02	0521054573	FRAME LEFT WITH SHAFT WHEELED 5950	7	01
03	0501110791	FRONT ARTICULATOR HUB WITH GLOVES		01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	NUT		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581018960	TROUGH 24 X 50 X 1855		02
20	0581018961	TROUGH 24 X 50 X 945		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8" SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
01	0521068946	RIGHT FRAME 5950		01
02	0521069430	RIGHT SIDE RIGHT ARTICULATED AXLE 5950		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521068947	LEFT FRAME 5950		01
02	0521069431	LEFT ARTICULATED AXLE 5950		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521053420	RIGHT FRAME WITH WHEELED AXLE 6850	9	01
02	0521053419	FRAME LEFT WITH SHAFT WHEELED 6850	10	01
03	0501110791	FRONT ARTICULATOR HUB WITH GLOVES		01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	NUT		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581017758	TROUGH 24 X 50 X 1900 6850		02
20	0581017759	TROUGH 24 X 50 X 1350 6850		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8" SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03
26	0591019177	GLOVE		01




Item	Code	Description	See page	QT
01	0521068950	RIGHT FRAME 6850		01
02	0521069172	RIGHT SIDE RIGHT ARTICULATED AXLE 6850		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521068951	LEFT FRAME 6850		01
02	0521069173	LEFT ARTICULATED AXLE 6850		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		06
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		12
03	0501012140	FLAT WASHER		24




Item	Code	Description	See page	QT
01	0521055230	ASSY WHEELED SUPPORT	14	01
02	0521055234	WHEELED FASTENER	21	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503014887	2050 CHAIN X 80 LINK + REDUCTION		01




Item	Code	Description	See page	QT
01	0521058395	WHEEL SUPPORT ASSY WITH TRANSMISSION	15	01
02	0501058240	WHELL FASTENER WITH STRETCHER	17	01
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503012212	2050 CHAIN X 81 LINK + MENDING		01
06	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
07	0503011254	7/8" HEX SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521061565	WHEEL SUPPORT ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0501058241	TENSIONER CHAIN SUPPORT	16	01
07	0521055232	WHEEL WITH PNEU	19	01
08	0503018981	BOLT		02
09	0503010027	5/8" SPRING WASHER		04
10	0521012190	AXLE LOCK		01
11	0581011124	WHEELED COVER		01
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
13	0551017715	FLAT WASHER		02
14	0503013030	5/8" X 3.1/4" BOLT		01
15	0511050681	TRACTION SPRING		01
15A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
15B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0521061565	WHEEL SUPPORT ARM		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511050681	TRACTION SPRING		01
06A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
06B	0561016062	SPRING HITCH		02
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0501058241	TENSIONER CHAIN SUPPORT	16	01
11	0521058393	WHEEL WITH PNEU 7.00X16 14L PR TT WITH 18 TRANSMISSION		01
12	0521069983	WHEEL COVER		01
13	0591010589	BODY LOCK WHEEL		01
14	0503010027	5/8" SPRING WASHER		04
15	0503018981	BOLT		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	STRETCHER INTERMEDIATE RODE CURRENT	25	01
07	0501058244	STRETCHER FIXED CURRENT	26	01
08	0501058242	MOVIL CHAIN TENSIONER	27	01




Item	Code	Description	See page	QT
01	0503063172	WHEEL		01
02	0521055233	WHEELED TRANSMISSION WITHOUT TIRE	20	01




Item	Code	Description	See page	QT
01	0503062159	WHEEL	84	01
02	0521055233	WHEELED TRANSMISSION WITHOUT TIRE	20	01




Item	Code	Description	See page	QT
01	0521012185	TRANSM AXLE CARRYING-WHEEL	01	
02	0503010330	KM 9 LOCKNUT	01	
03	0503010329	LOCK WASHER	01	
04	0511015949	LOCK NUT	01	
05	0503010804	00547-B SEAL	02	
06	0503019364	BEARING 25590/25523	02	
07	0501110721	WHEEL HUB WITH SCREW / NUTS	01	
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION	01	
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR	06	
07C	0503016516	5/8 UNF CONIC NUT	06	
08	0502011339	15Z GEAR P 1.25"	01	
09	0503012550	5/16" X 3/4" BOLT	06	
10	0503010002	1800 GREASE FITTING	01	




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0521055236	INTERMEDIARY CURRENT STRETCHER	22	01
07	0521055237	WHEEL FIXED CURRENT STRETCHER	23	01
08	0521055235	WHEEL MOBILE CURRENT STRETCHER	24	01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
02	0551018245	CHAIN TENSIONER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0551018239	SLEEVE 19 X 13,50 X 45		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
02	0551018252	CHAIN TIGHTENER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
02	0551018244	CHAIN UPPER AXLE		01
03	0591017923	GLOVE 15.30 X 30 X 32		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	CHAIN TENSIONER BEARING		01
02A	0503012882	BEARING		01
02B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02C	0502012853	GEAR		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TIGHTENER AXLE		01
02	0501058239	CHAIN TENSIONER BEARING		01
02A	0503012882	BEARING		01
02B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02C	0502012853	GEAR		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN UPPER AXLE		01
02	0501058239	CHAIN TENSIONER BEARING		01
02A	0503012882	BEARING		01
02B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02C	0502012853	GEAR		01
03	0551018240	SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	29	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521015501	COUPLING SHAFT		02
04	0503010523	1/4" X 2" COTTERPIN		04
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
06	0531012565	SLEEVE 16,3X 30 X 88		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O'RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O'RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01



Item	Code	Description	See page	QT
01	0571017027	SOPORTE VALV		01
02	0503010920	1/2" X 1.1/2" BOLT		02
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0501054452	FLOW DIVIDING VALVE		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	33	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		02
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057089	HOSE KIT SYSTEM HYDRAULIC		01
19A	0501080045	3/8" X 850 TR-TR HOSE		01
19B	0501080999	3/8" X 39" TC-TC HOSE		01
19C	0501081987	HOSE 3/8 X 1550 TR-TC		01
19D	0501081986	HOSE 3/8 X 1550 TC-TC		01
19E	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
19EA	0501080185	HOSE 1/2 X 4000 TR-TM		01
19EB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
19EC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
19ED	0503018952	PLASTIC BOLT		06
19F	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
19FA	0501080185	HOSE 1/2 X 4000 TR-TM		01
19FB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01




Item	Code	Description	See page	QT
19FC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
19FD	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0571017027	SOPORTE VALV		01
02	0503010920	1/2" X 1.1/2" BOLT		02
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0501054694	FLOW DIVIDING VALVE ASSY	32	01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	33	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		01
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057106	ASSY HYDRAULIC SYSTEM HOSE 6850		01
19A	0501080373	TR-TR HOSE ASSY		01
19B	0501081989	HOSE 3/8 X 1400 TC-TC 90G		01
19C	0501081992	HOSE		01
19D	0501081991	HOSE 3/8 X 1950 TC-TC 180G		01
20	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
20A	0501080185	HOSE 1/2 X 4000 TR-TM		01
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
20C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
20D	0503018952	PLASTIC BOLT		06
21	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
21A	0501080185	HOSE 1/2 X 4000 TR-TM		01
21B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01

Item	Code	Description	See page	QT
21C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21D	0503018952	PLASTIC BOLT		06
22	0503013100	NYLON CLAMP		02




Item	Code	Description	See page	QT
01	0503012481	FLOW DIVIDING VALVE		01
02	0503030923	3/4" UNF X 13/16UN OFS X 40 NIPPLE		03
03	0503010190	2-114 N 3006-9B O'RING		03



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01

HEADER ASSY

0909095172




Item	Code	Description	See page	4880	5340	5720	5950	6350	6850
01	0521068561	LONG COUPLING HEADER		001	001	001	001	001	001
02	0511055096	TRACTOR HITCH	35	001	001	001	001	001	001
03	0511053179	TRACTOR HITCH AXLE		001	001	001	001	001	001
03A	0521064036	TRACTOR HITCH AXLE		001	001	001	001	001	001
03B	0503030012	HAIR PIN		001	001	001	001	001	001
04	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		001	001	001	001	001	001
05	0503014120	CHAIN		001	001	001	001	001	001
06	0503014321	CABLE STEEL SHACKLE		002	002	002	002	002	002
07	0571010661	PIVOT SHAFT		001	001	001	001	001	001
08	0503010010	1/4" X 2.1/2" COTTERPIN		002	002	002	002	002	002
09	0521064203	EAR PIVOT DRAWBAR		001	001	001	001	001	001
10	0521053310	LEFT EXTENSION HEADER 36.00 - 4880/5720/5950	36	001	000	001	001	000	000
10.	0521053313	LEFT EXTENSION HEADER 36.00 - 5340		000	001	000	000	000	000
10..	0521053320	LEFT EXTENSION HEADER 36.00 - 6350		000	000	000	000	001	000
10...	0521053318	LEFT EXTENSION HEADER 36.00 - 6850	37	000	000	000	000	000	001
11	0501010500	3/4"X3"BOLT		002	002	002	002	002	002
12	0503010023	3/4" SPRING WASHER		002	002	002	002	002	002
13	0503010014	3/4" NUT		002	002	002	002	002	002
14	0571019949	JUNCTION SHAFT		002	002	002	002	002	002
15	0503030119	LOCK PIN		002	002	002	002	002	002
16	0521053311	RIGHT EXTENSOR HEAD 36.00 - 4880/5720/5950	38	001	000	001	001	000	000
16.	0521053312	RIGHT EXTENSOR HEAD 36.00 - 5340		000	001	000	000	000	000
16..	0521053321	RIGHT EXTENSOR HEAD 36.00 - 6350		000	000	000	000	001	000
16...	0521053319	RIGHT EXTENSOR HEAD 36.00 - 6850	39	000	000	000	000	000	001
17	0521010572	0.9" X 2.9" COUPLING SHAFT		001	001	001	001	001	001
18	0503030085	LOCK PIN		004	004	004	004	004	004
19	0521063528	EXTENDING FIXER		001	001	001	001	001	001
20	0501010171	BOLT 1 UNC X 3.1/2 C S G.5		003	003	003	003	003	003
21	0503010012	1" SPRING WASHER		003	003	003	003	003	003
22	0501010059	1.5/8 NUT		003	003	003	003	003	003
23	0521062916	LEFT FRENCH HAND		001	001	001	001	001	001




HEADER ASSY

0909095172


Item	Code	Description	See page	4880	5340	5720	5950	6350	6850
24	0521010585	0.9" X 5.9" COUPLING SHAFT		001	001	001	001	001	001
25	0511052311	3 POINT TURNBUCKLE	40	001	001	001	001	001	001
26	0521012532	0.9" X 3.9" COUPLING SHAFT		001	001	001	001	001	001
27	0521010582	COUPLING SHAFT		001	001	001	001	001	001
28	0521063529	LOCK AXLE		001	001	001	001	001	001
29	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		001	001	001	001	001	001




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	COMPRESSION SPRING LEFT		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0521064426	POINT FIXER EXTENDING LEFT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064238	POINT FIXER EXTENDING LEFT		01
02	0521065193	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064425	POINT FIXER EXTENDING RIGHT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064237	POINT FIXER EXTENDING RIGHT		01
02	0521065193	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0571012279	JACK RIGHT		01
03	0571012280	JACK LEFT		01
04	0531010264	SIDE RATCHET		02
05	0521018500	SHAFT LEVER EXTENSOR		01
06	0511061881	RATCHET FOLLOWER		01
07	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
08	0503011179	3/8" X 2-1/4" BOLT		05
09	0503010025	3/8" SPRING WASHER		05
10	0503010026	3/8" NUT		05
11	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0521054528	SILO FERTILIZER RIGHT SUPPORT 4880	43	01
02	0521054527	LEFT FERTILIZER BEAM SUPPORT 4880	44	01
03	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		02
04	0501010984	FLAT WASHER		24
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12
07	0503010849	3/8" X 1-1/2" BOLT		12
08	0503013751	3/8 UNC X 1.1/4 BOLT		21
09	0571019051	FIXER BOX WASHER		21
10	0503012535	3/8" SPRING WASHER		21
11	0503012531	3/8" INOX NUT		21
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	5/16" ZN SPRING WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0581018923	LOWER LEVER LEVER CHANGE		02
19	0581018922	LEVER ARM DISARMING MINOR		02
20	0521061741	INNTER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0511017302	FLAT WASHER		06
23	0551019167	SLEEVE UNION		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501013518	FLAT WASHER		06
27	0503010140	1/8" X 3/4" COTTERPIN		06
28	0503010479	BOLT		02
29	0551019168	SLEEVE		02
30	0503011336	1/2" HEX SELF ADJUSTING NUT		06
31	0511069678	LH LOWER LEVER		02




Item	Code	Description	See page	QT
32	0561016468	FASTENER		02
33	0551019159	LEVER FIXER BODY		02
34	0503034396	FERTILIZER SIDE COVER		12
35	0503010362	1/8" X 1.1/4" COTTERPIN		12




Item	Code	Description	See page	QT
01	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	45	01
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	46	05
03	0501010942	3/8" X 1-1/4" BOLT		24
04	0503011443	3/8" SPRING WASHER		24
05	0503010026	3/8" NUT		24
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0503013816	5/16" LOCKNUT		02
11	0581018921	SQUARE AXLE 3/4 X 2275		01
12	1902010685	18Z CONICAL GEAR		06
13	0503030275	AGRICULTURAL BEARING		06
14	0501053788	Q3/4" FASTENER AXLE ASSY	47	01
15	0501110392	SILO SUPPORT BEARING		01
16	0503010003	1845 GREASE FITTING		01
17	0521069407	SUPPORT RIGHT SILO FERTILIZER		01
18	0503011953	5/16" X 1" BOLT		02
19	0521011039	FLAT WASHER		02
20	0503011444	SPRING WASHER		02
21	0503010337	5/16" NUT		02
22	0521012485	GEAR BOX BEARING AGRICUTURAL		01




Item	Code	Description	See page	QT
01	0521069406	LEFT SUPPORT SILO FERTILIZER		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	45	05
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	46	01
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503011443	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0503010337	5/16" NUT		02
12	0581018921	SQUARE AXLE 3/4 X 2275		01
13	0503030275	AGRICULTURAL BEARING		06
14	1902010685	18Z CONICAL GEAR		06
15	0503010003	1845 GREASE FITTING		01
16	0501053788	Q3/4" FASTENER AXLE ASSY	47	01
17	0521012485	GEAR BOX BEARING AGRICUTURAL		01
18	0501110392	SILO SUPPORT BEARING		01
19	0503011953	5/16" X 1" BOLT		02
20	0521011039	FLAT WASHER		02
21	0503011444	SPRING WASHER		02
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01



Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0521054539	SILO FERTILIZER RIGHT SUPPORT 5950	49	01
02	0521054538	LEFT FERTILIZER BEAM SUPPORT 5950	50	01
03	0503062362	SILO FERTILIZER 04 MOUTH		02
04	0501010984	FLAT WASHER		24
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12
07	0503010849	3/8" X 1-1/2" BOLT		12
08	0503013751	3/8 UNC X 1.1/4 BOLT		20
09	0571019051	FIXER BOX WASHER		20
10	0503012535	3/8" SPRING WASHER		20
11	0503012531	3/8" INOX NUT		20
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	5/16" ZN SPRING WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0581012605	GEAR BOX LEVER LOCK		02
19	0551019160	LEVER		02
20	0521061741	INNTER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0511017302	FLAT WASHER		06
23	0551019167	SLEEVE UNION		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501013518	FLAT WASHER		06
27	0503010140	1/8" X 3/4" COTTERPIN		06
28	0503010479	BOLT		02
29	0551019168	SLEEVE		02
30	0503011336	1/2" HEX SELF ADJUSTING NUT		06
31	0511069678	LH LOWER LEVER		02




Item	Code	Description	See page	QT
32	0561016468	FASTENER		02
33	0551019159	LEVER FIXER BODY		02
34	0503034396	FERTILIZER SIDE COVER		12
35	0503010362	1/8" X 1.1/4" COTTERPIN		12
36	0503062927	SILO FERTILIZER 3 MOUTHS		02



Item	Code	Description	See page	QT
01	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	45	02
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	46	05
03	0501010942	3/8" X 1-1/4" BOLT		28
04	0503011443	3/8" SPRING WASHER		28
05	0503010026	3/8" NUT		28
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0503013816	5/16" LOCKNUT		02
11	0581018930	SQUARE AXLE 3/4 X 2788 - 5950		01
12	1902010685	18Z CONICAL GEAR		07
13	0503030275	AGRICULTURAL BEARING		07
14	0501053788	Q3/4" FASTENER AXLE ASSY	47	01
15	0501110392	SILO SUPPORT BEARING		01
16	0503010003	1845 GREASE FITTING		01
17	0521069410	SUPPORT RIGHT SILO FERTILIZER 5950		01
18	0503011953	5/16" X 1" BOLT		02
19	0521011039	FLAT WASHER		02
20	0503011444	SPRING WASHER		02
21	0503010337	5/16" NUT		02
22	0521012485	GEAR BOX BEARING AGRICUTURAL		01




Item	Code	Description	See page	QT
01	0521069411	LEFT SILO FERTILIZER 5950 SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	45	05
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	46	02
04	0501010942	3/8" X 1-1/4" BOLT		28
05	0503011443	3/8" SPRING WASHER		28
06	0503010026	3/8" NUT		28
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0503010337	5/16" NUT		02
12	0581018930	SQUARE AXLE 3/4 X 2788 - 5950		01
13	0503030275	AGRICULTURAL BEARING		07
14	1902010685	18Z CONICAL GEAR		07
15	0503010003	1845 GREASE FITTING		01
16	0501053788	Q3/4" FASTENER AXLE ASSY	47	01
17	0521012485	GEAR BOX BEARING AGRICUTURAL		01
18	0501110392	SILO SUPPORT BEARING		01
19	0503011953	5/16" X 1" BOLT		02
20	0521011039	FLAT WASHER		02
21	0503011444	SPRING WASHER		02
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521054544	SILO FERTILIZER RIGHT SUPPORT 6850	52	01
02	0521054545	LEFT FERTILIZER BEAM SUPPORT 6850	53	01
03	0503062362	SILO FERTILIZER 04 MOUTH		04
04	0501010984	FLAT WASHER		24
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12
07	0503010849	3/8" X 1-1/2" BOLT		12
08	0503013751	3/8 UNC X 1.1/4 BOLT		24
09	0571019051	FIXER BOX WASHER		24
10	0503012535	3/8" SPRING WASHER		24
11	0503012531	3/8" INOX NUT		24
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	5/16" ZN SPRING WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0581012605	GEAR BOX LEVER LOCK		02
19	0551019160	LEVER		02
20	0521061741	INNTER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0511017302	FLAT WASHER		06
23	0551019167	SLEEVE UNION		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501013518	FLAT WASHER		06
27	0503010140	1/8" X 3/4" COTTERPIN		06
28	0503010479	BOLT		02
29	0551019168	SLEEVE		02
30	0503011336	1/2" HEX SELF ADJUSTING NUT		06
31	0511069678	LH LOWER LEVER		02




Item	Code	Description	See page	QT
32	0561016468	FASTENER		02
33	0551019159	LEVER FIXER BODY		02
34	0503034396	FERTILIZER SIDE COVER		12
35	0503010362	1/8" X 1.1/4" COTTERPIN		12



Item	Code	Description	See page	QT
01	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	45	04
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	46	04
03	0501010942	3/8" X 1-1/4" BOLT		32
04	0503011443	3/8" SPRING WASHER		32
05	0503010026	3/8" NUT		32
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0503013816	5/16" LOCKNUT		02
11	0581018942	SQUARE AXLE 3/4 X 3185 6850		01
12	1902010685	18Z CONICAL GEAR		08
13	0503030275	AGRICULTURAL BEARING		08
14	0501053788	Q3/4" FASTENER AXLE ASSY	47	01
15	0501110392	SILO SUPPORT BEARING		01
16	0503010003	1845 GREASE FITTING		01
17	0521069414	SUPPORT RIGHT SILO FERTILIZER 6850		01
18	0503011953	5/16" X 1" BOLT		02
19	0521011039	FLAT WASHER		02
20	0503011444	SPRING WASHER		02
21	0503010337	5/16" NUT		02
22	0521012485	GEAR BOX BEARING AGRICUTURAL		01




Item	Code	Description	See page	QT
01	0521069415	LEFT SILO FERTILIZER 6850 SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	45	04
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	46	04
04	0501010942	3/8" X 1-1/4" BOLT		32
05	0503011443	3/8" SPRING WASHER		32
06	0503010026	3/8" NUT		32
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0503010337	5/16" NUT		02
12	0581018942	SQUARE AXLE 3/4 X 3185 6850		01
13	0503030275	AGRICULTURAL BEARING		08
14	1902010685	18Z CONICAL GEAR		08
15	0503010003	1845 GREASE FITTING		01
16	0501053788	Q3/4" FASTENER AXLE ASSY	47	01
17	0521012485	GEAR BOX BEARING AGRICUTURAL		01
18	0501110392	SILO SUPPORT BEARING		01
19	0503011953	5/16" X 1" BOLT		02
20	0521011039	FLAT WASHER		02
21	0503011444	SPRING WASHER		02
22	0503013816	5/16" LOCKNUT		02



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	57	01
15	0511051434	TRANSMISSION DRIVING ASSY	58	02
16	0511047069	SIDE TRANSMISSION DRIVING	59	01
17	0521043316	RIGHT GEAR BOX ASSY	61	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	73	01
26	0501058234	LOWER CHAIN TENSIONER	74	01
27	0521055207	TOP CURRENT STRETCHER	75	01
28	0501058236	BEARING WITH 21Z GEAR	76	01
29	0501058237	16Z GEAR BEARING	77	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	72	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01




Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0571011442	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	57	01
15	0511051434	TRANSMISSION DRIVING ASSY	58	02
16	0511047069	SIDE TRANSMISSION DRIVING	59	01
17	0521043316	RIGHT GEAR BOX ASSY	61	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	73	01
26	0501058234	LOWER CHAIN TENSIONER	74	01
27	0521055207	TOP CURRENT STRETCHER	75	01
28	0501058236	BEARING WITH 21Z GEAR	76	01
29	0501058237	16Z GEAR BEARING	77	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	72	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01




Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0571017032	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	57	01
15	0511051434	TRANSMISSION DRIVING ASSY	58	02
16	0511047069	SIDE TRANSMISSION DRIVING	59	01
17	0521043316	RIGHT GEAR BOX ASSY	61	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	73	01
26	0501058234	LOWER CHAIN TENSIONER	74	01
27	0521055207	TOP CURRENT STRETCHER	75	01
28	0501058236	BEARING WITH 21Z GEAR	76	01
29	0501058237	16Z GEAR BEARING	77	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	72	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01


Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503030303	SUPPORT WASHER		01
35	0501010984	FLAT WASHER		01
36	0503010025	3/8" SPRING WASHER		01
37	0501010637	FLAT WASHER		01
38	0503010256	3/8" X 3/4" BOLT		01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	5/16" X 3/4" BOLT		02
03	0503010179	5/16" ZN SPRING WASHER		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ETIQUETA ADHESIVA		01



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY


0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	63	01
02	0511059266	CLOSED BEARING	65	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	BEARING ASSY GEAR BOX	67	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH LINK ASSY	69	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	70	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	71	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	64	01
02	0511059266	CLOSED BEARING	65	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	BEARING ASSY GEAR BOX	67	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH LINK ASSY	69	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	70	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	71	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0501056271	BEARING CLOSED	66	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	68	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
05	0503010179	5/16" ZN SPRING WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503019355	BEARING 6202 2RS1		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0551019173	CHAIN SLEEVE TENSIONER		01
05	0511017302	FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019174	DOBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0521055242	WHEELED SUPPORT ASSY 585 WITHOUT TRANSMISSION	80	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0521058398	WHEEL SUPPORT WITHOUT TRANSMISSION	81	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0521061565	WHEEL SUPPORT ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0503018981	BOLT		02
07	0503010027	5/8" SPRING WASHER		02
08	0521012190	AXLE LOCK		02
09	0521055239	WHEEL WITH PNEUME WHEELED BOX WITHOUT TRANSMISSION	82	01




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0521061565	WHEEL SUPPORT ARM		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0521058394	WHEEL WITH PNEUME	83	01
06	0591010589	BODY LOCK WHEEL		02
07	0503018981	BOLT		02
08	0503010027	5/8" SPRING WASHER		02
09	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL	84	01
02	0521055244	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	85	01




Item	Code	Description	See page	QT
01	0503063172	WHEEL		01
02	0521055244	WHEELED WITHOUT TRANSMISSION WITHOUT 85 TIRE		01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503012114	7.00 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0521012185	TRANSM AXLE CARRYING-WHEEL		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521069416	RIGHT PLATFORM		01
02	0521069421	LEFT PLATFORM		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	FLAT WASHER		18
06	0503010025	3/8" SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	HAIR PIN		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521069418	RIGHT PLATFORM 5950		01
02	0521069423	LEFT PLATFORM 5950		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	FLAT WASHER		18
06	0503010025	3/8" SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	HAIR PIN		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521069420	RIGHT PLATFORM 6850		01
02	0521069425	LEFT PLATFORM 6850		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	FLAT WASHER		18
06	0503010025	3/8" SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	HAIR PIN		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521062988	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8" SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0521063175	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8" SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0521065192	HANDRAIL 6850		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8" SELF-ADJUSTING NUT		08



Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0501014177	5/8" X 2-1/2" BOLT		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0531061696	LINE MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	97	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	HAIR PIN		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	SEQUENTIAL VALVE ASSY	98	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0511057090	HYDRAULIC MARKER HAND SET		01
24A	0501081728	HOSE 3/8 X 3100 TR-TR		01
24B	0501080392	3/8" X 3300 TR-TC HOSE		01
24C	0501081988	3/8" X 145.6" TR-TC HOSE		01
24D	0501081682	TC-TC HOSE ASSY		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	33	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04
38	0551018948	BODY MARKER SUPPORT LINE		02




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	97	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	HAIR PIN		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	SEQUENTIAL VALVE ASSY	98	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0511057091	HYDRAULIC MARKER HANDLE SET		01
24A	0501081793	HOSE		01
24B	0501081967	TR-TC HOSE ASSY		01
24C	0501081996	HOSE		01
24D	0501081997	HOSE		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	33	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	97	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	HAIR PIN		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	SEQUENTIAL VALVE ASSY	98	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0511057103	HYDRAULIC MARKER HANDLE ASSY 6850		01
24A	0501081990	HOSE 3/8 X 4100 TR-TR		01
24B	0501080388	3/8 X 4300 TR-TC HOSE ASSY		01
24C	0501080724	3/8" X 4700 TR-TC HOSE ASSY		01
24D	0501081993	HOSE 3/8 X 4900 TC-TC 180G		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01


Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	33	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0521069643	DISC AXLE MARKER LINE		01
02	0602023094	DR16X3 C36AFPAFR73+4FR+4FR D474 10R		01
03	0581019513	DEPTH WHEEL BOX		01
04	0503019342	ROLLER BEARING		01
05	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503013758	1/4" X 1-1/2" BOLT		03
11	0503010143	1/4" SPRING WASHER		03
12	0503010358	5/16" X 5/8" BOLT		04
13	0503010179	5/16" ZN SPRING WASHER		04
14	0503010337	5/16" NUT		04
15	0503034055	CLAMPING RING		01




Item	Code	Description	See page	QT
01	0511059584	ASSEMBLY CSU C3 2 BOXES 6B WITH 10 4880	101	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RH SUPPORT TOWER SILO	103	01
07	0521051931	LH SUPPORT TOWER SILO	104	01
08	0521051927	TOWER SUPPORT HOPPER	105	02




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		04
02	0501010984	FLAT WASHER		04
03	0503010025	3/8" SPRING WASHER		52
04	0503010026	3/8" NUT		52
05	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	102	10
06	0571015773	SUPPORT SEED CSU		02
07	0501011643	3/8 X 1" BOLT		08
08	0501010942	3/8" X 1-1/4" BOLT		40
09	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS		02
10	0503061899	REAR BEAN FERTILIZER ASSY		02




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
09	0503010179	5/16" ZN SPRING WASHER		02
10	0503010337	5/16" NUT		02
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT		01




Item	Code	Description	See page	QT
01	0521066206	RH SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066207	LH SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066208	SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066204	TOWER SUPPORT LEFT SIDE FIXER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066205	TOWER SUPPORT LEFT SIDE FIXER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0511058724	ASSEMBLY CSU C3 2BOXES 7/6 12E500	109	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521051931	LH SUPPORT TOWER SILO	104	02
07	0521051927	TOWER SUPPORT HOPPER	105	02




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		04
02	0501010984	FLAT WASHER		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	102	12
06	0571015773	SUPPORT SEED CSU		02
07	0501011643	3/8 X 1"BOLT		08
08	0501010942	3/8" X 1-1/4" BOLT		48
09	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0511058802	ASSEMBLY CSU C3 2 BOXES 7B WITH 13 C 111 5720/6350		01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RH SUPPORT TOWER SILO	103	01
07	0521051931	LH SUPPORT TOWER SILO	104	01
08	0531051996	LEFT TOWER SUPPORT SILO SUPPORT WITH SCREW		01
09	0531051994	RIGHT TOWER SUPPORT SILO SUPPORT WITH SCREW		01




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		04
02	0501010984	FLAT WASHER		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	102	13
06	0571015773	SUPPORT SEED CSU		01
07	0501011643	3/8 X 1"BOLT		04
08	0501010942	3/8" X 1-1/4" BOLT		52
09	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0521054560	ASSEMBLY CSU C3 2 BOXES 5/4 2 BOXES 5/3 6850	113	01
02	0501010942	3/8" X 1-1/4" BOLT		16
03	0501010984	FLAT WASHER		16
04	0503010025	3/8" SPRING WASHER		16
05	0503010026	3/8" NUT		16
06	0521051927	TOWER SUPPORT HOPPER	105	04
07	0521051928	FIXED TOWER SIDE RIGHT SILO SUPPORT WITH SCREW	106	01
08	0521051929	SIDE FIXED TOWER LEFT SILO SUPPORT WITH SCREW	107	01




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		08
02	0501010984	FLAT WASHER		08
03	0503010025	3/8" SPRING WASHER		88
04	0503010026	3/8" NUT		88
05	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	102	14
06	0571015773	SUPPORT SEED CSU		06
07	0501011643	3/8 X 1" BOLT		24
08	0501010942	3/8" X 1-1/4" BOLT		56
09	0503061987	SILO FERTILIZER 05 MOUTHS FRONT MOUNTED		04
10	0521064748	05 MOUTHS CSU SUPPORT		04




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		15mt
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		02
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	117	02
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		14




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		17mt
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		02
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	117	02
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		14




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		22mt
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		04
04	0503012903	T-80M CRAMP NYLON		70
05	0521052792	MOUNTED REAR LIGHT	117	04
06	3505151602	TUBE		0,6mt
07	0503017702	FIXER		20



Item	Code	Description	See page	QT
01	0503018738	LIGHTHOUSE		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	5/16" ZN SPRING WASHER		04
08	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
05	0503010179	5/16" ZN SPRING WASHER		01
06	0503010337	5/16" NUT		01
07	0511033473	PACKING WITH MANUAL		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	57	01
15	0511051434	TRANSMISSION DRIVING ASSY	58	02
16	0511047070	LH SIDE TRANSMISSION DRIVING	60	01
17	0521043317	LEFT GEAR BOX ASSY	62	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	73	01
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	72	01
27	0501058234	LOWER CHAIN TENSIONER	74	01
28	0521055207	TOP CURRENT STRETCHER	75	01
29	0501058236	BEARING WITH 21Z GEAR	76	01
30	0501058237	16Z GEAR BEARING	77	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0571011442	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	57	01
15	0511051434	TRANSMISSION DRIVING ASSY	58	02
16	0511047070	LH SIDE TRANSMISSION DRIVING	60	01
17	0521043317	LEFT GEAR BOX ASSY	62	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	73	01
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	72	01
27	0501058234	LOWER CHAIN TENSIONER	74	01
28	0521055207	TOP CURRENT STRETCHER	75	01
29	0501058236	BEARING WITH 21Z GEAR	76	01
30	0501058237	16Z GEAR BEARING	77	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0571017032	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	57	01
15	0511051434	TRANSMISSION DRIVING ASSY	58	02
16	0511047070	LH SIDE TRANSMISSION DRIVING	60	01
17	0521043317	LEFT GEAR BOX ASSY	62	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	73	01
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	72	01
27	0501058234	LOWER CHAIN TENSIONER	74	01
28	0521055207	TOP CURRENT STRETCHER	75	01
29	0501058236	BEARING WITH 21Z GEAR	76	01
30	0501058237	16Z GEAR BEARING	77	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01


Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503030303	SUPPORT WASHER		01
35	0501010984	FLAT WASHER		01
36	0503010025	3/8" SPRING WASHER		01
37	0501010637	FLAT WASHER		01
38	0503010256	3/8" X 3/4" BOLT		01




Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
02	0511017302	FLAT WASHER		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0521069295	SUPPORT TOOL CHEST		01
06	0581017000	PLATE INTERMEDIARY		02
07	0503034772	BOX		01
08	0501011643	3/8 X 1" BOLT		04
09	0503010025	3/8" SPRING WASHER		04
10	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
02	0511017302	FLAT WASHER		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0521069405	WATER TANK SUPPORT		01
06	0503014820	COROTE BLACK WATER		01




Item	Code	Description	See page	4880	5950	6850
01	0521013430	HEX AXLE 5/8 X 2580		001	000	000
02	0521013434	HEX AXLE 5/8 X 2300		001	000	000
03	0541019101	HEX AXLE 5/8 X 3110		000	001	000
03.	0581018948	HEX AXLE 5/8 X 3540		000	000	001
04	0541019102	HEX AXLE 5/8 X 2830		000	001	000
04.	0581018949	HEX AXLE 5/8 X 3294		000	000	001
05	0502011299	BUSHING GEAR		002	002	002
06	0503010010	1/4" X 2.1/2" COTTERPIN		002	002	002
07	0511065562	20Z GEAR		002	002	002
08	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8		002	002	002
09	0511017305	FLAT WASHER		004	004	004
10	0511815098	FLAT WASHER		002	002	002
11	0503010003	1845 GREASE FITTING		002	002	002
12	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"		002	002	002
12A	0521012503	BEARING BOX CHANGE		001	001	001
12B	0521012288	1.2" X 1.5" X 1.6" SLEEVE		001	001	001
13	0503010571	1/4" X 1.1/2 COTTERPIN		002	002	002
14	0503010365	NUT		004	004	004
15	0501010694	8.5 X 18 X 1.5 FLAT WASHER		008	008	008
16	0501010984	FLAT WASHER		004	004	004
17	0503010179	5/16" ZN SPRING WASHER		004	004	004
18	0503010337	5/16" NUT		004	004	004



Item	Code	Description	See page	QT
01	0503062795	KIT MONITORING SEED 10L 45/50 PM400 PM410SSM		01
01A	0503016556	10 ROW SIMPLE MONITOR CABLE		01
01B	0503019100	SENSOR		10
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503013100	NYLON CLAMP		50
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		150
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
08	0503010669	FLAT WASHER		02
09	0503010668	3/16" SPRING WASHER		02
10	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0503062796	KIT MONITORING SEED 11L 45/50 PM400 PM411SSM		01
01A	0503016557	11 ROW SIMPLE MONITOR CABLE		01
01B	0503019100	SENSOR		11
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503013100	NYLON CLAMP		55
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		165
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
08	0503010669	FLAT WASHER		02
09	0503010668	3/16" SPRING WASHER		02
10	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0503062798	KIT MONITORING SEED 13L 45/50 PM400 PM413SSM		01
01A	0503016559	13 ROW SIMPLE CABLE MONITORING		01
01B	0503019100	SENSOR		13
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503013100	NYLON CLAMP		65
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		195
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
08	0503010669	FLAT WASHER		02
09	0503010668	3/16" SPRING WASHER		02
10	0503010667	3/16" NUT		02



Item	Code	Description	See page	QT
01	0503034780	ADHESIVE LABEL PST DUO (04/06 MOUTHS)		01
02	0503034114	ADHESIVE LABEL LOGO TATU BOX 190 X 530		01
03	0503033855	ADHESIVE LABEL		01
04	0503033854	ADHESIVE LABEL		01
05	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
07	0503033422	ADHESIVE LABEL		04
08	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
09	0503033008	ADHESIVE LABEL		02
10	0503031428	READ MANUAL DECAL		01
11	0503031942	ADHESIVE LABEL		01
12	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		01
13	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
14	0503031565	ADHESIVE LABEL CARE		02
15	0503031566	ADHESIVE LABEL		02
16	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
17	0503031425	ADHESIVE LABEL ATTENTION		02
18	0503031669	ADHESIVE LABEL		01
19	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
20	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
21	0503032930	ADHESIVE LABEL DANGER		06
22	0503031087	ADHESIVE LABEL		01
23	0503034078	LIFTING POINTS DECAL		03
24	0503034003	SERIAL NUMBER TAG 61 X 118		01
25	0503010001	3.2 X 5.5 RIVET		04
26	0503032979	ADHESIVE LABEL LETTERS A B C D		02
27	0503034500	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0503034780	ADHESIVE LABEL PST DUO (04/06 MOUTHS)		01
02	0503034114	ADHESIVE LABEL LOGO TATU BOX 190 X 530		01
03	0503033855	ADHESIVE LABEL		01
04	0503033854	ADHESIVE LABEL		01
05	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
07	0503033422	ADHESIVE LABEL		04
08	0503033008	ADHESIVE LABEL		02
09	0503031428	READ MANUAL DECAL		01
10	0503031942	ADHESIVE LABEL		01
11	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		01
12	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
13	0503031565	ADHESIVE LABEL CARE		02
14	0503031566	ADHESIVE LABEL		02
15	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
16	0503031425	ADHESIVE LABEL ATTENTION		02
17	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
18	0503031669	ADHESIVE LABEL		01
19	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
20	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
21	0503032930	ADHESIVE LABEL DANGER		06
22	0503031087	ADHESIVE LABEL		01
23	0503034078	LIFTING POINTS DECAL		03
24	0503034003	SERIAL NUMBER TAG 61 X 118		01
25	0503010001	3.2 X 5.5 RIVET		04
26	0503032979	ADHESIVE LABEL LETTERS A B C D		02
27	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503034781	LABEL ADHESIVE PST DUO MINOR (03 MOUTHS)		01
02	0503034780	ADHESIVE LABEL PST DUO (04/06 MOUTHS)		01
03	0503034782	LABEL ADHESIVE LOGO SMALLER TATU (03 MOUTHS)		01
04	0503034114	ADHESIVE LABEL LOGO TATU BOX 190 X 530		01
05	0503033855	ADHESIVE LABEL		01
06	0503033854	ADHESIVE LABEL		01
07	0503033853	ADHESIVE LABEL		02
08	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
09	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		04
10	0503033423	LABEL ADHESIVE NUMBER 9		02
11	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
12	0503033008	ADHESIVE LABEL		02
13	0503031428	READ MANUAL DECAL		01
14	0503031942	ADHESIVE LABEL		01
15	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		01
16	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
17	0503031565	ADHESIVE LABEL CARE		02
18	0503031566	ADHESIVE LABEL		02
19	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
20	0503031425	ADHESIVE LABEL ATTENTION		02
21	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
22	0503031669	ADHESIVE LABEL		01
23	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
24	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
25	0503032930	ADHESIVE LABEL DANGER		08
26	0503031087	ADHESIVE LABEL		01
27	0503034078	LIFTING POINTS DECAL		03
28	0503034003	SERIAL NUMBER TAG 61 X 118		01

Item	Code	Description	See page	QT
29	0503010001	3.2 X 5.5 RIVET		04
30	0503032979	ADHESIVE LABEL LETTERS A B C D		02
31	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503034780	ADHESIVE LABEL PST DUO (04/06 MOUTHS)	02	
02	0503034114	ADHESIVE LABEL LOGO TATU BOX 190 X 530	02	
03	0503033855	ADHESIVE LABEL	02	
04	0503033854	ADHESIVE LABEL	02	
05	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING	02	
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
07	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING	02	
08	0503033422	ADHESIVE LABEL	02	
09	0503033424	DIRECT PLANTIO ADHESIVE LABEL	02	
10	0503033008	ADHESIVE LABEL	02	
11	0503031428	READ MANUAL DECAL	01	
12	0503031942	ADHESIVE LABEL	01	
13	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS	01	
14	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
15	0503031565	ADHESIVE LABEL CARE	02	
16	0503031566	ADHESIVE LABEL	02	
17	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
18	0503031425	ADHESIVE LABEL ATTENTION	02	
19	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO	02	
20	0503031669	ADHESIVE LABEL	01	
21	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
22	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
23	0503032930	ADHESIVE LABEL DANGER	08	
24	0503031087	ADHESIVE LABEL	01	
25	0503034078	LIFTING POINTS DECAL	03	
26	0503034003	SERIAL NUMBER TAG 61 X 118	01	
27	0503010001	3.2 X 5.5 RIVET	04	
28	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
29	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0521054803	ASSEMBLY LINE SEED/FERTILIZER SHORT WITHOUT LUBRICATION CSU TITANIUM	133	01
02	0521054804	ASSEMBLY LINE SEED/FERTILIZER LONG WITHOUT LUBRICATION CSU TITANIUM	134	01
03	0521054768	DDD RIGHT FERTILIZER WITH SUPPORT	156	01
04	0521054769	LEFT FERTILIZER WITH SUPPORT	157	01
05	0521054984	DEPTH SYSTEM / COMPACTOR WITHOUT LUBRICATION	160	01
05.	0521054758	CONTROL DEPTH WITH REGULATOR	171	01
05..	0521055053	DEEP WHEEL / COMPACTOR SYSTEM	183	01
06	0503030391	RIGHT FERTILIZER NOZZLE		01
07	0503030392	LEFT FERTILIZER NOZZLE		01
08	0503031050	CURVED CONDUCTOR		01
09	0503010246	CLAMP		01
10	0503031145	2" X 2" X 20" HOSE		01
11	0503031076	2" HOSE CLAMP		01
12	0571011730	SEED CONDUCTOR 3X1500		01
13	0521050525	FIXER FERTILIZER CONDUCTOR	189	01
14	0501013714	STABILIZER BAR		01
15	0581015215	STABILIZER BAR E500 PIVOTED HIGH LINE		01
15.	0581015213	STABILIZER BAR E450		01
16	0503010741	1/2" X 2-3/4" BOLT		01
17	0503010547	1/2" X 4" BOLT		01
18	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
19	0511017302	FLAT WASHER		01
20	0503010019	1/2" SPRING WASHER		01
21	0503010060	1/2" NUT		01
22	0521053946	SCARING ROD	190	01
23	0511017969	0.1" SPACING PLATE		01
24	0511018662	SPACING PLATE		01
25	0521069124	BOCAL FILLED LINE PIVOTED WITH LINGUET		01
26	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01

Item	Code	Description	See page	QT
27	0501010984	FLAT WASHER		01
28	0503010025	3/8" SPRING WASHER		01
29	0503010026	3/8" NUT		01
30	0503062066	DISC SET WITH CORN RING		01
31	0503062067	DISC SET / RING SOY 90F TITANIUM		01
32	0521053947	HDA ELEVATION 0869	191	01
33	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
34	0503010019	1/2" SPRING WASHER		01
35	0503010060	1/2" NUT		01
36	0521068982	KEY CASH DISC CUTTING		01
37	0581010082	FERTILIZER SOCKET RIGHT		01
38	0581010083	FERTILIZER SOCKET LEFT		01
39	0521054912	RIGHT SUPPORT WITH DOC 18	194	01
40	0521054913	LEFT SUPPORT WITH DOC 18	196	01
41	0521050168	MOUNTED FERTILIZER CONDUCTOR	198	01
42	0501018652	CORN STABILIZER BAR		01
43	0501110814	SCARIFIER ROD WITH IAPAR NOZZLE	199	01
44	0521058721	WHEEL CBR FERTILIZER V RIGHT RUBBER ROD 200 HIGH LINE		01
45	0521058722	WHEEL CBR FERTILIZER V LEFT RUBBER ROD 201 HIGH LINE		01




Item	Code	Description	See page	QT
01	0521054813	SHORT PIVOT LIFT LINE	135	01
02	0521054718	SYSTEM SEED POPCORN	149	01
03	0501010066	3/4" X 9" BOLT		01
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0502012873	SUPPORT DC LINE FERTILIZER		01
07	0503019278	LUBRICANT GLOVE		02
08	0581019195	SIDE GUIDE GLOVE		02
09	0581019196	CENTRAL GUIDE GLOVE		01
10	0503010410	RING		02
11	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
12	0503010013	5/8" NUT		02
13	0521053231	DPL 20 SHORT LINE WITHOUT LUBRICATION 151 CONICAL BEARING		01
14	0521069482	ARM FERTILIZER LINE SHORT RISE WITHOUT LUBRICATION		01
15	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	155	01
16	0503017857	BOLT 5/8 UNF 4		03
17	0503010811	5/8" UNF SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0521054814	LONG PIVOT LIFT LINE	136	01
02	0521054718	SYSTEM SEED POPCORN	149	01
03	0501010066	3/4" X 9" BOLT		01
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0502012873	SUPPORT DC LINE FERTILIZER		01
07	0503019278	LUBRICANT GLOVE		02
08	0581019195	SIDE GUIDE GLOVE		02
09	0581019196	CENTRAL GUIDE GLOVE		01
10	0503010410	RING		02
11	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
12	0503010013	5/8" NUT		02
13	0521053232	DPL 20 LONG LINE WITHOUT LUBRICATION 152 CONICAL BEARING		01
14	0521069483	ARM LONG LINE HIGH FERTILIZER WITHOUT LUBRICATION		01
15	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	155	01
16	0503017857	BOLT 5/8 UNF 4		03
17	0503010811	5/8" UNF SELF ADJUSTING NUT		03

SHORT PIVOT LIFT LINE


0521054813




Item	Code	Description	See page	QT
01	0502011505	18Z CONICAL GEAR		01
02	1902010426	UPPER BEARING SEMI		02
03	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
04	0521018079	SEEP ROW DRAWBAR COVER		01
05	0521068663	SHORT SEED LINE ARM		01
06	0511052024	FAST CLOSING SET	137	01
07	0511059244	ROD SPRING LINE SEED	138	01
08	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	139	01
09	0502012872	PIVOTING CLAMP		01
10	0503010479	BOLT		04
11	0503010019	1/2" SPRING WASHER		08
12	0503010060	1/2" NUT		08
13	0581019188	ARTICULATED SUPPORT WITHOUT LUBRICATION		01
14	0503019343	AUTO LUBRICANT GLOVE		02
15	0503019344	AUTO LUBRICANT GLOVE		01
16	0581019189	BEARING GLOVE AXIS SEXTAVADO 1/2 WITHOUT LUBRICATION		01
17	0581019190	GEAR 18Z 5/8 ENGINE WITHOUT LUBRICATION		01
18	0503010410	RING		04
19	0501013352	FLAT WASHER		02
20	0501013354	FLAT WASHER		02
21	0521054775	LEFT REAR SEAL LINE BASE 1/2	140	01
22	0521018077	1/2" X 58.6" HEX AXLE		01
23	0503014729	1/4" UNF X 1/2" BOLT		02
24	0503010143	1/4" SPRING WASHER		02
25	0503010752	1/2" X 3.1/2" BOLT		02
26	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0502011505	18Z CONICAL GEAR		01
02	1902010426	UPPER BEARING SEMI		02
03	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
04	0521018079	SEEP ROW DRAWBAR COVER		01
05	0521068664	LONG SEED LINE ARM		01
06	0511052024	FAST CLOSING SET	137	01
07	0511059244	ROD SPRING LINE SEED	138	01
08	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	139	01
09	0502012872	PIVOTING CLAMP		01
10	0503010479	BOLT		04
11	0503010019	1/2" SPRING WASHER		08
12	0503010060	1/2" NUT		08
13	0581019188	ARTICULATED SUPPORT WITHOUT LUBRICATION		01
14	0503019343	AUTO LUBRICANT GLOVE		02
15	0503019344	AUTO LUBRICANT GLOVE		01
16	0581019189	BEARING GLOVE AXIS SEXTAVADO 1/2 WITHOUT LUBRICATION		01
17	0581019190	GEAR 18Z 5/8 ENGINE WITHOUT LUBRICATION		01
18	0503010410	RING		04
19	0501013352	FLAT WASHER		02
20	0501013354	FLAT WASHER		02
21	0521054774	REAR RIGHT LINE SEED LIFT	141	01
22	0521018078	1/2" X 66.5" HEX AXLE		01
23	0503014729	1/4" UNF X 1/2" BOLT		02
24	0503010143	1/4" SPRING WASHER		02
25	0503010752	1/2" X 3.1/2" BOLT		02
26	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0511060376	SEEP SPRING GUIDE		01
02	0503010834	1/2 X 1 BOLT		02
03	0502040534	SPRING GUIDE BUSHING LOCK		02
04	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
05	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
06	0501013753	FLAT WASHER		01
07	0521010542	COUPLING SHAFT		01
08	0503010257	1/8" X 1" COTTERPIN		01
09	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0502012538	SPRING VARON SUPPORT		01
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
03	0511017302	FLAT WASHER		02
04	0503011336	1/2" HEX SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521054819	BASE 1/2 FIXED WITHOUT ASSY LUBRICATION	142	01
02	0521054763	DDD LEFT SEED	143	01
03	0581014527	ELEVATION PLATE 12,5		03
04	0581014526	ELEVATION PLATE 3/8		01
05	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
06	0503010025	3/8" SPRING WASHER		04
07	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521054819	BASE 1/2 FIXED WITHOUT ASSY LUBRICATION	142	01
02	0521054762	RIGHT DDD SEED	144	01
03	0581014527	ELEVATION PLATE 12,5		03
04	0581014526	ELEVATION PLATE 3/8		01
05	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
06	0503010025	3/8" SPRING WASHER		04
07	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0581019199	FIXED BASE		01
02	0581019200	CONICA 40Z GEAR		01
03	0581019201	CROWN SHAFT		01
04	0503019340	LUBRICANT GLOVE		02
05	0503019341	LUBRICANT GLOVE		01
06	0503011030	2-014 N 3006-9B O'RING		02
07	0503010410	RING		02
08	0501013354	FLAT WASHER		01
09	0581019203	CONICAL PINION		01




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	145	01
02	0521054761	LEFT LOW CUBE	147	01
03	0521054760	DOWN LOW CUBE	148	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0511015098	FLAT WASHER		04
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	146	01
02	0521054761	LEFT LOW CUBE	147	01
03	0521054760	DOWN LOW CUBE	148	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0511015098	FLAT WASHER		04
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O-RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502012736	HUB LOWR DDD		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012736	HUB LOWR DDD		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0511052058	SEED SYSTEM TITANIUM	150	01
02	0521050118	DEPOSIT SEED BOCAL		01
03	0503010358	5/16" X 5/8" BOLT		05
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		05
05	0503010179	5/16" ZN SPRING WASHER		05
06	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0503062031	BASE SET		01
02	0503062032	NECK TITANIUM ASSY		01
03	0503062033	OPPOSITE BASE SET		01
04	0503062034	CENTRAL ADAPTER SET		01
05	0503062035	SET FALSE ADAPT CENTER		01
06	0503062036	SUBSET ASSY LOCK BASE		01
07	0503062037	SUBSET ESCOVAFLEX ASSY		01
08	0503062038	ASSY ANTI-LEAP		01
09	0503062039	POLIFLOW TITANIUM ASSY		01
09.	0503016279	POLIFLOW TITANIUM ASSY		01
10	0503062040	DISPLAY ASSY TITANIUM 1050010		01
11	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
12	0503062042	SET BOLT ARTICULADOR		01
13	0503062043	ASSY LIMIT WEIGHT		01
14	0503062044	SET MOUNT BOX FOR SEED		01
14A	0503016285	BOLT		05
14B	0503016286	HEX NUT		05
14C	0503016287	FLAT WASHER		05



Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	153	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	153	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012824	FIXING SHAFT DISC CUT LINE		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	CUTTING DISK BOX	154	01

CUTTING DISK BOX


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	CUTTING DISK BOX		01
09	0502040873	CUTTING DISC AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK	02	
02	0502012184	FERTILIZER SPRING GUIDE	02	
03	0503031910	1.7" X 22.8" X 0.3" SPRING	01	
04	0502012510	SPRING ROD SUPPORT	01	
05	0521068568	LARGE ELEVATION SPRING FERTILIZER	01	
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN	01	
07	0501018535	1/2 X 1 BOLT	02	
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
09	0503010060	1/2" NUT	02	
10	0502010891	SPRING CHOCK SUPPORT VARON	01	
11	0503010014	3/4" NUT	01	
12	0561014471	COUPLING SHAFT	01	
13	0511017302	FLAT WASHER	01	
14	0503010257	1/8" X 1" COTTERPIN	01	




Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	147	01
03	0521054760	DOWN LOW CUBE	148	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511015098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	147	01
03	0521054760	DOWN LOW CUBE	148	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511015098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	161	01
02	0501052538	DEPTH BAND WITH ARMS	167	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0521054990	LEFT COMPACTOR WHEEL	168	01
06	0521055017	RIGHT COMPACTOR WHEEL	169	01




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	162	01
02	0521054987	LEFT ARM WHEEL DEPTH WITH NO LUBRICATION CUBE	163	01
03	0521054988	RIGHT ARM ROD DEPTH WITH LUBRICANT-FREE HUB	164	01
04	0521055033	COMPACTADOR BODY	166	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	SCREWEW 3/8 UNC X 3/4		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED GLOVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	165	01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	165	01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL BOX		01
02	0581019515	AXIS		01
03	0503034055	CLAMPING RING		01
04	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
05	0503013758	1/4" X 1-1/2" BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0503010878	5/8" SELF ALIGNING NUT		01
10	0503030757	2.9" X 2" X 0.02" JOINT		01
11	0521019178	COVER DEPTH		01




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT GLOVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	170	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	170	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05



Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521054751	DEPTH CONTROL WITH THREAD	172	01
02	0511055819	DEPTH WHIT AROS BAND	179	02
03	0521054752	V COMPACTING SYSTEM	180	01
04	0503010479	BOLT		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2" NUT		02
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
08	0503013816	5/16" LOCKNUT		08
09	0521054753	DRIVE WHEEL V RUBBER RIGHT	181	01
10	0521054754	DRIVE WHEEL V LEFT RUBBER	182	01




Item	Code	Description	See page	QT
01	0581017621	CONTROL AXLE		01
02	0521063812	REGULATOR LEVER ALXE		01
03	0503011336	1/2" HEX SELF ADJUSTING NUT		01
04	0511065308	LOCK REGULATOR		01
05	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
06	0541011627	FLAT WASHER		01
07	0503010140	1/8" X 3/4" COTTERPIN		01
08	0521053245	LEFT ARM WHEELS	175	01
09	0521053244	ARM RIGHT WHEEL COBRIDORA	176	01
10	0581017646	SLEEVE LOCK CONTROL ARM		02
11	0571013189	SLEEVE SUPPORT BEATER		01
12	0521063813	WHEEL PRESS BEATER		01
13	0501010937	13.5 X 28 X 3 FLAT WASHER		01
14	0503010045	O'RING		04
15	0503017375	1/2" X 1-1/4" BOLT		01
16	0503014007	1/2" X 1-1/4" BOLT		01
17	0503010019	1/2" SPRING WASHER		03
18	0503010920	1/2" X 1.1/2" BOLT		01
19	0503010023	3/4" SPRING WASHER		04
20	0521053483	CPRA RIGHT DEPTH CONTROL CUBE WITHOUT 173 LUBRICATION		01
21	0521053484	CPRA LEFT DEPTH CONTROL CUBE WITHOUT 174 LUBRICATION		01
22	0581019171	REGULATOR		01
23	0521069476	EXTERNAL COLUMN CONTROL DEPTH		01
24	0521069475	INTERNAL COLUMN CHECK DEPTH		01
25	0503010683	0,2" X 1,2" SPRING PIN		01
26	0503034830	REGULATION LANCHE		01
27	0521054750	CRANK ASSEMBLY		01
27A	0521069477	HAND CRANK		01
27B	0503030878	LEVER CRANK		01
28	0503030751	REGULATOR PLATE		01




Item	Code	Description	See page	QT
29	0503010001	3.2 X 5.5 RIVET		04




Item	Code	Description	See page	QT
01	0502012912	WHEEL BOX DEPTH WITHOUT LUBRICATION		01
02	0503019342	ROLLER BEARING		01
03	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
04	0581017828	RIGHT AXLE CPRA WITHOUT LUBRICATION		01
05	0503034055	CLAMPING RING		01
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0521019178	COVER DEPTH		01
09	0503010143	1/4" SPRING WASHER		03
10	0503011105	SEAL RING		01
11	0503014729	1/4" UNF X 1/2" BOLT		03




Item	Code	Description	See page	QT
01	0502012912	WHEEL BOX DEPTH WITHOUT LUBRICATION		01
02	0503019342	ROLLER BEARING		01
03	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
04	0581017845	LEFT AXLE CPRA WITHOUT LUBRICATION		01
05	0503034055	CLAMPING RING		01
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0521019178	COVER DEPTH		01
09	0503010143	1/4" SPRING WASHER		03
10	0503013758	1/4" X 1-1/2" BOLT		03
11	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0581017620	LEFT ARM WHEELS		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503019275	SLEEVE LUBRICATION SYSTEM		01




Item	Code	Description	See page	QT
01	0581011340	ARM COVER		01
02	0503011402	0.2" X 0.8" SPRING PIN		02
03	0581017645	WHEEL RIGHT ARM		01
04	0503019275	SLEEVE LUBRICATION SYSTEM		01




Item	Code	Description	See page	QT
01	0581019165	CASE WHEEL DEPTH WITHOUT GREASE FITTING		01
02	0503015081	502052 CLAMPING RING (FOR AXLE)		01
03	0503014679	2-134 O'RING		01
04	0581019170	CUBE COVER		01
05	0501010984	FLAT WASHER		01
06	0503010025	3/8" SPRING WASHER		01
07	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
08	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
09	0581019166	RIGHT AXIS		01
10	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		01




Item	Code	Description	See page	QT
01	0581019165	CASE WHEEL DEPTH WITHOUT GREASE FITTING		01
02	0503015081	502052 CLAMPING RING (FOR AXLE)		01
03	0503014679	2-134 O'RING		01
04	0581019170	CUBE COVER		01
05	0581019167	LEFT AXLE		01
06	0501010984	FLAT WASHER		01
07	0503010025	3/8" SPRING WASHER		01
08	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
09	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
10	0503019348	SCREW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503013758	1/4" X 1-1/2" BOLT		05
04	0503013814	1/4" NC LOCKNUT		05




Item	Code	Description	See page	QT
01	0581017647	PRESS WHEELS ARM		01
02	0503030883	RIGHT TORSION SPRING		01
03	0581017622	SEAT SUPPORT		01
04	0581017648	PIVOT SHAFT		01
05	0503010839	03"X 0.6" SPRING PIN		01
06	0521069490	RIGHT REGULATOR		01
07	0521069491	LEFT REGULATOR		01
08	0581017817	ADJUSTMENT SHAFT COMPACTOR 1/2 THREAD WITHOUT LUBRICATION		01
09	0521063812	REGULATOR LEVER ALXE		01
10	0503011336	1/2" HEX SELF ADJUSTING NUT		02
11	0511065308	LOCK REGULATOR		01
12	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
13	0541011627	FLAT WASHER		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0571013293	SLEEVE LOCK COMPACTOR V CONTROL WITH SCREW		01
16	0581013744	PROTECTION COVER - CPRA		01
17	0503013096	5/16" X 4" BOLT		01
18	0503013816	5/16" LOCKNUT		01
19	0503019273	SLEEVE		02
20	0503010045	O'RING		02
21	0503010025	3/8" SPRING WASHER		02
22	0503010026	3/8" NUT		02
23	0503011404	BOLT		02
24	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01




Item	Code	Description	See page	QT
01	0581019097	BOX LOWER WHEEL		01
02	0581012949	BEARING COVER		01
03	0503018045	2-130 (AGEL) O'RING		01
04	0503011105	SEAL RING		01
05	0502012893	WHEEL BOX		01
06	0521018928	PRESS WHEEL RIM		02
07	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
08	0503013816	5/16" LOCKNUT		09
09	0503010011	5/16" X 1/2" BOLT		06
10	0503010358	5/16" X 5/8" BOLT		03
11	0581019166	RIGHT AXIS		01
12	0501010984	FLAT WASHER		01
13	0503010025	3/8" SPRING WASHER		01
14	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
15	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		01
16	0503033787	NUT 3/4 UNF		01
17	0581019215	DUST CLOAK		01




Item	Code	Description	See page	QT
01	0581019097	BOX LOWER WHEEL		01
02	0581012949	BEARING COVER		01
03	0503018045	2-130 (AGEL) O'RING		01
04	0503011105	SEAL RING		01
05	0502012893	WHEEL BOX		01
06	0521018928	PRESS WHEEL RIM		02
07	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
08	0503013816	5/16" LOCKNUT		09
09	0503010011	5/16" X 1/2" BOLT		06
10	0503010358	5/16" X 5/8" BOLT		03
11	0581019167	LEFT AXLE		01
12	0501010984	FLAT WASHER		01
13	0503010025	3/8" SPRING WASHER		01
14	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
15	0503033788	NUT 3/4		01
16	0503019348	SCREW 3/8 UNC X 3/4		01
17	0581019215	DUST CLOAK		01




Item	Code	Description	See page	QT
01	0521055065	ASSY DEPTH / COMPACTOR	184	01
02	0521055068	RAYED WHEEL CENTER CLOSED	187	02
03	0521054990	LEFT COMPACTOR WHEEL	168	01
04	0521055017	RIGHT COMPACTOR WHEEL	169	01
05	0503016453	1/2" X 2.1/2 BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010028	1/2" NUT		02




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0571013054	DEPTH CONTROL WHEEL AXLE		01
04	0502012663	EXTENSION		01
05	0501056769	DEPTH WHEELS REGULATOR ASSY		01
06	0503019398	AXLE RETAINER RING		01
07	0521055033	COMPACTADOR BODY	166	01
08	0521055054	LEFT ARM WITH SLEEVE	185	01
09	0521055066	RIGHT ARM WITH GLOVE	186	01
10	0511015346	FLAT WASHER		04
11	0571015974	WASHER		02
12	0511017302	FLAT WASHER		02
13	0503010256	3/8" X 3/4" BOLT		01
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		04
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2" NUT		02
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0581019473	ARTICULATED GLOVE		02
20	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0581019523	LEFT ARM WHEEL DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019524	RIGHT ARM DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	188	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	5/16" ZN SPRING WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0581019522	CASE WHEEL DEPTH WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0503010143	1/4" SPRING WASHER		03
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019529	DEPTH REGULATOR SHAFT		01
11	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010365	NUT		02




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070085	FIXED ROD BEARING		01
03	0513010288	ELASTIC PIN 701211 10 X 24		02
04	0513010289	ELASTIC PIN 701211 10 X 24		02




Item	Code	Description	See page	QT
01	0521068567	BOX SPRING		01
02	0521053951	STEM	192	01
03	0503034106	80 X 230 X 16,50 HDA COMPRESSION SPRING		01
04	0581012094	SUPPORT WASHER		01
05	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
06	0571019462	SUPPORT GUIDE PRING		01
07	0503012795	5/8" HEX SELF ADJUSTING NUT		01
08	0503010691	1/4" GREASE FITTING		01
09	0503010384	1/2" X 5" BOLT		02
10	0511017302	FLAT WASHER		04
11	0503011336	1/2" HEX SELF ADJUSTING NUT		04
12	0503017874	BOLT 1/2 UNC		02
13	0571018541	BODY SOCKET FERTILIZER		01
14	0503010026	3/8" NUT		02
15	0503010025	3/8" SPRING WASHER		02
16	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
17	0501010984	FLAT WASHER		04
18	0503010417	7/8" NUT		01
19	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
20	0581012084	ARTICULATED GLOVE		01
21	0581012082	SCREW		01
22	0581012081	GLOVE		01




Item	Code	Description	See page	QT
01	0521053932	ROD WITH BEAK 0869	193	01
02	0521067065	FLANGE WASHER SPRING		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0581012092	AXLE FIXER		01
05	0521015818	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521067523	STEM WITHOUT BEAK DISARM		01
02	0502040901	FIXED ROD NOZZLE		01
03	0503016853	SPRING PIN		02
04	0503011402	0.2" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0521069504	DOC DISK ARM		01
02	0581011838	SLEVE GUIDES		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0521015376	DUST CLOAK		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2" NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503016063	ROLLER BEARING		01
10	0503030832	FLAT WASHER		01
11	0521054914	BOX WITH DOC 18 RIGHT	195	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0503011800	SEAL RING		01
02	0503012417	SEAL		01
03	0503016063	ROLLER BEARING		01
04	0503030832	FLAT WASHER		01
05	0502020641	BLADE DISC FLANGE		01
06	0607025032	PLAIN COULTER BLADE		01
07	0503010371	5/16" X 1" BOLT		06
08	0503010179	5/16" ZN SPRING WASHER		06
09	0503010337	5/16" NUT		06
10	0581019304	BOX DC		01




Item	Code	Description	See page	QT
01	0521069504	DOC DISK ARM		01
02	0581011838	SLEEVE GUIDES		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0521015376	DUST CLOAK		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2" NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503016063	ROLLER BEARING		01
10	0503030832	FLAT WASHER		01
11	0521054915	BOX WITH DOC 18 LEFT	197	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0503011800	SEAL RING		01
02	0503012417	SEAL		01
03	0503016063	ROLLER BEARING		01
04	0503030832	FLAT WASHER		01
05	0502020641	BLADE DISC FLANGE		01
06	0607025032	PLAIN COULTER BLADE		01
07	0503010371	5/16" X 1" BOLT		06
08	0503010179	5/16" ZN SPRING WASHER		06
09	0503010337	5/16" NUT		06
10	0581019304	BOX DC		01




Item	Code	Description	See page	QT
01	0581013298	SUPPORT		01
02	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
03	0521018517	FLAT WASHER		01
04	0503010060	1/2" NUT		01
05	0503010019	1/2" SPRING WASHER		01
06	0503030483	FERTILIZER SOCKET		01
07	0503031050	CURVED CONDUCTOR		01
08	0503010246	CLAMP		01




Item	Code	Description	See page	QT
01	0521066350	ROD SCARIFIER SPINDLE		01
02	1902070082	POINT SUBSOILER		01
03	0503010585	0,24" X 1.18" SPRING PIN		03




Item	Code	Description	See page	QT
01	0531061197	RIGHT WHEEL SUPPORT CBR HIGH LINE ROD FERTILIZER		01
02	0511064765	SMALLER WHEEL PRESS FERTILIZER ARM		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0503010002	1800 GREASE FITTING		01
05	0503010013	5/8" NUT		02
06	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
07	0502011757	PRESS REGULATOR		01
08	0503010849	3/8" X 1-1/2" BOLT		02
09	0503010026	3/8" NUT		02
10	0511054333	COMPACT WHEEL RIGHT WITH BEARING	202	01
11	0511054334	COMPACT WHEEL LEFT WITH BEARING	203	01
12	0501013491	5/8" TENSIONER SPRING		01
13	0521010579	COUPLING SHAFT		01
14	0503010025	3/8" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0531061198	LEFT WHEEL SUPPORT CBR HIGH LINE ROD FERTILIZER		01
02	0511064765	SMALLER WHEEL PRESS FERTILIZER ARM		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0503010002	1800 GREASE FITTING		01
05	0503010013	5/8" NUT		02
06	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
07	0502011757	PRESS REGULATOR		01
08	0503010849	3/8" X 1-1/2" BOLT		02
09	0503010026	3/8" NUT		02
10	0511054333	COMPACT WHEEL RIGHT WITH BEARING	202	01
11	0511054334	COMPACT WHEEL LEFT WITH BEARING	203	01
12	0501013491	5/8" TENSIONER SPRING		01
13	0521010579	COUPLING SHAFT		01
14	0503010025	3/8" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	204	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01



Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	204	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01



Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

