

ROW CROP PLANTERS

PST DUO - FRAME 4880/5340/5950/6850 - CSU

Code: 0501092633
Series: S-0116
Revision: 00
Date Revision: JULHO/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS

Code	Description
0111230190	PST DUO 4880/10E500 ELEV HDA BC DC20 CSU S-0116
0111230201	PST DUO 4880/11E450 D/HDA BC MH DC20 CSU S-0116
0111230141	PST DUO 4880/11E450 D/HDA MH PM100 CSU S-0116
0111230163	PST DUO 4880/11E450 ESPECIAL S-0116
0111230153	PST DUO 4880/11E450 HDA CSU S-0116
0111230134	PST DUO 4880/11E450 MH CSU S-0116
0111230166	PST DUO 5340/11E500 MH CSU S-0116
0111230198	PST DUO 5950/13E450 CI MH DC20 CSU S-0116
0111230158	PST DUO 5950/13E450 CPRA MH CSU S-0116
0111230196	PST DUO 5950/13E450 D/HDA BC MH DC20 CSU S-0116
0111230146	PST DUO 5950/13E450 D/HDA MH CSU S-0116
0111230203	PST DUO 5950/13E450 ESPECIAL S-0116
0111230188	PST DUO 5950/13E450 ESPECIAL S-0116
0111230144	PST DUO 5950/13E450 MH CSU S-0116
0111230135	PST DUO 6850/14E500 D CSU S-0116
0111230148	PST DUO 6850/14E500 D MH CSU S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.



MARCHESAN

INDEX

0909098690	FRAME ASSY	1
0511056545	CHASSI COM ARTICULATION	2
0511056546	RIGHT FRAME WITH WHEEL AXLE - FRAME 4880	3
0511056738	LEFT FRAME WITH WHEEL AXLE - FRAME 4880	4
0511056737	ARTICULATED FRAME - FRAME 5340	5
0511056347	RIGHT FRAME WITH WHEEL AXLE - FRAME 5340	6
0511056739	LEFT FRAME WITH WHEEL AXLE - FRAME 5340	7
0511056787	FRAME WHIT ARTICULATION	8
0511056786	RIGHT FRAME WITH WHEEL AXLE - FRAME 5950	9
0511056785	LEFT FRAME WITH WHEEL AXLE - FRAME 5950	10
0511056828	FRAME WHIT ARTICULATION	11
0511056015	RIGHT FRAME WITH WHEEL AXLE - FRAME 6850	12
0511056829	LEFT FRAME WITH WHEEL AXLE - FRAME 6850	13
0511058667	SPRING FLOW ENSEMBLY	14
0511056529	CYLINDER ASSY	15
0511058406	HYDRAULIC CYLINDER	16
0521043934	CARRYING WHEELS SPRING TRACTION	17
0501058240	WHELL FASTENER WITH STRETCHER	18
0501058243	STRETCHER INTERMEDIATE RODE CURRENT	19
0501058244	STRETCHER FIXED CURRENT	20
0501058242	MOVIL CHAIN TENSIONER	21
0501059909	CARRYING WHEELS SUPPORT	22
0511048532	WHEELS SPRING WITHOUT TRANSMISSION	23
0501059910	WHEELED SUPPORT WITHOUT TRANSMISSION	24
0511052770	WHEEL WITH TIRE 7.00X16 ASSY WHEELED BOX	25
0511052769	WHEEL TRANSMISSION WITHOUT TIRE	26
0511056740	RIGHT TRANSMISSION ASSY - 4880	27
0511056530	RIGHT TRANSMISSION ASSY - 5340	28
0511056790	RIGHT TRANSMISSION ASSY - 5950	29
0511059306	RIGHT TRANSMISSION ASSY - 6850	30
0511056741	LEFT TRANSMISSION ASSEMBLY - 4880	31
0511056531	LEFT TRANSMISSION ASSEMBLY - 5340	32
0511056791	LEFT TRANSMISSION ASSEMBLY - 5950	33
0511059307	LEFT TRANSMISSION ASSEMBLY - 6850	34
0501052560	AXLE MOTOR SLOW-MOVING ASSY	35
0511051434	TRANSMISSION DRIVING ASSY	36
0511047069	SIDE TRANSMISSION DRIVING	37
0511047070	LH SIDE TRANSMISSION DRIVING	38
0521043316	RIGHT GEAR BOX ASSY	39
0501058212	SEMI MOUNTED RIGHT CHANGE	40
0521043317	LEFT GEAR BOX ASSY	41
0501058213	LH GEAR BOX	42
0511059266	CLOSED BEARING	43
0501056271	BEARING CLOSED	44
0501056443	BEARING ASSY GEAR BOX	45
0501056444	BEARING WITH ROLLING	46
0501048790	AXLE WITH LINK ASSY	47
0501054655	CHAIN TENSIONER ASSY	48
0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	49
0511054363	CHAIN TENSIONER	50
0501058234	LOWER CHAIN TENSIONER	51
0521055207	TOP CURRENT STRETCHER	52
0501058236	BEARING WITH 21Z GEAR	53
0501058237	16Z GEAR BEARING	54
0501055112	MICRO GRANULATED CHAIN TENSIONER	55



MARCHESAN

INDEX

0511056744	SET FERTILIZER SILO	56
0511056747	RH BEAM SUPPORT	57
0511056748	LH BEAM SUPPORT	58
0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	59
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	60
0511056533	SET FERTILIZER SILO	61
0511056350	RH BEAM SUPPORT PST DUO/F 11E500	62
0511056351	LH BEAM SUPPORT PST DUO/F 11E500	63
0511056792	SET FERTILIZER SILO	64
0511051932	RH BEAM SUPPORT	65
0511051933	LH BEAM SUPPORT	66
0511056834	ASSY FERTILIZER SILO 6850	67
0511056745	LATFORM SET	68
0511056534	PLATFORM ASSY	69
0511056793	PLATFORM SET	70
0511056835	PLATFORM ASSY 6850	71
0511056746	HANDRAIL ASSY 4880	72
0511056535	HANDRAIL ASSY 5340	73
0511056794	HANDRAIL ASSY 5950	74
0511056836	HANDRAIL ASSY 6850	75
0511056536	ASSEMBLY LADDER	76
0909094295	HEADER ASSY	77
0511054601	FULL ARTICULATED TRACTOR HITCH	78
0521053311	RIGHT EXTENSOR HEAD 36,00 - 4880/5720/5950	79
0521053312	RIGHT EXTENSOR HEAD 36,00 - 5340	80
0521053319	RIGHT EXTENSOR HEAD 36,00 - 6850	81
0521053310	LEFT EXTENSION HEADER 36.00 - 4880/5720/5950	82
0521053313	LEFT EXTENSION HEADER 36.00 - 5340	83
0521053318	LEFT EXTENSION HEADER 36.00 - 6850	84
0511052311	3 POINT TURNBUCKLE	85
0511056736	HOSE SUPPORT	86
0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	87
0511056532	ASSY SYSTEM HYDRAULIC 5340	88
0511056832	ASSY SYSTEM HYDRAULIC 6850	89
0501054649	SEQUENTIAL VALVE ASSY	90
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	91
0511056743	SEMI MOUNTED HYDRAULIC MARKER 4880	92
0511056735	SEMI MOUNTED HYDRAULIC MARKER 5340	93
0511056789	SEMI MOUNTED HYDRAULIC MARKER 5720/5950	94
0511056833	SEMI MOUNTED HYDRAULIC MARKER 6850	95
0511058449	HYDRAULIC CYLINDER	96
0511054971	RESTING ASSEMBLY	97
0511056538	ASSY PORT MANUAL INSTRUCCION	98
0909098691	SEED/FERTILIZER ROW ASSY	99
0511058790	SHORT SEED LINE CSU	100
0511059123	SHORT SEED LINE	101
0521053324	SEED HIGH SHORT LINE CSU	102
0521053110	LINE SEED HIGH SHORT HUB HIGH CSU	103
0521053472	LINE SEED SHORT HUB HIGH	104
0511058791	LONG SEED LINE CSU	105
0511059125	LONG SEED LINE	106
0521053325	SEED LONG HIGH LINE CSU	107
0521053109	SEED HIGH LINE LONG HUB HIGH	108
0521053473	HIGH CUBE LONG SEED LINE	109
0511058796	SHORT LEFT FERTILIZER LINE DDD	110



MARCHESAN

INDEX


0511059469	SHORT LEFT FERTILIZER LINE WITHOUT DDD	111
0521050203	RIGHT SHORT FERTILIZER LINE	112
0521053166	SHORT HIGH FERTILIZER LINE WITHOUT DDD / DC20	113
0521052636	DDD / DC20 HIGH LEFT FERTILIZER LINE	114
0521052812	SHORT HIGH FERTILIZER LINE DAOC/DC18	115
0511058798	SHORT LEFT FERTILIZER LINE DDD/DC20	116
0511058797	RIGHT LONG FERTILIZER LINE DDD	117
0511059470	RIGHT LONG FERTILIZER LINE WITHOUT DDD	118
0521050205	LEFT LONG FERTILIZER LINE	119
0521053165	LONG HIGH FERTILIZER LINE WITHOUT DDD / DC20	120
0521052637	DDD / DC20 RIGHT HIGH RIGHT FERTILIZER LINE	121
0521052813	LONG HIGH FERTILIZER LINE	122
0511058799	RIGHT LONG FERTILIZER LINE DDD DC20	123
0511056600	FRONT LINE SEED SHORT DDD RIGHT	124
0511056601	LONG SEED ROW FRONT DDD LEFT	125
0521052654	FRONT LINE SEED SHORT DDD RIGHT HIGH CUBE	126
0521052655	FRONT LINE SEED LONG DDD LEFT HIGH CUBE	127
0511051693	BASE FIXING SYSTEM	128
0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	129
0511056586	15 X 15 SEED DDD LEFT	130
0511052301	SUPPORT DDD 15 RIGHT	131
0511052302	LH SUPPORT DDD GUIDE	132
0511053173	CUBE LOW RIGHT WITH DISC 15	133
0511053172	LEFT LOW CUBE WITH DISC 15	134
0521052840	SHORT PIVOTING HIGH LINE	135
0521052841	LONG PIVOTANT HIGH LINE	136
0521052847	HIGH LINE PIVOTED SHORT HUB HIGH	137
0521052848	HIGH LINE PIVOTED SHORT HUB HIGH	138
0511059244	ROD SPRING LINE SEED	139
0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	140
0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	141
0511052024	FAST CLOSING SET	142
0511059023	SEED SYSTEM ASSY	143
0501051094	SEED DISTRIB ASSY WITH DOUB PULLEY	144
0501051119	DOUBLE PULLEY ROCKER'S	145
0501059631	DDD SEED 15" X 15" RIGHT	146
0501059632	DDD SEED 15X15 LEFT	147
0501054167	BOX DDD ASSY DPL 15 RIGHT	148
0501054168	BOX DDD ASSY DPL 15 LEFT	149
0511053250	SHORT ARM FERTILIZER LINE WITH DDD LEFT	150
0511053251	ARM LONG FERTILIZER LINE WITH DDD RIGHT	151
0521053151	ARM LONG FERTILIZER LINE WITH DDD RIGHT	152
0521053152	ARM SHORT LINE FERTILIZER WITH DDD LEFT	153
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	154
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	155
0511058617	DISC CUT 18 SHORT LINE	156
0511058618	DISC CUT 18 LONG LINE	157
0511058619	DISC CUT 20 SHORT LINE	158
0511058620	DISC CUT 20 LONG LINE	159
0511056910	BOX WITH DISC CUT 18	160
0511058648	BOX WITH DISC BLADE 20"	161
0511056909	DISC BOX CUT WITHOUT THE DISC	162
0501058423	FERTILIZER ROD SPRING ROW	163
0521050169	DAOC 18 RIGHT WITH NOZZLE	164
0521050170	DAOC 18 LEFT WITH NOZZLE	165



MARCHESAN

INDEX

0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	166
0511059218	RIGHT SUPPORT	167
0511059219	LEFT SUPPORT	168
0521052838	RIGHT SUPPORT DOC18	169
0521052839	LEFT SUPPORT DOC18	170
0511059229	BOX WITH DOC 18 TURBO RIGHT	171
0511059230	BOX WITH DOC 18 TURBO LEFT	172
0521050168	MOUNTED FERTILIZER CONDUCTOR	173
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	174
0511058650	SEMI-MOUNTED DEPTH CONTROL	175
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	176
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	177
0501052627	ASSY DEPTH WHEEL BOX	178
0501052297	DEPTH WHEELS REGULATOR ASSY	179
0501052538	DEPTH BAND WITH ARMS	180
0511054333	COMPACT WHEEL RIGHT WITH BEARING	181
0511054334	COMPACT WHEEL LEFT WITH BEARING	182
0501052908	COMPACTOR WHEEL WITH BEARING	183
0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	184
0511052971	CONTROL DEPTH WITH SEMI MOUNTED THREAD	185
0511059325	LEFT ARM WHEELS	186
0511059324	RIGHT ARM COATING WHEEL MOUNTED	187
0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	188
0511051546	CUBE RIGHT CONTROL DEPTH	189
0511051547	LEFT CUBE CONTROL DEPTH	190
0511051583	DEPTH WHEEL HUB SEMIFINISHED	191
0511055819	DEPTH WHIT AROS BAND	192
0501110231	SCARIFIER HEAD WITH SPIKE 0061	193
0501050120	LARGER WALKING BEAM ASSY	194
0511059410	HDA BC	195
0511059396	SCARIFIER SPINDLE WITH POINT	196
0521050525	FIXER FERTILIZER CONDUCTOR	197
0521052631	HDA HIGH AUTOMATIC DISARM	198
0521050364	ROD WITH BEAK	199
0501110865	ROD WITH BEAK HDA	200
0501110804	ROD SCARIFIER SPINDLE WIHT POINT	201
0501050633	MARKER DISC ASSY LINE	203
0511053904	DISC LINE MARKER	204
0909098671	ASSY HEX AXLE	205
0511058997	ASSEMBLY CSU	206
0511058996	ASSEMBLY CSU	207
0511059072	ASSEMBLY CSU C3 SEMI MOUNTED 5340	208
0511057919	ASSEMBLY CSU C3 2 BOXES 7B WITH 11 5340	209
0511058628	ASSEMBLY CSU C3 SEMI MOUNTED 5720/5950	210
0511058802	ASSEMBLY CSU C3 2 BOXES 7B WITH 13 C 5720/6350	211
0511059479	ASSEMBLY CSU C3 SEMI MOUNTED 6850	212
0511059478	ASSEMBLY CSU C3 2 BOXES 7B WITH 14	213
0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	214
0521052687	RH SUPPORT TOWER SILO	215
0521051931	LH SUPPORT TOWER SILO	216
0521051927	TOWER SUPPORT HOPPER	217
0521053407	MONITORING ASSEMBLY PLANTING SEEDS 13L PM400	218
0511052679	MONITORING ASSEMBLY PLANTING SEEDS 11L PM100	219




Item	Code	Description	See page	4880	5340	5950	6850
01	0511056545	CHASSI COM ARTICULATION	2	001	000	000	000
01.	0511056737	ARTICULATED FRAME - FRAME 5340	5	000	001	000	000
01..	0511056787	FRAME WHIT ARTICULATION	8	000	001	000	000
01...	0511056828	FRAME WHIT ARTICULATION	11	000	000	001	000
02	0521064285	LOCK LOWER FRAME		001	001	001	001
03	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		001	001	001	001
04	0511058667	SPRING FLOW ENSEMBLY	14	001	001	001	001
05	0503010002	1800 GREASE FITTING		001	001	001	001
06	0503010003	1845 GREASE FITTING		002	002	002	002
07	0503010004	1890 GREASE FITTING		005	002	002	002
08	0511056529	CYLINDER ASSY	15	001	001	001	001
09	0521043934	CARRYING WHEELS SPRING TRACTION	17	004	004	004	004
10	0511048532	WHEELS SPRING WITHOUT TRANSMISSION	23	000	000	002	002
11	0511056740	RIGHT TRANSMISSION ASSY - 4880	27	001	000	000	000
11.	0511056530	RIGHT TRANSMISSION ASSY - 5340	28	000	001	000	000
11..	0511056790	RIGHT TRANSMISSION ASSY - 5950	29	000	000	001	000
11...	0511059306	RIGHT TRANSMISSION ASSY - 6850	30	000	000	000	001
12	0511056741	LEFT TRANSMISSION ASSEMBLY - 4880	31	001	000	000	000
12.	0511056531	LEFT TRANSMISSION ASSEMBLY - 5340	32	000	001	000	000
12..	0511056791	LEFT TRANSMISSION ASSEMBLY - 5950	33	000	000	001	000
12...	0511059307	LEFT TRANSMISSION ASSEMBLY - 6850	34	000	000	000	001
13	0511056744	SET FERTILIZER SILO	56	001	000	000	000
13.	0511056533	SET FERTILIZER SILO	61	000	001	000	000
13..	0511056792	SET FERTILIZER SILO	64	000	000	001	000
13...	0511056834	ASSY FERTILIZER SILO 6850	67	000	000	000	001
14	0511056745	LATFORM SET	68	001	000	000	000
14.	0511056534	PLATFORM ASSY	69	000	001	000	000
14..	0511056793	PLATFORM SET	70	000	000	001	000
14...	0511056835	PLATFORM ASSY 6850	71	000	000	000	001
15	0511056746	HANDRAIL ASSY 4880	72	001	000	000	000
15.	0511056535	HANDRAIL ASSY 5340	73	000	001	000	000


FRAME ASSY

0909098690


Item	Code	Description	See page	4880	5340	5950	6850
15..	0511056794	HANDRAIL ASSY 5950	74	000	000	001	000
15...	0511056836	HANDRAIL ASSY 6850	75	000	000	000	001
16	0511056536	ASSEMBLY LADDER	76	002	002	002	002
17	0909094295	HEADER ASSY	77	001	001	001	001
18	0501047895	ROD STOP		002	002	002	002
19	0501047885	ROD STOP		002	002	002	002
20	0501047886	ROD STOP		002	002	002	002
21	0501047887	ROD STOP		002	002	002	002
22	0521013022	TRANSPORT LOCK		002	002	002	002
23	0501068994	0.3" X 3.1"LOCK PIN		002	002	002	002
24	0503030168	HAIR PIN		002	002	002	002
25	0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	87	001	000	001	000
25..	0511056532	ASSY SYSTEM HYDRAULIC 5340	88	000	001	000	000
25...	0511056832	ASSY SYSTEM HYDRAULIC 6850	89	000	000	000	001
26	0511056743	SEMI MOUNTED HYDRAULIC MARKER 4880	92	001	000	000	000
26..	0511056735	SEMI MOUNTED HYDRAULIC MARKER 5340	93	000	001	000	000
26...	0511056789	SEMI MOUNTED HYDRAULIC MARKER 5720/5950	94	000	000	001	000
26...	0511056833	SEMI MOUNTED HYDRAULIC MARKER 6850	95	000	000	000	001
27	0511054971	RESTING ASSEMBLY	97	001	001	001	001
28	0511056538	ASSY PORT MANUAL INSTRUCCION	98	001	001	001	001
29	0909098691	SEED/FERTILIZER ROW ASSY	99	001	001	001	001
30	0501065677	STRUT		002	002	002	002
31	0503032624	SILO FERTILIZER GUTTER		006	006	006	006
32	0501050633	MARKER DISC ASSY LINE	203	002	002	002	002
33	0541015451	FIXED KEY 2.3/8 X 2.3/4		001	001	001	001
34	0909098671	ASSY HEX AXLE	205	001	001	001	001
35	0511058997	ASSEMBLY CSU	206	001	000	000	000
35..	0511059072	ASSEMBLY CSU C3 SEMI MOUNTED 5340	208	000	001	000	000
35...	0511058628	ASSEMBLY CSU C3 SEMI MOUNTED 5720/5950	210	000	000	001	000
35...	0511059479	ASSEMBLY CSU C3 SEMI MOUNTED 6850	212	000	000	000	001
36	0521053407	MONITORING ASSEMBLY PLANTING SEEDS 13L PM400	218	000	000	001	000
37	0511052679	MONITORING ASSEMBLY PLANTING SEEDS 11L PM100	219	001	000	000	000




Item	Code	Description	See page	QT
001	0511056546	RIGHT FRAME WITH WHEEL AXLE - FRAME 4880	3	01
002	0511056738	LEFT FRAME WITH WHEEL AXLE - FRAME 4880	4	01
003	0501110791	DRIVER WHEEL HUB		01
004	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		01
005	0503011442	3/4" SPRING WASHER		09
006	0501010098	3/4" UNC BOLT		09
007	0571010094	SLEEVE FLANGE		02
008	0521065616	ARTICULATION		01
009	0502012698	CLAMP		02
010	0503011444	SPRING WASHER		02
011	0571013510	LOCK AXLE		01
012	0503030085	LOCK PIN		01
013	0571010095	FLAT WASHER		01
014	0521063003	LOCK PIN		01
015	0571010969	LOCK SLEEVE FRAME		01
016	0503013627	1.1/2 SPRING WASHER		01
017	0501010110	1.1/2" NUT		01
018	0503010365	NUT		02
019	0501018059	3/4" X 2-1/4" BOLT		03
020	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
001	0521065512	CH RIGHT		01
002	0521063930	PIVOT SHAFT		01
003	0521013199	LOWER BEARING SEMI		03
004	0503010899	5/8" X 2-1/4" BOLT		06
005	0531013922	0.6" X 0.8" X 1" SLEEVE		06
006	0503010013	5/8" NUT		06
007	0503011445	SPRING WASHER		06
008	0501012140	FLAT WASHER		12




Item	Code	Description	See page	QT
001	0521065632	CH LEFT		01
002	0521063929	CARRYING-WHEELS PIVOT SHAFT		01
003	0521013199	LOWER BEARING SEMI		03
004	0503010899	5/8" X 2-1/4" BOLT		06
005	0531013922	0.6" X 0.8" X 1" SLEEVE		06
006	0503010013	5/8" NUT		06
007	0503011445	SPRING WASHER		06
008	0501012140	FLAT WASHER		12




Item	Code	Description	See page	QT
001	0511056347	RIGHT FRAME WITH WHEEL AXLE - FRAME 5340	6	01
002	0511056739	LEFT FRAME WITH WHEEL AXLE - FRAME 5340	7	01
003	0501110791	DRIVER WHEEL HUB		01
004	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		01
005	0503011442	3/4" SPRING WASHER		09
006	0501010098	3/4" UNC BOLT		09
007	0571010094	SLEEVE FLANGE		02
008	0521065616	ARTICULATION		01
009	0502012698	CLAMP		02
010	0503011444	SPRING WASHER		02
011	0571013510	LOCK AXLE		01
012	0503030085	LOCK PIN		01
013	0571010095	FLAT WASHER		01
014	0521063003	LOCK PIN		01
015	0571010969	LOCK SLEEVE FRAME		01
016	0503013627	1.1/2 SPRING WASHER		01
017	0501010110	1.1/2" NUT		01
018	0503010365	NUT		02
019	0501018059	3/4" X 2-1/4" BOLT		03
020	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
001	0521068944	RIGHT FRAME 5340		01
002	0521063930	PIVOT SHAFT		01
003	0521013199	LOWER BEARING SEMI		03
004	0503010899	5/8" X 2-1/4" BOLT		06
005	0531013922	0.6" X 0.8" X 1" SLEEVE		06
006	0503010013	5/8" NUT		06
007	0503011445	SPRING WASHER		06
008	0501012140	FLAT WASHER		12




Item	Code	Description	See page	QT
001	0521068945	LEFT FRAME 5340		01
002	0521065391	CARRYING-WHEELS PIVOT SHAFT		01
003	0521013199	LOWER BEARING SEMI		03
004	0503010899	5/8" X 2-1/4" BOLT		06
005	0531013922	0.6" X 0.8" X 1" SLEEVE		06
006	0503010013	5/8" NUT		06
007	0503011445	SPRING WASHER		06
008	0501012140	FLAT WASHER		12




Item	Code	Description	See page	QT
001	0511056786	RIGHT FRAME WITH WHEEL AXLE - FRAME 5950	9	01
002	0511056785	LEFT FRAME WITH WHEEL AXLE - FRAME 5950	10	01
003	0501110791	DRIVER WHEEL HUB		01
004	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		01
005	0503011442	3/4" SPRING WASHER		09
006	0501010098	3/4" UNC BOLT		09
007	0571010094	SLEEVE FLANGE		02
008	0521065616	ARTICULATION		01
009	0502012698	CLAMP		02
010	0503010365	NUT		02
011	0503011444	SPRING WASHER		02
012	0571013510	LOCK AXLE		01
013	0503030085	LOCK PIN		01
014	0571010095	FLAT WASHER		01
015	0521063003	LOCK PIN		01
016	0571010969	LOCK SLEEVE FRAME		01
017	0503013627	1.1/2 SPRING WASHER		01
018	0501010110	1.1/2" NUT		01




Item	Code	Description	See page	QT
001	0521065639	CH RIGHT		01
002	0521063938	CARRYING-WHEELS PIVOT SHAFT		01
003	0521013199	LOWER BEARING SEMI		03
004	0503010899	5/8" X 2-1/4" BOLT		06
005	0531013922	0.6" X 0.8" X 1" SLEEVE		06
006	0503010013	5/8" NUT		06
007	0503011445	SPRING WASHER		06
008	0501012140	FLAT WASHER		12




Item	Code	Description	See page	QT
001	0521065634	CH LEFT		01
002	0521063937	PIVOT SHAFT		01
003	0521013199	LOWER BEARING SEMI		03
004	0503010899	5/8" X 2-1/4" BOLT		06
005	0531013922	0.6" X 0.8" X 1" SLEEVE		06
006	0503010013	5/8" NUT		06
007	0503011445	SPRING WASHER		06
008	0501012140	FLAT WASHER		12




Item	Code	Description	See page	QT
01	0511056015	RIGHT FRAME WITH WHEEL AXLE - FRAME 6850	12	01
02	0511056829	LEFT FRAME WITH WHEEL AXLE - FRAME 6850	13	01
03	0501110791	DRIVER WHEEL HUB		01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		01
05	0503011442	3/4" SPRING WASHER		09
06	0501010098	3/4" UNC BOLT		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	NUT		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0501018059	3/4" X 2-1/4" BOLT		03
20	0503011255	3/4" LOCK NUT		03



Item	Code	Description	See page	QT
001	0521065194	RH FRAME 15		01
002	0521065188	CARRYING-WHEELS PIVOT SHAFT		01
003	0521013199	LOWER BEARING SEMI		03
004	0503010899	5/8" X 2-1/4" BOLT		06
005	0531013922	0.6" X 0.8" X 1" SLEEVE		06
006	0503010013	5/8" NUT		06
007	0503011445	SPRING WASHER		06
008	0501012140	FLAT WASHER		12




Item	Code	Description	See page	QT
01	0521068951	LEFT FRAME 6850		01
02	0521065189	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0531013922	0.6" X 0.8" X 1" SLEEVE		06
06	0503010013	5/8" NUT		06
07	0503011445	SPRING WASHER		06
08	0501012140	FLAT WASHER		12




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		06
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		12
03	0501012140	FLAT WASHER		24

CYLINDER ASSY


0511056529




Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	16	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521012536	COUPLING SHAFT		02
04	0503010523	1/4" X 2" COTTERPIN		04
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01




Item	Code	Description	See page	QT
01	0501058240	WHELL FASTENER WITH STRETCHER	18	01
02	0503011119	7/8" X 6" BOLT		04
03	0501014251	FLAT WASHER		04
04	0503011254	7/8" HEX SELF ADJUSTING NUT		04
05	0501059909	CARRYING WHEELS SUPPORT	22	01
06	0503014887	2050 CHAIN X 80 LINK + REDUCTION		01
07	0502010584	CARRYING-WHEELS SUPPORT FIXER		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	STRETCHER INTERMEDIATE RODE CURRENT	19	01
07	0501058244	STRETCHER FIXED CURRENT	20	01
08	0501058242	MOVIL CHAIN TENSIONER	21	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	CHAIN TENSIONER BEARING		01
02A	0503012882	BEARING		01
02B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02C	0502012853	GEAR		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TIGHTENER AXLE		01
02	0501058239	CHAIN TENSIONER BEARING		01
02A	0503012882	BEARING		01
02B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02C	0502012853	GEAR		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN UPPER AXLE		01
02	0501058239	CHAIN TENSIONER BEARING		01
02A	0503012882	BEARING		01
02B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02C	0502012853	GEAR		01
03	0551018240	SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0531016887	CARRYING WHEEL AXLE ARM		01
03	0503010523	1/4" X 2" COTTERPIN		01
04	0503010003	1845 GREASE FITTING		01
05	0511050681	TRACTION SPRING		01
05A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
05B	0561016062	SPRING HITCH		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		04
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0511052770	WHEEL WITH TIRE 7.00X16 ASSY WHEELED BOX	25	01
11	0581011124	WHEELED COVER		01
12	0521012190	AXLE LOCK		01
13	0503011167	M16 X 2 X 30 BOLT		02
14	0501058241	TENSIONER CHAIN SUPPORT		01
15	0521061565	WHEEL SUPPORT ARM		01




Item	Code	Description	See page	QT
01	0501059910	WHEELED SUPPORT WITHOUT TRANSMISSION	24	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521061565	WHEEL SUPPORT ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511052770	WHEEL WITH TIRE 7.00X16 ASSY WHEELED BOX	25	01
07	0521012190	AXLE LOCK		02
08	0503010027	5/8" SPRING WASHER		02
09	0503011167	M16 X 2 X 30 BOLT		02



Item	Code	Description	See page	QT
01	0503062159	WHEEL		01
02	0511052769	WHEEL TRANSMISSION WITHOUT TIRE	26	01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSM AXLE CARRYING-WHEEL		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	35	01
15	0511051434	TRANSMISSION DRIVING ASSY	36	02
16	0511047069	SIDE TRANSMISSION DRIVING	37	01
17	0521043316	RIGHT GEAR BOX ASSY	39	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	50	01
26	0501058234	LOWER CHAIN TENSIONER	51	01
27	0521055207	TOP CURRENT STRETCHER	52	01
28	0501058236	BEARING WITH 21Z GEAR	53	01
29	0501058237	16Z GEAR BEARING	54	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	55	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01




Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0571017428	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	35	01
15	0511051434	TRANSMISSION DRIVING ASSY	36	02
16	0511047069	SIDE TRANSMISSION DRIVING	37	01
17	0521043316	RIGHT GEAR BOX ASSY	39	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	50	01
26	0501058234	LOWER CHAIN TENSIONER	51	01
27	0521055207	TOP CURRENT STRETCHER	52	01
28	0501058236	BEARING WITH 21Z GEAR	53	01
29	0501058237	16Z GEAR BEARING	54	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	55	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01


Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503030303	SUPPORT WASHER		01
35	0501010984	FLAT WASHER		01
36	0503010025	3/8" SPRING WASHER		01
37	0501010637	FLAT WASHER		01
38	0503010256	3/8" X 3/4" BOLT		01



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0571011442	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	35	01
15	0511051434	TRANSMISSION DRIVING ASSY	36	02
16	0511047069	SIDE TRANSMISSION DRIVING	37	01
17	0521043316	RIGHT GEAR BOX ASSY	39	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	50	01
26	0501058234	LOWER CHAIN TENSIONER	51	01
27	0521055207	TOP CURRENT STRETCHER	52	01
28	0501058236	BEARING WITH 21Z GEAR	53	01
29	0501058237	16Z GEAR BEARING	54	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	55	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01




Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0571017032	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	35	01
15	0511051434	TRANSMISSION DRIVING ASSY	36	02
16	0511047069	SIDE TRANSMISSION DRIVING	37	01
17	0521043316	RIGHT GEAR BOX ASSY	39	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	50	01
26	0501058234	LOWER CHAIN TENSIONER	51	01
27	0521055207	TOP CURRENT STRETCHER	52	01
28	0501058236	BEARING WITH 21Z GEAR	53	01
29	0501058237	16Z GEAR BEARING	54	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	55	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503030303	SUPPORT WASHER		01
35	0501010984	FLAT WASHER		01
36	0503010025	3/8" SPRING WASHER		01
37	0501010637	FLAT WASHER		01
38	0503010256	3/8" X 3/4" BOLT		01



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	35	01
15	0511051434	TRANSMISSION DRIVING ASSY	36	02
16	0511047070	LH SIDE TRANSMISSION DRIVING	38	01
17	0521043317	LEFT GEAR BOX ASSY	41	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	50	01
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	55	01
27	0501058234	LOWER CHAIN TENSIONER	51	01
28	0521055207	TOP CURRENT STRETCHER	52	01
29	0501058236	BEARING WITH 21Z GEAR	53	01
30	0501058237	16Z GEAR BEARING	54	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0571017428	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	35	01
15	0511051434	TRANSMISSION DRIVING ASSY	36	02
16	0511047070	LH SIDE TRANSMISSION DRIVING	38	01
17	0521043317	LEFT GEAR BOX ASSY	41	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	50	01
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	55	01
27	0501058234	LOWER CHAIN TENSIONER	51	01
28	0521055207	TOP CURRENT STRETCHER	52	01
29	0501058236	BEARING WITH 21Z GEAR	53	01
30	0501058237	16Z GEAR BEARING	54	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01

LEFT TRANSMISSION ASSEMBLY - 5340

0511056531


Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503030303	SUPPORT WASHER		01
35	0501010984	FLAT WASHER		01
36	0503010025	3/8" SPRING WASHER		01
37	0501010637	FLAT WASHER		01
38	0503010256	3/8" X 3/4" BOLT		01



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0571011442	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	35	01
15	0511051434	TRANSMISSION DRIVING ASSY	36	02
16	0511047070	LH SIDE TRANSMISSION DRIVING	38	01
17	0521043317	LEFT GEAR BOX ASSY	41	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	50	01
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	55	01
27	0501058234	LOWER CHAIN TENSIONER	51	01
28	0521055207	TOP CURRENT STRETCHER	52	01
29	0501058236	BEARING WITH 21Z GEAR	53	01
30	0501058237	16Z GEAR BEARING	54	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01



Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0571017032	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	35	01
15	0511051434	TRANSMISSION DRIVING ASSY	36	02
16	0511047070	LH SIDE TRANSMISSION DRIVING	38	01
17	0521043317	LEFT GEAR BOX ASSY	41	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	50	01
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	55	01
27	0501058234	LOWER CHAIN TENSIONER	51	01
28	0521055207	TOP CURRENT STRETCHER	52	01
29	0501058236	BEARING WITH 21Z GEAR	53	01
30	0501058237	16Z GEAR BEARING	54	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01


LEFT TRANSMISSION ASSEMBLY - 6850

0511059307


Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503030303	SUPPORT WASHER		01
35	0501010984	FLAT WASHER		01
36	0503010025	3/8" SPRING WASHER		01
37	0501010637	FLAT WASHER		01
38	0503010256	3/8" X 3/4" BOLT		01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	5/16" X 3/4" BOLT		02
03	0503010179	5/16" ZN SPRING WASHER		02
04	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER	01	
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
03	0503010060	1/2" NUT	01	
04	0521017590	GUIDE AXLE	01	
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING	01	
06	0502012009	DRIVING AXLE RIGHT FOLLOWER	01	
07	0501019734	FLAT WASHER	02	
08	0502010710	RIGHT CAM, SMALLER	02	
09	0503010003	1845 GREASE FITTING	02	
10	0502012539	26Z P12,7 GEAR	01	
11	0501019735	FLAT WASHER	01	
12	0521017593	FLAT WASHER	01	
13	0503010542	501045 CLAMPING RING (FOR AXLE)	01	




Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY

0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	40	01
02	0511059266	CLOSED BEARING	43	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	BEARING ASSY GEAR BOX	45	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH LINK ASSY	47	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	48	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	49	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01



Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX	01	
02	0502011758	REAR TENSIONER LEVER	02	
03	0503010292	0.2" X 1.6" SPRING PIN	02	
04	0511061794	CHAIN TENSIONER	01	
05	0503031367	SPRING	01	
06	0511060392	CHAIN TENSIONER	01	
07	0503031366	RIGHT TWISTED SPRING RECAMBIO	01	

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	42	01
02	0511059266	CLOSED BEARING	43	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	BEARING ASSY GEAR BOX	45	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH LINK ASSY	47	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	48	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	49	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LH GEAR BOX


0501058213




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0501056271	BEARING CLOSED	44	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	46	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
05	0503010179	5/16" ZN SPRING WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503019355	BEARING 6202 2RS1		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0551019173	CHAIN SLEEVE TENSIONER		01
05	0511017302	FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01



Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019174	DOBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01



Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
001	0511056747	RH BEAM SUPPORT	57	01
002	0511056748	LH BEAM SUPPORT	58	01
003	0503010849	3/8" X 1-1/2" BOLT		12
004	0501010984	FLAT WASHER		24
005	0503010025	3/8" SPRING WASHER		12
006	0503010026	3/8" NUT		12
007	0503034396	FERTILIZER SIDE COVER		12
008	0503010362	1/8" X 1.1/4" COTTERPIN		12
009	0503062169	SILO FERTILIZER 6 MOUTHS MOUNTED		02
010	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
011	0503010849	3/8" X 1-1/2" BOLT		08
012	0501010984	FLAT WASHER		16
013	0503010025	3/8" SPRING WASHER		08
014	0503010026	3/8" NUT		08
015	0551019156	GEAR BOX LEVER LOCK		02
016	0503011953	5/16" X 1" BOLT		04
017	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
018	0503010179	5/16" ZN SPRING WASHER		04
019	0503010337	5/16" NUT		04
020	0503010847	1/2" X 3.1/4" BOLT		02
021	0551019168	SLEEVE		02
022	0551019160	LEVER		02
023	0511017302	FLAT WASHER		02
024	0503010019	1/2" SPRING WASHER		02
025	0503010060	1/2" NUT		02
026	0551019167	SLEEVE UNION		02
027	0511069676	INNER LEVER		02
028	0511017302	FLAT WASHER		02
029	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
030	0511017302	FLAT WASHER		02
031	0503010019	1/2" SPRING WASHER		02


SET FERTILIZER SILO

0511056744


Item	Code	Description	See page	QT
032	0503010060	1/2" NUT		02
033	0501013518	FLAT WASHER		02
034	0503010140	1/8" X 3/4" COTTERPIN		02
035	0511069678	LH LOWER LEVER		02
036	0503013357	3/8" SELF-ADJUSTING NUT		02
037	0503010140	1/8" X 3/4" COTTERPIN		04
038	0551019159	LEVER FIXER BODY		02
039	0561016468	FASTENER		02
040	0503011336	1/2" HEX SELF ADJUSTING NUT		04
041	0551019115	LOCKING PLATFORM FIXATION		02
042	0501010096	3/8" X 2" BOLT		02
043	0501010984	FLAT WASHER		02




Item	Code	Description	See page	QT
001	0521065561	FERTILIZER BEAN RIGHT SUPPORT		01
002	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	59	04
003	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	60	02
004	0511061759	22Z P12,70 FQ 3/4" GEAR		01
005	0521014167	CONE LOCK		01
006	0503030275	AGRICULTURAL BEARING		06
007	1902010685	18Z CONICAL GEAR		06
008	0521010691	AXLE FASTENER		02
009	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
010	0503011441	SPRING WASHER		02
011	0503010144	1/4" NUT		02
012	0501110392	SILO SUPPORT BEARING		01
013	0551018055	22,65 X 60 SLEEVE		01
014	0571012299	SQUARE SHAFT		01
015	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
016	0521012485	GEAR BOX BEARING AGRICUTURAL		01
017	0503011953	5/16" X 1" BOLT		02
018	0521011039	FLAT WASHER		02
019	0503011444	SPRING WASHER		02
020	0503010337	5/16" NUT		02
021	0503010003	1845 GREASE FITTING		01
022	0501010942	3/8" X 1-1/4" BOLT		24
023	0503011443	3/8" SPRING WASHER		24
024	0503010026	3/8" NUT		24




Item	Code	Description	See page	QT
001	0521065562	LH FERTILIZER BOX SUPPORT		01
002	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	60	04
003	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	59	02
004	0571012299	SQUARE SHAFT		01
005	0501010942	3/8" X 1-1/4" BOLT		24
006	0503011443	3/8" SPRING WASHER		24
007	0503010026	3/8" NUT		24
008	0511061759	22Z P12,70 FQ 3/4" GEAR		01
009	0521014167	CONE LOCK		01
010	0503030275	AGRICULTURAL BEARING		06
011	1902010685	18Z CONICAL GEAR		06
012	0521010691	AXLE FASTENER		02
013	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
014	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
015	0503011441	SPRING WASHER		02
016	0503010144	1/4" NUT		02
017	0501110392	SILO SUPPORT BEARING		01
018	0521012485	GEAR BOX BEARING AGRICUTURAL		01
019	0503011953	5/16" X 1" BOLT		02
020	0521011039	FLAT WASHER		02
021	0503011444	SPRING WASHER		02
022	0503010337	5/16" NUT		02
023	0551018055	22,65 X 60 SLEEVE		01
024	0503010003	1845 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01



Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
001	0511056350	RH BEAM SUPPORT PST DUO/F 11E500	62	01
002	0511056351	LH BEAM SUPPORT PST DUO/F 11E500	63	01
003	0503010849	3/8" X 1-1/2" BOLT		12
004	0501010984	FLAT WASHER		24
005	0503010025	3/8" SPRING WASHER		12
006	0503010026	3/8" NUT		12
007	0503034396	FERTILIZER SIDE COVER		12
008	0503010362	1/8" X 1.1/4" COTTERPIN		12
009	0503060642	COVER BOX RIGHT FERTILIZER		02
009.	0503060643	COVER BOX LEFT FERTILIZER		02
010	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
011	0503010849	3/8" X 1-1/2" BOLT		08
012	0501010984	FLAT WASHER		16
013	0503010025	3/8" SPRING WASHER		08
014	0503010026	3/8" NUT		08
015	0551019156	GEAR BOX LEVER LOCK		02
016	0503011953	5/16" X 1" BOLT		04
017	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
018	0503010179	5/16" ZN SPRING WASHER		04
019	0503010337	5/16" NUT		04
020	0503010847	1/2" X 3.1/4" BOLT		02
021	0551019168	SLEEVE		02
022	0551019160	LEVER		02
023	0511017302	FLAT WASHER		02
024	0503010019	1/2" SPRING WASHER		02
025	0503010060	1/2" NUT		02
026	0551019167	SLEEVE UNION		02
027	0511069676	INNER LEVER		02
028	0511017302	FLAT WASHER		02
029	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
030	0511017302	FLAT WASHER		02


SET FERTILIZER SILO

0511056533

Item	Code	Description	See page	QT
031	0503010019	1/2" SPRING WASHER		02
032	0503010060	1/2" NUT		02
033	0501013518	FLAT WASHER		02
034	0503010140	1/8" X 3/4" COTTERPIN		02
035	0511069678	LH LOWER LEVER		02
036	0503013357	3/8" SELF-ADJUSTING NUT		02
037	0503010140	1/8" X 3/4" COTTERPIN		04
038	0551019159	LEVER FIXER BODY		02
039	0561016468	FASTENER		02
040	0503011336	1/2" HEX SELF ADJUSTING NUT		04
041	0551019115	LOCKING PLATFORM FIXATION		02
042	0501010096	3/8" X 2" BOLT		02
043	0501010984	FLAT WASHER		02




Item	Code	Description	See page	QT
001	0521065374	RH FERTILIZER BEAN SUPPORT PST DUO/F 11E500		01
002	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	59	04
003	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	60	02
004	0511061759	22Z P12,70 FQ 3/4" GEAR		01
005	0521014167	CONE LOCK		01
006	0503030275	AGRICULTURAL BEARING		06
007	1902010685	18Z CONICAL GEAR		06
008	0521010691	AXLE FASTENER		02
009	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
010	0503011441	SPRING WASHER		02
011	0503010144	1/4" NUT		02
012	0501110392	SILO SUPPORT BEARING		01
013	0551018055	22,65 X 60 SLEEVE		01
014	0571017429	SQUARE SHAFT		01
015	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
016	0521012485	GEAR BOX BEARING AGRICUTURAL		01
017	0503011953	5/16" X 1" BOLT		02
018	0521011039	FLAT WASHER		02
019	0503011444	SPRING WASHER		02
020	0503010337	5/16" NUT		02
021	0503010003	1845 GREASE FITTING		01
022	0501010942	3/8" X 1-1/4" BOLT		24
023	0503011443	3/8" SPRING WASHER		24
024	0503010026	3/8" NUT		24



Item	Code	Description	See page	QT
001	0521065375	LH FERTILIZER BEAM SUPPORT		01
002	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	59	04
003	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	60	02
004	0571017426	HEX AXLE		01
005	0501010942	3/8" X 1-1/4" BOLT		24
006	0503011443	3/8" SPRING WASHER		24
007	0503010026	3/8" NUT		24
008	0511061759	22Z P12,70 FQ 3/4" GEAR		01
009	0521014167	CONE LOCK		01
010	0503030275	AGRICULTURAL BEARING		06
011	1902010685	18Z CONICAL GEAR		06
012	0521010691	AXLE FASTENER		02
013	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
014	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
015	0503011441	SPRING WASHER		02
016	0503010144	1/4" NUT		02
017	0501110392	SILO SUPPORT BEARING		01
018	0521012485	GEAR BOX BEARING AGRICUTURAL		01
019	0503011953	5/16" X 1" BOLT		02
020	0521011039	FLAT WASHER		02
021	0503011444	SPRING WASHER		02
022	0503010337	5/16" NUT		02
023	0551018055	22,65 X 60 SLEEVE		01
024	0503010003	1845 GREASE FITTING		01

SET FERTILIZER SILO

0511056792




Item	Code	Description	See page	QT
001	0511051932	RH BEAM SUPPORT	65	01
002	0511051933	LH BEAM SUPPORT	66	01
003	0503010849	3/8" X 1-1/2" BOLT		28
004	0501010984	FLAT WASHER		60
005	0503010025	3/8" SPRING WASHER		28
006	0503010026	3/8" NUT		28
007	0503062018	FERTILIZER SILO SUPORT ASSY		02
008	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		02
009	0503010362	1/8" X 1.1/4" COTTERPIN		14
010	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		08
011	0551019156	GEAR BOX LEVER LOCK		02
012	0503011953	5/16" X 1" BOLT		04
013	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
014	0503010847	1/2" X 3.1/4" BOLT		02
015	0551019168	SLEEVE		02
016	0551019160	LEVER		02
017	0511017302	FLAT WASHER		06
018	0503010060	1/2" NUT		04
019	0551019167	SLEEVE UNION		02
020	0511069676	INNER LEVER		02
021	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
022	0501013518	FLAT WASHER		02
023	0503010179	5/16" ZN SPRING WASHER		04
024	0503010337	5/16" NUT		04
025	0503010019	1/2" SPRING WASHER		04
026	0503013357	3/8" SELF-ADJUSTING NUT		02
027	0501010096	3/8" X 2" BOLT		02
028	0551019115	LOCKING PLATFORM FIXATION		02
029	0503011336	1/2" HEX SELF ADJUSTING NUT		04
030	0511069679	RH UPPER LEVER		02
031	0503010140	1/8" X 3/4" COTTERPIN		06




SET FERTILIZER SILO

0511056792


Item	Code	Description	See page	QT
032	0511069678	LH LOWER LEVER		01
033	0511069677	RH LOWER LEVER		01
034	0561016468	FASTENER		02
035	0503034396	FERTILIZER SIDE COVER		14



Item	Code	Description	See page	QT
01	0521063171	RH FERTILIZER BOX SUPPORT		01
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	59	04
03	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	60	03
04	0501010942	3/8" X 1-1/4" BOLT		28
05	0503011443	3/8" SPRING WASHER		28
06	0503010026	3/8" NUT		28
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571011428	SQUARE SHAFT		01
09	0501053788	Q3/4" FASTENER AXLE ASSY		02
09.	0503010144	1/4" NUT		01
09A	0521010691	AXLE FASTENER		01
09B	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
09C	0511017303	FLAT WASHER		02
09D	0503010143	1/4" SPRING WASHER		01
10	0501110392	SILO SUPPORT BEARING		01
11	0521012485	GEAR BOX BEARING AGRICUTURAL		01
12	0503011953	5/16" X 1" BOLT		02
13	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
14	0503011444	SPRING WASHER		02
15	0503010337	5/16" NUT		02
16	0551018055	22,65 X 60 SLEEVE		01
17	0503010003	1845 GREASE FITTING		01
18	0521014167	CONE LOCK		01
19	0503030275	AGRICULTURAL BEARING		07
20	0503030303	SUPPORT WASHER		01
21	1902010685	18Z CONICAL GEAR		07




Item	Code	Description	See page	QT
001	0521063172	LH FERTILIZER BOX SUPPORT		01
002	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	59	03
003	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	60	04
004	0501010942	3/8" X 1-1/4" BOLT		28
005	0503011443	3/8" SPRING WASHER		28
006	0503010026	3/8" NUT		28
007	0511061759	22Z P12,70 FQ 3/4" GEAR		01
008	0571011428	SQUARE SHAFT		01
009	0501053788	Q3/4" FASTENER AXLE ASSY		02
009A	0521010691	AXLE FASTENER		01
009B	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
009C	0511017303	FLAT WASHER		02
009D	0503010143	1/4" SPRING WASHER		01
009E	0503010144	1/4" NUT		01
010	0501110392	SILO SUPPORT BEARING		01
011	0521012485	GEAR BOX BEARING AGRICUTURAL		01
012	0503011953	5/16" X 1" BOLT		02
013	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
014	0503011444	SPRING WASHER		02
015	0503010337	5/16" NUT		02
016	0551018055	22,65 X 60 SLEEVE		01
017	0503010003	1845 GREASE FITTING		01
018	0521014167	CONE LOCK		01
019	0503030275	AGRICULTURAL BEARING		07
020	0503030303	SUPPORT WASHER		01
021	1902010685	18Z CONICAL GEAR		07




Item	Code	Description	See page	QT
01	0511056834	ASSY FERTILIZER SILO 6850	67	01
01A	0511056012	RH BEAM SUPPORT		01
02	0521065197	RH FERTILIZER BOX SUPPORT		07
02A	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		07
02B	0501019851	DISTRIBUTOR FERTILIZER AXLE		14
02C	0521010309	SLEEVE INTER		14
02D	0503030275	AGRICULTURAL BEARING		42
02E	0503031164	RIGHT HELICAL CONDUTOR		07
02F	0501010637	FLAT WASHER		14
02G	0503030303	SUPPORT WASHER		14
02H	0501013774	GREASE SEAL		14
02I	0502011412	18Z CONICAL GEAR		14
02J	0503010523	1/4" X 2" COTTERPIN		14
02K	0503011962	GREASE FITTING		14
02L	0503010003	1845 GREASE FITTING		14
02M	0503012826	CREASE FITTING		14
03	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	60	07
03A	0501110676	SIDE FERTILIZER DISTRIBUTOR		07
03B	0503031165	LEFT HELICAL CONDUTOR		07
04	0501010942	3/8" X 1-1/4" BOLT		56
05	0503011443	3/8" SPRING WASHER		56
06	0503010026	3/8" NUT		56
07	0511061759	22Z P12,70 FQ 3/4" GEAR		02
08	0521014167	CONE LOCK		02
09	0502010685	18Z CONICAL GEAR		14
10	0551018200	SQUARE SHAFT		02
11	0521010691	AXLE FASTENER		04
12	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		04
13	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
14	0503011441	SPRING WASHER		04
15	0503010144	1/4" NUT		04


Item	Code	Description	See page	QT
16	0501110392	SILO SUPPORT BEARING		02
17	0521012485	GEAR BOX BEARING AGRICUTURAL		02
18	0503011953	5/16" X 1" BOLT		08
19	0501010694	8.5 X 18 X 1.5 FLAT WASHER		08
20	0521011039	FLAT WASHER		04
21	0503011444	SPRING WASHER		04
22	0503010337	5/16" NUT		08
23	0551018055	22,65 X 60 SLEEVE		02
24	0503010003	1845 GREASE FITTING		02
25	0511056013	LH BEAM SUPPORT		01
25A	0521065196	LH FERTILIZER BOX SUPPORT		01
26	0503010849	3/8" X 1-1/2" BOLT		28
27	0501010984	FLAT WASHER		56
28	0503010025	3/8" SPRING WASHER		28
29	0503010026	3/8" NUT		28
30	0503034396	FERTILIZER SIDE COVER		14
31	0503010362	1/8" X 1.1/4" COTTERPIN		14
32	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		04
33	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		08
34	0551019156	GEAR BOX LEVER LOCK		02
35	0503011953	5/16" X 1" BOLT		04
36	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
37	0503010179	5/16" ZN SPRING WASHER		02
38	0503010337	5/16" NUT		02
39	0503010847	1/2" X 3.1/4" BOLT		06
40	0551019168	SLEEVE		04
41	0551019160	LEVER		04
42	0511017302	FLAT WASHER		02
43	0503010019	1/2" SPRING WASHER		02
44	0503010060	1/2" NUT		02
45	0551019167	SLEEVE UNION		04
46	0511069676	INNER LEVER		06
47	0511069678	LH LOWER LEVER		01
48	0511069679	RH UPPER LEVER		02
49	0561016468	FASTENER		02
50	0503011336	1/2" HEX SELF ADJUSTING NUT		04
51	0551019115	LOCKING PLATFORM FIXATION		02
52	0501010096	3/8" X 2" BOLT		02
53	0501010984	FLAT WASHER		02
54	0503013357	3/8" SELF-ADJUSTING NUT		02
55	0503032624	SILO FERTILIZER GUTTER		07
56	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01
57	0501013518	FLAT WASHER		02
58	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
001	0511069661	PLATFORM SUPPORT PIVOT	04	
002	0503010849	3/8" X 1-1/2" BOLT	08	
003	0501010984	FLAT WASHER	16	
004	0503010025	3/8" SPRING WASHER	08	
005	0503010026	3/8" NUT	08	
006	0521062991	RIGHT PLATFORM	01	
007	0521062992	LEFT PLATFORM PST DUO 11/F	01	
008	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
009	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
010	0503011333	COVER FIXER	02	
011	0503010274	5/32"X 2" COTTERPIN	02	
012	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
013	0502012739	PLATFORM LEFT FIXER SUPPORT	01	
014	0571017990	PLATFORM ENHANCEMENT PROTECTION	01	
015	0501010942	3/8" X 1-1/4" BOLT	02	
016	0501010984	FLAT WASHER	02	
017	0503010025	3/8" SPRING WASHER	02	
018	0503010026	3/8" NUT	02	




Item	Code	Description	See page	QT
001	0511069661	PLATFORM SUPPORT PIVOT		04
002	0503010849	3/8" X 1-1/2" BOLT		08
003	0501010984	FLAT WASHER		18
004	0503010025	3/8" SPRING WASHER		10
005	0503010026	3/8" NUT		10
006	0521065381	RIGHT PLATFORM PST DUO/F 11 E500 S-0614		01
007	0521065382	LEFT PLATFORM PST DUO/F 11 E500 S-0614		01
008	0503011336	1/2" HEX SELF ADJUSTING NUT		04
009	0503011333	COVER FIXER		02
010	0503010274	5/32"X 2" COTTERPIN		02
011	0571017990	PLATFORM ENHANCEMENT PROTECTION		01
012	0501010942	3/8" X 1-1/4" BOLT		02
013	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
014	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
015	0502012739	PLATFORM LEFT FIXER SUPPORT		01




Item	Code	Description	See page	QT
001	0511069661	PLATFORM SUPPORT PIVOT		04
002	0503010849	3/8" X 1-1/2" BOLT		08
003	0501010984	FLAT WASHER		18
004	0503010025	3/8" SPRING WASHER		10
005	0503010026	3/8" NUT		10
006	0521063178	RIGHT PLATFORM		01
007	0521063179	LEFT PLATFORM PST DUO 13/F		01
008	0503011336	1/2" HEX SELF ADJUSTING NUT		04
009	0503011333	COVER FIXER		02
010	0503010274	5/32"X 2" COTTERPIN		02
011	0571017990	PLATFORM ENHANCEMENT PROTECTION		01
012	0501010942	3/8" X 1-1/4" BOLT		02
013	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
014	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
015	0502012739	PLATFORM LEFT FIXER SUPPORT		01




Item	Code	Description	See page	QT
001	0511069661	PLATFORM SUPPORT PIVOT		04
002	0503010849	3/8" X 1-1/2" BOLT		08
003	0501010984	FLAT WASHER		18
004	0503010025	3/8" SPRING WASHER		10
005	0503010026	3/8" NUT		10
006	0521065191	RIGHT PLATAFORM		01
007	0521065190	LEFT PLATAFORM		01
008	0503011336	1/2" HEX SELF ADJUSTING NUT		04
009	0503011333	COVER FIXER		02
010	0503010274	5/32"X 2" COTTERPIN		02
011	0571017990	PLATFORM ENHANCEMENT PROTECTION		01
012	0501010942	3/8" X 1-1/4" BOLT		02
013	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
014	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
015	0502012739	PLATFORM LEFT FIXER SUPPORT		01




Item	Code	Description	See page	QT
01	0521062988	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8" SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0521065384	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8" SELF-ADJUSTING NUT		08



Item	Code	Description	See page	QT
001	0521063175	HANDRAIL		02
002	0503014007	1/2" X 1-1/4" BOLT		04
003	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
004	0503010905	1/2" X 2-1/4" BOLT		02
005	0503010019	1/2" SPRING WASHER		08
006	0503010060	1/2" NUT		08
007	0503034094	22 TWISTED CHAIN		02
008	0571017991	CHAIN FIXER HANDRAIL		04
009	0551019884	45 X 50 X 3/8 FASTENER		04
010	0503013357	3/8" SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0521065192	HANDRAIL 6850		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8" SELF-ADJUSTING NUT		08



Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	

HEADER ASSY

0909094295




Item	Code	Description	See page	4880	5340	5950	6850
01	0521065557	CABEÇALHO		001	001	001	001
02	0511054601	FULL ARTICULATED TRACTOR HITCH	78	001	001	001	001
03	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		001	001	001	001
04	0511053179	TRACTOR HITCH AXLE		001	001	001	001
04A	0521064036	TRACTOR HITCH AXLE		001	001	001	001
04B	0503030012	HAIR PIN		001	001	001	001
05	0521063529	LOCK AXLE		001	001	001	001
06	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		001	001	001	001
07	0503010010	1/4" X 2.1/2" COTTERPIN		001	001	001	001
08	0521063528	EXTENDING FIXER		001	001	001	001
09	0521062916	LEFT FRENCH HAND		001	001	001	001
10	0501010171	BOLT 1 UNC X 3.1/2 C S G.5		002	002	002	002
11	0503010012	1" SPRING WASHER		002	002	002	002
12	0501010059	1.5/8 NUT		002	002	002	002
13	0521010585	0.9" X 5.9" COUPLING SHAFT		001	001	001	001
14	0503030085	LOCK PIN		001	001	001	001
15	0521064203	EAR PIVOT DRAWBAR		001	001	001	001
16	0571010661	PIVOT SHAFT		001	001	001	001
17	0503010010	1/4" X 2.1/2" COTTERPIN		001	001	001	001
18	0521053311	RIGHT EXTENSOR HEAD 36,00 - 4880/5720/5950	79	001	000	001	000
18.	0521053312	RIGHT EXTENSOR HEAD 36,00 - 5340	80	000	001	000	000
18..	0521053319	RIGHT EXTENSOR HEAD 36,00 - 6850	81	000	000	000	001
19	0521053310	LEFT EXTENSION HEADER 36.00 - 4880/5720/5950	82	001	000	001	000
19.	0521053313	LEFT EXTENSION HEADER 36.00 - 5340	83	000	001	000	000
19..	0521053318	LEFT EXTENSION HEADER 36.00 - 6850	84	000	000	000	001
20	0501010500	3/4"X3"BOLT		002	002	002	002
21	0503010023	3/4" SPRING WASHER		002	002	002	002
22	0503010014	3/4" NUT		002	002	002	002
23	0571019949	JUNCTION SHAFT		002	002	002	002
24	0503030119	LOCK PIN		002	002	002	002
25	0521010572	0.9" X 2.9" COUPLING SHAFT		001	001	001	001




HEADER ASSY

0909094295


Item	Code	Description	See page	4880	5340	5950	6850
26	0503030085	LOCK PIN		003	003	003	003
27	0511052311	3 POINT TURNBUCKLE	85	001	001	001	001
28	0521012532	0.9" X 3.9" COUPLING SHAFT		001	001	001	001
29	0521010582	COUPLING SHAFT		001	001	001	001
30	0511056736	HOSE SUPPORT	86	001	001	001	001




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0571012612	PIVOT SHAFT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521064425	POINT FIXER EXTENDING RIGHT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064425	POINT FIXER EXTENDING RIGHT		01
02	0521065193	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064237	POINT FIXER EXTENDING RIGHT		01
02	0521065193	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064426	POINT FIXER EXTENDING LEFT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064426	POINT FIXER EXTENDING LEFT		01
02	0521065193	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064238	POINT FIXER EXTENDING LEFT		01
02	0521065193	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0571012279	JACK RIGHT		01
03	0571012280	JACK LEFT		01
04	0531010264	SIDE RATCHET		02
05	0521018500	SHAFT LEVER EXTENSOR		01
06	0511061881	RATCHET FOLLOWER		01
07	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
08	0503011179	3/8" X 2-1/4" BOLT		05
09	0503011443	3/8" SPRING WASHER		05
10	0503010026	3/8" NUT		05
11	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01



Item	Code	Description	See page	QT
01	0571017027	SOPORTE VALV		01
02	0503010920	1/2" X 1.1/2" BOLT		02
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0501054694	FLOW DIVIDING VALVE ASSY		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	91	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		02
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057089	HOSE KIT SYSTEM HYDRAULIC		01
19A	0501080045	3/8" X 850 TR-TR HOSE		01
19B	0501080999	3/8" X 39" TC-TC HOSE		01
19C	0501081987	HOSE 3/8 X 1550 TR-TC		01
19D	0501081986	HOSE 3/8 X 1550 TC-TC		01
20	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
20A	0501080185	HOSE 1/2 X 4000 TR-TM		01
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
20C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
20D	0503018952	PLASTIC BOLT		06
21	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
21A	0501080185	HOSE 1/2 X 4000 TR-TM		01
21B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01




Item	Code	Description	See page	QT
21C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0571017027	SOPORTE VALV		01
02	0503010920	1/2" X 1.1/2" BOLT		02
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0501054694	FLOW DIVIDING VALVE ASSY		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	91	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		01
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057104	HOSE KIT SYSTEM HYDRAULIC		01
19A	0501080104	3/8 X 900 TR-TR HOSE		01
19B	0501080963	3/8 X 1050 TC-TC 90G LEFT OSE		01
19C	0501080714	HOSE 3/8 X 1600 TR-TC		01
19D	0501081994	3/8 X 1600 TC-TC 180G HOSE		01
20	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
20A	0501080185	HOSE 1/2 X 4000 TR-TM		01
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
20C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
20D	0503018952	PLASTIC BOLT		06
21	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
21A	0501080185	HOSE 1/2 X 4000 TR-TM		01
21B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01

Item	Code	Description	See page	QT
21C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21D	0503018952	PLASTIC BOLT		06
22	0503013100	NYLON CLAMP		02




Item	Code	Description	See page	QT
01	0571017027	SOPORTE VALV		01
02	0503010920	1/2" X 1.1/2" BOLT		02
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0501054694	FLOW DIVIDING VALVE ASSY		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	91	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		01
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057106	ASSY HYDRAULIC SYSTEM HOSE 6850		01
19A	0501080373	TR-TR HOSE ASSY		01
19B	0501081989	HOSE 3/8 X 1400 TC-TC 90G		01
19C	0501081992	HOSE		01
19D	0501081991	HOSE 3/8 X 1950 TC-TC 180G		01
20	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
20A	0501080185	HOSE 1/2 X 4000 TR-TM		01
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
20C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
20D	0503018952	PLASTIC BOLT		06
21	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
21A	0501080185	HOSE 1/2 X 4000 TR-TM		01
21B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01


Item	Code	Description	See page	QT
21C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21D	0503018952	PLASTIC BOLT		06
22	0503013100	NYLON CLAMP		02



Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	96	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	HAIR PIN		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	SEQUENTIAL VALVE ASSY	90	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0511057090	HYDRAULIC MARKER HAND SET		01
24A	0501081728	HOSE 3/8 X 3100 TR-TR		01
24B	0501080392	3/8" X 3300 TR-TC HOSE		01
24C	0501081988	3/8" X 145.6" TR-TC HOSE		01
24D	0501081682	TC-TC HOSE ASSY		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	91	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	96	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	HAIR PIN		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	SEQUENTIAL VALVE ASSY	90	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0511057101	HYDRAULIC MARKER HANDLE SET		01
24A	0501081330	HOSE		01
24B	0501081718	HOSE		01
24C	0501081799	HOSE		01
24D	0501081995	HOSE		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	91	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	96	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	HAIR PIN		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	SEQUENTIAL VALVE ASSY	90	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0511057091	HYDRAULIC MARKER HANDLE SET		01
24A	0501081793	HOSE		01
24B	0501081967	TR-TC HOSE ASSY		01
24C	0501081996	HOSE		01
24D	0501081997	HOSE		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	91	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	96	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	HAIR PIN		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	SEQUENTIAL VALVE ASSY	90	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0511057103	HYDRAULIC MARKER HANDLE ASSY 6850		01
24A	0501081990	HOSE 3/8 X 4100 TR-TR		01
24B	0501080388	3/8 X 4300 TR-TC HOSE ASSY		01
24C	0501080724	3/8" X 4700 TR-TC HOSE ASSY		01
24D	0501081993	HOSE 3/8 X 4900 TC-TC 180G		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01


Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	91	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02



Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
05	0503010179	5/16" ZN SPRING WASHER		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0511058790	SHORT SEED LINE CSU	100	01
01.	0511059123	SHORT SEED LINE	101	01
01..	0521053324	SEED HIGH SHORT LINE CSU	102	01
01...	0521053110	LINE SEED HIGH SHORT HUB HIGH CSU	103	01
01....	0521053472	LINE SEED SHORT HUB HIGH	104	01
02	0511058791	LONG SEED LINE CSU	105	01
02.	0511059125	LONG SEED LINE	106	01
02..	0521053325	SEED LONG HIGH LINE CSU	107	01
02...	0521053109	SEED HIGH LINE LONG HUB HIGH	108	01
02....	0521053473	HIGH CUBE LONG SEED LINE	109	01
03	0511058796	SHORT LEFT FERTILIZER LINE DDD	110	01
03.	0511059469	SHORT LEFT FERTILIZER LINE WITHOUT DDD	111	01
03..	0521050203	RIGHT SHORT FERTILIZER LINE	112	01
03...	0521053166	SHORT HIGH FERTILIZER LINE WITHOUT DDD / DC20	113	01
03....	0521052636	DDD / DC20 HIGH LEFT FERTILIZER LINE	114	01
03.....	0521052812	SHORT HIGH FERTILIZER LINE DAOC/DC18	115	01
03.....	0511058798	SHORT LEFT FERTILIZER LINE DDD/DC20	116	01
04	0511058797	RIGHT LONG FERTILIZER LINE DDD	117	01
04.	0511059470	RIGHT LONG FERTILIZER LINE WITHOUT DDD	118	01
04..	0521050205	LEFT LONG FERTILIZER LINE	119	01
04...	0521053165	LONG HIGH FERTILIZER LINE WITHOUT DDD / DC20	120	01
04....	0521052637	DDD / DC20 RIGHT HIGH RIGHT FERTILIZER LINE	121	01
04.....	0521052813	LONG HIGH FERTILIZER LINE	122	01
04.....	0511058799	RIGHT LONG FERTILIZER LINE DDD DC20	123	01
05	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	174	01
05.	0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	184	01
06	0501018652	CORN STABILIZER BAR		01
07	0501110231	SCARIFIER HEAD WITH SPIKE 0061	193	01
08	0511017969	0.1" SPACING PLATE		01


Item	Code	Description	See page	QT
09	0511018662	SPACING PLATE		01
10	0521069124	BOCAL FILLED LINE PIVOTED WITH LINGUET		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		01
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0511061769	RIGHT FERTILIZER CONDUCTOR WITH REGULATOR		01
16	0511061770	LEFT CONDUCTOR FERTILIZER WITH REGULATOR		01
17	0503031050	CURVED CONDUCTOR		01
18	0503010246	CLAMP		01
19	0503016204	CORN DISK 12 ORANGE		01
20	0503016214	RING CORN (APOLLO740)		01
21	0503016218	DISC OF SOYBEAN		01
22	0503016220	RING TO SOYBEANS (APOLLO 745)		01
23	0503016221	RING TO SOYBEANS (APOLLO 571)		01
24	0501050120	LARGER WALKING BEAM ASSY	194	01
25	0503030558	PULLEY 4Z CORN PLASTIC		01
26	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
27	0503010019	1/2" SPRING WASHER		01
28	0503010060	1/2" NUT		01
29	0511058877	REGULATORY KEY		01
29A	0521066800	BODY REGULATORY KEY		01
29B	0503030878	LEVER CRANK		01
30	0521067360	PROTRACTOR CPRA		01
31	0511059410	HDA BC	195	01
32	0581010082	FERTILIZER SOCKET RIGHT		01
33	0581010083	FERTILIZER SOCKET LEFT		01
34	0503031145	2" X 2" X 20" HOSE		01
35	0503031076	2" HOSE CLAMP		01
36	0581015215	STABILIZER BAR E500 PIVOTED HIGH LINE		01
36.	0581015213	STABILIZER BAR E450		01
37	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
38	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
39	0511017302	FLAT WASHER		01
40	0503010019	1/2" SPRING WASHER		01
41	0503010060	1/2" NUT		01
42	0503010479	BOLT		01
43	0501013714	STABILIZER BAR		01
44	0521050525	FIXER FERTILIZER CONDUCTOR	197	01
45	0571011730	SEED CONDUCTOR 3X1500		01
46	0521052631	HDA HIGH AUTOMATIC DISARM	198	01
47	0501110804	ROD SCARIFIER SPINDLE WIHT POINT	201	01
48	0503030391	RIGHT FERTILIZER NOZZLE		01
49	0503030392	LEFT FERTILIZER NOZZLE		01




Item	Code	Description	See page	QT
01	0511056600	FRONT LINE SEED SHORT DDD RIGHT	124	01
02	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	141	01
03	0501010197	5/8" X 3-1/2" BOLT		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0502012538	SPRING VARON SUPPORT		01
06	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
07	0511017302	FLAT WASHER		02
08	0503011336	1/2" HEX SELF ADJUSTING NUT		02
09	0511060376	SEEP SPRING GUIDE		01
10	0521010542	COUPLING SHAFT		01
11	0503010257	1/8" X 1" COTTERPIN		01
12	0502040534	SPRING GUIDE BUSHING LOCK		01
13	0501018535	1/2 X 1 BOLT		01
14	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
15	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
16	0502040534	SPRING GUIDE BUSHING LOCK		01
17	0501013753	FLAT WASHER		01
18	0501018535	1/2 X 1 BOLT		01
19	0503010013	5/8" NUT		01
20	0511052024	FAST CLOSING SET	142	01
21	0511059023	SEED SYSTEM ASSY	143	01
22	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
23	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
24	0511017302	FLAT WASHER		01
25	0503010019	1/2" SPRING WASHER		01
26	0503010060	1/2" NUT		01
27	0503011099	GREASE FITTING		02
28	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511056600	FRONT LINE SEED SHORT DDD RIGHT	124	01
02	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	141	01
03	0503016110	BOLT 5/8 UNC X 4 C S G.7 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0502012538	SPRING VARON SUPPORT		01
06	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
07	0511017302	FLAT WASHER		02
08	0503011336	1/2" HEX SELF ADJUSTING NUT		02
09	0511060376	SEEP SPRING GUIDE		01
10	0521010542	COUPLING SHAFT		01
11	0503010257	1/8" X 1" COTTERPIN		01
12	0502040534	SPRING GUIDE BUSHING LOCK		01
13	0501018535	1/2 X 1 BOLT		01
14	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
15	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
16	0502040534	SPRING GUIDE BUSHING LOCK		01
17	0501013753	FLAT WASHER		01
18	0501018535	1/2 X 1 BOLT		01
19	0503010013	5/8" NUT		01
20	0511052024	FAST CLOSING SET	142	01
21	0511059023	SEED SYSTEM ASSY	143	01
22	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
23	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
24	0511017302	FLAT WASHER		01
25	0503010019	1/2" SPRING WASHER		01
26	0503010060	1/2" NUT		01
27	0503011099	GREASE FITTING		02
28	0511053118	ASSEMBLY SENSOR ELECTRONIC		01
28A	0503016492	ELECTRIC PHOTO SENSOR PM 100		01
28B	0503013100	NYLON CLAMP		05




Item	Code	Description	See page	QT
01	0521052840	SHORT PIVOTING HIGH LINE	135	01
02	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	141	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0511059023	SEED SYSTEM ASSY	143	01




Item	Code	Description	See page	QT
01	0521052847	HIGH LINE PIVOTED SHORT HUB HIGH	137	01
02	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	141	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0511059023	SEED SYSTEM ASSY	143	01




Item	Code	Description	See page	QT
01	0521052654	FRONT LINE SEED SHORT DDD RIGHT HIGH CUBE	126	01
02	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	141	01
03	0503016110	BOLT 5/8 UNC X 4 C S G.7 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0502012538	SPRING VARON SUPPORT		01
06	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
07	0511017302	FLAT WASHER		02
08	0503011336	1/2" HEX SELF ADJUSTING NUT		02
09	0511060376	SEEP SPRING GUIDE		01
10	0521010542	COUPLING SHAFT		01
11	0503010257	1/8" X 1" COTTERPIN		01
12	0502040534	SPRING GUIDE BUSHING LOCK		01
13	0501018535	1/2 X 1 BOLT		01
14	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
15	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
16	0502040534	SPRING GUIDE BUSHING LOCK		01
17	0501013753	FLAT WASHER		01
18	0501018535	1/2 X 1 BOLT		01
19	0503010013	5/8" NUT		01
20	0511052024	FAST CLOSING SET	142	01
21	0511059023	SEED SYSTEM ASSY	143	01
22	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
23	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
24	0511017302	FLAT WASHER		01
25	0503010019	1/2" SPRING WASHER		01
26	0503010060	1/2" NUT		01
27	0503011099	GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511056601	LONG SEED ROW FRONT DDD LEFT	125	01
02	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	141	01
03	0501010197	5/8" X 3-1/2" BOLT		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0502012538	SPRING VARON SUPPORT		01
06	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
07	0511017302	FLAT WASHER		02
08	0503011336	1/2" HEX SELF ADJUSTING NUT		02
09	0511060376	SEEP SPRING GUIDE		01
10	0521010542	COUPLING SHAFT		01
11	0503010257	1/8" X 1" COTTERPIN		01
12	0502040534	SPRING GUIDE BUSHING LOCK		01
13	0501018535	1/2 X 1 BOLT		01
14	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
15	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
16	0502040534	SPRING GUIDE BUSHING LOCK		01
17	0501013753	FLAT WASHER		01
18	0501018535	1/2 X 1 BOLT		01
19	0503010013	5/8" NUT		01
20	0511052024	FAST CLOSING SET	142	01
21	0511059023	SEED SYSTEM ASSY	143	01
22	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
23	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
24	0511017302	FLAT WASHER		01
25	0503010019	1/2" SPRING WASHER		01
26	0503010060	1/2" NUT		01
27	0503011099	GREASE FITTING		02
28	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511056601	LONG SEED ROW FRONT DDD LEFT	125	01
02	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	141	01
03	0503016110	BOLT 5/8 UNC X 4 C S G.7 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0502012538	SPRING VARON SUPPORT		01
06	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
07	0511017302	FLAT WASHER		02
08	0503011336	1/2" HEX SELF ADJUSTING NUT		02
09	0511060376	SEEP SPRING GUIDE		01
10	0521010542	COUPLING SHAFT		01
11	0503010257	1/8" X 1" COTTERPIN		01
12	0502040534	SPRING GUIDE BUSHING LOCK		01
13	0501018535	1/2 X 1 BOLT		01
14	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
15	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
16	0502040534	SPRING GUIDE BUSHING LOCK		01
17	0501013753	FLAT WASHER		01
18	0501018535	1/2 X 1 BOLT		01
19	0503010013	5/8" NUT		01
20	0511052024	FAST CLOSING SET	142	01
21	0511059023	SEED SYSTEM ASSY	143	01
22	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
23	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
24	0511017302	FLAT WASHER		01
25	0503010019	1/2" SPRING WASHER		01
26	0503010060	1/2" NUT		01
27	0503011099	GREASE FITTING		02
28	0511053118	ASSEMBLY SENSOR ELECTRONIC		01
28A	0503016492	ELECTRIC PHOTO SENSOR PM 100		01
28B	0503013100	NYLON CLAMP		05




Item	Code	Description	See page	QT
01	0521052841	LONG PIVOTANT HIGH LINE	136	01
02	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	141	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0511059023	SEED SYSTEM ASSY	143	01




Item	Code	Description	See page	QT
01	0521052848	HIGH LINE PIVOTED SHORT HUB HIGH	138	01
02	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	141	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0511059023	SEED SYSTEM ASSY	143	01




Item	Code	Description	See page	QT
01	0521052655	FRONT LINE SEED LONG DDD LEFT HIGH CUBE	127	01
02	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	141	01
03	0503016110	BOLT 5/8 UNC X 4 C S G.7 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0502012538	SPRING VARON SUPPORT		01
06	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
07	0511017302	FLAT WASHER		02
08	0503011336	1/2" HEX SELF ADJUSTING NUT		02
09	0511060376	SEEP SPRING GUIDE		01
10	0521010542	COUPLING SHAFT		01
11	0503010257	1/8" X 1" COTTERPIN		01
12	0502040534	SPRING GUIDE BUSHING LOCK		01
13	0501018535	1/2 X 1 BOLT		01
14	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
15	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
16	0502040534	SPRING GUIDE BUSHING LOCK		01
17	0501013753	FLAT WASHER		01
18	0501018535	1/2 X 1 BOLT		01
19	0503010013	5/8" NUT		01
20	0511052024	FAST CLOSING SET	142	01
21	0511059023	SEED SYSTEM ASSY	143	01
22	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
23	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
24	0511017302	FLAT WASHER		01
25	0503010019	1/2" SPRING WASHER		01
26	0503010060	1/2" NUT		01
27	0503011099	GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511053250	SHORT ARM FERTILIZER LINE WITH DDD LEFT	150	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058617	DISC CUT 18 SHORT LINE	156	01
07	0501058423	FERTILIZER ROD SPRING ROW	163	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521061121	SHORT FERTILIZER ROW ARM		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058617	DISC CUT 18 SHORT LINE	156	01
07	0501058423	FERTILIZER ROD SPRING ROW	163	01




Item	Code	Description	See page	QT
01	0521061121	SHORT FERTILIZER ROW ARM		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058619	DISC CUT 20 SHORT LINE	158	01
07	0501058423	FERTILIZER ROD SPRING ROW	163	01
08	0503031145	2" X 2" X 20" HOSE		01
09	0503031076	2" HOSE CLAMP		02
10	0521050169	DAOC 18 RIGHT WITH NOZZLE	164	01




Item	Code	Description	See page	QT
01	0521068566	SHORT FERTILIZER LINE ARM		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058619	DISC CUT 20 SHORT LINE	158	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	166	01




Item	Code	Description	See page	QT
01	0521053152	ARM SHORT LINE FERTILIZER WITH DDD LEFT	153	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058619	DISC CUT 20 SHORT LINE	158	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	166	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521068566	SHORT FERTILIZER LINE ARM		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058617	DISC CUT 18 SHORT LINE	156	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	166	01
08	0503031145	2" X 2" X 20" HOSE		01
09	0503031076	2" HOSE CLAMP		02
10	0521052838	RIGHT SUPPORT DOC18	169	01
11	0521050168	MOUNTED FERTILIZER CONDUCTOR	173	01




Item	Code	Description	See page	QT
01	0511053250	SHORT ARM FERTILIZER LINE WITH DDD LEFT	150	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058619	DISC CUT 20 SHORT LINE	158	01
07	0501058423	FERTILIZER ROD SPRING ROW	163	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511053251	ARM LONG FERTILIZER LINE WITH DDD RIGHT	151	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058618	DISC CUT 18 LONG LINE	157	01
07	0501058423	FERTILIZER ROD SPRING ROW	163	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521061153	LONG ARM FERTILIZER LINE		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058618	DISC CUT 18 LONG LINE	157	01
07	0501058423	FERTILIZER ROD SPRING ROW	163	01




Item	Code	Description	See page	QT
01	0521061153	LONG ARM FERTILIZER LINE		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058620	DISC CUT 20 LONG LINE	159	01
07	0501058423	FERTILIZER ROD SPRING ROW	163	01
08	0503031145	2" X 2" X 20" HOSE		01
09	0503031076	2" HOSE CLAMP		02
10	0521050170	DAOC 18 LEFT WITH NOZZLE	165	01




Item	Code	Description	See page	QT
01	0521068565	LONG FERTILIZER LINE ARM		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058620	DISC CUT 20 LONG LINE	159	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	166	01




Item	Code	Description	See page	QT
01	0521053151	ARM LONG FERTILIZER LINE WITH DDD RIGHT	152	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058620	DISC CUT 20 LONG LINE	159	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	166	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521068565	LONG FERTILIZER LINE ARM		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058618	DISC CUT 18 LONG LINE	157	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	166	01
08	0503031145	2" X 2" X 20" HOSE		01
09	0503031076	2" HOSE CLAMP		02
10	0521052839	LEFT SUPPORT DOC18	170	01
11	0521050168	MOUNTED FERTILIZER CONDUCTOR	173	01




Item	Code	Description	See page	QT
01	0511053251	ARM LONG FERTILIZER LINE WITH DDD RIGHT	151	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058620	DISC CUT 20 LONG LINE	159	01
07	0501058423	FERTILIZER ROD SPRING ROW	163	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521062183	SHORT SEED ROW ARM		01
02	0502011830	ARTICULACCION SUPPORT		01
03	0521018079	SEEP ROW DRAWBAR COVER		01
04	0503014729	1/4" UNF X 1/2" BOLT		02
05	0503011441	SPRING WASHER		02
06	0503010752	1/2" X 3.1/2" BOLT		02
07	0503011440	SPRING WASHER		02
08	0503010060	1/2" NUT		02
09	0502011561	BEARING SEMI		01
10	0502010426	UPPER BEARING SEMI		02
11	0503010479	BOLT		04
12	0503011440	SPRING WASHER		04
13	0503010060	1/2" NUT		04
14	0501013354	FLAT WASHER		02
15	0502011400	18Z CONICAL GEAR		01
16	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
17	0502011505	18Z CONICAL GEAR		01
18	0521018077	1/2" X 58.6" HEX AXLE		01
19	0501013352	FLAT WASHER		04
20	0503033672	NOZZLE WITHOUT TITANIUM		01
21	0511051693	BASE FIXING SYSTEM	128	01
22	0503015920	3/8" UNC X 1.3/4" BOLT		04
23	0503011443	3/8" SPRING WASHER		04
24	0503010026	3/8" NUT		04
25	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
26	0503011440	SPRING WASHER		02
27	0503010060	1/2" NUT		02
28	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	129	01




Item	Code	Description	See page	QT
01	0521062184	LONG SEED ROW ARM		01
02	0502011830	ARTICULACION SUPPORT		01
03	0521018079	SEEP ROW DRAWBAR COVER		01
04	0503014729	1/4" UNF X 1/2" BOLT		02
05	0503011441	SPRING WASHER		02
06	0503010752	1/2" X 3.1/2" BOLT		02
07	0503011440	SPRING WASHER		02
08	0503010060	1/2" NUT		02
09	0502011561	BEARING SEMI		01
10	0502010426	UPPER BEARING SEMI		02
11	0503010479	BOLT		04
12	0503011440	SPRING WASHER		04
13	0503010060	1/2" NUT		04
14	0501013354	FLAT WASHER		02
15	0502011400	18Z CONICAL GEAR		01
16	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
17	0502011505	18Z CONICAL GEAR		01
18	0521018078	1/2" X 66.5" HEX AXLE		01
19	0501013352	FLAT WASHER		04
20	0503033672	NOZZLE WITHOUT TITANIUM		01
21	0511051693	BASE FIXING SYSTEM	128	01
22	0503015920	3/8" UNC X 1.3/4" BOLT		04
23	0503011443	3/8" SPRING WASHER		04
24	0503010026	3/8" NUT		04
25	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
26	0503011440	SPRING WASHER		02
27	0503010060	1/2" NUT		02
28	0511056586	15 X 15 SEED DDD LEFT	130	01




Item	Code	Description	See page	QT
01	0521062183	SHORT SEED ROW ARM		01
02	0502011830	ARTICULACCION SUPPORT		01
03	0521018079	SEEP ROW DRAWBAR COVER		01
04	0503014729	1/4" UNF X 1/2" BOLT		02
05	0503011441	SPRING WASHER		02
06	0503010752	1/2" X 3.1/2" BOLT		02
07	0503011440	SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0502011561	BEARING SEMI		01
10	0502010426	UPPER BEARING SEMI		02
11	0503010479	BOLT		04
12	0501013354	FLAT WASHER		02
13	0502011400	18Z CONICAL GEAR		01
14	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
15	0502011505	18Z CONICAL GEAR		01
16	0521018077	1/2" X 58.6" HEX AXLE		01
17	0501013352	FLAT WASHER		04
18	0501059631	DDD SEED 15" X 15" RIGHT	146	01
19	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
20	0503033672	NOZZLE WITHOUT TITANIUM		01
21	0511051693	BASE FIXING SYSTEM	128	01
22	0503015920	3/8" UNC X 1.3/4" BOLT		04
23	0503011443	3/8" SPRING WASHER		04
24	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521062184	LONG SEED ROW ARM		01
02	0502011830	ARTICULACCION SUPPORT		01
03	0521018079	SEEP ROW DRAWBAR COVER		01
04	0503014729	1/4" UNF X 1/2" BOLT		02
05	0503011441	SPRING WASHER		02
06	0503010752	1/2" X 3.1/2" BOLT		02
07	0503011440	SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0502011561	BEARING SEMI		01
10	0502010426	UPPER BEARING SEMI		02
11	0503010479	BOLT		04
12	0501013354	FLAT WASHER		02
13	0502011400	18Z CONICAL GEAR		01
14	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
15	0502011505	18Z CONICAL GEAR		01
16	0521018078	1/2" X 66.5" HEX AXLE		01
17	0501013352	FLAT WASHER		04
18	0501059632	DDD SEED 15X15 LEFT	147	01
19	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
20	0503033672	NOZZLE WITHOUT TITANIUM		01
21	0511051693	BASE FIXING SYSTEM	128	01
22	0503015920	3/8" UNC X 1.3/4" BOLT		04
23	0503011443	3/8" SPRING WASHER		04
24	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502011411	10Z CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	131	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	133	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	134	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511015098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O-RING		02
14	0511011927	DUST CLOAK		02




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	132	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	133	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	134	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER		02
08	0503011443	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511015098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0521068663	SHORT SEED LINE ARM		01
02	0511059244	ROD SPRING LINE SEED	139	01
03	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	140	01
04	0511052024	FAST CLOSING SET	142	01
05	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
06	0521018077	1/2" X 58.6" HEX AXLE		01
07	0521018079	SEEP ROW DRAWBAR COVER		01
08	0502011830	ARTICULACCION SUPPORT		01
09	1902010426	UPPER BEARING SEMI		02
10	0511051693	BASE FIXING SYSTEM	128	01
11	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	129	01
12	0503010752	1/2" X 3.1/2" BOLT		02
13	0503011440	SPRING WASHER		08
14	0503010060	1/2" NUT		08
15	1902011561	BEARING SEMI		01
16	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
17	0503014729	1/4" UNF X 1/2" BOLT		02
18	0503011441	SPRING WASHER		02
19	0503010479	BOLT		04
20	0501013352	FLAT WASHER		01
21	0502011505	18Z CONICAL GEAR		01
22	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
23	0501013354	FLAT WASHER		02
24	0502011400	18Z CONICAL GEAR		01
25	0581014526	ELEVATION PLATE 3/8		01
26	0581014527	ELEVATION PLATE 12,5		03
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
28	0503010025	3/8" SPRING WASHER		04
29	0503010026	3/8" NUT		04
30	0503011099	GREASE FITTING		02
31	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521068664	LONG SEED LINE ARM		01
02	0511059244	ROD SPRING LINE SEED	139	01
03	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	140	01
04	0511052024	FAST CLOSING SET	142	01
05	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
06	0521018078	1/2" X 66.5" HEX AXLE		01
07	0521018079	SEEP ROW DRAWBAR COVER		01
08	0502011830	ARTICULACCION SUPPORT		01
09	1902010426	UPPER BEARING SEMI		02
10	0511051693	BASE FIXING SYSTEM	128	01
11	0511056586	15 X 15 SEED DDD LEFT	130	01
12	0503010752	1/2" X 3.1/2" BOLT		02
13	0503011440	SPRING WASHER		08
14	0503010060	1/2" NUT		08
15	1902011561	BEARING SEMI		01
16	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
17	0503014729	1/4" UNF X 1/2" BOLT		02
18	0503011441	SPRING WASHER		02
19	0503010479	BOLT		04
20	0501013352	FLAT WASHER		01
21	0502011505	18Z CONICAL GEAR		01
22	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
23	0501013354	FLAT WASHER		02
24	0502011400	18Z CONICAL GEAR		01
25	0581014526	ELEVATION PLATE 3/8		01
26	0581014527	ELEVATION PLATE 12,5		03
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
28	0503010025	3/8" SPRING WASHER		04
29	0503010026	3/8" NUT		04
30	0503011099	GREASE FITTING		02
31	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521068663	SHORT SEED LINE ARM		01
02	0511059244	ROD SPRING LINE SEED	139	01
03	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	140	01
04	0511052024	FAST CLOSING SET	142	01
05	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
06	0521018077	1/2" X 58.6" HEX AXLE		01
07	0521018079	SEEP ROW DRAWBAR COVER		01
08	0502011830	ARTICULACCION SUPPORT		01
09	1902010426	UPPER BEARING SEMI		02
10	0511051693	BASE FIXING SYSTEM	128	01
11	0501059631	DDD SEED 15" X 15" RIGHT	146	01
12	0503010752	1/2" X 3.1/2" BOLT		02
13	0503011440	SPRING WASHER		08
14	0503010060	1/2" NUT		08
15	1902011561	BEARING SEMI		01
16	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
17	0503014729	1/4" UNF X 1/2" BOLT		02
18	0503011441	SPRING WASHER		02
19	0503010479	BOLT		04
20	0501013352	FLAT WASHER		01
21	0502011505	18Z CONICAL GEAR		01
22	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
23	0501013354	FLAT WASHER		02
24	0502011400	18Z CONICAL GEAR		01
25	0581014526	ELEVATION PLATE 3/8		01
26	0581014527	ELEVATION PLATE 12,5		03
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
28	0503010025	3/8" SPRING WASHER		04
29	0503010026	3/8" NUT		04
30	0503011099	GREASE FITTING		02
31	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521068664	LONG SEED LINE ARM		01
02	0511059244	ROD SPRING LINE SEED	139	01
03	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	140	01
04	0511052024	FAST CLOSING SET	142	01
05	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
06	0521018078	1/2" X 66.5" HEX AXLE		01
07	0521018079	SEEP ROW DRAWBAR COVER		01
08	0502011830	ARTICULACCION SUPPORT		01
09	1902010426	UPPER BEARING SEMI		02
10	0511051693	BASE FIXING SYSTEM	128	01
11	0501059632	DDD SEED 15X15 LEFT	147	01
12	0503010752	1/2" X 3.1/2" BOLT		02
13	0503011440	SPRING WASHER		08
14	0503010060	1/2" NUT		08
15	1902011561	BEARING SEMI		01
16	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
17	0503014729	1/4" UNF X 1/2" BOLT		02
18	0503011441	SPRING WASHER		02
19	0503010479	BOLT		04
20	0501013352	FLAT WASHER		01
21	0502011505	18Z CONICAL GEAR		01
22	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
23	0501013354	FLAT WASHER		02
24	0502011400	18Z CONICAL GEAR		01
25	0581014526	ELEVATION PLATE 3/8		01
26	0581014527	ELEVATION PLATE 12,5		03
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
28	0503010025	3/8" SPRING WASHER		04
29	0503010026	3/8" NUT		04
30	0503011099	GREASE FITTING		02
31	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511060376	SEEP SPRING GUIDE		01
02	0503010834	1/2 X 1 BOLT		02
03	0502040534	SPRING GUIDE BUSHING LOCK		02
04	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
05	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
06	0501013753	FLAT WASHER		01
07	0521010542	COUPLING SHAFT		01
08	0503010257	1/8" X 1" COTTERPIN		01
09	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0502012538	SPRING VARON SUPPORT		01
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
03	0511017302	FLAT WASHER		02
04	0503011336	1/2" HEX SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0502012823	CUTTING DISC SUPPORT		01
02	0503034318	5/8 UNC X 2 BOLT		02
03	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0502020693	SUPPORT SEED BOX		01
02	0502012721	SEED DISC LOWER TRAIL		01
03	0503034131	DEFLECTOR		01
04	0503010025	3/8" SPRING WASHER		03
05	0503010209	3/8" UNC BUTTERFLY NUT		03
06	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
07	0571018536	HEX PRISONER		01
08	0501010984	FLAT WASHER		01
09	0503010337	5/16" NUT		01
10	0503010179	5/16" ZN SPRING WASHER		05
11	0503062582	DEPOSIT SEED		01
12	0581011346	ADAPTER DEPOSIT		01
13	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
14	0503016282	ALLEN BOLT		01
15	0503016283	M8 NUT HEX		01
16	0501051094	SEED DISTRIB ASSY WITH DOUB PULLEY	144	01
17	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
18	0503016219	RING TO SOYBEANS		01
19	0503010675	5/16" X 2.1/4" BOLT		01
20	0503030083	3/8" X 3/8" X 1.6" STUD		02




Item	Code	Description	See page	QT
01	0503030381	SEED DISTRIBUTOR BOX		01
02	0502010447	TRIGGER		02
03	0501013467	KEY AXLE		01
04	0503030378	0.4" X 1.1" X 0.03" SPRING		03
05	0501013466	KEY LIMITER AXLE		01
06	0501051119	DOUBLE PULLEY ROCKER'S	145	01
07	0501013468	ROCKER ARM AXLE, OF THE PULLEY		01
08	0503030377	SCRAPER		01




Item	Code	Description	See page	QT
01	0503031129	DOUBLE PULLEY ROCKER ARM		01
02	0503031128	5Z PLASTIC DOUB PULLEY FOR SOYBEAN		02
03	0521010649	TOOTH PULLEY COUPLING SHAFT		01
04	0503011853	503050 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	BOX DDD ASSY DPL 15 RIGHT	148	01
04	0501054168	BOX DDD ASSY DPL 15 LEFT	149	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	COVER DEPTH		02
07	0503014729	1/4" UNF X 1/2" BOLT		06
08	0503011441	SPRING WASHER		06
09	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503011443	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0511052301	SUPPORT DDD 15 RIGHT	131	01
15A	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
15B	0571012491	SOCKET SEED GUIDE		01
15C	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	BOX DDD ASSY DPL 15 RIGHT	148	01
04	0501054168	BOX DDD ASSY DPL 15 LEFT	149	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	COVER DEPTH		02
07	0503014729	1/4" UNF X 1/2" BOLT		06
08	0503011441	SPRING WASHER		06
09	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503011443	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0511052302	LH SUPPORT DDD GUIDE	132	01
15A	0561015592	LEFT DOUBLE DISC SUPPORT		01
15B	0571012491	SOCKET SEED GUIDE		01
15C	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502011930	DOUBLE DISC COULTER BOX		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019154	RIGHT DOUB DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011930	DOUBLE DISC COULTER BOX		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019148	LEFT DOUBLE DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503011440	SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	154	01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503011440	SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521061153	LONG ARM FERTILIZER LINE		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	155	01




Item	Code	Description	See page	QT
01	0521068565	LONG FERTILIZER LINE ARM		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	155	01
07	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0521068566	SHORT FERTILIZER LINE ARM		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	154	01
07	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	134	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	133	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503011443	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	133	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	134	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O-RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0503010003	1845 GREASE FITTING		01
03	0571019976	LEFT BRACELET CUTTING DISC		01
04	0503011411	1/2" X 5-1/2" BOLT		01
05	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
06	0503011440	SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0502020394	SPRING SUPPORT		01
09	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
10	0502020393	SPRING UPPER SUPPORT		01
11	0521010452	SLEEVE		01
12	0503013185	3/4" X 5-1/2" BOLT		01
13	0501067323	SPRING REGULATOR		01
14	0511056910	BOX WITH DISC CUT 18	160	01
15	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01
16	0503011255	3/4" LOCK NUT		02
17	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
18	0581011111	WASHER BRACKET AXIS DC PST		01
19	0503034319	LOCK PIN		01
20	0511056909	DISC BOX CUT WITHOUT THE DISC	162	01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0503010003	1845 GREASE FITTING		01
03	0571019976	LEFT BRACELET CUTTING DISC		01
04	0503011411	1/2" X 5-1/2" BOLT		01
05	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
06	0503011440	SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0502020394	SPRING SUPPORT		01
09	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
10	0502020393	SPRING UPPER SUPPORT		01
11	0521010452	SLEEVE		01
12	0503013185	3/4" X 5-1/2" BOLT		01
13	0501067323	SPRING REGULATOR		01
14	0511056910	BOX WITH DISC CUT 18	160	01
15	0502012824	FIXING SHAFT DISC CUT LINE		01
16	0503011255	3/4" LOCK NUT		02
17	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
18	0581011111	WASHER BRACKET AXIS DC PST		01
19	0503034319	LOCK PIN		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	WASHER BRACKET AXIS DC PST		01
17	0503034319	LOCK PIN		01
18	0511058648	BOX WITH DISC BLADE 20"	161	01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012824	FIXING SHAFT DISC CUT LINE		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	WASHER BRACKET AXIS DC PST		01
17	0503034319	LOCK PIN		01
18	0511058648	BOX WITH DISC BLADE 20"	161	01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511056909	DISC BOX CUT WITHOUT THE DISC	162	01
02	0603026013	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0511056909	DISC BOX CUT WITHOUT THE DISC	162	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01




Item	Code	Description	See page	QT
01	0502012793	DC PST		01
02	0571018049	DOOR DUST		02
03	0571018047	AXLE DISC		01
04	0503017755	NUT		01
05	0502020641	BLADE DISC FLANGE		01
06	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
07	0503018441	5/16" X 1-1/4" BOLT		06
08	0503013816	5/16" LOCKNUT		06
09	0503010691	1/4" GREASE FITTING		01
10	0571018048	WASHER		02
11	0521065882	SEAL RING		02
12	0503010816	6207 RS ROLLER BEARING		02
13	0581010575	7/8" X 145 BOLT		01




Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD		01
02	0502040534	SPRING GUIDE BUSHING LOCK		02
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502012510	SPRING ROD SUPPORT		01
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		01
07	0501018535	1/2 X 1 BOLT		02
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
09	0503010060	1/2" NUT		02
10	1902010891	SPRING CHOCK SUPPORT VARON		01
11	0503010014	3/4" NUT		01
12	0561014471	COUPLING SHAFT		01
13	0511017302	FLAT WASHER		01
14	0503010257	1/8" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
001	0511059218	RIGHT SUPPORT	167	01
002	0521050168	MOUNTED FERTILIZER CONDUCTOR	173	01




Item	Code	Description	See page	QT
001	0511059219	LEFT SUPPORT	168	01
002	0521050168	MOUNTED FERTILIZER CONDUCTOR	173	01




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK	02	
02	0502012184	FERTILIZER SPRING GUIDE	02	
03	0503031910	1.7" X 22.8" X 0.3" SPRING	01	
04	0502012510	SPRING ROD SUPPORT	01	
05	0521068568	LARGE ELEVATION SPRING FERTILIZER	01	
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN	01	
07	0501018535	1/2 X 1 BOLT	02	
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
09	0503010060	1/2" NUT	02	
10	0502010891	SPRING CHOCK SUPPORT VARON	01	
11	0503010014	3/4" NUT	01	
12	0561014471	COUPLING SHAFT	01	
13	0511017302	FLAT WASHER	01	
14	0503010257	1/8" X 1" COTTERPIN	01	




Item	Code	Description	See page	QT
01	0521066977	ARM BLADE DISC		01
02	0581011838	SLEVE GUIDES		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0521015376	DUST CLOAK		01
05	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02
08	0503012417	SEAL		01
09	0503011800	SEAL RING		01
10	0503010276	6206 BALL BEARING		01
11	0503030832	FLAT WASHER		01
12	0511059229	BOX WITH DOC 18 TURBO RIGHT	171	01




Item	Code	Description	See page	QT
01	0521066977	ARM BLADE DISC		01
02	0581011838	SLEVE GUIDES		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0521015376	DUST CLOAK		01
05	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02
08	0503012417	SEAL		01
09	0503011800	SEAL RING		01
10	0503010276	6206 BALL BEARING		01
11	0503030832	FLAT WASHER		01
12	0511059230	BOX WITH DOC 18 TURBO LEFT	172	01




Item	Code	Description	See page	QT
01	0521068662	DOC SHORT ARM		01
02	0581011838	SLEEVE GUIDES		01
03	0521015376	DUST CLOAK		01
04	0503010878	5/8" SELF ALIGNING NUT		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2" NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503010276	6206 BALL BEARING		01
10	0503030832	FLAT WASHER		01
11	0511059229	BOX WITH DOC 18 TURBO RIGHT	171	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0521068662	DOC SHORT ARM		01
02	0581011838	SLEVE GUIDES		01
03	0521015376	DUST CLOAK		01
04	0503010878	5/8" SELF ALIGNING NUT		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2" NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503010276	6206 BALL BEARING		01
10	0503030832	FLAT WASHER		01
11	0511059230	BOX WITH DOC 18 TURBO LEFT	172	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0502011562	DC BOX		01
02	0503011800	SEAL RING		01
03	0503012417	SEAL		01
04	0503010276	6206 BALL BEARING		01
05	0503030832	FLAT WASHER		01
06	0503011444	SPRING WASHER		06
07	0503010691	1/4" GREASE FITTING		01
08	0503010337	5/16" NUT		06
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0607025032	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0502011562	DC BOX		01
02	0503011800	SEAL RING		01
03	0503012417	SEAL		01
04	0503010276	6206 BALL BEARING		01
05	0503030832	FLAT WASHER		01
06	0503011444	SPRING WASHER		06
07	0503010691	1/4" GREASE FITTING		01
08	0503010337	5/16" NUT		06
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0607025032	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0581013298	SUPPORT		01
02	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
03	0521018517	FLAT WASHER		01
04	0503010060	1/2" NUT		01
05	0503010019	1/2" SPRING WASHER		01
06	0503030483	FERTILIZER SOCKET		01
07	0503031050	CURVED CONDUCTOR		01
08	0503010246	CLAMP		01




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	175	01
02	0501052538	DEPTH BAND WITH ARMS	180	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	181	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	182	01
07	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	176	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	177	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	179	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	SCREWEW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL BOX	178	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL BOX	178	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	COVER DEPTH		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0511015976	FLAT WASHER		01
05	0503010257	1/8" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503010071	3/16" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	183	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	183	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0511052971	CONTROL DEPTH WITH SEMI MOUNTED THREAD	185	01
02	0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	188	01
03	0501052908	COMPACTOR WHEEL WITH BEARING	183	02
04	0503010019	1/2" SPRING WASHER		06
05	0503010752	1/2" X 3.1/2" BOLT		01
06	0503013739	1/2" X 1" BOLT		01
07	0503010479	BOLT		02
08	0503010060	1/2" NUT		04
09	0503030012	HAIR PIN		01
10	0571013222	FIXING CHOCK		01
11	0503010741	1/2" X 2-3/4" BOLT		02
12	0511055819	DEPTH WHIT AROS BAND	192	02
13	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
14	0503013816	5/16" LOCKNUT		08




Item	Code	Description	See page	QT
01	0521063808	DEPTH CONTROL INNER COLUMN CONTROL WITH SCREW		01
02	0521063809	DEPTH CONTROL EXTERNAL COLUMN CONTROL WITH SCREW		01
03	0571013194	REGULATOR SPINDLE		01
04	0551010616	ROD HEX		01
05	0503010683	0,2" X 1,2" SPRING PIN		01
06	0571013202	REGULATOR AXLE WHEELS COBRIDORA		01
07	0521063812	REGULATOR LEVER ALXE		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		01
09	0511065308	LOCK REGULATOR		01
10	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
11	0541011627	FLAT WASHER		01
12	0503010140	1/8" X 3/4" COTTERPIN		01
13	0511059325	LEFT ARM WHEELS	186	01
14	0511059324	RIGHT ARM COATING WHEEL MOUNTED	187	01
15	0571014709	SLEEVE LOCK CONTROL ARM		02
16	0503011440	SPRING WASHER		03
17	0503819099	BOLT		02
18	0511051546	CUBE RIGHT CONTROL DEPTH	189	01
19	0511051547	LEFT CUBE CONTROL DEPTH	190	01
20	0503011442	3/4" SPRING WASHER		02
21	0571013189	SLEEVE SUPPORT BEATER		01
22	0521063813	WHEEL PRESS BEATER		01
23	0501010937	13.5 X 28 X 3 FLAT WASHER		01
24	0503010920	1/2" X 1.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502012844	LEFT ARM WHEELS		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	GLOVE SUPPORT ARM WHEEL COBRIDORA		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012843	RIGHT WHEEL ARM		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	GLOVE SUPPORT ARM WHEEL COBRIDORA		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012850	PRESS WHEELS ARM		01
02	0503030883	RIGHT TORSION SPRING		01
03	0502011066	PRESS WHEELS ARM SUPPORT		01
04	0531017415	1" X 4.72" AXLE JOINT		01
05	0503010839	03"X 0.6" SPRING PIN		01
06	0521063841	REGULATOR RIGHT COMPACTOR		01
07	0521063842	REGULATOR LEFT COMPACTOR		01
08	0503811404	BOLT		02
09	0503011443	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0571013295	ALXE REGULATOR COMPACTOR		01
12	0521063812	REGULATOR LEVER ALXE		01
13	0503011336	1/2" HEX SELF ADJUSTING NUT		02
14	0511065308	LOCK REGULATOR		01
15	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
16	0541011627	FLAT WASHER		01
17	0503010140	1/8" X 3/4" COTTERPIN		01
18	0571013293	SLEEVE LOCK COMPACTOR V CONTROL WITH SCREW		01
19	0503811172	BOLT		01
20	0503010002	1800 GREASE FITTING		01
21	0581013744	PROTECTION COVER - CPRA		01
22	0503813096	BOLT		01
23	0503013816	5/16" LOCKNUT		0




Item	Code	Description	See page	QT
01	0511051583	DEPTH WHEEL HUB SEMIFINISHED	191	01
02	0511066638	AXLE WHEEL RIGHT DEPTH WITH DOOR DUST		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	COVER DEPTH		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0511051583	DEPTH WHEEL HUB SEMIFINISHED	191	01
02	0511066637	AXLE WHEEL LEFT DEPTH WITH DOOR DUST		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	COVER DEPTH		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0502011907	DEPTH CONTROL WHEEL HUB		01
02	0503010269	6204 BALL BEARING		02
03	0501013636	SPACING SLEEVE		01
04	0503010689	SEAL 00763-BR		01
05	0503011105	SEAL RING		01
06	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER SPINDLE		01
02	1902070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503030379	LARGER ROCKER ARM		01
02	0502060001	PLASTIC PULLEY FOR MAIZE		01
03	0503010669	FLAT WASHER		01
04	0503010667	3/16" NUT		02
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		01




Item	Code	Description	See page	QT
01	0521067063	SPRING BOX HDA		01
02	0511059396	SCARIFIER SPINDLE WITH POINT	196	01
03	0581812084	LARGE BUSHING		01
04	0503012795	5/8" HEX SELF ADJUSTING NUT		01
05	0581812082	BOLT FIXER		01
06	0503810417	NUT		01
07	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
08	0503034106	80 X 230 X 16,50 HDA COMPRESSSION SPRING		01
09	0503010691	1/4" GREASE FITTING		01
10	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
11	0571018541	BODY SOCKET FERTILIZER		01
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
13	0501010984	FLAT WASHER		04
14	0503010026	3/8" NUT		02
15	0503010025	3/8" SPRING WASHER		02
16	0503010384	1/2" X 5" BOLT		02
17	0511017302	FLAT WASHER		04
18	0503010547	1/2" X 4" BOLT		02
19	0503011336	1/2" HEX SELF ADJUSTING NUT		04
20	0571019462	SUPPORT GUIDE PRING		01
21	0581812081	SMALLER BUSHING		01
22	0581012094	SUPPORT WASHER		01




Item	Code	Description	See page	QT
01	0501110849	STEM WITH BEAK		01
01A	0521067064	ROD WITHOUT BEAK AUTO DISARM HDA		01
01B	0521066870	POINT SUBSOILER		01
01C	0503016853	SPRING PIN		02
01D	0503011402	0.2" X 0.8" SPRING PIN		02
02	0581012092	AXLE FIXER		01
03	0581012093	WASHER		02
04	0503010406	501025 CLAMPING RING (FOR AXLE)		02
05	0521067065	FLANGE WASHER SPRING		01




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010365	NUT		02




Item	Code	Description	See page	QT
01	0521068567	BOX SPRING		01
02	0521050364	ROD WITH BEAK	199	01
03	0503034106	80 X 230 X 16,50 HDA COMPRESSION SPRING		01
04	0581012094	SUPPORT WASHER		01
05	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
06	0571019462	SUPPORT GUIDE PRING		01
07	0581012081	GLOVE		01
08	0581012084	ARTICULATED GLOVE		01
09	0581012082	SCREW		01
10	0503012795	5/8" HEX SELF ADJUSTING NUT		01
11	0503010691	1/4" GREASE FITTING		01
12	0503010384	1/2" X 5" BOLT		02
13	0511017302	FLAT WASHER		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0503017874	BOLT 1/2 UNC		02
16	0571018541	BODY SOCKET FERTILIZER		01
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
18	0501010984	FLAT WASHER		04
19	0503010025	3/8" SPRING WASHER		02
20	0503010026	3/8" NUT		02
21	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
22	0503010417	7/8" NUT		01




Item	Code	Description	See page	QT
01	0501110865	ROD WITH BEAK HDA	200	01
02	0521067065	FLANGE WASHER SPRING		01
03	0581012092	AXLE FIXER		01
04	0581012093	WASHER		02
05	0503010406	501025 CLAMPING RING (FOR AXLE)		02




Item	Code	Description	See page	QT
01	0521067524	ROD WITHOUT BEAK AUTO DISARM HDA		01
02	0521066870	POINT SUBSOILER		01
03	0503016853	SPRING PIN		02
04	0503011402	0.2" X 0.8" SPRING PIN		02



Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01




Item	Code	Description	See page	QT
01	0511053904	DISC LINE MARKER	204	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04

ASSY HEX AXLE


0909098671




Item	Code	Description	See page	4880	5340	5950	6850
01	0521013430	HEX AXLE 5/8 X 2580	001	000	000	000	000
01.	0571017426	HEX AXLE	000	001	000	000	000
01..	0541019101	HEX AXLE 5/8 X 3110	000	000	001	000	000
01...	0571017031	AXLE HEX	000	000	000	001	001
02	0521013434	HEX AXLE 5/8 X 2300	001	000	000	000	000
02.	0571017424	5/8" X 2530 HEX AXLE	000	001	000	000	000
02..	0541019102	HEX AXLE 5/8 X 2830	000	000	001	000	000
02...	0571017029	AXLE HEX	000	000	000	001	001
03	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"	002	002	002	002	002
04	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8	002	002	002	002	002
05	0503010003	1845 GREASE FITTING	002	002	002	002	002
06	0503010365	NUT	004	004	004	004	004
07	0501010984	FLAT WASHER	004	004	004	004	004
08	0501010694	8.5 X 18 X 1.5 FLAT WASHER	008	008	008	008	008
09	0503010179	5/16" ZN SPRING WASHER	004	004	004	004	004
10	0503010337	5/16" NUT	004	004	004	004	004
11	0511815098	FLAT WASHER	002	002	002	002	002
12	0511017305	FLAT WASHER	004	004	004	004	004
13	0511065562	20Z GEAR	002	002	002	002	002
14	0502011299	BUSHING GEAR	002	002	002	002	002
15	0503010571	1/4" X 1.1/2 COTTERPIN	002	002	002	002	002
16	0503010010	1/4" X 2.1/2" COTTERPIN	002	002	002	002	002




Item	Code	Description	See page	QT
01	0511058996	ASSEMBLY CSU	207	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RH SUPPORT TOWER SILO	215	01
07	0521051931	LH SUPPORT TOWER SILO	216	01
08	0521051927	TOWER SUPPORT HOPPER	217	02




Item	Code	Description	See page	QT
01	0503061899	REAR BEAN FERTILIZER ASSY		02
02	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS		02
03	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	214	11
04	0501010942	3/8" X 1-1/4" BOLT		44
05	0503010025	3/8" SPRING WASHER		52
06	0503010026	3/8" NUT		52
07	0501011643	3/8 X 1"BOLT		04
08	0571015773	SUPPORT SEED CSU		01
09	0521063401	SEED BOX ONLY FIXING LOCK		04
10	0501010984	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511057919	ASSEMBLY CSU C3 2 BOXES 7B WITH 11 5340	209	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RH SUPPORT TOWER SILO	215	01
07	0521051931	LH SUPPORT TOWER SILO	216	01
08	0521051927	TOWER SUPPORT HOPPER	217	02




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		04
02	0501010984	FLAT WASHER		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	214	11
06	0571015773	SUPPORT SEED CSU		03
07	0501011643	3/8 X 1"BOLT		12
08	0501010942	3/8" X 1-1/4" BOLT		44
09	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0511058802	ASSEMBLY CSU C3 2 BOXES 7B WITH 13 C 211 5720/6350		01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RH SUPPORT TOWER SILO	215	01
07	0521051931	LH SUPPORT TOWER SILO	216	01
08	0521051927	TOWER SUPPORT HOPPER	217	02




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		04
02	0501010984	FLAT WASHER		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	214	13
06	0571015773	SUPPORT SEED CSU		01
07	0501011643	3/8 X 1"BOLT		04
08	0501010942	3/8" X 1-1/4" BOLT		52
09	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0511059478	ASSEMBLY CSU C3 2 BOXES 7B WITH 14	213	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521051931	LH SUPPORT TOWER SILO	216	01
07	0521051927	TOWER SUPPORT HOPPER	217	03




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		04
02	0501010984	FLAT WASHER		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	214	14
06	0501010942	3/8" X 1-1/4" BOLT		56
07	0503010025	3/8" SPRING WASHER		56
08	0503010026	3/8" NUT		56
09	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION	01	
02	0501010942	3/8" X 1-1/4" BOLT	01	
03	0503010025	3/8" SPRING WASHER	01	
04	0501010984	FLAT WASHER	01	
05	0503010209	3/8" UNC BUTTERFLY NUT	01	
06	0521066332	CONDUCTOR WITH FLANGE	01	
07	0503010371	5/16" X 1" BOLT	02	
08	0501010694	8.5 X 18 X 1.5 FLAT WASHER	02	
09	0503010179	5/16" ZN SPRING WASHER	02	
10	0503010337	5/16" NUT	02	
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT	01	




Item	Code	Description	See page	QT
01	0521066206	RH SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066207	LH SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066208	SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02



Item	Code	Description	See page	QT
01	0503062798	KIT MONITORING SEED 13L 45/50 PM400 PM413SSM		01
01A	0503016559	13 ROW SIMPLE CABLE MONITORING		01
01B	0503019100	SENSOR		13
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503013100	NYLON CLAMP		65
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		195
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
08	0503010669	FLAT WASHER		02
09	0503010668	3/16" SPRING WASHER		02
10	0503010667	3/16" NUT		02



Item	Code	Description	See page	QT
01	0503016491	MONITOR PLANT PM100		01
02	0503017031	CLEANING BRUSH		01
03	0503016557	11 ROW SIMPLE MONITOR CABLE		01
04	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		165



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

