

ROW CROP PLANTERS

PST PLUS FLEX - FRAME 4045 - CSU - WITHOUT LUBRIFICATION (UP TO 03/2022)

Code: 0501092666
Series: S-0116
Revision: 00
Date Revision: JUNHO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111380303	PST PLUS FLEX 4045/9E450 SPT CI MH DC20 CSU S/LUB S-0116

ATTENTION: IMPORTANT


Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.

INDEX

0909098811	4045 - FRAME ASSY	1
0511057303	FRAME WITH WHEEL AXLE - 4045	2
0511057305	FERTILIZER BOX ASSEMBLY - 4045	3
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	4
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	5
0511057307	PLATFORM ASSEMBLY - 4045	6
0511058658	TRANSMISSION ASSEMBLY - 4045	7
0501058241	WHEEL SUPPORT CHAIN TENSIONER	8
0501052560	MOTOR AXLE SIGNAL	9
0511051434	TRANSMISSION ACTUATOR	10
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	11
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	12
0501053788	3/4 SQUARE AXLE FASTENER	13
0501056271	GEARBOX CLOSED BEARING	14
0511057265	TRANSMISSION CHAIN TENSIONER	15
0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	16
0511050652	CHAIN TENSIONER	17
0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	18
0521055335	RIGHT GEAR HOUSING SET	19
0521055337	LEFT GEAR HOUSING SET	20
0511058382	LEFT GEAR HOUSING	21
0511058381	RIGHT GEAR HOUSING	22
0501048790	AXLE WITH RING	23
0501056443	GEAR HOUSING BEARING	24
0511057258	TENSIONER WITH GEAR	25
0511054363	CHAIN TENSIONER	26
0511058827	SINGLE SEED BOX - 4045/9 E450	27
0511058828	2 BOXES WITH 9 CONDUCTORS ASSEMBLY	28
0511057311	SEMI-ASSEMBLED HYDRAULIC MARKER - 4045	29
0511058449	HYDRAULIC CYLINDER	30
0501054649	HBM SEQUENTIAL VALVE	31
0511058119	VALVE SUPPORT ASSEMBLY	32
0501053834	MALE QUICK COUPLER	33
0521056500	FRONT SHORT SEED ROW WITH RIGHT TRANSMISSION WITHOUT LUBRIFICATION	34
0909098810	SEED ROW/FERTILIZER WITHOUT LUBRICATION ASSY	34
0521056501	FRONT LONG SEED ROW WITH RIGHT TRANSMISSION WITHOUT LUBRIFICATION	35
0511057159	TRANSMISSION BOX SEED ROW	36
0511058766	BEARING	37
0511059872	BEARING	38
0511057269	CHAIN TENSIONER	39
0511058512	PROTECTION COVER	40
0521054770	RIGHT REAR SEED ROW	41
0521054771	LEFT REAR SEED ROW	42
0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	43
0521054762	RIGHT DDD SEED	44
0521054763	DDD LEFT SEED	45
0511052302	LH SUPPORT DDD GUIDE	46
0511052301	SUPPORT DDD 15 RIGHT	47
0521054761	LEFT LOW CUBE	48
0521054760	DOWN LOW CUBE	49
0521055338	ROW SEED BEARING	50
0501053566	ROW SEED BEARING	51
0511059312	BEARING TRANSMISSION SEED	52


INDEX


0511059023	SEED SYSTEM ASSY		53
0501051094	ASSY SEED DISTRIBUTOR		54
0501051119	DOUBLE PULLEY ROCKER'S		55
0521054984	DEPTH/COMPACTOR SYSTEM - SPT		56
0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION		57
0501052297	DEPTH WHEELS REGULATOR ASSY		58
0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION		59
0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION		60
0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION		61
0521055033	SEMI-ASSEMBLED COMPACTOR BODY		62
0521056477	SHORT FERTILIZER ROW DC20 WITHOUT LUBRICATION		63
0521056479	LONG DC20 FERTILIZER ROW WITHOUT LUBRICATION		64
0521056476	DC 20" ASSY		65
0521053697	CUTTING DISK BOX		66
0521054769	LEFT DDD FERTILIZER WITH SUPPORT		67
0521054768	RIGHT DDD FERTILIZER WITH SUPPORT		68
0521054765	DDD LEFT FERTILIZER		69
0521054764	DDD RIGHT FERTILIZER		70
0521050525	FIXER FERTILIZER CONDUCTOR		71
0521050560	ASSY HOSE SUPPORT 3"		72
0501110804	SCARIFIER ROD WITH POINT		73
0501050120	LARGER WALKING BEAM ASSY		74
0511052024	FAST CLOSING SET		75




Item	Code	Description	See page	4045
01	0511057303	FRAME WITH WHEEL AXLE - 4045	2	01
02	0511057307	PLATFORM ASSEMBLY - 4045	6	01
03	0511057305	FERTILIZER BOX ASSEMBLY - 4045	3	01
04	0511058827	SINGLE SEED BOX - 4045/9 E450	27	01
05	0909098810	SEED ROW/FERTILIZER WITHOUT LUBRICATION ASSY	34	09
06	0909091038	HEX AXLE ASSEMBLY		01
07	0511058653	WHEELS WITH TRACTION SPRING		04
08	0511056536	LADDER ASSEMBLY		02
09	0511054971	JACK ASSEMBLY		02
10	0511054601	HITCH ARTICULATED TRACTOR		01
11	0511057333	DRAWBAR ASSEMBLY 3495/4045/4395/4845/5345/5745	-	01
12	0511057270	DRAWBAR EXTENDER		01
13	0511058655	CYLINDER SET - 3245/3495/4045/4395		01
14	0501068994	8,30 X 78 LOCK PIN		01
15	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
16	0501047895	ROD STOP		01
17	0501047885	ROD STOP		01
18	0501047886	ROD STOP		01
19	0501047887	ROD STOP		01
20	0511056736	HOSE SUPPORT		01
21	0501065677	STRUT		02
22	0503030168	HITCH PIN CLIP		01
23	0503032624	FERTILIZER BOX GUTTER		05
24	0511057266	HYDRAULIC SYSTEM ASSEMBLY 3245/3495/4045/4395	-	01
25	0503010003	1845 GREASE FITTING		04
26	0511053179	TRACTOR COUPLING SHAFT		01
26A	0521064036	TRACTOR HITCH AXLE		01
26B	0503030012	HITCH PIN CLIP		01
27	0521013022	TRANSPORT LOCK		01

Item	Code	Description	See page	4045
28	0503010780	N-2050 AMENDMENT		02
29	0503010951	REDUCTION		04
30	0511057311	SEMI-ASSEMBLED HYDRAULIC MARKER - 4045	29	01
31	0511057845	MANUAL CANISTER		01
32	0511057834	LABELS KIT - 4045		01
33	0511059322	LIFTING SUPPORT ASSEMBLY		02
34	0511058658	TRANSMISSION ASSEMBLY - 4045	7	01
35	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		02
36	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
37	0511017302	FLAT WASHER		04
38	0503010019	1/2" SPRING WASHER		04
39	0503010060	1/2" NUT		04







Item	Code	Description	See page	QT
01	0511057309	BOX SUPPORT WITH DISTRIBUTOR - 4045		01
02	0503062391	FERTILIZER BOX		02
03	0503013751	3/8 UNC X 1.1/4 BOLT		16
04	0571019051	FIXER BOX WASHER		16
05	0503012535	3/8" SPRING WASHER		16
06	0503012531	3/8" INOX NUT		16
07	0503011957	NYLON LUG		02
08	0503010371	5/16" X 1" BOLT		04
09	0503010179	LOCK WASHER		04
10	0503010337	5/16" NUT		04
11	0503034396	FERTILIZER SIDE COVER		10
12	0503010362	1/8 X 1.1/4 COTTERPIN		10
13	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		10
14	0501010984	FLAT WASHER		20
15	0503010025	3/8" SPRING WASHER		10
16	0503010026	3/8" NUT		10




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01



Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0571018866	SET PLATFORM 4045		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	FLAT WASHER		16
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2" NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2" NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	8	04
13	0571018906	AXLE MOTOR 1950		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	9	02
16	0511051434	TRANSMISSION ACTUATOR	10	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	11	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	12	01
19	0511061759	22Z P12,70 FQ 3/4" GEAR		02
20	0501053788	3/4 SQUARE AXLE FASTENER	13	02
21	0503030303	SUPPORT WASHER		04
22	0501056271	GEARBOX CLOSED BEARING	14	02
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
24	0501010984	FLAT WASHER		08
25	0503010025	3/8" SPRING WASHER		04
26	0503010026	3/8" NUT		04
27	0511057265	TRANSMISSION CHAIN TENSIONER	15	02
28	0521010773	0.37" X 1.18" COUPLING SHAFT		02
29	0501010984	FLAT WASHER		06
30	0503010140	1/8" X 3/4" COTTERPIN		02
31	0571018846	DISASSEMBLE LEVER		02


Item	Code	Description	See page	QT
32	0503033942	COVER REGULATORY WHEEL		02
33	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
34	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
35	0503030093	TRACTION SPRING		02
36	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
37	0503012412	5/8 UNC SELF LOCKING NUT		04
38	0511061759	22Z P12,70 FQ 3/4" GEAR		02
39	0501053788	3/4 SQUARE AXLE FASTENER	13	02
40	0503030275	AGRICULTURAL BEARING		02
41	0501056271	GEARBOX CLOSED BEARING	14	02
42	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
43	0501010984	FLAT WASHER		08
44	0503010025	3/8" SPRING WASHER		04
45	0503010026	3/8" NUT		04
46	0511057265	TRANSMISSION CHAIN TENSIONER	15	02
47	0511065209	20Z GEAR		02
48	0501053788	3/4 SQUARE AXLE FASTENER	13	02
49	0503030303	SUPPORT WASHER		02
50	0503010292	0.2" X 1.6" SPRING PIN		02
51	0521018630	1.4" X SQUARE 0.8" WASHER		02
52	0501056271	GEARBOX CLOSED BEARING	14	02
53	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
54	0501010984	FLAT WASHER		08
55	0503010025	3/8" SPRING WASHER		04
56	0503010026	3/8" NUT		04
57	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	16	02
58	0511050652	CHAIN TENSIONER	17	04
59	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	18	02
60	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
61	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
62	0503015001	40-1 X 153 CHAIN LINK + MENDING		02
63	0511069678	LH LOWER LEVER		02
64	0551019159	LEVER FIXER BODY		02
65	0561016468	FASTENER		02
66	0503011336	1/2" HEX SELF ADJUSTING NUT		04
67	0501010984	FLAT WASHER		04
68	0503010140	1/8" X 3/4" COTTERPIN		04
69	0521055335	RIGHT GEAR HOUSING SET	19	01
70	0521055337	LEFT GEAR HOUSING SET	20	01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		03
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0541011713	TENSIONER CHAIN LOWER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551019171	CHAIN TIGHTENER AXLE		01
02	0503011410	ROLLER BEARING		01
03	0511062169	21Z P 1/2" GEAR		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503011105	SEAL RING		01
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0571010265	16.5 X 40 X 3 FLAT WASHER		01
08	0503012412	5/8 UNC SELF LOCKING NUT		01



Item	Code	Description	See page	QT
01	0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING		01
02	0511063185	20Z GEAR WITH HEX HOLE AXLE 20		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010365	NUT		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0511058381	RIGHT GEAR HOUSING	22	01
02	0521065955	RH GEAR BOX COVER		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0503010019	1/2" SPRING WASHER		01
07	0501010694	FLAT WASHER		06
08	0511017302	FLAT WASHER		01



Item	Code	Description	See page	QT
01	0511058382	LEFT GEAR HOUSING	21	01
02	0521065956	LH GEAR BOX COVER		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0511017302	FLAT WASHER		01
07	0503010019	1/2" SPRING WASHER		01
08	0501010694	FLAT WASHER		06

LEFT GEAR HOUSING

0511058382




Item	Code	Description	See page	QT
01	0521065940	LEFT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN AXLE CONE		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
05	0503010060	1/2" NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING		01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING	14	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER		06
14	0503010179	LOCK WASHER		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TENSIONER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	23	02
20	0503031367	SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	24	01
31	0503010292	0.2" X 1.6" SPRING PIN		08

Item	Code	Description	See page	QT
32	0511057258	TENSIONER WITH GEAR	25	01
33	0511054363	CHAIN TENSIONER	26	01
34	0571018901	DRIVEN AXLE		01


RIGHT GEAR HOUSING

0511058381




Item	Code	Description	See page	QT
01	0521065939	RIGHT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN AXLE CONE		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04
05	0503010060	1/2" NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING		01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING	14	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER		06
14	0503010179	LOCK WASHER		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TENSIONER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	23	02
20	0503031366	RIGHT TWISTED SPRING RECAMBIO		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	24	01
31	0503010292	0.2" X 1.6" SPRING PIN		08


Item	Code	Description	See page	QT
32	0511057258	TENSIONER WITH GEAR	25	01
33	0511054363	CHAIN TENSIONER	26	01
34	0571018901	DRIVEN AXLE		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING		01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0571019207	DEVIATION AXLE GEAR BOX		01
06	0503010899	5/8" X 2-1/4" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0511058828	2 BOXES WITH 9 CONDUCTORS ASSEMBLY	28	01
02	0521066102	TOWER SUPPORT HOPPER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8 UNC SELF LOCKING NUT		08
10	0571019393	PROTECTOR		02
11	0551019884	45 X 50 X 3/8 FASTENER		08
12	0501010453	FLAT WASHER		16
13	0503010025	3/8" SPRING WASHER		16
14	0503010026	3/8" NUT		16
15	0521066211	PROTECTOR CENTRAL		01
16	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
17	0501013519	FLAT WASHER		04
18	0503010019	1/2" SPRING WASHER		04
19	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521064748	05 NOZZLES SINGLE SEED BOX SUPPORT		02
02	0503061987	05 NOZZLES FERTILIZER BOX		02
03	0521063401	SEED BOX ONLY FIXING LOCK		04
04	0501010984	FLAT WASHER		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR		09
08	0501010942	3/8" X 1-1/4" BOLT		36
09	0503010025	3/8" SPRING WASHER		36
10	0503010026	3/8" NUT		36
11	0571015773	SUPPORT SEED		01
12	0501011643	3/8 X 1"BOLT		04
13	0503010025	3/8" SPRING WASHER		04
14	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
03	0503012412	5/8 UNC SELF LOCKING NUT		04
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0511058449	HYDRAULIC CYLINDER	30	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" COTTERPIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501069643	890 TURNBUCKLE		02
21	0503011854	5/8" X 1-1/4" BOLT		04
22	0501054649	HBM SEQUENTIAL VALVE	31	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	FLAT WASHER		02
25	0503010025	3/8" SPRING WASHER		02
26	0511058119	VALVE SUPPORT ASSEMBLY	32	01
27	0501053834	MALE QUICK COUPLER	33	02
28	0502012702	BODY SUPPORT CLAMP		08
29	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		08
30	0503010180	7/16" SPRING WASHER		08
31	0503010244	7/16" NUT		02


Item	Code	Description	See page	QT
32	0571014419	PLASTIC PROTECTION SPRING HOSE 3/4 X 700MM		04
33	0511057312	HOSE KIT MARKER HYDRAULIC		
33A	0501081727	TR-TR HOSE ASSY		02
33B	0501080408	HOSE 3/8 X 3200 TR-TC		02
34	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
34A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
34B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
34C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
34D	0503018952	PLASTIC BOLT		06
35	0521052850	3/8 X 4200 TC-TM PURPLE/BUE HOSE		01
35A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
35B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
35C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
35D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02



Item	Code	Description	See page	QT
01	0581010011	VALVE FIXING SUPPORT		01
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
03	0501010984	FLAT WASHER		04
04	0503010025	3/8" SPRING WASHER		02
05	0503010026	3/8" NUT		02



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
001	0521065941	FRAME SEED ROW FRONT		01
002	0502012789	FIXER SUPPORT FERTILIZER ROW		01
003	0503010811	5/8" UNF SELF ADJUSTING NUT		04
004	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
005	0503012412	5/8 UNC SELF LOCKING NUT		04
006	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
007	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
008	0571018883	PIN FIXER SPRING		03
009	0571018884	LOCK PIN ROW ARTICULAT		01
010	0503030168	HITCH PIN CLIP		04
011	0511058766	BEARING	37	01
012	0511057159	TRANSMISSION BOX SEED ROW	36	01
013	0571012492	5/8 X 330 AXLE HEX		01
014	0501056296	UNIVERSAL JOINT		01
015	0503011855	0.2" X 1.8" SPRING PIN		03
016	0521065942	FRAME REAR SHORT ROW SEED		01
017	0511059872	BEARING	38	01
018	0581010239	SEED ROW AXLE TRANSMISSION		01
019	0521011859	FLAT WASHER		02
020	0581011694	PROTECTION REAR COVER SEED ROW		01
021	0503010765	3/8" X 3" BOLT		01
022	0503010025	3/8" SPRING WASHER		01
023	0503010026	3/8" NUT		01
024	0501012140	FLAT WASHER		08
025	0511058512	PROTECTION COVER	40	01
026	0581011430	DRAWBAR ASSY		01
027	0581010976	5/8" HEX AXLE		01
028	0503032984	HOOD HEX AXLE ROW		01
029	0503013100	NYLON CLAMP		01
030	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
031	0511057269	CHAIN TENSIONER	39	01



**PST PLUS FLEX - FRAME 4045 - CSU - WITHOUT
FRONT SHORT SEED ROW WITH RIGHT TRANSMISSION**


Page 34
0521056500

Item	Code	Description	See page	QT
032	0503017857	BOLT 5/8 UNF 4		04
033	0591011156	PIVOT ARM SEED ROW		02
034	0591011157	SPACER LOWER SLEEVE		08
035	0503019273	SLEEVE		08
036	0503010045	O'RING		08



Item	Code	Description	See page	4045
01	0521056500	FRONT SHORT SEED ROW WITH RIGHT 34	01	
		TRANSMISSION WITHOUT LUBRIFICATION		
02	0521056501	FRONT LONG SEED ROW WITH RIGHT 35	01	
		TRANSMISSION WITHOUT LUBRIFICATION		
03	0521054770	RIGHT REAR SEED ROW	41	01
04	0521054771	LEFT REAR SEED ROW	42	01
05	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02
08	0503010246	CLAMP		02
09	0511059023	SEED SYSTEM ASSY	53	01
10	0521054984	DEPTH/COMPACTOR SYSTEM - SPT	56	01
11	0521056477	SHORT FERTILIZER ROW DC20 WITHOUT 63	01	
		LUBRICATION		
12	0521056479	LONG DC20 FERTILIZER ROW WITHOUT 64	01	
		LUBRICATION		
13	0521054769	LEFT DDD FERTILIZER WITH SUPPORT	67	01
14	0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	68	01
15	0503030391	RIGHT FERTILIZER NOZZLE		01
16	0503030392	LEFT FERTILIZER NOZZLE		01
17	0503031145	2" X 2" X 20" HOSE		01
18	0503031076	2" HOSE CLAMP		02
19	0521050525	FIXER FERTILIZER CONDUCTOR	71	02
20	0521050560	ASSY HOSE SUPPORT 3"	72	01
21	0501010984	FLAT WASHER		04
22	0503010025	3/8" SPRING WASHER		02
23	0503010026	3/8" NUT		02
24	0503010905	1/2" X 2-1/4" BOLT		02
25	0531013600	PRESS ADJUSTMENT LEVER		01
26	0501110804	SCARIFIER ROD WITH POINT	73	04
27	0521069127	BOTTOM NOZZLE FERTILIZER		01
28	0503031050	CURVED CONDUCTOR		01

Item	Code	Description	See page	4045
29	0511017969	0.1" SPACING PLATE		01
30	0511018662	SPACING PLATE		01
31	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
32	0503016204	CORN DISK 12 ORANGE		09
33	0503016214	RING CORN (APOLLO740)		09
34	0503016218	DISC OF SOYBEAN		09
35	0503016220	RING TO SOYBEANS (APOLLO 745)		09
36	0503016221	RING TO SOYBEANS (APOLLO 571)		09
37	0501050120	LARGER WALKING BEAM ASSY	74	09
38	0503030558	PULLEY 4Z CORN PLASTIC		01
39	0511052024	FAST CLOSING SET	75	01
40	0503033672	NOZZLE WITHOUT TITANIUM		01
41	0503030520	SEED SOCKET		01
42	0521068982	KEY CASH DISC CUTTING		01




Item	Code	Description	See page	QT
001	0521065941	FRAME SEED ROW FRONT		01
002	0502012789	FIXER SUPPORT FERTILIZER ROW		01
003	0503010811	5/8" UNF SELF ADJUSTING NUT		04
004	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
005	0503012412	5/8 UNC SELF LOCKING NUT		04
006	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
007	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
008	0571018883	PIN FIXER SPRING		03
009	0571018884	LOCK PIN ROW ARTICULAT		01
010	0503030168	HITCH PIN CLIP		04
011	0511058766	BEARING	37	01
012	0511057159	TRANSMISSION BOX SEED ROW	36	01
013	0571012492	5/8 X 330 AXLE HEX		01
014	0501056296	UNIVERSAL JOINT		01
015	0503011855	0.2" X 1.8" SPRING PIN		03
016	0521065943	REAR FRAME LONG ROW SEED		01
017	0511059872	BEARING	38	01
018	0581010240	SEED ROW AXLE TRANSMISSION		01
019	0521011859	FLAT WASHER		02
020	0581011694	PROTECTION REAR COVER SEED ROW		01
021	0503010765	3/8" X 3" BOLT		01
022	0503010025	3/8" SPRING WASHER		01
023	0503010026	3/8" NUT		01
024	0501012140	FLAT WASHER		08
025	0511058512	PROTECTION COVER	40	01
026	0581011430	DRAWBAR ASSY		01
027	0581010976	5/8" HEX AXLE		01
028	0503032984	HOOD HEX AXLE ROW		01
029	0503013100	NYLON CLAMP		01
030	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
031	0511057269	CHAIN TENSIONER	39	01




PST PLUS FLEX - FRAME 4045 - CSU - WITHOUT
FRONT LONG SEED ROW WITH RIGHT TRANSMISSION

Page 35
0521056501


Item	Code	Description	See page	QT
032	0503017857	BOLT 5/8 UNF 4		04
033	0591011156	PIVOT ARM SEED ROW		02
034	0591011157	SPACER LOWER SLEEVE		08
035	0503019273	SLEEVE		08
036	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB	01	
02	0502012464	BOX TRANSMISSION COVER	01	
03	0503016995	6006 BALL BEARING	02	
04	0503015895	6005 Z BALL BEARING	01	
05	0503010143	1/4" SPRING WASHER	03	
06	0503011378	M6X1X16 C S 8.8 ZN BOLT	03	
07	0503010406	501025 CLAMPING RING (FOR AXLE)	01	
08	0503010707	501030 CLAMPING RING (FOR AXLE)	02	
09	0502040856	CONICAL GEAR	01	
10	0571018870	14Z CONICAL GEAR	01	
11	0503011105	SEAL RING	01	
12	0503011409	6005 Z BALL BEARING	01	
13	0503017008	SEAL RING	01	
14	0503017007	SEAL RING	02	
15	0511017907	1/8" BSPT X 6 PLUG	01	
16	0503010003	1845 GREASE FITTING	01	
17	0503035316	LUBRICATED POINTS ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0502012852	ROW SEED UPPER BEARING		01
02	0503011105	SEAL RING		01
03	0502012851	17Z GEAR WITH HEX HOLE		01
04	0503011410	ROLLER BEARING		02
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010237	3/8" X 1" BOLT		02
07	0503010025	3/8" SPRING WASHER		02
08	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0581012948	HOUSING BEARING		01
02	0503011105	SEAL RING		01
03	0581012949	BEARING COVER		01
04	0503011410	ROLLER BEARING		02
05	0503018045	2-130 (AGEL) O'RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0502012851	17Z GEAR WITH HEX HOLE		01
08	0503011953	5/16" X 1" BOLT		02
09	0501010694	FLAT WASHER		02
10	0503010179	LOCK WASHER		02
11	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0503031805	11Z 1/2" GEAR		01
02	0511017302	FLAT WASHER		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0521066693	CAP BEARING		01
02	0503010834	1/2 X 1 BOLT		02
03	0503010019	1/2" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	43	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0521055870	RIGHT DOUBLE DISC SEED 15 X 15		01




Item	Code	Description	See page	QT
01	0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	43	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0521055871	LEFT DOUBLE DISC SEED 15 X 15		01




Item	Code	Description	See page	QT
01	0581019201	CROWN SHAFT		01
02	0503019340	LUBRICANT SLEEVE		02
03	0503011030	2-014 N 3006-9B O'RING		02
04	0581019200	CONICA 40Z GEAR		01
05	0581019199	FIXED BASE		01
06	0581019202	PINHAO CONICO 10Z X 5/8		01
07	0501013354	FLAT WASHER		01
08	0503010410	RING		02
09	0503019341	LUBRICANT SLEEVE		01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	47	01
02	0521054761	LEFT LOW CUBE	48	01
03	0521054760	DOWN LOW CUBE	49	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0511815098	FLAT WASHER		04
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	46	01
02	0521054761	LEFT LOW CUBE	48	01
03	0521054760	DOWN LOW CUBE	49	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0511815098	FLAT WASHER		04
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502012736	HUB LOWER		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012736	HUB LOWER		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	ROW SEED BEARING	51	01
03A	0502012030	HOUSING BEARING		01
03B	0503012861	6006 2RS BALL BEARING		01
03C	0503012858	502075 CLAMPING RING (FOR HOLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02
07	0501013518	FLAT WASHER		02
08	0501010694	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0502012030	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		01
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0502012030	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		01
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0502020693	SUPPORT SEED BOX		01
02	0502012721	SEED DISC LOWER TRAIL		01
03	0503034131	DEFLECTOR		01
04	0503010025	3/8" SPRING WASHER		03
05	0503010209	3/8" UNC BUTTERFLY NUT		03
06	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
07	0571018536	HEX PRISONER		01
08	0501010984	FLAT WASHER		01
09	0503010337	5/16" NUT		01
10	0503010179	LOCK WASHER		05
11	0503062582	DEPOSIT SEED		01
12	0581011346	ADAPTER DEPOSIT		01
13	0501010694	FLAT WASHER		04
14	0503016282	ALLEN BOLT		01
15	0503016283	M8 NUT HEX		01
16	0501051094	ASSY SEED DISTRIBUTOR	54	01
17	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
18	0503016219	RING TO SOYBEANS		01
19	0503010675	5/16" X 2.1/4" BOLT		01
20	0503030083	3/8" X 3/8" X 1.6" STUD		02




Item	Code	Description	See page	QT
01	0503030381	SEED DISTRIBUTOR BOX		01
02	0502010447	TRIGGER		02
03	0501013467	KEY AXLE		01
04	0503030378	0.4" X 1.1" X 0.03" SPRING		03
05	0501013466	KEY LIMITER AXLE		01
06	0501051119	DOUBLE PULLEY ROCKER'S	55	01
07	0501013468	ROCKER ARM AXLE, OF THE PULLEY		01
08	0503030377	SCRAPER		01




Item	Code	Description	See page	QT
01	0503031129	DOUBLE PULLEY ROCKER ARM		01
02	0503031128	5Z PLASTIC DOUB PULLEY FOR SOYBEAN		02
03	0521010649	TOOTH PULLEY COUPLING SHAFT		01
04	0503011853	503050 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT 57 LUBRICATION	57	01
02	0501052538	DEPTH BAND WITH ARMS		02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0521054990	LEFT COMPACTOR WHEEL		01
06	0521055017	RIGHT COMPACTOR WHEEL		01




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	58	01
02	0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	59	01
03	0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	61	01
04	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	62	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	SCREEW 3/8 UNC X 3/4		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED SLEEVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	60	01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL BOX		01
02	0581019515	AXIS		01
03	0503034055	CLAMPING RING		01
04	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
05	0503013758	1/4" X 1-1/2" BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0503010878	5/8" SELF ALIGNING NUT		01
10	0503030757	2.9" X 2" X 0.02" JOINT		01
11	0521019178	COVER DEPTH		01




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	60	01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT SLEEVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0521065972	LH SHORT ARM ROW FERTILIZER		01
01A	0521065972	LH SHORT ARM ROW FERTILIZER		01
02	0503011255	3/4" LOCK NUT		02
03	0571019062	SLEEVE		01
04	0571019059	SUPPORT WASHER		01
05	0503034320	COMPRESSSION SPRING		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503011854	5/8" X 1-1/4" BOLT		02
08	0511016281	3/4" X 8" BOLT		02
09	0503017960	5/8" X 3-12" BOLT		04
10	0502012813	FLANGE WASHER SPRING		01
11	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
12	0503010417	7/8" NUT		02
13	0502012789	FIXER SUPPORT FERTILIZER ROW		01
14	0521056476	DC 20" ASSY	65	01
15	0503011254	7/8" HEX SELF ADJUSTING NUT		01
16	0591011145	FERTILIZER ROW SUPPORT		01
17	0503019278	LUBRICANT SLEEVE		02
18	0591011147	SLEEVE ARM ROW		02
19	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521065973	RH LONG ARM ROW FERTILIZER		01
01A	0511057271	RH LONG ARM ROW FERTILIZER		01
02	0503011255	3/4" LOCK NUT		02
03	0571019062	SLEEVE		01
04	0571019059	SUPPORT WASHER		01
05	0503034320	COMPRESSSION SPRING		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503011854	5/8" X 1-1/4" BOLT		02
08	0511016281	3/4" X 8" BOLT		02
09	0503017960	5/8" X 3-12" BOLT		04
10	0502012813	FLANGE WASHER SPRING		01
11	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
12	0503010417	7/8" NUT		02
13	0502012789	FIXER SUPPORT FERTILIZER ROW		01
14	0521056476	DC 20" ASSY	65	01
15	0503011254	7/8" HEX SELF ADJUSTING NUT		01
16	0591011146	SUPPORT LONG		01
17	0503019278	LUBRICANT SLEEVE		02
18	0591011147	SLEEVE ARM ROW		02
19	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
001	0571019034	FLANGE WASHER AXLE		01
002	0571019032	SUPPORT WASHER		01
003	0502012813	FLANGE WASHER SPRING		01
004	0591010619	DC SPRING SUPPORT		01
005	0503019274	WASHER		02
006	0581017628	COVER		02
007	0503019277	SLEEVE LUBRICATION SYSTEM		01
008	0501110964	RIGHT ARM WITH SLEEVE		01
009	0501110965	LEFT ARM WITH SLEEVE		01
010	0503034320	COMPRESSION SPRING		01
011	0591010624	SUPPORT ARM SLEEVE		01
012	0591010625	19,50 X 25 X 91,50/91,30 SLEEVE		01
013	0503010417	7/8" NUT		02
014	0503010390	SEAL RING		02
015	0503011198	C3/4" X 6" SCREW		01
016	0501010322	FLAT WASHER		01
017	0503011411	1/2" X 5-1/2" BOLT		01
018	0503010060	1/2" NUT		01
019	0503010019	1/2" SPRING WASHER		01
020	0503011255	3/4" LOCK NUT		01
021	0503030430	7/16 X 2" PIN LOCK		01
022	0503019271	SELF LUBRICATING BUSHING		01
023	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING		01
024	0503011254	7/8" HEX SELF ADJUSTING NUT		01
025	0521066743	REGULACION SPRING		01
026	0591011144	FIXATION AXLE		01
027	0591010628	DC AXIS BACKREST WASHER		01




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	CUTTING DISK BOX		01
09	0502040873	CUTTING DISC AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	48	01
03	0521054760	DOWN LOW CUBE	49	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511815098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	48	01
03	0521054760	DOWN LOW CUBE	49	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511815098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	NUT		02




Item	Code	Description	See page	QT
01	0521067601	LH REGULATOR		01
02	0521067600	FIXER SUPPORT		01
03	0521067602	GUIDE ASSY		01
04	0501012140	FLAT WASHER		02
05	0511015098	FLAT WASHER		01
06	0503010806	5/8" X 3" BOLT		01
07	0521069693	EAR FIXATION		01
08	0503012795	5/8" HEX SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01



Item	Code	Description	See page	QT
01	0503030379	LARGER ROCKER ARM		01
02	0502060001	PLASTIC PULLEY FOR MAIZE		01
03	0503010669	FLAT WASHER		01
04	0503010667	3/16" NUT		02
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		01



Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02



MARCHESAN

Technical Publications | Elaboration and Revision

JOSÉ DOMINGOS GASPARI

www.marchesan.com.br

