

ROW CROP PLANTERS

COP TRIO 650 SUPREMA P.P MINI HOPPER - FRAME 6850/7655 - CSC/APT/CBA

Code: 0501092684
Series: S-0419
Revision: 00
Date Revision: FEVEREIRO/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111420023	COP TRIO 650 SUP 6850/15E450 ESPECIAL S-0419
0111420042	COP TRIO 650 SUP 6850/15E450 ESPECIAL S-0419
0111420068	COP TRIO 650 SUP 6850/15E450 ESPECIAL S-0419
0111420043	COP TRIO 650 SUP 7655/17E450 ESPECIAL S-0419

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.

INDEX

0909098858	ASSY FRAME	1
0521056065	FRAME SHAFT	2
0521056111	FRAME WITH ARTICULATION 7655	3
0909098859	DRAWBAR ASSY - 5750/6350/6850/7655	4
0521045756	HYDRAULIC CYLINDER	5
0511057653	HYDRAULIC CYLINDER	6
0501053835	FEMALE QUICK COUPLER	7
0521050573	EXTENSOR 3RD POINT	8
0511057817	SUPPORT HOSE	9
0511055096	TRACTOR HITCH	10
0521050133	TURNBUCKLE SIDE 755/480	11
0521050574	EXTENSOR	12
0521057452	ASSY INTERMEDIATE DRAWBAR FIXATION SUPPORT	13
0501053834	MALE QUICK COUPLER	14
0521056088	WHEEL ASSY RIGHT FIXING EXTENSOR	15
0521057945	RIGHT WHEEL ASSY FASTENER EXTENSOR	16
0521056089	WHEEL ASSY LEFT FIXING EXTENSOR	17
0521057946	LEFT WHEEL ASSY FASTENER EXTENSOR	18
0521056090	RIGHT WHEEL ASSY	19
0521057820	WHEEL ASSEMBLY WITHOUT TRANSMISSION	20
0521056091	LEFT WHEEL ASSY	21
0521056092	LEFT WHEEL ASSEMBLY WITHOUT TRANSMISSION	22
0521056093	RIGHT WHEEL ASSEMBLY WITHOUT TRANSMISSION	23
0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH TRANSMISSION	24
0503063073	EE WHEEL WITH TIRE 7.00 X 16 14L ASSEMBLY	25
0521056100	WHEEL HUB ASSY WITH TRANSMISSION	26
0521056160	SIDE TRANSMISSION CURRENT STRETCHER	27
0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	28
0521056299	MOUNTED RIGHT STRETCHER	29
0521055238	BEARING TENSIONER CHAIN	30
0521056095	ARTICULATED BEARING WHEELED WITHOUT LUBRICATION	31
0501058239	WHEEL CHAIN TENSIONER BEARING	32
0521056101	EE WHEEL WITH TIRE 7.00X16 ASSY WITHOUT TRANSMISSION	33
0521056102	ASSY WHEEL HUB WITHOUT TRANSMISSION	34
0521056300	MOUNTED LEFT STRETCHER	35
0521057818	WHEEL WITH TIRE 7.00 X 16 14L ASSY WITHOUT TRANSMISSION	36
0521057819	ASSY WHEEL HUB WITHOUT TRANSMISSION	37
0521057817	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	38
0521056119	SQUARE AXIS ASSEMBLY 730	39
0501056271	GEARBOX CLOSED BEARING	40
0501056444	BEARING WITH ROLLER	41
0501053788	3/4 SQUARE AXLE FASTENER	42
0521056084	MOTOR SHAFT ASSEMBLY - 6850	43
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	44
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	45
0511051434	TRANSMISSION ACTUATOR	46
0521056085	PLATE BEARING ASSY	47
0521056121	HEX AXLE ASSEMBLY	48
0521056103	BEARING WITH GEAR 20Z HEX SHAFT 3/4	49
0521055498	SEED TRANSMISSION DOUBLE BEARING	50
0521056144	INTERMEDIATE SEED TRANSMISSION	51
0531054818	6850 APT HEX AXLE SET	52



MARCHESAN

INDEX

0531052779	BEARING WITH 26Z GEAR	53
0521056071	FERTILIZER HOPPER SET	54
0521056073	FERTILIZER BEAM SUPPORT	55
0521056072	CENTER FERTILIZER HOPPER SUPPORT	56
0521056074	LFT FERTILIZER BEAM SUPPORT	57
0531054819	6850 APT FERTILIZER HOPPER ASSEMBLY	58
0531054820	6850 APT FERTILIZER HOPPER CENTRAL SUPPORT	59
0521056435	7655 FERTILIZER HOPPER SET	60
0521056437	7655 RIGHT FERTILIZER HOPPER SUPPORT	61
0521056117	CENTRAL FERTILIZER HOPPER SUPPORT	62
0521056436	7655 LEFT FERTILIZER HOPPER SUPPORT	63
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	64
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	65
0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	66
0521050194	SQUARE AXLE RIGHT SUPPORT	67
0521050195	SQUARE AXLE LEFT SUPPORT	68
0521056104	PLATFORM SET	69
0521056434	PLATFORM ASSY 7655	70
0521056078	HANDRAIL SET	71
0521056433	HANDRAIL ASSY 7655	72
0521057311	RIGHT HANDRAIL CSC ASSY	73
0521057314	LEFT HANDRAIL CSC ASSY	74
0521057334	ASSY RIGHT HANDRAIL - 7655/8450	75
0521057333	ASSY LEFT HANDRAIL - 7655/8450	76
0521056125	KIT DISTRIBUTOR	77
0521056123	CSC AIR DISTRIBUTOR ASSY 7655/8450	78
0521051725	CENTRAL SEED HOPPER	79
0521056081	ASSY HOSE SUPPORT	80
0521056143	RIGHT SIDE AIR DISTRIBUTOR	81
0521056112	LEFT SIDE AIR DISTRIBUTOR	82
0521057461	7655/8450 CENTRAL SEED HOPPER	83
0521057177	ASSY ANTI CAVITATION VALVE	84
0521058023	NOZZLE Y ASSY	85
0521053173	CENTRAL SEED HOPPER 15 OUTPUTS	86
0521053175	BASE CSC HOPPER 15 OUTPUTS	87
0521045392	HYDRAULIC TURBINE WITH SCREEN	88
0501054983	NIPPLE HIDRAULIC MOTOR	89
0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE	90
0521057188	ASSY SUPPORT AIR DUCT REAR	91
0521057462	CENTRAL REAR AIR CONDUCTOR 7655/8450	92
0521056114	CENTRAL REAR AIR CONDUCTOR	93
0521057463	CENTRAL AIR DISTRIBUTOR	94
0521057341	CENTRAL AIR DISTRIBUTOR	95
0521056987	FIXED ARTICULATOR SUPPORT	96
0521057187	MOUNTED REAR AIR DUCT SUPPORT	97
0521057346	FRONT / REAR SUPPORT	98
0521056083	MOUNTED CSC PLATFORM	99
0521056990	REAR SUPPORT HOSE ASSY	100
0521056989	ASSY CSC FIXED SUPPORT	101
0521056988	ASSY TURBINE REGULATOR BLOCK SUPPORT	102
0511059542	BLOCK COMMAND TURBINES	103
0521057315	ASSY SUPPORT TRANSPORT CSC	104
0521056985	ASSY CSC PLATFORM SUPPORT	105
0521056986	FIXED SUPPORT ASSY CSC DRAIN	106
0521057178	TURBINE PRECISION PLANTING WITHOUT VALVE	107



MARCHESAN

INDEX

0521050154	PRECISION PLANTING TURBINE WITH HOLE	108
0521057919	ASSY CSC TURBINE PROTECTION	109
0521057917	RIGHT REAR AIR DUCT FIXING COMPLETE ASSY	110
0511053356	ASSY LADDER	111
0511058191	REST ASSY	112
0511054971	JACK ASSEMBLY	113
0511057803	ASSY PORT MANUAL INSTRUCCION	114
0521057201	SET LABEL ADHESIVE	115
0521057949	SET LABEL ADHESIVE	116
0521056086	ASSY RIGHT EXCHANGE	117
0531052781	RIGHT GEAR BOX ASSY	118
0521056087	ASSY LEFT EXCHANGE	119
0531052782	LEFT GEAR BOX ASSY	120
0501048790	AXLE WITH RING	121
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	122
0501056443	GEAR HOUSING BEARING	123
0511059266	CLOSED BEARING	124
0501054655	CHAIN TENSIONER ASSY	125
0511059261	CHAIN TENSIONER	126
0521056118	TRANSMISSION ASSY	127
0521056135	BEARING GEAR WITH DOUBLE	128
0531052790	TRANSMISSION ASSY	129
0531052780	DOUBLE BEARING WITH 22Z X 20Z GEAR	130
0521055217	LOWER CURRENT STRETCH	131
0521056134	STRETCHER FERTILIZER CURRENT 17Z	132
0521054446	LOWER CURRENT STRETCHER 21Z	133
0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	134
0511052333	ASSEMBLY SUPPORT LEFT FIXER CHANGE	135
0511059494	TRACTION SPRING ASSY	136
0521057199	HYDRAULIC SET	137
0521057184	HYDRAULIC ASSY 7655	138
0521057259	OIL CONDUCTOR FIXATION	139
0521057704	SLIDING SUPPORT HYDRAULIC HOSE	140
0521057854	SUPPORT VALVE BLOCK VACUOMETER ASSY 7655/8450	141
0521057291	TRIPLE VALVE	142
0521057886	HOSE CLAMP ASSEMBLY	143
0521057936	KIT HOSE / LABEL ASSY CSC 5750 A 7350	144
0521057937	KIT HOSE / LABEL ASSY CSC 7655 A 8450	145
0521057337	ISOBUS USAP SET	146
0503063101	KIT ISO	147
0511056972	FILTER HYDAC	148
0531051005	15 ROWS 450/500 6 CANALS ISO6 MS SET	149
0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	150
0521054490	FLOW DIVIDING VALVE ASSY	151
0503063150	KIT ISO	152
0521057435	ISO CONTROL FERTILIZER/SEED MECHANICAL SET	153
0521057274	SUPPORT HIDRAULIC MOTOR	154
0521057272	PROTECTION COVER	155
0521057273	PROTECTION COVER	156
0521057275	COVER MOTOR	157
0521057276	COVER MOTOR	158
0511059348	APT ASSY MODULE BOX	159
0531054826	15 ROWS FERTILIZER/SEED CONTROL MECHANICAL SET	160
0531054821	RIGHT FERTILIZER MOTOR SUPPORT	161
0531054822	SUPPORT WITH LEFT MOTOR	162



MARCHESAN

INDEX

0531050693	MODULE BOX	163
0531050763	FIXING OIL CONDUCTORS SET FOR 5 TUBES	164
0503063134	KIT MONITORING	165
0521057954	SUPPORT TRANSP	166
0521057928	REAR HEADLIGHT ASSY 6850 A 7350	167
0521053672	LIGHTHOUSE ASSY	168
0521052792	MOUNTED REAR LIGHT	169
0521050693	ASSEMBLY SET HOSE CYLINDER FRONT HEAD	170
0521056993	ASSY WATER RESERVOIR	171
0521056994	ASSY TOOL CHEST	172
0909098869	SEED/FERTILIZER ROW ASSY	173
0521056240	FRONT SHORT ROW	174
0521056241	FRONT LONG ROW	175
0531052956	ASSEMBLY SEED ROW TRANSMISSION FIXING BEARING	176
0521056938	RIGHT REAR PRECISION PLANTING CSC TRANSMISSION / CABLE	177
0521056939	LEFT REAR PRECISION PLANTING CSC TRANSMISSION/CABLE	178
0521056954	LEFT DDD ASSY	179
0521056955	RIGHT DDD ASSY	180
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	181
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	182
0521056640	PRECISION PLANTING CSC CABLE / TRANSMISSION ASSY	183
0521052131	DISTRIBUTOR VSET2 WITH CORN DISK WITHOUT PROTECTION	184
0521056644	REAR RIGHT SPI	185
0521056642	REAR LEFT SPI	186
0521056646	LEFT REAR FRAME	187
0521056645	RIGHT SPI TRANSMISSION	188
0521056632	DEPTH CONTROL	189
0521056633	MOUNTED RIGHT ARM	190
0521056631	MOUNTED LEFT ARM	191
0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	192
0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	193
0521055093	BODY COMPACTOR	194
0521054990	LEFT COMPACTOR WHEEL	195
0521055017	RIGHT COMPACTOR WHEEL	196
0521055059	WHEEL RAYED ASSY SPA WITHOUT LUBRICATION	197
0521055073	ASSEMBLY DEPTH WHEEL HUB	198
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	199
0521054984	DEPTH/COMPACTOR SYSTEM - SPT	200
0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	201
0501052297	DEPTH WHEELS REGULATOR ASSY	202
0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	203
0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	204
0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	205
0521055033	SEMI-ASSEMBLED COMPACTOR BODY	206
0501052538	DEPTH BAND WITH ARMS	207
0521056069	SEMI-ASSEMBLED SHORT FERTILIZER ROW	208
0521056070	DC 20 ASSY	209
0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	210
0521053697	DISC BLADE HUB	211
0521056066	SEMI-ASSEMBLED LONG FERTILIZER ROW	212
0521055868	RIGHT DUAL FERTILIZER DISC	213
0521056068	DDD LEFT FERTILIZER WITH FIXATION	214




MARCHESAN

INDEX

0521055869	LEFT DUAL FERTILIZER DISC		215
0521056844	SCARIFIER ROD		216
0521053673	SCARIFIER ROD WITH NOZZLE		217
0521056992	SCARIFIER ROD TIP 3 HOLES		218
0501110723	SCARIFIER ROD		219
0521051447	FRONT ASSY ROW BEARING		220
0521053987	SCARIFIER SPINDLE WITH SOCKET RIGHT		221
0521053956	SCARIFIER SPINDLE WITH SOCKET LEFT		222
0521053957	ROD WITH ARM/DISARMMENT		223
0521053958	STEM WITH NOZZLE HDA		224
0521053959	ROD WITH AUTOMATIC DISARM TIP		225
0511059454	ADJUSTMENT BAR		226
0531053036	SHORT SEED ROW HOSE GUIDE STEEL CABLE		227
0531053037	LONG SEED ROW HOSE GUIDE STEEL CABLE		228
0531052349	CURRENT GUIDE ASSEMBLY		229
0531052347	HOSE SUPPORT ASSEMBLY		230

ASSY FRAME

0909098858



Item	Code	Description	See page	6850/7655
01	0521056065	FRAME SHAFT	2	01 00
02	0521056111	FRAME WITH ARTICULATION 7655	3	00 01
03	0909098859	DRAWBAR ASSY - 5750/6350/6850/7655	4	01 01
04	0521056088	WHEEL ASSY RIGHT FIXING EXTENSOR	15	01 01
05	0521057945	RIGHT WHEEL ASSY FASTENER EXTENSOR	16	01 01
06	0521056089	WHEEL ASSY LEFT FIXING EXTENSOR	17	01 00
07	0521057946	LEFT WHEEL ASSY FASTENER EXTENSOR	18	00 01
08	0521056090	RIGHT WHEEL ASSY	19	01 00
09	0521057820	WHEEL ASSEMBLY WITHOUT TRANSMISSION	20	00 04
10	0521056091	LEFT WHEEL ASSY	21	01 00
11	0521056092	LEFT WHEEL ASSEMBLY WITHOUT TRANSMISSION	22	02 01
12	0521056093	RIGHT WHEEL ASSEMBLY WITHOUT TRANSMISSION	23	02 01
13	0521056119	SQUARE AXIS ASSEMBLY 730	39	01 00
14	0521056084	MOTOR SHAFT ASSEMBLY - 6850	43	01 00
15	0521056121	HEX AXLE ASSEMBLY	48	01 00
15.	0531054818	6850 APT HEX AXLE SET	52	01 00
16	0521056071	FERTILIZER HOPPER SET	54	01 00
16.	0531054819	6850 APT FERTILIZER HOPPER ASSEMBLY	58	01 00
17	0521056435	7655 FERTILIZER HOPPER SET	60	00 01
18	0521056104	PLATFORM SET	69	01 00
19	0521056434	PLATFORM ASSY 7655	70	00 01
20	0521056078	HANDRAIL SET	71	01 00
21	0521056433	HANDRAIL ASSY 7655	72	00 01
22	0521056125	KIT DISTRIBUTOR	77	01 00
23	0521056123	CSC AIR DISTRIBUTOR ASSY 7655/8450	78	00 01
24	0511053356	ASSY LADDER	111	01 01
25	0511058191	REST ASSY	112	01 00
26	0511054971	JACK ASSEMBLY	113	00 01
27	0511057803	ASSY PORT MANUAL INSTRUION	114	01 01
28	0521057201	SET LABEL ADHESIVE	115	01 00

ASSY FRAME

0909098858

Item	Code	Description	See page	6850/7655	
29	0521057949	SET LABEL ADHESIVE	116	00	01
30	0521056086	ASSY RIGHT EXCHANGE	117	01	01
30.	0531052781	RIGHT GEAR BOX ASSY	118	01	00
31	0521056087	ASSY LEFT EXCHANGE	119	01	01
31.	0531052782	LEFT GEAR BOX ASSY	120	01	00
32	0521056118	TRANSMISSION ASSY	127	01	00
32.	0531052790	TRANSMISSION ASSY	129	01	00
33	0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	134	01	00
34	0511052333	ASSEMBLY SUPPORT LEFT FIXER CHANGE	135	01	00
35	0511059494	TRACTION SPRING ASSY	136	10	10
36	0501047895	25 ROD STOP		10	10
37	0501047885	30 ROD STOP		08	08
38	0501047886	35 ROD STOP		08	08
39	0501047887	40 ROD STOP		08	08
40	0521013022	TRANSPORT LOCK		08	08
41	0501068994	8,30 X 78 LOCK PIN		08	08
42	0503030168	HITCH PIN CLIP		08	08
43	0511057817	SUPPORT HOSE	9	01	01
44	0521066303	HOSE GUIDE		01	01
45	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		02	02
46	0503013816	5/16" LOCKNUT		02	02
47	0503011750	AMENDMENT WITH LOCK		06	06
48	0503011751	REDUCTION		06	06
49	0503010780	N-2050 AMENDMENT		06	06
50	0503010246	CLAMP		19	19
51	0503032624	FERTILIZER HOPPER GUTTER		07	07
52	0503010002	1800 GREASE FITTING		01	01
53	0541015451	FIXED KEY 2.3/8 X 2.3/4		01	01
54	0521057199	HYDRAULIC SET	137	01	00
55	0521057184	HYDRAULIC ASSY 7655	138	00	01
56	0521057936	KIT HOSE / LABEL ASSY CSC 5750 A 7350	144	01	00
57	0521057937	KIT HOSE / LABEL ASSY CSC 7655 A 8450	145	00	01
58	0521057337	ISOBUS USAP SET	146	01	00
58.	0531051005	15 ROWS 450/500 6 CANALS ISO6 MS SET	149	01	00
59	0503063150	KIT ISO	152	00	01
60	0521057435	ISO CONTROL FERTILIZER/SEED MECHANICAL SET	153	01	00
60.	0531054826	15 ROWS FERTILIZER/SEED CONTROL MECHANICAL SET	160	01	00
61	0503063134	KIT MONITORING	165	01	00
62	0521057954	SUPPORT TRANSP	166	01	01
63	0503034867	AIR DITRIBUTOR PUMP		08	07
64	0503034345	AIR DISPENSER COVER		07	07
65	0503010243	CLAMP		08	08
66	0503010184	CLAMP		07	07
67	0521057928	REAR HEADLIGHT ASSY 6850 A 7350	167	01	01
68	0521018501	TURNBUCKLE LEVER		01	01
69	0521050693	ASSEMBLY SET HOSE CYLINDER FRONT HEAD	170	01	01
70	0581013729	NIPLE 1/2 NPT		01	01
71	0541010080	TERMINAL R.1 / 2 NPT		01	01
72	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01	01
73	0503010045	O'RING		01	01
74	0501053834	MALE QUICK COUPLER	14	01	01
75	0503014321	CABLE STEEL SHACKLE		02	02
76	0503014120	CHAIN		01	01
77	0521056993	ASSY WATER RESERVOIR	171	01	01
78	0521056994	ASSY TOOL CHEST	172	01	01
79	0503019262	SOAP DISH VACUUM		01	01
80	0501093353	MARCHESAN OPERATOR'S MANUAL - ISO6		01	01

**COP TRIO 650 SUPREMA P.P MINI HOPPER - FRAME**

Page 1


ASSY FRAME

0909098858


Item	Code	Description	See page	6850/7655
81	0909098869	SEED/FERTILIZER ROW ASSY	173	15 17

FRAME SHAFT


0521056065



Item	Code	Description	See page	QT
01	0521069990	RIGHT SIDE FRAME 6850		01
02	0521069989	LEFT SIDE FRAME 6850		01
03	0521063003	LOCK PIN		02
04	0571010969	LOCK SLEEVE FRAME		02
05	0503013627	1.1/2 SPRING WASHER		02
06	0501010110	1.1/2" NUT		02
07	0521069988	CENTRAL FRAME		01
08	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		04
09	0503011442	3/4" SPRING WASHER		20
10	0501010098	3/4" UNC BOLT		20
11	0571010094	SLEEVE FLANGE		12
12	0521066298	ARTICULATOR		04
13	0571013510	LOCK AXLE		04
14	0503030085	LOCK PIN		04
15	0571010095	FLAT WASHER		04
16	0521064285	LOCK LOWER FRAME		04
17	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		04
18	0591012308	SIDE GUTTER 24 X 50 X 1950		02
19	0591012303	CENTRAL TRACK		02
20	0503013029	3/8" X 3/4" BOLT		08
21	0501013518	FLAT WASHER		08
22	0503010025	3/8 SPRING WASHER		08
23	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0531060111	CENTRAL FRAME 8450		01
02	0521069990	RIGHT SIDE FRAME 6850		01
03	0521069989	LEFT SIDE FRAME 6850		01
04	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		04
05	0521066298	ARTICULATOR		04
06	0521063003	LOCK PIN		02
07	0571010969	LOCK SLEEVE FRAME		02
08	0503013627	1.1/2 SPRING WASHER		02
09	0501010110	1.1/2" NUT		02
10	0503011442	3/4" SPRING WASHER		20
11	0501010098	3/4" UNC BOLT		20
12	0571010094	SLEEVE FLANGE		12
13	0571013510	LOCK AXLE		04
14	0503030085	LOCK PIN		04
15	0571010095	FLAT WASHER		04
16	0521064285	LOCK LOWER FRAME		04
17	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		04
18	0591012305	CENTRAL GUTTER 24 X 50 X 1550		02
19	0591012308	SIDE GUTTER 24 X 50 X 1950		02
20	0503013029	3/8" X 3/4" BOLT		08
21	0501013518	FLAT WASHER		08
22	0503010025	3/8 SPRING WASHER		08
23	0503010026	3/8" NUT		08




Item	Code	Description	See page	5750	6350	6850	7655
01	0521066289	5750/6350/6850 FRONT DRAWBAR		01	00	01	00
01.	0521067406	DRAWBAR ASSY 7655		00	00	00	01
02	0531060570	INTERMEDIATE HEADER 5750/6850		01	00	01	00
02.	0531060568	INTERMEDIATE DRAWBAR 7655/8450		00	00	00	01
02..	0531060569	INTERMEDIATE DRAWBAR 6350/7350		01	00	00	00
03	0571019949	JUNCTION SHAFT		06	06	06	06
04	0503030119	LOCK PIN		10	10	10	10
05	0521045756	HYDRAULIC CYLINDER	5	01	01	01	01
06	0521010779	31.75 X 95 COUPLING SHAFT		01	01	01	01
07	0521010581	0.9" X 4.9" COUPLING SHAFT		01	01	01	01
08	0503030085	LOCK PIN		06	06	06	06
09	0531016049	FLAT WASHER		02	02	02	02
10	0521050573	EXTENSOR 3RD POINT	8	01	01	01	01
11	0511057817	SUPPORT HOSE	9	01	01	01	01
12	0571019951	JUNCTION SHAFT		02	02	02	02
13	0503010523	1/4" X 2" COTTERPIN		04	04	04	04
14	0511055096	TRACTOR HITCH	10	01	01	01	01
15	0511053179	TRACTOR COUPLING SHAFT		01	01	01	01
16	0501212237	HITCH SLEEVE ARTICULATED 85 X 35 MM		01	01	01	01
17	0521050133	TURNBUCKLE SIDE 755/480	11	02	02	02	02
17.	0521050196	TURNBUCKLE SIDE 1125/480		00	00	02	00
18	0521050574	EXTENSOR	12	02	02	02	02
19	0521010571	COUPLING SHAFT		04	04	04	04
20	0521057452	ASSY INTERMEDIATE DRAWBAR FIXATION SUPPORT	13	04	04	04	04
21	0521050693	ASSEMBLY SET HOSE CYLINDER FRONT HEAD	170	01	01	01	01
21A	0521050692	HOSE KIT CYLINDER HEAD FRONT		01	01	01	01
21AA	0521052310	HOSE 1/2 X 4500 TM-TM GREEN / RED		01	01	01	01
21AAA	0501081929	HOSE 1/2 X 4500 TM-TM		01	01	01	01
21AAB	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01	01	01	01
21AAC	0503034495	HYDRAULIC HOSE GRIP (RED)		01	01	01	01
21AAD	0503018952	PLASTIC BOLT		06	06	06	06


Item	Code	Description	See page	5750	6350	6850	7655
21AB	0521052309	HOSE 1/2 X 4500 TM-TM GREEN / BLUE		01	01	01	01
21ABA	0501081929	HOSE 1/2 X 4500 TM-TM		01	01	01	01
21ABB	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01	01	01	01
21ABC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01	01	01	01
21ABD	0503018952	PLASTIC BOLT		06	06	06	06
21C	0501053834	MALE QUICK COUPLER	14	04	04	04	04
22	0571019950	COUPLING SHAFT		02	02	02	02




Item	Code	Description	See page	QT
01	0511057653	HYDRAULIC CYLINDER	6	01
02	0501053835	FEMALE QUICK COUPLER	7	02




Item	Code	Description	See page	QT
01	0521066550	CASE		01
02	0521066551	EXTENSION DRAWBAR		01
03	0503010002	1800 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010669	EMBOLUS 63.50 X 40 USAP		01
06	0503018005	RING		01
07	0503010558	7/8" NUT		01
08	0502010471	63,50 MOBILE CAP		01
09	0503011058	8-330 BACK-UP RING		01
10	0571019866	RING SUPPORT		01
11	0503010163	D-1500 SCRAPER RING		01
12	0503018004	RING		01
13	0503010161	2-330 N 3006 9B O'RING		01
14	0503018003	GASKET		01
15	0503010605	O'RING		01
16	0581010652	JIC ADAPTER		01



Item	Code	Description	See page	QT
01	0503011883	QUICK CONNECTION COVER		01
02	0503011628	FEMALE QUICK COUPLER		01




Item	Code	Description	See page	QT
01	0511061880	SIDE RIGHT RATCHET		01
02	0531010264	SIDE RATCHET		01
03	0511061881	RATCHET FOLLOWER		01
04	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
05	0503011179	3/8" X 2-1/4" BOLT		05
06	0503011443	3/8" SPRING WASHER		05
07	0503010026	3/8" NUT		05
08	0503010002	1800 GREASE FITTING		02
09	0503030012	HITCH PIN CLIP		01
10	0502012783	STABILIZER BODY GREATER		01
11	0521067623	FUSE 713 EXTENSION RIGHT 3RD POINT		01
12	0521067622	FUSE 470 EXTENSION LEFT 3RD POINT		01




Item	Code	Description	See page	QT
01	0521066302	HOSE HOLDER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01

TRACTOR HITCH


0511055096




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	COMPRESSION SPRING LEFT		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0521065193	TURNBUCKLE AXLE		01
02	0521067392	FIXED BRACKET		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0521067393	EXTERNAL SIDE EAR		01
06	0571019949	JUNCTION SHAFT		01
07	0503030119	LOCK PIN		01
08	0503010002	1800 GREASE FITTING		03




Item	Code	Description	See page	QT
01	0521066300	RIGHT TURNBUCKLE		01
02	0503010002	1800 GREASE FITTING		02
03	0521066301	LEFT TURNBUCKLE		01
04	0541018672	COUNTERNUT		01
05	0502011195	ADJUSTMENT NUT BODY		01



Item	Code	Description	See page	QT
01	0521067716	FIXER TUBE		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0503010152	3/4" SELF LOCKING NUT		04
05	0501010322	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521066480	RH WHEELS SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 24 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	27	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	28	01
15	0501047888	45 ROD STOP		02
16	0511064744	WHEEL FORK		01
17	0531016051	CARRY-WHEEL CHAIN PROTECTION CAP		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8 SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" COTTERPIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056299	MOUNTED RIGHT STRETCHER	29	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8 NUT		02

Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 31 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOCK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TENSIONER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	WHEEL CHAIN TENSIONER BEARING	32	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01



Item	Code	Description	See page	QT
01	0521066480	RH WHELLS SUPPORT	01	
02	0503010019	1/2" SPRING WASHER	12	
03	0503013232	1/2" BOLT	08	
04	0561013021	BEARING INNER LOCK	02	
05	0561013022	BEARING EXTERNAL LOCK	02	
06	0503010398	501082 CLAMPING RING (FOR AXLE)	02	
07	0561013020	KM 12 NUT	02	
08	0503010027	5/8 SPRING WASHER	02	
09	0503011167	M16 X 2 X 30 BOLT	02	
10	0501047888	45 ROD STOP	01	
11	0521056101	EE WHEEL WITH TIRE 7.00X16 ASSY WITHOUT 33 TRANSMISSION	01	
12	0503016485	BOLT 3/4	04	
13	0503010152	3/4" SELF LOCKING NUT	04	
14	0541010763	FLAT WASHER	04	
15	0503017857	BOLT 5/8 UNF 4	04	
16	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
17	0501012140	FLAT WASHER	04	
18	0503010834	1/2 X 1 BOLT	04	
19	0501017779	32 X 60 X 4.75 FLAT WASHER	02	
20	0503010523	1/4" X 2" COTTERPIN	01	
21	0521010546	1.2" X 5.7" COUPLING SHAFT	01	
22	0511064744	WHEEL FORK	01	
23	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION	02	
24	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 28 WITHOUT LUBRICATION	01	
25	0502010584	CARRYING-WHEELS SUPPORT FIXER	02	
26	0591010098	ARTICULATED BEARING WHEELED WITHOUT TRANSMISSION WITHOUT LUBRICATION	02	
27	0502012720	WHEEL SUPPORT FIXER	01	




Item	Code	Description	See page	QT
01	0521066479	RH WHEELS SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 24 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	27	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	28	01
15	0501047888	45 ROD STOP		01
16	0511065842	LEFT WHEEL FORK		01
17	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8 SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" COTTERPIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056300	MOUNTED LEFT STRETCHER	35	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8 NUT		02


WHEEL ASSY LEFT FIXING EXTENSOR

0521056089

Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 31 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOCK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TENSIONER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	WHEEL CHAIN TENSIONER BEARING	32	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01



Item	Code	Description	See page	QT
01	0521066479	RH WHELLS SUPPORT	01	
02	0503010019	1/2" SPRING WASHER	12	
03	0503013232	1/2" BOLT	08	
04	0561013021	BEARING INNER LOCK	02	
05	0561013022	BEARING EXTERNAL LOCK	02	
06	0503010398	501082 CLAMPING RING (FOR AXLE)	02	
07	0561013020	KM 12 NUT	02	
08	0503010027	5/8 SPRING WASHER	02	
09	0503011167	M16 X 2 X 30 BOLT	02	
10	0501047888	45 ROD STOP	01	
11	0521056101	EE WHEEL WITH TIRE 7.00X16 ASSY WITHOUT 33 TRANSMISSION	01	
12	0503016485	BOLT 3/4	04	
13	0503010152	3/4" SELF LOCKING NUT	04	
14	0541010763	FLAT WASHER	04	
15	0503017857	BOLT 5/8 UNF 4	04	
16	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
17	0501012140	FLAT WASHER	04	
18	0503010834	1/2 X 1 BOLT	04	
19	0501017779	32 X 60 X 4.75 FLAT WASHER	02	
20	0503010523	1/4" X 2" COTTERPIN	01	
21	0521010546	1.2" X 5.7" COUPLING SHAFT	01	
22	0511065842	LEFT WHEEL FORK	01	
23	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION	02	
24	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 28 WITHOUT LUBRICATION	01	
25	0502012720	WHEEL SUPPORT FIXER	01	
26	0591010098	ARTICULATED BEARING WHEELED WITHOUT TRANSMISSION WITHOUT LUBRICATION	02	
27	0502010584	CARRYING-WHEELS SUPPORT FIXER	02	




Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 24 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	27	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	28	01
15	0501047888	45 ROD STOP		01
16	0511064744	WHEEL FORK		01
17	0531016051	CARRY-WHEEL CHAIN PROTECTION CAP		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8 SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" COTTERPIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056299	MOUNTED RIGHT STRETCHER	29	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8 NUT		02

RIGHT WHEEL ASSY

0521056090


Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 31 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOCK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TENSIONER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	WHEEL CHAIN TENSIONER BEARING	32	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01



Item	Code	Description	See page	QT
01	0531060795	WHEEL SUPPORT		01
02	0503010019	1/2" SPRING WASHER		13
03	0503013232	1/2" BOLT		08
04	0561013021	BEARING INNER LOCK		02
05	0561013022	BEARING EXTERNAL LOCK		02
06	0503010398	501082 CLAMPING RING (FOR AXLE)		02
07	0561013020	KM 12 NUT		02
08	0503010408	7/8" SPRING WASHER		02
09	0503012419	7/8" X 2-3/4" BOLT		02
10	0501047888	45 ROD STOP		02
11	0521057818	WHEEL WITH TIRE 7.00 X 16 14L ASSY WITHOUT TRANSMISSION	36	01
12	0503016485	BOLT 3/4		04
13	0503010152	3/4" SELF LOCKING NUT		04
14	0501010322	FLAT WASHER		04
15	0503017857	BOLT 5/8 UNF 4		04
16	0503010811	5/8" UNF SELF ADJUSTING NUT		04
17	0501012140	FLAT WASHER		04
18	0503010834	1/2 X 1 BOLT		05
19	0501017779	32 X 60 X 4.75 FLAT WASHER		02
20	0503010523	1/4" X 2" COTTERPIN		01
21	0521010546	1.2" X 5.7" COUPLING SHAFT		01
22	0531060798	CENTRAL WHEEL FORK WITHOUT TRANSMISSION		01
23	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
24	0521057817	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	38	01
25	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
26	0591010098	ARTICULATED BEARING WHEELED WITHOUT TRANSMISSION WITHOUT LUBRICATION		02
27	0502012720	WHEEL SUPPORT FIXER		01

LEFT WHEEL ASSY

0521056091




Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 24 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	27	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	28	01
15	0501047888	45 ROD STOP		01
16	0511065842	LEFT WHEEL FORK		01
17	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8 SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" COTTERPIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056300	MOUNTED LEFT STRETCHER	35	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8 NUT		02


LEFT WHEEL ASSY

0521056091


Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 31 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOCK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TENSIONER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	WHEEL CHAIN TENSIONER BEARING	32	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT	01	
02	0503010019	1/2" SPRING WASHER	12	
03	0503013232	1/2" BOLT	08	
04	0561013021	BEARING INNER LOCK	02	
05	0561013022	BEARING EXTERNAL LOCK	02	
06	0503010398	501082 CLAMPING RING (FOR AXLE)	02	
07	0561013020	KM 12 NUT	02	
08	0503010027	5/8 SPRING WASHER	02	
09	0503011167	M16 X 2 X 30 BOLT	02	
10	0501047888	45 ROD STOP	01	
11	0521056101	EE WHEEL WITH TIRE 7.00X16 ASSY WITHOUT 33 TRANSMISSION	01	
12	0503016485	BOLT 3/4	04	
13	0503010152	3/4" SELF LOCKING NUT	04	
14	0541010763	FLAT WASHER	04	
15	0503017857	BOLT 5/8 UNF 4	04	
16	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
17	0501012140	FLAT WASHER	04	
18	0503010834	1/2 X 1 BOLT	04	
19	0501017779	32 X 60 X 4.75 FLAT WASHER	02	
20	0503010523	1/4" X 2" COTTERPIN	01	
21	0521010546	1.2" X 5.7" COUPLING SHAFT	01	
22	0511065842	LEFT WHEEL FORK	01	
23	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION	02	
24	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 28 WITHOUT LUBRICATION	01	
25	0502012720	WHEEL SUPPORT FIXER	01	
26	0591010098	ARTICULATED BEARING WHEELED WITHOUT TRANSMISSION WITHOUT LUBRICATION	02	
27	0502010584	CARRYING-WHEELS SUPPORT FIXER	02	




Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0503010019	1/2" SPRING WASHER		12
03	0503013232	1/2" BOLT		08
04	0561013021	BEARING INNER LOCK		02
05	0561013022	BEARING EXTERNAL LOCK		02
06	0503010398	501082 CLAMPING RING (FOR AXLE)		02
07	0561013020	KM 12 NUT		02
08	0503010027	5/8 SPRING WASHER		02
09	0503011167	M16 X 2 X 30 BOLT		02
10	0501047888	45 ROD STOP		01
11	0521056101	EE WHEEL WITH TIRE 7.00X16 ASSY WITHOUT 33 TRANSMISSION		01
12	0503016485	BOLT 3/4		04
13	0503010152	3/4" SELF LOCKING NUT		04
14	0541010763	FLAT WASHER		04
15	0503017857	BOLT 5/8 UNF 4		04
16	0503010811	5/8" UNF SELF ADJUSTING NUT		04
17	0501012140	FLAT WASHER		04
18	0503010834	1/2 X 1 BOLT		04
19	0501017779	32 X 60 X 4.75 FLAT WASHER		02
20	0503010523	1/4" X 2" COTTERPIN		01
21	0521010546	1.2" X 5.7" COUPLING SHAFT		01
22	0511064744	WHEEL FORK		01
23	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
24	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 28 WITHOUT LUBRICATION		01
25	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
26	0591010098	ARTICULATED BEARING WHEELED WITHOUT TRANSMISSION WITHOUT LUBRICATION		02
27	0502012720	WHEEL SUPPORT FIXER		01




Item	Code	Description	See page	QT
01	0503063073	EE WHEEL WITH TIRE 7.00 X 16 14L ASSEMBLY	25	01
02	0521056100	WHEEL HUB ASSY WITH TRANSMISSION	26	01




Item	Code	Description	See page	QT
01	0503016518	WHEEL		01
02	0503010033	7.50 X 16 INNER TIRE		01
03	0503019458	TIRE 7.00X16 14PR		01




Item	Code	Description	See page	QT
01	0503010804	00547-B SEAL		02
02	0503010330	KM 9 LOCKNUT		01
03	0511015949	LOCK NUT		01
04	0503010329	LOCK WASHER		01
05	0503010002	1800 GREASE FITTING		01
06	0501110721	WHEEL HUB WITH SCREW / NUTS		01
06A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
06B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
06C	0503016516	5/8 UNF CONIC NUT		06
07	0503019364	BEARING 25590/25523		02
08	0521018363	00547-B SEAL		01
09	0511062015	14Z GEAR WITH FLANGE		01
10	0503010421	5/16" X 1-1/2" BOLT		06
11	0503011444	SPRING WASHER		06




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		01
02	0591010747	CURRENT STRETCHER AXIS		01
03	0503010302	501019 SEAL RING		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
07	0541016454	PULLEY		01




Item	Code	Description	See page	QT
01	0531060012	CASE 101.6 X 324.5 WITHOUT LUBRICATION		01
02	0541017674	TURNBUCLE BODY		01
03	0511064408	FORK		01
04	0503011094	3/8" X 2" BOLT		01
05	0503010025	3/8 SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581010302	RING OF SUPPORT		01
08	0502012822	101.60 END CAP		01
09	0503011061	8-342 BACK-UP RING		02
10	0503010338	2-342 N 3006-9B O'RING		02
11	0503017936	RING		01
12	0503017938	RING GUIDE		01
13	0503017937	GASKET		01
14	0503010761	D-1750 SCRAPER RING		01
15	0581010837	PISTON		01
16	0503010817	1.1/4" SELF LOCKING NUT		01
17	0503015633	SELEMASTER SEALING		01
18	0503018029	2-217 O'RING		01
19	0503018045	2-130 (AGEL) O'RING		04
20	0503030387	PLUG		02
21	0511033019	CYLINDER REPAIR KIT 44.45 X 101.60		01




Item	Code	Description	See page	QT
01	0503010027	5/8 SPRING WASHER		01
02	0503010013	5/8 NUT		01
03	0521055238	BEARING TENSIONER CHAIN	30	01
04	0551018241	SLEEVE 16,30 X 30 X 8		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	0551018252	CHAIN TENSIONER AXLE		01
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
09	0503010232	5/8" X 1.3/4" BOLT		01
10	0531016916	SLEEVE BEARING SUPPORT		01
11	0531018654	CHAIN TIGHTENER SUPPORT		01




Item	Code	Description	See page	QT
01	0503019355	BEARING 6202 2RS1		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0591010097	ARTICULATED BEARING WHEELED WITHOUT LUBRICATION		01
02	0503019409	SELF LUBRICATING BUSHING		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0503063073	EE WHEEL WITH TIRE 7.00 X 16 14L ASSEMBLY	25	01
02	0521056102	ASSY WHEEL HUB WITHOUT TRANSMISSION	34	01



Item	Code	Description	See page	QT
01	0503010804	00547-B SEAL		02
02	0503010330	KM 9 LOCKNUT		01
03	0511015949	LOCK NUT		01
04	0503010329	LOCK WASHER		01
05	0503010002	1800 GREASE FITTING		01
06	0501110721	WHEEL HUB WITH SCREW / NUTS		01
06A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
06B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
06C	0503016516	5/8 UNF CONIC NUT		06
07	0503019364	BEARING 25590/25523		02
08	0521018363	00547-B SEAL		01




Item	Code	Description	See page	QT
01	0503010027	5/8 SPRING WASHER		01
02	0503010013	5/8 NUT		01
03	0521055238	BEARING TENSIONER CHAIN	30	01
04	0551018241	SLEEVE 16,30 X 30 X 8		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	0551018252	CHAIN TENSIONER AXLE		01
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
09	0503010232	5/8" X 1.3/4" BOLT		01
10	0531016916	SLEEVE BEARING SUPPORT		01
11	0541012098	LEFT CHAIN TIGHTENER LARGER SUPPORT		01




Item	Code	Description	See page	QT
01	0503063073	EE WHEEL WITH TIRE 7.00 X 16 14L ASSEMBLY	25	01
02	0521057819	ASSY WHEEL HUB WITHOUT TRANSMISSION	37	01

ASSY WHEEL HUB WITHOUT TRANSMISSION


0521057819




Item	Code	Description	See page	QT
01	0503010804	00547-B SEAL		02
02	0503010330	KM 9 LOCKNUT		01
03	0511015949	LOCK NUT		01
04	0503010329	LOCK WASHER		01
05	0503010002	1800 GREASE FITTING		01
06	0501110721	WHEEL HUB WITH SCREW / NUTS		01
06A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
06B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
06C	0503016516	5/8 UNF CONIC NUT		06
07	0503019364	BEARING 25590/25523		02
08	0591013435	TRANSMISSION WHEEL AXLE		01




Item	Code	Description	See page	QT
01	0531060797	CYLINDER CASE		01
02	0541017674	TURNBUCLE BODY		01
03	0511064408	FORK		01
04	0503011094	3/8" X 2" BOLT		01
05	0503010025	3/8 SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581010302	RING OF SUPPORT		01
08	0591013736	MOBILE COVER		01
09	0503011061	8-342 BACK-UP RING		02
10	0503010338	2-342 N 3006-9B O'RING		02
11	0503017936	RING		01
12	0503017938	RING GUIDE		01
13	0503017937	GASKET		01
14	0503010761	D-1750 SCRAPER RING		01
15	0581010837	PISTON		01
16	0503010817	1.1/4" SELF LOCKING NUT		01
17	0503015633	SELEMASTER SEALING		01
18	0503018029	2-217 O'RING		01
19	0503018045	2-130 (AGEL) O'RING		04
20	0503030387	PLUG		02
21	0511033019	CYLINDER REPAIR KIT 44.45 X 101.60		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	40	02
02	0501056444	BEARING WITH ROLLER	41	02
03	0503011953	5/16" X 1" BOLT		08
04	0501010694	FLAT WASHER		08
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
06	0503010337	5/16" NUT		08
07	0511014218	3/4" X 28.7"SQUARE SHAFT		02
08	0501053788	3/4 SQUARE AXLE FASTENER	42	04
09	0503030275	AGRICULTURAL BEARING		04
10	0521061852	LEVER RATCHET		02
11	0521061847	AXLE ADRIVING ASSY		02
12	0521061849	DISASSEMBLE LEVER		02
13	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
14	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
15	0503010140	1/8" X 3/4" COTTERPIN		04
16	0571012792	LOWER LEVER		02
17	0503011082	C1/2" X 1.3/4" SCREW		02
18	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2 UNC G.5 ZN HEX NUT		02
21	0561016797	SLEEVE UNION LEVER		02
22	0503010026	3/8" NUT		02
23	0503010025	3/8 SPRING WASHER		02
24	0503010849	3/8" X 1-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0503011082	C1/2" X 1.3/4" SCREW		08
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
03	0503010019	1/2" SPRING WASHER		08
04	0503010060	1/2 UNC G.5 ZN HEX NUT		08
05	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	44	01
06	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	45	01
07	0511051434	TRANSMISSION ACTUATOR	46	04
08	0591010711	MOTOR AXLE BEARING SUPPORT		04
09	0521056085	PLATE BEARING ASSY	47	08
10	0571014441	MOTOR SHAFT		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0503019402	BEARING B207-22 V22 FRM		01
02	0503019403	PFL 207 FRM BEARING PLATE		02
03	0503010026	3/8" NUT		02
04	0503010025	3/8 SPRING WASHER		02
05	0501011643	3/8 X 1"BOLT		02

HEX AXLE ASSEMBLY


0521056121




Item	Code	Description	See page	QT
01	0521056103	BEARING WITH GEAR 20Z HEX SHAFT 3/4	49	02
02	0591011101	HEX AXLE 3/4 X 1727		01
03	0591011100	HEX AXLE 3/4 X 1847		01
04	0591010702	HEX SHAFT 3/4 X 750		01
05	0591010701	HEX SHAFT 3/4 X 1270		01
06	0521056144	INTERMEDIATE SEED TRANSMISSION	51	02
07	0511063123	BUSHING WITH NUT		08
08	0501018535	1/2 X 1 BOLT		08
09	0581015056	SLEEVE		08




Item	Code	Description	See page	QT
01	0521055498	SEED TRANSMISSION DOUBLE BEARING	50	01
02	0531060014	GEAR 20Z X 48.50 HEX HOLE 20		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02
06	0501010694	FLAT WASHER		04
07	0503018441	5/16" X 1-1/4" BOLT		02




Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012858	502075 CLAMPING RING (FOR HOLE)		01
03	0503019373	6006 2RS1 NATIONAL BEARING		02




Item	Code	Description	See page	QT
01	0503010243	CLAMP		02
02	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
03	0503012880	1/4" UNC SELF ADJUSTING NUT		02
04	0503063012	SEED TRANSMISSION SHAFT HEX 3/4		01
05	0503034773	HOSE 1.1/2 X 1.1/2 X 120		01




Item	Code	Description	See page	QT
01	0531052779	BEARING WITH 26Z GEAR	53	02
02	0591010685	3/4 X 2127 HEX AXLE		01
03	0591014453	HEX AXLE 3/4 X 2000		01
04	0591010683	3/4 X 2247 HEX AXLE		01
05	0511063123	BUSHING WITH NUT		08
06	0501018535	1/2 X 1 BOLT		08
07	0581015056	SLEEVE		08




Item	Code	Description	See page	QT
01	0521055498	SEED TRANSMISSION DOUBLE BEARING	50	01
02	0531062897	26Z GEAR		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02
06	0501010694	FLAT WASHER		04
07	0503018441	5/16" X 1-1/4" BOLT		02




Item	Code	Description	See page	QT
01	0521056073	FERTILIZER BEAM SUPPORT	55	01
02	0521056072	CENTER FERTILIZER HOPPER SUPPORT	56	01
03	0521056074	LFT FERTILIZER BEAM SUPPORT	57	01
04	0571019051	FIXER HOPPER WASHER		28
05	0503013751	3/8 UNC X 1.1/4 BOLT		28
06	0503012535	3/8" SPRING WASHER		28
07	0503012531	3/8" INOX NUT		28
08	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
09	0503010026	3/8" NUT		16
10	0503010849	3/8" X 1-1/2" BOLT		16
11	0503010025	3/8 SPRING WASHER		16
12	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	66	02
13	0503034396	FERTILIZER SIDE COVER		17
14	0503010362	1/8 X 1.1/4 COTTERPIN		17
15	0503011957	NYLON LUG		02
16	0503010371	5/16" X 1" BOLT		04
17	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
18	0503010337	5/16" NUT		04
19	0503062391	FERTILIZER HOPPER		03
20	0521050194	SQUARE AXLE RIGHT SUPPORT	67	01
21	0521050195	SQUARE AXLE LEFT SUPPORT	68	01
22	0521010572	0.9" X 2.9" COUPLING SHAFT		02
23	0503030085	LOCK PIN		02




Item	Code	Description	See page	QT
01	0521066295	FERTILIZER BEAM RIGHT SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	64	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	65	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503010025	3/8 SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0501056271	GEARBOX CLOSED BEARING	40	01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
11	0503010337	5/16" NUT		02
12	0581016972	AXIS Q 3/4 X 1953		01
13	0571019828	LOCK AXLE		01
14	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521018630	1.4" X SQUARE 0.8" WASHER		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	3/4 SQUARE AXLE FASTENER	42	01
20	0503030275	AGRICULTURAL BEARING		05
21	1902010685	18Z CONICAL GEAR		05




Item	Code	Description	See page	QT
01	0521066296	CENTRAL SEED HOPPER SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	64	03
03	1902010685	18Z CONICAL GEAR		05
04	0581016971	AXIS Q 3/4 X 1063		01
05	0571019828	LOCK AXLE		02
06	0503013816	5/16" LOCKNUT		04
07	0581016970	AXIS Q 3/4 X 763		01
08	0501010942	3/8" X 1-1/4" BOLT		20
09	0503010025	3/8 SPRING WASHER		20
10	0503010026	3/8" NUT		20
11	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
12	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	65	02
13	0503030275	AGRICULTURAL BEARING		05




Item	Code	Description	See page	QT
01	0521066297	FERTILIZER SUPPORT LEFT BEAM		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	64	02
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	65	03
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503010025	3/8 SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0501056271	GEARBOX CLOSED BEARING	40	01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
11	0503010337	5/16" NUT		02
12	0581016972	AXIS Q 3/4 X 1953		01
13	0571019828	LOCK AXLE		01
14	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521018630	1.4" X SQUARE 0.8" WASHER		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	3/4 SQUARE AXLE FASTENER	42	01
20	0503030275	AGRICULTURAL BEARING		05
21	1902010685	18Z CONICAL GEAR		05




Item	Code	Description	See page	QT
01	0521056073	FERTILIZER BEAM SUPPORT	55	01
02	0531054820	6850 APT FERTILIZER HOPPER CENTRAL SUPPORT	59	01
03	0521056074	LFT FERTILIZER BEAM SUPPORT	57	01
04	0571019051	FIXER HOPPER WASHER		24
05	0503013751	3/8 UNC X 1.1/4 BOLT		24
06	0503012535	3/8" SPRING WASHER		24
07	0503012531	3/8" INOX NUT		24
08	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
09	0503010026	3/8" NUT		16
10	0503010849	3/8" X 1-1/2" BOLT		16
11	0503010025	3/8 SPRING WASHER		16
12	0503030085	LOCK PIN		02
13	0503034396	FERTILIZER SIDE COVER		15
14	0503010362	1/8 X 1.1/4 COTTERPIN		15
15	0503011957	NYLON LUG		02
16	0503010371	5/16" X 1" BOLT		04
17	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
18	0503010337	5/16" NUT		04
19	0503062391	FERTILIZER HOPPER		03
20	0521050194	SQUARE AXLE RIGHT SUPPORT	67	01
21	0521050195	SQUARE AXLE LEFT SUPPORT	68	01
22	0521010572	0.9" X 2.9" COUPLING SHAFT		02




Item	Code	Description	See page	QT
01	0521066296	CENTRAL SEED HOPPER SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	64	03
03	0502012990	CONICA 14Z SQUARE GEAR		05
04	0591018053	3/4 X 2094 SQUARE AXLE		01
05	0571019828	LOCK AXLE		01
06	0503013816	5/16" LOCKNUT		01
07	0501010942	3/8" X 1-1/4" BOLT		20
08	0503010025	3/8 SPRING WASHER		20
09	0503010026	3/8" NUT		20
10	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		01
11	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	65	02
12	0503030275	AGRICULTURAL BEARING		05




Item	Code	Description	See page	QT
01	0521056437	7655 RIGHT FERTILIZER HOPPER SUPPORT	61	01
02	0521056117	CENTRAL FERTILIZER HOPPER SUPPORT	62	01
03	0521056436	7655 LEFT FERTILIZER HOPPER SUPPORT	63	01
04	0571019051	FIXER HOPPER WASHER		28
05	0503013751	3/8 UNC X 1.1/4 BOLT		28
06	0503012535	3/8" SPRING WASHER		28
07	0503012531	3/8" INOX NUT		28
08	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
09	0503010026	3/8" NUT		16
10	0503010849	3/8" X 1-1/2" BOLT		16
11	0503010025	3/8 SPRING WASHER		16
12	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	66	02
13	0503034396	FERTILIZER SIDE COVER		17
14	0503010362	1/8 X 1.1/4 COTTERPIN		17
15	0503011957	NYLON LUG		02
16	0503010371	5/16" X 1" BOLT		04
17	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
18	0503010337	5/16" NUT		04
19	0503062362	FERTILIZER HOPPER		02
20	0503062391	FERTILIZER HOPPER		02
21	0521010572	0.9" X 2.9" COUPLING SHAFT		02
22	0503030085	LOCK PIN		02




Item	Code	Description	See page	QT
01	0521066295	FERTILIZER BEAM RIGHT SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	64	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	65	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503010025	3/8 SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0501056271	GEARBOX CLOSED BEARING	40	01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
11	0503010337	5/16" NUT		02
12	0591011113	SQUARE SHAFT 3/4 X 1896		01
13	0571019828	LOCK AXLE		01
14	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521018630	1.4" X SQUARE 0.8" WASHER		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	3/4 SQUARE AXLE FASTENER	42	01
20	0503030275	AGRICULTURAL BEARING		05
21	1902010685	18Z CONICAL GEAR		05




Item	Code	Description	See page	QT
01	0521067404	CENTRAL FERTILIZER HOPPER SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	64	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	65	04
04	0501010942	3/8" X 1-1/4" BOLT		32
05	0503010025	3/8 SPRING WASHER		32
06	0503010026	3/8" NUT		32
07	0571019828	LOCK AXLE		02
08	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
09	0503013816	5/16" LOCKNUT		04
10	0581016965	3/4" X 1070 SQUARE SHAFT 19 E 450		01
11	0581016966	AXIS Q 3/4 X 1371		01
12	1902010685	18Z CONICAL GEAR		07
13	0503030275	AGRICULTURAL BEARING		07
14	0511062163	FERTILIZER BEAM LOWER COVER		01
15	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521066297	FERTILIZER SUPPORT LEFT BEAM		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	64	02
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	65	03
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503010025	3/8 SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0501056271	GEARBOX CLOSED BEARING	40	01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
11	0503010337	5/16" NUT		02
12	0591011113	SQUARE SHAFT 3/4 X 1896		01
13	0571019828	LOCK AXLE		01
14	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521018630	1.4" X SQUARE 0.8" WASHER		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	3/4 SQUARE AXLE FASTENER	42	01
20	0503030275	AGRICULTURAL BEARING		05
21	1902010685	18Z CONICAL GEAR		05




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01



Item	Code	Description	See page	QT
01	0503030331	1.2" X 1.2" X 12.2" HOSE		01
02	0503010243	CLAMP		02
03	0503062755	TRANSMISSION AXLE		01
04	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
05	0503012880	1/4" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0581013322	BEARING RIGHT SUPPORT		01
02	0503011953	5/16" X 1" BOLT		04
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	0501010694	FLAT WASHER		04
05	0503013816	5/16" LOCKNUT		04
06	0501056444	BEARING WITH ROLLER	41	01




Item	Code	Description	See page	QT
01	0581013324	BEARING LEFT SUPPORT		01
02	0503011953	5/16" X 1" BOLT		04
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	0501010694	FLAT WASHER		04
05	0503013816	5/16" LOCKNUT		04
06	0501056444	BEARING WITH ROLLER	41	01

PLATFORM SET

0521056104




Item	Code	Description	See page	QT
001	0521067102	ARTICULATION CENTRAL PLATFORM		04
002	0531060015	PLATFORM SET		01
003	0503011336	1/2" HEX SELF ADJUSTING NUT		06
004	0503010741	1/2" X 2-3/4" BOLT		06
005	0521067100	LEFT PLATAFORM		01
006	0521067104	LEFT SIDE ARTICULATION PLATFORM		01
007	0521067101	RIGHT PLATAFORM		01
008	0521067103	RIGHT SIDE ARTICULATION PLATFORM		01
009	0581012193	PLATFORM AMENDMENT PROTECTION		02
010	0551019115	LOCKING PLATFORM FIXATION		03
011	0571019831	X 0.2" SLEEVE		03
012	0501010096	3/8" X 2" BOLT		03
013	0501010984	10,50 X 27 X 3,00 FLAT WASHER		31
014	0503013357	3/8 SELF-ADJUSTING NUT		03
015	0503011333	COVER FIXER		03
016	0503010274	5/32"X 2" COTTERPIN		03
017	1902012740	PLATFORM RIGHT FIXER SUPPORT		02
018	1902012739	PLATFORM LEFT FIXER SUPPORT		01
019	0503010849	3/8" X 1-1/2" BOLT		12
020	0503010025	3/8 SPRING WASHER		16
021	0503010026	3/8" NUT		16
022	0501010942	3/8" X 1-1/4" BOLT		04
023	0503010019	1/2" SPRING WASHER		02
024	0503010060	1/2 UNC G.5 ZN HEX NUT		02
025	0503011082	C1/2" X 1.3/4" SCREW		02




Item	Code	Description	See page	QT
01	0521067102	ARTICULATION CENTRAL PLATFORM	04	
02	0531060020	CENTRAL PLATFORM 8450	01	
03	0503011336	1/2" HEX SELF ADJUSTING NUT	06	
04	0503010741	1/2" X 2-3/4" BOLT	06	
05	0531060162	LEFT PLATFORM 7655	01	
06	0521067104	LEFT SIDE ARTICULATION PLATFORM	01	
07	0531060161	RIGHT PLATFORM 7655	01	
08	0521067103	RIGHT SIDE ARTICULATION PLATFORM	01	
09	0581012193	PLATFORM AMENDMENT PROTECTION	02	
10	0551019115	LOCKING PLATFORM FIXATION	03	
11	0571019831	X 0.2" SLEEVE	03	
12	0501010096	3/8" X 2" BOLT	03	
13	0501010984	10,50 X 27 X 3,00 FLAT WASHER	31	
14	0503013357	3/8 SELF-ADJUSTING NUT	03	
15	0503011333	COVER FIXER	03	
16	0503010274	5/32"X 2" COTTERPIN	03	
17	1902012740	PLATFORM RIGHT FIXER SUPPORT	02	
18	1902012739	PLATFORM LEFT FIXER SUPPORT	01	
19	0503010849	3/8" X 1-1/2" BOLT	12	
20	0503010025	3/8 SPRING WASHER	16	
21	0503010026	3/8" NUT	16	
22	0501010942	3/8" X 1-1/4" BOLT	04	
23	0503010019	1/2" SPRING WASHER	02	
24	0503010060	1/2 UNC G.5 ZN HEX NUT	02	
25	0503011082	C1/2" X 1.3/4" SCREW	02	

HANDRAIL SET


0521056078




Item	Code	Description	See page	QT
01	0503011082	C1/2" X 1.3/4" SCREW		04
02	0503010019	1/2" SPRING WASHER		08
03	0503010060	1/2 UNC G.5 ZN HEX NUT		08
04	0503034094	22 TWISTED CHAIN		04
05	0551019884	45 X 50 X 3/8 FASTENER		08
06	0503013357	3/8 SELF-ADJUSTING NUT		16
07	0571017991	CHAIN FIXER HANDRAIL		08
08	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
09	0521063871	SIDE HANDRAIL		02
10	0521057311	RIGHT HANDRAIL CSC ASSY	73	01
11	0521057314	LEFT HANDRAIL CSC ASSY	74	01




Item	Code	Description	See page	QT
01	0503011082	C1/2" X 1.3/4" SCREW		04
02	0503010019	1/2" SPRING WASHER		08
03	0503010060	1/2 UNC G.5 ZN HEX NUT		08
04	0503034094	22 TWISTED CHAIN		04
05	0551019884	45 X 50 X 3/8 FASTENER		08
06	0503013357	3/8 SELF-ADJUSTING NUT		16
07	0571017991	CHAIN FIXER HANDRAIL		08
08	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
09	0521063871	SIDE HANDRAIL		02
10	0521057334	ASSY RIGHT HANDRAIL - 7655/8450	75	01
11	0521057333	ASSY LEFT HANDRAIL - 7655/8450	76	01




Item	Code	Description	See page	QT
001	0531060546	CENTRAL CHAIN		01
002	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
003	0503010025	3/8 SPRING WASHER		04
004	0503010026	3/8" NUT		04
005	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04




Item	Code	Description	See page	QT
001	0531060547	CENTRAL CHAIN		01
002	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
003	0503010026	3/8" NUT		04
004	0503010025	3/8 SPRING WASHER		04
005	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04




Item	Code	Description	See page	QT
01	0531060562	RIGHT CENTRAL CHAIN 7655/8450		01
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04




Item	Code	Description	See page	QT
01	0531060561	LEFT CENTRAL CHAIN 7655/8450		01
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
03	0503010026	3/8" NUT		04
04	0503010025	3/8 SPRING WASHER		04
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04



Item	Code	Description	See page	QT
001	0503011372	102 TO 121 CLAMP		04
002	0521056081	ASSY HOSE SUPPORT	80	06
003	0521056143	RIGHT SIDE AIR DISTRIBUTOR	81	01
004	0521056112	LEFT SIDE AIR DISTRIBUTOR	82	01
005	0521051725	CENTRAL SEED HOPPER	79	01
006	0501082279	SPIRAL HOSE AIR 4 X 1300		02



Item	Code	Description	See page	QT
01	0503011372	102 TO 121 CLAMP		04
02	0521056081	ASSY HOSE SUPPORT	80	04
03	0521056143	RIGHT SIDE AIR DISTRIBUTOR	81	01
04	0521056112	LEFT SIDE AIR DISTRIBUTOR	82	01
05	0521057461	7655/8450 CENTRAL SEED HOPPER	83	01
06	0501082256	HOSE 3/8 X 200 TC-TC 90G RIGHT		01
07	0501082257	HOSE 3/8 X 200 TC-TC 90G LEFT		01
08	0503011271	3/4" UNF "T" CONNECTION T 3 SIDES		01
09	0501082255	HOSE 1/2 X 200 TR-TC		02
10	0503013493	T CONNECTION MALE		01
11	0501080113	1/2 X600 HOSE TR-TC		01
12	0521057177	ASSY ANTI CAVITATION VALVE	84	01
13	0501080113	1/2 X600 HOSE TR-TC		01
14	0521058023	NOZZLE Y ASSY	85	02
15	0501082279	SPIRAL HOSE AIR 4 X 1300		02




Item	Code	Description	See page	QT
01	0531060684	FIXED FRAME SEED HOPPER		01
02	0521053173	CENTRAL SEED HOPPER 15 OUTPUTS	86	01
03	0521045392	HYDRAULIC TURBINE WITH SCREEN	88	01
04	0511059406	TURBINE P.P MOUNTED		01
05	0521057188	ASSY SUPPORT AIR DUCT REAR	91	02
06	0521056114	CENTRAL REAR AIR CONDUCTOR	93	01
07	0521057341	CENTRAL AIR DISTRIBUTOR	95	01
08	0521056987	FIXED ARTICULATOR SUPPORT	96	02
09	0521057187	MOUNTED REAR AIR DUCT SUPPORT	97	02
10	0551019884	45 X 50 X 3/8 FASTENER		01
11	0503013357	3/8 SELF-ADJUSTING NUT		02
12	0531060402	FIXING LEFT		01
13	0531060401	RIGHT FIXATION		01
14	0521057346	FRONT / REAR SUPPORT	98	03
15	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
16	0503010026	3/8" NUT		04
17	0503010025	3/8 SPRING WASHER		04
18	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
19	0503013736	SCREW 5/8 UNF X 1.1/2 CS G.5 ZN		08
20	0501012140	FLAT WASHER		08
21	0503010811	5/8" UNF SELF ADJUSTING NUT		08
22	0591010677	PLATFORM SUPPORT SLEEVE		02
23	0521056083	MOUNTED CSC PLATFORM	99	01
24	0521056990	REAR SUPPORT HOSE ASSY	100	02
25	0521056989	ASSY CSC FIXED SUPPORT	101	02
26	0521056988	ASSY TURBINE REGULATOR BLOCK SUPPORT	102	01
27	0501082277	SPIRAL HOSE AIR 4 X 700		01
28	0501082278	SPIRAL HOSE AIR 4 X 1100		01
29	0501082279	SPIRAL HOSE AIR 4 X 1300		01
30	0503011372	102 TO 121 CLAMP		10
31	0521056986	FIXED SUPPORT ASSY CSC DRAIN	106	01


Item	Code	Description	See page	QT
32	0591011787	FRONT REAR SUPPORT TAPE		02
33	0591011785	SIDE SUPPORT TAPE 1300		02
34	0503010849	3/8" X 1-1/2" BOLT		04
35	0521053176	COVER KAP		01
35A	0581017528	15 OUTPUT TUBE COVER		01
35B	0503011372	102 TO 121 CLAMP		01
36	0521057315	ASSY SUPPORT TRANSPORT CSC	104	02
37	0521057288	VACUOMETER FIXING SUPPORT		01
37A	0591012157	VACUOMETER FIXATION		01
37B	0503013584	VACUUM GAUGE		02
38	0521056985	ASSY CSC PLATFORM SUPPORT	105	01
39	0501082274	SPIRAL HOSE AIR 4 X 600		01
40	0503013493	T CONNECTION MALE		01
41	0503011336	1/2" HEX SELF ADJUSTING NUT		02
42	0503014735	SCREW 1/2 UNC X 2		02

ASSY HOSE SUPPORT


0521056081




Item	Code	Description	See page	QT
01	0531060004	DUCT SEED SUPPORT		01
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
03	0571019403	STAPLE FIXER		01
04	0501013519	FLAT WASHER		02
05	0503011336	1/2" HEX SELF ADJUSTING NUT		02
06	0503010026	3/8" NUT		02
07	0501013518	FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		02



Item	Code	Description	See page	QT
01	0591010690	CONDUCTOR BODY AIR 5 MOUTH 1650 5 HOLES		01
02	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		05
02A	0503034812	SOCKET DISTRIBUTOR AR		01
02B	0503012856	POP RIVET		04
03	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
03A	0503034763	AIR DITRIBUTOR PUMP		01
03B	0503015341	POP RIVET		02
04	0503017845	90 PVC KNEE		01
05	0581013890	AIR DISTRIBUTOR SOCKET		01




Item	Code	Description	See page	QT
01	0591010690	CONDUCTOR BODY AIR 5 MOUTH 1650 5 HOLES		01
02	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		05
02A	0503034812	SOCKET DISTRIBUTOR AR		01
02B	0503012856	POP RIVET		04
03	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
03A	0503034763	AIR DITRIBUTOR PUMP		01
03B	0503015341	POP RIVET		02
04	0503017845	90 PVC KNEE		01
05	0581013890	AIR DISTRIBUTOR SOCKET		01




Item	Code	Description	See page	QT
01	0521053173	CENTRAL SEED HOPPER 15 OUTPUTS	86	01
02	0521045392	HYDRAULIC TURBINE WITH SCREEN	88	01
03	0521057188	ASSY SUPPORT AIR DUCT REAR	91	02
04	0521057462	CENTRAL REAR AIR CONDUCTOR 7655/8450	92	01
05	0521057463	CENTRAL AIR DISTRIBUTOR	94	01
06	0521056987	FIXED ARTICULATOR SUPPORT	96	02
07	0521057187	MOUNTED REAR AIR DUCT SUPPORT	97	02
08	0531060402	FIXING LEFT		01
09	0531060401	RIGHT FIXATION		01
10	0521057346	FRONT / REAR SUPPORT	98	03
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
12	0503010026	3/8" NUT		04
13	0503010025	3/8 SPRING WASHER		04
14	0503010849	3/8" X 1-1/2" BOLT		04
15	0503010811	5/8" UNF SELF ADJUSTING NUT		12
16	0503013736	SCREW 5/8 UNF X 1.1/2 CS G.5 ZN		12
17	0591010677	PLATFORM SUPPORT SLEEVE		02
18	0521056083	MOUNTED CSC PLATFORM	99	01
19	0521056990	REAR SUPPORT HOSE ASSY	100	02
20	0521056989	ASSY CSC FIXED SUPPORT	101	02
21	0521056988	ASSY TURBINE REGULATOR BLOCK SUPPORT	102	01
22	0521018615	HOSE 4 X 1300		01
23	0503011372	102 TO 121 CLAMP		12
24	0521056986	FIXED SUPPORT ASSY CSC DRAIN	106	01
25	0591011787	FRONT REAR SUPPORT TAPE		02
26	0591011785	SIDE SUPPORT TAPE 1300		02
27	0521053176	COVER KAP		01
27A	0581017528	15 OUTPUT TUBE COVER		01
27B	0503011372	102 TO 121 CLAMP		01
28	0521057315	ASSY SUPPORT TRANSPORT CSC	104	02
29	0521057288	VACUOMETER FIXING SUPPORT		01


Item	Code	Description	See page	QT
29A	0531060817	VACUOMETER FIXING SUPPORT		01
29B	0503013584	VACUUM GAUGE		02
30	0521056985	ASSY CSC PLATFORM SUPPORT	105	01
31	0531060571	7655/8450 CENTRAL SEED HOPPER FIXED BASE		01
32	0521057178	TURBINE PRECISION PLANTING WITHOUT VALVE	107	02
33	0501082273	SPIRAL HOSE AIR 4 X 500		02
34	0501082275	SPIRAL HOSE AR 4 X 900		01
35	0503017845	90 PVC KNEE		01
36	0581013890	AIR DISTRIBUTOR SOCKET		01
37	0501082276	SPIRAL HOSE AIR 4 X 1000		01
38	0501082274	SPIRAL HOSE AIR 4 X 600		01
39	0521056081	ASSY HOSE SUPPORT	80	02
40	0503011271	3/4" UNF "T" CONNECTION T 3 SIDES		04
41	0503011336	1/2" HEX SELF ADJUSTING NUT		02
42	0503014735	SCREW 1/2 UNC X 2		02
43	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
44	0521057919	ASSY CSC TURBINE PROTECTION	109	01
45	0521057917	RIGHT REAR AIR DUCT FIXING COMPLETE ASSY	110	01
46	0501012140	FLAT WASHER		12




Item	Code	Description	See page	QT
01	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
02	0503010190	2-114 N 3006-9B O'RING		02
03	0501011460	7/8 NF REDUCTION NIPPLE		02
04	0503013055	"T" ADAPTOR WITH GIRAT NUT		01




Item	Code	Description	See page	QT
01	0531060909	CSC SEED NOZZLE 7655/8450		01
02	0503010184	CLAMP		03
03	0591013769	NOZZLE HOSE FIXING SLEEVE		02




Item	Code	Description	See page	QT
01	0521068977	15 OUTPUTS AIR TUBE		01
02	0521053175	BASE CSC HOPPER 15 OUTPUTS	87	01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		26
04	0503015075	M10 SPRING WASHER		26
05	0503010025	3/8 SPRING WASHER		08
06	0503010172	M10 X 1,5 X 25 BOLT		26
07	0503062687	SEED HOPPER		01
08	0503019284	M8 X BOLT		04
09	0503010849	3/8" X 1-1/2" BOLT		08
10	0581017922	WASHER		04




Item	Code	Description	See page	QT
01	0521068978	CASH FUND COVER	03	
02	0503015135	FLAT WASHER 10 X 18 X 2	06	
03	0503011823	0.1" X 0.6" SPRING PIN	06	
04	0521068851	SYSTEM ASSY	01	
05	0503034571	SEALING	01	
06	0503034573	SEALING	03	
07	0581017529	ROD 9,53	03	
08	0503062759	SEALING	03	
09	0503034692	FAST LOCK ASSY	06	
10	0503030085	LOCK PIN	06	
11	0503019290	BOLT	24	




Item	Code	Description	See page	QT
01	0501054983	NIPPLE HIDRAULIC MOTOR	89	01
02	0503010025	3/8 SPRING WASHER		12
03	0503010026	3/8" NUT		10
04	0521044613	FAN 480X50 (HIDRAULIC)		01
05	0503010143	1/4" SPRING WASHER		01
06	0503010849	3/8" X 1-1/2" BOLT		02
07	0531018764	FLAT WASHER		01
08	0503011104	M6 X 1" BOLT		01
09	0503012722	0.16" X 0.4" BLIND RIVET		24
10	0521065857	CARACOL MECHANICAL TURBINE S MEC		01
11	0521065858	TURBIN SUPPORT		01
12	0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC 90 TURBINE		01
13	0561010634	VALVE SUPPORT ASSY		01
14	0503010237	3/8" X 1" BOLT		08
15	0503010206	3/8 X 1/2 BOLT		02
16	0571018577	COVER SNAIL TURBINE		01
17	0571018578	TURBINE PROTECTIVE SCREEN		01
18	0541013274	LISA WASHER 10 X 38 X 4.75		02
19	0521069167	FRONT PROTECTION		01
20	0501080709	3/8" X 21.6" TR-TR HOSE		01
21	0501080091	1/2" X 550 TR-TR HOSE		02
22	0503031087	ADHESIVE LABEL		01
23	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01
24	0503033981	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503012871	HYDRAULIC MOTOR		01
02	0531018770	R 3/4"UNF X R 1/4"BSP ELBOW		01
03	0561016941	3/4" NUT		01
04	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
05	0541011065	3/4"UNF X R1/4BSP19FPP X43.5 NIPPLE		01
06	3914103037	TEFLON		0,001RI




Item	Code	Description	See page	QT
01	0503012291	BLOCK COMMAND		01
02	0501010590	NIPPLE		04
03	0503010045	O'RING		04
04	0541011066	3/4" UNF X 43.5 NIPPLE		01
05	0503010190	2-114 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0591012159	CENTRAL REAR AIR DUCT SUPPORT		01
02	0521014442	LOWER AIR DISTRIBUTOR SUPPORT		01
03	0503010371	5/16" X 1" BOLT		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
08	0503010025	3/8 SPRING WASHER		02
09	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0591010691	1650 REAR AIR CONDUCTOR BODY		01
02	0503017845	90 PVC KNEE		02
03	0581013890	AIR DISTRIBUTOR SOCKET		03
04	0503012567	T-JOIN FOR TUBE 110		01
05	0591013551	REAR AIR CONDUCTOR BODY 490		01




Item	Code	Description	See page	QT
01	0591010691	1650 REAR AIR CONDUCTOR BODY		01
02	0503017845	90 PVC KNEE		02
03	0581013890	AIR DISTRIBUTOR SOCKET		02




Item	Code	Description	See page	QT
01	0503012567	T-JOIN FOR TUBE 110		03
02	0581013890	AIR DISTRIBUTOR SOCKET		04
03	0503017845	90 PVC KNEE		01
04	0591012376	110 X 230 SLEEVE		01
05	0591010690	CONDUCTOR BODY AIR 5 MOUTH 1650 5 HOLES		01
06	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		07
06A	0503034812	SOCKET DISTRIBUTOR AR		01
06B	0503012856	POP RIVET		04
07	0591012415	AR 500 DISTRIBUTOR BODY 7655/8450		01
08	0581012427	AIR DISTRIBUTOR NOZZLE		01
09	0591012414	AR 400 DISTRIBUTOR BODY 7655/8450		01




Item	Code	Description	See page	QT
01	0591010690	CONDUCTOR BODY AIR 5 MOUTH 1650 5 HOLES		01
02	0503012567	T-JOIN FOR TUBE 110		02
03	0581013890	AIR DISTRIBUTOR SOCKET		04
04	0503017845	90 PVC KNEE		01
05	0591012376	110 X 230 SLEEVE		01
06	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		05
06A	0503034812	SOCKET DISTRIBUTOR AR		01
06B	0503012856	POP RIVET		04




Item	Code	Description	See page	QT
01	0531060396	ARTICULED SUPPORT		01
02	0591011817	ARTICULATED SLEEVE SUPPORT		02
03	0502011170	FIXER		02
04	0501012140	FLAT WASHER		08
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503018814	SCREW 5/8 UNF X 5" G.5 CS ZN		04
07	0551019884	45 X 50 X 3/8 FASTENER		01
08	0503013357	3/8 SELF-ADJUSTING NUT		02
09	0501014251	FLAT WASHER		02
10	0503011125	SELF ADJUSTING 7/8" UNC NUT		02
11	0503011121	7/8" X 7" BOLT		02




Item	Code	Description	See page	QT
01	0591012158	REAR AIR DUCT SUPPORT		01
02	0521014442	LOWER AIR DISTRIBUTOR SUPPORT		01
03	0503010371	5/16" X 1" BOLT		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
07	0503010025	3/8 SPRING WASHER		02
08	0503010026	3/8" NUT		02
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02




Item	Code	Description	See page	QT
01	0581012238	SEED HOPPER SUPPORT		01
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
03	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0531060007	PLATFORM		01
02	0591010677	PLATFORM SUPPORT SLEEVE		02
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010371	5/16" X 1" BOLT		04
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
06	0503010337	5/16" NUT		04
07	0503011907	NYLON HANDLE		02
08	0503011082	C1/2" X 1.3/4" SCREW		02
09	0503011336	1/2" HEX SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0531060404	REAR SUPPORT HOSE		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02




Item	Code	Description	See page	QT
01	0531060403	SUPPORT FIXING ARTICULATION		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0502010891	SPRING CHOCK SUPPORT VARON		01
04	0503030679	BOLT 1/2 UNC X 1.1/4 C50A G.5 ZN		01
05	0503017857	BOLT 5/8 UNF 4		04
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0591012104	COMMAND BLOCK SUPPORT		01
02	0511059542	BLOCK COMMAND TURBINES	103	01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503014007	1/2" X 1-1/4" BOLT		04
07	0503015115	M8 X 1,25 X 12 BOLT		04
08	0503014371	M8 SPRING WASHER		04




Item	Code	Description	See page	QT
01	0503018597	BLOCK COMMAND		01
02	0503010190	2-114 N 3006-9B O'RING		02
03	0501011460	7/8 NF REDUCTION NIPPLE		02
04	0503011109	2-119 N 3006-9B O'RING		04
05	0571013917	7/8"NF X 1.1/16 UNF NIPPLE		04




Item	Code	Description	See page	QT
01	0531060397	TRANSPORT SUPPORT		01
02	0503011121	7/8" X 7" BOLT		01
03	0503011125	SELF ADJUSTING 7/8" UNC NUT		01
04	0501014251	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0591011797	PLATFORM SUPPORT BODY		01
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04




Item	Code	Description	See page	QT
01	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0502010477	HOSE CLAMP		02
06	0581018419	SUPPORT		02
07	0531060398	BODY SUPPORT SUPPORT FIXING DRAIN		01
08	0503011135	BOLT		02




Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE		01
02	0501011460	7/8 NF REDUCTION NIPPLE		02
03	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
04	0503010392	2-046 N 3006 9B O'RING		01
05	0581012096	ROUND SLEEVE		02
06	0521050154	PRECISION PLANTING TURBINE WITH HOLE	108	01
07	0503010190	2-114 N 3006-9B O'RING		02
08	0501081235	1/2 X 650 TR- TC HOSE		01
09	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01
10	0503031087	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01




Item	Code	Description	See page	QT
01	0591013550	TURBINE MOTOR PROTECTION		01
02	0503010026	3/8" NUT		02
03	0503010025	3/8 SPRING WASHER		02
04	0503012456	3/8" X 7/8" BOLT		02
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
06	0503012560	3/8" X 1" BOLT		04
07	0503019413	THREAD SCREW INTERNAL		04




Item	Code	Description	See page	QT
01	0591013546	RIGHT REAR AIR DUCT SUPPORT BODY		01
02	0521014442	LOWER AIR DISTRIBUTOR SUPPORT		01
03	0503010371	5/16" X 1" BOLT		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2 UNC G.5 ZN HEX NUT		02
08	0501010161	1/2" X 1.1/4" BOLT		02

ASSY LADDER

0511053356




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		04
02	0503010237	3/8" X 1" BOLT		08
03	0503010025	3/8 SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0511069636	LADDER		02
06	0503011179	3/8" X 2-1/4" BOLT		04
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
08	0503013357	3/8 SELF-ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0502011530	SUPPORT		02
02	0502010175	HITCH CLAMP		02
03	0501011543	5/8" X 4" BOLT		04
04	0503012412	5/8 UNC SELF LOCKING NUT		04
05	0501069951	PLOUGH SUPPORT		04
06	0501011075	PIN		02
07	0503030012	HITCH PIN CLIP		02

JACK ASSEMBLY


0511054971



Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01



Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0503010267	NYLON CLAMP		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	5/16" NUT		01



Item	Code	Description	See page	QT
001	0503034968	ADHESIVE LABEL CSC 170 X 820		01
002	0503034969	ADHESIVE LABEL CSC 165 X 850		01
003	0503034970	LOGO TATU MARCHESAN (CSC) 155 X 1120 ADHESIVE LABEL		01
004	0503034971	ADHESIVE LABEL LOGO TATU MARCHESAN (CSC) 150 X 1130		01
005	0503034338	ADHESIVE LABEL		02
006	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		03
007	0503034985	ADHESIVE LABEL		03
008	0503031565	ADHESIVE LABEL CARE		02
009	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
010	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
011	0503032930	ADHESIVE LABEL DANGER		04
012	0503031425	ADHESIVE LABEL ATTENTION		02
013	0503031087	ADHESIVE LABEL		01
014	0503031942	ADHESIVE LABEL		01
015	0503031669	ADHESIVE LABEL		01
016	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
017	0503034249	ADHESIVE LABEL TABLE PLANTS		02
018	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
019	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
020	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
021	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING		02
022	0503033422	ADHESIVE LABEL		02
023	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		04
024	0503034078	LIFTING POINTS DECAL		03
025	0503032979	ADHESIVE LABEL LETTERS A B C D		02
026	0503032949	ADHESIVE LABEL		01
027	0503031428	READ MANUAL DECAL		01

SET LABEL ADHESIVE

0521057201

Item	Code	Description	See page	QT
028	0503034500	ADHESIVE LABEL		01
029	0521056998	ALUMINUM IDENTIFICATION LABEL WITH RIVET		01
029A	0503034003	SERIAL NUMBER TAG 61 X 118		01
029B	0503010001	3.2 X 5.5 RIVET		04
030	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER		02
031	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER		01
032	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM		02
033	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM		02




Item	Code	Description	See page	QT
001	0503034968	ADHESIVE LABEL CSC 170 X 820		01
002	0503034969	ADHESIVE LABEL CSC 165 X 850		01
003	0503034970	LOGO TATU MARCHESAN (CSC) 155 X 1120 ADHESIVE LABEL		01
004	0503034971	ADHESIVE LABEL LOGO TATU MARCHESAN (CSC) 150 X 1130		01
005	0503034338	ADHESIVE LABEL		02
006	0503034964	ADHESIVE LABEL		02
007	0503034983	LOGO TATU MARCHESAN ADHESIVE LABEL 190 X 613		02
008	0503034965	ADHESIVE LABEL		02
009	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		02
010	0503034985	ADHESIVE LABEL		02
011	0503031565	ADHESIVE LABEL CARE		02
012	0503032930	ADHESIVE LABEL DANGER		06
013	0503031425	ADHESIVE LABEL ATTENTION		02
014	0503031428	READ MANUAL DECAL		01
015	0503031087	ADHESIVE LABEL		01
016	0503031942	ADHESIVE LABEL		01
017	0503031669	ADHESIVE LABEL		01
018	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
019	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
020	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING		02
021	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		04
022	0503033421	ADHESIVE LABEL 7 NUMBER FOR PLANTING		02
023	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		04
024	0503034078	LIFTING POINTS DECAL		03
025	0503032979	ADHESIVE LABEL LETTERS A B C D		02
026	0503032949	ADHESIVE LABEL		01
027	0503034500	ADHESIVE LABEL		01
028	0521056998	ALUMINUM IDENTIFICATION LABEL WITH RIVET		01

**SET LABEL ADHESIVE**

0521057949

Item	Code	Description	See page	QT
028A	0503034003	SERIAL NUMBER TAG 61 X 118		01
028B	0503010001	3.2 X 5.5 RIVET		04
029	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER		02
030	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER		01
031	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM		02
032	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM		02



Item	Code	Description	See page	QT
01	0501048790	AXLE WITH RING	121	02
02	0551018209	DRIVING AXLE		01
03	0521018259	DRIVEN AXLE		01
04	0551018210	DRIVEN AXLE		01
05	0551018211	INTERM SHAFT		01
06	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	122	01
07	0503030303	SUPPORT WASHER		06
08	0501056443	GEAR HOUSING BEARING	123	02
09	0511059266	CLOSED BEARING	124	05
10	0503012389	1/2 BALL		04
11	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04
12	0503010834	1/2 X 1 BOLT		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		06
14	0503031805	11Z 1/2" GEAR		04
15	0503010302	501019 SEAL RING		04
16	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
17	0511067501	26Z GEAR		01
18	0521018630	1.4" X SQUARE 0.8" WASHER		05
19	0503010292	701164 6 X 40 SPRING PIN		10
20	0501054655	CHAIN TENSIONER ASSY	125	02
21	0591010679	19.4 / 19.6 X 26 BEARING		01
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
23	0503010256	3/8" X 3/4" BOLT		01
24	0503012204	40-1 CHAIN X 82 LINK + RED		02
25	0503019573	CHAIN		01
26	0511060396	DRIVE/DRIVEN SHAFT		04
27	0511061822	25Z P0.5" GEAR SQUARE HOL		01
28	0502011758	REAR TIGHTENER LEVER		02
29	0531060029	LONGER CURRENT STRETCHER WITHOUT LUBRICATION		01
30	0503031367	SPRING		01
31	0503031366	RIGHT TWISTED SPRING		01


ASSY RIGHT EXCHANGE

0521056086

Item	Code	Description	See page	QT
32	0531060009	RIGHT EXCHANGE BODY WITHOUT LUBRICATION		01
33	0503019418	SLEEVE		04
34	0503011034	RING		04
35	0531060025	MINOR CHAIN STRETCHER WITHOUT LUBRICATION		01
36	0511059261	CHAIN TENSIONER	126	01
37	0503014734	BOLT		02
38	0503010019	1/2" SPRING WASHER		02
39	0521060879	38Z GEAR		01
40	0511061759	22Z P12,70 FQ 3/4" GEAR		01

RIGHT GEAR BOX ASSY

0531052781



Item	Code	Description	See page	QT
01	0501048790	AXLE WITH RING	121	02
02	0551018209	DRIVING AXLE		01
03	0521018259	DRIVEN AXLE		01
04	0551018210	DRIVEN AXLE		01
05	0551018211	INTERM SHAFT		01
06	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	122	01
07	0503030303	SUPPORT WASHER		06
08	0501056443	GEAR HOUSING BEARING	123	02
09	0511059266	CLOSED BEARING	124	05
10	0503012389	1/2 BALL		04
11	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
12	0503010834	1/2 X 1 BOLT		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		06
14	0503031805	11Z 1/2" GEAR		04
15	0503010302	501019 SEAL RING		04
16	0511061830	17Z P 0.5" GEAR SQUARE HOL		03
17	0511067501	26Z GEAR		01
18	0521018630	1.4" X SQUARE 0.8" WASHER		05
19	0503010292	701164 6 X 40 SPRING PIN		10
20	0501054655	CHAIN TENSIONER ASSY	125	02
21	0591010679	19.4 / 19.6 X 26 BEARING		01
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
23	0503010256	3/8" X 3/4" BOLT		01
24	0503012204	40-1 CHAIN X 82 LINK + RED		02
25	0503012713	40-1 CHAIN X 45 LINK + MEN		01
26	0511060396	DRIVE/DRIVEN SHAFT		04
27	0511061822	25Z P0.5" GEAR SQUARE HOL		01
28	0502011758	REAR TIGHTENER LEVER		02
29	0531060029	LONGER CURRENT STRETCHER WITHOUT LUBRICATION		01
30	0503031367	SPRING		01
31	0503031366	RIGHT TWISTED SPRING		01


RIGHT GEAR BOX ASSY

0531052781

Item	Code	Description	See page	QT
32	0531060009	RIGHT EXCHANGE BODY WITHOUT LUBRICATION		01
33	0503019418	SLEEVE		04
34	0503011034	RING		04
35	0531060025	MINOR CHAIN STRETCHER WITHOUT LUBRICATION		01
36	0511059261	CHAIN TENSIONER	126	01
37	0503014734	BOLT		02
38	0503010019	1/2" SPRING WASHER		02

ASSY LEFT EXCHANGE

0521056087



Item	Code	Description	See page	QT
01	0501048790	AXLE WITH RING	121	02
02	0551018209	DRIVING AXLE		01
03	0521018259	DRIVEN AXLE		01
04	0551018210	DRIVEN AXLE		01
05	0551018211	INTERM SHAFT		01
06	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	122	01
07	0503030303	SUPPORT WASHER		06
08	0501056443	GEAR HOUSING BEARING	123	02
09	0511059266	CLOSED BEARING	124	05
10	0503012389	1/2 BALL		04
11	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
12	0503010834	1/2 X 1 BOLT		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		06
14	0503031805	11Z 1/2" GEAR		04
15	0503010302	501019 SEAL RING		04
16	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
17	0511067501	26Z GEAR		01
18	0521018630	1.4" X SQUARE 0.8" WASHER		05
19	0503010292	701164 6 X 40 SPRING PIN		10
20	0501054655	CHAIN TENSIONER ASSY	125	02
21	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
22	0503010256	3/8" X 3/4" BOLT		01
23	0503012204	40-1 CHAIN X 82 LINK + RED		02
24	0503019573	CHAIN		01
25	0511060396	DRIVE/DRIVEN SHAFT		04
26	0511061822	25Z P0.5" GEAR SQUARE HOL		01
27	0502011758	REAR TIGHTENER LEVER		02
28	0531060029	LONGER CURRENT STRETCHER WITHOUT LUBRICATION		01
29	0503031367	SPRING		01
30	0503031366	RIGHT TWISTED SPRING		01
31	0531060008	LEFT EXCHANGE BODY WITHOUT LUBRICATION		01


ASSY LEFT EXCHANGE

0521056087

Item	Code	Description	See page	QT
32	0531060025	MINOR CHAIN STRETCHER WITHOUT LUBRICATION		01
33	0503019418	SLEEVE		04
34	0503011034	RING		04
35	0511059261	CHAIN TENSIONER	126	01
36	0591010679	19.4 / 19.6 X 26 BEARING		01
37	0503014734	BOLT		02
38	0503010019	1/2" SPRING WASHER		02
39	0521060879	38Z GEAR		01
40	0511061759	22Z P12,70 FQ 3/4" GEAR		01


LEFT GEAR BOX ASSY

0531052782




Item	Code	Description	See page	QT
01	0501048790	AXLE WITH RING	121	02
02	0551018209	DRIVING AXLE		01
03	0521018259	DRIVEN AXLE		01
04	0551018210	DRIVEN AXLE		01
05	0551018211	INTERM SHAFT		01
06	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	122	01
07	0503030303	SUPPORT WASHER		06
08	0501056443	GEAR HOUSING BEARING	123	02
09	0511059266	CLOSED BEARING	124	05
10	0503012389	1/2 BALL		04
11	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04
12	0503010834	1/2 X 1 BOLT		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		06
14	0503031805	11Z 1/2" GEAR		04
15	0503010302	501019 SEAL RING		04
16	0511061830	17Z P 0.5" GEAR SQUARE HOL		03
17	0511067501	26Z GEAR		01
18	0521018630	1.4" X SQUARE 0.8" WASHER		05
19	0503010292	701164 6 X 40 SPRING PIN		10
20	0501054655	CHAIN TENSIONER ASSY	125	02
21	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
22	0503010256	3/8" X 3/4" BOLT		01
23	0503012204	40-1 CHAIN X 82 LINK + RED		02
24	0503012713	40-1 CHAIN X 45 LINK + MEN		01
25	0511060396	DRIVE/DRIVEN SHAFT		04
26	0511061822	25Z P0.5" GEAR SQUARE HOL		01
27	0502011758	REAR TIGHTENER LEVER		02
28	0531060029	LONGER CURRENT STRETCHER WITHOUT LUBRICATION		01
29	0503031367	SPRING		01
30	0503031366	RIGHT TWISTED SPRING		01
31	0531060008	LEFT EXCHANGE BODY WITHOUT LUBRICATION		01


Item	Code	Description	See page	QT
32	0531060025	MINOR CHAIN STRETCHER WITHOUT LUBRICATION		01
33	0503019418	SLEEVE		04
34	0503011034	RING		04
35	0511059261	CHAIN TENSIONER	126	01
36	0591010679	19.4 / 19.6 X 26 BEARING		01
37	0503014734	BOLT		02
38	0503010019	1/2" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	41	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	40	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503031805	1 1/2" GEAR		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
02	0503010019	1/2" SPRING WASHER		02
03	0503010060	1/2 UNC G.5 ZN HEX NUT		02
04	0561017281	ARTICULACION ARM		02
05	0521056135	BEARING GEAR WITH DOUBLE	128	02
06	0521055217	LOWER CURRENT STRETCH	131	04
07	0521056134	STRETCHER FERTILIZER CURRENT 17Z	132	02
08	0521054446	LOWER CURRENT STRETCHER 21Z	133	02
09	0571019829	LEVER FIXER		02
10	0503010237	3/8" X 1" BOLT		06
11	0503010025	3/8 SPRING WASHER		06
12	0503010026	3/8" NUT		06
13	0571019830	LEVER FIXER		02
14	0503011312	ROTATIVE CABLE		02
15	0503030093	TRACTION SPRING		02
16	0561017273	FIXER SPRING		02
17	0561017282	LOWER LEVER		02
18	0561016797	SLEEVE UNION LEVER		02
19	0591010705	ARTICULATION SLEEVE		02
20	0503011082	C1/2" X 1.3/4" SCREW		02
21	0521010773	0.37" X 1.18" COUPLING SHAFT		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
23	0541014973	COUPLING SHAFT		02
24	0503010140	1/8" X 3/4" COTTERPIN		04
25	0503017874	BOLT 1/2 UNC		02
26	0503011336	1/2" HEX SELF ADJUSTING NUT		02
27	0503013065	40-1 X 159 CHAIN LINK + MENDING		02
28	0503016737	40-1 X 114 CHAIN LINK + REDUCION		02




Item	Code	Description	See page	QT
01	0503019356	BEARING 6005 2RS1		02
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0503012412	5/8 UNC SELF LOCKING NUT		01
04	0521061843	20Z DOBLE GEAR		01
05	0551019175	DOUBLE GEAR AXLE		01
06	0501010163	5/8" X 4-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
02	0503010019	1/2" SPRING WASHER		02
03	0503010060	1/2 UNC G.5 ZN HEX NUT		02
04	0561017281	ARTICULACION ARM		02
05	0531052780	DOUBLE BEARING WITH 22Z X 20Z GEAR	130	02
06	0521055217	LOWER CURRENT STRETCH	131	04
07	0521056134	STRETCHER FERTILIZER CURRENT 17Z	132	02
08	0521054446	LOWER CURRENT STRETCHER 21Z	133	02
09	0571019829	LEVER FIXER		02
10	0503010237	3/8" X 1" BOLT		06
11	0503010025	3/8 SPRING WASHER		06
12	0503010026	3/8" NUT		06
13	0571019830	LEVER FIXER		02
14	0503011312	ROTATIVE CABLE		02
15	0503030093	TRACTION SPRING		02
16	0561017273	FIXER SPRING		02
17	0561017282	LOWER LEVER		02
18	0561016797	SLEEVE UNION LEVER		02
19	0591010705	ARTICULATION SLEEVE		02
20	0503011082	C1/2" X 1.3/4" SCREW		02
21	0521010773	0.37" X 1.18" COUPLING SHAFT		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
23	0541014973	COUPLING SHAFT		02
24	0503010140	1/8" X 3/4" COTTERPIN		04
25	0503017874	BOLT 1/2 UNC		02
26	0503011336	1/2" HEX SELF ADJUSTING NUT		02
27	0503013065	40-1 X 159 CHAIN LINK + MENDING		02
28	0503016737	40-1 X 114 CHAIN LINK + REDUCION		02




Item	Code	Description	See page	QT
01	0503019356	BEARING 6005 2RS1		02
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0503012412	5/8 UNC SELF LOCKING NUT		01
04	0531062898	DOUBLE GEAR		01
05	0551019175	DOUBLE GEAR AXLE		01
06	0501010163	5/8" X 4-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8 SPRING WASHER		01
09	0503010013	5/8 NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503019355	BEARING 6202 2RS1		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	0591010693	CURRENT DEVIATION SLEEVE		01
08	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01




Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503019356	BEARING 6005 2RS1		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0501012140	FLAT WASHER		01
06	0581015136	40MM STRETCHING SHAFT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01
08	0501011541	5/8" X 3" BOLT		01




Item	Code	Description	See page	QT
01	0561019899	RIGHT GEARBOX FIXER SUPPORT		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0503011082	C1/2" X 1.3/4" SCREW		02
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2 UNC G.5 ZN HEX NUT		02



Item	Code	Description	See page	QT
01	0561019898	LEFT SUPPORT FIXER GEARBOX		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0503011082	C1/2" X 1.3/4" SCREW		02
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0503013030	5/8" X 3.1/4" BOLT		02
02	0511050681	TRACTION SPRING		01
02A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
02B	0561016062	SPRING HITCH		02
03	0501012140	FLAT WASHER		04



Item	Code	Description	See page	QT
01	0521057899	SUPPORT VALVE BLOCK VACUOMETER ASSY 5750/7350		01
02	0521057886	HOSE CLAMP ASSEMBLY	143	02
03	0581010324	HOSE PROTECTOR		01
04	0503010358	5/16" X 5/8" BOLT		04
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
06	0503010337	5/16" NUT		04
07	0503013493	T CONNECTION MALE		02
08	0521057259	OIL CONDUCTOR FIXATION	139	08
09	0531060538	OIL CONDUCTOR		04
10	0531060537	OIL CONDUCTOR		02
11	0531060540	OIL TUBE		02
12	0531060545	OIL DUCT 275 6350		02
13	0521057915	HOSE KIT HYDRAULIC SYSTEM 6 WHEEL		01
13A	0501082269	HOSE 1/2 X 300 TR-TR		04
13B	0501080087	1/2" X 450 HOSE		03
13C	0501080096	1/2 X 500 TC-TC HOSE		08
13D	0501081235	1/2 X 650 TR- TC HOSE		02
13E	0501080024	1/2" X 700 TR-TR HOSE		04
13F	0501080218	1/2 X 750 HOSE		02
13G	0501080093	1/2 X 1300 HOSE TR-TC		01
13H	0501080058	HOSE 1/2 X 1400 TR-TC		01
13I	0501081834	1/2 X 1500 TR-TC HOSE		02
13J	0521057243	1/2 X 4350 TC-TM HOSE BLACK / RED		01
13JA	0501082259	HOSE 1/2 X 4350 TC-TM		01
13JB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
13JC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
13JD	0503018952	PLASTIC BOLT		06
13K	0521057244	HOSE 1/2 X 4900 TC-TM BLACK / BLUE		01
13KA	0501082260	HOSE 1/2 X 4900 TC-TM		01
13KB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
13KC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01

Item	Code	Description	See page	QT
13KD	0503018952	PLASTIC BOLT		06
14	0521057704	SLIDING SUPPORT HYDRAULIC HOSE	140	04
15	0581010091	SPRING PROTECTION PLASTIC HOSE		01
16	0581012991	SPRING PROTECTION PLASTIC HOSE		01
17	0501053834	MALE QUICK COUPLER	14	02
18	0581010090	SPRING PROTECTION PLASTIC HOSE		02
19	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		01




Item	Code	Description	See page	QT
01	0521057854	SUPPORT VALVE BLOCK VACUOMETER ASSY 7655/8450	141	01
02	0521057886	HOSE CLAMP ASSEMBLY	143	02
03	0581010324	HOSE PROTECTOR		01
04	0503010358	5/16" X 5/8" BOLT		04
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
06	0503010337	5/16" NUT		04
07	0503013493	T CONNECTION MALE		02
08	0521057259	OIL CONDUCTOR FIXATION	139	08
09	0531060539	OIL CONDUCTOR 1465 WHEEL CYLINDER 8450		04
10	0531060516	OIL DUCT 1200 7655		02
11	0531060515	OIL DUCT 3 OUTPUT 655 MM 7655		02
12	0531060545	OIL DUCT 275 6350		02
13	0521057704	SLIDING SUPPORT HYDRAULIC HOSE	140	04
14	0581010091	SPRING PROTECTION PLASTIC HOSE		01
15	0581012991	SPRING PROTECTION PLASTIC HOSE		01
16	0581010090	SPRING PROTECTION PLASTIC HOSE		02
17	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		01
18	0501053834	MALE QUICK COUPLER	14	02
19	0521057304	HOSE KIT HYDRAULIC SYSTEM		01
19A	0501082269	HOSE 1/2 X 300 TR-TR		04
19B	0501080087	1/2" X 450 HOSE		03
19C	0501080096	1/2 X 500 TC-TC HOSE		12
19D	0501081834	1/2 X 1500 TR-TC HOSE		02
19E	0501080058	HOSE 1/2 X 1400 TR-TC		01
19F	0501080093	1/2 X 1300 HOSE TR-TC		01
19G	0501080218	1/2 X 750 HOSE		02
19H	0501081235	1/2 X 650 TR- TC HOSE		02
19I	0501080024	1/2" X 700 TR-TR HOSE		04
20	0521057244	HOSE 1/2 X 4900 TC-TM BLACK / BLUE		01
20A	0501082260	HOSE 1/2 X 4900 TC-TM		01
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01


Item	Code	Description	See page	QT
20C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
20D	0503018952	PLASTIC BOLT		06
21	0521057243	1/2 X 4350 TC-TM HOSE BLACK / RED		01
21A	0501082259	HOSE 1/2 X 4350 TC-TM		01
21B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
21C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
21D	0503018952	PLASTIC BOLT		06

OIL CONDUCTOR FIXATION


0521057259



Item	Code	Description	See page	QT
01	0591012302	LOWER CLAMP FIXING OIL CONDUCTOR		01
02	0591012301	TOP CLAMP FIXING OIL CONDUCTOR		01
03	0503010025	3/8 SPRING WASHER		03
04	0503010026	3/8" NUT		03
05	0561017277	OIL CONDUCTOR FIXER PLATE		01
06	0521010718	5/8" U BOLT		01
07	0501012140	FLAT WASHER		02
08	0503010027	5/8 SPRING WASHER		02
09	0503010013	5/8 NUT		02
10	0501011755	3/8" X 3" BOLT		02
11	0502010477	HOSE CLAMP		02
12	0501010096	3/8" X 2" BOLT		01




Item	Code	Description	See page	QT
01	0591012962	SLIDING SUPPORT BODY HYDRAULIC HOSE		01
02	0591012961	16,30 X 30 X 230 SLEEVE		01
03	0591012963	HOSE SLEEVE FIXING AXLE		01
04	0503010013	5/8 NUT		02
05	0501012140	FLAT WASHER		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010071	3/16" X 1" COTTERPIN		02




Item	Code	Description	See page	QT
01	0503062960	COMMAND BLOCK		01
02	0591013473	VACUOMETER GUIDE SCREW BOLT		02
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	0503010026	3/8" NUT		02
05	0503010025	3/8 SPRING WASHER		02
06	0502011170	FIXER		02
07	0503010384	1/2" X 5" BOLT		04
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
09	0503010589	1/2" UNC SELF ADJUSTING NUT		04
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
11	0503015114	BOLT		04
12	0531060808	SUPPORT FIXING VALVE TRIPLE BLOCK		01
13	0521057291	TRIPLE VALVE	142	01
14	0591014208	HYDRAULIC BLOCK SUPPORT SLEEVE		02

TRIPLE VALVE


0521057291




Item	Code	Description	See page	QT
01	0503019571	DIVIDER VALVE TRI-DIREC PLD20 CASAPPA BRP00095		01
02	0501010590	NIPPLE		03
03	0503010026	3/8" NUT		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0511018014	7/8"NF X 1.1/16 UN NIPPLE		01
08	0503010045	O'RING		03
09	0503011109	2-119 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0502010477	HOSE CLAMP		02
02	0502012702	BODY SUPPORT CLAMP		01
03	0503010718	3/8" X 3-1/2" BOLT		01
04	0503010026	3/8" NUT		01
05	0503010025	3/8 SPRING WASHER		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521056827	CSC 5750 TO 7350 TURBINE HOSE KIT		01
01A	0501080436	3/8 X 1600 TR-TC HOSE		02
01B	0501080134	1/2 X 1600 TC-TC HOSE		02
01C	0501080137	1/2 X 3000 TC-TC HOSE		02
02	0521052522	HOSE 1/2 X 7500 TC-TM YELLOW / RED		01
02A	0501082026	HOSE 1/2 X 7500 TC-TM		01
02B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
02C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
02D	0503018952	PLASTIC BOLT		06
03	0521052523	HOSE 1/2 X 7500 TC-TM YELLOW / BLUE		01
03A	0501082026	HOSE 1/2 X 7500 TC-TM		01
03B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
03C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
03D	0503018952	PLASTIC BOLT		06
04	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
04A	0501080477	HOSE 3/8 X 7012 TC-TM		01
04B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
04C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
04D	0503018952	PLASTIC BOLT		06
05	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN		01
06	0501053834	MALE QUICK COUPLER	14	02
07	0503014278	MP100 PLASTIC PROTECTION SPRING FOR 3/4 HOSE		12
08	0503033981	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0521057484	TURBINE HOSE KIT CSC 7655 A 8450		01
01A	0501082256	HOSE 3/8 X 200 TC-TC 90G RIGHT		01
01B	0501082257	HOSE 3/8 X 200 TC-TC 90G LEFT		01
01C	0501080113	1/2 X600 HOSE TR-TC		02
01D	0501082255	HOSE 1/2 X 200 TR-TC		02
01E	0501080436	3/8 X 1600 TR-TC HOSE		02
02	0521052523	HOSE 1/2 X 7500 TC-TM YELLOW / BLUE		01
02A	0501082026	HOSE 1/2 X 7500 TC-TM		01
02B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
02C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
02D	0503018952	PLASTIC BOLT		06
03	0521057172	3/8 X 5500 TR-TM HOSE YELLOW / GREEN		01
03A	0501080205	HOSE 3/8 X 5500 TR-TM		01
03B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
03C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
03D	0503018952	PLASTIC BOLT		06
04	0521057109	1/2 X 7000 TR-TM HOSE YELLOW / BLUE		01
04A	0501082007	HOSE 1/2 X 7000 TR-TM		01
04B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
04C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
04D	0503018952	PLASTIC BOLT		06
05	0521052534	HOSE 1/2 X 7012 TC-TM YELLOW / RED		02
05A	0501081247	HOSE 1/2 X 7012 TC-TM		01
05B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
05C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
05D	0503018952	PLASTIC BOLT		06
06	0501053834	MALE QUICK COUPLER	14	04
07	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN		01
08	0503014278	MP100 PLASTIC PROTECTION SPRING FOR 3/4 HOSE		12
09	0503033981	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
001	0503063101	KIT ISO	147	01
002	0511056972	FILTER HYDAC	148	01
003	0521055707	MOTOR HYDRAULIC PARKER		04
004	0503018769	MOTOR SPEED SENSOR		04
005	0503019291	SUPPORT SENSOR		01
006	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		**




Item	Code	Description	See page	QT
001	0503015065	MASTER CONTROL MODULE	01	
002	0503015066	CABLE CONTROL MASTER MODULE	01	
003	0503016029	CONNECTOR CABLE TRACTOR 6M KTATU6,0	01	
004	0503015071	CONCTOR	01	
005	0503019077	SIMPLE CABLE	01	
006	0503017443	ANTENNA GPS PM 400	01	
007	0503017031	CLEANING BRUSH	01	
008	0503015218	SENSOR FOTOELE PM 400	15	




Item	Code	Description	See page	QT
01	0503016376	FILTER SPRING		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8"NF UNF NIPPLE		02
04	0503012341	T 7/8" ADAPOR GIRAT NUT		01
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0503063387	15 ROWS ISO6 INTELLIAG KIT		01
01A	0503019526	CONTROL MODULE ISO6 6CH ADV		01
01B	0503019384	CABLE CTRL MASTER MODULE		01
01C	0503015071	CONCTOR		01
01D	0503019386	MODULES "C"		01
01E	0503019385	WHIP ELETTRIC		01
01F	0503019616	EXTENSION CABLE		06
01G	0503019617	EXTENSION CABLE		06
01H	0513010023	EXTERNAL LIFTING CABLE		01
01I	0503017443	ANTENNA GPS PM 400		01
01J	0503017031	CLEANING BRUSH		01
01K	0503015218	SENSOR FOTOELE PM 400		15
01L	0503019685	CABLE ISO CONNECTION TRACTOR 8,0 MT 020011353		01
01M	0503016561	15 ROW SIMPLE MONITOR CABLE		01
02	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	150	06
03	0511056972	FILTER HYDAC	148	01
04	0503019291	SUPPORT SENSOR		01
05	0521054490	FLOW DIVIDING VALVE ASSY	151	01
06	0503013100	NYLON CLAMP		75
07	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		**




Item	Code	Description	See page	QT
01	0503018768	MOTOR OMP 80		01
02	0503018769	MOTOR SPEED SENSOR		01
03	0503010045	O'RING		02
04	0503019320	VALVE		01
05	0501010590	NIPPLE		02



Item	Code	Description	See page	QT
01	0503016227	FLOW DIVIDING VALVE		01
02	0503013917	O'RING 2-224		03
03	0571013917	7/8\"NF X 1.1/16 UNF NIPPLE		03




Item	Code	Description	See page	QT
001	0503019527	CONTROL MODULE		01
002	0503019778	MODULES WITH		09
003	0503019384	CABLE CTRL MASTER MODULE		01
004	0503019779	CABLE		01
005	0503015071	CONCTOR		02
006	0503015218	SENSOR FOTOELE PM 400		17
007	0503017443	ANTENNA GPS PM 400		02
008	0503017006	ISO CONEX TRACTOR		01
009	0503017031	CLEANING BRUSH		01
010	0503019720	NYLON CLAMP		02
011	0503019713	EXTENSION CABLE		02
012	0503019780	EXTENSION CABLE		02
013	0503019591	MOTOR		17
014	0503019781	WHIP ELETTRIC		01
015	0503018932	FLOW FERTILIZER SENSOR		17
016	0503019782	SUPPORT FIXER MOTOR		17
017	0503019783	COUPLING		17
018	0503019784	M8 X 0.5" BOLT		17
019	0503019785	FLAT WASHER		51
020	0503019786	SPRING WASHER		51
021	0503019592	COVER PROTECTION FOR SHAFT		17
022	0503019787	BOLT HEX		51
023	0503019788	ZINC PARTS		34
024	0503019789	ZINC PARTS		34
025	0503019790	SPRING WASHER		34
026	0503019791	ZINC NUT		34




Item	Code	Description	See page	QT
001	0521057274	SUPPORT HIDRAULIC MOTOR	154	02
002	0591012322	FIXER PLATE		02
003	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
004	0503010025	3/8 SPRING WASHER		04
005	0503010026	3/8" NUT		04
006	0521069832	15Z GEAR		02
007	0503010282	1/4" X 3/4" BOLT		02
008	0503010143	1/4" SPRING WASHER		02
009	0561011665	FLAT WASHER		02
010	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		04
011	0503010019	1/2" SPRING WASHER		06
012	0503010060	1/2 UNC G.5 ZN HEX NUT		06
013	0531019479	AXLE CHAIN GEAR		02
014	0503030402	PULLEY		02
015	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
016	0503062754	GEAR 34Z P.1/2 APT		02
017	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
018	0521057272	PROTECTION COVER	155	01
019	0521057273	PROTECTION COVER	156	01
020	0531060542	HIDRAULIC MOTOR SUPPORT		02
021	0502012789	FIXER SUPPORT FERTILIZER ROW		02
022	0503017960	5/8" X 3-12" BOLT		08
023	0503010811	5/8" UNF SELF ADJUSTING NUT		08
024	0591012331	SUPPORT SIDE		02
025	0503010237	3/8" X 1" BOLT		08
026	0503010025	3/8 SPRING WASHER		08
027	0503010026	3/8" NUT		08
028	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		04
029	0503010019	1/2" SPRING WASHER		06
030	0503010060	1/2 UNC G.5 ZN HEX NUT		06
031	0531060544	15Z GEAR P		02


Item	Code	Description	See page	QT
032	0503010282	1/4" X 3/4" BOLT		02
033	0503010143	1/4" SPRING WASHER		02
034	0561011665	FLAT WASHER		02
035	0531060543	25Z GEAR WITH		02
036	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
037	0503030402	PULLEY		02
038	0531019479	AXLE CHAIN GEAR		02
039	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
040	0503012706	40-1 CHAIN X 47 LINK + MENDING		02
041	0521057275	COVER MOTOR	157	01
042	0521057276	COVER MOTOR	158	01
043	0581019507	SUPPORT FILTER		01
044	0581019503	3/8" FASTENER		02
045	0503015135	FLAT WASHER 10 X 18 X 2		04
046	0503010025	3/8 SPRING WASHER		04
047	0503010026	3/8" NUT		04
048	0581018875	SENSOR DRIVER		01
049	0521069589	POSITION SENSOR SUPPORT		01
050	0503011135	BOLT		02
051	0503010244	7/16" NUT		02
052	0503010180	7/16" SPRING WASHER		02
053	0503013356	RIVET POP 3,2 X 10,0		01
054	0511059348	APT ASSY MODULE BOX	159	01
055	0521069584	BOX SUPPORT		02
056	0581019503	3/8" FASTENER		02
057	0503015135	FLAT WASHER 10 X 18 X 2		04
058	0503010025	3/8 SPRING WASHER		04
059	0503010026	3/8" NUT		04
060	0521069588	HOSE HOLDER		01
061	0581019503	3/8" FASTENER		01
062	0503015135	FLAT WASHER 10 X 18 X 2		02
063	0503010025	3/8 SPRING WASHER		02
064	0503010026	3/8" NUT		02
065	0531011180	UPPER BODY CLIP		01
066	0503011102	BOLT 7/16 UNC X 1.1/4 C S G.5 ZN		01
067	0503010180	7/16" SPRING WASHER		01
068	0521052519	HOSE 1/2 X 4200 TC-TM GRAY / RED		01
068A	0501081073	HOSE 1/2 X 4200 TC-TM		01
068B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
068C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
068D	0503018952	PLASTIC BOLT		06
069	0521055645	HOSE 1/2 X 7500 TR-TM GRAY / BLUE		01
069A	0501081911	HOSE 1/2 X 7500 TR-TM		01
069B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
069C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
069D	0503018952	PLASTIC BOLT		06
070	0501080496	1/2" X 145.6" HOSE ASSY		01
071	0501082270	1/2" HOSE		01
072	0501080275	1/2 X 1500 TR-TC 1G140689 HOSE ASSY		01
073	0501080865	1/2" X 212" TR-TR HOSE ASSY		01
074	0501053834	MALE QUICK COUPLER	14	02



Item	Code	Description	See page	QT
001	0502012724	FERTILIZER ROW FIXER		01
002	0531060541	HIDRAULIC MOTOR SUPPORT		01
003	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		04
004	0503012412	5/8 UNC SELF LOCKING NUT		04




Item	Code	Description	See page	QT
001	0591012316	PROTECTION COVER		01
002	0503019412	RIVET SCREW INTERNAL		04
003	0591012314	GEAR PROTECTION		01
004	0503013849	1/4" UNC X 3/4" BOLT		04
005	0503010143	1/4" SPRING WASHER		04
006	0503010305	FLAT WASHER		04



Item	Code	Description	See page	QT
001	0591012318	PROTECTION COVER		01
002	0503019412	RIVET SCREW INTERNAL		04
003	0591012314	GEAR PROTECTION		01
004	0503013849	1/4" UNC X 3/4" BOLT		04
005	0503010143	1/4" SPRING WASHER		04
006	0503010305	FLAT WASHER		04

COVER MOTOR


0521057275




Item	Code	Description	See page	QT
001	0591012329	PROTECTION COVER		01
002	0503019412	RIVET SCREW INTERNAL		03
003	0503013849	1/4" UNC X 3/4" BOLT		02
004	0503010143	1/4" SPRING WASHER		03
005	0503010305	FLAT WASHER		03
006	0591012327	PROTECTION COVER		01
007	0503013813	1/4" UNC X 7/8" BOLT		01
008	0591012328	PROTECTION COVER		01

COVER MOTOR


0521057276



Item	Code	Description	See page	QT
01	0591012330	PROTECTION COVER		01
02	0591012328	PROTECTION COVER		01
03	0591012327	PROTECTION COVER		01
04	0503019412	RIVET SCREW INTERNAL		03
05	0503013813	1/4" UNC X 7/8" BOLT		01
06	0503010143	1/4" SPRING WASHER		03
07	0503010305	FLAT WASHER		03
08	0503013849	1/4" UNC X 3/4" BOLT		02




Item	Code	Description	See page	QT
01	0521066834	MODULE BOX		01
02	0503018171	FAST LOCK ASSY		02
03	0521066833	BOX COVER		01
04	0571012006	COVER PIVOT SHAFT		01
05	0571012005	SUPPORT GUIDE ASSY		01
06	0501010694	FLAT WASHER		03
07	0503010257	1/8" X 1" COTTERPIN		02
08	0511017303	FLAT WASHER		10
09	0503010298	1/4" X 1/2" BOLT		04
10	0503010143	1/4" SPRING WASHER		10
11	0503010294	1/4" X 7/8" BOLT		06
12	0503010144	1/4" NUT		06
13	0501011643	3/8 X 1" BOLT		04
14	0503010025	3/8 SPRING WASHER		04
15	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
16	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0531054821	RIGHT FERTILIZER MOTOR SUPPORT	161	03
02	0531054822	SUPPORT WITH LEFT MOTOR	162	03
03	0521069589	POSITION SENSOR SUPPORT		01
04	0531050693	MODULE BOX	163	01
05	0581019507	SUPPORT FILTER		01
06	0501213673	VALVE SUPPORT		01
07	0581018875	SENSOR DRIVER		01
08	0531054827	HOSE SET		01
08A	0501081381	TC-TC HOSE		01
08B	0501080024	1/2" X 700 TR-TR HOSE		04
08C	0521052519	HOSE 1/2 X 4200 TC-TM GRAY / RED		01
08CA	0501081073	HOSE 1/2 X 4200 TC-TM		01
08CB	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
08CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
08CD	0503018952	PLASTIC BOLT		06
08D	0501080982	1/2 X 700 TC-TCHOSE ASSY		01
08E	0501080218	1/2 X 750 HOSE		01
08F	0501080010	1/2 X 1000 TR-TC HOSE		01
08G	0501080825	1/2" X 1100 TR-TC HOSE		01
08H	0501080022	1/2" X 43" TR-TR HOSE ASSY		01
08I	0501080103	1/2" X 47" TR-TR HOSE		01
08J	0501080058	HOSE 1/2 X 1400 TR-TC		01
08K	0521056808	HOSE 1/2 X 5000 TC-TM GRAY / BLUE		01
08KA	0501080711	HOSE 1/2 X 5000 TC-TM		01
08KB	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
08KC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
08KD	0503018952	PLASTIC BOLT		06
08L	0501082086	1/2 X 650 TC-TC 180G HOSE		01
08M	0501080092	1/2 X 700 TR-TC HOSE		01
08N	0501080109	1/2" X 800 TR-TR HOSE		01
08O	0501081834	1/2 X 1500 TR-TC HOSE		01


Item	Code	Description	See page	QT
08P	0501081886	HOSE 1/2 X 1600 TR-TC		01
09	0501053834	MALE QUICK COUPLER	14	02
10	0531060540	OIL TUBE		08
11	0531063860	OIL DISTRIBUTOR		01
12	0503013055	"T" ADAPTOR WITH GIRAT NUT		01
13	0503010180	7/16" SPRING WASHER		02
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
15	0503010025	3/8 SPRING WASHER		04
16	0503015135	FLAT WASHER 10 X 18 X 2		04
17	0503011135	BOLT		02
18	0503011053	5/16" X 3" C S 6.5 ZN BOLT		02
19	0503010026	3/8" NUT		04
20	0503010337	5/16" NUT		02
21	0503010244	7/16" NUT		02
22	0581019503	3/8" FASTENER		02
23	0503013356	RIVET POP 3,2 X 10,0		01
24	0531050763	FIXING OIL CONDUCTORS SET FOR 5 TUBES	164	06
25	0531050694	HOSE SUPPORT		01
25A	0581019503	3/8" FASTENER		01
25B	0503015135	FLAT WASHER 10 X 18 X 2		02
25C	0503010025	3/8 SPRING WASHER		02
25D	0503010026	3/8" NUT		02
25E	0521069588	HOSE HOLDER		01
25F	0531011180	UPPER BODY CLIP		01
25G	0503011102	BOLT 7/16 UNC X 1.1/4 C S G.5 ZN		01
25H	0503010180	7/16" SPRING WASHER		01
25I	0581018419	SUPPORT		01




Item	Code	Description	See page	QT
01	0521057274	SUPPORT HIDRAULIC MOTOR	154	01
02	0591012322	FIXER PLATE		01
03	0503062754	GEAR 34Z P.1/2 APT		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		03
06	0503010060	1/2 UNC G.5 ZN HEX NUT		03
07	0503030402	PULLEY		01
08	0531019479	AXLE CHAIN GEAR		01
09	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
10	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		01
11	0503010025	3/8 SPRING WASHER		02
12	0503010026	3/8" NUT		02
13	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
14	0521057272	PROTECTION COVER	155	01
15	0501111116	MOTOR GEAR		01
16	0501212320	ENCODER LOCK SCREW		01
17	0503019880	AGRICULTURAL ENCODER		01




Item	Code	Description	See page	QT
01	0531060542	HIDRAULIC MOTOR SUPPORT		01
02	0591012331	SUPPORT SIDE		01
03	0503010237	3/8" X 1" BOLT		04
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503010019	1/2" SPRING WASHER		03
07	0503010060	1/2 UNC G.5 ZN HEX NUT		03
08	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
10	0503030402	PULLEY		01
11	0531060543	25Z GEAR WITH		01
12	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
13	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		02
14	0531019479	AXLE CHAIN GEAR		01
15	0521057276	COVER MOTOR	158	01
16	0501111116	MOTOR GEAR		01
17	0503017960	5/8" X 3-12" BOLT		04
18	0502012789	FIXER SUPPORT FERTILIZER ROW		01
19	0503010811	5/8" UNF SELF ADJUSTING NUT		04
20	0503015162	M 8 X 1,25 X 20 BOLT		01
21	0501212320	ENCODER LOCK SCREW		01
22	0503019880	AGRICULTURAL ENCODER		01
23	0503016055	PARKER OMP 80 ISOBUS HYDRAULIC MOTOR		01




Item	Code	Description	See page	QT
01	0511059348	APT ASSY MODULE BOX	159	01
02	0521069584	BOX SUPPORT		02
03	0581019503	3/8" FASTENER		02
04	0503015135	FLAT WASHER 10 X 18 X 2		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0581018415	PROTECTION BODY		02
02	0503010025	3/8 SPRING WASHER		03
03	0503010026	3/8" NUT		03
04	0561017277	OIL CONDUCTOR FIXER PLATE		01
05	0521010718	5/8" U BOLT		01
06	0501012140	FLAT WASHER		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010013	5/8 NUT		02
09	0501011755	3/8" X 3" BOLT		02
10	0502010477	HOSE CLAMP		02
11	0501010096	3/8" X 2" BOLT		01




Item	Code	Description	See page	QT
001	0503019716	MONITOR CABLE		01
002	0503019717	CHICOTE FEEDING		01
003	0503019718	WHIP		01




Item	Code	Description	See page	QT
001	0591012960	SUPPORT TRANSP		01
002	0503010060	1/2 UNC G.5 ZN HEX NUT		04
003	0503010019	1/2" SPRING WASHER		04
004	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
005	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
006	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		17
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		03
04	0503012903	T-80M CRAMP NYLON		50
05	0521053672	LIGHTHOUSE ASSY	168	02
06	0521052792	MOUNTED REAR LIGHT	169	01
07	0503015907	MALE TERMINAL		02
08	0503015908	FEMALE TERMINAL		02
09	0503015906	TWO-WAY MALE CONNECTOR		01
10	0503015905	TWO-WAY FEMALE MALE CONNECTOR		01
11	0503015911	CABLE SEAL		04
12	3505151602	TUBE		01
13	0503017702	FIXER		03




Item	Code	Description	See page	QT
01	0581015856	REDLIGHT SUPPORT		01
02	0503018738	HEADLIGHT		01
03	0501010694	FLAT WASHER		02
04	0503010358	5/16" X 5/8" BOLT		02
05	0551019884	45 X 50 X 3/8 FASTENER		02
06	0503013357	3/8 SELF-ADJUSTING NUT		04
07	0503010337	5/16" NUT		02
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		02




Item	Code	Description	See page	QT
01	0503018738	HEADLIGHT		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
08	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
001	0521050692	HOSE KIT CYLINDER HEAD FRONT		01
001A	0521052309	HOSE 1/2 X 4500 TM-TM GREEN / BLUE		01
001AA	0501081929	HOSE 1/2 X 4500 TM-TM		01
001AB	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
001AC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
001AD	0503018952	PLASTIC BOLT		06
001B	0521052310	HOSE 1/2 X 4500 TM-TM GREEN / RED		01
001BA	0501081929	HOSE 1/2 X 4500 TM-TM		01
001BB	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
001BC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
001BD	0503018952	PLASTIC BOLT		06
002	0501053834	MALE QUICK COUPLER	14	04



Item	Code	Description	See page	QT
01	0503014820	BLACK WATER RESERVOIR		01
02	0521068651	SUPPORT BOX		01
03	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		02
04	0503010025	3/8 SPRING WASHER		02
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02



Item	Code	Description	See page	QT
01	0521068652	TOOLS BOX SUPPORT		01
02	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		02
03	0503010025	3/8 SPRING WASHER		06
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
05	0501011643	3/8 X 1"BOLT		04
06	0503010026	3/8" NUT		04
07	0503034772	BOX		01
08	0581017000	PLATE INTERMEDIARY		02



Item	Code	Description	See page	QT
01	0521056240	FRONT SHORT ROW	174	01
02	0521056241	FRONT LONG ROW	175	01
03	0521056938	RIGHT REAR PRECISION PLANTING TRANSMISSION / CABLE	CSC 177	01
04	0521056939	LEFT REAR PRECISION PLANTING TRANSMISSION/CABLE	CSC 178	01
05	0521056644	REAR RIGHT SPI	185	01
06	0521056642	REAR LEFT SPI	186	01
07	0521054984	DEPTH/COMPACTOR SYSTEM - SPT	200	01
08	0521056069	SEMI-ASSEMBLED SHORT FERTILIZER ROW	208	01
09	0521056066	SEMI-ASSEMBLED LONG FERTILIZER ROW	212	01
10	0521056067	DDD RIGHT FERTILIZER WITH FIXATION		01
11	0521056068	DDD LEFT FERTILIZER WITH FIXATION	214	01
12	0521056844	SCARIFIER ROD	216	01
13	0521056992	SCARIFIER ROD TIP 3 HOLES	218	01
14	0503031145	2" X 2" X 20" HOSE		01
15	0503031076	2" HOSE CLAMP		01
16	1164920015	BLACK SUCTION HOSE		01
17	0503019869	CLAMP		01
18	0503010246	CLAMP		01
19	0501082283	SEED CONDUCTOR 1.1 / 2 X 1600		01
20	0521052549	CLAMP		01
21	0503031050	CURVED CONDUCTOR		01
22	0503010184	CLAMP		01
23	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
24	0531013600	PRESS ADJUSTMENT LEVER		01
25	0521068982	DISC BLADE HUB KEY		01
26	0503010905	1/2" X 2-1/4" BOLT		01
27	0503010019	1/2" SPRING WASHER		01
28	0503010060	1/2 UNC G.5 ZN HEX NUT		01
29	0503063031	1200 TRANSMISSION ROW SET		01


SEED/FERTILIZER ROW ASSY

0909098869


Item	Code	Description	See page	QT
30	0503063033	1350 TRANSMISSION ROW SET		01
31	0503063520	1580 TRANSMISSION ROW SET		01
32	0521051447	FRONT ASSY ROW BEARING	220	01
33	0521053987	SCARIFIER SPINDLE WITH SOCKET RIGHT	221	01
34	0521053956	SCARIFIER SPINDLE WITH SOCKET LEFT	222	01
35	0531053036	SHORT SEED ROW HOSE GUIDE STEEL CABLE	227	01
36	0531053037	LONG SEED ROW HOSE GUIDE STEEL CABLE	228	01
37	0531053038	SEED ROW ENCAPSULATED CHAIN GUIDE		01
38	0531050181	ASSY JOINT TCE		01
39	0531050182	ASSY JOINT TCE		01
40	0531051830	ASSY JOINT TCE 1441		01
41	0531060405	EXTENSION		01

FRONT SHORT ROW


0521056240




Item	Code	Description	See page	QT
01	0503019273	AUTO LUBRICANT SLEEVE	08	
02	0591011316	SEED ROW SUPPORT SLEEVE	08	
03	0531060069	TOP ARM	01	
04	0531062744	FRONT LOWER ARM SHORT SEED ROW	01	
05	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
06	0531060077	PRESSURE REGULATOR	01	
07	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	02	
08	0591010915	SPRING REGULATOR	01	
09	0591010914	LOWER AXLE	01	
10	0591011315	SPRING AXLE	01	
11	0503010045	O'RING	08	
12	0503010131	3/16" X 1-1/2" COTTERPIN	01	
13	0503030168	HITCH PIN CLIP	01	
14	0531060068	REAR ROW	01	
15	0503019295	SCREW 5/8 UNF X 7 CS RP G.5 ZN	04	
16	0502010175	HITCH CLAMP	02	
17	0503017857	BOLT 5/8 UNF 4	04	
18	0501012140	FLAT WASHER	04	
19	0531060073	FRONT ROW SUPPORT	01	
20	0521010542	COUPLING SHAFT	01	
21	0503010300	5/32" X 1" COTTERPIN	01	
22	0591010913	TRANSPORT BUMPER	01	
23	0501010301	FLAT WASHER	04	
24	0503010878	5/8" SELF ALIGNING NUT	04	
25	0503030012	HITCH PIN CLIP	01	
26	0571016296	FLAT WASHER	04	
27	0531052956	ASSEMBLY SEED ROW TRANSMISSION FIXING BEARING	176	01




Item	Code	Description	See page	QT
01	0503019273	AUTO LUBRICANT SLEEVE		08
02	0591011316	SEED ROW SUPPORT SLEEVE		08
03	0531060069	TOP ARM		01
04	0531060070	LOWER ARM		01
05	0503010811	5/8" UNF SELF ADJUSTING NUT		08
06	0531060077	PRESSURE REGULATOR		01
07	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		02
08	0591010915	SPRING REGULATOR		01
09	0591010914	LOWER AXLE		01
10	0591011315	SPRING AXLE		01
11	0503010045	O'RING		08
12	0503010131	3/16" X 1-1/2" COTTERPIN		01
13	0503030168	HITCH PIN CLIP		01
14	0531060068	REAR ROW		01
15	0503019295	SCREW 5/8 UNF X 7 CS RP G.5 ZN		04
16	0531060073	FRONT ROW SUPPORT		01
17	0521010542	COUPLING SHAFT		01
18	0503010300	5/32" X 1" COTTERPIN		01
19	0591010913	TRANSPORT BUMPER		01
20	0501010301	FLAT WASHER		04
21	0531060072	EXTENDER		01
22	0502010175	HITCH CLAMP		02
23	0503017857	BOLT 5/8 UNF 4		04
24	0501012140	FLAT WASHER		08
25	0503012798	5/8" X 2" BOLT		04
26	0503010878	5/8" SELF ALIGNING NUT		04
27	0503030012	HITCH PIN CLIP		01
28	0571016296	FLAT WASHER		04
29	0531052956	ASSEMBLY SEED ROW TRANSMISSION FIXING 176 BEARING		01



Item	Code	Description	See page	QT
01	0531060071	BEARING		01
02	0551015804	BEARING AXLE BODY		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02
07	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
08	0503012880	1/4" UNC SELF ADJUSTING NUT		02
09	0503019373	6006 2RS1 NATIONAL BEARING		01
10	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0521056955	RIGHT DDD ASSY	180	01
02	0503062403	TUBE SEED P.P		01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" COTTERPIN		01
05	0521056640	PRECISION PLANTING CSC CABLE / 183		01
06	0503012136	NUT 1/2 NF		04
07	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04




Item	Code	Description	See page	QT
01	0521056954	LEFT DDD ASSY	179	01
02	0503062403	TUBE SEED P.P		01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" COTTERPIN		01
05	0521056640	PRECISION PLANTING CSC CABLE / 183		01
06	0503012136	NUT 1/2 NF		04
07	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04

LEFT DDD ASSY


0521056954




Item	Code	Description	See page	QT
01	0591011772	LEFT DDD BODY		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 181 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 182 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0591011773	RIGHT DDD BODY		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 181 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 182 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED		01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED		01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0502012924	PRECISION PLANTING SUPPORT		01
02	0502012800	SUPPORT ARTICULATION PNEUMATIC		01
03	0503062406	SEED HOPPER		01
04	0521052131	DISTRIBUTOR VSET2 WITH CORN DISK WITHOUT 184 PROTECTION		01
05	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01
07	0503810009	BOLT		02
08	0571018649	SUPPORT FIXER		02
09	0503010243	CLAMP		01
10	0581017816	TERMINAL		01
11	0503034204	SEALING		01
12	0503010140	1/8" X 3/4" COTTERPIN		01
13	0571014024	FAST BOLT GUIDE AXLE		01
14	0503034824	FIXATIVE		01
15	0503010293	CLAMP KNOB		01
16	0503010025	3/8 SPRING WASHER		05
17	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
18	0501110894	FIXER		01
19	0502012922	FIXING SUPPORT		01
20	0503011404	BOLT		01
21	0503013357	3/8 SELF-ADJUSTING NUT		01
22	0503010026	3/8" NUT		04
23	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04



Item	Code	Description	See page	QT
01	0503062417	KIT CORN DISTRIBUTION		01
01A	0503018160	CORN PLASTIC DISC		01
01B	0503062472	SELECTOR SEED CORN		01
01C	0503062474	EJECTOR CORN SEED SET		01
02	0503062405	SEED DISTRIBUTOR		01
02A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
02B	0503062974	MOBILE BASE WITHOUT SNORKEL		01
02C	0503062973	SNORKEL ASSY PP768718		01




Item	Code	Description	See page	QT
01	0521056645	RIGHT SPI TRANSMISSION	188	01
02	0503062403	TUBE SEED P.P		01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" COTTERPIN		01
05	0591011327	PROTECTION CAP		01
06	0521056640	PRECISION PLANTING TRANSMISSION ASSY	CSC CABLE / 183	01



Item	Code	Description	See page	QT
01	0521056646	LEFT REAR FRAME	187	01
02	0503062403	TUBE SEED P.P		01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" COTTERPIN		01
05	0591011327	PROTECTION CAP		01
06	0521056640	PRECISION PLANTING TRANSMISSION ASSY	CSC CABLE / 183	01

LEFT REAR FRAME

0521056646




Item	Code	Description	See page	QT
01	0502012923	BEATER		01
02	0521056632	DEPTH CONTROL	189	01
03	0591011323	AXLE ARTICULATION WHEEL DEPTH		02
04	0502012920	SUPPORT ADJUSTING		01
05	0502012611	DEPTH CONTROL AXLE		01
06	0591011309	ADJUSTMENT BUSHING		02
07	0591011310	ADJUSTMENT BAR		02
08	0503019275	SLEEVE LUBRICATION SYSTEM		01
09	0581019473	ARTICULATED SLEEVE		02
10	0503010045	O'RING		02
11	0503013357	3/8 SELF-ADJUSTING NUT		02
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
13	0591011326	LOCK PIN		01
14	0571015326	ARTICULATION SLEEVE HANDLE		01
15	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
16	0503010060	1/2 UNC G.5 ZN HEX NUT		02
17	0503010019	1/2" SPRING WASHER		04
18	0591011324	SMALLER AXLE		01
19	0591011325	LARGER AXLE		01
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
21	0503030012	HITCH PIN CLIP		02
22	0501011445	FLAT WASHER		04
23	0521056633	MOUNTED RIGHT ARM	190	01
24	0521056631	MOUNTED LEFT ARM	191	01
25	0503010025	3/8 SPRING WASHER		02
26	0503012556	1/2" X 1" BOLT		02
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
28	0591011306	ADJUSTMENT LOCK		02
29	0503012136	NUT 1/2 NF		04
30	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
31	0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	192	01

**LEFT REAR FRAME**


0521056646

Item	Code	Description	See page	QT
32	0521055093	BODY COMPACTOR	194	01
33	0521054990	LEFT COMPACTOR WHEEL	195	01
34	0521055017	RIGHT COMPACTOR WHEEL	196	01




Item	Code	Description	See page	QT
01	0502012923	BEATER		01
02	0521056632	DEPTH CONTROL	189	01
03	0591011323	AXLE ARTICULATION WHEEL DEPTH		02
04	0502012920	SUPPORT ADJUSTING		01
05	0502012611	DEPTH CONTROL AXLE		01
06	0591011309	ADJUSTMENT BUSHING		02
07	0591011310	ADJUSTMENT BAR		02
08	0503019275	SLEEVE LUBRICATION SYSTEM		01
09	0581019473	ARTICULATED SLEEVE		02
10	0503010045	O'RING		02
11	0503013357	3/8 SELF-ADJUSTING NUT		02
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
13	0591011326	LOCK PIN		01
14	0571015326	ARTICULATION SLEEVE HANDLE		01
15	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
16	0503010060	1/2 UNC G.5 ZN HEX NUT		02
17	0503010019	1/2" SPRING WASHER		04
18	0591011324	SMALLER AXLE		01
19	0591011325	LARGER AXLE		01
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
21	0503030012	HITCH PIN CLIP		02
22	0501011445	FLAT WASHER		04
23	0521056633	MOUNTED RIGHT ARM	190	01
24	0521056631	MOUNTED LEFT ARM	191	01
25	0503010025	3/8 SPRING WASHER		02
26	0503012556	1/2" X 1" BOLT		02
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
28	0591011306	ADJUSTMENT LOCK		02
29	0503012136	NUT 1/2 NF		04
30	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
31	0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	193	01

Item	Code	Description	See page	QT
32	0521055093	BODY COMPACTOR	194	01
33	0521054990	LEFT COMPACTOR WHEEL	195	01
34	0521055017	RIGHT COMPACTOR WHEEL	196	01




Item	Code	Description	See page	QT
01	0502012925	ADJUSTMENT BODY		01
02	0511015976	FLAT WASHER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0503010581	RING		01
05	0502012892	DEPTH CONTROL HANDLE		01
06	0581019526	ARTICULATED AXLE LEVER DEPTH		01
07	0503010302	501019 SEAL RING		01




Item	Code	Description	See page	QT
01	0502012926	RIGHT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055059	WHEEL RAYED ASSY SPA WITHOUT 197 LUBRICATION		01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01

MOUNTED LEFT ARM


0521056631




Item	Code	Description	See page	QT
01	0502012927	LEFT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055059	WHEEL RAYED ASSY SPA WITHOUT 197 LUBRICATION		01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0502012928	LEFT EXTENSOR		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 181 FERTILIZER / SEED		01
11	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 182 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0502012929	BODY RIGHT		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 182 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 181 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0501011753	5/16" X 1-3/4" BOLT	02	
02	0503013816	5/16" LOCKNUT	04	
03	0581015855	SLEEVE	02	
04	0502012877	PRESS WHEEL ADJUSTMENT LEVER	01	
05	0521068661	LEVER	01	
06	0503030878	LEVER CRANK	01	
07	0503031393	1.57" X 5.98" X 0.2"TRACTION SPRING	01	
08	0581019520	AXIS	01	
09	0571812442	COUPLING SHAFT	01	
10	0503010257	1/8" X 1" COTTERPIN	01	
11	0581019511	COVER	01	
12	0503010848	5/16" X 3.1/2" BOLT	02	
13	0503010752	1/2" X 3.1/2" BOLT	01	
14	0503011336	1/2" HEX SELF ADJUSTING NUT	01	
15	0503030190	0.5" X 1.6" X 0.05" SPRING	01	
16	0581019510	AXIS	01	
17	0581019512	PLATE TOP	01	
18	0503019351	LUBRICANT SLEEVE	02	
19	0521069591	LEFT SIDE	01	
20	0581019548	RIGHT SIDE BODY	01	




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	199	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	199	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503030891	RUBBER BAND		01
03	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
05	0503010337	5/16" NUT		06
06	0521055073	ASSEMBLY DEPTH WHEEL HUB	198	01




Item	Code	Description	See page	QT
01	0581019528	WHEEL DEPTH SPA HUB WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019168	DUST CLOAK		01
11	0581019529	DEPTH REGULATOR SHAFT		01




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	201	01
02	0501052538	DEPTH BAND WITH ARMS	207	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0521054990	LEFT COMPACTOR WHEEL	195	01
06	0521055017	RIGHT COMPACTOR WHEEL	196	01




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	202	01
02	0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	203	01
03	0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	205	01
04	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	206	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	3/8 UNC X 3/4 BOLT		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED SLEEVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	204	01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL HUB		01
02	0581019515	AXIS		01
03	0503034055	CLAMPING RING		01
04	0581019168	DUST CLOAK		01
05	0503013758	1/4" X 1-1/2" BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0503010878	5/8" SELF ALIGNING NUT		01
10	0503030757	2.9" X 2" X 0.02" JOINT		01
11	0521019178	PROTECTION LID		01




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	204	01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT SLEEVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05



Item	Code	Description	See page	QT
01	0531060002	FERTILIZER ROW REAR SUPPORT		01
02	0503019405	SLEEVE		08
03	0591010640	ARM SPACER SLEEVE WITHOUT LUBRICATION		08
04	0503010045	O'RING		04
05	0531060001	TOP SUPPORT FERTILIZER ROW		01
06	0521069998	LOWER SUPPORT FERTILIZER ROW		01
07	0591010629	SHORT FERTILIZER ROW SUPPORT		01
08	0503010233	5/8" X 2-1/2" BOLT		02
09	0503012412	5/8 UNC SELF LOCKING NUT		05
10	0501010452	5/8" X 5" BOLT		03
11	0502012727	BLADE DISC SUPPORT		01
12	0503011255	3/4" LOCK NUT		02
13	0503011328	3/4" X 4" BOLT		02
14	0501010322	FLAT WASHER		02
15	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
16	0503010013	5/8 NUT		02
17	0521056070	DC 20 ASSY	209	01
18	0521011158	SPRING LOCKNUT		01
19	0521062073	SPRING GUIDE		01
20	0521018575	REGULATOR SPINDLE 100		01
21	0503031450	2.7" X 9.2" X 0.03" SPRING		01
22	0521016057	COUP SHA OF THE CARRY-W SPRING GUI		01
23	0503030168	HITCH PIN CLIP		01
24	0502020393	SPRING UPPER SUPPORT		02




Item	Code	Description	See page	QT
01	0571019034	FLANGE WASHER AXLE		02
02	0571019032	SUPPORT WASHER		01
03	0502012813	FLANGE WASHER SPRING		01
04	0591010619	DC SPRING SUPPORT		01
05	0503019274	WASHER		02
06	0581017628	LID		02
07	0503019277	SLEEVE LUBRICATION SYSTEM		01
08	0501110964	RIGHT ARM WITH SLEEVE		01
09	0501110965	LEFT ARM WITH SLEEVE		01
10	0503034709	COMPRESSION SPRING 100 X 315 X 15.87		01
11	0521069996	ROD SPRING FERTILIZER		01
12	0591010624	SUPPORT ARM SLEEVE		01
13	0591010625	19,50 X 25 X 91,50/91,30 SLEEVE		01
14	0503010417	7/8" NUT		02
15	0503010390	SEAL RING		02
16	0503011198	C3/4" X 6" SCREW		01
17	0501010322	FLAT WASHER		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503010060	1/2 UNC G.5 ZN HEX NUT		01
20	0503010019	1/2" SPRING WASHER		01
21	0503011255	3/4" LOCK NUT		01
22	0503030430	7/16 X 2" PIN LOCK		01
23	0503019271	SELF LUBRICATING BUSHING		01
24	0521069997	DC FIXING AXIS WITH LIMITER		01
25	0591010628	DC AXIS BACKREST WASHER		01
26	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	210	01
27	0503011254	7/8" HEX SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	DISC BLADE HUB	211	01

DISC BLADE HUB


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	DISC BLADE HUB		01
09	0502040873	DISC BLADE AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02




Item	Code	Description	See page	QT
01	0531060002	FERTILIZER ROW REAR SUPPORT		01
02	0503019405	SLEEVE		08
03	0591010640	ARM SPACER SLEEVE WITHOUT LUBRICATION		08
04	0503010045	O'RING		04
05	0531060001	TOP SUPPORT FERTILIZER ROW		01
06	0521069998	LOWER SUPPORT FERTILIZER ROW		01
07	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		04
08	0503010233	5/8" X 2-1/2" BOLT		02
09	0503012412	5/8 UNC SELF LOCKING NUT		09
10	0501010452	5/8" X 5" BOLT		02
11	0502012727	BLADE DISC SUPPORT		01
12	0503011255	3/4" LOCK NUT		02
13	0521069993	LONG FERTILIZER ROW SUPPORT		01
14	0501010125	3/4" X 2-1/2" BOLT		02
15	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
16	0503010013	5/8 NUT		02
17	0521056070	DC 20 ASSY	209	01
18	0521011158	SPRING LOCKNUT		01
19	0521062073	SPRING GUIDE		01
20	0521018575	REGULATOR SPINDLE 100		01
21	0503031450	2.7" X 9.2" X 0.03" SPRING		01
22	0521016057	COUP SHA OF THE CARRY-W SPRING GUI		01
23	0503030168	HITCH PIN CLIP		01
24	0502020393	SPRING UPPER SUPPORT		02
25	0502012724	FERTILIZER ROW FIXER		01
26	0501010163	5/8" X 4-1/2" BOLT		01



Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 182 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 181 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC	215	01
02	0511018662	SPACING PLATE		02
03	0503010060	1/2 UNC G.5 ZN HEX NUT		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010479	BOLT		02




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 182 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 181 FERTILIZER / SEED		01

SCARIFIER ROD


0521056844




Item	Code	Description	See page	QT
01	0521053673	SCARIFIER ROD WITH NOZZLE	217	01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521069127	BOTTOM NOZZLE FERTILIZER		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
08	0503010025	3/8 SPRING WASHER		02
09	0503010026	3/8" NUT		02
10	0503030483	FERTILIZER SOCKET		01



Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER ROD		01
02	0503011402	0.2" X 0.8" SPRING PIN		02
03	0503016853	SPRING PIN		02
04	0502040869	FIXED ROD BEARING		01




Item	Code	Description	See page	QT
01	0501110723	SCARIFIER ROD	219	01
02	0521069127	BOTTOM NOZZLE FERTILIZER		01
03	0503030483	FERTILIZER SOCKET		01
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		02
06	0503010026	3/8" NUT		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02




Item	Code	Description	See page	QT
01	0521063867	SCARIFIER ROD		01
02	0502070082	POINT SUBSOILER		01
03	0503010585	0,24" X 1.18" SPRING PIN		03

FRONT ASSY ROW BEARING


0521051447




Item	Code	Description	See page	QT
01	0581014691	BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503012861	6006 2RS BALL BEARING		01
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0581015056	SLEEVE		01
08	0551015804	BEARING AXLE BODY		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0581010082	FERTILIZER SOCKET RIGHT		01
02	0511059454	ADJUSTMENT BAR	226	01
03	0521053957	ROD WITH ARM/DISARMENT	223	01




Item	Code	Description	See page	QT
01	0521053957	ROD WITH ARM/DISARMENT	223	01
02	0581010083	FERTILIZER SOCKET LEFT		01
03	0511059454	ADJUSTMENT BAR	226	01




Item	Code	Description	See page	QT
01	0503012795	5/8" HEX SELF ADJUSTING NUT		01
02	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
03	0503010691	1/4" GREASE FITTING		01
04	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
06	0503011336	1/2" HEX SELF ADJUSTING NUT		04
07	0521067063	SPRING HUB		01
08	0571018541	BODY SOCKET FERTILIZER		01
09	0521053958	STEM WITH NOZZLE HDA	224	01
10	0581012108	SPRING SUPPORT WASHER HDA		01
11	0503034107	71,50 X 230 X 16,50 SPRING COMPRESSION		01
12	0571018053	GUIDE SPRING SUPPORT		01
13	0503010384	1/2" X 5" BOLT		02
14	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
15	0503010547	1/2" X 4" BOLT		02
16	0503010026	3/8" NUT		02
17	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
18	0503010025	3/8 SPRING WASHER		02
19	0581012084	ARTICULATED SLEEVE		01
20	0581012081	ARTICULATED SLEEVE		01
21	0581012082	SCREW		01
22	0503010417	7/8" NUT		01




Item	Code	Description	See page	QT
01	0521053959	ROD WITH AUTOMATIC DISARM TIP	225	01
02	0521067067	WASHER SPRING WASHER 71.50 HDA		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0581012092	AXLE FIXER		01
05	0521015818	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521067066	ROD WITHOUT NOZZLE AUTOMATIC DISARM		01
02	0502040901	FIXED ROD NOZZLE		01
03	0503016853	SPRING PIN		02
04	0503011402	0.2" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0571016532	ADJUSTMENT BAR		02
02	0511017969	0.1" SPACING PLATE		02




Item	Code	Description	See page	QT
001	0531052349	CURRENT GUIDE ASSEMBLY	229	01
002	0531052347	HOSE SUPPORT ASSEMBLY	230	01




Item	Code	Description	See page	QT
01	0531052349	CURRENT GUIDE ASSEMBLY	229	01
02	0531052347	HOSE SUPPORT ASSEMBLY	230	01
03	0531052953	TRANSMISSION CABLE GUIDE		01
03A	0531062742	CABLE GUIDE		01
03B	0503010071	3/16" X 1" COTTERPIN		01



Item	Code	Description	See page	QT
01	0501011778	3/8" X 2-1/2" BOLT		02
02	0503010025	3/8 SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0591016329	ENCAPSULATED CHAIN CLOSING		01
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
06	0503010669	FLAT WASHER		02
07	0503010668	3/16" SPRING WASHER		02
08	0503010667	3/16" NUT		02
09	0531062745	CHAIN GUIDE		01



Item	Code	Description	See page	QT
01	0501210006	ASSY ARTICULATED CONDUCTOR SUPPORT		01
02	0501011643	3/8 X 1" BOLT		03
03	0503013357	3/8 SELF-ADJUSTING NUT		03
04	0531062741	SEED HOSE GUIDE		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
06	0503010071	3/16" X 1" COTTERPIN		01
07	0521065815	GUIDE SUPPORT		01



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

