

ROW CROP PLANTERS

PST4 TITANIUM - FRAME 4045/4495/4845/5345 - CSU

Code: 0501092688
Series: S-0116
Revision: 00
Date Revision: JULHO/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111151247	PST4 4045/8E500 CI MH DC20 CSU TIT S-0116
0111150213	PST4 4045/8E500 CSU TIT S-0116
0111151250	PST4 4045/8E500 ELEV CI MH DC20 CSU TIT S-0116
0111151249	PST4 4045/8E500 ESPECIAL S-0116
0111151238	PST4 4045/9E450 CI MH DC20 CSU TIT S-0116
0111151187	PST4 4045/9E450 CPRA CI MH CSU TIT S-0116
0111151224	PST4 4495/9E500 CI DC20 CSU TIT S-0116
0111151243	PST4 4495/9E500 CI MH DC20 CSU TIT S-0116
0111151140	PST4 4495/9E500 D/HDA CSU TIT CEAC S-0116
0111151217	PST4 4845/10E500 CI DC20 CSU TIT S-0116
0111151244	PST4 4845/10E500 CI MH DC20 CSU TIT S-0116
0111151163	PST4 4845/10E500 MH CSU TIT S-0116
0111151201	PST4 4845/11E450 ESPECIAL S-0116
0111151183	PST4 4845/11E450 ESPECIAL S-0116
0111151153	PST4 5345/11E500 D/HDA MH CSU TIT S-0116
0111151240	PST4 5345/12E450 CPRA CI MH DC20 CSU TIT S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.



MARCHESAN

INDEX

0909098885	ASSY FRAME	1
0501058195	FRAME WITH AXLE WHEEL - 4045	2
0511050836	WHEEL AXLE FRAME - 4495	3
0501058196	WHEEL AXLE FRAME - 4845	4
0511051118	WHEEL AXLE FRAME - 5345	5
0511057124	CYLINDER ASSY	6
0511056529	CYLINDER ASSY	7
0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	8
0511058406	HYDRAULIC CYLINDER	9
0511056536	ASSEMBLY LADDER	10
0511054971	RESTING ASSEMBLY	11
0511057131	MANUAL CANISTER ASSY	12
0511057133	LABEL ASSY FOR HYDRAULIC MARKER - 4045	13
0511057380	LABEL ASSY FOR HYDRAULIC MARKER - 4845	14
0511057142	ASSY HEADER - 3245/3695/4045/4495	15
0511057150	HEADER ASSEMBLY - 4845/5345	16
0511057130	HANDRAIL ASSY - 4045	17
0511057566	HANDRAIL ASSY - 4495	18
0511057651	HANDRAIL ASSY - 4845	19
0511058101	ASSEMBLY CSU C3 SEMI MOUNTED 4045/4495	20
0511057918	CSU C3 SEMI-ASSEMBLED ASSY 4845/5345	21
0511059318	CSU C3 SEMI-ASSEMBLED ASSY 5950/12	22
0511058100	ENSEMBLE BOX UNIQUE SEED C3	23
0511057919	ASSEMBLY CSU C3 2 BOXES 7B WITH 11 5340	24
0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	25
0521051927	TOWER SUPPORT HOPPER	26
0511057129	PLATFORM ASSY - 4045	27
0511057565	PLATFORM ASSY - 4495	28
0511057650	PLATFORM ASSY - 4845	29
0511057128	SET SUPPORT RIGHT LEFT	30
0511057147	ASSEMBLY SUPPORT RIGHT/LEFT BOX FERTILIZER	31
0501058206	RIGHT SILO SUPPORT WITH DISTRIBUTOR 11	32
0501058207	LEFT SILO SUPPORT WITH DISTRIBUTOR 11	33
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	34
0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	35
0501053788	Q3/4" FASTENER AXLE ASSY	36
0501058170	SEMI-ASSEMBLED HYDRAULIC MARKER 4045/9	37
0501058172	SEMI-ASSEMBLED HYDRAULIC MARKER 4845/11	38
0511058449	HYDRAULIC CYLINDER	39
0501054649	SEQUENTIAL VALVE ASSY	40
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	41
0501050633	MARKER DISC ASSY LINE	42
0511058597	RIGHT TRANSMISSION ASSY - 4045	43
0511056740	RIGHT TRANSMISSION ASSY - 4880	44
0511058598	LEFT TRANSMISSION ASSY - 4045	45
0511056741	LEFT TRANSMISSION ASSEMBLY - 4880	46
0501052560	AXLE MOTOR SLOW-MOVING ASSY	47
0511051434	TRANSMISSION DRIVING ASSY	48
0511047069	SIDE TRANSMISSION DRIVING	49
0511047070	LH SIDE TRANSMISSION DRIVING	50
0521043316	RIGHT GEAR BOX ASSY	51
0521043317	LEFT GEAR BOX ASSY	52
0501058212	SEMI MOUNTED RIGHT CHANGE	53
0501058213	LH GEAR BOX	54
0511059266	CLOSED BEARING	55



MARCHESAN

INDEX

0501056271	BEARING CLOSED	56
0501056443	BEARING ASSY GEAR BOX	57
0501056444	BEARING WITH ROLLING	58
0501048790	AXLE WITH LINK ASSY	59
0501054655	CHAIN TENSIONER ASSY	60
0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	61
0511054363	CHAIN TENSIONER	62
0501058234	LOWER CHAIN TENSIONER	63
0501058235	STRETCHER CURRENT TOP SEED 17Z	64
0521055207	TOP CURRENT STRETCHER	65
0501058236	BEARING WITH 21Z GEAR	66
0501058237	16Z GEAR BEARING	67
0501055112	MICRO GRANULATED CHAIN TENSIONER	68
0521043934	CARRYING WHEELS SPRING TRACTION	69
0501058240	WHELL FASTENER WITH STRETCHER	70
0501058243	STRETCHER INTERMEDIATE RODE CURRENT	71
0501058244	STRETCHER FIXED CURRENT	72
0501058242	MOVIL CHAIN TENSIONER	73
0501059909	CARRYING WHEELS SUPPORT	74
0511052770	WHEEL WITH TIRE 7.00X16 ASSY WHEELED BOX	75
0511052769	WHEEL TRANSMISSION WITHOUT TIRE	76
0501058241	TENSIONER CHAIN SUPPORT	77
0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	78
0511057146	HYDRAULIC SYSTEM ASSY - 4845/5345	79
0501054258	DRAWBAR ESTABILIZER ASSY	80
0511054601	FULL ARTICULATED TRACTOR HITCH	81
0511056736	HOSE SUPPORT	82
0909095145	ASSY HEX AXLE	83
0511058368	EAR MOVABLE	84
0909098892	SEED LINE/FERTILIZER ASSEMBLY	85
0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	86
0521052845	LINE SEED HIGH CUBE CSU TITANIUM	87
0521052636	DDD / DC20 HIGH LEFT FERTILIZER LINE	88
0521052846	LINE SEED HIGH CUBE CSU TITANIUM	89
0521052637	DDD / DC20 RIGHT HIGH RIGHT FERTILIZER LINE	90
0521052842	SHORT HIGH SEED LINE CSU TITATIUM	91
0511056564	SHORT SEED LINE TITANIUM CSU	92
0521052843	SEED LONG HIGH LINE CSU TITANIUM	93
0511056565	LONG SEED LINE TITANIUM CSU	94
0511056600	FRONT LINE SEED SHORT DDD RIGHT	95
0511056601	LONG SEED ROW FRONT DDD LEFT	96
0511058212	ASSY LINE SUPPORT FERTILIZER	97
0521052847	HIGH LINE PIVOTED SHORT HUB HIGH	98
0521052848	HIGH LINE PIVOTED SHORT HUB HIGH	99
0511059244	ROD SPRING LINE SEED	100
0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	101
0511052024	FAST CLOSING SET	102
0511051693	BASE FIXING SYSTEM	103
0501059631	DDD SEED 15" X 15" RIGHT	104
0501059632	DDD SEED 15X15 LEFT	105
0501054167	BOX DDD ASSY DPL 15 RIGHT	106
0501054168	BOX DDD ASSY DPL 15 LEFT	107
0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	108
0521050096	SEED DEPOSIT SYSTEM (CSU)	109
0511052058	SEED SYSTEM TITANIUM	110




MARCHESAN

INDEX

0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	111
0511056586	15 X 15 SEED DDD LEFT	112
0511052301	SUPPORT DDD 15 RIGHT	113
0511052302	LH SUPPORT DDD GUIDE	114
0511053173	CUBE LOW RIGHT WITH DISC 15	115
0511053172	LEFT LOW CUBE WITH DISC 15	116
0521054642	SHORT HIGH FERTILIZER LINE DAOC DC20	117
0521054643	LONG HIGH FERTILIZER LINE DAOC DC20	118
0511053254	SHORT FERTILIZER LINE DDD LEFT DC20	119
0511053255	LONG FERTILIZER LINE DDD RIGHT DC20	120
0521052838	RIGHT SUPPORT DOC18	121
0521052839	LEFT SUPPORT DOC18	122
0511059229	BOX WITH DOC 18 TURBO RIGHT	123
0511059230	BOX WITH DOC 18 TURBO LEFT	124
0521050168	MOUNTED FERTILIZER CONDUCTOR	125
0511058619	DISC CUT 20 SHORT LINE	126
0511058620	DISC CUT 20 LONG LINE	127
0511058648	BOX WITH DISC BLADE 20"	128
0511056909	DISC BOX CUT WITHOUT THE DISC	129
0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	130
0511053250	SHORT ARM FERTILIZER LINE WITH DDD LEFT	131
0511053251	ARM LONG FERTILIZER LINE WITH DDD RIGHT	132
0521053152	ARM SHORT LINE FERTILIZER WITH DDD LEFT	133
0521053151	ARM LONG FERTILIZER LINE WITH DDD RIGHT	134
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	135
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	136
0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	137
0511044585	20" COULTER BLADE ASSY FOR LONG ROW	138
0501054887	20 BLADE DISC WITH FLAT PLAN DISC	139
0521052841	LONG PIVOTANT HIGH LINE	140
0521052840	SHORT PIVOTING HIGH LINE	141
0501058423	FERTILIZER ROD SPRING ROW	142
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	143
0511058650	SEMI-MOUNTED DEPTH CONTROL	144
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	145
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	146
0501052627	ASSY DEPTH WHEEL BOX	147
0501052297	DEPTH WHEELS REGULATOR ASSY	148
0501052538	DEPTH BAND WITH ARMS	149
0511054333	COMPACT WHEEL RIGHT WITH BEARING	150
0511054334	COMPACT WHEEL LEFT WITH BEARING	151
0501052908	COMPACTOR WHEEL WITH BEARING	152
0501110804	ROD SCARIFIER SPINDLE WITH POINT	153
0501110231	SCARIFIER HEAD WITH SPIKE 0061	154
0521050525	FIXER FERTILIZER CONDUCTOR	155

ASSY FRAME

0909098885




Item	Code	Description	See page	4045	4495	4845	5345
01	0501058195	FRAME WITH AXLE WHEEL - 4045	2	01	00	00	00
01.	0511050836	WHEEL AXLE FRAME - 4495	3	00	01	00	00
01..	0501058196	WHEEL AXLE FRAME - 4845	4	00	00	01	00
01...	0511051118	WHEEL AXLE FRAME - 5345	5	00	00	00	01
02	0503010003	1845 GREASE FITTING		04	04	06	06
03	0511057124	CYLINDER ASSY	6	01	01	00	00
03.	0511056529	CYLINDER ASSY	7	00	00	01	01
04	0521013022	TRANSPORT LOCK		01	01	02	02
05	0501068994	0.3" X 3.1" LOCK PIN		01	01	02	02
06	0503030168	HAIR PIN		01	01	02	02
07	0511056536	ASSEMBLY LADDER	10	02	02	02	02
08	0511054971	RESTING ASSEMBLY	11	02	02	02	02
09	0511057131	MANUAL CANISTER ASSY	12	01	01	01	01
10	0511057133	LABEL ASSY FOR HYDRAULIC MARKER - 4045	13	01	00	00	00
10.	0511059621	ASSY STICKER		00	01	00	00
10..	0511057380	LABEL ASSY FOR HYDRAULIC MARKER - 4845	14	00	00	01	00
10...	0521050177	LABEL ASSY FOR HYDRAULIC MARKER - 5485		00	00	00	01
11	0511057142	ASSY HEADER - 3245/3695/4045/4495	15	01	01	00	00
11.	0511057150	HEADER ASSEMBLY - 4845/5345	16	00	00	01	01
12	0511057130	HANDRAIL ASSY - 4045	17	01	00	00	00
12.	0511057566	HANDRAIL ASSY - 4495	18	00	01	00	00
12..	0511057651	HANDRAIL ASSY - 4845	19	00	00	01	01
13	0511058101	ASSEMBLY CSU C3 SEMI MOUNTED 4045/4495	20	01	01	00	00
13.	0511059318	CSU C3 SEMI-ASSEMBLED ASSY 5950/12	22	00	00	01	00
13..	0511057736	CSU C3 SEMI-ASSEMBLED ASSY 4845/10		00	00	00	01
14	0511057129	PLATFORM ASSY - 4045	27	01	00	00	00
14.	0511057650	PLATFORM ASSY - 4845	29	00	00	01	01
14..	0511057565	PLATFORM ASSY - 4495	28	00	01	00	00
15	0511057128	SET SUPPORT RIGHT LEFT	30	01	00	00	00
15.	0511059622	SET SUPPORT RIGHT LEFT		00	01	00	00
15..	0511057147	ASSEMBLY SUPPORT RIGHT/LEFT FERTILIZER	BOX 31	00	00	01	00


ASSY FRAME

0909098885


Item	Code	Description	See page	4045	4495	4845	5345
15...	0511057147	ASSEMBLY SUPPORT RIGHT/LEFT BOX 31 FERTILIZER		00	00	00	01
16	0501058170	SEMI-ASSEMBLED HYDRAULIC MARKER 4045/9	37	01	01	00	00
16.	0501058172	SEMI-ASSEMBLED HYDRAULIC MARKER 4845/11	38	00	00	01	01
17	0501050633	MARKER DISC ASSY LINE	42	02	02	02	02
18	0511058597	RIGHT TRANSMISSION ASSY - 4045	43	01	00	00	00
18.	0511059624	SET TRANSMISSION RIGHT		00	01	00	00
18..	0511056740	RIGHT TRANSMISSION ASSY - 4880	44	00	00	01	00
18...	0521050178	RIGHT TRANSMISSION ASSY - 5345		00	00	00	01
19	0511058598	LEFT TRANSMISSION ASSY - 4045	45	01	00	00	00
19.	0511059625	SET TRANSMISSION LEFT		00	01	00	00
19..	0511056741	LEFT TRANSMISSION ASSEMBLY - 4880	46	00	00	01	00
19...	0521050179	ASSY TRANSMISSION LEFT - 5345		00	00	00	01
20	0521043934	CARRYING WHEELS SPRING TRACTION	69	04	04	04	04
21	0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	78	01	01	00	00
21.	0511057146	HYDRAULIC SYSTEM ASSY - 4845/5345	79	00	00	01	01
22	0501065677	STRUT		02	02	02	02
23	0521013164	EXTENSOR		00	00	02	02
24	0501011310	FIXER LOCK		00	00	08	08
25	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		00	00	04	04
26	0503010019	1/2" SPRING WASHER		00	00	04	04
27	0503010060	1/2" NUT		00	00	04	04
28	0501054258	DRAWBAR ESTABILIZER ASSY	80	01	01	01	01
29	0511054601	FULL ARTICULATED TRACTOR HITCH	81	01	01	01	01
30	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01	01	01	01
31	0511053179	TRACTOR HITCH AXLE		01	01	01	01
31A	0521064036	TRACTOR HITCH AXLE		01	01	01	01
31B	0503030012	HAIR PIN		01	01	01	01
32	0511056736	HOSE SUPPORT	82	01	01	01	01
33	0501047895	ROD STOP		01	01	02	02
34	0501047885	ROD STOP		01	01	02	02
35	0501047886	ROD STOP		01	01	02	02
36	0501047887	ROD STOP		01	01	02	02
37	0503032624	SILO FERTILIZER GUTTER		05	05	06	06
38	0503014120	CHAIN		01	01	01	01
39	0503014321	CABLE STEEL SHACKLE		02	02	02	02
40	0503010780	N-2050 AMENDMENT		02	02	02	02
41	0503011750	AMENDMENT WITH LOCK		06	06	06	06
42	0503011751	REDUCTION		06	06	06	06
43	0503010951	REDUCTION		04	04	04	04
44	0503010246	CLAMP		03	03	06	06
45	0909095145	ASSY HEX AXLE	83	01	01	01	01
46	0511058368	EAR MOVABLE	84	02	02	00	00
47	0909098892	SEED LINE/FERTILIZER ASSEMBLY	85	01	01	01	01




Item	Code	Description	See page	QT
01	0511069529	FRAME		01
02	0511069682	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0521062243	FRAME		01
02	0521062242	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0511069616	FRAME		01
02	0511069717	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8" X 2-1/4" BOLT		12
05	0501012140	FLAT WASHER		24
06	0531013922	0.6" X 0.8" X 1" SLEEVE		12
07	0503011445	SPRING WASHER		12
08	0503010013	5/8" NUT		12




Item	Code	Description	See page	QT
01	0521062442	FRAME		01
02	0521062447	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8" X 2-1/4" BOLT		12
05	0501012140	FLAT WASHER		24
06	0531013922	0.6" X 0.8" X 1" SLEEVE		12
07	0503011445	SPRING WASHER		12
08	0503010013	5/8" NUT		12



Item	Code	Description	See page	QT
01	0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	8	01
02	0531019171	1.25" X 7" COUPLING SHAFT		01
03	0521012536	COUPLING SHAFT		01
04	0503010523	1/4" X 2" COTTERPIN		02
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	9	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521012536	COUPLING SHAFT		02
04	0503010523	1/4" X 2" COTTERPIN		04
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0511064055	5" X 15" CYLINDER CASE		01
02	0511064056	BUSHING 2" X 14" TURNBUCLE		01
03	0502010382	5" END CAP		01
04	0502012227	50.80 X 127 RING SUPPORT		01
05	0503010039	D-2000 SCRAPER RING		01
06	0503010991	1870-2000-375-B GASKET		01
07	0503010952	W2-2250-500 RING		01
08	0503010351	2-425 N 3006-9B O'RING		01
09	0503011062	8-425 BACK-UP RING		01
10	0502010963	2.0" X 5.0" PISTON		01
11	0503010552	PACKING 3750-4250-625-B		02
12	0503010345	2-218 N 3006-9B O'RING		01
13	0503010974	W2-5000-500 RING		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503010003	1845 GREASE FITTING		01
16	0503030385	CYLINDER PLUG N-002		02

HYDRAULIC CYLINDER

0511058406




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O'RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O'RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	

RESTING ASSEMBLY


0511054971




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
05	0503010179	5/16" ZN SPRING WASHER		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING	02	
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
07	0503033424	DIRECT PLANTIO ADHESIVE LABEL	02	
08	0503033008	ADHESIVE LABEL	02	
09	0503031428	READ MANUAL DECAL	01	
10	0503031942	ADHESIVE LABEL	01	
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
12	0503031565	ADHESIVE LABEL CARE	02	
13	0503031566	ADHESIVE LABEL	02	
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
15	0503031425	ADHESIVE LABEL ATTENTION	02	
16	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO	02	
17	0503031669	ADHESIVE LABEL	01	
18	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
19	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
20	0503032930	ADHESIVE LABEL DANGER	05	
21	0503031087	ADHESIVE LABEL	01	
22	0503034078	LIFTING POINTS DECAL	03	
23	0503034003	SERIAL NUMBER TAG 61 X 118	01	
24	0503010001	3.2 X 5.5 RIVET	04	
25	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
26	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
06	0503033422	ADHESIVE LABEL	02	
07	0503033424	DIRECT PLANTIO ADHESIVE LABEL	02	
08	0503033008	ADHESIVE LABEL	02	
09	0503031428	READ MANUAL DECAL	01	
10	0503031942	ADHESIVE LABEL	01	
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
12	0503031565	ADHESIVE LABEL CARE	02	
13	0503031566	ADHESIVE LABEL	02	
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
15	0503031425	ADHESIVE LABEL ATTENTION	02	
16	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO	02	
17	0503031669	ADHESIVE LABEL	01	
18	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
19	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
20	0503032930	ADHESIVE LABEL DANGER	06	
21	0503031087	ADHESIVE LABEL	01	
22	0503034078	LIFTING POINTS DECAL	03	
23	0503034003	SERIAL NUMBER TAG 61 X 118	01	
24	0503010001	3.2 X 5.5 RIVET	04	
25	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
26	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0502012329	DRAWBAR FIXATION REAR SUPPORT		02
02	0502012330	SUPPORT FIXER PIVOT		04
03	0503011084	3/4" X 5" BOLT		08
04	0501010322	FLAT WASHER		08
05	0503010023	3/4" SPRING WASHER		08
06	0503010014	3/4" NUT		08
07	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02
08	0561014393	COUPLING SHAFT		02
09	0503030119	LOCK PIN		04
10	0511064808	DRAWBAR		01
11	0561019087	DRAWBAR TRANSPORT LOCK		01
12	0521010578	COUPLING SHAFT		01
13	0521010588	0.9" X 7.0" COUPLING SHAFT		01
14	0503030085	LOCK PIN		02
15	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	1902012329	REAR SUPPORT FIXING HEADER	04	
02	1902012330	FIXER SUPPORT ARTICULATED	08	
03	0503011084	3/4" X 5" BOLT	16	
04	0503010023	3/4" SPRING WASHER	16	
05	0503010014	3/4" NUT	16	
06	1902012328	FIXED FRONT SUPPORT HEADER	04	
07	0561014393	COUPLING SHAFT	04	
08	0503030119	LOCK PIN	08	
09	0511064808	DRAWBAR	01	
10	0561019087	DRAWBAR TRANSPORT LOCK	01	
11	0521010588	0.9" X 7.0" COUPLING SHAFT	01	
12	0521010578	COUPLING SHAFT	01	
13	0503030085	LOCK PIN	02	
14	0503010002	1800 GREASE FITTING	01	
15	0501010322	FLAT WASHER	16	




Item	Code	Description	See page	QT
001	0511069656	HANDRAIL		02
002	0503010395	1/2" X 1-1/4" BOLT		04
003	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
004	0503010019	1/2" SPRING WASHER		08
005	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0521062239	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0511069660	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
001	0511058100	ENSEMBLE BOX UNIQUE SEED C3	23	01
002	0521066208	SUPPORT TOWER SILO		04
003	0501010942	3/8" X 1-1/4" BOLT		08
004	0501010984	FLAT WASHER		08
005	0503010025	3/8" SPRING WASHER		08
006	0503010026	3/8" NUT		08
007	0502010175	HITCH CLAMP		04
008	0501011543	5/8" X 4" BOLT		08
009	0501012140	FLAT WASHER		08
010	0503012412	5/8 UNC SELF LOCKING NUT		08




Item	Code	Description	See page	QT
01	0511057919	ASSEMBLY CSU C3 2 BOXES 7B WITH 11 5340	24	01
02	0521051927	TOWER SUPPORT HOPPER	26	04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
001	0511058724	ASSEMBLY CSU C3 2BOXES 7/6 12E500		01
002	0501010942	3/8" X 1-1/4" BOLT		08
003	0501010984	FLAT WASHER		08
004	0503010025	3/8" SPRING WASHER		08
005	0503010026	3/8" NUT		08
006	0502010175	HITCH CLAMP		04
007	0501011543	5/8" X 4" BOLT		08
008	0503012412	5/8 UNC SELF LOCKING NUT		08
009	0521066208	SUPPORT TOWER SILO		04
010	0501010453	FLAT WASHER		08




Item	Code	Description	See page	QT
01	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS		02
02	0503061899	REAR BEAN FERTILIZER ASSY		02
03	0521063401	SEED BOX ONLY FIXING LOCK		04
04	0501010984	FLAT WASHER		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	25	09
08	0501010942	3/8" X 1-1/4" BOLT		36
09	0503010025	3/8" SPRING WASHER		36
10	0503010026	3/8" NUT		36
11	0571015773	SUPPORT SEED CSU		03
12	0501011643	3/8 X 1"BOLT		12
13	0503010025	3/8" SPRING WASHER		12
14	0503010026	3/8" NUT		12




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		04
02	0501010984	FLAT WASHER		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	25	11
06	0571015773	SUPPORT SEED CSU		03
07	0501011643	3/8 X 1" BOLT		12
08	0501010942	3/8" X 1-1/4" BOLT		44
09	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
09	0503010179	5/16" ZN SPRING WASHER		02
10	0503010337	5/16" NUT		02
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT		01




Item	Code	Description	See page	QT
01	0521066208	SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
001	0511069661	PLATFORM SUPPORT PIVOT	04	
002	0503010849	3/8" X 1-1/2" BOLT	08	
003	0501010984	FLAT WASHER	16	
004	0503010025	3/8" SPRING WASHER	08	
005	0503010026	3/8" NUT	08	
006	0511069665	PLATFORM RIGHT PST4 9	01	
007	0521062323	PLATFORM LEFT PST4 9	01	
008	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
009	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
010	0503011333	COVER FIXER	02	
011	0503010274	5/32"X 2" COTTERPIN	02	
012	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
013	0502012739	PLATFORM LEFT FIXER SUPPORT	01	



Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	FLAT WASHER	16	
04	0503010025	3/8" SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0521062237	RIGHT PLATAFORM	01	
07	0521062238	LEFT PLATAFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	



Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	FLAT WASHER	16	
04	0503010025	3/8" SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0511069718	PLATFORM RIGHT PST4 11	01	
07	0521062324	PLATFORM LEFT PST4 11	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	DIR	ESQ
01	0511052253	RH BEAM SUPPORT & METERING		01	00
01A	0521063436	FERTILIZER BEAN RIGHT SUPPORT		01	00
02	0511052254	LH BEAM SUPPORT & METERING		00	01
02A	0521063437	FERTILIZER BEAN LEFT SUPPORT		00	01
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	35	00	05
03A	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		00	05
03B	0501019851	DISTRIBUTOR FERTILIZER AXLE		05	05
03C	0521010309	SLEEVE INTER		05	05
03D	0503030275	AGRICULTURAL BEARING		10	10
03E	0503031164	RIGHT HELICAL CONDUCTOR		05	05
03F	0501010637	FLAT WASHER		05	05
03G	0503030303	SUPPORT WASHER		05	05
03H	0501013774	GREASE SEAL		05	05
03I	0502011412	18Z CONICAL GEAR		05	05
03J	0503010523	1/4" X 2" COTTERPIN		05	05
03K	0503011962	GREASE FITTING		05	05
03L	0503010003	1845 GREASE FITTING		05	05
03M	0503012826	CREASE FITTING		05	05
04	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	34	05	00
04A	0501110676	SIDE FERTILIZER DISTRIBUTOR		05	00
04B	0503031165	LEFT HELICAL CONDUCTOR		05	05
05	0501010942	3/8" X 1-1/4" BOLT		20	20
06	0503011443	3/8" SPRING WASHER		20	20
07	0503010026	3/8" NUT		20	20
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01	01
09	0521014167	CONE LOCK		01	01
10	0503030275	AGRICULTURAL BEARING		05	05
11	0502010685	18Z CONICAL GEAR		05	05
12	0551018213	3/4" X 1830 SQUARE SHAFT		01	01
13	0521010691	AXLE FASTENER		02	02
14	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02	02

SET SUPPORT RIGHT LEFT


0511057128

Item	Code	Description	See page	DIR	ESQ
15	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02
16	0503011441	SPRING WASHER		02	02
17	0503010144	1/4" NUT		02	02
18	0501110392	SILO SUPPORT BEARING		01	01
19	0521012485	GEAR BOX BEARING AGRICUTURAL		01	01
20	0503011953	5/16" X 1" BOLT		02	02
21	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02
22	0521011039	FLAT WASHER		02	02
23	0503011444	SPRING WASHER		02	02
24	0503010337	5/16" NUT		02	02
25	0551018055	22,65 X 60 SLEEVE		01	01
26	0503010003	1845 GREASE FITTING		01	01
27	0503010849	3/8" X 1-1/2" BOLT		08	08
28	0501010984	FLAT WASHER		17	17
29	0503010025	3/8" SPRING WASHER		08	08
30	0503010026	3/8" NUT		08	08
31	0571010590	FERTILIZER SIDE COVER		05	05
32	0503010362	1/8" X 1.1/4" COTTERPIN		05	05
33	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		01	01
34	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02	02
35	0551019156	GEAR BOX LEVER LOCK		01	01
36	0503011953	5/16" X 1" BOLT		02	02
37	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02	02
38	0503010179	5/16" ZN SPRING WASHER		02	02
39	0503010337	5/16" NUT		02	02
40	0503010847	1/2" X 3.1/4" BOLT		01	01
41	0551019168	SLEEVE		01	01
42	0551019160	LEVER		01	01
43	0511017302	FLAT WASHER		03	03
44	0503010019	1/2" SPRING WASHER		02	02
45	0503010060	1/2" NUT		02	02
46	0551019167	SLEEVE UNION		01	01
47	0511069676	INNER LEVER		01	01
48	0501013518	FLAT WASHER		02	02
49	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01	01
50	0503010140	1/8" X 3/4" COTTERPIN		03	03
51	0511069678	LH LOWER LEVER		02	02
52	0503011336	1/2" HEX SELF ADJUSTING NUT		02	02
53	0551019115	LOCKING PLATFORM FIXATION		01	01
54	0501010096	3/8" X 2" BOLT		01	01
55	0503013357	3/8" SELF-ADJUSTING NUT		01	01
56	0551019159	LEVER FIXER BODY		01	01
57	0561016468	FASTENER		01	01




Item	Code	Description	See page	QT
01	0501058206	RIGHT SILO SUPPORT WITH DISTRIBUTOR 11	32	01
02	0501058207	LEFT SILO SUPPORT WITH DISTRIBUTOR 11	33	01
03	0503062169	SILO FERTILIZER 6 MOUTHS MOUNTED		02
04	0503010849	3/8" X 1-1/2" BOLT		12
05	0501010984	FLAT WASHER		24
06	0503010025	3/8" SPRING WASHER		12
07	0503010026	3/8" NUT		12
08	0503034396	FERTILIZER SIDE COVER		12
09	0503010362	1/8" X 1.1/4" COTTERPIN		12
10	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
11	0503010849	3/8" X 1-1/2" BOLT		08
12	0501010984	FLAT WASHER		16
13	0503010025	3/8" SPRING WASHER		08
14	0503010026	3/8" NUT		08
15	0551019156	GEAR BOX LEVER LOCK		02
16	0503011953	5/16" X 1" BOLT		04
17	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
18	0503010179	5/16" ZN SPRING WASHER		04
19	0503010337	5/16" NUT		04
20	0551019160	LEVER		02
21	0551019168	SLEEVE		02
22	0503010847	1/2" X 3.1/4" BOLT		02
23	0511017302	FLAT WASHER		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501013518	FLAT WASHER		02
27	0503010140	1/8" X 3/4" COTTERPIN		02
28	0511069676	INNER LEVER		02
29	0551019167	SLEEVE UNION		02
30	0511017302	FLAT WASHER		02
31	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02


Item	Code	Description	See page	QT
32	0503010019	1/2" SPRING WASHER		02
33	0503010060	1/2" NUT		02
34	0511069678	LH LOWER LEVER		02
35	0501013518	FLAT WASHER		02
36	0503010140	1/8" X 3/4" COTTERPIN		04
37	0551019159	LEVER FIXER BODY		02
38	0561016468	FASTENER		02
39	0503011336	1/2" HEX SELF ADJUSTING NUT		04
40	0551019115	LOCKING PLATFORM FIXATION		02
41	0501010096	3/8" X 2" BOLT		02
42	0501010984	FLAT WASHER		02
43	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521066242	FERTILIZER BEAN RIGHT SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	34	03
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	35	03
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503011443	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		06
10	1902010685	18Z CONICAL GEAR		06
11	0511014265	3/4" X 86" SQUARE SHAFT		01
12	0501053788	Q3/4" FASTENER AXLE ASSY	36	02
13	0501110392	SILO SUPPORT BEARING		01
14	0521012485	GEAR BOX BEARING AGRICUTURAL		01
15	0503011953	5/16" X 1" BOLT		02
16	0521011039	FLAT WASHER		02
17	0503011444	SPRING WASHER		02
18	0503010337	5/16" NUT		02
19	0551018055	22,65 X 60 SLEEVE		01
20	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521066241	FERTILIZER BEAN LEFT SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	34	03
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	35	03
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503011443	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		06
10	1902010685	18Z CONICAL GEAR		06
11	0511014265	3/4" X 86" SQUARE SHAFT		01
12	0501053788	Q3/4" FASTENER AXLE ASSY	36	02
13	0501110392	SILO SUPPORT BEARING		01
14	0521012485	GEAR BOX BEARING AGRICUTURAL		01
15	0503011953	5/16" X 1" BOLT		02
16	0521011039	FLAT WASHER		02
17	0503011444	SPRING WASHER		02
18	0503010337	5/16" NUT		02
19	0551018055	22,65 X 60 SLEEVE		01
20	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01



Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511817303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8 UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0503012412	5/8 UNC SELF LOCKING NUT		02
13	0511058449	HYDRAULIC CYLINDER	39	02
14	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
15	0503010523	1/4" X 2" COTTERPIN		02
16	0511015779	1" X 4.2" AXLE		02
17	0503010523	1/4" X 2" COTTERPIN		02
18	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
19	0501068994	0.3" X 3.1" LOCK PIN		02
20	0503030168	HAIR PIN		02
21	0501069643	890 TURNBUCKLE		02
22	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
23	0511011311	VALVE SUPPORT		01
24	0503010232	5/8" X 1.3/4" BOLT		02
25	0503010027	5/8" SPRING WASHER		02
26	0503010013	5/8" NUT		02
27	0501054649	SEQUENTIAL VALVE ASSY	40	01
28	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
29	0501010984	FLAT WASHER		02
30	0503010025	3/8" SPRING WASHER		02
31	0511057095	HYDRAULIC MARKER HOSE KIT		01

Item	Code	Description	See page	QT
32	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	41	02
33	0502012702	BODY SUPPORT CLAMP		06
34	0503011103	7/16" X 2-1/2" BOLT		06
35	0501012803	FLAT WASHER		02
36	0503010180	7/16" SPRING WASHER		06
37	0503010244	7/16" NUT		06




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8 UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503011082	C1/2" X 1.3/4" SCREW		02
07	0501069470	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0501012140	FLAT WASHER		04
11	0503012412	5/8 UNC SELF LOCKING NUT		02
12	0511058449	HYDRAULIC CYLINDER	39	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" COTTERPIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	0.3" X 3.1" LOCK PIN		02
19	0503030168	HAIR PIN		02
20	0501066949	1235 TURNBUCKLE		02
21	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
22	0511011311	VALVE SUPPORT		01
23	0503010232	5/8" X 1.3/4" BOLT		02
24	0503010027	5/8" SPRING WASHER		02
25	0503010013	5/8" NUT		02
26	0501054649	SEQUENTIAL VALVE ASSY	40	01
27	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
28	0501010984	FLAT WASHER		02
29	0503010025	3/8" SPRING WASHER		02
30	0502012702	BODY SUPPORT CLAMP		06
31	0503011103	7/16" X 2-1/2" BOLT		06


Item	Code	Description	See page	QT
32	0501012803	FLAT WASHER		02
33	0503010180	7/16" SPRING WASHER		06
34	0503010244	7/16" NUT		06
35	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	41	02
36	0511057069	HYDRAULIC HOSE MARKER ASSY		01
36A	0501080343	TR-TR HOSE ASSY		02
36B	0501080720	HOSE 3/8 X 3500 TR-TC		02
37	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
37A	0501080422	HOSE 3/8 X 4000 TC-TM		01
37B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
37C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
37D	0503018952	PLASTIC BOLT		06
38	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
38A	0501080422	HOSE 3/8 X 4000 TC-TM		01
38B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
38C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
38D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01



Item	Code	Description	See page	QT
01	0511053904	DISC LINE MARKER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016881	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	47	01
15	0511051434	TRANSMISSION DRIVING ASSY	48	02
16	0511047069	SIDE TRANSMISSION DRIVING	49	01
17	0521043316	RIGHT GEAR BOX ASSY	51	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	62	01
26	0501058234	LOWER CHAIN TENSIONER	63	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	64	01
28	0501058236	BEARING WITH 21Z GEAR	66	01
29	0501058237	16Z GEAR BEARING	67	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	68	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

RIGHT TRANSMISSION ASSY - 4045


0511058597

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8" SPRING WASHER		01
36	0501010984	FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	47	01
15	0511051434	TRANSMISSION DRIVING ASSY	48	02
16	0511047069	SIDE TRANSMISSION DRIVING	49	01
17	0521043316	RIGHT GEAR BOX ASSY	51	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	62	01
26	0501058234	LOWER CHAIN TENSIONER	63	01
27	0521055207	TOP CURRENT STRETCHER	65	01
28	0501058236	BEARING WITH 21Z GEAR	66	01
29	0501058237	16Z GEAR BEARING	67	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	68	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016881	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	47	01
15	0511051434	TRANSMISSION DRIVING ASSY	48	02
16	0511047070	LH SIDE TRANSMISSION DRIVING	50	01
17	0521043317	LEFT GEAR BOX ASSY	52	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	62	01
26	0501058234	LOWER CHAIN TENSIONER	63	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	64	01
28	0501058236	BEARING WITH 21Z GEAR	66	01
29	0501058237	16Z GEAR BEARING	67	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	68	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8" SPRING WASHER		01
36	0501010984	FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	47	01
15	0511051434	TRANSMISSION DRIVING ASSY	48	02
16	0511047070	LH SIDE TRANSMISSION DRIVING	50	01
17	0521043317	LEFT GEAR BOX ASSY	52	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	62	01
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	68	01
27	0501058234	LOWER CHAIN TENSIONER	63	01
28	0521055207	TOP CURRENT STRETCHER	65	01
29	0501058236	BEARING WITH 21Z GEAR	66	01
30	0501058237	16Z GEAR BEARING	67	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01


Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	5/16" X 3/4" BOLT		02
03	0503010179	5/16" ZN SPRING WASHER		02
04	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 C5PC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY


0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	53	01
02	0511059266	CLOSED BEARING	55	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	BEARING ASSY GEAR BOX	57	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH LINK ASSY	59	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	60	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	61	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	54	01
02	0511059266	CLOSED BEARING	55	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	BEARING ASSY GEAR BOX	57	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH LINK ASSY	59	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	60	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	61	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX	01	
02	0502011758	REAR TENSIONER LEVER	02	
03	0503010292	0.2" X 1.6" SPRING PIN	02	
04	0511061794	CHAIN TENSIONER	01	
05	0503031367	SPRING	01	
06	0511060392	CHAIN TENSIONER	01	
07	0503031366	RIGHT TWISTED SPRING RECAMBIO	01	




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0501056271	BEARING CLOSED	56	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	58	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
05	0503010179	5/16" ZN SPRING WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503012882	BEARING		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0551019173	CHAIN SLEEVE TENSIONER		01
05	0511017302	FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503019355	BEARING 6202 2RS1		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0551019173	CHAIN SLEEVE TENSIONER		01
05	0511017302	FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019174	DOBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501058240	WHELL FASTENER WITH STRETCHER	70	01
02	0503011119	7/8" X 6" BOLT		04
03	0501014251	FLAT WASHER		04
04	0503011254	7/8" HEX SELF ADJUSTING NUT		04
05	0501059909	CARRYING WHEELS SUPPORT	74	01
06	0503014887	2050 CHAIN X 80 LINK + REDUCTION		01
07	0502010584	CARRYING-WHEELS SUPPORT FIXER		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	STRETCHER INTERMEDIATE RODE CURRENT	71	01
07	0501058244	STRETCHER FIXED CURRENT	72	01
08	0501058242	MOVIL CHAIN TENSIONER	73	01



Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	CHAIN TENSIONER BEARING		01
02A	0503012882	BEARING		01
02B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02C	0502012853	GEAR		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TIGHTENER AXLE		01
02	0501058239	CHAIN TENSIONER BEARING		01
02A	0503012882	BEARING		01
02B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02C	0502012853	GEAR		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN UPPER AXLE		01
02	0501058239	CHAIN TENSIONER BEARING		01
02A	0503012882	BEARING		01
02B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02C	0502012853	GEAR		01
03	0551018240	SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01

CARRYING WHEELS SUPPORT


0501059909




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0531016887	CARRYING WHEEL AXLE ARM		01
03	0503010523	1/4" X 2" COTTERPIN		01
04	0503010003	1845 GREASE FITTING		01
05	0511050681	TRACTION SPRING		01
05A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
05B	0561016062	SPRING HITCH		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		04
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0511052770	WHEEL WITH TIRE 7.00X16 ASSY WHEELED BOX	75	01
11	0581011124	WHEELED COVER		01
12	0521012190	AXLE LOCK		01
13	0503011167	M16 X 2 X 30 BOLT		02
14	0501058241	TENSIONER CHAIN SUPPORT	77	01
15	0521061565	WHEEL SUPPORT ARM		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL		01
02	0511052769	WHEEL TRANSMISSION WITHOUT TIRE	76	01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSM AXLE CARRYING-WHEEL		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511057070	HOSE KIT HYDRAULIC		01
01A	0521052285	TC-TM HOSE ASSY		01
01AA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01AB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01AD	0503018952	PLASTIC BOLT		06
01B	0521052287	TC-TM HOSE ASSY		01
01BA	0501080446	3/8 X" 169" TC-TM HOSE ASSY		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01BD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	41	02
03	0503013100	NYLON CLAMP		02
04	0581010091	SPRING PROTECTION PLASTIC HOSE		01




Item	Code	Description	See page	QT
01	0511063404	"T" OIL CONDUCTOR		02
02	0581010091	SPRING PROTECTION PLASTIC HOSE		01
03	0503013100	NYLON CLAMP		02
04	0502012702	BODY SUPPORT CLAMP		02
05	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		02
06	0503010180	7/16" SPRING WASHER		02
07	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	41	02
08	0511057068	HOSE KIT SYSTEM HYDRAULIC		01
08A	0501080449	3/8" X 1500 TC-TC HOSE		04
09	0521052334	3/8 X 4000 TR-TM HOSE BLACK / BLUE		01
09A	0501080361	3/8" X 157" TR-TM HOSE		01
09B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
09C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
09D	0503018952	PLASTIC BOLT		06
10	0521052333	3/8 X 4000 TR-TM HOSE BLACK / RED		01
10A	0501080361	3/8" X 157" TR-TM HOSE		01
10B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
10C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
10D	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0511062887	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0571012612	PIVOT SHAFT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01

ASSY HEX AXLE


0909095145



Item	Code	Description	See page	3245	4045	4845
01	0521013432	5/8" X 59" AXLE HEX		01	00	00
01.	0521013429	AXLE HEX 5/8 X 2180		00	01	00
01..	0521013430	HEX AXLE 5/8 X 2580		00	00	01
02	0521013428	HEX AXLE		01	00	00
02.	0521013433	5/8" X 75" AXLE HEX		00	01	00
02..	0521013434	HEX AXLE 5/8 X 2300		00	00	01
03	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"		02	02	02
04	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8		02	02	02
05	0503010003	1845 GREASE FITTING		02	02	02
06	0503010365	NUT		04	04	04
07	0501010984	FLAT WASHER		04	04	04
08	0501010694	8.5 X 18 X 1.5 FLAT WASHER		08	08	08
09	0503010179	5/16" ZN SPRING WASHER		04	04	04
10	0503010337	5/16" NUT		04	04	04
11	0511815098	FLAT WASHER		02	02	02
12	0511017305	FLAT WASHER		04	04	04
13	0511065562	20Z GEAR		02	02	02
14	0502011299	BUSHING GEAR		02	02	02
15	0503010571	1/4" X 1.1/2 COTTERPIN		02	02	02
16	0503010010	1/4" X 2.1/2" COTTERPIN		02	02	02




Item	Code	Description	See page	QT
001	0521066608	LIFTING HOOK		01
002	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
003	0511017302	FLAT WASHER		04
004	0503010019	1/2" SPRING WASHER		04
005	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521052845	LINE SEED HIGH CUBE CSU TITANIUM	87	01
01.	0521052636	DDD / DC20 HIGH LEFT FERTILIZER LINE	88	01
02	0521052846	LINE SEED HIGH CUBE CSU TITANIUM	89	01
02.	0521052637	DDD / DC20 RIGHT HIGH RIGHT FERTILIZER LINE	90	01
03	0511056564	SHORT SEED LINE TITANIUM CSU	92	01
04	0511056565	LONG SEED LINE TITANIUM CSU	94	01
05	0521054642	SHORT HIGH FERTILIZER LINE DAOC DC20	117	01
05.	0521052842	SHORT HIGH SEED LINE CSU TITATIUM	91	01
06	0521054643	LONG HIGH FERTILIZER LINE DAOC DC20	118	01
06.	0521052843	SEED LONG HIGH LINE CSU TITANIUM	93	01
07	0511053254	SHORT FERTILIZER LINE DDD LEFT DC20	119	01
08	0511053255	LONG FERTILIZER LINE DDD RIGHT DC20	120	01
09	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	143	01
10	0501110804	ROD SCARIFIER SPINDLE WIHT POINT	153	01
11	0501110231	SCARIFIER HEAD WITH SPIKE 0061	154	01
12	0511017969	0.1" SPACING PLATE		01
13	0511018662	SPACING PLATE		01
14	0521069124	BOCAL FILLED LINE PIVOTED WITH LINGUET		01
15	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
16	0501010984	FLAT WASHER		01
17	0503010025	3/8" SPRING WASHER		01
18	0503010026	3/8" NUT		01
19	0503030391	RIGHT FERTILIZER NOZZLE		01
20	0503030392	LEFT FERTILIZER NOZZLE		01
21	0503062066	DISC SET WITH CORN RING		01
22	0503062067	DISC SET / RING SOY 90F TITANIUM		01
23	0581015215	STABILIZER BAR E500 PIVOTED HIGH LINE		01
24	0501018652	CORN STABILIZER BAR		01
25	0501013714	STABILIZER BAR		01
26	0581015213	STABILIZER BAR E450		01
27	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01


Item	Code	Description	See page	QT
28	0503010479	BOLT		01
29	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
30	0511017302	FLAT WASHER		01
31	0503010019	1/2" SPRING WASHER		01
32	0503010060	1/2" NUT		01
33	0503031050	CURVED CONDUCTOR		01
34	0503010246	CLAMP		01
35	0571011730	SEED CONDUCTOR 3X1500		01
36	0521050525	FIXER FERTILIZER CONDUCTOR	155	01
37	0503010905	1/2" X 2-1/4" BOLT		01
38	0503010019	1/2" SPRING WASHER		01
39	0503010060	1/2" NUT		01
40	0521044538	DEPHT WHIT REGULACION ANGLE COMPACT 86 CONTROL		




Item	Code	Description	See page	QT
01	0511052971	CONTROL DEPTH WITH SEMI MOUNTED THREAD		01
02	0511052970	SYSTEM COMPACTOR V SEMI MOUNTED		01
03	0501052908	COMPACTOR WHEEL WITH BEARING	152	02
04	0503010019	1/2" SPRING WASHER		06
05	0503010752	1/2" X 3.1/2" BOLT		01
06	0503013739	1/2" X 1" BOLT		01
07	0503010479	BOLT		02
08	0503010060	1/2" NUT		04
09	0503030012	HAIR PIN		01
10	0571013222	FIXING CHOCK		01
11	0503010741	1/2" X 2-3/4" BOLT		02
12	0511055819	DEPTH WHIT AROS BAND		02
13	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
14	0503013816	5/16" LOCKNUT		08




Item	Code	Description	See page	QT
01	0521052847	HIGH LINE PIVOTED SHORT HUB HIGH	98	01
02	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	108	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0521050096	SEED DEPOSIT SYSTEM (CSU)	109	01




Item	Code	Description	See page	QT
01	0521053152	ARM SHORT LINE FERTILIZER WITH DDD LEFT	133	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058619	DISC CUT 20 SHORT LINE	126	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	130	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521052848	HIGH LINE PIVOTED SHORT HUB HIGH	99	01
02	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	108	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0521050096	SEED DEPOSIT SYSTEM (CSU)	109	01




Item	Code	Description	See page	QT
01	0521053151	ARM LONG FERTILIZER LINE WITH DDD RIGHT	134	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058620	DISC CUT 20 LONG LINE	127	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	130	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521052840	SHORT PIVOTING HIGH LINE	141	01
02	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	108	01
03	0521050096	SEED DEPOSIT SYSTEM (CSU)	109	01
04	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
05	0503012412	5/8 UNC SELF LOCKING NUT		02




Item	Code	Description	See page	QT
01	0511056600	FRONT LINE SEED SHORT DDD RIGHT	95	01
02	0511058212	ASSY LINE SUPPORT FERTILIZER	97	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0502012538	SPRING VARON SUPPORT		01
06	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
07	0511017302	FLAT WASHER		02
08	0503011336	1/2" HEX SELF ADJUSTING NUT		02
09	0511060376	SEEP SPRING GUIDE		01
10	0521010542	COUPLING SHAFT		01
11	0503010257	1/8" X 1" COTTERPIN		01
12	0502040534	SPRING GUIDE BUSHING LOCK		01
13	0501018535	1/2 X 1 BOLT		01
14	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
15	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
16	0502040534	SPRING GUIDE BUSHING LOCK		01
17	0501013753	FLAT WASHER		01
18	0501018535	1/2 X 1 BOLT		01
19	0503010013	5/8" NUT		01
20	0511052024	FAST CLOSING SET	102	01
21	0521050096	SEED DEPOSIT SYSTEM (CSU)	109	01
22	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
23	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
24	0511017302	FLAT WASHER		01
25	0503010019	1/2" SPRING WASHER		01
26	0503010060	1/2" NUT		01
27	0503011099	GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521052841	LONG PIVOTANT HIGH LINE	140	01
02	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	108	01
03	0521050096	SEED DEPOSIT SYSTEM (CSU)	109	01
04	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
05	0503012412	5/8 UNC SELF LOCKING NUT		02




Item	Code	Description	See page	QT
01	0511056601	LONG SEED ROW FRONT DDD LEFT	96	01
02	0511058212	ASSY LINE SUPPORT FERTILIZER	97	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0502012538	SPRING VARON SUPPORT		01
06	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
07	0511017302	FLAT WASHER		02
08	0503011336	1/2" HEX SELF ADJUSTING NUT		02
09	0511060376	SEEP SPRING GUIDE		01
10	0521010542	COUPLING SHAFT		01
11	0503010257	1/8" X 1" COTTERPIN		01
12	0502040534	SPRING GUIDE BUSHING LOCK		01
13	0501018535	1/2 X 1 BOLT		01
14	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
15	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
16	0502040534	SPRING GUIDE BUSHING LOCK		01
17	0501013753	FLAT WASHER		01
18	0501018535	1/2 X 1 BOLT		01
19	0503010013	5/8" NUT		01
20	0511052024	FAST CLOSING SET	102	01
21	0521050096	SEED DEPOSIT SYSTEM (CSU)	109	01
22	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
23	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
24	0511017302	FLAT WASHER		01
25	0503010019	1/2" SPRING WASHER		01
26	0503010060	1/2" NUT		01
27	0503011099	GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521062183	SHORT SEED ROW ARM		01
02	0502011830	ARTICULACION SUPPORT		01
03	0521018079	SEEP ROW DRAWBAR COVER		01
04	0503014729	1/4" UNF X 1/2" BOLT		02
05	0503011441	SPRING WASHER		02
06	0503010752	1/2" X 3.1/2" BOLT		02
07	0503011440	SPRING WASHER		02
08	0503010060	1/2" NUT		02
09	0502011561	BEARING SEMI		01
10	0502010426	UPPER BEARING SEMI		02
11	0503010479	BOLT		04
12	0503011440	SPRING WASHER		04
13	0503010060	1/2" NUT		04
14	0501013354	FLAT WASHER		02
15	0502011400	18Z CONICAL GEAR		01
16	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
17	0502011505	18Z CONICAL GEAR		01
18	0521018077	1/2" X 58.6" HEX AXLE		01
19	0501013352	FLAT WASHER		04
20	0503033672	NOZZLE WITHOUT TITANIUM		01
21	0511051693	BASE FIXING SYSTEM	103	01
22	0503015920	3/8" UNC X 1.3/4" BOLT		04
23	0503011443	3/8" SPRING WASHER		04
24	0503010026	3/8" NUT		04
25	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
26	0503011440	SPRING WASHER		02
27	0503010060	1/2" NUT		02
28	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	111	01




Item	Code	Description	See page	QT
01	0521062184	LONG SEED ROW ARM		01
02	0502011830	ARTICULACCION SUPPORT		01
03	0521018079	SEEP ROW DRAWBAR COVER		01
04	0503014729	1/4" UNF X 1/2" BOLT		02
05	0503011441	SPRING WASHER		02
06	0503010752	1/2" X 3.1/2" BOLT		02
07	0503011440	SPRING WASHER		02
08	0503010060	1/2" NUT		02
09	0502011561	BEARING SEMI		01
10	0502010426	UPPER BEARING SEMI		02
11	0503010479	BOLT		04
12	0503011440	SPRING WASHER		04
13	0503010060	1/2" NUT		04
14	0501013354	FLAT WASHER		02
15	0502011400	18Z CONICAL GEAR		01
16	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
17	0502011505	18Z CONICAL GEAR		01
18	0521018078	1/2" X 66.5" HEX AXLE		01
19	0501013352	FLAT WASHER		04
20	0503033672	NOZZLE WITHOUT TITANIUM		01
21	0511051693	BASE FIXING SYSTEM	103	01
22	0503015920	3/8" UNC X 1.3/4" BOLT		04
23	0503011443	3/8" SPRING WASHER		04
24	0503010026	3/8" NUT		04
25	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
26	0503011440	SPRING WASHER		02
27	0503010060	1/2" NUT		02
28	0511056586	15 X 15 SEED DDD LEFT	112	01




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02




Item	Code	Description	See page	QT
01	0521068663	SHORT SEED LINE ARM		01
02	0511059244	ROD SPRING LINE SEED	100	01
03	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	101	01
04	0511052024	FAST CLOSING SET	102	01
05	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
06	0521018077	1/2" X 58.6" HEX AXLE		01
07	0521018079	SEEP ROW DRAWBAR COVER		01
08	0502011830	ARTICULACCION SUPPORT		01
09	1902010426	UPPER BEARING SEMI		02
10	0511051693	BASE FIXING SYSTEM	103	01
11	0501059631	DDD SEED 15" X 15" RIGHT	104	01
12	0503010752	1/2" X 3.1/2" BOLT		02
13	0503011440	SPRING WASHER		08
14	0503010060	1/2" NUT		08
15	1902011561	BEARING SEMI		01
16	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
17	0503014729	1/4" UNF X 1/2" BOLT		02
18	0503011441	SPRING WASHER		02
19	0503010479	BOLT		04
20	0501013352	FLAT WASHER		01
21	0502011505	18Z CONICAL GEAR		01
22	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
23	0501013354	FLAT WASHER		02
24	0502011400	18Z CONICAL GEAR		01
25	0581014526	ELEVATION PLATE 3/8		01
26	0581014527	ELEVATION PLATE 12,5		03
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
28	0503010025	3/8" SPRING WASHER		04
29	0503010026	3/8" NUT		04
30	0503011099	GREASE FITTING		02
31	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521068664	LONG SEED LINE ARM		01
02	0511059244	ROD SPRING LINE SEED	100	01
03	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	101	01
04	0511052024	FAST CLOSING SET	102	01
05	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
06	0521018078	1/2" X 66.5" HEX AXLE		01
07	0521018079	SEEP ROW DRAWBAR COVER		01
08	0502011830	ARTICULACCION SUPPORT		01
09	1902010426	UPPER BEARING SEMI		02
10	0511051693	BASE FIXING SYSTEM	103	01
11	0501059632	DDD SEED 15X15 LEFT	105	01
12	0503010752	1/2" X 3.1/2" BOLT		02
13	0503011440	SPRING WASHER		08
14	0503010060	1/2" NUT		08
15	1902011561	BEARING SEMI		01
16	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
17	0503014729	1/4" UNF X 1/2" BOLT		02
18	0503011441	SPRING WASHER		02
19	0503010479	BOLT		04
20	0501013352	FLAT WASHER		01
21	0502011505	18Z CONICAL GEAR		01
22	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
23	0501013354	FLAT WASHER		02
24	0502011400	18Z CONICAL GEAR		01
25	0581014526	ELEVATION PLATE 3/8		01
26	0581014527	ELEVATION PLATE 12,5		03
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
28	0503010025	3/8" SPRING WASHER		04
29	0503010026	3/8" NUT		04
30	0503011099	GREASE FITTING		02
31	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511060376	SEEP SPRING GUIDE		01
02	0503010834	1/2 X 1 BOLT		02
03	0502040534	SPRING GUIDE BUSHING LOCK		02
04	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
05	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
06	0501013753	FLAT WASHER		01
07	0521010542	COUPLING SHAFT		01
08	0503010257	1/8" X 1" COTTERPIN		01
09	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0502012538	SPRING VARON SUPPORT		01
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
03	0511017302	FLAT WASHER		02
04	0503011336	1/2" HEX SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502011411	10Z CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	BOX DDD ASSY DPL 15 RIGHT	106	01
04	0501054168	BOX DDD ASSY DPL 15 LEFT	107	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	COVER DEPTH		02
07	0503014729	1/4" UNF X 1/2" BOLT		06
08	0503011441	SPRING WASHER		06
09	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503011443	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0511052301	SUPPORT DDD 15 RIGHT	113	01
15A	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
15B	0571012491	SOCKET SEED GUIDE		01
15C	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	BOX DDD ASSY DPL 15 RIGHT	106	01
04	0501054168	BOX DDD ASSY DPL 15 LEFT	107	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	COVER DEPTH		02
07	0503014729	1/4" UNF X 1/2" BOLT		06
08	0503011441	SPRING WASHER		06
09	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503011443	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0511052302	LH SUPPORT DDD GUIDE	114	01
15A	0561015592	LEFT DOUBLE DISC SUPPORT		01
15B	0571012491	SOCKET SEED GUIDE		01
15C	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502011930	DOUBLE DISC COULTER BOX		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019154	RIGHT DOUB DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011930	DOUBLE DISC COULTER BOX		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019148	LEFT DOUBLE DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012823	CUTTING DISC SUPPORT		01
02	0503034318	5/8 UNC X 2 BOLT		02
03	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0521050118	DEPOSIT SEED BOCAL		01
02	0581014295	FIXING GLOVE		01
03	0511052058	SEED SYSTEM TITANIUM	110	01
04	0503010358	5/16" X 5/8" BOLT		05
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		05
06	0503010179	5/16" ZN SPRING WASHER		05
07	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0503062031	BASE SET		01
02	0503062032	NECK TITANIUM ASSY		01
03	0503062033	OPPOSITE BASE SET		01
04	0503062034	CENTRAL ADAPTER SET		01
05	0503062035	SET FALSE ADAPT CENTER		01
06	0503062036	SUBSET ASSY LOCK BASE		01
07	0503062037	SUBSET ESCOVAFLEX ASSY		01
08	0503062038	ASSY ANTI-LEAP		01
09	0503062039	POLIFLOW TITANIUM ASSY		01
10	0503062040	DISPLAY ASSY TITANIUM 1050010		01
11	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
12	0503062042	SET BOLT ARTICULADOR		01
13	0503062043	ASSY LIMIT WEIGHT		01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	113	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	115	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	116	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511015098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O-RING		02
14	0511011927	DUST CLOAK		02




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	114	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	115	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	116	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER		02
08	0503011443	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511015098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0521068566	SHORT FERTILIZER LINE ARM		01
02	0521052838	RIGHT SUPPORT DOC18	121	01
03	0521050168	MOUNTED FERTILIZER CONDUCTOR	125	01
04	0501010066	3/4" X 9" BOLT		01
05	0521017831	SUPPORT SLEEVE SPACER		02
06	0511017232	FLAT WASHER		02
07	0503011255	3/4" LOCK NUT		01
08	0511058619	DISC CUT 20 SHORT LINE	126	01
09	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	130	01
10	0503031145	2" X 2" X 20" HOSE		01
11	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521068565	LONG FERTILIZER LINE ARM		01
02	0521052839	LEFT SUPPORT DOC18	122	01
03	0521050168	MOUNTED FERTILIZER CONDUCTOR	125	01
04	0501010066	3/4" X 9" BOLT		01
05	0521017831	SUPPORT SLEEVE SPACER		02
06	0511017232	FLAT WASHER		02
07	0503011255	3/4" LOCK NUT		01
08	0511058620	DISC CUT 20 LONG LINE	127	01
09	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	130	01
10	0503031145	2" X 2" X 20" HOSE		01
11	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
001	0511053250	SHORT ARM FERTILIZER LINE WITH DDD LEFT	131	01
002	0501010066	3/4" X 9" BOLT		01
003	0521017831	SUPPORT SLEEVE SPACER		02
004	0511017232	FLAT WASHER		02
005	0503011255	3/4" LOCK NUT		01
006	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	137	01
007	0501058423	FERTILIZER ROD SPRING ROW	142	01
008	0503030391	RIGHT FERTILIZER NOZZLE		01
009	0503031145	2" X 2" X 20" HOSE		01
010	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
001	0511053251	ARM LONG FERTILIZER LINE WITH DDD RIGHT	132	01
002	0501010066	3/4" X 9" BOLT		01
003	0521017831	SUPPORT SLEEVE SPACER		02
004	0511017232	FLAT WASHER		02
005	0503011255	3/4" LOCK NUT		01
006	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	138	01
007	0501058423	FERTILIZER ROD SPRING ROW	142	01
008	0503030392	LEFT FERTILIZER NOZZLE		01
009	0503031145	2" X 2" X 20" HOSE		01
010	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521068662	DOC SHORT ARM		01
02	0581011838	SLEVE GUIDES		01
03	0521015376	DUST CLOAK		01
04	0503010878	5/8" SELF ALIGNING NUT		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2" NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503010276	6206 BALL BEARING		01
10	0503030832	FLAT WASHER		01
11	0511059229	BOX WITH DOC 18 TURBO RIGHT	123	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0521068662	DOC SHORT ARM		01
02	0581011838	SLEVE GUIDES		01
03	0521015376	DUST CLOAK		01
04	0503010878	5/8" SELF ALIGNING NUT		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2" NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503010276	6206 BALL BEARING		01
10	0503030832	FLAT WASHER		01
11	0511059230	BOX WITH DOC 18 TURBO LEFT	124	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0502011562	DC BOX		01
02	0503011800	SEAL RING		01
03	0503012417	SEAL		01
04	0503010276	6206 BALL BEARING		01
05	0503030832	FLAT WASHER		01
06	0503011444	SPRING WASHER		06
07	0503010691	1/4" GREASE FITTING		01
08	0503010337	5/16" NUT		06
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0607025032	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0502011562	DC BOX		01
02	0503011800	SEAL RING		01
03	0503012417	SEAL		01
04	0503010276	6206 BALL BEARING		01
05	0503030832	FLAT WASHER		01
06	0503011444	SPRING WASHER		06
07	0503010691	1/4" GREASE FITTING		01
08	0503010337	5/16" NUT		06
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0607025032	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0581013298	SUPPORT		01
02	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
03	0521018517	FLAT WASHER		01
04	0503010060	1/2" NUT		01
05	0503010019	1/2" SPRING WASHER		01
06	0503030483	FERTILIZER SOCKET		01
07	0503031050	CURVED CONDUCTOR		01
08	0503010246	CLAMP		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	WASHER BRACKET AXIS DC PST		01
17	0503034319	LOCK PIN		01
18	0511058648	BOX WITH DISC BLADE 20"	128	01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012824	FIXING SHAFT DISC CUT LINE		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	WASHER BRACKET AXIS DC PST		01
17	0503034319	LOCK PIN		01
18	0511058648	BOX WITH DISC BLADE 20"	128	01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511056909	DISC BOX CUT WITHOUT THE DISC	129	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01




Item	Code	Description	See page	QT
01	0502012793	DC PST		01
02	0571018049	DOOR DUST		02
03	0571018047	AXLE DISC		01
04	0503017755	NUT		01
05	0502020641	BLADE DISC FLANGE		01
06	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
07	0503018441	5/16" X 1-1/4" BOLT		06
08	0503013816	5/16" LOCKNUT		06
09	0503010691	1/4" GREASE FITTING		01
10	0571018048	WASHER		02
11	0521065882	SEAL RING		02
12	0503010816	6207 RS ROLLER BEARING		02
13	0581010575	7/8" X 145 BOLT		01




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK	02	
02	0502012184	FERTILIZER SPRING GUIDE	02	
03	0503031910	1.7" X 22.8" X 0.3" SPRING	01	
04	0502012510	SPRING ROD SUPPORT	01	
05	0521068568	LARGE ELEVATION SPRING FERTILIZER	01	
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN	01	
07	0501018535	1/2 X 1 BOLT	02	
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
09	0503010060	1/2" NUT	02	
10	0502010891	SPRING CHOCK SUPPORT VARON	01	
11	0503010014	3/4" NUT	01	
12	0561014471	COUPLING SHAFT	01	
13	0511017302	FLAT WASHER	01	
14	0503010257	1/8" X 1" COTTERPIN	01	




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503011440	SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	135	01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503011440	SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521061153	LONG ARM FERTILIZER LINE		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	136	01




Item	Code	Description	See page	QT
01	0521068566	SHORT FERTILIZER LINE ARM		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	135	01
07	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0521068565	LONG FERTILIZER LINE ARM		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	136	01
07	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	116	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	115	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503011443	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	115	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	116	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE		01
03	0541018684	FLAT WASHER		01
04	0503010756	0.2" X 2.4" SPRING PIN		01
05	0503010361	SPRING PIN		01
06	0503010003	1845 GREASE FITTING		01
07	0521014137	RIGHT ARM OF THE BLADE DISC		01
08	0521014138	SUPPORT ARM LEFT BALDE DISC		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0503011255	3/4" LOCK NUT		01
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
14	0503011411	1/2" X 5-1/2" BOLT		01
15	0503011440	SPRING WASHER		01
16	0503010060	1/2" NUT		01
17	0502020393	SPRING UPPER SUPPORT		01
18	0502020394	SPRING SUPPORT		01
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
20	0503010014	3/4" NUT		02
21	0501054887	20 BLADE DISC WITH FLAT PLAN DISC	139	01
22	0521015376	DUST CLOAK		02
23	0511015346	FLAT WASHER		06
24	0503011442	3/4" SPRING WASHER		02
25	0521013510	3/4" NUT		02
26	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE		01
03	0541018684	FLAT WASHER		01
04	0503010756	0.2" X 2.4" SPRING PIN		01
05	0503010361	SPRING PIN		01
06	0503010003	1845 GREASE FITTING		01
07	0521014137	RIGHT ARM OF THE BLADE DISC		01
08	0521014138	SUPPORT ARM LEFT BALDE DISC		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0503011255	3/4" LOCK NUT		01
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
14	0503011411	1/2" X 5-1/2" BOLT		01
15	0503011440	SPRING WASHER		01
16	0503010060	1/2" NUT		01
17	0502020393	SPRING UPPER SUPPORT		02
18	0502020394	SPRING SUPPORT		01
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
20	0503010014	3/4" NUT		02
21	0501054887	20 BLADE DISC WITH FLAT PLAN DISC	139	01
22	0521015376	DUST CLOAK		02
23	0511015346	FLAT WASHER		06
24	0503011442	3/4" SPRING WASHER		02
25	0521013510	3/4" NUT		02
26	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02




Item	Code	Description	See page	QT
01	0502011562	DC BOX		01
02	0503010276	6206 BALL BEARING		02
03	0521013610	BLADE DISC HUB AXLE		01
04	0503030832	FLAT WASHER		02
05	0503012417	SEAL		02
06	0503011800	SEAL RING		02
07	0503010691	1/4" GREASE FITTING		01
08	0603027851	20" X 0.2" FLAT PLAIN DISC		01
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0503011444	SPRING WASHER		06
12	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0521068664	LONG SEED LINE ARM		01
02	0511059244	ROD SPRING LINE SEED	100	01
03	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	101	01
04	0511052024	FAST CLOSING SET	102	01
05	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
06	0521018078	1/2" X 66.5" HEX AXLE		01
07	0521018079	SEEP ROW DRAWBAR COVER		01
08	0502011830	ARTICULACCION SUPPORT		01
09	1902010426	UPPER BEARING SEMI		02
10	0511051693	BASE FIXING SYSTEM	103	01
11	0511056586	15 X 15 SEED DDD LEFT	112	01
12	0503010752	1/2" X 3.1/2" BOLT		02
13	0503011440	SPRING WASHER		08
14	0503010060	1/2" NUT		08
15	1902011561	BEARING SEMI		01
16	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
17	0503014729	1/4" UNF X 1/2" BOLT		02
18	0503011441	SPRING WASHER		02
19	0503010479	BOLT		04
20	0501013352	FLAT WASHER		01
21	0502011505	18Z CONICAL GEAR		01
22	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
23	0501013354	FLAT WASHER		02
24	0502011400	18Z CONICAL GEAR		01
25	0581014526	ELEVATION PLATE 3/8		01
26	0581014527	ELEVATION PLATE 12,5		03
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
28	0503010025	3/8" SPRING WASHER		04
29	0503010026	3/8" NUT		04
30	0503011099	GREASE FITTING		02
31	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521068663	SHORT SEED LINE ARM		01
02	0511059244	ROD SPRING LINE SEED	100	01
03	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	101	01
04	0511052024	FAST CLOSING SET	102	01
05	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
06	0521018077	1/2" X 58.6" HEX AXLE		01
07	0521018079	SEEP ROW DRAWBAR COVER		01
08	0502011830	ARTICULACCION SUPPORT		01
09	1902010426	UPPER BEARING SEMI		02
10	0511051693	BASE FIXING SYSTEM	103	01
11	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	111	01
12	0503010752	1/2" X 3.1/2" BOLT		02
13	0503011440	SPRING WASHER		08
14	0503010060	1/2" NUT		08
15	1902011561	BEARING SEMI		01
16	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
17	0503014729	1/4" UNF X 1/2" BOLT		02
18	0503011441	SPRING WASHER		02
19	0503010479	BOLT		04
20	0501013352	FLAT WASHER		01
21	0502011505	18Z CONICAL GEAR		01
22	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
23	0501013354	FLAT WASHER		02
24	0502011400	18Z CONICAL GEAR		01
25	0581014526	ELEVATION PLATE 3/8		01
26	0581014527	ELEVATION PLATE 12,5		03
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
28	0503010025	3/8" SPRING WASHER		04
29	0503010026	3/8" NUT		04
30	0503011099	GREASE FITTING		02
31	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD		01
02	0502040534	SPRING GUIDE BUSHING LOCK		02
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502012510	SPRING ROD SUPPORT		01
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		01
07	0501018535	1/2 X 1 BOLT		02
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
09	0503010060	1/2" NUT		02
10	1902010891	SPRING CHOCK SUPPORT VARON		01
11	0503010014	3/4" NUT		01
12	0561014471	COUPLING SHAFT		01
13	0511017302	FLAT WASHER		01
14	0503010257	1/8" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	144	01
02	0501052538	DEPTH BAND WITH ARMS	149	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	150	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	151	01
07	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	145	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	146	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	148	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	SCREWEW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL BOX	147	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL BOX	147	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	COVER DEPTH		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0511015976	FLAT WASHER		01
05	0503010257	1/8" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503010071	3/16" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	152	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	152	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01



Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER SPINDLE		01
02	1902070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01



Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010365	NUT		02



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

