

ROW CROP PLANTERS

PST TRIO FLEX TITANIUM - FRAME 7450 - CSU - P.1

Code: 0501092695
Series: S-0119
Revision: 00
Date Revision: JULHO/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111260479	PST TRIO FLEX 7450/15E500 ESPECIAL S-0119

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.

INDEX

0909098914	FRAME ASSY	1
0511053196	PST JOINT FRAME	2
0511053188	RIGHT FRAME WITH WHEELED AXLE 7450	3
0511053189	LEFT FRAME WITH WHEELED AXLE 7450	4
0511053190	CENTRAL FRAME WITH WHEELED AXLE 6450/7285/7450/8460	5
0511059232	ASSEMBLY SPRING TRACTION	6
0521058402	WHEELED WITH 655 DRIFT SPRING WITH TRANSMISSION	7
0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	8
0521058401	655 WHEELED SUPPORT WITH TRANSMISSION	9
0521058403	655 WHEELED BRACKET WITHOUT TRANSMISSION	10
0501058241	TENSIONER CHAIN SUPPORT	11
0521058393	WHEEL WITH PNEU 7.00X16 14L PR TT WITH TRANSMISSION	12
0521058394	WHEEL WITH PNEUME	13
0503063172	WHEEL	14
0521055233	WHEELED TRANSMISSION WITHOUT TIRE	15
0521055244	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	16
0521055234	WHEELED FASTENER	17
0521055236	INTERMEDIARY CURRENT STRETCHER	18
0521055237	WHEEL FIXED CURRENT STRETCHER	19
0521055235	WHEEL MOBILE CURRENT STRETCHER	20
0909098915	HEADER FULL ASSEMBLY	21
0511055096	TRACTOR HITCH	22
0521051614	TURNBUCKLE SIDE UPPER	23
0521050133	TURNBUCKLE SIDE 755/480	24
0511059237	3 POINT TURNBUCKLE	25
0521045756	HYDRAULIC CYLINDER	26
0511057653	HYDRAULIC CYLINDER	27
0511059419	HYDRAULIC SYSTEM ASSEMBLY 6850/7285/7450/7860/7960	28
0511059290	VALVE ASSEMBLY	29
0501053835	FEMALE QUICK COUPLER	30
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	31
0521056487	ASSY SILO FERTILIZER P.1 7450	32
0521056484	SUPPORT SILO RIGHT FERTILIZER WITH DISTRIBUTOR P.1 7450	33
0521056485	SILO SUPPORT LEFT FERTILIZER WITH DISTRIBUTOR P.1 7450	34
0521056486	SUPPORT SILO CENTRAL FERTILIZER P.1 7450	35
0511056339	DISTRIBUTOR FERTILIZER SIDE RIGHT STEP 1"	36
0511056338	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 1"	37
0501053788	Q3/4" FASTENER AXLE ASSY	38
0511058249	ASSEMBLY TRANSMISSION 7450	39
0501052560	AXLE MOTOR SLOW-MOVING ASSY	40
0511051434	TRANSMISSION DRIVING ASSY	41
0511047069	SIDE TRANSMISSION DRIVING	42
0511047070	LH SIDE TRANSMISSION DRIVING	43
0521043316	RIGHT GEAR BOX ASSY	44
0521043317	LEFT GEAR BOX ASSY	45
0501058212	SEMI MOUNTED RIGHT CHANGE	46
0501058213	LH GEAR BOX	47
0511059266	CLOSED BEARING	48
0501056271	BEARING CLOSED	49
0501056443	BEARING ASSY GEAR BOX	50
0501056444	BEARING WITH ROLLING	51
0501048790	AXLE WITH LINK ASSY	52



MARCHESAN


INDEX

0501054655	CHAIN TENSIONER ASSY	53
0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	54
0511059261	CHAIN TENSIONER	55
0521055217	LOWER CURRENT STRETCH	56
0501058254	UPPER SEED CHAIN TENSIONER	57
0521055216	BEARING WITH GEAR	58
0521055218	BEARING GEAR WITH DOUBLE	59
0521055214	BEARING GEAR WITH	60
0521055215	DOUBLE TRANSMISSION BEARING	61
0521052672	PLATFORM ASSEMBLY 7450	62
0511058252	HANDLE ASSEMBLY 7450	63
0511054971	RESTING ASSEMBLY	64
0511056536	ASSEMBLY LADDER	65
0909098916	DOUBLE HYDRAULIC MARKER ASSEMBLY 7450	66
0521055204	LIGNE DE DISQUE MARKER	67
0501054649	SEQUENTIAL VALVE ASSY	68
0511058431	HYDRAULIC CYLINDER	69
0521052827	AXIS TRANSMISSION SEED ASSY 7450	70
0511059233	INTERMEDIATE TRANSMISSION	71
0503062206	CARDAN TERMINAL	72
0521052803	REAR LIGHT ASSEMBLY 5750/5850/6450/6850/7285/7450	73
0521052792	MOUNTED REAR LIGHT	74
0521052698	ASSEMBLY CSU C3 SEMI MOUNTED 7285/7450	75
0521052699	ASSEMBLY CSU C3 2BOX 6/5 - 1BOX 7/5 7285/7450	76
0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	77
0521052687	RH SUPPORT TOWER SILO	78
0521051927	TOWER SUPPORT HOPPER	79
0521051931	LH SUPPORT TOWER SILO	80
0521052810	ASSY MANUAL DOOR	81
0909098917	SEED LINE/FERTILIZER ASSEMBLY	82
0521053227	LEFT SHORT SEED ROW FRONT	83
0521053230	SHORT SEED ROW FRONT	84
0521053228	LEFT SHORT SEED ROW FRONT	85
0521053229	SHORT SEED ROW FRONT	86
0521054737	FRONT SEMI MOUNTED LINE LONG LEFT SEED WITHOUT LUBRICATION	87
0521054736	FRONT SEMI MOUNTED ROW LONG RIGHT SEED LINE WITHOUT LUBRICATION	88
0521055213	LINE BEARING SEED	89
0521055223	SEED LINE TRANSMISSION BOX	90
0511055260	SEED ROW CHAIN TENSIONER	91
0521055226	BEARING WITH AXLE JOINT	92
0501059326	UNIVERSAL JOINT AXLE	93
0521055227	BEARING SHAFT HEX	94
0501059363	5/8" HEX AXLE BEARING	95
0521055219	BEARING WITH GEAR 17Z HEX 5/8	96
0521055220	BEARING FRONT LINE SEED	97
0511059333	SEMI-ASSEMBLED MECHANICAL FRAME	98
0511059334	BEARING WITH LONG FRONT AXLE	99
0511058143	UNIVERSAL JOINT AXLE	100
0521054771	LEFT REAR SEAL LINE WITHOUT LUBRICATION	101
0521054770	REAR RIGHT SEED LINE WITHOUT LUBRICATION	102
0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	103
0521054763	DDD LEFT SEED	104
0521054762	RIGHT DDD SEED	105

(OPTIONAL)

INDEX

0511052302	LH SUPPORT DDD GUIDE	106
0511052301	SUPPORT DDD 15 RIGHT	107
0521054761	LEFT LOW CUBE	108
0521054760	DOWN LOW CUBE	109
0521055053	DEEP WHEEL / COMPACTOR SYSTEM	110
0521055065	ASSY DEPTH / COMPACTOR	111
0521055033	COMPACTADOR BODY	112
0521055054	LEFT ARM WITH SLEEVE	113
0521055066	RIGHT ARM WITH GLOVE	114
0521055068	RAYED WHEEL CENTER CLOSED	115
0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	116
0521054990	LEFT COMPACTOR WHEEL	117
0521055017	RIGHT COMPACTOR WHEEL	118
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	119
0521056477	SHORT FERTILIZER LINE DC20 WITHOUT LUBRICATION	120
0521056479	LONG DC20 FERTILIZER LINE WITHOUT LUBRICATION	121
0521056476	DC 20 ASSY	122
0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	123
0521053697	CUTTING DISK BOX	124
0521054769	LEFT FERTILIZER WITH SUPPORT	125
0521054768	DDD RIGHT FERTILIZER WITH SUPPORT	126
0521054765	DDD LEFT FERTILIZER	127
0521054764	DDD RIGHT FERTILIZER	128
0521050096	SEED DEPOSIT SYSTEM (CSU)	129
0511052058	SEED SYSTEM TITANIUM	130
0511052024	FAST CLOSING SET	131
0521053946	SCARING ROD	132
0521050525	FIXER FERTILIZER CONDUCTOR	133
0521057957	FIXED ROD EXTENSION WITH FIXATION	134
0511056736	HOSE SUPPORT	135
0521052796	CYLINDER ASSEMBLY 5750/6850/7860/7960/8460	136
0511058406	HYDRAULIC CYLINDER	137
0521056488	ASSY LABEL MARKER HIDRAULICO/CSU/P.1 - 7450	138



Item	Code	Description	See page	QT
01	0511053196	PST JOINT FRAME	2	01
02	0521064285	LOCK LOWER FRAME		02
03	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		02
04	0503010002	1800 GREASE FITTING		02
05	0503010003	1845 GREASE FITTING		08
06	0503010004	1890 GREASE FITTING		02
07	0511059232	ASSEMBLY SPRING TRACTION	6	02
08	0521058402	WHEELED WITH 655 DRIFT SPRING WITH 7 TRANSMISSION		04
09	0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT 8 TRANSMISSION		02
10	0909098915	HEADER FULL ASSEMBLY	21	01
11	0511059419	HYDRAULIC SYSTEM ASSEMBLY 6850/7285/7450/7860/7960	28	01
12	0521056487	ASSY SILO FERTILIZER P.1 7450	32	01
13	0511058249	ASSEMBLY TRANSMISSION 7450	39	01
14	0521052672	PLATFORM ASSEMBLY 7450	62	01
15	0511058252	HANDLE ASSEMBLY 7450	63	01
16	0511054971	RESTING ASSEMBLY	64	02
17	0511056536	ASSEMBLY LADDER	65	02
18	0909098916	DOUBLE HYDRAULIC MARKER ASSEMBLY 7450	66	01
19	0521052827	AXIS TRANSMISSION SEED ASSY 7450	70	01
20	0521052803	REAR LIGHT ASSEMBLY 5750/5850/6450/6850/7285/7450	73	01
21	0521052698	ASSEMBLY CSU C3 SEMI MOUNTED 7285/7450	75	01
22	0521052810	ASSY MANUAL DOOR	81	01
23	0909098917	SEED LINE/FERTILIZER ASSEMBLY	82	01
24	0541015451	FIXED KEY 2.3/8 X 2.3/4		01
25	0501065677	STRUT		02
26	0501047895	ROD STOP		03
27	0501047885	ROD STOP		03
28	0501047886	ROD STOP		03


FRAME ASSY

0909098914


Item	Code	Description	See page	QT
29	0501047887	ROD STOP		03
30	0511056736	HOSE SUPPORT	135	01
31	0521013022	TRANSPORT LOCK		03
32	0503030168	HAIR PIN		03
33	0501068994	0.3" X 3.1"LOCK PIN		03
34	0521066304	HOSE GUIDE		01
35	0503019262	SOAP DISH VACUUM		01
36	0503010780	N-2050 AMENDMENT		02
37	0503011750	AMENDMENT WITH LOCK		06
38	0503011751	REDUCTION		06
39	0503010951	REDUCTION		04
40	0503010246	CLAMP		15
41	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		02
42	0503013816	5/16" LOCKNUT		02
43	0521052796	CYLINDER ASSEMBLY 5750/6850/7860/7960/8460	136	01
44	0521056488	ASSY LABEL MARKER HIDRAULICO/CSU/P.1 - 7450	138	01

PST JOINT FRAME


0511053196




Item	Code	Description	See page	QT
01	0511053188	RIGHT FRAME WITH WHEELED AXLE 7450	3	01
02	0511053189	LEFT FRAME WITH WHEELED AXLE 7450	4	01
03	0511053190	CENTRAL FRAME WITH WHEELED AXLE 6450/7285/7450/8460	5	01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0503011442	3/4" SPRING WASHER		18
06	0501010098	3/4" UNC BOLT		18
07	0571010094	SLEEVE FLANGE		06
08	0521063912	PIVOT SHAFT		02
09	0571013510	LOCK AXLE		02
10	0503030085	LOCK PIN		02
11	0571010095	FLAT WASHER		02
12	0503010365	NUT		04
13	0503011444	SPRING WASHER		04
14	0502012698	CLAMP		04
15	0501011643	3/8 X 1" BOLT		14
16	0503010025	3/8" SPRING WASHER		14
17	0503010026	3/8" NUT		14
18	0521063003	LOCK PIN		02
19	0571010969	LOCK SLEEVE FRAME		02
20	0503013627	1.1/2 SPRING WASHER		02
21	0501010110	1.1/2" NUT		02
22	0581018018	TROUGH 24 X 50 X 1255		02
23	0581018019	TROUGH 24 X 50 X 1070		02
24	0581015857	GUTTER 24 X 50 X 1080		02




Item	Code	Description	See page	QT
01	0521064009	RIGHT FRAME PST TRIO 15		01
02	0521064023	ARTICLES AXLE RIGHT ROLLED		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521064010	LEFT FRAME PST TRIO 15		01
02	0521064021	ARTICLES AXLE LEFT ROLLED		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521064011	CENTRAL FRAME PST TRIO 15		01
02	0521064022	CENTRAL ARTICLES AXLE ROLLED		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		05
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		10
03	0501012140	FLAT WASHER		10




Item	Code	Description	See page	QT
01	0521058401	655 WHEELED SUPPORT WITH TRANSMISSION	9	01
02	0521055234	WHEELED FASTENER	17	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0521058403	655 WHEELED BRACKET WITHOUT 10 TRANSMISSION	10	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0521061566	CARRYING WHEEL ARM TRACTION		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0501058241	TENSIONER CHAIN SUPPORT	11	01
07	0521058393	WHEEL WITH PNEU 7.00X16 14L PR TT WITH 12 TRANSMISSION		01
08	0503018981	BOLT		02
09	0503010027	5/8" SPRING WASHER		04
10	0591010589	BODY LOCK WHEEL		01
11	0521069983	WHEEL COVER		01
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
13	0551017715	FLAT WASHER		02
14	0503013030	5/8" X 3.1/4" BOLT		01
15	0511050681	TRACTION SPRING		01
15A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
15B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0521061566	CARRYING WHEEL ARM TRACTION		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0503018981	BOLT		02
07	0503010027	5/8" SPRING WASHER		02
08	0591010589	BODY LOCK WHEEL		02
09	0521058394	WHEEL WITH PNEUME	13	01



Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503063172	WHEEL	14	01
02	0521055233	WHEELED TRANSMISSION WITHOUT TIRE	15	01




Item	Code	Description	See page	QT
01	0503063172	WHEEL	14	01
02	0521055244	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	16	01

WHEEL


0503063172



Item	Code	Description	See page	QT
01	0503019458	TIRE 7.00X16 14PR		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0521012185	TRANSM AXLE CARRYING-WHEEL	01	
02	0503010330	KM 9 LOCKNUT	01	
03	0503010329	LOCK WASHER	01	
04	0511015949	LOCK NUT	01	
05	0503010804	00547-B SEAL	02	
06	0503019364	BEARING 25590/25523	02	
07	0501110721	WHEEL HUB WITH SCREW / NUTS	01	
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION	01	
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR	06	
07C	0503016516	5/8 UNF CONIC NUT	06	
08	0502011339	15Z GEAR P 1.25"	01	
09	0503012550	5/16" X 3/4" BOLT	06	
10	0503010002	1800 GREASE FITTING	01	




Item	Code	Description	See page	QT
01	0521012185	TRANSM AXLE CARRYING-WHEEL		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01

WHEELED FASTENER


0521055234




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0521055236	INTERMEDIARY CURRENT STRETCHER	18	01
07	0521055237	WHEEL FIXED CURRENT STRETCHER	19	01
08	0521055235	WHEEL MOBILE CURRENT STRETCHER	20	01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
01A	0503019355	BEARING 6202 2RS1		01
01B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
01C	0502012853	GEAR		01
02	0551018245	CHAIN TENSIONER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0551018239	SLEEVE 19 X 13,50 X 45		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
01A	0503019355	BEARING 6202 2RS1		01
01B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
01C	0502012853	GEAR		01
02	0551018252	CHAIN TIGHTENER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
01A	0503019355	BEARING 6202 2RS1		01
01B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
01C	0502012853	GEAR		01
02	0551018244	CHAIN UPPER AXLE		01
03	0551018240	SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0531060180	FRONT HEADER		01
02	0521067075	INTERMEDIATE HEAD 6450/7285/7350/7450/8460		01
03	0571019949	JUNCTION SHAFT		06
04	0503030119	LOCK PIN		10
05	0511055096	TRACTOR HITCH	22	01
06	0511053179	TRACTOR HITCH AXLE		01
06A	0521064036	TRACTOR HITCH AXLE		01
06B	0503030012	HAIR PIN		01
07	0503014120	CHAIN		01
08	0521051614	TURNBUCKLE SIDE UPPER	23	02
09	0521010571	COUPLING SHAFT		04
10	0503030085	LOCK PIN		06
11	0521050133	TURNBUCKLE SIDE 755/480	24	02
12	0571019951	JUNCTION SHAFT		03
13	0503010523	1/4" X 2" COTTERPIN		04
14	0503034772	BOX		01
15	0521068652	TOOLS BOX SUPPORT		01
16	0501011643	3/8 X 1" BOLT		04
17	0503010025	3/8" SPRING WASHER		04
18	0503010026	3/8" NUT		04
19	0581017000	PLATE INTERMEDIARY		02
20	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		04
21	0503010025	3/8" SPRING WASHER		04
22	0501010984	FLAT WASHER		04
23	0503014321	CABLE STEEL SHACKLE		02
24	0502010584	CARRYING-WHEELS SUPPORT FIXER		08
25	0503016485	BOLT 3/4		16
26	0501010322	FLAT WASHER		32
27	0503010152	3/4" SELF LOCKING NUT		16
28	0521067716	FIXER TUBE		04
29	0511059237	3 POINT TURNBUCKLE	25	01


HEADER FULL ASSEMBLY

0909098915


Item	Code	Description	See page	QT
30	0571019950	COUPLING SHAFT		01
31	0521045756	HYDRAULIC CYLINDER	26	01
32	0521010779	31.75 X 95 COUPLING SHAFT		01
33	0521010581	0.9" X 4.9" COUPLING SHAFT		01
34	0531016049	FLAT WASHER		02
35	0503014820	COROTE BLACK WATER		01
36	0521068651	SUPPORT BOX		01

TRACTOR HITCH


0511055096



Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	COMPRESSION SPRING LEFT		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0502011195	ADJUSTMENT NUT BODY		01
02	0521068096	EXTENSOR R.1.1 / 2 UNC RIGHT		01
03	0521068095	EXTENSOR R.1.1/2 UNC LEFT		01
04	0541018672	COUNTERNUT		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521065193	TURNBUCKLE AXLE		01
02	0521067392	FIXED BRACKET		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0521067393	EXTERNAL SIDE EAR		01
06	0571019949	JUNCTION SHAFT		01
07	0503030119	LOCK PIN		01
08	0503010002	1800 GREASE FITTING		03

3 POINT TURNBUCKLE


0511059237




Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0511061880	SIDE RIGHT RATCHET		01
03	0511061881	RATCHET FOLLOWER		01
04	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
05	0503011179	3/8" X 2-1/4" BOLT		05
06	0503010025	3/8" SPRING WASHER		05
07	0503010026	3/8" NUT		05
08	0503010002	1800 GREASE FITTING		02
09	0531010264	SIDE RATCHET		01
10	0521066919	3-POINT EXTENSOR RIGHT FUSE		01
11	0521066337	LEFT EXTENSOR 3 SPIKE		01



Item	Code	Description	See page	QT
01	0511057653	HYDRAULIC CYLINDER	27	01
02	0501053835	FEMALE QUICK COUPLER	30	02




Item	Code	Description	See page	QT
01	0521066550	CYLINDER CASE		01
02	0521066551	EXTENSION DRAWBAR		01
03	0503010002	1800 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010669	EMBOLUS 63.50 X 40 USAP		01
06	0503018005	RING		01
07	0503010558	7/8" NUT		01
08	0502010471	MOBILE COVER		01
09	0503011058	8-330 BACK-UP RING		01
10	0571019866	RING SUPPORT		01
11	0503010163	D-1500 SCRAPER RING		01
12	0503018004	RING		01
13	0503010161	2-330 N 3006 9B O'RING		01
14	0503018003	GASKET		01
15	0503010605	O'RING		01
16	0581010652	JIC ADAPTER		01




Item	Code	Description	See page	QT
01	0571013472	FIXER BODY VALVE		01
02	0511059290	VALVE ASSEMBLY	29	01
03	0501053835	FEMALE QUICK COUPLER	30	02
04	0501010984	FLAT WASHER		04
05	0531011180	UPPER BODY CLIP		04
06	0521066564	DUCT SEAL OIL		01
07	0531013922	0.6" X 0.8" X 1" SLEEVE		02
08	0503011179	3/8" X 2-1/4" BOLT		02
09	0503010025	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0502012702	BODY SUPPORT CLAMP		12
12	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
13	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	31	04
14	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		04
15	0503010244	7/16" NUT		04
16	0503010180	7/16" SPRING WASHER		08
17	0503010920	1/2" X 1.1/2" BOLT		02
18	0511017302	FLAT WASHER		02
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2" NUT		02
21	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
22	0571017774	SPRING PROTECTION QUICK HOSE		01
23	0511059418	HYDRAULIC SYSTEM HOSE ASSEMBLY		01
23A	0501080406	3/8" X 23" TR-TC HOSE		01
23B	0501080150	HOSE ASSY		01
23C	0501081930	HOSE		01
23D	0501081646	TC-TC HOSE ASSY		03
24	0521052484	HOSE 1/2 X 4122 TM-TM BLACK / RED		01
24A	0501080881	HOSE		01
24B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
24C	0503034495	HYDRAULIC HOSE GRIP (RED)		02


Item	Code	Description	See page	QT
24D	0503018952	PLASTIC BOLT		12
25	0521052485	HOSE 1/2 X 4122 TM-TM BLACK / BLUE		01
25A	0501080881	HOSE		01
25B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
25C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		02
25D	0503018952	PLASTIC BOLT		12




Item	Code	Description	See page	QT
01	0503016524	DIVIDER VALVE		01
02	0581011593	NIPPLE R.1.1/16 UN		01
03	0511010111	7/8" NIPPLE		03
04	0503011109	2-119 N 3006-9B O'RING		01
05	0503010045	O'RING		03



Item	Code	Description	See page	QT
01	0503011883	QUICK CONNECTION COVER		01
02	0503011628	FEMALE QUICK COUPLER		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521056484	SUPPORT SILO RIGHT FERTILIZER WITH 33 DISTRIBUTOR P.1 7450	01	01
02	0521056485	SILO SUPPORT LEFT FERTILIZER WITH 34 DISTRIBUTOR P.1 7450	01	01
03	0521056486	SUPPORT SILO CENTRAL FERTILIZER P.1 7450	35	01
04	0501010984	FLAT WASHER		40
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0503062391	SILO FERTILIZER 05 MOUTHS		02
09	0571019051	FIXER BOX WASHER		26
10	0503013751	3/8 UNC X 1.1/4 BOLT		26
11	0503012535	3/8" SPRING WASHER		26
12	0503012531	3/8" INOX NUT		26
13	0503011957	NYLON LUG		02
14	0503010371	5/16" X 1" BOLT		04
15	0503010179	5/16" ZN SPRING WASHER		08
16	0503010337	5/16" NUT		08
17	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
18	0503011953	5/16" X 1" BOLT		04
19	0551019168	SLEEVE		02
20	0551019160	LEVER		02
21	0551019167	SLEEVE UNION		02
22	0511017302	FLAT WASHER		06
23	0503010479	BOLT		02
24	0503011336	1/2" HEX SELF ADJUSTING NUT		06
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
26	0503010019	1/2" SPRING WASHER		02
27	0503010060	1/2" NUT		02
28	0501013518	FLAT WASHER		06
29	0503010140	1/8" X 3/4" COTTERPIN		06
30	0511069678	LH LOWER LEVER		02


Item	Code	Description	See page	QT
31	0561016468	FASTENER		02
32	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER		02
33	0581012605	GEAR BOX LEVER LOCK		02
34	0521061741	INNTER LEVER		02
35	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER		01
36	0551019159	LEVER FIXER BODY		02
37	0503034396	FERTILIZER SIDE COVER		15
38	0503010362	1/8" X 1.1/4" COTTERPIN		15
39	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		01
40	0521050195	SILO FERTILIZER LEFT SQUARE AXLE		01




Item	Code	Description	See page	QT
01	0521068562	RH FERTILIZER BEAM SUPPORT		01
02	0511056339	DISTRIBUTOR FERTILIZER SIDE RIGHT STEP 1"	36	02
03	0511056338	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 1"	37	03
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0501053788	Q3/4" FASTENER AXLE ASSY	38	01
12	0501110392	SILO SUPPORT BEARING		01
13	0521012485	GEAR BOX BEARING AGRICUTURAL		01
14	0503011953	5/16" X 1" BOLT		02
15	0521011039	FLAT WASHER		02
16	0503010179	5/16" ZN SPRING WASHER		02
17	0503010337	5/16" NUT		02
18	0503010003	1845 GREASE FITTING		01
19	1902010685	18Z CONICAL GEAR		05
20	0503030275	AGRICULTURAL BEARING		05
21	0581016776	SQUARE AXLE 3/4 X 2028		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521068563	LEFT SILO FERTILIZER SUPPORT		01
02	0511056339	DISTRIBUTOR FERTILIZER SIDE RIGHT STEP 1"	36	03
03	0511056338	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 1"	37	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0501053788	Q3/4" FASTENER AXLE ASSY	38	01
12	0501110392	SILO SUPPORT BEARING		01
13	0521012485	GEAR BOX BEARING AGRICUTURAL		01
14	0503011953	5/16" X 1" BOLT		02
15	0521011039	FLAT WASHER		02
16	0503011444	SPRING WASHER		02
17	0503010337	5/16" NUT		02
18	0503010003	1845 GREASE FITTING		01
19	1902010685	18Z CONICAL GEAR		05
20	0503030275	AGRICULTURAL BEARING		05
21	0581016776	SQUARE AXLE 3/4 X 2028		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521068089	SUPPORT CENTRAL SILO FERTILIZER		01
02	0511056339	DISTRIBUTOR FERTILIZER SIDE RIGHT STEP 1"	36	03
03	0511056338	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 1"	37	02
04	0581016973	SQUARE AXLE 3/4 X 790		01
05	0581016950	SQUARE AXLE 3/4 X 1115		01
06	0571019828	LOCK AXLE		02
07	1902010685	18Z CONICAL GEAR		05
08	0503030275	AGRICULTURAL BEARING		05
09	0503013816	5/16" LOCKNUT		04
10	0511062163	FERTILIZER BEAM LOWER COVER		01
11	0501010942	3/8" X 1-1/4" BOLT		24
12	0503010025	3/8" SPRING WASHER		24
13	0503010026	3/8" NUT		24
14	0503010365	NUT		04




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031166	LEFT CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01



Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031159	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511817303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0571014439	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	40	02
15	0511051434	TRANSMISSION DRIVING ASSY	41	04
16	0511047069	SIDE TRANSMISSION DRIVING	42	01
17	0511047070	LH SIDE TRANSMISSION DRIVING	43	01
18	0521043316	RIGHT GEAR BOX ASSY	44	01
19	0521043317	LEFT GEAR BOX ASSY	45	01
20	0503014734	BOLT		06
21	0503010920	1/2" X 1.1/2" BOLT		04
22	0511017302	FLAT WASHER		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2" NUT		10
25	0521064448	GEAR		02
26	0511059261	CHAIN TENSIONER	55	04
27	0521055217	LOWER CURRENT STRETCH	56	02
28	0501058254	UPPER SEED CHAIN TENSIONER	57	02
29	0521055216	BEARING WITH GEAR	58	02
30	0521055218	BEARING GEAR WITH DOUBLE	59	02
31	0521055214	BEARING GEAR WITH	60	02


Item	Code	Description	See page	QT
32	0503012204	40-1 CHAIN X 82 LINK + RED		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	5/16" X 3/4" BOLT		02
03	0503010179	5/16" ZN SPRING WASHER		02
04	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY


0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	46	01
02	0511059266	CLOSED BEARING	48	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	BEARING ASSY GEAR BOX	50	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH LINK ASSY	52	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	53	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	54	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	47	01
02	0511059266	CLOSED BEARING	48	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	BEARING ASSY GEAR BOX	50	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH LINK ASSY	52	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	53	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	54	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0501056271	BEARING CLOSED	49	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	51	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	1 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
05	0503010179	5/16" ZN SPRING WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0503031805	11Z 1/2" GEAR		01
02	0511017302	FLAT WASHER		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER		01
03	0511062169	21Z P 1/2" GEAR		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0521018933	FERT CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501011234	5/8" X 3" BOLT		01
02	0531017086	50 AXLETIGHTENER		01
03	0511062169	21Z P 1/2" GEAR		01
04	0503019356	BEARING 6005 2RS1		01
05	0503011105	SEAL RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0503016460	5/8" X 4.1/2" BOLT		01
02	0551019175	DOUBLE GEAR AXLE		01
03	0503019356	BEARING 6005 2RS1		02
04	0511069680	20Z X 28Z DOBLE GEAR		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511063106	20Z AXLE BEARING DOBLE		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0521055215	DOUBLE TRANSMISSION BEARING	61	01
04	0503010365	NUT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503019356	BEARING 6005 2RS1		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521068580	RIGHT PLATFORM	01	
02	0521068596	CENTRAL PLATFORM	01	
03	0521068588	LEFT PLATFORM	01	
04	0581015863	PLATFORM ENHANCEMENT PROTECTION	02	
05	0501010942	3/8" X 1-1/4" BOLT	04	
06	0501010984	FLAT WASHER	28	
07	0503010025	3/8" SPRING WASHER	16	
08	0503010026	3/8" NUT	16	
09	0521068316	JOINT SUPPORT	06	
10	0503010849	3/8" X 1-1/2" BOLT	12	
11	0521010549	COUPLING SHAFT	06	
12	0503030168	HAIR PIN	06	
13	0503010741	1/2" X 2-3/4" BOLT	06	
14	0503011336	1/2" HEX SELF ADJUSTING NUT	06	
15	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
16	0502012739	PLATFORM LEFT FIXER SUPPORT	02	
17	0503011333	COVER FIXER	03	
18	0503010274	5/32"X 2" COTTERPIN	03	




Item	Code	Description	See page	QT
01	0521064019	SIDE HANDRAIL	02	
02	0521064018	CENTRAL HANDRAIL	01	
03	0503010395	1/2" X 1-1/4" BOLT	04	
04	0503010019	1/2" SPRING WASHER	12	
05	0503010060	1/2" NUT	12	
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	06	
07	0503011082	C1/2" X 1.3/4" SCREW	02	
08	0551019884	45 X 50 X 3/8 FASTENER	08	
09	0571017991	CHAIN FIXER HANDRAIL	08	
10	0503013357	3/8" SELF-ADJUSTING NUT	16	
11	0503034094	22 TWISTED CHAIN	04	



Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0521055204	LIGNE DE DISQUE MARKER	67	02
02	0521061790	1750 TURNBUCKLE		02
03	0511060014	ROW MARKER ARM		02
04	0521012324	1/2" X 3.2"X 2.54" FASTENER		04
05	0511017302	FLAT WASHER		08
06	0503010019	1/2" SPRING WASHER		08
07	0503010060	1/2" NUT		08
08	0503010003	1845 GREASE FITTING		02
09	0511060013	ROW MARKER ARM		02
10	0503010004	1890 GREASE FITTING		02
11	0521011142	1.1/4" X 7.5" AXLE		04
12	0501019435	32 X 50 X 1.5 FLAT WASHER		16
13	0511061022	ROW MARKER SUPPORT		02
14	0511066119	MARKER SUPP FIXER FASTENER		04
15	0502010175	HITCH CLAMP		08
16	0501010216	3/4" X 4-1/2" BOLT		16
17	0503010023	3/4" SPRING WASHER		16
18	0503010014	3/4" NUT		16
19	0503010523	1/4" X 2" COTTERPIN		16
20	0521013347	1.1/4" X 8.4" AXLE		02
21	0521011141	1.1/4" X 6.5" AXLE		02
22	0501054649	SEQUENTIAL VALVE ASSY	68	01
23	0511058431	HYDRAULIC CYLINDER	69	02
24	0511015573	2.07" X 1.6" TRANSPORT LOCK		02
25	0501068994	0.3" X 3.1" LOCK PIN		02
26	0503030168	HAIR PIN		02
27	0511018012	HIDRAULIC ADAPTER		04
28	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	31	02
29	0511057094	HYDRAULIC HOSE MARKER ASSY 6450		01
29A	0501080783	HOSE 3/8 X 5000 TR-TR		02
29B	0501081659	HOSE 3/8 X 5300 TR-TR 2T		02


Item	Code	Description	See page	QT
30	0521052513	HOSE 3/8 X 5200 TC-TM PURPLE / BLUE		01
30A	0501081980	HOSE 3/8 X 5200 TC-TM		01
30B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
30C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
30D	0503018952	PLASTIC BOLT		06
31	0521052512	HOSE 3/8 X 5200 TC-TM PURPLE / RED		01
31A	0501081980	HOSE 3/8 X 5200 TC-TM		01
31B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
31C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
31D	0503018952	PLASTIC BOLT		06
32	0501010617	3/4" NIPPLE		04




Item	Code	Description	See page	QT
01	0521069643	DISC AXLE MARKER LINE		01
02	0602023094	DR16X3 C36AFPAFR73+4FR+4FR D474 10R		01
03	0581019513	DEPTH WHEEL BOX		01
04	0503019342	ROLLER BEARING		01
05	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503013758	1/4" X 1-1/2" BOLT		03
11	0503010143	1/4" SPRING WASHER		03
12	0503010358	5/16" X 5/8" BOLT		04
13	0503010179	5/16" ZN SPRING WASHER		04
14	0503010337	5/16" NUT		04
15	0503034055	CLAMPING RING		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENTIAL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0501067700	2.5" X 25" CYLINDER CASE		01
02	0521066632	EXTENDER		01
03	0503030384	CON PLUG N-001		02
04	0502012837	PISTON		01
05	0503018005	RING		01
06	0503011109	2-119 N 3006-9B O'RING		01
07	0503010163	D-1500 SCRAPER RING		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503018004	RING		01
11	0503018003	GASKET		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0581012154	HEX 5/8 X AXIS 755		01
02	0571013470	5/8 X 1100 HEX AXLE		01
03	0581013813	5/8" X HEX AXLE		02
04	0511059233	INTERMEDIATE TRANSMISSION	71	02
05	0561014215	BEARING COVER LOWER ROW FRAME		02
06	0502040534	SPRING GUIDE BUSHING LOCK		08
07	0501018535	1/2 X 1 BOLT		08



Item	Code	Description	See page	QT
01	0503062206	CARDAN TERMINAL	72	01
02	0503030331	1.2" X 1.2" X 12.2" HOSE		01
03	0503010243	CLAMP		02
04	0503011855	0.2" X 1.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503062206	CARDAN TERMINAL	72	01




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		16
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		03
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	74	03
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		15

MOUNTED REAR LIGHT


0521052792




Item	Code	Description	See page	QT
01	0503018738	LIGHTHOUSE		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	5/16" ZN SPRING WASHER		04
08	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0521052699	ASSEMBLY CSU C3 2BOX 6/5 - 1BOX 7/5 7285/7450	76	01
02	0501010942	3/8" X 1-1/4" BOLT		12
03	0501010984	FLAT WASHER		12
04	0503010025	3/8" SPRING WASHER		12
05	0503010026	3/8" NUT		12
06	0521052687	RH SUPPORT TOWER SILO	78	02
07	0521051931	LH SUPPORT TOWER SILO	80	02
08	0521051927	TOWER SUPPORT HOPPER	79	02




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		06
02	0501010984	FLAT WASHER		06
03	0503010025	3/8" SPRING WASHER		82
04	0503010026	3/8" NUT		82
05	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	77	15
06	0501010942	3/8" X 1-1/4" BOLT		60
07	0571015773	SUPPORT SEED CSU		04
08	0501011643	3/8 X 1"BOLT		16
09	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS		02
10	0503061899	REAR BEAN FERTILIZER ASSY		02
11	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		01
12	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		01




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
09	0503010179	5/16" ZN SPRING WASHER		02
10	0503010337	5/16" NUT		02
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT		01




Item	Code	Description	See page	QT
01	0521066206	RH SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066208	SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02



Item	Code	Description	See page	QT
01	0521066207	LH SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
05	0503010179	5/16" ZN SPRING WASHER		01
06	0503010337	5/16" NUT		01



Item	Code	Description	See page	QT
01	0521053227	LEFT SHORT SEED ROW FRONT	83	01
02	0521053230	SHORT SEED ROW FRONT	84	01
03	0521053228	LEFT SHORT SEED ROW FRONT	85	01
04	0521053229	SHORT SEED ROW FRONT	86	01
05	0521054737	FRONT SEMI MOUNTED LINE LONG LEFT SEED WITHOUT LUBRICATION	87	01
06	0521054736	FRONT SEMI MOUNTED ROW LONG RIGHT SEED LINE WITHOUT LUBRICATION	88	01
07	0511059333	SEMI-ASSEMBLED MECHANICAL FRAME	98	01
08	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		01
09	0503010019	1/2" SPRING WASHER		01
10	0503010060	1/2" NUT		01
11	0521054771	LEFT REAR SEAL LINE WITHOUT LUBRICATION	101	01
12	0521054770	REAR RIGHT SEED LINE WITHOUT LUBRICATION	102	01
13	0521055053	DEEP WHEEL / COMPACTOR SYSTEM	110	01
14	0521056477	SHORT FERTILIZER LINE DC20 WITHOUT LUBRICATION	120	01
15	0521056479	LONG DC20 FERTILIZER LINE WITHOUT LUBRICATION	121	01
16	0521054769	LEFT FERTILIZER WITH SUPPORT	125	01
17	0521054768	DDD RIGHT FERTILIZER WITH SUPPORT	126	01
18	0521050096	SEED DEPOSIT SYSTEM (CSU)	129	01
19	0511052024	FAST CLOSING SET	131	01
20	0521053946	SCARING ROD	132	01
21	0511017969	0.1" SPACING PLATE		01
22	0511018662	SPACING PLATE		01
23	0521069127	BOTTOM NOZZLE FERTILIZER		01
24	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
25	0501010984	FLAT WASHER		04
26	0503010025	3/8" SPRING WASHER		02
27	0503010026	3/8" NUT		02
28	0521050525	FIXER FERTILIZER CONDUCTOR	133	01

Item	Code	Description	See page	QT
29	0571011730	SEED CONDUCTOR 3X1500		01
30	0503030391	RIGHT FERTILIZER NOZZLE		01
31	0503030392	LEFT FERTILIZER NOZZLE		01
32	0503031050	CURVED CONDUCTOR		01
33	0503010246	CLAMP		01
34	0503030483	FERTILIZER SOCKET		01
35	0521057957	FIXED ROD EXTENSION WITH FIXATION	134	01
36	0503031076	2" HOSE CLAMP		01
37	0503031145	2" X 2" X 20" HOSE		01
38	0531013600	PRESS ADJUSTMENT LEVER		01
39	0503062066	DISC SET WITH CORN RING		01
40	0503062067	DISC SET / RING SOY 90F TITANIUM		01
41	0503033672	NOZZLE WITHOUT TITANIUM		01
42	0521018501	TURNBUCKLE LEVER		01
43	0521068982	KEY CASH DISC CUTTING		01
44	0503010905	1/2" X 2-1/4" BOLT		02
45	0503010019	1/2" SPRING WASHER		04
46	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	89	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	90	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	91	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	92	01
20	0521064651	LEFT SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	96	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01
31	0581017624	SPACING SLEEVE		06



Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08

SHORT SEED ROW FRONT

0521053230



Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0521061426	LH SEED ROW SUPPORT FRONT		01
03	0521055213	LINE BEARING SEED	89	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	90	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	91	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	92	01
20	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	96	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01
31	0581017624	SPACING SLEEVE		06




SHORT SEED ROW FRONT

0521053230

Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08

LEFT SHORT SEED ROW FRONT


0521053228



Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	89	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	90	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	91	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	92	01
20	0521064650	LEFT SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	96	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01
31	0581017624	SPACING SLEEVE		06



Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	89	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	90	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	91	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	92	01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	96	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01
31	0581017624	SPACING SLEEVE		06



SHORT SEED ROW FRONT

0521053229

Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0503010045	O'RING		08
03	0521055213	LINE BEARING SEED	89	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	90	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	91	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
20	0521064650	LEFT SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	96	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01



PST TRIO FLEX TITANIUM - FRAME 7450 - CSU - P.1
FRONT SEMI MOUNTED LINE LONG LEFT SEED WITHOUT

Page 87
0521054737

Item	Code	Description	See page	QT
31	0581017624	SPACING SLEEVE		06
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01




Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0503010045	O'RING		08
03	0521055213	LINE BEARING SEED	89	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	90	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	91	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	96	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01




PST TRIO FLEX TITANIUM - FRAME 7450 - CSU - P.1
FRONT SEMI MOUNTED ROW LONG RIGHT SEED LINE

Page 88
0521054736


Item	Code	Description	See page	QT
31	0581017624	SPACING SLEEVE		06
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01




Item	Code	Description	See page	QT
01	0502012718	BEARIN BODY		01
02	0503019355	BEARING 6202 2RS1		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	BOX TRANSMISSION COVER		01
03	0503019361	BEARING 6006 RS1		02
04	0503019363	BEARING 6005		01
05	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503019362	BEARING 6005 RS1		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501059326	UNIVERSAL JOINT AXLE	93	01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0521055227	BEARING SHAFT HEX	94	01




Item	Code	Description	See page	QT
01	0561016322	5/8" HEX AXLE		01
02	0501056296	UNIVERSAL JOINT		01
03	0503011855	0.2" X 1.8" SPRING PIN		02
04	0561014794	350 AXLE HEX		01




Item	Code	Description	See page	QT
01	0501059363	5/8" HEX AXLE BEARING	95	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0561014911	AXLE SLEEVE GUIDES HEX		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		02




Item	Code	Description	See page	QT
01	0502012819	17Z GEAR WITH HEX HOLE		01
02	0521055220	BEARING FRONT LINE SEED	97	01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503019356	BEARING 6005 2RS1		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521066496	FRAME MECHANICAL CENTRAL SEED LINE		01
02	0511059334	BEARING WITH LONG FRONT AXLE	99	01




Item	Code	Description	See page	QT
01	0511058143	UNIVERSAL JOINT AXLE	100	01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0521055227	BEARING SHAFT HEX	94	01




Item	Code	Description	See page	QT
01	0561014794	350 AXLE HEX		01
02	0501056296	UNIVERSAL JOINT		01
03	0503011855	0.2" X 1.8" SPRING PIN		02
04	0581010483	HEX AXLE		01




Item	Code	Description	See page	QT
01	0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	103	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0521054763	DDD LEFT SEED	104	01




Item	Code	Description	See page	QT
01	0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	103	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0521054762	RIGHT DDD SEED	105	01




Item	Code	Description	See page	QT
01	0581019201	CROWN SHAFT		01
02	0503019340	LUBRICANT GLOVE		02
03	0503011030	2-014 N 3006-9B O'RING		02
04	0581019200	CONICA 40Z GEAR		01
05	0581019199	FIXED BASE		01
06	0581019202	PINHAO CONICO 10Z X 5/8		01
07	0501013354	FLAT WASHER		01
08	0503010410	RING		02
09	0503019341	LUBRICANT GLOVE		01




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	106	01
02	0521054761	LEFT LOW CUBE	108	01
03	0521054760	DOWN LOW CUBE	109	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0511015098	FLAT WASHER		04
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	107	01
02	0521054761	LEFT LOW CUBE	108	01
03	0521054760	DOWN LOW CUBE	109	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0511015098	FLAT WASHER		04
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O-RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502012736	HUB LOWR DDD		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012736	HUB LOWR DDD		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0521055065	ASSY DEPTH / COMPACTOR	111	01
02	0521055068	RAYED WHEEL CENTER CLOSED	115	02
03	0521054990	LEFT COMPACTOR WHEEL	117	01
04	0521055017	RIGHT COMPACTOR WHEEL	118	01
05	0503016453	1/2" X 2.1/2 BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010028	1/2" NUT		02




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0571013054	DEPTH CONTROL WHEEL AXLE		01
04	0502012663	EXTENSION		01
05	0501056769	DEPTH WHEELS REGULATOR ASSY		01
06	0503010581	RING		01
07	0521055033	COMPACTADOR BODY	112	01
08	0521055054	LEFT ARM WITH SLEEVE	113	01
09	0521055066	RIGHT ARM WITH GLOVE	114	01
10	0511015346	FLAT WASHER		04
11	0571015974	WASHER		02
12	0511017302	FLAT WASHER		02
13	0503010256	3/8" X 3/4" BOLT		01
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		04
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2" NUT		02
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0581019473	ARTICULATED GLOVE		02
20	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT GLOVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0581019523	LEFT ARM WHEEL DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019524	RIGHT ARM DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	116	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	5/16" ZN SPRING WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0581019522	CASE WHEEL DEPTH WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0503010143	1/4" SPRING WASHER		03
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019529	DEPTH REGULATOR SHAFT		01
11	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	119	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	119	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521065972	LH SHORT ARM ROW FERTILIZER		01
01A	0521065972	LH SHORT ARM ROW FERTILIZER		01
02	0503011255	3/4" LOCK NUT		02
03	0571019062	SLEEVE		01
04	0571019059	SUPPORT WASHER		01
05	0503034320	COMPRESSSION SPRING		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503011854	5/8" X 1-1/4" BOLT		02
08	0511016281	3/4" X 8" BOLT		02
09	0503017960	5/8" X 3-12" BOLT		04
10	0502012813	FLANGE WASHER SPRING		01
11	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
12	0503010417	7/8" NUT		02
13	0502012789	FIXER SUPPORT FERTILIZER ROW		01
14	0521056476	DC 20 ASSY	122	01
15	0503011254	7/8" HEX SELF ADJUSTING NUT		01
16	0591011145	FERTILIZER ROW SUPPORT		01
17	0503019278	LUBRICANT GLOVE		02
18	0591011147	SLEEVE ARM LINE		02
19	0503011109	2-119 N 3006-9B O'RING		02



Item	Code	Description	See page	QT
01	0521065973	RH LONG ARM ROW FERTILIZER		01
01A	0511057271	RH LONG ARM ROW FERTILIZER		01
02	0503011255	3/4" LOCK NUT		02
03	0571019062	SLEEVE		01
04	0571019059	SUPPORT WASHER		01
05	0503034320	COMPRESSSION SPRING		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503011854	5/8" X 1-1/4" BOLT		02
08	0511016281	3/4" X 8" BOLT		02
09	0503017960	5/8" X 3-12" BOLT		04
10	0502012813	FLANGE WASHER SPRING		01
11	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
12	0503010417	7/8" NUT		02
13	0502012789	FIXER SUPPORT FERTILIZER ROW		01
14	0521056476	DC 20 ASSY	122	01
15	0503011254	7/8" HEX SELF ADJUSTING NUT		01
16	0591011146	SUPPORT LONG		01
17	0503019278	LUBRICANT GLOVE		02
18	0591011147	SLEEVE ARM LINE		02
19	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
001	0571019034	FLANGE WASHER AXLE		01
002	0571019032	SUPPORT WASHER		01
003	0502012813	FLANGE WASHER SPRING		01
004	0591010619	DC SPRING SUPPORT		01
005	0503019274	WASHER		02
006	0581017628	COVER		02
007	0503019277	SLEEVE LUBRICATION SYSTEM		01
008	0501110964	RIGHT ARM WITH GLOVE		01
009	0501110965	LEFT ARM WITH GLOVE		01
010	0503034320	COMPRESSION SPRING		01
011	0591010624	GLOVE SUPPORT ARM DC		01
012	0591010625	GLOVE 19,50 X 25 X 91,50 / 91,30		01
013	0503010417	7/8" NUT		02
014	0503010390	SEAL RING		02
015	0503011198	C3/4" X 6" SCREW		01
016	0501010322	FLAT WASHER		01
017	0503011411	1/2" X 5-1/2" BOLT		01
018	0503010060	1/2" NUT		01
019	0503010019	1/2" SPRING WASHER		01
020	0503011255	3/4" LOCK NUT		01
021	0503030430	7/16 X 2" PIN LOCK		01
022	0503019271	SELF LUBRICATING BUSHING		01
023	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	123	01
024	0503011254	7/8" HEX SELF ADJUSTING NUT		01
025	0521066743	REGULACION SPRING		01
026	0591011144	FIXATION AXLE		01
027	0591010628	DC AXIS BACKREST WASHER		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	CUTTING DISK BOX	124	01

CUTTING DISK BOX


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4	01	
02	0502040872	REGULATORY NUT	01	
03	0503010370	502072 CLAMPING RING (FOR AXLE)	02	
04	0503010590	00674-B SEAL	02	
05	0503019285	RING	02	
06	0503012170	30207 ROLLER BEARING	02	
07	0502020641	BLADE DISC FLANGE	01	
08	0502012862	CUTTING DISK BOX	01	
09	0502040873	CUTTING DISC AXLE	01	
10	0503017755	NUT	01	
11	0503018825	5/16 UNC UNC BOLT	06	
12	0501010694	8.5 X 18 X 1.5 FLAT WASHER	06	
13	0503013816	5/16" LOCKNUT	06	
14	0511017907	1/8" BSPT X 6 PLUG	02	




Item	Code	Description	See page	QT
01	0521054765	DDD LEFT FERTILIZER	127	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521054764	DDD RIGHT FERTILIZER	128	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	108	01
03	0521054760	DOWN LOW CUBE	109	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511015098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	108	01
03	0521054760	DOWN LOW CUBE	109	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511015098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01



Item	Code	Description	See page	QT
01	0521050118	DEPOSIT SEED BOCAL		01
02	0581014295	FIXING GLOVE		01
03	0511052058	SEED SYSTEM TITANIUM	130	01
04	0503010358	5/16" X 5/8" BOLT		05
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		05
06	0503010179	5/16" ZN SPRING WASHER		05
07	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0503062031	BASE SET		01
02	0503062032	NECK TITANIUM ASSY		01
03	0503062033	OPPOSITE BASE SET		01
04	0503062034	CENTRAL ADAPTER SET		01
05	0503062035	SET FALSE ADAPT CENTER		01
06	0503062036	SUBSET ASSY LOCK BASE		01
07	0503062037	SUBSET ESCOVAFLEX ASSY		01
08	0503062038	ASSY ANTI-LEAP		01
09	0503062039	POLIFLOW TITANIUM ASSY		01
10	0503062040	DISPLAY ASSY TITANIUM 1050010		01
11	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
12	0503062042	SET BOLT ARTICULADOR		01
13	0503062043	ASSY LIMIT WEIGHT		01




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02

SCARING ROD


0521053946




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502040869	FIXED ROD BEARING		01
03	0503010546	5/16" X 7/8" BOLT		02
04	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010365	NUT		02




Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01



Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	137	03
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521015501	COUPLING SHAFT		03
04	0503010523	1/4" X 2" COTTERPIN		06
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		03
06	0531012565	SLEEVE 16,3X 30 X 88		03
07	0503010027	5/8" SPRING WASHER		03
08	0503010013	5/8" NUT		03
09	0531019171	1.25" X 7" COUPLING SHAFT		01




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O'RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O'RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01



Item	Code	Description	See page	QT
01	0503034382	LABEL ADHESIVE PST TRIO FLEX (04 MOUTHS)		01
02	0503034381	ADHESIVE LABEL PST TRIO FLEX LOWER (05 MOUTH)		02
03	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 MOUTH)		02
04	0503033854	ADHESIVE LABEL		01
05	0503033900	ADHESIVE LABEL		02
06	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
07	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
08	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
09	0503033421	ADHESIVE LABEL 7 NUMBER FOR PLANTING		02
10	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
11	0503033008	ADHESIVE LABEL		02
12	0503031428	READ MANUAL DECAL		01
13	0503031942	ADHESIVE LABEL		01
14	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		02
15	0503031547	ADHESIVE LABEL TABLE FERTILIZER P.1		02
16	0503031565	ADHESIVE LABEL CARE		02
17	0503031566	ADHESIVE LABEL		02
18	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
19	0503031425	ADHESIVE LABEL ATTENTION		02
20	0503031669	ADHESIVE LABEL		01
21	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
22	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
23	0503032930	ADHESIVE LABEL DANGER		08
24	0503031087	ADHESIVE LABEL		01
25	0503034078	LIFTING POINTS DECAL		03
26	0503034003	SERIAL NUMBER TAG 61 X 118		01
27	0503010001	3.2 X 5.5 RIVET		04

Item	Code	Description	See page	QT
28	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
29	0503032979	ADHESIVE LABEL LETTERS A B C D		02
30	0503034500	ADHESIVE LABEL		01



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

