

ROW CROP PLANTERS

PST DUO FLEX SUPREMA P.P - FRAME 5950 - CSU - APT

Code: 0501092711
Series: S-0119
Revision: 00
Date Revision: OUTUBRO/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111250108	PST DUO FLEX SUP PP 5950/12E500 ESPECIAL S-0119
0111250076	PST DUO FLEX SUP PP 5950/13E450 ESPECIAL S-0119

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.

INDEX

0909098923	ASSY FRAME	1
0521054578	FRAME WITH ARTICULATION 5950	2
0521054572	RIGHT FRAME WITH WHEELED AXLE 5950	3
0521054573	FRAME LEFT WITH SHAFT WHEELED 5950	4
0511058667	SPRING FLOW ENSEMBLY	5
0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	6
0521058403	655 WHEELED BRACKET WITHOUT TRANSMISSION	7
0521058394	WHEEL WITH PNEUME	8
0503063172	WHEEL	9
0521055244	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	10
0521054561	CYLINDER ASSEMBLY	11
0511058406	HYDRAULIC CYLINDER	12
0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	13
0501054694	FLOW DIVIDING VALVE ASSY	14
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	15
0909095186	HEADER ASSY	16
0511055096	TRACTOR HITCH	17
0521053310	LEFT EXTENSION HEADER 36.00 - 4880/5720/5950	18
0521053311	RIGHT EXTENSOR HEAD 36,00 - 4880/5720/5950	19
0511052311	3 POINT TURNBUCKLE	20
0511057817	SUPPORT HOSE	21
0521055528	SILO FERTILIZER ASSY 5950 - APT	22
0521055526	SUPPORT RIGHT FERTILIZER WITH DISTRIBUTOR - 5950 APT	23
0521055527	SUPPORT SILO LEFT FERTILIZER WITH DISTRIBUTOR - 5950 APT	24
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	25
0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	26
0521054564	PLATFORM ASSEMBLY 5950	27
0521054568	HANDRAIL ASSY 5950	28
0511058628	ASSEMBLY CSU C3 SEMI MOUNTED 5720/5950	29
0511058802	ASSEMBLY CSU C3 2 BOXES 7B WITH 13 C 5720/6350	30
0511058723	ASSEMBLY CSU C3 SEMI MOUNTED 5950	31
0511058724	ASSEMBLY CSU C3 2BOXES 7/6 12E500	32
0521052687	RH SUPPORT TOWER SILO	33
0521051931	LH SUPPORT TOWER SILO	34
0521051927	TOWER SUPPORT HOPPER	35
0511056789	SEMI MOUNTED HYDRAULIC MARKER 5720/5950	36
0511058449	HYDRAULIC CYLINDER	37
0501054649	SEQUENTIAL VALVE ASSY	38
0511054971	RESTING ASSEMBLY	39
0511056536	ASSEMBLY LADDER	40
0521055204	LIGNE DE DISQUE MARKER	41
0521054582	REAR LIGHTING ASSEMBLY 5720/5950	42
0521052792	MOUNTED REAR LIGHT	43
0521054677	TURBINE ASSEMBLY MTH PP CSU 5950/6350	44
0521054676	TURBINE ASSEMBLY	45
0521050262	RIGHT AIR DISTRIBUTOR	46
0521050263	LEFT AIR DISTRIBUTOR	47
0511059319	AIR FIXING SUPPORT	48
0511059406	TURBINE P.P MOUNTED	49
0521050154	TURBINE P.P WITH HOLE	50
0521052549	CLAMP	51
0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	52
0521054586	ASSY MANUAL DOOR	53



MARCHESAN

INDEX

0521054181	TOOL BOX ASSEMBLY	54
0521054525	CONTAINER WATER TANK	55
0909095190	ASSY HEX AXLE	56
0521055214	BEARING GEAR WITH	57
0521055215	DOUBLE TRANSMISSION BEARING	58
0521055529	LABEL ASSY MH/APT/CSU - 5950	59
0521053616	ASSY ISO MONITORING PLANTING SEED AND FERTILIZER 13L 45/50 4C C/M/E	60
0521058495	ISOBUS SET	61
0511055638	BLOCK FLOW LIMITER	62
0511056974	MOTOR	63
0511056973	PARKER OMP 80 HYDRAULIC MOTOR WITH VALVE	64
0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	65
0511056972	FILTER HYDAC	66
0521051264	MECHANICAL ASSY APT	67
0531052081	APT MECHANICAL ASSY	68
0511054956	SUPPORT WITH HYDRAULIC MOTOR FERTILIZER	69
0501053788	Q3/4" FASTENER AXLE ASSY	70
0521050273	MOTOR SUPPORT SEED	71
0511059348	APT ASSY MODULE BOX	72
0531050765	MODULE BOX	73
0531052052	COVER MOTOR HYDRAULIC	74
0531052053	COVER MOTOR HYDRAULIC	75
0531052049	SEED ENGINE LEFT CHAIN COVER	76
0531052051	COVER MOTOR HYDRAULIC	77
0521055525	HOSE KIT 13L - APT	78
0909098925	ASSY SEED / FERTILIZER LINE	79
0521054739	FRONT LINE SHORT LEFT SEED WITH CARDAN WITHOUT LUBRICATION	80
0521054738	FRONT LINE SHORT RIGHT SEED WITH CARDAN WITHOUT LUBRICATION	81
0521054741	FRONT LINE SEED LONG LEFT WITH CARDAN WITHOUT LUBRICATION	82
0521054740	FRONT LINE LONG RIGHT SEED WITH CARDAN WITHOUT LUBRICATION	83
0521054736	FRONT SEMI MOUNTED ROW LONG RIGHT SEED LINE WITHOUT LUBRICATION	84
0521055213	LINE BEARING SEED	85
0521055223	SEED LINE TRANSMISSION BOX	86
0511055260	SEED ROW CHAIN TENSIONER	87
0521055224	TRANSMISSION CARDAN ASSY	88
0521055225	BEARING DOUBLE FRONT LINE SEED	89
0521055219	BEARING WITH GEAR 17Z HEX 5/8	90
0521055220	BEARING FRONT LINE SEED	91
0521055226	BEARING WITH AXLE JOINT	92
0501059326	UNIVERSAL JOINT AXLE	93
0521055227	BEARING SHAFT HEX	94
0501059363	5/8" HEX AXLE BEARING	95
0521054794	REAR RIGHT SEAL LINE P.P CSU 3 NAC	96
0521054795	REAR LEFT LINE SEED P.P CSU 3 NAC	97
0521054786	DDD RIGHT SEED SUPREME 15 X 15 NAC	98
0521054787	DDD LEFT SUPREME SEED 15 X 15 NAC	99
0521054761	LEFT LOW CUBE	100
0521054760	DOWN LOW CUBE	101
0521055208	ASSEMBLY PRECISION PLANTING V-SET2 CSU 3 CSU SUPREMA P.P	102




MARCHESAN

INDEX

0521055210	LEFT P.P TRANSMISSION BOX	103
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	104
0521054984	DEPTH SYSTEM / COMPACTOR WITHOUT LUBRICATION	105
0521055053	DEEP WHEEL / COMPACTOR SYSTEM	106
0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	107
0501052297	DEPTH WHEELS REGULATOR ASSY	108
0521054987	LEFT ARM WHEEL DEPTH WITH NO LUBRICATION CUBE	109
0521054988	RIGHT ARM ROD DEPTH WITH LUBRICANT-FREE HUB	110
0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	111
0521055033	COMPACTADOR BODY	112
0501052538	DEPTH BAND WITH ARMS	113
0521054990	LEFT COMPACTOR WHEEL	114
0521055017	RIGHT COMPACTOR WHEEL	115
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	116
0521055065	ASSY DEPTH / COMPACTOR	117
0521055068	RAYED WHEEL CENTER CLOSED	118
0511059501	FRAME PRECISION PLANTING SEMI MOUNTED	119
0511052426	TRANSMISSION CARDAN ASSY	120
0511052389	BEARING DOUBLE FRONT ROW SEED	121
0521054811	FERTILIZER SHORT LINE	122
0521054812	LONG FERTILIZER LINE	123
0521054900	FERTILIZER LINE SHORT ASSY DOC20	124
0521054901	LONG FERTILIZER DOC20 ASSY LINE	125
0521054845	DPLO 20 LOW LINE WITHOUT LUBRICATION	126
0521054846	DPLO 20 LONG LINE WITHOUT LUBRICATION CONICAL BEARING	127
0521053231	DPL 20 SHORT LINE WITHOUT LUBRICATION CONICAL BEARING	128
0521053232	DPL 20 LONG LINE WITHOUT LUBRICATION CONICAL BEARING	129
0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	130
0521053697	CUTTING DISK BOX	131
0521054906	SPRING ASSY FERTILIZER	132
0521054768	DDD RIGHT FERTILIZER WITH SUPPORT	133
0521054769	LEFT FERTILIZER WITH SUPPORT	134
0521054764	DDD RIGHT FERTILIZER	135
0521054765	DDD LEFT FERTILIZER	136
0521053946	SCARING ROD	137
0521050525	FIXER FERTILIZER CONDUCTOR	138
0521057957	FIXED ROD EXTENSION WITH FIXATION	139

ASSY FRAME

0909098923




Item	Code	Description	See page	QT
01	0521054578	FRAME WITH ARTICULATION 5950	2	01
02	0521064285	LOCK LOWER FRAME		01
03	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		01
04	0503010002	1800 GREASE FITTING		01
05	0503010003	1845 GREASE FITTING		05
06	0503010004	1890 GREASE FITTING		02
07	0511058667	SPRING FLOW ENSEMBLY	5	01
08	0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	6	06
09	0521054561	CYLINDER ASSEMBLY	11	01
10	0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	13	01
11	0909095186	HEADER ASSY	16	01
12	0511057817	SUPPORT HOSE	21	01
13	0521055528	SILO FERTILIZER ASSY 5950 - APT	22	01
14	0521054564	PLATFORM ASSEMBLY 5950	27	01
15	0521054568	HANDRAIL ASSY 5950	28	01
16	0511058628	ASSEMBLY CSU C3 SEMI MOUNTED 5720/5950	29	01
16.	0511058723	ASSEMBLY CSU C3 SEMI MOUNTED 5950	31	01
17	0511056789	SEMI MOUNTED HYDRAULIC MARKER 5720/5950	36	01
18	0511054971	RESTING ASSEMBLY	39	04
19	0511056536	ASSEMBLY LADDER	40	02
20	0521055204	LIGNE DE DISQUE MARKER	41	02
21	0521054582	REAR LIGHTING ASSEMBLY 5720/5950	42	01
22	0503010023	3/4" SPRING WASHER		02
23	0503010014	3/4" NUT		02
24	0521054677	TURBINE ASSEMBLY MTH PP CSU 5950/6350	44	01
24.	0521054676	TURBINE ASSEMBLY	45	01
25	0521054586	ASSY MANUAL DOOR	53	01
26	0501065677	STRUT		02
27	0541015451	FIXED KEY 2.3/8 X 2.3/4		01
28	0501047895	ROD STOP		02
29	0501047885	ROD STOP		02


ASSY FRAME

0909098923


Item	Code	Description	See page	QT
30	0501047886	ROD STOP		02
31	0501047887	ROD STOP		02
32	0521013022	TRANSPORT LOCK		02
33	0503030168	HAIR PIN		02
34	0501068994	0.3" X 3.1" LOCK PIN		02
35	0521054181	TOOL BOX ASSEMBLY	54	01
36	0521054525	CONTAINER WATER TANK	55	01
37	0503019262	SOAP DISH VACUUM		01
38	0503032624	SILO FERTILIZER GUTTER		07
39	0503010246	CLAMP		13
40	0909095190	ASSY HEX AXLE	56	01
41	0521065613	HOSE HOLDER		01
42	0503011953	5/16" X 1" BOLT		02
43	0503013816	5/16" LOCKNUT		02
44	0521055529	LABEL ASSY MH/APT/CSU - 5950	59	01
45	0521053616	ASSY ISO MONITORING PLANTING SEED AND FERTILIZER 13L 45/50 4C C/M/E	60	01
46	0521051264	MECHANICAL ASSY APT	67	01
47	0521055525	HOSE KIT 13L - APT	78	01
48	0909098925	ASSY SEED / FERTILIZER LINE	79	01
49	0521013164	EXTENSOR		02
50	0501011310	FIXER LOCK		08
51	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
52	0503010019	1/2" SPRING WASHER		02
53	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0521054572	RIGHT FRAME WITH WHEELED AXLE 5950	3	01
02	0521054573	FRAME LEFT WITH SHAFT WHEELED 5950	4	01
03	0501110791	DRIVER WHEEL HUB		01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	NUT		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581018960	TROUGH 24 X 50 X 1855		02
20	0581018961	TROUGH 24 X 50 X 945		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8" SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
01	0521068946	RIGHT FRAME 5950		01
02	0521069430	RIGHT SIDE RIGHT ARTICULATED AXLE 5950		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521068947	LEFT FRAME 5950		01
02	0521069431	LEFT ARTICULATED AXLE 5950		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		06
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		12
03	0501012140	FLAT WASHER		24




Item	Code	Description	See page	QT
01	0521058403	655 WHEELED BRACKET WITHOUT TRANSMISSION	7	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0521061566	CARRYING WHEEL ARM TRACTION		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0503018981	BOLT		02
07	0503010027	5/8" SPRING WASHER		02
08	0591010589	BODY LOCK WHEEL		02
09	0521058394	WHEEL WITH PNEUME	8	01




Item	Code	Description	See page	QT
01	0503063172	WHEEL	9	01
02	0521055244	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	10	01




Item	Code	Description	See page	QT
01	0503019458	TIRE 7.00X16 14PR		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0521012185	TRANSM AXLE CARRYING-WHEEL		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	12	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521015501	COUPLING SHAFT		02
04	0503010523	1/4" X 2" COTTERPIN		04
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
06	0531012565	SLEEVE 16,3X 30 X 88		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01




Item	Code	Description	See page	QT
01	0571017027	SOPORTE VALV		01
02	0503010920	1/2" X 1.1/2" BOLT		02
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0501054694	FLOW DIVIDING VALVE ASSY	14	01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	15	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		02
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057089	HOSE KIT SYSTEM HYDRAULIC		01
19A	0501080045	3/8" X 850 TR-TR HOSE		01
19B	0501080999	3/8" X 39" TC-TC HOSE		01
19C	0501081987	HOSE 3/8 X 1550 TR-TC		01
19D	0501081986	HOSE 3/8 X 1550 TC-TC		01
20	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
20A	0501080185	HOSE 1/2 X 4000 TR-TM		01
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
20C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
20D	0503018952	PLASTIC BOLT		06
21	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
21A	0501080185	HOSE 1/2 X 4000 TR-TM		01
21B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01



Item	Code	Description	See page	QT
21C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0503012481	FLOW DIVIDING VALVE		01
02	0503030923	3/4" UNF X 13/16UN OFS X 40 NIPPLE		03
03	0503010190	2-114 N 3006-9B O'RING		03



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01

HEADER ASSY

0909095186



Item	Code	Description	See page	4880	5340	5950	6350	6850
01	0521068561	LONG COUPLING HEADER		001	001	001	001	001
02	0511055096	TRACTOR HITCH	17	001	001	001	001	001
03	0511053179	TRACTOR HITCH AXLE		001	001	001	001	001
03A	0521064036	TRACTOR HITCH AXLE		001	001	001	001	001
03B	0503030012	HAIR PIN		001	001	001	001	001
04	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		001	001	001	001	001
05	0503014120	CHAIN		001	001	001	001	001
06	0503014321	CABLE STEEL SHACKLE		002	002	002	002	002
07	0571010661	PIVOT SHAFT		001	001	001	001	001
08	0503010010	1/4" X 2.1/2" COTTERPIN		002	002	002	002	002
09	0521064203	EAR PIVOT DRAWBAR		001	001	001	001	001
10	0521053310	LEFT EXTENSION HEADER 36.00 - 4880/5720/5950	18	001	000	001	000	000
10.	0521053313	LEFT EXTENSION HEADER 36.00 - 5340		000	001	000	000	000
10..	0521053320	LEFT EXTENSION HEADER 36.00 - 6350		000	000	000	001	000
10...	0521053318	LEFT EXTENSION HEADER 36.00 - 6850		000	000	000	000	001
11	0501010500	3/4"X3"BOLT		002	002	002	002	002
12	0503010023	3/4" SPRING WASHER		002	002	002	002	002
13	0503010014	3/4" NUT		002	002	002	002	002
14	0571019949	JUNCTION SHAFT		002	002	002	002	002
15	0503030119	LOCK PIN		002	002	002	002	002
16	0521053311	RIGHT EXTENSOR HEAD 36.00 - 4880/5720/5950	19	001	000	001	000	000
16.	0521053312	RIGHT EXTENSOR HEAD 36.00 - 5340		000	001	000	000	000
16..	0521053321	RIGHT EXTENSOR HEAD 36.00 - 6350		000	000	000	001	000
16...	0521053319	RIGHT EXTENSOR HEAD 36.00 - 6850		000	000	000	000	001
17	0521010572	0.9" X 2.9" COUPLING SHAFT		001	001	001	001	001
18	0503030085	LOCK PIN		004	004	004	004	004
19	0521063528	EXTENDING FIXER		001	001	001	001	001
20	0501010171	BOLT 1 UNC X 3.1/2 C S G.5		003	003	003	003	003
21	0503010012	1" SPRING WASHER		003	003	003	003	003
22	0501010059	1.5/8 NUT		003	003	003	003	003
23	0521062916	LEFT FRENCH HAND		001	001	001	001	001




HEADER ASSY

0909095186


Item	Code	Description	See page	4880	5340	5950	6350	6850
24	0521010585	0.9" X 5.9" COUPLING SHAFT		001	001	001	001	001
25	0511052311	3 POINT TURNBUCKLE	20	001	001	001	001	001
26	0521012532	0.9" X 3.9" COUPLING SHAFT		001	001	001	001	001
27	0521010582	COUPLING SHAFT		001	001	001	001	001
28	0521063529	LOCK AXLE		001	001	001	001	001
29	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		001	001	001	001	001

TRACTOR HITCH


0511055096




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	COMPRESSION SPRING LEFT		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0521064426	POINT FIXER EXTENDING LEFT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064425	POINT FIXER EXTENDING RIGHT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0571012279	JACK RIGHT		01
03	0571012280	JACK LEFT		01
04	0531010264	SIDE RATCHET		02
05	0521018500	SHAFT LEVER EXTENSOR		01
06	0511061881	RATCHET FOLLOWER		01
07	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
08	0503011179	3/8" X 2-1/4" BOLT		05
09	0503011443	3/8" SPRING WASHER		05
10	0503010026	3/8" NUT		05
11	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521066302	HOSE HOLDER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0521055526	SUPPORT RIGHT FERTILIZER WITH DISTRIBUTOR - 5950 APT	23	01
02	0521055527	SUPPORT SILO LEFT FERTILIZER WITH DISTRIBUTOR - 5950 APT	24	01
03	0503062362	SILO FERTILIZER 04 MOUTH		02
04	0503062927	SILO FERTILIZER 3 MOUTHS		02
05	0501010984	FLAT WASHER		24
06	0503010025	3/8" SPRING WASHER		12
07	0503010026	3/8" NUT		12
08	0503010849	3/8" X 1-1/2" BOLT		12
09	0571019051	FIXER BOX WASHER		20
10	0503013751	3/8 UNC X 1.1/4 BOLT		20
11	0503012535	3/8" SPRING WASHER		20
12	0503012531	3/8" INOX NUT		20
13	0503011957	NYLON LUG		02
14	0503010371	5/16" X 1" BOLT		04
15	0503010179	5/16" ZN SPRING WASHER		04
16	0503010337	5/16" NUT		04
17	0503034396	FERTILIZER SIDE COVER		12
18	0503010362	1/8" X 1.1/4" COTTERPIN		12




Item	Code	Description	See page	QT
01	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	25	02
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	26	05
03	0501010942	3/8" X 1-1/4" BOLT		28
04	0503011443	3/8" SPRING WASHER		28
05	0503010026	3/8" NUT		28
06	0571019828	LOCK AXLE		01
07	0503010365	NUT		02
08	0501110392	SILO SUPPORT BEARING		01
09	0521012485	GEAR BOX BEARING AGRICUTURAL		01
10	0503011953	5/16" X 1" BOLT		02
11	0521011039	FLAT WASHER		02
12	0503011444	SPRING WASHER		02
13	0503010337	5/16" NUT		02
14	0503010003	1845 GREASE FITTING		01
15	0503030275	AGRICULTURAL BEARING		07
16	0581018930	SQUARE AXLE 3/4 X 2788 - 5950		01
17	0521069410	SUPPORT RIGHT SILO FERTILIZER 5950		01
18	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	25	02
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	26	05
03	0501010942	3/8" X 1-1/4" BOLT		28
04	0503011443	3/8" SPRING WASHER		28
05	0503010026	3/8" NUT		28
06	0571019828	LOCK AXLE		01
07	0503010365	NUT		02
08	0501110392	SILO SUPPORT BEARING		01
09	0521012485	GEAR BOX BEARING AGRICUTURAL		01
10	0503011953	5/16" X 1" BOLT		02
11	0521011039	FLAT WASHER		02
12	0503011444	SPRING WASHER		02
13	0503010337	5/16" NUT		02
14	0503010003	1845 GREASE FITTING		01
15	0503030275	AGRICULTURAL BEARING		07
16	0581018930	SQUARE AXLE 3/4 X 2788 - 5950		01
17	0521069411	LEFT SILO FERTILIZER 5950 SUPPORT		01
18	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0521069418	RIGHT PLATFORM 5950		01
02	0521069423	LEFT PLATFORM 5950		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	FLAT WASHER		18
06	0503010025	3/8" SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	HAIR PIN		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521063175	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8" SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0511058802	ASSEMBLY CSU C3 2 BOXES 7B WITH 13 C 30 5720/6350		01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RH SUPPORT TOWER SILO	33	01
07	0521051931	LH SUPPORT TOWER SILO	34	01
08	0521051927	TOWER SUPPORT HOPPER	35	02




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		04
02	0501010984	FLAT WASHER		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU		13
06	0571015773	SUPPORT SEED CSU		01
07	0501011643	3/8 X 1" BOLT		04
08	0501010942	3/8" X 1-1/4" BOLT		52
09	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0511058724	ASSEMBLY CSU C3 2BOXES 7/6 12E500	32	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521051931	LH SUPPORT TOWER SILO	34	02
07	0521051927	TOWER SUPPORT HOPPER	35	02




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		04
02	0501010984	FLAT WASHER		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU		12
06	0571015773	SUPPORT SEED CSU		02
07	0501011643	3/8 X 1"BOLT		08
08	0501010942	3/8" X 1-1/4" BOLT		48
09	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0521066206	RH SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02



Item	Code	Description	See page	QT
01	0521066207	LH SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066208	SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	37	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	HAIR PIN		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	SEQUENTIAL VALVE ASSY	38	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0511057091	HYDRAULIC MARKER HANDLE SET		01
24A	0501081793	HOSE		01
24B	0501081967	TR-TC HOSE ASSY		01
24C	0501081996	HOSE		01
24D	0501081997	HOSE		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	15	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02

RESTING ASSEMBLY


0511054971




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0521069643	DISC AXLE MARKER LINE		01
02	0602023094	DR16X3 C36AFPAFR73+4FR+4FR D474 10R		01
03	0581019513	DEPTH WHEEL BOX		01
04	0503019342	ROLLER BEARING		01
05	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503013758	1/4" X 1-1/2" BOLT		03
11	0503010143	1/4" SPRING WASHER		03
12	0503010358	5/16" X 5/8" BOLT		04
13	0503010179	5/16" ZN SPRING WASHER		04
14	0503010337	5/16" NUT		04
15	0503034055	CLAMPING RING		01



Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		17mt
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		02
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	43	02
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		14



Item	Code	Description	See page	QT
01	0503018738	LIGHTHOUSE		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	5/16" ZN SPRING WASHER		04
08	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02
02	0501012140	FLAT WASHER		02
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0521066426	TURBINE SUPPORT		01
05	0503011082	C1/2" X 1.3/4" SCREW		01
06	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
07	0503010019	1/2" SPRING WASHER		03
08	0503010060	1/2" NUT		03
09	0561011377	HOSE 4 X 2200		02
10	0503011372	102 TO 121 CLAMP		04
11	0521050262	RIGHT AIR DISTRIBUTOR	46	01
12	0521050263	LEFT AIR DISTRIBUTOR	47	01
13	0511059319	AIR FIXING SUPPORT	48	04
14	0571013731	VACUUM GAUGE SUPPORT		01
15	0503013584	VACUUM GAUGE		01
16	0571019716	ADAPTER		13
17	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		13
18	0503031436	AIR DITRIBUTOR PUMP		01
19	0503010246	CLAMP		01
20	0511059406	TURBINE P.P MOUNTED	49	01
21	0521052549	CLAMP	51	26
22	0511057906	HOSE ASSY		01
22A	0511057840	ASSY TURBINE HOSE REAR		01
22AA	0521052534	HOSE 1/2 X 7012 TC-TM YELLOW / RED		01
22AAA	0501081247	HOSE 1/2 X 7012 TC-TM		01
22AAB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
22AAC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
22AAD	0503018952	PLASTIC BOLT		06
23	0521052535	HOSE 1/2 X 7012 TC-TM YELLOW / BLUE		01
23A	0501081247	HOSE 1/2 X 7012 TC-TM		01
23B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01

Item	Code	Description	See page	QT
23C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
23D	0503018952	PLASTIC BOLT		06
24	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
24A	0501080477	HOSE 3/8 X 7012 TC-TM		01
24B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
24C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
24D	0503018952	PLASTIC BOLT		06
25	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	15	02
26	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
27	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	52	01

TURBINE ASSEMBLY

0521054676




Item	Code	Description	See page	QT
01	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02
02	0501012140	FLAT WASHER		02
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0521066426	TURBINE SUPPORT		01
05	0503011082	C1/2" X 1.3/4" SCREW		01
06	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
07	0503010019	1/2" SPRING WASHER		03
08	0503010060	1/2" NUT		03
09	0561011377	HOSE 4 X 2200		02
10	0503011372	102 TO 121 CLAMP		04
11	0521050262	RIGHT AIR DISTRIBUTOR	46	01
12	0521050263	LEFT AIR DISTRIBUTOR	47	01
13	0511059319	AIR FIXING SUPPORT	48	04
14	0571013731	VACUUM GAUGE SUPPORT		01
15	0503013584	VACUUM GAUGE		01
16	0571019716	ADAPTER		12
17	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		12
18	0503031436	AIR DITRIBUTOR PUMP		02
19	0503010246	CLAMP		02
20	0511059406	TURBINE P.P MOUNTED	49	01
21	0521052549	CLAMP	51	24
22	0511057906	HOSE ASSY		01
22A	0511057840	ASSY TURBINE HOSE REAR		01
22AA	0521052534	HOSE 1/2 X 7012 TC-TM YELLOW / RED		01
22AAA	0501081247	HOSE 1/2 X 7012 TC-TM		01
22AAB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
22AAC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
22AAD	0503018952	PLASTIC BOLT		06
23	0521052535	HOSE 1/2 X 7012 TC-TM YELLOW / BLUE		01
23A	0501081247	HOSE 1/2 X 7012 TC-TM		01
23B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01


TURBINE ASSEMBLY

0521054676


Item	Code	Description	See page	QT
23C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
23D	0503018952	PLASTIC BOLT		06
24	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
24A	0501080477	HOSE 3/8 X 7012 TC-TM		01
24B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
24C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
24D	0503018952	PLASTIC BOLT		06
25	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	15	02
26	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
27	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	52	01




Item	Code	Description	See page	QT
01	0503012566	COVER KAP 110 YELLOW		01
02	0503012856	REBITE POP		14
03	0503031943	SOCKET		07
04	0503017845	PVC KNEE 90 SOLD AVEL		01
05	0571018559	WHITE PVC TUBE		01
06	0581011923	BODY DISTRIBUTOR VACUUM COP		01
07	0521015543	DUTO 110 X 55		01




Item	Code	Description	See page	QT
01	0503012566	COVER KAP 110 YELLOW		01
02	0503012856	REBITE POP		14
03	0503031943	SOCKET		07
04	0503017845	PVC KNEE 90 SOLD AVEL		01
05	0571018559	WHITE PVC TUBE		01
06	0581011923	BODY DISTRIBUTOR VACUUM COP		01
07	0521015543	DUTO 110 X 55		01



Item	Code	Description	See page	QT
01	0571019403	STAPLE FIXER		01
02	0503010025	3/8" SPRING WASHER		04
03	0503010026	3/8" NUT		04
04	0501013518	FLAT WASHER		02
05	0571019921	AIR SUPPORT FIXATION		01
06	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE		01
02	0501011460	7/8 NF REDUCTION NIPPLE		04
03	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
04	0503010392	2-046 N 3006 9B O'RING		01
05	0581012096	ROUND SLEEVE		02
06	0503015420	VALVE ANTI-CAVITACAO CV10208TN5		01
07	0521050154	TURBINE P.P WITH HOLE	50	01
08	0503011372	102 TO 121 CLAMP		02
09	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
10	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
11	0503010143	1/4" SPRING WASHER		02
12	0503010144	1/4" NUT		02
13	0503010190	2-114 N 3006-9B O'RING		04
14	0501081235	1/2 X 650 TR- TC HOSE		01




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01

CLAMP


0521052549




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0503018799	QUICK COUPLING		01
02	0503011883	QUICK CONNECTION COVER		01



Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
05	0503010179	5/16" ZN SPRING WASHER		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
02	0511017302	FLAT WASHER		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0521069295	SUPPORT TOOL CHEST		01
06	0581017000	PLATE INTERMEDIARY		02
07	0503034772	BOX		01
08	0501011643	3/8 X 1"BOLT		04
09	0503010025	3/8" SPRING WASHER		04
10	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
02	0511017302	FLAT WASHER		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0521069405	WATER TANK SUPPORT		01
06	0503014820	COROTE BLACK WATER		01

ASSY HEX AXLE


0909095190



Item	Code	Description	See page	4880	5340	5950	6350	6850
01	0531016944	RIGHT 5/8" X 96" HEX AXLE		001	000	000	000	000
01.	0561019199	5/8" X 2275 AXLE HEX		001	000	000	000	000
02	0571017427	5/8" X 2700 HEX AXLE		000	001	000	000	000
02.	0571017425	5/8" X 2530 HEX AXLE		000	001	000	000	000
03	0561018502	SHAFT AXIS 5/8 X 3000		000	000	001	001	000
03.	0571011980	HEX AXLE		000	000	001	000	000
04	0531016949	LEFT 5/8" X 125" AXLE HEX		000	000	000	001	000
04.	0561018502	SHAFT AXIS 5/8 X 3000		000	000	000	001	000
05	0571017030	SHAFT AXLE 5 / 8X3450 14E500		000	000	000	000	001
05.	0571017029	AXLE HEX		000	000	000	000	001
05..	0571017030	SHAFT AXLE 5 / 8X3450 14E500		000	000	000	000	001
05...	0571017029	AXLE HEX		000	000	000	000	001
06	0561014215	BEARING COVER LOWER ROW FRAME		002	002	002	002	002
07	0521055214	BEARING GEAR WITH	57	002	002	002	002	002
08	0502040534	SPRING GUIDE BUSHING LOCK		004	004	004	004	004
09	0501018535	1/2 X 1 BOLT		004	004	004	004	004




Item	Code	Description	See page	QT
01	0511063106	20Z AXLE BEARING DOBLE		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0521055215	DOUBLE TRANSMISSION BEARING	58	01
04	0503010365	NUT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503019356	BEARING 6005 2RS1		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0503034788	ADHESIVE LABEL		01
02	0503034787	ADHESIVE LABEL		01
03	0503034782	LABEL ADHESIVE LOGO SMALLER TATU (03 MOUTHS)		01
04	0503034114	ADHESIVE LABEL LOGO TATU BOX 190 X 530		01
05	0503033858	ADHESIVE LABEL		01
06	0503033854	ADHESIVE LABEL		01
07	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
08	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		04
09	0503033423	LABEL ADHESIVE NUMBER 9		02
10	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
11	0503031428	READ MANUAL DECAL		01
12	0503031942	ADHESIVE LABEL		01
13	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		01
14	0503031565	ADHESIVE LABEL CARE		02
15	0503031566	ADHESIVE LABEL		02
16	0503031425	ADHESIVE LABEL ATTENTION		02
17	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
18	0503031669	ADHESIVE LABEL		01
19	0503032930	ADHESIVE LABEL DANGER		08
20	0503031087	ADHESIVE LABEL		01
21	0503034078	LIFTING POINTS DECAL		03
22	0503034003	SERIAL NUMBER TAG 61 X 118		01
23	0503010001	3.2 X 5.5 RIVET		04
24	0503034500	ADHESIVE LABEL		01
25	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM		04
26	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM		02
27	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER		01
28	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER		04
29	0503033981	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503062900	KIT ISO 13LINES 45/50 4C C/M/E A E S 010080954		01
01A	0503015065	MASTER CONTROL MODULE		01
01B	0503015066	CABLE CONTROL MASTER MODULE		01
01C	0503015209	MODULES WSMB 18L ISOBUS 4679811100S1		01
01D	0503015210	CABLE MODULO WSMB ISOBUS 467981200		01
01E	0503016029	CONNECTOR CABLE TRACTOR 6M KTATU6,0		01
01F	0503015071	CONCTOR		01
01G	0503015220	ENCODER ISOB 4,5M 464360171S1		04
01H	0503019169	DOUBLE CABLE 4C C/M/E ISOBUS 13L 50 A/S 020011191		01
01I	0503017443	ANTENNA GPS PM 400		01
01J	0503017031	CLEANING BRUSH		01
01K	0503015218	SENSOR FOTOELE PM 400		13
01L	0503018932	FLOW FERTILIZER SENSOR		13
02	0511055638	BLOCK FLOW LIMITER	62	01
03	0511056974	MOTOR	63	02
04	0511056973	PARKER OMP 80 HYDRAULIC MOTOR WITH VALVE	64	02
05	0511056972	FILTER HYDAC	66	01
06	0503017984	LIFT SENSOR		02
07	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		300




Item	Code	Description	See page	QT
01	0503063185	KIT INTELLIAG ISO 4C 12L 45/50 MS		01
01A	0503015065	MASTER CONTROL MODULE		01
01B	0503015066	CABLE CONTROL MASTER MODULE		01
01C	0503015071	CONCTOR		01
01D	0503019840			01
01E	0503017443	ANTENNA GPS PM 400		01
01F	0503017031	CLEANING BRUSH		01
01G	0503015218	SENSOR FOTOELE PM 400		12
01H	0503019685	CABLE ISO CONNECTION TRACTOR 8,0 MT 020011353		01
02	0511056972	FILTER HYDAC	66	01
03	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	65	04
04	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		180
05	0503013100	NYLON CLAMP		60
06	0503019291	SUPPORT SENSOR		01




Item	Code	Description	See page	QT
01	0503014953	LIMITING FLOW PACK		01
02	0503010045	O'RING		02
03	0503011109	2-119 N 3006-9B O'RING		02
04	0501010590	NIPPLE		02
05	0571013917	7/8"NF X 1.1/16 UNF NIPPLE		02




Item	Code	Description	See page	QT
01	0503014364	MOTOR W/ AXLE		01
02	0503016037	VALVE		01
03	0501010590	NIPPLE		02
04	0503010045	O'RING		02
05	0521064025	TRACTOR HITCH		01
06	0503011807	SCREW M8 X 1,25X10		02




Item	Code	Description	See page	QT
01	0503016037	VALVE		01
02	0501010590	NIPPLE		02
03	0503010045	O'RING		02
04	0503016055	MOTOR HYDRAULIC PARKER OMP 80 ISOBUS		01




Item	Code	Description	See page	QT
01	0503018768	MOTOR OMP 80		01
02	0503018769	MOTOR SPEED SENSOR		01
03	0503010045	O'RING		02
04	0503019320	VALVE		01
05	0501010590	NIPPLE		02



Item	Code	Description	See page	QT
01	0503016376	FILTER SPRING		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8"NF UNF NIPPLE		02
04	0503012341	T 7/8" ADAPOR GIRAT NUT		01
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0511054956	SUPPORT WITH HYDRAULIC MOTOR FERTILIZER	69	02
02	0521050273	MOTOR SUPPORT SEED	71	02
03	0581011347	SUPPORT FILTER		01
04	0511059348	APT ASSY MODULE BOX	72	01
05	0521064978	BOX SUPPORT		02
06	0571016237	1/2"UNC X2.1" X1.6" FASTENER ASSY		02
07	0511017302	FLAT WASHER		04
08	0503010019	1/2" SPRING WASHER		04
09	0503010060	1/2" NUT		04
10	0581013257	LIFT SENSOR SUPPORT		02
11	0501011643	3/8 X 1"BOLT		02
12	0503010026	3/8" NUT		02
13	0503010025	3/8" SPRING WASHER		02
14	0501013518	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0591019625	ASSY FILTER SUPPORT		01
02	0531050765	MODULE BOX	73	01
03	0591015026	LIFTING SENSOR DRIVING BODY		01
04	0561016468	FASTENER		01
05	0503011336	1/2" HEX SELF ADJUSTING NUT		02
06	0591015027	SENSOR DRIVER		01
07	0503010282	1/4" X 3/4" BOLT		05
08	0503010144	1/4" NUT		01
09	0503010143	1/4" SPRING WASHER		17
10	0591015101	LIFT SENSOR SUPPORT		01
11	0503013356	RIVET POP 3,2 X 10,0		01
12	0521069832	15Z GEAR		04
13	0561011665	FLAT WASHER		04
14	0503062754	GEAR 34Z P.1/2 APT		02
15	0503011064	40-1 X 51 CHAIN LINK + MENDING		02
16	0511017302	FLAT WASHER		04
17	0503010019	1/2" SPRING WASHER		04
18	0503010060	1/2" NUT		04
19	0531019479	AXLE CHAIN GEAR		04
20	0503030402	PULLEY		04
21	0521065328	20Z GEAR WITH HOLE SHAFT HEX 16.5		02
22	0503012142	40-1 CHAIN X 61 LINK + MENDING		02
23	0521052519	HOSE 1/2 X 4200 TC-TM GRAY / RED		01
23A	0501081073	HOSE 1/2 X 4200 TC-TM		01
23B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
23C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
23D	0503018952	PLASTIC BOLT		06
24	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	15	02
25	0503018033	37 X R.7/8 UNF 90° JIC MALE CONNECTOR WITH ROTATING NUT		04
26	0501080896	HOSE 1/2 X 2300 TC-TC		01
27	0501080062	1/2 X 2000 TR-TC HOSE		02


Item	Code	Description	See page	QT
28	0501080454	1/2 X 170" TR-TR HOSE ASSY		01
29	0521056480	HOSE 1/2 X 5500 TC-TM GRAY / BLUE		01
29A	0501082246	HOSE 1/2 X 5500 TC-TM		01
29B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
29C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
29D	0503018952	PLASTIC BOLT		06
30	0531052052	COVER MOTOR HYDRAULIC	74	01
31	0531052053	COVER MOTOR HYDRAULIC	75	01
32	0531052049	SEED ENGINE LEFT CHAIN COVER	76	01
33	0531052051	COVER MOTOR HYDRAULIC	77	01
34	0503013849	1/4" UNC X 3/4" BOLT		12
35	0503010305	FLAT WASHER		12




Item	Code	Description	See page	QT
01	0521064816	SUPPORT HIDRAULIC MOTOR		01
02	0503031805	1 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0531019479	AXLE CHAIN GEAR		01
07	0503011336	1/2" HEX SELF ADJUSTING NUT		02
08	0503010384	1/2" X 5" BOLT		02
09	0571015808	SUPPORT FIXER		01
10	0503010019	1/2" SPRING WASHER		02
11	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
12	0503010060	1/2" NUT		02
13	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01
14	0501053788	Q3/4" FASTENER AXLE ASSY	70	02
15	0503011321	40-1 CHAIN X 94 LINK + REDUCTION		01
16	0521064025	TRACTOR HITCH		01
17	0503011807	SCREW M8 X 1,25X10		02
18	0571012766	SUPPORT ENCODER		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511817303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0521067490	HYDRAULIC MOTOR SUPPORT APT	01	
02	0503031805	11Z 1/2" GEAR	01	
03	0511017302	FLAT WASHER	01	
04	0503010019	1/2" SPRING WASHER	03	
05	0503010060	1/2" NUT	03	
06	0531019479	AXLE CHAIN GEAR	01	
07	0521065328	20Z GEAR WITH HOLE SHAFT HEX 16.5	01	
08	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN	02	
09	0571012766	SUPPORT ENCODER	01	
10	0521064025	TRACTOR HITCH	01	
11	0503011082	C1/2" X 1.3/4" SCREW	01	
12	0502010175	HITCH CLAMP	01	
13	0503010013	5/8" NUT	02	
14	0503010027	5/8" SPRING WASHER	02	
15	0501011027	5/8" X 3-3/4" BOLT	02	
16	0501011299	FLAT WASHER	02	
17	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	01	
18	0503011807	SCREW M8 X 1,25X10	02	




Item	Code	Description	See page	QT
01	0521066834	CAIXA MODULO		01
02	0503018171	FAST LOCK ASSY		02
03	0521066833	BOX COVER		01
04	0571012006	COVER PIVOT SHAFT		01
05	0571012005	SUPPORT GUIDE ASSY		01
06	0501010694	8.5 X 18 X 1.5 FLAT WASHER		03
07	0503010257	1/8" X 1" COTTERPIN		02
08	0511017303	FLAT WASHER		10
09	0503010298	1/4" X 1/2" BOLT		04
10	0503010143	1/4" SPRING WASHER		10
11	0503010294	1/4" X 7/8" BOLT		06
12	0503010144	1/4" NUT		06
13	0501011643	3/8 X 1" BOLT		04
14	0503010025	3/8" SPRING WASHER		04
15	0501010984	FLAT WASHER		04
16	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0511059348	APT ASSY MODULE BOX	72	01
02	0521064978	BOX SUPPORT		02
03	0571016237	1/2"UNC X2.1" X1.6" FASTENER ASSY		02
04	0511017302	FLAT WASHER		04
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
001	0591019627	COVER MOTOR HYDRAULIC		01
002	0503019412	RIVET SCREW INTERNAL		03




Item	Code	Description	See page	QT
01	0591019626	COVER MOTOR HYDRAULIC		01
02	0503019412	RIVET SCREW INTERNAL		03




Item	Code	Description	See page	QT
01	0591019610	LEFT CHAIN COVER		01
02	0503019412	RIVET SCREW INTERNAL		03



Item	Code	Description	See page	QT
01	0591019607	RIGHT CURRENT COVER		01
02	0503019412	RIVET SCREW INTERNAL		03




Item	Code	Description	See page	QT
01	0501082024	HOSE 1/2 X 450 TR-TC		01
02	0501081209	HOSE 1/2 X 1200 TC-TR 2T		02
03	0521052419	HOSE 1/2 X 4200 TR-TM GRAY / RED		01
03A	0501080933	HOSE 1/2 X 4200 TR-TM		01
03B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
03C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
03D	0503018952	PLASTIC BOLT		06
04	0521052420	HOSE 1/2 X 4200 TR-TM GRAY / BLUE		01
04A	0501080933	HOSE 1/2 X 4200 TR-TM		01
04B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
04C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
04D	0503018952	PLASTIC BOLT		06
05	0501080350	HOSE 1/2 X 4500 TC-TM		01
06	0501082111	HOSE 1/2 X 6500 TC-TC		01



Item	Code	Description	See page	QT
01	0521054739	FRONT LINE SHORT LEFT SEED WITH CARDAN WITHOUT LUBRICATION	80	01
02	0521054738	FRONT LINE SHORT RIGHT SEED WITH CARDAN WITHOUT LUBRICATION	81	01
03	0521054741	FRONT LINE SEED LONG LEFT WITH CARDAN WITHOUT LUBRICATION	82	01
04	0521054740	FRONT LINE LONG RIGHT SEED WITH CARDAN WITHOUT LUBRICATION	83	01
05	0521054736	FRONT SEMI MOUNTED ROW LONG RIGHT SEED LINE WITHOUT LUBRICATION	84	01
06	0521054794	REAR RIGHT SEAL LINE P.P CSU 3 NAC	96	01
07	0521054795	REAR LEFT LINE SEED P.P CSU 3 NAC	97	01
08	0521054984	DEPTH SYSTEM / COMPACTOR WITHOUT LUBRICATION	105	01
08.	0521055053	DEEP WHEEL / COMPACTOR SYSTEM	106	01
09	0511059501	FRAME PRECISION PLANTING SEMI MOUNTED	119	01
10	0521054811	FERTILIZER SHORT LINE	122	01
10.	0521054900	FERTILIZER LINE SHORT ASSY DOC20	124	01
11	0521054812	LONG FERTILIZER LINE	123	01
11.	0521054901	LONG FERTILIZER DOC20 ASSY LINE	125	01
12	0521054768	DDD RIGHT FERTILIZER WITH SUPPORT	133	01
13	0521054769	LEFT FERTILIZER WITH SUPPORT	134	01
14	0521053946	SCARING ROD	137	01
15	0511017969	0.1" SPACING PLATE		01
16	0511018662	SPACING PLATE		01
17	0521069127	BOTTOM NOZZLE FERTILIZER		01
18	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
19	0501010984	FLAT WASHER		01
20	0503010025	3/8" SPRING WASHER		01
21	0503010026	3/8" NUT		01
22	0503030391	RIGHT FERTILIZER NOZZLE		01
23	0503030392	LEFT FERTILIZER NOZZLE		01
24	0503031050	CURVED CONDUCTOR		01

Item	Code	Description	See page	QT
25	0503010246	CLAMP		01
26	0503031145	2" X 2" X 20" HOSE		01
27	0503031076	2" HOSE CLAMP		01
28	0571011730	SEED CONDUCTOR 3X1500		01
29	0521050525	FIXER FERTILIZER CONDUCTOR	138	01
30	0503030483	FERTILIZER SOCKET		01
31	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
32	0531013600	PRESS ADJUSTMENT LEVER		01
33	0521068982	KEY CASH DISC CUTTING		01
34	0521057957	FIXED ROD EXTENSION WITH FIXATION	139	01
35	0503010905	1/2" X 2-1/4" BOLT		02
36	0503010019	1/2" SPRING WASHER		02
37	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0521065847	SHORT TIRE SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	85	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	86	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	87	01
17	0581018487	FIXER UPPER SPRING		01
18	0521055224	TRANSMISSION CARDAN ASSY	88	01
19	0502012782	17Z GEAR WITH HEX HOLE		01
20	0521064651	LEFT SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	90	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01
31	0581017624	SPACING SLEEVE		06



PST DUO FLEX SUPREMA P.P - FRAME 5950 - CSU - APT
FRONT LINE SHORT LEFT SEED WITH CARDAN WITHOUT

Page 80
0521054739

Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0521065847	SHORT TIRE SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	85	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	86	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	87	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	92	01
20	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	90	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01
31	0581017624	SPACING SLEEVE		06



PST DUO FLEX SUPREMA P.P - FRAME 5950 - CSU - APT
FRONT LINE SHORT RIGHT SEED WITH CARDAN WITHOUT

Page 81
0521054738

Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0521065847	SHORT TIRE SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	85	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	86	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	87	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055224	TRANSMISSION CARDAN ASSY	88	01
20	0521064650	LEFT SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	90	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01
31	0581017624	SPACING SLEEVE		06



PST DUO FLEX SUPREMA P.P - FRAME 5950 - CSU - APT
FRONT LINE SEED LONG LEFT WITH CARDAN WITHOUT

Page 82
0521054741

Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0521065847	SHORT TIRE SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	85	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	86	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	87	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055224	TRANSMISSION CARDAN ASSY	88	01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	90	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01
31	0581017624	SPACING SLEEVE		06



PST DUO FLEX SUPREMA P.P - FRAME 5950 - CSU - APT
FRONT LINE LONG RIGHT SEED WITH CARDAN WITHOUT

Page 83
0521054740

Item	Code	Description	See page	QT
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0581017623	LOWER ARM SEED LINE WITHOUT LUBRICATION		01
02	0503010045	O'RING		08
03	0521055213	LINE BEARING SEED	85	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	86	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HAIR PIN		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	87	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	90	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0581017653	ARM SUPPORT LINE SEED WITHOUT LUBRICATION		01




PST DUO FLEX SUPREMA P.P - FRAME 5950 - CSU - APT
FRONT SEMI MOUNTED ROW LONG RIGHT SEED LINE

Page 84
0521054736


Item	Code	Description	See page	QT
31	0581017624	SPACING SLEEVE		06
32	0503019273	SLEEVE		08
33	0581017626	SPACER		01




Item	Code	Description	See page	QT
01	0502012718	BEARIN BODY		01
02	0503019355	BEARING 6202 2RS1		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	BOX TRANSMISSION COVER		01
03	0503019361	BEARING 6006 RS1		02
04	0503019363	BEARING 6005		01
05	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503019362	BEARING 6005 RS1		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551017540	5/8" X 73 AXLE HEX		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0503011855	0.2" X 1.8" SPRING PIN		03
04	0503013958	1/4" X 1" BOLT		02
05	0551017559	BEARING AXLE BODY		01
06	0561014778	HEX UNIVERSAL JOINT		01
07	0571012412	HEX AXLE		01
08	0521055225	BEARING DOUBLE FRONT LINE SEED	89	01
09	0501056296	UNIVERSAL JOINT		01




Item	Code	Description	See page	QT
01	0502011971	HOUSING WITH DOUBLE BEARING		01
02	0503019356	BEARING 6005 2RS1		02
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012819	17Z GEAR WITH HEX HOLE		01
02	0521055220	BEARING FRONT LINE SEED	91	01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503019356	BEARING 6005 2RS1		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501059326	UNIVERSAL JOINT AXLE	93	01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0521055227	BEARING SHAFT HEX	94	01




Item	Code	Description	See page	QT
01	0561016322	5/8" HEX AXLE		01
02	0501056296	UNIVERSAL JOINT		01
03	0503011855	0.2" X 1.8" SPRING PIN		02
04	0561014794	350 AXLE HEX		01




Item	Code	Description	See page	QT
01	0501059363	5/8" HEX AXLE BEARING	95	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0561014911	AXLE SLEEVE GUIDES HEX		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		02




Item	Code	Description	See page	QT
01	0521054786	DDD RIGHT SEED SUPREME 15 X 15 NAC	98	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0521055208	ASSEMBLY PRECISION PLANTING V-SET2 CSU 3 102 CSU SUPREMA P.P		01




Item	Code	Description	See page	QT
01	0521054787	DDD LEFT SUPREME SEED 15 X 15 NAC	99	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0521055208	ASSEMBLY PRECISION PLANTING V-SET2 CSU 3 102 CSU SUPREMA P.P		01




Item	Code	Description	See page	QT
01	0521054761	LEFT LOW CUBE	100	01
02	0521054760	DOWN LOW CUBE	101	01
03	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0502012780	SUPPORT DDD RIGHT		01
06	0511015098	FLAT WASHER		04
07	0503011402	0.2" X 0.8" SPRING PIN		01
08	0503013129	ELASTIC PIN		01
09	0503015081	502052 CLAMPING RING (FOR AXLE)		02
10	0511011927	DUST CLOAK		02
11	0571011152	DOUBLE DISC CAP		02
12	0502012779	PNEUMATIC DRIVING PROTECTOR		01
13	0503014679	2-134 O'RING		02
14	0503034055	CLAMPING RING		02
15	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
16	0501010984	FLAT WASHER		02
17	0503010025	3/8" SPRING WASHER		01
18	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0521054761	LEFT LOW CUBE	100	01
02	0521054760	DOWN LOW CUBE	101	01
03	0503013129	ELASTIC PIN		01
04	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0502012781	SUPPORT DDD LEFT		01
07	0511015098	FLAT WASHER		04
08	0503011402	0.2" X 0.8" SPRING PIN		01
09	0571011152	DOUBLE DISC CAP		02
10	0511011927	DUST CLOAK		02
11	0503015081	502052 CLAMPING RING (FOR AXLE)		02
12	0502012779	PNEUMATIC DRIVING PROTECTOR		01
13	0503014679	2-134 O'RING		02
14	0503034055	CLAMPING RING		02
15	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
16	0501010984	FLAT WASHER		02
17	0503010026	3/8" NUT		01
18	0503010025	3/8" SPRING WASHER		01



Item	Code	Description	See page	QT
01	0502012736	HUB LOWR DDD		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012736	HUB LOWR DDD		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
02	0571017899	PIN LOCK PP		01
03	0503030190	0.5" X 1.6" X 0.05" SPRING		01
04	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
05	0521055210	LEFT P.P TRANSMISSION BOX	103	01
06	0571017894	PIN DRAG PRECISION PLANTING		01
07	0503013357	3/8" SELF-ADJUSTING NUT		01
08	0501013518	FLAT WASHER		02
09	0503015356	SPRING PIN		01
10	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
11	0571017895	PIN FIXER CONDUCTOR P.P		01
12	0503011776	M6 SELF ADJUSTINGNUT		03
13	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
14	0503010293	BAQUELITE MANIPULACION		02
15	0503010140	1/8" X 3/4" COTTERPIN		02
16	0503010131	3/16" X 1-1/2" COTTERPIN		01
17	0503010025	3/8" SPRING WASHER		01
18	0571019491	SLUICE PNEUMATIC PRECISION PLANTING		01
19	0501011643	3/8 X 1"BOLT		01
20	0503010209	3/8" UNC BUTTERFLY NUT		01
21	0502012807	SUPPORT BOX PRECISION PLANTING		01
22	0571019489	CLAMP PRECISION PLANTING		01
23	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
24	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	104	01
25	0561014778	HEX UNIVERSAL JOINT		01
26	0503013958	1/4" X 1" BOLT		02
27	0503011855	0.2" X 1.8" SPRING PIN		01
28	0503012721	1/4" X 4" BOLT		01
29	0503012880	1/4" UNC SELF ADJUSTING NUT		01
30	0571014024	FAST BOLT GUIDE AXLE		01

Item	Code	Description	See page	QT
31	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
32	0503015110	M06 SPRING WASHER		02
33	0503818139	BOLT		03
34	0503037390	PACKING FOR PLANTING		01
35	0503015752	3/8" X 2" BOLT		01
36	0503034824	FIXATIVE		01
37	0581011226	FIXER CLOSING P PLANTING CONTR CPRA		01
38	0503010337	5/16" NUT		04
39	0503010179	5/16" ZN SPRING WASHER		04
40	0503011953	5/16" X 1" BOLT		03
41	0503012163	5/16" X 1-1/2" BOLT		01
42	0521066707	FEEDER		01




Item	Code	Description	See page	QT
01	0502050052	LEFT SIDE TRANSMISSION BOX PP		01
02	0502050053	RIGHT SIDE TRANSMISSION BOX PP		01
03	0503019356	BEARING 6005 2RS1		02
04	0503019367	BEARING 6203 2RS1 NAC		02
05	0503011184	502040 CLAMPING RING (FOR AXLE)		01
06	0571017655	SLEVE FIXER HITCH PNEUMATIC		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
08	0503010144	1/4" NUT		03
09	0511057504	JOIN GEAR		01
09A	0571017898	BODY GEAR TRANSMISSION		01
09B	0503033975	24Z GEAR PNEUMATIC		01
09C	0503011769	M8 X 0.5" BOLT		01
10	0581011222	PINION AXLE 6Z PNEUMATIC		01
11	0503034340	PINION AXLE 6Z PNEUMATIC		01
12	3402510052	GRAXA SHELL STAMINA/RL-2		00




Item	Code	Description	See page	QT
01	0503062405	SEED DISTRIBUTOR		01
01A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
01AA	0503018908	BODY FIXED BASE DISTRIBUTOR SEED		01
01AB	0503018909	COVER CONDUCTOR DISTRIBUTOR SEED		01
01AC	0503062652	SEED INPUT DEFLECTOR		01
01AD	0503062653	FULL COVER		01
01AE	0503018910	RIVETS LARGEST		01
01AF	0503018911	SPACING BUSHING		01
01AG	0503018912	BOLT		03
01AH	0503018476	SPRING		01
01AI	0503018474	LOWER BRUSH		01
01AJ	0503018475	TOP BRUSH		01
01AK	0503018157	RUBBER		01
01AL	0503018477	LOCK SPRING		01
01B	0503062568	FIXER MOBILE		01
01BA	0503018919	BASE		01
01BB	0503018913	RIVET		01
01BC	0503018914	WASHER		01
01BD	0503018915	BEARING		02
01BE	0503062654	BEARING		01
01BF	0503018916	ADJUSTMENT CHOCK		03
01BG	0503018917	RING		01
01BH	0503018918	CHOCK		02
01BI	0503019288	RUBBER SEAL PP 730518		01
01BJ	0503018478	SPRING		01
01BK	0503018920	SEALING		01
01BL	0503018479	TUBE		01
01BM	0503018735	PROTECTIVE COVER		01
01BN	0503018921	BOLT		06
01BO	0503018922	BOLT		02
01BP	0503018480	REGULATOR PIN		01


Item	Code	Description	See page	QT
01BQ	0503018923	ADAPTER		01
01BR	0503018924	SPRING PIN		01
02	0503062417	KIT CORN DISTRIBUTION		01
02A	0503018160	CORN PLASTIC DISC		01
02B	0503062472	SELECTOR SEED CORN		01
02C	0503062474	EJECTOR CORN SEED SET		01
03	0571019613	STRAW PRECISION PLANTING SHIELD		01
03A	0503017957	PROTECTIVE COVER AIR INPUT		01




Item	Code	Description	See page	QT
01	0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	107	01
02	0501052538	DEPTH BAND WITH ARMS	113	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0521054990	LEFT COMPACTOR WHEEL	114	01
06	0521055017	RIGHT COMPACTOR WHEEL	115	01




Item	Code	Description	See page	QT
01	0521055065	ASSY DEPTH / COMPACTOR	117	01
02	0521055068	RAYED WHEEL CENTER CLOSED	118	02
03	0521054990	LEFT COMPACTOR WHEEL	114	01
04	0521055017	RIGHT COMPACTOR WHEEL	115	01
05	0503016453	1/2" X 2.1/2 BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010028	1/2" NUT		02




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	108	01
02	0521054987	LEFT ARM WHEEL DEPTH WITH NO LUBRICATION CUBE	109	01
03	0521054988	RIGHT ARM ROD DEPTH WITH LUBRICANT-FREE HUB	110	01
04	0521055033	COMPACTADOR BODY	112	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	SCREEW 3/8 UNC X 3/4		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED GLOVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0511015976	FLAT WASHER		01
05	0503010257	1/8" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503010071	3/16" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	111	01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	111	01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL BOX		01
02	0581019515	AXIS		01
03	0503034055	CLAMPING RING		01
04	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
05	0503013758	1/4" X 1-1/2" BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0503010878	5/8" SELF ALIGNING NUT		01
10	0503030757	2.9" X 2" X 0.02" JOINT		01
11	0521019178	COVER DEPTH		01




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT GLOVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	116	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	116	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0571013054	DEPTH CONTROL WHEEL AXLE		01
04	0502012663	EXTENSION		01
05	0501056769	DEPTH WHEELS REGULATOR ASSY		01
06	0503010581	RING		01
07	0521055033	COMPACTADOR BODY	112	01
08	0521055054	LEFT ARM WITH SLEEVE		01
09	0521055066	RIGHT ARM WITH GLOVE		01
10	0511015346	FLAT WASHER		04
11	0571015974	WASHER		02
12	0511017302	FLAT WASHER		02
13	0503010256	3/8" X 3/4" BOLT		01
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		04
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2" NUT		02
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0581019473	ARTICULATED GLOVE		02
20	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION		01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	5/16" ZN SPRING WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0521066539	CENTRAL SEED LINE FRAME		01
02	0511052426	TRANSMISSION CARDAN ASSY	120	01




Item	Code	Description	See page	QT
01	0511052389	BEARING DOUBLE FRONT ROW SEED	121	01
02	0551017559	BEARING AXLE BODY		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0551017540	5/8" X 73 AXLE HEX		01
05	0501056296	UNIVERSAL JOINT		01
06	0503011855	0.2" X 1.8" SPRING PIN		03
07	0571012412	HEX AXLE		01
08	0561014778	HEX UNIVERSAL JOINT		01
09	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0502011971	HOUSING WITH DOUBLE BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521066231	SHORT FERTILIZER LINE ARM		01
02	0502012873	SUPPORT DC LINE FERTILIZER		01
03	0502012876	CLAMP		01
04	0503016110	BOLT 5/8 UNC X 4 C S G.7 ZN		02
05	0503012412	5/8 UNC SELF LOCKING NUT		03
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0503019116	BOLT		02
08	0503010013	5/8" NUT		02
09	0521053231	DPL 20 SHORT LINE WITHOUT LUBRICATION 128 CONICAL BEARING		01
10	0521054906	SPRING ASSY FERTILIZER	132	01
11	0501010066	3/4" X 9" BOLT		01
12	0511017232	FLAT WASHER		02
13	0581019195	SIDE GUIDE GLOVE		02
14	0503010410	RING		02
15	0503019278	LUBRICANT GLOVE		02
16	0581019196	CENTRAL GUIDE GLOVE		01
17	0503011255	3/4" LOCK NUT		01




Item	Code	Description	See page	QT
01	0521066230	LONG FERTILIZER LINE ARM		01
02	0502012873	SUPPORT DC LINE FERTILIZER		01
03	0502012876	CLAMP		01
04	0503016110	BOLT 5/8 UNC X 4 C S G.7 ZN		02
05	0503012412	5/8 UNC SELF LOCKING NUT		03
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0503019116	BOLT		02
08	0503010013	5/8" NUT		02
09	0521053232	DPL 20 LONG LINE WITHOUT LUBRICATION 129 CONICAL BEARING		01
10	0521054906	SPRING ASSY FERTILIZER	132	01
11	0501010066	3/4" X 9" BOLT		01
12	0511017232	FLAT WASHER		02
13	0581019195	SIDE GUIDE GLOVE		02
14	0503010410	RING		02
15	0503019278	LUBRICANT GLOVE		02
16	0581019196	CENTRAL GUIDE GLOVE		01
17	0503011255	3/4" LOCK NUT		01




Item	Code	Description	See page	QT
01	0521066231	SHORT FERTILIZER LINE ARM		01
02	0502012873	SUPPORT DC LINE FERTILIZER		01
03	0502012876	CLAMP		01
04	0503017857	BOLT 5/8 UNF 4		03
05	0503010811	5/8\" UNF SELF ADJUSTING NUT		03
06	0503011255	3/4\" LOCK NUT		01
07	0503019116	BOLT		02
08	0503010013	5/8\" NUT		02
09	0521054845	DPLO 20 LOW LINE WITHOUT LUBRICATION	126	01
10	0521054906	SPRING ASSY FERTILIZER	132	01
11	0501010066	3/4\" X 9\" BOLT		01
12	0511017232	FLAT WASHER		02
13	0581019195	SIDE GUIDE GLOVE		02
14	0503010410	RING		02
15	0503019278	LUBRICANT GLOVE		02
16	0581019196	CENTRAL GUIDE GLOVE		01




Item	Code	Description	See page	QT
01	0521066230	LONG FERTILIZER LINE ARM		01
02	0502012873	SUPPORT DC LINE FERTILIZER		01
03	0502012876	CLAMP		01
04	0503017857	BOLT 5/8 UNF 4		03
05	0503010811	5/8\" UNF SELF ADJUSTING NUT		03
06	0503011255	3/4\" LOCK NUT		01
07	0503019116	BOLT		02
08	0503010013	5/8\" NUT		02
09	0521054846	DPLO 20 LONG LINE WITHOUT LUBRICATION 127 CONICAL BEARING		01
10	0521054906	SPRING ASSY FERTILIZER	132	01
11	0501010066	3/4\" X 9\" BOLT		01
12	0511017232	FLAT WASHER		02
13	0581019195	SIDE GUIDE GLOVE		02
14	0503010410	RING		02
15	0503019278	LUBRICANT GLOVE		02
16	0581019196	CENTRAL GUIDE GLOVE		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521054844	DPLO 20 CUTTING DISK BOX		01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521054844	DPLO 20 CUTTING DISK BOX		01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012824	FIXING SHAFT DISC CUT LINE		01



Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	130	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	130	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012824	FIXING SHAFT DISC CUT LINE		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	CUTTING DISK BOX	131	01

CUTTING DISK BOX


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	CUTTING DISK BOX		01
09	0502040873	CUTTING DISC AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02




Item	Code	Description	See page	QT
01	0521067619	TUBE LINE FERTILIZER		01
02	0502012510	SPRING ROD SUPPORT		01
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502040534	SPRING GUIDE BUSHING LOCK		02
06	0501018535	1/2 X 1 BOLT		02
07	0503010014	3/4" NUT		01
08	0502010891	SPRING CHOCK SUPPORT VARON		01
09	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
10	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		02
12	0581013793	PIN LOCK		01
13	0503010577	3/16" X 1-1/4" COTTERPIN		01




Item	Code	Description	See page	QT
01	0521054764	DDD RIGHT FERTILIZER	135	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04



Item	Code	Description	See page	QT
01	0521054765	DDD LEFT FERTILIZER	136	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	100	01
03	0521054760	DOWN LOW CUBE	101	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511015098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	100	01
03	0521054760	DOWN LOW CUBE	101	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511015098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01

SCARING ROD


0521053946




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502040869	FIXED ROD BEARING		01
03	0503010546	5/16" X 7/8" BOLT		02
04	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010365	NUT		02



Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

