

ROW CROP PLANTERS

**PST4 - FRAME 3245/3695/4045/4495/4845/5345
(UP TO 03/2022)**

Code: 0501092717
Series: S-0116
Revision: 00
Date Revision: DEZEMBRO/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111151169	PST4 3245/4E800 MH S-0116
0111151157	PST4 3245/5E700 MH S-0116
0111151165	PST4 3245/6E500 MH DOC20 S-0116
0111151230	PST4 3245/7E450 CI MH DC20 S-0116
0111151147	PST4 3245/7E450 D/HDA S-0116
0111151227	PST4 3245/7E450 H CI MH DC20 S-0116
0111151167	PST4 3245/7E450 H S-0116
0111150243	PST4 3245/7E450 MH S-0116
0111151177	PST4 3695/7E500 CI MH DC20 CBRF S-0116
0111151192	PST4 3695/7E500 CI MH DC20 S-0116
0111151139	PST4 3695/8E450 D CPRA S-0116
0111151172	PST4 4045/6E700 CI MH DC20 S-0116
0111150468	PST4 4045/7E500 MH S-0116
0111151215	PST4 4045/8E500 CI DC20 S-0116
0111151229	PST4 4045/8E500 CI DOC20 S-0116
0111151208	PST4 4045/8E500 CI MH DC20 S-0116
0111151235	PST4 4045/8E500 H CI DC20 CBRF S-0116
0111151137	PST4 4045/8E500 H MM S-0116
0111151152	PST4 4045/8E500 H S-0116
0111151150	PST4 4045/8E500 MH DC20 SPCRR CBRF S-0116
0111151124	PST4 4045/8E500 MH S-0116
0111151141	PST4 4045/8E500 P.1 MH DC20 S-0116
0111151125	PST4 4045/8E500 S-0116
0111151146	PST4 4045/9E450 CPRA HDA S-0116
0111151159	PST4 4045/9E450 D MH S-0116
0111151256	PST4 4045/9E450 D/HDA BF MH DC20 S-0116
0111151130	PST4 4045/9E450 D/HDA S-0116
0111151118	PST4 4045/9E450 DC20 S-0116
0111151207	PST4 4045/9E450 H CI DC20 S-0116
0111151145	PST4 4045/9E450 H MH DC20 S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.

PRODUCTS

0111151122	PST4 4045/9E450 H MM DC20 S-0116
0111151131	PST4 4045/9E450 H S-0116
0111151119	PST4 4045/9E450 HDA S-0116
0111151138	PST4 4045/9E450 IAPAR MH S-0116
0111151144	PST4 4045/9E450 MH DC20 S-0116
0111151129	PST4 4045/9E450 MH S-0116
0111151134	PST4 4045/9E450 RAIAD MH S-0116
0111151142	PST4 4045/9E450 S-0116
0111151261	PST4 4495/10E450 CI DC20 S-0116
0111151234	PST4 4495/10E450 CI MH DC20 S-0116
0111151175	PST4 4495/10E450 D MH S-0116
0111151127	PST4 4495/10E450 H S-0116
0111151148	PST4 4495/10E450 MH DC20 S-0116
0111151198	PST4 4495/8E550 CI MH DC20 S-0116
0111151226	PST4 4495/9E500 CI MH DC20 S-0116
0111151216	PST4 4495/9E500 CI MH S-0116
0111151164	PST4 4495/9E500 DC20 S-0116
0111151184	PST4 4495/9E500 H CI DC20 S-0116
0111151143	PST4 4495/9E500 H MH S-0116
0111151151	PST4 4495/9E500 H S-0116
0111151154	PST4 4495/9E500 MH DC20 S-0116
0111150454	PST4 4495/9E500 MH S-0116
0111151149	PST4 4495/9E500 MM S-0116
0111151176	PST4 4845/10E500 CI H MH DC20 S-0116
0111151170	PST4 4845/10E500 HDA MH DC20 S-0116
0111151123	PST4 4845/10E500 MH DC20 S-0116
0111151210	PST4 4845/11E450 CI DC20 S-0116
0111150456	PST4 4845/11E450 ESPECIAL S-0116
0111151126	PST4 4845/11E450 IAPAR MH S-0116
0111151120	PST4 4845/11E450 MH S-0116
0111151162	PST4 4845/11E450 P.1 D/IAPAR MH DC20 S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.

PRODUCTS



0111151136

PST4 4845/7E700 MH S-0116

0111151241

PST4 5345/12E450 S/D/H MH DC20 S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909098920	ASSY FRAME	1
0501058194	FRAME WITH AXLE WHEEL - 3245	2
0511051956	FRAME WITH AXLE WHEEL - 3695	3
0501058195	FRAME WITH AXLE WHEEL - 4045	4
0511050836	WHEEL AXLE FRAME - 4495	5
0501058196	WHEEL AXLE FRAME - 4845	6
0511051118	WHEEL AXLE FRAME - 5345	7
0511057124	CYLINDER ASSY	8
0511056529	CYLINDER ASSY	9
0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	10
0511058406	HYDRAULIC CYLINDER	11
0521043934	CARRYING WHEELS SPRING TRACTION	12
0501058240	WHEEL FASTENER WITH TENSIONER	13
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	14
0501058244	WHEEL FIXED CHAIN TENSIONER	15
0501058242	WHEEL MOBILE CHAIN TENSIONER	16
0501059909	CARRYING WHEELS SUPPORT	17
0511052770	WHEEL WITH TIRE	18
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	19
0501058241	WHEEL SUPPORT CHAIN TENSIONER	20
0511057493	RIGHT TRANSMISSION ASSY - 3245	21
0511059611	RIGHT TRANSMISSION ASSY - 3695	22
0511058597	RIGHT TRANSMISSION ASSY - 4045	23
0511058970	RIGHT TRANSMISSION ASSY - 4495	24
0511056740	RIGHT TRANSMISSION ASSY - 4880	25
0521050178	RIGHT TRANSMISSION ASSY - 5345	26
0511057346	LEFT TRANSMISSION ASSY - 3245	27
0511059612	LEFT TRANSMISSION ASSY - 3695	28
0511058598	LEFT TRANSMISSION ASSY - 4045	29
0511058971	LEFT TRANSMISSION ASSY - 4495	30
0511056741	LEFT TRANSMISSION ASSEMBLY - 4880	31
0521050179	ASSY TRANSMISSION LEFT - 5345	32
0501052560	MOTOR AXLE SIGNAL	33
0511051434	TRANSMISSION ACTUATOR	34
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	35
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	36
0521043316	RIGHT GEAR BOX ASSY	37
0521043317	LEFT GEAR BOX ASSY	38
0501058212	SEMI MOUNTED RIGHT CHANGE	39
0501058213	LH GEAR BOX	40
0511059266	CLOSED BEARING	41
0501056443	GEAR HOUSING BEARING	42
0501056444	BEARING WITH ROLLING	43
0501048790	AXLE WITH RING	44
0501054655	CHAIN TENSIONER ASSY	45
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	46
0511054363	CHAIN TENSIONER	47
0501058234	LOWER CHAIN TENSIONER	48
0501058235	STRETCHER CURRENT TOP SEED 17Z	49
0501058236	BEARING WITH 21Z GEAR	50
0501058237	16Z GEAR BEARING	51
0501055112	MICRO GRANULATED CHAIN TENSIONER	52
0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	53
0511057146	HYDRAULIC SYSTEM ASSY - 4845/5345	54
0501053834	MALE QUICK COUPLER	55



MARCHESAN

INDEX

0501058165	SEMI-ASSEMBLED HYDRAULIC MARKER 3245/7	56
0511052482	SEMI-ASSEMBLED HYDRAULIC MARKER 3695	57
0501058170	SEMI-ASSEMBLED HYDRAULIC MARKER 4045/9	58
0501058169	SEMI-ASSEMBLED MECHANICAL MARKER 4045/9	59
0511050854	MECANIC ROW MARK 4495/9	60
0511050838	SEMI-ASSEMBLED HYDRAULIC MARKER 4495	61
0501058172	SEMI-ASSEMBLED HYDRAULIC MARKER 4845/11	62
0511051119	SEMI-ASSEMBLED HYDRAULIC MARKER 5345	63
0511058449	HYDRAULIC CYLINDER	64
0501054649	HBM SEQUENTIAL VALVE	65
0511057095	HYDRAULIC MARKER HOSE KIT	66
0501050633	ROW MARKER DISK ASSEMBLY	67
0511057235	SET SUPPORT RIGHT LEFT	68
0511058317	RIGHT/LEFT SUPPORT BOX ASSEMBLY ASSY 8	69
0511057128	SET SUPPORT RIGHT LEFT	70
0511057564	SET SUPPORT RIGHT LEFT	71
0511057147	ASSEMBLY SUPPORT RIGHT/LEFT BOX FERTILIZER	72
0511058311	RIGHT / LEFT SUPPORT BOX ASSEMBLY ASSY 12	73
0511051968	RIGHT SILO SUPPORT WITH DISTRIBUTOR 8	74
0511051969	LEFT SILO SUPPORT WITH DISTRIBUTOR 8	75
0511053240	RIGHT SILO SUPPORT WITH DISTRIBUTOR 10	76
0511053241	LEFT SILO SUPPORT WITH DISTRIBUTOR 10	77
0501058206	RIGHT SILO SUPPORT WITH DISTRIBUTOR 11	78
0501058207	LEFT SILO SUPPORT WITH DISTRIBUTOR 11	79
0511051120	RIGHT BEAM SUPPORT WITH DISTRIBUTOR 12	80
0511051121	LEFT BEAM SUPPORT WITH DISTRIBUTOR 12	81
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	82
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	83
0501053788	3/4 SQUARE AXLE FASTENER	84
0511057237	PLATFORM ASSY - 3245	85
0511058319	PLATFORM ASSY - 3695	86
0511057129	PLATFORM ASSY - 4045	87
0511057565	PLATFORM ASSY - 4495	88
0511057650	PLATFORM ASSY - 4845	89
0511058312	PLATFORM ASSY - 5345	90
0511057236	HANDRAIL ASSY - 3245	91
0511058318	HANDRAIL ASSY - 3695	92
0511057130	HANDRAIL ASSY - 4045	93
0511057566	HANDRAIL ASSY - 4495	94
0511057651	HANDRAIL ASSY - 4845	95
0511058308	HANDRAIL ASSY - 5345	96
0511056536	LADDER ASSEMBLY	97
0511054971	JACK ASSEMBLY	98
0511057142	ASSY HEADER - 3245/3695/4045/4495	99
0511057150	HEADER ASSEMBLY - 4845/5345	100
0511057131	MANUAL CANISTER ASSY	101
0511058270	HYDRAULIC MARKER LABEL ASSY - 3245	102
0511059613	LABEL ASSY - 3695	103
0521052757	HYDRAULIC MARKER LABEL ASSY - 3695	104
0511057541	LABEL ASSY - 4045	105
0511057133	LABEL ASSY FOR HYDRAULIC MARKER - 4045	106
0511058969	LABEL ASSY - 4495	107
0511057858	HYDRAULIC MARKER LABEL ASSY - 4495	108
0511057380	LABEL ASSY FOR HYDRAULIC MARKER - 4845	109
0521050177	LABEL ASSY FOR HYDRAULIC MARKER - 5485	110



MARCHESAN

INDEX


0909098921	ASSY HEX AXLE	111
0501054258	DRAWBAR ESTABILIZER ASSY	112
0511054601	HITCH ARTICULATED TRACTOR	113
0511053179	TRACTOR COUPLING SHAFT	114
0511056736	HOSE SUPPORT	115
0511058368	EAR MOVABLE	116
0909098922	SEED LINE/FERTILIZER ASSEMBLY	117
0511053254	SHORT FERTILIZER LINE DDD LEFT DC20	118
0531050532	SHORT FERTILIZER LOWER LEFT DDD DC20	119
0511050967	SHORT FERTILIZER ROW	120
0521051039	SHORT FERTILIZER LINE DDD LEFT DOC20	121
0511053255	LONG FERTILIZER LINE DDD RIGHT DC20	122
0531050534	RIGHT LONGER FERTILIZER DDD RIGHT DC20	123
0511050968	LONG FERTILIZER ROW	124
0521051041	LONG FERTILIZER LINE DDD RIGHT DOC20	125
0501058271	SHORT FERTILIZER LINE S/DDD/H	126
0501058272	LONG FERTILIZER LINE S/DDD/H	127
0511053253	RIGHT FERTILIZER LINE DDD RIGHT	128
0511053252	SHORT FERTILIZER LINE DDD LEFT	129
0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	130
0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	131
0521052634	SHORT ARM LOWER LINE FERTILIZER WITH LEFT DDD	132
0521052635	LONGER ARM LOWER LINE FERTILIZER WITH RIGHT DDD	133
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	134
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	135
0511053172	LEFT LOW CUBE WITH DISC 15	136
0511053173	CUBE LOW RIGHT WITH DISC 15	137
0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	138
0511044585	20" COULTER BLADE ASSY FOR LONG ROW	139
0511044573	18" COULTER BLADE ASSY FOR LONG ROW	140
0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	141
0501054887	20 BLADE DISC WITH FLAT PLAN DISC	142
0521044545	20" SHORT CURVED CORRIGATED DISC	143
0521044546	20" LONG CURVED CORRUGATED DISC	144
0501058423	FERTILIZER ROD SPRING ROW	145
0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	146
0511056554	SHORT SEED ROW FRONT	147
0511056555	LONG SEED ROW FRONT	148
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	149
0511058650	SEMI-MOUNTED DEPTH CONTROL	150
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	151
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	152
0501052627	ASSY DEPTH WHEEL BOX	153
0501052297	DEPTH WHEELS REGULATOR ASSY	154
0501052538	DEPTH BAND WITH ARMS	155
0511054333	COMPACT WHEEL RIGHT WITH BEARING	156
0511054334	COMPACT WHEEL LEFT WITH BEARING	157
0501052908	COMPACTOR WHEEL WITH BEARING	158
0521051424	WHEEL SYSTEM DEPTH/COMPACTOR QUICK ADJUSTMENT	159
0501056769	DEPTH WHEELS REGULATOR ASSY	160
0521051423	COMPACTOR SUPPORT	161
0511050077	WHEEL STRIPED	162
0511052287	DEPTH WHEEL HUB ASSY	163
0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	164
0511052971	SEMI-ASSEMBLED DEPTH CONTROL WITH THREAD	165

INDEX

0511059325	LEFT ARM COVERED WHEEL ASSEMBLED		166
0511059324	RIGHT ARM COVERED WHEEL ASSEMBLED		167
0511051546	CUBE RIGHT CONTROL DEPTH		168
0511051547	LEFT CUBE CONTROL DEPTH		169
0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB		170
0511052970	SYSTEM COMPACTOR V SEMI MOUNTED		171
0511055819	DEPTH WHIT AROS BAND		172
0521042327	DEPTH CONTROL & PRESS WHEEL ASSY		173
0511053550	DEPTH CONTROL ASSY		174
0501110231	SCARIFIER HEAD WITH SPIKE 0061		175
0501050120	LARGER WALKING BEAM ASSY		176
0501053866	COVERING WHEEL FERTILIZER V RIGHT IRON		177
0501053867	COVERING V WHEEL FERTILIZER LEFT IRON		178
0511054837	RH IRON PRESS WHEEL		179
0511054838	LH IRON PRESS WHEEL		180
0501052957	IRON V PRESS WHEELS		181
0501052735	COVERING WHEEL RIGHT FERTILIZER ASSY IRON		182
0501052736	COVERING WHEEL LEFT FERTILIZER ASSY IRON		183
0501056288	WHEEL COVER ROD FERRO		184
0501056289	IRON LEFT PRESS WHEEL FERT UP		185
0501053186	RIGHT IRON PRESS WHEEL ASSY		186
0511059410	HDA BC		187
0511059396	SCARIFIER SPINDLE WITH POINT		188
0521052631	HDA HIGH AUTOMATIC DISARM		189
0521050364	ROD WITH BEAK		190
0501110723	SCARIFIER ROD		191
0521050168	MOUNTED FERTILIZER CONDUCTOR		192
0521053945	HDA PIVOTED LINE		193
0521053937	SCARIFIER SPINDLE WITH POINT		194
0521053959	ROD WITH AUTOMATIC DISARM TIP		195

ASSY FRAME

0909098920



Item	Code	Description	See page	3245	3695	4045	4495	4845	5345
01	0501058194	FRAME WITH AXLE WHEEL - 3245	2	01	00	00	00	00	00
01.	0511051956	FRAME WITH AXLE WHEEL - 3695	3	00	01	00	00	00	00
01..	0501058195	FRAME WITH AXLE WHEEL - 4045	4	00	00	01	00	00	00
01...	0511050836	WHEEL AXLE FRAME - 4495	5	00	00	00	01	00	00
01....	0501058196	WHEEL AXLE FRAME - 4845	6	00	00	00	00	01	00
01.....	0511051118	WHEEL AXLE FRAME - 5345	7	00	00	00	00	00	01
02	0503010003	1845 GREASE FITTING		04	04	04	04	06	06
03	0511057124	CYLINDER ASSY	8	01	01	01	01	00	01
03.	0511056529	CYLINDER ASSY	9	00	00	00	00	01	01
04	0521043934	CARRYING WHEELS SPRING TRACTION	12	04	02	04	04	04	04
05	0511057493	RIGHT TRANSMISSION ASSY - 3245	21	01	00	00	00	00	00
05.	0511059611	RIGHT TRANSMISSION ASSY - 3695	22	00	01	00	00	00	00
05..	0511058597	RIGHT TRANSMISSION ASSY - 4045	23	00	00	01	00	00	00
05...	0511058970	RIGHT TRANSMISSION ASSY - 4495	24	00	00	00	01	00	00
05....	0511056740	RIGHT TRANSMISSION ASSY - 4880	25	00	00	00	00	01	00
05.....	0521050178	RIGHT TRANSMISSION ASSY - 5345	26	00	00	00	00	00	01
06	0511057346	LEFT TRANSMISSION ASSY - 3245	27	01	00	00	00	00	00
06.	0511059612	LEFT TRANSMISSION ASSY - 3695	28	00	01	00	00	00	00
06..	0511058598	LEFT TRANSMISSION ASSY - 4045	29	00	00	01	00	00	00
06...	0511058971	LEFT TRANSMISSION ASSY - 4495	30	00	00	00	01	00	00
06....	0511056741	LEFT TRANSMISSION ASSEMBLY - 4880	31	00	00	00	00	01	00
06.....	0521050179	ASSY TRANSMISSION LEFT - 5345	32	00	00	00	00	00	01
07	0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	53	01	01	01	01	00	00
07.	0511057146	HYDRAULIC SYSTEM ASSY - 4845/5345	54	00	00	00	00	01	01
08	0501058165	SEMI-ASSEMBLED HYDRAULIC MARKER 3245/7	56	01	00	00	00	00	00
08.	0511052482	SEMI-ASSEMBLED HYDRAULIC MARKER 3695	57	00	01	00	00	00	00
08..	0501058170	SEMI-ASSEMBLED HYDRAULIC MARKER 4045/9	58	00	00	01	00	00	00
08...	0501058169	SEMI-ASSEMBLED MECHANICAL MARKER 4045/9	59	00	00	01	00	00	00
08....	0511050854	MECANIC ROW MARK 4495/9	60	00	00	00	01	00	00
08.....	0511050838	SEMI-ASSEMBLED HYDRAULIC MARKER 4495	61	00	00	00	01	00	00
08.....	0501058172	SEMI-ASSEMBLED HYDRAULIC MARKER 4845/11	62	00	00	00	00	01	00

ASSY FRAME

0909098920


Item	Code	Description	See page	3245	3695	4045	4495	4845	5345
08.....	0511051119	SEMI-ASSEMBLED HYDRAULIC MARKER 5345	63	00	00	00	00	00	01
09	0501050633	ROW MARKER DISK ASSEMBLY	67	02	02	02	02	02	02
10	0511057235	SET SUPPORT RIGHT LEFT	68	01	00	00	00	00	00
10.	0511058317	RIGHT/LEFT SUPPORT BOX ASSEMBLY ASSY 8	69	00	01	00	00	00	00
10..	0511057128	SET SUPPORT RIGHT LEFT	70	00	00	01	00	00	00
10...	0511057564	SET SUPPORT RIGHT LEFT	71	00	00	00	01	00	00
10....	0511057147	ASSEMBLY SUPPORT RIGHT/LEFT BOX FERTILIZER	72	00	00	00	00	01	00
10.....	0511058311	RIGHT / LEFT SUPPORT BOX ASSEMBLY ASSY 12	73	00	00	00	00	00	01
11	0511057237	PLATFORM ASSY - 3245	85	01	00	00	00	00	00
11.	0511058319	PLATFORM ASSY - 3695	86	00	01	00	00	00	00
11..	0511057129	PLATFORM ASSY - 4045	87	00	00	01	00	00	00
11...	0511057565	PLATFORM ASSY - 4495	88	00	00	00	01	00	00
11....	0511057650	PLATFORM ASSY - 4845	89	00	00	00	00	01	00
11.....	0511058312	PLATFORM ASSY - 5345	90	00	00	00	00	00	01
12	0511057236	HANDRAIL ASSY - 3245	91	01	00	00	00	00	00
12.	0511058318	HANDRAIL ASSY - 3695	92	00	01	00	00	00	00
12..	0511057130	HANDRAIL ASSY - 4045	93	00	00	01	00	00	00
12...	0511057566	HANDRAIL ASSY - 4495	94	00	00	00	01	00	00
12....	0511057651	HANDRAIL ASSY - 4845	95	00	00	00	00	01	00
12.....	0511058308	HANDRAIL ASSY - 5345	96	00	00	00	00	00	01
13	0511056536	LADDER ASSEMBLY	97	02	02	02	02	02	02
14	0511054971	JACK ASSEMBLY	98	02	02	02	02	02	02
15	0511057142	ASSY HEADER - 3245/3695/4045/4495	99	01	01	01	01	00	00
15.	0511057150	HEADER ASSEMBLY - 4845/5345	100	00	00	00	00	01	01
16	0511057131	MANUAL CANISTER ASSY	101	01	01	01	01	01	01
17	0511058270	HYDRAULIC MARKER LABEL ASSY - 3245	102	01	00	00	00	00	00
17.	0511059613	LABEL ASSY - 3695	103	00	01	00	00	00	00
17..	0521052757	HYDRAULIC MARKER LABEL ASSY - 3695	104	00	01	00	00	00	00
17...	0511057541	LABEL ASSY - 4045	105	00	00	01	00	00	00
17....	0511057133	LABEL ASSY FOR HYDRAULIC MARKER - 4045	106	00	00	01	00	00	00
17.....	0511058969	LABEL ASSY - 4495	107	00	00	00	01	00	00
17.....	0511057858	HYDRAULIC MARKER LABEL ASSY - 4495	108	00	00	00	01	00	00
17.....	0511057380	LABEL ASSY FOR HYDRAULIC MARKER - 4845	109	00	00	00	00	01	00
17.....	0521050177	LABEL ASSY FOR HYDRAULIC MARKER - 5485	110	00	00	00	00	00	01
17.....	0511059676	LABEL ASSY FOR P.1 / MH		01	00	00	00	00	00
18	0909098921	ASSY HEX AXLE	111	01	01	01	01	01	01
19	0501065677	STRUT		02	02	02	02	02	02
20	0501054258	DRAWBAR ESTABILIZER ASSY	112	01	01	01	01	01	01
21	0511054601	HITCH ARTICULATED TRACTOR	113	01	01	01	01	01	01
22	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01	01	01	01	01	01
23	0511053179	TRACTOR COUPLING SHAFT	114	01	01	01	01	01	01
24	0521013022	TRANSPORT LOCK		01	01	01	01	01	01
25	0501068994	0.3" X 3.1"LOCK PIN		01	01	01	01	01	01
26	0503030168	CUPILLA		01	01	01	01	01	01
27	0503014120	CHAIN		01	01	01	01	01	01
28	0503014321	CABLE STEEL SHACKLE		02	02	02	02	02	02
29	0511056736	HOSE SUPPORT	115	01	01	01	01	01	01
30	0501047895	ROD STOP		01	01	01	01	02	02
31	0501047885	ROD STOP		01	01	01	01	02	02
32	0501047886	ROD STOP		01	01	01	01	02	02
33	0501047887	ROD STOP		01	01	01	01	02	02
34	0503032624	SILO FERTILIZER GUTTER		05	04	05	05	06	06
35	0503010780	N-2050 AMENDMENT		02	02	02	02	02	02
36	0503011750	AMENDMENT WITH LOCK		06	06	06	06	06	06
37	0503010951	REDUCTION		04	04	04	04	04	04
38	0503011751	REDUCTION		06	06	06	06	06	06
39	0503010246	CLAMP		03	02	03	03	04	06
40	0511058368	EAR MOVABLE	116	02	02	02	02	00	00




ASSY FRAME

0909098920


Item	Code	Description	See page	3245	3695	4045	4495	4845	5345
41	0909098922	SEED LINE/FERTILIZER ASSEMBLY	117	07	08	09	10	11	12




Item	Code	Description	See page	QT
01	0511069615	FRAME		01
02	0511069724	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0521063230	FRAME		01
02	0521063231	WHEEL ARTICULATED AXLE		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0511069529	FRAME		01
02	0511069682	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08



Item	Code	Description	See page	QT
01	0521062243	FRAME		01
02	0521062242	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0511069616	FRAME		01
02	0511069717	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8" X 2-1/4" BOLT		12
05	0501012140	FLAT WASHER		24
06	0531013922	0.6" X 0.8" X 1" SLEEVE		12
07	0503011445	SPRING WASHER		12
08	0503010013	5/8" NUT		12



Item	Code	Description	See page	QT
01	0521062442	FRAME		01
02	0521062447	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8" X 2-1/4" BOLT		12
05	0501012140	FLAT WASHER		24
06	0531013922	0.6" X 0.8" X 1" SLEEVE		12
07	0503011445	SPRING WASHER		12
08	0503010013	5/8" NUT		12

CYLINDER ASSY


0511057124




Item	Code	Description	See page	QT
01	0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	10	01
02	0531019171	1.25" X 7" COUPLING SHAFT		01
03	0521012536	COUPLING SHAFT		01
04	0503010523	1/4" X 2" COTTERPIN		02
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010013	5/8" NUT		02

CYLINDER ASSY

0511056529




Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	11	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521012536	COUPLING SHAFT		02
04	0503010523	1/4" X 2" COTTERPIN		04
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0511064055	5" X 15" CYLINDER CASE		01
02	0511064056	BUSHING 2" X 14" TURNBUCLE		01
03	0502010382	5" END CAP		01
04	0502012227	50.80 X 127 RING SUPPORT		01
05	0503010039	D-2000 SCRAPER RING		01
06	0503010991	1870-2000-375-B GASKET		01
07	0503010952	W2-2250-500 RING		01
08	0503010351	2-425 N 3006-9B O'RING		01
09	0503011062	8-425 BACK-UP RING		01
10	0502010963	2.0" X 5.0" PISTON		01
11	0503010552	PACKING 3750-4250-625-B		02
12	0503010345	2-218 N 3006-9B O'RING		01
13	0503010974	W2-5000-500 RING		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503010003	1845 GREASE FITTING		01
16	0503030385	CYLINDER PLUG N-002		02

HYDRAULIC CYLINDER


0511058406




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0501058240	WHEEL FASTENER WITH TENSIONER	13	01
02	0503011119	7/8" X 6" BOLT		04
03	0501014251	FLAT WASHER		04
04	0503011254	7/8" HEX SELF ADJUSTING NUT		04
05	0501059909	CARRYING WHEELS SUPPORT	17	01
06	0503014887	2050 CHAIN X 80 LINK + REDUCTION		01
07	0502010584	CARRYING-WHEELS SUPPORT FIXER		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	14	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	15	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	16	01



Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TIGHTENER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN UPPER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0591017923	GLOVE 15.30 X 30 X 32		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01

CARRYING WHEELS SUPPORT


0501059909




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0531016887	CARRYING WHEEL AXLE ARM		01
03	0503010523	1/4" X 2" COTTERPIN		01
04	0503010003	1845 GREASE FITTING		01
05	0511050681	TRACTION SPRING		01
05A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
05B	0561016062	SPRING HITCH		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		04
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0511052770	WHEEL WITH TIRE	18	01
11	0501058241	WHEEL SUPPORT CHAIN TENSIONER	20	01
12	0521061565	WHEEL SUPPORT ARM		01
13	0503018981	BOLT		02
14	0521069983	WHEEL COVER		01
15	0591010589	BODY LOCK WHEEL		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE		01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	19	01



Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSM AXLE CARRYING-WHEEL		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016882	1535 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	35	01
17	0521043316	RIGHT GEAR BOX ASSY	37	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8" SPRING WASHER		01
36	0501010984	FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0571011602	MOTOR AXLE		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	35	01
17	0521043316	RIGHT GEAR BOX ASSY	37	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

**RIGHT TRANSMISSION ASSY - 3695**

0511059611

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8" SPRING WASHER		01
36	0501010984	FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016881	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	35	01
17	0521043316	RIGHT GEAR BOX ASSY	37	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

**RIGHT TRANSMISSION ASSY - 4045**

0511058597


Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8" SPRING WASHER		01
36	0501010984	FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561018351	2155 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 C50 G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	35	01
17	0521043316	RIGHT GEAR BOX ASSY	37	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8" SPRING WASHER		01
36	0501010984	FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	35	01
17	0521043316	RIGHT GEAR BOX ASSY	37	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0521055207	TOP CURRENT STRETCHER		01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01




Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561019204	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	35	01
17	0521043316	RIGHT GEAR BOX ASSY	37	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2" X 1.1/2" BOLT		02
20	0511017302	FLAT WASHER		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0503030303	SUPPORT WASHER		03
26	0501010637	FLAT WASHER		01
27	0501010984	FLAT WASHER		01
28	0503010025	3/8" SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	47	01
31	0501058234	LOWER CHAIN TENSIONER	48	01

Item	Code	Description	See page	QT
32	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
33	0501058236	BEARING WITH 21Z GEAR	50	01
34	0501058237	16Z GEAR BEARING	51	01
35	0503012391	40-1 CHAIN X 83 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
38	0503012719	40-1 CHAIN X 113 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016882	1535 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	36	01
17	0521043317	LEFT GEAR BOX ASSY	38	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

**LEFT TRANSMISSION ASSY - 3245**

0511057346

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8" SPRING WASHER		01
36	0501010984	FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0571011602	MOTOR AXLE		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	36	01
17	0521043317	LEFT GEAR BOX ASSY	38	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

**LEFT TRANSMISSION ASSY - 3695**

0511059612

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8" SPRING WASHER		01
36	0501010984	FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016881	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	36	01
17	0521043317	LEFT GEAR BOX ASSY	38	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

**LEFT TRANSMISSION ASSY - 4045**

0511058598

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8" SPRING WASHER		01
36	0501010984	FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561018351	2155 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	36	01
17	0521043317	LEFT GEAR BOX ASSY	38	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

**LEFT TRANSMISSION ASSY - 4495**

0511058971

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8" SPRING WASHER		01
36	0501010984	FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	36	01
17	0521043317	LEFT GEAR BOX ASSY	38	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
27	0501058234	LOWER CHAIN TENSIONER	48	01
28	0521055207	TOP CURRENT STRETCHER		01
29	0501058236	BEARING WITH 21Z GEAR	50	01
30	0501058237	16Z GEAR BEARING	51	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01

LEFT TRANSMISSION ASSEMBLY - 4880

0511056741

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561019204	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	36	01
17	0521043317	LEFT GEAR BOX ASSY	38	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2" X 1.1/2" BOLT		02
20	0511017302	FLAT WASHER		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0503030303	SUPPORT WASHER		03
26	0501010637	FLAT WASHER		01
27	0501010984	FLAT WASHER		01
28	0503010025	3/8" SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	47	01
31	0501058234	LOWER CHAIN TENSIONER	48	01


ASSY TRANSMISSION LEFT - 5345

0521050179

Item	Code	Description	See page	QT
32	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
33	0501058236	BEARING WITH 21Z GEAR	50	01
34	0501058237	16Z GEAR BEARING	51	01
35	0503012391	40-1 CHAIN X 83 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
38	0503012719	40-1 CHAIN X 113 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02

RIGHT SIDE TRANSMISSION ACTUATOR


0511047069



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

LEFT SIDE TRANSMISSION ACTUATOR


0511047070



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY


0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	39	01
02	0511059266	CLOSED BEARING	41	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	42	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	44	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	45	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	46	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	40	01
02	0511059266	CLOSED BEARING	41	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	42	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	44	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	45	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	46	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	43	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503012882	BEARING		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0551019173	CHAIN SLEEVE TENSIONER		01
05	0511017302	FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019174	DOBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01



Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511057070	HOSE KIT HYDRAULIC		01
01A	0521052285	TC-TM HOSE ASSY		01
01AA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01AB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01AD	0503018952	PLASTIC BOLT		06
01B	0521052287	TC-TM HOSE ASSY		01
01BA	0501080446	3/8 X" 169" TC-TM HOSE ASSY		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01BD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	55	02
03	0503013100	NYLON CLAMP		02
04	0581010091	SPRING PROTECTION PLASTIC HOSE		01




Item	Code	Description	See page	QT
01	0511063404	"T" OIL CONDUCTOR		02
02	0581010091	SPRING PROTECTION PLASTIC HOSE		01
03	0503013100	NYLON CLAMP		02
04	0502012702	BODY SUPPORT CLAMP		02
05	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		02
06	0503010180	7/16" SPRING WASHER		02
07	0501053834	MALE QUICK COUPLER	55	02
08	0511057068	HOSE KIT SYSTEM HYDRAULIC		01
08A	0501080449	3/8" X 1500 TC-TC HOSE		04
09	0521052334	3/8 X 4000 TR-TM HOSE BLACK / BLUE		01
09A	0501080361	3/8" X 157" TR-TM HOSE		01
09B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
09C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
09D	0503018952	PLASTIC BOLT		06
10	0521052333	3/8 X 4000 TR-TM HOSE BLACK / RED		01
10A	0501080361	3/8" X 157" TR-TM HOSE		01
10B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
10C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
10D	0503018952	PLASTIC BOLT		06

MALE QUICK COUPLER

0501053834




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8 UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0503012412	5/8 UNC SELF LOCKING NUT		02
13	0511058449	HYDRAULIC CYLINDER	64	02
14	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
15	0503010523	1/4" X 2" COTTERPIN		02
16	0511015779	1" X 4.2" AXLE		02
17	0503010523	1/4" X 2" COTTERPIN		02
18	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
19	0501068994	0.3" X 3.1" LOCK PIN		02
20	0503030168	CUPILLA		02
21	0501069643	890 TURNBUCKLE		02
22	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
23	0511011311	VALVE SUPPORT		01
24	0503010232	5/8" X 1.3/4" BOLT		02
25	0503010027	5/8" SPRING WASHER		02
26	0503010013	5/8" NUT		02
27	0501054649	HBM SEQUENTIAL VALVE	65	01
28	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
29	0501010984	FLAT WASHER		02
30	0503010025	3/8" SPRING WASHER		02
31	0511057191	HYDRAULIC HOSE MARKER ASSY 3245/7		01

Item	Code	Description	See page	QT
31A	0501080452	3/8" X 98" TR-TR HOSE		02
31B	0501080401	3/8" X 106" TR-TC HOSE		02
31C	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
31CA	0501080422	HOSE 3/8 X 4000 TC-TM		01
31CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
31CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
31CD	0503018952	PLASTIC BOLT		06
31D	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
31DA	0501080422	HOSE 3/8 X 4000 TC-TM		01
31DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
31DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
31DD	0503018952	PLASTIC BOLT		06
32	0501053834	MALE QUICK COUPLER	55	02
33	0502012702	BODY SUPPORT CLAMP		06
34	0503011103	7/16" X 2-1/2" BOLT		06
35	0501012803	FLAT WASHER		02
36	0503010180	7/16" SPRING WASHER		06
37	0503010244	7/16" NUT		06



Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8 UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0503012412	5/8 UNC SELF LOCKING NUT		02
13	0511058449	HYDRAULIC CYLINDER	64	02
14	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
15	0503010523	1/4" X 2" COTTERPIN		02
16	0511015779	1" X 4.2" AXLE		02
17	0503010523	1/4" X 2" COTTERPIN		02
18	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
19	0501068994	0.3" X 3.1" LOCK PIN		02
20	0503030168	CUPILLA		02
21	0501069643	890 TURNBUCKLE		02
22	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
23	0511011311	VALVE SUPPORT		01
24	0503010232	5/8" X 1.3/4" BOLT		02
25	0503010027	5/8" SPRING WASHER		02
26	0503010013	5/8" NUT		02
27	0501054649	HBM SEQUENTIAL VALVE	65	01
28	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
29	0501010984	FLAT WASHER		02
30	0503010025	3/8" SPRING WASHER		02
31	0511057075	HYDRAULIC MARKER HOSE KIT		01


Item	Code	Description	See page	QT
31A	0501080296	3/8" X 106" TR-TR HOSE		02
31B	0501080397	3/8" X 120" TR-TC HOSE		02
31C	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
31CA	0501080422	HOSE 3/8 X 4000 TC-TM		01
31CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
31CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
31CD	0503018952	PLASTIC BOLT		06
31D	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
31DA	0501080422	HOSE 3/8 X 4000 TC-TM		01
31DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
31DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
31DD	0503018952	PLASTIC BOLT		06
32	0501053834	MALE QUICK COUPLER	55	02
33	0502012702	BODY SUPPORT CLAMP		06
34	0503011103	7/16" X 2-1/2" BOLT		06
35	0501012803	FLAT WASHER		02
36	0503010180	7/16" SPRING WASHER		06
37	0503010244	7/16" NUT		06



Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8 UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0503012412	5/8 UNC SELF LOCKING NUT		02
13	0511058449	HYDRAULIC CYLINDER	64	02
14	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
15	0503010523	1/4" X 2" COTTERPIN		02
16	0511015779	1" X 4.2" AXLE		02
17	0503010523	1/4" X 2" COTTERPIN		02
18	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
19	0501068994	0.3" X 3.1" LOCK PIN		02
20	0503030168	CUPILLA		02
21	0501069643	890 TURNBUCKLE		02
22	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
23	0511011311	VALVE SUPPORT		01
24	0503010232	5/8" X 1.3/4" BOLT		02
25	0503010027	5/8" SPRING WASHER		02
26	0503010013	5/8" NUT		02
27	0501054649	HBM SEQUENTIAL VALVE	65	01
28	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
29	0501010984	FLAT WASHER		02
30	0503010025	3/8" SPRING WASHER		02
31	0511057095	HYDRAULIC MARKER HOSE KIT	66	01




Item	Code	Description	See page	QT
32	0501053834	MALE QUICK COUPLER	55	02
33	0502012702	BODY SUPPORT CLAMP		06
34	0503011103	7/16" X 2-1/2" BOLT		06
35	0501012803	FLAT WASHER		02
36	0503010180	7/16" SPRING WASHER		06
37	0503010244	7/16" NUT		06




Item	Code	Description	See page	QT
01	0511069621	MECANIC ROW MARK SUPPORT	02	
02	0503012407	5/8" X 1-1/2" BOLT	08	
03	0551018204	RIGHT ROW MARKER FIXER	01	
04	0551018205	LH ROW MARKER FIXER	01	
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04	
06	0501010984	FLAT WASHER	08	
07	0503010025	3/8" SPRING WASHER	04	
08	0503010026	3/8" NUT	04	
09	0521010549	COUPLING SHAFT	02	
10	0503030168	CUPILLA	02	
11	0511060475	ROW MARKER ARM	01	
12	0511060576	LH ROW MARKER ARM	01	
13	0503010769	5/8" X 2-1/4" BOLT	04	
14	0521010479	SLEEVE ARTICULATION	04	
15	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	02	
16	0501010984	FLAT WASHER	04	
17	0503010025	3/8" SPRING WASHER	02	
18	0503010026	3/8" NUT	02	
19	0501069643	890 TURNBUCKLE	02	
20	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN	04	
21	0502010421	SIDE PULLEY	02	
22	0521010445	0.53" X 0.75" X 0.45" SLEEVE	02	
23	0521010641	COUPLING SHAFT	02	
24	0503010140	1/8" X 3/4" COTTERPIN	02	
25	0501058197	ROW MARKER PIVOT	01	
25A	0501065640	ROW MARKER ROD GUIDE	02	
25B	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN	04	
25C	0511017302	FLAT WASHER	06	
25D	0503010019	1/2" SPRING WASHER	09	
25E	0503010060	1/2" NUT	07	
25F	0501065644	ROW MARKER ARM/DISARMMENT ROD	01	

Item	Code	Description	See page	QT
25G	0501064229	REGULATOR ARM/DISARMMENT ROD		01
25H	0501062547	ROW MARKER BAR REGULATOR		01
25I	0503010395	1/2" X 1-1/4" BOLT		01
25J	0521010454	0.83" X 1.25" X 0.79" SLEEVE		01
25K	0503010734	1/2" X 2-1/2" BOLT		01
25L	0521010539	0.3" X 1.2" COUPLING SHAFT		02
25M	0503010140	1/8" X 3/4" COTTERPIN		02
25N	0521062281	ROW MARK ARM LOCK		02
25O	0503032995	STEEL CABLE		01
25P	0501010096	3/8" X 2" BOLT		02
25Q	0531010415	ROW MARKER ARM/DISARM GUIDE SLEEVE		04
25R	0503010025	3/8" SPRING WASHER		02
25S	0503010026	3/8" NUT		02
25T	0501065642	ROW MARKER SUPPORT		01
25U	0502011231	CENTRAL PULLEY		02
25V	0521010693	PULLEY FIXER PLATE		01
25W	0511011308	BOLT		02
25Y	0503010691	1/4" GREASE FITTING		02
25Z	0503010232	5/8" X 1.3/4" BOLT		02
25Z1	0503010027	5/8" SPRING WASHER		02
25Z2	0503010013	5/8" NUT		02
26	0502011231	CENTRAL PULLEY		01
27	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
28	0503011128	6,4 X 1400 CHAIN		02
29	0502011291	CHAIN SLEEVE		02
30	0503010683	0,2" X 1,2" SPRING PIN		02
31	0551018206	LEFT COVER ARM/DISARMMENT		01
32	0551018207	LEFT COVER PROTECTION		01
33	0511017961	1/2" X 1-1/4" REB BOLT		02
34	0503010019	1/2" SPRING WASHER		02
35	0503010060	1/2" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		09




Item	Code	Description	See page	QT
01	0511069621	MECANIC ROW MARK SUPPORT	02	
02	0503012407	5/8" X 1-1/2" BOLT	08	
03	0551018204	RIGHT ROW MARKER FIXER	01	
04	0551018205	LH ROW MARKER FIXER	01	
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04	
06	0501010984	FLAT WASHER	08	
07	0503010025	3/8" SPRING WASHER	04	
08	0503010026	3/8" NUT	04	
09	0521010549	COUPLING SHAFT	02	
10	0503030168	CUPILLA	02	
11	0511060475	ROW MARKER ARM	01	
12	0511060576	LH ROW MARKER ARM	01	
13	0503010769	5/8" X 2-1/4" BOLT	04	
14	0521010479	SLEEVE ARTICULATION	04	
15	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	02	
16	0501010984	FLAT WASHER	04	
17	0503010025	3/8" SPRING WASHER	02	
18	0503010026	3/8" NUT	02	
19	0501069643	890 TURNBUCKLE	02	
20	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN	04	
21	0502010421	SIDE PULLEY	02	
22	0521010445	0.53" X 0.75" X 0.45" SLEEVE	02	
23	0521010641	COUPLING SHAFT	02	
24	0503010140	1/8" X 3/4" COTTERPIN	02	
25	0501058197	ROW MARKER PIVOT	01	
25A	0501065640	ROW MARKER ROD GUIDE	02	
25B	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN	04	
25C	0511017302	FLAT WASHER	04	
25D	0503010019	1/2" SPRING WASHER	04	
25E	0503010060	1/2" NUT	04	
25F	0501065644	ROW MARKER ARM/DISARMMENT ROD	01	

Item	Code	Description	See page	QT
25G	0501064229	REGULATOR ARM/DISARMMENT ROD		01
25H	0501062547	ROW MARKER BAR REGULATOR		01
25I	0511017302	FLAT WASHER		01
25J	0521010454	0.83" X 1.25" X 0.79" SLEEVE		01
25K	0503010734	1/2" X 2-1/2" BOLT		01
25L	0521010539	0.3" X 1.2" COUPLING SHAFT		02
25M	0503010140	1/8" X 3/4" COTTERPIN		02
25N	0521062281	ROW MARK ARM LOCK		02
25O	0503032995	STEEL CABLE		01
25P	0501010096	3/8" X 2" BOLT		02
25Q	0531010415	ROW MARKER ARM/DISARM GUIDE SLEEVE		04
25R	0503010025	3/8" SPRING WASHER		02
25S	0503010026	3/8" NUT		02
25T	0501065642	ROW MARKER SUPPORT		01
25U	0502011231	CENTRAL PULLEY		02
25V	0521010693	PULLEY FIXER PLATE		01
25W	0511011308	BOLT		02
25Y	0503010691	1/4" GREASE FITTING		02
25Z	0503010232	5/8" X 1.3/4" BOLT		02
25Z1	0503010027	5/8" SPRING WASHER		02
25Z2	0503010013	5/8" NUT		02
26	0502011231	CENTRAL PULLEY		01
27	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
28	0503016066	6,4 X 1630 CHAIN		02
29	0502011291	CHAIN SLEEVE		02
30	0503010683	0,2" X 1,2" SPRING PIN		02
31	0561018354	RIGHT COVER PROTECTION		01
32	0561018355	LEFT COVER PROTECTION		01
33	0511017961	1/2" X 1-1/4" REB BOLT		02
34	0503010019	1/2" SPRING WASHER		02
35	0503010060	1/2" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		08
37	0503012412	5/8 UNC SELF LOCKING NUT		04
38	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0501069470	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	64	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	CUPILLA		02
18	0501069643	890 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	65	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0501053834	MALE QUICK COUPLER	55	02
25	0502012702	BODY SUPPORT CLAMP		06
26	0503011103	7/16" X 2-1/2" BOLT		06
27	0501012803	FLAT WASHER		02
28	0503010180	7/16" SPRING WASHER		06
29	0503010244	7/16" NUT		06
30	0501012140	FLAT WASHER		04
31	0503012412	5/8 UNC SELF LOCKING NUT		02

Item	Code	Description	See page	QT
32	0511011311	VALVE SUPPORT		01
33	0503010232	5/8" X 1.3/4" BOLT		02
34	0503010027	5/8" SPRING WASHER		02
35	0503010013	5/8" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		08
37	0511057071	HYDRAULIC HOSE MARKER ASSY 10L		01
37A	0501081729	HOSE 3/8 X 3125 TR-TR		02
37B	0501081633	HOSE 3/8 X 3325 TR-TC		02
38	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
38A	0501080422	HOSE 3/8 X 4000 TC-TM		01
38B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
38C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
38D	0503018952	PLASTIC BOLT		06
39	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
39A	0501080422	HOSE 3/8 X 4000 TC-TM		01
39B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
39C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
39D	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8 UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503011082	C1/2" X 1.3/4" SCREW		02
07	0501069470	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0501012140	FLAT WASHER		04
11	0503012412	5/8 UNC SELF LOCKING NUT		02
12	0511058449	HYDRAULIC CYLINDER	64	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" COTTERPIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	0.3" X 3.1" LOCK PIN		02
19	0503030168	CUPILLA		02
20	0501066949	1235 TURNBUCKLE		02
21	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
22	0511011311	VALVE SUPPORT		01
23	0503010232	5/8" X 1.3/4" BOLT		02
24	0503010027	5/8" SPRING WASHER		02
25	0503010013	5/8" NUT		02
26	0501054649	HBM SEQUENTIAL VALVE	65	01
27	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
28	0501010984	FLAT WASHER		02
29	0503010025	3/8" SPRING WASHER		02
30	0502012702	BODY SUPPORT CLAMP		06
31	0503011103	7/16" X 2-1/2" BOLT		06

Item	Code	Description	See page	QT
32	0501012803	FLAT WASHER		02
33	0503010180	7/16" SPRING WASHER		06
34	0503010244	7/16" NUT		06
35	0501053834	MALE QUICK COUPLER	55	02
36	0511057069	HYDRAULIC HOSE MARKER ASSY		01
36A	0501080343	TR-TR HOSE ASSY		02
36B	0501080720	HOSE 3/8 X 3500 TR-TC		02
37	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
37A	0501080422	HOSE 3/8 X 4000 TC-TM		01
37B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
37C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
37D	0503018952	PLASTIC BOLT		06
38	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
38A	0501080422	HOSE 3/8 X 4000 TC-TM		01
38B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
38C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
38D	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0501012140	FLAT WASHER		12
04	0503012412	5/8 UNC SELF LOCKING NUT		10
05	0503011070	BEATER		02
06	0503010920	1/2" X 1.1/2" BOLT		02
07	0503010019	1/2" SPRING WASHER		02
08	0511061811	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0511058449	HYDRAULIC CYLINDER	64	02
12	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
13	0503010523	1/4" X 2" COTTERPIN		04
14	0511015779	1" X 4.2" AXLE		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	CUPILLA		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	65	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0501053834	MALE QUICK COUPLER	55	02
25	0531011180	UPPER BODY CLIP		08
26	0503010180	7/16" SPRING WASHER		08
27	0511011311	VALVE SUPPORT		01
28	0511059271	HYDRAULIC MARKER HAND SET		01
28A	0501081731	3/8 X 3550 TR-TR HOSE		02
28B	0501081732	3/8" X 3750 TR-TR HOSE		02
28C	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01


**SEMI-ASSEMBLED HYDRAULIC MARKER 5345**

0511051119


Item	Code	Description	See page	QT
28D	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
29	0503011103	7/16" X 2-1/2" BOLT		08
30	0502012702	BODY SUPPORT CLAMP		08
31	0503010244	7/16" NUT		08
32	0503010232	5/8" X 1.3/4" BOLT		02
33	0503010027	5/8" SPRING WASHER		02
34	0503010013	5/8" NUT		02

HYDRAULIC CYLINDER


0511058449




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02



Item	Code	Description	See page	QT
01	0501081727	TR-TR HOSE ASSY		02
02	0501080447	3/8" X 122" TR-TC HOSE ASSY		02
03	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
03A	0501080422	HOSE 3/8 X 4000 TC-TM		01
03B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
03C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
03D	0503018952	PLASTIC BOLT		06
04	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
04A	0501080422	HOSE 3/8 X 4000 TC-TM		01
04B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
04C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
04D	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	DIR	ESQ
01	0511052419	RH BEAM SUPPORT		01	00
01A	0521063542	FERTILIZER BEAN RIGHT SUPPORT		01	00
02	0511052420	LH BEAM SUPPORT & METERING		00	01
02A	0521063543	FERTILIZER BEAN LEFT SUPPORT		00	01
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	82	00	04
04	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	83	04	00
05	0501010942	3/8" X 1-1/4" BOLT		16	16
06	0503011443	3/8" SPRING WASHER		16	16
07	0503010026	3/8" NUT		16	16
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01	01
09	0521014167	CONE LOCK		01	01
10	0503030275	AGRICULTURAL BEARING		04	04
11	0502010685	18Z CONICAL GEAR		04	04
12	0561018362	SQUARE SHAFT		01	01
13	0501053788	3/4 SQUARE AXLE FASTENER	84	02	02
14	0501110392	SILO SUPPORT BEARING		01	01
15	0521012485	GEAR BOX BEARING AGRICUTURAL		01	01
16	0503011953	5/16" X 1" BOLT		02	02
17	0501010694	FLAT WASHER		02	02
18	0521011039	FLAT WASHER		02	02
19	0503011444	SPRING WASHER		02	02
20	0503010337	5/16" NUT		02	02
21	0551018055	22,65 X 60 SLEEVE		02	02
22	0503010003	1845 GREASE FITTING		01	01
23	0503010849	3/8" X 1-1/2" BOLT		08	08
24	0501010984	FLAT WASHER		17	17
25	0503010025	3/8" SPRING WASHER		08	08
26	0503010026	3/8" NUT		08	08
27	0571010590	FERTILIZER SIDE COVER		04	04
28	0503010362	1/8" X 1.1/4" COTTERPIN		04	04
29	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		01	01

SET SUPPORT RIGHT LEFT


0511057235

Item	Code	Description	See page	DIR	ESQ
30	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02	02
31	0551019156	GEAR BOX LEVER LOCK		01	01
32	0503011953	5/16" X 1" BOLT		02	02
33	0501010694	FLAT WASHER		02	02
34	0503010179	LOCK WASHER		02	02
35	0503010337	5/16" NUT		02	02
36	0503010847	1/2" X 3.1/4" BOLT		01	01
37	0551019168	SLEEVE		01	01
38	0551019160	LEVER		01	01
39	0511017302	FLAT WASHER		03	03
40	0503010019	1/2" SPRING WASHER		02	02
41	0503010060	1/2" NUT		01	01
42	0551019167	SLEEVE UNION		01	01
43	0511069676	INNER LEVER		01	01
44	0501013518	FLAT WASHER		02	02
45	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01	01
46	0503010140	1/8" X 3/4" COTTERPIN		03	03
47	0511069678	LH LOWER LEVER		02	02
48	0503011336	1/2" HEX SELF ADJUSTING NUT		02	02
49	0551019115	LOCKING PLATFORM FIXATION		01	01
50	0501010096	3/8" X 2" BOLT		01	01
51	0503013357	3/8" SELF-ADJUSTING NUT		01	01
52	0551019159	LEVER FIXER BODY		01	01
53	0561016468	FASTENER		01	01



Item	Code	Description	See page	QT
01	0511051968	RIGHT SILO SUPPORT WITH DISTRIBUTOR 8	74	01
02	0511051969	LEFT SILO SUPPORT WITH DISTRIBUTOR 8	75	01
03	0503010849	3/8" X 1-1/2" BOLT		08
04	0501010984	FLAT WASHER		16
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0503034396	FERTILIZER SIDE COVER		08
08	0503010362	1/8" X 1.1/4" COTTERPIN		08
09	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		02
10	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
11	0503010849	3/8" X 1-1/2" BOLT		08
12	0501010984	FLAT WASHER		16
13	0503010025	3/8" SPRING WASHER		08
14	0503010026	3/8" NUT		08
15	0551019156	GEAR BOX LEVER LOCK		02
16	0503011953	5/16" X 1" BOLT		04
17	0501010694	FLAT WASHER		04
18	0503010179	LOCK WASHER		04
19	0503010337	5/16" NUT		04
20	0503010847	1/2" X 3.1/4" BOLT		02
21	0551019168	SLEEVE		02
22	0551019160	LEVER		02
23	0511017302	FLAT WASHER		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0551019167	SLEEVE UNION		02
27	0511069676	INNER LEVER		02
28	0511017302	FLAT WASHER		02
29	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
30	0511017302	FLAT WASHER		02
31	0503010019	1/2" SPRING WASHER		02

Item	Code	Description	See page	QT
32	0503010060	1/2" NUT		02
33	0501013518	FLAT WASHER		02
34	0503010140	1/8" X 3/4" COTTERPIN		02
35	0511069678	LH LOWER LEVER		02
36	0551019159	LEVER FIXER BODY		02
37	0561016468	FASTENER		02
38	0503011336	1/2" HEX SELF ADJUSTING NUT		04
39	0551019115	LOCKING PLATFORM FIXATION		02
40	0501010096	3/8" X 2" BOLT		02
41	0501010984	FLAT WASHER		02
42	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	DIR	ESQ
01	0511052253	RH BEAM SUPPORT & METERING		01	00
01A	0521063436	FERTILIZER BEAN RIGHT SUPPORT		01	00
02	0511052254	LH BEAM SUPPORT & METERING		00	01
02A	0521063437	FERTILIZER BEAN LEFT SUPPORT		00	01
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	82	00	05
04	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	83	05	00
05	0501010942	3/8" X 1-1/4" BOLT		20	20
06	0503011443	3/8" SPRING WASHER		20	20
07	0503010026	3/8" NUT		20	20
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01	01
09	0521014167	CONE LOCK		01	01
10	0503030275	AGRICULTURAL BEARING		05	05
11	0502010685	18Z CONICAL GEAR		05	05
12	0551018213	3/4" X 1830 SQUARE SHAFT		01	01
13	0521010691	AXLE FASTENER		02	02
14	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02	02
15	0501010694	FLAT WASHER		02	02
16	0503011441	SPRING WASHER		02	02
17	0503010144	1/4" NUT		02	02
18	0501110392	SILO SUPPORT BEARING		01	01
19	0521012485	GEAR BOX BEARING AGRICUTURAL		01	01
20	0503011953	5/16" X 1" BOLT		02	02
21	0501010694	FLAT WASHER		02	02
22	0521011039	FLAT WASHER		02	02
23	0503011444	SPRING WASHER		02	02
24	0503010337	5/16" NUT		02	02
25	0551018055	22,65 X 60 SLEEVE		01	01
26	0503010003	1845 GREASE FITTING		01	01
27	0503010849	3/8" X 1-1/2" BOLT		08	08
28	0501010984	FLAT WASHER		17	17
29	0503010025	3/8" SPRING WASHER		08	08

SET SUPPORT RIGHT LEFT

0511057128

Item	Code	Description	See page	DIR	ESQ
30	0503010026	3/8" NUT		08	08
31	0503034396	FERTILIZER SIDE COVER		05	05
32	0503010362	1/8" X 1.1/4" COTTERPIN		05	05
33	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		01	01
34	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02	02
35	0551019156	GEAR BOX LEVER LOCK		01	01
36	0503011953	5/16" X 1" BOLT		02	02
37	0501010694	FLAT WASHER		02	02
38	0503010179	LOCK WASHER		02	02
39	0503010337	5/16" NUT		02	02
40	0503010847	1/2" X 3.1/4" BOLT		01	01
41	0551019168	SLEEVE		01	01
42	0511069678	LH LOWER LEVER		01	01
43	0511017302	FLAT WASHER		03	03
44	0503010019	1/2" SPRING WASHER		02	02
45	0503010060	1/2" NUT		02	02
46	0551019167	SLEEVE UNION		01	01
47	0511069678	LH LOWER LEVER		01	01
48	0501013518	FLAT WASHER		02	02
49	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01	01
50	0503010140	1/8" X 3/4" COTTERPIN		03	03
51	0511069678	LH LOWER LEVER		02	02
52	0503011336	1/2" HEX SELF ADJUSTING NUT		02	02
53	0551019115	LOCKING PLATFORM FIXATION		01	01
54	0501010096	3/8" X 2" BOLT		01	01
55	0503013357	3/8" SELF-ADJUSTING NUT		01	01
56	0551019159	LEVER FIXER BODY		01	01
57	0561016468	FASTENER		01	01




Item	Code	Description	See page	DIR	ESQ
01	0511053240	RIGHT SILO SUPPORT WITH DISTRIBUTOR 10	76	01	00
02	0511053241	LEFT SILO SUPPORT WITH DISTRIBUTOR 10	77	00	01
03	0503010849	3/8" X 1-1/2" BOLT		08	08
04	0501010984	FLAT WASHER		17	17
05	0503010025	3/8" SPRING WASHER		08	08
06	0503010026	3/8" NUT		08	08
07	0571010590	FERTILIZER SIDE COVER		05	05
08	0503010362	1/8" X 1.1/4" COTTERPIN		05	05
09	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		01	01
10	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02	02
11	0551019156	GEAR BOX LEVER LOCK		01	01
12	0503011953	5/16" X 1" BOLT		02	02
13	0501010694	FLAT WASHER		02	02
14	0503010179	LOCK WASHER		02	02
15	0503010337	5/16" NUT		02	02
16	0503010847	1/2" X 3.1/4" BOLT		01	01
17	0551019168	SLEEVE		01	01
18	0551019160	LEVER		01	01
19	0511017302	FLAT WASHER		03	03
20	0503010019	1/2" SPRING WASHER		02	02
21	0503010060	1/2" NUT		02	02
22	0551019167	SLEEVE UNION		01	01
23	0511069676	INNER LEVER		01	01
24	0501013518	FLAT WASHER		02	02
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01	01
26	0503010140	1/8" X 3/4" COTTERPIN		03	03
27	0511069678	LH LOWER LEVER		02	02
28	0503011336	1/2" HEX SELF ADJUSTING NUT		02	02
29	0551019115	LOCKING PLATFORM FIXATION		01	01
30	0501010096	3/8" X 2" BOLT		01	01
31	0503013357	3/8" SELF-ADJUSTING NUT		01	01



SET SUPPORT RIGHT LEFT


0511057564

Item	Code	Description	See page	DIR	ESQ
32	0551019159	LEVER FIXER BODY		01	01
33	0561016468	FASTENER		01	01



Item	Code	Description	See page	QT
01	0501058206	RIGHT SILO SUPPORT WITH DISTRIBUTOR 11	78	01
02	0501058207	LEFT SILO SUPPORT WITH DISTRIBUTOR 11	79	01
03	0503062169	SILO FERTILIZER 6 MOUTHS MOUNTED		02
04	0503010849	3/8" X 1-1/2" BOLT		12
05	0501010984	FLAT WASHER		24
06	0503010025	3/8" SPRING WASHER		12
07	0503010026	3/8" NUT		12
08	0503034396	FERTILIZER SIDE COVER		12
09	0503010362	1/8" X 1.1/4" COTTERPIN		12
10	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
11	0503010849	3/8" X 1-1/2" BOLT		08
12	0501010984	FLAT WASHER		16
13	0503010025	3/8" SPRING WASHER		08
14	0503010026	3/8" NUT		08
15	0551019156	GEAR BOX LEVER LOCK		02
16	0503011953	5/16" X 1" BOLT		04
17	0501010694	FLAT WASHER		04
18	0503010179	LOCK WASHER		04
19	0503010337	5/16" NUT		04
20	0551019160	LEVER		02
21	0551019168	SLEEVE		02
22	0503010847	1/2" X 3.1/4" BOLT		02
23	0511017302	FLAT WASHER		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501013518	FLAT WASHER		02
27	0503010140	1/8" X 3/4" COTTERPIN		02
28	0511069676	INNER LEVER		02
29	0551019167	SLEEVE UNION		02
30	0511017302	FLAT WASHER		02
31	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02


Item	Code	Description	See page	QT
32	0503010019	1/2" SPRING WASHER		02
33	0503010060	1/2" NUT		02
34	0511069678	LH LOWER LEVER		02
35	0501013518	FLAT WASHER		02
36	0503010140	1/8" X 3/4" COTTERPIN		04
37	0551019159	LEVER FIXER BODY		02
38	0561016468	FASTENER		02
39	0503011336	1/2" HEX SELF ADJUSTING NUT		04
40	0551019115	LOCKING PLATFORM FIXATION		02
41	0501010096	3/8" X 2" BOLT		02
42	0501010984	FLAT WASHER		02
43	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0511051120	RIGHT BEAM SUPPORT WITH DISTRIBUTOR 12	80	01
02	0511051121	LEFT BEAM SUPPORT WITH DISTRIBUTOR 12	81	01
03	0503062169	SILO FERTILIZER 6 MOUTHS MOUNTED		02
04	0503010849	3/8" X 1-1/2" BOLT		20
05	0501010984	FLAT WASHER		42
06	0503010025	3/8" SPRING WASHER		20
07	0503010026	3/8" NUT		20
08	0503034396	FERTILIZER SIDE COVER		12
09	0503010362	1/8" X 1.1/4" COTTERPIN		12
10	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
11	0551019156	GEAR BOX LEVER LOCK		02
12	0503011953	5/16" X 1" BOLT		04
13	0501010694	FLAT WASHER		04
14	0503010179	LOCK WASHER		04
15	0503010337	5/16" NUT		04
16	0551019160	LEVER		02
17	0551019168	SLEEVE		02
18	0503010847	1/2" X 3.1/4" BOLT		02
19	0511017302	FLAT WASHER		06
20	0503010019	1/2" SPRING WASHER		04
21	0503010060	1/2" NUT		04
22	0511069676	INNER LEVER		02
23	0551019167	SLEEVE UNION		02
24	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
25	0511069678	LH LOWER LEVER		02
26	0501013518	FLAT WASHER		06
27	0503010140	1/8" X 3/4" COTTERPIN		06
28	0551019159	LEVER FIXER BODY		02
29	0561016468	FASTENER		02
30	0503011336	1/2" HEX SELF ADJUSTING NUT		04
31	0551019115	LOCKING PLATFORM FIXATION		02




Item	Code	Description	See page	QT
32	0501010096	3/8" X 2" BOLT		02
33	0503013357	3/8" SELF-ADJUSTING NUT		02



Item	Code	Description	See page	QT
01	0521063255	FERTILIZER BEAM SUPPORT		01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	82	02
03	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	83	02
04	0501010942	3/8" X 1-1/4" BOLT		16
05	0503011443	3/8" SPRING WASHER		16
06	0503010026	3/8" NUT		16
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		04
10	1902010685	18Z CONICAL GEAR		04
11	0501018695	3/4" X 63"SQUARE SHAFT		01
12	0521010691	AXLE FASTENER		02
13	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
14	0501010694	FLAT WASHER		02
15	0503011441	SPRING WASHER		02
16	0503010144	1/4" NUT		02
17	0501110392	SILO SUPPORT BEARING		01
18	0521012485	GEAR BOX BEARING AGRICUTURAL		01
19	0503011953	5/16" X 1" BOLT		02
20	0501010694	FLAT WASHER		02
21	0521011039	FLAT WASHER		02
22	0503011444	SPRING WASHER		02
23	0503010337	5/16" NUT		02
24	0551018055	22,65 X 60 SLEEVE		01
25	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521063261	FERTILIZER BEAM SUPPORT		01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	82	02
03	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	83	02
04	0501010942	3/8" X 1-1/4" BOLT		16
05	0503011443	3/8" SPRING WASHER		16
06	0503010026	3/8" NUT		16
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		04
10	1902010685	18Z CONICAL GEAR		04
11	0501018695	3/4" X 63"SQUARE SHAFT		01
12	0521010691	AXLE FASTENER		02
13	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
14	0501010694	FLAT WASHER		02
15	0503011441	SPRING WASHER		02
16	0503010144	1/4" NUT		02
17	0501110392	SILO SUPPORT BEARING		01
18	0521012485	GEAR BOX BEARING AGRICUTURAL		01
19	0503011953	5/16" X 1" BOLT		02
20	0501010694	FLAT WASHER		02
21	0521011039	FLAT WASHER		02
22	0503011444	SPRING WASHER		02
23	0503010337	5/16" NUT		02
24	0551018055	22,65 X 60 SLEEVE		01
25	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521064058	FERTILIZER BEAN RIGHT SUPPORT		01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	82	03
03	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	83	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		05
10	1902010685	18Z CONICAL GEAR		05
11	0571013830	SQUARE SHAFT		01
12	0521010691	AXLE FASTENER		02
13	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
14	0501010694	FLAT WASHER		02
15	0503011441	SPRING WASHER		02
16	0503010144	1/4" NUT		02
17	0501110392	SILO SUPPORT BEARING		01
18	0521012485	GEAR BOX BEARING AGRICUTURAL		01
19	0503011953	5/16" X 1" BOLT		02
20	0501010694	FLAT WASHER		02
21	0521011039	FLAT WASHER		02
22	0503011444	SPRING WASHER		02
23	0503010337	5/16" NUT		02
24	0551018055	22,65 X 60 SLEEVE		01
25	0503010003	1845 GREASE FITTING		01

LEFT SILO SUPPORT WITH DISTRIBUTOR 10

0511053241




Item	Code	Description	See page	QT
01	0521064059	FERTILIZER BEAN LEFT SUPPORT		01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	82	02
03	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	83	03
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		05
10	1902010685	18Z CONICAL GEAR		05
11	0571013830	SQUARE SHAFT		01
12	0521010691	AXLE FASTENER		02
13	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
14	0501010694	FLAT WASHER		02
15	0503011441	SPRING WASHER		02
16	0503010144	1/4" NUT		02
17	0501110392	SILO SUPPORT BEARING		01
18	0521012485	GEAR BOX BEARING AGRICUTURAL		01
19	0503011953	5/16" X 1" BOLT		02
20	0501010694	FLAT WASHER		02
21	0521011039	FLAT WASHER		02
22	0503011444	SPRING WASHER		02
23	0503010337	5/16" NUT		02
24	0551018055	22,65 X 60 SLEEVE		01
25	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521066242	FERTILIZER BEAN RIGHT SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	83	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	82	03
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503011443	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		06
10	1902010685	18Z CONICAL GEAR		06
11	0511014265	3/4" X 86" SQUARE SHAFT		01
12	0501053788	3/4 SQUARE AXLE FASTENER	84	02
13	0501110392	SILO SUPPORT BEARING		01
14	0521012485	GEAR BOX BEARING AGRICUTURAL		01
15	0503011953	5/16" X 1" BOLT		02
16	0521011039	FLAT WASHER		02
17	0503011444	SPRING WASHER		02
18	0503010337	5/16" NUT		02
19	0551018055	22,65 X 60 SLEEVE		01
20	0503010003	1845 GREASE FITTING		01

LEFT SILO SUPPORT WITH DISTRIBUTOR 11


0501058207



Item	Code	Description	See page	QT
01	0521066241	FERTILIZER BEAN LEFT SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	83	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	82	03
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503011443	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		06
10	1902010685	18Z CONICAL GEAR		06
11	0511014265	3/4" X 86" SQUARE SHAFT		01
12	0501053788	3/4 SQUARE AXLE FASTENER	84	02
13	0501110392	SILO SUPPORT BEARING		01
14	0521012485	GEAR BOX BEARING AGRICUTURAL		01
15	0503011953	5/16" X 1" BOLT		02
16	0521011039	FLAT WASHER		02
17	0503011444	SPRING WASHER		02
18	0503010337	5/16" NUT		02
19	0551018055	22,65 X 60 SLEEVE		01
20	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	82	01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	83	05
03	0511061759	22Z P12,70 FQ 3/4" GEAR		01
04	0521014167	CONE LOCK		01
05	0503030275	AGRICULTURAL BEARING		06
06	0502010685	18Z CONICAL GEAR		06
07	0551018198	SQUARE SHAFT		01
08	0501053788	3/4 SQUARE AXLE FASTENER	84	02
09	0501110392	SILO SUPPORT BEARING		01
10	0521012485	GEAR BOX BEARING AGRICUTURAL		01
11	0503010003	1845 GREASE FITTING		01
12	0551018055	22,65 X 60 SLEEVE		01
13	0521066239	RIGHT SUPPORT SILO FERTILIZER 12		01
14	0501010694	FLAT WASHER		02
15	0521011039	FLAT WASHER		02
16	0503010337	5/16" NUT		02
17	0503010179	LOCK WASHER		02
18	0503011953	5/16" X 1" BOLT		02
19	0501010942	3/8" X 1-1/4" BOLT		24
20	0503010025	3/8" SPRING WASHER		24
21	0503010026	3/8" NUT		24




Item	Code	Description	See page	QT
01	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	82	03
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	83	03
03	0521014167	CONE LOCK		01
04	0503030275	AGRICULTURAL BEARING		06
05	0502010685	18Z CONICAL GEAR		06
06	0551018198	SQUARE SHAFT		01
07	0501053788	3/4 SQUARE AXLE FASTENER	84	02
08	0501110392	SILO SUPPORT BEARING		01
09	0521012485	GEAR BOX BEARING AGRICUTURAL		01
10	0503010003	1845 GREASE FITTING		01
11	0551018055	22,65 X 60 SLEEVE		01
12	0521066240	LEFT SUPPORT SILO FERTILIZER 12		01
13	0511061759	22Z P12,70 FQ 3/4" GEAR		01
14	0501010942	3/8" X 1-1/4" BOLT		24
15	0503010025	3/8" SPRING WASHER		24
16	0503010026	3/8" NUT		24
17	0503011953	5/16" X 1" BOLT		02
18	0501010694	FLAT WASHER		02
19	0521011039	FLAT WASHER		02
20	0503010337	5/16" NUT		02
21	0503010179	LOCK WASHER		02

LEFT SIDE FERTILIZER DISTRIBUTOR


0511051558




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	FLAT WASHER	16	
04	0503010025	3/8" SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0511069725	RIGHT PLATFORM	01	
07	0521062318	LEFT PLATFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	FLAT WASHER	16	
04	0503010025	3/8" SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0521063248	RIGHT PLATFORM	01	
07	0521063249	LEFT PLATFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	FLAT WASHER	16	
04	0503010025	3/8" SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0511069665	PLATFORM RIGHT	01	
07	0521062323	PLATFORM LEFT	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	FLAT WASHER	16	
04	0503010025	3/8" SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0521062237	RIGHT PLATAFORM	01	
07	0521062238	LEFT PLATAFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT		04
02	0503010849	3/8" X 1-1/2" BOLT		08
03	0501010984	FLAT WASHER		16
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0511069718	PLATFORM RIGHT		01
07	0521062324	PLATFORM LEFT		01
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
09	0503011336	1/2" HEX SELF ADJUSTING NUT		04
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
13	0502012739	PLATFORM LEFT FIXER SUPPORT		01




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	FLAT WASHER	16	
04	0503010025	3/8" SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0521062450	RIGHT PLATFORM	01	
07	0521062451	LEFT PLATFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069635	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0521063250	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0511069656	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0521062239	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0511069660	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0521062449	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012329	DRAWBAR FIXATION REAR SUPPORT		02
02	0502012330	SUPPORT FIXER PIVOT		04
03	0503011084	3/4" X 5" BOLT		08
04	0501010322	FLAT WASHER		08
05	0503010023	3/4" SPRING WASHER		08
06	0503010014	3/4" NUT		08
07	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02
08	0561014393	COUPLING SHAFT		02
09	0503030119	LOCK PIN		04
10	0531063130	HEADER		01
11	0561019087	DRAWBAR TRANSPORT LOCK		01
12	0521010578	COUPLING SHAFT		01
13	0521010588	0.9" X 7.0" COUPLING SHAFT		01
14	0503030085	LOCK PIN		02
15	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	1902012329	REAR SUPPORT FIXING HEADER	04	
02	1902012330	FIXER SUPPORT ARTICULATED	08	
03	0503011084	3/4" X 5" BOLT	16	
04	0503010023	3/4" SPRING WASHER	16	
05	0503010014	3/4" NUT	16	
06	1902012328	FIXED FRONT SUPPORT HEADER	04	
07	0561014393	COUPLING SHAFT	04	
08	0503030119	LOCK PIN	08	
09	0511064808	DRAWBAR	01	
10	0561019087	DRAWBAR TRANSPORT LOCK	01	
11	0521010588	0.9" X 7.0" COUPLING SHAFT	01	
12	0521010578	COUPLING SHAFT	01	
13	0503030085	LOCK PIN	02	
14	0503010002	1800 GREASE FITTING	01	
15	0501010322	FLAT WASHER	16	




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033416	ADHESIVE LABEL	02	
05	0503033417	ADHESIVE LABEL	02	
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	02	
07	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
08	0503033424	DIRECT PLANTIO ADHESIVE LABEL	02	
09	0503033008	ADHESIVE LABEL	02	
10	0503031428	READ MANUAL DECAL	01	
11	0503031942	ADHESIVE LABEL	01	
12	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
13	0503031565	ADHESIVE LABEL CARE	02	
14	0503031566	ADHESIVE LABEL	02	
15	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
16	0503031425	ADHESIVE LABEL ATTENTION	02	
17	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO	02	
18	0503031669	ADHESIVE LABEL	01	
19	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
20	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
21	0503032930	ADHESIVE LABEL DANGER	04	
22	0503031087	ADHESIVE LABEL	01	
23	0503034003	SERIAL NUMBER TAG 61 X 118	01	
24	0503010001	3.2 X 5.5 RIVET	04	
25	0503034078	LIFTING POINTS DECAL	03	
26	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
27	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0503033854	ADHESIVE LABEL	02	
02	0503033853	ADHESIVE LABEL	02	
03	0503033417	ADHESIVE LABEL	02	
04	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
05	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING	02	
06	0503033423	LABEL ADHESIVE NUMBER 9	02	
07	0503033424	DIRECT PLANTIO ADHESIVE LABEL	02	
08	0503033008	ADHESIVE LABEL	02	
09	0503031428	READ MANUAL DECAL	01	
10	0503031942	ADHESIVE LABEL	01	
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
12	0503031565	ADHESIVE LABEL CARE	02	
13	0503031566	ADHESIVE LABEL	02	
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
15	0503031425	ADHESIVE LABEL ATTENTION	02	
16	0503031669	ADHESIVE LABEL	01	
17	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
19	0503032930	ADHESIVE LABEL DANGER	04	
20	0503031087	ADHESIVE LABEL	01	
21	0503034078	LIFTING POINTS DECAL	03	
22	0503034003	SERIAL NUMBER TAG 61 X 118	01	
23	0503010001	3.2 X 5.5 RIVET	04	
24	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
25	0503034500	ADHESIVE LABEL	01	
26	0503033869	ADHESIVE LABEL	02	




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL		02
02	0503033854	ADHESIVE LABEL		02
03	0503033853	ADHESIVE LABEL		02
04	0503033417	ADHESIVE LABEL		02
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
06	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING		02
07	0503033423	LABEL ADHESIVE NUMBER 9		02
08	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
09	0503033008	ADHESIVE LABEL		02
10	0503031428	READ MANUAL DECAL		01
11	0503031942	ADHESIVE LABEL		01
12	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
13	0503031565	ADHESIVE LABEL CARE		02
14	0503031566	ADHESIVE LABEL		02
15	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
16	0503031425	ADHESIVE LABEL ATTENTION		02
17	0503031567	ADHESIVE LABEL ATTENTION		02
18	0503031669	ADHESIVE LABEL		01
19	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
20	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
21	0503032930	ADHESIVE LABEL DANGER		04
22	0503031087	ADHESIVE LABEL		01
23	0503034078	LIFTING POINTS DECAL		03
24	0503034003	SERIAL NUMBER TAG 61 X 118		01
25	0503010001	3.2 X 5.5 RIVET		04
26	0503032979	ADHESIVE LABEL LETTERS A B C D		02
27	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING	02	
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
07	0503033424	DIRECT PLANTIO ADHESIVE LABEL	02	
08	0503033008	ADHESIVE LABEL	02	
09	0503031428	READ MANUAL DECAL	01	
10	0503031942	ADHESIVE LABEL	01	
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
12	0503031565	ADHESIVE LABEL CARE	02	
13	0503031566	ADHESIVE LABEL	02	
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
15	0503031425	ADHESIVE LABEL ATTENTION	02	
16	0503031669	ADHESIVE LABEL	01	
17	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
19	0503032930	ADHESIVE LABEL DANGER	05	
20	0503031087	ADHESIVE LABEL	01	
21	0503034003	SERIAL NUMBER TAG 61 X 118	01	
22	0503010001	3.2 X 5.5 RIVET	04	
23	0503034078	LIFTING POINTS DECAL	03	
24	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
25	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL		02
02	0503033854	ADHESIVE LABEL		02
03	0503033853	ADHESIVE LABEL		02
04	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
07	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
08	0503033008	ADHESIVE LABEL		02
09	0503031428	READ MANUAL DECAL		01
10	0503031942	ADHESIVE LABEL		01
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
12	0503031565	ADHESIVE LABEL CARE		02
13	0503031566	ADHESIVE LABEL		02
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
15	0503031425	ADHESIVE LABEL ATTENTION		02
16	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
17	0503031669	ADHESIVE LABEL		01
18	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
19	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
20	0503032930	ADHESIVE LABEL DANGER		05
21	0503031087	ADHESIVE LABEL		01
22	0503034078	LIFTING POINTS DECAL		03
23	0503034003	SERIAL NUMBER TAG 61 X 118		01
24	0503010001	3.2 X 5.5 RIVET		04
25	0503032979	ADHESIVE LABEL LETTERS A B C D		02
26	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL		02
02	0503033854	ADHESIVE LABEL		02
03	0503033853	ADHESIVE LABEL		02
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
06	0503033423	LABEL ADHESIVE NUMBER 9		02
07	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
08	0503033008	ADHESIVE LABEL		02
09	0503031428	READ MANUAL DECAL		01
10	0503031942	ADHESIVE LABEL		01
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
12	0503031565	ADHESIVE LABEL CARE		02
13	0503031566	ADHESIVE LABEL		02
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
15	0503031425	ADHESIVE LABEL ATTENTION		02
16	0503031669	ADHESIVE LABEL		01
17	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
18	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
19	0503032930	ADHESIVE LABEL DANGER		05
20	0503031087	ADHESIVE LABEL		01
21	0503034078	LIFTING POINTS DECAL		03
22	0503034003	SERIAL NUMBER TAG 61 X 118		01
23	0503010001	3.2 X 5.5 RIVET		04
24	0503032979	ADHESIVE LABEL LETTERS A B C D		02
25	0503034500	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
06	0503033423	LABEL ADHESIVE NUMBER 9	02	
07	0503033424	DIRECT PLANTIO ADHESIVE LABEL	02	
08	0503033008	ADHESIVE LABEL	02	
09	0503031428	READ MANUAL DECAL	01	
10	0503031942	ADHESIVE LABEL	01	
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
12	0503031565	ADHESIVE LABEL CARE	02	
13	0503031566	ADHESIVE LABEL	02	
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
15	0503031425	ADHESIVE LABEL ATTENTION	02	
16	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO	02	
17	0503031669	ADHESIVE LABEL	01	
18	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
19	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
20	0503032930	ADHESIVE LABEL DANGER	04	
21	0503031087	ADHESIVE LABEL	01	
22	0503034003	SERIAL NUMBER TAG 61 X 118	01	
23	0503010001	3.2 X 5.5 RIVET	04	
24	0503034078	LIFTING POINTS DECAL	03	
25	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
26	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
06	0503033422	ADHESIVE LABEL	02	
07	0503033424	DIRECT PLANTIO ADHESIVE LABEL	02	
08	0503033008	ADHESIVE LABEL	02	
09	0503031428	READ MANUAL DECAL	01	
10	0503031942	ADHESIVE LABEL	01	
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
12	0503031565	ADHESIVE LABEL CARE	02	
13	0503031566	ADHESIVE LABEL	02	
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
15	0503031425	ADHESIVE LABEL ATTENTION	02	
16	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO	02	
17	0503031669	ADHESIVE LABEL	01	
18	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
19	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
20	0503032930	ADHESIVE LABEL DANGER	06	
21	0503031087	ADHESIVE LABEL	01	
22	0503034078	LIFTING POINTS DECAL	03	
23	0503034003	SERIAL NUMBER TAG 61 X 118	01	
24	0503010001	3.2 X 5.5 RIVET	04	
25	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
26	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033417	ADHESIVE LABEL	02	
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	02	
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	04	
07	0503033424	DIRECT PLANTIO ADHESIVE LABEL	02	
08	0503033008	ADHESIVE LABEL	02	
09	0503031428	READ MANUAL DECAL	01	
10	0503031942	ADHESIVE LABEL	01	
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
12	0503031565	ADHESIVE LABEL CARE	02	
13	0503031566	ADHESIVE LABEL	02	
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
15	0503031425	ADHESIVE LABEL ATTENTION	02	
16	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO	02	
17	0503031669	ADHESIVE LABEL	01	
18	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
19	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
20	0503032930	ADHESIVE LABEL DANGER	06	
21	0503031087	ADHESIVE LABEL	01	
22	0503034078	LIFTING POINTS DECAL	03	
23	0503034003	SERIAL NUMBER TAG 61 X 118	01	
24	0503010001	3.2 X 5.5 RIVET	04	
25	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
26	0503034500	ADHESIVE LABEL	01	

ASSY HEX AXLE


0909098921




Item	Code	Description	See page	3695	4045	4495	4845	5345
01	0571011601	SEXT AXIS 5/8 X 2005 PST4 8 S-0812	01	00	00	00	00	00
01.	0521013429	AXLE HEX 5/8 X 2180	00	01	00	00	00	00
01..	0561018352	RIGHT HEX SHAFT 5/8 X 2375	00	00	01	00	00	00
01...	0521013430	HEX AXLE 5/8 X 2580	00	00	00	01	00	00
01....	0561019214	HEX AXLE 5/8 X 2805 RIGHT	00	00	00	00	00	01
02	0571011600	SIXTH AXIS 5/8 X 1725	01	00	00	00	00	00
02.	0521013433	5/8" X 75" AXLE HEX	00	01	00	00	00	00
02..	0561018353	5/8 X 2150 LEFT HEX AXLE	00	00	01	00	00	00
02...	0521013434	HEX AXLE 5/8 X 2300	00	00	00	00	01	00
02....	0561019215	HEX AXLE 5/8 X 2555 LEFT	00	00	00	00	00	01
03	0503010571	1/4" X 1.1/2 COTTERPIN	02	02	02	02	02	02
04	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"	02	02	02	02	02	02
05	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8	02	02	02	02	02	02
06	0503010003	1845 GREASE FITTING	02	02	02	02	02	02
07	0503010365	NUT	04	04	04	04	04	04
08	0501010984	FLAT WASHER	04	04	04	04	04	04
09	0501010694	FLAT WASHER	08	08	08	08	08	08
10	0503010179	LOCK WASHER	04	04	04	04	04	04
11	0503010337	5/16" NUT	04	04	04	04	04	04
12	0511015098	FLAT WASHER	02	02	02	02	02	02
13	0511017305	FLAT WASHER	04	04	04	04	04	04
14	0511065562	20Z GEAR	02	02	02	02	02	02
15	0502011299	BUSHING GEAR	02	02	02	02	02	02
16	0503010010	1/4" X 2.1/2" COTTERPIN	02	02	02	02	02	02



Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0511062887	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HAIR PIN		01

HOSE SUPPORT


0511056736



Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01



Item	Code	Description	See page	QT
01	0521066608	LIFTING HOOK		01
02	0581019707	FIXATION SUPPORT SUPPORT		01
03	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
04	0501012140	FLAT WASHER		04
05	0503012412	5/8 UNC SELF LOCKING NUT		04




Item	Code	Description	See page	QT
01	0511053254	SHORT FERTILIZER LINE DDD LEFT DC20	118	01
01.	0531050532	SHORT FERTILIZER LOWER LEFT DDD DC20	119	01
02	0511050967	SHORT FERTILIZER ROW	120	01
03	0521051039	SHORT FERTILIZER LINE DDD LEFT DOC20	121	01
04	0511053255	LONG FERTILIZER LINE DDD RIGHT DC20	122	01
04.	0531050534	RIGHT LONGER FERTILIZER DDD RIGHT DC20	123	01
05	0511050968	LONG FERTILIZER ROW	124	01
06	0521051041	LONG FERTILIZER LINE DDD RIGHT DOC20	125	01
07	0501058271	SHORT FERTILIZER LINE S/DDD/H	126	01
08	0501058272	LONG FERTILIZER LINE S/DDD/H	127	01
09	0511053253	RIGHT FERTILIZER LINE DDD RIGHT	128	01
10	0511053252	SHORT FERTILIZER LINE DDD LEFT	129	01
11	0511056554	SHORT SEED ROW FRONT	147	01
12	0511056555	LONG SEED ROW FRONT	148	01
13	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	149	01
13.	0521051424	WHEEL SYSTEM DEPTH/COMPACTOR QUICK ADJUSTMENT	159	01
13..	0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	164	01
13...	0521042327	DEPTH CONTROL & PRESS WHEEL ASSY	173	01
14	0501110231	SCARIFIER HEAD WITH SPIKE 0061	175	01
15	0511017969	0.1" SPACING PLATE		01
16	0521069124	BOCAL FILLED LINE PIVOTED WITH LINGUET		01
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
18	0501010984	FLAT WASHER		01
19	0503010025	3/8" SPRING WASHER		01
20	0503010026	3/8" NUT		01
21	0503010905	1/2" X 2-1/4" BOLT		01
22	0503010019	1/2" SPRING WASHER		01
23	0503010060	1/2" NUT		01
24	0503016204	CORN DISK 12 ORANGE		01
25	0503016218	DISC OF SOYBEAN		01


SEED LINE/FERTILIZER ASSEMBLY

0909098922


Item	Code	Description	See page	QT
26	0503016214	RING CORN (APOLLO740)		01
27	0503016220	RING TO SOYBEANS (APOLLO 745)		01
28	0503016221	RING TO SOYBEANS (APOLLO 571)		01
29	0501050120	LARGER WALKING BEAM ASSY	176	01
30	0503030558	PULLEY 4Z CORN PLASTIC		01
31	0501053866	COVERING WHEEL FERTILIZER V RIGHT IRON	177	01
32	0501053867	COVERING V WHEEL FERTILIZER LEFT IRON	178	01
33	0503030391	RIGHT FERTILIZER NOZZLE		01
34	0503030392	LEFT FERTILIZER NOZZLE		01
35	0501013714	STABILIZER BAR		01
36	0503031050	CURVED CONDUCTOR		01
37	0503010246	CLAMP		01
38	0501018652	CORN STABILIZER BAR		01
39	0511018662	SPACING PLATE		01
40	0511061769	RIGHT FERTILIZER CONDUCTOR WITH REGULATOR		01
41	0511061770	LEFT CONDUCTOR FERTILIZER WITH REGULATOR		01
42	0501052735	COVERING WHEEL RIGHT FERTILIZER ASSY IRON	182	01
43	0501052736	COVERING WHEEL LEFT FERTILIZER ASSY IRON	183	01
44	0511059410	HDA BC	187	01
45	0581010082	FERTILIZER SOCKET RIGHT		01
46	0581010083	FERTILIZER SOCKET LEFT		01
47	0503031145	2" X 2" X 20" HOSE		01
48	0521067360	PROTRACTOR CPRA		01
49	0521052631	HDA HIGH AUTOMATIC DISARM	189	01
50	0501110723	SCARIFIER ROD	191	01
51	0503031076	2" HOSE CLAMP		01
52	0521050168	MOUNTED FERTILIZER CONDUCTOR	192	01
53	0511058877	REGULATORY KEY		01
53A	0521066800	BODY REGULATORY KEY		01
53B	0503030878	LEVER CRANK		01
54	0521053945	HDA PIVOTED LINE	193	01




Item	Code	Description	See page	QT
01	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	130	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	138	01
07	0501058423	FERTILIZER ROD SPRING ROW	145	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521052634	SHORT ARM LOWER LINE FERTILIZER WITH LEFT DDD	132	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	138	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	146	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521061121	SHORT FERTILIZER ROW ARM		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	138	01
07	0501058423	FERTILIZER ROD SPRING ROW	145	01




Item	Code	Description	See page	QT
01	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT 130		01
		DOUBLE DISC		
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0521044545	20" SHORT CURVED CORRIGATED DISC	143	01
07	0501058423	FERTILIZER ROD SPRING ROW	145	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	131	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	139	01
07	0501058423	FERTILIZER ROD SPRING ROW	145	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521052635	LONGER ARM LOWER LINE FERTILIZER WITH 133 RIGHT DDD		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	139	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	146	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521061153	LONG ARM FERTILIZER LINE		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	139	01
07	0501058423	FERTILIZER ROD SPRING ROW	145	01




Item	Code	Description	See page	QT
01	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT 131 DOUBLE DISC		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0521044546	20" LONG CURVED CORRUGATED DISC	144	01
07	0501058423	FERTILIZER ROD SPRING ROW	145	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521061121	SHORT FERTILIZER ROW ARM		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	141	01
07	0501058423	FERTILIZER ROD SPRING ROW	145	01




Item	Code	Description	See page	QT
01	0521061153	LONG ARM FERTILIZER LINE		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	140	01
07	0501058423	FERTILIZER ROD SPRING ROW	145	01




Item	Code	Description	See page	QT
01	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	131	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	140	01
07	0501058423	FERTILIZER ROD SPRING ROW	145	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT 130		01
02	0501010066	DOUBLE DISC		01
03	0521017831	3/4" X 9" BOLT		02
04	0511017232	SUPPORT SLEEVE SPACER		02
05	0503011255	FLAT WASHER		01
06	0511044549	3/4" LOCK NUT	141	01
07	0511058423	18" COULTER BLADE ASSY FOR SHORT ROW	145	01
08	0503030391	FERTILIZER ROD SPRING ROW		01
09	0503031145	RIGHT FERTILIZER NOZZLE		01
10	0503031076	2" X 2" X 20" HOSE		01
		2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	134	01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521061153	LONG ARM FERTILIZER LINE		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	135	01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521068566	SHORT FERTILIZER LINE ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	134	01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521068565	LONG FERTILIZER LINE ARM		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	135	01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	136	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	137	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011161	15\"X15\" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8\" X 1.1/4\" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010026	3/8\" NUT		01
14	0503010025	3/8\" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2\" X 0.8\" SPRING PIN		01




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	137	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	136	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01



Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	
02	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01	
03	0541018684	FLAT WASHER	01	
04	0503010756	0.2" X 2.4" SPRING PIN	01	
05	0503010361	SPRING PIN	01	
06	0503010003	1845 GREASE FITTING	01	
07	0521014137	RIGHT ARM OF THE BLADE DISC	01	
08	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503013185	3/4" X 5-1/2" BOLT	01	
12	0503011255	3/4" LOCK NUT	01	
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
14	0503011411	1/2" X 5-1/2" BOLT	01	
15	0503010019	1/2" SPRING WASHER	01	
16	0503010060	1/2" NUT	01	
17	0502020393	SPRING UPPER SUPPORT	01	
18	0502020394	SPRING SUPPORT	01	
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
20	0503010014	3/4" NUT	02	
21	0521054680	CUTTING DISC BOX 20	01	



Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	
02	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE	01	
03	0541018684	FLAT WASHER	01	
04	0503010756	0.2" X 2.4" SPRING PIN	01	
05	0503010361	SPRING PIN	01	
06	0503010003	1845 GREASE FITTING	01	
07	0521014137	RIGHT ARM OF THE BLADE DISC	01	
08	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503013185	3/4" X 5-1/2" BOLT	01	
12	0503011255	3/4" LOCK NUT	01	
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
14	0503011411	1/2" X 5-1/2" BOLT	01	
15	0503010019	1/2" SPRING WASHER	01	
16	0503010060	1/2" NUT	01	
17	0502020393	SPRING UPPER SUPPORT	02	
18	0502020394	SPRING SUPPORT	01	
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
20	0503010014	3/4" NUT	02	
21	0521054680	CUTTING DISC BOX 20	01	

18" COULTER BLADE ASSY FOR LONG ROW


0511044573




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	
02	0503010003	1845 GREASE FITTING	01	
03	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE	01	
04	0521014137	RIGHT ARM OF THE BLADE DISC	01	
05	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
06	0521054686	CUTTING DISC BOX 18	01	
07	0503010756	0.2" X 2.4" SPRING PIN	01	
08	0503010361	SPRING PIN	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503011255	3/4" LOCK NUT	01	
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
13	1902020394	SPRING SUPPORT	01	
14	1902020393	SPRING UPPER SUPPORT	01	
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
16	0503010014	3/4" NUT	02	
17	0541018684	FLAT WASHER	01	
18	0503013185	3/4" X 5-1/2" BOLT	01	
19	0503010019	1/2" SPRING WASHER	01	
20	0503010060	1/2" NUT	01	
21	0503011411	1/2" X 5-1/2" BOLT	01	

18" COULTER BLADE ASSY FOR SHORT ROW

0511044549




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	
02	0503010003	1845 GREASE FITTING	01	
03	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01	
04	0521014137	RIGHT ARM OF THE BLADE DISC	01	
05	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
06	0521054686	CUTTING DISC BOX 18	01	
07	0503010756	0.2" X 2.4" SPRING PIN	01	
08	0503010361	SPRING PIN	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503011255	3/4" LOCK NUT	01	
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
13	1902020394	SPRING SUPPORT	01	
14	1902020393	SPRING UPPER SUPPORT	01	
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
16	0503010014	3/4" NUT	02	
17	0541018684	FLAT WASHER	01	
18	0503013185	3/4" X 5-1/2" BOLT	01	
19	0503010019	1/2" SPRING WASHER	01	
20	0503010060	1/2" NUT	01	
21	0503011411	1/2" X 5-1/2" BOLT	01	



Item	Code	Description	See page	QT
01	0502011562	DC BOX		01
02	0503010276	6206 BALL BEARING		02
03	0521013610	BLADE DISC HUB AXLE		01
04	0503030832	FLAT WASHER		02
05	0503012417	SEAL		02
06	0503011800	SEAL RING		02
07	0503010691	1/4" GREASE FITTING		01
08	0603027851	20" X 0.2" FLAT PLAIN DISC		01
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0503011444	SPRING WASHER		06
12	0503010337	5/16" NUT		06

20" SHORT CURVED CORRIGATED DISC

0521044545



Item	Code	Description	See page	QT
01	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01	
02	0502012368	BLADE DISC SUPPORT AXLE	01	
03	0541018684	FLAT WASHER	01	
04	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN	02	
05	0503010756	0.2" X 2.4" SPRING PIN	01	
06	0503010361	SPRING PIN	01	
07	0521014137	RIGHT ARM OF THE BLADE DISC	01	
08	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503013185	3/4" X 5-1/2" BOLT	01	
12	0503011255	3/4" LOCK NUT	01	
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
14	0503011411	1/2" X 5-1/2" BOLT	01	
15	0503011440	SPRING WASHER	01	
16	0503010060	1/2" NUT	01	
17	1902020393	SPRING UPPER SUPPORT	01	
18	0502020394	SPRING SUPPORT	01	
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
20	0503010014	3/4" NUT	02	
21	0511054673	DPLO20	01	
21A	0502011562	DC BOX	01	
21B	0503010276	6206 BALL BEARING	02	
21C	0521013610	BLADE DISC HUB AXLE	01	
21D	0503030832	FLAT WASHER	02	
21E	0503012417	SEAL	02	
21F	0503011800	SEAL RING	02	
21G	0503010691	1/4" GREASE FITTING	01	
21H	0607026025	DPLO20X4,5	01	
21I	0502020641	BLADE DISC FLANGE	01	
21J	0503010371	5/16" X 1" BOLT	06	


**20" SHORT CURVED CORRIGATED DISC**

0521044545

Item	Code	Description	See page	QT
21K	0503011444	SPRING WASHER		06
21L	0503010337	5/16" NUT		06
22	0521015376	DUST CLOAK		02
23	0511015346	FLAT WASHER		06
24	0503011438	SPRING WASHER		02
25	0521013510	3/4" NUT		02
26	0503010003	1845 GREASE FITTING		01

20" LONG CURVED CORRUGATED DISC

0521044546



Item	Code	Description	See page	QT
01	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE	01	
02	0502012368	BLADE DISC SUPPORT AXLE	01	
03	0541018684	FLAT WASHER	01	
04	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN	02	
05	0503010756	0.2" X 2.4" SPRING PIN	01	
06	0503010361	SPRING PIN	01	
07	0521014137	RIGHT ARM OF THE BLADE DISC	01	
08	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503013185	3/4" X 5-1/2" BOLT	01	
12	0503011255	3/4" LOCK NUT	01	
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
14	0503011411	1/2" X 5-1/2" BOLT	01	
15	0503011440	SPRING WASHER	01	
16	0503010060	1/2" NUT	01	
17	1902020393	SPRING UPPER SUPPORT	02	
18	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
19	0503010014	3/4" NUT	02	
20	0511054673	DPLO20	01	
20A	0502011562	DC BOX	01	
20B	0503010276	6206 BALL BEARING	02	
20C	0521013610	BLADE DISC HUB AXLE	01	
20D	0503030832	FLAT WASHER	02	
20E	0503012417	SEAL	02	
20F	0503011800	SEAL RING	02	
20G	0503010691	1/4" GREASE FITTING	01	
20H	0607026025	DPLO20X4,5	01	
20I	0502020641	BLADE DISC FLANGE	01	
20J	0503010371	5/16" X 1" BOLT	06	
20K	0503011444	SPRING WASHER	06	


**20" LONG CURVED CORRUGATED DISC**

0521044546


Item	Code	Description	See page	QT
20L	0503010337	5/16" NUT		06
21	0521015376	DUST CLOAK		02
22	0511015346	FLAT WASHER		06
23	0503011438	SPRING WASHER		02
24	0521013510	3/4" NUT		02
25	0503010003	1845 GREASE FITTING		01

FERTILIZER ROD SPRING ROW

0501058423




Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD		01
02	0502040534	SPRING GUIDE BUSHING LOCK		02
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502012510	SPRING ROD SUPPORT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0501018535	1/2 X 1 BOLT		02
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		02
09	0503010060	1/2" NUT		02
10	1902010891	SPRING CHOCK SUPPORT VARON		01
11	0503010014	3/4" NUT		01
12	0561014471	COUPLING SHAFT		01
13	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK	02	
02	0502012184	FERTILIZER SPRING GUIDE	02	
03	0503031910	1.7" X 22.8" X 0.3" SPRING	01	
04	0502012510	SPRING ROD SUPPORT	01	
05	0521068568	LARGE ELEVATION SPRING FERTILIZER	01	
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN	01	
07	0501018535	1/2 X 1 BOLT	02	
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
09	0503010060	1/2" NUT	02	
10	0502010891	SPRING CHOCK SUPPORT VARON	01	
11	0503010014	3/4" NUT	01	
12	0561014471	COUPLING SHAFT	01	
13	0511017302	FLAT WASHER	01	
14	0503010257	1/8" X 1" COTTERPIN	01	

SHORT SEED ROW FRONT


0511056554




Item	Code	Description	See page	QT
01	0511056600	FRONT LINE SEED SHORT DDD RIGHT		01
02	0511058212	ASSY LINE SUPPORT FERTILIZER		01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0511060376	SEEP SPRING GUIDE		01
06	0502012538	SPRING VARON SUPPORT		01
07	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
08	0511017302	FLAT WASHER		03
09	0503011336	1/2" HEX SELF ADJUSTING NUT		02
10	0521010542	COUPLING SHAFT		01
11	0503010257	1/8" X 1" COTTERPIN		01
12	0502040534	SPRING GUIDE BUSHING LOCK		02
13	0501018535	1/2 X 1 BOLT		02
14	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
15	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
16	0501013753	FLAT WASHER		01
17	0503010013	5/8" NUT		01
18	0511052024	FAST CLOSING SET		01
19	0511057017	SEED SYSTEM ASSY		01
20	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
22	0503010019	1/2" SPRING WASHER		01
23	0503010060	1/2" NUT		01
24	0503011099	GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511056601	LONG SEED ROW FRONT DDD LEFT	01	
02	0511058212	ASSY LINE SUPPORT FERTILIZER	01	
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN	02	
04	0503012412	5/8 UNC SELF LOCKING NUT	02	
05	0511060376	SEEP SPRING GUIDE	01	
06	0502012538	SPRING VARON SUPPORT	01	
07	0521014021	1/2" X 4.5" X 5.4" FASTENER	01	
08	0511017302	FLAT WASHER	03	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	02	
10	0521010542	COUPLING SHAFT	01	
11	0503010257	1/8" X 1" COTTERPIN	01	
12	0502040534	SPRING GUIDE BUSHING LOCK	02	
13	0501018535	1/2 X 1 BOLT	02	
14	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING	01	
15	0503031339	1" X 19" X 0.1" COMPRESSION SPRING	01	
16	0501013753	FLAT WASHER	01	
17	0503010013	5/8" NUT	01	
18	0511052024	FAST CLOSING SET	01	
19	0511057017	SEED SYSTEM ASSY	01	
20	0521010505	13,50 X 19,00 X 21,50 SLEEVE	01	
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	01	
22	0503010019	1/2" SPRING WASHER	01	
23	0503010060	1/2" NUT	01	
24	0503011099	GREASE FITTING	02	




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	150	01
02	0501052538	DEPTH BAND WITH ARMS	155	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	156	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	157	01
07	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	151	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	152	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	154	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	SCREWEW 3/8 UNC X 3/4		01



Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL BOX	153	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL BOX	153	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	COVER DEPTH		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01

DEPTH WHEELS REGULATOR ASSY


0501052297




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	158	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	158	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0581014858	DEPTH WHEEL AXLE		01
04	0501110720	ARM LEFT		01
05	0501110719	DEPTH CONTROL RIGHT ARM		01
06	0502012663	EXTENSION		01
07	0503010002	1800 GREASE FITTING		02
08	0501056769	DEPTH WHEELS REGULATOR ASSY	160	01
09	0503034793	ARTICULATION SLEEVE		02
10	0521051423	COMPACTOR SUPPORT	161	01
11	0571017749	FLAT WASHER		02
12	0503010311	1/2" X 1-1/4" BOLT		02
13	0503016453	1/2" X 2.1/2 BOLT		02
14	0503034817	SPRING		01
15	0503010581	RING		01
16	0503034377	SCREWEW 3/8 UNC X 3/4		01
17	0503010019	1/2" SPRING WASHER		08
18	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
19	0503010060	1/2" NUT		04
20	0501052908	COMPACTOR WHEEL WITH BEARING	158	02
21	0503013739	1/2" X 1" BOLT		01
22	0511050077	WHEEL STRIPED	162	02
23	0503010752	1/2" X 3.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	SEED SIST CONTROL DEPTH LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0521068003	RIGHT SIDE		01
02	0521068002	LEFT SIDE		01
03	0581014847	PLATE UPPER		01
04	0581015855	SLEEVE		02
05	0521068004	HANDLE BODY		01
06	0581014969	SLEEVE GUIDE		01
07	0581014968	SLEEVE FLANGE		01
08	0503010937	5/16" X 3" BOLT		02
09	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
10	0521068005	LEVER		01
11	0503010179	LOCK WASHER		04
12	0503010337	5/16" NUT		04
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2" NUT		01
15	0503010847	1/2" X 3.1/4" BOLT		01
16	0503010882	BOLT		02
17	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
18	0503030878	LEVER CRANK		01
19	0581015854	RIGHT PROTECTION COVER		01
20	0581015853	LEFT PROTECTION COVER		01
21	0581015903	SPACER WASHER		01




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	163	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	LOCK WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEELS BOX		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0511052971	SEMI-ASSEMBLED DEPTH CONTROL WITH THREAD	165	01
02	0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	171	01
03	0501052908	COMPACTOR WHEEL WITH BEARING	158	02
04	0503010019	1/2" SPRING WASHER		06
05	0503010752	1/2" X 3.1/2" BOLT		01
06	0503013739	1/2" X 1" BOLT		01
07	0503010479	BOLT		02
08	0503010060	1/2" NUT		04
09	0503030012	HAIR PIN		01
10	0571013222	FIXING CHOCK		01
11	0503010741	1/2" X 2-3/4" BOLT		02
12	0511055819	DEPTH WHIT AROS BAND	172	02
13	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
14	0503013816	5/16" LOCKNUT		08




Item	Code	Description	See page	QT
01	0521063808	DEPTH CONTROL INNER COLUMN CONTROL WITH SCREW		01
02	0521063809	DEPTH CONTROL EXTERNAL COLUMN CONTROL WITH SCREW		01
03	0571013194	REGULATOR SPINDLE		01
04	0551010616	ROD HEX		01
05	0503010683	0,2" X 1,2" SPRING PIN		01
06	0571013202	REGULATOR AXLE WHEELS COBRIDORA		01
07	0521063812	REGULATOR LEVER ALXE		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		01
09	0511065308	LOCK REGULATOR		01
10	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
11	0541011627	FLAT WASHER		01
12	0503010140	1/8" X 3/4" COTTERPIN		01
13	0511059325	LEFT ARM COVERED WHEEL ASSEMBLED	166	01
14	0511059324	RIGHT ARM COVERED WHEEL ASSEMBLED	167	01
15	0571014709	SLEEVE LOCK CONTROL ARM		02
16	0503011440	SPRING WASHER		03
17	0503819099	BOLT		02
18	0511051546	CUBE RIGHT CONTROL DEPTH	168	01
19	0511051547	LEFT CUBE CONTROL DEPTH	169	01
20	0503011442	3/4" SPRING WASHER		02
21	0571013189	SLEEVE SUPPORT BEATER		01
22	0521063813	WHEEL PRESS BEATER		01
23	0501010937	13.5 X 28 X 3 FLAT WASHER		01
24	0503010920	1/2" X 1.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502012844	LEFT ARM WHEELS		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	GLOVE SUPPORT ARM WHEEL COBRIDORA		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012843	RIGHT WHEEL ARM		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	GLOVE SUPPORT ARM WHEEL COBRIDORA		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB	170	01
02	0511066638	AXLE WHEEL RIGHT DEPTH WITH DOOR DUST		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	COVER DEPTH		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB	170	01
02	0511066637	AXLE WHEEL LEFT DEPTH WITH DOOR DUST		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	COVER DEPTH		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0502011907	DEPTH CONTROL WHEEL HUB		01
02	0503010269	6204 BALL BEARING		02
03	0501013636	SPACING SLEEVE		01
04	0503010689	SEAL 00763-BR		01
05	0503011105	SEAL RING		01
06	0503010691	1/4" GREASE FITTING		01



Item	Code	Description	See page	QT
01	0502012850	PRESS WHEELS ARM		01
02	0503030883	RIGHT TORSION SPRING		01
03	0502011066	PRESS WHEELS ARM SUPPORT		01
04	0531017415	1" X 4.72" AXLE JOINT		01
05	0503010839	03"X 0.6" SPRING PIN		01
06	0521063841	REGULATOR RIGHT COMPACTOR		01
07	0521063842	REGULATOR LEFT COMPACTOR		01
08	0503811404	BOLT		02
09	0503011443	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0571013295	ALXE REGULATOR COMPACTOR		01
12	0521063812	REGULATOR LEVER ALXE		01
13	0503011336	1/2" HEX SELF ADJUSTING NUT		02
14	0511065308	LOCK REGULATOR		01
15	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
16	0541011627	FLAT WASHER		01
17	0503010140	1/8" X 3/4" COTTERPIN		01
18	0571013293	SLEEVE LOCK COMPACTOR V CONTROL WITH SCREW		01
19	0503811172	BOLT		01
20	0503010002	1800 GREASE FITTING		01
21	0581013744	PROTECTION COVER - CPRA		01
22	0503813096	BOLT		01
23	0503013816	5/16" LOCKNUT		0




Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503013758	1/4" X 1-1/2" BOLT		05
04	0503013814	1/4" NC LOCKNUT		05




Item	Code	Description	See page	QT
01	0511053550	DEPTH CONTROL ASSY	174	01
02	0511050077	WHEEL STRIPED	162	02
03	0511054333	COMPACT WHEEL RIGHT WITH BEARING	156	01
04	0511054334	COMPACT WHEEL LEFT WITH BEARING	157	01
05	0503033942	COVER REGULATORY WHEEL		01

DEPTH CONTROL ASSY


0511053550




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521064073	REGULACION WHEEL COMPACTOR		01
03	0521019093	0.6" X 2.7" PIVOT SHAFT		01
04	0503010581	RING		01
05	0571013054	DEPTH CONTROL WHEEL AXLE		01
06	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
07	0511015346	FLAT WASHER		04
08	0501110720	ARM LEFT		01
08A	0502012726	LEFT DEPTH WHEEL ARM		01
08B	0503034375	SLEEVE ARM WHEEL DEPTH CONTROL		02
09	0501110719	DEPTH CONTROL RIGHT ARM		01
09A	0502012725	DEPTH WHEEL RIGHT ARM		01
09B	0503034375	SLEEVE ARM WHEEL DEPTH CONTROL		02
10	0511017302	FLAT WASHER		02
11	0503011440	SPRING WASHER		04
12	1902012116	PRESS WHEEL ADJUSTER		01
13	0503010849	3/8" X 1-1/2" BOLT		02
14	0503011443	3/8" SPRING WASHER		02
15	0503010026	3/8" NUT		02
16	0521010539	0.3" X 1.2" COUPLING SHAFT		01
17	0503010140	1/8" X 3/4" COTTERPIN		01
18	0502012663	EXTENSION		01
19	0503010002	1800 GREASE FITTING		02
20	0503010060	1/2" NUT		02
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
22	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
23	0541016906	PRESS WHEELS REGULATOR BODY		01
24	0501056769	DEPTH WHEELS REGULATOR ASSY	160	01
25	0503010311	1/2" X 1-1/4" BOLT		02
26	0503010256	3/8" X 3/4" BOLT		01




Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER ROD		01
02	1902070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503030379	LARGER ROCKER ARM		01
02	0502060001	PLASTIC PULLEY FOR MAIZE		01
03	0503010669	FLAT WASHER		01
04	0503010667	3/16" NUT		02
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		01




Item	Code	Description	See page	QT
01	0511062081	RH SUPPORT		01
02	0511064765	SMALLER WHEEL PRESS FERTILIZER ARM		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0503010002	1800 GREASE FITTING		01
05	0503010013	5/8" NUT		02
06	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
07	0502011757	PRESS REGULATOR		01
08	0503010849	3/8" X 1-1/2" BOLT		02
09	0503010025	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0501013491	5/8" TENSIONER SPRING		01
12	0521010579	COUPLING SHAFT		01
13	0511054837	RH IRON PRESS WHEEL	179	01
14	0511054838	LH IRON PRESS WHEEL	180	01




Item	Code	Description	See page	QT
01	0511062082	LH SUPPORT		01
02	0511064765	SMALLER WHEEL PRESS FERTILIZER ARM		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0503010002	1800 GREASE FITTING		01
05	0503010013	5/8" NUT		02
06	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
07	0502011757	PRESS REGULATOR		01
08	0503010849	3/8" X 1-1/2" BOLT		02
09	0503010025	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0501013491	5/8" TENSIONER SPRING		01
12	0521010579	COUPLING SHAFT		01
13	0511054837	RH IRON PRESS WHEEL	179	01
14	0511054838	LH IRON PRESS WHEEL	180	01




Item	Code	Description	See page	QT
01	0501052957	IRON V PRESS WHEELS	181	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		05
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052957	IRON V PRESS WHEELS	181	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		05
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011932	IRON PRESS WHEELS		01
02	0503010269	6204 BALL BEARING		02
03	0503011105	SEAL RING		01
04	0503013848	5072-BR SEAL		02
05	0521019147	V COMPACT WHEELS AXLE		02
06	0511011927	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501056288	WHEEL COVER ROD FERRO	184	01
02	0502012347	LEFT WHEEL ARM SUPPORT		01
03	0531016207	0.6" X 1" X 2.8" SLEEVE		01
04	0501010163	5/8" X 4-1/2" BOLT		01
05	0503010027	5/8" SPRING WASHER		01
06	0503010013	5/8" NUT		01
07	0503010003	1845 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0501056289	IRON LEFT PRESS WHEEL FERT UP	185	01
02	0502012347	LEFT WHEEL ARM SUPPORT		01
03	0531016207	0.6" X 1" X 2.8" SLEEVE		01
04	0501010163	5/8" X 4-1/2" BOLT		01
05	0503010027	5/8" SPRING WASHER		01
06	0503010013	5/8" NUT		01
07	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503011440	SPRING WASHER		02
02	0511017302	FLAT WASHER		02
03	0503010920	1/2" X 1.1/2" BOLT		02
04	0501053186	RIGHT IRON PRESS WHEEL ASSY	186	01
05	0502012348	RIGHT WHEEL ARM		01
06	0502011155	RIGHT FIXER WHEEL		01




Item	Code	Description	See page	QT
01	0503011440	SPRING WASHER		02
02	0511017302	FLAT WASHER		02
03	0503010920	1/2" X 1.1/2" BOLT		02
04	0501053186	RIGHT IRON PRESS WHEEL ASSY	186	01
05	0502012349	LEFT WHEEL ARM STEEL		01
06	0502011156	LEFT FIXER WHEEL		01

RIGHT IRON PRESS WHEEL ASSY


0501053186




Item	Code	Description	See page	QT
01	0502011970	IRON PRESS WHEEL		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019154	RIGHT DOUB DISC HUB		01
05	0511015098	FLAT WASHER		01
06	0503030282	3/4" CASTLE NUT		01
07	0503010257	1/8" X 1" COTTERPIN		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503011441	SPRING WASHER		03
11	0503013758	1/4" X 1-1/2" BOLT		03
12	0511016896	DUST CLOAK		01



Item	Code	Description	See page	QT
01	0521067063	SPRING BOX HDA		01
02	0511059396	SCARIFIER SPINDLE WITH POINT	188	01
03	0581812084	LARGE BUSHING		01
04	0503012795	5/8" HEX SELF ADJUSTING NUT		01
05	0581812082	BOLT FIXER		01
06	0503810417	NUT		01
07	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
08	0503034106	80 X 230 X 16,50 HDA COMPRESSSION SPRING		01
09	0503010691	1/4" GREASE FITTING		01
10	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
11	0571018541	BODY SOCKET FERTILIZER		01
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
13	0501010984	FLAT WASHER		04
14	0503010026	3/8" NUT		02
15	0503010025	3/8" SPRING WASHER		02
16	0503010384	1/2" X 5" BOLT		02
17	0511017302	FLAT WASHER		04
18	0503010547	1/2" X 4" BOLT		02
19	0503011336	1/2" HEX SELF ADJUSTING NUT		04
20	0571019462	SUPPORT GUIDE PRING		01
21	0581812081	SMALLER BUSHING		01
22	0581012094	SUPPORT WASHER		01




Item	Code	Description	See page	QT
01	0501110849	STEM WITH BEAK		01
01A	0521067064	ROD WITHOUT BEAK AUTO DISARM HDA		01
01B	0521066870	POINT SUBSOILER		01
01C	0503016853	SPRING PIN		02
01D	0503011402	0.2" X 0.8" SPRING PIN		02
02	0581012092	AXLE FIXER		01
03	0581012093	WASHER		02
04	0503010406	501025 CLAMPING RING (FOR AXLE)		02
05	0521067065	FLANGE WASHER SPRING		01



Item	Code	Description	See page	QT
01	0521068567	BOX SPRING		01
02	0521050364	ROD WITH BEAK	190	01
03	0503034106	80 X 230 X 16,50 HDA COMPRESSSSION SPRING		01
04	0581012094	SUPPORT WASHER		01
05	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
06	0571019462	SUPPORT GUIDE PRING		01
07	0581012081	GLOVE		01
08	0581012084	ARTICULATED GLOVE		01
09	0581012082	SCREW		01
10	0503012795	5/8" HEX SELF ADJUSTING NUT		01
11	0503010691	1/4" GREASE FITTING		01
12	0503010384	1/2" X 5" BOLT		02
13	0511017302	FLAT WASHER		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0503017874	BOLT 1/2 UNC		02
16	0571018541	BODY SOCKET FERTILIZER		01
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
18	0501010984	FLAT WASHER		04
19	0503010025	3/8" SPRING WASHER		02
20	0503010026	3/8" NUT		02
21	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
22	0503010417	7/8" NUT		01

ROD WITH BEAK


0521050364




Item	Code	Description	See page	QT
01	0501110865	ROD WITH BEAK HDA		01
02	0521067065	FLANGE WASHER SPRING		01
03	0581012092	AXLE FIXER		01
04	0581012093	WASHER		02
05	0503010406	501025 CLAMPING RING (FOR AXLE)		02

SCARIFIER ROD

0501110723




Item	Code	Description	See page	QT
01	0521063867	SCARIFIER ROD		01
02	0502070082	POINT SUBSOILER		01
03	0503010585	0,24" X 1.18" SPRING PIN		03




Item	Code	Description	See page	QT
01	0581013298	SUPPORT		01
02	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
03	0521018517	FLAT WASHER		01
04	0503010060	1/2" NUT		01
05	0503010019	1/2" SPRING WASHER		01
06	0503030483	FERTILIZER SOCKET		01
07	0503031050	CURVED CONDUCTOR		01
08	0503010246	CLAMP		01

HDA PIVOTED LINE


0521053945




Item	Code	Description	See page	QT
01	0521053937	SCARIFIER SPINDLE WITH POINT	194	01
02	0503012795	5/8" HEX SELF ADJUSTING NUT		01
03	0503010417	7/8" NUT		01
04	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
05	0503034106	80 X 230 X 16,50 HDA COMPRESSION SPRING		01
06	0503010691	1/4" GREASE FITTING		01
07	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		04
09	0521067875	HDA SPRING BOX PIVOTING LINE		01
10	0581012084	ARTICULATED GLOVE		01
11	0581012082	SCREW		01
12	0581012081	GLOVE		01
13	0571019462	SUPPORT GUIDE PRING		01
14	0581012094	SUPPORT WASHER		01
15	0571018541	BODY SOCKET FERTILIZER		01
16	0503010026	3/8" NUT		02
17	0503010025	3/8" SPRING WASHER		02
18	0501010984	FLAT WASHER		04
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
20	0511017302	FLAT WASHER		04
21	0503010384	1/2" X 5" BOLT		02
22	0503010547	1/2" X 4" BOLT		02



Item	Code	Description	See page	QT
01	0521053959	ROD WITH AUTOMATIC DISARM TIP	195	01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0521067065	FLANGE WASHER SPRING		01
04	0521015818	FLAT WASHER		02
05	0581012092	AXLE FIXER		01



Item	Code	Description	See page	QT
01	0521067066	ROD WITHOUT NOZZLE AUTOMATIC DISARM		01
02	0502040901	FIXED ROD NOZZLE		01
03	0503016853	SPRING PIN		02
04	0503011402	0.2" X 0.8" SPRING PIN		02



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

