

ROW CROP PLANTERS

PST4 FLEX - FRAME 4495 (UP TO 03/2022)

Code: 0501092743
Series: S-0116
Revision: 00
Date Revision: JULHO/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111280382	PST4 FLEX 4495/9E500 CI MH DC20 PM400 S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX


0909098988	ASSY FRAME	1
0501058196	WHEEL AXLE FRAME - 4845	2
0511057124	CYLINDER ASSY	3
0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	4
0511056536	LADDER ASSEMBLY	5
0511054971	JACK ASSEMBLY	6
0511057151	ASSY DOOR HAND BOOK	7
0511058302	LABEL ASSY FOR HYDRAULIC MARKER 4495	8
0511057142	ASSY HEADER - 3245/3695/4045/4495	9
0511057566	HANDRAIL ASSY - 4495	10
0511057565	PLATFORM ASSY - 4495	11
0511057564	SET SUPPORT RIGHT LEFT	12
0511053240	RIGHT SILO SUPPORT WITH DISTRIBUTOR 10	13
0511053241	LEFT SILO SUPPORT WITH DISTRIBUTOR 10	14
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	15
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	16
0501053788	3/4 SQUARE AXLE FASTENER	17
0511050838	SEMI-ASSEMBLED HYDRAULIC MARKER 4495	18
0511058449	HYDRAULIC CYLINDER	19
0501054649	HBM SEQUENTIAL VALVE	20
0501053834	MALE QUICK COUPLER	21
0501050633	ROW MARKER DISK ASSEMBLY	22
0511053904	ROW MARKER DISC	23
0909091892	TRANSMISSION 7 / 9 / 10 / 11	24
0511058593	LEFT TRANSMISSION ASSY - 4495	25
0511058592	RIGHT TRANSMISSION ASSY - 4495	26
0501052560	MOTOR AXLE SIGNAL	27
0511051434	TRANSMISSION ACTUATOR	28
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	29
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	30
0521043316	RIGHT GEAR BOX ASSY	31
0521043317	LEFT GEAR BOX ASSY	32
0501058212	SEMI MOUNTED RIGHT CHANGE	33
0501058213	LH GEAR BOX	34
0511059266	CLOSED BEARING	35
0501056271	GEARBOX CLOSED BEARING	36
0501056443	GEAR HOUSING BEARING	37
0501056444	BEARING WITH ROLLING	38
0501048790	AXLE WITH RING	39
0501054655	CHAIN TENSIONER ASSY	40
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	41
0511054363	CHAIN TENSIONER	42
0501058265	STRETCHER LOWER CURRENT 21Z SEED	43
0501058254	UPPER SEED CHAIN TENSIONER	44
0501058236	BEARING WITH 21Z GEAR	45
0501058237	16Z GEAR BEARING	46
0501055112	MICRO GRANULATED CHAIN TENSIONER	47
0521043934	CARRYING WHEELS SPRING TRACTION	48
0501058240	WHEEL FASTENER WITH TENSIONER	49
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	50
0501058244	WHEEL FIXED CHAIN TENSIONER	51
0501058242	WHEEL MOBILE CHAIN TENSIONER	52
0501059909	CARRYING WHEELS SUPPORT	53
0511052770	WHEEL WITH TIRE	54
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	55



MARCHESAN

INDEX

0501058241	WHEEL SUPPORT CHAIN TENSIONER	56
0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	57
0501054258	DRAWBAR ESTABILIZER ASSY	58
0511054601	HITCH ARTICULATED TRACTOR	59
0511056736	HOSE SUPPORT	60
0909095145	ASSY HEX AXLE	61
0909098989	SEED LINE/FERTILIZER ASSEMBLY	62
0909092325	SEED LINE	63
0909093293	SEED ROW FRONT ASSY UNTIL (9/2011)	64
0511056621	REAR RIGHT SEED LINE	65
0511056622	LEFT REAR LINE SEED	66
0511057017	SEED SYSTEM ASSY	67
0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	68
0511052024	FAST CLOSING SET	69
0511051693	BASE FIXING SYSTEM	70
0501059631	DDD SEED 15 X 15 RIGHT	71
0501059632	DDD SEED 15X15 LEFT	72
0501054167	BOX DDD ASSY DPL 15 RIGHT	73
0501054168	BOX DDD ASSY DPL 15 LEFT	74
0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	75
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	76
0511058650	SEMI-MOUNTED DEPTH CONTROL	77
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	78
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	79
0501052627	ASSY DEPTH WHEEL BOX	80
0501052297	DEPTH WHEELS REGULATOR ASSY	81
0501052538	DEPTH BAND WITH ARMS	82
0511054333	COMPACT WHEEL RIGHT WITH BEARING	83
0511054334	COMPACT WHEEL LEFT WITH BEARING	84
0501052908	COMPACTOR WHEEL WITH BEARING	85
0909091899	FERTILIZER ROW WITH DDD & 18"/20" COULTER BLADE	86
0521052838	RIGHT SUPPORT DOC18	87
0521052839	LEFT SUPPORT DOC18	88
0511059229	BOX WITH DOC 18 TURBO RIGHT	89
0511059230	BOX WITH DOC 18 TURBO LEFT	90
0521050168	MOUNTED FERTILIZER CONDUCTOR	91
0511058619	DISC CUT 20 SHORT LINE	92
0511058620	DISC CUT 20 LONG LINE	93
0511058648	BOX WITH DISC BLADE 20	94
0511056909	DISC BOX CUT WITHOUT THE DISC	95
0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	96
0909092327	FERTILIZER LINE WITH STEM	97
0501110804	SCARIFIER ROD WITH POINT	98
0521053445	MONITORING ASSEMBLY PLANTING SEEDS 09L PM400	99
0501110231	SCARIFIER HEAD WITH SPIKE 0061	100
0501050120	LARGER WALKING BEAM ASSY	101
0521057957	FIXED ROD EXTENSION WITH FIXATION	102




Item	Code	Description	See page	QT
01	0511050836	WHEEL AXLE FRAME - 4495		01
02	0503010003	1845 GREASE FITTING		06
03	0511057124	CYLINDER ASSY	3	01
04	0521013022	TRANSPORT LOCK		02
05	0501068994	0.3" X 3.1" LOCK PIN		02
06	0503030168	CUPILLA		02
07	0511056536	LADDER ASSEMBLY	5	02
08	0511054971	JACK ASSEMBLY	6	02
09	0511057131	MANUAL CANISTER ASSY		01
10	0511057380	LABEL ASSY FOR HYDRAULIC MARKER - 4845		01
11	0511057150	HEADER ASSEMBLY - 4845/5345		01
12	0511057651	HANDRAIL ASSY - 4845		01
13	0521053445	MONITORING ASSEMBLY PLANTING SEEDS 09L 99 PM400		01
14	0511057650	PLATFORM ASSY - 4845		01
15	0511057147	ASSEMBLY SUPPORT RIGHT/LEFT BOX FERTILIZER		01
16	0511050838	SEMI-ASSEMBLED HYDRAULIC MARKER 4495	18	01
17	0501050633	ROW MARKER DISK ASSEMBLY	22	02
18	0511056740	RIGHT TRANSMISSION ASSY - 4880		01
19	0511056741	LEFT TRANSMISSION ASSEMBLY - 4880		01
20	0521043934	CARRYING WHEELS SPRING TRACTION	48	04
21	0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	57	01
22	0501065677	STRUT		02
23	0521013164	EXTENSOR		02
24	0501011310	FIXER LOCK		08
25	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		04
26	0503010019	1/2" SPRING WASHER		04
27	0503010060	1/2" NUT		04
28	0501054258	DRAWBAR ESTABILIZER ASSY	58	01
29	0511054601	HITCH ARTICULATED TRACTOR	59	01
30	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01


ASSY FRAME

0909098988


Item	Code	Description	See page	QT
31	0511053179	TRACTOR COUPLING SHAFT		01
31A	0521064036	TRACTOR HITCH AXLE		01
31B	0503030012	HAIR PIN		01
32	0511056736	HOSE SUPPORT	60	01
33	0501047895	ROD STOP		02
34	0501047885	ROD STOP		02
35	0501047886	ROD STOP		02
36	0501047887	ROD STOP		02
37	0503032624	SILO FERTILIZER GUTTER		06
38	0503014120	CHAIN		01
39	0503014321	CABLE STEEL SHACKLE		02
40	0503010780	N-2050 AMENDMENT		02
41	0503011750	AMENDMENT WITH LOCK		06
42	0503011751	REDUCTION		06
43	0503010951	REDUCTION		04
44	0503010246	CLAMP		06
45	0909095145	ASSY HEX AXLE	61	01
46	0909098989	SEED LINE/FERTILIZER ASSEMBLY	62	01




Item	Code	Description	See page	QT
01	0511069616	FRAME		01
02	0511069717	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8" X 2-1/4" BOLT		12
05	0501012140	FLAT WASHER		24
06	0531013922	0.6" X 0.8" X 1" SLEEVE		12
07	0503011445	SPRING WASHER		12
08	0503010013	5/8" NUT		12




Item	Code	Description	See page	QT
01	0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	4	01
02	0531019171	1.25" X 7" COUPLING SHAFT		01
03	0521012536	COUPLING SHAFT		01
04	0503010523	1/4" X 2" COTTERPIN		02
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0511064055	5" X 15" CYLINDER CASE		01
02	0511064056	BUSHING 2" X 14" TURNBUCLE		01
03	0502010382	5" END CAP		01
04	0502012227	50.80 X 127 RING SUPPORT		01
05	0503010039	D-2000 SCRAPER RING		01
06	0503010991	1870-2000-375-B GASKET		01
07	0503010952	W2-2250-500 RING		01
08	0503010351	2-425 N 3006-9B O'RING		01
09	0503011062	8-425 BACK-UP RING		01
10	0502010963	2.0" X 5.0" PISTON		01
11	0503010552	PACKING 3750-4250-625-B		02
12	0503010345	2-218 N 3006-9B O'RING		01
13	0503010974	W2-5000-500 RING		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503010003	1845 GREASE FITTING		01
16	0503030385	CYLINDER PLUG N-002		02




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
001	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
002	0503010267	NYLON CLAMP		01
003	0503010363	5/16" X 1" BOLT		01
004	0501010694	FLAT WASHER		01
005	0503010179	LOCK WASHER		01
006	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
001	0503033867	ADHESIVE LABEL		02
002	0503033854	ADHESIVE LABEL		02
003	0503033853	ADHESIVE LABEL		02
004	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
005	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
006	0503033423	LABEL ADHESIVE NUMBER 9		02
007	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
008	0503033008	ADHESIVE LABEL		02
009	0503031428	READ MANUAL DECAL		01
010	0503031942	ADHESIVE LABEL		01
011	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
012	0503031565	ADHESIVE LABEL CARE		02
013	0503031566	ADHESIVE LABEL		02
014	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
015	0503031425	ADHESIVE LABEL ATTENTION		02
016	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
017	0503031669	ADHESIVE LABEL		01
018	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
019	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER RIGHT		01
020	0503032930	ADHESIVE LABEL DANGER		05
021	0503031087	ADHESIVE LABEL		01
022	0503034003	SERIAL NUMBER TAG 61 X 118		01
023	0503010001	3.2 X 5.5 RIVET		04
024	0503034078	LIFTING POINTS DECAL		03
025	0503032979	ADHESIVE LABEL LETTERS A B C D		02
026	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012329	DRAWBAR FIXATION REAR SUPPORT		02
02	0502012330	SUPPORT FIXER PIVOT		04
03	0503011084	3/4" X 5" BOLT		08
04	0501010322	FLAT WASHER		08
05	0503010023	3/4" SPRING WASHER		08
06	0503010014	3/4" NUT		08
07	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02
08	0561014393	COUPLING SHAFT		02
09	0503030119	LOCK PIN		04
10	0531063130	HEADER		01
11	0561019087	DRAWBAR TRANSPORT LOCK		01
12	0521010578	COUPLING SHAFT		01
13	0521010588	0.9" X 7.0" COUPLING SHAFT		01
14	0503030085	LOCK PIN		02
15	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0521062239	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	FLAT WASHER	16	
04	0503010025	3/8" SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0521062237	RIGHT PLATAFORM	01	
07	0521062238	LEFT PLATAFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	DIR	ESQ
01	0511053240	RIGHT SILO SUPPORT WITH DISTRIBUTOR 10	13	01	00
02	0511053241	LEFT SILO SUPPORT WITH DISTRIBUTOR 10	14	00	01
03	0503010849	3/8" X 1-1/2" BOLT		08	08
04	0501010984	FLAT WASHER		17	17
05	0503010025	3/8" SPRING WASHER		08	08
06	0503010026	3/8" NUT		08	08
07	0571010590	FERTILIZER SIDE COVER		05	05
08	0503010362	1/8" X 1.1/4" COTTERPIN		05	05
09	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		01	01
10	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02	02
11	0551019156	GEAR BOX LEVER LOCK		01	01
12	0503011953	5/16" X 1" BOLT		02	02
13	0501010694	FLAT WASHER		02	02
14	0503010179	LOCK WASHER		02	02
15	0503010337	5/16" NUT		02	02
16	0503010847	1/2" X 3.1/4" BOLT		01	01
17	0551019168	SLEEVE		01	01
18	0551019160	LEVER		01	01
19	0511017302	FLAT WASHER		03	03
20	0503010019	1/2" SPRING WASHER		02	02
21	0503010060	1/2" NUT		02	02
22	0551019167	SLEEVE UNION		01	01
23	0511069676	INNER LEVER		01	01
24	0501013518	FLAT WASHER		02	02
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01	01
26	0503010140	1/8" X 3/4" COTTERPIN		03	03
27	0511069678	LH LOWER LEVER		02	02
28	0503011336	1/2" HEX SELF ADJUSTING NUT		02	02
29	0551019115	LOCKING PLATFORM FIXATION		01	01
30	0501010096	3/8" X 2" BOLT		01	01
31	0503013357	3/8" SELF-ADJUSTING NUT		01	01




Item	Code	Description	See page	DIR	ESQ
32	0551019159	LEVER FIXER BODY		01	01
33	0561016468	FASTENER		01	01




Item	Code	Description	See page	QT
01	0521064058	FERTILIZER BEAN RIGHT SUPPORT		01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	16	03
03	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	15	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		05
10	1902010685	18Z CONICAL GEAR		05
11	0571013830	SQUARE SHAFT		01
12	0521010691	AXLE FASTENER		02
13	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
14	0501010694	FLAT WASHER		02
15	0503011441	SPRING WASHER		02
16	0503010144	1/4" NUT		02
17	0501110392	SILO SUPPORT BEARING		01
18	0521012485	GEAR BOX BEARING AGRICUTURAL		01
19	0503011953	5/16" X 1" BOLT		02
20	0501010694	FLAT WASHER		02
21	0521011039	FLAT WASHER		02
22	0503011444	SPRING WASHER		02
23	0503010337	5/16" NUT		02
24	0551018055	22,65 X 60 SLEEVE		01
25	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521064059	FERTILIZER BEAN LEFT SUPPORT		01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	16	02
03	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	15	03
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		05
10	1902010685	18Z CONICAL GEAR		05
11	0571013830	SQUARE SHAFT		01
12	0521010691	AXLE FASTENER		02
13	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
14	0501010694	FLAT WASHER		02
15	0503011441	SPRING WASHER		02
16	0503010144	1/4" NUT		02
17	0501110392	SILO SUPPORT BEARING		01
18	0521012485	GEAR BOX BEARING AGRICUTURAL		01
19	0503011953	5/16" X 1" BOLT		02
20	0501010694	FLAT WASHER		02
21	0521011039	FLAT WASHER		02
22	0503011444	SPRING WASHER		02
23	0503010337	5/16" NUT		02
24	0551018055	22,65 X 60 SLEEVE		01
25	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01



Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0501069470	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	19	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	0.3" X 3.1" LOCK PIN		02
17	0503030168	CUPILLA		02
18	0501069643	890 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	20	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER		02
23	0503010025	3/8" SPRING WASHER		02
24	0501053834	MALE QUICK COUPLER	21	02
25	0502012702	BODY SUPPORT CLAMP		06
26	0503011103	7/16" X 2-1/2" BOLT		06
27	0501012803	FLAT WASHER		02
28	0503010180	7/16" SPRING WASHER		06
29	0503010244	7/16" NUT		06
30	0501012140	FLAT WASHER		04
31	0503012412	5/8 UNC SELF LOCKING NUT		02


Item	Code	Description	See page	QT
32	0511011311	VALVE SUPPORT		01
33	0503010232	5/8" X 1.3/4" BOLT		02
34	0503010027	5/8" SPRING WASHER		02
35	0503010013	5/8" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		08
37	0511057071	HYDRAULIC HOSE MARKER ASSY 10L		01
37A	0501081729	HOSE 3/8 X 3125 TR-TR		02
37B	0501081633	HOSE 3/8 X 3325 TR-TC		02
38	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
38A	0501080422	HOSE 3/8 X 4000 TC-TM		01
38B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
38C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
38D	0503018952	PLASTIC BOLT		06
39	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
39A	0501080422	HOSE 3/8 X 4000 TC-TM		01
39B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
39C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
39D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCIAL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01



Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	23	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04



Item	Code	Description	See page	07	09	10	11
00	0511058304	RIGHT TRANSMISSION ASSY - 3245		01	00	00	00
00.	0511058305	LEFT TRANSMISSION ASSY - 3245		01	00	00	00
00..	0511058599	RIGHT TRANSMISSION ASSY - 4045		00	01	00	00
00...	0511058600	LEFT TRANSMISSION ASSY - 4045		00	01	00	00
00....	0511058592	RIGHT TRANSMISSION ASSY - 4495	26	00	00	01	00
00.....	0511058593	LEFT TRANSMISSION ASSY - 4495	25	00	00	01	00
00.....	0511056751	RIGHT TRANSMISSION ASSY - 4880		00	00	00	01
00.....	0511056752	LEFT TRANSMISSION ASSY - 4880		00	00	00	01
01	0511069724	CARRYING-WHEELS PIVOT SHAFT		01	00	00	00
02	0511069682	CARRYING-WHEELS PIVOT SHAFT		00	01	00	00
03	0521062242	CARRYING-WHEELS PIVOT SHAFT		00	00	01	00
04	0511069717	CARRYING-WHEELS PIVOT SHAFT		00	00	00	01
05	0521013199	LOWER BEARING SEMI		04	04	04	06
06	0503010899	5/8" X 2-1/4" BOLT		08	08	08	08
07	0501012140	FLAT WASHER		16	16	16	16
08	0531013922	0.6" X 0.8" X 1" SLEEVE		08	08	08	08
09	0503010013	5/8" NUT		08	08	08	08
10	0503011445	SPRING WASHER		16	16	16	16
11	0501110639	BEARING		03	04	04	04
12	0503011099	GREASE FITTING		03	04	04	04
13	0503010300	5/32" X 1" COTTERPIN		03	04	04	04
14	0551019114	MOTOR BEARING AXLE SUPPORT		01	02	02	02
15	0521014021	1/2" X 4.5" X 5.4" FASTENER		01	02	02	02
16	0511017302	FLAT WASHER		02	04	04	04
17	0503010019	1/2" SPRING WASHER		02	04	04	04
18	0503010060	1/2" NUT		02	04	04	04
19	0561016882	1535 MOTOR SHAFT		01	00	00	00
20	0561016881	MOTOR SHAFT		00	01	00	00
21	0561018351	2155 MOTOR SHAFT		00	00	01	00
22	0561016876	MOTOR SHAFT		00	00	00	01
23	0501018466	FLAT WASHER		02	02	02	02


Item	Code	Description	See page	07	09	10	11
24	0511015961	LOCK BUSHING		02	02	02	02
25	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02	02	02	02
26	0501052560	MOTOR AXLE SIGNAL	27	01	01	01	01
27	0511051434	TRANSMISSION ACTUATOR	28	01	02	02	02
28	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	29	01	01	01	01
29	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	30	01	01	01	01
30	0521043316	RIGHT GEAR BOX ASSY	31	01	01	01	01
31	0521043317	LEFT GEAR BOX ASSY	32	01	01	01	01
32	0501010243	1/2" X 1-1/2" BOLT		03	03	03	03
33	0503012682	1/2" BSW NUT		03	03	03	03
34	0503010920	1/2" X 1.1/2" BOLT		02	02	02	02
35	0511017302	FLAT WASHER		04	04	04	04
36	0503010019	1/2" SPRING WASHER		05	05	05	05
37	0503010060	1/2" NUT		02	02	02	02
38	0521064448	GEAR		01	01	01	01
39	0503030275	AGRICULTURAL BEARING		01	01	01	01
40	0501010637	FLAT WASHER		02	02	02	02
41	0501010984	FLAT WASHER		01	01	01	01
42	0503010025	3/8" SPRING WASHER		01	01	01	01
43	0503010256	3/8" X 3/4" BOLT		01	01	01	01
44	0511054363	CHAIN TENSIONER	42	01	01	01	01
44A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01	01	01	01
44B	0503031805	11Z 1/2" GEAR		01	01	01	01
44C	0511017302	FLAT WASHER		02	02	02	02
44D	0503010019	1/2" SPRING WASHER		01	01	01	01
44E	0503010060	1/2" NUT		01	01	01	01
45	0501058265	STRETCHER LOWER CURRENT 21Z SEED	43	01	01	01	01
45A	0511062169	21Z P 1/2" GEAR		01	01	01	01
45B	0503011410	ROLLER BEARING		01	01	01	01
45C	0503011105	SEAL RING		01	01	01	01
45D	0531017086	50 AXLETIGHTENER		01	01	01	01
45E	0503010406	501025 CLAMPING RING (FOR AXLE)		01	01	01	01
45F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01	01	01	01
45G	0501012140	FLAT WASHER		01	01	01	01
45H	0503010027	5/8" SPRING WASHER		01	01	01	01
45I	0503010013	5/8" NUT		01	01	01	01
46	0501058254	UPPER SEED CHAIN TENSIONER	44	01	01	01	01
47	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED		01	01	01	01
48	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED		01	01	01	01
48A	0511069680	20Z X 28Z DOBLE GEAR		01	01	01	01
48B	0503011410	ROLLER BEARING		01	01	01	01
48C	0551019175	DOUBLE GEAR AXLE		01	01	01	01
48D	0503010406	501025 CLAMPING RING (FOR AXLE)		01	01	01	01
48E	0501010163	5/8" X 4-1/2" BOLT		01	01	01	01
48F	0503012412	5/8 UNC SELF LOCKING NUT		01	01	01	01
49	0503012204	40-1 CHAIN X 82 LINK + RED		01	01	01	01
50	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01	01	01	01
51	0503012719	40-1 CHAIN X 113 LINK + MENDING		01	01	01	01
52	0503014907	40-1 X 151 CHAIN LINK + MENDING		01	01	01	01
53	0531016940	5/8 X 1650 RIGHT HEX AXLE		01	00	00	00
54	0531016941	LEFT 5/8" X 59" AXLE HEX		01	00	00	00
55	0531016942	RIGHT HEX AXLE 5/8 X 2050		00	01	00	00
56	0531016943	LEFT HEX AXLE 5/8 X 1900		00	01	00	00
57	0561019199	5/8" X 2275 AXLE HEX		00	00	01	00
58	0561019200	5/8" X 2125 AXLE HEX		00	00	01	00
59	0531016944	RIGHT 5/8" X 96" HEX AXLE		00	00	00	01
60	0531016945	LEFT 5/8" X 90" HEX AXLE		00	00	00	01
61	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE		02	02	02	02
62	0561014215	BEARING COVER LOWER ROW FRAME		02	02	02	02

Item	Code	Description	See page	07	09	10	11
63	0502040534	SPRING GUIDE BUSHING LOCK		04	04	04	04
64	0501018535	1/2 X 1 BOLT		04	04	04	04
65	0503011750	AMENDMENT WITH LOCK		06	06	06	06
66	0503011751	REDUCTION		06	06	06	06
67	0503010780	N-2050 AMENDMENT		02	02	02	02
68	0503010951	REDUCTION		04	04	04	04
69	0503010179	LOCK WASHER		02	02	02	02
70	0501010694	FLAT WASHER		04	04	04	04
71	0503010337	5/16" NUT		02	02	02	02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561018351	2155 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	27	01
15	0511051434	TRANSMISSION ACTUATOR	28	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	30	01
17	0521043317	LEFT GEAR BOX ASSY	32	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2" X 1.1/2" BOLT		02
20	0511017302	FLAT WASHER		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2" NUT		02
24	0521064448	GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	FLAT WASHER		01
28	0503010025	3/8" SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	42	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	43	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	44	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED		01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED		01
35	0501055112	MICRO GRANULATED CHAIN TENSIONER	47	01
36	0503012204	40-1 CHAIN X 82 LINK + RED		01
37	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
38	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
39	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561018351	2155 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	27	01
15	0511051434	TRANSMISSION ACTUATOR	28	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	29	01
17	0521043316	RIGHT GEAR BOX ASSY	31	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2" X 1.1/2" BOLT		02
20	0511017302	FLAT WASHER		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2" NUT		02
24	0521064448	GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	FLAT WASHER		01
28	0503010025	3/8" SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	42	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	43	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	44	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED		01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED		01
35	0501055112	MICRO GRANULATED CHAIN TENSIONER	47	01
36	0503012204	40-1 CHAIN X 82 LINK + RED		01
37	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
38	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
39	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02

RIGHT SIDE TRANSMISSION ACTUATOR

0511047069




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY


0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	33	01
02	0511059266	CLOSED BEARING	35	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	37	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	39	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	40	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	41	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	34	01
02	0511059266	CLOSED BEARING	35	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	37	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	39	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	40	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	41	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX	01	
02	0502011758	REAR TENSIONER LEVER	02	
03	0503010292	0.2" X 1.6" SPRING PIN	02	
04	0511061794	CHAIN TENSIONER	01	
05	0503031367	SPRING	01	
06	0511060392	CHAIN TENSIONER	01	
07	0503031366	RIGHT TWISTED SPRING RECAMBIO	01	




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	36	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	38	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0521018933	FERT CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019174	DOBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501058240	WHEEL FASTENER WITH TENSIONER	49	01
02	0503011119	7/8" X 6" BOLT		04
03	0501014251	FLAT WASHER		04
04	0503011254	7/8" HEX SELF ADJUSTING NUT		04
05	0501059909	CARRYING WHEELS SUPPORT	53	01
06	0503014887	2050 CHAIN X 80 LINK + REDUCTION		01
07	0502010584	CARRYING-WHEELS SUPPORT FIXER		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	50	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	51	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	52	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TIGHTENER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN UPPER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0591017923	GLOVE 15.30 X 30 X 32		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0531016887	CARRYING WHEEL AXLE ARM		01
03	0503010523	1/4" X 2" COTTERPIN		01
04	0503010003	1845 GREASE FITTING		01
05	0511050681	TRACTION SPRING		01
05A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
05B	0561016062	SPRING HITCH		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		04
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0511052770	WHEEL WITH TIRE	54	01
11	0501058241	WHEEL SUPPORT CHAIN TENSIONER	56	01
12	0521061565	WHEEL SUPPORT ARM		01
13	0503018981	BOLT		02
14	0521069983	WHEEL COVER		01
15	0591010589	BODY LOCK WHEEL		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE		01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	55	01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSM AXLE CARRYING-WHEEL		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511057070	HOSE KIT HYDRAULIC		01
01A	0521052285	TC-TM HOSE ASSY		01
01AA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01AB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01AD	0503018952	PLASTIC BOLT		06
01B	0521052287	TC-TM HOSE ASSY		01
01BA	0501080446	3/8 X" 169" TC-TM HOSE ASSY		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01BD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	21	02
03	0503013100	NYLON CLAMP		02
04	0581010091	SPRING PROTECTION PLASTIC HOSE		01



Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0511062887	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01

ASSY HEX AXLE


0909095145




Item	Code	Description	See page	3245	4045	4845
01	0521013432	5/8" X 59" AXLE HEX	01	00	00	
01.	0521013429	AXLE HEX 5/8 X 2180	00	01	00	
01..	0521013430	HEX AXLE 5/8 X 2580	00	00	01	
02	0521013428	HEX AXLE	01	00	00	
02.	0521013433	5/8" X 75" AXLE HEX	00	01	00	
02..	0521013434	HEX AXLE 5/8 X 2300	00	00	01	
03	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"	02	02	02	
04	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8	02	02	02	
05	0503010003	1845 GREASE FITTING	02	02	02	
06	0503010365	NUT	04	04	04	
07	0501010984	FLAT WASHER	04	04	04	
08	0501010694	FLAT WASHER	08	08	08	
09	0503010179	LOCK WASHER	04	04	04	
10	0503010337	5/16" NUT	04	04	04	
11	0511815098	FLAT WASHER	02	02	02	
12	0511017305	FLAT WASHER	04	04	04	
13	0511065562	20Z GEAR	02	02	02	
14	0502011299	BUSHING GEAR	02	02	02	
15	0503010571	1/4" X 1.1/2 COTTERPIN	02	02	02	
16	0503010010	1/4" X 2.1/2" COTTERPIN	02	02	02	



Item	Code	Description	See page	QT
01	0909092325	SEED LINE	63	01
02	0909091899	FERTILIZER ROW WITH DDD & 18"/20" COULTER BLADE	86	01
03	0909092327	FERTILIZER LINE WITH STEM	97	01
04	0531013600	PRESS ADJUSTMENT LEVER		01
05	0501110231	SCARIFIER HEAD WITH SPIKE 0061	100	09
06	0511017969	0.1" SPACING PLATE		18
07	0521069127	BOTTOM NOZZLE FERTILIZER		09
08	0503030483	FERTILIZER SOCKET		09
09	0503016204	CORN DISK 12 ORANGE		09
10	0503016214	RING CORN (APOLLO740)		09
11	0503016218	DISC OF SOYBEAN		09
12	0503016220	RING TO SOYBEANS (APOLLO 745)		09
13	0503016221	RING TO SOYBEANS (APOLLO 571)		09
14	0501050120	LARGER WALKING BEAM ASSY	101	09
15	0503030558	PULLEY 4Z CORN PLASTIC		09
16	0511052024	FAST CLOSING SET	69	09
17	0521057957	FIXED ROD EXTENSION WITH FIXATION	102	04




Item	Code	Description	See page	QT
01	0909093293	SEED ROW FRONT ASSY UNTIL (9/2011)	64	01
02	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0511056622	LEFT REAR LINE SEED	66	01
06	0511056621	REAR RIGHT SEED LINE	65	01
07	0531016944	RIGHT 5/8" X 96" HEX AXLE		01
08	0531016945	LEFT 5/8" X 90" HEX AXLE		01
09	0503016204	CORN DISK 12 ORANGE		01
10	0503016214	RING CORN (APOLLO740)		01
11	0503016218	DISC OF SOYBEAN		01
12	0503016220	RING TO SOYBEANS (APOLLO 745)		01
13	0503016221	RING TO SOYBEANS (APOLLO 571)		01
14	0501050120	LARGER WALKING BEAM ASSY	101	01
15	0503030558	PULLEY 4Z CORN PLASTIC		01
16	0511057017	SEED SYSTEM ASSY	67	01
17	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	76	01




Item	Code	Description	See page	QT
00	0501059834	FRONT LINE SEED SHORT LEFT CARDAN	01	
00A	0501059835	FRONT LINE SEED LONG RIGHT CARDAN	00	
00B	0501059833	FRONT LINE SEED SHORT RIGHT CARDAN	01	
00C	0501059836	FRONT LINE SEED LONG LEFT CARDAN	00	
01	0521061237	LH SEED ROW SUPPORT FRONT	01	
02	0521061425	RH SEED ROW SUPPORT FRONT	00	
03	0502010175	HITCH CLAMP	02	
04	0501010163	5/8" X 4-1/2" BOLT	04	
05	0501012140	FLAT WASHER	04	
06	0503012412	5/8 UNC SELF LOCKING NUT	04	
07	0503012882	BEARING	04	
08	0503011945	503050 CLAMPING RING (FOR AXLE)	04	
09	0561017947	17Z GEAR WITH HEX HOLE	02	
10	0511050073	SEED ROW TRANSMISSION HUB	02	
11	0561014904	TRANSMISSION AXLE FRAME LINE	02	
12	0511050609	BEARING WITH 17Z GEAR ASSY	02	
12A	0511050617	FRONT SEED ROW BEARING	02	
12Aa	0502011697	BEARING OF THE GEAR BOX	02	
12Ab	0503011410	ROLLER BEARING	02	
12Ac	0503011105	SEAL RING	06	
12Ad	0503011953	5/16" X 1" BOLT	04	
12Ae	0501010694	FLAT WASHER	08	
12Af	0503010179	LOCK WASHER	08	
12Ag	0503010337	5/16" NUT	08	
12B	0561017909	17Z GEAR WITH HEX HOLE	02	
12C	0503010406	501025 CLAMPING RING (FOR AXLE)	06	
13	0511050610	SEED ROW CHAIN TENSIONER ASSY	02	
13A	0531019479	AXLE CHAIN GEAR	02	
13B	0541016454	PULLEY	02	
13C	0521014188	FLAT WASHER	02	
13D	0503010019	1/2" SPRING WASHER	02	


Item	Code	Description	See page	QT
13E	0503010060	1/2" NUT		02
14	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		02
15	0502012666	SEED ROW LOWER ARM		02
16	0503010003	1845 GREASE FITTING		08
17	0561015858	SPACER LOWER SLEEVE		02
18	0531015151	0.6" X 1" X 2.4" SLEEVE		14
19	0531015184	FLAT WASHER		16
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		08
21	0503012412	5/8 UNC SELF LOCKING NUT		08
22	0502012350	SEED ROW UPPER ARM		02
23	0521061427	SHORT SEED ROW FRAME		02
24	0502012568	UPPER ROCKER ARM		02
25	0561019032	SEED FERTIL ROW LOCK		02
26	0501011388	COUPLING SHAFT		04
27	0503010071	3/16" X 1" COTTERPIN		02
28	0503030168	CUPILLA		02
29	0521061850	SPRING UPPER FIXER		02
30	0521010773	0.37" X 1.18" COUPLING SHAFT		02
31	0503010140	1/8" X 3/4" COTTERPIN		02
32	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		04
33	0511050611	5/8" HEX AXLE BEARING		02
33A	0501059363	5/8" HEX AXLE BEARING		02
33Aa	0502011697	BEARING OF THE GEAR BOX		02
33Ab	0561014911	AXLE SLEVE GUIDES HEX		02
33B	0503011953	5/16" X 1" BOLT		04
34	0501059326	UNIVERSAL JOINT AXLE		02
34A	0561014794	350 AXLE HEX		02
34B	0501056296	UNIVERSAL JOINT		02
34C	0561016322	5/8" HEX AXLE		02
34D	0503011855	0.2" X 1.8" SPRING PIN		04
35	0521061238	RH SEED ROW SUPPORT FRONT		01
36	0521061426	LH SEED ROW SUPPORT FRONT		00




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503011443	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED		01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503011443	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511056586	15 X 15 SEED DDD LEFT		01




Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG	01	
02	0503016219	RING TO SOYBEANS	01	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010209	3/8" UNC BUTTERFLY NUT	03	
05	0503016283	M8 NUT HEX	01	
06	0502020693	SUPPORT SEED BOX	01	
07	0502012721	SEED DISC LOWER TRAIL	01	
08	0503030083	3/8" X 3/8" X 1.6" STUD	02	
09	0503016282	ALLEN BOLT	01	
10	0503010675	5/16" X 2.1/4" BOLT	01	
11	0503010179	LOCK WASHER	05	
12	0503010337	5/16" NUT	01	
13	0501010694	FLAT WASHER	04	
14	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN	04	
15	0501051094	ASSY SEED DISTRIBUTOR	01	
16	0503031508	COVER GREEN BEAM SEED YELLOW	01	
17	0571018536	HEX PRISONER	01	
18	0501013518	FLAT WASHER	02	
19	0503034131	DEFLECTOR	01	




Item	Code	Description	See page	QT
01	0502012538	SPRING VARON SUPPORT		01
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
03	0511017302	FLAT WASHER		02
04	0503011336	1/2" HEX SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502011411	10Z CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	BOX DDD ASSY DPL 15 RIGHT	73	01
04	0501054168	BOX DDD ASSY DPL 15 LEFT	74	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	COVER DEPTH		02
07	0503014729	1/4" UNF X 1/2" BOLT		06
08	0503011441	SPRING WASHER		06
09	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503011443	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0511052301	SUPPORT DDD 15 RIGHT		01
15A	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
15B	0571012491	SOCKET SEED GUIDE		01
15C	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	BOX DDD ASSY DPL 15 RIGHT	73	01
04	0501054168	BOX DDD ASSY DPL 15 LEFT	74	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	COVER DEPTH		02
07	0503014729	1/4" UNF X 1/2" BOLT		06
08	0503011441	SPRING WASHER		06
09	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503011443	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0511052302	LH SUPPORT DDD GUIDE		01
15A	0561015592	LEFT DOUBLE DISC SUPPORT		01
15B	0571012491	SOCKET SEED GUIDE		01
15C	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502011930	DOUBLE DISC COULTER BOX		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019154	RIGHT DOUB DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011930	DOUBLE DISC COULTER BOX		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019148	LEFT DOUBLE DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012823	CUTTING DISC SUPPORT		01
02	0503034318	5/8 UNC X 2 BOLT		02
03	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	77	01
02	0501052538	DEPTH BAND WITH ARMS	82	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	83	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	84	01
07	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	78	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	79	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	81	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	SCREWEW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL BOX	80	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL BOX	80	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	COVER DEPTH		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	85	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	85	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0502010175	HITCH CLAMP		01
03	0501011543	5/8" X 4" BOLT		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC		01
06	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC		00
07	0501010066	3/4" X 9" BOLT		01
08	0521017831	SUPPORT SLEEVE SPACER		02
09	0511017232	FLAT WASHER		02
10	0503011255	3/4" LOCK NUT		01
11	0501058423	FERTILIZER ROD SPRING ROW		01
12	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW		01
13	0511044573	18" COULTER BLADE ASSY FOR LONG ROW		00
14	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW		01
15	0511044585	20" COULTER BLADE ASSY FOR LONG ROW		01
16	0503030391	RIGHT FERTILIZER NOZZLE		01
17	0503030392	LEFT FERTILIZER NOZZLE		00
18	0503031050	CURVED CONDUCTOR		01
19	0503010246	CLAMP		01
20	0503031145	2" X 2" X 20" HOSE		01
21	0503031076	2" HOSE CLAMP		02
22	0521044545	20" SHORT CURVED CORRIGATED DISC		04
23	0521044546	20" LONG CURVED CORRUGATED DISC		03
24	0909092327	FERTILIZER LINE WITH STEM	97	




Item	Code	Description	See page	QT
01	0521068662	DOC SHORT ARM		01
02	0581011838	SLEEVE GUIDES		01
03	0521015376	DUST CLOAK		01
04	0503010878	5/8" SELF ALIGNING NUT		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2" NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503010276	6206 BALL BEARING		01
10	0503030832	FLAT WASHER		01
11	0511059229	BOX WITH DOC 18 TURBO RIGHT	89	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0521068662	DOC SHORT ARM		01
02	0581011838	SLEEVE GUIDES		01
03	0521015376	DUST CLOAK		01
04	0503010878	5/8" SELF ALIGNING NUT		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2" NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503010276	6206 BALL BEARING		01
10	0503030832	FLAT WASHER		01
11	0511059230	BOX WITH DOC 18 TURBO LEFT	90	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0502011562	DC BOX		01
02	0503011800	SEAL RING		01
03	0503012417	SEAL		01
04	0503010276	6206 BALL BEARING		01
05	0503030832	FLAT WASHER		01
06	0503011444	SPRING WASHER		06
07	0503010691	1/4" GREASE FITTING		01
08	0503010337	5/16" NUT		06
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0607025032	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0502011562	DC BOX		01
02	0503011800	SEAL RING		01
03	0503012417	SEAL		01
04	0503010276	6206 BALL BEARING		01
05	0503030832	FLAT WASHER		01
06	0503011444	SPRING WASHER		06
07	0503010691	1/4" GREASE FITTING		01
08	0503010337	5/16" NUT		06
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0607025032	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0581013298	SUPPORT		01
02	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
03	0521018517	FLAT WASHER		01
04	0503010060	1/2" NUT		01
05	0503010019	1/2" SPRING WASHER		01
06	0503030483	FERTILIZER SOCKET		01
07	0503031050	CURVED CONDUCTOR		01
08	0503010246	CLAMP		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	WASHER BRACKET AXIS DC PST		01
17	0503034319	LOCK PIN		01
18	0511058648	BOX WITH DISC BLADE 20	94	01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012824	FIXING SHAFT DISC CUT LINE		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	WASHER BRACKET AXIS DC PST		01
17	0503034319	LOCK PIN		01
18	0511058648	BOX WITH DISC BLADE 20	94	01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511056909	DISC BOX CUT WITHOUT THE DISC	95	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01



Item	Code	Description	See page	QT
01	0502012793	DC PST		01
02	0571018047	CUTTING DISC BOX SHAFT		01
03	0503017755	NUT		01
04	0502020641	BLADE DISC FLANGE		01
05	0503013816	5/16" LOCKNUT		06
06	0571018048	BACKREST WASHER		02
07	0521065882	NILOS SEALING RING		02
08	0571018049	DOOR DUST		02
09	0581010575	7/8" X 145 BOLT		01
10	0503018825	5/16 UNC UNC BOLT		06
11	0501010694	FLAT WASHER		06
12	0503016061	BEARING		02
13	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK	02	
02	0502012184	FERTILIZER SPRING GUIDE	02	
03	0503031910	1.7" X 22.8" X 0.3" SPRING	01	
04	0502012510	SPRING ROD SUPPORT	01	
05	0521068568	LARGE ELEVATION SPRING FERTILIZER	01	
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN	01	
07	0501018535	1/2 X 1 BOLT	02	
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
09	0503010060	1/2" NUT	02	
10	0502010891	SPRING CHOCK SUPPORT VARON	01	
11	0503010014	3/4" NUT	01	
12	0561014471	COUPLING SHAFT	01	
13	0511017302	FLAT WASHER	01	
14	0503010257	1/8" X 1" COTTERPIN	01	




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0502010175	HITCH CLAMP		01
03	0501011543	5/8" X 4" BOLT		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0521061153	LONG ARM FERTILIZER LINE		00
07	0501010066	3/4" X 9" BOLT		01
08	0521017831	SUPPORT SLEEVE SPACER		02
09	0511017232	FLAT WASHER		02
10	0503011255	3/4" LOCK NUT		01
11	0501058423	FERTILIZER ROD SPRING ROW		01
12	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW		01
13	0511044585	20" COULTER BLADE ASSY FOR LONG ROW		00
14	0503031050	CURVED CONDUCTOR		01
15	0503010246	CLAMP		01
16	0503031145	2" X 2" X 20" HOSE		01
17	0503031076	2" HOSE CLAMP		02
18	0501110231	SCARIFIER HEAD WITH SPIKE 0061	100	01
18A	0511061768	FERTILIZER SCARIFIER ROD		01
18B	0501056132	POINT SUBSOILER		01
18BA	0502070061	POINT SUBSOILER		01
18BB	0503010585	0.24" X 1.18" SPRING PIN		01
18BC	0503011373	0.4" X 1.1" SPRING PIN		01
19	0511017969	0.1" SPACING PLATE		01
20	0511061852	ADJUSTMENT CONDUCTOR FERTILIZER		01
20.	0521069127	BOTTOM NOZZLE FERTILIZER		01
21	0503010547	1/2" X 4" BOLT		02
22	0503011440	SPRING WASHER		02
23	0503010060	1/2" NUT		02
24	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
25	0501010984	FLAT WASHER		01




Item	Code	Description	See page	QT
26	0503010025	3/8" SPRING WASHER		01
27	0503010026	3/8" NUT		01
28	0521044545	20" SHORT CURVED CORRIGATED DISC		04
29	0521044546	20" LONG CURVED CORRUGATED DISC		03




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503062794	SEED MONITORING KIT 9L 45/50 PM400		01
01A	0503016555	9 ROW SIMPLE MONITOR CABLE		01
01B	0503019100	SENSOR		09
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503013100	NYLON CLAMP		45
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		**
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
08	0503010669	FLAT WASHER		02
09	0503010668	3/16" SPRING WASHER		02
10	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER ROD		01
02	1902070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01



Item	Code	Description	See page	QT
01	0503030379	LARGER ROCKER ARM		01
02	0502060001	PLASTIC PULLEY FOR MAIZE		01
03	0503010669	FLAT WASHER		01
04	0503010667	3/16" NUT		02
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		01



Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02



MARCHESAN

Technical Publications | Elaboration and Revision

JOSÉ DOMINGOS GASPARI

www.marchesan.com.br

