

ROW CROP PLANTERS

PST TRIO - FRAME 6850/7450 (UP TO 03/2022)

Code:	0501092753
Series:	S-0119
Revision:	00
Date Revision:	NOVEMBRO/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111270086	PST TRIO 6850/15E450 CI DC20 S-0119
0111270090	PST TRIO 7450/15E500 DAOC/H CI MH DC20 PM400 S0119

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.

INDEX

0909099094	FRAME ASSY	1
0511059420	FRAME WITH ARTICULATION 6850	2
0511053196	PST JOINT FRAME	3
0511053188	RIGHT FRAME WITH WHEELED AXLE 7450	4
0511053046	RIGHT FRAME WITH AXLE WHEELED 6850	5
0511059288	CENTRAL FRAME WITH WHEELED AXLE 5750/6850/7860/8160	6
0511053190	CENTRAL FRAME WITH WHEELED AXLE 6450/7285/7450/8460	7
0511053047	LEFT FRAME WITH WHEELED AXLE 6850	8
0511053189	LEFT FRAME WITH WHEELED AXLE 7450	9
0511059232	ASSEMBLY SPRING TRACTION	10
0521058397	WHEELSET WITH SPRING TRACTION	11
0521058400	WHEEL WITH DRAW SPRING 585 WITHOUT TRANSMISSION	12
0521058395	WHEEL SUPPORT ASSY WITH TRANSMISSION	13
0521058398	WHEEL SUPPORT WITHOUT TRANSMISSION	14
0501058241	WHEEL SUPPORT CHAIN TENSIONER	15
0521058393	WHEEL WITH PNEU 7.00X16 14L PR TT WITH TRANSMISSION	16
0521058394	WHEEL WITH PNEUME	17
0503063172	WHEEL	18
0521055233	WHEELED TRANSMISSION WITHOUT TIRE	19
0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	20
0501058240	WHEEL FASTENER WITH TENSIONER	21
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	22
0501058244	WHEEL FIXED CHAIN TENSIONER	23
0501058242	WHEEL MOBILE CHAIN TENSIONER	24
0909095124	HEADER FULL ASSEMBLY	25
0511055096	TRACTOR HITCH	26
0521051614	TURNBUCKLE SIDE UPPER	27
0521050133	TURNBUCKLE SIDE 755/480	28
0511059237	3 POINT TURNBUCKLE	29
0521045756	HYDRAULIC CYLINDER	30
0511059419	HYDRAULIC SYSTEM ASSEMBLY 6850/7285/7450/7860/7960	31
0511059290	VALVE ASSEMBLY	32
0501053835	FEMALE QUICK COUPLER	33
0501053834	MALE QUICK COUPLER	34
0521052737	SILO FERTILIZER ASSEMBLY 6850	35
0521052622	ASSY SILO FERTILIZER 7450	36
0521052620	SUPPORT SILO RIGHT FERTILIZER WITH DISTRIBUTOR 7450	37
0521052621	SILO SUPPORT LEFT FERTILIZER WITH DISTRIBUTOR 7450	38
0521051607	SUPPORT SILO CENTRAL FERTILIZER 6450/7285/7450/8460	39
0521052712	SILO FERTILIZER RIGHT SUPPORT 6850	40
0521052721	SILO FERTILIZER LEFT SUPPORT 6850	41
0521052734	SUPPORT SILO CENTRAL FERTILIZER 6850/7860	42
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	43
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	44
0501053788	3/4 SQUARE AXLE FASTENER	45
0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	46
0521050195	SILO FERTILIZER LEFT SQUARE AXLE	47
0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	48
0511058263	TRANSMISSION ASSEMBLY 6850	49
0511058271	TRANSMISSION ASSEMBLY 7450	50
0501052560	MOTOR AXLE SIGNAL	51
0511051434	TRANSMISSION ACTUATOR	52
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	53
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	54
0521043316	RIGHT GEAR BOX ASSY	55



MARCHESAN

INDEX


0521043317	LEFT GEAR BOX ASSY	56
0501058212	SEMI MOUNTED RIGHT CHANGE	57
0501058213	LH GEAR BOX	58
0511059266	CLOSED BEARING	59
0501056271	GEARBOX CLOSED BEARING	60
0501056443	GEAR HOUSING BEARING	61
0501056444	BEARING WITH ROLLING	62
0501048790	AXLE WITH RING	63
0501054655	CHAIN TENSIONER ASSY	64
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	65
0511054363	CHAIN TENSIONER	66
0501058234	LOWER CHAIN TENSIONER	67
0521055207	TOP CURRENT STRETCHER	68
0501058236	BEARING WITH 21Z GEAR	69
0501058237	16Z GEAR BEARING	70
0501055112	MICRO GRANULATED CHAIN TENSIONER	71
0521052671	PLATFORM ASSEMBLY 6850	72
0521052672	PLATFORM ASSEMBLY 7450	73
0511058234	HANDLE ASSEMBLY 6850	74
0511058252	HANDLE ASSEMBLY 7450	75
0511054971	JACK ASSEMBLY	76
0511056536	LADDER ASSEMBLY	77
0521052796	CYLINDER ASSEMBLY 5750/6850/7860/7960/8460	78
0511058406	HYDRAULIC CYLINDER	79
0521053545	TRANSMISSION AXLE ASSEMBLY SEED 6850	80
0521054780	TRANSMISSION AXLE ASSEMBLY SEED 7450	81
0521043408	TRANSMISSION INTERMEDIARY SEED	82
0521052784	INTERMEDIATE TRANSMISSION RIGHT	83
0511054435	SUPPORT INTERMEDIARY TRANSMISSION RIGHT	84
0521052785	SUPPORT INTERMEDIARY TRANSMISSION LEFT PIVOTING	85
0521052787	INTERMEDIATE TRANSMISSION LEFT	86
0521052786	SUPPORT INTERMEDIARY TRANSMISSION RIGHT PIVOTING	87
0511054436	LEFT INTERMEDIATE TRANSMISSION SUPPORT	88
0521052803	REAR LIGHT ASSEMBLY	89
0521052792	MOUNTED REAR LIGHT	90
0521053479	ASSY MANUAL DOOR	91
0511057512	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE	92
0501054649	HBM SEQUENTIAL VALVE	93
0511058431	HYDRAULIC CYLINDER	94
0521025447	BOX WITH HYDRAULIC MARKER COMPONENTS	95
0521058756	ADHESIVE LABEL ASSY	96
0521053374	LABEL SET	97
0511056736	HOSE SUPPORT	98
0909099096	SEED LINE/FERTILIZER ASSEMBLY	99
0521054797	ASSEMBLY LINE SEED/FERTILIZER SHORT WITHOUT LUBRICATION	100
0521054798	CONJUNTO LINHA SEMENTE/ADUBO LONGA SEM LUBRIFICAÇÃO	101
0521054813	SHORT PIVOT LIFT LINE	102
0521054814	LONG PIVOT LIFT LINE	103
0511052024	FAST CLOSING SET	104
0511059244	ROD SPRING LINE SEED	105
0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	106
0521054775	LEFT REAR SEAL LINE BASE 1/2	107
0521054819	BASE 1/2 FIXED WITHOUT ASSY LUBRICATION	108



MARCHESAN


INDEX

0521054763	DDD LEFT SEED	109
0511052302	LH SUPPORT DDD GUIDE	110
0521054761	LEFT LOW CUBE	111
0521054760	DOWN LOW CUBE	112
0521053231	DPL 20 SHORT LINE WITHOUT LUBRICATION CONICAL BEARING	113
0521053232	DPL 20 LONG LINE WITHOUT LUBRICATION CONICAL BEARING	114
0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	115
0521053697	CUTTING DISK BOX	116
0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	117
0511057017	SEED SYSTEM ASSY	118
0521054768	DDD RIGHT FERTILIZER WITH SUPPORT	119
0521054769	LEFT FERTILIZER WITH SUPPORT	120
0521054764	DDD RIGHT FERTILIZER	121
0521054765	DDD LEFT FERTILIZER	122
0521054984	DEPTH/COMPACTOR SYSTEM - SPT	123
0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	124
0501052297	DEPTH WHEELS REGULATOR ASSY	125
0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	126
0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	127
0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	128
0521055033	COMPACTADOR BODY	129
0501052538	DEPTH BAND WITH ARMS	130
0521054990	LEFT COMPACTOR WHEEL	131
0521055017	RIGHT COMPACTOR WHEEL	132
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	133
0501050120	LARGER WALKING BEAM ASSY	134
0521053946	SCARING ROD	135
0521054912	RIGHT SUPPORT WITH DOC 18	136
0521054913	LEFT SUPPORT WITH DOC 18	137
0521050168	MOUNTED FERTILIZER CONDUCTOR	138
0521054914	BOX WITH DOC 18 RIGHT	139
0521054915	BOX WITH DOC 18 LEFT	140



Item	Code	Description	See page	6850	7450
01	0511059420	FRAME WITH ARTICULATION 6850	2	01	00
01.	0511053196	PST JOINT FRAME	3	00	01
02	0521064285	LOCK LOWER FRAME		02	02
03	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		02	02
04	0503010002	1800 GREASE FITTING		02	02
05	0503010003	1845 GREASE FITTING		08	08
06	0503010004	1890 GREASE FITTING		02	02
07	0511059232	ASSEMBLY SPRING TRACTION	10	02	02
08	0521058397	WHEELSET WITH SPRING TRACTION	11	04	04
09	0521058400	WHEEL WITH DRAW SPRING 585 WITHOUT TRANSMISSION	12	02	02
10	0909095124	HEADER FULL ASSEMBLY	25	01	01
11	0511059419	HYDRAULIC SYSTEM 6850/7285/7450/7860/7960	ASSEMBLY 31	01	01
12	0521052737	SILO FERTILIZER ASSEMBLY 6850	35	01	00
12.	0521052622	ASSY SILO FERTILIZER 7450	36	00	01
13	0511058263	TRANSMISSION ASSEMBLY 6850	49	01	00
13.	0511058271	TRANSMISSION ASSEMBLY 7450	50	00	01
14	0521052671	PLATFORM ASSEMBLY 6850	72	01	00
14.	0521052672	PLATFORM ASSEMBLY 7450	73	00	01
15	0511058234	HANDLE ASSEMBLY 6850	74	01	00
15.	0511058252	HANDLE ASSEMBLY 7450	75	00	01
16	0511054971	JACK ASSEMBLY	76	02	02
17	0511056536	LADDER ASSEMBLY	77	02	02
18	0521052796	CYLINDER ASSEMBLY 5750/6850/7860/7960/8460	78	01	01
19	0521053545	TRANSMISSION AXLE ASSEMBLY SEED 6850	80	01	00
19.	0521054780	TRANSMISSION AXLE ASSEMBLY SEED 7450	81	00	01
20	0521052803	REAR LIGHT ASSEMBLY	89	01	01
21	0521053479	ASSY MANUAL DOOR	91	01	01
22	0521058756	ADHESIVE LABEL ASSY	96	01	00
22.	0521053374	LABEL SET	97	00	01
23	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01	01


Item	Code	Description	See page	6850	7450
24	0541015451	FIXED KEY 2.3/8 X 2.3/4		01	01
25	0501065677	STRUT		02	02
26	0501047895	ROD STOP		03	03
27	0501047885	ROD STOP		03	03
28	0501047886	ROD STOP		03	03
29	0501047887	ROD STOP		03	03
30	0511056736	HOSE SUPPORT	98	01	01
31	0521013022	TRANSPORT LOCK		03	03
32	0503030168	CUPILLA		03	03
33	0501068994	0.3" X 3.1"LOCK PIN		03	03
34	0521066304	HOSE GUIDE		01	01
35	0503019262	SOAP DISH VACUUM		01	01
36	0503010780	N-2050 AMENDMENT		02	02
37	0503011750	AMENDMENT WITH LOCK		06	06
38	0503011751	REDUCTION		06	06
39	0503010951	REDUCTION		04	04
40	0503010246	CLAMP		15	15
41	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		02	02
42	0503013816	5/16" LOCKNUT		02	02
43	0511057512	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE	92	00	01
44	0521025447	BOX WITH HYDRAULIC MARKER COMPONENTS	95	00	01
45	0521053426	MONITORING ASSEMBLY PLANTING SEEDS PM400	15L	00	01
46	0909099096	SEED LINE/FERTILIZER ASSEMBLY	99	13	15




Item	Code	Description	See page	QT
01	0511053046	RIGHT FRAME WITH AXLE WHEELED 6850	5	01
02	0511059288	CENTRAL FRAME WITH WHEELED AXLE 5750/6850/7860/8160	6	01
03	0511053047	LEFT FRAME WITH WHEELED AXLE 6850	8	01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0503011442	3/4" SPRING WASHER		18
06	0501010098	3/4" UNC BOLT		18
07	0571010094	SLEEVE FLANGE		06
08	0571013510	LOCK AXLE		02
09	0503030085	LOCK PIN		02
10	0571010095	FLAT WASHER		02
11	0521063003	LOCK PIN		02
12	0571010969	LOCK SLEEVE FRAME		02
13	0503013627	1.1/2 SPRING WASHER		02
14	0501010110	1.1/2" NUT		02
15	0502012698	CLAMP		04
16	0503011444	SPRING WASHER		04
17	0503010365	NUT		04
18	0521063912	PIVOT SHAFT		02
19	0581015857	GUTTER 24 X 50 X 1080		01
20	0581018001	GUTTER 24 X 50 X 980		02
21	0581017747	GUTTER 25 X 50 X 1200		02
22	0503010026	3/8" NUT		12
23	0503010025	3/8" SPRING WASHER		12
24	0501011643	3/8 X 1" BOLT		12

PST JOINT FRAME


0511053196




Item	Code	Description	See page	QT
01	0511053188	RIGHT FRAME WITH WHEELED AXLE 7450	4	01
02	0511053189	LEFT FRAME WITH WHEELED AXLE 7450	9	01
03	0511053190	CENTRAL FRAME WITH WHEELED AXLE 7450/7285/7450/8460	7	01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0503011442	3/4" SPRING WASHER		18
06	0501010098	3/4" UNC BOLT		18
07	0571010094	SLEEVE FLANGE		06
08	0521063912	PIVOT SHAFT		02
09	0571013510	LOCK AXLE		02
10	0503030085	LOCK PIN		02
11	0571010095	FLAT WASHER		02
12	0503010365	NUT		04
13	0503011444	SPRING WASHER		04
14	0502012698	CLAMP		04
15	0501011643	3/8 X 1" BOLT		14
16	0503010025	3/8" SPRING WASHER		14
17	0503010026	3/8" NUT		14
18	0521063003	LOCK PIN		02
19	0571010969	LOCK SLEEVE FRAME		02
20	0503013627	1.1/2 SPRING WASHER		02
21	0501010110	1.1/2" NUT		02
22	0581018018	TROUGH 24 X 50 X 1255		02
23	0581018019	TROUGH 24 X 50 X 1070		02
24	0581015857	GUTTER 24 X 50 X 1080		02




Item	Code	Description	See page	QT
01	0521064009	RIGHT FRAME PST TRIO 15		01
02	0521064023	ARTICLES AXLE RIGHT ROLLED		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521063886	RIGHT FRAME		01
02	0521063872	ARTICLES AXLE RIGHT ROLLED		01
03	0521013199	LOWER BEARING SEMI		02
04	0503010899	5/8" X 2-1/4" BOLT		04
05	0501012140	FLAT WASHER		08
06	0531013922	0.6" X 0.8" X 1" SLEEVE		04
07	0503011445	SPRING WASHER		04
08	0503010013	5/8" NUT		04




Item	Code	Description	See page	QT
01	0521066916	CENTRAL CHASSIS		01
02	0521013199	LOWER BEARING SEMI		04
03	0503010899	5/8" X 2-1/4" BOLT		08
04	0501012140	FLAT WASHER		16
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503010013	5/8" NUT		08
08	0521063878	ARTICLE AXLE ROLLED		01




Item	Code	Description	See page	QT
01	0521064011	CENTRAL FRAME PST TRIO 15		01
02	0521064022	CENTRAL ARTICLES AXLE ROLLED		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0521063885	LEFT FRAME		01
02	0521063873	ARTICLES AXLE LEFT ROLLED		01
03	0521013199	LOWER BEARING SEMI		02
04	0503010899	5/8" X 2-1/4" BOLT		04
05	0501012140	FLAT WASHER		08
06	0531013922	0.6" X 0.8" X 1" SLEEVE		04
07	0503011445	SPRING WASHER		04
08	0503010013	5/8" NUT		04




Item	Code	Description	See page	QT
01	0521064010	LEFT FRAME PST TRIO 15		01
02	0521064021	ARTICLES AXLE LEFT ROLLED		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		05
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		10
03	0501012140	FLAT WASHER		10




Item	Code	Description	See page	QT
01	0521058395	WHEEL SUPPORT ASSY WITH TRANSMISSION	13	01
02	0501058240	WHEEL FASTENER WITH TENSIONER	21	01
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503012212	2050 CHAIN X 81 LINK + MENDING		01
06	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
07	0503011254	7/8" HEX SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521058398	WHEEL SUPPORT WITHOUT TRANSMISSION	14	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0521061565	WHEEL SUPPORT ARM		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511050681	TRACTION SPRING		01
06A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
06B	0561016062	SPRING HITCH		02
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0501058241	WHEEL SUPPORT CHAIN TENSIONER	15	01
11	0521058393	WHEEL WITH PNEU 7.00X16 14L PR TT WITH 16 TRANSMISSION		01
12	0521069983	WHEEL COVER		01
13	0591010589	BODY LOCK WHEEL		01
14	0503010027	5/8" SPRING WASHER		04
15	0503018981	BOLT		02




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0521061565	WHEEL SUPPORT ARM		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0521058394	WHEEL WITH PNEUME	17	01
06	0591010589	BODY LOCK WHEEL		02
07	0503018981	BOLT		02
08	0503010027	5/8" SPRING WASHER		02
09	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503063172	WHEEL	18	01
02	0521055233	WHEELED TRANSMISSION WITHOUT TIRE	19	01




Item	Code	Description	See page	QT
01	0503063172	WHEEL	18	01
02	0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	20	01




Item	Code	Description	See page	QT
01	0503019458	TIRE 7.00X16 14PR		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0521012185	TRANSM AXLE CARRYING-WHEEL	01	
02	0503010330	KM 9 LOCKNUT	01	
03	0503010329	LOCK WASHER	01	
04	0511015949	LOCK NUT	01	
05	0503010804	00547-B SEAL	02	
06	0503019364	BEARING 25590/25523	02	
07	0501110721	WHEEL HUB WITH SCREW / NUTS	01	
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION	01	
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR	06	
07C	0503016516	5/8 UNF CONIC NUT	06	
08	0502011339	15Z GEAR P 1.25"	01	
09	0503012550	5/16" X 3/4" BOLT	06	
10	0503010002	1800 GREASE FITTING	01	




Item	Code	Description	See page	QT
01	0521012185	TRANSM AXLE CARRYING-WHEEL		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	22	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	23	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	24	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01



Item	Code	Description	See page	QT
01	0551018252	CHAIN TIGHTENER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0551018244	CHAIN UPPER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0591017923	GLOVE 15.30 X 30 X 32		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01



Item	Code	Description	See page	6450	6850
01	0521066289	FRONT HEADER 5750/6350/6850		001	001
02	0521067075	INTERMEDIATE HEAD 6450/7285/7350/7450/8460		001	000
02.	0521066290	INTERMEDIATE HEAD 5750/6850/7860/8160		000	001
03	0571019949	JUNCTION SHAFT		006	006
04	0503030119	LOCK PIN		010	010
05	0511055096	TRACTOR HITCH	26	001	001
06	0511053179	TRACTOR COUPLING SHAFT		001	001
06A	0521064036	TRACTOR HITCH AXLE		001	001
06B	0503030012	HAIR PIN		001	001
07	0503014120	CHAIN		001	001
08	0521051614	TURNBUCKLE SIDE UPPER	27	002	002
09	0521010571	COUPLING SHAFT		004	004
10	0503030085	LOCK PIN		006	006
11	0521051616	TURNBUCKLE SIDE 505/480		002	000
11.	0521050133	TURNBUCKLE SIDE 755/480	28	000	002
12	0571019951	JUNCTION SHAFT		003	003
13	0503010523	1/4" X 2" COTTERPIN		004	004
14	0503034772	BOX		001	001
15	0521068652	TOOLS BOX SUPPORT		001	001
16	0501011643	3/8 X 1" BOLT		004	004
17	0503010025	3/8" SPRING WASHER		004	004
18	0503010026	3/8" NUT		004	004
19	0581017000	PLATE INTERMEDIARY		002	002
20	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		004	004
21	0503010025	3/8" SPRING WASHER		004	004
22	0501010984	FLAT WASHER		004	004
23	0503014321	CABLE STEEL SHACKLE		002	002
24	0502010584	CARRYING-WHEELS SUPPORT FIXER		008	008
25	0503016485	BOLT 3/4		016	016
26	0501010322	FLAT WASHER		032	032
27	0503010152	3/4" SELF LOCKING NUT		016	016




HEADER FULL ASSEMBLY

0909095124


Item	Code	Description	See page	6450	6850
28	0521067716	FIXER TUBE		004	004
29	0511059237	3 POINT TURNBUCKLE	29	001	001
30	0571019950	COUPLING SHAFT		001	001
31	0521045756	HYDRAULIC CYLINDER	30	001	001
32	0521010779	31.75 X 95 COUPLING SHAFT		001	001
33	0521010581	0.9" X 4.9" COUPLING SHAFT		001	001
34	0531016049	FLAT WASHER		002	002
35	0503014820	BLACK WATER RESERVOIR		001	001
36	0521068651	SUPPORT BOX		001	001

TRACTOR HITCH


0511055096




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	COMPRESSION SPRING LEFT		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0502011195	ADJUSTMENT NUT BODY		01
02	0521068096	EXTENSOR R.1.1 / 2 UNC RIGHT		01
03	0521068095	EXTENSOR R.1.1/2 UNC LEFT		01
04	0541018672	COUNTERNUT		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521065193	TURNBUCKLE AXLE		01
02	0521067392	FIXED BRACKET		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0521067393	EXTERNAL SIDE EAR		01
06	0571019949	JUNCTION SHAFT		01
07	0503030119	LOCK PIN		01
08	0503010002	1800 GREASE FITTING		03



Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0511061880	SIDE RIGHT RATCHET		01
03	0511061881	RATCHET FOLLOWER		01
04	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
05	0503011179	3/8" X 2-1/4" BOLT		05
06	0503010025	3/8" SPRING WASHER		05
07	0503010026	3/8" NUT		05
08	0503010002	1800 GREASE FITTING		02
09	0531010264	SIDE RATCHET		01
10	0521066919	3-POINT EXTENSOR RIGHT FUSE		01
11	0521066337	LEFT EXTENSOR 3 SPIKE		01




Item	Code	Description	See page	QT
01	0511057653	HYDRAULIC CYLINDER		01
02	0501053835	FEMALE QUICK COUPLER	33	02




Item	Code	Description	See page	QT
01	0591019605	FLUXO DIVIDER VALVE SUPPORT		01
01.	0591019604	VALVE SUPPORT		01
02	0511059290	VALVE ASSEMBLY	32	01
03	0501053835	FEMALE QUICK COUPLER	33	02
04	0501010984	FLAT WASHER		04
05	0531011180	UPPER BODY CLIP		04
06	0521066564	DUCT SEAL OIL		01
07	0531013922	0.6" X 0.8" X 1" SLEEVE		02
08	0503011179	3/8" X 2-1/4" BOLT		02
09	0503010025	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0502012702	BODY SUPPORT CLAMP		12
12	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
13	0501053834	MALE QUICK COUPLER	34	04
14	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		04
15	0503010244	7/16" NUT		04
16	0503010180	7/16" SPRING WASHER		08
17	0503010920	1/2" X 1.1/2" BOLT		02
18	0511017302	FLAT WASHER		02
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2" NUT		02
21	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
22	0571017774	SPRING PROTECTION QUICK HOSE		01
23	0511059418	HYDRAULIC SYSTEM HOSE ASSEMBLY		01
23A	0501080406	3/8" X 23" TR-TC HOSE		01
23B	0501080150	3/8 X 800 TR-TC HOSE		01
23C	0501081930	HOSE		01
23D	0501081646	TC-TC HOSE ASSY		03
24	0521052484	HOSE 1/2 X 4122 TM-TM BLACK / RED		01
24A	0501080881	HOSE		01
24B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02


Item	Code	Description	See page	QT
24C	0503034495	HYDRAULIC HOSE GRIP (RED)		02
24D	0503018952	PLASTIC BOLT		12
25	0521052485	HOSE 1/2 X 4122 TM-TM BLACK / BLUE		01
25A	0501080881	HOSE		01
25B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
25C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		02
25D	0503018952	PLASTIC BOLT		12




Item	Code	Description	See page	QT
01	0503016524	DIVIDER VALVE		01
02	0581011593	NIPPLE R.1.1/16 UN		01
03	0511010111	7/8" NIPPLE		03
04	0503011109	2-119 N 3006-9B O'RING		01
05	0503010045	O'RING		03



Item	Code	Description	See page	QT
01	0503011883	QUICK CONNECTION COVER		01
02	0503011628	FEMALE QUICK COUPLER		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521052712	SILO FERTILIZER RIGHT SUPPORT 6850	40	01
02	0521052721	SILO FERTILIZER LEFT SUPPORT 6850	41	01
03	0521052734	SUPPORT SILO CENTRAL FERTILIZER 6850/7860	42	01
04	0501010984	FLAT WASHER		40
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0503062391	FERTILIZER BOX		03
09	0571019051	FIXER BOX WASHER		24
10	0503013751	3/8 UNC X 1.1/4 BOLT		24
11	0503012535	3/8" SPRING WASHER		24
12	0503012531	3/8" INOX NUT		24
13	0503011957	NYLON LUG		02
14	0503010371	5/16" X 1" BOLT		04
15	0503010179	LOCK WASHER		08
16	0503010337	5/16" NUT		08
17	0501010694	FLAT WASHER		04
18	0503011953	5/16" X 1" BOLT		04
19	0551019168	SLEEVE		02
20	0551019160	LEVER		02
21	0551019167	SLEEVE UNION		02
22	0511017302	FLAT WASHER		06
23	0503010479	BOLT		02
24	0503011336	1/2" HEX SELF ADJUSTING NUT		06
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
26	0503010019	1/2" SPRING WASHER		02
27	0503010060	1/2" NUT		02
28	0501013518	FLAT WASHER		06
29	0503010140	1/8" X 3/4" COTTERPIN		06
30	0511069678	LH LOWER LEVER		02
31	0561016468	FASTENER		02

Item	Code	Description	See page	QT
32	0581012605	GEAR BOX LEVER LOCK		02
33	0521061741	INNER LEVER		02
34	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	46	01
35	0551019159	LEVER FIXER BODY		02
36	0503034396	FERTILIZER SIDE COVER		15
37	0503010362	1/8" X 1.1/4" COTTERPIN		15
38	0521050195	SILO FERTILIZER LEFT SQUARE AXLE	47	01
39	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	48	02




Item	Code	Description	See page	QT
01	0521052620	SUPPORT SILO RIGHT FERTILIZER WITH 37 DISTRIBUTOR 7450	01	01
02	0521052621	SILO SUPPORT LEFT FERTILIZER WITH 38 DISTRIBUTOR 7450	01	01
03	0521051607	SUPPORT SILO CENTRAL FERTILIZER 39	01	01
04	0501010984	FLAT WASHER		40
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0503062391	FERTILIZER BOX		02
09	0571019051	FIXER BOX WASHER		26
10	0503013751	3/8 UNC X 1.1/4 BOLT		26
11	0503012535	3/8" SPRING WASHER		26
12	0503012531	3/8" INOX NUT		26
13	0503011957	NYLON LUG		02
14	0503010371	5/16" X 1" BOLT		04
15	0503010179	LOCK WASHER		08
16	0503010337	5/16" NUT		08
17	0501010694	FLAT WASHER		04
18	0503011953	5/16" X 1" BOLT		04
19	0551019168	SLEEVE		02
20	0551019160	LEVER		02
21	0551019167	SLEEVE UNION		02
22	0511017302	FLAT WASHER		06
23	0503010479	BOLT		02
24	0503011336	1/2" HEX SELF ADJUSTING NUT		06
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
26	0503010019	1/2" SPRING WASHER		02
27	0503010060	1/2" NUT		02
28	0501013518	FLAT WASHER		06
29	0503010140	1/8" X 3/4" COTTERPIN		06


Item	Code	Description	See page	QT
30	0511069678	LH LOWER LEVER		02
31	0561016468	FASTENER		02
32	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	48	02
33	0581012605	GEAR BOX LEVER LOCK		02
34	0521061741	INNTER LEVER		02
35	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	46	01
36	0551019159	LEVER FIXER BODY		02
37	0503034396	FERTILIZER SIDE COVER		15
38	0503010362	1/8" X 1.1/4" COTTERPIN		15
39	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		01
40	0521050195	SILO FERTILIZER LEFT SQUARE AXLE	47	01




Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	43	02
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	44	03
03	0501010942	3/8" X 1-1/4" BOLT		20
04	0503011443	3/8" SPRING WASHER		20
05	0503010026	3/8" NUT		20
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0501053788	3/4 SQUARE AXLE FASTENER	45	01
11	0501110392	SILO SUPPORT BEARING		01
12	0503030275	AGRICULTURAL BEARING		05
13	0503011953	5/16" X 1" BOLT		02
14	0521011039	FLAT WASHER		02
15	0503011444	SPRING WASHER		02
16	0503010337	5/16" NUT		02
17	0503010003	1845 GREASE FITTING		01
18	1902010685	18Z CONICAL GEAR		05
19	0521012485	GEAR BOX BEARING AGRICUTURAL		01
20	0581018078	SQUARE AXLE 3/4 X 1944.5		01
21	0521069062	SILO FERTILIZER RIGHT SUPPORT		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521068563	LEFT SILO FERTILIZER SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	43	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	44	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0501053788	3/4 SQUARE AXLE FASTENER	45	01
12	0501110392	SILO SUPPORT BEARING		01
13	0521012485	GEAR BOX BEARING AGRICUTURAL		01
14	0503011953	5/16" X 1" BOLT		02
15	0521011039	FLAT WASHER		02
16	0503011444	SPRING WASHER		02
17	0503010337	5/16" NUT		02
18	0503010003	1845 GREASE FITTING		01
19	1902010685	18Z CONICAL GEAR		05
20	0503030275	AGRICULTURAL BEARING		05
21	0581016776	SQUARE AXLE 3/4 X 2028		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521068089	SUPPORT CENTRAL SILO FERTILIZER		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	43	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	44	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0581016973	SQUARE AXLE 3/4 X 790		01
08	0571019828	LOCK AXLE		02
09	0503010365	NUT		04
10	1902010685	18Z CONICAL GEAR		05
11	0503030275	AGRICULTURAL BEARING		05
12	0503013816	5/16" LOCKNUT		04
13	0511062163	FERTILIZER BEAM LOWER COVER		01
14	0501010984	FLAT WASHER		04
15	0501011643	3/8 X 1" BOLT		04
16	0581016950	SQUARE AXLE 3/4 X 1115		01




Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	43	02
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	44	03
03	0501010942	3/8" X 1-1/4" BOLT		20
04	0503011443	3/8" SPRING WASHER		20
05	0503010026	3/8" NUT		20
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0501053788	3/4 SQUARE AXLE FASTENER	45	01
11	0501110392	SILO SUPPORT BEARING		01
12	0521012485	GEAR BOX BEARING AGRICUTURAL		01
13	0503011953	5/16" X 1" BOLT		02
14	0521011039	FLAT WASHER		02
15	0503011444	SPRING WASHER		02
16	0503010337	5/16" NUT		02
17	0503010003	1845 GREASE FITTING		01
18	1902010685	18Z CONICAL GEAR		05
19	0503030275	AGRICULTURAL BEARING		05
20	0581016972	AXIS Q 3/4 X 1953		01
21	0521068605	SUPPORT RIGHT SILO FERTILIZER		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521068615	LEFT SILO FERTILIZER SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	43	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	44	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0501053788	3/4 SQUARE AXLE FASTENER	45	01
12	0501110392	SILO SUPPORT BEARING		01
13	0521012485	GEAR BOX BEARING AGRICUTURAL		01
14	0503011953	5/16" X 1" BOLT		02
15	0521011039	FLAT WASHER		02
16	0503011444	SPRING WASHER		02
17	0503010337	5/16" NUT		02
18	0503010003	1845 GREASE FITTING		01
19	1902010685	18Z CONICAL GEAR		05
20	0503030275	AGRICULTURAL BEARING		05
21	0581016972	AXIS Q 3/4 X 1953		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521066913	CENTER FERTILIZER SILO SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	43	02
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	44	03
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0581016971	AXIS Q 3/4 X 1063		01
08	0571019828	LOCK AXLE		02
09	0503010365	NUT		04
10	1902010685	18Z CONICAL GEAR		05
11	0503030275	AGRICULTURAL BEARING		05
12	0503013816	5/16" LOCKNUT		04
13	0581016970	AXIS Q 3/4 X 763		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0581013322	BEARING RIGHT SUPPORT		01
02	0503011953	5/16" X 1" BOLT		04
03	0501010984	FLAT WASHER		02
04	0501010694	FLAT WASHER		04
05	0503013816	5/16" LOCKNUT		04
06	0501056444	BEARING WITH ROLLING	62	01



Item	Code	Description	See page	QT
01	0581013324	BEARING LEFT SUPPORT		01
02	0503011953	5/16" X 1" BOLT		04
03	0501010984	FLAT WASHER		02
04	0501010694	FLAT WASHER		04
05	0503013816	5/16" LOCKNUT		04
06	0501056444	BEARING WITH ROLLING	62	01




Item	Code	Description	See page	QT
01	0503030331	1.2" X 1.2" X 12.2" HOSE		01
02	0503010243	CLAMP		02
03	0503062755	TRANSMISSION AXLE		01
04	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
05	0503012880	1/4" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0571014441	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0501052560	MOTOR AXLE SIGNAL	51	02
15	0511051434	TRANSMISSION ACTUATOR	52	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	53	01
16.	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	54	01
17	0521043316	RIGHT GEAR BOX ASSY	55	01
17.	0521043317	LEFT GEAR BOX ASSY	56	01
18	0501010243	1/2" X 1-1/2" BOLT		06
19	0511017302	FLAT WASHER		08
20	0503010019	1/2" SPRING WASHER		10
21	0503012682	1/2" BSW NUT		06
22	0503010920	1/2" X 1.1/2" BOLT		04
23	0503010060	1/2" NUT		04
24	0521062072	33Z GEAR		02
25	0511054363	CHAIN TENSIONER	66	02
26	0501058234	LOWER CHAIN TENSIONER	67	02
27	0521055207	TOP CURRENT STRETCHER	68	02
28	0501058236	BEARING WITH 21Z GEAR	69	02
29	0501058237	16Z GEAR BEARING	70	02

Item	Code	Description	See page	QT
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	71	02
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		02
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		04
34	0503010256	3/8" X 3/4" BOLT		02
35	0503010025	3/8" SPRING WASHER		02
36	0501010984	FLAT WASHER		02
37	0501010637	FLAT WASHER		02
38	0503030303	SUPPORT WASHER		06




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0571014439	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0501052560	MOTOR AXLE SIGNAL	51	02
15	0511051434	TRANSMISSION ACTUATOR	52	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	53	01
16.	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	54	01
17	0521043316	RIGHT GEAR BOX ASSY	55	01
17.	0521043317	LEFT GEAR BOX ASSY	56	01
18	0501010243	1/2" X 1-1/2" BOLT		06
19	0511017302	FLAT WASHER		08
20	0503010019	1/2" SPRING WASHER		10
21	0503012682	1/2" BSW NUT		06
22	0503010920	1/2" X 1.1/2" BOLT		04
23	0503010060	1/2" NUT		04
24	0521062072	33Z GEAR		02
25	0511054363	CHAIN TENSIONER	66	02
26	0501058234	LOWER CHAIN TENSIONER	67	02
27	0521055207	TOP CURRENT STRETCHER	68	02
28	0501058236	BEARING WITH 21Z GEAR	69	02
29	0501058237	16Z GEAR BEARING	70	02


Item	Code	Description	See page	QT
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	71	02
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		02
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		04
34	0503010256	3/8" X 3/4" BOLT		02
35	0503010025	3/8" SPRING WASHER		02
36	0501010984	FLAT WASHER		02
37	0501010637	FLAT WASHER		02
38	0503030303	SUPPORT WASHER		06




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY


0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	57	01
02	0511059266	CLOSED BEARING	59	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	61	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	63	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	64	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	65	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	58	01
02	0511059266	CLOSED BEARING	59	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	61	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	63	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	64	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	65	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	60	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	62	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503019355	BEARING 6202 2RS1		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0551019173	CHAIN SLEEVE TENSIONER		01
05	0511017302	FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019174	DOBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521068581	RIGHT PLATFORM		01
02	0521068597	CENTRAL PLATFORM		01
03	0521068589	LEFT PLATFORM		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		28
07	0503010025	3/8" SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	CUPILLA		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32"X 2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0521068580	RIGHT PLATFORM		01
02	0521068596	CENTRAL PLATFORM		01
03	0521068588	LEFT PLATFORM		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		28
07	0503010025	3/8" SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	CUPILLA		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32"X 2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0521063871	SIDE HANDRAIL		02
02	0521063875	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2" NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8" SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
01	0521064019	SIDE HANDRAIL		02
02	0521064018	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2" NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8" SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	79	03
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521015501	COUPLING SHAFT		03
04	0503010523	1/4" X 2" COTTERPIN		06
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		03
06	0531012565	SLEEVE 16,3X 30 X 88		03
07	0503010027	5/8" SPRING WASHER		03
08	0503010013	5/8" NUT		03
09	0551014099	COUPLING SHAFT 31,75 X 185		01




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"		02
02	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8		02
03	0503010003	1845 GREASE FITTING		02
04	0503010365	NUT		04
05	0501010984	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0511017305	FLAT WASHER		04
09	0511065562	20Z GEAR		02
10	0502011299	BUSHING GEAR		02
11	0503010571	1/4" X 1.1/2 COTTERPIN		02
12	0503010010	1/4" X 2.1/2" COTTERPIN		02
13	0521013429	AXLE HEX 5/8 X 2180		02
14	0571013470	5/8 X 1100 HEX AXLE		01
15	0571013469	5/8 X 700 HEX AXLE		01
16	0521052784	INTERMEDIATE TRANSMISSION RIGHT	83	01
17	0521052787	INTERMEDIATE TRANSMISSION LEFT	86	01
18	0502040534	SPRING GUIDE BUSHING LOCK		04
19	0501018535	1/2 X 1 BOLT		04




Item	Code	Description	See page	QT
01	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"		02
02	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8		02
03	0503010003	1845 GREASE FITTING		02
04	0503010365	NUT		04
05	0501010984	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0511017305	FLAT WASHER		04
09	0511065562	20Z GEAR		02
10	0502011299	BUSHING GEAR		02
11	0503010571	1/4" X 1.1/2 COTTERPIN		02
12	0503010010	1/4" X 2.1/2" COTTERPIN		02
13	0581017003	SHAFT HEX 5/8 X 900 PIVOTED		01
14	0521013434	HEX AXLE 5/8 X 2300		02
15	0581017004	SHAFT HEX 5/8 X 1410 PIVOTED		01
16	0521043408	TRANSMISSION INTERMEDIARY SEED	82	02
17	0521052799	HEX AXLE ASSY BEARING PIVOTING LINE		02
18	0502040534	SPRING GUIDE BUSHING LOCK		04
19	0501018535	1/2 X 1 BOLT		04




Item	Code	Description	See page	QT
01	0511054435	SUPPORT INTERMEDIARY TRANSMISSION RIGHT	84	01
02	0511054436	LEFT INTERMEDIATE TRANSMISSION SUPPORT	88	01
03	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
04	0511017302	FLAT WASHER		08
05	0503010019	1/2" SPRING WASHER		08
06	0503010060	1/2" NUT		08
07	0502012819	17Z GEAR WITH HEX HOLE		02
08	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		02
09	0502040534	SPRING GUIDE BUSHING LOCK		04
10	0501018535	1/2 X 1 BOLT		04
11	0521066760	CARDAN 16 X 805 X 1213 X 211		01
12	0503030331	1.2" X 1.2" X 12.2" HOSE		01
13	0503010243	CLAMP		02
14	0503011855	0.2" X 1.8" SPRING PIN		02



Item	Code	Description	See page	QT
01	0511054435	SUPPORT INTERMEDIARY TRANSMISSION RIGHT	84	01
02	0521052785	SUPPORT INTERMEDIARY TRANSMISSION LEFT PIVOTING	85	01
03	0521014021	1/2" X 4.5" X 5.4" FASTENER		03
04	0511017302	FLAT WASHER		06
05	0503010019	1/2" SPRING WASHER		08
06	0503010060	1/2" NUT		08
07	0502012819	17Z GEAR WITH HEX HOLE		02
08	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		02
09	0502040534	SPRING GUIDE BUSHING LOCK		04
10	0501018535	1/2 X 1 BOLT		04
11	0521066760	CARDAN 16 X 805 X 1213 X 211		01
12	0503030331	1.2" X 1.2" X 12.2" HOSE		01
13	0503010243	CLAMP		02
14	0503011855	0.2" X 1.8" SPRING PIN		02
15	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
16	0501013519	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521064434	SUPPORT INTERMEDIARY TRANSMISSION		01
02	0502011697	BEARING OF THE GEAR BOX		04
03	0503011410	ROLLER BEARING		04
04	0503011105	SEAL RING		04
05	0503011953	5/16" X 1" BOLT		08
06	0501010694	FLAT WASHER		08
07	0503010179	LOCK WASHER		08
08	0503010337	5/16" NUT		08
09	0503010406	501025 CLAMPING RING (FOR AXLE)		06
10	0502012819	17Z GEAR WITH HEX HOLE		02
11	0521064436	LOWER AXIS TRANSMISSION INTERMEDIATE		01
12	0521064435	TRANSMISSION MAJOR AXIS INTERMEDIATE		01
13	0561014911	AXLE SLEVE GUIDES HEX		02




Item	Code	Description	See page	QT
01	0521068648	SUPPORT INTERMEDIARY TRANSMISSION RIGHT PIVOTING		01
02	0502011697	BEARING OF THE GEAR BOX		04
03	0503011410	ROLLER BEARING		04
04	0503011105	SEAL RING		04
05	0503011953	5/16" X 1" BOLT		08
06	0501010694	FLAT WASHER		08
07	0503010179	LOCK WASHER		08
08	0503010337	5/16" NUT		08
09	0503010406	501025 CLAMPING RING (FOR AXLE)		06
10	0502012819	17Z GEAR WITH HEX HOLE		02
11	0521064436	LOWER AXIS TRANSMISSION INTERMEDIATE		01
12	0521064435	TRANSMISSION MAJOR AXIS INTERMEDIATE		01
13	0561014911	AXLE SLEVE GUIDES HEX		02

INTERMEDIATE TRANSMISSION LEFT

0521052787




Item	Code	Description	See page	QT
01	0521052786	SUPPORT INTERMEDIARY TRANSMISSION RIGHT PIVOTING	87	01
02	0511054436	LEFT INTERMEDIATE TRANSMISSION SUPPORT	88	01
03	0521014021	1/2" X 4.5" X 5.4" FASTENER		03
04	0511017302	FLAT WASHER		06
05	0503010019	1/2" SPRING WASHER		08
06	0503010060	1/2" NUT		08
07	0502012819	17Z GEAR WITH HEX HOLE		02
08	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		02
09	0502040534	SPRING GUIDE BUSHING LOCK		04
10	0501018535	1/2 X 1 BOLT		04
11	0521066760	CARDAN 16 X 805 X 1213 X 211		01
12	0503030331	1.2" X 1.2" X 12.2" HOSE		01
13	0503010243	CLAMP		02
14	0503011855	0.2" X 1.8" SPRING PIN		02
15	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
16	0501013519	FLAT WASHER		02



Item	Code	Description	See page	QT
01	0521068647	SUPPORT INTERMEDIARY TRANSMISSION LEFT PIVOTING		01
02	0502011697	BEARING OF THE GEAR BOX		04
03	0503011410	ROLLER BEARING		04
04	0503011105	SEAL RING		04
05	0503011953	5/16" X 1" BOLT		08
06	0501010694	FLAT WASHER		08
07	0503010179	LOCK WASHER		08
08	0503010337	5/16" NUT		08
09	0503010406	501025 CLAMPING RING (FOR AXLE)		06
10	0502012819	17Z GEAR WITH HEX HOLE		02
11	0521064436	LOWER AXIS TRANSMISSION INTERMEDIATE		01
12	0521064435	TRANSMISSION MAJOR AXIS INTERMEDIATE		01
13	0561014911	AXLE SLEEVE GUIDES HEX		02

LEFT INTERMEDIATE TRANSMISSION SUPPORT


0511054436



Item	Code	Description	See page	QT
01	0521064434	SUPPORT INTERMEDIARY TRANSMISSION		01
02	0502011697	BEARING OF THE GEAR BOX		04
03	0503011410	ROLLER BEARING		04
04	0503011105	SEAL RING		04
05	0503011953	5/16" X 1" BOLT		08
06	0501010694	FLAT WASHER		08
07	0503010179	LOCK WASHER		08
08	0503010337	5/16" NUT		08
09	0503010406	501025 CLAMPING RING (FOR AXLE)		06
10	0502012819	17Z GEAR WITH HEX HOLE		02
11	0521064436	LOWER AXIS TRANSMISSION INTERMEDIATE		01
12	0521064435	TRANSMISSION MAJOR AXIS INTERMEDIATE		01
13	0561014911	AXLE SLEEVE GUIDES HEX		02

REAR LIGHT ASSEMBLY


0521052803




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		16
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		03
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	90	03
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		15

MOUNTED REAR LIGHT


0521052792




Item	Code	Description	See page	QT
01	0503018738	LIGHTHOUSE		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8\" SPRING WASHER		04
05	0503010026	3/8\" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	LOCK WASHER		04
08	0503010337	5/16\" NUT		04




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0501054649	HBM SEQUENTIAL VALVE	93	01
02	0511058431	HYDRAULIC CYLINDER	94	01
03	0511058431	HYDRAULIC CYLINDER	94	01
04	0511015573	2.07" X 1.6" TRANSPORT LOCK		02
05	0501068994	0.3" X 3.1" LOCK PIN		02
06	0503030168	CUPILLA		02
07	0511057094	HYDRAULIC HOSE MARKER ASSY 6450		01
07A	0501080783	HOSE 3/8 X 5000 TR-TR		02
07B	0501081659	HOSE 3/8 X 5300 TR-TR 2T		02
07C	0521052512	HOSE 3/8 X 5200 TC-TM PURPLE / RED		01
07CA	0501081980	HOSE 3/8 X 5200 TC-TM		01
07CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
07CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
07CD	0503018952	PLASTIC BOLT		06
07D	0521052513	HOSE 3/8 X 5200 TC-TM PURPLE / BLUE		01
07DA	0501081980	HOSE 3/8 X 5200 TC-TM		01
07DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
07DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
07DE	0503018952	PLASTIC BOLT		06
08	0501053834	MALE QUICK COUPLER	34	02
09	0511018012	HIDRAULIC ADAPTER		04




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0501067700	2.5" X 25" CYLINDER CASE		01
02	0521066632	EXTENDER		01
03	0503030384	CON PLUG N-001		02
04	0502012837	PISTON		01
05	0503018005	RING		01
06	0503011109	2-119 N 3006-9B O'RING		01
07	0503010163	D-1500 SCRAPER RING		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503018004	RING		01
11	0503018003	GASKET		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0503010002	1800 GREASE FITTING		02
15	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0501100045	WOODEN BOX	01	
02	0511061022	ROW MARKER SUPPORT	02	
03	0511066119	MARKER SUPP FIXER FASTENER	04	
04	0502010175	HITCH CLAMP	08	
05	0501010216	3/4" X 4-1/2" BOLT	16	
06	0503010023	3/4" SPRING WASHER	16	
07	0503010014	3/4" NUT	16	
08	0511060013	ROW MARKER ARM	02	
09	0521013347	1.1/4" X 8.4" AXLE	02	
10	0501019435	32 X 50 X 1.5 FLAT WASHER	16	
11	0503010523	1/4" X 2" COTTERPIN	16	
12	0511060014	ROW MARKER ARM	02	
13	0521011142	1.1/4" X 7.5" AXLE	04	
14	0521011141	1.1/4" X 6.5" AXLE	02	
15	0521061790	1750 TURNBUCKLE	02	
16	0521055204	LIGNE DE DISQUE MARKER	02	
17	0521012324	1/2" X 3.2" X 2.54" FASTENER	04	
18	0511017302	FLAT WASHER	08	
19	0503010019	1/2" SPRING WASHER	08	
20	0503010060	1/2" NUT	08	
21	0503010004	1890 GREASE FITTING	02	
22	0503010003	1845 GREASE FITTING	02	




Item	Code	Description	See page	QT
01	0503034694	PST TRIO MENOR ADHESIVE LABEL (05 MOUTH)		06
02	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 MOUTH)		06
03	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
04	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
05	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING		02
06	0503033422	ADHESIVE LABEL		02
07	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
08	0503033008	ADHESIVE LABEL		02
09	0503031428	READ MANUAL DECAL		01
10	0503031942	ADHESIVE LABEL		01
11	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		02
12	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
13	0503031565	ADHESIVE LABEL CARE		02
14	0503031566	ADHESIVE LABEL		02
15	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
16	0503031425	ADHESIVE LABEL ATTENTION		02
17	0503031669	ADHESIVE LABEL		01
18	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
19	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
20	0503032930	ADHESIVE LABEL DANGER		08
21	0503031087	ADHESIVE LABEL		01
22	0503034078	LIFTING POINTS DECAL		03
23	0503034003	SERIAL NUMBER TAG 61 X 118		01
24	0503010001	3.2 X 5.5 RIVET		04
25	0503032979	ADHESIVE LABEL LETTERS A B C D		02
26	0503034500	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0503034693	ADHESIVE LABEL		01
02	0503034694	PST TRIO MENOR ADHESIVE LABEL (05 MOUTH)		04
03	0503034114	ADHESIVE LABEL LOGO TATU BOX 190 X 530		01
04	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 MOUTH)		04
05	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
07	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
08	0503033421	ADHESIVE LABEL 7 NUMBER FOR PLANTING		02
09	0503033008	ADHESIVE LABEL		02
10	0503031428	READ MANUAL DECAL		01
11	0503031942	ADHESIVE LABEL		01
12	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		02
13	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
14	0503031565	ADHESIVE LABEL CARE		02
15	0503031566	ADHESIVE LABEL		02
16	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
17	0503031425	ADHESIVE LABEL ATTENTION		02
18	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
19	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
20	0503032930	ADHESIVE LABEL DANGER		08
21	0503031087	ADHESIVE LABEL		01
22	0503034078	LIFTING POINTS DECAL		03
23	0503034003	SERIAL NUMBER TAG 61 X 118		01
24	0503010001	3.2 X 5.5 RIVET		04
25	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
26	0503032979	ADHESIVE LABEL LETTERS A B C D		02
27	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0521054797	ASSEMBLY LINE SEED/FERTILIZER SHORT WITHOUT LUBRICATION	100	01
02	0521054798	CONJUNTO LINHA SEMENTE/ADUBO LONGA SEM LUBRIFICAÇÃO	101	01
03	0521054768	DDD RIGHT FERTILIZER WITH SUPPORT	119	01
04	0521054769	LEFT FERTILIZER WITH SUPPORT	120	01
05	0521054984	DEPTH/COMPACTOR SYSTEM - SPT	123	01
06	0503030391	RIGHT FERTILIZER NOZZLE		01
07	0503030392	LEFT FERTILIZER NOZZLE		01
08	0503031050	CURVED CONDUCTOR		01
09	0503010246	CLAMP		01
10	0503031145	2" X 2" X 20" HOSE		01
11	0503031076	2" HOSE CLAMP		01
12	0501013714	STABILIZER BAR		01
13	0503016204	CORN DISK 12 ORANGE		01
14	0503016214	RING CORN (APOLLO740)		01
15	0503016218	DISC OF SOYBEAN		01
16	0503016220	RING TO SOYBEANS (APOLLO 745)		01
17	0503016221	RING TO SOYBEANS (APOLLO 571)		01
18	0521068982	KEY CASH DISC CUTTING		01
19	0581015213	STABILIZER BAR E450		01
19.	0581015215	STABILIZER BAR E500 PIVOTED HIGH LINE		01
20	0501050120	LARGER WALKING BEAM ASSY	134	01
21	0503030558	PULLEY 4Z CORN PLASTIC		01
22	0521018501	TURNBUCKLE LEVER		01
23	0503010741	1/2" X 2-3/4" BOLT		01
24	0521053946	SCARING ROD	135	01
25	0511017969	0.1" SPACING PLATE		01
26	0511018662	SPACING PLATE		01
27	0521069124	BOCAL FILLED LINE PIVOTED WITH LINGUET		01
28	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
29	0501010984	FLAT WASHER		01


Item	Code	Description	See page	QT
30	0503010025	3/8" SPRING WASHER		01
31	0503010026	3/8" NUT		01
32	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
33	0511017302	FLAT WASHER		01
34	0503010019	1/2" SPRING WASHER		01
35	0503010060	1/2" NUT		01
36	0503010547	1/2" X 4" BOLT		01
37	0503010905	1/2" X 2-1/4" BOLT		01
38	0503010019	1/2" SPRING WASHER		01
39	0503010060	1/2" NUT		01
40	0521054912	RIGHT SUPPORT WITH DOC 18	136	01
41	0521054913	LEFT SUPPORT WITH DOC 18	137	01
42	0521050168	MOUNTED FERTILIZER CONDUCTOR	138	01




Item	Code	Description	See page	QT
001	0521054813	SHORT PIVOT LIFT LINE	102	01
002	0501010066	3/4" X 9" BOLT		01
003	0511017232	FLAT WASHER		02
004	0503011255	3/4" LOCK NUT		01
005	0502012873	SUPPORT DC LINE FERTILIZER		01
006	0503019278	LUBRICANT GLOVE		02
007	0581019195	SIDE GUIDE GLOVE		02
008	0581019196	CENTRAL GUIDE GLOVE		01
009	0503010410	RING		02
010	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
011	0503010013	5/8" NUT		02
012	0521053231	DPL 20 SHORT LINE WITHOUT LUBRICATION 113 CONICAL BEARING		01
013	0521069482	ARM FERTILIZER LINE SHORT RISE WITHOUT LUBRICATION		01
014	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	117	01
015	0511057017	SEED SYSTEM ASSY	118	01
016	0503017857	BOLT 5/8 UNF 4		03
017	0503010811	5/8" UNF SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
001	0521054814	LONG PIVOT LIFT LINE	103	01
002	0501010066	3/4" X 9" BOLT		01
003	0511017232	FLAT WASHER		02
004	0503011255	3/4" LOCK NUT		01
005	0502012873	SUPPORT DC LINE FERTILIZER		01
006	0503019278	LUBRICANT GLOVE		02
007	0581019195	SIDE GUIDE GLOVE		02
008	0581019196	CENTRAL GUIDE GLOVE		01
009	0503010410	RING		02
010	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
011	0503010013	5/8" NUT		02
012	0521053232	DPL 20 LONG LINE WITHOUT LUBRICATION 114 CONICAL BEARING		01
013	0521069483	ARM LONG LINE HIGH FERTILIZER WITHOUT LUBRICATION		01
014	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	117	01
015	0511057017	SEED SYSTEM ASSY	118	01
016	0503017857	BOLT 5/8 UNF 4		03
017	0503010811	5/8" UNF SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0502011505	18Z CONICAL GEAR		01
02	1902010426	UPPER BEARING SEMI		02
03	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
04	0521018079	SEEP ROW DRAWBAR COVER		01
05	0521068663	SHORT SEED LINE ARM		01
06	0511052024	FAST CLOSING SET	104	01
07	0511059244	ROD SPRING LINE SEED	105	01
08	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	106	01
09	0502012872	PIVOTING CLAMP		01
10	0503010479	BOLT		04
11	0503010019	1/2" SPRING WASHER		08
12	0503010060	1/2" NUT		08
13	0581019188	ARTICULATED SUPPORT WITHOUT LUBRICATION		01
14	0503019343	AUTO LUBRICANT GLOVE		02
15	0503019344	AUTO LUBRICANT GLOVE		01
16	0581019189	BEARING GLOVE AXIS SEXTAVADO 1/2 WITHOUT LUBRICATION		01
17	0581019190	GEAR 18Z 5/8 ENGINE WITHOUT LUBRICATION		01
18	0503010410	RING		04
19	0501013352	FLAT WASHER		02
20	0501013354	FLAT WASHER		02
21	0521054775	LEFT REAR SEAL LINE BASE 1/2	107	01
22	0521018077	1/2" X 58.6" HEX AXLE		01
23	0503014729	1/4" UNF X 1/2" BOLT		02
24	0503010143	1/4" SPRING WASHER		02
25	0503010752	1/2" X 3.1/2" BOLT		02
26	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0502011505	18Z CONICAL GEAR		01
02	1902010426	UPPER BEARING SEMI		02
03	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
04	0521018079	SEEP ROW DRAWBAR COVER		01
05	0521068664	LONG SEED LINE ARM		01
06	0511052024	FAST CLOSING SET	104	01
07	0511059244	ROD SPRING LINE SEED	105	01
08	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	106	01
09	0502012872	PIVOTING CLAMP		01
10	0503010479	BOLT		04
11	0503010019	1/2" SPRING WASHER		08
12	0503010060	1/2" NUT		08
13	0581019188	ARTICULATED SUPPORT WITHOUT LUBRICATION		01
14	0503019343	AUTO LUBRICANT GLOVE		02
15	0503019344	AUTO LUBRICANT GLOVE		01
16	0581019189	BEARING GLOVE AXIS SEXTAVADO 1/2 WITHOUT LUBRICATION		01
17	0581019190	GEAR 18Z 5/8 ENGINE WITHOUT LUBRICATION		01
18	0503010410	RING		04
19	0501013352	FLAT WASHER		02
20	0501013354	FLAT WASHER		02
21	0521054774	REAR RIGHT LINE SEED LIFT		01
22	0521018078	1/2" X 66.5" HEX AXLE		01
23	0503014729	1/4" UNF X 1/2" BOLT		02
24	0503010143	1/4" SPRING WASHER		02
25	0503010752	1/2" X 3.1/2" BOLT		02
26	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0511060376	SEEP SPRING GUIDE		01
02	0503010834	1/2 X 1 BOLT		02
03	0502040534	SPRING GUIDE BUSHING LOCK		02
04	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
05	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
06	0501013753	FLAT WASHER		01
07	0521010542	COUPLING SHAFT		01
08	0503010257	1/8" X 1" COTTERPIN		01
09	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0502012538	SPRING VARON SUPPORT		01
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
03	0511017302	FLAT WASHER		02
04	0503011336	1/2" HEX SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521054819	BASE 1/2 FIXED WITHOUT ASSY LUBRICATION	108	01
02	0521054763	DDD LEFT SEED	109	01
03	0581014527	ELEVATION PLATE 12,5		03
04	0581014526	ELEVATION PLATE 3/8		01
05	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
06	0503010025	3/8" SPRING WASHER		04
07	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0581019199	FIXED BASE		01
02	0581019200	CONICA 40Z GEAR		01
03	0581019201	CROWN SHAFT		01
04	0503019340	LUBRICANT GLOVE		02
05	0503019341	LUBRICANT GLOVE		01
06	0503011030	2-014 N 3006-9B O'RING		02
07	0503010410	RING		02
08	0501013354	FLAT WASHER		01
09	0581019203	CONICAL PINION		01




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	110	01
02	0521054761	LEFT LOW CUBE	111	01
03	0521054760	DOWN LOW CUBE	112	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0511015098	FLAT WASHER		04
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502012736	HUB LOWR DDD		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012736	HUB LOWR DDD		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06



Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	115	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	115	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012824	FIXING SHAFT DISC CUT LINE		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	CUTTING DISK BOX	116	01

CUTTING DISK BOX


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	CUTTING DISK BOX		01
09	0502040873	CUTTING DISC AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK	02	
02	0502012184	FERTILIZER SPRING GUIDE	02	
03	0503031910	1.7" X 22.8" X 0.3" SPRING	01	
04	0502012510	SPRING ROD SUPPORT	01	
05	0521068568	LARGE ELEVATION SPRING FERTILIZER	01	
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN	01	
07	0501018535	1/2 X 1 BOLT	02	
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
09	0503010060	1/2" NUT	02	
10	0502010891	SPRING CHOCK SUPPORT VARON	01	
11	0503010014	3/4" NUT	01	
12	0561014471	COUPLING SHAFT	01	
13	0511017302	FLAT WASHER	01	
14	0503010257	1/8" X 1" COTTERPIN	01	




Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG	01	
02	0503016219	RING TO SOYBEANS	01	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010209	3/8" UNC BUTTERFLY NUT	03	
05	0503016283	M8 NUT HEX	01	
06	0502020693	SUPPORT SEED BOX	01	
07	0502012721	SEED DISC LOWER TRAIL	01	
08	0503030083	3/8" X 3/8" X 1.6" STUD	02	
09	0503016282	ALLEN BOLT	01	
10	0503010675	5/16" X 2.1/4" BOLT	01	
11	0503010179	LOCK WASHER	05	
12	0503010337	5/16" NUT	01	
13	0501010694	FLAT WASHER	04	
14	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN	04	
15	0501051094	ASSY SEED DISTRIBUTOR	01	
16	0503031508	COVER GREEN BEAM SEED YELLOW	01	
17	0571018536	HEX PRISONER	01	
18	0501013518	FLAT WASHER	02	
19	0503034131	DEFLECTOR	01	




Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	111	01
03	0521054760	DOWN LOW CUBE	112	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511015098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	111	01
03	0521054760	DOWN LOW CUBE	112	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511015098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	124	01
02	0501052538	DEPTH BAND WITH ARMS	130	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0521054990	LEFT COMPACTOR WHEEL	131	01
06	0521055017	RIGHT COMPACTOR WHEEL	132	01




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	125	01
02	0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	126	01
03	0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	127	01
04	0521055033	COMPACTADOR BODY	129	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	SCREW 3/8 UNC X 3/4		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED GLOVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	128	01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	128	01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL BOX		01
02	0581019515	AXIS		01
03	0503034055	CLAMPING RING		01
04	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
05	0503013758	1/4" X 1-1/2" BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0503010878	5/8" SELF ALIGNING NUT		01
10	0503030757	2.9" X 2" X 0.02" JOINT		01
11	0521019178	COVER DEPTH		01




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT GLOVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	133	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	133	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0503030379	LARGER ROCKER ARM		01
02	0502060001	PLASTIC PULLEY FOR MAIZE		01
03	0503010669	FLAT WASHER		01
04	0503010667	3/16" NUT		02
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		01




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070085	FIXED ROD BEARING		01
03	0513010288	ELASTIC PIN 701211 10 X 24		02
04	0513010289	ELASTIC PIN 701211 10 X 24		02




Item	Code	Description	See page	QT
01	0521069504	DOC DISK ARM		01
02	0581011838	SLEVE GUIDES		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0521015376	DUST CLOAK		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2" NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503016063	ROLLER BEARING		01
10	0503030832	FLAT WASHER		01
11	0521054914	BOX WITH DOC 18 RIGHT	139	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0521069504	DOC DISK ARM		01
02	0581011838	SLEEVE GUIDES		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0521015376	DUST CLOAK		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2" NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503016063	ROLLER BEARING		01
10	0503030832	FLAT WASHER		01
11	0521054915	BOX WITH DOC 18 LEFT	140	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0581013298	SUPPORT		01
02	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
03	0521018517	FLAT WASHER		01
04	0503010060	1/2" NUT		01
05	0503010019	1/2" SPRING WASHER		01
06	0503030483	FERTILIZER SOCKET		01
07	0503031050	CURVED CONDUCTOR		01
08	0503010246	CLAMP		01



Item	Code	Description	See page	QT
01	0503011800	SEAL RING		01
02	0503012417	SEAL		01
03	0503016063	ROLLER BEARING		01
04	0503030832	FLAT WASHER		01
05	0502020641	BLADE DISC FLANGE		01
06	0607025032	PLAIN COULTER BLADE		01
07	0503010371	5/16" X 1" BOLT		06
08	0503010179	LOCK WASHER		06
09	0503010337	5/16" NUT		06
10	0581019304	BOX DC		01



Item	Code	Description	See page	QT
01	0503011800	SEAL RING		01
02	0503012417	SEAL		01
03	0503016063	ROLLER BEARING		01
04	0503030832	FLAT WASHER		01
05	0502020641	BLADE DISC FLANGE		01
06	0607025032	PLAIN COULTER BLADE		01
07	0503010371	5/16" X 1" BOLT		06
08	0503010179	LOCK WASHER		06
09	0503010337	5/16" NUT		06
10	0581019304	BOX DC		01



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

