

ROW CROP PLANTERS

COP TRIO 650 SUPREMA P.P MINI HOPPER - FRAME 6050 - CSU/CBA

Code: 0501092781
Series: S-0419
Revision: 00
Date Revision: FEVEREIRO/2022

PARTS CATALOGUE



MARCHESAN



PRODUCTS

Code	Description
0111420047	COP TRIO 650 SUP 6050/12E500 ESPECIAL S-0419
0111420040	COP TRIO 650 SUP 6050/12E500 ESPECIAL S-0419

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909099166	FRAME ASSY	1
0521057472	FRAME WITH ARTICULATION 6050	2
0909099168	COMPLETE HEADER ASSY	3
0521045756	HYDRAULIC CYLINDER	4
0511057653	HYDRAULIC CYLINDER	5
0501053835	FEMALE QUICK COUPLER	6
0521050573	EXTENSOR 3RD POINT	7
0511057817	SUPPORT HOSE	8
0511055096	TRACTOR HITCH	9
0521051616	TURNBUCKLE SIDE 505/480	10
0521050574	EXTENSOR	11
0521057452	ASSY INTERMEDIATE HEADER FIXATION SUPPORT	12
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	13
0521056993	COROT D' WATER ASSY	14
0521056994	ASSY TOOL CHEST	15
0521057153	RIGHT WHEEL ASSY WITH LEFT TRANSMISSION EXTENSION FIXATION	16
0521056089	WHEEL ASSY LEFT FIXING EXTENSOR	17
0521056090	RIGHT WHEEL ASSY	18
0521056093	RIGHT WHEEL ASSEMBLY WITHOUT TRANSMISSION	19
0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH TRANSMISSION	20
0521056101	EE WHEEL WITH TIRE 7.00X16 ASSY WITHOUT TRANSMISSION	21
0521056100	WHEEL BOX ASSY WITH TRANSMISSION	22
0521056102	ASSY WHEEL BOX WITHOUT TRANSMISSION	23
0521056160	SIDE TRANSMISSION CURRENT STRETCHER	24
0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	25
0521056300	MOUNTED LEFT STRETCHER	26
0521056299	MOUNTED RIGHT STRETCHER	27
0521055238	BEARING TENSIONER CHAIN	28
0521056095	ARTICULATED BEARING WHEELED WITHOUT LUBRICATION	29
0501058239	CHAIN TENSIONER BEARING	30
0521056119	SQUARE AXIS ASSEMBLY 730	31
0501056271	BEARING CLOSED	32
0501056444	BEARING WITH ROLLING	33
0501053788	Q3/4" FASTENER AXLE ASSY	34
0521056398	MOTOR SHAFT ASSEMBLY	35
0511047069	SIDE TRANSMISSION DRIVING	36
0511047070	LH SIDE TRANSMISSION DRIVING	37
0511051434	TRANSMISSION DRIVING ASSY	38
0521057471	HEX AXLE ASSEMBLY 6050	39
0521056103	BEARING WITH GEAR 20Z HEX SHAFT 3/4	40
0521055498	SEED TRANSMISSION DOUBLE BEARING	41
0521056144	INTERMEDIATE SEED TRANSMISSION	42
0521056118	TRANSMISSION ASSY	43
0521056135	BEARING GEAR WITH DOUBLE	44
0521055217	LOWER CURRENT STRETCH	45
0521056134	STRETCHER FERTILIZER CURRENT 17Z	46
0521054446	LOWER CURRENT STRETCHER 21Z	47
0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	48
0511052333	ASSEMBLY SUPPORT LEFT FIXER CHANGE	49
0521056086	ASSY RIGHT EXCHANGE	50
0521056087	ASSY LEFT EXCHANGE	51
0501048790	AXLE WITH LINK ASSY	52



MARCHESAN

INDEX

0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	53
0501056443	BEARING ASSY GEAR BOX	54
0511059266	CLOSED BEARING	55
0501054655	CHAIN TENSIONER ASSY	56
0511059261	CHAIN TENSIONER	57
0521051728	SILO FERTILIZER ASSY 6050	58
0521056889	RIGHT SILO FERTILIZER SUPPORT	59
0521050218	CENTER FERTILIZER SILO SUPPORT 7350	60
0521056888	SUPPORT SILO LEFT FERTILIZER	61
0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	62
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	63
0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	64
0521051731	HANDRAIL ASSY 6050 CSU	65
0521057473	PLATFORM ASSY 6050	66
0521057386	HYDRAULIC ASSY 6050	67
0521057899	SUPPORT VALVE BLOCK VACUOMETER ASSY 5750/7350	68
0521057855	CASAPPA DIVIDER VALVE WITH FIXING NIPLES	69
0521057886	HOSE CLAMP ASSEMBLY	70
0521057259	OIL CONDUCTOR FIXATION	71
0521058235	ARM ROLLER SPINDLE	72
0511053356	ASSY LADDER	73
0511058191	REST ASSY	74
0511057803	ASSY PORT MANUAL INSTRUCCION	75
0511059494	TRACTION SPRING ASSY	76
0521057470	REAR TURBINE ASSY 6050 CSU	77
0521057131	CENTRAL TURBINE MOUNTED WITH CSU SUPPORT	78
0521056673	TURBINE P.P CSC	79
0521050154	TURBINE P.P WITH HOLE	80
0521056411	AIR CONDUCTOR 04 MOUTH	81
0521056412	AIR CONDUCTOR 04 RIGHT MOUTH	82
0521057136	CENTRAL AIR DISTRIBUTOR	83
0521052549	CLAMP	84
0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	85
0521057289	VACUOMETER FIXING SUPPORT CSU	86
0521051723	CSU CONDUCTOR 3 SEMI-ASSEMBLED ASSY - 6050	87
0521051730	ASSY FIXING SUPPORT	88
0521051726	ASSY CSU CONDUCTOR 3 2BOXES 5/3 1BOXE 7/6	89
0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	90
0521057149	ASSY RIGHT FIXING SUPPORT	91
0521057151	FIXING SUPPORT LEFT ASSY	92
0521059078	LABEL ASSY - 6050 CSU	93
0521053448	MONITORING ASSEMBLY PLANTING SEEDS 12L PM400	94
0521057927	MOUNTED REAR LIGHT	95
0909099167	SEED LINE/FERTILIZER ASSEMBLY	96
0521056240	FRONT SHORT LINE	97
0521056241	FRONT LONG LINE	98
0531052956	ASSEMBLY SEED LINE TRANSMISSION FIXING BEARING	99
0521056941	RIGHT REAR P.P CSU TRANSMISSION/CABLE	100
0521056940	LEFT REAR P.P CSU TRANSMISSION CABLE	101
0521056955	RIGHT DDD ASSY	102
0521056954	LEFT DDD ASSY	103
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	104
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	105
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	106
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	107




MARCHESAN

INDEX

0521056956	PRECISION PLANTING CSU CABLE/TRANSMISSION ASSY	108
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	109
0521055053	DEEP WHEEL/COMPACTOR SYSTEM	110
0521055065	ASSY DEPTH / COMPACTOR	111
0521055033	COMPACTADOR BODY	112
0521055054	LEFT ARM WITH SLEEVE	113
0521055066	RIGHT ARM WITH GLOVE	114
0521055068	RAYED WHEEL CENTER CLOSED	115
0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	116
0521054990	LEFT COMPACTOR WHEEL	117
0521055017	RIGHT COMPACTOR WHEEL	118
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	119
0521056069	SEMI-ASSEMBLED SHORT FERTILIZER LINE	120
0521056066	SEMI-ASSEMBLED LONG FERTILIZER LINE	121
0521056070	DC 20 ASSY	122
0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	123
0521053697	CUTTING DISK BOX	124
0521056067	DDD RIGHT FERTILIZER WITH FIXATION	125
0521056068	DDD LEFT FERTILIZER WITH FIXATION	126
0521055868	RIGHT DUAL FERTILIZER DISC	127
0521055869	LEFT DUAL FERTILIZER DISC	128
0521051447	FRONT ASSY ROW BEARING	129
0521056844	ASSY SCARIFYING ROD	130
0521053673	SCARIFYING ROD WITH NOZZLE 0869 FIXED ROD	131
0521050525	FIXER FERTILIZER CONDUCTOR	132
0531053036	SHORT SEED LINE HOSE GUIDE STEEL CABLE	133
0531053037	LONG SEED LINE HOSE GUIDE STEEL CABLE	134
0531052349	CURRENT GUIDE ASSEMBLY	135
0531052347	HOSE SUPPORT ASSEMBLY	136
0521057284	SEMI-ASSEMBLED HYDRAULIC MARKER	137
0511058449	HYDRAULIC CYLINDER	138
0909098768	HYDRAULIC CIRCUIT HYDRAULIC MARKER	139

FRAME ASSY

0909099166




Item	Code	Description	See page	QT
01	0521057472	FRAME WITH ARTICULATION 6050	2	01
02	0909099168	COMPLETE HEADER ASSY	3	01
03	0521057153	RIGHT WHEEL ASSY WITH LEFT TRANSMISSION EXTENSION FIXATION	16	01
04	0521056089	WHEEL ASSY LEFT FIXING EXTENSOR	17	01
05	0521056090	RIGHT WHEEL ASSY	18	02
06	0521056093	RIGHT WHEEL ASSEMBLY WITHOUT TRANSMISSION	19	02
07	0521056119	SQUARE AXIS ASSEMBLY 730	31	01
08	0521056398	MOTOR SHAFT ASSEMBLY	35	01
09	0521057471	HEX AXLE ASSEMBLY 6050	39	01
10	0521056118	TRANSMISSION ASSY	43	01
11	0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	48	01
12	0511052333	ASSEMBLY SUPPORT LEFT FIXER CHANGE	49	01
13	0521056086	ASSY RIGHT EXCHANGE	50	01
14	0521056087	ASSY LEFT EXCHANGE	51	01
15	0521051728	SILO FERTILIZER ASSY 6050	58	01
16	0521051731	HANDRAIL ASSY 6050 CSU	65	01
17	0521057473	PLATFORM ASSY 6050	66	01
18	0521057386	HYDRAULIC ASSY 6050	67	01
19	0511053356	ASSY LADDER	73	01
20	0511058191	REST ASSY	74	02
21	0521064285	LOCK LOWER FRAME		04
22	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		04
23	0511057803	ASSY PORT MANUAL INSTRUCCION	75	01
24	0511059494	TRACTION SPRING ASSY	76	10
25	0521057470	REAR TURBINE ASSY 6050 CSU	77	01
26	0521051723	CSU CONDUCTOR 3 SEMI-ASSEMBLED ASSY - 6050	87	01
27	0503010246	CLAMP		12
28	0521059078	LABEL ASSY - 6050 CSU	93	01

FRAME ASSY

0909099166


Item	Code	Description	See page	QT
29	0521053448	MONITORING ASSEMBLY PLANTING SEEDS 12L PM400	94	01
30	0521057927	MOUNTED REAR LIGHT	95	02
31	0503010243	CLAMP		06
32	0503034867	AIR DISTRIBUTOR PUMP		06
33	0503032624	SILO FERTILIZER GUTTER		12
34	0521013022	TRANSPORT LOCK		08
35	0501068994	0.3" X 3.1" LOCK PIN		08
36	0503030168	HAIR PIN		08
37	0501047895	ROD STOP		08
38	0501047885	ROD STOP		08
39	0501047886	ROD STOP		08
40	0501047887	ROD STOP		08
41	0503010002	1800 GREASE FITTING		01
42	0541015451	FIXED KEY 2.3/8 X 2.3/4		01
43	0521066303	HOSE GUIDE		01
44	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		02
45	0503013816	5/16" LOCKNUT		02
46	0503011750	AMENDMENT WITH LOCK		06
47	0503011751	REDUCTION		06
48	0503010780	N-2050 AMENDMENT		06
49	0909099167	SEED LINE/FERTILIZER ASSEMBLY	96	01
50	0521057284	SEMI-ASSEMBLED HYDRAULIC MARKER	137	01
51	0521055204	LIGNE DE DISQUE MARKER		02



Item	Code	Description	See page	QT
01	0531060153	RIGHT SIDE FRAME		01
02	0531060023	CENTRAL FRAME		01
03	0531060152	LEFT SIDE FRAME		01
04	0521063003	LOCK PIN		02
05	0571010969	LOCK SLEEVE FRAME		02
06	0503013627	1.1/2 SPRING WASHER		02
07	0501010110	1.1/2" NUT		02
08	0521066298	ARTICULATOR		04
09	0571013510	LOCK AXLE		04
10	0503030085	LOCK PIN		04
11	0571010094	SLEEVE FLANGE		12
12	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
13	0501010098	3/4" UNC BOLT		20
14	0503011442	3/4" SPRING WASHER		20
15	0571010095	FLAT WASHER		04
16	0521064285	LOCK LOWER FRAME		04
17	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		04
18	0591012492	SIDE TROUGH 24 X 50 X 1400		02
19	0591012493	TROUGH CENTRAL 24 X 50 X 1300		02
20	0503013029	3/8" X 3/4" BOLT		08
21	0501013518	FLAT WASHER		08
22	0503010025	3/8" SPRING WASHER		08
23	0503010026	3/8" NUT		08

COMPLETE HEADER ASSY

0909099168




Item	Code	Description	See page	QT
01	0521066289	FRONT HEADER 5750/6350/6850		01
02	0531060569	INTERMEDIATE HEADER 6350/7350		01
03	0571019949	JUNCTION SHAFT		06
04	0503030119	LOCK PIN		10
05	0521045756	HYDRAULIC CYLINDER	4	01
06	0521010779	31.75 X 95 COUPLING SHAFT		01
07	0521010581	0.9" X 4.9" COUPLING SHAFT		01
08	0503030085	LOCK PIN		06
09	0531016049	FLAT WASHER		02
10	0521050573	EXTENSOR 3RD POINT	7	01
11	0511057817	SUPPORT HOSE	8	01
12	0571019951	JUNCTION SHAFT		02
13	0503010523	1/4" X 2" COTTERPIN		04
14	0511055096	TRACTOR HITCH	9	01
15	0511053179	TRACTOR HITCH AXLE		01
15A	0521064036	TRACTOR HITCH AXLE		01
15B	0503030012	HAIR PIN		01
16	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
17	0521051616	TURNBUCKLE SIDE 505/480	10	02
18	0521050574	EXTENSOR	11	02
19	0521010571	COUPLING SHAFT		04
20	0521057452	ASSY INTERMEDIATE HEADER FIXATION SUPPORT	12	04
21	0521050693	ASSEMBLY SET HOSE CYLINDER FRONT HEAD		01
21A	0521050692	HOSE KIT CYLINDER HEAD FRONT		01
21AA	0521052310	HOSE 1/2 X 4500 TM-TM GREEN / RED		01
21AAA	0501081929	HOSE 1/2 X 4500 TM-TM		01
21AAB	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
21AAC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
21AAD	0503018952	PLASTIC BOLT		06
21AB	0521052309	HOSE 1/2 X 4500 TM-TM GREEN / BLUE		01
21ABA	0501081929	HOSE 1/2 X 4500 TM-TM		01


COMPLETE HEADER ASSY

0909099168


Item	Code	Description	See page	QT
21ABB	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
21ABC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21ABD	0503018952	PLASTIC BOLT		06
21C	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	13	04
22	0571019950	COUPLING SHAFT		02
23	0503014321	CABLE STEEL SHACKLE		02
24	0503014120	CHAIN		01
25	0521056993	COROT D' WATER ASSY	14	01
26	0521056994	ASSY TOOL CHEST	15	01
27	0503019262	SOAP DISH VACUUM		01




Item	Code	Description	See page	QT
01	0511057653	HYDRAULIC CYLINDER	5	01
02	0501053835	FEMALE QUICK COUPLER	6	02




Item	Code	Description	See page	QT
01	0521066550	CASE		01
02	0521066551	EXTENSION DRAWBAR		01
03	0503010002	1800 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010669	EMBOLUS 63.50 X 40 USAP		01
06	0503018005	RING		01
07	0503010558	7/8" NUT		01
08	0502010471	MOBILE COVER		01
09	0503011058	8-330 BACK-UP RING		01
10	0571019866	RING SUPPORT		01
11	0503010163	D-1500 SCRAPER RING		01
12	0503018004	RING		01
13	0503010161	2-330 N 3006 9B O'RING		01
14	0503018003	GASKET		01
15	0503010605	O'RING		01
16	0581010652	JIC ADAPTER		01



Item	Code	Description	See page	QT
01	0503011883	QUICK CONNECTION COVER		01
02	0503011628	FEMALE QUICK COUPLER		01




Item	Code	Description	See page	QT
01	0511061880	SIDE RIGHT RATCHET		01
02	0531010264	SIDE RATCHET		01
03	0511061881	RATCHET FOLLOWER		01
04	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
05	0503011179	3/8" X 2-1/4" BOLT		05
06	0503011443	3/8" SPRING WASHER		05
07	0503010026	3/8" NUT		05
08	0503010002	1800 GREASE FITTING		02
09	0503030012	HAIR PIN		01
10	0502012783	STABILIZER BODY GREATER		01
11	0521067623	FUSE 713 EXTENSION RIGHT 3RD POINT		01
12	0521067622	FUSE 470 EXTENSION LEFT 3RD POINT		01




Item	Code	Description	See page	QT
01	0521066302	HOSE HOLDER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01

TRACTOR HITCH


0511055096




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	COMPRESSION SPRING LEFT		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0521068097	505 SIDE EXTENSOR FIXED POINT		01
02	0521066338	EXTERNAL ROTATING BRIDGE		01
03	0561019879	LOCK ATTACHMENT BAR		01
04	0521067393	EXTERNAL SIDE EAR		01
05	0571019949	JUNCTION SHAFT		01
06	0503030119	LOCK PIN		01
07	0503010002	1800 GREASE FITTING		03
08	0521065193	TURNBUCKLE AXLE		01




Item	Code	Description	See page	QT
01	0521066300	RIGHT TURNBUCKLE		01
02	0503010002	1800 GREASE FITTING		02
03	0521066301	LEFT TURNBUCKLE		01
04	0541018672	COUNTERNUT		01
05	0502011195	ADJUSTMENT NUT BODY		01




Item	Code	Description	See page	QT
01	0521067716	FIXER TUBE		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0503010152	3/4" SELF LOCKING NUT		04
05	0501010322	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01



Item	Code	Description	See page	QT
01	0503014820	COROTE BLACK WATER		01
02	0521068651	SUPPORT BOX		01
03	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		02
04	0503010025	3/8" SPRING WASHER		02
05	0501010984	FLAT WASHER		02



Item	Code	Description	See page	QT
01	0521068652	TOOLS BOX SUPPORT		01
02	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		02
03	0503010025	3/8" SPRING WASHER		06
04	0501010984	FLAT WASHER		02
05	0501011643	3/8 X 1"BOLT		04
06	0503010026	3/8" NUT		04
07	0503034772	BOX		01
08	0581017000	PLATE INTERMEDIARY		02




Item	Code	Description	See page	QT
01	0521066480	RH WHEELS SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 20 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	24	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	25	01
15	0501047888	ROD STOP		01
16	0511065842	LEFT WHEEL FORK		01
17	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8" SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" COTTERPIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056300	MOUNTED LEFT STRETCHER	26	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8" NUT		02

Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 29 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TIGHTENER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	CHAIN TENSIONER BEARING	30	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01

WHEEL ASSY LEFT FIXING EXTENSOR

0521056089



Item	Code	Description	See page	QT
01	0521066479	RH WHEELS SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 20 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	24	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	25	01
15	0501047888	ROD STOP		01
16	0511065842	LEFT WHEEL FORK		01
17	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8" SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" COTTERPIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056300	MOUNTED LEFT STRETCHER	26	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8" NUT		02


WHEEL ASSY LEFT FIXING EXTENSOR

0521056089

Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 29 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TIGHTENER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	CHAIN TENSIONER BEARING	30	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01

RIGHT WHEEL ASSY

0521056090



Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 20 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	24	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	25	01
15	0501047888	ROD STOP		01
16	0511064744	WHEEL FORK		01
17	0531016051	CARRY-WHEEL CHAIN PROTECTION CAP		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8" SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" COTTERPIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056299	MOUNTED RIGHT STRETCHER	27	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8" NUT		02


RIGHT WHEEL ASSY

0521056090


Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 29 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TIGHTENER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	CHAIN TENSIONER BEARING	30	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01

RIGHT WHEEL ASSEMBLY WITHOUT TRANSMISSION


0521056093



Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0503010019	1/2" SPRING WASHER		12
03	0503013232	1/2" BOLT		08
04	0561013021	BEARING INNER LOK		02
05	0561013022	BEARING EXTERNAL LOCK		02
06	0503010398	501082 CLAMPING RING (FOR AXLE)		02
07	0561013020	KM 12 NUT		02
08	0503010027	5/8" SPRING WASHER		02
09	0503011167	M16 X 2 X 30 BOLT		02
10	0501047888	ROD STOP		01
11	0521056101	EE WHEEL WITH TIRE 7.00X16 ASSY WITHOUT 21 TRANSMISSION		01
12	0503016485	BOLT 3/4		04
13	0503010152	3/4" SELF LOCKING NUT		04
14	0541010763	FLAT WASHER		04
15	0503017857	BOLT 5/8 UNF 4		04
16	0503010811	5/8" UNF SELF ADJUSTING NUT		04
17	0501012140	FLAT WASHER		04
18	0503010834	1/2 X 1 BOLT		04
19	0501017779	32 X 60 X 4.75 FLAT WASHER		02
20	0503010523	1/4" X 2" COTTERPIN		01
21	0521010546	1.2" X 5.7" COUPLING SHAFT		01
22	0511064744	WHEEL FORK		01
23	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
24	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 25 WITHOUT LUBRICATION		01
25	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
26	0591010098	ARTICULATED BEARING WHEELED WITHOUT TRANSMISSION WITHOUT LUBRICATION		02
27	0502012720	WHEEL SUPPORT FIXER		01




Item	Code	Description	See page	QT
01	0503063073	EE WHEEL WITH TIRE 7.00 X 16 14L ASSEMBLY		01
02	0521056100	WHEEL BOX ASSY WITH TRANSMISSION	22	01




Item	Code	Description	See page	QT
01	0503063073	EE WHEEL WITH TIRE 7.00 X 16 14L ASSEMBLY		01
02	0521056102	ASSY WHEEL BOX WITHOUT TRANSMISSION	23	01

WHEEL BOX ASSY WITH TRANSMISSION


0521056100




Item	Code	Description	See page	QT
01	0503010804	00547-B SEAL		02
02	0503010330	KM 9 LOCKNUT		01
03	0511015949	LOCK NUT		01
04	0503010329	LOCK WASHER		01
05	0503010002	1800 GREASE FITTING		01
06	0501110721	WHEEL HUB WITH SCREW / NUTS		01
06A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
06B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
06C	0503016516	5/8 UNF CONIC NUT		06
07	0503019364	BEARING 25590/25523		02
08	0521018363	00547-B SEAL		01
09	0511062015	14Z GEAR WITH FLANGE		01
10	0503010421	5/16" X 1-1/2" BOLT		06
11	0503011444	SPRING WASHER		06




Item	Code	Description	See page	QT
01	0503010804	00547-B SEAL		02
02	0503010330	KM 9 LOCKNUT		01
03	0511015949	LOCK NUT		01
04	0503010329	LOCK WASHER		01
05	0503010002	1800 GREASE FITTING		01
06	0501110721	WHEEL HUB WITH SCREW / NUTS		01
06A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
06B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
06C	0503016516	5/8 UNF CONIC NUT		06
07	0503019364	BEARING 25590/25523		02
08	0521018363	00547-B SEAL		01




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		01
02	0591010747	CURRENT STRETCHER AXIS		01
03	0503010302	501019 SEAL RING		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0511017302	FLAT WASHER		01
07	0541016454	PULLEY		01




Item	Code	Description	See page	QT
01	0531060012	CASE 101.6 X 324.5 WITHOUT LUBRICATION		01
02	0541017674	TURNBUCLE BODY		01
03	0511064408	FORK		01
04	0503011094	3/8" X 2" BOLT		01
05	0503010025	3/8" SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581010302	RING OF SUPPORT		01
08	0502012822	101.60 END CAP		01
09	0503011061	8-342 BACK-UP RING		02
10	0503010338	2-342 N 3006-9B O'RING		02
11	0503017936	RING		01
12	0503017938	RING GUIDE		01
13	0503017937	GASKET		01
14	0503010761	D-1750 SCRAPER RING		01
15	0581010837	PISTON		01
16	0503010817	1.1/4" SELF LOCKING NUT		01
17	0503015633	SELEMASTER SEALING		01
18	0503018029	2-217 O'RING		01
19	0503018045	2-130 (AGEL) O'RING		04
20	0503030387	PLUG		02
21	0511033019	CYLINDER REPAIR KIT 44.45 X 101.60		01




Item	Code	Description	See page	QT
01	0503010027	5/8" SPRING WASHER		01
02	0503010013	5/8" NUT		01
03	0521055238	BEARING TENSIONER CHAIN	28	01
04	0551018241	SLEEVE 16,30 X 30 X 8		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0551018252	CHAIN TIGHTENER AXLE		01
08	0511017302	FLAT WASHER		01
09	0503010232	5/8" X 1.3/4" BOLT		01
10	0531016916	SLEEVE BEARING SUPPORT		01
11	0541012098	LEFT CHAIN TIGHTENER LARGER SUPPORT		01




Item	Code	Description	See page	QT
01	0503010027	5/8" SPRING WASHER		01
02	0503010013	5/8" NUT		01
03	0521055238	BEARING TENSIONER CHAIN	28	01
04	0551018241	SLEEVE 16,30 X 30 X 8		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0551018252	CHAIN TIGHTENER AXLE		01
08	0511017302	FLAT WASHER		01
09	0503010232	5/8" X 1.3/4" BOLT		01
10	0531016916	SLEEVE BEARING SUPPORT		01
11	0531018654	CHAIN TIGHTENER SUPPORT		01



Item	Code	Description	See page	QT
01	0503019355	BEARING 6202 2RS1		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0591010097	ARTICULATED BEARING WHEELED WITHOUT LUBRICATION		01
02	0503019409	SELF LUBRICATING BUSHING		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01

SQUARE AXIS ASSEMBLY 730


0521056119




Item	Code	Description	See page	QT
01	0501056271	BEARING CLOSED	32	02
02	0501056444	BEARING WITH ROLLING	33	02
03	0503011953	5/16" X 1" BOLT		08
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		08
05	0503010179	5/16" ZN SPRING WASHER		08
06	0503010337	5/16" NUT		08
07	0511014218	3/4" X 28.7"SQUARE SHAFT		02
08	0501053788	Q3/4" FASTENER AXLE ASSY	34	04
09	0503030275	AGRICULTURAL BEARING		04
10	0521061852	LEVER RATCHET		02
11	0521061847	AXLE ADRIVING ASSY		02
12	0521061849	DISASSEMBLE LEVER		02
13	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
14	0501010984	FLAT WASHER		08
15	0503010140	1/8" X 3/4" COTTERPIN		04
16	0571012792	LOWER LEVER		02
17	0503011082	C1/2" X 1.3/4" SCREW		02
18	0511017302	FLAT WASHER		04
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2" NUT		02
21	0561016797	SLEEVE UNION LEVER		02
22	0503010026	3/8" NUT		02
23	0503010025	3/8" SPRING WASHER		02
24	0503010849	3/8" X 1-1/2" BOLT		02



Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01

MOTOR SHAFT ASSEMBLY


0521056398




Item	Code	Description	See page	QT
001	0503011082	C1/2" X 1.3/4" SCREW		08
002	0511017302	FLAT WASHER		16
003	0503010019	1/2" SPRING WASHER		08
004	0503010060	1/2" NUT		08
005	0511047069	SIDE TRANSMISSION DRIVING	36	01
006	0511047070	LH SIDE TRANSMISSION DRIVING	37	01
007	0511051434	TRANSMISSION DRIVING ASSY	38	04
008	0591010711	MOTOR AXLE BEARING SUPPORT		04
009	0521056085	PLATE BEARING ASSY		08
010	0581010468	MOTOR SHAFT ASSEMBLY		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0521056103	BEARING WITH GEAR 20Z HEX SHAFT 3/4	40	02
02	0591010701	HEX SHAFT 3/4 X 1270		02
03	0521056144	INTERMEDIATE SEED TRANSMISSION	42	02
04	0511063123	BUSHING WITH NUT		09
05	0501018535	1/2 X 1 BOLT		09
06	0591012435	HEX SHAFT 3/4 X 1470		01
07	0591012434	3/4 X 1350 HEX AXLE		01
08	0581015056	SLEEVE		09



Item	Code	Description	See page	QT
01	0521055498	SEED TRANSMISSION DOUBLE BEARING	41	01
02	0531060014	GEAR 20Z X 48.50 HEX HOLE 20		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02
06	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
07	0503018441	5/16" X 1-1/4" BOLT		02




Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012858	502075 CLAMPING RING (FOR HOLE)		01
03	0503019373	6006 2RS1 NATIONAL BEARING		02




Item	Code	Description	See page	QT
01	0503010243	CLAMP		02
02	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
03	0503012880	1/4" UNC SELF ADJUSTING NUT		02
04	0503063012	SEED TRANSMISSION SHAFT HEX 3/4		01
05	0503034773	HOSE 1.1/2 X 1.1/2 X 120		01

TRANSMISSION ASSY


0521056118




Item	Code	Description	See page	QT
01	0511017302	FLAT WASHER		06
02	0503010019	1/2" SPRING WASHER		02
03	0503010060	1/2" NUT		02
04	0561017281	ARTICULACION ARM		02
05	0521056135	BEARING GEAR WITH DOUBLE	44	02
06	0521055217	LOWER CURRENT STRETCH	45	04
07	0521056134	STRETCHER FERTILIZER CURRENT 17Z	46	02
08	0521054446	LOWER CURRENT STRETCHER 21Z	47	02
09	0571019829	LEVER FIXER		02
10	0503010237	3/8" X 1" BOLT		06
11	0503010025	3/8" SPRING WASHER		06
12	0503010026	3/8" NUT		06
13	0571019830	LEVER FIXER		02
14	0503011312	ROTATIVE CABLE		02
15	0503030093	TRACTION SPRING		02
16	0561017273	FIXER SPRING		02
17	0561017282	LOWER LEVER		02
18	0561016797	SLEEVE UNION LEVER		02
19	0591010705	ARTICULATION GLOVE		02
20	0503011082	C1/2" X 1.3/4" SCREW		02
21	0521010773	0.37" X 1.18" COUPLING SHAFT		02
22	0501010984	FLAT WASHER		06
23	0541014973	COUPLING SHAFT		02
24	0503010140	1/8" X 3/4" COTTERPIN		04
25	0503017874	BOLT 1/2 UNC		02
26	0503011336	1/2" HEX SELF ADJUSTING NUT		02
27	0503013065	40-1 X 159 CHAIN LINK + MENDING		02
28	0503016737	40-1 X 114 CHAIN LINK + REDUCION		02




Item	Code	Description	See page	QT
01	0503019356	BEARING 6005 2RS1		02
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0503012412	5/8 UNC SELF LOCKING NUT		01
04	0521061843	20Z DOBLE GEAR		01
05	0551019175	DOUBLE GEAR AXLE		01
06	0501010163	5/8" X 4-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503019355	BEARING 6202 2RS1		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0591010693	CURRENT DEVIATION GLOVE		01
08	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		01




Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503019356	BEARING 6005 2RS1		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0501012140	FLAT WASHER		01
06	0581015136	40MM STRETCHING SHAFT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01
08	0501011541	5/8" X 3" BOLT		01



Item	Code	Description	See page	QT
01	0561019899	RIGHT SUPPORT FIXER RECAMBIO		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0503011082	C1/2" X 1.3/4" SCREW		02
05	0511017302	FLAT WASHER		04
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02



Item	Code	Description	See page	QT
01	0561019898	LEFT SUPPORT FIXER RECAMBIO		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0503011082	C1/2" X 1.3/4" SCREW		02
05	0511017302	FLAT WASHER		04
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02



Item	Code	Description	See page	QT
01	0501048790	AXLE WITH LINK ASSY	52	02
02	0551018209	DRIVING AXLE		01
03	0521018259	DRIVEN AXLE		01
04	0551018210	DRIVEN AXLE		01
05	0551018211	INTERM SHAFT		01
06	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	53	01
07	0503030303	SUPPORT WASHER		06
08	0501056443	BEARING ASSY GEAR BOX	54	02
09	0511059266	CLOSED BEARING	55	05
10	0503012389	1/2 BALL		04
11	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
12	0503010834	1/2 X 1 BOLT		04
13	0503010060	1/2" NUT		06
14	0503031805	11Z 1/2" GEAR		04
15	0503010302	501019 SEAL RING		04
16	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
17	0511067501	26Z GEAR		01
18	0521018630	1.4" X SQUARE 0.8" WASHER		05
19	0503010292	0.2" X 1.6" SPRING PIN		10
20	0501054655	CHAIN TENSIONER ASSY	56	02
21	0591010679	AGRICOLA BEARING SQUARE HOLE 19.4 / 19.6X26		01
22	0501010984	FLAT WASHER		01
23	0503010256	3/8" X 3/4" BOLT		01
24	0503012204	40-1 CHAIN X 82 LINK + RED		02
25	0503019573	CHAIN		01
26	0511060396	DRIVE/DRIVEN AXLE CONE		04
27	0511061822	25Z P0.5" GEAR SQUARE HOL		01
28	0502011758	REAR TENSIONER LEVER		02
29	0531060029	LONGER CURRENT STRETCHER WITHOUT LUBRICATION		01
30	0503031367	SPRING		01
31	0503031366	RIGHT TWISTED SPRING RECAMBIO		01


ASSY RIGHT EXCHANGE

0521056086

Item	Code	Description	See page	QT
32	0531060009	RIGHT EXCHANGE BODY WITHOUT LUBRICATION		01
33	0503019418	GLOVE		04
34	0503011034	RING		04
35	0531060025	MINOR CHAIN STRETCHER WITHOUT LUBRICATION		01
36	0511059261	CHAIN TENSIONER	57	01
37	0503014734	BOLT		02
38	0503010019	1/2" SPRING WASHER		02
39	0521060879	38Z GEAR		01
40	0511061759	22Z P12,70 FQ 3/4" GEAR		01

ASSY LEFT EXCHANGE

0521056087




Item	Code	Description	See page	QT
01	0501048790	AXLE WITH LINK ASSY	52	02
02	0551018209	DRIVING AXLE		01
03	0521018259	DRIVEN AXLE		01
04	0551018210	DRIVEN AXLE		01
05	0551018211	INTERM SHAFT		01
06	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	53	01
07	0503030303	SUPPORT WASHER		06
08	0501056443	BEARING ASSY GEAR BOX	54	02
09	0511059266	CLOSED BEARING	55	05
10	0503012389	1/2 BALL		04
11	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
12	0503010834	1/2 X 1 BOLT		04
13	0503010060	1/2" NUT		06
14	0503031805	11Z 1/2" GEAR		04
15	0503010302	501019 SEAL RING		04
16	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
17	0511067501	26Z GEAR		01
18	0521018630	1.4" X SQUARE 0.8" WASHER		05
19	0503010292	0.2" X 1.6" SPRING PIN		10
20	0501054655	CHAIN TENSIONER ASSY	56	02
21	0501010984	FLAT WASHER		01
22	0503010256	3/8" X 3/4" BOLT		01
23	0503012204	40-1 CHAIN X 82 LINK + RED		02
24	0503019573	CHAIN		01
25	0511060396	DRIVE/DRIVEN AXLE CONE		04
26	0511061822	25Z P0.5" GEAR SQUARE HOL		01
27	0502011758	REAR TENSIONER LEVER		02
28	0531060029	LONGER CURRENT STRETCHER WITHOUT LUBRICATION		01
29	0503031367	SPRING		01
30	0503031366	RIGHT TWISTED SPRING RECAMBIO		01
31	0531060008	LEFT EXCHANGE BODY WITHOUT LUBRICATION		01


ASSY LEFT EXCHANGE

0521056087


Item	Code	Description	See page	QT
32	0531060025	MINOR CHAIN STRETCHER WITHOUT LUBRICATION		01
33	0503019418	GLOVE		04
34	0503011034	RING		04
35	0511059261	CHAIN TENSIONER	57	01
36	0591010679	AGRICOLA BEARING SQUARE HOLE 19.4 / 19.6X26		01
37	0503014734	BOLT		02
38	0503010019	1/2" SPRING WASHER		02
39	0521060879	38Z GEAR		01
40	0511061759	22Z P12,70 FQ 3/4" GEAR		01



Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01



Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
05	0503010179	5/16" ZN SPRING WASHER		02
06	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
------	------	-------------	----------	----