

ROW CROP PLANTERS

**COP FLEX 600 SUPREMA P.P - FRAME
4845-5345-5745 - APT - CSU**

Code: 0501092845
Series: S-0115
Revision: 00
Date Revision: JUNHO/2022

PARTS CATALOGUE



MARCHESAN



PRODUCTS

Code	Description
0111201123	COP FLEX 600 SUP PP 4845/10E500 ESPECIAL S-0115
0111200332	COP FLEX 600 SUP PP 5345/11E500 ESPECIAL S-0115
0111200321	COP FLEX 600 SUP PP 5745/12E500 ESPECIAL S-0115
0111200310	COP FLEX 600 SUP PP4845/10E500 ESPECIAL S-0115

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909099165	ASSY FRAME	1
0511053436	DRAWBAR ASSY	2
0511053393	DRAWBAR	3
0511053289	ASSY DRAWBAR	4
0511054601	HITCH ARTICULATED TRACTOR	5
0511057860	WHEELED SET RIGHT	6
0511057861	WITH LEFT WHEEL	7
0501054284	STRETCHER CURRENT TRANSMISSION SIDE	8
0501110625	BEARING ARTICULATION WHEEL	9
0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX	10
0511052766	CARRYING WHEEL HUB ASSY	11
0503062158	EEE WHEEL WITH TIRE 700 X 16-10L ASSY	12
0501053522	WHEEL CHAIN TENSIONER	13
0511053375	CURRENT DEVIATION ASSY WHEEL	14
0521051217	SET HIDRAULICO	15
0511053358	VALVE FIXING ASSEMBLY	16
0511053384	HYDRAULIC CYLINDER ASSEMBLY	17
0511058411	HYDRAULIC CYLINDER	18
0511054302	HOSE KIT	19
0521051213	HOSE KIT	20
0501053834	MALE QUICK COUPLER	21
0511050639	RIGHT GEAR BOX ASSY	22
0511050640	LEFT GEAR BOX ASSY	23
0501048790	AXLE WITH RING	24
0501056443	GEAR HOUSING BEARING	25
0501056444	BEARING WITH ROLLING	26
0501056271	GEARBOX CLOSED BEARING	27
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	28
0501054655	CHAIN TENSIONER ASSY	29
0501058213	LH GEAR BOX	30
0511053352	SET BOX FERTILIZER	31
0511053374	SET BOX FERTILIZER COP F 600 13	32
0511053353	PLATFORM SET	33
0511053339	PLATFORM SET	34
0511053356	ASSY LADDER	35
0511054298	HANDRAIL ASSY	36
0511053388	JOINT HANDRAIL SET	37
0511053376	JOINT HANDRAIL SET	38
0511054295	MARKER HIDRAULICO	39
0511053287	MARKER HIDRAULICO	40
0511053306	MARKER HIDRAULICO	41
0909094616	MARKER CYLINDER	42
0909094617	CIRCUIT MARKER HIDRAULICO	43
0501050633	ROW MARKER DISK ASSEMBLY	44
0511053904	ROW MARKER DISC	45
0511058449	HYDRAULIC CYLINDER	46
0511040203	1.5" X 2.5" X 19" X 9" HYDRAULIC CYLINDER	47
0511054971	JACK ASSEMBLY	48
0511054292	MOTOR SHAFT ASSEMBLY	49
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	50
0511051434	TRANSMISSION ACTUATOR	51
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	52
0511053380	MOTOR SHAFT ASSEMBLY	53
0511053341	MOTOR SHAFT ASSEMBLY	54
0511056597	ASSY PORT MANUAL INSTRUCCION	55



MARCHESAN

INDEX

0511056598	MANUAL STORAGE TUBE ASSY	56
0511053342	SQUARE AXLE ASSEMBLY	57
0511053434	SQUARE SHAFT SET	58
0909099293	LINEA ABONO SEMILLA COMPL	59
0521051622	FRONT SEED SHORT ROW	60
0521051621	FRONT SEED LONG ROW	61
0511052393	BEARING FOLLOWER ROW ASSY	62
0511050609	BEARING WITH 17Z GEAR ASSY	63
0511055260	SEED ROW CHAIN TENSIONER	64
0511054635	BEARING AXLE BODY	65
0511057159	TRANSMISSION BOX SEED LINE	66
0511057625	ROW SEED BEARING	67
0511057729	FRONT SEED SHORT	68
0511057730	FRONT SEED LONG	69
0511054884	TRANSMISSION BOX	70
0511057496	LEFT REAR ROW SEED SUP PP PM 400	71
0511057495	RIGHT REAR ROW SEED SUP PP PM 400	72
0521050012	RIGHT REAR ROW SEED P.P PM400/CSU	73
0521050013	LEFT REAR ROW SEED P.P PM400/CSU	74
0511057108	RIGHT REAR SEED ROW PRECISION PLANTING CSU 3	75
0511057115	REAR LEFT SEED LINE PRECISION PLANTING CSU 3	76
0511057209	ROW RIGHT REAR SEED	77
0511057210	ROW LEFT REAR SEED	78
0511057155	PRECISION PLANTING LEFT TRANSMISSION BOX	79
0511057494	SET TURBINE 4045/4395	80
0511053172	LEFT LOW CUBE WITH DISC 15	81
0501053173	FERTILIZER SILO SUPORT ASSY	82
0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA CSU 3	83
0511057153	DDD LEFT SUPREMA PRECISION PLANTING	84
0501054481	RIGHT ARM DEPTH CONTROL WITH WHEEL	85
0501054482	DEPTH CONTROL LEFT ARM WITH TIRE	86
0511053023	LONG FERTILIZER LINE	87
0511053024	FERTILIZER SHORT LINE	88
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	89
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	90
0511051818	DISC CUT 18 SEMI MOUNTED	91
0511051819	DC 20 SEMI MOUNTED	92
0501052139	ASSY CUTTING DISK DPL18	93
0501054887	20 BLADE DISC WITH FLAT PLAN DISC	94
0511057154	DDD RITGH SUPREMA PRECISION PLANTING	95
0511057509	SEED RESERVOIR PNEUMATIC ASSY	96
0521050525	FIXER FERTILIZER CONDUCTOR	97
0521044460	SYSTEM DEPTH / COMPACTOR	98
0511055690	WHEEL SISTEM	99
0501059228	ADJUSTMENT LEVER	100
0511055628	DEPTH WHEEL SYSTEM	101
0511055629	DEPTH WHEEL SYSTEM	102
0511055627	WHEEL ASSY RAYED	103
0511055327	COMPACTING WHEEL V ASSY RUBBER	104
0501052908	COMPACTOR WHEEL WITH BEARING	105
0521051424	WHEEL SYSTEM DEPTH/COMPACTOR QUICK ADJUSTMENT	106
0501056769	DEPTH WHEELS REGULATOR ASSY	107
0521051423	COMPACTOR SUPPORT	108
0511050077	WHEEL STRIPED	109
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	110



MARCHESAN

INDEX


0511058650	SEMI-MOUNTED DEPTH CONTROL	111
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	112
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	113
0501052297	DEPTH WHEELS REGULATOR ASSY	114
0501052538	DEPTH BAND WITH ARMS	115
0511054333	COMPACT WHEEL RIGHT WITH BEARING	116
0511054334	COMPACT WHEEL LEFT WITH BEARING	117
0521044269	PRESS WHEELS/DEPTH ASSY	118
0511055326	DEPTH CONTROL PRESS WHEEL ASSY	119
0511055328	DEPTH WHEEL SYSTEM	120
0521042327	DEPTH CONTROL & PRESS WHEEL ASSY	121
0511053550	DEPTH CONTROL ASSY	122
0521055198	AIR CONDUCTOR LAT	123
0501052501	CONVEX PRESS WHEEL	124
0501056269	SUPPORT WHEEL ASSY CONCAVE RIGHT	125
0521046501	DEPTH CONTROL AND PRESS WHEEL WITH FAST ADJUSTING	126
0511059462	DEPTH CONTROL WITH FAST ADJUSTMENT	127
0511059463	COMFORT WHEEL WITH FAST ADJUSTMENT	128
0521044538	DEPTH WHIT REGULACION ANGLE COMPACT CONTROL	129
0511052971	SEMI-ASSEMBLED DEPTH CONTROL WITH THREAD	130
0511059325	LEFT ARM COVERED WHEEL ASSEMBLED	131
0511059324	RIGHT ARM COVERED WHEEL ASSEMBLED	132
0511051546	CUBE RIGHT CONTROL DEPTH	133
0511051547	LEFT CUBE CONTROL DEPTH	134
0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	135
0511055819	DEPTH WHIT AROS BAND	136
0511054291	HEX AXLE ASSEMBLY	137
0511053381	HEX AXLE ASSEMBLY	138
0511053361	HEX AXLE ASSEMBLY	139
0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	140
0511052333	ASSEMBLY SUPPORT LEFT FIXER CHANGE	141
0511057863	SET TRANSMISSION LEFT ASSY	142
0511057862	SET TRANSMISSION RIGHT ASSY	143
0511050385	BEARING DOUBLE GEAR	144
0501058265	STRETCHER LOWER CURRENT 21Z SEED	145
0511056387	INTERMEDIATE BEARING SEED WITH GEAR 21Z	146
0511050127	CHAIN TENSIONER SUPPORT	147
0501053126	FERTILIZER CHAIN TENSIONER ASSY	148
0511053366	CHAIN TENSIONER EXCHANGE	149
0521050174	ASSEMBLY CSU	150
0521050173	ASSEMBLY CSU	151
0511057690	3" ARTICULATED SEED CONDUCTOR	152
0521050783	ASSEMBLY CSU	153
0511058100	2 BOXES WITH 9 CONDUCTORS ASSEMBLY	154
0511058842	ASSEMBLY CSU	155
0511057737	2 BOXES WITH 10 CONDUCTORS ASSEMBLY	156
0511058841	ASSEMBLY CSU	157
0511057919	2 BOXES WITH 11 CONDUCTORS ASSEMBLY	158
0521050884	ASSEMBLY CSU	159
0521050886	ASSEMBLY CSU	160
0521050869	ASSEMBLY CSU	161
0511058702	ASSEMBLY CSU	162
0521050710	ASSEMBLY CSU	163
0511058880	ASSEMBLY CSU	164

INDEX

0511058843	ASSEMBLY CSU		165
0511058564	ASSEMBLY CSU		166
0511057728	HYDRAULIC TURBINE ASSEMBLY		167
0521050976	ASSY TURBINE		168
0511059459	PRECISION PLANTING SUPREME TURBINE ASSY		169
0511053218	REAR FIXING TURBINE ASSY		170
0511057700	HYDRAULIC TURBINE		171
0511059319	AIR FIXING SUPPORT		172
0511059406	TURBINE P.P MOUNTED		173
0501054983	NIPPLE HIDRAULIC MOTOR		174
0521044613	FAN 480X50 (HIDRAULIC)		175
0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE		176
0521050154	TURBINE P.P WITH HOLE		177
0511050906	DRAWBAR TURNBUCKLE		178
0511056392	PLANTING MONITORING ASSY 09L SEED AND FERTILIZER		179
0501059537	10 ROW SEED MONITOR		180
0511056394	11L SEED OR FERTILIZER PLANT MONITORING ASSEMBLY PM400		181
0501059539	12 ROW SEED MONITOR		182
0511056396	13L SEED OR FERTILIZER PLANT MONITORING ASSEMBLY PM400		183
0511057872	SET LABEL ADHESIVE		184
0521053677	SET LABEL ADHESIVE		185
0511059400	HYDRAULIC TURBINE ASSEMBLY		186
0909096365	CEAC ASSY		187

ASSY FRAME

0909099165



Item	Code	Description	See page	4845	5345	5745
01	0521063941	FREME (4395)		01	00	00
02	0521063953	FRAME (5345)		00	01	00
03	0521061933	FRAME (5745)		00	00	01
04	0511053436	DRAWBAR ASSY	2	01	00	00
05	0511053393	DRAWBAR	3	00	01	01
06	0511053289	ASSY DRAWBAR	4	00	00	01
07	0511054601	HITCH ARTICULATED TRACTOR	5	01	01	01
08	0511053179	TRACTOR COUPLING SHAFT		01	01	01
08A	0521064036	TRACTOR HITCH AXLE		01	01	01
08B	0503030012	HITCH PIN CLIP		01	01	01
09	0511057860	WHEELED SET RIGHT	6	01	01	01
10	0511057861	WITH LEFT WHEEL	7	01	01	01
11	0521051217	SET HIDRAULICO	15	01	01	01
12	0511050639	RIGHT GEAR BOX ASSY	22	01	01	01
13	0511050640	LEFT GEAR BOX ASSY	23	01	01	01
14	0511053352	SET BOX FERTILIZER	31	01	01	00
15	0511053374	SET BOX FERTILIZER COP F 600 13	32	00	01	01
16	0511053353	PLATFORM SET	33	01	01	00
17	0511053339	PLATFORM SET	34	00	00	01
18	0511053356	ASSY LADDER	35	02	02	02
19	0511054298	HANDRAIL ASSY	36	01	00	00
20	0511053388	JOINT HANDRAIL SET	37	00	01	00
21	0511053376	JOINT HANDRAIL SET	38	00	00	01
22	0511054295	MARKER HIDRAULICO	39	01	00	00
23	0511053306	MARKER HIDRAULICO	41	00	01	01
24	0511053287	MARKER HIDRAULICO	40	00	01	01
25	0909094616	MARKER CYLINDER	42	01	01	01
26	0909094617	CIRCUIT MARKER HIDRAULICO	43	01	01	01
27	0501050633	ROW MARKER DISK ASSEMBLY	44	02	02	02
28	0511054971	JACK ASSEMBLY	48	02	02	02
29	0511054292	MOTOR SHAFT ASSEMBLY	49	01	00	00

ASSY FRAME

0909099165

Item	Code	Description	See page	4845	5345	5745
30	0511053380	MOTOR SHAFT ASSEMBLY	53	00	01	00
31	0511053341	MOTOR SHAFT ASSEMBLY	54	00	00	01
32	0511056597	ASSY PORT MANUAL INSTRUCCION	55	01	00	00
33	0511056598	MANUAL STORAGE TUBE ASSY	56	00	01	01
34	0511053342	SQUARE AXLE ASSEMBLY	57	01	00	00
35	0511053434	SQUARE SHAFT SET	58	00	01	01
36	0909099293	LINEA ABONO SEMILLA COMPL	59	09	10	11
37	0511054291	HEX AXLE ASSEMBLY	137	01	00	00
38	0511053381	HEX AXLE ASSEMBLY	138	00	01	01
39	0511053361	HEX AXLE ASSEMBLY	139	00	00	00
40	0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	140	01	01	01
41	0511052333	ASSEMBLY SUPPORT LEFT FIXER CHANGE	141	01	01	01
42	0511057863	SET TRANSMISSION LEFT ASSY	142	01	01	01
43	0511057862	SET TRANSMISSION RIGHT ASSY	143	01	01	01
44	0521050174	ASSEMBLY CSU	150	01	00	00
45	0521050783	ASSEMBLY CSU	153	01	00	00
46	0511058842	ASSEMBLY CSU	155	01	00	00
47	0511058841	ASSEMBLY CSU	157	00	01	00
48	0521050884	ASSEMBLY CSU	159	00	00	01
49	0521050869	ASSEMBLY CSU	161	00	00	01
50	0521050710	ASSEMBLY CSU	163	00	00	01
51	0511058843	ASSEMBLY CSU	165	00	00	01
52	0511057728	HYDRAULIC TURBINE ASSEMBLY	167	01	00	00
53	0521050976	ASSY TURBINE	168	00	01	01
54	0511059459	PRECISION PLANTING SUPREME TURBINE ASSY	169	00	00	01
55	0511059400	HYDRAULIC TURBINE ASSEMBLY	186	00	00	01
56	0511050906	DRAWBAR TURNBUCKLE	178	01	01	01
57	0521018532	1.4" X 12" COUPLING SHAFT		01	01	01
58	0521010578	COUPLING SHAFT		01	01	01
59	0503030085	LOCK PIN		03	03	03
60	0511056392	PLANTING MONITORING ASSY 09L SEED AND FERTILIZER	179	01	00	00
61	0501059537	10 ROW SEED MONITOR	180	00	01	00
62	0511056394	11L SEED OR FERTILIZER PLANT MONITORING ASSEMBLY PM400	181	00	00	01
63	0501059539	12 ROW SEED MONITOR	182	00	00	01
64	0511056396	13L SEED OR FERTILIZER PLANT MONITORING ASSEMBLY PM400	183	00	00	01
65	0501110723	SCARIFIER ROD		09	10	11
65A	0502070082	POINT SUBSOILER		09	10	11
65B	0503010585	0,24" X 1.18" SPRING PIN		27	30	33
65C	0521063867	SCARIFIER ROD		09	10	11
66	0571014383	GUTTER		02	02	00
67	0571018391	GUTTER 25 X 58 X 1200		00	02	02
68	0571018663	SUPPORT GUTTER		06	06	06
69	0501011643	3/8 X 1"BOLT		04	06	08
70	0501010984	FLAT WASHER		04	06	08
71	0503010025	3/8" SPRING WASHER		04	06	08
72	0503010026	3/8" NUT		04	06	08
73	0503032624	SILO FERTILIZER GUTTER		04	04	04
74	0521013164	EXTENSOR		02	02	02
75	0501011310	FIXER LOCK		02	02	02
76	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		04	04	04
77	0503010019	1/2" SPRING WASHER		04	04	04
78	0503010060	1/2" NUT		04	04	04
79	0511057872	SET LABEL ADHESIVE	184	01	01	01
80	0521053677	SET LABEL ADHESIVE	185	01	01	01
81	0503034003	SERIAL NUMBER TAG 61 X 118		01	01	01
82	0503010001	3.2 X 5.5 RIVET		04	04	04




ASSY FRAME

0909099165

Item	Code	Description	See page	4845	5345	5745
83	0909096365	CEAC ASSY	187	01	01	01

DRAWBAR ASSY


0511053436



Item	Code	Description	See page	QT
01	0531063130	HEADER	01	
02	0502012328	DRAWBAR SUPPORT FRONT FIXATION	02	
03	0502012329	DRAWBAR FIXATION REAR SUPPORT	02	
04	0561014393	COUPLING SHAFT	02	
05	0503030119	LOCK PIN	02	
06	0502012330	SUPPORT FIXER PIVOT	04	
07	0503011084	3/4" X 5" BOLT	08	
08	0503010023	3/4" SPRING WASHER	04	
09	0503010014	3/4" NUT	04	
10	0503010002	1800 GREASE FITTING	01	
11	0561019087	DRAWBAR TRANSPORT LOCK	01	
12	0521018532	1.4" X 12" COUPLING SHAFT	01	
13	0521010578	COUPLING SHAFT	01	
14	0503030085	LOCK PIN	03	
15	0501010322	FLAT WASHER	04	

DRAWBAR


0511053393




Item	Code	Description	See page	QT
01	0511064808	DRAWBAR		01
02	0502012328	DRAWBAR SUPPORT FRONT FIXATION		04
03	0502012329	DRAWBAR FIXATION REAR SUPPORT		04
04	0561014393	COUPLING SHAFT		04
05	0503030119	LOCK PIN		04
06	0502012330	SUPPORT FIXER PIVOT		08
07	0503011084	3/4" X 5" BOLT		16
08	0503010023	3/4" SPRING WASHER		08
09	0503010014	3/4" NUT		08
10	0503010002	1800 GREASE FITTING		01
11	0561019087	DRAWBAR TRANSPORT LOCK		01
12	0521018532	1.4" X 12" COUPLING SHAFT		01
13	0521010578	COUPLING SHAFT		01
14	0503030085	LOCK PIN		03
15	0501010322	FLAT WASHER		08

ASSY DRAWBAR

0511053289




Item	Code	Description	See page	QT
01	0511062824	DRAWBAR		00
02	0502012328	DRAWBAR SUPPORT FRONT FIXATION		04
03	0502012329	DRAWBAR FIXATION REAR SUPPORT		04
04	0561014393	COUPLING SHAFT		04
05	0503030119	LOCK PIN		04
06	0502012330	SUPPORT FIXER PIVOT		08
07	0503011084	3/4" X 5" BOLT		16
08	0503010023	3/4" SPRING WASHER		08
09	0503010014	3/4" NUT		08
10	0503010002	1800 GREASE FITTING		01
11	0561019087	DRAWBAR TRANSPORT LOCK		01
12	0521018532	1.4" X 12" COUPLING SHAFT		01
13	0521010578	COUPLING SHAFT		01
14	0503030085	LOCK PIN		03
15	0501010322	FLAT WASHER		08



Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01

WHEELED SET RIGHT

0511057860




Item	Code	Description	See page	QT
001	0521063678	WHEEL SUPPORT		01
002	0501054284	STRETCHER CURRENT TRANSMISSION SIDE	8	01
003	0511064744	WHEEL FORK		01
004	0501110625	BEARING ARTICULATION WHEEL	9	02
005	0503013232	1/2" BOLT		08
006	0503010019	1/2" SPRING WASHER		08
007	0561013021	BEARING INNER LOK		02
008	0561013022	BEARING EXTERNAL LOCK		02
009	0503010398	501082 CLAMPING RING (FOR AXLE)		02
010	0561013020	KM 12 NUT		02
011	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED 10 BOX		01
012	0591010589	BODY LOCK WHEEL		02
013	0503010027	5/8" SPRING WASHER		02
014	0503011167	M16 X 2 X 30 BOLT		02
015	0511061808	15Z GEAR WITH AXLE		01
016	0501018466	FLAT WASHER		01
017	0511061809	15Z GEAR WITH COUPLING		01
018	0503011103	7/16" X 2-1/2" BOLT		01
019	0503010180	7/16" SPRING WASHER		01
020	0503010244	7/16" NUT		01
021	0503010004	1890 GREASE FITTING		02
022	0531018654	CHAIN TIGHTENER SUPPORT		01
023	0531018653	CHAIN TIGHTENER MINOR SUPPORT		01
024	0511014513	1" X 0.6" X 0.4" ARTUCULAT SLEEVE		01
025	0531016916	SLEEVE BEARING SUPPORT		02
026	0503010899	5/8" X 2-1/4" BOLT		01
027	0503010027	5/8" SPRING WASHER		01
028	0503010013	5/8" NUT		01
029	0501013491	5/8" TENSIONER SPRING		01
030	0503010013	5/8" NUT		01
031	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01

WHEELED SET RIGHT


0511057860

Item	Code	Description	See page	QT
032	0501053522	WHEEL CHAIN TENSIONER	13	01
033	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
034	0511053375	CURRENT DEVIATION ASSY WHEEL	14	01
035	0531016051	CARRY-WHEEL CHAIN PROTECTION CAP		01
036	0503010847	1/2" X 3.1/4" BOLT		02
037	0503010019	1/2" SPRING WASHER		02
038	0501054284	STRETCHER CURRENT TRANSMISSION SIDE	8	01
039	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
040	0511010736	5/8" X 5-1/4" BOLT		04
041	0503010811	5/8" UNF SELF ADJUSTING NUT		04
042	0502012720	WHEEL SUPPORT FIXER		01
043	0503017857	BOLT 5/8 UNF 4		04
044	0503010811	5/8" UNF SELF ADJUSTING NUT		04
045	0501012140	FLAT WASHER		04
046	0501047888	ROD STOP		01




Item	Code	Description	See page	QT
001	0521063678	WHEEL SUPPORT		01
002	0501054284	STRETCHER CURRENT TRANSMISSION SIDE	8	01
003	0511065842	LEFT WHEEL FORK		01
004	0501110625	BEARING ARTICULATION WHEEL	9	02
005	0503013232	1/2" BOLT		08
006	0503010019	1/2" SPRING WASHER		08
007	0561013021	BEARING INNER LOK		02
008	0561013022	BEARING EXTERNAL LOCK		02
009	0503010398	501082 CLAMPING RING (FOR AXLE)		02
010	0561013020	KM 12 NUT		02
011	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED 10 BOX		01
012	0591010589	BODY LOCK WHEEL		02
013	0503010027	5/8" SPRING WASHER		02
014	0503011167	M16 X 2 X 30 BOLT		02
015	0511061808	15Z GEAR WITH AXLE		01
016	0501018466	FLAT WASHER		01
017	0511061809	15Z GEAR WITH COUPLING		01
018	0503011103	7/16" X 2-1/2" BOLT		01
019	0503010180	7/16" SPRING WASHER		01
020	0503010244	7/16" NUT		01
021	0503010004	1890 GREASE FITTING		02
022	0541012098	LEFT CHAIN TIGHTENER LARGER SUPPORT		01
023	0531018653	CHAIN TIGHTENER MINOR SUPPORT		01
024	0511014513	1" X 0.6" X 0.4" ARTUCULAT SLEEVE		01
025	0531016916	SLEEVE BEARING SUPPORT		02
026	0503010899	5/8" X 2-1/4" BOLT		01
027	0503010027	5/8" SPRING WASHER		01
028	0503010013	5/8" NUT		01
029	0501013491	5/8" TENSIONER SPRING		01
030	0503010013	5/8" NUT		02
031	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01


Item	Code	Description	See page	QT
032	0501053522	WHEEL CHAIN TENSIONER	13	01
033	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
034	0511053375	CURRENT DEVIATION ASSY WHEEL	14	01
035	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		01
036	0503010847	1/2" X 3.1/4" BOLT		02
037	0503010019	1/2" SPRING WASHER		02
038	0501054284	STRETCHER CURRENT TRANSMISSION SIDE	8	01
039	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
040	0511010736	5/8" X 5-1/4" BOLT		04
041	0503010811	5/8" UNF SELF ADJUSTING NUT		04
042	0502012720	WHEEL SUPPORT FIXER		01
043	0503017857	BOLT 5/8 UNF 4		04
044	0503010811	5/8" UNF SELF ADJUSTING NUT		04
045	0501012140	FLAT WASHER		04
046	0501047888	ROD STOP		01




Item	Code	Description	See page	QT
01	0531017202	AXLE CHAIN TIGHTENER		01
02	0503030402	PULLEY		01
03	0503010302	501019 SEAL RING		01
04	0503010004	1890 GREASE FITTING		01
05	0511017302	FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0511015098	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0561015879	WHEELED JOINT BEARING		01
02	0561012895	GLOVE 30,16 X 45,32/45,28 X 47		01




Item	Code	Description	See page	QT
01	0511052766	CARRYING WHEEL HUB ASSY	11	01
02	0503062158	EEE WHEEL WITH TIRE 700 X 16-10L ASSY	12	01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503010328	25590/25523 ROLLER BEARING		02
03	0503010804	00547-B SEAL		02
04	0521018363	00547-B SEAL		01
05	0511062015	14Z GEAR WITH FLANGE		01
06	0503010421	5/16" X 1-1/2" BOLT		06
07	0503011444	SPRING WASHER		06
08	0511015949	LOCK NUT		01
09	0503010329	LOCK WASHER		01
10	0503010330	KM 9 LOCKNUT		01
11	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503016518	RUEDA		01
02	0503012114	7.00 X 16 INNER TIRE		01
03	0503012113	PLY TIRE		01



Item	Code	Description	See page	QT
01	0531012640	AXLE CHAIN TIGHTENER		01
02	0531012678	4.5" X 0.9" X 0.2" SLEEVE		01
03	0502012853	GEAR		01
04	0503012882	BEARING		01
05	0503011945	503050 CLAMPING RING (FOR AXLE)		01
06	0511017302	FLAT WASHER		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TIGHTENER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0521010479	SLEEVE ARTICULATION		01
04	0503011336	1/2" HEX SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
001	0511053358	VALVE FIXING ASSEMBLY	16	01
002	0521051216	FIXER HYDRAULIC HOSE ASSEMBLY		01
003	0511053384	HYDRAULIC CYLINDER ASSEMBLY	17	01
004	0511054302	HOSE KIT	19	01
005	0521051213	HOSE KIT	20	01
006	0503018033	37 X R.7/8 UNF 90° JIC MALE CONNECTOR WITH ROTATING NUT		01
007	0501053834	MALE QUICK COUPLER	21	04
007A	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		04
007B	0503011882	MALE QUICK COUPLER CAP		04

VALVE FIXING ASSEMBLY

0511053358




Item	Code	Description	See page	QT
01	0571010596	SUPPORT VALVE 50/50		01
02	0503010371	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02
06	0503013791	DOUBLE MOTOR		01
07	0541018940	7/8 NF X R 1 BSPT X 55 NIPPLE		01
08	0551012463	1/2" BSPT X 3/4" UNF X 51 NIPPLE		02
09	0503015075	M10 SPRING WASHER		04
10	0501010984	FLAT WASHER		04
11	0503011051	M10 X 0.6" NUT		04
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0503012341	T 7/8" ADAPOR GIRAT NUT		02
14	0541012166	NIPPLE 3/4" UNF X 7/8"		01
15	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01



Item	Code	Description	See page	QT
01	0511066351	FLANGE CYLINDER HYDRAULIC FIXER		08
02	0503010834	1/2 X 1 BOLT		16
03	0503010019	1/2" SPRING WASHER		16
04	0511058411	HYDRAULIC CYLINDER	18	04
05	0521010546	1.2" X 5.7" COUPLING SHAFT		04
06	0501017779	32 X 60 X 4.75 FLAT WASHER		08
07	0503010523	1/4" X 2" COTTERPIN		04

HYDRAULIC CYLINDER


0511058411




Item	Code	Description	See page	QT
01	0511066774	2.5" X 28" CYLINDER CASE		01
02	0541017674	TURNBUCLE BODY		01
03	0503030385	CYLINDER PLUG N-002		02
04	0511064408	FORK		01
05	0503011094	3/8" X 2" BOLT		01
06	0503010025	3/8" SPRING WASHER		01
07	0503010026	3/8" NUT		01
08	0581010302	RING OF SUPPORT		01
09	0502012822	101.60 END CAP		01
10	0503011061	8-342 BACK-UP RING		02
11	0503010338	2-342 N 3006-9B O'RING		02
12	0503017936	RING		01
13	0503017938	RING GUIDE		01
14	0503017937	GASKET		01
15	0503010761	D-1750 SCRAPER RING		01
16	0581010837	PISTON		01
17	0503010817	1.1/4" SELF LOCKING NUT		01
18	0503015633	SELEMASTER SEALING		01
19	0503018029	2-217 O'RING		01

HOSE KIT


0511054302



Item	Code	Description	See page	QT
01	0501080760	3/8" X 500 TC-TC HOSE		04
02	0501080321	3/8" X 47" TR-TR HOSE ASSY		03
03	0501080348	3/8 X 1200 TR-TC HOSE		01
04	0501080436	3/8 X 1500 TR-TC HOSE		02
05	0501080714	3/8 X 1600 TR-TC HOSE		02
06	0521052275	HOSE		01
06A	0501081073	HOSE 1/2 X 4200 TC-TM		01
06B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
06C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
06D	0503018952	PLASTIC BOLT		06
07	0521052276	HOSE		01
07A	0501081073	HOSE 1/2 X 4200 TC-TM		01
07B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
07C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
07D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
001	0521052419	HOSE 1/2 X 4200 TR-TM GRAY / RED		01
002	0521056480	HOSE 1/2 X 5500 TC-TM GRAY / BLUE		01
003	0501080829	HOSE		04
004	0501080788	1/2" X 570 HOSE ASSY		03
005	0501080250	HOSE		04
006	0501080113	1/2 X600 HOSE TR-TC		01



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01

RIGHT GEAR BOX ASSY

0511050639



Item	Code	Description	See page	QT
01	0511050639	RIGHT GEAR BOX ASSY	22	01
01A	0501058212	SEMI MOUNTED RIGHT CHANGE		01
02	0503031805	11Z 1/2" GEAR		04
03	0503010302	501019 SEAL RING		04
04	0501048790	AXLE WITH RING	24	02
05	0503010002	1800 GREASE FITTING		02
06	0551018209	DRIVING AXLE		01
07	0521018259	DRIVEN AXLE		01
08	0551018210	DRIVEN AXLE		01
09	0551018211	INTERM SHAFT		01
10	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	28	01
11	0503030303	SUPPORT WASHER		05
12	0501056443	GEAR HOUSING BEARING	25	02
13	0501056271	GEARBOX CLOSED BEARING	27	05
14	0503010256	3/8" X 3/4" BOLT		01
15	0503030275	AGRICULTURAL BEARING		01
16	0521018630	1.4" X SQUARE 0.8" WASHER		03
17	0511061822	25Z P0.5" GEAR SQUARE HOL		01
18	0502040868	GEAR CONE REPLACEMENT		04
19	0503012389	1/2 BALL		04
20	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04
21	0503010060	1/2" NUT		04
22	0503010395	1/2" X 1-1/4" BOLT		04
23	0521062072	33Z GEAR		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0511067501	26Z GEAR		01
26	0503010292	0.2" X 1.6" SPRING PIN		07
27	0503012204	40-1 CHAIN X 82 LINK + RED		02
28	0503012713	40-1 CHAIN X 45 LINK + MEN		01
29	0501054655	CHAIN TENSIONER ASSY	29	02
30	0501010984	FLAT WASHER		01




RIGHT GEAR BOX ASSY

0511050639

Item	Code	Description	See page	QT
31	0503010025	3/8" SPRING WASHER		01

LEFT GEAR BOX ASSY

0511050640




Item	Code	Description	See page	QT
01	0511050640	LEFT GEAR BOX ASSY	23	01
01A	0501058213	LH GEAR BOX	30	01
02	0503031805	11Z 1/2" GEAR		04
03	0503010302	501019 SEAL RING		04
04	0501048790	AXLE WITH RING	24	02
05	0503010002	1800 GREASE FITTING		02
06	0551018209	DRIVING AXLE		01
07	0521018259	DRIVEN AXLE		01
08	0551018210	DRIVEN AXLE		01
09	0551018211	INTERM SHAFT		01
10	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	28	01
11	0503030303	SUPPORT WASHER		05
12	0501056443	GEAR HOUSING BEARING	25	02
13	0501056271	GEARBOX CLOSED BEARING	27	05
14	0503010256	3/8" X 3/4" BOLT		01
15	0503030275	AGRICULTURAL BEARING		01
16	0521018630	1.4" X SQUARE 0.8" WASHER		03
17	0511061822	25Z P0.5" GEAR SQUARE HOL		01
18	0502040868	GEAR CONE REPLACEMENT		04
19	0503012389	1/2 BALL		04
20	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04
21	0503010060	1/2" NUT		04
22	0503010395	1/2" X 1-1/4" BOLT		04
23	0521062072	33Z GEAR		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0511067501	26Z GEAR		01
26	0503010292	0.2" X 1.6" SPRING PIN		07
27	0503012204	40-1 CHAIN X 82 LINK + RED		02
28	0503012713	40-1 CHAIN X 45 LINK + MEN		01
29	0501054655	CHAIN TENSIONER ASSY	29	02
30	0501010984	FLAT WASHER		01




LEFT GEAR BOX ASSY

0511050640


Item	Code	Description	See page	QT
31	0503010025	3/8" SPRING WASHER		01



Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	26	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01

GEARBOX CLOSED BEARING


0501056271




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0511050392	BOX SUPPORT RIGHT FERTILIZER		01
02	0511050391	FERTILIZER LEFT BOX SUPPORT		01
03	0503034396	FERTILIZER SIDE COVER		12
04	0503010362	1/8 X 1.1/4 COTTERPIN		12
05	0503010849	3/8" X 1-1/2" BOLT		12
06	0501010984	FLAT WASHER		12
07	0503010025	3/8" SPRING WASHER		12
08	0503010026	3/8" NUT		12
09	0503060663	FERTILIZER HOPPER WITH 4 TRUNNELS		03
10	0571013223	ANGLE BAR		02
11	0571013224	STRINGER FIXING CASH FERTILIZER		02
12	0503010849	3/8" X 1-1/2" BOLT		08
13	0501010984	FLAT WASHER		16
14	0503010025	3/8" SPRING WASHER		08
15	0503010026	3/8" NUT		08



Item	Code	Description	See page	QT
01	0511050891	BOX SUPPORT RIGHT FERTILIZER		01
02	0511050892	FERTILIZER LEFT BOX SUPPORT		01
03	0503034396	FERTILIZER SIDE COVER		14
04	0503010362	1/8 X 1.1/4 COTTERPIN		14
05	0503010849	3/8" X 1-1/2" BOLT		08
06	0501010984	FLAT WASHER		08
07	0503010025	3/8" SPRING WASHER		08
08	0503010026	3/8" NUT		08
09	0503060664	FERTILIZER HOPPER WITH 5 TRUNNELS		02
10	0503060663	FERTILIZER HOPPER WITH 4 TRUNNELS		01
11	0571013223	ANGLE BAR		02
12	0571013225	STRINGER FIXING CASH FERTILIZER		02
13	0503010849	3/8" X 1-1/2" BOLT		08
14	0501010984	FLAT WASHER		16
15	0503010025	3/8" SPRING WASHER		08
16	0503010026	3/8" NUT		08

PLATFORM SET


0511053353




Item	Code	Description	See page	QT
01	0521061861	PLATFORM FIXER	02	
02	0521062061	CENTRAL ARTICULACION	01	
03	0521062062	CENTRAL ARTICULACION	01	
04	0503010849	3/8" X 1-1/2" BOLT	08	
05	0501010984	FLAT WASHER	16	
06	0503010025	3/8" SPRING WASHER	08	
07	0503010026	3/8" NUT	08	
08	0511069718	PLATFORM RIGHT	01	
09	0521062324	PLATFORM LEFT	01	
10	0521010549	COUPLING SHAFT	04	
11	0503010300	5/32" X 1" COTTERPIN	04	
12	0503011333	COVER FIXER	02	
13	0503010274	5/32"X 2" COTTERPIN	02	
14	0551019115	LOCKING PLATFORM FIXATION	02	
15	0501010096	3/8" X 2" BOLT	02	
16	0501010984	FLAT WASHER	02	
17	0503013357	3/8" SELF-ADJUSTING NUT	02	
18	0521061676	PLATFORM PROLONG	02	
19	0511069664	PLATFORM EXTENSION LOCK	02	
20	0503010257	1/8" X 1" COTTERPIN	02	
21	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
22	0502012739	PLATFORM LEFT FIXER SUPPORT	01	
23	0503014007	1/2" X 1-1/4" BOLT	04	
24	0503010019	1/2" SPRING WASHER	04	
25	0503010060	1/2" NUT	04	

PLATFORM SET


0511053339




Item	Code	Description	See page	QT
01	0521061861	PLATFORM FIXER	02	
02	0521062061	CENTRAL ARTICULACION	01	
03	0521062062	CENTRAL ARTICULACION	01	
04	0503010849	3/8" X 1-1/2" BOLT	08	
05	0501010984	FLAT WASHER	16	
06	0503010025	3/8" SPRING WASHER	08	
07	0503010026	3/8" NUT	08	
08	0521062091	PLATFORM LEFT COP FLEX 13	01	
09	0521062092	PLATFORM RIGHT	01	
10	0521010549	COUPLING SHAFT	04	
11	0503010300	5/32" X 1" COTTERPIN	04	
12	0503011333	COVER FIXER	02	
13	0503010274	5/32"X 2" COTTERPIN	02	
14	0551019115	LOCKING PLATFORM FIXATION	02	
15	0501010096	3/8" X 2" BOLT	02	
16	0501010984	FLAT WASHER	02	
17	0503013357	3/8" SELF-ADJUSTING NUT	02	
18	0521061676	PLATFORM PROLONG	02	
19	0511069664	PLATFORM EXTENSION LOCK	02	
20	0503010257	1/8" X 1" COTTERPIN	02	
21	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
22	0502012739	PLATFORM LEFT FIXER SUPPORT	01	
23	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	04	
24	0503010019	1/2" SPRING WASHER	04	
25	0503010060	1/2" NUT	04	




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		04
02	0503010237	3/8" X 1" BOLT		08
03	0503010025	3/8" SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0511069636	LADDER		02
06	0503011179	3/8" X 2-1/4" BOLT		04
07	0501010984	FLAT WASHER		04
08	0503013357	3/8" SELF-ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521063948	JOINT HANDRAIL SET		02
02	0521018290	RANDRAIL HOLDER		02
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2" NUT		04



Item	Code	Description	See page	QT
01	0511069660	HANDRAIL		02
02	0521018290	RANDRAIL HOLDER		02
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2" NUT		04



Item	Code	Description	See page	QT
01	0521061171	HANDRAIL		02
02	0521018290	RANDRAIL HOLDER		02
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0511065449	ROW MARKER ARM SUPPORT		02
02	0501018059	3/4" X 2-1/4" BOLT		08
03	0503011255	3/4" LOCK NUT		08
04	0501069470	ROW MARKER ARM		02
05	0503011067	5/8" X 2-1/2" BOLT		04
06	0521010479	SLEEVE ARTICULATION		04
07	0503012795	5/8" HEX SELF ADJUSTING NUT		04
08	0511058449	HYDRAULIC CYLINDER	46	02
09	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
10	0503010571	1/4" X 1.1/2 COTTERPIN		02
11	0511015779	1" X 4.2" AXLE		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
14	0501068994	8,30 X 78 LOCK PIN		02
15	0503030168	HITCH PIN CLIP		02
16	0501069643	890 TURNBUCKLE		02
17	0503010962	5/8" X 1-1/4" BOLT		04
18	0501054649	HBM SEQUENTIAL VALVE		01
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
20	0501010984	FLAT WASHER		02
21	0503010025	3/8" SPRING WASHER		02
22	0521052279	HYDRAULIC MARKER HOSE SET		01
22A	0501080635	3/8" X 19" TR-TR HOSE		02
22B	0501080105	3/8 X 700 TR-TR HOSE		02
22C	0501080750	3/8" X 149" TC-TC HOSE ASSY		04
22D	0521052277	HOSE 3/8 X 4212 TC-TM PURPLE / RED		01
22E	0521052278	HOSE 3/8 X 4212 TC-TM PURPLE / BLUE		01
23	0541012165	3/4" NIPPLE		04
24	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		04
25	0501053834	MALE QUICK COUPLER	21	02
26	0503011070	BEATER		02

**MARKER HIDRAULICO**

0511054295

Item	Code	Description	See page	QT
27	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
28	0503010019	1/2" SPRING WASHER		02
29	0501012140	FLAT WASHER		04
30	0501050633	ROW MARKER DISK ASSEMBLY	44	01




Item	Code	Description	See page	QT
01	0511065449	ROW MARKER ARM SUPPORT		02
02	0501010098	3/4" UNC BOLT		08
03	0503011255	3/4" LOCK NUT		08
04	0511061811	ROW MARKER ARM		02
05	0503011067	5/8" X 2-1/2" BOLT		04
06	0521010479	SLEEVE ARTICULATION		04
07	0503012795	5/8" HEX SELF ADJUSTING NUT		04
08	0511058449	HYDRAULIC CYLINDER	46	02
09	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
10	0503010571	1/4" X 1.1/2 COTTERPIN		02
11	0511015779	1" X 4.2" AXLE		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
14	0501068994	8,30 X 78 LOCK PIN		02
15	0503030168	HITCH PIN CLIP		02
16	0501066949	1235 TURNBUCKLE		02
17	0503010962	5/8" X 1-1/4" BOLT		04
18	0501054649	HBM SEQUENTIAL VALVE		01
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
20	0501010984	FLAT WASHER		02
21	0503010025	3/8" SPRING WASHER		02
22	0511057082	HOSE KIT SYSTEM HYDRAULIC		01
22A	0501080635	3/8" X 19" TR-TR HOSE		02
22B	0501080124	HOSE 3/8 X 900 TR-TC		04
22C	0501080105	3/8 X 700 TR-TR HOSE		02
22D	0501080675	3/8 X 1000 TC-TC 180G HOSE		02
22E	0501080301	HOSE 3/8 X 1300 TC-TC		02
22F	0501080878	3/8 X 4200 TC-TM HOSE ASSY		02
23	0541012165	3/4" NIPPLE		04
24	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		04
25	0501053834	MALE QUICK COUPLER	21	02



MARKER HIDRAULICO

0511053287

Item	Code	Description	See page	QT
26	0503011070	BEATER		02
27	0503010019	1/2" SPRING WASHER		02
28	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
29	0501012140	FLAT WASHER		04
30	0501050633	ROW MARKER DISK ASSEMBLY	44	01



Item	Code	Description	See page	QT
01	0511065449	ROW MARKER ARM SUPPORT		02
02	0501010098	3/4" UNC BOLT		08
03	0503011255	3/4" LOCK NUT		08
04	0501069470	ROW MARKER ARM		02
05	0503011067	5/8" X 2-1/2" BOLT		04
06	0521010479	SLEEVE ARTICULATION		04
07	0503012795	5/8" HEX SELF ADJUSTING NUT		04
08	0511058449	HYDRAULIC CYLINDER	46	02
09	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
10	0503010571	1/4" X 1.1/2 COTTERPIN		02
11	0511015779	1" X 4.2" AXLE		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
14	0501068994	8,30 X 78 LOCK PIN		02
15	0503030168	HITCH PIN CLIP		02
16	0501069643	890 TURNBUCKLE		02
17	0503010962	5/8" X 1-1/4" BOLT		04
18	0501054649	HBM SEQUENTIAL VALVE		01
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
20	0501010984	FLAT WASHER		02
21	0503010025	3/8" SPRING WASHER		02
22	0511057082	HOSE KIT SYSTEM HYDRAULIC		01
22A	0501080635	3/8" X 19" TR-TR HOSE		02
22B	0501080124	HOSE 3/8 X 900 TR-TC		04
22C	0501080105	3/8 X 700 TR-TR HOSE		02
22D	0501080675	3/8 X 1000 TC-TC 180G HOSE		02
22E	0501080301	HOSE 3/8 X 1300 TC-TC		02
22F	0501080878	3/8 X 4200 TC-TM HOSE ASSY		02
23	0541012165	3/4" NIPPLE		04
24	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		04
25	0501053834	MALE QUICK COUPLER	21	02


**MARKER HIDRAULICO**

0511053306


Item	Code	Description	See page	QT
26	0503011070	BEATER		02
27	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
28	0503010019	1/2" SPRING WASHER		02
29	0501012140	FLAT WASHER		04
30	0501050633	ROW MARKER DISK ASSEMBLY	44	01

MARKER CYLINDER

0909094616



Item	Code	Description	See page	QT
01	0511065449	ROW MARKER ARM SUPPORT		02
02	0501018059	3/4" X 2-1/4" BOLT		08
03	0503010023	3/4" SPRING WASHER		08
04	0503011255	3/4" LOCK NUT		08
05	0501069470	ROW MARKER ARM		02
06	0503011067	5/8" X 2-1/2" BOLT		04
07	0521010479	SLEEVE ARTICULATION		04
08	0501012140	FLAT WASHER		04
09	0503012795	5/8" HEX SELF ADJUSTING NUT		04
10	0511040203	1.5" X 2.5" X 19" X 9" HYDRAULIC CYLINDER	47	02
11	0521010574	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010571	1/4" X 1.1/2 COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501069643	890 TURNBUCKLE		02
19	0503010962	5/8" X 1-1/4" BOLT		04
20	0503011070	BEATER		02
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0501050633	ROW MARKER DISK ASSEMBLY	44	02
24	0521013164	EXTENSOR		02
25	0501011310	FIXER LOCK		08
26	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		08
27	0503010060	1/2" NUT		08




Item	Code	Description	See page	07	09	10	11	13	15	L
01	0501054649	HBM SEQUENTIAL VALVE		01	01	01	01	01	01	
01A	0503060132	VDFS-002 T SEQUENCCEL VALVE		01	01	01	01	01	01	
01B	0501010617	3/4" NIPPLE		02	02	02	02	02	02	
01C	0503010190	2-114 N 3006-9B O'RING		02	02	02	02	02	02	
01D	0501012109	3/4" X 9/16" NIPPLE FITTING		04	04	04	04	04	04	
01E	0503011036	2-111 N 3006-9B O'RING		06	06	06	06	06	06	
01F	0531019339	9/16" UNF X 12 PUMP		02	02	02	02	02	02	
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02	02	02	02	02	02	
03	0501010984	FLAT WASHER		02	02	02	02	02	02	
04	0503010025	3/8" SPRING WASHER		02	02	02	02	02	02	
05	0541012165	3/4" NIPPLE		04	04	04	04	04	04	
06	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		04	04	04	04	04	04	
07	0501080635	3/8" X 19" TR-TR HOSE		02	02	02	02	02	02	
08	0501080105	3/8 X 700 TR-TR HOSE		02	02	02	02	02	02	
09	0501080750	3/8" X 149" TC-TC HOSE ASSY		00	04	00	00	00	00	
10	0501080878	3/8 X 4200 TC-TM HOSE ASSY		02	02	02	02	02	02	
11	0501053834	MALE QUICK COUPLER	21	02	02	02	02	02	02	
11A	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		02	02	02	02	02	02	
11B	0503011882	MALE QUICK COUPLER CAP		02	02	02	02	02	02	
12	0561017277	OIL CONDUCTOR FIXER PLATE		02	02	02	02	02	02	
13	0521010718	5/8" U BOLT		02	02	02	02	02	02	
14	0501012140	FLAT WASHER		04	04	04	04	04	04	
15	0503010027	5/8" SPRING WASHER		04	04	04	04	04	04	
16	0503010013	5/8" NUT		04	04	04	04	04	04	
17	0502012702	BODY SUPPORT CLAMP		04	04	04	04	04	04	
18	0503011103	7/16" X 2-1/2" BOLT		04	04	04	04	04	04	
19	0503010180	7/16" SPRING WASHER		04	04	04	04	04	04	
20	0503010244	7/16" NUT		04	04	04	04	04	04	
21	0501081646	TC-TC HOSE ASSY		04	00	00	00	00	00	
22	0501081644	HOSE 3/8 X 3350 TC-TC USAP		00	04	00	00	00	00	
23	0501080750	3/8" X 149" TC-TC HOSE ASSY		00	00	04	00	00	00	




Item	Code	Description	See page	07	09	10	11	13	15	L
24	0501081639	HOSE		00	00	00	04	00	00	
25	0501080611	3/8" X 17.8" TR-TR HOSE ASSY		00	00	00	00	04	00	
26	0501080753	HOSE 3/8 X 4700 TC-TC		00	00	00	00	00	04	

ROW MARKER DISK ASSEMBLY


0501050633




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	45	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01



Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01



Item	Code	Description	See page	QT
01	0511062810	2.5" X 15" CYLINDER CASE		01
02	0501065662	HYDRAULIC CYLINDER TURNBUCKLE		01
03	0502010471	MOBILE COVER		01
04	0502010780	RING SUPPORT		01
05	0503010163	D-1500 SCRAPER RING		01
06	0503010989	1870-1500-375-B GASKET		01
07	0503010970	W1-1650-500 PK O'RING G.E		01
08	0503011058	8-330 BACK-UP RING		01
09	0503010161	2-330 N 3006 9B O'RING		01
10	0503010285	2-222 N 3006-9B O'RING		01
11	0502010783	1.5" X 2.5" PISTON		01
12	0503010160	2500 2000 GASKET		02
13	0503010973	W2-2500-500 PK O'RING G.E		01
14	0503010063	1" SELF-ALIGNING NUT		01
15	0503030384	CON PLUG N-001		02
16	0501032666	HYDRAULIC CYLINDER REPAIR KIT		01

JACK ASSEMBLY


0511054971




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01

MOTOR SHAFT ASSEMBLY


0511054292




Item	Code	Description	See page	QT
01	0561017269	MOTOR AXLE BEARING SUPPORT		04
02	0503011082	C1/2" X 1.3/4" SCREW		08
03	0511017302	FLAT WASHER		16
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0501110639	BEARING		08
07	0503010300	5/32" X 1" COTTERPIN		08
08	0503011099	GREASE FITTING		08
09	0571013539	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	50	01
15	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	52	01
16	0511051434	TRANSMISSION ACTUATOR	51	04
17	0503012958	2050 CHAIN X 42 LINK + REDUCTION		04



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

MOTOR SHAFT ASSEMBLY


0511053380




Item	Code	Description	See page	QT
01	0561017269	MOTOR AXLE BEARING SUPPORT		04
02	0503011082	C1/2" X 1.3/4" SCREW		08
03	0511017302	FLAT WASHER		16
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0501110639	BEARING		08
07	0503010300	5/32" X 1" COTTERPIN		08
08	0503011099	GREASE FITTING		08
09	0561016876	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	50	01
15	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	52	01
16	0511051434	TRANSMISSION ACTUATOR	51	04
17	0503012958	2050 CHAIN X 42 LINK + REDUCTION		04

MOTOR SHAFT ASSEMBLY


0511053341



Item	Code	Description	See page	QT
01	0561017269	MOTOR AXLE BEARING SUPPORT		04
02	0503011082	C1/2" X 1.3/4" SCREW		08
03	0511017302	FLAT WASHER		16
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0501110639	BEARING		08
07	0503010300	5/32" X 1" COTTERPIN		08
08	0503011099	GREASE FITTING		08
09	0561016795	2775 MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	50	01
15	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	52	01
16	0511051434	TRANSMISSION ACTUATOR	51	04
17	0503012958	2050 CHAIN X 42 LINK + REDUCTION		04




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0511031562	BAG WITH MANUAL		01
03	0503010267	NYLON CLAMP		01
04	0503010363	5/16" X 1" BOLT		01
05	0501010694	FLAT WASHER		01
06	0503010179	LOCK WASHER		01
07	0503010337	5/16" NUT		01



Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0511031563	BAG WITH MANUAL		01
03	0503010267	NYLON CLAMP		01
04	0503010363	5/16" X 1" BOLT		01
05	0501010694	FLAT WASHER		01
06	0503010179	LOCK WASHER		01
07	0503010337	5/16" NUT		01

SQUARE AXLE ASSEMBLY


0511053342




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	27	02
02	0501056444	BEARING WITH ROLLING	26	02
03	0503011953	5/16" X 1" BOLT		08
04	0501010694	FLAT WASHER		08
05	0503010179	LOCK WASHER		08
06	0503010337	5/16" NUT		08
07	0511014218	3/4" X 28.7" SQUARE SHAFT		02
08	0521010691	AXLE FASTENER		04
09	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		04
10	0511017303	FLAT WASHER		04
11	0503010143	1/4" SPRING WASHER		04
12	0503010144	1/4" NUT		04
13	0503030303	SUPPORT WASHER		04
14	0521061852	LEVER RATCHET		02
15	0521061847	AXLE ADRIVING ASSY		02
16	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
17	0521061849	DISASSEMBLE LEVER		02
18	0503010140	1/8" X 3/4" COTTERPIN		04
19	0571012792	LOWER LEVER		02
20	0503011082	C1/2" X 1.3/4" SCREW		02
21	0511017302	FLAT WASHER		04
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2" NUT		02
24	0561016797	SLEEVE UNION LEVER		02
25	0501010096	3/8" X 2" BOLT		02
26	0501010984	FLAT WASHER		04
27	0503010026	3/8" NUT		04

SQUARE SHAFT SET

0511053434



Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	27	02
02	0501056444	BEARING WITH ROLLING	26	02
03	0503011953	5/16" X 1" BOLT		08
04	0501010694	FLAT WASHER		08
05	0503010179	LOCK WASHER		08
06	0503010337	5/16" NUT		08
07	0501018653	3/4" X 46" SQUARE SHAFT		02
08	0521010691	AXLE FASTENER		04
09	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		04
10	0511017303	FLAT WASHER		04
11	0503010143	1/4" SPRING WASHER		04
12	0503010144	1/4" NUT		04
13	0503030303	SUPPORT WASHER		04
14	0521061852	LEVER RATCHET		02
15	0521061847	AXLE ADRIVING ASSY		02
16	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
17	0521061849	DISASSEMBLE LEVER		02
18	0503010140	1/8" X 3/4" COTTERPIN		04
19	0571012792	LOWER LEVER		02
20	0503011082	C1/2" X 1.3/4" SCREW		02
21	0511017302	FLAT WASHER		04
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2" NUT		02
24	0561016797	SLEEVE UNION LEVER		02
25	0501010096	3/8" X 2" BOLT		02
26	0501010984	FLAT WASHER		04
27	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0511057729	FRONT SEED SHORT	68	01
02	0521051622	FRONT SEED SHORT ROW	60	01
03	0511057730	FRONT SEED LONG	69	01
04	0521051621	FRONT SEED LONG ROW	61	01
05	0511057496	LEFT REAR ROW SEED SUP PP PM 400	71	01
06	0511057495	RIGHT REAR ROW SEED SUP PP PM 400	72	01
07	0521050012	RIGHT REAR ROW SEED P.P PM400/CSU	73	01
08	0521050013	LEFT REAR ROW SEED P.P PM400/CSU	74	01
09	0511057108	RIGHT REAR SEED ROW PRECISION PLANTING CSU 3	75	01
10	0511057115	REAR LEFT SEED LINE PRECISION PLANTING CSU 3	76	01
11	0511057209	ROW RIGHT REAR SEED	77	01
12	0511057210	ROW LEFT REAR SEED	78	01
13	0501054481	RIGHT ARM DEPTH CONTROL WITH WHEEL	85	01
14	0501054482	DEPTH CONTROL LEFT ARM WITH TIRE	86	01
15	0511053023	LONG FERTILIZER LINE	87	01
16	0511053024	FERTILIZER SHORT LINE	88	01
17	0511051818	DISC CUT 18 SEMI MOUNTED	91	01
18	0511051819	DC 20 SEMI MOUNTED	92	01
19	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	89	01
20	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	90	01
21	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
22	0501110723	SCARIFIER ROD		01
23	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	84	01
24	0511057154	DDD RITGH SUPREMA PRECISION PLANTING	95	01
25	0511065909	DEPTH FIXER BASE		01
26	0503010547	1/2" X 4" BOLT		02
27	0503010019	1/2" SPRING WASHER		02
28	0503010060	1/2" NUT		02
29	0503031050	CURVED CONDUCTOR		01
30	0503010246	CLAMP		02

Item	Code	Description	See page	QT
31	0571019714	AIR CONDUCTOR		01
33	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		01
34	0571019716	ADAPTER		02
35	0531016195	4" X 94" AIR CONDUCTOR		01
36	0521019552	5" X 188" AIR CONDUCTOR		01
37	0503011372	102 TO 121 CLAMP		01
38	0503012724	121 TO 140 CLAMP		01
39	0521050525	FIXER FERTILIZER CONDUCTOR	97	02
40	0503062417	KIT CORN DISTRIBUTION		01
41	0501110714	INNER SOCKET FASTENER		01
42	0503030483	FERTILIZER SOCKET		01
43	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
44	0501010984	FLAT WASHER		04
45	0503010025	3/8" SPRING WASHER		02
46	0503010026	3/8" NUT		02
47	0531013600	PRESS ADJUSTMENT LEVER		01
48	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
49	0503010905	1/2" X 2-1/4" BOLT		02
50	0503010019	1/2" SPRING WASHER		04
51	0503010060	1/2" NUT		04
52	0521044460	SYSTEM DEPTH / COMPACTOR	98	01
53	0521051424	WHEEL SYSTEM DEPTH/COMPACTOR QUICK ADJUSTMENT	106	01
54	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	110	01
55	0521044269	PRESS WHEELS/DEPTH ASSY	118	01
56	0521042327	DEPTH CONTROL & PRESS WHEEL ASSY	121	01
57	0521045198	PRESS WHEELS		01
58	0521046501	DEPTH CONTROL AND PRESS WHEEL WITH FAST ADJUSTING	126	01
59	0521044538	DEPTH WHIT REGULACION ANGLE COMPACT CONTROL	129	01

FRONT SEED SHORT ROW

0521051622



Item	Code	Description	See page	QT
001	0521065914	FRAME ASSY		01
002	0571012443	COUPLING SHAFT		01
003	0571012442	COUPLING SHAFT		03
004	0571012441	TRANSMISSION AXLE		01
005	0511052393	BEARING FOLLOWER ROW ASSY	62	01
006	0571012449	CONTROL AXLE		01
007	0571012448	LOCK SLEEVE AXLE REGULATION		01
008	0521068100	SUPPORT FRONT LINE SHORT SEED		01
009	0502012784	DRIVER PIVOT		02
010	1902012814	BODY LOCK REGULATOR LEVER REGULATOR SEED		01
011	0502012785	SEED ROW ADJUSTMENT LEVER ASSY		01
012	0503017857	BOLT 5/8 UNF 4		04
013	0503010811	5/8" UNF SELF ADJUSTING NUT		04
014	0502012789	FIXER SUPPORT FERTILIZER ROW		01
015	0503016501	40-1 X 49 CHAIN LINK + MENDING		01
016	0511050609	BEARING WITH 17Z GEAR ASSY	63	01
017	0511055260	SEED ROW CHAIN TENSIONER	64	01
018	0503010002	1800 GREASE FITTING		04
019	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
020	0503012412	5/8 UNC SELF LOCKING NUT		04
021	0503030024	1.7" X 10.2" X 0.2" EXTENSION SPRING		02
022	0503030168	HITCH PIN CLIP		02
023	0503010131	3/16" X 1-1/2" COTTERPIN		03
024	0511054635	BEARING AXLE BODY	65	02
025	0503011953	5/16" X 1" BOLT		08
026	0501010694	FLAT WASHER		08
027	0503010179	LOCK WASHER		08
028	0503010337	5/16" NUT		08
029	0511057159	TRANSMISSION BOX SEED LINE	66	01
030	0503011378	M6X1X16 C S 8.8 ZN BOLT		02
031	0503015110	M06 SPRING WASHER		02


**FRONT SEED SHORT ROW**

0521051622

Item	Code	Description	See page	QT
032	0502012782	17Z GEAR WITH HEX HOLE		01
033	0581014435	SLEEVE ARM LINE SEED		08
034	0511057625	ROW SEED BEARING	67	01
035	0503032984	HOOD HEX AXLE ROW		01
036	0503013100	NYLON CLAMP		01
037	0581015124	LIMITER COURSE		01

FRONT SEED LONG ROW

0521051621




Item	Code	Description	See page	QT
01	0521065914	FRAME ASSY		01
02	0571012443	COUPLING SHAFT		01
03	0571012442	COUPLING SHAFT		03
04	0571012441	TRANSMISSION AXLE		01
05	0511052393	BEARING FOLLOWER ROW ASSY	62	01
06	0571012449	CONTROL AXLE		01
07	0571012448	LOCK SLEEVE AXLE REGULATION		01
08	0521068102	LONG SEED LINE FRONT SUPPORT		01
09	0502012784	DRIVER PIVOT		02
10	1902012814	BODY LOCK REGULATOR LEVER REGULATOR SEED		01
11	0502012785	SEED ROW ADJUSTMENT LEVER ASSY		01
12	0503017857	BOLT 5/8 UNF 4		04
13	0503010811	5/8" UNF SELF ADJUSTING NUT		04
14	0502012789	FIXER SUPPORT FERTILIZER ROW		01
15	0503012142	40-1 CHAIN X 61 LINK + MENDING		01
16	0511050609	BEARING WITH 17Z GEAR ASSY	63	01
17	0511055260	SEED ROW CHAIN TENSIONER	64	01
18	0503010002	1800 GREASE FITTING		04
19	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
20	0503012412	5/8 UNC SELF LOCKING NUT		04
21	0503030024	1.7" X10.2" X 0.2" EXTENSION SPRING		02
22	0503030168	HITCH PIN CLIP		02
23	0503010131	3/16" X 1-1/2" COTTERPIN		03
24	0511054635	BEARING AXLE BODY	65	02
25	0503011953	5/16" X 1" BOLT		08
26	0501010694	FLAT WASHER		08
27	0503010179	LOCK WASHER		08
28	0503010337	5/16" NUT		08
29	0511057159	TRANSMISSION BOX SEED LINE	66	01
30	0503011378	M6X1X16 C S 8.8 ZN BOLT		02
31	0503015110	M06 SPRING WASHER		02


**FRONT SEED LONG ROW**

0521051621


Item	Code	Description	See page	QT
32	0502012782	17Z GEAR WITH HEX HOLE		01
33	0581014435	SLEEVE ARM LINE SEED		08
34	0511057625	ROW SEED BEARING	67	01
35	0503032984	HOOD HEX AXLE ROW		01
36	0503013100	NYLON CLAMP		01
37	0581015124	LIMITER COURSE		01




Item	Code	Description	See page	QT
01	0521063532	BEARING FOLLOWER ROW ASSY		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0571012450	COP FLEX AXLE		01
05	0571012459	COP FLEX AXLE		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		02
07	0503015356	SPRING PIN		01
08	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511050617	FRONT SEED ROW BEARING		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0502012819	17Z GEAR WITH HEX HOLE		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0502012718	BEARIN BODY		01
02	0503012882	BEARING		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	BOX TRANSMISSION COVER		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01
17	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0511057156	BEARING LINE SEMI MOUNTED		01
02	0571018731	HEX AXLE		01
03	0571017900	5/8" X 77" HEX AXLE		01
04	0501056296	UNIVERSAL JOINT		01
05	0503011855	0.2" X 1.8" SPRING PIN		03
06	0503013958	1/4" X 1" BOLT		02
07	0561014778	HEX UNIVERSAL JOINT		01

FRONT SEED SHORT

0511057729




Item	Code	Description	See page	QT
001	0502012784	DRIVER PIVOT		02
002	0503010002	1800 GREASE FITTING		04
003	0531015151	0.6" X 1" X 2.4" SLEEVE		08
004	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
005	0531015184	FLAT WASHER		08
006	0503012412	5/8 UNC SELF LOCKING NUT		04
007	0571012449	CONTROL AXLE		01
008	0503030024	1.7" X10.2" X 0.2" EXTENSION SPRING		02
009	0503030168	HITCH PIN CLIP		02
010	0571012448	LOCK SLEEVE AXLE REGULATION		01
011	0503010131	3/16" X 1-1/2" COTTERPIN		01
012	0521065914	FRAME ASSY		01
013	0521065677	LIMITER		01
014	0571012443	COUPLING SHAFT		01
015	0571012442	COUPLING SHAFT		03
016	0503010131	3/16" X 1-1/2" COTTERPIN		02
017	0502012785	SEED ROW ADJUSTMENT LEVER ASSY		01
018	0502012814	BOX LEVER LOCK		01
019	0511054635	BEARING AXLE BODY	65	02
019A	0502012718	BEARIN BODY		01
019B	0503012882	BEARING		01
019C	0503017011	SEAL RING		01
019D	0503011945	503050 CLAMPING RING (FOR AXLE)		01
020	0503011953	5/16" X 1" BOLT		04
021	0501010694	FLAT WASHER		04
022	0503010179	LOCK WASHER		04
023	0503010337	5/16" NUT		04
024	0571012441	TRANSMISSION AXLE		01
025	0511054884	TRANSMISSION BOX	70	01
026	0503011378	M6X1X16 C S 8.8 ZN BOLT		02
027	0503015110	M06 SPRING WASHER		02

FRONT SEED SHORT

0511057729

Item	Code	Description	See page	QT
028	0503011855	0.2" X 1.8" SPRING PIN		01
029	0511052393	BEARING FOLLOWER ROW ASSY	62	01
029A	0521063532	BEARING FOLLOWER ROW ASSY		01
029B	0503011410	ROLLER BEARING		01
029C	0503011105	SEAL RING		01
029D	0571012450	COP FLEX AXLE		01
029E	0571012459	COP FLEX AXLE		01
029F	0503010406	501025 CLAMPING RING (FOR AXLE)		02
029G	0503015356	SPRING PIN		01
029H	0503010691	1/4" GREASE FITTING		01
030	0503032984	HOOD HEX AXLE ROW		01
031	0503013100	NYLON CLAMP		01
032	0511057625	ROW SEED BEARING	67	01
032A	0511057156	BEARING LINE SEMI MOUNTED		01
032AA	0521065913	ROW SEED BEARING		01
032AB	0503011410	ROLLER BEARING		02
032AC	0503011105	SEAL RING		01
032AD	0503010406	501025 CLAMPING RING (FOR AXLE)		02
032AE	0571017815	BEARING AXLE BODY		01
032AF	0503017008	SEAL RING		01
032B	0571018731	HEX AXLE		01
032C	0571017900	5/8" X 77" HEX AXLE		01
032D	0561014778	HEX UNIVERSAL JOINT		01
032E	0501056296	UNIVERSAL JOINT		01
032F	0503011855	0.2" X 1.8" SPRING PIN		03
032G	0503013958	1/4" X 1" BOLT		02
033	0503011953	5/16" X 1" BOLT		04
034	0501010694	FLAT WASHER		04
035	0503010179	LOCK WASHER		04
036	0503010337	5/16" NUT		04
037	0521063525	SHORT SEED ROW FRONT		01
038	0511050609	BEARING WITH 17Z GEAR ASSY	63	01
038A	0511050617	FRONT SEED ROW BEARING		01
038AA	0502011697	BEARING OF THE GEAR BOX		01
038AB	0503011410	ROLLER BEARING		01
038AC	0503011105	SEAL RING		01
038AD	0503011953	5/16" X 1" BOLT		02
038AE	0501010694	FLAT WASHER		02
038AF	0503010179	LOCK WASHER		02
038AG	0503010337	5/16" NUT		02
038B	0503010406	501025 CLAMPING RING (FOR AXLE)		01
038C	0502012819	17Z GEAR WITH HEX HOLE		01
039	0503011953	5/16" X 1" BOLT		02
040	0501010694	FLAT WASHER		02
041	0503010179	LOCK WASHER		02
042	0503010337	5/16" NUT		02
043	1902010175	HITCH CLAMP		01
044	0503010811	5/8" UNF SELF ADJUSTING NUT		02
045	0531019479	AXLE CHAIN GEAR		01
046	0541016454	PULLEY		01
047	0503011828	FLAT WASHER		01
048	0503010019	1/2" SPRING WASHER		01
049	0503010060	1/2" NUT		01
050	0503016501	40-1 X 49 CHAIN LINK + MENDING		01
051	0501012140	FLAT WASHER		02
052	0502012782	17Z GEAR WITH HEX HOLE		01
053	0571019706	HEX AXLE		01
054	0503016460	5/8" X 4.1/2" BOLT		02



Item	Code	Description	See page	QT
001	0502012784	DRIVER PIVOT		02
002	0503010002	1800 GREASE FITTING		04
003	0531015151	0.6" X 1" X 2.4" SLEEVE		08
004	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
005	0531015184	FLAT WASHER		08
006	0503012412	5/8 UNC SELF LOCKING NUT		04
007	0571012449	CONTROL AXLE		01
008	0503030024	1.7" X10.2" X 0.2" EXTENSION SPRING		02
009	0503030168	HITCH PIN CLIP		02
010	0571012448	LOCK SLEEVE AXLE REGULATION		01
011	0503010131	3/16" X 1-1/2" COTTERPIN		01
012	0521065677	LIMITER		01
013	0571012443	COUPLING SHAFT		01
014	0571012442	COUPLING SHAFT		03
015	0503010131	3/16" X 1-1/2" COTTERPIN		02
016	0502012785	SEED ROW ADJUSTMENT LEVER ASSY		01
017	0502012814	BOX LEVER LOCK		01
018	0511054635	BEARING AXLE BODY	65	02
018A	0502012718	BEARIN BODY		01
018B	0503012882	BEARING		01
018C	0503017011	SEAL RING		01
018D	0503011945	503050 CLAMPING RING (FOR AXLE)		01
019	0503011953	5/16" X 1" BOLT		04
020	0501010694	FLAT WASHER		04
021	0503010179	LOCK WASHER		04
022	0503010337	5/16" NUT		04
023	0571012441	TRANSMISSION AXLE		01
024	0511054884	TRANSMISSION BOX	70	01
025	0503011378	M6X1X16 C S 8.8 ZN BOLT		02
026	0503015110	M06 SPRING WASHER		02
027	0503011855	0.2" X 1.8" SPRING PIN		01


FRONT SEED LONG

0511057730


Item	Code	Description	See page	QT
028	0511052393	BEARING FOLLOWER ROW ASSY	62	01
028A	0521063532	BEARING FOLLOWER ROW ASSY		01
028B	0503011410	ROLLER BEARING		01
028C	0503011105	SEAL RING		01
028D	0571012450	COP FLEX AXLE		01
028E	0571012459	COP FLEX AXLE		01
028F	0503010406	501025 CLAMPING RING (FOR AXLE)		02
028G	0503015356	SPRING PIN		01
028H	0503010691	1/4" GREASE FITTING		01
029	0503032984	HOOD HEX AXLE ROW		01
030	0503013100	NYLON CLAMP		01
031	0511057625	ROW SEED BEARING	67	01
031A	0511057156	BEARING LINE SEMI MOUNTED		01
031AA	0521065913	ROW SEED BEARING		01
031AB	0503011410	ROLLER BEARING		02
031AC	0503011105	SEAL RING		01
031AD	0503010406	501025 CLAMPING RING (FOR AXLE)		02
031AE	0571017815	BEARING AXLE BODY		01
031AF	0503017008	SEAL RING		01
031B	0571018731	HEX AXLE		01
031C	0571017900	5/8" X 77" HEX AXLE		01
031D	0561014778	HEX UNIVERSAL JOINT		01
031E	0501056296	UNIVERSAL JOINT		01
031F	0503011855	0.2" X 1.8" SPRING PIN		03
031G	0503013958	1/4" X 1" BOLT		02
032	0503011953	5/16" X 1" BOLT		04
033	0501010694	FLAT WASHER		04
034	0503010179	LOCK WASHER		04
035	0503010337	5/16" NUT		04
036	0571019706	HEX AXLE		01
037	0521063524	FRAME FRONT LINE SEED		01
038	0511050609	BEARING WITH 17Z GEAR ASSY	63	01
038A	0511050617	FRONT SEED ROW BEARING		01
038AA	0502011697	BEARING OF THE GEAR BOX		01
038AB	0503011410	ROLLER BEARING		01
038AC	0503011105	SEAL RING		01
038AD	0503011953	5/16" X 1" BOLT		02
038AE	0501010694	FLAT WASHER		02
038AF	0503010179	LOCK WASHER		02
038AG	0503010337	5/16" NUT		02
038B	0503010406	501025 CLAMPING RING (FOR AXLE)		01
038C	0502012819	17Z GEAR WITH HEX HOLE		01
039	0503011953	5/16" X 1" BOLT		02
040	0501010694	FLAT WASHER		02
041	0503010179	LOCK WASHER		02
042	0503010337	5/16" NUT		02
043	1902010175	HITCH CLAMP		01
044	0503010811	5/8" UNF SELF ADJUSTING NUT		02
045	0531019479	AXLE CHAIN GEAR		01
046	0541016454	PULLEY		01
047	0503011828	FLAT WASHER		01
048	0503010019	1/2" SPRING WASHER		01
049	0503010060	1/2" NUT		01
050	0503012142	40-1 CHAIN X 61 LINK + MENDING		01
051	0501012140	FLAT WASHER		02
052	0502012782	17Z GEAR WITH HEX HOLE		01
053	0521065914	FRAME ASSY		01
054	0503817859	5/8" X 4.3/4" BOLT		02

TRANSMISSION BOX


0511054884




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	BOX TRANSMISSION COVER		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0502040857	CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503010003	1845 GREASE FITTING		01
13	0503011409	6005 Z BALL BEARING		01
14	0503017008	SEAL RING		01
15	0503017007	SEAL RING		02
16	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0511057502	SET PRECISION PLANTING		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	84	01
07	0501058972	ASSEMBLY SENSOR ELECTRONIC		01
07A	0503015218	SENSOR FOTOELE PM 400		01
07B	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		03




Item	Code	Description	See page	QT
01	0511057502	SET PRECISION PLANTING		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	DDD RITGH SUPREMA PRECISION PLANTING	95	01
07	0501058972	ASSEMBLY SENSOR ELECTRONIC		01
07A	0503015218	SENSOR FOTOELE PM 400		01
07B	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		03




Item	Code	Description	See page	QT
001	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA 83 CSU 3		01
002	0503015920	3/8" UNC X 1.3/4" BOLT		04
003	0503010025	3/8" SPRING WASHER		04
004	0503010026	3/8" NUT		04
005	0503062403	TUBE SEED P.P		01
006	0511057154	DDD RITGH SUPREMA PRECISION PLANTING	95	01
007	0501058972	ASSEMBLY SENSOR ELECTRONIC		01




Item	Code	Description	See page	QT
001	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA CSU 3	83	01
002	0503015920	3/8" UNC X 1.3/4" BOLT		04
003	0503010025	3/8" SPRING WASHER		04
004	0503010026	3/8" NUT		04
005	0503062403	TUBE SEED P.P		01
006	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	84	01
007	0501058972	ASSEMBLY SENSOR ELECTRONIC		01




Item	Code	Description	See page	QT
01	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA CSU 3	83	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	DDD RITGH SUPREMA PRECISION PLANTING	95	01




Item	Code	Description	See page	QT
01	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA CSU 3	83	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	84	01




Item	Code	Description	See page	QT
01	0511057502	SET PRECISION PLANTING		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	DDD RITGH SUPREMA PRECISION PLANTING	95	01




Item	Code	Description	See page	QT
01	0511057502	SET PRECISION PLANTING		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	84	01




Item	Code	Description	See page	QT
01	0502050052	LEFT SIDE TRANSMISSION BOX PP		01
02	0502050053	RIGHT SIDE TRANSMISSION BOX PP		01
03	0503011410	ROLLER BEARING		02
04	0503011182	6203 ROLLER BEARING		02
05	0503011184	502040 CLAMPING RING (FOR AXLE)		01
06	0571017655	SLEEVE FIXER HITCH PNEUMATIC		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
08	0503010144	1/4" NUT		03
09	0511057504	JOIN GEAR		01
09A	0571017898	BODY GEAR TRANSMISSION		01
09B	0503011769	M8 X 0.5" BOLT		01
10	0581011222	PINION AXLE 6Z PNEUMATIC		01
11	0503034340	PINION AXLE 6Z PNEUMATIC		01




Item	Code	Description	See page	QT
001	0511057701	TURBINE WITH HIDRAULIC MOTOR	01	
002	0521066116	BOX PROTECTION HYDRAULIC CIRCUIT	01	
003	0503011082	C1/2" X 1.3/4" SCREW	04	
004	0501010937	13,50 X 28 X 3,00 FLAT WASHER	02	
005	0503010019	1/2" SPRING WASHER	14	
006	0503010060	1/2" NUT	12	
007	0571019399	SUPPORT FIXER RIGHT TURBINE	01	
008	0571019398	SUPPORT FIXER LEFT TURBINE	01	
009	0571019397	SUPPORT TUBE AR	04	
010	0521014021	1/2" X 4.5" X 5.4" FASTENER	04	
011	0511017302	FLAT WASHER	08	
012	0511057348	DISTRIBUTOR VACUUM	02	
013	0571019403	STAPLE FIXER	04	
014	0503010025	3/8" SPRING WASHER	08	
015	0503010026	3/8" NUT	08	
016	0571019552	SUPPORT VACUUM	01	
017	0503013584	VACUUM GAUGE	01	
018	0503015062	TUBE	03	



Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0501010984	FLAT WASHER		24
02	0501052817	BEAM SUPPORT & METERING		01
03	0501053126	FERTILIZER CHAIN TENSIONER ASSY	148	02
04	0501061485	GUTTER P/BOÎTE METALLIQUE		10
05	0503010019	1/2" SPRING WASHER		08
06	0503010025	3/8" SPRING WASHER		12
07	0503010026	3/8" NUT		12
08	0503010060	1/2" NUT		08
09	0503010246	CLAMP		04
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0503031050	CURVED CONDUCTOR		04
12	0503060443	FERTILIZER HOPPER WITH 4 TRUNNELS		02
13	0503060444	FERTILIZER HOPPER WITH 5 TRUNNELS		02
14	0511061884	FERTILIZER BOX FIXER		08
15	0511061886	FERTILIZER BEAM LOCK		08




Item	Code	Description	See page	QT
01	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
02	0571017899	PIN LOCK PP		01
03	0503030190	0.5" X 1.6" X 0.05" SPRING		01
04	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
05	0511057155	PRECISION PLANTING LEFT TRANSMISSION BOX	79	01
06	0571017894	PIN DRAG PRECISION PLANTING		01
07	0503013357	3/8" SELF-ADJUSTING NUT		01
08	0501013518	FLAT WASHER		02
09	0503015356	SPRING PIN		01
10	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
11	0571017895	PIN FIXER CONDUCTOR P.P		01
12	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
13	0503010293	BAQUELITE MANIPULACION		02
14	0503010140	1/8" X 3/4" COTTERPIN		02
15	0503010131	3/16" X 1-1/2" COTTERPIN		01
16	0503010025	3/8" SPRING WASHER		02
17	0571019491	SLUICE PNEUMATIC PRECISION PLANTING		01
18	0501011643	3/8 X 1"BOLT		01
19	0503010209	3/8" UNC BUTTERFLY NUT		01
20	0502012807	SUPPORT BOX PRECISION PLANTING		01
21	0571019489	CLAMP PRECISION PLANTING		01
22	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
23	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC		01
24	0561014778	HEX UNIVERSAL JOINT		01
25	0503013958	1/4" X 1" BOLT		02
26	0503011855	0.2" X 1.8" SPRING PIN		01
27	0503012721	1/4" X 4" BOLT		01
28	0503012880	1/4" UNC SELF ADJUSTING NUT		04
29	0571014024	FAST BOLT GUIDE AXLE		01
30	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02


Item	Code	Description	See page	QT
31	0503015110	M06 SPRING WASHER		02
32	0503818139	BOLT		03
33	0503037390	PACKING FOR PLANTING		01
34	0503015752	3/8" X 2" BOLT		01
35	0503034824	FIXATIVE		01
36	0581011226	FIXER CLOSING P PLANTING CONTR CPRA		01
37	0503010337	5/16" NUT		04
38	0503010179	LOCK WASHER		04
39	0503011953	5/16" X 1" BOLT		03
40	0503012163	5/16" X 1-1/2" BOLT		01
41	0521066707	FEEDER		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	81	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15		01
04	0503810026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501810984	FLAT WASHER		02
07	0503810751	3/8 UNC X 1.1/4 C S G.5 - SCREW		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012781	SUPPORT DDD LEFT		01
11	0511815098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O-RING		02
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02



Item	Code	Description	See page	QT
01	0501056430	ARM RIGHT CONTROL DEPTH WITHOUT WHEEL		01
02	0501052538	DEPTH BAND WITH ARMS	115	01
03	0503010358	5/16" X 5/8" BOLT		04
04	0503013816	5/16" LOCKNUT		04




Item	Code	Description	See page	QT
01	0501056435	LEFT CONTROL ARM DEPTH WITHOUT WHEEL		01
02	0501052538	DEPTH BAND WITH ARMS	115	01
03	0503010358	5/16" X 5/8" BOLT		04
04	0503013816	5/16" LOCKNUT		04



Item	Code	Description	See page	QT
01	0521063759	ROW FERTILIZER SUPPORT	01	
02	0511053223	FERTILIZER ROW SUPPORT WITH SCREW	01	
03	0503017855	3/4" BOLT	02	
04	0503010152	3/4" SELF LOCKING NUT	02	
05	0521063504	FERTILIZER ROW LOWER SUPPORT	01	
06	0503010233	5/8" X 2-1/2" BOLT	02	
07	0511015098	FLAT WASHER	06	
08	0561017928	FERTILIZER ROW ARTICULAT SLEEVE	02	
09	0503012412	5/8 UNC SELF LOCKING NUT	02	
10	0511063862	FERTILIZER ROW UPPER SUPPORT	01	
11	0501010163	5/8" X 4-1/2" BOLT	01	
12	0531015184	FLAT WASHER	01	
13	0531016031	1/2" SPRING WASHER	01	
14	0503012412	5/8 UNC SELF LOCKING NUT	01	
15	0531016207	0.6" X 1" X 2.8" SLEEVE	01	
16	0521061855	FERTILIZER ROW REAR SUPPORT	01	
17	0501010452	5/8" X 5" BOLT	02	
18	0531016031	1/2" SPRING WASHER	04	
19	0531016207	0.6" X 1" X 2.8" SLEEVE	02	
20	0503012412	5/8 UNC SELF LOCKING NUT	02	
21	0521062073	SPRING GUIDE	01	
22	0521016057	COUP SHA OF THE CARRY-W SPRING GUI	01	
23	0503030168	HITCH PIN CLIP	01	
24	1902020393	SPRING UPPER SUPPORT	01	
25	0503031450	2.7" X 9.2" X 0.03" SPRING	01	
26	1902020393	SPRING UPPER SUPPORT	01	
27	0521011158	SPRING LOCKNUT	01	
28	0521018575	REGULATOR SPINDLE 100	01	
29	0502012724	FERTILIZER ROW FIXER	01	
30	0503017960	5/8" X 3-12" BOLT	04	
31	0503010811	5/8" UNF SELF ADJUSTING NUT	04	

Item	Code	Description	See page	QT
32	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	89	01
33	0502012352	DOUBLE-DISC SPACING PLATE		01
34	0541013035	5.55" X 4.0" X 0.38" PLATE		01
35	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
36	0503010019	1/2" SPRING WASHER		02
37	0503010060	1/2" NUT		02
38	0503010752	1/2" X 3.1/2" BOLT		02
39	0503010019	1/2" SPRING WASHER		02
40	0503010060	1/2" NUT		02
41	0503030520	SEED SOCKET		01
42	0503031145	2" X 2" X 20" HOSE		01
43	0503031076	2" HOSE CLAMP		02
44	0503010003	1845 GREASE FITTING		02
45	0503010004	1890 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511053223	FERTILIZER ROW SUPPORT WITH SCREW		01
02	0502012728	ROW FERTILIZER SUPPORT		01
03	0503017856	BOLT 3/4		02
04	0503010152	3/4" SELF LOCKING NUT		02
05	0521063504	FERTILIZER ROW LOWER SUPPORT		01
06	0561017928	FERTILIZER ROW ARTICULAT SLEEVE		02
07	0511015098	FLAT WASHER		06
08	0503010233	5/8" X 2-1/2" BOLT		02
09	0503012412	5/8 UNC SELF LOCKING NUT		02
10	0511063862	FERTILIZER ROW UPPER SUPPORT		01
11	0501010452	5/8" X 5" BOLT		01
12	0531016207	0.6" X 1" X 2.8" SLEEVE		01
13	0503012412	5/8 UNC SELF LOCKING NUT		01
14	0521061855	FERTILIZER ROW REAR SUPPORT		01
15	0501010452	5/8" X 5" BOLT		02
16	0531016031	1/2" SPRING WASHER		04
17	0531016207	0.6" X 1" X 2.8" SLEEVE		02
18	0503012412	5/8 UNC SELF LOCKING NUT		02
19	0521062073	SPRING GUIDE		01
20	0521016057	COUP SHA OF THE CARRY-W SPRING GUI		01
21	0503030168	HITCH PIN CLIP		01
22	1902020393	SPRING UPPER SUPPORT		01
23	0503031450	2.7" X 9.2" X 0.03" SPRING		01
24	1902020393	SPRING UPPER SUPPORT		01
25	0521011158	SPRING LOCKNUT		01
26	0521018575	REGULATOR SPINDLE 100		01
27	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	90	01
28	0502012352	DOUBLE-DISC SPACING PLATE		01
29	0541013035	5.55" X 4.0" X 0.38" PLATE		01
30	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
31	0503010019	1/2" SPRING WASHER		02




FERTILIZER SHORT LINE

0511053024


Item	Code	Description	See page	QT
32	0503010060	1/2" NUT		02
33	0503010752	1/2" X 3.1/2" BOLT		02
34	0503010019	1/2" SPRING WASHER		02
35	0503010060	1/2" NUT		02
36	0503030520	SEED SOCKET		01
37	0503031145	2" X 2" X 20" HOSE		01
38	0503031076	2" HOSE CLAMP		02
39	0503010003	1845 GREASE FITTING		03




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15		01
02	0511053172	LEFT LOW CUBE WITH DISC 15	81	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	81	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15		01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0502012369	BLADE DISC SUPPORT		01
02	0501067323	SPRING REGULATOR		01
03	0521010452	SLEEVE		01
04	0521015376	DUST CLOAK		02
05	0521013510	3/4" NUT		02
06	0503011438	SPRING WASHER		02
07	0503034498	SPRING		01
08	0521067844	RIGHT ARM		01
09	0521067843	LEFT ARM		01
10	0503011255	3/4" LOCK NUT		02
11	0581014407	FLAT WASHER 36.5 X 65.00 X 3.00		01
12	0503030430	7/16 X 2" PIN LOCK		01
13	0503010003	1845 GREASE FITTING		01
14	0501052139	ASSY CUTTING DISK DPL18	93	01
15	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
16	0521062962	BLADE DISC AXLE		01
17	0581014524	SPRING SUPPORT WASHER		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503010060	1/2" NUT		01
20	0503011440	SPRING WASHER		01
21	0503013185	3/4" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0521062962	BLADE DISC AXLE		01
02	0502012369	BLADE DISC SUPPORT		01
03	0541018684	FLAT WASHER		01
04	0503010361	SPRING PIN		01
05	0503010756	0.2" X 2.4" SPRING PIN		01
06	0503010003	1845 GREASE FITTING		01
07	0521018935	RIGHT ARM OF THE BLADE DISC		01
08	0521018936	LEFT ARM OF THE BLADE DISC		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503016525	3/4" X 6" BOLT		01
12	0503011442	3/4" SPRING WASHER		01
13	0503010014	3/4" NUT		01
14	0502020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0502020394	SPRING SUPPORT		01
17	0503010014	3/4" NUT		02
18	0501054887	20 BLADE DISC WITH FLAT PLAN DISC	94	01
19	0521015376	DUST CLOAK		02
20	0511015346	FLAT WASHER		02
21	0503011438	SPRING WASHER		02
22	0521013510	3/4" NUT		02
23	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
24	0503011411	1/2" X 5-1/2" BOLT		01
25	0503011440	SPRING WASHER		01
26	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011562	DC BOX		01
02	0503010276	6206 BALL BEARING		02
03	0521013610	BLADE DISC HUB AXLE		01
04	0503030832	FLAT WASHER		02
05	0503012417	SEAL		02
06	0503011800	SEAL RING		02
07	0503010691	1/4" GREASE FITTING		01
08	0603026013	PLAIN COULTER BLADE		01
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0503011444	SPRING WASHER		06
12	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011562	DC BOX		01
02	0503010276	6206 BALL BEARING		02
03	0521013610	BLADE DISC HUB AXLE		01
04	0503030832	FLAT WASHER		02
05	0503012417	SEAL		02
06	0503011800	SEAL RING		02
07	0503010691	1/4" GREASE FITTING		01
08	0603027851	20" X 0.2" FLAT PLAIN DISC		01
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0503011444	SPRING WASHER		06
12	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	81	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15		01
04	0503810026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501810984	FLAT WASHER		02
07	0503810751	3/8 UNC X 1.1/4 C S G.5 - SCREW		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012780	SUPPORT DDD RIGHT		01
11	0511815098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O-RING		02
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0502012798	SUPPORT BOX SEED		01
02	0581012694	COMPACT PROTECTION		01
03	0503010849	3/8" X 1-1/2" BOLT		03
04	0501010096	3/8" X 2" BOLT		01
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0503031508	COVER GREEN BEAM SEED YELLOW		01
08	0503010358	5/16" X 5/8" BOLT		04
09	0501010694	FLAT WASHER		04
10	0503010179	LOCK WASHER		04
11	0503010337	5/16" NUT		04



Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	NUT		02




Item	Code	Description	See page	QT
01	0511055690	WHEEL SISTEM	99	01
02	0551019650	SLEEVE 13,20 X 25 X 74		01
03	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0511055327	COMPACTING WHEEL V ASSY RUBBER	104	01



Item	Code	Description	See page	QT
01	0502012758	DEPTH CONTROL SUPPORT		01
02	0503010585	0,24" X 1.18" SPRING PIN		02
03	0503010002	1800 GREASE FITTING		01
04	0501059228	ADJUSTMENT LEVER	100	01
05	0502012611	DEPTH CONTROL AXLE		01
06	0571015326	ARTICULATION SLEEVE HANDLE		01
07	0501010984	FLAT WASHER		01
08	0503011443	3/8" SPRING WASHER		01
09	0503010237	3/8" X 1" BOLT		01
10	0571016132	PIVOT SHAFT		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0561014336	PIVOT SHAFT		01
13	0503010071	3/16" X 1" COTTERPIN		02
14	0511055628	DEPTH WHEEL SYSTEM	101	01
15	0511055629	DEPTH WHEEL SYSTEM	102	01

ADJUSTMENT LEVER


0501059228



Item	Code	Description	See page	QT
01	0502012603	ADJUSTMENT LEVER		01
02	0502011689	1/8" DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0511015976	FLAT WASHER		01
05	0503010140	1/8" X 3/4" COTTERPIN		01

DEPTH WHEEL SYSTEM


0511055628




Item	Code	Description	See page	QT
01	0561014385	CARRYING-WHEELS PIVOT SHAFT		01
02	0503010019	1/2" SPRING WASHER		01
03	0511055627	WHEEL ASSY RAYED	103	01
04	0503016453	1/2" X 2.1/2 BOLT		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01
07	0503030012	HITCH PIN CLIP		01
08	0501110777	RIGHT WHEEL ARM		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER		01
11	0501011445	FLAT WASHER		03
12	0503012412	5/8 UNC SELF LOCKING NUT		01
13	0503011440	SPRING WASHER		01

DEPTH WHEEL SYSTEM

0511055629




Item	Code	Description	See page	QT
01	0571015973	CARRYING-WHEELS PIVOT SHAFT		01
02	0503010019	1/2" SPRING WASHER		01
03	0511055627	WHEEL ASSY RAYED	103	01
04	0503016453	1/2" X 2.1/2 BOLT		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01
07	0503030012	HITCH PIN CLIP		01
08	0501110776	ARM,LEFT		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER		01
11	0501011445	FLAT WASHER		03
12	0503012412	5/8 UNC SELF LOCKING NUT		01
13	0503011440	SPRING WASHER		01




Item	Code	Description	See page	QT
01	0511055626	BOX ROUND DEPTH ROYAL WITH SPA		01
02	0551019904	PRESS WHEEL RIM		02
03	0503030891	RUBBER BAND		01
04	0503010365	NUT		06
05	0503010179	LOCK WASHER		06
06	0503010337	5/16" NUT		06

COMPACTING WHEEL V ASSY RUBBER


0511055327




Item	Code	Description	See page	QT
01	0571015324	COMPACT WHEEL RIGHT ARM		01
02	0571015325	LH ARM PRESS WHEELS		01
03	0541012145	SLEEV 13,5 X 25 X 18		02
04	0501058362	LARGER HANDLE ASSY		01
04A	0502011689	1/8" DEPTH CONTROL LEVER		01
04B	0521064892	REGULACION SPRING COMPACTOR		01
04C	0541012146	0.53" X 0.74" X 0.33" SLEEVE		01
04D	0503030174	COMPRESSION SPRING		01
04E	0541012143	FLAT WASHER		01
04F	0503010257	1/8" X 1" COTTERPIN		01
05	0503010479	BOLT		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0503031393	1.57" X 5.98" X 0.2"TRACTION SPRING		01
09	0501055289	HANDLE SMALLER ASSY		01
09A	0511065451	PRESS WHEEL ADJUSTER		01
09B	0511065496	PRESS WHEEL FIXER		01
09C	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
09D	0541012143	FLAT WASHER		01
09E	0503010257	1/8" X 1" COTTERPIN		01
10	0503010397	5/16" X 1-3/4" BOLT		02
11	0541012144	8,50 X 16 X 21 SLEEVE		02
12	0503011444	SPRING WASHER		02
13	0503010337	5/16" NUT		02
14	0501052908	COMPACTOR WHEEL WITH BEARING	105	02
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503013739	1/2" X 1" BOLT		01
17	0503011440	SPRING WASHER		02



Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0581014858	DEPTH WHEEL AXLE		01
04	0501110720	ARM LEFT		01
05	0501110719	DEPTH CONTROL RIGHT ARM		01
06	0502012663	EXTENSION		01
07	0503010002	1800 GREASE FITTING		02
08	0501056769	DEPTH WHEELS REGULATOR ASSY	107	01
09	0503034793	ARTICULATION SLEEVE		02
10	0521051423	COMPACTOR SUPPORT	108	01
11	0571017749	FLAT WASHER		02
12	0503010311	1/2" X 1-1/4" BOLT		02
13	0503016453	1/2" X 2.1/2 BOLT		02
14	0503034817	SPRING		01
15	0503010581	RING		01
16	0503034377	SCREWEW 3/8 UNC X 3/4		01
17	0503010019	1/2" SPRING WASHER		08
18	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
19	0503010060	1/2" NUT		04
20	0501052908	COMPACTOR WHEEL WITH BEARING	105	02
21	0503013739	1/2" X 1" BOLT		01
22	0511050077	WHEEL STRIPED	109	02
23	0503010752	1/2" X 3.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	SEED SIST CONTROL DEPTH LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01

COMPACTOR SUPPORT


0521051423




Item	Code	Description	See page	QT
01	0521068003	RIGHT SIDE		01
02	0521068002	LEFT SIDE		01
03	0581014847	PLATE UPPER		01
04	0581015855	SLEEVE		02
05	0521068004	HANDLE BODY		01
06	0581014969	SLEEVE GUIDE		01
07	0581014968	SLEEVE FLANGE		01
08	0503010937	5/16" X 3" BOLT		02
09	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
10	0521068005	LEVER		01
11	0503010179	LOCK WASHER		04
12	0503010337	5/16" NUT		04
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2" NUT		01
15	0503010847	1/2" X 3.1/4" BOLT		01
16	0503010882	BOLT		02
17	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
18	0503030878	LEVER CRANK		01
19	0581015854	RIGHT PROTECTION COVER		01
20	0581015853	LEFT PROTECTION COVER		01
21	0581015903	SPACER WASHER		01




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY		01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	LOCK WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	111	01
02	0501052538	DEPTH BAND WITH ARMS	115	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	116	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	117	01
07	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	112	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	113	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	114	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	SCREWEW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL BOX		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL BOX		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05



Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	105	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	105	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01



Item	Code	Description	See page	QT
01	0511055326	DEPTH CONTROL PRESS WHEEL ASSY	119	01
02	0551019650	SLEEVE 13,20 X 25 X 74		01
03	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0511055327	COMPACTING WHEEL V ASSY RUBBER	104	01

DEPTH CONTROL PRESS WHEEL ASSY


0511055326




Item	Code	Description	See page	QT
01	0502012758	DEPTH CONTROL SUPPORT		01
02	0503010585	0,24" X 1.18" SPRING PIN		02
03	0503010002	1800 GREASE FITTING		01
04	0501059228	ADJUSTMENT LEVER	100	01
05	0502012611	DEPTH CONTROL AXLE		01
06	0571015326	ARTICULATION SLEEVE HANDLE		01
07	0501010984	FLAT WASHER		01
08	0503011443	3/8" SPRING WASHER		01
09	0503010237	3/8" X 1" BOLT		01
10	0571016132	PIVOT SHAFT		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0561014336	PIVOT SHAFT		01
13	0503010071	3/16" X 1" COTTERPIN		02
14	0511055328	DEPTH WHEEL SYSTEM	120	01
15	0511055329	LEFT DEPTH WHEEL		01

DEPTH WHEEL SYSTEM


0511055328




Item	Code	Description	See page	QT
01	0561014385	CARRYING-WHEELS PIVOT SHAFT		01
02	0501110777	RIGHT WHEEL ARM		01
03	0503010019	1/2" SPRING WASHER		01
04	0511055627	WHEEL ASSY RAYED	103	01
05	0503016453	1/2" X 2.1/2 BOLT		01
06	0503010060	1/2" NUT		01
07	0503010002	1800 GREASE FITTING		01
08	0503030012	HITCH PIN CLIP		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER		01
11	0501011445	FLAT WASHER		03
12	0571015974	WASHER		01
13	0503012412	5/8 UNC SELF LOCKING NUT		01
14	0503011440	SPRING WASHER		01




Item	Code	Description	See page	QT
01	0511053550	DEPTH CONTROL ASSY	122	01
02	0511050077	WHEEL STRIPED	109	02
03	0511054333	COMPACT WHEEL RIGHT WITH BEARING	116	01
04	0511054334	COMPACT WHEEL LEFT WITH BEARING	117	01
05	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521064073	REGULACION WHEEL COMPACTOR		01
03	0521019093	0.6" X 2.7" PIVOT SHAFT		01
04	0503010581	RING		01
05	0571013054	DEPTH CONTROL WHEEL AXLE		01
06	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
07	0511015346	FLAT WASHER		04
08	0501110720	ARM LEFT		01
08A	0502012726	LEFT DEPTH WHEEL ARM		01
08B	0503034375	SLEEVE ARM WHEEL DEPTH CONTROL		02
09	0501110719	DEPTH CONTROL RIGHT ARM		01
09A	0502012725	DEPTH WHEEL RIGHT ARM		01
09B	0503034375	SLEEVE ARM WHEEL DEPTH CONTROL		02
10	0511017302	FLAT WASHER		02
11	0503011440	SPRING WASHER		04
12	1902012116	PRESS WHEEL ADJUSTER		01
13	0503010849	3/8" X 1-1/2" BOLT		02
14	0503011443	3/8" SPRING WASHER		02
15	0503010026	3/8" NUT		02
16	0521010539	0.3" X 1.2" COUPLING SHAFT		01
17	0503010140	1/8" X 3/4" COTTERPIN		01
18	0502012663	EXTENSION		01
19	0503010002	1800 GREASE FITTING		02
20	0503010060	1/2" NUT		02
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
22	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
23	0541016906	PRESS WHEELS REGULATOR BODY		01
24	0501056769	DEPTH WHEELS REGULATOR ASSY	107	01
25	0503010311	1/2" X 1-1/4" BOLT		02
26	0503010256	3/8" X 3/4" BOLT		01




Item	Code	Description	See page	QT
001	0511057036	AIR DISTRIBUTOR BOARD		02
001A	0503012567	T-JOIN FOR TUBE 110		01
001B	0581013890	SOCKET DISTRIBUTOR AR		01
002	0503034812	SOCKET DISTRIBUTOR AR		10
003	0503012856	POP RIVET		40
004	0503034763	AIR DITRIBUTOR PUMP		01
005	0503015341	POP RIVET		02
006	0581019623	CONDUCTOR BODY		01
007	0581019625	CONDUCTOR BODY		01
008	0581019624	CONDUCTOR BODY		01
009	0521050393	ASSY KNEE		01
009A	0503017845	PVC KNEE 90 SOLD AVEL		01
009B	0581013890	SOCKET DISTRIBUTOR AR		01



Item	Code	Description	See page	QT
01	0502020600	MARKER ARM DISC HUB	02	
02	0503010272	SEAL 00715-BA	02	
03	0503010690	6204 BALL BEARING	02	
04	0501015883	COMPACT WHEEL AXLE	01	
05	0503030143	3.3" X 1.9" X 0.1" JOINT	02	
06	0503010691	1/4" GREASE FITTING	02	
07	0501014071	RIM SEMI	02	
08	0503010743	1/4" X 1-1/4" BOLT	05	
09	0503010143	1/4" SPRING WASHER	05	
10	0503010144	1/4" NUT	05	
11	0503030240	DEPTH CONTROL WHEEL RUBBER BAND	01	
12	0503013758	1/4" X 1-1/2" BOLT	05	
13	0503010143	1/4" SPRING WASHER	05	
14	0503010144	1/4" NUT	05	




Item	Code	Description	See page	QT
01	0502012121	RIGHT ARM CONVEX PRESS WHEELS		01
02	0503030883	RIGHT TORSION SPRING		01
03	0502011066	PRESS WHEELS ARM SUPPORT		01
04	0531017415	1" X 4.72" AXLE JOINT		01
05	0503010839	03"X 0.6" SPRING PIN		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511059462	DEPTH CONTROL WITH FAST ADJUSTMENT	127	01
02	0511050077	WHEEL STRIPED	109	02
03	0503016453	1/2" X 2.1/2 BOLT		02
04	0503010019	1/2" SPRING WASHER		04
05	0503010028	1/2" NUT		02
06	0501052908	COMPACTOR WHEEL WITH BEARING	105	02
07	0503010752	1/2" X 3.1/2" BOLT		01
08	0503013739	1/2" X 1" BOLT		01

DEPTH CONTROL WITH FAST ADJUSTMENT


0511059462




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0503010257	1/8" X 1" COTTERPIN		01
04	0571013054	DEPTH CONTROL WHEEL AXLE		01
05	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
06	0511015346	FLAT WASHER		04
07	0501110720	ARM LEFT		01
07A	0502012726	LEFT DEPTH WHEEL ARM		01
07B	0503034375	SLEEVE ARM WHEEL DEPTH CONTROL		02
08	0501110719	DEPTH CONTROL RIGHT ARM		01
08A	0501110720	ARM LEFT		01
08B	0503034375	SLEEVE ARM WHEEL DEPTH CONTROL		02
09	0511017302	FLAT WASHER		02
10	0503011440	SPRING WASHER		04
11	0502012663	EXTENSION		01
12	0503010002	1800 GREASE FITTING		02
13	0503010060	1/2" NUT		02
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
15	0503031393	1.57" X 5.98" X 0.2"TRACTION SPRING		01
16	0501056769	DEPTH WHEELS REGULATOR ASSY	107	01
17	0503010311	1/2" X 1-1/4" BOLT		02
18	0503010256	3/8" X 3/4" BOLT		01
19	0511059463	COMFORT WHEEL WITH FAST ADJUSTMENT	128	01




Item	Code	Description	See page	QT
01	0521067072	COMPACT WHEEL RIGHT ARM		01
02	0521067071	COMPACT RUEDA LEFT ARM		01
03	0541012144	8,50 X 16 X 21 SLEEVE		02
04	0501055289	HANDLE SMALLER ASSY		01
04A	0511065451	PRESS WHEEL ADJUSTER		01
04B	0511065496	PRESS WHEEL FIXER		01
04C	0503031719	0.7" X 1" X 1,1" COMPRESSION SPRING		01
04D	0541012143	FLAT WASHER		01
04E	0503010257	1/8" X 1" COTTERPIN		01
05	0511059461	COMPLETE REGULATOR		01
05A	0503030174	COMPRESSION SPRING		01
05B	0502011689	1/8" DEPTH CONTROL LEVER		01
05C	0503010257	1/8" X 1" COTTERPIN		01
05D	0521067070	PRESS WHEEL ADJUSTER		01
05E	0511015976	FLAT WASHER		01
05F	0541012146	0.53" X 0.74" X 0.33" SLEEVE		01
06	0541012145	SLEEV 13,5 X 25 X 18		02
07	0503010479	BOLT		01
08	0503010060	1/2" NUT		01
09	0503011440	SPRING WASHER		01
10	0503010397	5/16" X 1-3/4" BOLT		02
11	0503011444	SPRING WASHER		02
12	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0511052971	SEMI-ASSEMBLED DEPTH CONTROL WITH THREAD	130	01
02	0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	135	01
03	0501052908	COMPACTOR WHEEL WITH BEARING	105	02
04	0503010019	1/2" SPRING WASHER		06
05	0503010752	1/2" X 3.1/2" BOLT		01
06	0503013739	1/2" X 1" BOLT		01
07	0503010479	BOLT		02
08	0503010060	1/2" NUT		04
09	0503030012	HITCH PIN CLIP		01
10	0571013222	FIXING CHOCK		01
11	0503010741	1/2" X 2-3/4" BOLT		02
12	0511055819	DEPTH WHIT AROS BAND	136	02
13	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
14	0503013816	5/16" LOCKNUT		08




Item	Code	Description	See page	QT
01	0521063808	DEPTH CONTROL INNER COLUMN CONTROL WITH SCREW		01
02	0521063809	DEPTH CONTROL EXTERNAL COLUMN CONTROL WITH SCREW		01
03	0571013194	REGULATOR SPINDLE		01
04	0551010616	ROD HEX		01
05	0503010683	0,2" X 1,2" SPRING PIN		01
06	0571013202	REGULATOR AXLE WHEELS COBRIDORA		01
07	0521063812	REGULATOR LEVER ALXE		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		01
09	0511065308	LOCK REGULATOR		01
10	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
11	0541011627	FLAT WASHER		01
12	0503010140	1/8" X 3/4" COTTERPIN		01
13	0511059325	LEFT ARM COVERED WHEEL ASSEMBLED	131	01
14	0511059324	RIGHT ARM COVERED WHEEL ASSEMBLED	132	01
15	0571014709	SLEEVE LOCK CONTROL ARM		02
16	0503011440	SPRING WASHER		03
17	0503819099	BOLT		02
18	0511051546	CUBE RIGHT CONTROL DEPTH	133	01
19	0511051547	LEFT CUBE CONTROL DEPTH	134	01
20	0503011442	3/4" SPRING WASHER		02
21	0571013189	SLEEVE SUPPORT BEATER		01
22	0521063813	WHEEL PRESS BEATER		01
23	0501010937	13,50 X 28 X 3,00 FLAT WASHER		01
24	0503010920	1/2" X 1.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502012844	LEFT ARM WHEELS		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	GLOVE SUPPORT ARM WHEEL COBRIDORA		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012843	RIGHT WHEEL ARM		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	GLOVE SUPPORT ARM WHEEL COBRIDORA		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB		01
02	0511066638	AXLE WHEEL RIGHT DEPTH WITH DOOR DUST		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	COVER DEPTH		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03



Item	Code	Description	See page	QT
01	0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB		01
02	0511066637	AXLE WHEEL LEFT DEPTH WITH DOOR DUST		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	COVER DEPTH		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0502012850	PRESS WHEELS ARM	01	01
02	0503030883	RIGHT TORSION SPRING	01	01
03	0502011066	PRESS WHEELS ARM SUPPORT	01	01
04	0531017415	1" X 4.72" AXLE JOINT	01	01
05	0503010839	03"X 0.6" SPRING PIN	01	01
06	0521063841	REGULATOR RIGHT COMPACTOR	01	01
07	0521063842	REGULATOR LEFT COMPACTOR	01	01
08	0503811404	BOLT	02	02
09	0503011443	3/8" SPRING WASHER	02	02
10	0503010026	3/8" NUT	02	02
11	0571013295	ALXE REGULATOR COMPACTOR	01	01
12	0521063812	REGULATOR LEVER ALXE	01	01
13	0503011336	1/2" HEX SELF ADJUSTING NUT	02	02
14	0511065308	LOCK REGULATOR	01	01
15	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING	01	01
16	0541011627	FLAT WASHER	01	01
17	0503010140	1/8" X 3/4" COTTERPIN	01	01
18	0571013293	SLEEVE LOCK COMPACTOR V CONTROL WITH SCREW	01	01
19	0503811172	BOLT	01	01
20	0503010002	1800 GREASE FITTING	01	01
21	0581013744	PROTECTION COVER - CPRA	01	01
22	0503813096	BOLT	01	01
23	0503013816	5/16" LOCKNUT	0	0



Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503013758	1/4" X 1-1/2" BOLT		05
04	0503013814	1/4" NC LOCKNUT		05

HEX AXLE ASSEMBLY


0511054291



Item	Code	Description	See page	QT
01	0501053610	BEARING WITH 17Z GEAR INNER AXLE		02
02	0571013540	5/8" X 85" HEX AXLE		01
03	0571013538	5/8" X 2075 AXLE BODY		01
04	0511063123	BUSHING WITH NUT		04
05	0503010834	1/2 X 1 BOLT		04

HEX AXLE ASSEMBLY


0511053381




Item	Code	Description	See page	QT
01	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	02	
02	0531016944	RIGHT 5/8" X 96" HEX AXLE	01	
03	0531016945	LEFT 5/8" X 90" HEX AXLE	01	
04	0511063123	BUSHING WITH NUT	04	
05	0503010834	1/2 X 1 BOLT	04	

HEX AXLE ASSEMBLY


0511053361



Item	Code	Description	See page	QT
01	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	02	
02	0531016946	5/8" X 114" AXLE HEX	01	
03	0531016947	LEFT 5/8" X 108" AXLE HEX	01	
04	0511063123	BUSHING WITH NUT	04	
05	0503010834	1/2 X 1 BOLT	04	




Item	Code	Description	See page	QT
01	0561019899	RIGHT SUPPORT FIXER RECAMBIO		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0503011082	C1/2" X 1.3/4" SCREW		02
05	0511017302	FLAT WASHER		04
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02



Item	Code	Description	See page	QT
01	0561019898	LEFT SUPPORT FIXER RECAMBIO		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0503011082	C1/2" X 1.3/4" SCREW		02
05	0511017302	FLAT WASHER		04
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02

SET TRANSMISSION LEFT ASSY


0511057863



Item	Code	Description	See page	QT
001	0561018212	ARTICULAT SLEEVE		01
002	0503010547	1/2" X 4" BOLT		01
003	0511017302	FLAT WASHER		01
004	0503010019	1/2" SPRING WASHER		01
005	0503010060	1/2" NUT		01
006	0561017281	ARTICULACION ARM		01
007	0511053366	CHAIN TENSIONER EXCHANGE	149	01
008	0511050385	BEARING DOUBLE GEAR	144	01
009	0501058265	STRETCHER LOWER CURRENT 21Z SEED	145	01
010	0511056387	INTERMEDIATE BEARING SEED WITH GEAR 21Z	146	01
011	0511050127	CHAIN TENSIONER SUPPORT	147	01
012	0501053126	FERTILIZER CHAIN TENSIONER ASSY	148	01
013	0561017275	LEVER FIXER		01
014	0503010237	3/8" X 1" BOLT		02
015	0503010025	3/8" SPRING WASHER		02
016	0503010026	3/8" NUT		02
017	0561017280	LH LEVER DISASSEMBLE (COP 11)		01
018	0503030093	TRACTION SPRING		01
019	0561017273	FIXER SPRING		01
020	0503010237	3/8" X 1" BOLT		01
021	0503010025	3/8" SPRING WASHER		01
022	0503010026	3/8" NUT		01
023	0561017282	LOWER LEVER		01
024	0561016797	SLEEVE UNION LEVER		01
025	0503011082	C1/2" X 1.3/4" SCREW		01
026	0511017302	FLAT WASHER		02
027	0503010019	1/2" SPRING WASHER		01
028	0503010060	1/2" NUT		01
029	0521010773	0.37" X 1.18" COUPLING SHAFT		02
030	0501010984	FLAT WASHER		01
031	0503010140	1/8" X 3/4" COTTERPIN		02



Item	Code	Description	See page	QT
032	0503016737	40-1 X 114 CHAIN LINK + REDUCION		02




Item	Code	Description	See page	QT
001	0561018212	ARTICULAT SLEEVE		01
002	0503010547	1/2" X 4" BOLT		01
003	0511017302	FLAT WASHER		01
004	0503010019	1/2" SPRING WASHER		01
005	0503010060	1/2" NUT		01
006	0561017281	ARTICULACION ARM		01
007	0511053366	CHAIN TENSIONER EXCHANGE	149	01
008	0511050385	BEARING DOUBLE GEAR	144	01
009	0501058265	STRETCHER LOWER CURRENT 21Z SEED	145	01
010	0511056387	INTERMEDIATE BEARING SEED WITH GEAR 21Z	146	01
011	0511050127	CHAIN TENSIONER SUPPORT	147	01
012	0501053126	FERTILIZER CHAIN TENSIONER ASSY	148	01
013	0561017275	LEVER FIXER		01
014	0503010237	3/8" X 1" BOLT		02
015	0503010025	3/8" SPRING WASHER		02
016	0503010026	3/8" NUT		02
017	0561017279	RH LEVER DISASSEMBLE (COP 11)		01
018	0503030093	TRACTION SPRING		01
019	0561017273	FIXER SPRING		01
020	0503010237	3/8" X 1" BOLT		01
021	0503010025	3/8" SPRING WASHER		01
022	0503010026	3/8" NUT		01
023	0561017282	LOWER LEVER		01
024	0561016797	SLEEVE UNION LEVER		01
025	0503011082	C1/2" X 1.3/4" SCREW		01
026	0511017302	FLAT WASHER		02
027	0503010019	1/2" SPRING WASHER		01
028	0503010060	1/2" NUT		01
029	0521010773	0.37" X 1.18" COUPLING SHAFT		02
030	0501010984	FLAT WASHER		01
031	0503010140	1/8" X 3/4" COTTERPIN		02




SET TRANSMISSION RIGHT ASSY

0511057862


Item	Code	Description	See page	QT
032	0503016737	40-1 X 114 CHAIN LINK + REDUCION		02




Item	Code	Description	See page	QT
01	0521061843	20Z DOBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019175	DOUBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0501010163	5/8" X 4-1/2" BOLT		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0561015677	CHAIN TIGHTENER AXLE		01
02	0501010452	5/8" X 5" BOLT		01
03	0521069698	GEAR 21Z P 1/2		01
04	0503011410	ROLLER BEARING		01
05	0503011105	SEAL RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01
08	0501012140	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521018415	TIGHTENER AXLE		01
02	0503011410	ROLLER BEARING		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0521069698	GEAR 21Z P 1/2		01
05	0503011105	SEAL RING		01
06	0501011234	5/8" X 3" BOLT		01
07	0503010027	5/8" SPRING WASHER		01
08	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	1 1/2" GEAR		01
03	0503010060	1/2" NUT		01
04	0511017302	FLAT WASHER		02
05	0503010019	1/2" SPRING WASHER		01




Item	Code	Description	See page	QT
001	0521050173	ASSEMBLY CSU	151	01
002	0521063064	SUPPORT TOWER SILO SEED CSU		06
003	0501010942	3/8" X 1-1/4" BOLT		12
004	0501010984	FLAT WASHER		12
005	0503010025	3/8" SPRING WASHER		12
006	0503010026	3/8" NUT		12
007	0502010175	HITCH CLAMP		06
008	0501011543	5/8" X 4" BOLT		12
009	0503012412	5/8 UNC SELF LOCKING NUT		12
010	0501010453	FLAT WASHER		12




Item	Code	Description	See page	QT
001	0521064748	05 MOUTHS CSU SUPPORT		03
002	0503061987	SILO FERTILIZER 05 MOUTHS FRONT MOUNTED		03
003	0521063401	SEED BOX ONLY FIXING LOCK		06
004	0501010984	FLAT WASHER		06
005	0503010025	3/8" SPRING WASHER		06
006	0503010026	3/8" NUT		06
007	0511057690	3" ARTICULATED SEED CONDUCTOR	152	09
008	0501010942	3/8" X 1-1/4" BOLT		36
009	0503010025	3/8" SPRING WASHER		36
010	0503010026	3/8" NUT		36




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER		02
09	0503010179	LOCK WASHER		02
10	0503010337	5/16" NUT		02
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT		01




Item	Code	Description	See page	QT
01	0511058100	2 BOXES WITH 9 CONDUCTORS ASSEMBLY	154	01
02	0521063064	SUPPORT TOWER SILO SEED CSU		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8 UNC SELF LOCKING NUT		08
10	0501012140	FLAT WASHER		08




Item	Code	Description	See page	QT
01	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS		02
02	0503061899	REAR BEAN FERTILIZER ASSY		02
03	0521063401	SEED BOX ONLY FIXING LOCK		04
04	0501010984	FLAT WASHER		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	152	09
08	0501010942	3/8" X 1-1/4" BOLT		36
09	0503010025	3/8" SPRING WASHER		36
10	0503010026	3/8" NUT		36
11	0571015773	SUPPORT SEED		03
12	0501011643	3/8 X 1"BOLT		12
13	0503010025	3/8" SPRING WASHER		12
14	0503010026	3/8" NUT		12




Item	Code	Description	See page	QT
001	0511057737	2 BOXES WITH 10 CONDUCTORS ASSEMBLY	156	01
002	0521063064	SUPPORT TOWER SILO SEED CSU		04
003	0501010942	3/8" X 1-1/4" BOLT		08
004	0501010984	FLAT WASHER		08
005	0503010025	3/8" SPRING WASHER		08
006	0503010026	3/8" NUT		08
007	0502010175	HITCH CLAMP		04
008	0501011543	5/8" X 4" BOLT		08
009	0503012412	5/8 UNC SELF LOCKING NUT		08
010	0501010453	FLAT WASHER		08




Item	Code	Description	See page	QT
01	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		02
02	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02
03	0521063401	SEED BOX ONLY FIXING LOCK		04
04	0501010984	FLAT WASHER		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	152	10
08	0501010942	3/8" X 1-1/4" BOLT		40
09	0503010025	3/8" SPRING WASHER		40
10	0503010026	3/8" NUT		40
11	0571015773	SUPPORT SEED		04
12	0501011643	3/8 X 1"BOLT		16
13	0503010025	3/8" SPRING WASHER		16
14	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0511057919	2 BOXES WITH 11 CONDUCTORS ASSEMBLY	158	01
02	0521063064	SUPPORT TOWER SILO SEED CSU		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8 UNC SELF LOCKING NUT		08
10	0501010453	FLAT WASHER		08




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		04
02	0501010984	FLAT WASHER		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	3" ARTICULATED SEED CONDUCTOR	152	11
06	0571015773	SUPPORT SEED		03
07	0501011643	3/8 X 1"BOLT		12
08	0501010942	3/8" X 1-1/4" BOLT		44
09	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0521050886	ASSEMBLY CSU	160	01
02	0521063064	SUPPORT TOWER SILO SEED CSU		06
03	0501010942	3/8" X 1-1/4" BOLT		12
04	0501010984	FLAT WASHER		12
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12
07	0502010175	HITCH CLAMP		06
08	0501011543	5/8" X 4" BOLT		12
09	0501010453	FLAT WASHER		12
10	0503012412	5/8 UNC SELF LOCKING NUT		12




Item	Code	Description	See page	QT
01	0521064748	05 MOUTHS CSU SUPPORT		03
02	0503061987	SILO FERTILIZER 05 MOUTHS FRONT MOUNTED		03
03	0521063401	SEED BOX ONLY FIXING LOCK		06
04	0501010984	FLAT WASHER		06
05	0503010025	3/8" SPRING WASHER		06
06	0503010026	3/8" NUT		06
07	0511057690	3" ARTICULATED SEED CONDUCTOR	152	11
08	0501010942	3/8" X 1-1/4" BOLT		44
09	0503010025	3/8" SPRING WASHER		44
10	0503010026	3/8" NUT		44




Item	Code	Description	See page	QT
001	0511058702	ASSEMBLY CSU	162	01
002	0521063064	SUPPORT TOWER SILO SEED CSU		06
003	0501010942	3/8" X 1-1/4" BOLT		12
004	0501010984	FLAT WASHER		12
005	0503010025	3/8" SPRING WASHER		12
006	0503010026	3/8" NUT		12
007	0502010175	HITCH CLAMP		06
008	0501011543	5/8" X 4" BOLT		12
009	0501010453	FLAT WASHER		12
010	0503012412	5/8 UNC SELF LOCKING NUT		12




Item	Code	Description	See page	QT
001	0521064748	05 MOUTHS CSU SUPPORT		02
002	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS		01
003	0503061987	SILO FERTILIZER 05 MOUTHS FRONT MOUNTED		02
004	0503061899	REAR BEAN FERTILIZER ASSY		01
005	0521063401	SEED BOX ONLY FIXING LOCK		06
006	0501010984	FLAT WASHER		06
007	0503010025	3/8" SPRING WASHER		06
008	0503010026	3/8" NUT		06
009	0511057690	3" ARTICULATED SEED CONDUCTOR	152	11
010	0501010942	3/8" X 1-1/4" BOLT		44
011	0503010025	3/8" SPRING WASHER		44
012	0503010026	3/8" NUT		44
013	0571015773	SUPPORT SEED		05
014	0501011643	3/8 X 1"BOLT		20
015	0503010025	3/8" SPRING WASHER		20
016	0503010026	3/8" NUT		20




Item	Code	Description	See page	QT
01	0511058880	ASSEMBLY CSU	164	01
02	0521063064	SUPPORT TOWER SILO SEED CSU		06
03	0501010942	3/8" X 1-1/4" BOLT		12
04	0501010984	FLAT WASHER		12
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12
07	0502010175	HITCH CLAMP		06
08	0501011543	5/8" X 4" BOLT		12
09	0501010453	FLAT WASHER		12
10	0503012412	5/8 UNC SELF LOCKING NUT		12



Item	Code	Description	See page	QT
01	0521064748	05 MOUTHS CSU SUPPORT		02
02	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS		01
03	0503061987	SILO FERTILIZER 05 MOUTHS FRONT MOUNTED		02
04	0503061899	REAR BEAN FERTILIZER ASSY		01
05	0521063401	SEED BOX ONLY FIXING LOCK		06
06	0501010984	FLAT WASHER		06
07	0503010025	3/8" SPRING WASHER		06
08	0503010026	3/8" NUT		06
09	0511057690	3" ARTICULATED SEED CONDUCTOR	152	12
10	0501010942	3/8" X 1-1/4" BOLT		48
11	0503010025	3/8" SPRING WASHER		48
12	0503010026	3/8" NUT		48
13	0571015773	SUPPORT SEED		04
14	0501011643	3/8 X 1"BOLT		16
15	0503010025	3/8" SPRING WASHER		16
16	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0511058564	ASSEMBLY CSU	166	01
02	0521063064	SUPPORT TOWER SILO SEED CSU		06
03	0501010942	3/8" X 1-1/4" BOLT		12
04	0501010984	FLAT WASHER		12
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12
07	0502010175	HITCH CLAMP		06
08	0501011543	5/8" X 4" BOLT		12
09	0503012412	5/8 UNC SELF LOCKING NUT		12
10	0501010453	FLAT WASHER		12



Item	Code	Description	See page	QT
01	0521064748	05 MOUTHS CSU SUPPORT		02
02	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS		01
03	0503061987	SILO FERTILIZER 05 MOUTHS FRONT MOUNTED		02
04	0503061899	REAR BEAN FERTILIZER ASSY		01
05	0521063401	SEED BOX ONLY FIXING LOCK		06
06	0501010984	FLAT WASHER		06
07	0503010025	3/8" SPRING WASHER		06
08	0503010026	3/8" NUT		06
09	0511057690	3" ARTICULATED SEED CONDUCTOR	152	13
10	0501010942	3/8" X 1-1/4" BOLT		52
11	0503010025	3/8" SPRING WASHER		52
12	0503010026	3/8" NUT		52
13	0571015773	SUPPORT SEED		03
14	0501011643	3/8 X 1"BOLT		12
15	0503010025	3/8" SPRING WASHER		12
16	0503010026	3/8" NUT		12

HYDRAULIC TURBINE ASSEMBLY


0511057728




Item	Code	Description	See page	QT
001	0581011414	BODY RIGHT SUPPORT TURBINE		01
002	0581011413	SOPORTE IZQUIERDO CUERPO DE LA TURBINA		01
003	0503011239	1/2" X 2" BOLT		04
004	0503010019	1/2" SPRING WASHER		04
005	0503010060	1/2" NUT		04
006	0581011415	SUPPORTER FIXING BAR		01
007	0503011082	C1/2" X 1.3/4" SCREW		04
008	0511017302	FLAT WASHER		08
009	0503010019	1/2" SPRING WASHER		04
010	0503010060	1/2" NUT		04
011	0511057700	HYDRAULIC TURBINE	171	01
012	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02
013	0501012140	FLAT WASHER		02
014	0503012412	5/8 UNC SELF LOCKING NUT		02
015	0503015062	TUBE		03
016	0503031576	ELBOW		04
017	0521018615	HOSE 4 X 1300		02
018	0503011372	102 TO 121 CLAMP		04
019	0511059319	AIR FIXING SUPPORT	172	04
020	0511057347	DISTRIBUTOR VACUUM 4845/5345		02
021	0503013584	VACUUM GAUGE		01
022	0571019552	SUPPORT VACUUM		01
023	0511057906	HOSE ASSY		01
023A	0511057840	ASSY TURBINE HOSE REAR		01
023AA	0501081247	HOSE 1/2 X 7012 TC-TM		02
023AB	0501080477	HOSE 3/8 X 7012 TC-TM		01
023B	0501053834	MALE QUICK COUPLER	21	02
023C	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
023D	0503033981	ADHESIVE LABEL		01
023E	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN		01

ASSY TURBINE

0521050976



Item	Code	Description	See page	QT
01	0571019978	LEFT BODY		01
02	0571019979	SHAFT FIXER BODY		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2" NUT		04
06	0511059406	TURBINE P.P MOUNTED	173	01
07	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02
08	0501012140	FLAT WASHER		02
09	0503012412	5/8 UNC SELF LOCKING NUT		02
10	0571019552	SUPPORT VACUUM		01
11	0503013584	VACUUM GAUGE		01
12	0571019963	AIR DISTRIBUTOR SUPPORT		04
13	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
14	0503010019	1/2" SPRING WASHER		08
15	0503010060	1/2" NUT		08
16	0521014442	LOWER AIR DISTRIBUTOR SUPPORT		04
17	0511057348	DISTRIBUTOR VACUUM		02
18	0503031576	ELBOW		02
19	0503010371	5/16" X 1" BOLT		08
20	0503010179	LOCK WASHER		08
21	0503010337	5/16" NUT		08
22	0581012166	HOSE		02
23	0503011372	102 TO 121 CLAMP		04
24	0511057906	HOSE ASSY		01
25	0503015062	TUBE		01




Item	Code	Description	See page	QT
001	0581011414	BODY RIGHT SUPPORT TURBINE		01
002	0581011413	SOPORTE IZQUIERDO CUERPO DE LA TURBINA		01
003	0503011239	1/2" X 2" BOLT		04
004	0503010019	1/2" SPRING WASHER		04
005	0503010060	1/2" NUT		04
006	0581011415	SUPPORTER FIXING BAR		01
007	0503011082	C1/2" X 1.3/4" SCREW		04
008	0511017302	FLAT WASHER		08
009	0503010019	1/2" SPRING WASHER		04
010	0503010060	1/2" NUT		04
011	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02
012	0501012140	FLAT WASHER		02
013	0503012412	5/8 UNC SELF LOCKING NUT		02
014	0561011377	HOSE 4 X 2200		02
015	0503011372	102 TO 121 CLAMP		02
016	0503015062	TUBE		03
017	0503013584	VACUUM GAUGE		01
018	0511059319	AIR FIXING SUPPORT	172	06
018A	0571019403	STAPLE FIXER		01
018B	0503010025	3/8" SPRING WASHER		04
018C	0503010026	3/8" NUT		04
018D	0501013518	FLAT WASHER		02
018E	0571019921	AIR SUPPORT FIXATION		01
018F	0503010237	3/8" X 1" BOLT		02
019	0511059090	VACUUM 8B LEFT DISTRIBUTOR		02
020	0571013731	VACUUM GAUGE SUPPORT		01
021	0511057906	HOSE ASSY		01
021A	0511057840	ASSY TURBINE HOSE REAR		01
021B	0501053834	MALE QUICK COUPLER	21	02
021BA	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
021BB	0503011882	MALE QUICK COUPLER CAP		01

Item	Code	Description	See page	QT
021C	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
021D	0503033981	ADHESIVE LABEL		01
021E	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN		01
021EA	0503018799	QUICK COUPLING		01
021EB	0503011883	QUICK CONNECTION COVER		01
022	0511059406	TURBINE P.P MOUNTED	173	01

REAR FIXING TURBINE ASSY

0511053218




Item	Code	Description	See page	13 L
001	0571019979	SHAFT FIXER BODY		01
002	0571019978	LEFT BODY		01
003	0551019213	FLAT WASHER		02
004	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
005	0503010019	1/2" SPRING WASHER		02
006	0503010060	1/2" NUT		02
007	0511057700	HYDRAULIC TURBINE	171	01
008	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02
009	0501012140	FLAT WASHER		02
010	0503012412	5/8 UNC SELF LOCKING NUT		02
011	0503015062	TUBE		03
012	0503031576	ELBOW		04
013	0521018615	HOSE 4 X 1300		02
014	0503011372	102 TO 121 CLAMP		04
015	0571019963	AIR DISTRIBUTOR SUPPORT		04
016	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
017	0501013519	FLAT WASHER		08
018	0503010019	1/2" SPRING WASHER		08
019	0503010060	1/2" NUT		08
020	0521014442	LOWER AIR DISTRIBUTOR SUPPORT		04
021	0503010371	5/16" X 1" BOLT		08
022	0503010179	LOCK WASHER		08
023	0503010337	5/16" NUT		08
024	0511057785	VACUUM DISTRIBUTOR		02
025	0502012702	BODY SUPPORT CLAMP		02
026	0503010481	BOLT		01
027	0503010025	3/8" SPRING WASHER		01
028	0503010026	3/8" NUT		01
029	0503010371	5/16" X 1" BOLT		02
030	0501010984	FLAT WASHER		02
031	0501010694	FLAT WASHER		02


REAR FIXING TURBINE ASSY

0511053218


Item	Code	Description	See page	13 L
032	0503010179	LOCK WASHER		02
033	0503010337	5/16" NUT		02
034	0503013584	VACUUM GAUGE		01
035	0521063404	SUPPORT FIXER HOSE		01
036	0501010452	5/8" X 5" BOLT		01
037	0503010027	5/8" SPRING WASHER		01
038	0503010013	5/8" NUT		01
039	0501081811	3/8 X 7100 TC-TM HOSE ASSY		01
040	0501081810	HOSE 1/2 X 6200 TC-TM		02
041	0571013731	VACUUM GAUGE SUPPORT		01




Item	Code	Description	See page	QT
01	0501054983	NIPPLE HIDRAULIC MOTOR	174	01
02	0503010025	3/8" SPRING WASHER		10
03	0503010026	3/8" NUT		08
04	0521044613	FAN 480X50 (HIDRAULIC)	175	01
05	0503010143	1/4" SPRING WASHER		01
06	0503010849	3/8" X 1-1/2" BOLT		02
07	0531018764	FLAT WASHER		01
08	0503011104	M6 X 1" BOLT		01
09	0503012722	0.16" X 0.4" BLIND RIVET		20
10	0521065858	TURBIN SUPPORT		01
11	0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE	176	01
12	0561010634	VALVE SUPPORT ASSY		01
13	0503010237	3/8" X 1" BOLT		06
14	0503010206	3/8" X 1/2" BOLT		02
15	0571018577	COVER SNAIL TURBINE		01
16	0521066237	SNAIL MECHANICAL TURBINE HIDRAULIC		01
17	0503010358	5/16" X 5/8" BOLT		02
18	0503010179	LOCK WASHER		02
19	0503010337	5/16" NUT		02
20	0501080125	HOSE 1/2 X 500 TR TR		02
21	0501080635	3/8" X 19" TR-TR HOSE		01
22	0521018517	FLAT WASHER		02
23	0503031649	CONECTOR CENTER		01




Item	Code	Description	See page	QT
01	0571019403	STAPLE FIXER		01
02	0503010025	3/8" SPRING WASHER		04
03	0503010026	3/8" NUT		04
04	0501013518	FLAT WASHER		02
05	0571019921	AIR SUPPORT FIXATION		01
06	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE		01
02	0501011460	7/8 NF REDUCTION NIPPLE		04
03	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
04	0503010392	2-046 N 3006 9B O'RING		01
05	0581012096	ROUND SLEEVE		02
06	0503015420	VALVE ANTI-CAVITACAO CV10208TN5		01
07	0521050154	TURBINE P.P WITH HOLE	177	01
08	0503031087	ADHESIVE LABEL		01
09	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
10	0501010694	FLAT WASHER		02
11	0503010143	1/4" SPRING WASHER		02
12	0503010144	1/4" NUT		02
13	0503010190	2-114 N 3006-9B O'RING		04
14	0501081235	1/2 X 650 TR- TC HOSE		01
15	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01




Item	Code	Description	See page	QT
01	0503012871	HYDRAULIC MOTOR		01
02	0531018770	R 3/4"UNF X R 1/4"BSP ELBOW		01
03	0561016941	3/4" NUT		01
04	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
05	0541011065	3/4"UNF X R1/4BSP19FPP X43.5 NIPPLE		01
06	3914103037	TEFLON 50M/M BRANCO		0,001RI



Item	Code	Description	See page	QT
01	0571016947	DISC FRONT TURBINE		01
02	0571016949	DISC REAR TURBINE		01
03	0521065171	HUB FLANGE		01
04	0571016950	DISC STRENGTHENING TURBINE		01
05	0571016951	FLIP TURBINE		10
06	0503012651	M6 X 1" BOLT		05
07	0503010143	1/4" SPRING WASHER		05
08	0503011776	M6 SELF ADJUSTINGNUT		05




Item	Code	Description	See page	QT
01	0503012291	BLOCK COMMAND		01
02	0501010590	NIPPLE		04
03	0503010045	O'RING		04
04	0541011066	3/4" UNF X 43.5 NIPPLE		01
05	0503010190	2-114 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01

DRAWBAR TURNBUCKLE

0511050906




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0521062278	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	09 L
01	0503016555	9 ROW SIMPLE MONITOR CABLE		01
02	0503017602	MONITOR PLANT PM400		01
03	0503016234	TRIMBLE FIXING WINDOW		01
04	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
05	0571012196	MOUNTING BRACKET PM 400		01
06	0503017443	ANTENNA GPS PM 400		01
07	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		135
08	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
09	0503010669	FLAT WASHER		02
10	0503010668	3/16" SPRING WASHER		02
11	0503010667	3/16" NUT		02

10 ROW SEED MONITOR


0501059537




Item	Code	Description	See page	QT
01	0501059537	10 ROW SEED MONITOR	180	01
01A	0503016556	10 ROW SIMPLE MONITOR CABLE		01
01B	0503016552	UNIQUE CABLE PM 400		01
01C	0503015481	MONITOR PLANT PM400		01
01D	0503016234	TRIMBLE FIXING WINDOW		01
01E	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
01F	0571012196	MOUNTING BRACKET PM 400		01
01G	0503017443	ANTENNA GPS PM 400		01
01H	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		01
02	0501059537	10 ROW SEED MONITOR	180	01
02.	0501058973	CONJ SENSOR ELECTRIC SENSOR Ø25MM		10
02A	0503015219	CONJ SENSOR ELECTRIC SENSOR Ø25MM		10
02B	0503013100	NYLON CLAMP		30
02C	0503034030	MANGO		10
02D	0503010368	1.1/2" X 2" X 12.2" HOSE		10
02E	0571013891	CONVEYOR FIXING GLOVE		10
02F	0503010243	CLAMP		10
03	0501058972	ASSEMBLY SENSOR ELECTRONIC		10
03A	0503015218	SENSOR FOTOELE PM 400		10
03B	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		30
04	0571014383	GUTTER		02
05	0571018663	SUPPORT GUTTER		04
06	0501011643	3/8 X 1" BOLT		06
07	0501010984	FLAT WASHER		06
08	0503010025	3/8" SPRING WASHER		06
09	0503010026	3/8" NUT		06



Item	Code	Description	See page	11 L
01	0503016557	11 ROW SIMPLE MONITOR CABLE		01
02	0503017602	MONITOR PLANT PM400		01
03	0503016234	TRIMBLE FIXING WINDOW		01
04	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
05	0571012196	MOUNTING BRACKET PM 400		01
06	0503017443	ANTENNA GPS PM 400		01
07	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		165
08	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
09	0503010669	FLAT WASHER		02
10	0503010668	3/16" SPRING WASHER		02
11	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0501059539	12 ROW SEED MONITOR	182	01
01A	0503016558	12 ROW SIMPLE CABLE MONITORING		01
01B	0503016552	UNIQUE CABLE PM 400		01
01C	0503015481	MONITOR PLANT PM400		01
01D	0503016234	TRIMBLE FIXING WINDOW		01
01E	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
01F	0571012196	MOUNTING BRACKET PM 400		01
01G	0503017443	ANTENNA GPS PM 400		01
01H	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		01
02	0501059539	12 ROW SEED MONITOR	182	01
02.	0501058973	CONJ SENSOR ELECTRIC SENSOR Ø25MM		10
02A	0503015219	CONJ SENSOR ELECTRIC SENSOR Ø25MM		10
02B	0503013100	NYLON CLAMP		30
02C	0503034030	MANGO		10
02D	0503010368	1.1/2" X 2" X 12.2" HOSE		10
02E	0571013891	CONVEYOR FIXING GLOVE		10
02F	0503010243	CLAMP		10
03	0501058972	ASSEMBLY SENSOR ELECTRONIC		10
03A	0503015218	SENSOR FOTOELE PM 400		10
03B	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		30
04	0571018391	GUTTER 25 X 58 X 1200		04
05	0571018663	SUPPORT GUTTER		08
06	0501011643	3/8 X 1"BOLT		08
07	0501010984	FLAT WASHER		08
08	0503010025	3/8" SPRING WASHER		08
09	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0503016559	13 ROW SIMPLE CABLE MONITORING		01
02	0503017602	MONITOR PLANT PM400		01
03	0503016234	TRIMBLE FIXING WINDOW		01
04	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
05	0571012196	MOUNTING BRACKET PM 400		01
06	0503017443	ANTENNA GPS PM 400		01
07	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		210
08	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
09	0503010669	FLAT WASHER		02
10	0503010668	3/16" SPRING WASHER		02
11	0503010667	3/16" NUT		02



Item	Code	Description	See page	QT
001	0503033889	LABEL ADHESIVE		03
002	0503033854	ADHESIVE LABEL		03
003	0503033853	ADHESIVE LABEL		02
004	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
005	0503031565	ADHESIVE LABEL CARE		02
006	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
007	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
008	0503032930	ADHESIVE LABEL DANGER		04
009	0503031425	ADHESIVE LABEL ATTENTION		02
010	0503031087	ADHESIVE LABEL		01
011	0503031942	ADHESIVE LABEL		01
012	0503031669	ADHESIVE LABEL		01
013	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
014	0503034249	ADHESIVE LABEL TABLE PLANTS		02
015	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
016	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER		01
017	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER		04
018	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM		02
019	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM		02
020	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
021	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
022	0503033422	ADHESIVE LABEL		02
023	0503032979	ADHESIVE LABEL LETTERS A B C D		02
024	0503032949	ADHESIVE LABEL		01
025	0503031428	READ MANUAL DECAL		01
026	0503034500	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
02	0503031565	ADHESIVE LABEL CARE		02
03	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
04	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
05	0503032930	ADHESIVE LABEL DANGER		04
06	0503031425	ADHESIVE LABEL ATTENTION		02
07	0503031087	ADHESIVE LABEL		01
08	0503031942	ADHESIVE LABEL		01
09	0503031669	ADHESIVE LABEL		01
10	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
11	0503034249	ADHESIVE LABEL TABLE PLANTS		02
12	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
13	0503033889	LABEL ADHESIVE		03
14	0503033854	ADHESIVE LABEL		03
15	0503033853	ADHESIVE LABEL		02
16	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		04
17	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
18	0503033421	ADHESIVE LABEL 7 NUMBER FOR PLANTING		02
19	0503032979	ADHESIVE LABEL LETTERS A B C D		02
20	0503032949	ADHESIVE LABEL		01
21	0503031428	READ MANUAL DECAL		01
22	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER		02
23	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER		01
24	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0581011414	BODY RIGHT SUPPORT TURBINE		01
02	0581011413	SOPORTE IZQUIERDO CUERPO DE LA TURBINA		01
03	0503011239	1/2" X 2" BOLT		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2" NUT		04
06	0581011415	SUPPORTER FIXING BAR		01
07	0503011082	C1/2" X 1.3/4" SCREW		04
08	0511017302	FLAT WASHER		08
09	0503010019	1/2" SPRING WASHER		04
10	0503010060	1/2" NUT		04
11	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02
12	0501012140	FLAT WASHER		02
13	0503012412	5/8 UNC SELF LOCKING NUT		02
14	0503015062	TUBE		03
15	0503031576	ELBOW		02
16	0561011377	HOSE 4 X 2200		02
17	0503011372	102 TO 121 CLAMP		02
18	0511059319	AIR FIXING SUPPORT	172	04
18A	0571019403	STAPLE FIXER		01
18B	0503010025	3/8" SPRING WASHER		04
18C	0503010026	3/8" NUT		04
18D	0501013518	FLAT WASHER		02
18E	0571019921	AIR SUPPORT FIXATION		01
18F	0503010237	3/8" X 1" BOLT		02
19	0511057347	DISTRIBUTOR VACUUM 4845/5345		02
20	0503013584	VACUUM GAUGE		01
21	0571013731	VACUUM GAUGE SUPPORT		01
22	0511057906	HOSE ASSY		01
22A	0511057840	ASSY TURBINE HOSE REAR		01
22B	0501053834	MALE QUICK COUPLER	21	02
22BA	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01


HYDRAULIC TURBINE ASSEMBLY

0511059400

Item	Code	Description	See page	QT
22BB	0503011882	MALE QUICK COUPLER CAP		01
22C	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
22D	0503033981	ADHESIVE LABEL		01
22E	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN		01
22EA	0503018799	QUICK COUPLING		01
22EB	0503011883	QUICK CONNECTION COVER		01
23	0511059406	TURBINE P.P MOUNTED	173	01



Item	Code	Description	See page	QT
01	0511057774	CEAC ASSY		01
01A	0503019629	COMMAND WHIP		01
01B	0503017852	TRANSMISSION DRIVING		01
01C	0503017853	TRANSMISSION DRIVING		01
01D	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		06
01E	0501010984	FLAT WASHER		06
01F	0503013357	3/8" SELF-ADJUSTING NUT		06
01G	0503016455	SUPPORT FUSE		01
01H	0503014591	RING CONNECTOR		02
01I	0503013146	FUSE		01
02	0511031852	CENTRAL COMMAND CEAC		01
02A	0503017847	CENTRAL COMMAND		01
02B	0503017849	CHICOTE FEEDING		01
02C	0503017850	WHIPPING COMMAND TRACTOR		01



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

