

PARTS CATALOGUE




ROW CROP PLANTERS

Code:

0501092846

Product:

COP FLEX 600 SUPREMA P.P - FRAME 4045 - MTH/EPP/APT ISO
MSA/DOUBLE HEADER

**Series:**

S-0115

Revision:

00

Date Revision:

OUTUBRO/2020

PRODUCTS



Code	Description
0521047692	CABECALHO DUPLO COP FLEX 600 SUPREMA - MH/MTH/APT
0111200317	COP FLEX 600 SUP PP 4045/9E450 ESPECIAL S-0115
0111200318	COP FLEX 600 SUP PP 4045/9E450 ESPECIAL S-0115

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.

INDEX

0909095409	COP FLEX 600 SUPREMA P.P - FRAME 4045 WITH DOUBLE HEADER	1
0521047692	DOUBLE HEADER COP FLEX 600 SUPREMA - MH/MTH/APT	2
0909098784	COP FLEX 600 SUPREMA P.P - FRAME 4045 - MASTER	3
0909098802	COP FLEX 600 SUPREMA P.P - FRAME 4045 - SLAVE	4
0521051815	DOUBLE HEADER SEMI MOUNTED MH/MTH/APT	5
0501054694	FLOW DIVIDING VALVE ASSY	6
0511052464	FLOW DIVIDING VALVE	7
0501054061	SEQUENCE VALVE WITH NIPPLES	8
0501053835	FEMALE QUICK COUPLER	9
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	10
0521051805	DOUBLE HEADED HYDRAULIC SYSTEM APT	11
0909099246	LIFTING HYDRAULIC CIRCUIT 9L	12
0909099247	LINE MARKER HYDRAULIC CIRCUIT 9L	13
0909099245	HYDRAULIC CIRCUIT TURBINE 9L	14
0501054863	WELL AND TIRE ASSY	15
0503060414	WHEEL AND TIRE	16
0501051799	STUB SHAFT & HUB ASSY	17
0501028912	BOX WITH DOUBLE HEADER COMPONENTS 9L/MH	18
0909099272	2T HYDRAULIC MARKER ASSY	19
0501050633	MARKER DISC ASSY LINE	20
0511053904	DISC LINE MARKER	21
0511058431	HYDRAULIC CYLINDER	22
0501054258	DRAWBAR ESTABILIZER ASSY	23
0501040364	HOSE SUPPORT 3/4X640 ASSY	24
0501054862	AXIS LOCK RODE ASSY	25
0501051160	TRACTOR HITCH PIN	26
0511056409	TRACTOR HITCH	27
0511050443	WHITH RIGHT WHEEL ASSY WITHOUT TRANSMISSION	28
0511050444	WHITH LEFT WHEEL ASSY WITHOUT TRANSMISSION	29
0501110625	BEARING ARTICULATION WHEEL	30
0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX	31
0511052766	CARRYING WHEEL HUB ASSY	32
0503062158	EEE WHEEL WITH TIRE 700 X 16-10L ASSY	33
0511053424	HEX AXLE ASSEMBLY	34
0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	35
0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8	36
0511053428	COMPLETE HYDRAULIC ASSEMBLY WITHOUT HYDRAULIC MARKER	37
0511053358	VALVE FIXING ASSEMBLY	38
0511056277	HYDRAULIC HOSE FIXING ASSEMBLY	39
0511053384	HYDRAULIC CYLINDER ASSEMBLY	40
0511058411	HYDRAULIC CYLINDER	41
0511053425	HOSE KIT	42
0511053429	COMPLETE RIGHT/LEFT FERTILIZER BOX ASSY	43
0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	44
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	45
0511053430	PLATFORM ASSY	46
0511053356	ASSY LADDER	47
0511053431	HANDRAIL ASSY	48
0521051813	LABEL ASSY 4045 APT/ISO	49
0511056598	MANUAL STORAGE TUBE ASSY	50
0521050976	ASSY TURBINE	51
0511059406	TURBINE PRECISION PLANTING MOUNTED	52
0521050154	TURBINE PRECISION PLANTING WITH HOLE	53




MARCHESAN

INDEX


0511057348	DISTRIBUTOR VACUUM	54
0511057906	HOSE ASSY	55
0511057840	ASSY TURBINE HOSE REAR	56
0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	57
0521051814	ISO 4C FERTILIZER/SEED WITH MONITOR/EPP ASSY	58
0511056972	FILTER HYDAC	59
0511055638	BLOCK FLOW LIMITER	60
0511056974	MOTOR	61
0511056973	PARKER OMP 80 HYDRAULIC MOTOR WITH VALVE	62
0521051808	MASTER/SLAVE MECHANICAL ASSY APT	63
0521051806	FERTILIZER ENGINE SUPPORT APT	64
0511059969	CHAIN TENSIONER	65
0501053788	Q3/4" FASTENER AXLE ASSY	66
0521050273	MOTOR SUPPORT SEED	67
0521051807	MODULE BOX APT	68
0511059348	APT ASSY MODULE BOX	69
0521051278	LIFTING SENSOR SUPPORT FIXING APT	70
0511053436	DRAWBAR ASSY 07/08/09/10 LINES	71
0511053342	SQUARE AXLE ASSEMBLY (730)	72
0501056271	BEARING CLOSED	73
0501056444	BEARING WITH BALL BEARING	74
0521052549	CLAMP	75
0511050906	DRAWBAR TURNBUCKLE	76
0511056736	HOSE SUPPORT	77
0511054601	FULL ARTICULATED TRACTOR HITCH	78
0511053179	TRACTOR HITCH AXLE	79
0909099057	SEED/FERTILIZER ROW ASSY	80
0521051622	FRONT SEED SHORT ROW	81
0521051621	FRONT SEED LONG ROW	82
0511052393	BEARING FOLLOWER ROW ASSY	83
0511050609	BEARING WITH 17Z GEAR ASSY	84
0511050617	FRONT SEED ROW BEARING	85
0511055260	SEED ROW CHAIN TENSIONER	86
0511054635	BEARING AXLE BODY	87
0511057159	TRANSMISSION BOX SEED LINE	88
0511057625	ROW SEED BEARING	89
0511057156	BEARING LINE SEMI MOUNTED	90
0511053024	FERTILIZER SHORT LINE	91
0511053023	LONG FERTILIZER LINE	92
0511053223	FERTILIZER ROW SUPPORT WITH SCREW	93
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	94
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	95
0511053172	LEFT LOW CUBE WITH DISC 15	96
0511053173	CUBE LOW RIGHT WITH DISC 15	97
0511051819	DC 20 SEMI MOUNTED	98
0501054887	20 BLADE DISC WITH FLAT PLAN DISC	99
0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	100
0511052971	CONTROL DEPTH WITH SEMI MOUNTED THREAD	101
0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	102
0511059325	LEFT ARM WHEELS	103
0511059324	RIGHT ARM COATING WHEEL MOUNTED	104
0511051546	CUBE RIGHT CONTROL DEPTH	105
0511051547	LEFT CUBE CONTROL DEPTH	106
0511051583	DEPTH WHEEL HUB SEMIFINISHED	107
0501052908	COMPACTOR WHEEL WITH BEARING	108

INDEX


0511055819	DEPTH WHIT AROS BAND	109
0501054482	DEPTH CONTROL LEFT ARM WITH TIRE	110
0501054481	RIGHT ARM DEPTH CONTROL WITH WHEEL	111
0501056435	LEFT CONTROL ARM DEPTH WITHOUT WHEEL	112
0501056430	ARM RIGHT CONTROL DEPTH WITHOUT WHEEL	113
0501052538	DEPTH BAND WITH ARMS	114
0511057509	SEED RESERVOIR PNEUMATIC ASSY	115
0521051810	LEFT REAR LINE SEED - EPP	116
0521051811	RIGHT REAR LINE SEED - EPP	117
0521051809	ASSY P.P V-SET FOR EPP	118
0521051253	TRANSMISSION BOX PRECISION PLANTING LEFT EPP/APT	119
0511057491	PRECISION PLANTING SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	120
0511057153	DDD LEFT SUPREMA PRECISION PLANTING	121
0511057154	DDD RITGH SUPREMA PRECISION PLANTING	122
0521050772	FUSE ROD WITH CONDUCTOR	123
0501110860	ROD WITH BEAK	124



Item	Code	Description	See page	QT
01	0521047692	DOUBLE HEADER COP FLEX 600 SUPREMA - 2 MH/MTH/APT		01
02	0909098784	COP FLEX 600 SUPREMA P.P - FRAME 4045 - 3 MASTER		01
03	0909098802	COP FLEX 600 SUPREMA P.P - FRAME 4045 - 4 SLAVE		01




Item	Code	Description	See page	QT
01	0521051815	DOUBLE HEADER SEMI MOUNTED MH/MTH/APT	5	01
02	0501054863	WELL AND TIRE ASSY	15	02
03	0501028912	BOX WITH DOUBLE HEADER COMPONENTS 9L/MH	18	01




Item	Code	Description	See page	QT
01	0521061932	FRAME COP FLEX 9 (4045)		01
02	0511050443	WHITH RIGHT WHEEL ASSY WITHOUT 28		02
03	0511050444	WHITH LEFT WHEEL ASSY WITHOUT 29		02
04	0511053424	HEX AXLE ASSEMBLY	34	01
05	0511053428	COMPLETE HYDRAULIC ASSEMBLY WITHOUT 37		01
06	0511053429	COMPLETE RIGHT/LEFT FERTILIZER BOX ASSY	43	01
07	0511053430	PLATFORM ASSY	46	01
08	0511053356	ASSY LADDER	47	01
09	0511053431	HANDRAIL ASSY	48	01
10	0521051813	LABEL ASSY 4045 APT/ISO	49	01
11	0503011957	PMC 596-S NYLON LUG		02
12	0503010371	5/16" X 1" BOLT		04
13	0503010179	5/16" ZN SPRING WASHER		04
14	0503010337	5/16" NUT		04
15	0511056598	MANUAL STORAGE TUBE ASSY	50	01
16	0503034003	SERIAL NUMBER TAG 61 X 118		01
17	0503010001	3.2 X 5.5 RIVET		04
18	0503010246	CLAMP		09
19	0521050976	ASSY TURBINE	51	01
20	0571019716	ADAPTER		09
21	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		09
22	0521051814	ISO 4C FERTILIZER/SEED WITH MONITOR/EPP ASSY	58	01
23	0521051808	MASTER/SLAVE MECHANICAL ASSY APT	63	01
24	0571017368	SUPPORT GUTTER		04
25	0571013990	GUTTER		02
26	0501011643	3/8 X 1" BOLT		04
27	0501010984	FLAT WASHER		04
28	0503010025	3/8" SPRING WASHER		04

Item	Code	Description	See page	QT
29	0503010026	3/8" NUT		04
30	0511053436	DRAWBAR ASSY 07/08/09/10 LINES	71	01
31	0511053342	SQUARE AXLE ASSEMBLY (730)	72	01
32	0521052549	CLAMP	75	18
33	0511050906	DRAWBAR TURNBUCKLE	76	01
34	0503032624	SILO FERTILIZER GUTTER		04
35	0503031436	AIR DITRIBUTOR PUMP		04
36	0521013022	TRANSPORT LOCK		04
37	0501068994	0.3" X 3.1"LOCK PIN		04
38	0503030168	HAIR PIN		04
39	0501047895	ROD STOP		04
40	0501047885	ROD STOP		04
41	0501047886	ROD STOP		04
42	0501047887	ROD STOP		04
43	0511056736	HOSE SUPPORT	77	01
44	0511054601	FULL ARTICULATED TRACTOR HITCH	78	01
45	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
46	0511053179	TRACTOR HITCH AXLE	79	01
47	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	10	01
48	0503010045	2-116 N 3006-9B O'RING		01
49	0541010080	TERMINAL R.1 / 2 NPT		01
50	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01
51	0581013729	NIPLE 1 / 2NPT		01
52	0503014120	CHAIN		01
53	0503014321	CABLE STEEL SHACKLE		02
54	0909099057	SEED/FERTILIZER ROW ASSY	80	09




Item	Code	Description	See page	QT
01	0521061932	FRAME COP FLEX 9 (4045)		01
02	0511050443	WHITH RIGHT WHEEL ASSY WITHOUT 28		02
03	0511050444	WHITH LEFT WHEEL ASSY WITHOUT 29		02
04	0511053424	HEX AXLE ASSEMBLY	34	01
05	0511053428	COMPLETE HYDRAULIC ASSEMBLY WITHOUT 37		01
06	0511053429	COMPLETE RIGHT/LEFT FERTILIZER BOX ASSY	43	01
07	0511053430	PLATFORM ASSY	46	01
08	0511053356	ASSY LADDER	47	01
09	0511053431	HANDRAIL ASSY	48	01
10	0521051813	LABEL ASSY 4045 APT/ISO	49	01
11	0503011957	PMC 596-S NYLON LUG		02
12	0503010371	5/16" X 1" BOLT		04
13	0503010179	5/16" ZN SPRING WASHER		04
14	0503010337	5/16" NUT		04
15	0511056598	MANUAL STORAGE TUBE ASSY	50	01
16	0503034003	SERIAL NUMBER TAG 61 X 118		01
17	0503010001	3.2 X 5.5 RIVET		04
18	0503010246	CLAMP		09
19	0521050976	ASSY TURBINE	51	01
20	0571019716	ADAPTER		09
21	0503014120	CHAIN		01
22	0503014321	CABLE STEEL SHACKLE		02
23	0521051808	MASTER/SLAVE MECHANICAL ASSY APT	63	01
24	0571017368	SUPPORT GUTTER		04
25	0571013990	GUTTER		02
26	0501011643	3/8 X 1" BOLT		04
27	0501010984	FLAT WASHER		04
28	0503010025	3/8" SPRING WASHER		04
29	0503010026	3/8" NUT		04

Item	Code	Description	See page	QT
30	0511053436	DRAWBAR ASSY 07/08/09/10 LINES	71	01
31	0511053342	SQUARE AXLE ASSEMBLY (730)	72	01
32	0521052549	CLAMP	75	18
33	0511050906	DRAWBAR TURNBUCKLE	76	01
34	0503032624	SILO FERTILIZER GUTTER		04
35	0503031436	AIR DITRIBUTOR PUMP		04
36	0521013022	TRANSPORT LOCK		04
37	0501068994	0.3" X 3.1"LOCK PIN		04
38	0503030168	HAIR PIN		04
39	0501047895	ROD STOP		04
40	0501047885	ROD STOP		04
41	0501047886	ROD STOP		04
42	0501047887	ROD STOP		04
43	0511056736	HOSE SUPPORT	77	01
44	0511054601	FULL ARTICULATED TRACTOR HITCH	78	01
45	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
46	0511053179	TRACTOR HITCH AXLE	79	01
47	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	10	01
48	0503010045	2-116 N 3006-9B O'RING		01
49	0541010080	TERMINAL R.1 / 2 NPT		01
50	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01
51	0581013729	NIPLE 1 / 2NPT		01
52	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		09
53	0909099057	SEED/FERTILIZER ROW ASSY	80	09



Item	Code	Description	See page	QT
01	0511064304	FRAME HEADER DOUBLE		01
02	0511064219	FORK WHEEL DRAWBAR DOUBLE		02
03	0503010007	3982/3920 ROLLER BEARING		02
04	0503010059	33287/33462 ROLLER BEARING		02
05	0503013106	SEAL 00085-B		02
06	0502040080	2.1/2" SLOTTED NUT		02
07	0503011345	1/4" X 3-1/2" COTTERPIN		02
08	0541013225	WHEEL BOX COVER		02
09	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		12
10	0503011444	SPRING WASHER		12
11	1882970002	GREASE SOAP		00
12	0503010002	1800 GREASE FITTING		03
13	0511064222	FIXER SUPPORT BOLT HOSE		04
14	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
15	0503010019	1/2" SPRING WASHER		08
16	0503010060	1/2" NUT		08
17	0531017560	DISPLAYED IDENTIFICATION		14
18	0502012702	BODY SUPPORT CLAMP		10
19	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		10
20	0503010180	7/16" SPRING WASHER		10
21	0521063568	SUPPORT VALVE		01
22	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
23	0501010984	FLAT WASHER		04
24	0503010025	3/8" SPRING WASHER		02
25	0503010026	3/8" NUT		02
26	0501054694	FLOW DIVIDING VALVE ASSY	6	01
27	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
28	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
29	0503010143	1/4" SPRING WASHER		02
30	0503010144	1/4" NUT		02
31	0511052464	FLOW DIVIDING VALVE	7	01


Item	Code	Description	See page	QT
32	0501054061	SEQUENCE VALVE WITH NIPPLES	8	01
33	0503010237	3/8" X 1" BOLT		02
34	0503010025	3/8" SPRING WASHER		02
35	0503010026	3/8" NUT		02
36	0503062157	HEADER JACK		01
37	0521010549	COUPLING SHAFT		01
38	0503030168	HAIR PIN		01
39	0503034003	SERIAL NUMBER TAG 61 X 118		01
40	0503010001	3.2 X 5.5 RIVET		04
41	0501053835	FEMALE QUICK COUPLER	9	14
42	0503010217	501040 CLAMPING RING (FOR AXLE)		28
43	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	10	07
44	0521051805	DOUBLE HEADED HYDRAULIC SYSTEM APT	11	01
45	0909099246	LIFTING HYDRAULIC CIRCUIT 9L	12	01
46	0909099247	LINE MARKER HYDRAULIC CIRCUIT 9L	13	01
47	0909099245	HYDRAULIC CIRCUIT TURBINE 9L	14	01




Item	Code	Description	See page	QT
01	0503012481	FLOW DIVIDING VALVE		01
02	0503030923	3/4" UNF X 13/16UN OFS X 40 NIPPLE		03
03	0503010190	2-114 N 3006-9B O'RING		03

FLOW DIVIDING VALVE


0511052464




Item	Code	Description	See page	QT
01	0503013791	DOUBLE MOTOR		01
02	0541018940	7/8 NF X R 1 BSPT X 55 NIPPLE		01
03	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
04	0503010025	3/8" SPRING WASHER		04
05	0503011051	M10 X 0.6" NUT		04




Item	Code	Description	See page	QT
01	0501011460	7/8 NF REDUCTION NIPPLE		02
02	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0503011883	QUICK CONNECTION COVER		01
02	0503011628	FEMALE QUICK COUPLER		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0501053835	FEMALE QUICK COUPLER	9	04
02	0503010217	501040 CLAMPING RING (FOR AXLE)		08
03	0503010013	5/8" NUT		02
04	0503010027	5/8" SPRING WASHER		02
05	0501080933	HOSE 1/2 X 4200 TR-TM		02
06	0501080214	HOSE 1/2 X 800 TR-TM		01
07	1163890552	HOSE 1/2 DIN EN 853 2SN/SAE 100R2AT		01
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
09	0503010019	1/2" SPRING WASHER		02
10	0503010060	1/2" NUT		02
11	0581015257	FLOW LIMITING BLOCK SUPPORT		01
12	0511064222	FIXER SUPPORT BOLT HOSE		01
13	0501080327	HOSE 1/2 X 1500 TR-TR		01
14	0501080120	1/2" X 400 TR-TR HOSE		01
15	0501010452	5/8" X 5" BOLT		02
16	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	10	02




Item	Code	Description	See page	QT
01	0501080512	1/2" X 1400 TR-TM HOSE		02
02	0501080796	1/2" X 1400 TC-TM HOSE		02
03	0501080678	HOSE 1/2 X 3800 TC-TM		02
04	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	10	02




Item	Code	Description	See page	QT
01	0501080440	HOSE 3/8 X 1350 TR-TM		04
02	0501080185	HOSE 1/2 X 4000 TR-TM		02
03	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	10	02



Item	Code	Description	See page	QT
01	0501080512	1/2" X 1400 TR-TM HOSE		04
02	0501080796	1/2" X 1400 TC-TM HOSE		02
03	0501080185	HOSE 1/2 X 4000 TR-TM		03
04	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	10	03




Item	Code	Description	See page	QT
01	0503060414	WHEEL AND TIRE	16	01
02	0501051799	STUB SHAFT & HUB ASSY	17	01
03	0531015109	WHEEL AXLE LOCK		02




Item	Code	Description	See page	QT
01	0503012108	RODA 10 LB X 15 X 8F X 203 GCRO		01
02	0503010860	CAMARA AR 11L 15		01
03	0503011469	RIB TIRE 12L		01

STUB SHAFT & HUB ASSY

0501051799



Item	Code	Description	See page	QT
01	0502010908	CARRYING WHEEL HUB	01	
02	0503012159	4.0" X 2.5" X 0.5" SEAL 5144	01	
03	0503010008	ROLAMENTO 3780/37203	01	
04	0503010328	25590/25523 ROLLER BEARING	01	
05	0503012162	5046 BAG SEAL RING	01	
06	0521011209	425 TRANSP WHEEL AXLE	01	
07	0511015949	LOCK NUT	01	
08	0503010329	LOCK WASHER	01	
09	0503010330	KM 9 LOCKNUT	01	
10	0501010086	FLAT WASHER	01	
11	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR	08	
12	0503010064	5/8 UNF CONIC NUT	08	
13	0503011052	1.1/4" X 0.77" CASTLE NUT	02	
14	0503010067	3/16" X 2.1/2" COTTER PIN	02	




Item	Code	Description	See page	QT
01	0511064220	COUPLING SUPPORT DOUBLE DRAWBAR		02
02	0531017551	COUPLING SUPPORT FIXING BASE		02
03	0909099272	2T HYDRAULIC MARKER ASSY	19	01
04	0501069807	FIXER SUPPORT ESTABILIZER		02
05	0521014754	FIXING BASE ESTABILIZER		02
06	0501110262	245 ADJUSTMENT NUT		01
07	0501069529	653 TURNBUCKLE		02
08	0501054258	DRAWBAR ESTABILIZER ASSY	23	01
09	0511064217	TURNBUCKLE WITH EAR		02
10	0501068300	TURNBUCKLE WITH EAR		02
11	0501061056	RH LOCKNUT WITH HANDLER		04
12	0511060916	TURNBUCKLE WITH GLOVE		01
13	0511061029	TURNBUCKLE WITH GLOVE		01
14	0511060919	TURNBUCKLE WITH GLOVE		01
15	0501066284	SUPPORT FRONT TURNBUCKLE FIXER		02
16	0521012329	3/4 UNC X 130 X 173 FASTENER		02
17	0502012702	BODY SUPPORT CLAMP		02
18	0511064228	HOSE HOLDER		02
19	0511064310	FIXER PLATE FASTENER		02
20	0521014021	1/2" X 4.5" X 5.4" FASTENER		06
21	0501040364	HOSE SUPPORT 3/4X640 ASSY	24	02
22	0521062077	SUPPORT STABILIZER REAR RIGHT DRAWBAR		02
23	0511064353	FASTENER		02
24	0501013233	5/8" X 2-3/4" BOLT		08
25	0503012412	5/8 UNC SELF LOCKING NUT		08
26	0501080779	1/2 X 1500 TM-TM HOSE		02
27	0501080844	3/8 X 5500 TC-TM HOSE		04
28	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	10	04
29	0501053835	FEMALE QUICK COUPLER	9	02
30	0511053179	TRACTOR HITCH AXLE	79	01
31	0501054862	AXIS LOCK RODE ASSY	25	02


Item	Code	Description	See page	QT
32	0501051160	TRACTOR HITCH PIN	26	02
33	0511056409	TRACTOR HITCH	27	01
34	0571017510	GLOVE ARTICULATED HITCH		01
35	0501014172	1" X 8" BOLT		08
36	0503010012	1" SPRING WASHER		08
37	0501010059	1.5/8 NUT		08
38	0521010572	0.9" X 2.9" COUPLING SHAFT		02
39	0503030085	LOCK PIN		02
40	0503010019	1/2" SPRING WASHER		20
41	0503010060	1/2" NUT		20
42	0503011135	BOLT		04
43	0503010180	7/16" SPRING WASHER		04
44	0521010594	1.1" X 4.1" COUPLING SHAFT		06
45	0503031035	HAIR PIN		07
46	0503010797	3/4" X 4" BOLT		08
47	0503010023	3/4" SPRING WASHER		11
48	0503010014	3/4" NUT		11
49	0503010002	1800 GREASE FITTING		11
50	0501100045	WOODEN BOX		01
51	0511015573	2.07" X 1.6" TRANSPORT LOCK		02
52	0501068994	0.3" X 3.1" LOCK PIN		02
53	0503030168	HAIR PIN		02

2T HYDRAULIC MARKER ASSY

0909099272




Item	Code	Description	See page	QT
01	0511061022	ROW MARKER SUPPORT		02
02	0511061021	SUPPORT FASTENER		04
03	0502010175	HITCH CLAMP		08
04	0501010216	3/4" X 4-1/2" BOLT		16
05	0503010023	3/4" SPRING WASHER		16
06	0503010014	3/4" NUT		16
07	0511060013	ROW MARKER ARM		02
08	0521013347	1.1/4" X 8.4" AXLE		02
09	0501019435	32 X 50 X 1.5 FLAT WASHER		08
10	0503010523	1/4" X 2" COTTERPIN		08
11	0511060014	ROW MARKER ARM		02
12	0521011142	1.1/4" X 7.5" AXLE		04
13	0521011141	1.1/4" X 6.5" AXLE		02
14	0511060010	1400 TURNBUCKLE		02
15	0501050633	MARKER DISC ASSY LINE	20	02
16	0521012324	1/2" X 3.2" X 2.54" FASTENER		04
17	0511017302	FLAT WASHER		08
18	0503010019	1/2" SPRING WASHER		08
19	0503010060	1/2" NUT		08
20	0511058431	HYDRAULIC CYLINDER	22	02
21	0503010002	1800 GREASE FITTING		04
22	0501010617	3/4" NIPPLE		04
23	0511018012	HIDRAULIC ADAPTER		04




Item	Code	Description	See page	QT
01	0511053904	DISC LINE MARKER	21	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01

DISC LINE MARKER


0511053904




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0501067700	2.5" X 25" CYLINDER CASE		01
02	0521066632	EXTENSOR		01
03	0503030384	CON PLUG N-001		02
04	0502012837	PISTON		01
05	0503018005	RING		01
06	0503011109	2-119 N 3006-9B O'RING		01
07	0503010163	D-1500 SCRAPER RING		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503018004	RING		01
11	0503018003	GASKET		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
001	0501069529	653 TURNBUCKLE		01
002	0511062887	RIGHT TURNBUCKLE		01
003	0511062888	LH TURNBUCKLE		01
004	0501061056	RH LOCKNUT WITH HANDLER		01
005	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
001	0501060409	HOSE SOPPORT ASSY		01
002	0503011442	3/4" SPRING WASHER		01
003	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0511064229	LOCK PIN		01
02	0503030978	COMPRES SPRING		01
03	0503010131	3/16" X 1-1/2" COTTERPIN		01
04	0503010292	0.2" X 1.6" SPRING PIN		01




Item	Code	Description	See page	QT
01	0521010681	BUSHING COUPLING BODY		01
02	0502040556	HITCH TURNER		01
03	0521010639	COUPLING SHAFT		01
04	0503010571	1/4" X 1.1/2 COTTERPIN		01

TRACTOR HITCH


0511056409




Item	Code	Description	See page	QT
001	0571017512	HITCH JOINT		01
002	0571017511	SLEEVE HITCH ARTICULATION		01
003	0502040850	U TRACTOR COUPLING		01
004	0571012612	PIVOT SHAFT		01
005	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
006	0503010010	1/4" X 2.1/2" COTTERPIN		01
007	0521010681	BUSHING COUPLING BODY		01
008	0521010639	COUPLING SHAFT		01
009	0503010571	1/4" X 1.1/2 COTTERPIN		01
010	0503016482	BOLT		02
011	0503033731	COMPRESSION SPRING LEFT		02
012	0503011331	3/8 BALL		02
013	0503010002	1800 GREASE FITTING		01
014	1882970002	GREASE SOAP		01
015	0503010378	CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	5750/6850
01	0521063678	WHEEL SUPPORT		01
02	0503011167	M16 X 2 X 30 BOLT		02
03	0511064744	WHEEL FORK		01
04	0501110625	BEARING ARTICULATION WHEEL	30	02
05	0503013232	1/2' BOLT		08
06	0503010019	1/2" SPRING WASHER		08
07	0561013021	BEARING INNER LOK		02
08	0561013022	BEARING EXTERNAL LOCK		02
09	0503010398	501082 CLAMPING RING (FOR AXLE)		02
10	0561013020	KM 12 NUT		02
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED 31 BOX		01
12	0521012190	AXLE LOCK		02
13	0503010027	5/8" SPRING WASHER		02
14	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
15	0511010736	5/8" X 5-1/4" BOLT		04
16	0501013753	FLAT WASHER		04
17	0503010811	5/8" UNF SELF ADJUSTING NUT		04
18	0502012720	WHEEL SUPPORT FIXER		01
19	0503017857	BOLT 5/8 UNF 4		04
20	0503010811	5/8" UNF SELF ADJUSTING NUT		04
21	0501012140	FLAT WASHER		04
22	0501047888	ROD STOP		01




Item	Code	Description	See page	5750/6850
01	0521063678	WHEEL SUPPORT		01
02	0503011167	M16 X 2 X 30 BOLT		02
03	0511065842	LEFT WHEEL FORK		01
04	0501110625	BEARING ARTICULATION WHEEL	30	02
05	0503013232	1/2" BOLT		08
06	0503010019	1/2" SPRING WASHER		08
07	0561013021	BEARING INNER LOK		02
08	0561013022	BEARING EXTERNAL LOCK		02
09	0503010398	501082 CLAMPING RING (FOR AXLE)		02
10	0561013020	KM 12 NUT		02
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED 31 BOX		01
12	0521012190	AXLE LOCK		02
13	0503010027	5/8" SPRING WASHER		02
14	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
15	0511010736	5/8" X 5-1/4" BOLT		04
16	0501013753	FLAT WASHER		04
17	0503010811	5/8" UNF SELF ADJUSTING NUT		04
18	0503017857	BOLT 5/8 UNF 4		04
19	0503010811	5/8" UNF SELF ADJUSTING NUT		04
20	0501012140	FLAT WASHER		04
21	0502012720	WHEEL SUPPORT FIXER		01
22	0501047888	ROD STOP		01




Item	Code	Description	See page	QT
01	0561015879	WHEELED JOINT BEARING		01
02	0561012895	GLOVE 30,16 X 45,32/45,28 X 47		01



Item	Code	Description	See page	QT
01	0511052766	CARRYING WHEEL HUB ASSY	32	01
02	0503062158	EEE WHEEL WITH TIRE 700 X 16-10L ASSY	33	01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503010328	25590/25523 ROLLER BEARING		02
03	0503010804	00547-B SEAL		02
04	0521018363	00547-B SEAL		01
05	0511062015	14Z GEAR WITH FLANGE		01
06	0503010421	5/16" X 1-1/2" BOLT		06
07	0503011444	SPRING WASHER		06
08	0511015949	LOCK NUT		01
09	0503010329	LOCK WASHER		01
10	0503010330	KM 9 LOCKNUT		01
11	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503016518	RUEDA		01
02	0503012114	7.00 X 16 INNER TIRE		01
03	0503012113	PLY TIRE		01

HEX AXLE ASSEMBLY


0511053424




Item	Code	Description	See page	09 L
001	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	35	02
001A	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8	36	01
001AA	0502011987	DOUBLE HOUSING BEARING		01
001AB	0503011410	ROLLER BEARING		02
001AC	0503011105	SEAL RING		01
001B	0511063106	20Z AXLE BEARING DOBLE		01
001C	0503010406	501025 CLAMPING RING (FOR AXLE)		02
001D	0503010365	NUT		02
001E	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
001F	0503010179	5/16" ZN SPRING WASHER		02
001G	0503010337	5/16" NUT		02
002	0531016942	RIGHT HEX AXLE 5/8 X 2050		01
003	0531016943	LEFT HEX AXLE 5/8 X 1900		01
004	0511063123	BUSHING WITH NUT		04
005	0503010834	1/2 X 1 BOLT		04



Item	Code	Description	See page	QT
01	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8	36	01
02	0511063106	20Z AXLE BEARING DOBLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0503010365	NUT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0511053358	VALVE FIXING ASSEMBLY	38	01
02	0511056277	HYDRAULIC HOSE FIXING ASSEMBLY	39	01
03	0511053384	HYDRAULIC CYLINDER ASSEMBLY	40	01
04	0511053425	HOSE KIT	42	01
05	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	10	02

VALVE FIXING ASSEMBLY


0511053358



Item	Code	Description	See page	QT
001	0571010596	SUPPORT VALVE 50/50		01
002	0503010371	5/16" X 1" BOLT		02
003	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
004	0503010179	5/16" ZN SPRING WASHER		02
005	0503010337	5/16" NUT		02
006	0503013791	DOUBLE MOTOR		01
007	0541018940	7/8 NF X R 1 BSPT X 55 NIPPLE		01
008	0551012463	1/2" BSPT X 3/4" UNF X 51 NIPPLE		02
009	0503015075	M10 SPRING WASHER		04
010	0501010984	FLAT WASHER		04
011	0503011051	M10 X 0.6" NUT		04
012	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
013	0503012341	T 7/8" ADAPOR GIRAT NUT		02
014	0541012166	NIPPLE 3/4" UNF X 7/8"		01
015	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01




Item	Code	Description	See page	QT
01	0561017277	OIL CONDUCTOR FIXER PLATE		04
02	0521010718	5/8" U BOLT		04
03	0503010027	5/8" SPRING WASHER		08
04	0503010013	5/8" NUT		08
05	0521065265	OIL CONDUCTOR		04
06	0502012702	BODY SUPPORT CLAMP		04
07	0503011268	3/8" X 2-1/2" BOLT		04
08	0503010025	3/8" SPRING WASHER		04
09	0503010026	3/8" NUT		04
10	0501012140	FLAT WASHER		08



Item	Code	Description	See page	QT
001	0511066351	FLANGE CYLINDER HYDRAULIC FIXER		08
002	0503010834	1/2 X 1 BOLT		16
003	0503010019	1/2" SPRING WASHER		16
004	0511058411	HYDRAULIC CYLINDER	41	04
005	0521010546	1.2" X 5.7" COUPLING SHAFT		04
006	0501017779	32 X 60 X 4.75 FLAT WASHER		08
007	0503010523	1/4" X 2" COTTERPIN		04

HYDRAULIC CYLINDER


0511058411



Item	Code	Description	See page	QT
01	0511066774	2.5" X 28" CYLINDER CASE		01
02	0541017674	TURNBUCLE BODY		01
03	0503030385	CYLINDER PLUG N-002		02
04	0511064408	FORK COP		01
05	0503011094	3/8" X 2" BOLT		01
06	0503010025	3/8" SPRING WASHER		01
07	0503010026	3/8" NUT		01
08	0581010302	RING OF SUPPORT		01
09	0502012822	101.60 END CAP		01
10	0503011061	8-342 BACK-UP RING		02
11	0503010338	2-342 N 3006-9B O'RING		02
12	0503017936	RING		01
13	0503017938	RING GUIDE		01
14	0503017937	GASKET		01
15	0503010761	D-1750 SCRAPER RING		01
16	0581010837	PISTON		01
17	0503010817	1.1/4" SELF LOCKING NUT		01
18	0503015633	SELEMASTER SEALING		01
19	0503018029	2-217 O'RING		01

HOSE KIT


0511053425



Item	Code	Description	See page	QT
001	0501080760	3/8" X 500 TC-TC HOSE		04
002	0501080027	3/8" X 1000 TR-TR HOSE ASSY		03
003	0501080055	3/8" X 1000 TR-TC HOSE		01
004	0501080150	TR-TC HOSE ASSY		02
005	0501080055	3/8" X 1000 TR-TC HOSE		02
006	0501081073	HOSE 1/2 X 4200 TC-TM		02

COMPLETE RIGHT/LEFT FERTILIZER BOX ASSY

0511053429




Item	Code	Description	See page	09 L
01	0511053429	COMPLETE RIGHT/LEFT FERTILIZER BOX ASSY	43	01
01A	0511050936	BOX SUPPORT RIGHT FERTILIZER		01
01Aa	0521062290	RH FERTILIZER SILO SUPORT ASSY		01
02	0511050935	FERTILIZER LEFT BOX SUPPORT		01
02A	0521062291	LH FERTILIZER SILO SUPORT ASSY		01
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	44	05
03A	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		05
03B	0501019851	DISTRIBUTOR FERTILIZER AXLE		10
03C	0521010309	SLEEVE INTER		10
03D	0503030275	AGRICULTURAL BEARING		20
03E	0503031164	RIGHT HELICAL CONDUTOR		10
03F	0501010637	FLAT WASHER		10
03G	0503030303	SUPPORT WASHER		10
03H	0501013774	GREASE SEAL		10
03I	0502011412	18Z CONICAL GEAR		10
03J	0503010523	1/4" X 2" COTTERPIN		10
03K	0503011962	GREASE FITTING		10
03L	0503010003	1845 GREASE FITTING		10
03M	0503012826	CREASE FITTING		10
04	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	45	05
04A	0501110676	SIDE FERTILIZER DISTRIBUTOR		05
04B	0503031165	LEFT HELICAL CONDUTOR		05
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		40
06	0501010984	FLAT WASHER		40
07	0503011443	3/8" SPRING WASHER		40
08	0503010026	3/8" NUT		40
09	0511061759	22Z P12,70 FQ 3/4" GEAR		02
10	0521014167	CONE LOCK		04
11	0551018055	22,65 X 60 SLEEVE		04
12	0551018213	3/4" X 1830 SQUARE SHAFT		01
13	0561018365	SQUARE SHAFT		01


COMPLETE RIGHT/LEFT FERTILIZER BOX ASSY

0511053429


Item	Code	Description	See page	09 L
14	0501053788	Q3/4" FASTENER AXLE ASSY	66	04
14A	0521010691	AXLE FASTENER		04
14B	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		04
14C	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
14D	0503010143	1/4" SPRING WASHER		04
14E	0503010144	1/4" NUT		04
15	0501110392	SILO SUPPORT BEARING		02
16	0521012485	GEAR BOX BEARING AGRICUTURAL		02
17	0503010363	5/16" X 1" BOLT		04
18	0503011444	SPRING WASHER		04
19	0503010337	5/16" NUT		04
20	0503030303	SUPPORT WASHER		02
21	0571010590	FERTILIZER SIDE COVER		10
22	0503010257	1/8" X 1" COTTERPIN		10
23	0503010849	3/8" X 1-1/2" BOLT		16
24	0501010984	FLAT WASHER		24
25	0503010025	3/8" SPRING WASHER		16
26	0503010026	3/8" NUT		16
27	0503060664	FERTILIZER HOPPER WITH 5 TRUNNELS		02
28	0571013223	ANGLE BAR		04



Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	09 L
001	0521061861	PLATFORM FIXER		02
002	0521062061	CENTRAL ARTICULACION		01
003	0521062062	CENTRAL ARTICULACION		01
004	0503010849	3/8" X 1-1/2" BOLT		08
005	0501010984	FLAT WASHER		16
006	0503010025	3/8" SPRING WASHER		08
007	0503010026	3/8" NUT		08
008	0511069665	PLATFORM RIGHT PST4 9		01
009	0521062323	PLATFORM LEFT PST4 9		01
010	0521010549	COUPLING SHAFT		04
011	0503010300	5/32" X 1" COTTERPIN		04
012	0503011333	COVER FIXER		02
013	0503010274	5/32"X 2" COTTERPIN		02
014	0551019115	LOCKING PLATFORM FIXATION		02
015	0501010096	3/8" X 2" BOLT		02
016	0501010984	FLAT WASHER		02
017	0503013357	3/8" SELF-ADJUSTING NUT		02
018	0521061676	PLATFORM PROLONG		02
019	0511069664	PLATFORM EXTENSION LOCK		02
020	0503010257	1/8" X 1" COTTERPIN		02
021	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
022	0502012739	PLATFORM LEFT FIXER SUPPORT		01
023	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
024	0503010019	1/2" SPRING WASHER		04
025	0503010060	1/2" NUT		04

ASSY LADDER


0511053356




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		04
02	0503010237	3/8" X 1" BOLT		08
03	0503010025	3/8" SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0511069636	LADDER		02
06	0503011179	3/8" X 2-1/4" BOLT		04
07	0501010984	FLAT WASHER		04
08	0503013357	3/8" SELF-ADJUSTING NUT		04



Item	Code	Description	See page	09 L
001	0511069656	HANDRAIL COP FLEX 600 9		02
002	0521018290	RANDRAIL HOLDER		02
003	0503010395	1/2" X 1-1/4" BOLT		04
004	0503010019	1/2" SPRING WASHER		04
005	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0503033889	SET LABEL ADHESIVE		02
02	0503033854	ADHESIVE LABEL		02
03	0503033853	ADHESIVE LABEL		02
04	0503031565	ADHESIVE LABEL CARE		02
05	0503032930	ADHESIVE LABEL DANGER		04
06	0503031425	ADHESIVE LABEL ATTENTION		02
07	0503031087	ADHESIVE LABEL		01
08	0503031942	ADHESIVE LABEL		01
09	0503031669	ADHESIVE LABEL		01
10	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
11	0503034249	ADHESIVE LABEL TABLE PLANTS		02
12	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
13	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
14	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
15	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
16	0503032979	ADHESIVE LABEL LETTERS A B C D		02
17	0503032949	ADHESIVE LABEL		01
18	0503031428	READ MANUAL DECAL		01
19	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER		02
20	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER		01
21	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM		02
22	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM		02
23	0503034500	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
001	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
002	0511031563	BAG WITH MANUAL		01
003	0503010267	NYLON CLAMP		01
004	0503010363	5/16" X 1" BOLT		01
005	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
006	0503010179	5/16" ZN SPRING WASHER		01
007	0503010337	5/16" NUT		01

ASSY TURBINE

0521050976




Item	Code	Description	See page	QT
001	0571019978	SHAFT FIXER BODY		01
002	0571019979	SHAFT FIXER BODY		01
003	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
004	0503010019	1/2" SPRING WASHER		04
005	0503010060	1/2" NUT		04
006	0511059406	TURBINE PRECISION PLANTING MOUNTED	52	01
007	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02
008	0501012140	FLAT WASHER		02
009	0503012412	5/8 UNC SELF LOCKING NUT		02
010	0571019552	SUPPORT VACUUM		01
011	0503013584	VACUUM GAUGE		01
012	0571019963	AIR DISTRIBUTOR SUPPORT		04
013	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
014	0503010019	1/2" SPRING WASHER		08
015	0503010060	1/2" NUT		08
016	0521014442	LOWER AIR DISTRIBUTOR SUPPORT		04
017	0511057348	DISTRIBUTOR VACUUM	54	02
018	0503031576	ELBOW		02
019	0503010371	5/16" X 1" BOLT		08
020	0503010179	5/16" ZN SPRING WASHER		08
021	0503010337	5/16" NUT		08
022	0581012166	HOSE		02
023	0503011372	102 TO 121 CLAMP		04
024	0511057906	HOSE ASSY	55	01
024A	0511057840	ASSY TURBINE HOSE REAR	56	01
024AA	0501081247	HOSE 1/2 X 7012 TC-TM		02
024AB	0501080477	HOSE 3/8 X 7012 TC-TM		01
024B	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	10	02
024C	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
024D	0503033981	ADHESIVE LABEL		01
024E	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	57	01




ASSY TURBINE

0521050976


Item	Code	Description	See page	QT
25	0503015062	TUBE		01




Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE		01
02	0501011460	7/8 NF REDUCTION NIPPLE		04
03	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
04	0503010392	2-046 N 3006 9B O'RING		01
05	0581012096	ROUND SLEEVE		02
06	0503015420	VALVE ANTI-CAVITACAO CV10208TN5		01
07	0521050154	TURBINE PRECISION PLANTING WITH HOLE	53	01
08	0503011372	102 TO 121 CLAMP		02
09	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
10	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
11	0503010143	1/4" SPRING WASHER		02
12	0503010144	1/4" NUT		02
13	0503010190	2-114 N 3006-9B O'RING		04
14	0501081235	1/2 X 650 TR- TC HOSE		01




Item	Code	Description	See page	QT
01	0503034404	TURBINE REAR COVER		01
02	0503034405	MOTOR PP 730425		01
03	0503034406	FAN PP 730115		01
04	0503034407	NUT		01
05	0503062606	COVER		01
06	0503034409	JOINT PP 730134		01
07	0503034410	DISTRIBUTOR TUBE		01
08	0503034411	DISTRIBUTOR TUBE GUIDE		04
09	0503034402	WASHER 3/8		04
10	0503034403	SCREW 3/8 16FPP X 1		04
11	0503034412	NUT 3/8 16 FPP		02
12	0503034413	FLAT WASHER		07
13	0503034414	SCREW 5/16 X 1		07
14	0503011336	1/2" HEX SELF ADJUSTING NUT		02
15	0511817302	FLAT WASHER		02
16	0503810706	SCREW 1/2 UNC X 4.1/2 C S G.5 SA		02
17	0503062560	TUBE FOR METER CLOCK 730142		01




Item	Code	Description	See page	QT
01	0571017215	SOCKET DISTRIBUTOR AR		01
02	0503012566	COVER KAP 110 YELLOW		01
03	0503031943	SOCKET		05
04	0503012856	REBITE POP		10
05	0571019405	BODY DISTRIBUTOR VACUUM 4845/5345		01




Item	Code	Description	See page	QT
01	0511057840	ASSY TURBINE HOSE REAR	56	01
01A	0521052534	HOSE 1/2 X 7012 TC-TM YELLOW / RED		01
01AA	0501081247	HOSE 1/2 X 7012 TC-TM		01
01AB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01AD	0503018952	PLASTIC BOLT		06
01B	0521052535	HOSE 1/2 X 7012 TC-TM YELLOW / BLUE		01
01BA	0501081247	HOSE 1/2 X 7012 TC-TM		01
01BB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01BD	0503018952	PLASTIC BOLT		06
01C	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
01CA	0501080477	HOSE 3/8 X 7012 TC-TM		01
01CB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01CC	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
01CD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	10	02
03	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
04	0503033981	ADHESIVE LABEL		01
05	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	57	01




Item	Code	Description	See page	QT
01	0521052534	HOSE 1/2 X 7012 TC-TM YELLOW / RED		01
01A	0501081247	HOSE 1/2 X 7012 TC-TM		01
01B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01D	0503018952	PLASTIC BOLT		06
02	0521052535	HOSE 1/2 X 7012 TC-TM YELLOW / BLUE		01
02A	0501081247	HOSE 1/2 X 7012 TC-TM		01
02B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
02C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
02D	0503018952	PLASTIC BOLT		06
03	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
03A	0501080477	HOSE 3/8 X 7012 TC-TM		01
03B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
03C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
03D	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0503018799	QUICK COUPLING		01
02	0503011883	QUICK CONNECTION COVER		01




Item	Code	Description	See page	QT
01	0503062712	18L DOUBLE HEAD KIT		01
02	0503017984	LIFT SENSOR		02
03	0511056972	FILTER HYDAC	59	01
04	0511055638	BLOCK FLOW LIMITER	60	01
05	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		270
06	0511056974	MOTOR	61	02
07	0511056973	PARKER OMP 80 HYDRAULIC MOTOR WITH VALVE	62	02
08	0581014609	FLANGE NYLON		18
09	0503819014	BOLT ALLEN		18
10	0503019015	BOLT		54




Item	Code	Description	See page	QT
01	0503016376	FILTER SPRING		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8"NF UNF NIPPLE		02
04	0503012341	T 7/8" ADAPOR GIRAT NUT		01
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02

BLOCK FLOW LIMITER


0511055638




Item	Code	Description	See page	QT
01	0503014953	LIMITING FLOW PACK		01
02	0503010045	2-116 N 3006-9B O'RING		02
03	0503011109	2-119 N 3006-9B O'RING		02
04	0501010590	7/8" REDUCTION NIPPLE		02
05	0571013917	7/8"NF X 1.1/16 UNF NIPPLE		02




Item	Code	Description	See page	QT
01	0503014364	MOTOR W/ AXLE		01
02	0503016037	VALVE		01
03	0501010590	7/8" REDUCTION NIPPLE		02
04	0503010045	2-116 N 3006-9B O'RING		02
05	0521064025	TRACTOR HITCH		01
06	0503011807	SCREW M8 X 1,25X10		02



Item	Code	Description	See page	QT
01	0503016037	VALVE		01
02	0501010590	7/8" REDUCTION NIPPLE		02
03	0503010045	2-116 N 3006-9B O'RING		02
04	0503016055	MOTOR HYDRAULIC PARKER OMP 80 ISOBUS		01




Item	Code	Description	See page	QT
01	0521051806	FERTILIZER ENGINE SUPPORT APT	64	01
02	0521050273	MOTOR SUPPORT SEED	67	01
03	0521051807	MODULE BOX APT	68	01
04	0521051278	LIFTING SENSOR SUPPORT FIXING APT	70	02
05	0571012016	SLEEVE		01
06	0502012007	SQUARE SLEEVE		01
07	0501055489	SPRING GUIDE LOCK SLEEVE		02
07A	0502040534	SPRING GUIDE BUSHING LOCK		01
07B	0501018535	1/2 X 1 BOLT		01
08	0501053788	Q3/4" FASTENER AXLE ASSY	66	02
09	0501080005	1/2" X 216" TR-TM HOSE ASSY		01
10	0501080021	1/2 X 1300 TR-TR HOSE ASSY		01
11	0501081073	HOSE 1/2 X 4200 TC-TM		01
12	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	10	02




CHAIN TENSIONER

0511059969




Item	Code	Description	See page	QT
01	0581012970	TIGHTENER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511817303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01

MOTOR SUPPORT SEED


0521050273




Item	Code	Description	See page	QT
01	0521067490	HYDRAULIC MOTOR SUPPORT APT	01	
02	0503031805	1 1/2" GEAR	01	
03	0511017302	FLAT WASHER	01	
04	0503010019	1/2" SPRING WASHER	03	
05	0503010060	1/2" NUT	03	
06	0531019479	AXLE CHAIN GEAR	01	
07	0521065328	20Z GEAR WITH HOLE SHAFT HEX 16.5	01	
08	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN	02	
09	0571012766	SUPPORT ENCODER	01	
10	0521064025	TRACTOR HITCH	01	
11	0503011082	C1/2" X 1.3/4" SCREW	01	
12	0502010175	HITCH CLAMP	01	
13	0503010013	5/8" NUT	02	
14	0503010027	5/8" SPRING WASHER	02	
15	0501011027	5/8" X 3-3/4" BOLT	02	
16	0501011299	FLAT WASHER	02	
17	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	01	
18	0503011807	SCREW M8 X 1,25X10	02	




Item	Code	Description	See page	QT
01	0511059348	APT ASSY MODULE BOX	69	01
02	0571013729	RIGHT SUPPORT CASE MODULE APT		01
03	0571013730	LEFT SUPPORT BOX MODULO APT		01
04	0521010718	5/8" U BOLT		02
05	0503010027	5/8" SPRING WASHER		04
06	0503010013	5/8" NUT		04



Item	Code	Description	See page	QT
01	0521066834	CAIXA MODULO		01
02	0503018171	FAST LOCK ASSY		02
03	0521066833	BOX COVER		01
04	0571012006	COVER PIVOT SHAFT		01
05	0571012005	SUPPORT GUIDE ASSY		01
06	0501010694	8.5 X 18 X 1.5 FLAT WASHER		03
07	0503010257	1/8" X 1" COTTERPIN		02
08	0511017303	FLAT WASHER		10
09	0503010298	1/4" X 1/2" BOLT		04
10	0503010143	1/4" SPRING WASHER		10
11	0503010294	1/4" X 7/8" BOLT		06
12	0503010144	1/4" NUT		06
13	0501011643	3/8 X 1" BOLT		04
14	0503010025	3/8" SPRING WASHER		04
15	0501010984	FLAT WASHER		04
16	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0581014325	SENSOR SUPPORT		01
02	0501011643	3/8 X 1"BOLT		01
03	0503010026	3/8" NUT		01
04	0503010025	3/8" SPRING WASHER		01
05	0501013518	FLAT WASHER		01




Item	Code	Description	See page	007	008	009	010
001	0511064808	DRAWBAR		001	001	001	001
002	0502012328	DRAWBAR SUPPORT FRONT FIXATION		002	002	002	002
003	0502012329	DRAWBAR FIXATION REAR SUPPORT		002	002	002	002
004	0561014393	COUPLING SHAFT		002	002	002	002
005	0503030119	LOCK PIN		002	002	002	002
006	0502012330	SUPPORT FIXER PIVOT		004	004	004	004
007	0503011084	3/4" X 5" BOLT		008	008	008	008
008	0503010023	3/4" SPRING WASHER		004	004	004	004
009	0503010014	3/4" NUT		004	004	004	004
010	0503010002	1800 GREASE FITTING		001	001	001	001
011	0561019087	DRAWBAR TRANSPORT LOCK		001	001	001	001
012	0521018532	1.4" X 12" COUPLING SHAFT		001	001	001	001
013	0521010578	COUPLING SHAFT		001	001	001	001
014	0503030085	LOCK PIN		003	003	003	003
015	0501010322	FLAT WASHER		004	004	004	004

SQUARE AXLE ASSEMBLY (730)


0511053342



Item	Code	Description	See page	QT
01	0501056271	BEARING CLOSED	73	02
02	0501056444	BEARING WITH BALL BEARING	74	02
03	0503011953	5/16" X 1" BOLT		08
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		08
05	0503010179	5/16" ZN SPRING WASHER		08
06	0503010337	5/16" NUT		08
07	0511014218	3/4" X 28.7"SQUARE SHAFT		02
08	0521010691	AXLE FASTENER		04
09	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		04
10	0511017303	FLAT WASHER		04
11	0503010143	1/4" SPRING WASHER		04
12	0503010144	1/4" NUT		04
13	0503030303	SUPPORT WASHER		04
14	0521061852	LEVER RATCHET		02
15	0521061847	AXLE ADRIVING ASSY		02
16	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
17	0521061849	DISASSEMBLE LEVER		02
18	0503010140	1/8" X 3/4" COTTERPIN		04
19	0571012792	LOWER LEVER		02
20	0503011082	C1/2" X 1.3/4" SCREW		02
21	0511017302	FLAT WASHER		04
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2" NUT		02
24	0561016797	SLEEVE UNION LEVER ARM/DESARM		02
25	0501010096	3/8" X 2" BOLT		02
26	0501010984	FLAT WASHER		04
27	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01



Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01

CLAMP


0521052549




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01

DRAWBAR TURNBUCKLE


0511050906




Item	Code	Description	See page	QT
001	0501069529	653 TURNBUCKLE		01
002	0521062278	RIGHT TURNBUCKLE		01
003	0511062888	LH TURNBUCKLE		01
004	0501061056	RH LOCKNUT WITH HANDLER		01
005	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01



Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0571012612	PIVOT SHAFT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HAIR PIN		01



Item	Code	Description	See page	QT
01	0521051622	FRONT SEED SHORT ROW	81	01
02	0521051621	FRONT SEED LONG ROW	82	01
03	0511053024	FERTILIZER SHORT LINE	91	01
04	0511053023	LONG FERTILIZER LINE	92	01
05	0511051819	DC 20 SEMI MOUNTED	98	01
06	0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	100	01
07	0501054482	DEPTH CONTROL LEFT ARM WITH TIRE	110	01
08	0501054481	RIGHT ARM DEPTH CONTROL WITH WHEEL	111	01
09	0511057509	SEED RESERVOIR PNEUMATIC ASSY	115	01
10	0511065909	DEPTH FIXER BASE		01
11	0521051810	LEFT REAR LINE SEED - EPP	116	01
12	0521051811	RIGHT REAR LINE SEED - EPP	117	01
13	0503010060	1/2" NUT		01
14	0503031050	CURVED CONDUCTOR		01
15	0503010246	CLAMP		01
16	0531013600	PRESS ADJUSTMENT LEVER		01
17	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
18	0521050772	FUSE ROD WITH CONDUCTOR	123	01
19	0511058877	REGULATORY KEY		01
19A	0521066800	BODY REGULATORY KEY		01
19B	0503030878	LEVER CRANK		01
20	0521067360	PROTRACTOR CPRA		01
21	0503010479	1/2" X 3" BOLT		01
22	0503010019	1/2" SPRING WASHER		01
23	0503010060	1/2" NUT		01
24	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		01
25	0503010547	1/2" X 4" BOLT		01
26	0503010019	1/2" SPRING WASHER		01

FRONT SEED SHORT ROW

0521051622



Item	Code	Description	See page	QT
001	0521065914	FRAME ASSY		01
002	0571012443	COUPLING SHAFT		01
003	0571012442	COUPLING SHAFT		03
004	0571012441	TRANSMISSION AXLE		01
005	0511052393	BEARING FOLLOWER ROW ASSY	83	01
006	0571012449	CONTROL AXLE		01
007	0571012448	LOCK SLEEVE AXLE REGULATION		01
008	0521068100	SUPPORT FRONT LINE SHORT SEED		01
009	0502012784	DRIVER PIVOT		02
010	1902012814	BODY LOCK REGULATOR LEVER REGULATOR SEED		01
011	0502012785	SEED ROW ADJUSTMENT LEVER ASSY		01
012	0503017857	BOLT 5/8 UNF 4		04
013	0503010811	5/8" UNF SELF ADJUSTING NUT		04
014	0502012789	FIXER SUPPORT FERTILIZER ROW		01
015	0503016501	40-1 X 49 CHAIN LINK + MENDING		01
016	0511050609	BEARING WITH 17Z GEAR ASSY	84	01
017	0511055260	SEED ROW CHAIN TENSIONER	86	01
018	0503010002	1800 GREASE FITTING		04
019	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
020	0503012412	5/8 UNC SELF LOCKING NUT		04
021	0503030024	1.7" X10.2" X 0.2" EXTENSION SPRING		02
022	0503030168	HAIR PIN		02
023	0503010131	3/16" X 1-1/2" COTTERPIN		03
024	0511054635	BEARING AXLE BODY	87	02
025	0503011953	5/16" X 1" BOLT		08
026	0501010694	8.5 X 18 X 1.5 FLAT WASHER		08
027	0503010179	5/16" ZN SPRING WASHER		08
028	0503010337	5/16" NUT		08
029	0511057159	TRANSMISSION BOX SEED LINE	88	01
030	0503011378	M6X1X16 C S 8.8 ZN BOLT		02
031	0503015110	M06 SPRING WASHER		02


**FRONT SEED SHORT ROW**

0521051622

Item	Code	Description	See page	QT
032	0502012782	17Z GEAR WITH HEX HOLE		01
033	0581014435	SLEEVE ARM LINE SEED		08
034	0511057625	ROW SEED BEARING	89	01
035	0503032984	HOOD HEX AXLE ROW		01
036	0503013100	NYLON CLAMP		01
037	0581015124	LIMITER COURSE		01

FRONT SEED LONG ROW

0521051621




Item	Code	Description	See page	QT
01	0521065914	FRAME ASSY		01
02	0571012443	COUPLING SHAFT		01
03	0571012442	COUPLING SHAFT		03
04	0571012441	TRANSMISSION AXLE		01
05	0511052393	BEARING FOLLOWER ROW ASSY	83	01
06	0571012449	CONTROL AXLE		01
07	0571012448	LOCK SLEEVE AXLE REGULATION		01
08	0521068102	LONG SEED LINE FRONT SUPPORT		01
09	0502012784	DRIVER PIVOT		02
10	1902012814	BODY LOCK REGULATOR LEVER REGULATOR SEED		01
11	0502012785	SEED ROW ADJUSTMENT LEVER ASSY		01
12	0503017857	BOLT 5/8 UNF 4		04
13	0503010811	5/8" UNF SELF ADJUSTING NUT		04
14	0502012789	FIXER SUPPORT FERTILIZER ROW		01
15	0503012142	40-1 CHAIN X 61 LINK + MENDING		01
16	0511050609	BEARING WITH 17Z GEAR ASSY	84	01
17	0511055260	SEED ROW CHAIN TENSIONER	86	01
18	0503010002	1800 GREASE FITTING		04
19	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
20	0503012412	5/8 UNC SELF LOCKING NUT		04
21	0503030024	1.7" X10.2" X 0.2" EXTENSION SPRING		02
22	0503030168	HAIR PIN		02
23	0503010131	3/16" X 1-1/2" COTTERPIN		03
24	0511054635	BEARING AXLE BODY	87	02
25	0503011953	5/16" X 1" BOLT		08
26	0501010694	8.5 X 18 X 1.5 FLAT WASHER		08
27	0503010179	5/16" ZN SPRING WASHER		08
28	0503010337	5/16" NUT		08
29	0511057159	TRANSMISSION BOX SEED LINE	88	01
30	0503011378	M6X1X16 C S 8.8 ZN BOLT		02
31	0503015110	M06 SPRING WASHER		02




FRONT SEED LONG ROW

0521051621

Item	Code	Description	See page	QT
32	0502012782	17Z GEAR WITH HEX HOLE		01
33	0581014435	SLEEVE ARM LINE SEED		08
34	0511057625	ROW SEED BEARING	89	01
35	0503032984	HOOD HEX AXLE ROW		01
36	0503013100	NYLON CLAMP		01
37	0581015124	LIMITER COURSE		01




Item	Code	Description	See page	QT
01	0521063532	BEARING FOLLOWER ROW ASSY		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0571012450	COP FLEX AXLE		01
05	0571012459	COP FLEX AXLE		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		02
07	0503015356	SPRING PIN		01
08	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511050617	FRONT SEED ROW BEARING	85	01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0502012819	17Z GEAR WITH HEX HOLE		01

FRONT SEED ROW BEARING


0511050617




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502012718	BEARIN BODY		01
02	0503012882	BEARING		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB	01	
02	0502012464	BOX TRANSMISSION COVER	01	
03	0503016995	6006 BALL BEARING	02	
04	0503015895	6005 Z BALL BEARING	01	
05	0503010143	1/4" SPRING WASHER	03	
06	0503011378	M6X1X16 C S 8.8 ZN BOLT	03	
07	0503010406	501025 CLAMPING RING (FOR AXLE)	01	
08	0503010707	501030 CLAMPING RING (FOR AXLE)	02	
09	0502040856	CONICAL GEAR	01	
10	0571018870	14Z CONICAL GEAR	01	
11	0503011105	SEAL RING	01	
12	0503011409	6005 Z BALL BEARING	01	
13	0503017008	SEAL RING	01	
14	0503017007	SEAL RING	02	
15	0511017907	1/8" BSPT X 6 PLUG	01	
16	0503010003	1845 GREASE FITTING	01	




Item	Code	Description	See page	QT
01	0511057156	BEARING LINE SEMI MOUNTED	90	01
02	0571018731	HEX AXLE		01
03	0571017900	5/8" X 77" HEX AXLE		01
04	0501056296	UNIVERSAL JOINT		01
05	0503011855	0.2" X 1.8" SPRING PIN		03
06	0503013958	1/4" X 1" BOLT		02
07	0561014778	HEX UNIVERSAL JOINT		01



Item	Code	Description	See page	QT
01	0521065913	ROW SEED BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		02
05	0571017815	BEARING AXLE BODY		01
06	0503017008	SEAL RING		01

FERTILIZER SHORT LINE

0511053024




Item	Code	Description	See page	QT
01	0511053223	FERTILIZER ROW SUPPORT WITH SCREW	93	01
02	0502012728	ROW FERTILIZER SUPPORT		01
03	0503017856	BOLT 3/4		02
04	0503010152	3/4" SELF LOCKING NUT		02
05	0521063504	FERTILIZER ROW LOWER SUPPORT		01
06	0561017928	FERTILIZER ROW ARTICULAT SLEEVE		02
07	0511015098	FLAT WASHER		06
08	0503010233	5/8" X 2-1/2" BOLT		02
09	0503012412	5/8 UNC SELF LOCKING NUT		02
10	0511063862	FERTILIZER ROW UPPER SUPPORT		01
11	0501010452	5/8" X 5" BOLT		01
12	0531016207	0.6" X 1" X 2.8" SLEEVE		01
13	0503012412	5/8 UNC SELF LOCKING NUT		01
14	0521061855	FERTILIZER ROW REAR SUPPORT		01
15	0501010452	5/8" X 5" BOLT		02
16	0531016031	1/2" SPRING WASHER		04
17	0531016207	0.6" X 1" X 2.8" SLEEVE		02
18	0503012412	5/8 UNC SELF LOCKING NUT		02
19	0521062073	SPRING GUIDE		01
20	0521016057	COUP SHA OF THE CARRY-W SPRING GUI		01
21	0503030168	HAIR PIN		01
22	1902020393	SPRING UPPER SUPPORT		01
23	0503031450	2.7" X 9.2" X 0.03" SPRING		01
24	1902020393	SPRING UPPER SUPPORT		01
25	0521011158	SPRING LOCKNUT		01
26	0521018575	REGULATOR SPINDLE 100		01
27	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	94	01
28	0502012352	DOUBLE-DISC SPACING PLATE		01
29	0541013035	5.55" X 4.0" X 0.38" PLATE		01
30	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
31	0503010019	1/2" SPRING WASHER		02



FERTILIZER SHORT LINE

0511053024

Item	Code	Description	See page	QT
32	0503010060	1/2" NUT		02
33	0503010752	1/2" X 3.1/2" BOLT		02
34	0503010019	1/2" SPRING WASHER		02
35	0503010060	1/2" NUT		02
36	0503030520	SEED SOCKET		01
37	0503031145	2" X 2" X 20" HOSE		01
38	0503031076	2" HOSE CLAMP		02
39	0503010003	1845 GREASE FITTING		03




Item	Code	Description	See page	QT
01	0521063759	ROW FERTILIZER SUPPORT		01
02	0511053223	FERTILIZER ROW SUPPORT WITH SCREW	93	01
03	0503017855	3/4" BOLT		02
04	0503010152	3/4" SELF LOCKING NUT		02
05	0521063504	FERTILIZER ROW LOWER SUPPORT		01
06	0503010233	5/8" X 2-1/2" BOLT		02
07	0511015098	FLAT WASHER		06
08	0561017928	FERTILIZER ROW ARTICULAT SLEEVE		02
09	0503012412	5/8 UNC SELF LOCKING NUT		02
10	0511063862	FERTILIZER ROW UPPER SUPPORT		01
11	0501010163	5/8" X 4-1/2" BOLT		01
12	0531015184	FLAT WASHER		01
13	0531016031	1/2" SPRING WASHER		01
14	0503012412	5/8 UNC SELF LOCKING NUT		01
15	0531016207	0.6" X 1" X 2.8" SLEEVE		01
16	0521061855	FERTILIZER ROW REAR SUPPORT		01
17	0501010452	5/8" X 5" BOLT		02
18	0531016031	1/2" SPRING WASHER		04
19	0531016207	0.6" X 1" X 2.8" SLEEVE		02
20	0503012412	5/8 UNC SELF LOCKING NUT		02
21	0521062073	SPRING GUIDE		01
22	0521016057	COUP SHA OF THE CARRY-W SPRING GUI		01
23	0503030168	HAIR PIN		01
24	1902020393	SPRING UPPER SUPPORT		01
25	0503031450	2.7" X 9.2" X 0.03" SPRING		01
26	1902020393	SPRING UPPER SUPPORT		01
27	0521011158	SPRING LOCKNUT		01
28	0521018575	REGULATOR SPINDLE 100		01
29	0502012724	FERTILIZER ROW FIXER		01
30	0503017960	5/8" X 3-12" BOLT		04
31	0503010811	5/8" UNF SELF ADJUSTING NUT		04


LONG FERTILIZER LINE

0511053023


Item	Code	Description	See page	QT
32	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	95	01
33	0502012352	DOUBLE-DISC SPACING PLATE		01
34	0541013035	5.55" X 4.0" X 0.38" PLATE		01
35	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
36	0503010019	1/2" SPRING WASHER		02
37	0503010060	1/2" NUT		02
38	0503010752	1/2" X 3.1/2" BOLT		02
39	0503010019	1/2" SPRING WASHER		02
40	0503010060	1/2" NUT		02
41	0503030520	SEED SOCKET		01
42	0503031145	2" X 2" X 20" HOSE		01
43	0503031076	2" HOSE CLAMP		02
44	0503010003	1845 GREASE FITTING		02
45	0503010004	1890 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012727	BLADE DISC SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	96	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	97	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RH DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503011443	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	97	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	96	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RH DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0521062962	BLADE DISC AXLE		01
02	0502012369	BLADE DISC SUPPORT		01
03	0541018684	FLAT WASHER		01
04	0503010361	SPRING PIN		01
05	0503010756	0.2" X 2.4" SPRING PIN		01
06	0503010003	1845 GREASE FITTING		01
07	0521018935	RIGHT ARM OF THE BLADE DISC		01
08	0521018936	LEFT ARM OF THE BLADE DISC		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503016525	3/4" X 6" BOLT		01
12	0503011442	3/4" SPRING WASHER		01
13	0503010014	3/4" NUT		01
14	0502020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0502020394	SPRING SUPPORT		01
17	0503010014	3/4" NUT		02
18	0501054887	20 BLADE DISC WITH FLAT PLAN DISC	99	01
19	0521015376	DUST CLOAK		02
20	0511015346	FLAT WASHER		02
21	0503011438	SPRING WASHER		02
22	0521013510	3/4" NUT		02
23	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
24	0503011411	1/2" X 5-1/2" BOLT		01
25	0503011440	SPRING WASHER		01
26	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011562	DC PST ACT/ULTR BOX		01
02	0503010276	6206 BALL BEARING		02
03	0521013610	BLADE DISC HUB AXLE		01
04	0503030832	FLAT WASHER		02
05	0503012417	SEAL		02
06	0503011800	SEAL RING		02
07	0503010691	1/4" GREASE FITTING		01
08	0603027851	20" X 0.2" FLAT PLAIN DISC		01
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0503011444	SPRING WASHER		06
12	0503010337	5/16" NUT		06



Item	Code	Description	See page	QT
01	0511052971	CONTROL DEPTH WITH SEMI MOUNTED THREAD	101	01
02	0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	102	01
03	0501052908	COMPACTOR WHEEL WITH BEARING	108	02
04	0503010019	1/2" SPRING WASHER		06
05	0503010752	1/2" X 3.1/2" BOLT		01
06	0503013739	1/2" X 1" BOLT		01
07	0503010479	1/2" X 3" BOLT		02
08	0503010060	1/2" NUT		04
09	0503030012	HAIR PIN		01
10	0571013222	FIXING CHOCK		01
11	0503010741	1/2" X 2-3/4" BOLT		02
12	0511055819	DEPTH WHIT AROS BAND	109	02
13	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
14	0503013816	5/16" LOCKNUT		08




Item	Code	Description	See page	QT
01	0521063808	DEPTH CONTROL INNER COLUMN CONTROL WITH SCREW		01
02	0521063809	DEPTH CONTROL EXTERNAL COLUMN CONTROL WITH SCREW		01
03	0571013194	REGULATOR SPINDLE		01
04	0551010616	ROD HEX		01
05	0503010683	0,2" X 1,2" SPRING PIN		01
06	0571013202	REGULATOR AXLE WHEELS COBRIDORA		01
07	0521063812	REGULATOR LEVER ALXE		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		01
09	0511065308	LOCK REGULATOR		01
10	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
11	0541011627	FLAT WASHER		01
12	0503010140	1/8" X 3/4" COTTERPIN		01
13	0511059325	LEFT ARM WHEELS	103	01
14	0511059324	RIGHT ARM COATING WHEEL MOUNTED	104	01
15	0571014709	SLEEVE LOCK CONTROL ARM		02
16	0503011440	SPRING WASHER		03
17	0503819099	BOLT		02
18	0511051546	CUBE RIGHT CONTROL DEPTH	105	01
19	0511051547	LEFT CUBE CONTROL DEPTH	106	01
20	0503011442	3/4" SPRING WASHER		02
21	0571013189	SLEEVE SUPPORT BEATER		01
22	0521063813	WHEEL PRESS BEATER		01
23	0501010937	13.5 X 28 X 3 FLAT WASHER		01
24	0503010920	1/2" X 1.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502012850	PRESS WHEELS ARM	01	01
02	0503030883	RIGHT TORSION SPRING	01	01
03	0502011066	PRESS WHEELS ARM SUPPORT	01	01
04	0531017415	1" X 4.72" AXLE JOINT	01	01
05	0503010839	03"X 0.6" SPRING PIN	01	01
06	0521063841	REGULATOR RIGHT COMPACTOR	01	01
07	0521063842	REGULATOR LEFT COMPACTOR	01	01
08	0503811404	BOLT	02	02
09	0503011443	3/8" SPRING WASHER	02	02
10	0503010026	3/8" NUT	02	02
11	0571013295	ALXE REGULATOR COMPACTOR	01	01
12	0521063812	REGULATOR LEVER ALXE	01	01
13	0503011336	1/2" HEX SELF ADJUSTING NUT	02	02
14	0511065308	LOCK REGULATOR	01	01
15	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING	01	01
16	0541011627	FLAT WASHER	01	01
17	0503010140	1/8" X 3/4" COTTERPIN	01	01
18	0571013293	SLEEVE LOCK COMPACTOR V CONTROL WITH SCREW	01	01
19	0503811172	BOLT	01	01
20	0503010002	1800 GREASE FITTING	01	01
21	0581013744	PROTECTION COVER - CPRA	01	01
22	0503813096	BOLT	01	01
23	0503013816	5/16" LOCKNUT	0	0

LEFT ARM WHEELS


0511059325




Item	Code	Description	See page	QT
01	0502012844	LEFT ARM WHEELS		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	GLOVE SUPPORT ARM WHEEL COBRIDORA		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012843	RIGHT WHEEL ARM		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	GLOVE SUPPORT ARM WHEEL COBRIDORA		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511051583	DEPTH WHEEL HUB SEMIFINISHED	107	01
02	0511066638	AXLE WHEEL RIGHT DEPTH WITH DOOR DUST		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	COVER DEPTH		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0511051583	DEPTH WHEEL HUB SEMIFINISHED	107	01
02	0511066637	AXLE WHEEL LEFT DEPTH WITH DOOR DUST		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	COVER DEPTH		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0502011907	DEPTH CONTROL WHEEL HUB		01
02	0503010269	6204 BALL BEARING		02
03	0501013636	SPACING SLEEVE		01
04	0503010689	SEAL 00763-BR		01
05	0503011105	SEAL RING		01
06	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03



Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501056435	LEFT CONTROL ARM DEPTH WITHOUT WHEEL	112	01
02	0501052538	DEPTH BAND WITH ARMS	114	01
03	0503010358	5/16" X 5/8" BOLT		04
04	0503013816	5/16" LOCKNUT		04




Item	Code	Description	See page	QT
01	0501056430	ARM RIGHT CONTROL DEPTH WITHOUT WHEEL	113	01
02	0501052538	DEPTH BAND WITH ARMS	114	01
03	0503010358	5/16" X 5/8" BOLT		04
04	0503013816	5/16" LOCKNUT		04

LEFT CONTROL ARM DEPTH WITHOUT WHEEL


0501056435




Item	Code	Description	See page	QT
01	0502012091	DEPTH CONTROL LEFT ARM		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
08	0503010878	5/8" SELF ALIGNING NUT		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0521019178	COVER DEPTH		01
11	0503011441	SPRING WASHER		03
12	0503014729	1/4" UNF X 1/2" BOLT		03
13	0503010691	1/4" GREASE FITTING		01
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
15	0503011440	SPRING WASHER		01
16	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502012090	DEPTH CONTROL RIGHT ARM		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
08	0503010878	5/8" SELF ALIGNING NUT		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0521019178	COVER DEPTH		01
11	0503011441	SPRING WASHER		03
12	0503014729	1/4" UNF X 1/2" BOLT		03
13	0503010691	1/4" GREASE FITTING		01
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
15	0503011440	SPRING WASHER		01
16	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0502012798	SUPPORT BOX SEED		01
02	0581012694	COMPACT PROTECTION		01
03	0503010849	3/8" X 1-1/2" BOLT		03
04	0501010096	3/8" X 2" BOLT		01
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0503031508	COVER GREEN BEAM SEED YELLOW		01
08	0503010358	5/16" X 5/8" BOLT		04
09	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
10	0503010179	5/16" ZN SPRING WASHER		04
11	0503010337	5/16" NUT		04



Item	Code	Description	See page	QT
01	0521051809	ASSY P.P V-SET FOR EPP	118	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	121	01




Item	Code	Description	See page	QT
01	0521051809	ASSY P.P V-SET FOR EPP	118	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	DDD RITGH SUPREMA PRECISION PLANTING	122	01




Item	Code	Description	See page	QT
01	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
02	0571017899	PIN LOCK PP		01
03	0503030190	0.5" X 1.6" X 0.05" SPRING		01
04	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
05	0521051253	TRANSMISSION BOX PRECISION PLANTING LEFT 119 EPP/APT		01
06	0503013357	3/8" SELF-ADJUSTING NUT		01
07	0501013518	FLAT WASHER		02
08	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
09	0571017895	PIN FIXER CONDUCTOR P.P		01
10	0503011776	M6 SELF ADJUSTINGNUT		03
11	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
12	0503010293	BAQUELITE MANIPULACION		02
13	0503010140	1/8" X 3/4" COTTERPIN		02
14	0503010131	3/16" X 1-1/2" COTTERPIN		01
15	0503010025	3/8" SPRING WASHER		01
16	0571019491	SLUICE PNEUMATIC PRECISION PLANTING		01
17	0501011643	3/8 X 1"BOLT		01
18	0503010209	3/8" UNC BUTTERFLY NUT		01
19	0502012807	SUPPORT BOX PRECISION PLANTING		01
20	0571019489	CLAMP PRECISION PLANTING		01
21	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
22	0511057491	PRECISION PLANTING SEED ASSY SEED 120 DISTRIBUTOR WITH CORN DISC		01
23	0561014778	HEX UNIVERSAL JOINT		01
24	0503013958	1/4" X 1" BOLT		02
25	0503011855	0.2" X 1.8" SPRING PIN		01
26	0503012721	1/4" X 4" BOLT		01
27	0503012880	1/4" UNC SELF ADJUSTING NUT		01
28	0571014024	FAST BOLT GUIDE AXLE		01
29	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02

Item	Code	Description	See page	QT
30	0503015110	M06 SPRING WASHER		02
31	0503018139	PARAF M6 X 10 CAB CIL C/FENDA		03
32	0503037390	PACKING FOR PLANTING		01
33	0503015752	3/8" X 2" BOLT		01
34	0503034824	FIXATIVE		01
35	0581011226	FIXER CLOSING P PLANTING CONTR CPRA		01
36	0503010298	1/4" X 1/2" BOLT		01
37	0503010143	1/4" SPRING WASHER		01
38	0503010305	FLAT WASHER		01
39	0581014620			01




Item	Code	Description	See page	QT
01	0502050052	LEFT SIDE TRANSMISSION BOX PP		01
02	0502050053	RIGHT SIDE TRANSMISSION BOX PP		01
03	0503011410	ROLLER BEARING		02
04	0503011182	6203 ROLLER BEARING		02
05	0503011184	502040 CLAMPING RING (FOR AXLE)		01
06	0571017655	SLEEVE FIXER HITCH PNEUMATIC		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
08	0503010144	1/4" NUT		03
09	0521051252	GEAR JUNCTION		01
10	0581011222	PINION AXLE 6Z PNEUMATIC		01
11	0503034340	PINION AXLE 6Z PNEUMATIC		01
12	3402510052	GRAXA SHELL STAMINA/RL-2		00
13	0581014611	LOCKING CLUTCH		01




Item	Code	Description	See page	QT
01	0503062405	SEED DISTRIBUTOR		01
01A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
01AA	0503018908	BODY FIXED BASE DISTRIBUTOR SEED		01
01AB	0503018909	COVER CONDUCTOR DISTRIBUTOR SEED		01
01AC	0503062652	SEED INPUT DEFLECTOR		01
01AD	0503062653	FULL COVER		01
01AE	0503018910	RIVETS LARGEST		01
01AF	0503018911	SPACING BUSHING		01
01AG	0503018912	BOLT		03
01AH	0503018476	SPRING		01
01AI	0503018474	LOWER BRUSH		01
01AJ	0503018475	TOP BRUSH		01
01AK	0503018157	RUBBER		01
01AL	0503018477	LOCK SPRING		01
01B	0503062568	FIXER MOBILE		01
01BA	0503018919	BASE		01
01BB	0503018913	RIVET		01
01BC	0503018914	WASHER		01
01BD	0503018915	BEARING		02
01BE	0503062654	BEARING		01
01BF	0503018916	ADJUSTMENT CHOCK		03
01BG	0503018917	RING		01
01BH	0503018918	CHOCK		02
01BI	0503019288	RUBBER SEAL PP 730518		01
01BJ	0503018478	SPRING		01
01BK	0503018920	SEALING		01
01BL	0503018479	TUBE		01
01BM	0503018735	PROTECTIVE COVER		01
01BN	0503018921	BOLT		06
01BO	0503018922	BOLT		02
01BP	0503018480	REGULATOR PIN		01


Item	Code	Description	See page	QT
01BQ	0503018923	ADAPTER		01
01BR	0503018924	SPRING PIN		01
02	0503062417	KIT CORN DISTRIBUTION		01
02A	0503018160	CORN PLASTIC DISC		01
02B	0503062472	SELECTOR SEED CORN		01
02C	0503062474	EJECTOR CORN SEED SET		01
03	0571019613	STRAW PRECISION PLANTING SHIELD		01
03A	0503017957	PROTECTIVE COVER AIR INPUT		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	96	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15	97	01
04	0503010026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501010984	FLAT WASHER		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012781	SUPPORT DDD LEFT		01
11	0511015098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02



Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	96	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15	97	01
04	0503010026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501010984	FLAT WASHER		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012780	SUPPORT DDD RIGHT		01
11	0511015098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02



Item	Code	Description	See page	QT
01	0501110860	ROD WITH BEAK	124	01
02	0503010849	3/8" X 1-1/2" BOLT		02
03	0501010984	FLAT WASHER		04
04	0503010025	3/8" SPRING WASHER		02
05	0503010026	3/8" NUT		02
06	0503010019	1/2" SPRING WASHER		03
07	0503010060	1/2" NUT		03
08	0521067688	LEFT ROD FASTENER		01
09	0521067689	FIXER RIGHT ROD		01
10	0503030483	FERTILIZER SOCKET		01
11	0521069125	LOW FERTILIZER NOZZLE		01
12	0503012558	1/2" X 4" BOLT		03
13	0581016854	GLOVE SPACER STEM FUSE		01



Item	Code	Description	See page	QT
01	0521067442	ROD WITH SCREW FUSE		01
02	0502070086	BODY FUSE ROD		01
03	0503013128	ELASTIC PIN		02



www.marchesan.com.br



Technical Publications | Elaboration and Revision
ALESSANDRA PATRICIA KAWAHARA CARRILI