

PARTS CATALOGUE



ROW CROP PLANTERS

Code:

0501092862

Product:

USAP SUPREMA P.P - FRAME 32945 - CSU/CM/CBA/APT
ISOBUS/MS/PNA

**Series:**

S-0419

Revision:

00

Date Revision:

NOVEMBRO/2020

PRODUCTS



Code	Description
0111440161	USAP SUP 32945/60E550 CSU CM PP ESPECIAL S-0419

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.



MARCHESAN

INDEX

0909095475	FRAME ASSY	1
0909095476	ASSY HEADER	2
0909095477	ASSY RIGHT SIDE CHASSIS	3
0909095478	ASSY RIGHT INTERMEDIATE CHASSIS	4
0909095479	ASSY RIGHT FRAME	5
0909095480	ASSY CENTRAL FRAME	6
0909095481	ASSY LEFT FRAME	7
0909095482	ASSY LEFT INTERMEDIATE FRAME	8
0909095483	ASSY LEFT SIDE FRAME	9
0521059751	TELESCOPIC HEADER 560/4290/5860/6295 WITH FIXATION	10
0521058140	HYDRAULIC CYLINDER 50.8 X 101.6 X 947 X 621	11
0521059747	TELESCOPICO 10500 WITH LOCK	12
0521059750	PANTOGRAPHIC HEADER	13
0521059753	HYDRAULIC CYLINDER 50.8 X 127 X 822 X 477	14
0521058358	HYDRAULIC HOSE SUPPORT WITH FIXATION	15
0521059752	SEMI-ASSEMBLED REST	16
0521058344	WATER RESERVOIR WITH SOAP	17
0521058359	VALVE 02 WAYS	18
0521059746	ASSY RIGHT FRONT WHEEL	19
0521053037	TIRE WITH WHEEL 15 X 19,50 14 LONAS	20
0521058137	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION 564	21
0521058145	AXLE LOCK ARM ROD	22
0521058360	SUPPORT WITH FLOW DIVIDER BLOCK FOR 4 TURBINES	23
0511053121	GREATER TOOL BOX ASSY	24
0521059743	TELESCOPIC FRENCH HAND	25
0521058437	FRENCH HAND 8420 ASSY LEFT	26
0521058232	FRENCH HAND 8420 ASSY RIGHT	27
0521058088	ROTULA WITH EXTENSOR AXIS 2	28
0521059745	FRENCH HAND ARTICULATED SUPPORT BIGGER TELESCOPE	29
0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	30
0521058150	ROTULA WITH EXTENSOR AXIS 2.1 / 2	31
0521059896	ASSY SIDE HEX AXLE	32
0521059712	RODE SIDE ASSY	33
0531050362	HYDRAULIC CYLINDER 50.80 X 127.00 X 276	34
0521055981	TIRE WITH WHEEL 15X19.50 14 CANVAS	35
0521059709	WHEEL BLOCK SUPPORT	36
0521059667	RIGHT SIDE SUPPORT 7 MOUTH 3463X3407 ASSY	37
0521055370	SEED CONDUCTOR	38
0521058136	SIDE SHOE SUPPORT SILO WITH FIXATION	39
0521053054	ASSY SIDE HANDLE	40
0521059897	LEFT SIDE PLATFORM	41
0521058413	ASSY PLATFORM SUPPORT	42
0521059898	LEFT SIDE HANDRAIL 3070	43
0521059661	SIDE HANDRAIL 1643	44
0521059666	CENTRAL/SIDE HANDRAIL 1742	45
0521053096	ASSY SIDE FRAME HANDRAIL FIXER	46
0511053320	ASSY SIDE LADDER	47
0521059911	RIGHT SIDE AIR DUCT ASSEMBLY	48
0521059710	RIGHT SIDE AIR CONDUCTOR 7 MOUTH 3668	49
0511050198	CENTRAL AIR DUTY FIXING SUPPORT	50
0521059912	RIGHT SIDE DUCT ASSEMBLY	51
0511059943	SUPPORT FASTENER ASSY	52
0521059711	OIL CONDUCTOR SUPPORT	53
0521058476	SIDE FRAME ADHESIVE LABEL ASSY	54



MARCHESAN

INDEX

0521059913	AXIS ARTICULATION RIGHT SIDE LINE	55
0521059895	HYDRAULIC CYLINDER 50.8 X 101.6 X 802 X 570	56
0521058132	AXLE EXTENSOR ARTICULATION	57
0521059708	LOCK EAR	58
0521058541	SUPPORT SIDE FRAME WITHOUT ASSY TIRE	59
0521059901	SIDE HEX AXLE	60
0521056144	INTERMEDIATE SEED TRANSMISSION	61
0521059574	RIGHT SUPPORT 4 MOUTH 1633 X 1142 ASSY	62
0521059686	5 MOUTH SUPPORT 2033 X 1977 ASSY	63
0521059921	LEFT INTERMEDIATE PLATFORM	64
0521059926	RIGHT INTERMEDIATE HANDRAIL	65
0521059685	CENTRAL HANDRAIL 2028 X 1207	66
0521059744	CENTRAL HANDRAIL 2731 X 2037	67
0521059654	INTERNAL SIDE HANDRAIL 643 X 875	68
0521058148	P.P TURBINE WITH ASSY SUPPORT	69
0521050154	TURBINE P.P WITH HOLE	70
0521059927	RIGHT INTERMEDIATE AIR DUCT ASSY	71
0521059682	RIGHT SIDE AIR CONDUCTOR 9 MOUTH 4656	72
0521059924	INTERMEDIATE GUTTER ASSEMBLY	73
0521059928	RIGHT INTERMEDIATE DUCT ASSY	74
0521059681	SUPPORT DUCT OIL 5 DUCTS	75
0521059929	AXLE ARTICULATION RIGHT INTERMEDIATE SIDE LINE	76
0521059649	RIGHT SUPPORT 4 MOUTH 1633 X 1190 ASSY	77
0521059650	RIGHT SUPPORT 2033 X 1590 ASSY	78
0521059902	LEFT SIDE PLATFORM	79
0521059914	RIGHT SIDE HANDRAIL	80
0521059652	CENTRAL HANDRAIL 2120 X 1252	81
0521059653	CENTRAL HANDRAIL 2554 X 1652	82
0521053859	TURBINE P.P SIDE FRAME ASSY LARGER	83
0511059406	TURBINE P.P MOUNTED	84
0521059915	RIGHT SIDE AIR DUCT ASSEMBLY	85
0521059651	RIGHT SIDE AIR CONDUCTOR 9 MOUTH 4373	86
0521059905	SIDE RAIL ASSY	87
0521059916	RIGHT SIDE DUCT ASSEMBLY	88
0521059917	RIGHT FRAME HYDRAULIC ASSEMBLY	89
0521059918	AXIS ARTICULATION RIGHT SIDE LINE	90
0521059935	CENTRAL FRAME WITH FIXATION	91
0521053207	INTERNAL PLATE WITH FIXATION SCREW 1/2	92
0521059936	ASSY CENTRAL HEX AXLE	93
0521058328	FIXED CANUDE DC SUPPORT	94
0521059696	RODE SUPPORT WITH GLOVE ASSY	95
0531040591	HYDRAULIC CYLINDER 63.5 X 150 X 781 X 355	96
0521058408	CENTRAL WHEEL AXLE CUBE	97
0511045858	WHEEL HUB ASSY WITH BRAKE	98
0503061865	WHEELS AND TIRE	99
0521059695	5 MOUTH SUPPORT 2021 X 1487 ASSY	100
0521058329	SEED CONDUCTOR	101
0521051407	FIXER SILO FERTILIZER	102
0521059693	CENTRAL INTERNAL HANDRAIL 675 X 875	103
0521059694	CENTRAL HANDRAIL 675 X 875	104
0511059383	INTERNAL FIXER ASSY HANDLE	105
0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	106
0521059941	CENTRAL PLATFORM ASSY	107
0521053066	PLATFORM SUPPORT ASSY	108
0521058118	ASSY ARTICULATED LEFT ARM	109



MARCHESAN

INDEX


0521058117	ASSY ARTICULATED RIGHT ARM	110
0521058514	ARTICULATED ARM CYLINDER ASSY	111
0521058104	HYDRAULIC CYLINDER 63.50 X 150	112
0521059937	HYDRAULIC ASSEMBLY CSU/APT	113
0521059938	CENTRAL DUCT ASSY CSU/APT	114
0521051537	CENTRAL REAR DUCT SUPPORT	115
0521058489	CASAPPA TRIPLE DIVIDER VALVE BRP00090 WITH NIPLES	116
0521058407	ASSY APT/CBA ENGINE SUPPORT	117
0521051293	16Z/32Z GEAR BEARING	118
0501054655	CHAIN TENSIONER ASSY	119
0511059969	CHAIN TENSIONER	120
0521058103	CENTRAL SUPPORT	121
0521058505	ARTICULATION HOSE GAME	122
0521058506	HEAD HOSE ASSY	123
0521058507	LIFT HOSE GAME	124
0521058508	HOSE KIT 4 TURBINES	125
0521058509	APT HOSE KIT	126
0521058510	TRANSPORT HOSE KIT	127
0521058511	LINES HOSE KIT ARTICULATION	128
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	129
0521059995	ELECTRICAL ASSEMBLY 32MT/8F3500-L APT	130
0521057760	LED FLASHLIGHT WITH SUPPORT	131
0521053672	LIGHTHOUSE ASSY	132
0521059939	CENTRAL AIR DUCT ASSY CSU	133
0521059688	CENTRAL AIR CONDUCTOR 10 MOUTH	134
0521058488	CENTRAL AIR CONDUCTOR 1575	135
0521058409	CENTRAL AIR DUCT FIXER SUPPORT	136
0521058411	CENTRAL ASSY AIR CONDUCTOR SUPPORT	137
0521052549	CLAMP	138
0521059940	CENTRAL GUTTER ASSEMBLY	139
0521055102	BIGGEST FULL GUTTER SUPPORT	140
0521057185	ISOBUS 60L55 ASSY WITH SEED MONITOR	141
0511056972	FILTER HYDAC	142
0521057179	PARKER OMR 125 ISOBUS HYDRAULIC ENGINE WITH VALVE	143
0511056973	PARKER OMP 80 HYDRAULIC MOTOR WITH VALVE	144
0521059943	ADHESIVE LABEL ASSY CENTRAL FRAME 60LINES APT	145
0521059942	CENTRAL INTERMEDIATE SIDE ARTICULATION AXIS	146
0531040592	HYDRAULIC CYLINDER 50.8 X 101.6 X 372 X 97	147
0521053296	AXIS ARTICULATOR	148
0521050332	VACUOMETER WITH ASSY SUPPORT	149
0521058518	ELECTRIC ASSEMBLY BCE (EMB) APT	150
0521051707	ASSY PANEL FIXER PLATE	151
0909095484	SEED LINE/ASSY FERTILIZER	152
0521059700	FRONT SEED LINE SHORT CBA/CM WITHOUT LUBRICATION	153
0521059701	FRONT SEED LINE LONG CBA/CM WITHOUT LUBRICATION	154
0521059702	FRONT SEED LINE SHORT CBA/CM WITHOUT LUBRICATION	155
0521059687	INTERNAL FRONT LONG SEED LINE CBA/CM WITHOUT LUBRICATION	156
0521051447	FRONT ASSY ROW BEARING	157
0521059706	SEED HOSE SUPPORT	158
0521055965	LEFT REAR QUICK CHANGE WITHOUT NOZZLE SEED	159
0521055964	RIGHT REAR QUICK CHANGE WITHOUT NOZZLE SEED	160
0521055873	LEFT DOUBLE DISK FAST EXCHANGE SEED 15X15	161
0521055872	RIGHT DOUBLE DISK FAST EXCHANGE SEED 15X15	162
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	163



MARCHESAN

INDEX


0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	164
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	165
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	166
0521051434	ASSY P.P CSU 2 STEEL CABLE	167
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	168
0521050525	FIXER FERTILIZER CONDUCTOR	169
0521055346	20 BLADE DISC ASSY	170
0521055344	LOWER SUPPORT	171
0521054844	DPLO 20 CUTTING DISK BOX	172
0521053697	CUTTING DISK BOX	173
0521055397	DEEP WHEEL / COMPACTOR SYSTEM	174
0521055398	DEPTH WHEEL	175
0501059228	ADJUSTMENT LEVER	176
0521055399	LEFT ARM WITH WHEEL	177
0521055400	RIGHT ARM WITH WHEEL	178
0521055058	LEFT ARM	179
0521055074	RIGHT ARM WITH O-RING	180
0521055401	ASSY WHEEL	181
0521055073	ASSEMBLY DEPTH WHEEL BOX	182
0521055093	BODY COMPACTOR	183
0521055017	RIGHT COMPACTOR WHEEL	184
0521054990	LEFT COMPACTOR WHEEL	185
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	186
0521059672	LEFT SUPPORT 4 MOUTH 1632 X 1521 ASSY	187
0521059673	LEFT SUPPORT 5 MOUTH 2033 X 1590 ASSY	188
0521059903	LEFT SIDE HANDRAIL	189
0521059670	CENTRAL HANDRAIL 2554 X 1652	190
0521059671	CENTRAL HANDRAIL 2166 X 1582	191
0521059904	LEFT SIDE AIR DUCT ASSY	192
0521059669	LEFT SIDE AIR CONDUCTOR 973 MOUTH	193
0521059906	LEFT SIDE DUCT ASSEMBLY	194
0521058412	ECU BOX WITH ASSY SUPPORT	195
0521056857	ECU APT / TVT BOX WITH EXCHANGE	196
0521059907	LEFT FRAME HYDRAULIC ASSY	197
0521058426	ASSY FILTER SUPPORT	198
0521059655	LEFT SUPPORT 4 MOUTH 1633 X 1142 ASSY	199
0521059922	LEFT INTERMEDIATE HANDRAIL	200
0521059657	CENTRAL HANDRAIL 2731 X 2037	201
0521059656	CENTRAL HANDRAIL 2391 X 1453	202
0521059923	LEFT INTERMEDIATE AIR DUCT ASSY	203
0521059925	LEFT INTERMEDIATE DUCT ASSY	204
0521059908	ARTICULATION AXIS LINE INTERMEDIATE SIDE LEFT	205
0521059899	LEFT SIDE AIR DUCT ASSY	206
0521059900	SIDE DUCT ASSEMBLY	207
0521058421	OIL CONDUCTIVE SUPPORT 02 ASSY	208
0521059894	AXIS ARTICULATION LEFT SIDE LINE	209




Item	Code	Description	See page	QT
01	0909095476	ASSY HEADER	2	01
02	0909095477	ASSY RIGHT SIDE CHASSIS	3	01
03	0909095478	ASSY RIGHT INTERMEDIATE CHASSIS	4	01
04	0909095479	ASSY RIGHT FRAME	5	01
05	0909095480	ASSY CENTRAL FRAME	6	01
06	0909095481	ASSY LEFT FRAME	7	01
07	0909095482	ASSY LEFT INTERMEDIATE FRAME	8	01
08	0909095483	ASSY LEFT SIDE FRAME	9	01

ASSY HEADER

0909095476




Item	Code	Description	See page	QT
01	0521059751	TELESCOPIC HEADER 560/4290/5860/6295 WITH FIXATION	10	01
02	0521059747	TELESCOPICO 10500 WITH LOCK	12	01
03	0521059750	PANTOGRAPHIC HEADER	13	01
04	0521058429	ASSY TRACTOR HITCH AXLE		01
04A	0531061113	EJE DE ENGANCHE DE TRACTORES		01
04B	0503030119	LOCK PIN		01
05	0521058358	HYDRAULIC HOSE SUPPORT WITH FIXATION	15	01
06	0521058345	SAFETY CHAIN WITH SHACKLE		01
06A	0503014120	CHAIN		01
06B	0503014321	CABLE STEEL SHACKLE		02
07	0521059752	SEMI-ASSEMBLED REST	16	01
08	0521058344	WATER RESERVOIR WITH SOAP	17	01
09	0521058359	VALVE 02 WAYS	18	01
10	0503011372	102 TO 121 CLAMP		10
11	0503018829	NYLON CLAMP		32
12	0521059746	ASSY RIGHT FRONT WHEEL	19	02
13	0521058360	SUPPORT WITH FLOW DIVIDER BLOCK FOR 4 TURBINES	23	01
14	0521068718	TRANSPORT LOCK 1250		02
15	0521058433	LOCK AXIS FRENCH HAND TELESCOPIC		02
15A	0531061118	AXLE JOIN 31.75 X 205 WITH HANDLE		01
15B	0503030085	LOCK PIN		01
16	0511053121	GREATER TOOL BOX ASSY	24	01
17	0521059743	TELESCOPIC FRENCH HAND	25	02
18	0521058437	FRENCH HAND 8420 ASSY LEFT	26	01
19	0521058232	FRENCH HAND 8420 ASSY RIGHT	27	01



Item	Code	Description	See page	QT
01	0531061557	RIGHT SIDE FRAME		01
02	0591015833	ARTICULATION AXIS HORIZONTAL		01
03	0503034318	5/8 UNC X 2 BOLT		02
04	0503010013	5/8" NUT		02
05	0503010002	1800 GREASE FITTING		03
06	0521059896	ASSY SIDE HEX AXLE	32	01
07	0521058328	FIXED CANUDE DC SUPPORT	94	05
08	0521059712	RODE SIDE ASSY	33	01
09	0521059709	WHEEL BLOCK SUPPORT	36	01
10	0521059667	RIGHT SIDE SUPPORT 7 MOUTH 3463X3407 ASSY	37	01
11	0521058136	SIDE SHOE SUPPORT SILO WITH FIXATION	39	02
12	0521053054	ASSY SIDE HANDLE	40	01
13	0521059897	LEFT SIDE PLATFORM	41	01
14	0521059898	LEFT SIDE HANDRAIL 3070	43	01
15	0511053320	ASSY SIDE LADDER	47	01
16	0521059911	RIGHT SIDE AIR DUCT ASSEMBLY	48	01
17	0503011372	102 TO 121 CLAMP		04
18	0591015832	GUTTER 30 X 55 X 3600		01
19	0521059912	RIGHT SIDE DUCT ASSEMBLY	51	01
20	0521058476	SIDE FRAME ADHESIVE LABEL ASSY	54	01
21	0521059913	AXIS ARTICULATION RIGHT SIDE LINE	55	01
22	0521058541	SUPPORT SIDE FRAME WITHOUT ASSY TIRE	59	02
23	0909095484	SEED LINE/ASSY FERTILIZER	152	07

ASSY RIGHT INTERMEDIATE CHASSIS


0909095478



Item	Code	Description	See page	QT
01	0531061531	RIGHT INTERMEDIATE FRAME		01
02	0591015833	ARTICULATION AXIS HORIZONTAL		01
03	0503010002	1800 GREASE FITTING		03
04	0503034318	5/8 UNC X 2 BOLT		02
05	0503010013	5/8" NUT		02
06	0581012179	SLEEVE		02
07	0521059901	SIDE HEX AXLE	60	01
08	0521056144	INTERMEDIATE SEED TRANSMISSION	61	02
09	0521058328	FIXED CANUDE DC SUPPORT	94	07
10	0521059712	RODE SIDE ASSY	33	01
11	0521059709	WHEEL BLOCK SUPPORT	36	01
12	0503019917	COMMAND BLOCK		01
13	0521059574	RIGHT SUPPORT 4 MOUTH 1633 X 1142 ASSY	62	01
14	0521059686	5 MOUTH SUPPORT 2033 X 1977 ASSY	63	01
15	0521058136	SIDE SHOE SUPPORT SILO WITH FIXATION	39	03
16	0521059921	LEFT INTERMEDIATE PLATFORM	64	01
17	0521059926	RIGHT INTERMEDIATE HANDRAIL	65	01
18	0521058148	P.P TURBINE WITH ASSY SUPPORT	69	01
19	0521059927	RIGHT INTERMEDIATE AIR DUCT ASSY	71	01
20	0503011372	102 TO 121 CLAMP		03
21	0521059924	INTERMEDIATE GUTTER ASSEMBLY	73	01
22	0521059928	RIGHT INTERMEDIATE DUCT ASSY	74	01
23	0521059929	AXLE ARTICULATION RIGHT INTERMEDIATE SIDE LINE	76	01
24	0521050332	VACUOMETER WITH ASSY SUPPORT	149	01
25	0503015062	TUBE		02mts
26	0909095484	SEED LINE/ASSY FERTILIZER	152	09

ASSY RIGHT FRAME


0909095479



Item	Code	Description	See page	QT
01	0531061503	RIGHT FRAME 4686		01
02	0503010002	1800 GREASE FITTING		01
03	0591014479	GLOVE 102 X 77 X 150		02
04	0581012179	SLEEVE		02
05	0521059901	SIDE HEX AXLE	60	01
06	0521058328	FIXED CANUDE DC SUPPORT	94	07
07	0521059712	RODE SIDE ASSY	33	01
08	0521059649	RIGHT SUPPORT 4 MOUTH 1633 X 1190 ASSY	77	01
09	0521059650	RIGHT SUPPORT 2033 X 1590 ASSY	78	01
10	0521058136	SIDE SHOE SUPPORT SILO WITH FIXATION	39	04
11	0521059902	LEFT SIDE PLATFORM	79	01
12	0521059914	RIGHT SIDE HANDRAIL	80	01
13	0521053859	TURBINE P.P SIDE FRAME ASSY LARGER	83	01
14	0521059915	RIGHT SIDE AIR DUCT ASSEMBLY	85	01
15	0503011372	102 TO 121 CLAMP		05
16	0521059905	SIDE RAIL ASSY	87	01
17	0521059916	RIGHT SIDE DUCT ASSEMBLY	88	01
18	0521059917	RIGHT FRAME HYDRAULIC ASSEMBLY	89	01
19	0521059918	AXIS ARTICULATION RIGHT SIDE LINE	90	01
20	0521050332	VACUUMETER WITH ASSY SUPPORT	149	01
21	0503015062	TUBE		02mts
22	0909095484	SEED LINE/ASSY FERTILIZER	152	09

ASSY CENTRAL FRAME

0909095480



Item	Code	Description	See page	QT
01	0521059935	CENTRAL FRAME WITH FIXATION	91	01
02	0521059936	ASSY CENTRAL HEX AXLE	93	01
03	0521058328	FIXED CANUDE DC SUPPORT	94	08
04	0521059696	RODE SUPPORT WITH GLOVE ASSY	95	01
05	0503061865	WHEELS AND TIRE	99	04
06	0521059695	5 MOUTH SUPPORT 2021 X 1487 ASSY	100	02
07	0521059693	CENTRAL INTERNAL HANDRAIL 675 X 875	103	01
08	0521059694	CENTRAL HANDRAIL 675 X 875	104	02
09	0521059941	CENTRAL PLATFORM ASSY	107	01
10	0521058118	ASSY ARTICULATED LEFT ARM	109	01
11	0521058117	ASSY ARTICULATED RIGHT ARM	110	01
12	0521058514	ARTICULATED ARM CYLINDER ASSY	111	01
13	0521059937	HYDRAULIC ASSEMBLY CSU/APT	113	01
14	0521059995	ELECTRICAL ASSEMBLY 32MT/8F3500-L APT	130	01
15	0521059939	CENTRAL AIR DUCT ASSY CSU	133	01
16	0521059940	CENTRAL GUTTER ASSEMBLY	139	01
17	0521057185	ISOBUS 60L55 ASSY WITH SEED MONITOR	141	01
18	0521059943	ADHESIVE LABEL ASSY CENTRAL FRAME 60LINES APT	145	01
19	0521059942	CENTRAL INTERMEDIATE SIDE ARTICULATION AXIS	146	01
20	0531050012	TRANSPORT LOCK		06
20A	0591015726	LATERAL CYLINDER LOCK		01
20B	0503030012	HAIR PIN		01
20C	0541016844	FIXER LOCK		01
21	0521059883	TRANSPORT LOCK 325 X 66 X 9.50 ASSY		04
21A	0591016108	TRANSPORT LOCK 325 X 66 X 9.50		01
21B	0531061649	AXLE LOCKS TRANSPORT		01
21C	0503030168	HAIR PIN		01
22	0561016793	FIXED WRENCH		01
23	0501047885	ROD STOP		08
24	0511042163	2.1/2" ROD STOP ASSY		02


ASSY CENTRAL FRAME

0909095480

Item	Code	Description	See page	QT
25	0511042161	2.1/2" ROD STOP ASSY		02
26	0561017063	HOLDER TUBE		02
27	0521053296	AXIS ARTICULATOR	148	01
28	0503011883	QUICK CONNECTION COVER		01
29	0503011628	FEMALE QUICK COUPLER		01
30	0521058518	ELECTRIC ASSEMBLY BCE (EMB) APT	150	01
31	0521059540	ASSY TRACTOR HITCH AXLE		01
31A	0521068010	HITCH AXLE		01
31B	0503030119	LOCK PIN		01
32	0503010045	2-116 N 3006-9B O'RING		01
33	0541010080	TERMINAL R.1 / 2 NPT		01
34	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01
35	0581013729	NIPLE 1 / 2NPT		01
36	0909095484	SEED LINE/ASSY FERTILIZER	152	10

ASSY LEFT FRAME


0909095481



Item	Code	Description	See page	QT
01	0531061523	LEFT FRAME		01
02	0503010002	1800 GREASE FITTING		01
03	0591014479	GLOVE 102 X 77 X 150		02
04	0581012179	SLEEVE		02
05	0521059901	SIDE HEX AXLE	60	01
06	0521058328	FIXED CANUDE DC SUPPORT	94	07
07	0521059712	RODE SIDE ASSY	33	01
08	0521059672	LEFT SUPPORT 4 MOUTH 1632 X 1521 ASSY	187	01
09	0521059673	LEFT SUPPORT 5 MOUTH 2033 X 1590 ASSY	188	01
10	0521059902	LEFT SIDE PLATFORM	79	01
11	0521059903	LEFT SIDE HANDRAIL	189	01
12	0521053859	TURBINE P.P SIDE FRAME ASSY LARGER	83	01
13	0521059904	LEFT SIDE AIR DUCT ASSY	192	01
14	0503011372	102 TO 121 CLAMP		05
15	0521059905	SIDE RAIL ASSY	87	01
16	0521059906	LEFT SIDE DUCT ASSEMBLY	194	01
17	0521058412	ECU BOX WITH ASSY SUPPORT	195	01
18	0521059907	LEFT FRAME HYDRAULIC ASSY	197	01
19	0521059908	ARTICULATION AXIS LINE INTERMEDIATE SIDE LEFT	205	01
20	0521050332	VACUOMETER WITH ASSY SUPPORT	149	01
21	0503015062	TUBE		02mts
22	0909095484	SEED LINE/ASSY FERTILIZER	152	09

ASSY LEFT INTERMEDIATE FRAME


0909095482




Item	Code	Description	See page	QT
01	0531061515	LEFT INTERMEDIATE FRAME		01
02	0591015833	ARTICULATION AXIS HORIZONTAL		01
03	0503010002	1800 GREASE FITTING		03
04	0503034318	5/8 UNC X 2 BOLT		02
05	0503010013	5/8" NUT		02
06	0581012179	SLEEVE		02
07	0521059901	SIDE HEX AXLE	60	01
08	0521056144	INTERMEDIATE SEED TRANSMISSION	61	02
09	0521058328	FIXED CANUDE DC SUPPORT	94	07
10	0521059712	RODE SIDE ASSY	33	01
11	0521059709	WHEEL BLOCK SUPPORT	36	01
12	0521059655	LEFT SUPPORT 4 MOUTH 1633 X 1142 ASSY	199	01
13	0521059686	5 MOUTH SUPPORT 2033 X 1977 ASSY	63	01
14	0521058136	SIDE SHOE SUPPORT SILO WITH FIXATION	39	03
15	0521059921	LEFT INTERMEDIATE PLATFORM	64	01
16	0521059922	LEFT INTERMEDIATE HANDRAIL	200	01
17	0521058148	P.P TURBINE WITH ASSY SUPPORT	69	01
18	0521059923	LEFT INTERMEDIATE AIR DUCT ASSY	203	01
19	0503011372	102 TO 121 CLAMP		03
20	0521059924	INTERMEDIATE GUTTER ASSEMBLY	73	01
21	0521059925	LEFT INTERMEDIATE DUCT ASSY	204	01
22	0521059908	ARTICULATION AXIS LINE INTERMEDIATE SIDE LEFT	205	01
23	0521050332	VACUOMETER WITH ASSY SUPPORT	149	01
24	0503015062	TUBE		02mts
25	0909095484	SEED LINE/ASSY FERTILIZER	152	09

ASSY LEFT SIDE FRAME


0909095483




Item	Code	Description	See page	QT
01	0531061516	LEFT SIDE FRAME		01
02	0591015833	ARTICULATION AXIS HORIZONTAL		01
03	0503034318	5/8 UNC X 2 BOLT		02
04	0503010013	5/8" NUT		02
05	0503010002	1800 GREASE FITTING		03
06	0521059896	ASSY SIDE HEX AXLE	32	01
07	0521058328	FIXED CANUDE DC SUPPORT	94	05
08	0521059712	RODE SIDE ASSY	33	01
09	0521059709	WHEEL BLOCK SUPPORT	36	01
10	0521059667	RIGHT SIDE SUPPORT 7 MOUTH 3463X3407 ASSY	37	01
11	0521058136	SIDE SHOE SUPPORT SILO WITH FIXATION	39	02
12	0521053054	ASSY SIDE HANDLE	40	01
13	0521059897	LEFT SIDE PLATFORM	41	01
14	0521059898	LEFT SIDE HANDRAIL 3070	43	01
15	0511053320	ASSY SIDE LADDER	47	01
16	0521059899	LEFT SIDE AIR DUCT ASSY	206	01
17	0503011372	102 TO 121 CLAMP		04
18	0591015832	GUTTER 30 X 55 X 3600		01
19	0521059900	SIDE DUCT ASSEMBLY	207	01
20	0521058476	SIDE FRAME ADHESIVE LABEL ASSY	54	01
21	0521059894	AXIS ARTICULATION LEFT SIDE LINE	209	01
22	0521058541	SUPPORT SIDE FRAME WITHOUT ASSY TIRE	59	02
23	0909095484	SEED LINE/ASSY FERTILIZER	152	07



Item	Code	Description	See page	QT
01	0531061590	TELESCOPE HEADER 560/4290/5860/6295		01
02	0521068716	AXIS HEADER TELESCOPIC WITHOUT GREASE FITTING		01
03	0503011052	1.1/4" X 0.77" CASTLE NUT		03
04	0521011688	FLAT WASHER		02
05	0503010010	1/4" X 2.1/2" COTTERPIN		07
06	0501012140	FLAT WASHER		16
07	0503010027	5/8" SPRING WASHER		08
08	0503010233	5/8" X 2-1/2" BOLT		08
09	0503010013	5/8" NUT		08
10	0531061070	AXIS 365 TELESCOPIC HEADER		02
11	0531060748	REST SUPPORT		01
12	0503010002	1800 GREASE FITTING		04
13	0521069354	TELESCOPIC HOSE GUIDE		01
14	0521058357	FRENCH HAND FRONT AXLE ASSY		04
15	0521058140	HYDRAULIC CYLINDER 50.8 X 101.6 X 947 X 621	11	01
16	0531060947	FRONT TRANSPORT ROD		01
17	0502010673	BEARING SEMI		04
18	0501015593	SUPPORT PLATE		02
19	0501010064	1" X 9" BOLT		04
20	0503014182	SELF-ADJUSTING NUT		04
21	0591014405	AXIS ROD CYLINDER LOWER		02
22	0503011135	BOLT		01
23	0503010180	7/16" SPRING WASHER		01
24	1902010477	UPPER CLAMP BODY		01




Item	Code	Description	See page	QT
01	0503010817	1.1/4" SELF LOCKING NUT		01
02	0503010039	D-2000 SCRAPER RING		01
03	0503018026	1870-2000-375 B GASKET		01
04	0503030385	CYLINDER PLUG N-002		02
05	0503010002	1800 GREASE FITTING		02
06	0531060983	CASE 126,95 X 535		01
07	0531060984	EXTENSOR 50,80 X 548		01
08	0502040876	COVER		01
09	0581010353	RING SUPPORT		01
10	0591014040	EMBOLOUS 126.4		01
11	0503018150	RING GUIDE		01
12	0503018151	RING BS		02
13	0503011453	O'RING		02
14	0503018152	O'RING		02
15	0503018024	RING BS		01
16	0503010345	2-218 N 3006-9B O'RING		01
17	0503018025	RING GUIDE		01




Item	Code	Description	See page	QT
01	0503010523	1/4" X 2" COTTERPIN	04	
02	0521011132	FLAT WASHER	04	
03	0571013059	PIVOT SHAFT LOCK	01	
04	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	01	
05	0511054270	TENSIONER SPRING	01	
05A	0511069520	TELESC LOCK SPRING TENSIONER	01	
05B	0503010013	5/8" NUT	02	
06	0521068719	LOCK	01	
07	0503010002	1800 GREASE FITTING	01	
08	0531061588	INTERNAL CANUD	01	

PANTOGRAPHIC HEADER


0521059750




Item	Code	Description	See page	QT
01	0531061106	PANTOGRAPHIC ARM		01
02	0531061598	PANTOGRAPHIC EAR		01
03	0531061114	BODY HITCH TRACTOR		01
04	0531061589	PANTOGRAPHIC UPPER ARM		01
05	0503012198	3/16" X 2" COTTERPIN		04
06	0503011052	1.1/4" X 0.77" CASTLE NUT		04
07	0591015986	HYDRAULIC HOSE SUPPORT FIXER		01
08	0531061597	FRONT AXLE HEADER		02
09	0531061105	PANTOGRAPHIC HEAD EAR		01
10	0531061599	PANTOGRAPHIC HEAD AXLE		02
11	0521059753	HYDRAULIC CYLINDER 50.8 X 127 X 822 X 477	14	01
12	0591015984	PANTOGRAPHIC HEAD ARM AXIS		01
13	0503010002	1800 GREASE FITTING		03
14	0503012215	5/16" X 2-1/2" COTTERPIN		02




Item	Code	Description	See page	QT
01	0531061596	CASE 127 X 605		01
02	0531061595	ROD 50,8 X 727		01
03	0503010002	1800 GREASE FITTING		02
04	0503010817	1.1/4" SELF LOCKING NUT		01
05	0503010345	2-218 N 3006-9B O'RING		01
06	0502010382	5" END CAP		01
07	0581010353	RING SUPPORT		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503011453	O'RING		02
10	0503018152	O'RING		02
11	0503018024	RING BS		01
12	0503018025	RING GUIDE		01
13	0581010354	PISTON		01
14	0503018150	RING GUIDE		01
15	0503018151	RING BS		02
16	0503010039	D-2000 SCRAPER RING		01
17	0503030385	CYLINDER PLUG N-002		02



Item	Code	Description	See page	QT
01	0531061071	HYDRAULIC HOSE SUPPORT		01
02	0503015490	NUT AUTOFREN 7/16 NC		02
03	0503011103	7/16" X 2-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0531061594	BODY REST WITH GLOVE		01
02	0531061593	REST SHOE		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		02
04	0521010585	0.9" X 5.9" COUPLING SHAFT		01
05	0521010784	COUPLING SHAFT		01
06	0531060758	AXLE JUNCTION 25.4 X 150 WITH HANDLE		01
07	0503030085	LOCK PIN		01



Item	Code	Description	See page	QT
01	0503014820	COROTE BLACK WATER		01
02	0503019262	SOAP DISH VACUUM		01

VALVE 02 WAYS


0521058359




Item	Code	Description	See page	QT
01	0503016612	VALVE		01
02	0571013798	3/4" UNF X 3/8 NPT NIPPLE		02
03	0591014399	VALVE FIXING		01
04	0503062180	T ADAPTER WITH ROTATING NUT		02
05	0503010589	1/2" UNC SELF ADJUSTING NUT		01

ASSY RIGHT FRONT WHEEL


0521059746



Item	Code	Description	See page	QT
01	0551014511	CARRYING WEELS AXLE SLEEVE GUIDES		02
02	0551014508	FLAT WASHER		01
03	0503011052	1.1/4" X 0.77" CASTLE NUT		02
04	0501017779	32 X 60 X 4.75 FLAT WASHER		02
05	0503010010	1/4" X 2.1/2" COTTERPIN		02
06	0521053037	TIRE WITH WHEEL 15 X 19,50 14 LONAS	20	01
07	0531060989	FRONT WHEEL FORK TRANSPORT		01
08	0503010095	01103-B SEAL		02
09	0503014559	ROLLER BEARING		02
10	0521058137	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION 564	21	01
11	0531061587	SIDE ARM WHEELED HEADER		01
12	0502040080	2.1/2" SLOTTED NUT		01
13	0591014056	GLOVE 108 X 75 X 40		01
14	0503010002	1800 GREASE FITTING		01
15	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
16	0503011444	SPRING WASHER		06
17	0531060987	ARM CUBE COVER		01
18	0521058145	AXLE LOCK ARM ROD	22	01
19	0503010152	3/4" SELF LOCKING NUT		12
20	0503019521	SCREW 3/4 UNF 3 CSRP G.8 ZN		12




Item	Code	Description	See page	QT
01	0503034606	WHEEL		01
02	0503019123	TIRE 385/65 R 22,50 D711 DRC 15-19,50 20L		01
03	0503016098	VALVE		01




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0591014038	LARGER WHEEL AXLE 564		01
03	0503010059	33287/33462 ROLLER BEARING		01
04	0503010009	RETAINER 00573-B		01
05	0503010086	SEAL 0009B-B		01
06	0551014473	GLOVE		01
07	0503012702	KM-12 NUT		02
08	0503012703	LOCK WASHER		01
09	0503010002	1800 GREASE FITTING		01
10	0503011444	SPRING WASHER		04
11	0503014048	22 X 1.5 HEX NUT		08
12	0503010363	5/16" X 1" BOLT		04
13	0503014050	22 X 1.5 BOLT		08
14	0511068415	PFFP-3770 SEAL GUIDE		01
15	0503010007	3982/3920 ROLLER BEARING		01

AXLE LOCK ARM ROD


0521058145




Item	Code	Description	See page	QT
01	0531060986	AXLE LOCK ROD		01
02	0503030978	COMPRES SPRING		01
03	0503010131	3/16" X 1-1/2" COTTERPIN		01
04	0503010292	0.2" X 1.6" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503010395	1/2" X 1-1/4" BOLT	02	
02	0503010589	1/2" UNC SELF ADJUSTING NUT	02	
03	0503010237	3/8" X 1" BOLT	06	
04	0503013357	3/8" SELF-ADJUSTING NUT	06	
05	0503010025	3/8" SPRING WASHER	04	
06	0503010172	M10 X 1,5 X 25 BOLT	04	
07	0581019743	FLOW DIVISOR BLOCK SUPPORT	02	
08	0503034719	FLOW DIVIDER BLOCK	02	
09	0503063064	DIVIDER BLOCK	01	
10	0591014400	BLOCK SUPPORT	01	
11	0503015114	BOLT	04	
12	0531061072	SUPPORT FLOW DIVIDING BLOCKS	01	
13	0531017427	3/4" X 06" PUMP	03	
14	0503010179	5/16" ZN SPRING WASHER	04	




Item	Code	Description	See page	QT
01	0521063662	BOX OF TOOLS		01
02	0551018356	BOX OF TOOLS COVER ASSY		01
03	0521010528	0.3" X 1.6" COUPLING SHAFT		02
04	0503010140	1/8" X 3/4" COTTERPIN		02
05	0503011907	PMC 594-S NYLON LUG		01
06	0503010358	5/16" X 5/8" BOLT		02
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531061584	TELESCOPIC INTERNAL CANUD		01
02	0521058441	ASSY TIGHTEN REGULATOR		02
02A	0531061125	TIGHTENING REGULATOR		01
02B	0591014567	SHIM		01
03	0503010002	1800 GREASE FITTING		01
04	0521058088	ROTULA WITH EXTENSOR AXIS 2	28	01
05	0531061585	EXTERNAL CANNES HAND FRENCH TELESCOPIC		01
06	0521059745	FRENCH HAND ARTICULATED SUPPORT BIGGER TELESCOPE	29	01
07	0503010589	1/2" UNC SELF ADJUSTING NUT		01
08	0503010964	BOLT		01




Item	Code	Description	See page	QT
01	0531061119	FRENCH HAND 8420		01
02	0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	30	01
03	0503010002	1800 GREASE FITTING		01
04	1902010477	UPPER CLAMP BODY		16
05	0502012907	FRENCH HAND DUCTS SUPPORT		08
06	0501010984	FLAT WASHER		16
07	0503010025	3/8" SPRING WASHER		16
08	0503010964	BOLT		08
09	0503010589	1/2" UNC SELF ADJUSTING NUT		08
10	0503011404	BOLT		16
11	0521069639	OIL TUBE		06
12	0501082189	HOSE 1/2 X 160 TR-TR		03
13	0521069638	OIL TUBE		10
14	0501082190	HOSE 3/8 X 160 TR-TR		05
15	0591014547	FRENCH HAND TRACK 20 X 38 X 3450		02
16	0521058150	ROTULA WITH EXTENSOR AXIS 2.1 / 2	31	01




Item	Code	Description	See page	QT
01	0531061119	FRENCH HAND 8420		01
02	0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	30	01
03	0503010002	1800 GREASE FITTING		01
04	0521058150	ROTULA WITH EXTENSOR AXIS 2.1 / 2	31	01
05	1902010477	UPPER CLAMP BODY		24
06	0502012907	FRENCH HAND DUCTS SUPPORT		08
07	0501010984	FLAT WASHER		16
08	0503010025	3/8" SPRING WASHER		16
09	0503010964	BOLT		07
10	0503010589	1/2" UNC SELF ADJUSTING NUT		07
11	0503011404	BOLT		12
12	0521069640	OIL TUBE		04
13	0501082208	HOSE 3/4 X 180 TR-TR		02
14	0521069639	OIL TUBE		06
15	0501082189	HOSE 1/2 X 160 TR-TR		03
16	0521069638	OIL TUBE		10
17	0501082190	HOSE 3/8 X 160 TR-TR		05
18	0503013665	SCREW 3/8 UNC X 3.1/4 C S RP G.2 ZN		04
19	0591014547	FRENCH HAND TRACK 20 X 38 X 3450		02




Item	Code	Description	See page	QT
01	0531061046	ROTULA WITH R2 LEFT NUT		01
02	0503010002	1800 GREASE FITTING		02
03	0501078990	TURNBUCLE AXLE		01
04	0561019879	LOCK ATTACHMENT BAR		01




Item	Code	Description	See page	QT
01	0531061586	FRENCH HAND ARTICULATION SUPPORT		01
02	0521058428	FRENCH HAND REAR AXLE COMPLETE TELESCOPE		01
02A	0531061112	ARTICULATION AXIS FRENCH HAND		01
02B	0551019529	FLAT WASHER		01
02C	0503010027	5/8" SPRING WASHER		01
02D	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		01
03	0591014545	ARTICULATION AXIS FRENCH HAND		01
04	0503012231	1/4" X 3" COTTERPIN		02




Item	Code	Description	See page	QT
01	0521062244	PIVOT SHAFT		01
02	0551019529	FLAT WASHER		01
03	0503010027	5/8" SPRING WASHER		01
04	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		01



Item	Code	Description	See page	QT
01	0531061134	ROTULA WITH NUT R.2.1 / 2 LEFT		01
02	0503010002	1800 GREASE FITTING		02
03	0531061133	EXTENSION AXIS		01
04	0591014096	FRENCH HAND ROTULA LOCK		01




Item	Code	Description	See page	QT
001	0591014452	HEX SHAFT 3/4 X 2127		01
002	0561018830	3/4 X AXLE HEX		01
003	0561015837	SLEEVE 31,75		01
004	0503010523	1/4" X 2" COTTERPIN		01
005	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		04
005A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
005B	0503010256	3/8" X 3/4" BOLT		01




Item	Code	Description	See page	QT
001	0531061840	SIDE WHEEL SUPPORT		01
002	0531061552	LARGE ROUND FORK CENTRAL		01
003	0531050362	HYDRAULIC CYLINDER 50.80 X 127.00 X 276	34	01
004	0521069575	FLANGE CYLINDER HYDRAULIC FIXER		02
005	0591015851	LIFTING AXLE BODY		01
006	0521055981	TIRE WITH WHEEL 15X19.50 14 CANVAS	35	01
007	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
008	0551014508	FLAT WASHER		01
009	0521058137	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION 21 564		01
010	0531012874	FLAT WASHER		02
011	0503010010	1/4" X 2.1/2" COTTERPIN		04
012	0531060981	ARTICULATED AXIS		01
013	0561019929	FLAT WASHER		01
014	0501010630	1.1/2" CASTLE NUT		01
015	0503011345	1/4" X 3-1/2" COTTERPIN		01
016	0503010003	1845 GREASE FITTING		03
017	0503010920	1/2" X 1.1/2" BOLT		04
018	0503010019	1/2" SPRING WASHER		04
019	0503010060	1/2" NUT		04
020	0502012731	WHEEL HOLDER		03
021	0503019245	SCREW 3/4 UNC X 4 C S R P G.8 ZN		03
022	0503019246	BOLT		03
023	0501010322	FLAT WASHER		06
024	0503010023	3/4" SPRING WASHER		06
025	0503019247	NUT 3/4 NC S G.8		06
026	0501017779	32 X 60 X 4.75 FLAT WASHER		02
027	0503011052	1.1/4" X 0.77" CASTLE NUT		02
028	0503010002	1800 GREASE FITTING		02
029	0503010882	BOLT		01
030	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
031	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
032	0503035229	CHAIN		01




Item	Code	Description	See page	QT
001	0531061554	CASE 127 X 450		01
002	0503010345	2-218 N 3006-9B O'RING		01
003	0503010817	1.1/4" SELF LOCKING NUT		01
004	0581010353	RING SUPPORT		01
005	0581010354	PISTON		01
006	0503018150	RING GUIDE		01
007	0503018151	RING BS		02
008	0503018026	1870-2000-375 B GASKET		01
009	0503011453	O'RING		02
010	0503018152	O'RING		02
011	0503018024	RING BS		01
012	0503018025	RING GUIDE		01
013	0503010039	D-2000 SCRAPER RING		01
014	0502040876	COVER		01
015	0531061555	ROD 50,80 X 532		01
016	0503030387	PLUG		02




Item	Code	Description	See page	QT
001	0503018841	DIAGONAL TIRE		01
002	0503034460	WHEEL		01
003	0503013999	VALVE		01




Item	Code	Description	See page	QT
001	0591015826	VALVE SUPPORT		01
002	0503013357	3/8" SELF-ADJUSTING NUT		02
003	0503015135	FLAT WASHER 10 X 18 X 2		02
004	0503010765	3/8" X 3" BOLT		02
005	0503019806	COMMAND BLOCK		01



Item	Code	Description	See page	QT
001	0521058329	SEED CONDUCTOR	101	07
002	0531061519	RIGHT SIDE SUPPORT 3463 X 3407		01
003	0503062961	FERTILIZER BEAM ASSY		02
004	0521055370	SEED CONDUCTOR	38	01
005	0521051407	FIXER SILO FERTILIZER	102	12




Item	Code	Description	See page	QT
01	0503010179	5/16" ZN SPRING WASHER		01
02	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
03	0503010499	5/16" UNC BUTTERFLY NUT		01
04	0503011953	5/16" X 1" BOLT		01
05	0503012880	1/4" UNC SELF ADJUSTING NUT		04
06	0581019780	COVER		01
07	0502012899	DUCT BODY		01
08	0503034859	JOIN		01
09	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		04




Item	Code	Description	See page	QT
001	0531060977	SIDE SUPPORT SHOE SILO		01
002	0571011070	5/8" UNC FASTENER		02
003	0503010027	5/8" SPRING WASHER		04
004	0503010013	5/8" NUT		04
005	0511017302	FLAT WASHER		03
006	0503010019	1/2" SPRING WASHER		03
007	0503010060	1/2" NUT		03
008	0503010920	1/2" X 1.1/2" BOLT		03

ASSY SIDE HANDLE

0521053054




Item	Code	Description	See page	QT
01	0521068962	HANDLE		01
02	0503013357	3/8" SELF-ADJUSTING NUT		02
03	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
001	0591011153	PLATFORM 3750		01
002	0521053066	PLATFORM SUPPORT ASSY	108	02
003	0521058413	ASSY PLATFORM SUPPORT	42	01

ASSY PLATFORM SUPPORT


0521058413




Item	Code	Description	See page	QT
001	0551019056	SIDE PLATFORM SUPPORT		01
002	0503010019	1/2" SPRING WASHER		07
003	0503010060	1/2" NUT		07
004	0503010395	1/2" X 1-1/4" BOLT		03
005	0511017302	FLAT WASHER		01
006	0591014507	GLOVE 1 X 20		04
007	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04




Item	Code	Description	See page	QT
001	0521059661	SIDE HANDRAIL 1643	44	01
002	0521059666	CENTRAL/SIDE HANDRAIL 1742	45	01
003	0521053096	ASSY SIDE FRAME HANDRAIL FIXER	46	01



Item	Code	Description	See page	QT
001	0591015730	TUBE 33,70 X 27 X 1555		03
002	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	106	02
003	0521067991	SIDE HANDRAIL		02
004	0581012718	HANDRAIL		02
005	0511059383	INTERNAL FIXER ASSY HANDLE	105	10
006	0581015992	TUBE 33,70 X 27 X 354		04




Item	Code	Description	See page	QT
001	0591015731	TUBE 33,70 X 27 X 1660		03
002	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	106	02
003	0521067991	SIDE HANDRAIL		02
004	0581012718	HANDRAIL		03
005	0511059383	INTERNAL FIXER ASSY HANDLE	105	10
006	0581015992	TUBE 33,70 X 27 X 354		04



Item	Code	Description	See page	QT
01	0581017326	HANDRAIL FIXER		01
02	0503010395	1/2" X 1-1/4" BOLT		02
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02

ASSY SIDE LADDER


0511053320




Item	Code	Description	See page	QT
01	0511069819	SIDE LADDER		01
02	0502012742	FIXER SUPPORT LADDER		02
03	0503013357	3/8" SELF-ADJUSTING NUT		02
04	0501010984	FLAT WASHER		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0503010237	3/8" X 1" BOLT		04
07	0503010025	3/8" SPRING WASHER		04
08	0503010026	3/8" NUT		04

RIGHT SIDE AIR DUCT ASSEMBLY


0521059911



Item	Code	Description	See page	QT
001	0521059710	RIGHT SIDE AIR CONDUCTOR 7 MOUTH 3668	49	01
002	0511050198	CENTRAL AIR DUTY FIXING SUPPORT	50	02
003	0521058409	CENTRAL AIR DUCT FIXER SUPPORT	136	01
004	0521052549	CLAMP	138	07




Item	Code	Description	See page	QT
001	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		07
001A	0503034812	SOCKET DISTRIBUTOR AR		01
001B	0503012856	REBITE POP		04
002	0591015830	AIR CONDUCTOR BODY		01
003	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
003A	0503034763	AIR DITRIBUTOR PUMP		01
003B	0503015341	RIVET POP		02
004	0581013633	SOCKET DISTRIBUTOR AR		01




Item	Code	Description	See page	QT
001	0571019755	FIXER LOWER REAR DRIVER AIR		01
002	0521018402	AIR CONDUCTOR CLAMP		01
003	0503010179	5/16" ZN SPRING WASHER		02
004	0503010337	5/16" NUT		02
005	0503010371	5/16" X 1" BOLT		02
006	0503010026	3/8" NUT		02
007	0503011404	BOLT		02
008	0503010025	3/8" SPRING WASHER		02

RIGHT SIDE DUCT ASSEMBLY


0521059912



Item	Code	Description	See page	QT
001	0511059943	SUPPORT FASTENER ASSY	52	04
002	0581018409	FASTENER BODY		03
003	0521059711	OIL CONDUCTOR SUPPORT	53	01
004	0503011268	3/8" X 2-1/2" BOLT		04
005	0503012456	3/8" X 7/8" BOLT		03
006	0503010025	3/8" SPRING WASHER		07
007	0501010984	FLAT WASHER		03
008	0503010026	3/8" NUT		07
009	0531061549	OIL DUCT R.3/4 X 2063		02
010	0531061548	OIL DUCT R.7/8 X 2336		02




Item	Code	Description	See page	QT
001	0581011417	DUTO HOLDER SUPPORT		01
002	0503010237	3/8" X 1" BOLT		02
003	0503010025	3/8" SPRING WASHER		02
004	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
001	0511017302	FLAT WASHER		04
002	0503010019	1/2" SPRING WASHER		04
003	0503010060	1/2" NUT		04
004	0571018437	PRISONER 1/2 X		02
005	0581018240	AIR CONDUCTOR SUPPORT BODY		01
006	0531061551	DUCT SUPPORT		01

TABELA DE DISTRIBUIÇÃO DE SEMENTES TABLE FOR DISTRIBUTION OF SEEDS													
TABELA DE DISTRIBUIÇÃO DE SEMILLAS													
Quantidade de Sementes por Unidade de Medida MATERIAL DE SEEDS QUANTITY OF SEEDS PER UNIT OF MEASURE	1	2	3	4	5	6	7	8	9	10	11	12	13
Quantidade de Sementes por Unidade de Medida QUANTITY OF SEEDS PER UNIT OF MEASURE	1	2	3	4	5	6	7	8	9	10	11	12	13
1	1	2	3	4	5	6	7	8	9	10	11	12	13
2	2	4	6	8	10	12	14	16	18	20	22	24	26
3	3	6	9	12	15	18	21	24	27	30	33	36	39
4	4	8	12	16	20	24	28	32	36	40	44	48	52
5	5	10	15	20	25	30	35	40	45	50	55	60	65
6	6	12	18	24	30	36	42	48	54	60	66	72	78
7	7	14	21	28	35	42	49	56	63	70	77	84	91
8	8	16	24	32	40	48	56	64	72	80	88	96	104
9	9	18	27	36	45	54	63	72	81	90	99	108	117
10	10	20	30	40	50	60	70	80	90	100	110	120	130
11	11	22	33	44	55	66	77	88	99	110	121	132	143
12	12	24	36	48	60	72	84	96	108	120	132	144	156
13	13	26	39	52	65	78	91	104	117	130	143	156	169
14	14	28	42	56	70	84	98	112	126	140	154	168	182
15	15	30	45	60	75	90	105	120	135	150	165	180	195
16	16	32	48	64	80	96	112	128	144	160	176	192	208
17	17	34	51	68	85	102	119	136	153	170	187	204	221
18	18	36	54	72	90	108	126	144	162	180	198	216	234
19	19	38	57	76	95	114	133	152	171	190	209	228	247
20	20	40	60	80	100	120	140	160	180	200	220	240	260
21	21	42	63	84	105	126	147	168	189	210	231	252	273
22	22	44	66	88	110	132	154	176	198	220	242	264	286
23	23	46	69	92	115	138	161	184	207	230	253	276	299
24	24	48	72	96	120	144	168	192	216	240	264	288	312
25	25	50	75	100	125	150	175	200	225	250	275	300	325
26	26	52	78	104	130	156	182	208	234	260	286	312	338
27	27	54	81	108	135	162	189	216	243	270	297	324	351
28	28	56	84	112	140	168	196	224	252	280	308	336	364
29	29	58	87	116	145	174	203	232	261	290	318	348	377
30	30	60	90	120	150	180	210	240	270	300	330	360	390
31	31	62	93	124	155	186	217	246	276	310	340	370	403
32	32	64	96	128	160	192	224	252	284	320	350	380	416
33	33	66	99	132	165	198	231	261	293	330	360	390	429
34	34	68	102	136	170	204	238	268	302	340	370	400	442
35	35	70	105	140	175	210	245	275	311	350	380	410	455
36	36	72	108	144	180	216	252	284	320	360	390	420	468
37	37	74	111	148	185	222	259	291	327	370	400	430	481
38	38	76	114	152	190	228	266	300	336	380	410	440	494
39	39	78	117	156	195	234	273	309	345	390	420	450	507
40	40	80	120	160	200	240	280	320	360	400	440	480	520
41	41	82	123	164	205	246	287	329	369	410	450	490	533
42	42	84	126	168	210	252	294	338	378	420	460	500	546
43	43	86	129	172	215	258	301	347	387	430	470	510	559
44	44	88	132	176	220	264	308	356	396	440	480	520	572
45	45	90	135	180	225	270	315	365	405	450	490	530	585
46	46	92	138	184	230	276	322	374	414	460	500	540	598
47	47	94	141	188	235	282	329	383	423	470	510	550	611
48	48	96	144	192	240	288	336	392	432	480	520	560	624
49	49	98	147	196	245	294	343	401	441	490	530	570	637
50	50	100	150	200	250	300	350	410	450	500	540	580	650
51	51	102	153	204	255	306	357	419	459	510	550	590	663
52	52	104	156	208	260	312	364	428	468	520	560	600	676
53	53	106	159	212	265	318	371	437	477	530	570	610	689
54	54	108	162	216	270	324	378	446	486	540	580	620	702
55	55	110	165	220	275	330	385	455	495	550	590	630	715
56	56	112	168	224	280	336	392	464	504	560	600	640	728
57	57	114	171	228	285	342	399	473	513	570	610	650	741
58	58	116	174	232	290	348	406	482	522	580	620	660	754
59	59	118	177	236	295	354	413	491	531	590	630	670	767
60	60	120	180	240	300	360	420	500	540	600	640	680	780
61	61	122	183	244	305	366	427	509	549	610	650	690	793
62	62	124	186	248	310	372	434	518	558	620	660	700	806
63	63	126	189	252	315	378	441	527	567	630	670	710	819
64	64	128	192	256	320	384	448	536	576	640	680	720	832
65	65	130	195	260	325	390	455	545	585	650	690	730	845
66	66	132	198	264	330	396	462	554	594	660	700	740	858
67	67	134	201	268	335	402	469	563	603	670	710	750	871
68	68	136	204	272	340	408	476	572	612	680	720	760	884
69	69	138	207	276	345	414	483	581	621	690	730	770	897
70	70	140	210	280	350	420	490	590	630	700	740	780	910
71	71	142	213	284	355	426	497	599	639	710	750	790	923
72	72	144	216	288	360	432	504	608	648	720	760	800	936
73	73	146	219	292	365	438	511	617	657	730	770	810	949
74	74	148	222	296	370	444	518	626	666	740	780	820	962
75	75	150	225	300	375	450	525	635	675	750	790	830	975
76	76	152	228	304	380	456	532	644	684	760	800	840	988
77	77	154	231	308	385	462	539	653	693	770	810	850	1001
78	78	156	234	312	390	468	546	662	702	780	820	860	1014
79	79	158	237	316	395	474	553	671	711	790	830	870	1027
80	80	160	240	320	400	480	560	680	720	800	840	880	1040
81	81	162	243	324	405	486	567	689	729	810	850	890	1053
82	82	164	246	328	410	492	574	698	738	820	860	900	1066
83	83	166	249	332	415	498	581	707	747	830	870	910	1079
84	84	168	252	336	420	504	588	716	756	840	880	920	1092
85	85	170	255	340	425	510	595	725	765	850	890	930	1105
86	86	172	258	344	430	516	602	734	774	860	900	940	1118
87	87	174	261	348	435	522	609	743	783	870	910	950	1131
88	88	176	264	352	440	528	616	752	792	880	920	960	1144
89	89	178	267	356	445	534	623	761	801	890	930	970	1157
90	90	180	270	360	450	540	630	770	810	900	940	980	1170
91	91	182	273	364	455	546	637	779	819	910	950	990	1183
92	92	184	276	368	460	552	644	788	828	920	960	1000	1196
93	93	186	279	372	465	558	651	797	837	930	970	1010	1209
94	94	188	282	376	470	564	658	806	846	940	980	1020	1222
95	95	190	285	380	475	570	665	815	855	950	990	1030	1235
96	96	192	288	384	480	576	672	824	864	960	1000	1040	1248
97	97	194	291	388	485	582	679	833	873	970	1010	1050	1261
98	98	196	294	392	490	588	686	842	882	980	1020	1060	1274
99	99	198	297	396	495	594	693	851	891	990	1030	1070	1287
100	100	200	300	400	500	600	700	860	900	1000	1040	1080	1300

0503032988



0503032986



0503032986




0503033621



0503033420



0503033414



0503031565


PLANTIO DIRETO

0503033424


LUBRIFICAR E REAPERTAR DIARIAMENTE
LUBRICATE AND TIGHTEN DAILY
LUBRICAR Y REAPERTAR DIARIAMENTE

0503031827


Item	Code	Description	See page	QT
001	0503032988	ADHESIVE LABEL		01
002	0503032986	ADHESIVE LABEL		01
003	0503033621	ADHESIVE LABEL		01
004	0503033424	DIRECT PLANTIO ADHESIVE LABEL		01
005	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING		01
006	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		01
007	0503031827	LUBRICATE AND RETIGHTEN DAILY DECAL		01
008	0503031565	ADHESIVE LABEL CARE		01



Item	Code	Description	See page	QT
001	0531061550	RIGHT SIDE REAR AXLE		01
002	0591014042	REAR SIDE CANUDO BEARING		02
003	0591014508	BACKREST LOCK		01
004	0591014460	BACKBOARD		01
005	0503019521	SCREW 3/4 UNF 3 CSRP G.8 ZN		12
006	0503010152	3/4" SELF LOCKING NUT		12
007	0503010237	3/8" X 1" BOLT		08
008	0503010025	3/8" SPRING WASHER		08
009	0503010002	1800 GREASE FITTING		04
010	0591015827	LOWER LINE AXLE LOCK		02
011	0503030085	LOCK PIN		04
012	0521059895	HYDRAULIC CYLINDER 50.8 X 101.6 X 802 X 570	56	01
013	0591015828	CYLINDER FIXING AXIS		02
014	0503012231	1/4" X 3" COTTERPIN		04
015	0591013969	LOCK CYLINDER ARTICULATION		01
016	0541016844	FIXER LOCK		01
017	0503030012	HAIR PIN		01
018	0521058132	AXLE EXTENSOR ARTICULATION	57	01
019	0521059708	LOCK EAR	58	01
020	0502012935	BEARING		02




Item	Code	Description	See page	QT
001	0581010678	50,80 X 101 RING SUPPORT		01
002	0502012842	50,80 X 101,60 PISTON		01
003	0503010817	1.1/4" SELF LOCKING NUT		01
004	0503015633	SELEMASTER SEALING		01
005	0503018029	2-217 O'RING		01
006	0503010039	D-2000 SCRAPER RING		01
007	0503018026	1870-2000-375 B GASKET		01
008	0503018025	RING GUIDE		01
009	0503011061	8-342 BACK-UP RING		02
010	0503010338	2-342 N 3006-9B O'RING		02
011	0502012822	101.60 END CAP		01
012	0503030385	CYLINDER PLUG N-002		02
013	0503010002	1800 GREASE FITTING		02
014	0531061545	CASE 101,6 X 423		01
015	0531061546	EXTENSOR 50,80 X 502		01




Item	Code	Description	See page	QT
001	0531060967	EXTENSOR R.1.1/2 UNC		01
002	0503010002	1800 GREASE FITTING		02
003	0531060966	EXTENSOR R.1.1/2 UNC		01
004	0501110486	REGULATING NUT		01
005	0521010571	COUPLING SHAFT		02
006	0503030085	LOCK PIN		02

LOCK EAR

0521059708




Item	Code	Description	See page	QT
001	0531061547	MOBILE LATCH ARTICULATION LINE		01
002	0531060990	LOWER LOCK LINE ARTICULATION		01
003	0503017855	3/4" BOLT		02
004	0503010152	3/4" SELF LOCKING NUT		02




Item	Code	Description	See page	QT
001	0531061153	SUPPORT SIDE FRAME SIDE WITHOUT TIRE		01
002	0571011070	5/8" UNC FASTENER		01
003	0503012412	5/8 UNC SELF LOCKING NUT		04
004	0501012140	FLAT WASHER		04
005	0503012410	5/8" X 7.1/2" BOLT		02
006	1902010024	LINE SUPPORT CLAMP		01

SIDE HEX AXLE


0521059901




Item	Code	Description	See page	QT
001	0591015718	HEX AXLE 3/4 X 2674		01
002	0591015719	HEX AXLE 3/4 X 2027		01
003	0561015837	SLEEVE 31,75		01
004	0503010523	1/4" X 2" COTTERPIN		01
005	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		04
005A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
005B	0503010256	3/8" X 3/4" BOLT		01




Item	Code	Description	See page	QT
01	0503010243	CLAMP		02
02	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
03	0503012880	1/4" UNC SELF ADJUSTING NUT		02
04	0503063012	SEED TRANSMISSION SHAFT HEX 3/4		01
05	0503034773	HOSE 1.1/2 X 1.1/2 X 120		01




Item	Code	Description	See page	QT
001	0521058329	SEED CONDUCTOR	101	04
002	0503062961	FERTILIZER BEAM ASSY		01
003	0531061530	SUPPORT RIGHT 1633 X 1142		01
004	0521051407	FIXER SILO FERTILIZER	102	06




Item	Code	Description	See page	QT
001	0521058329	SEED CONDUCTOR	101	05
002	0503062962	SILO SEED 05 ASSY MOUTH		01
003	0531061601	SUPPORT 2033 X 1977		01
004	0521051407	FIXER SILO FERTILIZER	102	08




Item	Code	Description	See page	QT
001	0591011211	PLATFORM		01
002	0591014066	PLATFORM 2640		01
003	0521053066	PLATFORM SUPPORT ASSY	108	04




Item	Code	Description	See page	QT
001	0521059685	CENTRAL HANDRAIL 2028 X 1207	66	01
002	0521059744	CENTRAL HANDRAIL 2731 X 2037	67	01
003	0521059654	INTERNAL SIDE HANDRAIL 643 X 875	68	01




Item	Code	Description	See page	QT
001	0591015761	TUBE 33,70 X 27 X 1125		03
002	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	106	08
003	0521067991	SIDE HANDRAIL		02
004	0581012718	HANDRAIL		04
005	0581014825	TUBE 33,70 X 27 X 924		02
006	0511059383	INTERNAL FIXER ASSY HANDLE	105	10
007	0581015992	TUBE 33,70 X 27 X 354		04
008	0591015721	TUBE 33,70 X 27 X 210		03
009	0581018303	TUBE		03




Item	Code	Description	See page	QT
001	0591015990	TUBE 33,70 X 27 X 1955		03
002	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	106	08
003	0521067991	SIDE HANDRAIL		02
004	0581012718	HANDRAIL		04
005	0581014825	TUBE 33,70 X 27 X 924		02
006	0511059383	INTERNAL FIXER ASSY HANDLE	105	10
007	0581015992	TUBE 33,70 X 27 X 354		04
008	0591015989	TUBE 33,70 X 27 X 320		03
009	0591015721	TUBE 33,70 X 27 X 210		03




Item	Code	Description	See page	QT
001	0511059383	INTERNAL FIXER ASSY HANDLE	105	06
002	0503013357	3/8" SELF-ADJUSTING NUT		04
003	0591011198	50MM HANDRAIL SUPPORT		04
004	0581012718	HANDRAIL		02
005	0591012480	SIDE L INTERNAL HANDRAIL		02
006	0591015723	TUBE 33,70 X 27 X 528		03
007	0501010984	FLAT WASHER		04
008	0503011268	3/8" X 2-1/2" BOLT		04




Item	Code	Description	See page	QT
001	0591014070	P.P TURBINE SUPPORT		01
002	0503010190	2-114 N 3006-9B O'RING		04
003	0503010392	2-046 N 3006 9B O'RING		01
004	0501011460	7/8 NF REDUCTION NIPPLE		04
005	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
006	0521050154	TURBINE P.P WITH HOLE	70	01
007	0503015420	VALVE ANTI-CAVITACAO CV10208TN5		01
008	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
009	0503010143	1/4" SPRING WASHER		02
010	0503010144	1/4" NUT		02
011	0503010305	FLAT WASHER		02
012	0503031426	ETIQ ADES ATENCAO TURBINA		01
013	0503031087	ADHESIVE LABEL		01
014	0511017907	1/8" BSPT X 6 PLUG		01
015	0581012096	ROUND SLEEVE		02
016	0503011372	102 TO 121 CLAMP		02
017	0501080788	1/2" X 570 HOSE ASSY		01
018	0581018240	AIR CONDUCTOR SUPPORT BODY		02
019	0571018437	PRISONER 1/2 X		04
020	0503010060	1/2" NUT		08
021	0503010019	1/2" SPRING WASHER		08
022	0511017302	FLAT WASHER		08




Item	Code	Description	See page	QT
01	0503034404	TURBINE REAR COVER		01
02	0503034405	MOTOR PP 730425		01
03	0503034406	FAN PP 730115		01
04	0503034407	NUT		01
05	0503062606	COVER		01
06	0503034409	JOINT PP 730134		01
07	0503034410	DISTRIBUTOR TUBE		01
08	0503034411	DISTRIBUTOR TUBE GUIDE		04
09	0503034402	WASHER 3/8		04
10	0503034403	SCREW 3/8 16FPP X 1		04
11	0503034412	NUT 3/8 16 FPP		02
12	0503034413	FLAT WASHER		07
13	0503034414	SCREW 5/16 X 1		07
14	0503011336	1/2" HEX SELF ADJUSTING NUT		02
15	0511817302	FLAT WASHER		02
16	0503810706	SCREW 1/2 UNC X 4.1/2 C S G.5 SA		02
17	0503062560	TUBE FOR METER CLOCK 730142		01



Item	Code	Description	See page	QT
001	0521059682	RIGHT SIDE AIR CONDUCTOR 9 MOUTH 4656	72	01
002	0521058409	CENTRAL AIR DUCT FIXER SUPPORT	136	01
003	0511050198	CENTRAL AIR DUTY FIXING SUPPORT	50	02
004	0521052549	CLAMP	138	09




Item	Code	Description	See page	QT
001	0511057036	AIR DISTRIBUTOR BOARD		01
001A	0503012567	T-JOIN FOR TUBE 110		01
001B	0581013890	SOCKET DISTRIBUTOR AR		01
002	0591015749	CONDUCTOR BODY AIR 2 MOUTH 595 4 HOLES		01
003	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		09
003A	0503034812	SOCKET DISTRIBUTOR AR		01
003B	0503012856	REBITE POP		04
004	0591015750	CONDUCTOR BODY AIR 250 MM		01
005	0591015759	CONDUCTOR BODY AIR 7 MOUTH 3520 4 HOLES		01
006	0521050393	ASSY KNEE		02
006A	0503017845	PVC KNEE 90 SOLDAREL		01
006B	0581013890	SOCKET DISTRIBUTOR AR		01
007	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
007A	0503034763	AIR DISTRIBUTOR PUMP		01
007B	0503015341	RIVET POP		02
008	0503012567	T-JOIN FOR TUBE 110		01
009	0591015760	CONDUCTOR BODY AIR 218		01




Item	Code	Description	See page	QT
001	0591015744	GUTTER 30 X 55 X 3105		01
002	0591015745	GUTTER 30 X 55 1260		01
003	0501010984	FLAT WASHER		04

RIGHT INTERMEDIATE DUCT ASSY


0521059928




Item	Code	Description	See page	QT
001	0511059943	SUPPORT FASTENER ASSY	52	05
002	0521059681	SUPPORT DUCT OIL 5 DUCTS	75	02
003	0581018415	PROTECTION BODY		04
004	0581018407	BODY FASTENER 2 DUCTS		06
005	0503012456	3/8" X 7/8" BOLT		04
006	0503011268	3/8" X 2-1/2" BOLT		03
007	0503010481	BOLT		02
008	0503011123	BOLT		01
009	0501010984	FLAT WASHER		04
010	0503010025	3/8" SPRING WASHER		10
011	0503010026	3/8" NUT		10
012	0521069206	OIL DUCT R.3/4 X 1770		01
013	0521069104	OIL DUCT R.7/8 X 1770		02
014	0531061526	OIL DUCT 3 OUTPUTS R.3 / 4 X 2202		02
015	0531061524	OIL DUCT R.7 / 8 X 2063		02
016	0531061525	OIL DUCT 3 OUTPUTS R.7 / 8 X 2202		02
017	0531061549	OIL DUCT R.3/4 X 2063		03
018	0531061507	OIL DUCT R.7 / 8 X 2063		02
019	0501082190	HOSE 3/8 X 160 TR-TR		03
020	0501082189	HOSE 1/2 X 160 TR-TR		04




Item	Code	Description	See page	QT
001	0511017302	FLAT WASHER		04
002	0503010019	1/2" SPRING WASHER		04
003	0503010060	1/2" NUT		04
004	0571018437	PRISONER 1/2 X		02
005	0581018240	AIR CONDUCTOR SUPPORT BODY		01
006	0531061527	SIDE SUPPORT FIXING 5 DUCT		01




Item	Code	Description	See page	QT
01	0531061600	RIGHT / INTERMEDIATE REAR AXLE		01
02	0591014042	REAR SIDE CANUDO BEARING		02
03	0591014508	BACKREST LOCK		02
04	0503019521	SCREW 3/4 UNF 3 CSRP G.8 ZN		12
05	0503010152	3/4" SELF LOCKING NUT		12
06	0503010237	3/8" X 1" BOLT		08
07	0503010025	3/8" SPRING WASHER		08
08	0503010002	1800 GREASE FITTING		04
09	0591015827	LOWER LINE AXLE LOCK		02
10	0503030085	LOCK PIN		04
11	0521059895	HYDRAULIC CYLINDER 50.8 X 101.6 X 802 X 570	56	01
12	0591015828	CYLINDER FIXING AXIS		02
13	0503012231	1/4" X 3" COTTERPIN		04
14	0591013969	LOCK CYLINDER ARTICULATION		01
15	0541016844	FIXER LOCK		01
16	0503030012	HAIR PIN		01
17	0521058132	AXLE EXTENSOR ARTICULATION	57	01
18	0521059708	LOCK EAR	58	01
19	0502012935	BEARING		02




Item	Code	Description	See page	QT
01	0521058329	SEED CONDUCTOR	101	04
02	0503062961	FERTILIZER BEAM ASSY		01
03	0531061501	SUPPORT RIGHT 1633 X 1190		01
04	0521051407	FIXER SILO FERTILIZER	102	06




Item	Code	Description	See page	QT
01	0521058329	SEED CONDUCTOR	101	05
02	0503062962	SILO SEED 05 ASSY MOUTH		01
03	0531061502	RIGHT SUPPORT 2033 X 1590		01
04	0521051407	FIXER SILO FERTILIZER	102	08




Item	Code	Description	See page	QT
01	0581017737	PLATFORM 2570		01
02	0591010469	PLATFORM 2300		01
03	0521053066	PLATFORM SUPPORT ASSY	108	04




Item	Code	Description	See page	QT
01	0521059652	CENTRAL HANDRAIL 2120 X 1252	81	01
02	0521059653	CENTRAL HANDRAIL 2554 X 1652	82	01
03	0521059654	INTERNAL SIDE HANDRAIL 643 X 875	68	01




Item	Code	Description	See page	QT
01	0591015722	TUBE 33,70 X 27 X 1170		03
02	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	106	08
03	0521067991	SIDE HANDRAIL		02
04	0581012718	HANDRAIL		04
05	0581014825	TUBE 33,70 X 27 X 924		02
06	0511059383	INTERNAL FIXER ASSY HANDLE	105	10
07	0581015992	TUBE 33,70 X 27 X 354		04
08	0581017332	TUBE		03
09	0591015721	TUBE 33,70 X 27 X 210		03




Item	Code	Description	See page	QT
01	0591015720	TUBE 33,70 X 27 X 1570		03
02	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	106	08
03	0521067991	SIDE HANDRAIL		02
04	0581012718	HANDRAIL		04
05	0581014825	TUBE 33,70 X 27 X 924		02
06	0511059383	INTERNAL FIXER ASSY HANDLE	105	10
07	0581015992	TUBE 33,70 X 27 X 354		04
08	0591015723	TUBE 33,70 X 27 X 528		03
09	0591015721	TUBE 33,70 X 27 X 210		03




Item	Code	Description	See page	QT
01	0581014830	FIXER MOVEL TURBINE		01
02	0511059406	TURBINE P.P MOUNTED	84	01
03	0503010027	5/8" SPRING WASHER		08
04	0503010013	5/8" NUT		08
05	0501012140	FLAT WASHER		04
06	0503010232	5/8" X 1.3/4" BOLT		04
07	0571011070	5/8" UNC FASTENER		02




Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE		01
02	0501011460	7/8 NF REDUCTION NIPPLE		04
03	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
04	0503010392	2-046 N 3006 9B O'RING		01
05	0581012096	ROUND SLEEVE		02
06	0503015420	VALVE ANTI-CAVITACAO CV10208TN5		01
07	0521050154	TURBINE P.P WITH HOLE	70	01
08	0503011372	102 TO 121 CLAMP		02
09	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
10	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
11	0503010143	1/4\" SPRING WASHER		02
12	0503010144	1/4\" NUT		02
13	0503010190	2-114 N 3006-9B O'RING		04
14	0501081235	1/2 X 650 TR- TC HOSE		01



Item	Code	Description	See page	QT
01	0521059651	RIGHT SIDE AIR CONDUCTOR 9 MOUTH 4373	86	01
02	0511050198	CENTRAL AIR DUTY FIXING SUPPORT	50	03
03	0521052549	CLAMP	138	18




Item	Code	Description	See page	QT
01	0511057036	AIR DISTRIBUTOR BOARD		02
01A	0503012567	T-JOIN FOR TUBE 110		01
01B	0581013890	SOCKET DISTRIBUTOR AR		01
02	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		09
02A	0503034812	SOCKET DISTRIBUTOR AR		01
02B	0503012856	REBITE POP		04
03	0591015717	CONDUCTOR BODY AIR 2 MOUTHS 650 4 HOLES		01
04	0591015716	CONDUCTOR BODY AIR 4 MOUTH 1952 4 HOLES		01
05	0591015715	CONDUCTOR BODY AIR 3 MOUTH 1480 4 HOLES		01
06	0521050393	ASSY KNEE		01
06A	0503017845	PVC KNEE 90 SOLDAREL		01
06B	0581013890	SOCKET DISTRIBUTOR AR		01
07	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
07A	0503034763	AIR DISTRIBUTOR PUMP		01
07B	0503015341	RIVET POP		02




Item	Code	Description	See page	QT
01	0591015711	GUTTER 30 X 55 X 2200		01
02	0591015710	GUTTER 30 X 55 X 2005		01
03	0501010984	FLAT WASHER		04

RIGHT SIDE DUCT ASSEMBLY


0521059916




Item	Code	Description	See page	QT
01	0511059943	SUPPORT FASTENER ASSY	52	07
02	0581018415	PROTECTION BODY		11
03	0581018409	FASTENER BODY		02
04	0581018407	BODY FASTENER 2 DUCTS		02
05	0503012456	3/8" X 7/8" BOLT		04
06	0503011268	3/8" X 2-1/2" BOLT		01
07	0503010481	BOLT		02
08	0503011123	BOLT		05
09	0503010025	3/8" SPRING WASHER		12
10	0503010026	3/8" NUT		12
11	0531061511	OIL DUCT 3 OUTPUTS R.3 / 4 X 2883		01
12	0531061510	OIL DUCT 3 OUTPUTS R.7 / 8 X 2882		02
13	0531061508	OIL DUCT 3 OUTPUTS R.3 / 4 X 1939		02
14	0531061507	OIL DUCT R.7 / 8 X 2063		02
15	0531061505	OIL DUCT R.1.1 / 16 X 2100		02
16	0531061509	OIL DUCT 3 OUTPUTS R.7 / 8 X 1939		02
17	0521068926	OIL DUCT R3 / 4 X 2730		02
18	0531061506	OIL DUCT R.7 / 8 X 2980		01
19	0521059681	SUPPORT DUCT OIL 5 DUCTS	75	01
20	0501082189	HOSE 1/2 X 160 TR-TR		02




Item	Code	Description	See page	QT
01	0521059709	WHEEL BLOCK SUPPORT	36	01
02	0521058407	ASSY APT/CBA ENGINE SUPPORT	117	01
03	0521057179	PARKER OMR 125 ISOBUS HYDRAULIC ENGINE WITH VALVE	143	01
04	0503019799	FLOW DIVIDER VALVE		01



Item	Code	Description	See page	QT
001	0531061600	RIGHT / INTERMEDIATE REAR AXLE		01
002	0591014042	REAR SIDE CANUDO BEARING		02
003	0591014508	BACKREST LOCK		02
004	0503019521	SCREW 3/4 UNF 3 CSRP G.8 ZN		12
005	0503010152	3/4" SELF LOCKING NUT		12
006	0503010237	3/8" X 1" BOLT		08
007	0503010025	3/8" SPRING WASHER		08
008	0503010002	1800 GREASE FITTING		04
009	0591015827	LOWER LINE AXLE LOCK		02
010	0503030085	LOCK PIN		04
011	0521059895	HYDRAULIC CYLINDER 50.8 X 101.6 X 802 X 570	56	01
012	0591015828	CYLINDER FIXING AXIS		02
013	0503012231	1/4" X 3" COTTERPIN		04
014	0591013969	LOCK CYLINDER ARTICULATION		01
015	0541016844	FIXER LOCK		01
016	0503030012	HAIR PIN		01
017	0521058132	AXLE EXTENSOR ARTICULATION	57	01
018	0521059708	LOCK EAR	58	01
019	0502012935	BEARING		02




Item	Code	Description	See page	QT
01	0531061532	FRAME CENTRAL 5230		01
02	0501010276	BOLT		20
03	0503010012	1" SPRING WASHER		20
04	0503012182	1" NUT		20
05	0571012964	AXLE BODY WHEELS PIVOT		02
06	0501010630	1.1/2" CASTLE NUT		02
07	0503011345	1/4" X 3-1/2" COTTERPIN		02
08	0521053207	INTERNAL PLATE WITH FIXATION SCREW 1/2	92	01




Item	Code	Description	See page	QT
01	0561017061	TUBE ADJUSTMENT PLATE		01
02	0503010019	1/2" SPRING WASHER		08
03	0501010161	1/2" X 1.1/4" BOLT		08

ASSY CENTRAL HEX AXLE


0521059936




Item	Code	Description	See page	QT
01	0561018835	3/4" X 2680 HEX AXLE		02
02	0561015837	SLEEVE 31,75		01
03	0503010523	1/4" X 2" COTTERPIN		01
04	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		04
04A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
04B	0503010256	3/8" X 3/4" BOLT		01




Item	Code	Description	See page	QT
001	0531061054	CUTTING DISK SUPPORT		01
002	0502012768	LINE SUPPORT CLAMP		02
003	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
004	0503013389	5/8" SELF LOCKING NUT		04




Item	Code	Description	See page	QT
01	0531061541	BALANCIN JOINT AXIS WITH FLANGE		02
02	0581013528	FLANGED NUT		02
03	0551012036	FLAT WASHER		02
04	0503010002	1800 GREASE FITTING		05
05	0503012213	1/4" COTTERPIN		02
06	0501010322	FLAT WASHER		12
07	0503010152	3/4" SELF LOCKING NUT		12
08	0501111028	CENTRAL WHEEL BALANCIN WITH GLOVE		02
09	0503014441	BOLT 3/4		12
10	0521059697	ROD SUPPORT WITH GLOVE		01
10A	0531061540	ROD SUPPORT		01
10B	0591014085	GLOVE 90MM		06
11	0531040591	HYDRAULIC CYLINDER 63.5 X 150 X 781 X 355	96	02
12	0531060954	SMALLER CYLINDER AXLE 179		02
13	0531060956	SMALLER WHEEL AXLE		02
14	0503011052	1.1/4" X 0.77" CASTLE NUT		04
15	0531061077	LOWER AXLE CYLINDER		03
16	0503011345	1/4" X 3-1/2" COTTERPIN		03
17	0501010630	1.1/2" CASTLE NUT		03
18	0561019929	FLAT WASHER		03
19	0521058408	CENTRAL WHEEL AXLE CUBE	97	04
20	0503010038	3/16 X 2 COTTERPIN		04




Item	Code	Description	See page	QT
01	0531061536	BAR ASSY		01
02	0531061534	CASE		01
03	0541010615	6" END CAP		01
04	0581018237	RING SUPPORT 63.50 X 150 X 80		01
05	0503014960	GASKET		01
06	0503010287	D-2500 SCRAPER RING		01
07	0503010971	W2-2750-500 PK RING G.I		02
08	0503010003	1845 GREASE FITTING		01
09	0581018236	PISTON 150 X 57 GASPM EHD 16		01
10	0503019098	O' RING 2-227 N 3006-90B		01
11	0581018235	10 X 30 NUT		01
12	0503015912	SELEMASTER SEALING		01
13	0503010002	1800 GREASE FITTING		01
14	0503030387	PLUG		02
15	0503010704	2-357 N 3006-9B O'RING		01
16	0503019286	BACK-UP RING 8-357		01




Item	Code	Description	See page	QT
01	0511045858	WHEEL HUB ASSY WITH BRAKE	98	01
02	0591014475	MOUNTED WHEEL AXLE		01
03	0561015521	FLANGE		05
04	0501010219	1" X 7-1/2" BOLT		01
05	0503010012	1" SPRING WASHER		01
06	0501010059	1.5/8 NUT		01



Item	Code	Description	See page	QT
01	0501110771	CARRYING WHEEL HUB		01
01A	0502012462	WHEEL HUB		01
01B	0503014048	22 X 1.5 HEX NUT		10
01C	0503014049	M22 X 1,5 X 89/97" BOLT		10
02	0503010118	32218 ROLLER BEARING		02
03	0531019986	64 X 110 X 9.5 FLAT WASHER		01
04	0502040080	2.1/2" SLOTTED NUT		01
05	0503013541	SEAL		01
06	0503012213	1/4" COTTERPIN		01
07	0503013548	DUST CAP		01
08	0503013549	HUB CUP		01
09	0503013546	10 X 1.5 X 20MM BOLT		04
10	0503013542	M10 SPRING WASHER		04




Item	Code	Description	See page	QT
01	0503015483	TIRE 600/50-22.5 TL T404 168A8		01
02	0503013045	WHEEL ASSY		01
03	0503013999	VALVE		01




Item	Code	Description	See page	QT
01	0531061539	SUPPORT 2021 X 1487		01
02	0503062962	SILO SEED 05 ASSY MOUTH		01
03	0521058329	SEED CONDUCTOR	101	05
04	0521051407	FIXER SILO FERTILIZER	102	08
05	0503010920	1/2" X 1.1/2" BOLT		06
06	0511017302	FLAT WASHER		06
07	0503010589	1/2" UNC SELF ADJUSTING NUT		06

SEED CONDUCTOR


0521058329




Item	Code	Description	See page	QT
01	0531061059	CONDUCTOR WITH FLANGED		01
02	0503010358	5/16" X 5/8" BOLT		02
03	0503010337	5/16" NUT		02
04	0503010179	5/16" ZN SPRING WASHER		03
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
06	0503010499	5/16" UNC BUTTERFLY NUT		01
07	0503011953	5/16" X 1" BOLT		01
08	0503013759	NUT		04
09	0581019780	COVER		01
10	0502012899	DUCT BODY		01
11	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		04
12	0503034859	JOIN		01



Item	Code	Description	See page	QT
01	0503012531	3/8" INOX NUT		01
02	0503012535	3/8" SPRING WASHER		01
03	0571019051	FIXER BOX WASHER		01
04	0503013751	3/8 UNC X 1.1/4 BOLT		01




Item	Code	Description	See page	QT
01	0511059383	INTERNAL FIXER ASSY HANDLE	105	06
02	0503013357	3/8" SELF-ADJUSTING NUT		04
03	0591011198	50MM HANDRAIL SUPPORT		04
04	0581012718	HANDRAIL		02
05	0591012480	SIDE L INTERNAL HANDRAIL		02
06	0591015787	TUBE 33,70 X 27 X 560		03
07	0501010984	FLAT WASHER		04
08	0503011268	3/8" X 2-1/2" BOLT		04




Item	Code	Description	See page	QT
01	0591015788	TUBE 33,70 X 27 X 1345		03
02	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	106	07
03	0521067991	SIDE HANDRAIL		02
04	0581012718	HANDRAIL		04
05	0581014825	TUBE 33,70 X 27 X 924		02
06	0511059383	INTERNAL FIXER ASSY HANDLE	105	08
07	0581015992	TUBE 33,70 X 27 X 354		02
08	0581017332	TUBE		06

INTERNAL FIXER ASSY HANDLE


0511059383




Item	Code	Description	See page	QT
01	0502012857	OUTER FIXER		01
02	0502012858	INNER FIXER		01
03	0503019083	7/16" X 2.1/4" BOLT		01
04	0503015490	NUT AUTOFREN 7/16 NC		01



Item	Code	Description	See page	QT
01	0502012855	CENTRAL FIXER		01
02	0502012856	CENTRAL FIXER		01
03	0503019083	7/16" X 2.1/4" BOLT		02
04	0503015490	NUT AUTOFREN 7/16 NC		02




Item	Code	Description	See page	QT
01	0591010990	PLATFORM 2700		02
02	0521053066	PLATFORM SUPPORT ASSY	108	04




Item	Code	Description	See page	QT
01	0551019056	SIDE PLATFORM SUPPORT		01
02	0503010019	1/2" SPRING WASHER		07
03	0503010060	1/2" NUT		07
04	0503014007	1/2" X 1-1/4" BOLT		07
05	0511017302	FLAT WASHER		01

ASSY ARTICULATED LEFT ARM


0521058118




Item	Code	Description	See page	QT
01	0503015322	BOLT 7/8		01
02	0503010408	7/8" SPRING WASHER		01
03	0591012103	ARTICULATION AXIS FLAT		01
04	0503010002	1800 GREASE FITTING		01
05	0503010004	1890 GREASE FITTING		01
06	0571011767	LISA WASHER 125 X 88 X 4.76		01
07	0503035026	PLATE 840 X 110 X 10		01
08	0501111024	LEFT ARTICULATION ARM WITH GLOVE		01
09	0503011075	3/4" UNC NUT		01
10	0503019246	BOLT		01
11	0531060964	ARTICULATION AXIS VERTICAL WITH LOCK		01
12	0503010814	5/16 BOLT		12




Item	Code	Description	See page	QT
01	0571011767	LISA WASHER 125 X 88 X 4.76		01
02	0503010002	1800 GREASE FITTING		01
03	0591012103	ARTICULATION AXIS FLAT		01
04	0531060964	ARTICULATION AXIS VERTICAL WITH LOCK		01
05	0503015322	BOLT 7/8		01
06	0503010408	7/8" SPRING WASHER		01
07	0503011075	3/4" UNC NUT		01
08	0503019246	BOLT		01
09	0503010004	1890 GREASE FITTING		01
10	0503035026	PLATE 840 X 110 X 10		01
11	0501111033	RIGHT ARTICULATION ARM WITH GLOVE		01
12	0503010814	5/16 BOLT		12




Item	Code	Description	See page	QT
01	0521058104	HYDRAULIC CYLINDER 63.50 X 150	112	02
02	0531060955	LOWER CYLINDER AXIS		02
03	0531060957	LARGER CYLINDER AXIS		02
04	0503011052	1.1/4" X 0.77" CASTLE NUT		04
05	0503010038	3/16 X 2 COTTERPIN		04



Item	Code	Description	See page	QT
01	0531060952	BAR 63,50 X 1091		01
02	0531060951	CASE 150 X 1026		01
03	0503010287	D-2500 SCRAPER RING		01
04	0503010971	W2-2750-500 PK RING G.I		02
05	0581011197	PISTON		01
06	0581013481	MOBILE COVER 150		01
07	0581011195	2.5" X 5" RING SUPPORT		01
08	0503014960	GASKET		01
09	0503018465	ANILLO O'RING		01
10	0503018467	RING		01
11	0503010002	1800 GREASE FITTING		02
12	0503030385	CYLINDER PLUG N-002		02
13	0511017907	1/8" BSPT X 6 PLUG		01
14	0503018466	O'RING		01




Item	Code	Description	See page	QT
01	0521059938	CENTRAL DUCT ASSY CSU/APT	114	01
02	0503019422	FILTER PDA 60 MICRA CASAPPA HHQ00540		02
03	0503063057	COMMAND BLOCK		01
04	0521058489	CASAPPA TRIPLE DIVIDER VALVE BRP00090 WITH NIPLES	116	01
05	0521058407	ASSY APT/CBA ENGINE SUPPORT	117	01
06	0521058103	CENTRAL SUPPORT	121	01
07	0591015767	NIPLE R.3/4 BSP 14 FPP X R.1.5/16" UN		01
08	0591015768	NIPLE R.1.1/16 UN X R.3/4 BSP 14 FPP		02
09	0521058505	ARTICULATION HOSE GAME	122	01
10	0521058506	HEAD HOSE ASSY	123	01
11	0521058507	LIFT HOSE GAME	124	01
12	0521058508	HOSE KIT 4 TURBINES	125	01
13	0521058509	APT HOSE KIT	126	01
14	0521058510	TRANSPORT HOSE KIT	127	01
15	0521058511	LINES HOSE KIT ARTICULATION	128	01
16	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	129	06
17	0581017815	MALE ADAPTER		01
18	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0521069199	OIL DUCT R.3/4 X 1480		04
02	0531061075	RETURN OIL DUCT		01
03	0531061076	OIL DUCT 3 OUTPUTS R7 / 8 X 1726		01
04	0521069198	OIL DUCT R.7/8 X 1480		06
05	0521069200	OIL DUCT R.1.1/16 X 1480		02
06	0521051537	CENTRAL REAR DUCT SUPPORT	115	02
07	0581018408	SUPPORT SCALE		04
08	0581018409	FASTENER BODY		04
09	0591015771	BODY HOLDER 3 DUCTS		02
10	0591015772	BODY HOLDER 4 DUCTS		02
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		06
12	0503010481	BOLT		08
13	0503010025	3/8" SPRING WASHER		14
14	0503010026	3/8" NUT		14
15	0501010984	FLAT WASHER		03
16	0591014472	RIGHT SUPPORT OF CENTRAL FRAME		02
17	0591014473	LEFT SUPPORT DUCT CHASSI CENTRAL		02

CENTRAL REAR DUCT SUPPORT


0521051537




Item	Code	Description	See page	QT
01	0571019615	FITTING 1/2 UNC 130 X 198 ZN		01
02	0511017302	FLAT WASHER		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0503010025	3/8" SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581014997	BODY SUPPORT DUCT REAR		01
08	0503011141	3/8" X 2-3/4" BOLT		01
09	0581014987	LOWER BODY FASTENER		01



Item	Code	Description	See page	QT
01	0503019501	VALVE		01
02	0581013111	NIPLE R 1.1/6 UN X 1.5/16 12 WIRES		01
03	0503014724	2-215 N 3006-9B O'RING		01
04	0503012923	2-116 3006-9B O'RING		03
05	0501010590	7/8" REDUCTION NIPPLE		03
06	0503010026	3/8" NUT		04
07	0501010984	FLAT WASHER		04
08	0503010025	3/8" SPRING WASHER		04
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04




Item	Code	Description	See page	QT
01	0531061073	HYDRAULIC MOTOR SUPPORT BODY APT/CBA		01
02	0521051293	16Z/32Z GEAR BEARING	118	01
03	0521067333	DRIVER GEAR		01
04	1902010024	LINE SUPPORT CLAMP		01
05	0581014672	SUPPORT ENCODER		01
06	0503010337	5/16" NUT		02
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503011953	5/16" X 1" BOLT		02
09	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
10	0503010019	1/2" SPRING WASHER		02
11	0503010060	1/2" NUT		02
12	0503011807	SCREW M8 X 1,25X10		02
13	0501054655	CHAIN TENSIONER ASSY	119	01
14	0511059969	CHAIN TENSIONER	120	01
15	0521067982	36Z P1/2 SH GEAR		01
16	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		02
16A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
16B	0503010256	3/8" X 3/4" BOLT		01
17	0503011106	40-1 CHAIN X 58 LINK + REDUCTION		01
18	0503015544	CURRENT 40-1 54 ELOS		01
19	0503012410	5/8" X 7.1/2" BOLT		02
20	0503013389	5/8" SELF LOCKING NUT		02
21	0501012140	FLAT WASHER		02
22	0531061078	MOTOR PROTECTION		01



Item	Code	Description	See page	QT
01	0581014670	DOUBLE GEAR AXLE		01
02	0521067941	DOUBLE GEAR AXLE		01
03	0503012882	BEARING		02
04	0503011945	503050 CLAMPING RING (FOR AXLE)		02
05	0581014671	DOUBLE GEAR SLEEVE		01
06	0501013519	FLAT WASHER		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2" NUT		01

CHAIN TENSIONER ASSY


0501054655



Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01

CHAIN TENSIONER


0511059969




Item	Code	Description	See page	QT
01	0581012970	TIGHTENER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01

CENTRAL SUPPORT


0521058103




Item	Code	Description	See page	QT
01	0591013866	HYDRAULIC BLOCK SUPPORT		01
02	0591014182	SOPORTE DIVIDIR		01
03	0511017302	FLAT WASHER		04
04	0503010589	1/2" UNC SELF ADJUSTING NUT		04
05	0503010920	1/2" X 1.1/2" BOLT		04
06	0503010025	3/8" SPRING WASHER		04
07	0503010172	M10 X 1,5 X 25 BOLT		04
08	0501010984	FLAT WASHER		04
09	0503013357	3/8" SELF-ADJUSTING NUT		04
10	0503010237	3/8" X 1" BOLT		04




Item	Code	Description	See page	QT
01	0501080419	TR-TC HOSE ASSY		01
02	0501080525	3/8 X 2300 TC-TC HOSE ASSY		01
03	0501081987	HOSE 3/8 X 1550 TR-TC		01
04	0501080249	3/8" X 33" TR-TC HOSE ASSY		01
05	0501080025	TR-TC HOSE ASSY		01
06	0501080450	TR-TC HOSE ASSY		01




Item	Code	Description	See page	QT
01	0501080461	TR-TC HOSE ASSY		02
02	0501080105	TR-TR HOSE ASSY		02
03	0501081447	3/8 X 6600 TC-TR HOSE		02
04	0501080128	3/8" X 71" TR-TR HOSE ASSY		02
05	0501080759	HOSE 3/8 X 350 TR-TC		01
06	0501080026	3/8 X 950 TR-TC HOSE		01




Item	Code	Description	See page	QT
01	0501081200	3/4 X 700 TR-TC HOSE		01
02	0501080040	HOSE 1/2 X 500 TR-TC		01
03	0501080120	1/2" X 400 TR-TR HOSE		01
04	0501080087	1/2" X 450 HOSE		01
05	0501080028	3/4 X 1200 TR-TC HOSE		01
06	0501080057	HOSE 1/2 X 900 TR-TC		04
07	0501080166	1/2" X 22" TR-TR HOSE ASSY		04
08	0501080218	1/2 X 750 HOSE		03
09	0501081299	HOSE 1/2 X 300 TR-TC		03
10	0501080621	1/2 X 1200 TC-TC HOSE		02
11	0501080023	3/4 X 1700 TR-TC HOSE		02
12	0501080234	HOSE 3/4 X 2700 TR-TR		02
13	0501081264	HOSE 1/2 X 3300 TR-TR 2T		02
14	0501080024	1/2" X 700 TR-TR HOSE		38




Item	Code	Description	See page	QT
01	0501080285	1/2" X 16" TR-TC HOSE ASSY		01
02	0501080239	HOSE 1/2 X 350 TR-TC		01
03	0501080054	3/8" X 17" TR-TC HOSE ASSY		01
04	0501080431	TR-TC HOSE ASSY		01
05	0501080783	HOSE 3/8 X 5000 TR-TR		01
06	0501080674	3/8" X 181" TR-TM HOSE ASSY		01
07	0501080394	HOSE TR-TC		01
08	0501081796	3/8" X 1650 TR-TC HOSE		01
09	0501080413	3/8" X 27" TR-TC HOSE		01
10	0501080166	1/2" X 22" TR-TR HOSE ASSY		01
11	0501080040	HOSE 1/2 X 500 TR-TC		02
12	0501080024	1/2" X 700 TR-TR HOSE		04
13	0501080282	HOSE 1/2		02
14	0501081751	HOSE 1/2 X 5200 TC-TR		04
15	0501080105	TR-TR HOSE ASSY		02
16	0501082266	HOSE 1/2 X 4600 TR-TM		04
17	0501080060	1/2 X 1600 TR-TC HOSE		02
18	0501080465	3/8 X 400 TR-TC HOSE ASSY		02
19	0501081208	HOSE 1/2 X 600 TC-TR 2T		02
20	0501082024	HOSE 1/2 X 450 TR-TC		01




Item	Code	Description	See page	QT
01	0501081327	HOSE 1/2 X 2700 TR-TR		01
02	0501080090	HOSE 1/2 X 1150 TR-TC 1G112161		02
03	0501080024	1/2" X 700 TR-TR HOSE		02
04	0501080040	HOSE 1/2 X 500 TR-TC		01
05	0501080037	HOSE 1/2 X 1500 TR-TR		01
06	0501080093	1/2 X 1300 HOSE TR-TC		01
07	0501080267	HOSE 1/2 X 2100 TR-TC		01
08	0501080825	1/2" X 1100 TR-TC HOSE		01
09	0501082267	HOSE 1/2 X 9100 TR-TM		02




Item	Code	Description	See page	QT
01	0501082268	HOSE 3/8 X 6200 TC-TM		01
02	0501080409	3/8" X 6000 TC-TM HOSE		01
02.	0501080128	3/8" X 71" TR-TR HOSE ASSY		01
02..	0501080714	HOSE 3/8 X 1600 TR-TC		01




Item	Code	Description	See page	QT
01	0501080524	3/8 X 1100 TC-TC HOSE ASSY		01
02	0501080105	TR-TR HOSE ASSY		10
03	0501080714	HOSE 3/8 X 1600 TR-TC		04
04	0501080396	3/8" X 45" HOSE		04
05	0501080065	3/8 X 1200 TC-TC HOSE ASSY		03
06	0501080469	3/8" X 98.42" TR-TR HOSE ASSY		02
07	0501081662	HOSE		04
08	0501080048	3/8" X 78" TR-TR HOSE ASSY		02
09	0501082265	HOSE 3/8 X 9100 TR-TM		02
10	0501080038	HOSE 1/2 X 4800 TR-TM		02
11	0501080931	3/8" X 39" TC-TC HOSE ASSY		04




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521057760	LED FLASHLIGHT WITH SUPPORT	131	02
02	0521053672	LIGHTHOUSE ASSY	132	08
03	0521059994	ELECTRICAL ASSEMBLY BCE (ASSEMBLY) APT 32/BF3500-L		01
03A	0503019596	LIGHT WHIP / LANTERN IMPLEMENT APT		01
03B	0503019593	WHIP BLOCK COMMAND IMPLEMENT		01




Item	Code	Description	See page	QT
01	0591013259	LED FLASHLIGHT SUPPORT		01
02	0503019579	LED LANTERN		01




Item	Code	Description	See page	QT
01	0581015856	REDLIGHT SUPPORT		01
02	0503018738	LIGHTHOUSE		01
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010358	5/16" X 5/8" BOLT		02
05	0551019884	45 X 50 X 3/8 FASTENER		02
06	0503013759	NUT		06




Item	Code	Description	See page	QT
01	0521059688	CENTRAL AIR CONDUCTOR 10 MOUTH	134	01
02	0521058488	CENTRAL AIR CONDUCTOR 1575	135	02
03	0521058409	CENTRAL AIR DUCT FIXER SUPPORT	136	04
04	0521058411	CENTRAL ASSY AIR CONDUCTOR SUPPORT	137	04
05	0503011372	102 TO 121 CLAMP		06
06	0521052549	CLAMP	138	10
07	0591014474	AIR CONDUCTOR PROTECTION		02




Item	Code	Description	See page	QT
01	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		10
01A	0503034812	SOCKET DISTRIBUTOR AR		01
01B	0503012856	REBITE POP		04
02	0511057036	AIR DISTRIBUTOR BOARD		02
02A	0503012567	T-JOIN FOR TUBE 110		01
02B	0581013890	SOCKET DISTRIBUTOR AR		01
03	0591015773	AIR CONDUCTOR BODY 3 MOUTH		01
04	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		02
04A	0503034763	AIR DITRIBUTOR PUMP		01
04B	0503015341	RIVET POP		02
05	0591015774	AIR CONDUCTOR BODY 3 MOUTH		01
06	0591015775	AIR CONDUCTOR BODY 4 MOUTH		01



Item	Code	Description	See page	QT
01	0591013854	AIR CONDUCTOR BODY		01
02	0581013633	SOCKET DISTRIBUTOR AR		02




Item	Code	Description	See page	QT
01	0571019755	FIXER LOWER REAR DRIVER AIR		01
02	0521018402	AIR CONDUCTOR CLAMP		01
03	0503010179	5/16" ZN SPRING WASHER		02
04	0503010337	5/16" NUT		02
05	0503010371	5/16" X 1" BOLT		02
06	0503010026	3/8" NUT		02
07	0503011404	BOLT		02
08	0503010025	3/8" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0591014476	AIR CONDUCTOR SUPPORT BODY		01
02	0521018402	AIR CONDUCTOR CLAMP		01
03	0503010371	5/16" X 1" BOLT		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02

CLAMP


0521052549




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01



Item	Code	Description	See page	QT
01	0591015769	GUTTER 30 X 55 X 1260		01
02	0591015770	GUTTER 30 X 55 X 3460		01
03	0591014466	GUTTER 24 X 46 X 1550		02
04	0521055102	BIGGEST FULL GUTTER SUPPORT	140	04




Item	Code	Description	See page	QT
01	0581019560	SOPORTE CONDUCTOR		01
02	0503010025	3/8" SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0503013029	3/8" X 3/4" BOLT		01
05	0501011643	3/8 X 1"BOLT		01




Item	Code	Description	See page	QT
01	0503063084	KIT INTELLIAG 60L		01
01A	0503019528	CONTROL MODULE		01
01B	0503015066	CABLE CONTROL MASTER MODULE		01
01C	0503019298	MODULATE BODY		03
01D	0503015210	CABLE MODULO WSMB ISOBUS 467981200		03
01E	0503019597	ISOBUS CONNECTION CABLE		01
01F	0503015071	CONCTOR		01
01G	0503015220	ENCODER ISOB 4,5M 464360171S1		03
01H	0503063083	MONITOR CABLE		01
01I	0503017443	ANTENNA GPS PM 400		01
01J	0503016369	THREE FEMALE CONNECTOR		03
01K	0503015908	FEMALE TERMINAL		09
01L	0503015911	CABLE SEAL		09
01M	0503017031	CLEANING BRUSH		01
01N	0503015218	SENSOR FOTOELE PM 400		60
02	0511056972	FILTER HYDAC	142	01
03	0521057179	PARKER OMR 125 ISOBUS HYDRAULIC ENGINE WITH VALVE	143	02
04	0511056973	PARKER OMP 80 HYDRAULIC MOTOR WITH VALVE	144	01
05	0503019017	WRENCH		01
06	0503019023	CABLE GLAND		01
07	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		900
08	0521068295	RATCHET DRIVING		01
09	0503010920	1/2" X 1.1/2" BOLT		04
10	0503010019	1/2" SPRING WASHER		04
11	0503010060	1/2" NUT		04
12	0503011828	FLAT WASHER		02

FILTER HYDAC


0511056972




Item	Code	Description	See page	QT
01	0503016376	FILTER SPRING		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8\"NF UNF NIPPLE		02
04	0503012341	T 7/8\" ADAPOR GIRAT NUT		01
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16\" ZN SPRING WASHER		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0503016083	MOTOR		01
02	0503010045	2-116 N 3006-9B O'RING		02
03	0503019320	VALVE		01
04	0501010590	7/8" REDUCTION NIPPLE		02




Item	Code	Description	See page	QT
01	0503016037	VALVE		01
02	0501010590	7/8" REDUCTION NIPPLE		02
03	0503010045	2-116 N 3006-9B O'RING		02
04	0503016055	MOTOR HYDRAULIC PARKER OMP 80 ISOBUS		01




Item	Code	Description	See page	QT
01	0521056998	ALUMINUM IDENTIFICATION LABEL WITH RIVET		01
01A	0503034003	SERIAL NUMBER TAG 61 X 118		01
01B	0503010001	3.2 X 5.5 RIVET		04
02	0503034114	ADHESIVE LABEL LOGO TATU BOX 190 X 530		08
03	0503034566	ADHESIVE LABEL		08
04	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 MOUTH)		08
05	0503034563	ADHESIVE LABEL		08
06	0503033853	ADHESIVE LABEL		02
07	0503031425	ADHESIVE LABEL ATTENTION		02
08	0503032988	ADHESIVE LABEL		01
09	0503033597	ADHESIVE		02
10	0503031087	ADHESIVE LABEL		01
11	0503032986	ADHESIVE LABEL		01
12	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM		02
13	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM		02
14	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER		04
15	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER		01
16	0503034471	ADHESIVE LABEL		01
17	0503034651	ADHESIVE LABEL		02
18	0503034683	ADHESIVE LABEL		02
19	0503034534	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0531061533	REAR AXLE CENTER		01
02	0591014042	REAR SIDE CANUDO BEARING		02
03	0591014460	BACKBOARD		02
04	0503019521	SCREW 3/4 UNF 3 CSRP G.8 ZN		12
05	0503010152	3/4" SELF LOCKING NUT		12
06	0503010237	3/8" X 1" BOLT		12
07	0503010025	3/8" SPRING WASHER		12
08	0503010002	1800 GREASE FITTING		04
09	0591015988	LOCK SMALLER		02
10	0503030119	LOCK PIN		02
11	0503030085	LOCK PIN		02
12	0531040592	HYDRAULIC CYLINDER 50.8 X 101.6 X 372 X 97	147	01
13	0591015777	FIXER AXLE CYLINDER		01
14	0591015778	FIXER AXLE CYLINDER		01
15	0591015766	SLEEVE		02
16	0502012935	BEARING		02




Item	Code	Description	See page	QT
01	0581010678	50,80 X 101 RING SUPPORT		01
02	0502012842	50,80 X 101,60 PISTON		01
03	0503010817	1.1/4" SELF LOCKING NUT		01
04	0503015633	SELEMASTER SEALING		01
05	0503018029	2-217 O'RING		01
06	0503010039	D-2000 SCRAPER RING		01
07	0503018026	1870-2000-375 B GASKET		01
08	0503018025	RING GUIDE		01
09	0503011061	8-342 BACK-UP RING		02
10	0503010338	2-342 N 3006-9B O'RING		02
11	0502012822	101.60 END CAP		01
12	0503030385	CYLINDER PLUG N-002		02
13	0503010002	1800 GREASE FITTING		02
14	0531061538	CASE 101,6 X 288		01
15	0531061537	EXTENSOR 50,80 X 303		01




Item	Code	Description	See page	QT
01	0521068930	SACADOR AXLE		01
02	0521068931	SLEEVE SACADOR		01

VACUOMETER WITH ASSY SUPPORT


0521050332




Item	Code	Description	See page	QT
01	0571019137	SWITCH FIXER		01
02	0503013584	VACUUM GAUGE		01
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0581014411	BREATHE		01




Item	Code	Description	See page	QT
01	0503019303	CONTROL PANEL		01
02	0503019594	TRACTOR BATTERY WHIP		01
03	0503019595	CABLE TRACTOR HEADLIGHT		01
04	0503019304	WIRES BLOCK COMMAND TRACTOR		01
05	0521051707	ASSY PANEL FIXER PLATE	151	01
06	0503016234	TRIMBLE FIXING WINDOW		01
07	0503016452	FIXING SUPPORT AG500 TRIMBLE		01



Item	Code	Description	See page	QT
01	0581015186	ELECTRIC PANEL FIXING PLATE		01
02	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
03	0503010669	FLAT WASHER		02
04	0503010667	3/16" NUT		02
05	0503010668	3/16" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0521059700	FRONT SEED LINE SHORT CBA/CM WITHOUT LUBRICATION	153	01
02	0521059701	FRONT SEED LINE LONG CBA/CM WITHOUT LUBRICATION	154	01
03	0521059702	FRONT SEED LINE SHORT CBA/CM WITHOUT LUBRICATION	155	01
04	0521059687	INTERNAL FRONT LONG SEED LINE CBA/CM WITHOUT LUBRICATION	156	01
05	0521055965	LEFT REAR QUICK CHANGE WITHOUT NOZZLE SEED	159	01
06	0521055964	RIGHT REAR QUICK CHANGE WITHOUT NOZZLE SEED	160	01
07	0521051434	ASSY P.P CSU 2 STEEL CABLE	167	01
08	0521050525	FIXER FERTILIZER CONDUCTOR	169	01
09	0521055346	20 BLADE DISC ASSY	170	01
10	0521055397	DEEP WHEEL / COMPACTOR SYSTEM	174	01
11	0503062667	SET TRANSMISSION		01
12	0503062668	SET TRANSMISSION		01
13	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
14	0521068982	KEY CASH DISC CUTTING		01
15	0531013600	PRESS ADJUSTMENT LEVER		01
16	0521052549	CLAMP	138	01




Item	Code	Description	See page	QT
01	0531061815	INTERNAL FRONT SUPPORT SHORT SEED LINE	01	
02	0581019793	LOWER UPPER ARM WITHOUT LUBRICATION	01	
03	0581018676	SLEEVE ARM LINE SEED	08	
04	0581019794	LOWER LOWER ARM WITHOUT LUBRICATION	01	
05	0521066168	FRAME SEED LINE	01	
06	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
07	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN	04	
08	0561014215	BEARING COVER LOWER ROW FRAME	01	
09	0503010179	5/16" ZN SPRING WASHER	02	
10	0503011952	5/16" X 3/4" BOLT	02	
11	0503010337	5/16" NUT	02	
12	0571012310	ROW LOCK BODY	01	
13	0551015826	SEED ROW LOCK GUIDE SLEEV	01	
14	0503010232	5/8" X 1.3/4" BOLT	01	
15	0503010027	5/8" SPRING WASHER	01	
16	0503010013	5/8" NUT	01	
17	0503030168	HAIR PIN	04	
18	0501012140	FLAT WASHER	01	
19	0503010019	1/2" SPRING WASHER	01	
20	0503010060	1/2" NUT	01	
21	0571012014	TRANSPORT LOCK	01	
22	0503010479	1/2" X 3" BOLT	01	
23	0503033728	FIXED SPRING PIN	02	
24	0571014704	UPPER AXLE	01	
25	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	01	
26	0521068188	HOSE GUIDE	01	
27	0503010025	3/8" SPRING WASHER	01	
28	0501011643	3/8 X 1" BOLT	01	
29	0503019273	SLEEVE	08	
30	0503010045	2-116 N 3006-9B O'RING	08	
31	0502012568	UPPER ROCKER ARM	01	

Item	Code	Description	See page	QT
32	0521068024	STELL GUIDE CABLO		01
33	0503011953	5/16" X 1" BOLT		01
34	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		01
35	0521051447	FRONT ASSY ROW BEARING	157	01
36	0503014876	NUT PARLOCK 1/4"		01
37	0503013759	NUT		01
38	0521059706	SEED HOSE SUPPORT	158	01
39	0531061542	SUPPORT SHAFT		01
40	0503010795	5/8" X 7" BOLT		04
41	0503013389	5/8" SELF LOCKING NUT		04
42	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0531061543	INTERNAL FRONT SUPPORT LONG SEED LINE	01	
02	0581019795	SEED ARM SUPPORT ROW	01	
03	0581018676	SLEEVE ARM LINE SEED	08	
04	0581019796	LOWER ARM LARGER	01	
05	0521066168	FRAME SEED LINE	01	
06	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
07	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN	04	
08	0561014215	BEARING COVER LOWER ROW FRAME	01	
09	0503010179	5/16" ZN SPRING WASHER	02	
10	0503011952	5/16" X 3/4" BOLT	02	
11	0503010337	5/16" NUT	02	
12	0571012310	ROW LOCK BODY	01	
13	0551015826	SEED ROW LOCK GUIDE SLEEV	01	
14	0503010232	5/8" X 1.3/4" BOLT	01	
15	0503010027	5/8" SPRING WASHER	01	
16	0503010013	5/8" NUT	01	
17	0503030168	HAIR PIN	04	
18	0501012140	FLAT WASHER	01	
19	0503010019	1/2" SPRING WASHER	01	
20	0503010060	1/2" NUT	01	
21	0571012014	TRANSPORT LOCK	01	
22	0503010479	1/2" X 3" BOLT	01	
23	0503033728	FIXED SPRING PIN	02	
24	0571014704	UPPER AXLE	01	
25	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	01	
26	0521068188	HOSE GUIDE	01	
27	0503010025	3/8" SPRING WASHER	01	
28	0501011643	3/8 X 1" BOLT	01	
29	0503019273	SLEEVE	08	
30	0503010045	2-116 N 3006-9B O'RING	08	
31	0502012568	UPPER ROCKER ARM	01	

Item	Code	Description	See page	QT
32	0521068024	STELL GUIDE CABLO		01
33	0503011953	5/16" X 1" BOLT		01
34	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		01
35	0521051447	FRONT ASSY ROW BEARING	157	01
36	0503014876	NUT PARLOCK 1/4"		01
37	0503013759	NUT		01
38	0521059706	SEED HOSE SUPPORT	158	01
39	1902010024	LINE SUPPORT CLAMP		02
40	0503012410	5/8" X 7.1/2" BOLT		04
41	0503013389	5/8" SELF LOCKING NUT		04
42	0503010026	3/8" NUT		01



Item	Code	Description	See page	QT
01	0531061815	INTERNAL FRONT SUPPORT SHORT SEED LINE	01	
02	0581019793	LOWER UPPER ARM WITHOUT LUBRICATION	01	
03	0581018676	SLEEVE ARM LINE SEED	08	
04	0581019794	LOWER LOWER ARM WITHOUT LUBRICATION	01	
05	0521066168	FRAME SEED LINE	01	
06	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
07	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN	04	
08	0561014215	BEARING COVER LOWER ROW FRAME	01	
09	0503010179	5/16" ZN SPRING WASHER	02	
10	0503011952	5/16" X 3/4" BOLT	02	
11	0503010337	5/16" NUT	02	
12	0571012310	ROW LOCK BODY	01	
13	0551015826	SEED ROW LOCK GUIDE SLEEV	01	
14	0503010232	5/8" X 1.3/4" BOLT	01	
15	0503010027	5/8" SPRING WASHER	01	
16	0503010013	5/8" NUT	01	
17	0503030168	HAIR PIN	04	
18	0501012140	FLAT WASHER	01	
19	0503010019	1/2" SPRING WASHER	01	
20	0503010060	1/2" NUT	01	
21	0571012014	TRANSPORT LOCK	01	
22	0503010479	1/2" X 3" BOLT	01	
23	0503033728	FIXED SPRING PIN	02	
24	0571014704	UPPER AXLE	01	
25	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	01	
26	0521068188	HOSE GUIDE	01	
27	0503010025	3/8" SPRING WASHER	01	
28	0501011643	3/8 X 1" BOLT	01	
29	0503019273	SLEEVE	08	
30	0503010045	2-116 N 3006-9B O'RING	08	
31	0502012568	UPPER ROCKER ARM	01	

Item	Code	Description	See page	QT
32	0521068024	STELL GUIDE CABLO		01
33	0503011953	5/16" X 1" BOLT		01
34	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		01
35	0521051447	FRONT ASSY ROW BEARING	157	01
36	0503014876	NUT PARLOCK 1/4"		01
37	0503013759	NUT		01
38	0521059706	SEED HOSE SUPPORT	158	01
39	1902010024	LINE SUPPORT CLAMP		02
40	0503012410	5/8" X 7.1/2" BOLT		04
41	0503013389	5/8" SELF LOCKING NUT		04
42	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0531061543	INTERNAL FRONT SUPPORT LONG SEED LINE	01	
02	0581019795	SEED ARM SUPPORT ROW	01	
03	0581018676	SLEEVE ARM LINE SEED	08	
04	0581019796	LOWER ARM LARGER	01	
05	0521066168	FRAME SEED LINE	01	
06	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
07	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN	04	
08	0561014215	BEARING COVER LOWER ROW FRAME	01	
09	0503010179	5/16" ZN SPRING WASHER	02	
10	0503011952	5/16" X 3/4" BOLT	02	
11	0503010337	5/16" NUT	02	
12	0571012310	ROW LOCK BODY	01	
13	0551015826	SEED ROW LOCK GUIDE SLEEV	01	
14	0503010232	5/8" X 1.3/4" BOLT	01	
15	0503010027	5/8" SPRING WASHER	01	
16	0503010013	5/8" NUT	01	
17	0503030168	HAIR PIN	04	
18	0501012140	FLAT WASHER	01	
19	0503010019	1/2" SPRING WASHER	01	
20	0503010060	1/2" NUT	01	
21	0571012014	TRANSPORT LOCK	01	
22	0503010479	1/2" X 3" BOLT	01	
23	0503033728	FIXED SPRING PIN	02	
24	0571014704	UPPER AXLE	01	
25	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	01	
26	0521068188	HOSE GUIDE	01	
27	0503010025	3/8" SPRING WASHER	01	
28	0501011643	3/8 X 1" BOLT	01	
29	0503019273	SLEEVE	08	
30	0503010045	2-116 N 3006-9B O'RING	08	
31	0502012568	UPPER ROCKER ARM	01	

Item	Code	Description	See page	QT
32	0521068024	STELL GUIDE CABLO		01
33	0503011953	5/16" X 1" BOLT		01
34	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		01
35	0521051447	FRONT ASSY ROW BEARING	157	01
36	0503014876	NUT PARLOCK 1/4"		01
37	0503013759	NUT		01
38	0521059706	SEED HOSE SUPPORT	158	01
39	0531061542	SUPPORT SHAFT		01
40	0503010795	5/8" X 7" BOLT		04
41	0503013389	5/8" SELF LOCKING NUT		04
42	0503010026	3/8" NUT		01

FRONT ASSY ROW BEARING


0521051447




Item	Code	Description	See page	QT
01	0581014691	BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0503010179	5/16" ZN SPRING WASHER		02
04	0503010337	5/16" NUT		02
05	0503012861	6006 2RS BALL BEARING		01
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0581015056	SLEEVE		01
08	0551015804	BEARING AXLE BODY		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01

SEED HOSE SUPPORT


0521059706




Item	Code	Description	See page	QT
01	0531061544	SUPPORT HOSE SEED		01
02	0503010026	3/8" NUT		02
03	0503010025	3/8" SPRING WASHER		02
04	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		03
02	0503010019	1/2" SPRING WASHER		03
03	0503010060	1/2" NUT		03
04	0521055873	LEFT DOUBLE DISK FAST EXCHANGE SEED 15X15 161		01
05	0521065999	FRONT SHIELD		01




Item	Code	Description	See page	QT
01	0521055872	RIGHT DOUBLE DISK FAST EXCHANGE SEED 162 15X15	162	01
02	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		03
03	0503010019	1/2" SPRING WASHER		03
04	0503010060	1/2" NUT		03
05	0521065999	FRONT SHIELD		01




Item	Code	Description	See page	QT
01	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
02	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
03	0502012781	SUPPORT DDD LEFT		01
04	0503011402	0.2" X 0.8" SPRING PIN		01
05	0503013129	ELASTIC PIN		01
06	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
07	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 163 FERTILIZER / SEED		01
08	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 164 FERTILIZER / SEED		01
09	0501010984	FLAT WASHER		02
10	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
11	0503010025	3/8" SPRING WASHER		01
12	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
02	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
03	0502012780	SUPPORT DDD RIGHT		01
04	0503011402	0.2" X 0.8" SPRING PIN		01
05	0503013129	ELASTIC PIN		01
06	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
07	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 163 FERTILIZER / SEED		01
08	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 164 FERTILIZER / SEED		01
09	0501010984	FLAT WASHER		02
10	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
11	0503010025	3/8" SPRING WASHER		01
12	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	165	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	166	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	LOW CUBE FERTILIZER / SEED BOX		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	5/16" ZN SPRING WASHER		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01



Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUB DISC - HUB		01
02	0502012896	LOW CUBE FERTILIZER / SEED BOX		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	5/16" ZN SPRING WASHER		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
001	0571017897	AXLE ARTICULATION PRECISION PLANTING	01	
002	0571017895	PIN FIXER CONDUCTOR P.P	01	
003	0503010293	BAQUELITE MANIPULACION	01	
004	0503010140	1/8" X 3/4" COTTERPIN	02	
005	0503010131	3/16" X 1-1/2" COTTERPIN	01	
006	0503010025	3/8" SPRING WASHER	06	
007	0571019491	SLUICE PNEUMATIC PRECISION PLANTING	01	
008	0501011643	3/8 X 1"BOLT	01	
009	0503010209	3/8" UNC BUTTERFLY NUT	01	
010	0502012807	SUPPORT BOX PRECISION PLANTING	01	
011	0571019489	CLAMP PRECISION PLANTING	01	
012	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING	01	
013	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN 168 DISC	01	
014	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN	02	
015	0503015110	M06 SPRING WASHER	02	
016	0503012721	1/4" X 4" BOLT	01	
017	0503012880	1/4" UNC SELF ADJUSTING NUT	01	
018	0503818139	BOLT	03	
019	0571014024	FAST BOLT GUIDE AXLE	01	
020	0503037390	PACKING FOR PLANTING	01	
021	0503011953	5/16" X 1" BOLT	03	
022	0503010337	5/16" NUT	04	
023	0503010179	5/16" ZN SPRING WASHER	04	
024	0503012163	5/16" X 1-1/2" BOLT	01	
025	0581011226	FIXER CLOSING P PLANTING CONTR CPRA	01	
026	0581011225	FIXER P PLANTING CONTR CPRA	01	
027	0521068012	FIXER LEVER LOWER	01	
028	0503015920	3/8" UNC X 1.3/4" BOLT	04	
029	0503010026	3/8" NUT	04	




Item	Code	Description	See page	QT
01	0503062405	SEED DISTRIBUTOR	01	
01A	0503062567	FIXED BASE SEEDS DISTRIBUTOR	01	
01AA	0503018908	BODY FIXED BASE DISTRIBUTOR SEED	01	
01AB	0503018909	COVER CONDUCTOR DISTRIBUTOR SEED	01	
01AC	0503062652	SEED INPUT DEFLECTOR	01	
01AD	0503062653	FULL COVER	01	
01AE	0503018910	RIVETS LARGEST	01	
01AF	0503018911	SPACING BUSHING	01	
01AG	0503018912	BOLT	03	
01AH	0503018476	SPRING	01	
01AI	0503018474	LOWER BRUSH	01	
01AJ	0503018475	TOP BRUSH	01	
01AK	0503018157	RUBBER	01	
01AL	0503018477	LOCK SPRING	01	
01B	0503062568	FIXER MOBILE	01	
01BA	0503018919	BASE	01	
01BB	0503018913	RIVET	01	
01BC	0503018914	WASHER	01	
01BD	0503018915	BEARING	02	
01BE	0503062654	BEARING	01	
01BF	0503018916	ADJUSTMENT CHOCK	03	
01BG	0503018917	RING	01	
01BH	0503018918	CHOCK	02	
01BI	0503019288	RUBBER SEAL PP 730518	01	
01BJ	0503018478	SPRING	01	
01BK	0503018920	SEALING	01	
01BL	0503018479	TUBE	01	
01BM	0503018735	PROTECTIVE COVER	01	
01BN	0503018921	BOLT	06	
01BO	0503018922	BOLT	02	
01BP	0503018480	REGULATOR PIN	01	

Item	Code	Description	See page	QT
01BQ	0503018923	ADAPTER		01
01BR	0503018924	SPRING PIN		01
02	0503062417	KIT CORN DISTRIBUTION		01
02A	0503018160	CORN PLASTIC DISC		01
02B	0503062472	SELECTOR SEED CORN		01
02C	0503062474	EJECTOR CORN SEED SET		01
03	0571019613	STRAW PRECISION PLANTING SHIELD		01
03A	0503017957	PROTECTIVE COVER AIR INPUT		01




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010365	NUT		02




Item	Code	Description	See page	QT
01	0502012470	UPPER SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
03	0503012798	5/8" X 2" BOLT		04
04	0503010878	5/8" SELF ALIGNING NUT		04
05	0521055344	LOWER SUPPORT	171	01

LOWER SUPPORT

0521055344




Item	Code	Description	See page	QT
01	0503019277	SLEEVE LUBRICATION SYSTEM		03
02	0503019278	LUBRICANT GLOVE		02
03	0581018679	SLEEVE		01
04	0581018677	SUPPORT DISC AXLE		01
05	0503010361	SPRING PIN		01
06	0551015883	SPRING GUIDES SLEVE		02
07	0503031575	2.5"X 12" X 0.5" COMPRESSION SPRING		02
08	0521068189	SPRING REGULACION		02
09	0501012140	FLAT WASHER		02
10	0503010152	3/4" SELF LOCKING NUT		01
11	0503010806	5/8" X 3" BOLT		02
12	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT		01
13	0503011075	3/4" UNC NUT		02
14	0503010878	5/8" SELF ALIGNING NUT		02
15	0521054844	DPLO 20 CUTTING DISK BOX	172	01
16	0521069351	RIGHT ARM		01
17	0521069350	LEFT ARM		01
18	0503010410	RING		02
19	0502012898	BOTTOM BRACKET		01
20	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		02
21	0503010179	5/16" ZN SPRING WASHER		02
22	0571012370	PROTECTION FRONT		01
23	0581018678	FLANGE WASHER		01




Item	Code	Description	See page	QT
01	0521053697	CUTTING DISK BOX	173	01
02	0607026025	DPLO20X4,5		01

CUTTING DISK BOX

0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4	01	
02	0502040872	REGULATORY NUT	01	
03	0503010370	502072 CLAMPING RING (FOR AXLE)	02	
04	0503010590	00674-B SEAL	02	
05	0503019285	RING	02	
06	0503012170	30207 ROLLER BEARING	02	
07	0502020641	BLADE DISC FLANGE	01	
08	0502012862	CUTTING DISK BOX	01	
09	0502040873	CUTTING DISC AXLE	01	
10	0503017755	NUT	01	
11	0503018825	5/16 UNC UNC BOLT	06	
12	0501010694	8.5 X 18 X 1.5 FLAT WASHER	06	
13	0503013816	5/16" LOCKNUT	06	
14	0511017907	1/8" BSPT X 6 PLUG	02	



Item	Code	Description	See page	QT
01	0521055398	DEPTH WHEEL	175	01
02	0521055093	BODY COMPACTOR	183	01
03	0521055017	RIGHT COMPACTOR WHEEL	184	01
04	0521054990	LEFT COMPACTOR WHEEL	185	01

DEPTH WHEEL


0521055398



Item	Code	Description	See page	QT
01	0581019532	DEPTH CONTROL SUPPORT		01
02	0581019531	ARTICULATED AXLE WHEEL DEPTH		02
03	0501059228	ADJUSTMENT LEVER	176	01
04	0502012611	DEPTH CONTROL AXLE		01
05	0571015326	ARTICULATION SLEEVE HANDLE		01
06	0581017075	LARGER AXLE		01
07	0581017076	SMALLER AXLE		01
08	0501011445	FLAT WASHER		04
09	0511017302	FLAT WASHER		02
10	0503011336	1/2" HEX SELF ADJUSTING NUT		02
11	0503030012	HAIR PIN		04
12	0503011402	0.2" X 0.8" SPRING PIN		02
13	0503012795	5/8" HEX SELF ADJUSTING NUT		02
14	0503010237	3/8" X 1" BOLT		01
15	0503010025	3/8" SPRING WASHER		01
16	0501010984	FLAT WASHER		01
17	0581019526	ARTICULATED AXLE LEVER DEPTH		01
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0503010302	501019 SEAL RING		01
20	0581019473	ARTICULATED GLOVE		02
21	0503010045	2-116 N 3006-9B O'RING		02
22	0521055399	LEFT ARM WITH WHEEL	177	01
23	0521055400	RIGHT ARM WITH WHEEL	178	01

ADJUSTMENT LEVER


0501059228




Item	Code	Description	See page	QT
01	0502012603	ADJUSTMENT LEVER		01
02	0502011689	1/8" DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0511015976	FLAT WASHER		01
05	0503010140	1/8" X 3/4" COTTERPIN		01

LEFT ARM WITH WHEEL

0521055399




Item	Code	Description	See page	QT
01	0521055058	LEFT ARM	179	01
02	0521055401	ASSY WHEEL	181	01
03	0581018815	SET DEVIATION		01
04	0503010741	1/2" X 2-3/4" BOLT		01
05	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0521055074	RIGHT ARM WITH O-RING	180	01
02	0521055401	ASSY WHEEL	181	01
03	0581018815	SET DEVIATION		01
04	0503010741	1/2" X 2-3/4" BOLT		01
05	0503010589	1/2" UNC SELF ADJUSTING NUT		01

LEFT ARM

0521055058




Item	Code	Description	See page	QT
001	0581019525	LEFT ARM WHEEL DEPTH		01
002	0503011109	2-119 N 3006-9B O'RING		02
003	0581019514	LUBRICANT GLOVE		02




Item	Code	Description	See page	QT
01	0581019530	RIGHT ARM ROD DEPTH SPA NO LUBRICATION		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT GLOVE		02

ASSY WHEEL

0521055401




Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503030891	RUBBER BAND		01
03	0503010365	NUT		06
04	0503010179	5/16" ZN SPRING WASHER		06
05	0503010337	5/16" NUT		06
06	0521055073	ASSEMBLY DEPTH WHEEL BOX	182	01
07	0561016889	STRIPED CAP WHEEL DEPTH		01




Item	Code	Description	See page	QT
01	0581019528	BOX WHEEL DEPTH SPA WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
11	0581019529	DEPTH REGULATOR SHAFT		01

BODY COMPACTOR

0521055093




Item	Code	Description	See page	QT
01	0501011753	5/16" X 1-3/4" BOLT	02	
02	0503013816	5/16" LOCKNUT	04	
03	0581015855	SLEEVE	02	
04	0502012877	PRESS WHEEL ADJUSTMENT LEVER	01	
05	0521068661	LEVER	01	
06	0503030878	LEVER CRANK	01	
07	0503031393	1.57" X 5.98" X 0.2" TRACTION SPRING	01	
08	0581019520	AXIS	01	
09	0571812442	COUPLING SHAFT	01	
10	0503010257	1/8" X 1" COTTERPIN	01	
11	0581019511	COVER	01	
12	0503010848	5/16" X 3.1/2" BOLT	02	
13	0503010752	1/2" X 3.1/2" BOLT	01	
14	0503011336	1/2" HEX SELF ADJUSTING NUT	01	
15	0503030190	0.5" X 1.6" X 0.05" SPRING	01	
16	0581019510	AXIS	01	
17	0581019512	PLATE TOP	01	
18	0503019351	LUBRICANT GLOVE	02	
19	0521069591	LEFT SIDE	01	
20	0581019548	RIGHT SIDE BODY	01	




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	186	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05

LEFT COMPACTOR WHEEL


0521054990




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	186	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
001	0521058329	SEED CONDUCTOR	101	04
002	0503062961	FERTILIZER BEAM ASSY		01
003	0531061522			01
004	0521051407	FIXER SILO FERTILIZER	102	06




Item	Code	Description	See page	QT
001	0521058329	SEED CONDUCTOR	101	05
002	0531061521	LEFT SUPPORT 2033 X 1590		01
003	0503062962	SILO SEED 05 ASSY MOUTH		01
004	0521051407	FIXER SILO FERTILIZER	102	08




Item	Code	Description	See page	QT
001	0521059670	CENTRAL HANDRAIL 2554 X 1652	190	01
002	0521059671	CENTRAL HANDRAIL 2166 X 1582	191	01
003	0521059654	INTERNAL SIDE HANDRAIL 643 X 875	68	01




Item	Code	Description	See page	QT
001	0591015720	TUBE 33,70 X 27 X 1570		03
002	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	106	08
003	0521067991	SIDE HANDRAIL		02
004	0581012718	HANDRAIL		04
005	0581014825	TUBE 33,70 X 27 X 924		02
006	0511059383	INTERNAL FIXER ASSY HANDLE	105	10
007	0581015992	TUBE 33,70 X 27 X 354		04
008	0591015723	TUBE 33,70 X 27 X 528		03
009	0591015721	TUBE 33,70 X 27 X 210		03



Item	Code	Description	See page	QT
001	0591015738	TUBE 33,70 X 27 X 1500		03
002	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	106	08
003	0521067991	SIDE HANDRAIL		02
004	0581012718	HANDRAIL		04
005	0581014825	TUBE 33,70 X 27 X 924		02
006	0511059383	INTERNAL FIXER ASSY HANDLE	105	10
007	0581015992	TUBE 33,70 X 27 X 354		04
008	0591015721	TUBE 33,70 X 27 X 210		06




Item	Code	Description	See page	QT
001	0521059669	LEFT SIDE AIR CONDUCTOR 973 MOUTH	193	01
002	0521058409	CENTRAL AIR DUCT FIXER SUPPORT	136	01
003	0511050198	CENTRAL AIR DUTY FIXING SUPPORT	50	02
004	0521052549	CLAMP	138	18




Item	Code	Description	See page	QT
001	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		09
001A	0503034812	SOCKET DISTRIBUTOR AR		01
001B	0503012856	REBITE POP		04
002	0511057036	AIR DISTRIBUTOR BOARD		02
002A	0503012567	T-JOIN FOR TUBE 110		01
002B	0581013890	SOCKET DISTRIBUTOR AR		01
003	0591015717	CONDUCTOR BODY AIR 2 MOUTHS 650 4 HOLES		01
004	0591015716	CONDUCTOR BODY AIR 4 MOUTH 1952 4 HOLES		01
005	0591015715	CONDUCTOR BODY AIR 3 MOUTH 1480 4 HOLES		01
006	0521050393	ASSY KNEE		01
006A	0503017845	PVC KNEE 90 SOLD AVEL		01
006B	0581013890	SOCKET DISTRIBUTOR AR		01
007	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
007A	0503034763	AIR DISTRIBUTOR PUMP		01
007B	0503015341	RIVET POP		02

LEFT SIDE DUCT ASSEMBLY


0521059906







Item	Code	Description	See page	QT
001	0511059943	SUPPORT FASTENER ASSY	52	06
002	0581018415	PROTECTION BODY		06
003	0581018408	SUPPORT SCALE		06
004	0581018407	BODY FASTENER 2 DUCTS		02
005	0503011268	3/8" X 2-1/2" BOLT		03
006	0503010481	BOLT		03
007	0503011123	BOLT		04
008	0503010025	3/8" SPRING WASHER		13
009	0503010026	3/8" NUT		13
010	0531061511	OIL DUCT 3 OUTPUTS R.3 / 4 X 2883		01
011	0531061510	OIL DUCT 3 OUTPUTS R.7 / 8 X 2882		02
012	0531061508	OIL DUCT 3 OUTPUTS R.3 / 4 X 1939		02
013	0531061507	OIL DUCT R.7 / 8 X 2063		02
014	0531061520	OIL DUCT 3 OUTPUTS R.7 / 8 X 1940		02
015	0531061387	OIL DUCT R.3 / 4 X 2654		02
016	0531061506	OIL DUCT R.7 / 8 X 2980		01
017	0501082189	HOSE 1/2 X 160 TR-TR		02



Item	Code	Description	See page	QT
001	0591014455	MOBILE FIXER ECU BOX		01
002	0503010027	5/8" SPRING WASHER		04
003	0503010013	5/8" NUT		04
004	0501012140	FLAT WASHER		04
005	0571011070	5/8" UNC FASTENER		02
006	0521056857	ECU APT / TVT BOX WITH EXCHANGE	196	01




Item	Code	Description	See page	QT
01	0503010257	1/8" X 1" COTTERPIN	02	
02	0503010026	3/8" NUT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010144	1/4" NUT	08	
05	0503010143	1/4" SPRING WASHER	08	
06	0503010237	3/8" X 1" BOLT	04	
07	0521068017	BOX BODY APT/TVT	01	
08	0571017090	ROD BOX	01	
09	0521068016	BOX COVER	01	
10	0503018171	FAST LOCK ASSY	02	
11	0503010461	1/4" X 1" BOLT	04	
12	0503010282	1/4" X 3/4" BOLT	04	




Item	Code	Description	See page	QT
001	0521059709	WHEEL BLOCK SUPPORT	36	01
002	0521058407	ASSY APT/CBA ENGINE SUPPORT	117	01
003	0511056972	FILTER HYDAC	142	01
004	0521058426	ASSY FILTER SUPPORT	198	01
005	0503019799	FLOW DIVIDER VALVE		01

ASSY FILTER SUPPORT


0521058426




Item	Code	Description	See page	QT
01	0571016995	FIXER SUPPORT		01
02	0511017302	FLAT WASHER		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0571018437	PRISONER 1/2 X		02
06	0571014216	FRONT HOSE SUPPORT FIXER		01




Item	Code	Description	See page	QT
001	0521058329	SEED CONDUCTOR	101	04
002	0503062961	FERTILIZER BEAM ASSY		01
003	0531061512	LEFT SUPPORT 1633 X 1142		01
004	0521051407	FIXER SILO FERTILIZER	102	06



Item	Code	Description	See page	QT
001	0521059657	CENTRAL HANDRAIL 2731 X 2037	201	01
002	0521059656	CENTRAL HANDRAIL 2391 X 1453	202	01
003	0521059654	INTERNAL SIDE HANDRAIL 643 X 875	68	01




Item	Code	Description	See page	QT
001	0591015990	TUBE 33,70 X 27 X 1955		03
002	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	106	08
003	0521067991	SIDE HANDRAIL		02
004	0581012718	HANDRAIL		04
005	0581014825	TUBE 33,70 X 27 X 924		02
006	0511059383	INTERNAL FIXER ASSY HANDLE	105	10
007	0581015992	TUBE 33,70 X 27 X 354		04
008	0591015721	TUBE 33,70 X 27 X 210		03
009	0591015989	TUBE 33,70 X 27 X 320		03



Item	Code	Description	See page	QT
001	0591015761	TUBE 33,70 X 27 X 1125		03
002	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	106	08
003	0521067991	SIDE HANDRAIL		02
004	0581012718	HANDRAIL		04
005	0581014825	TUBE 33,70 X 27 X 924		02
006	0511059383	INTERNAL FIXER ASSY HANDLE	105	10
007	0581015992	TUBE 33,70 X 27 X 354		04
008	0591015721	TUBE 33,70 X 27 X 210		03
009	0581018303	TUBE		03

LEFT INTERMEDIATE AIR DUCT ASSY


0521059923




Item	Code	Description	See page	QT
001	0521059768	LEFT SIDE AIR DUCT		01
002	0521058409	CENTRAL AIR DUCT FIXER SUPPORT	136	02
003	0511050198	CENTRAL AIR DUTY FIXING SUPPORT	50	01
004	0521052549	CLAMP	138	09

LEFT INTERMEDIATE DUCT ASSY


0521059925



Item	Code	Description	See page	QT
001	0511059943	SUPPORT FASTENER ASSY	52	05
002	0521059681	SUPPORT DUCT OIL 5 DUCTS	75	02
003	0581018415	PROTECTION BODY		04
004	0581018407	BODY FASTENER 2 DUCTS		04
005	0503012456	3/8" X 7/8" BOLT		04
006	0503011268	3/8" X 2-1/2" BOLT		04
007	0503010481	BOLT		01
008	0503011123	BOLT		01
009	0501010984	FLAT WASHER		04
010	0503010025	3/8" SPRING WASHER		10
011	0503010026	3/8" NUT		10
012	0531061514	OIL DUCT 3 EXIT R.3/4 X 2202		02
013	0531061513	OIL DUCT 3 EXIT R.7/8 X 2202		02
014	0531061388	OIL DUCT R.3/4 X 2100		01
015	0521069289	OIL DUCT R.7/8 X 2100		02
016	0531061549	OIL DUCT R.3/4 X 2063		02
017	0531061507	OIL DUCT R.7 / 8 X 2063		02
018	0501082189	HOSE 1/2 X 160 TR-TR		04




Item	Code	Description	See page	QT
001	0531061504	LEFT / INTERMEDIATE REAR AXLE		01
002	0591014042	REAR SIDE CANUDO BEARING		02
003	0591014508	BACKREST LOCK		02
004	0503019521	SCREW 3/4 UNF 3 CSRP G.8 ZN		12
005	0503010152	3/4" SELF LOCKING NUT		12
006	0503010237	3/8" X 1" BOLT		08
007	0503010025	3/8" SPRING WASHER		08
008	0503010002	1800 GREASE FITTING		04
009	0591015827	LOWER LINE AXLE LOCK		02
010	0503030085	LOCK PIN		04
011	0521059895	HYDRAULIC CYLINDER 50.8 X 101.6 X 802 X 570	56	01
012	0591015828	CYLINDER FIXING AXIS		02
013	0503012231	1/4" X 3" COTTERPIN		04
014	0591013969	LOCK CYLINDER ARTICULATION		01
015	0541016844	FIXER LOCK		01
016	0503030012	HAIR PIN		01
017	0521058132	AXLE EXTENSOR ARTICULATION	57	01
018	0521059708	LOCK EAR	58	01
019	0502012935	BEARING		02




Item	Code	Description	See page	QT
001	0521059660	7-MOUTH LEFT SIDE AIR CONDUCTOR		01
002	0511050198	CENTRAL AIR DUTY FIXING SUPPORT	50	01
003	0521058409	CENTRAL AIR DUCT FIXER SUPPORT	136	02
004	0521052549	CLAMP	138	07

SIDE DUCT ASSEMBLY


0521059900



Item	Code	Description	See page	QT
001	0511059943	SUPPORT FASTENER ASSY	52	04
002	0581018409	FASTENER BODY		03
003	0521058421	OIL CONDUCTIVE SUPPORT 02 ASSY	208	01
004	0581018407	BODY FASTENER 2 DUCTS		01
005	0521059711	OIL CONDUCTOR SUPPORT	53	01
006	0503011268	3/8" X 2-1/2" BOLT		05
007	0503012456	3/8" X 7/8" BOLT		03
008	0503011123	BOLT		04
009	0503010025	3/8" SPRING WASHER		07
010	0501010984	FLAT WASHER		03
011	0503010026	3/8" NUT		07
012	0531061549	OIL DUCT R.3/4 X 2063		02
013	0531061518	OIL DUCT R.7/8 X 2743		02
014	0501082189	HOSE 1/2 X 160 TR-TR		02



Item	Code	Description	See page	QT
001	0511017302	FLAT WASHER		04
002	0503010019	1/2" SPRING WASHER		04
003	0503010060	1/2" NUT		04
004	0571018437	PRISONER 1/2 X		02
005	0581018240	AIR CONDUCTOR SUPPORT BODY		01
006	0531061100	SIDE SUPPORT FIXING 2 DUCT		01



Item	Code	Description	See page	QT
001	0531061603	LEFT SIDE REAR AXLE		01
002	0591014042	REAR SIDE CANUDO BEARING		02
003	0591014508	BACKREST LOCK		02
004	0591014460	BACKBOARD		02
005	0503019521	SCREW 3/4 UNF 3 CSRP G.8 ZN		12
006	0503010152	3/4" SELF LOCKING NUT		12
007	0503010237	3/8" X 1" BOLT		08
008	0503010025	3/8" SPRING WASHER		08
009	0503010002	1800 GREASE FITTING		04
010	0591015827	LOWER LINE AXLE LOCK		02
011	0503030085	LOCK PIN		04
012	0521059895	HYDRAULIC CYLINDER 50.8 X 101.6 X 802 X 570	56	01
013	0591015828	CYLINDER FIXING AXIS		02
014	0503012231	1/4" X 3" COTTERPIN		04
015	0591013969	LOCK CYLINDER ARTICULATION		01
016	0541016844	FIXER LOCK		01
017	0503030012	HAIR PIN		01
018	0521058132	AXLE EXTENSOR ARTICULATION	57	01
019	0521059708	LOCK EAR	58	01
020	0502012935	BEARING		02



www.marchesan.com.br



Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI