

ROW CROP PLANTERS

PST PLUS FLEX SUPREMA P.P - FRAME 4845 - DOUBLE DRAWBAR

Code: 0501092866
Series: S-0116
Revision: 00
Date Revision: AGOSTO/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0531040570	CABEÇALHO DUPLO COMPLETO
0111390044	PST PLUS FLEX SUPREMA P.P 4845/10E500 DIREITO ESPECIAL S-0116
0111390043	PST PLUS FLEX SUPREMA P.P 4845/10E500 ESQUERDO ESPECIAL S-0116
0111390061	PST PLUS FLEX SUPREMA P.P 4845/8E600 DIREITO ESPECIAL S-0116
0111390060	PST PLUS FLEX SUPREMA P.P 4845/8E600 ESQUERDA ESPECIAL S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.



MARCHESAN

INDEX


0909095500	ASSY FRAME	1
0531040570	DOUBLE DRAWBAR ASSY	2
0909095501	PST PLUS FLEX SUPREME P.P - FRAME 4845 - RIGHT	3
0909095502	PST PLUS FLEX SUPREME P.P - FRAME 4845 - LEFT	4
0909095504	ASSY SEED/FERTILIZER ROW	5
0511056307	DOUBLE DRAWBAR ASSY	6
0909093876	FIXER SUPPORT BOLT HOSE	7
0521051583	HOSE SET HEADBOARD	8
0501054061	SEQUENCE VALVE WITH NIPPLES	9
0501054862	AXIS LOCK RODE ASSY	10
0501054694	FLOW DIVIDING VALVE ASSY	11
0503062157	HEADER JACK	12
0511052464	FLOW DIVIDING VALVE	13
0501054863	WELL AND TIRE ASSY	14
0503060414	WHEEL AND TIRE	15
0501051799	STUB SHAFT & HUB ASSY	16
0521026516	BOX WITH COMPONENTS	17
0501050633	MARKER DISC ASSY LINE	18
0511053904	DISC LINE MARKER	19
0511058431	HYDRAULIC CYLINDER	20
0501040364	HOSE SUPPORT 3/4X640 ASSY	21
0511053179	TRACTOR HITCH AXLE	22
0511056409	TRACTOR HITCH	23
0511057336	WHEEL AXLE FRAME - 4845	24
0511058656	4845/5345/5745 - CYLINDER ASSY	25
0511058608	HYDRAULIC CYLINDER	26
0511058653	ASSY TRACTION SPRING WHEEL	27
0511058654	WHEEL SUPPORT ASSY	28
0501058240	WHELL FASTENER WITH STRETCHER	29
0521050994	TRANSMISSION ASSY	30
0501058241	TENSIONER CHAIN SUPPORT	31
0501052560	AXLE MOTOR SLOW-MOVING ASSY	32
0511051434	TRANSMISSION DRIVING ASSY	33
0511047069	SIDE TRANSMISSION DRIVING	34
0511047070	LH SIDE TRANSMISSION DRIVING	35
0501053788	Q3/4" FASTENER AXLE ASSY	36
0501056271	BEARING CLOSED	37
0511057265	TIGHTENER TRANSMISSION	38
0501052810	TRANSMISSION CHAIN TENSIONER ASSY	39
0511050652	CHAIN TENSIONER	40
0501053653	BEARING WITH 20Z GEAR	41
0521055337	ASSY RECAMBIO LEFT	42
0511058381	RIGHT RECAMBIO	43
0511058382	LEFT RECAMBIO	44
0501048790	AXLE WITH LINK ASSY	45
0501056443	BEARING ASSY GEAR BOX	46
0511057258	GEAR WITH ADJUSTER	47
0511054363	CHAIN TENSIONER	48
0511057326	SET BEAM FERTILIZER - 4845	49
0511057327	4845 - SUPPORT HOPPER WITH DISTRIBUTOR	50
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	51
0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	52
0511057329	HYDRAULIC SYSTEM ASSY	53
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	54
0511057551	ASSY HANDRAIL 4845	55




MARCHESAN

INDEX


0511057331	ASSY PLATFORM - 4845	56
0511056536	ASSEMBLY LADDER	57
0511054971	RESTING ASSEMBLY	58
0511057333	ASSY HEADER 3495/4045/4395/4845/5345/5745	59
0521059615	SET LABEL ADHESIVE	60
0511059322	SUPPORT ASSY	61
0511059323	SUPPORT PLATFORM	62
0521054059	SET TURBINE	63
0531051809	SET TURBINE MTH P.P	64
0521050985	AIR DISTRIBUTOR	65
0511059887	TURBINE PRECISION PLANTING	66
0521050154	TURBINE P.P WITH HOLE	67
0909099159	ASSY HEX AXLE	68
0521055338	ROW SEED BEARING	69
0521057357	MONITORING ASSEMBLY	70
0531051787	MONITORING ASSEMBLY	71
0511057270	DRAWBAR TURNBUCKLE	72
0511054601	FULL ARTICULATED TRACTOR HITCH	73
0521056505	MANUAL CANISTER ASSY	74
0511057817	SUPPORT HOSE	75
0521057356	ROW SEED MONITOR	76
0511057505	SEED ROW FRONT PNEUM PP SHORT WITH RIGHT REAR	77
0511057506	SEED ROW FRONT PNEUM PP LONG WITH RIGHT REAR	78
0511057276	TRANSMISSION SUPPORT RIGHT ASSY	79
0511057273	ASSEMBLY TRANSMISSION	80
0511057159	TRANSMISSION BOX SEED LINE	81
0511057209	ROW RIGHT REAR SEED	82
0511057210	ROW LEFT REAR SEED	83
0511057502	SET PRECISION PLANTING	84
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	85
0511057155	PRECISION PLANTING LEFT TRANSMISSION BOX	86
0511053172	LEFT LOW CUBE WITH DISC 15	87
0511053173	CUBE LOW RIGHT WITH DISC 15	88
0511057153	DDD LEFT SUPREMA PRECISION PLANTING	89
0511058639	SHORT FERTILIZER LINE WITH DDD/DC20	90
0511058640	LONG FERTILIZER LINE WITH DDD / DC20	91
0511058630	20 DISC CUT	92
0511058648	BOX WITH DISC BLADE 20"	93
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	94
0511057509	SEED RESERVOIR PNEUMATIC ASSY	95
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	96
0511058650	SEMI-MOUNTED DEPTH CONTROL	97
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	98
0501052627	ASSY DEPTH WHEEL BOX	99
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	100
0501052297	DEPTH WHEELS REGULATOR ASSY	101
0501052538	DEPTH BAND WITH ARMS	102
0501052908	COMPACTOR WHEEL WITH BEARING	103
0511054333	COMPACT WHEEL RIGHT WITH BEARING	104
0511054334	COMPACT WHEEL LEFT WITH BEARING	105
0501110804	ROD SCARIFIER SPINDLE WIHT POINT	106
0521057957	FIXED ROD EXTENSION WITH FIXATION	107



Item	Code	Description	See page	QT
01	0531040570	DOUBLE DRAWBAR ASSY	2	01
02	0909095501	PST PLUS FLEX SUPREMA P.P - FRAME 4845 - 3 RIGHT		01
03	0909095502	PST PLUS FLEX SUPREMA P.P - FRAME 4845 - 4 LEFT		01




Item	Code	Description	See page	QT
001	0511056307	DOUBLE DRAWBAR ASSY	6	01
002	0501054863	WELL AND TIRE ASSY	14	02
003	0521026516	BOX WITH COMPONENTS	17	01




Item	Code	Description	See page	QT
01	0511057336	WHEEL AXLE FRAME - 4845	24	01
02	0503010003	1845 GREASE FITTING		06
03	0511058656	4845/5345/5745 - CYLINDER ASSY	25	01
04	0511058653	ASSY TRACTION SPRING WHEEL	27	04
05	0521050994	TRANSMISSION ASSY	30	01
06	0511057326	SET BEAM FERTILIZER - 4845	49	01
07	0511057329	HYDRAULIC SYSTEM ASSY	53	01
08	0511057551	ASSY HANDRAIL 4845	55	01
09	0511057331	ASSY PLATFORM - 4845	56	01
10	0511056536	ASSEMBLY LADDER	57	02
11	0511054971	RESTING ASSEMBLY	58	02
12	0511057333	ASSY HEADER 3495/4045/4395/4845/5345/5745	59	01
13	0521059615	SET LABEL ADHESIVE	60	01
14	0511059322	SUPPORT ASSY	61	02
15	0511059323	SUPPORT PLATFORM	62	04
16	0521054059	SET TURBINE	63	01
16.	0531051809	SET TURBINE MTH P.P	64	01
17	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		04
18	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
19	0511017302	FLAT WASHER		08
20	0503010019	1/2" SPRING WASHER		08
21	0503010060	1/2" NUT		08
22	0909099159	ASSY HEX AXLE	68	01
23	0521057357	MONITORING ASSEMBLY	70	01
23.	0531051787	MONITORING ASSEMBLY	71	01
24	0501065677	STRUT		02
25	0511057270	DRAWBAR TURNBUCKLE	72	01
26	0511054601	FULL ARTICULATED TRACTOR HITCH	73	01
27	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
28	0511053179	TRACTOR HITCH AXLE	22	01
29	0503031436	AIR DITRIBUTOR PUMP		04

Item	Code	Description	See page	QT
30	0503014120	CHAIN		01
31	0503014321	CABLE STEEL SHACKLE		02
32	0521056505	MANUAL CANISTER ASSY	74	01
33	0521013022	TRANSPORT LOCK		02
34	0503030168	HAIR PIN		02
35	0501068994	0.3" X 3.1" LOCK PIN		02
36	0511057817	SUPPORT HOSE	75	01
37	0501047895	ROD STOP		02
38	0501047885	ROD STOP		02
39	0501047886	ROD STOP		02
40	0501047887	ROD STOP		02
41	0503032624	SILO FERTILIZER GUTTER		06
42	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	54	01
43	0503010045	O'RING		01
44	0541010080	TERMINAL R.1 / 2 NPT		01
45	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01
46	0581013729	NIPLE 1/2 NPT		01
47	0503010246	CLAMP		14
48	0503010780	N-2050 AMENDMENT		02
49	0503010951	REDUCTION		04
50	0503011750	AMENDMENT WITH LOCK		06
51	0503011751	REDUCTION		06
52	0909095504	ASSY SEED/FERTILIZER ROW	5	10



Item	Code	Description	See page	QT
01	0511057336	WHEEL AXLE FRAME - 4845	24	01
02	0503010003	1845 GREASE FITTING		06
03	0511058656	4845/5345/5745 - CYLINDER ASSY	25	01
04	0511058653	ASSY TRACTION SPRING WHEEL	27	04
05	0521050994	TRANSMISSION ASSY	30	01
06	0511057326	SET BEAM FERTILIZER - 4845	49	01
07	0511057329	HYDRAULIC SYSTEM ASSY	53	01
08	0511057551	ASSY HANDRAIL 4845	55	01
09	0511057331	ASSY PLATFORM - 4845	56	01
10	0511056536	ASSEMBLY LADDER	57	02
11	0511054971	RESTING ASSEMBLY	58	02
12	0511057333	ASSY HEADER 3495/4045/4395/4845/5345/5745	59	01
13	0521059615	SET LABEL ADHESIVE	60	01
14	0511059322	SUPPORT ASSY	61	02
15	0511059323	SUPPORT PLATFORM	62	04
16	0521054059	SET TURBINE	63	01
16.	0531051809	SET TURBINE MTH P.P	64	01
17	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		04
18	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
19	0511017302	FLAT WASHER		08
20	0503010019	1/2" SPRING WASHER		08
21	0503010060	1/2" NUT		08
22	0909099159	ASSY HEX AXLE	68	01
23	0521057356	ROW SEED MONITOR	76	01
23.	0531051787	MONITORING ASSEMBLY	71	01
24	0501065677	STRUT		02
25	0511057270	DRAWBAR TURNBUCKLE	72	01
26	0511054601	FULL ARTICULATED TRACTOR HITCH	73	01
27	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
28	0511053179	TRACTOR HITCH AXLE	22	01
29	0503031436	AIR DITRIBUTOR PUMP		04

Item	Code	Description	See page	QT
30	0503014120	CHAIN		01
31	0503014321	CABLE STEEL SHACKLE		02
32	0521056505	MANUAL CANISTER ASSY	74	01
33	0521013022	TRANSPORT LOCK		02
34	0503030168	HAIR PIN		02
35	0501068994	0.3" X 3.1" LOCK PIN		02
36	0511057817	SUPPORT HOSE	75	01
37	0501047895	ROD STOP		02
38	0501047885	ROD STOP		02
39	0501047886	ROD STOP		02
40	0501047887	ROD STOP		02
41	0503032624	SILO FERTILIZER GUTTER		06
42	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	54	01
43	0503010045	O'RING		01
44	0541010080	TERMINAL R.1 / 2 NPT		01
45	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01
46	0581013729	NIPLE 1/2 NPT		01
47	0503010246	CLAMP		14
48	0503010780	N-2050 AMENDMENT		02
49	0503010951	REDUCTION		04
50	0503011750	AMENDMENT WITH LOCK		06
51	0503011751	REDUCTION		06
52	0909095504	ASSY SEED/FERTILIZER ROW	5	10




Item	Code	Description	See page	QT
01	0511057505	SEED ROW FRONT PNEUM PP SHORT WITH 77		01
		RIGHT REAR		
02	0511057506	SEED ROW FRONT PNEUM PP LONG WITH RIGHT 78		01
		REAR		
03	0511057209	ROW RIGHT REAR SEED	82	01
04	0511057210	ROW LEFT REAR SEED	83	01
05	0511058639	SHORT FERTILIZER LINE WITH DDD/DC20	90	01
06	0511058640	LONG FERTILIZER LINE WITH DDD / DC20	91	01
07	0511057509	SEED RESERVOIR PNEUMATIC ASSY	95	01
08	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	96	01
09	0501110804	ROD SCARIFIER SPINDLE WIHT POINT	106	10
10	0521069127	BOTTOM NOZZLE FERTILIZER		10
11	0503030391	RIGHT FERTILIZER NOZZLE		01
12	0503030392	LEFT FERTILIZER NOZZLE		01
13	0503031145	2" X 2" X 20" HOSE		01
14	0503031076	2" HOSE CLAMP		02
15	0531013600	PRESS ADJUSTMENT LEVER		01
16	0511017969	0.1" SPACING PLATE		20
17	0511018662	SPACING PLATE		20
18	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		10
19	0503030520	SEED SOCKET		10
20	0521057957	FIXED ROD EXTENSION WITH FIXATION	107	05
21	0571019693	GUN 25 X 58 X 800		02
22	0571018391	GUTTER 25 X 58 X 1200		02
23	0571017368	SUPPORT GUTTER		08
24	0501011643	3/8 X 1"BOLT		08
25	0501010984	FLAT WASHER		08
26	0503010025	3/8" SPRING WASHER		08
27	0503010026	3/8" NUT		08
28	0503031050	CURVED CONDUCTOR		10
29	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02



Item	Code	Description	See page	QT
30	0503010905	1/2" X 2-1/4" BOLT		02
31	0503010019	1/2" SPRING WASHER		06
32	0503010060	1/2" NUT		06
33	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
34	0501010984	FLAT WASHER		01
35	0503010025	3/8" SPRING WASHER		01
36	0503010026	3/8" NUT		01


DOUBLE DRAWBAR ASSY

0511056307




Item	Code	Description	See page	QT
001	0511064305	FRAME HEADER DOUBLE		01
002	0511064219	FORK WHEEL DRAWBAR DOUBLE		02
003	0503010007	3982/3920 ROLLER BEARING		02
004	0503010059	33287/33462 ROLLER BEARING		02
005	0503013106	SEAL 00085-B		02
006	0502040080	2.1/2" SLOTTED NUT		02
007	0503011345	1/4" X 3-1/2" COTTERPIN		02
008	0541013225	WHEEL BOX COVER		02
009	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		12
010	0503011444	SPRING WASHER		12
011	0503010002	1800 GREASE FITTING		03
012	0909093876	FIXER SUPPORT BOLT HOSE	7	04
013	0521051583	HOSE SET HEADBOARD	8	01
014	0531017560	DISPLAYED IDENTIFICATION		08
015	0502012702	BODY SUPPORT CLAMP		09
016	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		09
017	0503010180	7/16" SPRING WASHER		09
018	0501053835	FEMALE QUICK COUPLER		08
019	0503010217	501040 CLAMPING RING (FOR AXLE)		16
020	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	54	04
021	0501054061	SEQUENCE VALVE WITH NIPPLES	9	01
022	0503010237	3/8" X 1" BOLT		02
023	0503010025	3/8" SPRING WASHER		02
024	0503010026	3/8" NUT		02
025	0501054862	AXIS LOCK RODE ASSY	10	02
026	0511066114	CONDUCTOR VALVE SUPPORT DOUBLE HEADER		01
027	0501054694	FLOW DIVIDING VALVE ASSY	11	01
028	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
029	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
030	0503010143	1/4" SPRING WASHER		02
031	0503010144	1/4" NUT		02


Item	Code	Description	See page	QT
032	0503062157	HEADER JACK	12	01
033	0521010549	COUPLING SHAFT		01
034	0503030168	HAIR PIN		01
035	0511052464	FLOW DIVIDING VALVE	13	01
036	0503010001	3.2 X 5.5 RIVET		04
037	0521063568	SUPPORT VALVE		01




Item	Code	Description	See page	QT
01	0511064222	FIXER SUPPORT BOLT HOSE		04
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
03	0503010019	1/2" SPRING WASHER		08
04	0503010060	1/2" NUT		08
05	0502012702	BODY SUPPORT CLAMP		08
06	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		08
07	0503010180	7/16" SPRING WASHER		08




Item	Code	Description	See page	QT
001	0501080846	3/8" X 1550 TR-TM HOSE		04
002	0501080072	1/2" X 63" TR-TM HOSE ASSY		06
003	0501080335	1/2" X 63" TC-TM HOSE ASSY		04
004	0501080678	HOSE 1/2 X 3800 TC-TM		02
005	0501080185	HOSE 1/2 X 4000 TR-TM		05




Item	Code	Description	See page	QT
01	0501011460	7/8 NF REDUCTION NIPPLE		02
02	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0511064229	LOCK PIN		01
02	0503030978	COMPRES SPRING		01
03	0503010131	3/16" X 1-1/2" COTTERPIN		01
04	0503010292	0.2" X 1.6" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503012481	FLOW DIVIDING VALVE		01
02	0503030923	3/4" UNF X 13/16UN OFS X 40 NIPPLE		03
03	0503010190	2-114 N 3006-9B O'RING		03




Item	Code	Description	See page	QT
01	0503062157	HEADER JACK	12	01




Item	Code	Description	See page	QT
01	0503013791	DOUBLE MOTOR		01
02	0541018940	7/8 NF X R 1 BSPT X 55 NIPPLE		01
03	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
04	0503010025	3/8" SPRING WASHER		04
05	0503011051	M10 X 0.6" NUT		04




Item	Code	Description	See page	QT
01	0503060414	WHEEL AND TIRE	15	01
02	0501051799	STUB SHAFT & HUB ASSY	16	01
03	0531015109	WHEEL AXLE LOCK		02



Item	Code	Description	See page	QT
01	0503012108	RODA 10 LB X 15 X 8F X 203 GCRO		01
02	0503010860	CAMARA AR 11L 15		01
03	0503011469	RIB TIRE 12L		01




Item	Code	Description	See page	QT
01	0502010908	CARRYING WHEEL HUB	01	
02	0503012159	4.0" X 2.5" X 0.5" SEAL 5144	01	
03	0503010008	ROLAMENTO 3780/37203	01	
04	0503010328	25590/25523 ROLLER BEARING	01	
05	0503012162	5046 BAG SEAL RING	01	
06	0521011209	425 TRANSP WHEEL AXLE	01	
07	0511015949	LOCK NUT	01	
08	0503010329	LOCK WASHER	01	
09	0503010330	KM 9 LOCKNUT	01	
10	0501010086	FLAT WASHER	01	
11	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR	08	
12	0503010064	5/8 UNF CONIC NUT	08	
13	0503011052	1.1/4" X 0.77" CASTLE NUT	02	
14	0503010067	3/16" X 2.1/2" COTTER PIN	02	




Item	Code	Description	See page	QT
001	0501100160	WOODEN BOX 2450X1050X920		01
002	0521067306	SUPPORT FIXING REAR STABILIZER DOUBLE HEADER		02
003	0521014754	FIXING BASE ESTABILIZER		02
004	0511061022	ROW MARKER SUPPORT		02
005	0511061021	SUPPORT FASTENER		04
006	0502010175	HITCH CLAMP		08
007	0511060013	ROW MARKER ARM		02
008	0511060014	ROW MARKER ARM		02
009	0511060010	1400 TURNBUCKLE		02
010	0501050633	MARKER DISC ASSY LINE	18	02
011	0501110262	245 ADJUSTMENT NUT		01
012	0521064307	EXTENSOR 2400 DOUBLE HEAD		02
013	0501054258	DRAWBAR ESTABILIZER ASSY		01
014	0511064217	TURNBUCKLE WITH EAR		02
015	0501068300	TURNBUCKLE WITH EAR		02
016	0501061056	RH LOCKNUT WITH HANDLER		04
017	0511060916	TURNBUCKLE WITH GLOVE		01
018	0511061029	TURNBUCKLE WITH GLOVE		01
019	0511060919	TURNBUCKLE WITH GLOVE		01
020	0521013347	1.1/4" X 8.4" AXLE		02
021	0521011142	1.1/4" X 7.5" AXLE		04
022	0521011141	1.1/4" X 6.5" AXLE		02
023	0511058431	HYDRAULIC CYLINDER	20	02
024	0511015573	2.07" X 1.6" TRANSPORT LOCK		02
025	0501066284	SUPPORT FRONT TURNBUCKLE FIXER		02
026	0521012329	3/4 UNC X 130 X 173 FASTENER		02
027	0511064228	HOSE HOLDER		02
028	0511064310	FIXER PLATE FASTENER		02
029	0521014021	1/2" X 4.5" X 5.4" FASTENER		06
030	0501040364	HOSE SUPPORT 3/4X640 ASSY	21	02
031	0521067307	STABILITY FIXER		02


Item	Code	Description	See page	QT
032	0511064353	FASTENER		02
033	0502012702	BODY SUPPORT CLAMP		04
034	0501080901	3/8" X 5800 TC-TM HOSE		04
035	0501080779	1/2 X 1500 TM-TM HOSE		02
036	0501054862	AXIS LOCK RODE ASSY	10	02
037	0511053179	TRACTOR HITCH AXLE	22	01
038	0501051160	TRACTOR HITCH PIN		02
039	0511056409	TRACTOR HITCH	23	01
040	0571017510	GLOVE ARTICULATED HITCH		01
041	0511064220	COUPLING SUPPORT DOUBLE DRAWBAR		02
042	0531017551	COUPLING SUPPORT FIXING BASE		02
043	0503011345	1/4" X 3-1/2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0511053904	DISC LINE MARKER	19	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0501067700	2.5" X 25" CYLINDER CASE		01
02	0521066632	EXTENDER		01
03	0503030384	CON PLUG N-001		02
04	0502012837	PISTON		01
05	0503018005	RING		01
06	0503011109	2-119 N 3006-9B O'RING		01
07	0503010163	D-1500 SCRAPER RING		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503018004	RING		01
11	0503018003	GASKET		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
001	0501060409	HOSE SOPPORT ASSY		01
002	0503011442	3/4" SPRING WASHER		01
003	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HAIR PIN		01




Item	Code	Description	See page	QT
001	0571017512	HITCH JOINT		01
002	0571017511	SLEEVE HITCH ARTICULATION		01
003	0502040850	U TRACTOR COUPLING		01
004	0571012612	PIVOT SHAFT		01
005	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
006	0503010010	1/4" X 2.1/2" COTTERPIN		01
007	0521010681	BUSHING COUPLING BODY		01
008	0521010639	COUPLING SHAFT		01
009	0503010571	1/4" X 1.1/2 COTTERPIN		01
010	0503016482	BOLT		02
011	0503033731	COMPRESSION SPRING LEFT		02
012	0503011331	3/8 BALL		02
013	0503010002	1800 GREASE FITTING		01
014	1882970002	GREASE SOAP		01
015	0503010378	CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0521065921	FRAME - 4845		01
02	0521065930	PIVOT SHAFT WHEEL - 4845		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8" X 2-1/4" BOLT		12
05	0531013922	0.6" X 0.8" X 1" SLEEVE		12
06	0503011445	SPRING WASHER		12
07	0503010013	5/8" NUT		12
08	0501012140	FLAT WASHER		24



Item	Code	Description	See page	QT
01	0511058608	HYDRAULIC CYLINDER	26	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521010547	1.2" X 6.5" COUPLING SHAFT		02
04	0503010523	1/4" X 2" COTTERPIN		04
05	0501047888	ROD STOP		02
06	0571019384	SPACING SLEEVE 16,30 X 30 X 104		02
07	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		02
08	0503010027	5/8" SPRING WASHER		02
09	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0521066742	TURNBUCKLE		01
02	0521066741	CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0503010004	1890 GREASE FITTING		01
05	0502012821	50.80 X 101.60 RING SUPPORT		01
06	0503011061	8-342 BACK-UP RING		02
07	0503018024	RING BS		01
08	0503010338	2-342 N 3006-9B O'RING		02
09	0503018026	1870-2000-375 B GASKET		01
10	0503018025	RING GUIDE		01
11	0503010039	D-2000 SCRAPER RING		01
12	0502012822	101.60 END CAP		01
13	0502012842	50,80 X 101,60 PISTON		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503018029	2-217 O'RING		01
16	0503015633	SELEMASTER SEALING		01




Item	Code	Description	See page	QT
01	0511058654	WHEEL SUPPORT ASSY	28	01
02	0501058240	WHELL FASTENER WITH STRETCHER	29	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01

WHEEL SUPPORT ASSY

0511058654




Item	Code	Description	See page	QT
01	0521066716	WHEEL ARM ASSY		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511050681	TRACTION SPRING		01
06A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
06B	0561016062	SPRING HITCH		02
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
08	0503010027	5/8" SPRING WASHER		01
09	0501058241	TENSIONER CHAIN SUPPORT	31	01
10	0503013030	5/8" X 3.1/4" BOLT		01
11	0551017715	FLAT WASHER		02
12	0511052770	WHEEL WITH TIRE 7.00X16 ASSY WHEELED BOX		01
13	0591010589	BODY LOCK WHEEL		01
14	0503010027	5/8" SPRING WASHER		02
15	0503011167	M16 X 2 X 30 BOLT		02



Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	STRETCHER INTERMEDIATE RODE CURRENT		01
07	0501058244	STRETCHER FIXED CURRENT		01
08	0501058242	MOVIL CHAIN TENSIONER		01

TRANSMISSION ASSY

0521050994




Item	Code	Description	See page	QT
001	0521065954	SUPPORT BEARING AXLE MOTOR		04
002	0501110639	BEARING		08
003	0503011099	GREASE FITTING		08
004	0503010300	5/32" X 1" COTTERPIN		08
005	0511015961	LOCK BUSHING		04
006	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
007	0503010060	1/2" NUT		04
008	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
009	0511017302	FLAT WASHER		16
010	0503010019	1/2" SPRING WASHER		16
011	0503010060	1/2" NUT		16
012	0501058241	TENSIONER CHAIN SUPPORT	31	04
013	0571018908	MOTOR SHAFT 2350		02
014	0501018466	FLAT WASHER		02
015	0501052560	AXLE MOTOR SLOW-MOVING ASSY	32	02
016	0511051434	TRANSMISSION DRIVING ASSY	33	04
017	0511047069	SIDE TRANSMISSION DRIVING	34	01
018	0511047070	LH SIDE TRANSMISSION DRIVING	35	01
019	0511061759	22Z P12,70 FQ 3/4" GEAR		02
020	0501053788	Q3/4" FASTENER AXLE ASSY	36	02
021	0503030303	SUPPORT WASHER		04
022	0501056271	BEARING CLOSED	37	02
023	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
024	0501010984	FLAT WASHER		08
025	0503010025	3/8" SPRING WASHER		04
026	0503010026	3/8" NUT		04
027	0511057265	TIGHTENER TRANSMISSION	38	02
028	0521010773	0.37" X 1.18" COUPLING SHAFT		02
029	0501010984	FLAT WASHER		06
030	0503010140	1/8" X 3/4" COTTERPIN		02
031	0571018846	DISASSEMBLE LEVER		02


TRANSMISSION ASSY

0521050994


Item	Code	Description	See page	QT
032	0503033942	COVER REGULATORY WHEEL		02
033	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
034	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
035	0503030093	TRACTION SPRING		02
036	0503012407	5/8" X 1-1/2" BOLT		04
037	0503012412	5/8 UNC SELF LOCKING NUT		04
038	0511061759	22Z P12,70 FQ 3/4" GEAR		02
039	0501053788	Q3/4" FASTENER AXLE ASSY	36	02
040	0503030275	AGRICULTURAL BEARING		02
041	0501056271	BEARING CLOSED	37	02
042	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
043	0501010984	FLAT WASHER		08
044	0503010025	3/8" SPRING WASHER		04
045	0503010026	3/8" NUT		04
046	0511057265	TIGHTENER TRANSMISSION	38	02
047	0511064536	28Z GEAR		02
048	0501053788	Q3/4" FASTENER AXLE ASSY	36	02
049	0503030303	SUPPORT WASHER		02
050	0503010292	0.2" X 1.6" SPRING PIN		02
051	0521018630	1.4" X SQUARE 0.8" WASHER		02
052	0501056271	BEARING CLOSED	37	02
053	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
054	0501010984	FLAT WASHER		08
055	0503010025	3/8" SPRING WASHER		04
056	0503010026	3/8" NUT		04
057	0501052810	TRANSMISSION CHAIN TENSIONER ASSY	39	02
058	0511050652	CHAIN TENSIONER	40	04
059	0501053653	BEARING WITH 20Z GEAR	41	02
060	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
061	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
062	0503013149	40-1 CHAIN X 157 LINK + MENDING + RED		02
063	0511069678	LH LOWER LEVER		02
064	0551019159	LEVER FIXER BODY		02
065	0561016468	FASTENER		02
066	0503011336	1/2" HEX SELF ADJUSTING NUT		04
067	0501010984	FLAT WASHER		04
068	0503010140	1/8" X 3/4" COTTERPIN		04
069	0521055335	ASSY RECAMBIO RIGHT		01
070	0521055337	ASSY RECAMBIO LEFT	42	01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	5/16" X 3/4" BOLT		02
03	0503010179	5/16" ZN SPRING WASHER		02
04	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511817303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	1 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0503010002	1800 GREASE FITTING		01
05	0511017302	FLAT WASHER		03
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0541011713	TENSIONER CHAIN LOWER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551019171	CHAIN TIGHTENER AXLE		01
02	0503011410	ROLLER BEARING		01
03	0511062169	21Z P 1/2" GEAR		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503011105	SEAL RING		01
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0571010265	16.5 X 40 X 3 FLAT WASHER		01
08	0503012412	5/8 UNC SELF LOCKING NUT		01



Item	Code	Description	See page	QT
01	0501053654	DOUBLE BEARING TRANSMISSION SEED 3/4		01
02	0511063185	20Z GEAR WITH HEX HOLE AXLE 20		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010365	NUT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0511058382	LEFT RECAMBIO	44	01
02	0521065956	LH GEAR BOX COVER		01
03	0503010240	5/16" X 3/4" BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0511017302	FLAT WASHER		01
07	0503010019	1/2" SPRING WASHER		01
08	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06




Item	Code	Description	See page	QT
01	0521065939	RH GEAR BOX		01
02	0511060396	DRIVE/DRIVEN AXLE CONE		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
05	0503010060	1/2" NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE		01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	BEARING CLOSED	37	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
14	0503010179	5/16" ZN SPRING WASHER		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TENSIONER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH LINK ASSY	45	02
20	0503031366	RIGHT TWISTED SPRING RECAMBIO		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	BEARING ASSY GEAR BOX	46	01
31	0503010292	0.2" X 1.6" SPRING PIN		08



Item	Code	Description	See page	QT
32	0511057258	GEAR WITH ADJUSTER	47	01
33	0511054363	CHAIN TENSIONER	48	01
34	0571018901	DRIVEN AXLE		01

LEFT RECAMBIO


0511058382




Item	Code	Description	See page	QT
01	0521065940	LEFT BOX RECAMBIO		01
02	0511060396	DRIVE/DRIVEN AXLE CONE		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
05	0503010060	1/2" NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE		01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	BEARING CLOSED	37	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
14	0503010179	5/16" ZN SPRING WASHER		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TENSIONER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH LINK ASSY	45	02
20	0503031367	SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	BEARING ASSY GEAR BOX	46	01
31	0503010292	0.2" X 1.6" SPRING PIN		08




Item	Code	Description	See page	QT
32	0511057258	GEAR WITH ADJUSTER	47	01
33	0511054363	CHAIN TENSIONER	48	01
34	0571018901	DRIVEN AXLE		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING		01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0571019207	DEVIATION AXLE GEAR BOX		01
06	0503010899	5/8" X 2-1/4" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511057327	4845 - SUPPORT HOPPER WITH DISTRIBUTOR	50	01
02	0503062362	SILO FERTILIZER 04 MOUTH		03
03	0503013751	3/8 UNC X 1.1/4 BOLT		18
04	0571019051	FIXER BOX WASHER		18
05	0503012535	3/8" SPRING WASHER		18
06	0503012531	3/8" INOX NUT		18
07	0503011957	NYLON LUG		02
08	0503010371	5/16" X 1" BOLT		04
09	0503010179	5/16" ZN SPRING WASHER		04
10	0503010337	5/16" NUT		04
11	0503034396	FERTILIZER SIDE COVER		12
12	0503010362	1/8" X 1.1/4" COTTERPIN		12
13	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		14
14	0501010984	FLAT WASHER		28
15	0503010025	3/8" SPRING WASHER		14
16	0503010026	3/8" NUT		14




Item	Code	Description	See page	QT
01	0521065936	SUPPORT HOPPER FERTILIZER		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	51	06
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	52	06
04	0501010942	3/8" X 1-1/4" BOLT		48
05	0503011443	3/8" SPRING WASHER		48
06	0503010026	3/8" NUT		48
07	0571018898	SQUARE SHAFT 3/4 X 2315		02
08	0503030275	AGRICULTURAL BEARING		12
09	1902010685	18Z CONICAL GEAR		12
10	0551018055	22,65 X 60 SLEEVE		02
11	0501053788	Q3/4" FASTENER AXLE ASSY	36	04
12	0511061759	22Z P12,70 FQ 3/4" GEAR		02
13	0503030303	SUPPORT WASHER		04
14	0501056271	BEARING CLOSED	37	02
15	0503011953	5/16" X 1" BOLT		04
16	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
17	0521011039	FLAT WASHER		04
18	0503011444	SPRING WASHER		04
19	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0511057335	HOSE KIT HYDRAULIC		01
01A	0501080025	TR-TC HOSE ASSY		04
01B	0521052285	TC-TM HOSE ASSY		01
01BA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01BD	0503018952	PLASTIC BOLT		06
01C	0521052330	HOSE 3/8 X 4000 TC-TM PRET/AZUL		01
01CA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01CB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01CC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01CD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	54	02
03	0511058120	KIT VALVE SUPPORT		01
03A	0521066354	OIL DISTRIBUTOR BODY		02
03B	0502010477	HOSE CLAMP		04
03C	0503011268	3/8" X 2-1/2" BOLT		02
03D	0501010984	FLAT WASHER		04
03E	0503010025	3/8" SPRING WASHER		02
03F	0503010026	3/8" NUT		02
04	0503013100	NYLON CLAMP		02
05	0502012702	BODY SUPPORT CLAMP		04
06	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
07	0503010180	7/16" SPRING WASHER		04
08	0531011180	UPPER BODY CLIP		04
09	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
001	0521065952	HANDRAIL FRAME		02
002	0503010752	1/2" X 3.1/2" BOLT		08
003	0511017302	FLAT WASHER		08
004	0503010019	1/2" SPRING WASHER		08
005	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0571018868	SET PLATFORM 4845		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	FLAT WASHER		16
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012806	SUPPORT REAR FIXER DRAWBAR		04
02	0502012789	FIXER SUPPORT FERTILIZER ROW		04
03	0503017960	5/8" X 3-12" BOLT		16
04	0503010811	5/8" UNF SELF ADJUSTING NUT		16
05	0501010191	1" X 6" BOLT		04
06	0503010012	1" SPRING WASHER		04
07	0501010059	1.5/8 NUT		04
08	0502012805	SUPPORT FRONT FIXER DRAWBAR		04
09	0502012789	FIXER SUPPORT FERTILIZER ROW		04
10	0503017960	5/8" X 3-12" BOLT		16
11	0503010811	5/8" UNF SELF ADJUSTING NUT		16
12	0521065958	DRAWBAR		01
13	0561019087	DRAWBAR TRANSPORT LOCK		01
14	0551014099	COUPLING SHAFT 31,75 X 185		01
15	0521010544	1.2" X 4.9" COUPLING SHAFT		01
16	0503030085	LOCK PIN		02
17	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
001	0503034116	ADHESIVE LABEL	03	
002	0503034114	ADHESIVE LABEL LOGO TATU BOX 190 X 530	03	
003	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
004	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
005	0503033422	ADHESIVE LABEL	02	
006	0503033424	DIRECT PLANTIO ADHESIVE LABEL	02	
007	0503031428	READ MANUAL DECAL	01	
008	0503031942	ADHESIVE LABEL	01	
009	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
010	0503031565	ADHESIVE LABEL CARE	02	
011	0503031566	ADHESIVE LABEL	02	
012	0503034249	ADHESIVE LABEL TABLE PLANTS	02	
013	0503031425	ADHESIVE LABEL ATTENTION	02	
014	0503031669	ADHESIVE LABEL	01	
015	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
016	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
017	0503032930	ADHESIVE LABEL DANGER	06	
018	0503031087	ADHESIVE LABEL	01	
019	0503034003	SERIAL NUMBER TAG 61 X 118	01	
020	0503010001	3.2 X 5.5 RIVET	04	
021	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
022	0503034500	ADHESIVE LABEL	01	



Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0521067033	CONJ SUPT		01
03	0503017960	5/8" X 3-12" BOLT		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0581011989	SIDE BODY FIXER PLATFORM		01
02	0551019884	45 X 50 X 3/8 FASTENER		01
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0501010984	FLAT WASHER		02
07	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
001	0581012097	RIGHT SUPPORT		01
002	0581012098	LEFT SUPPORT		01
003	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
004	0503010019	1/2" SPRING WASHER		04
005	0503010060	1/2" NUT		04
006	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
007	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
008	0503010143	1/4" SPRING WASHER		02
009	0503010144	1/4" NUT		02
010	0581011439	AIR CONDUCTOR		02
011	0503011372	102 TO 121 CLAMP		02
012	0521050985	AIR DISTRIBUTOR	65	02
013	0503031436	AIR DITRIBUTOR PUMP		02
014	0503010246	CLAMP		02
015	0571019403	STAPLE FIXER		04
016	0501010984	FLAT WASHER		08
017	0503010025	3/8" SPRING WASHER		08
018	0503010026	3/8" NUT		08
019	0581012095	AIR DISTRIBUTOR SUPPORT		04
020	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
021	0503010019	1/2" SPRING WASHER		08
022	0503010060	1/2" NUT		08
023	0571013731	VACUUM GAUGE SUPPORT		01
024	0503013584	VACUUM GAUGE		01
025	0571019712	AIR CONDUCTOR		10
026	0571019716	ADAPTER		10
027	0511059887	TURBINE PRECISION PLANTING	66	01
028	0511057846	ASSY HOSE KIT		01
028A	0511057847	ASSY HOSE TURBINE		01
028AA	0503033158	PLASTIC BAG		01
028AB	0521052531	3/8 X 6108 TC-TM HOSE YELLOW / GREEN		01

Item	Code	Description	See page	QT
028ABA	0501080850	3/8" X 6100 TC-TM HOSE		01
028ABB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
028ABC	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
028ABD	0503018952	PLASTIC BOLT		06
028AC	0521052528	1/2 X 6200 TC-TM HOSE YELLOW / RED		01
028ACA	0501081810	HOSE 1/2 X 6200 TC-TM		01
028ACB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
028ACC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
028ACD	0503018952	PLASTIC BOLT		06
028AD	0521052529	1/2 X 6200 TC-TM HOSE YELLOW / BLUE		01
028ADA	0501081810	HOSE 1/2 X 6200 TC-TM		01
028ADB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
028ADC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
028ADD	0503018952	PLASTIC BOLT		06
028B	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	54	02
028C	0581012991	SPRING PROTECTION PLASTIC HOSE		01
028D	0503033981	ADHESIVE LABEL		01
028E	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN		01
029	0521052549	CLAMP		20




Item	Code	Description	See page	QT
01	0581012097	RIGHT SUPPORT		01
02	0581012098	LEFT SUPPORT		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2" NUT		04
06	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0581011439	AIR CONDUCTOR		02
11	0503011372	102 TO 121 CLAMP		02
12	0521050985	AIR DISTRIBUTOR	65	02
13	0503031436	AIR DITRIBUTOR PUMP		04
14	0503010246	CLAMP		04
15	0571019403	STAPLE FIXER		04
16	0501010984	FLAT WASHER		08
17	0503010025	3/8" SPRING WASHER		08
18	0503010026	3/8" NUT		08
19	0581012095	AIR DISTRIBUTOR SUPPORT		04
20	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
21	0503010019	1/2" SPRING WASHER		08
22	0503010060	1/2" NUT		08
23	0571013731	VACUUM GAUGE SUPPORT		01
24	0503013584	VACUUM GAUGE		01
25	0571019712	AIR CONDUCTOR		08
26	0571019716	ADAPTER		08
27	0511059887	TURBINE PRECISION PLANTING	66	01
28	0511057846	ASSY HOSE KIT		01
28A	0511057847	ASSY HOSE TURBINE		01
28AA	0521052531	3/8 X 6108 TC-TM HOSE YELLOW / GREEN		01
28AAA	0501080850	3/8" X 6100 TC-TM HOSE		01


Item	Code	Description	See page	QT
28AAB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
28AAC	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
28AAD	0503018952	PLASTIC BOLT		06
28AB	0521052528	1/2 X 6200 TC-TM HOSE YELLOW / RED		01
28ABA	0501081810	HOSE 1/2 X 6200 TC-TM		01
28ABB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
28ABC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
28ABD	0503018952	PLASTIC BOLT		06
28AC	0521052529	1/2 X 6200 TC-TM HOSE YELLOW / BLUE		01
28ACA	0501081810	HOSE 1/2 X 6200 TC-TM		01
28ACB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
28ACC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
28ACD	0503018952	PLASTIC BOLT		06
28B	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	54	02
28C	0581012991	SPRING PROTECTION PLASTIC HOSE		01
28D	0503033981	ADHESIVE LABEL		01
28E	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN		01
29	0521052549	CLAMP		16




Item	Code	Description	See page	QT
001	0581014326	BODY DISTRIBUTOR AR		01
002	0571017215	SOCKET DISTRIBUTOR AR		01
003	0503012566	COVER KAP 110 YELLOW		01
004	0503031943	SOCKET		06
005	0503012856	REBITE POP		12




Item	Code	Description	See page	QT
01	0521050154	TURBINE P.P WITH HOLE	67	01
02	0503015420	VALVE ANTI-CAVITACAO CV10208TN5		01
03	0501011460	7/8 NF REDUCTION NIPPLE		04
04	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
05	0503010392	2-046 N 3006 9B O'RING		01
06	0503010190	2-114 N 3006-9B O'RING		04
07	0501080218	1/2 X 750 HOSE		01
08	0581012096	ROUND SLEEVE		02
09	0503011372	102 TO 121 CLAMP		02
10	0503062614	KIT PLUG MANG TERMINAL PP		01




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01




Item	Code	Description	See page	QT
01	0521055338	ROW SEED BEARING	69	06
02	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		24
02A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
02B	0503010256	3/8" X 3/4" BOLT		01
03	0571018918	3/4 X 2490 3/4 X 2305		01
04	0571018919	3/4 X 2490 AXLE HEX		01




Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	BEARING SEED LINE		01
03A	0502012030	HOUSING BEARING		01
03B	0503012861	6006 2RS BALL BEARING		01
03C	0503012858	502075 CLAMPING RING (FOR HOLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	5/16" ZN SPRING WASHER		02
06	0503010337	5/16" NUT		02
07	0501013518	FLAT WASHER		02
08	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02




Item	Code	Description	See page	QT
001	0503063100	KIT MONITORING SEED		01
001A	0503017606	APEX EXTENSION CABLE		01
001B	0503016556	10 ROW SIMPLE MONITOR CABLE		01
001C	0503019100	SENSOR		10
002	0503013100	NYLON CLAMP		30
003	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		**




Item	Code	Description	See page	QT
01	0503063439	SEED MONITORING KIT 8 LINES		01
01A	0513010227	CABLE SIMPLE MONITORING 8 LINES		01
01B	0503019100	SENSOR		08
01C	0503017607	EXTENSOR CABLE PM400 6.0M 18X18 020010557		01
02	0503013100	NYLON CLAMP		40
03	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		30




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0521065959	JACK R.1.1/2 UNC RIGHT X 240		01
03	0521065960	JACK R.1.1/2 UNC LEFT X 240		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0571012612	PIVOT SHAFT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
05	0503010179	5/16" ZN SPRING WASHER		01
06	0503010337	5/16" NUT		01



Item	Code	Description	See page	QT
01	0521066302	HOSE HOLDER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
001	0503063097	KIT MONITORING SEED		01
001A	0503017602	MONITOR PLANT PM400		01
001B	0503017606	APEX EXTENSION CABLE		01
001C	0503016556	10 ROW SIMPLE MONITOR CABLE		01
001D	0503017443	ANTENNA GPS PM 400		01
001E	0503019100	SENSOR		10
002	0503016234	TRIMBLE FIXING WINDOW		01
003	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
004	0571012196	MOUNTING BRACKET PM 400		01
005	0503013100	NYLON CLAMP		30
006	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		**
007	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
008	0503010669	FLAT WASHER		02
009	0503010668	3/16" SPRING WASHER		02
010	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		02
03	0503017857	BOLT 5/8 UNF 4		04
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8 UNC SELF LOCKING NUT		04
08	0502012804	PIVOT ARM SEED ROW		02
09	0571018882	SLEEVE ARM LINE SEED		08
10	0503010002	1800 GREASE FITTING		04
11	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
12	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
13	0571018883	PIN FIXER SPRING		03
14	0571018884	LOCK PIN ROW ARTICULAT		01
15	0503030168	HAIR PIN		04
16	0511057276	TRANSMISSION SUPPORT RIGHT ASSY	79	01
17	0521065943	REAR FRAME LONG ROW SEED		01
18	0511057269	CHAIN TENSIONER LINE		01
18A	0531019479	AXLE CHAIN GEAR		01
18B	0503031805	11Z 1/2" GEAR		01
18C	0511017302	FLAT WASHER		01
18D	0503010019	1/2" SPRING WASHER		01
18E	0503010060	1/2" NUT		01
19	0511057507	TRANSMISSION LOWER FRONT		01
19A	0511059190	BEARING DOBLE		01
19B	0581010976	5/8" HEX AXLE		01
19C	0503010300	5/32" X 1" COTTERPIN		01
19D	0501056296	UNIVERSAL JOINT		01
19E	0503011855	0.2" X 1.8" SPRING PIN		02
19F	0561014794	350 AXLE HEX		01
20	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
21	0581011694	PROTECTION REAR COVER SEED ROW		01

Item	Code	Description	See page	QT
22	0503010765	3/8" X 3" BOLT		01
23	0503010025	3/8" SPRING WASHER		01
24	0503010026	3/8" NUT		01
25	0511058512	PROTECTION COVER		01
25A	0521066693	CAP BEARING		01
25B	0503010834	1/2 X 1 BOLT		02
25C	0503010019	1/2" SPRING WASHER		02
26	0581011430	DRAWBAR ASSY		01
27	0521064369	HOSE HOLDER		01
28	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		02
03	0503017960	5/8" X 3-12" BOLT		04
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8 UNC SELF LOCKING NUT		04
08	0502012804	PIVOT ARM SEED ROW		02
09	0571018882	SLEEVE ARM LINE SEED		08
10	0503010002	1800 GREASE FITTING		04
11	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
12	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
13	0571018883	PIN FIXER SPRING		03
14	0571018884	LOCK PIN ROW ARTICULAT		01
15	0503030168	HAIR PIN		04
16	0511057276	TRANSMISSION SUPPORT RIGHT ASSY	79	01
17	0521066158	FRAME REAR LONG ROW SEED		01
18	0511057269	CHAIN TENSIONER LINE		01
18A	0531019479	AXLE CHAIN GEAR		01
18B	0503031805	11Z 1/2" GEAR		01
18C	0511017302	FLAT WASHER		01
18D	0503010019	1/2" SPRING WASHER		01
18E	0503010060	1/2" NUT		01
19	0511057508	TRANSMISSION LOWER FRONT		01
19A	0511059190	BEARING DOBLE		01
19B	0581010976	5/8" HEX AXLE		01
19C	0503010300	5/32" X 1" COTTERPIN		02
19D	0501056296	UNIVERSAL JOINT		01
19E	0503011855	0.2" X 1.8" SPRING PIN		02
19F	0561014794	350 AXLE HEX		01
20	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
21	0581011694	PROTECTION REAR COVER SEED ROW		01


Item	Code	Description	See page	QT
22	0503010765	3/8" X 3" BOLT		01
23	0503010025	3/8" SPRING WASHER		01
24	0503010026	3/8" NUT		01
25	0511058512	PROTECTION COVER		01
25A	0521066693	CAP BEARING		01
25B	0503010834	1/2 X 1 BOLT		02
25C	0503010019	1/2" SPRING WASHER		02
26	0581011430	DRAWBAR ASSY		01
27	0521064369	HOSE HOLDER		01
28	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511058766	BEARING		01
02	0511057273	ASSEMBLY TRANSMISSION	80	01
03	0503010300	5/32" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0511057159	TRANSMISSION BOX SEED LINE	81	01
02	0503032984	HOOD HEX AXLE ROW		01
03	0503013100	NYLON CLAMP		01
04	0571012492	HEX AXLE 5/8" X 330		01
05	0501056296	UNIVERSAL JOINT		01
06	0581010976	5/8" HEX AXLE		01
07	0503011855	0.2" X 1.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	BOX TRANSMISSION COVER		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0511057502	SET PRECISION PLANTING	84	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	DDD RITGH SUPREMA PRECISION PLANTING		01




Item	Code	Description	See page	QT
01	0511057502	SET PRECISION PLANTING	84	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	89	01




Item	Code	Description	See page	QT
01	0502012807	SUPPORT BOX PRECISION PLANTING		01
01A	1902012807	SEED BOX SUPPORT		01
02	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
03	0571017899	PIN LOCK PP		01
04	0503030190	0.5" X 1.6" X 0.05" SPRING		01
05	0571014024	FAST BOLT GUIDE AXLE		02
06	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
07	0581011225	FIXER P PLANTING CONTR CPRA		01
08	0511057155	PRECISION PLANTING LEFT TRANSMISSION BOX	86	01
09	0571017894	PIN DRAG PRECISION PLANTING		01
10	0503013357	3/8" SELF-ADJUSTING NUT		01
11	0503015752	3/8" X 2" BOLT		01
12	0501013518	FLAT WASHER		02
13	0503015356	SPRING PIN		01
14	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
15	0571017895	PIN FIXER CONDUCTOR P.P		01
16	0503011776	M6 SELF ADJUSTINGNUT		03
17	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
18	0503010293	BAQUELITE MANIPULACION		01
19	0503010140	1/8" X 3/4" COTTERPIN		03
20	0503010131	3/16" X 1-1/2" COTTERPIN		01
21	0503010025	3/8" SPRING WASHER		01
22	0503037390	PACKING FOR PLANTING		01
23	0571019491	SLUICE PNEUMATIC PRECISION PLANTING		01
24	0501011643	3/8 X 1"BOLT		01
25	0503010209	3/8" UNC BUTTERFLY NUT		01
26	0503012721	1/4" X 4" BOLT		01
27	0503012880	1/4" UNC SELF ADJUSTING NUT		01
28	0581011226	FIXER CLOSING P PLANTING CONTR CPRA		01
29	0571019489	CLAMP PRECISION PLANTING		01
30	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01

Item	Code	Description	See page	QT
31	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	85	01
31A	0503062405	SEED DISTRIBUTOR		01
31B	0503062407	SET SOYBEAN DISTRIBUTION		01
31B-01	0503062417	KIT CORN DISTRIBUTION		01
31B-02	0503062471	DISTRIBUTION ASSY (SORGHUM / MILLET)		01
31B-03	0503062577	DISTRIBUTION ASSY (LARGE CORN / SUNFLOWER)		01
31B-04	0503062578	DISTRIBUTION ASSY (LARGE CORN)		01
31B-05	0503062579	DISTRIBUTION ASSY (CORN / SUNFLOWER)		01
31B-06	0503062580	DISTRIBUTION ASSY (POPCORN / COTTON)		01
31B-07	0503062581	DISTRIBUTION ASSY (SMALL CORN / POP CORN)		01
31B-08	0503062573	CONVERSATION SET FOR DISTRIBUTION (LARGE BEAN)		01
31B-09	0503062574	CONVERSATION SET FOR DISTRIBUTION (SMALL BEET)		01
31B-10	0503062564	CONVERSATION SET FOR DISTRIBUTION (SOYBEAN / BEAN)		01
32	0561014778	HEX UNIVERSAL JOINT		01
33	0503013958	1/4" X 1" BOLT		02
34	0503818139	BOLT		03
35	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
36	0503015110	M06 SPRING WASHER		02




Item	Code	Description	See page	QT
01	0503062405	SEED DISTRIBUTOR	01	
01A	0503062567	FIXED BASE SEEDS DISTRIBUTOR	01	
01AA	0503018908	BODY FIXED BASE DISTRIBUTOR SEED	01	
01AB	0503018909	COVER CONDUCTOR DISTRIBUTOR SEED	01	
01AC	0503062652	SEED INPUT DEFLECTOR	01	
01AD	0503062653	FULL COVER	01	
01AE	0503018910	RIVETS LARGEST	01	
01AF	0503018911	SPACING BUSHING	01	
01AG	0503018912	BOLT	03	
01AH	0503018476	SPRING	01	
01AI	0503018474	LOWER BRUSH	01	
01AJ	0503018475	TOP BRUSH	01	
01AK	0503018157	RUBBER	01	
01AL	0503018477	LOCK SPRING	01	
01B	0503062568	FIXER MOBILE	01	
01BA	0503018919	BASE	01	
01BB	0503018913	RIVET	01	
01BC	0503018914	WASHER	01	
01BD	0503018915	BEARING	02	
01BE	0503062654	BEARING	01	
01BF	0503018916	ADJUSTMENT CHOCK	03	
01BG	0503018917	RING	01	
01BH	0503018918	CHOCK	02	
01BI	0503019288	RUBBER SEAL PP 730518	01	
01BJ	0503018478	SPRING	01	
01BK	0503018920	SEALING	01	
01BL	0503018479	TUBE	01	
01BM	0503018735	PROTECTIVE COVER	01	
01BN	0503018921	BOLT	06	
01BO	0503018922	BOLT	02	
01BP	0503018480	REGULATOR PIN	01	


Item	Code	Description	See page	QT
01BQ	0503018923	ADAPTER		01
01BR	0503018924	SPRING PIN		01
02	0503062417	KIT CORN DISTRIBUTION		01
02A	0503018160	CORN PLASTIC DISC		01
02B	0503062472	SELECTOR SEED CORN		01
02C	0503062474	EJECTOR CORN SEED SET		01
03	0571019613	STRAW PRECISION PLANTING SHIELD		01
03A	0503017957	PROTECTIVE COVER AIR INPUT		01




Item	Code	Description	See page	QT
01	0502050052	LEFT SIDE TRANSMISSION BOX PP		01
02	0502050053	RIGHT SIDE TRANSMISSION BOX PP		01
03	0503011410	ROLLER BEARING		02
04	0503011182	6203 ROLLER BEARING		02
05	0503011184	502040 CLAMPING RING (FOR AXLE)		01
06	0571017655	SLEEVE FIXER HITCH PNEUMATIC		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
08	0503010144	1/4" NUT		03
09	0511057504	JOIN GEAR		01
09A	0571017898	BODY GEAR TRANSMISSION		01
09B	0503011769	M8 X 0.5" BOLT		01
10	0581011222	PINION AXLE 6Z PNEUMATIC		01
11	0503034340	PINION AXLE 6Z PNEUMATIC		01




Item	Code	Description	See page	QT
01	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	87	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15	88	01
04	0503010026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501010984	FLAT WASHER		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012781	SUPPORT DDD LEFT		01
11	0511015098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02




Item	Code	Description	See page	QT
01	0511058633	SHORT SUPPORT FIXED LINE FERTILIZER		01
01A	0502012794	SHORT SUPPORT FERTILIZER ROW		01
01B	0503011854	5/8" X 1-1/4" BOLT		02
01C	0503010002	1800 GREASE FITTING		01
01D	0502012789	FIXER SUPPORT FERTILIZER ROW		01
01E	0503017960	5/8" X 3-12" BOLT		04
01F	0503010811	5/8" UNF SELF ADJUSTING NUT		04
01G	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
01H	0571019062	SLEEVE		01
01I	0571019059	SUPPORT WASHER		01
01J	0503010417	7/8" NUT		04
01K	0503034320	COMPRESSION SPRING		01
01L	0502012813	FLANGE WASHER SPRING		01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	SLEEVE ARM LINE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057272	LH SHORT ARM ROW FERTILIZER		01
05A	0521065972	LH SHORT ARM ROW FERTILIZER		01
05B	0502012815	DOUBLE-DISC SPACING PLATE		02
05C	0503010479	BOLT		02
05D	0503011440	SPRING WASHER		02
05E	0503010060	1/2" NUT		02
05F	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	94	01
05G	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
05H	0503011440	SPRING WASHER		02
05I	0503010060	1/2" NUT		02
06	0511058630	20 DISC CUT	92	01




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG		01
01A	0502012795	SUPPORT LONG		01
01B	0503011854	5/8" X 1-1/4" BOLT		02
01C	0503010002	1800 GREASE FITTING		01
01D	0502012789	FIXER SUPPORT FERTILIZER ROW		01
01E	0503017960	5/8" X 3-12" BOLT		04
01F	0503010811	5/8" UNF SELF ADJUSTING NUT		04
01G	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
01H	0571019062	SLEEVE		01
01I	0571019059	SUPPORT WASHER		01
01J	0503010417	7/8" NUT		04
01K	0503034320	COMPRESSION SPRING		01
01L	0502012813	FLANGE WASHER SPRING		01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	SLEEVE ARM LINE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057271	RH LONG ARM ROW FERTILIZER		01
05A	0521065973	RH LONG ARM ROW FERTILIZER		01
05B	0502012815	DOUBLE-DISC SPACING PLATE		02
05C	0503010479	BOLT		02
05D	0503011440	SPRING WASHER		02
05E	0503010060	1/2" NUT		02
05F	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR		01
05G	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
05H	0503011440	SPRING WASHER		02
05I	0503010060	1/2" NUT		02
06	0511058630	20 DISC CUT	92	01




Item	Code	Description	See page	QT
01	0571018989	LH BLADE DISC ARM		01
02	0502012790	LOCK NUT		01
03	0511058648	BOX WITH DISC BLADE 20"	93	01
04	0521065978	RIGHT ARM WITH WASHER LOCK		01
05	0571019035	SLEEVE SUPPORT ARM		01
06	0521010452	SLEEVE		01
07	0521066743	REGULACION SPRING		01
08	0503010417	7/8" NUT		04
09	0571019033	FIXATION AXLE		01
10	0503034319	LOCK PIN		01
11	0502012813	FLANGE WASHER SPRING		01
12	0503034320	COMPRESSSION SPRING		01
13	0571019032	SUPPORT WASHER		01
14	0571019034	FLANGE WASHER AXLE		02
15	0503010002	1800 GREASE FITTING		01
16	0503013185	3/4" X 5-1/2" BOLT		01
17	0503011255	3/4" LOCK NUT		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503011440	SPRING WASHER		01
20	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511056909	DISC BOX CUT WITHOUT THE DISC		01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	87	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	88	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503011443	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0502012798	SUPPORT BOX SEED	01	
02	0581012694	COMPACT PROTECTION	01	
03	0503010849	3/8" X 1-1/2" BOLT	03	
04	0501010096	3/8" X 2" BOLT	01	
05	0503010025	3/8" SPRING WASHER	04	
06	0503010026	3/8" NUT	04	
07	0503031508	COVER GREEN BEAM SEED YELLOW	01	
08	0503010358	5/16" X 5/8" BOLT	04	
09	0501010694	8.5 X 18 X 1.5 FLAT WASHER	04	
10	0503010179	5/16" ZN SPRING WASHER	04	
11	0503010337	5/16" NUT	04	




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	97	01
02	0501052538	DEPTH BAND WITH ARMS	102	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	104	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	105	01
07	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	98	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	100	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	101	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	SCREWEW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL BOX	99	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	COVER DEPTH		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL BOX	99	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0511015976	FLAT WASHER		01
05	0503010257	1/8" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503010071	3/16" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	103	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	103	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01



Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01



Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

