

ROW CROP PLANTERS

**COP TRIO 650 - FRAME 8450 - CSU -
ENCAPSULATED (UP TO 03/2022)**

Code: 0501092905
Series: S-0419
Revision: 00
Date Revision: FEVEREIRO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111460052	COP TRIO 650 8450/17E500 ESPECIAL S-0419

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909095563	ASSY FRAME	1
0521056441	FRAME WITH ARTICULATION 8450	2
0909098865	HEADER ASSY ASSEMBLY	3
0511057817	SUPPORT HOSE	4
0521045756	HYDRAULIC CYLINDER	5
0511057653	HYDRAULIC CYLINDER	6
0501053835	FEMALE QUICK COUPLER	7
0521050573	EXTENSOR 3RD POINT	8
0521050681	LATERAL EXTENSOR 1250/480	9
0521050196	TURNBUCKLE SIDE 1125/480	10
0521050067	SIDE EXTENSOR 1525/480	11
0511055096	TRACTOR HITCH	12
0511053179	TRACTOR COUPLING SHAFT	13
0521050574	EXTENSOR	14
0521057452	ASSY INTERMEDIATE HEADER FIXATION SUPPORT	15
0501053834	MALE QUICK COUPLER	16
0521056088	WHEEL ASSY RIGHT FIXING EXTENSOR	17
0521056089	WHEEL ASSY LEFT FIXING EXTENSOR	18
0521056090	RIGHT WHEEL ASSY	19
0521056091	LEFT WHEEL ASSY	20
0521057820	WHEEL ASSEMBLY WITHOUT TRANSMISSION	21
0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH TRANSMISSION	22
0503063073	EE WHEEL WITH TIRE 7.00 X 16 14L ASSEMBLY	23
0521056100	WHEEL BOX ASSY WITH TRANSMISSION	24
0521056160	SIDE TRANSMISSION CURRENT STRETCHER	25
0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	26
0521056300	MOUNTED LEFT STRETCHER	27
0521055238	BEARING TENSIONER CHAIN	28
0521056095	ARTICULATED BEARING WHEELED WITHOUT LUBRICATION	29
0501058239	WHEEL CHAIN TENSIONER BEARING	30
0521056299	MOUNTED RIGHT STRETCHER	31
0521057818	WHEEL WITH TIRE 7.00 X 16 14L ASSY WITHOUT TRANSMISSION	32
0521057819	ASSY WHEEL BOX WITHOUT TRANSMISSION	33
0521057817	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	34
0521056119	SQUARE AXIS ASSEMBLY 730	35
0501056271	GEARBOX CLOSED BEARING	36
0501056444	BEARING WITH ROLLING	37
0501053788	3/4 SQUARE AXLE FASTENER	38
0521057032	MOTOR AXLE ASSEMBLY 8450	39
0521056085	PLATE BEARING ASSY	40
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	41
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	42
0511051434	TRANSMISSION ACTUATOR	43
0521056120	HEX AXLE ASSEMBLY 8450	44
0521056103	BEARING WITH GEAR 20Z HEX SHAFT 3/4	45
0521056144	INTERMEDIATE SEED TRANSMISSION	46
0521055498	SEED TRANSMISSION DOUBLE BEARING	47
0521056116	SILO FERTILIZER ASSY 8450	48
0521056141	SILO SUPPORT RIGHT FERTILIZER 8450	49
0521056117	CENTRAL SUPPORT SILO FERTILIZER	50
0521056140	SUPPORT SILO LEFT FERTILIZER 8450	51
0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	52



MARCHESAN

INDEX


0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	53
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	54
0521054516	PLATFORM ASSY 8450	55
0521057081	HANDRAIL SET	56
0521057059	CONJUNTO CSU	57
0521057149	ASSY RIGHT FIXING SUPPORT	58
0521057151	FIXING SUPPORT LEFT ASSY	59
0521050252	ASSEMBLY CSU C3 3BOXES 7B WITH 18 C	60
0511057690	3" ARTICULATED SEED CONDUCTOR	61
0511053356	ASSY LADDER	62
0511058191	REST ASSY	63
0511057803	ASSY PORT MANUAL INSTRUCCION	64
0521057103	SET LABEL ADHESIVE	65
0521057000	RIGHT GEAR BOX ASSY	66
0521056999	LEFT GEAR BOX ASSY	67
0501048790	AXLE WITH RING	68
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	69
0501056443	GEAR HOUSING BEARING	70
0511059266	CLOSED BEARING	71
0501054655	CHAIN TENSIONER ASSY	72
0511059261	CHAIN TENSIONER	73
0521056118	TRANSMISSION ASSY	74
0521056135	BEARING GEAR WITH DOUBLE	75
0521055217	LOWER CURRENT STRETCH	76
0521056134	STRETCHER FERTILIZER CURRENT 17Z	77
0521054446	LOWER CURRENT STRETCHER 21Z	78
0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	79
0511052333	ASSEMBLY SUPPORT LEFT FIXER CHANGE	80
0521057929	REAR HEADLIGHT ASSY 7655 A 8450	81
0521053672	LIGHTHOUSE ASSY	82
0521052792	MOUNTED REAR LIGHT	83
0511059494	TRACTION SPRING ASSY	84
0511056736	HOSE SUPPORT	85
0521057202	HYDRAULIC ASSY 8450	86
0521057854	SUPPORT VALVE BLOCK VACUOMETER ASSY 7655/8450	87
0521057886	HOSE CLAMP ASSEMBLY	88
0521057259	OIL CONDUCTOR FIXATION	89
0521057291	TRIPLE VALVE	90
0521057704	SLIDING SUPPORT HYDRAULIC HOSE	91
0521057310	HYDRAULIC ASSY MH2T 8450	92
0501054649	HBM SEQUENTIAL VALVE	93
0511058431	HYDRAULIC CYLINDER	94
0511025997	BOX WITH HYDRAULIC MARKER COMPONENTS	95
0501050633	ROW MARKER DISK ASSEMBLY	96
0521050693	ASSEMBLY SET HOSE CYLINDER FRONT HEAD	97
0521056993	ASSY WATER RESERVOIR	98
0521056994	ASSY TOOL CHEST	99
0909099225	SEED LINE/ASSY FERTILIZER	100
0521056877	SHORT ROW FRONT	101
0521056878	LONG FRONT ROW	102
0531052956	ASSEMBLY SEED LINE TRANSMISSION FIXING BEARING	103
0521056069	SEMI-ASSEMBLED SHORT FERTILIZER LINE	104
0521056070	DC 20 ASSY	105
0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	106
0521056066	SEMI-ASSEMBLED LONG FERTILIZER LINE	107



MARCHESAN


INDEX

0511059023	SEED SYSTEM ASSY	108
0501051094	ASSY SEED DISTRIBUTOR	109
0521054984	DEPTH/COMPACTOR SYSTEM - SPT	110
0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	111
0501052297	DEPTH WHEELS REGULATOR ASSY	112
0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	113
0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	114
0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	115
0521055033	SEMI-ASSEMBLED COMPACTOR BODY	116
0501052538	DEPTH BAND WITH ARMS	117
0521054990	LEFT COMPACTOR WHEEL	118
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	119
0521055017	RIGHT COMPACTOR WHEEL	120
0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	121
0521055065	ASSY DEPTH / COMPACTOR	122
0521055054	LEFT ARM WITH SLEEVE	123
0521055066	RIGHT ARM WITH GLOVE	124
0521055068	RAYED WHEEL CENTER CLOSED	125
0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	126
0521051447	FRONT ASSY ROW BEARING	127
0521056992	SCARIFIER ROD TIP 3 HOLES	128
0501110723	SCARIFIER ROD	129
0521050525	FIXER FERTILIZER CONDUCTOR	130
0503062066	DISC SET WITH CORN RING	131
0503062067	DISC SET / RING SOY 90F TITANIUM	132
0521056944	REAR FRAME	133
0521056945	REAR FRAME	134
0521056955	RIGHT DDD ASSY	135
0521056954	LEFT DDD ASSY	136
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	137
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	138
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	139
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	140
0521056582	DOSER	141
0521056639	SEED ROW TRANSMISSION	142
0531053040	ENCAPSULATED CHAIN GUIDE SEED ROW WITH CONDUCTOR	143
0521059683	ENCAPSULATED CHAIN SUPPORT GUIDE	144
0531052836	CSU SEED CONDUCTOR JOINT SUPPORT	145




Item	Code	Description	See page	QT
01	0521056441	FRAME WITH ARTICULATION 8450	2	01
02	0909098865	HEADER ASSY ASSEMBLY	3	01
03	0521056088	WHEEL ASSY RIGHT FIXING EXTENSOR	17	01
04	0521056089	WHEEL ASSY LEFT FIXING EXTENSOR	18	01
05	0521056090	RIGHT WHEEL ASSY	19	01
06	0521056091	LEFT WHEEL ASSY	20	01
07	0521057820	WHEEL ASSEMBLY WITHOUT TRANSMISSION	21	04
08	0503032624	SILO FERTILIZER GUTTER		09
09	0521056119	SQUARE AXIS ASSEMBLY 730	35	01
10	0521057032	MOTOR AXLE ASSEMBLY 8450	39	01
11	0521056120	HEX AXLE ASSEMBLY 8450	44	01
12	0521056116	SILO FERTILIZER ASSY 8450	48	01
13	0521054516	PLATFORM ASSY 8450	55	01
14	0521057081	HANDRAIL SET	56	01
15	0521057059	CONJUNTO CSU	57	01
16	0511053356	ASSY LADDER	62	01
17	0511058191	REST ASSY	63	01
18	0511057803	ASSY PORT MANUAL INSTRUCCION	64	01
19	0521057103	SET LABEL ADHESIVE	65	01
20	0521057000	RIGHT GEAR BOX ASSY	66	01
21	0521056999	LEFT GEAR BOX ASSY	67	01
22	0521056118	TRANSMISSION ASSY	74	01
23	0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	79	01
24	0511052333	ASSEMBLY SUPPORT LEFT FIXER CHANGE	80	01
25	0521057929	REAR HEADLIGHT ASSY 7655 A 8450	81	01
26	0511059494	TRACTION SPRING ASSY	84	10
27	0501047895	ROD STOP		10
28	0501047885	ROD STOP		08
29	0501047886	ROD STOP		08
30	0501047887	ROD STOP		08
31	0521013022	TRANSPORT LOCK		08

Item	Code	Description	See page	QT
32	0501068994	0.3" X 3.1" LOCK PIN		08
33	0503030168	CUPILLA		08
34	0511056736	HOSE SUPPORT	85	01
35	0521066304	HOSE GUIDE		01
36	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		02
37	0503013816	5/16" LOCKNUT		02
38	0541015451	FIXED KEY 2.3/8 X 2.3/4		01
39	0521057202	HYDRAULIC ASSY 8450	86	01
39.	0521057310	HYDRAULIC ASSY MH2T 8450	92	01
40	0511025997	BOX WITH HYDRAULIC MARKER COMPONENTS	95	01
41	0501050633	ROW MARKER DISK ASSEMBLY	96	02
42	0521050693	ASSEMBLY SET HOSE CYLINDER FRONT HEAD	97	01
43	0503014321	CABLE STEEL SHACKLE		02
44	0503014120	CHAIN		01
45	0521056993	ASSY WATER RESERVOIR	98	01
46	0521056994	ASSY TOOL CHEST	99	01
47	0521068982	KEY CASH DISC CUTTING		02
48	0503019262	SOAP DISH VACUUM		01
49	0503011750	AMENDMENT WITH LOCK		06
50	0503011751	REDUCTION		06
51	0503010780	N-2050 AMENDMENT		06
52	0503010002	1800 GREASE FITTING		01
53	0503010246	CLAMP		13
54	0909095571	SEED LINE/ASSY FERTILIZER		17




Item	Code	Description	See page	QT
01	0531060111	CENTRAL FRAME 8450		01
02	0531060163	RIGHT SIDE FRAME 8450		01
03	0531060164	LEFT SIDE FRAME 8450		01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0521066298	ARTICULATOR		04
06	0521063003	LOCK PIN		02
07	0571010969	LOCK SLEEVE FRAME		02
08	0503013627	1.1/2 SPRING WASHER		02
09	0501010110	1.1/2" NUT		02
10	0503011442	3/4" SPRING WASHER		20
11	0501010098	3/4" UNC BOLT		20
12	0571010094	SLEEVE FLANGE		12
13	0571013510	LOCK AXLE		04
14	0503030085	LOCK PIN		04
15	0571010095	FLAT WASHER		04
16	0521064285	LOCK LOWER FRAME		04
17	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		04
18	0591012305	CENTRAL GUTTER 24 X 50 X 1550		02
19	0591012310	SIDE GUTTER 24 X 50 X 2350		02
20	0503013029	3/8" X 3/4" BOLT		08
21	0501013518	FLAT WASHER		08
22	0503010025	3/8" SPRING WASHER		08
23	0503010026	3/8" NUT		08




Item	Code	Description	See page	7350	7655	8450
01	0521066289	FRONT HEADER 5750/6350/6850		001	000	000
01.	0521067406	DRAWBAR ASSY 7655		000	001	001
02	0531060569	INTERMEDIATE HEADER 6350/7350		001	000	000
02.	0531060568	INTERMEDIATE HEADER 7655/8450		000	001	001
03	0571019949	JUNCTION SHAFT		006	006	006
04	0503030119	LOCK PIN		010	010	010
05	0503010523	1/4" X 2" COTTERPIN		004	004	004
06	0511057817	SUPPORT HOSE	4	001	001	001
07	0521010779	31.75 X 95 COUPLING SHAFT		001	001	001
08	0521010581	0.9" X 4.9" COUPLING SHAFT		001	001	001
09	0503030085	LOCK PIN		006	006	006
10	0531016049	FLAT WASHER		002	002	002
11	0521045756	HYDRAULIC CYLINDER	5	001	001	001
12	0521050573	EXTENSOR 3RD POINT	8	001	001	001
13	0571019951	JUNCTION SHAFT		002	002	002
14	0521050681	LATERAL EXTENSOR 1250/480	9	002	000	000
14.	0521050196	TURNBUCKLE SIDE 1125/480	10	000	002	000
14..	0521050067	SIDE EXTENSOR 1525/480	11	000	000	002
15	0511055096	TRACTOR HITCH	12	001	001	001
16	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		001	001	001
17	0511053179	TRACTOR COUPLING SHAFT	13	001	001	001
18	0521010571	COUPLING SHAFT		004	004	004
19	0521018532	1.4" X 12" COUPLING SHAFT		001	001	001
20	0571019950	COUPLING SHAFT		002	002	002
21	0521050574	EXTENSOR	14	002	002	002
22	0521057452	ASSY INTERMEDIATE HEADER FIXATION SUPPORT	15	004	004	004
23	0521050693	ASSEMBLY SET HOSE CYLINDER FRONT HEAD	97	001	001	001
23A	0521050692	HOSE KIT CYLINDER HEAD FRONT		001	001	001
23AA	0521052309	HOSE 1/2 X 4500 TM-TM GREEN / BLUE		001	001	001
23AAA	0501081929	HOSE 1/2 X 4500 TM-TM		001	001	001
23AAB	0503034497	HYDRAULIC HOSE GRIP (GREEN)		001	001	001


Item	Code	Description	See page	7350	7655	8450
23AAC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		001	001	001
23AAD	0503018952	PLASTIC BOLT		006	006	006
23B	0521052310	HOSE 1/2 X 4500 TM-TM GREEN / RED		001	001	001
23BA	0501081929	HOSE 1/2 X 4500 TM-TM		001	001	001
23BB	0503034497	HYDRAULIC HOSE GRIP (GREEN)		001	001	001
23BC	0503034495	HYDRAULIC HOSE GRIP (RED)		001	001	001
23BD	0503018952	PLASTIC BOLT		006	006	006
23C	0501053834	MALE QUICK COUPLER	16	004	004	004




Item	Code	Description	See page	QT
01	0521066302	HOSE HOLDER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0511057653	HYDRAULIC CYLINDER	6	01
02	0501053835	FEMALE QUICK COUPLER	7	02




Item	Code	Description	See page	QT
01	0521066550	CASE		01
02	0521066551	EXTENSION DRAWBAR		01
03	0503010002	1800 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010669	EMBOLUS 63.50 X 40 USAP		01
06	0503018005	RING		01
07	0503010558	7/8" NUT		01
08	0502010471	MOBILE COVER		01
09	0503011058	8-330 BACK-UP RING		01
10	0571019866	RING SUPPORT		01
11	0503010163	D-1500 SCRAPER RING		01
12	0503018004	RING		01
13	0503010161	2-330 N 3006 9B O'RING		01
14	0503018003	GASKET		01
15	0503010605	O'RING		01
16	0581010652	JIC ADAPTER		01




Item	Code	Description	See page	QT
01	0503011883	QUICK CONNECTION COVER		01
02	0503011628	FEMALE QUICK COUPLER		01




Item	Code	Description	See page	QT
01	0511061880	SIDE RIGHT RATCHET		01
02	0531010264	SIDE RATCHET		01
03	0511061881	RATCHET FOLLOWER		01
04	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
05	0503011179	3/8" X 2-1/4" BOLT		05
06	0503011443	3/8" SPRING WASHER		05
07	0503010026	3/8" NUT		05
08	0503010002	1800 GREASE FITTING		02
09	0503030012	HAIR PIN		01
10	0502012783	STABILIZER BODY GREATER		01
11	0521067623	FUSE 713 EXTENSION RIGHT 3RD POINT		01
12	0521067622	FUSE 470 EXTENSION LEFT 3RD POINT		01




Item	Code	Description	See page	QT
01	0521065193	TURNBUCLE AXLE		01
02	0521067661	1250 SIDE EXTENSION FIXED TIP		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0521067393	EXTERNAL SIDE EAR		01
06	0571019949	JUNCTION SHAFT		01
07	0503030119	LOCK PIN		01
08	0503010002	1800 GREASE FITTING		03




Item	Code	Description	See page	QT
01	0521065193	TURNBUCKLE AXLE		01
02	0521067451	FIXED TIP 1125 SIDE EXTENSION 7350		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0521067393	EXTERNAL SIDE EAR		01
06	0571019949	JUNCTION SHAFT		01
07	0503030119	LOCK PIN		01
08	0503010002	1800 GREASE FITTING		03




Item	Code	Description	See page	QT
01	0521065193	TURNBUCLE AXLE		01
02	0521067391	TIP FIXED 1525 EXTENSION SIDE 8450		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0521067393	EXTERNAL SIDE EAR		01
06	0571019949	JUNCTION SHAFT		01
07	0503030119	LOCK PIN		01
08	0503010002	1800 GREASE FITTING		03




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	COMPRESSION SPRING LEFT		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HAIR PIN		01




Item	Code	Description	See page	QT
01	0521066300	RIGHT TURNBUCKLE		01
02	0503010002	1800 GREASE FITTING		02
03	0521066301	LEFT TURNBUCKLE		01
04	0541018672	COUNTERNUT		01
05	0502011195	ADJUSTMENT NUT BODY		01



Item	Code	Description	See page	QT
01	0521067716	FIXER TUBE		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0503010152	3/4" SELF LOCKING NUT		04
05	0501010322	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521066480	RH WHEELS SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 22 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	25	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	26	01
15	0501047888	ROD STOP		02
16	0511064744	WHEEL FORK		01
17	0531016051	CARRY-WHEEL CHAIN PROTECTION CAP		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8" SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" COTTERPIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056299	MOUNTED RIGHT STRETCHER	31	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8" NUT		02

Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 29 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TIGHTENER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	WHEEL CHAIN TENSIONER BEARING	30	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01



Item	Code	Description	See page	QT
01	0521066479	RH WHEELS SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 22 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	25	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	26	01
15	0501047888	ROD STOP		01
16	0511065842	LEFT WHEEL FORK		01
17	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8" SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" COTTERPIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056300	MOUNTED LEFT STRETCHER	27	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8" NUT		02

Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 29 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TIGHTENER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	WHEEL CHAIN TENSIONER BEARING	30	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 22 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	25	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	26	01
15	0501047888	ROD STOP		01
16	0511064744	WHEEL FORK		01
17	0531016051	CARRY-WHEEL CHAIN PROTECTION CAP		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8" SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" COTTERPIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056299	MOUNTED RIGHT STRETCHER	31	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8" NUT		02

Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 29 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TIGHTENER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	WHEEL CHAIN TENSIONER BEARING	30	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01


LEFT WHEEL ASSY

0521056091




Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4\" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8\" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 22 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8\" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	25	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	26	01
15	0501047888	ROD STOP		01
16	0511065842	LEFT WHEEL FORK		01
17	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8\" SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2\" SPRING WASHER		14
22	0521010546	1.2\" X 5.7\" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4\" X 2\" COTTERPIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056300	MOUNTED LEFT STRETCHER	27	01
27	0503031103	0.9\" X 4.1\" X 0.1\" TRACTION SPRING		01
28	0501013491	5/8\" TENSIONER SPRING		01
29	0503010013	5/8\" NUT		02


Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 29 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TIGHTENER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	WHEEL CHAIN TENSIONER BEARING	30	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0531060795	WHEEL SUPPORT		01
02	0503010019	1/2" SPRING WASHER		13
03	0503013232	1/2" BOLT		08
04	0561013021	BEARING INNER LOK		02
05	0561013022	BEARING EXTERNAL LOCK		02
06	0503010398	501082 CLAMPING RING (FOR AXLE)		02
07	0561013020	KM 12 NUT		02
08	0503010408	7/8" SPRING WASHER		02
09	0503012419	7/8" X 2-3/4" BOLT		02
10	0501047888	ROD STOP		02
11	0521057818	WHEEL WITH TIRE 7.00 X 16 14L ASSY WITHOUT TRANSMISSION	32	01
12	0503016485	BOLT 3/4		04
13	0503010152	3/4" SELF LOCKING NUT		04
14	0501010322	FLAT WASHER		04
15	0503017857	BOLT 5/8 UNF 4		04
16	0503010811	5/8" UNF SELF ADJUSTING NUT		04
17	0501012140	FLAT WASHER		04
18	0503010834	1/2 X 1 BOLT		05
19	0501017779	32 X 60 X 4.75 FLAT WASHER		02
20	0503010523	1/4" X 2" COTTERPIN		01
21	0521010546	1.2" X 5.7" COUPLING SHAFT		01
22	0531060798	CENTRAL WHEEL FORK WITHOUT TRANSMISSION		01
23	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
24	0521057817	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	34	01
25	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
26	0591010098	ARTICULATED BEARING WHEELED WITHOUT TRANSMISSION WITHOUT LUBRICATION		02
27	0502012720	WHEEL SUPPORT FIXER		01




Item	Code	Description	See page	QT
01	0503063073	EE WHEEL WITH TIRE 7.00 X 16 14L ASSEMBLY	23	01
02	0521056100	WHEEL BOX ASSY WITH TRANSMISSION	24	01




Item	Code	Description	See page	QT
01	0503016518	RUEDA		01
02	0503010033	7.50 X 16 INNER TIRE		01
03	0503019458	TIRE 7.00X16 14PR		01




Item	Code	Description	See page	QT
01	0503010804	00547-B SEAL		02
02	0503010330	KM 9 LOCKNUT		01
03	0511015949	LOCK NUT		01
04	0503010329	LOCK WASHER		01
05	0503010002	1800 GREASE FITTING		01
06	0501110721	WHEEL HUB WITH SCREW / NUTS		01
06A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
06B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
06C	0503016516	5/8 UNF CONIC NUT		06
07	0503019364	BEARING 25590/25523		02
08	0521018363	00547-B SEAL		01
09	0511062015	14Z GEAR WITH FLANGE		01
10	0503010421	5/16" X 1-1/2" BOLT		06
11	0503011444	SPRING WASHER		06




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		01
02	0591010747	CURRENT STRETCHER AXIS		01
03	0503010302	501019 SEAL RING		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0511017302	FLAT WASHER		01
07	0541016454	PULLEY		01




Item	Code	Description	See page	QT
01	0531060012	CASE 101.6 X 324.5 WITHOUT LUBRICATION		01
02	0541017674	TURNBUCLE BODY		01
03	0511064408	FORK		01
04	0503011094	3/8" X 2" BOLT		01
05	0503010025	3/8" SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581010302	RING OF SUPPORT		01
08	0502012822	101.60 END CAP		01
09	0503011061	8-342 BACK-UP RING		02
10	0503010338	2-342 N 3006-9B O'RING		02
11	0503017936	RING		01
12	0503017938	RING GUIDE		01
13	0503017937	GASKET		01
14	0503010761	D-1750 SCRAPER RING		01
15	0581010837	PISTON		01
16	0503010817	1.1/4" SELF LOCKING NUT		01
17	0503015633	SELEMASTER SEALING		01
18	0503018029	2-217 O'RING		01
19	0503018045	2-130 (AGEL) O'RING		04
20	0503030387	PLUG		02
21	0511033019	CYLINDER REPAIR KIT 44.45 X 101.60		01




Item	Code	Description	See page	QT
01	0503010027	5/8" SPRING WASHER		01
02	0503010013	5/8" NUT		01
03	0521055238	BEARING TENSIONER CHAIN	28	01
04	0551018241	SLEEVE 16,30 X 30 X 8		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0551018252	CHAIN TIGHTENER AXLE		01
08	0511017302	FLAT WASHER		01
09	0503010232	5/8" X 1.3/4" BOLT		01
10	0531016916	SLEEVE BEARING SUPPORT		01
11	0541012098	LEFT CHAIN TIGHTENER LARGER SUPPORT		01




Item	Code	Description	See page	QT
01	0503019355	BEARING 6202 2RS1		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0591010097	ARTICULATED BEARING WHEELED WITHOUT LUBRICATION		01
02	0503019409	SELF LUBRICATING BUSHING		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0503010027	5/8" SPRING WASHER		01
02	0503010013	5/8" NUT		01
03	0521055238	BEARING TENSIONER CHAIN	28	01
04	0551018241	SLEEVE 16,30 X 30 X 8		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0551018252	CHAIN TIGHTENER AXLE		01
08	0511017302	FLAT WASHER		01
09	0503010232	5/8" X 1.3/4" BOLT		01
10	0531016916	SLEEVE BEARING SUPPORT		01
11	0531018654	CHAIN TIGHTENER SUPPORT		01




Item	Code	Description	See page	QT
01	0503063073	EE WHEEL WITH TIRE 7.00 X 16 14L ASSEMBLY	23	01
02	0521057819	ASSY WHEEL BOX WITHOUT TRANSMISSION	33	01




Item	Code	Description	See page	QT
01	0503010804	00547-B SEAL		02
02	0503010330	KM 9 LOCKNUT		01
03	0511015949	LOCK NUT		01
04	0503010329	LOCK WASHER		01
05	0503010002	1800 GREASE FITTING		01
06	0501110721	WHEEL HUB WITH SCREW / NUTS		01
06A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
06B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
06C	0503016516	5/8 UNF CONIC NUT		06
07	0503019364	BEARING 25590/25523		02
08	0591013435	TRANSMISSION WHEEL AXLE		01




Item	Code	Description	See page	QT
01	0531060797	CYLINDER CASE		01
02	0541017674	TURNBUCLE BODY		01
03	0511064408	FORK		01
04	0503011094	3/8" X 2" BOLT		01
05	0503010025	3/8" SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581010302	RING OF SUPPORT		01
08	0591013736	MOBILE COVER		01
09	0503011061	8-342 BACK-UP RING		02
10	0503010338	2-342 N 3006-9B O'RING		02
11	0503017936	RING		01
12	0503017938	RING GUIDE		01
13	0503017937	GASKET		01
14	0503010761	D-1750 SCRAPER RING		01
15	0581010837	PISTON		01
16	0503010817	1.1/4" SELF LOCKING NUT		01
17	0503015633	SELEMASTER SEALING		01
18	0503018029	2-217 O'RING		01
19	0503018045	2-130 (AGEL) O'RING		04
20	0503030387	PLUG		02
21	0511033019	CYLINDER REPAIR KIT 44.45 X 101.60		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	36	02
02	0501056444	BEARING WITH ROLLING	37	02
03	0503011953	5/16" X 1" BOLT		08
04	0501010694	FLAT WASHER		08
05	0503010179	LOCK WASHER		08
06	0503010337	5/16" NUT		08
07	0511014218	3/4" X 28.7" SQUARE SHAFT		02
08	0501053788	3/4 SQUARE AXLE FASTENER	38	04
09	0503030275	AGRICULTURAL BEARING		04
10	0521061852	LEVER RATCHET		02
11	0521061847	AXLE ADRIVING ASSY		02
12	0521061849	DISASSEMBLE LEVER		02
13	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
14	0501010984	FLAT WASHER		08
15	0503010140	1/8" X 3/4" COTTERPIN		04
16	0571012792	LOWER LEVER		02
17	0503011082	C1/2" X 1.3/4" SCREW		02
18	0511017302	FLAT WASHER		04
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2" NUT		02
21	0561016797	SLEEVE UNION LEVER		02
22	0503010026	3/8" NUT		02
23	0503010025	3/8" SPRING WASHER		02
24	0503010849	3/8" X 1-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0503011082	C1/2" X 1.3/4" SCREW		08
02	0511017302	FLAT WASHER		16
03	0503010019	1/2" SPRING WASHER		08
04	0503010060	1/2" NUT		08
05	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	41	01
06	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	42	01
07	0511051434	TRANSMISSION ACTUATOR	43	04
08	0591010711	MOTOR AXLE BEARING SUPPORT		04
09	0521056085	PLATE BEARING ASSY	40	08
10	0581013152	MOTOR SHAFT		02




Item	Code	Description	See page	QT
01	0503019402	BEARING B207-22 V22 FRM		01
02	0503019403	PFL 207 FRM BEARING PLATE		02
03	0503010026	3/8" NUT		02
04	0503010025	3/8" SPRING WASHER		02
05	0501011643	3/8 X 1"BOLT		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0521056103	BEARING WITH GEAR 20Z HEX SHAFT 3/4	45	02
02	0591010724	HEX AXLE 3/4 X 2277		01
03	0591010722	HEX AXLE 3/4 X 2397		01
04	0591010721	HEX AXLE 3/4 X 1250		01
05	0591010723	HEX AXLE 3/4 X 1770		01
06	0521056144	INTERMEDIATE SEED TRANSMISSION	46	02
07	0511063123	BUSHING WITH NUT		08
08	0501018535	1/2 X 1 BOLT		08
09	0581015056	SLEEVE		08




Item	Code	Description	See page	QT
01	0521055498	SEED TRANSMISSION DOUBLE BEARING	47	01
02	0531060014	GEAR 20Z X 48.50 HEX HOLE 20		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02
06	0501010694	FLAT WASHER		04
07	0503018441	5/16" X 1-1/4" BOLT		02




Item	Code	Description	See page	QT
01	0503010243	CLAMP		02
02	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
03	0503012880	1/4" UNC SELF ADJUSTING NUT		02
04	0503063012	SEED TRANSMISSION SHAFT HEX 3/4		01
05	0503034773	HOSE 1.1/2 X 1.1/2 X 120		01




Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012858	502075 CLAMPING RING (FOR HOLE)		01
03	0503019373	6006 2RS1 NATIONAL BEARING		02




Item	Code	Description	See page	QT
01	0521056141	SILO SUPPORT RIGHT FERTILIZER 8450	49	01
02	0521056117	CENTRAL SUPPORT SILO FERTILIZER	50	01
03	0521056140	SUPPORT SILO LEFT FERTILIZER 8450	51	01
04	0571019051	FIXER BOX WASHER		32
05	0503013751	3/8 UNC X 1.1/4 BOLT		32
06	0503012535	3/8" SPRING WASHER		32
07	0503012531	3/8" INOX NUT		32
08	0501010984	FLAT WASHER		32
09	0503010026	3/8" NUT		16
10	0503010849	3/8" X 1-1/2" BOLT		16
11	0503010025	3/8" SPRING WASHER		16
12	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	52	02
13	0503034396	FERTILIZER SIDE COVER		17
14	0503010362	1/8" X 1.1/4" COTTERPIN		17
15	0503011957	NYLON LUG		02
16	0503010371	5/16" X 1" BOLT		04
17	0503010179	LOCK WASHER		04
18	0503010337	5/16" NUT		04
19	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		02
20	0503062362	FERTILIZER BOX		02
21	0521010572	0.9" X 2.9" COUPLING SHAFT		02
22	0503030085	LOCK PIN		02




Item	Code	Description	See page	QT
01	0521067403	RIGHT SUPPORT SILO FERTILIZER 8450		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	53	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	54	02
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503010025	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0501056271	GEARBOX CLOSED BEARING	36	01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	LOCK WASHER		02
11	0503010337	5/16" NUT		02
12	0591010692	SQUARE SHAFT 3/4 X 2297		01
13	0571019828	LOCK AXLE		01
14	0503010365	NUT		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521018630	1.4" X SQUARE 0.8" WASHER		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	3/4 SQUARE AXLE FASTENER	38	01
20	0503030275	AGRICULTURAL BEARING		05
21	1902010685	18Z CONICAL GEAR		05
22	0511062163	FERTILIZER BEAM LOWER COVER		01
23	0501010984	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521067404	CENTER FERTILIZER SILO SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	53	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	54	04
04	0501010942	3/8" X 1-1/4" BOLT		32
05	0503010025	3/8" SPRING WASHER		32
06	0503010026	3/8" NUT		32
07	0571019828	LOCK AXLE		02
08	0503010365	NUT		04
09	0503013816	5/16" LOCKNUT		04
10	0581016965	3/4" X 1070 SQUARE SHAFT 19 E 450		01
11	0581016966	AXIS Q 3/4 X 1371		01
12	1902010685	18Z CONICAL GEAR		07
13	0503030275	AGRICULTURAL BEARING		07
14	0511062163	FERTILIZER BEAM LOWER COVER		01
15	0501010984	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521067402	LH FERTILIZER BOX SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	53	02
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	54	03
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503010025	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0501056271	GEARBOX CLOSED BEARING	36	01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	LOCK WASHER		02
11	0503010337	5/16" NUT		02
12	0591010692	SQUARE SHAFT 3/4 X 2297		01
13	0571019828	LOCK AXLE		01
14	0503010365	NUT		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521018630	1.4" X SQUARE 0.8" WASHER		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	3/4 SQUARE AXLE FASTENER	38	01
20	0503030275	AGRICULTURAL BEARING		05
21	1902010685	18Z CONICAL GEAR		05
22	0511062163	FERTILIZER BEAM LOWER COVER		01
23	0501010984	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0503030331	1.2" X 1.2" X 12.2" HOSE		01
02	0503010243	CLAMP		02
03	0503062755	TRANSMISSION AXLE		01
04	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
05	0503012880	1/4" UNC SELF ADJUSTING NUT		02







Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0521067102	ARTICULATION CENTRAL PLATFORM		04
02	0531060020	CENTRAL PLATFORM 8450		01
03	0503011336	1/2" HEX SELF ADJUSTING NUT		06
04	0503010741	1/2" X 2-3/4" BOLT		06
05	0531060021	LEFT PLATFORM 8450		01
06	0521067104	LEFT SIDE ARTICULATION PLATFORM		01
07	0531060022	RIGHT PLATFORM 8450		01
08	0521067103	RIGHT SIDE ARTICULATION PLATFORM		01
09	0581012193	PLATFORM AMENDMENT PROTECTION		02
10	0551019115	LOCKING PLATFORM FIXATION		03
11	0571019831	X 0.2" SLEEVE		03
12	0501010096	3/8" X 2" BOLT		03
13	0501010984	FLAT WASHER		31
14	0503013357	3/8" SELF-ADJUSTING NUT		03
15	0503011333	COVER FIXER		03
16	0503010274	5/32"X 2" COTTERPIN		03
17	1902012740	PLATFORM RIGHT FIXER SUPPORT		02
18	1902012739	PLATFORM LEFT FIXER SUPPORT		01
19	0503010849	3/8" X 1-1/2" BOLT		12
20	0503010025	3/8" SPRING WASHER		16
21	0503010026	3/8" NUT		16
22	0501010942	3/8" X 1-1/4" BOLT		04
23	0503010019	1/2" SPRING WASHER		02
24	0503010060	1/2" NUT		02
25	0503011082	C1/2" X 1.3/4" SCREW		02




Item	Code	Description	See page	QT
001	0531060453	HANDRAIL		01
002	0503011082	C1/2" X 1.3/4" SCREW		08
003	0503010019	1/2" SPRING WASHER		12
004	0503010060	1/2" NUT		12
005	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
006	0531060454	HANDRAIL		02
007	0503034094	22 TWISTED CHAIN		02
008	0551019884	45 X 50 X 3/8 FASTENER		04
009	0571017991	CHAIN FIXER HANDRAIL		04
010	0503013357	3/8" SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
001	0521057149	ASSY RIGHT FIXING SUPPORT	58	03
002	0521057151	FIXING SUPPORT LEFT ASSY	59	03
003	0521050252	ASSEMBLY CSU C3 3BOXES 7B WITH 18 C	60	01




Item	Code	Description	See page	QT
01	0531060480	RIGHT FIXING SUPPORT CSU		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		04
07	0503010025	3/8" SPRING WASHER		04
08	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0531060485	FIXING SUPPORT LEFT CSU		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		04
07	0503010025	3/8" SPRING WASHER		04
08	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		03
02	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		03
03	0521063401	SEED BOX ONLY FIXING LOCK		06
04	0501010984	FLAT WASHER		06
05	0503010025	3/8" SPRING WASHER		90
06	0503010026	3/8" NUT		90
07	0511057690	3" ARTICULATED SEED CONDUCTOR	61	18
08	0571015773	SUPPORT SEED		03
09	0501011643	3/8 X 1"BOLT		12
10	0501010942	3/8" X 1-1/4" BOLT		72




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER		02
09	0503010179	LOCK WASHER		02
10	0503010337	5/16" NUT		02
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		04
02	0503010237	3/8" X 1" BOLT		08
03	0503010025	3/8" SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0511069636	LADDER		02
06	0503011179	3/8" X 2-1/4" BOLT		04
07	0501010984	FLAT WASHER		04
08	0503013357	3/8" SELF-ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0502011530	SUPPORT		02
02	0502010175	HITCH CLAMP		02
03	0501011543	5/8" X 4" BOLT		04
04	0503012412	5/8 UNC SELF LOCKING NUT		04
05	0501069951	PLOUGH SUPPORT		04
06	0501011075	PIN		02
07	0503030012	HAIR PIN		02



Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER		01
06	0503010337	5/16" NUT		01



Item	Code	Description	See page	QT
001	0503034963	ADHESIVE LABEL		01
002	0503034967	ADHESIVE LABEL (190 X 720)		04
003	0503034983	LOGO TATU MARCHESAN ADHESIVE LABEL 190 X 613		04
004	0503034984	ADHESIVE LABEL (190 X 613)		04
005	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
006	0503031565	ADHESIVE LABEL CARE		02
007	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
008	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
009	0503032930	ADHESIVE LABEL DANGER		06
010	0503031425	ADHESIVE LABEL ATTENTION		02
011	0503031087	ADHESIVE LABEL		01
012	0503031942	ADHESIVE LABEL		01
013	0503031669	ADHESIVE LABEL		01
014	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
015	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
016	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
017	0503033422	ADHESIVE LABEL		02
018	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
019	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
020	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
021	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		02
022	0503034078	LIFTING POINTS DECAL		03
023	0503032979	ADHESIVE LABEL LETTERS A B C D		02
024	0503031428	READ MANUAL DECAL		01
025	0503034500	ADHESIVE LABEL		01
026	0521056998	ALUMINUM IDENTIFICATION LABEL WITH RIVET		01
026A	0503034003	SERIAL NUMBER TAG 61 X 118		01
026B	0503010001	3.2 X 5.5 RIVET		04




Item	Code	Description	See page	QT
001	0501048790	AXLE WITH RING	68	02
002	0551018209	DRIVING AXLE		01
003	0521018259	DRIVEN AXLE		01
004	0551018210	DRIVEN AXLE		01
005	0551018211	INTERM SHAFT		01
006	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	69	01
007	0503030303	SUPPORT WASHER		06
008	0501056443	GEAR HOUSING BEARING	70	02
009	0511059266	CLOSED BEARING	71	05
010	0503012389	1/2 BALL		04
011	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
012	0503010834	1/2 X 1 BOLT		04
013	0503010060	1/2" NUT		06
014	0503031805	11Z 1/2" GEAR		04
015	0503010302	501019 SEAL RING		04
016	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
017	0511067501	26Z GEAR		02
018	0521018630	1.4" X SQUARE 0.8" WASHER		05
019	0503010292	0.2" X 1.6" SPRING PIN		10
020	0501054655	CHAIN TENSIONER ASSY	72	02
021	0591010679	AGRICOLA BEARING SQUARE HOLE 19.4 / 19.6X26		01
022	0501010984	FLAT WASHER		01
023	0503010256	3/8" X 3/4" BOLT		01
024	0503012204	40-1 CHAIN X 82 LINK + RED		02
025	0503012713	40-1 CHAIN X 45 LINK + MEN		01
026	0511060396	DRIVE/DRIVEN AXLE CONE		04
027	0511061822	25Z P0.5" GEAR SQUARE HOL		01
028	0502011758	REAR TENSIONER LEVER		02
029	0531060029	LONGER CURRENT STRETCHER WITHOUT LUBRICATION		01
030	0503031367	SPRING		01
031	0503031366	RIGHT TWISTED SPRING RECAMBIO		01



**COP TRIO 650 - FRAME 8450 - CSU - ENCAPSULATED (UP TO
RIGHT GEAR BOX ASSY**


Page 66
0521057000

Item	Code	Description	See page	QT
032	0531060009	RIGHT EXCHANGE BODY WITHOUT LUBRICATION		01
033	0503019418	GLOVE		04
034	0503011034	RING		04
035	0531060025	MINOR CHAIN STRETCHER WITHOUT LUBRICATION		01
036	0511059261	CHAIN TENSIONER	73	01
037	0503014734	BOLT		02
038	0503010019	1/2" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0501048790	AXLE WITH RING	68	02
02	0551018209	DRIVING AXLE		01
03	0521018259	DRIVEN AXLE		01
04	0551018210	DRIVEN AXLE		01
05	0551018211	INTERM SHAFT		01
06	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	69	01
07	0503030303	SUPPORT WASHER		06
08	0501056443	GEAR HOUSING BEARING	70	02
09	0511059266	CLOSED BEARING	71	05
10	0503012389	1/2 BALL		04
11	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
12	0503010834	1/2 X 1 BOLT		04
13	0503010060	1/2" NUT		06
14	0503031805	11Z 1/2" GEAR		04
15	0503010302	501019 SEAL RING		04
16	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
17	0511067501	26Z GEAR		02
18	0521018630	1.4" X SQUARE 0.8" WASHER		05
19	0503010292	0.2" X 1.6" SPRING PIN		10
20	0501054655	CHAIN TENSIONER ASSY	72	02
21	0501010984	FLAT WASHER		01
22	0503010256	3/8" X 3/4" BOLT		01
23	0503012204	40-1 CHAIN X 82 LINK + RED		02
24	0503012713	40-1 CHAIN X 45 LINK + MEN		01
25	0511060396	DRIVE/DRIVEN AXLE CONE		04
26	0511061822	25Z P0.5" GEAR SQUARE HOL		01
27	0502011758	REAR TENSIONER LEVER		02
28	0531060029	LONGER CURRENT STRETCHER WITHOUT LUBRICATION		01
29	0503031367	SPRING		01
30	0503031366	RIGHT TWISTED SPRING RECAMBIO		01
31	0531060008	LEFT EXCHANGE BODY WITHOUT LUBRICATION		01


Item	Code	Description	See page	QT
32	0531060025	MINOR CHAIN STRETCHER WITHOUT LUBRICATION		01
33	0503019418	GLOVE		04
34	0503011034	RING		04
35	0511059261	CHAIN TENSIONER	73	01
36	0591010679	AGRICOLA BEARING SQUARE HOLE 19.4 / 19.6X26		01
37	0503014734	BOLT		02
38	0503010019	1/2" SPRING WASHER		02
39	0521060879	38Z GEAR		01
40	0511061759	22Z P12,70 FQ 3/4" GEAR		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	37	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	36	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503031805	1 1/2" GEAR		01
02	0511017302	FLAT WASHER		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0511017302	FLAT WASHER		06
02	0503010019	1/2" SPRING WASHER		02
03	0503010060	1/2" NUT		02
04	0561017281	ARTICULACION ARM		02
05	0521056135	BEARING GEAR WITH DOUBLE	75	02
06	0521055217	LOWER CURRENT STRETCH	76	04
07	0521056134	STRETCHER FERTILIZER CURRENT 17Z	77	02
08	0521054446	LOWER CURRENT STRETCHER 21Z	78	02
09	0571019829	LEVER FIXER		02
10	0503010237	3/8" X 1" BOLT		06
11	0503010025	3/8" SPRING WASHER		06
12	0503010026	3/8" NUT		06
13	0571019830	LEVER FIXER		02
14	0503011312	ROTATIVE CABLE		02
15	0503030093	TRACTION SPRING		02
16	0561017273	FIXER SPRING		02
17	0561017282	LOWER LEVER		02
18	0561016797	SLEEVE UNION LEVER		02
19	0591010705	ARTICULATION GLOVE		02
20	0503011082	C1/2" X 1.3/4" SCREW		02
21	0521010773	0.37" X 1.18" COUPLING SHAFT		02
22	0501010984	FLAT WASHER		06
23	0541014973	COUPLING SHAFT		02
24	0503010140	1/8" X 3/4" COTTERPIN		04
25	0503017874	BOLT 1/2 UNC		02
26	0503011336	1/2" HEX SELF ADJUSTING NUT		02
27	0503013065	40-1 X 159 CHAIN LINK + MENDING		02
28	0503016737	40-1 X 114 CHAIN LINK + REDUCION		02




Item	Code	Description	See page	QT
01	0503019356	BEARING 6005 2RS1		02
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0503012412	5/8 UNC SELF LOCKING NUT		01
04	0521061843	20Z DOBLE GEAR		01
05	0551019175	DOUBLE GEAR AXLE		01
06	0501010163	5/8" X 4-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503019355	BEARING 6202 2RS1		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0591010693	CURRENT DEVIATION GLOVE		01
08	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01




Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503019356	BEARING 6005 2RS1		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0501012140	FLAT WASHER		01
06	0581015136	40MM STRETCHING SHAFT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01
08	0501011541	5/8" X 3" BOLT		01




Item	Code	Description	See page	QT
01	0561019899	RIGHT SUPPORT FIXER RECAMBIO		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0503011082	C1/2" X 1.3/4" SCREW		02
05	0511017302	FLAT WASHER		04
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0561019898	LEFT SUPPORT FIXER RECAMBIO		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0503011082	C1/2" X 1.3/4" SCREW		02
05	0511017302	FLAT WASHER		04
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		18
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		03
04	0503012903	T-80M CRAMP NYLON		50
05	0521053672	LIGHTHOUSE ASSY	82	02
06	0521052792	MOUNTED REAR LIGHT	83	01
07	0503015907	MALE TERMINAL		02
08	0503015908	FEMALE TERMINAL		02
09	0503015906	TWO-WAY MALE CONNECTOR		01
10	0503015905	TWO-WAY FEMALE MALE CONNECTOR		01
11	0503015911	CABLE SEAL		04
12	3505151602	TUBE		01
13	0503017702	FIXER		03




Item	Code	Description	See page	QT
01	0581015856	REDLIGHT SUPPORT		01
02	0503018738	LIGHTHOUSE		01
03	0501010694	FLAT WASHER		02
04	0503010358	5/16" X 5/8" BOLT		02
05	0551019884	45 X 50 X 3/8 FASTENER		02
06	0503013357	3/8" SELF-ADJUSTING NUT		04
07	0503010337	5/16" NUT		02
08	0503010179	LOCK WASHER		02




Item	Code	Description	See page	QT
01	0503018738	LIGHTHOUSE		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	LOCK WASHER		04
08	0503010337	5/16" NUT		04



Item	Code	Description	See page	QT
01	0503013030	5/8" X 3.1/4" BOLT		02
02	0511050681	TRACTION SPRING		01
02A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
02B	0561016062	SPRING HITCH		02
03	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0521057854	SUPPORT VALVE BLOCK VACUOMETER ASSY 7655/8450	87	01
02	0521057886	HOSE CLAMP ASSEMBLY	88	02
03	0581010324	HOSE PROTECTOR		01
04	0503010358	5/16" X 5/8" BOLT		04
05	0503010179	LOCK WASHER		04
06	0503010337	5/16" NUT		04
07	0503013493	T CONNECTION MALE		02
08	0521057259	OIL CONDUCTOR FIXATION	89	08
09	0531060539	OIL CONDUCTOR 1465 WHEEL CYLINDER 8450		04
10	0531060516	OIL DUCT 1200 7655		02
11	0531060515	OIL DUCT 3 OUTPUT 655 MM 7655		02
12	0531060545	OIL DUCT 275 6350		02
13	0521057704	SLIDING SUPPORT HYDRAULIC HOSE	91	04
14	0581010091	SPRING PROTECTION PLASTIC HOSE		01
15	0581012991	SPRING PROTECTION PLASTIC HOSE		01
16	0581010090	SPRING PROTECTION PLASTIC HOSE		02
17	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		01
18	0501053834	MALE QUICK COUPLER	16	02
19	0521057304	HOSE KIT HYDRAULIC SYSTEM		01
19A	0501082269	HOSE 1/2 X 300 TR-TR		04
19B	0501080087	1/2" X 450 HOSE		03
19C	0501080096	1/2 X 500 TC-TC HOSE		12
19D	0501081834	1/2 X 1500 TR-TC HOSE		02
19E	0501080058	HOSE 1/2 X 1400 TR-TC		01
19F	0501080093	1/2 X 1300 HOSE TR-TC		01
19G	0501080218	1/2 X 750 HOSE		02
19H	0501081235	1/2 X 650 TR- TC HOSE		02
19I	0501080024	1/2" X 700 TR-TR HOSE		04
20	0521057244	HOSE 1/2 X 4900 TC-TM BLACK / BLUE		01
20A	0501082260	HOSE 1/2 X 4900 TC-TM		01
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01


Item	Code	Description	See page	QT
20C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
20D	0503018952	PLASTIC BOLT		06
21	0521057243	1/2 X 4350 TC-TM HOSE BLACK / RED		01
21A	0501082259	HOSE 1/2 X 4350 TC-TM		01
21B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
21C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
21D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0503062960	COMMAND BLOCK		01
02	0591013473	VACUOMETER GUIDE SCREW BOLT		02
03	0501010984	FLAT WASHER		02
04	0503010026	3/8" NUT		02
05	0503010025	3/8" SPRING WASHER		02
06	0502011170	FIXER		02
07	0503010384	1/2" X 5" BOLT		04
08	0511017302	FLAT WASHER		08
09	0503010589	1/2" UNC SELF ADJUSTING NUT		04
10	0503010179	LOCK WASHER		04
11	0503015114	BOLT		04
12	0531060808	SUPPORT FIXING VALVE TRIPLE BLOCK		01
13	0521057291	TRIPLE VALVE	90	01
14	0591014208	GLOVE SUPPORT HYDRAULIC BLOCK		02




Item	Code	Description	See page	QT
01	0502010477	HOSE CLAMP		02
02	0502012702	BODY SUPPORT CLAMP		01
03	0503010718	3/8" X 3-1/2" BOLT		01
04	0503010026	3/8" NUT		01
05	0503010025	3/8" SPRING WASHER		01
06	0501010984	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0591012302	LOWER CLAMP FIXING OIL CONDUCTOR		01
02	0591012301	TOP CLAMP FIXING OIL CONDUCTOR		01
03	0503010025	3/8" SPRING WASHER		03
04	0503010026	3/8" NUT		03
05	0561017277	OIL CONDUCTOR FIXER PLATE		01
06	0521010718	5/8" U BOLT		01
07	0501012140	FLAT WASHER		02
08	0503010027	5/8" SPRING WASHER		02
09	0503010013	5/8" NUT		02
10	0501011755	3/8" X 3" BOLT		02
11	0502010477	HOSE CLAMP		02
12	0501010096	3/8" X 2" BOLT		01



Item	Code	Description	See page	QT
01	0503019571	DIVIDER VALVE TRI-DIREC PLD20 CASAPPA BRP00095		01
02	0501010590	NIPPLE		03
03	0503010026	3/8" NUT		04
04	0501010984	FLAT WASHER		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0511018014	7/8"NF X 1.1/16 UN NIPPLE		01
08	0503010045	O'RING		03
09	0503011109	2-119 N 3006-9B O'RING		01



Item	Code	Description	See page	QT
01	0591012962	SLIDING SUPPORT BODY HYDRAULIC HOSE		01
02	0591012961	GLOVE 16,30 X 30 X 230		01
03	0591012963	AXLE FIXING HOSE GLOVE		01
04	0503010013	5/8" NUT		02
05	0501012140	FLAT WASHER		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010071	3/16" X 1" COTTERPIN		02




Item	Code	Description	See page	QT
001	0501054649	HBM SEQUENTIAL VALVE	93	01
002	0591012041	LINE MARKER VALVE SUPPORT		01
003	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
004	0503010025	3/8" SPRING WASHER		02
005	0541012165	3/4" NIPPLE		04
006	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		04
007	0511058431	HYDRAULIC CYLINDER	94	01
008	0503010002	1800 GREASE FITTING		04
009	0501010617	3/4" NIPPLE		04
010	0551016274	HYDRAULIC CYLINDER ADAPTER		02
011	0501068994	0.3" X 3.1" LOCK PIN		02
012	0511015573	2.07" X 1.6" TRANSPORT LOCK		02
013	0503030168	CUPILLA		02
014	0581011173	SPRING PROTECTION PLASTIC HOSE		02
015	0501053834	MALE QUICK COUPLER	16	02
016	0502012702	BODY SUPPORT CLAMP		02
017	0503010677	7/16" X 2-3/4" BOLT		02
018	0503010180	7/16" SPRING WASHER		02
019	0503010244	7/16" NUT		02
020	0521067396	CONDUCTOR OIL 1250 HYDRAULIC MARKER 8450		04
021	0521067397	OIL CONDUCTOR 2000 MH 8450		04
022	0521057308	KIT HOSE MH 7350		01
022A	0501080714	3/8 X 1600 TR-TC HOSE		04
022B	0501080386	HOSE 3/8 X 1050 TR-TC		04
022C	0501080460	3/8" X 23" TR-TR HOSE		04
022D	0501080675	3/8 X 1000 TC-TC 180G HOSE		04
022E	0521052306	HOSE 3/8 X 4450 TC-TM PURPLE / RED		01
022EA	0501082121	3/8 X 4450 TR-TM HOSE		01
022EB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
022EC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
022ED	0503018952	PLASTIC BOLT		06




**COP TRIO 650 - FRAME 8450 - CSU - ENCAPSULATED (UP TO
HYDRAULIC ASSY MH2T 8450**

Page 92
0521057310


Item	Code	Description	See page	QT
022F	0521052307	HOSE 3/8 X 4450 TC-TM PURPLE / BLUE		01
022FA	0501082121	3/8 X 4450 TR-TM HOSE		01
022FB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
022FC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
022FD	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0501067700	2.5" X 25" CYLINDER CASE		01
02	0521066632	EXTENDER		01
03	0503030384	CON PLUG N-001		02
04	0502012837	PISTON		01
05	0503018005	RING		01
06	0503011109	2-119 N 3006-9B O'RING		01
07	0503010163	D-1500 SCRAPER RING		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503018004	RING		01
11	0503018003	GASKET		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0503010002	1800 GREASE FITTING		02
15	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
001	0501100045	WOODEN BOX		01
002	0511061022	ROW MARKER SUPPORT		02
003	0511066119	MARKER SUPP FIXER FASTENER		04
004	0502010175	HITCH CLAMP		08
005	0501010216	3/4" X 4-1/2" BOLT		16
006	0503010023	3/4" SPRING WASHER		16
007	0503010014	3/4" NUT		16
008	0511060013	ROW MARKER ARM		02
009	0521013347	1.1/4" X 8.4" AXLE		02
010	0501019435	32 X 50 X 1.5 FLAT WASHER		16
011	0503010523	1/4" X 2" COTTERPIN		16
012	0511060014	ROW MARKER ARM		02
013	0521011142	1.1/4" X 7.5" AXLE		04
014	0521011141	1.1/4" X 6.5" AXLE		02
015	0511060010	1400 TURNBUCKLE		02
016	0501050633	ROW MARKER DISK ASSEMBLY	96	02
017	0521012324	1/2" X 3.2" X 2.54" FASTENER		04
018	0511017302	FLAT WASHER		08
019	0503010019	1/2" SPRING WASHER		08
020	0503010060	1/2" NUT		08
021	0503010004	1890 GREASE FITTING		02
022	0503010003	1845 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
001	0521050692	HOSE KIT CYLINDER HEAD FRONT		01
001A	0521052309	HOSE 1/2 X 4500 TM-TM GREEN / BLUE		01
001AA	0501081929	HOSE 1/2 X 4500 TM-TM		01
001AB	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
001AC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
001AD	0503018952	PLASTIC BOLT		06
001B	0521052310	HOSE 1/2 X 4500 TM-TM GREEN / RED		01
001BA	0501081929	HOSE 1/2 X 4500 TM-TM		01
001BB	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
001BC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
001BD	0503018952	PLASTIC BOLT		06
002	0501053834	MALE QUICK COUPLER	16	04



Item	Code	Description	See page	QT
01	0503014820	BLACK WATER RESERVOIR		01
02	0521068651	SUPPORT BOX		01
03	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		02
04	0503010025	3/8" SPRING WASHER		02
05	0501010984	FLAT WASHER		02



Item	Code	Description	See page	QT
01	0521068652	TOOLS BOX SUPPORT		01
02	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		02
03	0503010025	3/8" SPRING WASHER		06
04	0501010984	FLAT WASHER		02
05	0501011643	3/8 X 1"BOLT		04
06	0503010026	3/8" NUT		04
07	0503034772	BOX		01
08	0581017000	PLATE INTERMEDIARY		02




Item	Code	Description	See page	QT
01	0521056877	SHORT ROW FRONT	101	01
02	0521056878	LONG FRONT ROW	102	01
03	0521056069	SEMI-ASSEMBLED SHORT FERTILIZER LINE	104	01
04	0521056066	SEMI-ASSEMBLED LONG FERTILIZER LINE	107	01
05	0521050096	SEED DEPOSIT SYSTEM (CSU)		01
06	0503063068	ENCAPSULATED CURRENT		01
07	0503063069	ENCAPSULATED CURRENT		01
08	0503063070	ENCAPSULATED CURRENT		01
09	0521054984	DEPTH/COMPACTOR SYSTEM - SPT	110	01
09.	0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	121	01
10	0503010905	1/2" X 2-1/4" BOLT		01
11	0503010019	1/2" SPRING WASHER		01
12	0503010060	1/2" NUT		01
13	0521051447	FRONT ASSY ROW BEARING	127	01
14	0531060405	EXTENSION		01
15	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		01
16	0503012136	NUT 1/2 NF		01
17	0521056992	SCARIFIER ROD TIP 3 HOLES	128	01
18	0503031145	2" X 2" X 20" HOSE		01
19	0503031076	2" HOSE CLAMP		01
20	0503010479	BOLT		01
21	0503010019	1/2" SPRING WASHER		01
22	0503010060	1/2" NUT		01
23	0571011730	SEED CONDUCTOR 3" X 1500		01
24	0521050525	FIXER FERTILIZER CONDUCTOR	130	01
25	0503031050	CURVED CONDUCTOR		01
26	0503010246	CLAMP		01
27	0503062066	DISC SET WITH CORN RING	131	01
28	0503062067	DISC SET / RING SOY 90F TITANIUM	132	01
29	0531013600	PRESS ADJUSTMENT LEVER		01
30	0521018501	TURNBUCKLE LEVER		01




**COP TRIO 650 - FRAME 8450 - CSU - ENCAPSULATED (UP TO
SEED LINE/ASSY FERTILIZER**

Page 100
0909099225


Item	Code	Description	See page	QT
31	0521068982	KEY CASH DISC CUTTING		01
32	0521056944	REAR FRAME	133	01
33	0521056945	REAR FRAME	134	01
34	0531053040	ENCAPSULATED CHAIN GUIDE SEED ROW WITH CONDUCTOR	143	01




Item	Code	Description	See page	QT
001	0503019273	SLEEVE	08	
002	0591011316	SEED LINE SUPPORT GLOVE	08	
003	0531060069	TOP ARM	01	
004	0531062744	FRONT LOWER ARM OF THE SHORT SEED LINE	01	
005	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
006	0531060077	PRESSURE REGULATOR	01	
007	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	02	
008	0591010915	SPRING REGULATOR	01	
009	0591010914	LOWER AXLE	01	
010	0591011315	SPRING AXLE	01	
011	0503010045	O'RING	08	
012	0503010131	3/16" X 1-1/2" COTTERPIN	01	
013	0503030168	CUPILLA	01	
014	0531060068	REAR LINE	01	
015	0503019295	SCREW 5/8 UNF X 7 CS RP G.5 ZN	04	
016	0502010175	HITCH CLAMP	02	
017	0503017857	BOLT 5/8 UNF 4	04	
018	0501012140	FLAT WASHER	04	
019	0531060073	FRONT LINE SUPPORT	01	
020	0521010542	COUPLING SHAFT	01	
021	0503010300	5/32" X 1" COTTERPIN	01	
022	0591010913	TRANSPORT BUMPER	01	
023	0501010301	FLAT WASHER	04	
024	0503010878	5/8" SELF ALIGNING NUT	04	
025	0503030012	HAIR PIN	01	
026	0571016296	FLAT WASHER	04	
027	0531052956	ASSEMBLY SEED LINE TRANSMISSION FIXING 103 BEARING	01	




Item	Code	Description	See page	QT
01	0503019273	SLEEVE	08	
02	0591011316	SEED LINE SUPPORT GLOVE	08	
03	0531060069	TOP ARM	01	
04	0531062744	FRONT LOWER ARM OF THE SHORT SEED LINE	01	
05	0503010811	5/8" UNF SELF ADJUSTING NUT	08	
06	0531060077	PRESSURE REGULATOR	01	
07	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	02	
08	0591010915	SPRING REGULATOR	01	
09	0591010914	LOWER AXLE	01	
10	0591011315	SPRING AXLE	01	
11	0503010045	O'RING	08	
12	0503010131	3/16" X 1-1/2" COTTERPIN	01	
13	0503030168	CUPILLA	01	
14	0531060068	REAR LINE	01	
15	0503019295	SCREW 5/8 UNF X 7 CS RP G.5 ZN	04	
16	0531060073	FRONT LINE SUPPORT	01	
17	0521010542	COUPLING SHAFT	01	
18	0503010300	5/32" X 1" COTTERPIN	01	
19	0591010913	TRANSPORT BUMPER	01	
20	0501010301	FLAT WASHER	04	
21	0531060072	EXTENDER	01	
22	0502010175	HITCH CLAMP	02	
23	0503017857	BOLT 5/8 UNF 4	04	
24	0501012140	FLAT WASHER	08	
25	0503012798	5/8" X 2" BOLT	04	
26	0503010878	5/8" SELF ALIGNING NUT	04	
27	0503030012	HAIR PIN	01	
28	0571016296	FLAT WASHER	04	
29	0531052956	ASSEMBLY SEED LINE TRANSMISSION FIXING 103 BEARING	01	




Item	Code	Description	See page	QT
01	0531060071	BEARING		01
02	0551015804	BEARING AXLE BODY		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02
07	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
08	0503012880	1/4" UNC SELF ADJUSTING NUT		02
09	0503019373	6006 2RS1 NATIONAL BEARING		01
10	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0531060002	REAR SUPPORT LINE FERTILIZER		01
02	0503019405	GLOVE		08
03	0591010640	SPACER GLOVE ARM WITHOUT LUBRICATION		08
04	0503010045	O'RING		04
05	0531060001	TOP SUPPORT FERTILIZER LINE		01
06	0521069998	LOWER SUPPORT LINE FERTILIZER		01
07	0591010629	SHORT FERTILIZER LINE SUPPORT		01
08	0503010233	5/8" X 2-1/2" BOLT		02
09	0503012412	5/8 UNC SELF LOCKING NUT		05
10	0501010452	5/8" X 5" BOLT		03
11	0502012727	BLADE DISC SUPPORT		01
12	0503011255	3/4" LOCK NUT		02
13	0503011328	3/4" X 4" BOLT		02
14	0501010322	FLAT WASHER		02
15	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
16	0503010013	5/8" NUT		02
17	0521056070	DC 20 ASSY	105	01
18	0521011158	SPRING LOCKNUT		01
19	0521062073	SPRING GUIDE		01
20	0521018575	REGULATOR SPINDLE 100		01
21	0503031450	2.7" X 9.2" X 0.03" SPRING		01
22	0521016057	COUP SHA OF THE CARRY-W SPRING GUI		01
23	0503030168	CUPILLA		01
24	0502020393	SPRING UPPER SUPPORT		02




Item	Code	Description	See page	QT
01	0571019034	FLANGE WASHER AXLE		02
02	0571019032	SUPPORT WASHER		01
03	0502012813	FLANGE WASHER SPRING		01
04	0591010619	DC SPRING SUPPORT		01
05	0503019274	WASHER		02
06	0581017628	COVER		02
07	0503019277	SLEEVE LUBRICATION SYSTEM		01
08	0501110964	RIGHT ARM WITH GLOVE		01
09	0501110965	LEFT ARM WITH GLOVE		01
10	0503034709	COMPRESSION SPRING 100 X 315 X 15.87		01
11	0521069996	ROD SPRING FERTILIZER		01
12	0591010624	GLOVE SUPPORT ARM DC		01
13	0591010625	GLOVE 19,50 X 25 X 91,50 / 91,30		01
14	0503010417	7/8" NUT		02
15	0503010390	SEAL RING		02
16	0503011198	C3/4" X 6" SCREW		01
17	0501010322	FLAT WASHER		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503010060	1/2" NUT		01
20	0503010019	1/2" SPRING WASHER		01
21	0503011255	3/4" LOCK NUT		01
22	0503030430	7/16 X 2" PIN LOCK		01
23	0503019271	SELF LUBRICATING BUSHING		01
24	0521069997	DC FIXING AXIS WITH LIMITER		01
25	0591010628	DC AXIS BACKREST WASHER		01
26	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	106	01
27	0503011254	7/8" HEX SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	CUTTING DISK BOX		01




Item	Code	Description	See page	QT
01	0531060002	REAR SUPPORT LINE FERTILIZER		01
02	0503019405	GLOVE		08
03	0591010640	SPACER GLOVE ARM WITHOUT LUBRICATION		08
04	0503010045	O'RING		04
05	0531060001	TOP SUPPORT FERTILIZER LINE		01
06	0521069998	LOWER SUPPORT LINE FERTILIZER		01
07	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		04
08	0503010233	5/8" X 2-1/2" BOLT		02
09	0503012412	5/8 UNC SELF LOCKING NUT		09
10	0501010452	5/8" X 5" BOLT		02
11	0502012727	BLADE DISC SUPPORT		01
12	0503011255	3/4" LOCK NUT		02
13	0521069993	LONG FERTILIZER LINE SUPPORT		01
14	0501010125	3/4" X 2-1/2" BOLT		02
15	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
16	0503010013	5/8" NUT		02
17	0521056070	DC 20 ASSY	105	01
18	0521011158	SPRING LOCKNUT		01
19	0521062073	SPRING GUIDE		01
20	0521018575	REGULATOR SPINDLE 100		01
21	0503031450	2.7" X 9.2" X 0.03" SPRING		01
22	0521016057	COUP SHA OF THE CARRY-W SPRING GUI		01
23	0503030168	CUPILLA		01
24	0502020393	SPRING UPPER SUPPORT		02
25	0502012724	FERTILIZER ROW FIXER		01
26	0501010163	5/8" X 4-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502020693	SUPPORT SEED BOX		01
02	0502012721	SEED DISC LOWER TRAIL		01
03	0503034131	DEFLECTOR		01
04	0503010025	3/8" SPRING WASHER		03
05	0503010209	3/8" UNC BUTTERFLY NUT		03
06	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
07	0571018536	HEX PRISONER		01
08	0501010984	FLAT WASHER		01
09	0503010337	5/16" NUT		01
10	0503010179	LOCK WASHER		05
11	0503062582	DEPOSIT SEED		01
12	0581011346	ADAPTER DEPOSIT		01
13	0501010694	FLAT WASHER		04
14	0503016282	ALLEN BOLT		01
15	0503016283	M8 NUT HEX		01
16	0501051094	ASSY SEED DISTRIBUTOR	109	01
17	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
18	0503016219	RING TO SOYBEANS		01
19	0503010675	5/16" X 2.1/4" BOLT		01
20	0503030083	3/8" X 3/8" X 1.6" STUD		02




Item	Code	Description	See page	QT
01	0503030381	SEED DISTRIBUTOR BOX		01
02	0502010447	TRIGGER		02
03	0501013467	KEY AXLE		01
04	0503030378	0.4" X 1.1" X 0.03" SPRING		03
05	0501013466	KEY LIMITER AXLE		01
06	0501051119	DOUBLE PULLEY ROCKER'S		01
07	0501013468	ROCKER ARM AXLE, OF THE PULLEY		01
08	0503030377	SCRAPER		01




Item	Code	Description	See page	QT
01	0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	111	01
02	0501052538	DEPTH BAND WITH ARMS	117	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0521054990	LEFT COMPACTOR WHEEL	118	01
06	0521055017	RIGHT COMPACTOR WHEEL	120	01




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	112	01
02	0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	113	01
03	0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	115	01
04	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	116	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	SCREW 3/8 UNC X 3/4		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED GLOVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	114	01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL BOX		01
02	0581019515	AXIS		01
03	0503034055	CLAMPING RING		01
04	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
05	0503013758	1/4" X 1-1/2" BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0503010878	5/8" SELF ALIGNING NUT		01
10	0503030757	2.9" X 2" X 0.02" JOINT		01
11	0521019178	COVER DEPTH		01




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	114	01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT GLOVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	119	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	119	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521055065	ASSY DEPTH / COMPACTOR	122	01
02	0521055068	RAYED WHEEL CENTER CLOSED	125	02
03	0521054990	LEFT COMPACTOR WHEEL	118	01
04	0521055017	RIGHT COMPACTOR WHEEL	120	01
05	0503016453	1/2" X 2.1/2 BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010028	1/2" NUT		02




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0571013054	DEPTH CONTROL WHEEL AXLE		01
04	0502012663	EXTENSION		01
05	0501056769	DEPTH WHEELS REGULATOR ASSY		01
06	0503019398	AXLE RETAINER RING		01
07	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	116	01
08	0521055054	LEFT ARM WITH SLEEVE	123	01
09	0521055066	RIGHT ARM WITH GLOVE	124	01
10	0511015346	FLAT WASHER		04
11	0571015974	WASHER		02
12	0511017302	FLAT WASHER		02
13	0503010256	3/8" X 3/4" BOLT		01
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		04
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2" NUT		02
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0581019473	ARTICULATED GLOVE		02
20	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0581019523	LEFT ARM WHEEL DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019524	RIGHT ARM DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	126	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	LOCK WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0581019522	CASE WHEEL DEPTH WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0503010143	1/4" SPRING WASHER		03
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019529	DEPTH REGULATOR SHAFT		01
11	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01




Item	Code	Description	See page	QT
01	0581014691	BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0503010179	LOCK WASHER		02
04	0503010337	5/16" NUT		02
05	0503012861	6006 2RS BALL BEARING		01
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0581015056	SLEEVE		01
08	0551015804	BEARING AXLE BODY		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0501110723	SCARIFIER ROD	129	01
02	0521069127	BOTTOM NOZZLE FERTILIZER		01
03	0503030483	FERTILIZER SOCKET		01
04	0501010984	FLAT WASHER		04
05	0503010025	3/8" SPRING WASHER		02
06	0503010026	3/8" NUT		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02




Item	Code	Description	See page	QT
01	0521063867	SCARIFIER ROD		01
02	0502070082	POINT SUBSOILER		01
03	0503010585	0,24" X 1.18" SPRING PIN		03




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	NUT		02




Item	Code	Description	See page	QT
01	0503016204	CORN DISK 12 ORANGE		01
02	0503016398	TITANIUM RING CORN / SOY (YELLOW FLAT)		01
03	0503016399	TITANIUM RING CORN (GREEN)		01
04	0503016400	TITANIUM RING CORN (GREY)		01
05	0503016401	TITANIUM RING CORN (BLUE)		01




Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016218	DISC OF SOYBEAN		01
03	0503016403	TITANIUM RING FOR SOYBEAN (LILAC)		01
04	0503016404	TITANIUM RING FOR SOYBEAN (PURPLE)		01
05	0503016406	TITANIUM RING FOR SOYBEAN (ORANGE)		01
06	0503016407	TITANIUM RING FOR SOYBEAN		01




Item	Code	Description	See page	QT
01	0521056955	RIGHT DDD ASSY	135	01
02	0503012136	NUT 1/2 NF		04
03	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
04	0521056582	DOSER	141	01




Item	Code	Description	See page	QT
01	0521056954	LEFT DDD ASSY	136	01
02	0503012136	NUT 1/2 NF		04
03	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
04	0521056582	DOSER	141	01




Item	Code	Description	See page	QT
01	0591011773	RIGHT DDD BODY		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0501010984	FLAT WASHER		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 137 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 139 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0591011772	LEFT DDD BODY		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0501010984	FLAT WASHER		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 137 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 139 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	138	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	LOW CUBE FERTILIZER / SEED BOX		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	140	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUB DISC - HUB		01
02	0502012896	LOW CUBE FERTILIZER / SEED BOX		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0521056639	SEED ROW TRANSMISSION	142	01
02	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
03	0503010257	1/8" X 1" COTTERPIN		01
04	0502012743	FAST BOLT ASSY		01
05	0571014024	FAST BOLT GUIDE AXLE		02
06	0561019270	FAST BOLT ADJUSTMENT		01
07	0502012744	SPEED LOCK LEVER ASSY		01
08	0502012921	BASE FIXING SYSTEM		01
09	0503010026	3/8" NUT		04
10	0503010025	3/8" SPRING WASHER		04
11	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04




Item	Code	Description	See page	QT
01	0502012932	MINOR SIDE		01
02	0503017046	BEARING		02
03	0503011410	ROLLER BEARING		02
04	0591011321	AXLE GEAR		01
05	0591011322	SPACER		01
06	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0503010025	3/8" SPRING WASHER		01
09	0503010179	LOCK WASHER		04
10	0503011945	503050 CLAMPING RING (FOR AXLE)		01
11	0503010420	BOLT		02
12	0503011053	5/16" X 3" C S 6.5 ZN BOLT		04
13	0502012919	GRAGGER		01
14	0502012933	LARGER SIDE		01
15	0502012930	CONICAL GEAR		01
16	0502012931	CONICAL GEAR		01
17	0503010585	0,24" X 1.18" SPRING PIN		01




Item	Code	Description	See page	QT
01	0521059683	ENCAPSULATED CHAIN SUPPORT GUIDE	144	01
02	0531052836	CSU SEED CONDUCTOR JOINT SUPPORT	145	01



Item	Code	Description	See page	QT
01	0591015754	CHAIN SUPPORT		01
02	0503010025	3/8" SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0591016329	ENCAPSULATED CHAIN CLOSING		01
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
06	0503010667	3/16" NUT		02
07	0503010668	3/16" SPRING WASHER		02
08	0503010669	FLAT WASHER		04
09	0501011778	3/8" X 2-1/2" BOLT		02



Item	Code	Description	See page	QT
01	0501012140	FLAT WASHER		01
02	0503010027	5/8" SPRING WASHER		01
03	0503010013	5/8" NUT		01
04	0503010019	1/2" SPRING WASHER		01
05	0511017302	FLAT WASHER		01
06	0503019656	HEXAGONAL NUT		01
07	0591016543	LOCK WASHER ARTICULATOR AXLE BODY		01
08	0531061797	LOWER ADJUSTMENT AXIS		01
09	0531062908	HOSE SUPPORT ARM		01
10	0531062907	ARTICULATOR HOSE		01
11	0513010322	LUBRICANT GLOVE		01
12	0501210533	FLANGE WASHER		01
13	0503013776	BOLT 1/2 UNC X 7/8 C S G.5 ZN		01



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

