

ROW CROP PLANTERS

USAP TITANIUM - FRAME 10970 - SEED/FERTILIZER/CSU/CM/TCE/APT/MH

Code: 0501092937
Series: S-0419
Revision: 00
Date Revision: FEVEREIRO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111140469	USAP 10970/22E500 CSU CM TIT DT ESPECIAL S-0419
0111140464	USAP 10970/24E450 CSU CM TIT DT ESPECIAL S-0419

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909095660	FRAME ASSY	1
0909095661	FRAME RIGHT SIDE ASSY	2
0909095662	ASSY CENTRAL FRAME	3
0909095663	LEFT SIDE FRAME ASSY	4
0909095453	SEED LINE/ASSY FERTILIZER	5
0521057750	TELESCOPIO WITH INTERMEDIARY TUBE 760/2208 ASSY	6
0521057792	PANTOGRAPHY HEADER	7
0521057786	HYDRAULIC CYLINDER HEAD PANTOGRAPH	8
0521059537	COMPLETE RIGHT FRENCH HAND	9
0531050073	FRENCH HAND	10
0521059536	COMPLETE LEFT FRENCH HAND	11
0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	12
0521058088	ROTULA WITH EXTENSOR AXIS 2	13
0511052052	SUPPORT WITH FIXATION	14
0521051438	HEADER 3 POINTS ASSY	15
0521057773	SEMI-ASSEMBLED REST	16
0511053121	GREATER TOOL BOX ASSY	17
0521058344	WATER RESERVOIR WITH SOAP	18
0521057815	HYDRAULIC HOSE SUPPORT WITH FIXATION	19
0511059814	TELESCOPIC LOCK ASSY	20
0521059378	COMPLETE SIDE HEX AXLE	21
0531050078	SIDE HEX SHAFT TCE/APT/SEED	22
0531050872	RIGHT WHEEL WITH TRANSMISSION	23
0531050873	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	24
0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	25
0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	26
0511054491	WHEEL WITHOUT TIRE WITH 27Z GEAR	27
0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	28
0511054463	WHEEL TENSIONER SUPORT CENTRAL	29
0511054464	WHEEL FORK TENSIONER	30
0511054500	TRANSMISSION EXCHANGE RIGHT	31
0511054461	STRETCHER TOP TRANSMISSION SWIRLED	32
0521056861	CENTRAL EXCHANGE STRETCHER FERTILIZER	33
0501056573	17Z GEAR ASSY	34
0521056865	EXCHANGE RIGHT ASSY FERTILIZER	35
0521056866	RIGHT SEMI-ASSEMBLED EXCHANGE	36
0501056444	BEARING WITH ROLLING	37
0501056271	BEARING CLOSED	38
0501052776	CHAIN TENSIONER RIGHT ASSY GREATEST	39
0501048790	AXLE WITH LINK ASSY	40
0521058853	FERTILIZER LEFT SUPPORT WITH COVER	41
0521058845	LEFT SIDE COVER MOUNTED	42
0521058844	SIDE SUPPORT LEFT MOUNTED FERTILIZER	43
0503062362	SILO FERTILIZER 04 MOUTH	44
0521058851	PRESSURE FILTER SUPPORT SET	45
0521053068	MOTOR SUPPORT APT ASSY	46
0511052600	STRETCHER HYDRAULIC MOTOR SUPPORT	47
0521059568	SUPPORT RIGHT SIDE SILO FULL FERTILIZER	48
0531050064	FERTILIZER SUPPORT RIGHT	49
0531050067	SEED RIGHT SUPPORT	50
0521055370	SEED CONDUCTOR	51
0531050079	PLATFORM SIDE	52
0531050080	SIDE GUTTER ASSEMBLY	53
0521058637	SIDE DUCT ASSEMBLY	54
0521059232	ADHESIVE LABEL SET	55



MARCHESAN

INDEX

0521059609	SUPPORT SIDE DERECHO SILO FERTILIZER COMPLETE	56
0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	57
0521059569	SUPPORT RIGHT SIDE SILO FULL FERTILIZER	58
0521054313	CLOSED BEARING	59
0521054282	BEARING	60
0501053788	Q3/4" FASTENER AXLE ASSY	61
0521051407	FIXER SILO FERTILIZER	62
0521050525	FIXER FERTILIZER CONDUCTOR	63
0521055365	SEED CONDUCTOR	64
0521054290	ASSY SIDE SUPPORT	65
0521053054	ASSY SIDE HANDLE	66
0521059607	SIDE PLATFORM	67
0521054279	PLATFORM FIXER	68
0521059476	INTERNAL RIGHT HANDRAIL 228	69
0511059383	INTERNAL FIXER ASSY HANDLE	70
0521059475	INTERNAL LEFT HANDRAIL 228	71
0521054272	LADDER ASSY	72
0521055384	ADHESIVE LABELS SET	73
0521059604	SEED SIDE TRACK ASSEMBLY	74
0521055102	BIGGEST FULL GUTTER SUPPORT	75
0521059606	CHASSIS LEFT SIDE DUCT SET	76
0511059943	SUPPORT FASTENER ASSY	77
0511059928	SIDE DUTY SUPPORT	78
0521059314	CENTRAL HEX AXLE 32E450 TCE/APT	79
0521058662	CENTRAL SHAFT AXLE	80
0521051437	BOX ECU APT TVT NO EXCHANGE	81
0521058852	FERTILIZER RIGHT SUPPORT	82
0521058842	SIDE SUPPORT RIGHT FERTILIZER ASSEMBLED	83
0521058843	RIGHT SIDE COVER ASSEMBLED	84
0531050093	HYDRAULIC ASSEMBLY	85
0531050094	CENTRAL DUCT ASSY	86
0511054499	TRANSMISSION OF LARGER CENTRAL EXCHANGE	87
0521057490	CHAIN STRETCHER WITH ASSY HOLE 13	88
0521057222	ASSY CENTRAL FERTILIZER EXCHANGE	89
0501052778	CHAIN TENSIONER ASSY	90
0511054489	LEFT TENSIONER CENTRAL EXCHANGE	91
0511056179	CLUTCH WITH CARDAN CENTRAL	92
0501056443	BEARING ASSY GEAR BOX	93
0521056856	ECU BOX WITH ASSY SUPPORT	94
0521056857	ECU APT / TVT BOX WITH EXCHANGE	95
0521059235	CENTRAL SUPPORT SILO 10 MOUTH FERTILIZER	96
0531050100	SILO CENTRAL SUPPORT	97
0531050059	RIGHT CENTRAL SUPPORT	98
0521059236	CENTRAL PLATFORM SET	99
0531050095	CENTRAL GUTTER SET	100
0531050101	ELECTRICAL ASSEMBLY	101
0531050091	ISO SET	102
0531050066	SEED LEFT SUPPORT	103
0531050065	FERTILIZER LEFT SUPPORT	104
0521054263	LEFT FERTILIZER CONDUCTOR ASSY	105
0503062391	SILO FERTILIZER 05 MOUTHS	106
0521059025	CENTRAL SUPPORT LEFT 5 MOUTH FULL FERTILIZER	107
0521059028	RIGHT CENTRAL SUPPORT 5 MOUTH FULL FERTILIZER	108
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	109
0521059026	RIGHT CENTRAL SEED BOX COMPLETE FERTILIZER	110



MARCHESAN

INDEX


0521059027	COMPLETE LEFT SEED CENTER BOX FERTILIZER	111
0521059187	CENTRAL PLATFORM ASSY	112
0511054515	ASSY LEFT ARTICULATION ARM	113
0511054516	ASSY RIGHT ARTICULATION ARM	114
0521055949	LOWER ARTICULATED ARM CYLINDER ASSY	115
0511058226	HYDRAULIC CYLINDER 50,80 X 114,30 X 810 X 1300	116
0521059619	HYDRAULIC FERTILIZER MARKER SET	117
0521059620	CENTRAL FERTILIZER DUCT SET	118
0521053537	CENTRAL REAR DUCT SUPPORT	119
0531050058	SUPPORT ASSY BLOCK/VALVES	120
0531050057	MH SEQUENTIAL VALVE SUPPORT WITH FIXATION	121
0521052155	SEQUENTIAL VALVE ASSY	122
0531050351	ARTICULATED FERTILIZER / SEED HOSE ASSY	123
0521055274	HEAD HOSE ASSY	124
0531050097	ASSY HOSE LIFTING FERTILIZER/SEED	125
0531051058	SET FERTILIZER AND SEED HOSE	126
0521055402	HOSE KIT MH/CH 12910	127
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	128
0521057013	TRIPLE DIVISER VALVE BRP00079 WITH NIPLES	129
0521059192	CENTER TRACK SET FERTILIZER SEED	130
0521058651	ELECTRICAL ASSY 15MT / 3F MECHANICAL LED	131
0521054283	HEADLIGHT WITH SUPPORT	132
0521059393	LED FLASHLIGHT WITH FIXATION SUPPORT	133
0521055426	ASSY ELECTRICAL BOX SUPPORT	134
0521052143	CLUTCH INDUCTIVE SENSOR ASSEMBLY	135
0521059594	ISOBUS 24L45/50 ASSY WITH SEED MONITOR	136
0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	137
0511056972	FILTER HYDAC	138
0531050871	LEFT WHEEL WITH TRANSMISSION	139
0511054501	TRANSMISSION CAMBIO LEFT	140
0521059621	ADHESIVE LABEL SET	141
0531050096	SET LABEL ADHESIVE	142
0521059368	SUPPORT/SENSOR ASSY PSS-X1005B 87780-000 TE	143
0521058330	SENSOR SUPPORT	144
0521058331	DRIVE HYDRAULIC ASSEMBLY	145
0521057203	ELECTRIC ASSEMBLY BCE (PACKED) MECHANICAL	146
0521056864	ASSY LEFT EXCHANGE FERTILIZER	147
0521056867	SEMI-ASSEMBLED LEFT EXCHANGE	148
0501047300	DRIVE SHAFT	149
0521058426	ASSY FILTER SUPPORT	150
0521059570	SUPPORT SILO SIDE LEFT COMPLETE FERTILIZER	151
0521059605	LEFT SIDE SUPPORT SILO ADOBO 7 MOUTH	152
0521058534	FRONT LINE SEED LONG TCE/CM	153
0521058533	FRONT SEED SHORT LINE TCE/CM	154
0521058612	FRONT SUPER LONG SEED LINE TCE	155
0521059045	BEARING WITH CURRENT ENCAPSULATED	156
0521058611	FRAME SEMI MOUNTED SUPER LONG CM/TCE	157
0521050096	SEED DEPOSIT SYSTEM (CSU)	158
0511052058	SEED SYSTEM TITANIUM	159
0521055346	20 BLADE DISC ASSY	160
0521055344	LOWER SUPPORT	161
0521058588	REAR WITH LEFT DDD SPICRR TITANIUM TCE	162
0521058085	REAR WITH DDD LEFT SPICRR	163
0531050193	DOSING ASSY TITANIUM/TATU	164
0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	165




MARCHESAN

INDEX

0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	166
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	167
0521056632	DEPTH CONTROL	168
0521056633	MOUNTED RIGHT ARM	169
0521055059	WHEEL RAYED ASSY SPA WITHOUT LUBRICATION	170
0521056631	MOUNTED LEFT ARM	171
0521055093	BODY COMPACTOR	172
0521054990	LEFT COMPACTOR WHEEL	173
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	174
0521055017	RIGHT COMPACTOR WHEEL	175
0521056639	SEED ROW TRANSMISSION	176
0511052024	FAST CLOSING SET	177
0521058586	REAR WITH RIGHT DDD SPICRR TITANIUM TCE	178
0521058084	REAR WITH RIGHT DDD SPICRR	179
0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	180
0521054262	RIGHT FERTILIZER CONDUCTOR	181
0521056855	ASSY SHORT FERTILIZER CONDUCTOR	182
0521056854	ASSY LONG FERTILIZER CONDUCTOR	183
0503062066	DISC SET WITH CORN RING	184
0503062067	DISC SET / RING SOY 90F TITANIUM	185
0521055341	CUTTING DISC	186
0521055340	CUT BOTTOM SUPPORT	187
0521055373	BOX WITH CUTTING DISC DPLE 20 TB 60E WITHOUT LUBRICATION	188
0521053697	CUTTING DISK BOX	189
0521055053	DEEP WHEEL/COMPACTOR SYSTEM	190
0521055065	ASSY DEPTH / COMPACTOR	191
0521055033	COMPACTADOR BODY	192
0521055054	LEFT ARM WITH SLEEVE	193
0521055066	RIGHT ARM WITH GLOVE	194
0521055068	RAYED WHEEL CENTER CLOSED	195
0521055360	COMPLETE MARKER	196
0511058553	HYDRAULIC CYLINDER	197
0511042494	ROW MARKER DISC ASSY	198



Item	Code	Description	See page	QT
01	0909095661	FRAME RIGHT SIDE ASSY	2	01
02	0909095662	ASSY CENTRAL FRAME	3	01
03	0909095663	LEFT SIDE FRAME ASSY	4	01
04	0521057750	TELESCOPIO WITH INTERMEDIARY TUBE 760/2208 ASSY	6	01
05	0531062243	TRANSPORT LOCK		01
06	0521057792	PANTOGRAPHY HEADER	7	01
07	0521059537	COMPLETE RIGHT FRENCH HAND	9	01
08	0521059536	COMPLETE LEFT FRENCH HAND	11	01
09	0511052052	SUPPORT WITH FIXATION	14	04
10	0521051438	HEADER 3 POINTS ASSY	15	01
11	0521057773	SEMI-ASSEMBLED REST	16	01
12	0511053121	GREATER TOOL BOX ASSY	17	01
13	0521058344	WATER RESERVOIR WITH SOAP	18	01
14	0521057815	HYDRAULIC HOSE SUPPORT WITH FIXATION	19	01
15	0503018829	NYLON CLAMP		12
16	0521058345	SAFETY CHAIN WITH SHACKLE		01
16A	0503014120	CHAIN		01
16B	0503014321	CABLE STEEL SHACKLE		02
17	0511059814	TELESCOPIC LOCK ASSY	20	01



Item	Code	Description	See page	QT
01	0531061457	RIGHT SIDE FERTILIZER CHASSIS		01
02	0503010002	1800 GREASE FITTING		01
03	0521059378	COMPLETE SIDE HEX AXLE	21	01
03.	0531050078	SIDE HEX SHAFT TCE/APT/SEED	22	01
04	0531050872	RIGHT WHEEL WITH TRANSMISSION	23	01
04.	0531050873	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	24	01
05	0521056861	CENTRAL EXCHANGE STRETCHER FERTILIZER	33	01
06	0521056865	EXCHANGE RIGHT ASSY FERTILIZER	35	01
07	0511047255	DRIVE SHAFT		01
08	0521053068	MOTOR SUPPORT APT ASSY	46	01
09	0521059609	SUPPORT SIDE DERECHO SILO FERTILIZER COMPLETE	56	01
09.	0531050064	FERTILIZER SUPPORT RIGHT	49	01
09..	0531050067	SEED RIGHT SUPPORT	50	01
10	0521059569	SUPPORT RIGHT SIDE SILO FULL FERTILIZER	58	01
10.	0503062362	SILO FERTILIZER 04 MOUTH	44	01
10..	0503062927	SILO FERTILIZER 3 MOUTHS		01
11	0521055360	COMPLETE MARKER	196	01
12	0521051407	FIXER SILO FERTILIZER	62	10
13	0521054290	ASSY SIDE SUPPORT	65	02
14	0521053054	ASSY SIDE HANDLE	66	02
15	0521059607	SIDE PLATFORM	67	01
15.	0531050079	PLATFORM SIDE	52	01
16	0521059476	INTERNAL RIGHT HANDRAIL 228	69	01
17	0521059475	INTERNAL LEFT HANDRAIL 228	71	01
18	0521054272	LADDER ASSY	72	01
19	0521055384	ADHESIVE LABELS SET	73	01
19.	0521059232	ADHESIVE LABEL SET	55	01
20	0521059604	SEED SIDE TRACK ASSEMBLY	74	01
20.	0531050080	SIDE GUTTER ASSEMBLY	53	01
21	0521059606	CHASSIS LEFT SIDE DUCT SET	76	01
21.	0521058637	SIDE DUCT ASSEMBLY	54	01




USAP TITANIUM - FRAME 10970 -
FRAME RIGHT SIDE ASSY

Page 2
0909095661

Item	Code	Description	See page	QT
22	0521059568	SUPPORT RIGHT SIDE SILO FULL FERTILIZER	48	01
23	0531050064	FERTILIZER SUPPORT RIGHT	49	01
24	0909095453	SEED LINE/ASSY FERTILIZER	5	07

ASSY CENTRAL FRAME

0909095662




Item	Code	Description	See page	QT
01	0531061276	CHASSIS CENTER LOWER FERTILIZER		01
02	0521059314	CENTRAL HEX AXLE 32E450 TCE/APT	79	01
02.	0521058662	CENTRAL SHAFT AXLE	80	01
03	0521044028	CENTRAL WHEEL WITH TRANSMISSION 8940		03
04	0531050873	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	24	01
05	0521057490	CHAIN STRETCHER WITH ASSY HOLE 13	88	01
06	0521057222	ASSY CENTRAL FERTILIZER EXCHANGE	89	01
07	0521056856	ECU BOX WITH ASSY SUPPORT	94	01
07.	0521051437	BOX ECU APT TVT NO EXCHANGE	81	01
08	0521053068	MOTOR SUPPORT APT ASSY	46	01
09	0521059235	CENTRAL SUPPORT SILO 10 MOUTH FERTILIZER	96	01
10	0521059026	RIGHT CENTRAL SEED BOX COMPLETE FERTILIZER	110	01
11	0521059027	COMPLETE LEFT SEED CENTER BOX FERTILIZER	111	01
11.	0531050100	SILO CENTRAL SUPPORT	97	01
12	0521059187	CENTRAL PLATFORM ASSY	112	01
12.	0521059236	CENTRAL PLATFORM SET	99	01
13	0511054515	ASSY LEFT ARTICULATION ARM	113	01
14	0511054516	ASSY RIGHT ARTICULATION ARM	114	01
15	0521055949	LOWER ARTICULATED ARM CYLINDER ASSY	115	01
16	0521059619	HYDRAULIC FERTILIZER MARKER SET	117	01
16.	0531050093	HYDRAULIC ASSEMBLY	85	01
17	0521059192	CENTER TRACK SET FERTILIZER SEED	130	01
17.	0531050095	CENTRAL GUTTER SET	100	01
18	0521058651	ELECTRICAL ASSY 15MT / 3F MECHANICAL LED	131	01
18.	0531050101	ELECTRICAL ASSEMBLY	101	01
19	0581018653	LESSER PROTECTION		02
20	0521059594	ISOBUS 24L45/50 ASSY WITH SEED MONITOR	136	01
20.	0531050091	ISO SET	102	01
21	0521059621	ADHESIVE LABEL SET	141	01
21.	0531050096	SET LABEL ADHESIVE	142	01


ASSY CENTRAL FRAME

0909095662


Item	Code	Description	See page	QT
22	0521059368	SUPPORT/SENSOR ASSY PSS-X1005B 87780-000 143 TE		01
23	1164920006	BLACK LIGHT SUCTION HOSE		23
24	1164920013	FLEX HOSE SPIRAL		01
25	0521055637	ASSY TRANSPORT LOCK		04
25A	0551018312	TRANSPORT LOCK		01
25B	0501068994	0.3" X 3.1"LOCK PIN		01
25C	0503030168	HAIR PIN		01
26	0561016793	FIXED WRENCH		01
27	0501047885	ROD STOP		08
28	0561017063	HOLDER TUBE		02
29	0581019559	AXIS		01
30	0521057203	ELECTRIC ASSEMBLY BCE (PACKED) 146 MECHANICAL		01
31	0521058852	FERTILIZER RIGHT SUPPORT	82	01
32	0909095453	SEED LINE/ASSY FERTILIZER	5	08




Item	Code	Description	See page	QT
01	0531061458	LEFT SIDE CHASSIS		01
02	0503010002	1800 GREASE FITTING		01
03	0521059378	COMPLETE SIDE HEX AXLE	21	01
03.	0531050078	SIDE HEX SHAFT TCE/APT/SEED	22	01
04	0531050871	LEFT WHEEL WITH TRANSMISSION	139	01
05	0521056861	CENTRAL EXCHANGE STRETCHER FERTILIZER	33	01
06	0521056864	ASSY LEFT EXCHANGE FERTILIZER	147	01
07	0501047300	DRIVE SHAFT	149	01
08	0521053068	MOTOR SUPPORT APT ASSY	46	01
09	0521058426	ASSY FILTER SUPPORT	150	01
10	0521059570	SUPPORT SILO SIDE LEFT COMPLETE FERTILIZER	151	01
10.	0531050066	SEED LEFT SUPPORT	103	01
11	0521059605	LEFT SIDE SUPPORT SILO ADOBO 7 MOUTH	152	01
12	0531050873	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	24	01
13	0521055360	COMPLETE MARKER	196	01
14	0521054290	ASSY SIDE SUPPORT	65	02
15	0521053054	ASSY SIDE HANDLE	66	02
16	0521059607	SIDE PLATFORM	67	01
17	0521059476	INTERNAL RIGHT HANDRAIL 228	69	01
18	0521059475	INTERNAL LEFT HANDRAIL 228	71	01
19	0521054272	LADDER ASSY	72	01
20	0521055384	ADHESIVE LABELS SET	73	01
20.	0521059232	ADHESIVE LABEL SET	55	01
21	0521059604	SEED SIDE TRACK ASSEMBLY	74	01
21.	0531050080	SIDE GUTTER ASSEMBLY	53	01
22	0521059606	CHASSIS LEFT SIDE DUCT SET	76	01
22.	0521058637	SIDE DUCT ASSEMBLY	54	01
23	0521058852	FERTILIZER RIGHT SUPPORT	82	01
24	0909095453	SEED LINE/ASSY FERTILIZER	5	07




Item	Code	Description	See page	QT
01	0521058534	FRONT LINE SEED LONG TCE/CM	153	01
02	0521058533	FRONT SEED SHORT LINE TCE/CM	154	01
03	0521058612	FRONT SUPER LONG SEED LINE TCE	155	01
04	0521058611	FRAME SEMI MOUNTED SUPER LONG CM/TCE	157	01
05	0521050096	SEED DEPOSIT SYSTEM (CSU)	158	01
06	0521055346	20 BLADE DISC ASSY	160	01
06.	0521055341	CUTTING DISC	186	01
07	0521058588	REAR WITH LEFT DDD SPICRR TITANIUM TCE	162	01
08	0521058586	REAR WITH RIGHT DDD SPICRR TITANIUM TCE	178	01
08.	0521055053	DEEP WHEEL/COMPACTOR SYSTEM	190	01
09	0521054262	RIGHT FERTILIZER CONDUCTOR	181	01
10	0521056855	ASSY SHORT FERTILIZER CONDUCTOR	182	01
11	0521056854	ASSY LONG FERTILIZER CONDUCTOR	183	01
12	0503019222	BRACELET TYPE WIRE 3.2MM X 48 X 63 MM		01
13	0591011691	TOP GLOVE CONDUCTOR FERTILIZER		01
14	0503031050	CURVED CONDUCTOR		01
15	0503062066	DISC SET WITH CORN RING	184	01
16	0503062067	DISC SET / RING SOY 90F TITANIUM	185	01
17	0531013600	PRESS ADJUSTMENT LEVER		01
18	0521068982	KEY CASH DISC CUTTING		01
19	0511052024	FAST CLOSING SET	177	01
20	0521050525	FIXER FERTILIZER CONDUCTOR	63	01
21	0531060941	PROTECTION		01
22	0503014234	BOLT 1/2 UNF X 1.3/4 CS G.5 ZN		01
23	0503012136	NUT 1/2 NF		01
24	0591014600	ENCAPSULATED CURRENT FIXER		01
25	0561016889	STRIPED CAP WHEEL DEPTH		01




Item	Code	Description	See page	QT
01	0503015764	BOLT 7/8		01
02	0501010076	FLAT WASHER		01
03	0503010408	7/8" SPRING WASHER		01
04	0503010417	7/8" NUT		01
05	0503011052	1.1/4" X 0.77" CASTLE NUT		03
06	0503010038	3/16 X 2 COTTERPIN		03
07	0503010002	1800 GREASE FITTING		03
08	0501012140	FLAT WASHER		08
09	0503010233	5/8" X 2-1/2" BOLT		04
10	0503010027	5/8" SPRING WASHER		04
11	0503010013	5/8" NUT		04
12	0521051433	FRENCH HAND FRONT AXLE ASSY		02
12A	0511069442	FRENCH HAND FRONT AXLE		01
12B	0501017779	32 X 60 X 4.75 FLAT WASHER		01
12C	0503011052	1.1/4" X 0.77" CASTLE NUT		01
12D	0503010038	3/16 X 2 COTTERPIN		01
12E	0581014420	SLEEVE GUIDE		02
13	0531060750	TELESCOPIC HEADER 760/2208		01
14	0531060748	REST SUPPORT		01
15	0531060747	TELESCOPIC HOSE GUIDE		01
16	0531060746	AXIS 278 TELESCOPIC HEADER		03
17	0521069928	INTERNAL CANUDO 4286/4290		01
18	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		01




Item	Code	Description	See page	QT
01	0531060744	UPPER ARM PANTOGRAPHIC HEADER		01
02	0531060743	LOWER ARM PANTOGRAPHIC HEADER		01
03	0531060745	PANTOGRAPHIC ARM EAR		02
04	0502040864	GEAR BOX WITH REGULATOR		01
05	0521068007	TRACTOR HITCH		01
06	1902040327	LOCK SLEEVE		01
07	0503010523	1/4" X 2" COTTERPIN		01
08	0503010002	1800 GREASE FITTING		04
09	0521063432	LOCK AXLE		02
10	0503031035	HAIR PIN		02
11	0531060746	AXIS 278 TELESCOPIC HEADER		02
12	0531060792	AXIS 200 TELESCOPIC HEADER		01
13	0531060776	HYDRAULIC HOSE SUPPORT FIXER		01
14	0503011052	1.1/4" X 0.77" CASTLE NUT		02
15	0503010038	3/16 X 2 COTTERPIN		03
16	0521010578	COUPLING SHAFT		01
17	0521057786	HYDRAULIC CYLINDER HEAD PANTOGRAPH	8	01
18	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		02




Item	Code	Description	See page	QT
01	0531060769	PANTOGRAPHIC HEAD CYLINDER CASE		01
02	0531060770	PANTOGRAPHIC HEAD CYLINDER ROD		01
03	0503010817	1.1/4" SELF LOCKING NUT		01
04	0503010345	2-218 N 3006-9B O'RING		01
05	0502010382	5" END CAP		01
06	0581010353	RING SUPPORT		01
07	0503018026	1870-2000-375 B GASKET		01
08	0503011453	O'RING		02
09	0503018152	O'RING		02
10	0503018024	RING BS		01
11	0503018025	RING GUIDE		01
12	0581010354	PISTON		01
13	0503018150	RING GUIDE		01
14	0503018151	RING BS		02
15	0503010039	D-2000 SCRAPER RING		01
16	0503030385	CYLINDER PLUG N-002		02




Item	Code	Description	See page	QT
001	0503010002	1800 GREASE FITTING		01
002	0502010477	HOSE CLAMP		06
003	0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	12	01
004	0521058088	ROTULA WITH EXTENSOR AXIS 2	13	01
005	0531060793	FRENCH HAND 1269 X 1500 X 3593		01
006	0521069926	OIL DUCT R1.1 / 16 X 2460		02
007	0502012907	FRENCH HAND DUCTS SUPPORT		04
008	0501010984	FLAT WASHER		06
009	0503010025	3/8" SPRING WASHER		06
010	0503010964	BOLT		04
011	0503010589	1/2" UNC SELF ADJUSTING NUT		04
012	0503011404	BOLT		06
013	0591010529	FRENCH HAND RAIL 20 X38 X 2380		01
014	0521069924	OIL DUTO R3/4 X 2460		02
015	0521069925	OIL DUCT R7/8 X 2460		01
016	0581018419	SUPPORT		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0502010477	HOSE CLAMP		04
03	0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	12	01
04	0521058088	ROTULA WITH EXTENSOR AXIS 2	13	01
05	0531060793	FRENCH HAND 1269 X 1500 X 3593		01
06	0521069926	OIL DUCT R1.1 / 16 X 2460		02
07	0502012907	FRENCH HAND DUCTS SUPPORT		04
08	0501010984	FLAT WASHER		04
09	0503010025	3/8" SPRING WASHER		04
10	0503010964	BOLT		04
11	0503010589	1/2" UNC SELF ADJUSTING NUT		04
12	0503011404	BOLT		04
13	0591010529	FRENCH HAND RAIL 20 X38 X 2380		01
14	0521069925	OIL DUCT R7/8 X 2460		01
15	0581018419	SUPPORT		02




Item	Code	Description	See page	QT
001	0503010002	1800 GREASE FITTING		01
002	0502010477	HOSE CLAMP		04
003	0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	12	01
004	0531060793	FRENCH HAND 1269 X 1500 X 3593		01
005	0521058088	ROTULA WITH EXTENSOR AXIS 2	13	01
006	0521069925	OIL DUCT R7/8 X 2460		01
007	0521069924	OIL DUTO R3/4 X 2460		02
008	0502012907	FRENCH HAND DUCTS SUPPORT		04
009	0501010984	FLAT WASHER		04
010	0503010025	3/8" SPRING WASHER		04
011	0503010964	BOLT		04
012	0503010589	1/2" UNC SELF ADJUSTING NUT		04
013	0503011404	BOLT		04
014	0591010529	FRENCH HAND RAIL 20 X38 X 2380		01
015	0581018419	SUPPORT		02



Item	Code	Description	See page	QT
01	0521062244	PIVOT SHAFT		01
02	0551019529	FLAT WASHER		01
03	0503010027	5/8" SPRING WASHER		01
04	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		01




Item	Code	Description	See page	QT
01	0531061046	ROTULA WITH R2 LEFT NUT		01
02	0503010002	1800 GREASE FITTING		02
03	0501078990	TURNBUCLE AXLE		01
04	0561019879	LOCK ATTACHMENT BAR		01




Item	Code	Description	See page	QT
01	0521063339	HIGHER		06
02	0571011070	5/8" UNC FASTENER		06
03	0503010027	5/8" SPRING WASHER		12
04	0503010013	5/8" NUT		12

HEADER 3 POINTS ASSY


0521051438




Item	Code	Description	See page	QT
01	0561013456	GUIDE DRAWBAR ASSY		02
02	0501010276	BOLT		04
03	0503010012	1" SPRING WASHER		04
04	0501010059	1.5/8 NUT		04
05	0503030119	LOCK PIN		02
06	0511069471	PLOUGH SUPPORT		02
07	0501011075	PIN		02
08	0503030285	HAIR PIN		02
09	0521068020	DRAWBAR ASSY		01
10	0503030085	LOCK PIN		04
11	0521068018	UPPER AXLE		01
12	0521068015	UPPER AXLE		01
13	0521068013	UPPER AXLE		01
14	0521068011	AXLE LOWER		02
15	0521068010	HITCH AXLE		01
16	0521068009	UPPER AXLE		01
17	0503031035	HAIR PIN		01




Item	Code	Description	See page	QT
01	0531060668	REST SUPPORT		01
02	0503010571	1/4" X 1.1/2 COTTERPIN		02
03	0521010784	COUPLING SHAFT		01
04	0531060758	AXLE JUNCTION 25.4 X 150 WITH HANDLE		01
05	0503030085	LOCK PIN		02
06	0531060667	REST		01
07	0591013219	INTERNAL TUBE REST		01
08	0521010580	COUPLING SHAFT		01
09	0521012533	COUPLING SHAFT		01




Item	Code	Description	See page	QT
01	0521063662	BOX OF TOOLS		01
02	0551018356	BOX OF TOOLS COVER ASSY		01
03	0521010528	0.3" X 1.6" COUPLING SHAFT		02
04	0503010140	1/8" X 3/4" COTTERPIN		02
05	0503011907	PMC 594-S NYLON LUG		01
06	0503010358	5/16" X 5/8" BOLT		02
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503010337	5/16" NUT		02
09	0511017302	FLAT WASHER		04
10	0503010964	BOLT		02
11	0503010589	1/2" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0503014820	COROTE BLACK WATER		01
02	0503019262	SOAP DISH VACUUM		01




Item	Code	Description	See page	QT
01	0531060794	HYDRAULIC HOSE SUPPORT		01
02	0503015490	SELF-LOCKING NUT 7/16		02
03	0503011173	7/16" X 2" BOLT		02
04	0501010937	13.5 X 28 X 3 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0571015072	LOCK AXLE		01
02	0503010765	3/8" X 3" BOLT		01
03	0521064540	TELESCOPIC LOCK		01
04	0503013357	3/8" SELF-ADJUSTING NUT		01
05	0521011132	FLAT WASHER		01
06	0503010131	3/16" X 1-1/2" COTTERPIN		01
07	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
08	0511054270	TENSIONER SPRING		01
08A	0511069520	TELESC LOCK SPRING TENSIONER		01
08B	0503010013	5/8" NUT		02



Item	Code	Description	See page	QT
001	0561015843	3/4 X 2070 HEX AXLE		02
002	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		04
002A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
002B	0503010256	3/8" X 3/4" BOLT		01
003	0561015837	SLEEVE 31,75		01
004	0503010523	1/4" X 2" COTTERPIN		01




Item	Code	Description	See page	QT
01	0581018254	HEX AXLE 3/4 X 2700 STM 29 USG		01
02	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		02
02A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
02B	0503010256	3/8" X 3/4" BOLT		01




Item	Code	Description	See page	QT
01	0521064543	WHEEL SUPPORT		01
02	0561019929	FLAT WASHER		01
03	0503010523	1/4" X 2" COTTERPIN		03
04	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
05	0551014508	FLAT WASHER		01
06	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
07	0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	25	01
08	0503010920	1/2" X 1.1/2" BOLT		04
09	0503010019	1/2" SPRING WASHER		04
10	0503010060	1/2" NUT		04
11	0502012731	WHEEL HOLDER		02
12	0503010002	1800 GREASE FITTING		04
13	0521064550	CARRYING-WHEELS FORK		01
14	0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	26	01
15	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
16	0511054491	WHEEL WITHOUT TIRE WITH 27Z GEAR	27	01
17	0511068422	WHEEL GEAR DOBLE		01
18	0551018571	FLAT WASHER		02
19	0511054463	WHEEL TENSIONER SUPORT CENTRAL	29	01
20	0511054464	WHEEL FORK TENSIONER	30	02
21	0561019941	RIGHT PROTECTIVE CAP WHEELS		01
22	0503010849	3/8" X 1-1/2" BOLT		02
23	0501013518	FLAT WASHER		02
24	0503010025	3/8" SPRING WASHER		02
25	0503010209	3/8" UNC BUTTERFLY NUT		02
26	0503016419	50-1 CHAIN X 128 LINK + REDUCION		01
27	0501010630	1.1/2" CASTLE NUT		01
28	0501017779	32 X 60 X 4.75 FLAT WASHER		02
29	0503011052	1.1/4" X 0.77" CASTLE NUT		02
30	0503014857	50-1 X CHAIN X 122 LINK + REDUCION		01
31	0511054500	TRANSMISSION EXCHANGE RIGHT	31	01


Item	Code	Description	See page	QT
32	0503033335	CURRENT 6 X 21 ELOS		01
33	0503010882	BOLT		01
34	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
35	0503010337	5/16" NUT		01
36	0581017245	AXLE BODY		01
37	0531012874	FLAT WASHER		02
38	0503012334	3/4" UNC X 3.1/2" BOLT		04
39	0503011075	3/4" UNC NUT		04
40	0503010571	1/4" X 1.1/2 COTTERPIN		02




Item	Code	Description	See page	QT
01	0521064543	WHEEL SUPPORT		01
02	0561019929	FLAT WASHER		01
03	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
04	0551014508	FLAT WASHER		01
05	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
06	0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	25	01
07	0503010920	1/2" X 1.1/2" BOLT		04
08	0503010019	1/2" SPRING WASHER		04
09	0503010060	1/2" NUT		04
10	0502012731	WHEEL HOLDER		02
11	0503010002	1800 GREASE FITTING		03
12	0521064550	CARRYING-WHEELS FORK		01
13	0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	26	01
14	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
15	0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	28	01
16	0501010630	1.1/2" CASTLE NUT		01
17	0501017779	32 X 60 X 4.75 FLAT WASHER		02
18	0503011052	1.1/4" X 0.77" CASTLE NUT		02
19	0503010882	BOLT		01
20	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
21	0503010337	5/16" NUT		01
22	0503033335	CURRENT 6 X 21 ELOS		01
23	0581017245	AXLE BODY		01
24	0531012874	FLAT WASHER		02
25	0503012334	3/4" UNC X 3.1/2" BOLT		04
26	0503011075	3/4" UNC NUT		04
27	0503010523	1/4" X 2" COTTERPIN		03
28	0503010571	1/4" X 1.1/2 COTTERPIN		02




Item	Code	Description	See page	QT
01	0521066557	CYLINDER CASE 101,60 X 352		01
02	0581010680	TURNBUCKLE 50,80 X 386		01
03	0571015629	CILINDER SPINDLE FORK		01
04	0503010817	1.1/4" SELF LOCKING NUT		01
05	0503010345	2-218 N 3006-9B O'RING		01
06	0503011094	3/8" X 2" BOLT		01
07	0503010026	3/8" NUT		01
08	0503010025	3/8" SPRING WASHER		01
09	0503030385	CYLINDER PLUG N-002		02
10	0503015633	SELEMASTER SEALING		01
11	0581010678	50,80 X 101 RING SUPPORT		01
12	0503015636	SCRAPER SEAL		01
13	0503018025	RING GUIDE		01
14	0503018026	1870-2000-375 B GASKET		01
15	0503010338	2-342 N 3006-9B O'RING		02
16	0503011061	8-342 BACK-UP RING		02
17	0502012822	101.60 END CAP		01
18	0502012820	50.80 X 101.60 PISTON		01
19	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0503033713	TIRE 12 X 16,5/12L TR SK 900		01
02	0503015029	WHEEL		01
03	0503015355	INNER TIRE		01




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503013633	BEARING 33287/33462		01
04	0503010009	RETAINER 00573-B		01
05	0503010086	SEAL 0009B-B		01
06	0551014473	GLOVE		01
07	0503012702	KM-12 NUT		02
08	0503012703	LOCK WASHER		01
09	0503010002	1800 GREASE FITTING		01
10	0503011444	SPRING WASHER		08
11	0503014048	22 X 1.5 HEX NUT		08
12	0503010363	5/16" X 1" BOLT		08
13	0521064563	27Z GEAR		01
14	0503014050	22 X 1.5 BOLT		08
15	0503013496	3982/3920 ROLLER BEARING		01
16	1882970002	GREASE SOAP		01




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503010007	3982/3920 ROLLER BEARING		01
04	0503010059	33287/33462 ROLLER BEARING		01
05	0503010009	RETAINER 00573-B		01
06	0503010086	SEAL 0009B-B		01
07	0551014473	GLOVE		01
08	0503012702	KM-12 NUT		02
09	0503012703	LOCK WASHER		01
10	0503010002	1800 GREASE FITTING		01
11	0503011444	SPRING WASHER		04
12	0503010363	5/16" X 1" BOLT		04
13	0503014048	22 X 1.5 HEX NUT		08
14	0503014050	22 X 1.5 BOLT		08
15	0511068415	PFFP-3770 SEAL GUIDE		01




Item	Code	Description	See page	QT
01	0511054462	17Z GEAR		01
01A	0511061836	17Z GEAR		01
01B	0503011410	ROLLER BEARING		01
01C	0503011105	SEAL RING		01
02	0571015149	TIGHTENER AXLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0501010163	5/8" X 4-1/2" BOLT		01
05	0503010027	5/8" SPRING WASHER		01
06	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0511054462	17Z GEAR		01
01A	0511061836	17Z GEAR		01
01B	0503011410	ROLLER BEARING		01
01C	0503011105	SEAL RING		01
02	0571015150	SLEEVE TENSIONER WHEEL		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0503010027	5/8" SPRING WASHER		01
05	0503010013	5/8" NUT		01
06	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
07	0501012140	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521064556	SUPPORT ASSY TRANSMISSION WHEEL SIDE		01
02	0503010025	3/8" SPRING WASHER		13
03	0503010026	3/8" NUT		11
04	0503010019	1/2" SPRING WASHER		03
05	0503010060	1/2" NUT		03
06	0503010741	1/2" X 2-3/4" BOLT		03
07	0521064555	27Z GEAR		01
08	0503062231	CLUTCH		01
09	0571015139	FIXER PLATE		01
10	0571015138	CHOCK FRICÇÃO		01
11	0571015141	FIXER CENTRAL TRANSMISSION		04
12	0511054461	STRETCHER TOP TRANSMISSION SWIRLED	32	02
13	0503011268	3/8" X 2-1/2" BOLT		01
14	0571015142	FIXER		02
15	0571015143	RIGHT PROTECTION SUPPORT WHEEL		01
16	0503010209	3/8" UNC BUTTERFLY NUT		02
17	0503013542	M10 SPRING WASHER		04
18	0503010188	M10 X 1,5 X 30 BOLT		04




Item	Code	Description	See page	QT
01	0521055499	GEAR WITH NATIONAL BEARING		01
01A	0511061836	17Z GEAR		01
01B	0503019356	BEARING 6005 2RS1		01
01C	0503011105	SEAL RING		01
02	0571015146	TIGHTENER AXLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0501011541	5/8" X 3" BOLT		01
05	0501012140	FLAT WASHER		01
06	0503010027	5/8" SPRING WASHER		01
07	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0501056573	17Z GEAR ASSY	34	01
02	0591011681	STRETCHER SPACER GLOVE		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0511017302	FLAT WASHER		01
06	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503019355	BEARING 6202 2RS1		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0551011625	PROTECTION COVER		01
02	0503010386	CABLE		01
03	0551015037	5/8" UNC X 210 X 198 FASTENER		02
04	0551018630	CARDAN SHAFT GUIDES SLEEVE		01
05	0551018629	GEAR BOX COVER FIXER ROD		01
06	0503010257	1/8" X 1" COTTERPIN		02
07	0503010179	5/16" ZN SPRING WASHER		01
08	0503010337	5/16" NUT		01
09	0501013518	FLAT WASHER		02
10	0521056866	RIGHT SEMI-ASSEMBLED EXCHANGE	36	01
11	0503012412	5/8 UNC SELF LOCKING NUT		04
12	0501012140	FLAT WASHER		04
13	0503011268	3/8" X 2-1/2" BOLT		01
14	0503013357	3/8" SELF-ADJUSTING NUT		01
15	0503034417	LETTER ADHESIVE LABEL		01
16	0503032987	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	37	02
02	0502011758	REAR TENSIONER LEVER		01
03	0551018627	SIDE GEAR BOX DRIVER AXLE		01
04	0503030303	SUPPORT WASHER		05
05	0501056271	BEARING CLOSED	38	02
06	0503010292	0.2" X 1.6" SPRING PIN		05
07	0503010002	1800 GREASE FITTING		01
08	0503010395	1/2" X 1-1/4" BOLT		02
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		02
10	0503012389	1/2 BALL		02
11	0503010060	1/2" NUT		02
12	0503011953	5/16" X 1" BOLT		08
13	0501010694	8.5 X 18 X 1.5 FLAT WASHER		08
14	0503010179	5/16" ZN SPRING WASHER		08
15	0503010337	5/16" NUT		08
16	0501052776	CHAIN TENSIONER RIGHT ASSY GREATEST	39	01
17	0501048790	AXLE WITH LINK ASSY	40	01
18	0503012204	40-1 CHAIN X 82 LINK + RED		01
19	0531060361	RIGHT SIDE EXCHANGE SUPPORT		01
20	0511060396	DRIVE/DRIVEN AXLE CONE		02
21	0591011683	MOVED AXIS		01
22	0511067501	26Z GEAR		01
23	0501010984	FLAT WASHER		01
24	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		01
25	0503010025	3/8" SPRING WASHER		01
26	0503019312	40-1 X 51 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0511061794	CHAIN TENSIONER		01
02	0503031367	SPRING		01
03	0503031805	11Z 1/2" GEAR		02
04	0503010302	501019 SEAL RING		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0521058845	LEFT SIDE COVER MOUNTED	42	01
02	0521058844	SIDE SUPPORT LEFT MOUNTED FERTILIZER	43	01




Item	Code	Description	See page	QT
01	0591013335	MAIN GEAR PROTECTION COVER		01
02	0503013849	1/4" UNC X 3/4" BOLT		04
03	0503010143	1/4" SPRING WASHER		04
04	0503010305	FLAT WASHER		04
05	0591013337	PROTECTION COVER		01
06	0503019412	RIVET SCREW INTERNAL		04




Item	Code	Description	See page	QT
01	0591013336	SIDE LEFT SUPPORT FERTILIZER		01
02	0503062754	GEAR 34Z P.1/2 APT		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		03
05	0503010060	1/2" NUT		03
06	0503030402	PULLEY		01
07	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
08	0503012515	40-1 X CHAIN 77 LINK+ MENDING		01
09	0501011643	3/8 X 1"BOLT		02
10	0503010025	3/8" SPRING WASHER		02
11	0503010026	3/8" NUT		02
12	0531019479	AXLE CHAIN GEAR		01
13	0521069832	15Z GEAR		01
14	0503010282	1/4" X 3/4" BOLT		01
15	0503010143	1/4" SPRING WASHER		01
16	0561011665	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0503034085	BEAN FERTILIZER ASSY		01
02	0503034086	BOX COVER		01
03	0503034087	TUBE COVER PIVOT		02
04	0503034088	WASHER		04
05	0503010131	3/16" X 1-1/2" COTTERPIN		04
06	0503034130	PLATE		01
07	0503032053	BOLT C.A.S.I		04
08	0503034220	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0571016995	FIXER SUPPORT		01
02	0571018437	PRISONER 1/2 X		02
03	0503010060	1/2" NUT		04
04	0503010019	1/2" SPRING WASHER		04
05	0511017302	FLAT WASHER		04
06	0591015040			01




Item	Code	Description	See page	QT
01	0521063601	SUPPORT HYDRAULIC MOTOR		01
02	0521062807	17Z GEAR WITH SLEEVE		01
03	0511052600	STRETCHER HYDRAULIC MOTOR SUPPORT	47	01
04	0571012677	WASHER GUIDE		01
05	0501010937	13.5 X 28 X 3 FLAT WASHER		02
06	0503010060	1/2" NUT		02
07	0503010019	1/2" SPRING WASHER		02
08	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
09	0571012684	FIXING SHAFT		01
10	0571012680	FLAT WASHER		01
11	0503010179	5/16" ZN SPRING WASHER		01
12	0503010025	3/8" SPRING WASHER		01
13	0503010026	3/8" NUT		01
14	0503013758	1/4" X 1-1/2" BOLT		01
15	0503010237	3/8" X 1" BOLT		01
16	0502012768	LINE SUPPORT CLAMP		01
17	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		02
18	0503010811	5/8" UNF SELF ADJUSTING NUT		02
19	0503017392	40-1 X 67 CHAIN LINK + MENDING		01
20	0521063774	GEAR ASSY		01
21	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		02
21A	0502012699	LATCH GLOVE BOX TRANSMISSION		02
21B	0503010256	3/8" X 3/4" BOLT		02




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503012882	BEARING		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0571012703	SLEEVE FLANGE		01
05	0503010479	BOLT		01
06	0511017302	FLAT WASHER		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
001	0531061466	SUPPORT RIGHT SIDE SILO BUTTERS FERTILIZER		01
002	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	57	07
003	0503030275	AGRICULTURAL BEARING		07
004	0502012990	CONICA 14Z SQUARE GEAR		07
005	0501010942	3/8" X 1-1/4" BOLT		28
006	0503010026	3/8" NUT		28
007	0503010025	3/8" SPRING WASHER		28
008	0511014237	3/4" X 110 SQUARE SHAFT		01
009	0521054313	CLOSED BEARING	59	01
010	0503030303	SUPPORT WASHER		04
011	0521054282	BEARING	60	02
012	0501053788	Q3/4" FASTENER AXLE ASSY	61	04
013	0511061759	22Z P12,70 FQ 3/4" GEAR		01
014	0503034396	FERTILIZER SIDE COVER		07
015	0503010362	1/8" X 1.1/4" COTTERPIN		07




Item	Code	Description	See page	QT
01	0503030303	SUPPORT WASHER		01
02	0501053788	Q3/4" FASTENER AXLE ASSY	61	02
03	0521054282	BEARING	60	02
04	0502012990	CONICA 14Z SQUARE GEAR		06
05	0503030275	AGRICULTURAL BEARING		07
06	0501010942	3/8" X 1-1/4" BOLT		28
07	0503010025	3/8" SPRING WASHER		28
08	0503010026	3/8" NUT		28
09	0531061716	FERTILIZER RIGHT SUPPORT		01
10	0521054313	CLOSED BEARING	59	01
11	0503034396	FERTILIZER SIDE COVER		06
12	0503010362	1/8" X 1.1/4" COTTERPIN		06
13	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	57	06
14	0511014237	3/4" X 110 SQUARE SHAFT		01
15	0511062163	FERTILIZER BEAM LOWER COVER		01




Item	Code	Description	See page	QT
01	0521055365	SEED CONDUCTOR	64	06
02	0521050525	FIXER FERTILIZER CONDUCTOR	63	06
03	0521051407	FIXER SILO FERTILIZER	62	10
04	0531061715	RIGHT SEED SUPPORT		01
05	0503062964	SILO SEED 03 MOUTH		01
06	0503062961	FERTILIZER BEAM ASSY		01
07	0521055370	SEED CONDUCTOR	51	01




Item	Code	Description	See page	QT
01	0503010179	5/16" ZN SPRING WASHER		01
02	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
03	0503010499	5/16" UNC BUTTERFLY NUT		01
04	0503011953	5/16" X 1" BOLT		01
05	0503012880	1/4" UNC SELF ADJUSTING NUT		04
06	0581019780	COVER		01
07	0502012899	DUCT BODY		01
08	0503034859	JOIN		01
09	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		04



Item	Code	Description	See page	QT
01	0591016375	PLATAFORM		01
02	0521054279	PLATFORM FIXER	68	03




Item	Code	Description	See page	QT
01	0581017698	TROUGH 30 X 55 X 2180		01
02	0521055102	BIGGEST FULL GUTTER SUPPORT	75	02




Item	Code	Description	See page	QT
01	0511059943	SUPPORT FASTENER ASSY	77	01
02	0511059928	SIDE DUTY SUPPORT	78	01
03	0581018407	BODY FASTENER 2 DUCTS		04
04	0521069713	OIL TUBE		02
05	0503011268	3/8" X 2-1/2" BOLT		02
06	0503010025	3/8" SPRING WASHER		02
07	0503010026	3/8" NUT		02


01



0503034679



0503032986



0503033416




0503033621



0503031827




0503033424




0503031565


Item	Code	Description	See page	QT
01	0503034679	ADHESIVE LABEL		01
02	0503032986	ADHESIVE LABEL		01
03	0503033621	ADHESIVE LABEL		01
04	0503033424	DIRECT PLANTIO ADHESIVE LABEL		01
05	0503033416	ADHESIVE LABEL		02
06	0503031827	LUBRICATE AND RETIGHTEN DAILY DECAL		01
07	0503031565	ADHESIVE LABEL CARE		01




Item	Code	Description	See page	QT
001	0503062927	SILO FERTILIZER 3 MOUTHS		01
002	0503062362	SILO FERTILIZER 04 MOUTH	44	01
003	0521059569	SUPPORT RIGHT SIDE SILO FULL FERTILIZER	58	01
004	0521051407	FIXER SILO FERTILIZER	62	10




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
001	0531061468	SUPPORT RIGHT SIDE SILO FERTILIZER		01
002	0503062961	FERTILIZER BEAM ASSY		01
003	0521050525	FIXER FERTILIZER CONDUCTOR	63	07
004	0521051407	FIXER SILO FERTILIZER	62	10
005	0521055365	SEED CONDUCTOR	64	07
006	0503062964	SILO SEED 03 MOUTH		01




Item	Code	Description	See page	QT
01	0501056271	BEARING CLOSED	38	01
01A	0502012310	GEAR BOX CLOSE BEARING		01
01B	0503013462	BEARING WITH BALL BEARING		01
01C	0503011105	SEAL RING		01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	37	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0503012531	3/8" INOX NUT		01
02	0503012535	3/8" SPRING WASHER		01
03	0571019051	FIXER BOX WASHER		01
04	0503013751	3/8 UNC X 1.1/4 BOLT		01




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010365	NUT		02




Item	Code	Description	See page	QT
01	0521069705	CONDUCTOR FIXER		01
02	0503010358	5/16" X 5/8" BOLT		02
03	0503010337	5/16" NUT		02
04	0503010179	5/16" ZN SPRING WASHER		03
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
06	0503010499	5/16" UNC BUTTERFLY NUT		01
07	0503011953	5/16" X 1" BOLT		01
08	0503013759	NUT		04
09	0581019780	COVER		01
10	0502012899	DUCT BODY		01
11	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		04
12	0503034859	JOIN		01




Item	Code	Description	See page	QT
01	0521069333	DEPTH SUPPORT		01
02	0551015037	5/8" UNC X 210 X 198 FASTENER		02
03	0541012939	5/8 UNC X 141 X 120 FASTENER		02
04	0501012140	FLAT WASHER		08
05	0503013389	5/8" SELF LOCKING NUT		08
06	0503010920	1/2" X 1.1/2" BOLT		06
07	0503010060	1/2" NUT		06
08	0511017302	FLAT WASHER		12
09	0503010019	1/2" SPRING WASHER		06




Item	Code	Description	See page	QT
01	0521068962	HANDLE		01
02	0503013357	3/8" SELF-ADJUSTING NUT		02
03	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
001	0591015758	PLATFORM 2920		01
002	0521054279	PLATFORM FIXER	68	02




Item	Code	Description	See page	QT
01	0581018560	PLATFORM SUPPORT		01
02	0503010395	1/2" X 1-1/4" BOLT		02
03	0503010589	1/2" UNC SELF ADJUSTING NUT		03
04	0511017302	FLAT WASHER		01
05	0501010063	1/2" X 1-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0591015465	RIGHT BODY INTERNAL HANDRAIL 237		01
02	0591015466	BODY L INTERNAL HANDRAIL 170 X 727		01
03	0581012718	HANDRAIL		01
04	0511059383	INTERNAL FIXER ASSY HANDLE	70	02
05	0503013357	3/8" SELF-ADJUSTING NUT		02
06	0591011198	50MM HANDRAIL SUPPORT		02
07	0501010984	FLAT WASHER		02
08	0503011268	3/8" X 2-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0502012857	EXTERNAL FIXER HANDRAIL		01
02	0502012858	INTERNAL FIXER HANDRAIL		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		01
04	0503015490	SELF-LOCKING NUT 7/16		01



Item	Code	Description	See page	QT
01	0591015464	LEFT BODY INTERNAL HANDRAIL 237		01
02	0591015466	BODY L INTERNAL HANDRAIL 170 X 727		01
03	0581012718	HANDRAIL		01
04	0511059383	INTERNAL FIXER ASSY HANDLE	70	02
05	0503013357	3/8" SELF-ADJUSTING NUT		02
06	0591011198	50MM HANDRAIL SUPPORT		02
07	0501010984	FLAT WASHER		02
08	0503011268	3/8" X 2-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0521069329	ASSY SIDE LADDER		01
02	0502012742	FIXER SUPPORT LADDER		02
03	0503013357	3/8" SELF-ADJUSTING NUT		02
04	0501010984	FLAT WASHER		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0503010237	3/8" X 1" BOLT		04
07	0503010025	3/8" SPRING WASHER		04
08	0503010026	3/8" NUT		04
09	0503030403	1.85" X 2.87" BEATER		02



01

0503034679



02

0503032986



03

0503033621



04

0503033424



05

0503033416



06

0503033418



07


0503031827




08

0503031565


Item	Code	Description	See page	QT
01	0503034679	ADHESIVE LABEL		01
02	0503032986	ADHESIVE LABEL		01
03	0503033621	ADHESIVE LABEL		01
04	0503033424	DIRECT PLANTIO ADHESIVE LABEL		01
05	0503033416	ADHESIVE LABEL		01
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		01
07	0503031827	LUBRICATE AND RETIGHTEN DAILY DECAL		01
08	0503031565	ADHESIVE LABEL CARE		01




Item	Code	Description	See page	QT
001	0581017745	TROUGH 30 X 55 X 2420		01
002	0521055102	BIGGEST FULL GUTTER SUPPORT	75	03




Item	Code	Description	See page	QT
01	0581019560	SOPORTE CONDUCTOR		01
02	0503010025	3/8" SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0503013029	3/8" X 3/4" BOLT		01
05	0501011643	3/8 X 1"BOLT		01




Item	Code	Description	See page	QT
001	0511059943	SUPPORT FASTENER ASSY	77	02
002	0511059928	SIDE DUTY SUPPORT	78	01
003	0581018407	BODY FASTENER 2 DUCTS		02
004	0581018409	FASTENER BODY		04
005	0521069271	OIL DUCT R.3/4 X 2950		02
006	0521069713	OIL TUBE		02
007	0503011268	3/8" X 2-1/2" BOLT		05
008	0503010025	3/8" SPRING WASHER		05
009	0503010026	3/8" NUT		05




Item	Code	Description	See page	QT
01	0581011417	DUTO HOLDER SUPPORT		01
02	0503010237	3/8" X 1" BOLT		02
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0581013094	DUTO HOLDER SUPPORT		01
02	0571019756	FASTENER 1/2 UNC X 220 X 198 ZN		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0571013341	HEX AXLE		02
02	0561015837	SLEEVE 31,75		01
03	0503010523	1/4" X 2" COTTERPIN		01
04	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		04
04A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
04B	0503010256	3/8" X 3/4" BOLT		01




Item	Code	Description	See page	QT
01	0561016762	3/4 X 2390 HEX AXLE		02
02	0561015837	SLEEVE 31,75		01
03	0503010523	1/4" X 2" COTTERPIN		01
04	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		04
04A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
04B	0503010256	3/8" X 3/4" BOLT		01




Item	Code	Description	See page	QT
01	0503010257	1/8" X 1" COTTERPIN	02	
02	0503010026	3/8" NUT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010144	1/4" NUT	08	
05	0503010143	1/4" SPRING WASHER	08	
06	0503010060	1/2" NUT	04	
07	0503010019	1/2" SPRING WASHER	04	
08	0511017302	FLAT WASHER	04	
09	0503010237	3/8" X 1" BOLT	04	
10	0521068017	BOX BODY APT/TVT	01	
11	0571017090	ROD BOX	01	
12	0521068016	BOX COVER	01	
13	0503018171	FAST LOCK ASSY	02	
14	0501013518	FLAT WASHER	04	
15	0501010161	1/2" X 1.1/4" BOLT	04	
16	0581014889	SUPPORT BOX	02	
17	0503010461	1/4" X 1" BOLT	04	
18	0503010282	1/4" X 3/4" BOLT	04	




Item	Code	Description	See page	QT
01	0521058842	SIDE SUPPORT RIGHT FERTILIZER ASSEMBLED	83	01
02	0521058843	RIGHT SIDE COVER ASSEMBLED	84	01




Item	Code	Description	See page	QT
01	0503062754	GEAR 34Z P.1/2 APT		01
02	0591013333	SIDE SUPPORT RIGHT FERTILIZER		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		03
05	0503010060	1/2" NUT		03
06	0503030402	PULLEY		01
07	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
08	0503012515	40-1 X CHAIN 77 LINK+ MENDING		01
09	0501011643	3/8 X 1"BOLT		02
10	0503010025	3/8" SPRING WASHER		02
11	0503010026	3/8" NUT		02
12	0531019479	AXLE CHAIN GEAR		01
13	0521069832	15Z GEAR		01
14	0503010282	1/4" X 3/4" BOLT		01
15	0503010143	1/4" SPRING WASHER		01
16	0561011665	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0503013849	1/4" UNC X 3/4" BOLT		04
02	0503010143	1/4" SPRING WASHER		04
03	0503010305	FLAT WASHER		04
04	0591013335	MAIN GEAR PROTECTION COVER		01
05	0591013334	PROTECTION COVER		01
06	0503019412	RIVET SCREW INTERNAL		04




Item	Code	Description	See page	QT
01	0531050094	CENTRAL DUCT ASSY	86	01
02	0503063242	COMMAND BLOCK		01
03	0521057013	TRIPLE DIVISER VALVE BRP00079 WITH NIPLES	129	01
04	0531050058	SUPPORT ASSY BLOCK/VALVES	120	01
05	0531050097	ASSY HOSE LIFTING FERTILIZER/SEED	125	01
06	0521055274	HEAD HOSE ASSY	124	01
07	0531050351	ARTICULATED FERTILIZER / SEED HOSE ASSY	123	01
08	0531051058	SET FERTILIZER AND SEED HOSE	126	01
09	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	128	04
10	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0521069339	OIL TUBE		04
02	0521069338	OIL TUBE		02
03	0521069009	OIL DUCT		01
04	0521069275	OIL TUBE		02
05	0521069341	OIL DUCT R.3/4 X 1050		06
06	0521053537	CENTRAL REAR DUCT SUPPORT	119	04
07	0503013029	3/8" X 3/4" BOLT		04
08	0503010237	3/8" X 1" BOLT		08
09	0503010481	BOLT		08
10	0503010025	3/8" SPRING WASHER		20
11	0503010026	3/8" NUT		20
12	0591010127	SUPPORT LEFT DISTRIBUTOR		02
13	0581014867	SIDE DUTY SUPPORT		02



Item	Code	Description	See page	QT
01	0521064557	SUPPORT SET TRANSMISSION WHEEL SIDE		01
02	0571015141	FIXER CENTRAL TRANSMISSION		04
03	0571015151	SUPPORT BEARING		01
04	0521061795	27Z GEAR		01
05	0501053654	DOUBLE BEARING TRANSMISSION SEED 3/4		01
06	0503010025	3/8" SPRING WASHER		08
07	0503010026	3/8" NUT		08
08	0503010019	1/2" SPRING WASHER		03
09	0503010060	1/2" NUT		03
10	0503010337	5/16" NUT		02
11	0503011953	5/16" X 1" BOLT		02
12	0503010179	5/16" ZN SPRING WASHER		02
13	0503010707	501030 CLAMPING RING (FOR AXLE)		02
14	0503010741	1/2" X 2-3/4" BOLT		03
15	0511054461	STRETCHER TOP TRANSMISSION SWIRLED	32	02




Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0591012478	HOLE TRANSMISSION STRETCHER AXLE 13		01
03	0503011410	ROLLER BEARING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503011105	SEAL RING		01
06	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		01
07	0511017302	FLAT WASHER		01
08	0503010060	1/2" NUT		01
09	0503010019	1/2" SPRING WASHER		01




Item	Code	Description	See page	QT
01	0521064562	CENTRAL GEAR BOX SUPPORT		01
02	0501056271	BEARING CLOSED	38	03
03	0571015170	CENTRAL GEAR BOX DRIVER AXLE		01
04	0503030303	SUPPORT WASHER		04
05	0591011682	CENTRAL EXCHANGE MOVED AXIS		01
06	0503010179	5/16" ZN SPRING WASHER		09
07	0503010337	5/16" NUT		09
08	0501010984	FLAT WASHER		03
09	0503011953	5/16" X 1" BOLT		06
10	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
11	0503010292	0.2" X 1.6" SPRING PIN		04
12	0503010395	1/2" X 1-1/4" BOLT		02
13	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		02
14	0503012389	1/2 BALL		02
15	0503010060	1/2" NUT		06
16	0502011758	REAR TENSIONER LEVER		01
17	0503010002	1800 GREASE FITTING		01
18	0503010025	3/8" SPRING WASHER		05
19	0503010683	0.2" X 1.2" SPRING PIN		01
20	0501048790	AXLE WITH LINK ASSY	40	01
21	0503012204	40-1 CHAIN X 82 LINK + RED		01
22	0501052778	CHAIN TENSIONER ASSY	90	01
23	0521018630	1.4" X SQUARE 0.8" WASHER		08
24	0511065209	20Z GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0511054489	LEFT TENSIONER CENTRAL EXCHANGE	91	01
27	0511060396	DRIVE/DRIVEN AXLE CONE		02
28	0571015172	CENTRAL GEAR BOX COVER		01
29	0551018585	CENTRAL GEAR BOX COVER SLEEVE		02
30	0503010371	5/16" X 1" BOLT		02
31	0503010386	CABLE		01


Item	Code	Description	See page	QT
32	0511056179	CLUTCH WITH CARDAN CENTRAL	92	01
33	0503010172	M10 X 1,5 X 25 BOLT		04
34	0511069512	20Z GEAR		01
35	0503011268	3/8" X 2-1/2" BOLT		01
36	0503013357	3/8" SELF-ADJUSTING NUT		01
37	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
38	0511017302	FLAT WASHER		08
39	0503010019	1/2" SPRING WASHER		04
40	0503011082	C1/2" X 1.3/4" SCREW		04
41	0511067501	26Z GEAR		01
42	0501056443	BEARING ASSY GEAR BOX	93	01
43	0503010256	3/8" X 3/4" BOLT		01
44	0503013215	40-1 CHAIN X 89 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503010302	501019 SEAL RING		02
03	0503031805	11Z 1/2" GEAR		02
04	0503031367	SPRING		01
05	0511061794	CHAIN TENSIONER		01




Item	Code	Description	See page	QT
01	0501056573	17Z GEAR ASSY	34	01
01A	0502012367	17Z X P 1/2" GEAR INTERM		01
01B	0503012882	BEARING		01
01C	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02	0503010019	1/2" SPRING WASHER		01
03	0503010060	1/2" NUT		01
04	0571015167	SLEEVE NYLON Ø21 X Ø31,75 X 36,50		01
05	0503010479	BOLT		01
06	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0503062231	CLUTCH		01
02	0503062272	CARDAN WITHOUT PROTECTION		01
03	0503013357	3/8" SELF-ADJUSTING NUT		02
04	0503011268	3/8" X 2-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	37	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531060360	BOX SUPPORT		01
02	0521056857	ECU APT / TVT BOX WITH EXCHANGE	95	01
03	0503010589	1/2" UNC SELF ADJUSTING NUT		04
04	0511017302	FLAT WASHER		04
05	0561016468	FASTENER		02




Item	Code	Description	See page	QT
01	0503010257	1/8" X 1" COTTERPIN		02
02	0503010026	3/8" NUT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010144	1/4" NUT		08
05	0503010143	1/4" SPRING WASHER		08
06	0503010237	3/8" X 1" BOLT		04
07	0521068017	BOX BODY APT/TVT		01
08	0571017090	ROD BOX		01
09	0521068016	BOX COVER		01
10	0503018171	FAST LOCK ASSY		02
11	0503010461	1/4" X 1" BOLT		04
12	0503010282	1/4" X 3/4" BOLT		04




Item	Code	Description	See page	QT
001	0503062391	SILO FERTILIZER 05 MOUTHS	106	02
002	0521059025	CENTRAL SUPPORT LEFT 5 MOUTH FULL FERTILIZER	107	01
003	0521059028	RIGHT CENTRAL SUPPORT 5 MOUTH FULL FERTILIZER	108	01
004	0511017302	FLAT WASHER		12
005	0503010589	1/2" UNC SELF ADJUSTING NUT		12
006	0503010920	1/2" X 1.1/2" BOLT		24
007	0521051407	FIXER SILO FERTILIZER	62	16
008	0503010010	1/4" X 2.1/2" COTTERPIN		01
009	0502012007	SQUARE SLEEVE		01




Item	Code	Description	See page	QT
01	0503062391	SILO FERTILIZER 05 MOUTHS	106	02
02	0531050059	RIGHT CENTRAL SUPPORT	98	01
03	0521059025	CENTRAL SUPPORT LEFT 5 MOUTH FULL FERTILIZER	107	01
04	0511017302	FLAT WASHER		12
05	0503010589	1/2" UNC SELF ADJUSTING NUT		12
06	0503010920	1/2" X 1.1/2" BOLT		12
07	0521051407	FIXER SILO FERTILIZER	62	16
08	0503010010	1/4" X 2.1/2" COTTERPIN		01
09	0502012007	SQUARE SLEEVE		01




Item	Code	Description	See page	QT
01	0531061297	SUIT CENTRAL RIGHT 5 MOUTH		01
02	0521054282	BEARING	60	03
03	0503030303	SUPPORT WASHER		02
04	0501053788	Q3/4" FASTENER AXLE ASSY	61	02
05	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	109	04
06	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	57	01
07	0503030275	AGRICULTURAL BEARING		05
08	0581019781	AXE CARRÉ		01
09	0503010025	3/8" SPRING WASHER		20
10	0501010942	3/8" X 1-1/4" BOLT		20
11	0503010026	3/8" NUT		20
12	0503034396	FERTILIZER SIDE COVER		05
13	0503010362	1/8" X 1.1/4" COTTERPIN		05
14	0502012990	CONICA 14Z SQUARE GEAR		05




Item	Code	Description	See page	QT
01	0591010469	PLATFORM 2300		02
02	0521054279	PLATFORM FIXER	68	04




Item	Code	Description	See page	QT
01	0581018654	GUTTER 24 X 46 X 1000		02
02	0581017952	GUTTER 30 X 55 X 1660		01
03	0581017683	GUTTER 30 X 55 X 2660		01
04	0521055102	BIGGEST FULL GUTTER SUPPORT	75	04




Item	Code	Description	See page	QT
01	0521054283	HEADLIGHT WITH SUPPORT	132	03
02	0521059393	LED FLASHLIGHT WITH FIXATION SUPPORT	133	02
03	0521057882	ELECTRIC ASSEMBLY BCE (ASSEMBLED) APT 15MT/3F-L		01
03A	0503019691	WHIP LIGHTHOUSE / LANTERN		01
03B	0503019337	COMMAND BLOCK WHIP		01
04	0503018829	NYLON CLAMP		20
05	0503019902	NYLON CLAMP 7,8X1,8X225 MM		80
06	0521055426	ASSY ELECTRICAL BOX SUPPORT	134	01




Item	Code	Description	See page	QT
01	0503063277	KIT INTELLIAG ISO6 6C 22L 45/50 MS		01
02	0511056972	FILTER HYDAC	138	01
03	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	137	06
04	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		330
05	0503013100	NYLON CLAMP		110
06	0503019291	SUPPORT SENSOR		01
07	0521054490	FLOW DIVIDING VALVE ASSY		01




Item	Code	Description	See page	QT
01	0521055365	SEED CONDUCTOR	64	06
02	0521050525	FIXER FERTILIZER CONDUCTOR	63	06
03	0521051407	FIXER SILO FERTILIZER	62	10
04	0531061718	SEED LEFT SUPPORT		01
05	0503062964	SILO SEED 03 MOUTH		01
06	0503062961	FERTILIZER BEAM ASSY		01
07	0521055370	SEED CONDUCTOR	51	01




Item	Code	Description	See page	QT
01	0503030303	SUPPORT WASHER		01
02	0501053788	Q3/4" FASTENER AXLE ASSY	61	02
03	0521054282	BEARING	60	02
04	0502012990	CONICA 14Z SQUARE GEAR		06
05	0503030275	AGRICULTURAL BEARING		07
06	0501010942	3/8" X 1-1/4" BOLT		28
07	0503010025	3/8" SPRING WASHER		28
08	0503010026	3/8" NUT		28
09	0531061717	FERTILIZER LEFT SUPPORT		01
10	0521054313	CLOSED BEARING	59	01
11	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	109	06
12	0503034396	FERTILIZER SIDE COVER		06
13	0503010362	1/8" X 1.1/4" COTTERPIN		06
14	0511014237	3/4" X 110 SQUARE SHAFT		01
15	0511062163	FERTILIZER BEAM LOWER COVER		01




Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
02	0503010019	1/2" SPRING WASHER		02
03	0503010060	1/2" NUT		02
04	0521069319	LEFT FERTILIZER CONDUCTOR		01




Item	Code	Description	See page	QT
01	0503034127	FERTILIZER BEAM COVER		01
02	0503034129	LOWER COVER		01
03	0503034128	UPPER COVER		01
04	0503034130	PLATE		01
05	0503032053	BOLT C.A.S.I		04
06	0503034220	FLAT WASHER		04
07	0503034087	TUBE COVER PIVOT		04
08	0503034088	WASHER		08
09	0503010131	3/16" X 1-1/2" COTTERPIN		08




Item	Code	Description	See page	QT
001	0521054282	BEARING	60	03
002	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	109	01
003	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	57	04
004	0581019781	AXE CARRÉ		01
005	0503030275	AGRICULTURAL BEARING		05
006	0503030303	SUPPORT WASHER		02
007	0501053788	Q3/4" FASTENER AXLE ASSY	61	02
008	0531061294	CENTRAL SUPPORT LEFT 5 MOUTH FERTILIZER		01
009	0503010025	3/8" SPRING WASHER		20
010	0501010942	3/8" X 1-1/4" BOLT		20
011	0503010026	3/8" NUT		20
012	0503034396	FERTILIZER SIDE COVER		05
013	0503010362	1/8" X 1.1/4" COTTERPIN		05
014	0502012990	CONICA 14Z SQUARE GEAR		05




Item	Code	Description	See page	QT
001	0531061297	SUIT CENTRAL RIGHT 5 MOUTH		01
002	0521054282	BEARING	60	03
003	0503030303	SUPPORT WASHER		04
004	0501053788	Q3/4" FASTENER AXLE ASSY	61	04
005	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	109	04
006	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	57	01
007	0503030275	AGRICULTURAL BEARING		05
008	0581019781	AXE CARRÉ		01
009	0503010025	3/8" SPRING WASHER		20
010	0501010942	3/8" X 1-1/4" BOLT		20
011	0503010026	3/8" NUT		20
012	0511061759	22Z P12,70 FQ 3/4" GEAR		01
013	0503034396	FERTILIZER SIDE COVER		05
014	0503010362	1/8" X 1.1/4" COTTERPIN		05
015	0502012990	CONICA 14Z SQUARE GEAR		05




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
001	0531061295	CENTRAL SUPPORT RIGHT FERTILIZER		01
002	0503062962	SILO SEED 05 ASSY MOUTH		01
003	0521051407	FIXER SILO FERTILIZER	62	08
004	0511017302	FLAT WASHER		06
005	0503010920	1/2" X 1.1/2" BOLT		06
006	0521050525	FIXER FERTILIZER CONDUCTOR	63	05
007	0521055365	SEED CONDUCTOR	64	05
008	0503010589	1/2" UNC SELF ADJUSTING NUT		06




Item	Code	Description	See page	QT
001	0531061296	CENTRAL SUPPORT LEFT FERTILIZER		01
002	0503062962	SILO SEED 05 ASSY MOUTH		01
003	0521055365	SEED CONDUCTOR	64	05
004	0511017302	FLAT WASHER		06
005	0503010920	1/2" X 1.1/2" BOLT		06
006	0521051407	FIXER SILO FERTILIZER	62	08
007	0521050525	FIXER FERTILIZER CONDUCTOR	63	05
008	0503010589	1/2" UNC SELF ADJUSTING NUT		06




Item	Code	Description	See page	QT
01	0581019588	PLATFORM 2380		02
02	0521054279	PLATFORM FIXER	68	04




Item	Code	Description	See page	QT
01	0521064536	LH PIVOT ARM		01
02	0561015688	PIVOT SMALLE AXLE		01
03	0501010452	5/8" X 5" BOLT		01
04	0503010027	5/8" SPRING WASHER		01
05	0503010013	5/8" NUT		01
06	0503010002	1800 GREASE FITTING		02
07	0503032042	SHEET POLYETHYLENE		01
08	0503010814	5/16 BOLT		14
09	0521063779	PIVOT SHAFT		01
10	0503015322	BOLT 7/8		01
11	0503010408	7/8" SPRING WASHER		01




Item	Code	Description	See page	QT
01	0521064551	RH PIVOT ARM		01
02	0503032042	SHEET POLYETHYLENE		01
03	0503010814	5/16 BOLT		14
04	0561015688	PIVOT SMALLE AXLE		01
05	0503010002	1800 GREASE FITTING		02
06	0501010452	5/8" X 5" BOLT		01
07	0503010027	5/8" SPRING WASHER		01
08	0503010013	5/8" NUT		01
09	0521063779	PIVOT SHAFT		01
10	0503010408	7/8" SPRING WASHER		01
11	0503015322	BOLT 7/8		01




Item	Code	Description	See page	QT
01	0511058226	HYDRAULIC CYLINDER 50,80 X 114,30 X 810 X 1300	116	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		04
03	0503010523	1/4" X 2" COTTERPIN		02




Item	Code	Description	See page	QT
01	0521066553	SHIRT 114.30 X 679 USAP		01
02	0581010657	ROD 50.80 X 695 USAP		01
03	0502040747	32.54 CLEVIS CLAMP		01
04	0502011222	0.56" END CAP		01
05	0503010952	W2-2250-500 RING		01
06	0503011094	3/8" X 2" BOLT		01
07	0503010025	3/8" SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503030384	CON PLUG N-001		02
10	0581010659	2" X 4" RING SUPPORT		01
11	0503010039	D-2000 SCRAPER RING		01
12	0503018026	1870-2000-375 B GASKET		01
13	0503018024	RING BS		01
14	0503011892	O' RING, 2-346 N 3006-9B		02
15	0503011893	BACK-UP RING, 8-346		02
16	0581010658	EMBOLO 50,80 X 114,30 USAP		01
17	0503018164	GAXETA 2500-4000-375 B (1150 AGEL)		02
18	0503010290	SELF ADJUSTING 1.1/2" UNF NUT		01
19	0503010141	2-226 N 3006-9B O'RING		01
20	0503018165	GUIDE RING W2-4500-590		01
21	0511032868	ASSY CYLINDER REPAIR KIT 50,8 X 114,3 (0511058401)		01




Item	Code	Description	See page	QT
001	0521059620	CENTRAL FERTILIZER DUCT SET	118	01
002	0503063242	COMMAND BLOCK		01
003	0531050058	SUPPORT ASSY BLOCK/VALVES	120	01
004	0531050057	MH SEQUENTIAL VALVE SUPPORT WITH FIXATION	121	01
005	0521052155	SEQUENTIAL VALVE ASSY	122	01
006	0531050351	ARTICULATED FERTILIZER / SEED HOSE ASSY	123	01
007	0521055274	HEAD HOSE ASSY	124	01
008	0531050097	ASSY HOSE LIFTING FERTILIZER/SEED	125	01
009	0531051058	SET FERTILIZER AND SEED HOSE	126	01
010	0521055402	HOSE KIT MH/CH 12910	127	01
011	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	128	06
012	0571017774	SPRING PROTECTION QUICK HOSE		01
013	0521057013	TRIPLE DIVISER VALVE BRP00079 WITH NIPLES	129	01




Item	Code	Description	See page	QT
001	0521069339	OIL TUBE		02
002	0521069338	OIL TUBE		02
003	0521069009	OIL DUCT		01
004	0521069275	OIL TUBE		02
005	0521069341	OIL DUCT R.3/4 X 1050		10
006	0581018409	FASTENER BODY		12
007	0521053537	CENTRAL REAR DUCT SUPPORT	119	04
008	0503013029	3/8" X 3/4" BOLT		04
009	0503010237	3/8" X 1" BOLT		08
010	0503010481	BOLT		08
011	0503010025	3/8" SPRING WASHER		20
012	0503010026	3/8" NUT		20
013	0591010127	SUPPORT LEFT DISTRIBUTOR		02
014	0581014867	SIDE DUTY SUPPORT		02




Item	Code	Description	See page	QT
01	0571019615	FITTING 1/2 UNC 130 X 198 ZN		01
02	0511017302	FLAT WASHER		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0503010025	3/8" SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581017885	SUPPORT BODY		01
08	0503011141	3/8" X 2-3/4" BOLT		01
09	0581018407	BODY FASTENER 2 DUCTS		01




Item	Code	Description	See page	QT
01	0591016376	VALVE SUPPORT		01
02	0503010172	M10 X 1,5 X 25 BOLT		03
03	0503010025	3/8" SPRING WASHER		03
04	0511017302	FLAT WASHER		02
05	0591016360	BLOCK SUPPORT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		02
07	0503011082	C1/2" X 1.3/4" SCREW		02




Item	Code	Description	See page	QT
01	0591016361	VALVE SUPPORT		01
02	0501010984	FLAT WASHER		02
03	0503010237	3/8" X 1" BOLT		02
04	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501012109	3/4" X 9/16" NIPPLE		04
03	0501010617	3/4" NIPPLE		02
04	0503010190	2-114 N 3006-9B O'RING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02
07	0501010984	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		02
09	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0501081108	3/8 X 1400 TC-TC HOSE		01
02	0501080514	3/8 X 1700 TC-TC HOSE		01
03	0501080055	3/8 X 1000 TR-TC HOSE		02
04	0501080150	3/8 X 800 TR-TC HOSE		02




Item	Code	Description	See page	QT
01	0501080461	3/8 X 1800 TR-TC HOSE		02
02	0501080297	3/8 X 2800 TR-TR HOSE		02
03	0501080526	3/8 X 2900 TR-TC HOSE		01
04	0501080527	3/8 X 3300 TR-TC HOSE		01




Item	Code	Description	See page	QT
01	0501081837	3/8 X 700 TR-TC HOSE		04
02	0501080700	3/8 X 650 TC-TC HOSE		02
03	0501080599	3/8 X 650 TR-TC HOSE		02
04	0501081838	3/8 X 1000 TR-TC HOSE		04
05	0501080065	3/8 X 1200 TC-TC HOSE		01
06	0501080675	3/8 X 1000 TC-TC 180G HOSE		03
07	0501080105	3/8 X 700 TR-TR HOSE		04
08	0501080302	TR-TC HOSE ASSY		01
09	0501080714	3/8 X 1600 TR-TC HOSE		01
10	0501082204	3/4 X 2750 TR-TR HOSE		02
11	0501081288	3/4 X 500 TR-TC HOSE		01
12	0521053712	3/4 X 5900 TR-TM BLACK/RED HOSE		01
12A	0501082205	3/4 X 5900 TR-TM HOSE		01
12B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
12C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
12D	0503018952	PLASTIC BOLT		06
13	0521053707	3/4 X 5900 TR-TM BLACK/BLUE HOSE		01
13A	0501082205	3/4 X 5900 TR-TM HOSE		01
13B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
13C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
13D	0503018952	PLASTIC BOLT		06
14	0501080485	3/8 X 1100 TR-TC HOSE		02
15	0501080200	3/4 X 1600 TR-TC HOSE		01
16	0501080150	3/8 X 800 TR-TC HOSE		02
17	0501080023	3/4 X 1700 TR-TC HOSE		02
18	0501081160	HOSE 3/4 X 1350 TR-TC		01




Item	Code	Description	See page	QT
01	0501081834	1/2 X 1500 TR-TC HOSE		03
02	0501081041	1/2 X 2400 TR-TC HOSE		03
03	0501080060	1/2 X 1600 TR-TC HOSE		01
04	0521052567	1/2 X 5900 TR-TM GRAY/RED HOSE		01
04A	0501081841	1/2 X 5900 TR-TM HOSE		01
04B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
04C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
04D	0503018952	PLASTIC BOLT		06
05	0521052566	1/2 X 5900 TR-TM GRAY/BLUE HOSE		01
05A	0501081841	1/2 X 5900 TR-TM HOSE		01
05B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
05C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
05D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0501081820	3/8 X 1700 TR-TC HOSE		02
02	0501081851	3/8 X 1400 TR-TC HOSE		02
03	0501080105	3/8 X 700 TR-TR HOSE		04
04	0501080352	3/8 X 1400 TR-TR HOSE		04
05	0501081975	3/8 X 1450 TR-TC HOSE		02
06	0501080297	3/8 X 2800 TR-TR HOSE		02
07	0521052592	3/8 X 5900 TR-TM PURPLE/BLUE HOSE		01
07A	0501082100	3/8 X 5900 TR-TM HOSE		01
07B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
07C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
07D	0503018952	PLASTIC BOLT		01
08	0521052593	3/8 X 5900 TR-TM PURPLE/RED HOSE		01
08A	0501082100	3/8 X 5900 TR-TM HOSE		01
08B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
08C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
08D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0503019426	TRIPLE FLOW DIVISING VALVE		01
02	0581013111	NIPLE R 1.1/6 UN X 1.5/16 12 WIRES		01
03	0503014724	2-215 N 3006-9B O'RING		01
04	0501010984	FLAT WASHER		04
05	0503010045	O'RING		03
06	0511010111	7/8" NIPPLE		02
07	0503013357	3/8" SELF-ADJUSTING NUT		04
08	0503010237	3/8" X 1" BOLT		04
09	0501012520	1-1/16" X 7/8" NIPPLE		01




Item	Code	Description	See page	QT
001	0581017745	TROUGH 30 X 55 X 2420		01
002	0581017744	GUTTER 30 X 55 X 1530		01
003	0581018654	GUTTER 24 X 46 X 1000		02
004	0521055102	BIGGEST FULL GUTTER SUPPORT	75	04




Item	Code	Description	See page	QT
01	0521054283	HEADLIGHT WITH SUPPORT	132	03
02	0521059393	LED FLASHLIGHT WITH FIXATION SUPPORT	133	02
03	0521057879	ECB ELECTRIC ASSEMBLY (ASSEMBLED)		01
03A	0503019329	COMMAND PANEL		01
03B	0503019061	WHIP		01
03C	0503019060	WHIP		01
03D	0503019390	WHIP BLOCK COMMAND IMPLEMENT		01
03E	0503019572	WHIP 3 HEADLIGHTS		01
03F	0503019694	LED LANTERN EXTENSOR WHIP 15M 4320.8 BCE		01
04	0503018829	NYLON CLAMP		20
05	0503019902	NYLON CLAMP 7,8X1,8X225 MM		80
06	0521055426	ASSY ELECTRICAL BOX SUPPORT	134	01
07	0521052143	CLUTCH INDUCTIVE SENSOR ASSEMBLY	135	01




Item	Code	Description	See page	QT
01	0581018571	REAR HEADLIGHT SUPPORT		01
02	0503018738	LIGHTHOUSE		01
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010358	5/16" X 5/8" BOLT		02
05	0503013759	NUT		02
06	0503010025	3/8" SPRING WASHER		02
07	0503010026	3/8" NUT		02
08	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0591013259	LED FLASHLIGHT SUPPORT		01
02	0503019579	LED LANTERN		01
03	0503013357	3/8" SELF-ADJUSTING NUT		02
04	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0581014432	ELECTRIC BOX SUPPORT		01
02	0503010019	1/2" SPRING WASHER		02
03	0503010060	1/2" NUT		02
04	0503014007	1/2" X 1-1/4" BOLT		02




Item	Code	Description	See page	QT
01	0581016487	SENSOR SUPPORT		01
02	0501010063	1/2" X 1-1/2" BOLT		02
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0503019085	INDUCTIVE SENSOR		01
06	0571015148	PLATE SENSIBLES		01
07	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02




Item	Code	Description	See page	QT
001	0503063248	INTEL KIT WITH MONITORING		01
001A	0503015065	MASTER CONTROL MODULE		01
001B	0503015066	CABLE CONTROL MASTER MODULE		01
001C	0503015209	MODULES WSMB 18L ISOBUS 4679811100S1		01
001D	0503015210	CABLE MODULO WSMB ISOBUS 467981200		01
001E	0503016320	ISO CONEX TRACTOR 13M CABLE		01
001F	0503015071	CONCTOR		01
001G	0503062525	CABLE COMPLETO		01
001H	0503017443	ANTENNA GPS PM 400		01
001I	0503017031	CLEANING BRUSH		01
001J	0503015218	SENSOR FOTOELE PM 400		24
002	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	137	03
003	0511056972	FILTER HYDAC	138	01
004	0503019291	SUPPORT SENSOR		01
005	0503013100	NYLON CLAMP		120
006	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		360



Item	Code	Description	See page	QT
01	0503018768	MOTOR OMP 80		01
02	0503018769	MOTOR SPEED SENSOR		01
03	0503010045	O'RING		02
04	0503019320	VALVE		01
05	0501010590	NIPPLE		02




Item	Code	Description	See page	QT
01	0503016376	FILTER SPRING		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8"NF UNF NIPPLE		02
04	0503012341	T 7/8" ADAPOR GIRAT NUT		01
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02



Item	Code	Description	See page	QT
01	0521064543	WHEEL SUPPORT		01
02	0561019929	FLAT WASHER		01
03	0503010523	1/4" X 2" COTTERPIN		03
04	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
05	0551014508	FLAT WASHER		01
06	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
07	0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	25	01
08	0503010920	1/2" X 1.1/2" BOLT		04
09	0503010019	1/2" SPRING WASHER		04
10	0503010060	1/2" NUT		04
11	0502012731	WHEEL HOLDER		02
12	0503010002	1800 GREASE FITTING		04
13	0521064550	CARRYING-WHEELS FORK		01
14	0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	26	01
15	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
16	0511054491	WHEEL WITHOUT TIRE WITH 27Z GEAR	27	01
17	0511068422	WHEEL GEAR DOBLE		01
18	0551018571	FLAT WASHER		02
19	0511054463	WHEEL TENSIONER SUPORT CENTRAL	29	01
20	0511054464	WHEEL FORK TENSIONER	30	02
21	0561019941	RIGHT PROTECTIVE CAP WHEELS		01
22	0503010849	3/8" X 1-1/2" BOLT		02
23	0501013518	FLAT WASHER		02
24	0503010025	3/8" SPRING WASHER		02
25	0503010209	3/8" UNC BUTTERFLY NUT		02
26	0503016419	50-1 CHAIN X 128 LINK + REDUCION		01
27	0501010630	1.1/2" CASTLE NUT		01
28	0501017779	32 X 60 X 4.75 FLAT WASHER		02
29	0503011052	1.1/4" X 0.77" CASTLE NUT		02
30	0503014857	50-1 X CHAIN X 122 LINK + REDUCION		01
31	0511054501	TRANSMISSION CAMBIO LEFT	140	01

Item	Code	Description	See page	QT
32	0503033335	CURRENT 6 X 21 ELOS		01
32.	0503014857	50-1 X CHAIN X 122 LINK + REDUCION		01
33	0503010882	BOLT		01
34	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
35	0503010337	5/16" NUT		01
36	0581017245	AXLE BODY		01
37	0531012874	FLAT WASHER		02
38	0503012334	3/4" UNC X 3.1/2" BOLT		04
39	0503011075	3/4" UNC NUT		04
40	0503010571	1/4" X 1.1/2 COTTERPIN		02




Item	Code	Description	See page	QT
01	0521064556	SUPPORT ASSY TRANSMISSION WHEEL SIDE		01
02	0503010025	3/8" SPRING WASHER		13
03	0503010026	3/8" NUT		11
04	0503010019	1/2" SPRING WASHER		03
05	0503010060	1/2" NUT		03
06	0503010741	1/2" X 2-3/4" BOLT		03
07	0503062231	CLUTCH		01
08	0571015139	FIXER PLATE		01
09	0571015138	CHOCK FRICÇÃO		01
10	0511054461	STRETCHER TOP TRANSMISSION SWIRLED	32	02
11	0503011268	3/8" X 2-1/2" BOLT		01
12	0503013542	M10 SPRING WASHER		04
13	0503010188	M10 X 1,5 X 30 BOLT		01
14	0511069511	27Z GEAR		02
15	0571015152	FIXER TRANSMISSION SIDE LEFT		04
16	0571015154	PROTECTION TRANSMISSION LEFT		04




Item	Code	Description	See page	QT
001	0521056998	ALUMINUM IDENTIFICATION LABEL WITH RIVET		01
001A	0503034003	SERIAL NUMBER TAG 61 X 118		01
001B	0503010001	3.2 X 5.5 RIVET		04
002	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 MOUTH)		04
003	0503034563	ADHESIVE LABEL		02
004	0503034114	ADHESIVE LABEL LOGO TATU BOX 190 X 530		02
005	0503034566	ADHESIVE LABEL		02
006	0503034782	LABEL ADHESIVE LOGO SMALLER TATU (03 MOUTHS)		02
007	0503035155	ADHESIVE LABEL		02
008	0503033853	ADHESIVE LABEL		02
009	0503031425	ADHESIVE LABEL ATTENTION		02
010	0503034679	ADHESIVE LABEL		01
011	0503033597	ADHESIVE		02
012	0503031087	ADHESIVE LABEL		01
013	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM		02
014	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM		02
015	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER		04
016	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER		01
017	0503032986	ADHESIVE LABEL		01
018	0503034471	ADHESIVE LABEL		01
019	0503034651	ADHESIVE LABEL		02
020	0503034683	ADHESIVE LABEL		02
021	0503034534	ADHESIVE LABEL		01
022	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		01
023	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02




Item	Code	Description	See page	QT
01	0521056998	ALUMINUM IDENTIFICATION LABEL WITH RIVET		01
01A	0503034003	SERIAL NUMBER TAG 61 X 118		01
01B	0503010001	3.2 X 5.5 RIVET		04
02	0503034782	LABEL ADHESIVE LOGO SMALLER TATU (03 MOUTHS)		04
03	0503035155	ADHESIVE LABEL		04
04	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 MOUTH)		08
05	0503034563	ADHESIVE LABEL		04
06	0503034114	ADHESIVE LABEL LOGO TATU BOX 190 X 530		04
07	0503034566	ADHESIVE LABEL		04
08	0503033853	ADHESIVE LABEL		02
09	0503031425	ADHESIVE LABEL ATTENTION		02
10	0503034679	ADHESIVE LABEL		01
11	0503033597	ADHESIVE		02
12	0503031087	ADHESIVE LABEL		01
13	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM		02
14	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM		02
15	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER		04
16	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER		01
17	0503034471	ADHESIVE LABEL		01
18	0503034651	ADHESIVE LABEL		02
19	0503034683	ADHESIVE LABEL		02
20	0503034534	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0521058330	SENSOR SUPPORT	144	01
02	0521058331	DRIVE HYDRAULIC ASSEMBLY	145	01




Item	Code	Description	See page	QT
01	0591014387	SENSOR SUPPORT		01
02	0501010942	3/8" X 1-1/4" BOLT		03
03	0503010026	3/8" NUT		03
04	0503010025	3/8" SPRING WASHER		03
05	0503013356	RIVET POP 3,2 X 10,0		01




Item	Code	Description	See page	QT
01	0591014389	LIFTING SENSOR DRIVING BODY		01
02	0521058332	FIXER BODY CONTROL		01
02A	0591014388	LIFT ACTUATOR FIXER		01
02B	0503019412	RIVET SCREW INTERNAL		02
03	0503010143	1/4" SPRING WASHER		02
04	0503010420	BOLT		02



Item	Code	Description	See page	QT
01	0503019327	CONTROL PANEL		01
02	0503019054	WHIP		01
03	0503019059	WHIP		01
04	0503019052	WHIP		01
05	0503019328	WHIP		01
06	0503019057	WHIP		01




Item	Code	Description	See page	QT
01	0551011625	PROTECTION COVER		01
02	0503010386	CABLE		01
03	0551015037	5/8" UNC X 210 X 198 FASTENER		02
04	0551018630	CARDAN SHAFT GUIDES SLEEVE		01
05	0551018629	GEAR BOX COVER FIXER ROD		01
06	0503010257	1/8" X 1" COTTERPIN		02
07	0503010179	5/16" ZN SPRING WASHER		01
08	0503010337	5/16" NUT		01
09	0501013518	FLAT WASHER		02
10	0521056867	SEMI-ASSEMBLED LEFT EXCHANGE	148	01
11	0503012412	5/8 UNC SELF LOCKING NUT		04
12	0501012140	FLAT WASHER		04
13	0503011268	3/8" X 2-1/2" BOLT		01
14	0503013357	3/8" SELF-ADJUSTING NUT		01
15	0503034417	LETTER ADHESIVE LABEL		01
16	0503032986	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0531060362	LEFT SIDE EXCHANGE FERTILIZER SUPPORT		01
02	0501056444	BEARING WITH ROLLING	37	02
03	0502011758	REAR TENSIONER LEVER		01
04	0551018627	SIDE GEAR BOX DRIVER AXLE		01
05	0503030303	SUPPORT WASHER		05
06	0501056271	BEARING CLOSED	38	02
07	0503010292	0.2" X 1.6" SPRING PIN		05
08	0503010002	1800 GREASE FITTING		01
09	0503010395	1/2" X 1-1/4" BOLT		02
10	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		02
11	0503012389	1/2 BALL		02
12	0503010060	1/2" NUT		02
13	0503011953	5/16" X 1" BOLT		08
14	0501010694	8.5 X 18 X 1.5 FLAT WASHER		08
15	0503010179	5/16" ZN SPRING WASHER		08
16	0503010337	5/16" NUT		08
17	0501052778	CHAIN TENSIONER ASSY	90	01
18	0501048790	AXLE WITH LINK ASSY	40	01
19	0503012204	40-1 CHAIN X 82 LINK + RED		01
20	0511060396	DRIVE/DRIVEN AXLE CONE		02
21	0591011683	MOVED AXIS		01
22	0511067501	26Z GEAR		01
23	0501010984	FLAT WASHER		01
24	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		01
25	0503010025	3/8" SPRING WASHER		01
26	0503019312	40-1 X 51 CHAIN LINK + MENDING		01

DRIVE SHAFT


0501047300




Item	Code	Description	See page	QT
01	0501051721	UNIVERSAL JOINT		01
02	0501051717	UNIVERSAL JOINT		01
03	0503012087	PROTECTION FOR UNIV JOINT AND SLEEVE		01
04	0501051722	PROTECTION FOR UNIV JOINT AND AXLE		01
05	0501051719	UNIVERSAL JOINT		01
06	0503012088	PROTECTION FOR UNIV JOINT AND AXLE		01
07	0501051718	UNIVERSAL JOINT		01
08	0511012101	0.9" X 15.75" SQUARE SLEEVE		01
09	0503010839	03"X 0.6" SPRING PIN		01
10	0501051720	UNIVERSAL JOINT		01
11	0511012100	0.9" X 15.75" SQUARE SHAFT		01
12	0503010301	0.3" X 1.8" SPRING PIN		01
13	0502010558	4-20 TERMINAL WITH ROLES		01
14	0503010835	CARDAN CROSSPIECE		01
15	0502011426	2-20 TERMINAL		01
16	0502011427	3-20 TERMINAL		01




Item	Code	Description	See page	QT
01	0571016995	FIXER SUPPORT		01
02	0511017302	FLAT WASHER		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0571018437	PRISONER 1/2 X		02
06	0571014216	FRONT HOSE SUPPORT FIXER		01




Item	Code	Description	See page	QT
001	0531061469	SUPPORT SILO SIDE LEFT FERTILIZER		01
002	0503062961	FERTILIZER BEAM ASSY		01
003	0521050525	FIXER FERTILIZER CONDUCTOR	63	07
004	0521051407	FIXER SILO FERTILIZER	62	10
005	0521055365	SEED CONDUCTOR	64	07
006	0503062964	SILO SEED 03 MOUTH		01




Item	Code	Description	See page	QT
001	0503062927	SILO FERTILIZER 3 MOUTHS		01
002	0503062362	SILO FERTILIZER 04 MOUTH	44	01
003	0521059567	SUPPORT SILO SIDE LEFT COMPLETE FERTILIZER		01
004	0521051407	FIXER SILO FERTILIZER	62	10




Item	Code	Description	See page	QT
01	0531060948	SEED LINE FRAME		01
02	0571012310	ROW LOCK BODY		01
03	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
04	0503010232	5/8" X 1.3/4" BOLT		01
05	0503030168	HAIR PIN		04
06	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
07	0503033728	FIXED SPRING PIN		02
08	0571014704	UPPER AXLE		01
09	0502012768	LINE SUPPORT CLAMP		02
10	0581018676	SLEEVE ARM LINE SEED		08
11	0503010811	5/8" UNF SELF ADJUSTING NUT		04
12	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
13	0581019795	SEED ARM SUPPORT ROW		01
14	0581019796	LOWER ARM LARGER		01
15	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
16	0521068452	UP SUPPORT		01
17	0503010878	5/8" SELF ALIGNING NUT		04
18	0503019273	SLEEVE		06
19	0503010045	O'RING		08
20	0502012568	UPPER ROCKER ARM		01
21	0591014726	ENCAPSULATED CURRENT GUIDE		01
22	0503013357	3/8" SELF-ADJUSTING NUT		01
23	0503010237	3/8" X 1" BOLT		01
24	0503013389	5/8" SELF LOCKING NUT		01
25	0501012140	FLAT WASHER		01
26	0521059045	BEARING WITH CURRENT ENCAPSULATED	156	01
27	0503063190	ENCAPSULATED CURRENT MAHM LONG 1060		01
28	0503018829	NYLON CLAMP		01
29	0503010179	5/16" ZN SPRING WASHER		02
30	0503019284	M8 X BOLT		02




Item	Code	Description	See page	QT
01	0531060948	SEED LINE FRAME		01
02	0571012310	ROW LOCK BODY		01
03	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
04	0503010232	5/8" X 1.3/4" BOLT		01
05	0503030168	HAIR PIN		04
06	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
07	0503033728	FIXED SPRING PIN		02
08	0571014704	UPPER AXLE		01
09	0502012768	LINE SUPPORT CLAMP		02
10	0503010811	5/8" UNF SELF ADJUSTING NUT		04
11	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
12	0581019793	LOWER UPPER ARM WITHOUT LUBRICATION		01
13	0581019794	LOWER LOWER ARM WITHOUT LUBRICATION		01
14	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
15	0521068448	FRONT SUPPORT SHORT SEED LINE		01
16	0503010878	5/8" SELF ALIGNING NUT		04
17	0503019273	SLEEVE		08
18	0581018676	SLEEVE ARM LINE SEED		08
19	0503010045	O'RING		08
20	0502012568	UPPER ROCKER ARM		01
21	0503013389	5/8" SELF LOCKING NUT		01
22	0501012140	FLAT WASHER		01
23	0591014726	ENCAPSULATED CURRENT GUIDE		01
24	0503013357	3/8" SELF-ADJUSTING NUT		01
25	0503010237	3/8" X 1" BOLT		01
26	0521059045	BEARING WITH CURRENT ENCAPSULATED	156	01
27	0503063191	ENCAPSULATED CURRENT MAHM SHORT 895		01
28	0503018829	NYLON CLAMP		01
29	0503010179	5/16" ZN SPRING WASHER		02
30	0503019284	M8 X BOLT		02




Item	Code	Description	See page	QT
01	0581018676	SLEEVE ARM LINE SEED		08
02	0503010811	5/8" UNF SELF ADJUSTING NUT		02
03	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		02
04	0503030168	HAIR PIN		03
05	0503033728	FIXED SPRING PIN		02
06	0571014704	UPPER AXLE		01
07	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
08	0502012768	LINE SUPPORT CLAMP		02
09	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
10	0581019795	SEED ARM SUPPORT ROW		01
11	0581019796	LOWER ARM LARGER		01
12	0503010878	5/8" SELF ALIGNING NUT		04
13	0503019273	SLEEVE		08
14	0503010045	O'RING		08
15	0502012568	UPPER ROCKER ARM		01
16	0521069981	FRONT SUPPORT LONG SUPER SEED LINE		01
17	0503018829	NYLON CLAMP		03
18	0521059045	BEARING WITH CURRENT ENCAPSULATED	156	01
19	0503063189	SUPER LONG MAHM ENCAPSULATED CHAIN		01
20	0503010179	5/16" ZN SPRING WASHER		02
21	0503011295	M 8 X 1,25 X 25 BOLT		02




Item	Code	Description	See page	QT
01	0531061301	ENCAPSULATED CURRENT BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0511017303	FLAT WASHER		04
04	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
05	0503012880	1/4" UNC SELF ADJUSTING NUT		02
06	0503013759	NUT		02
07	0503019373	6006 2RS1 NATIONAL BEARING		01
08	0503012858	502075 CLAMPING RING (FOR HOLE)		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01
10	0581019823	BEARING AXLE BODY WITHOUT LUBRICATION		01




Item	Code	Description	See page	QT
01	0531060948	SEED LINE FRAME		01
02	0503010811	5/8" UNF SELF ADJUSTING NUT		02
03	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		02
04	0571012310	ROW LOCK BODY		01
05	0551015826	SEED ROW LOCK GUIDE SLEEV		01
06	0503010232	5/8" X 1.3/4" BOLT		01
07	0503030168	HAIR PIN		01
08	0501012140	FLAT WASHER		01
09	0503013389	5/8" SELF LOCKING NUT		01
10	0591014726	ENCAPSULATED CURRENT GUIDE		01
11	0503010237	3/8" X 1" BOLT		01
12	0503013357	3/8" SELF-ADJUSTING NUT		01



Item	Code	Description	See page	QT
01	0521050118	DEPOSIT SEED BOCAL		01
02	0581014295	FIXING GLOVE		01
03	0511052058	SEED SYSTEM TITANIUM	159	01
04	0503010358	5/16" X 5/8" BOLT		05
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		05
06	0503010179	5/16" ZN SPRING WASHER		05
07	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0503062031	BASE SET		01
02	0503062032	NECK TITANIUM ASSY		01
03	0503062033	OPPOSITE BASE SET		01
04	0503062034	CENTRAL ADAPTER SET		01
05	0503062035	SET FALSE ADAPT CENTER		01
06	0503062036	SUBSET ASSY LOCK BASE		01
07	0503062037	SUBSET ESCOVAFLEX ASSY		01
08	0503062038	ASSY ANTI-LEAP		01
09	0503062039	POLIFLOW TITANIUM ASSY		01
09.	0503016279	POLIFLOW TITANIUM ASSY		01
10	0503062040	DISPLAY ASSY TITANIUM 1050010		01
11	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
12	0503062042	SET BOLT ARTICULADOR		01
13	0503062043	ASSY LIMIT WEIGHT		01
14	0503062044	ASSY MOUNT BOX FOR SEED		01
14A	0503016285	BOLT		05
14B	0503016286	HEX NUT		05
14C	0503016287	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012470	UPPER SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
03	0503012798	5/8" X 2" BOLT		04
04	0503010878	5/8" SELF ALIGNING NUT		04
05	0521055344	LOWER SUPPORT	161	01

LOWER SUPPORT


0521055344




Item	Code	Description	See page	QT
01	0503019277	SLEEVE LUBRICATION SYSTEM	03	
02	0503019278	LUBRICANT GLOVE	02	
03	0581018679	SLEEVE	01	
04	0581018677	SUPPORT DISC AXLE	01	
05	0503010361	SPRING PIN	01	
06	0551015883	SPRING GUIDES SLEVE	02	
07	0503031575	2.5"X 12" X 0.5" COMPRESSION SPRING	02	
08	0521068189	SPRING REGULACION	02	
09	0501012140	FLAT WASHER	02	
10	0503010152	3/4" SELF LOCKING NUT	01	
11	0503010806	5/8" X 3" BOLT	02	
12	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT	01	
13	0503011075	3/4" UNC NUT	02	
14	0503010878	5/8" SELF ALIGNING NUT	02	
15	0521054844	DPLO 20 CUTTING DISK BOX	01	
16	0521069351	RIGHT ARM	01	
17	0521069350	LEFT ARM	01	
18	0503010410	RING	02	
19	0502012898	BOTTOM BRACKET	01	
20	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN	02	
21	0503010179	5/16" ZN SPRING WASHER	02	
22	0571012370	PROTECTION FRONT	01	
23	0581018678	FLANGE WASHER	01	




Item	Code	Description	See page	QT
01	0521058085	REAR WITH DDD LEFT SPICRR	163	01
02	0531050193	DOSING ASSY TITANIUM/TATU	164	01
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04




Item	Code	Description	See page	QT
01	0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	165	01
02	0502012923	BEATER		01
03	0521056632	DEPTH CONTROL	168	01
04	0591011323	AXLE ARTICULATION WHEEL DEPTH		02
05	0502012920	SUPPORT ADJUSTING		01
06	0502012611	DEPTH CONTROL AXLE		01
07	0591011309	ADJUSTMENT BUSHING		02
08	0591011310	ADJUSTMENT BAR		02
09	0503019275	SLEEVE LUBRICATION SYSTEM		01
10	0581019473	ARTICULATED GLOVE		02
11	0503010045	O'RING		02
12	0503013357	3/8" SELF-ADJUSTING NUT		02
13	0501010984	FLAT WASHER		04
14	0591011326	LOCK PIN		01
15	0571015326	ARTICULATION SLEEVE HANDLE		01
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2" NUT		02
18	0503010019	1/2" SPRING WASHER		04
19	0591011324	SMALLER AXLE		01
20	0591011325	LARGER AXLE		01
21	0511017302	FLAT WASHER		02
22	0503030012	HAIR PIN		02
23	0501011445	FLAT WASHER		04
24	0521056633	MOUNTED RIGHT ARM	169	01
25	0521056631	MOUNTED LEFT ARM	171	01
26	0503012556	1/2" X 1" BOLT		02
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
28	0591011306	ADJUSTMENT LOCK		02
29	0521055093	BODY COMPACTOR	172	01
30	0521054990	LEFT COMPACTOR WHEEL	173	01
31	0521055017	RIGHT COMPACTOR WHEEL	175	01




Item	Code	Description	See page	QT
01	0521056639	SEED ROW TRANSMISSION	176	01
02	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
03	0502012921	BASE FIXING SYSTEM		01
04	0591014600	ENCAPSULATED CURRENT FIXER		01
05	0503014876	NUT PARLOCK 1/4"		02
06	0503010461	1/4" X 1" BOLT		02
07	0511052024	FAST CLOSING SET	177	01




Item	Code	Description	See page	QT
01	0502012928	LEFT EXTENSOR		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0501010984	FLAT WASHER		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 166 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 167 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED		01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED		01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0502012925	ADJUSTMENT BODY		01
02	0511015976	FLAT WASHER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0503010581	RING		01
05	0502012892	DEPTH CONTROL HANDLE		01
06	0581019526	ARTICULATED AXLE LEVER DEPTH		01
07	0503010302	501019 SEAL RING		01




Item	Code	Description	See page	QT
01	0502012926	RIGHT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT GLOVE		02
04	0521055059	WHEEL RAYED ASSY SPA WITHOUT 170 LUBRICATION		01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503030891	RUBBER BAND		01
03	0503010365	NUT		06
04	0503010179	5/16" ZN SPRING WASHER		06
05	0503010337	5/16" NUT		06
06	0521055073	ASSEMBLY DEPTH WHEEL BOX		01




Item	Code	Description	See page	QT
01	0502012927	LEFT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT GLOVE		02
04	0521055059	WHEEL RAYED ASSY SPA WITHOUT 170 LUBRICATION		01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0501011753	5/16" X 1-3/4" BOLT	02	
02	0503013816	5/16" LOCKNUT	04	
03	0581015855	SLEEVE	02	
04	0502012877	PRESS WHEEL ADJUSTMENT LEVER	01	
05	0521068661	LEVER	01	
06	0503030878	LEVER CRANK	01	
07	0503031393	1.57" X 5.98" X 0.2"TRACTION SPRING	01	
08	0581019520	AXIS	01	
09	0571812442	COUPLING SHAFT	01	
10	0503010257	1/8" X 1" COTTERPIN	01	
11	0581019511	COVER	01	
12	0503010848	5/16" X 3.1/2" BOLT	02	
13	0503010752	1/2" X 3.1/2" BOLT	01	
14	0503011336	1/2" HEX SELF ADJUSTING NUT	01	
15	0503030190	0.5" X 1.6" X 0.05" SPRING	01	
16	0581019510	AXIS	01	
17	0581019512	PLATE TOP	01	
18	0503019351	LUBRICANT GLOVE	02	
19	0521069591	LEFT SIDE	01	
20	0581019548	RIGHT SIDE BODY	01	




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	174	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	174	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012932	MINOR SIDE		01
02	0503017046	BEARING		02
03	0503011410	ROLLER BEARING		02
04	0591011321	AXLE GEAR		01
05	0591011322	SPACER		01
06	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0503010025	3/8" SPRING WASHER		01
09	0503010179	5/16" ZN SPRING WASHER		04
10	0503011945	503050 CLAMPING RING (FOR AXLE)		01
11	0503010420	BOLT		02
12	0503011053	5/16" X 3" C S 6.5 ZN BOLT		04
13	0502012919	GRAGGER		01
14	0502012933	LARGER SIDE		01
15	0502012930	CONICAL GEAR		01
16	0502012931	CONICAL GEAR		01
17	0503010585	0,24" X 1.18" SPRING PIN		01




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0521058084	REAR WITH RIGHT DDD SPICRR	179	01
02	0531050193	DOSING ASSY TITANIUM/TATU	164	01
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04




Item	Code	Description	See page	QT
01	0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	180	01
02	0502012923	BEATER		01
03	0521056632	DEPTH CONTROL	168	01
04	0591011323	AXLE ARTICULATION WHEEL DEPTH		02
05	0502012920	SUPPORT ADJUSTING		01
06	0502012611	DEPTH CONTROL AXLE		01
07	0591011309	ADJUSTMENT BUSHING		02
08	0591011310	ADJUSTMENT BAR		02
09	0503019275	SLEEVE LUBRICATION SYSTEM		01
10	0581019473	ARTICULATED GLOVE		02
11	0503010045	O'RING		02
12	0503013357	3/8" SELF-ADJUSTING NUT		02
13	0501010984	FLAT WASHER		04
14	0591011326	LOCK PIN		01
15	0571015326	ARTICULATION SLEEVE HANDLE		01
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2" NUT		02
18	0503010019	1/2" SPRING WASHER		04
19	0591011324	SMALLER AXLE		01
20	0591011325	LARGER AXLE		01
21	0511017302	FLAT WASHER		02
22	0503030012	HAIR PIN		02
23	0501011445	FLAT WASHER		04
24	0521056633	MOUNTED RIGHT ARM	169	01
25	0521056631	MOUNTED LEFT ARM	171	01
26	0503012556	1/2" X 1" BOLT		02
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
28	0591011306	ADJUSTMENT LOCK		02
29	0521055093	BODY COMPACTOR	172	01
30	0521054990	LEFT COMPACTOR WHEEL	173	01
31	0521055017	RIGHT COMPACTOR WHEEL	175	01




Item	Code	Description	See page	QT
01	0502012929	BODY RIGHT		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0501010984	FLAT WASHER		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 166 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 167 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521069328	RIGHT FERTILIZER CONDUCTOR		01
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0591011713	SHORT SUPPORT BODY CONDUCTOR FERTILIZER		01
02	0531060359	FERTILIZER CONDUCTOR		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
04	0511017302	FLAT WASHER		02
05	0503011336	1/2" HEX SELF ADJUSTING NUT		02
06	0503010589	1/2" UNC SELF ADJUSTING NUT		02
07	0503014007	1/2" X 1-1/4" BOLT		02



Item	Code	Description	See page	QT
01	0591011676	BODY LONG CONDUCTOR FERTILIZER		01
02	0531060359	FERTILIZER CONDUCTOR		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
04	0511017302	FLAT WASHER		02
05	0503011336	1/2" HEX SELF ADJUSTING NUT		02
06	0503010589	1/2" UNC SELF ADJUSTING NUT		02
07	0503014007	1/2" X 1-1/4" BOLT		02




Item	Code	Description	See page	QT
01	0503016204	CORN DISK 12 ORANGE		01
02	0503016398	TITANIUM RING CORN / SOY (YELLOW FLAT)		01
03	0503016399	TITANIUM RING CORN (GREEN)		01
04	0503016400	TITANIUM RING CORN (GREY)		01
05	0503016401	TITANIUM RING CORN (BLUE)		01



Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016218	DISC OF SOYBEAN		01
03	0503016403	TITANIUM RING FOR SOYBEAN (LILAC)		01
04	0503016404	TITANIUM RING FOR SOYBEAN (PURPLE)		01
05	0503016406	TITANIUM RING FOR SOYBEAN (ORANGE)		01
06	0503016407	TITANIUM RING FOR SOYBEAN		01

CUTTING DISC


0521055341




Item	Code	Description	See page	QT
01	0502012470	UPPER SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
03	0503012798	5/8" X 2" BOLT		04
04	0503010878	5/8" SELF ALIGNING NUT		04
05	0521055340	CUT BOTTOM SUPPORT	187	01

CUT BOTTOM SUPPORT

0521055340




Item	Code	Description	See page	QT
01	0503019277	SLEEVE LUBRICATION SYSTEM	03	
02	0503019278	LUBRICANT GLOVE	02	
03	0581018679	SLEEVE	01	
04	0581018677	SUPPORT DISC AXLE	01	
05	0503010361	SPRING PIN	01	
06	0551015883	SPRING GUIDES SLEVE	02	
07	0503031575	2.5"X 12" X 0.5" COMPRESSION SPRING	02	
08	0521068189	SPRING REGULACION	02	
09	0501012140	FLAT WASHER	02	
10	0503010152	3/4" SELF LOCKING NUT	01	
11	0503010806	5/8" X 3" BOLT	02	
12	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT	01	
13	0503011075	3/4" UNC NUT	02	
14	0503010878	5/8" SELF ALIGNING NUT	02	
15	0521055373	BOX WITH CUTTING DISC DPLE 20 TB 60E 188 WITHOUT LUBRICATION	01	
16	0521069351	RIGHT ARM	01	
17	0521069350	LEFT ARM	01	
18	0503010410	RING	02	
19	0502012898	BOTTOM BRACKET	01	
20	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN	02	
21	0503010179	5/16" ZN SPRING WASHER	02	
22	0571012370	PROTECTION FRONT	01	
23	0581018678	FLANGE WASHER	01	




Item	Code	Description	See page	QT
01	0521053697	CUTTING DISK BOX	189	01
02	0605027058	20" X 0.1771" PLAIN COULTER BLADE		01

CUTTING DISK BOX


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	CUTTING DISK BOX		01
09	0502040873	CUTTING DISC AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02




Item	Code	Description	See page	QT
01	0521055065	ASSY DEPTH / COMPACTOR	191	01
02	0521055068	RAYED WHEEL CENTER CLOSED	195	02
03	0521054990	LEFT COMPACTOR WHEEL	173	01
04	0521055017	RIGHT COMPACTOR WHEEL	175	01
05	0503016453	1/2" X 2.1/2 BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010028	1/2" NUT		02




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0571013054	DEPTH CONTROL WHEEL AXLE		01
04	0502012663	EXTENSION		01
05	0501056769	DEPTH WHEELS REGULATOR ASSY		01
06	0503019398	AXLE RETAINER RING		01
07	0521055033	COMPACTADOR BODY	192	01
08	0521055054	LEFT ARM WITH SLEEVE	193	01
09	0521055066	RIGHT ARM WITH GLOVE	194	01
10	0511015346	FLAT WASHER		04
11	0571015974	WASHER		02
12	0511017302	FLAT WASHER		02
13	0503010256	3/8" X 3/4" BOLT		01
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		04
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2" NUT		02
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0581019473	ARTICULATED GLOVE		02
20	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT GLOVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0581019523	LEFT ARM WHEEL DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019524	RIGHT ARM DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02



Item	Code	Description	See page	QT
01	0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION		01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	5/16" ZN SPRING WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
001	0521069359	BIGGEST ANTEBRACO FERTILIZER		01
002	0521067624	LOWER SUPPORT LINE		01
003	0521066719	EXTENDER		01
004	0521067626	BRACO MARKER		01
005	0521069710	FERTILIZER LEVER		01
006	0511058553	HYDRAULIC CYLINDER	197	01
007	0511017592	11.8" X 1.6" TRANSPORT LOCK		01
008	0551016251	PIVOT SHAFT		01
009	0501014063	25 X 55 COUPLING SHAFT		02
010	0581013816	ARM BEFORE ARTICULICION		01
011	0501019435	32 X 50 X 1.5 FLAT WASHER		04
012	0581013815	PIVOT SHAFT		01
013	0581013817	PIVOT SHAFT		01
014	0503011052	1.1/4" X 0.77" CASTLE NUT		02
015	0503010523	1/4" X 2" COTTERPIN		06
016	0503010010	1/4" X 2.1/2" COTTERPIN		02
017	0503010002	1800 GREASE FITTING		03
018	0521066871	BLOCK TURNBUCKLE		01
019	0503010013	5/8" NUT		06
020	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		02
021	0503010027	5/8" SPRING WASHER		04
022	0503010233	5/8" X 2-1/2" BOLT		04
023	0501068994	0.3" X 3.1" LOCK PIN		01
024	0503030168	HAIR PIN		01
025	0511042494	ROW MARKER DISC ASSY	198	01




Item	Code	Description	See page	QT
01	0503018005	RING		01
02	0551016274	HYDRAULIC CYLINDER ADAPTER		02
03	0581010669	EMBOLUS 63.50 X 40 USAP		01
04	0503010558	7/8" NUT		01
05	0503010605	O'RING		01
06	0503010163	D-1500 SCRAPER RING		01
07	0502010471	MOBILE COVER		01
08	0581010668	RING SUPPORT		01
09	0503018004	RING		01
10	0503018003	GASKET		01
11	0503018163	BACK-UP RING		02
12	0503018162	O'RING		02
13	0503030385	CYLINDER PLUG N-002		02
14	0521066717	2.9" X CYLINDER CASE		01
15	0521066718	38,10 X TURNBUCKLE		01
16	0511033698	ASSY REPLACEMENT GAME 38.10 X 63.50		

ROW MARKER DISC ASSY

0511042494



Item	Code	Description	See page	QT
01	0502011907	DEPTH CONTROL WHEEL HUB		01
02	0503010269	6204 BALL BEARING		02
03	0503010689	SEAL 00763-BR		01
04	0503011105	SEAL RING		01
05	0501013636	SPACING SLEEVE		01
06	0602023110	DR16X3 NOTCHED DISC BLADE		01
07	0503010358	5/16" X 5/8" BOLT		04
08	0503010179	5/16" ZN SPRING WASHER		04
09	0503010337	5/16" NUT		04
10	0511065478	ROW MARKER DISC AXLE		01
11	0503010878	5/8" SELF ALIGNING NUT		01
12	0521019178	COVER DEPTH		01
13	0503030757	2.9" X 2" X 0.02" JOINT		01
14	0503814729	BOLT		03
15	0503011441	SPRING WASHER		03
16	0503010691	1/4" GREASE FITTING		01
17	0501069226	ROW MARKER ROD STOP		01
18	0501011778	3/8" X 2-1/2" BOLT		04
19	0503010025	3/8" SPRING WASHER		04
20	0503010026	3/8" NUT		04
21	0503010023	3/4" SPRING WASHER		01
22	0503010014	3/4" NUT		01



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

